


ACOM 03AT

AUTOMATIC ANTENNA TUNNING UNIT



OPERATING MANUAL

ACOM 03AT
AUTOMATIC HF ANTENNA TUNING UNIT
OPERATING MANUAL

Table of contents

1. GENERAL INFORMATION	2
1.1. INTRODUCTION AND DESCRIPTION	2
1-2. OWNER ASSISTANCE	2
1-3. EQUIPMENT SUPPLIED AND OPTIONS.....	2
1-4. FEATURES.....	2
1-5. SAFETY CONSIDERATIONS, EXPLICIT DEFINITIONS	3
PRECAUTIONS:	3
2. INSTALLATION	4
2-1. UNPACKING AND INITIAL INSPECTION.....	4
2-2. LINE VOLTAGE	4
2-3. REMOTE UNIT INSTALLATION	4
3. POWER ON, RCU CONTROLS AND MENU	11
4. OPERATION	12
4-1. FUNCTION OPERATE AND AUTO TUNE PROCEDURE.....	12
4-2. USING THE MEMORY	14
4-3. FUNCTION BYPASS.....	15
4-4. FUNCTION STATUS	16
4-5. FUNCTION SWR-CHK.....	17
4-6. USING STATUS AND SWR-CHK FUNCTIONS FOR RF PATH DIAGNOSTICS	17
5. MAINTENANCE	18
5-1. CLEANING.....	18
5-2. FUSES REPLACEMENT	18
5-3. ACOM 03AT MATCHING CIRCUIT SCHEMATIC DIAGRAM	20
5-4. TROUBLESHOOTING.....	23
6. SPECIFICATIONS	24
6-1. PARAMETERS	24
6-2. FUNCTIONS.....	25
6-3. STORAGE AND SHIPMENT.....	26

1. GENERAL INFORMATION

1.1 Introduction and Description

This manual explains the installation, operation and maintenance of the ACOM 03AT Automatic HF Antenna Tuning Unit.

The Automatic HF Antenna Tuning Unit (AATU) model ACOM 03AT is a complete and self-contained unit for automatic matching of HF symmetrical-antenna impedance to an unbalanced 50Ω output, that covers a continuous 1.8 to 16MHz frequency range and will withstand 200 to 2500W input power depending on the antenna SWR used. Input power up to 1000W is permissible in the whole frequency range when antenna SWR is 10:1 or better. For SWR up to 50:1, matching is still possible but the frequency range and input power are restricted. AATU features a Remote Control Unit (RCU) and can be controlled via an optical link, up to 50m long.

All indicators and controls are available via the RCU. All command input to the RCU is menu-driven.

1-2. Owner Assistance

If assistance is needed, you should contact your local dealer first. If you still have an issue you need to discuss with one of ACOM's specialists. The contact information is as follows: phone (+359 2) 920 96 55, fax (+359 2) 920 96 56, e-mail acom@mail.orbitel.bg or by mail: Bul. Nikola Mushanov 151, 1330 Sofia, Bulgaria.

1-3. Equipment Supplied and Options

The ACOM 03AT AATU is shipped in a single cardboard carton. It contains three internal cartons:

- one internal carton, containing the remote AATU unit, the RCU, and installation accessories;
- a second internal carton containing the power supply cable, and
- a third internal carton with the optical control cable.

NOTE

A coaxial cable to the station is not included. It is normally a part of the antenna set.
Use type RG213 or equivalent.

Options:

- Unbalanced output with 50Ω UHF(SO239A) connector;
- Serial control port for the ACOM2000A HF Linear Amplifier and for ACOM2000S Automatic Antenna Selector;
- PC control via RS232 or RS422 serial port.

1-4. Features

- Easy to operate. The only operator's obligation is to apply CW power, while the matching process is fully automatic.
- Nonvolatile memory for 99 different user's tuning settings and selection of the power-on default.
- LCD comment display. All AATU status indications are explained via detailed text displayed on the dot-matrix, back-lighted liquid crystal display (LCD) on the RCU.
- Less interference and improved electromagnetic compatibility during tuning. Retuning can be achieved in 8s (2-3s typical) and at reduced RF power (10-100W).
- Guards your transmitter during the tuning process against excessive impedance mismatch via inserting a powerful attenuator at the input, and removing it after that.
- The RF power is disabled during each commutation in order to save the vacuum RF-relay contacts, as well as to keep the emitted spectrum as narrow as possible during the tuning process.
- Improves harmonic emission suppression of your transmitter since the matching circuit represents a low-pass Pi-filter.
- Saves space on the operating desk. Since the AATU is controlled by the RCU only, the remote unit can be located up to 50m from the operation position.

- Remote matching – less losses in the feed line. The design of the main (remote) unit is foreseen for outdoor-installation requirements. This permits you to locate it closely to the antenna feed-points, thus considerably reducing the mismatched RF path length.
- Operates automatically without special signals from the transceiver – 10 to 100W CW is the only requirement to perform automatic matching.
- Optical control link between RCU and remote AATU unit. This avoids erratic control in strong electromagnetic fields, which is a typical case in the near field of HF antennas emitting 1-2kW.
- Continuous monitoring of the antenna voltage, temperature and power supply in the remote unit, and indication on the RCU of any abnormal condition.
- Resource-estimate function (STATUS) giving the percentage of inductors and capacitors involved achieving a match. This offers a possibility for monitoring the condition of the RF path, thus to forewarn possible problems.
- Safe power supply voltage for the remote unit (24VAC provided by the RCU).
- Features BYPASS function, where the effect of the inductors and capacitors on the impedance is excluded for broadband operation (the balun transformer however still used) – you can use the antenna without a retune, provided the antenna is broadband.
- When AATU is powered off, the BYPASS function is performed by default, too – you can use your antenna without an AATU when the antenna features an acceptable SWR for any frequency segment.
- RF-path condition to the AATU can be checked using the functions “STATUS”, “BYPASS”, and “SWR-CHK” – you can timely know about possible problems.
- Protection against atmospheric electricity via sphere spark gaps and a bleeder choke.
- Options: Unbalanced output with 50Ω UHF (SO239A) connector; Control for the ACOM2000A HF Linear Amplifier and for ACOM2000S Automatic Antenna Selector; PC control via RS232 or RS422 serial port; Nonvolatile memory for user tunings.

1-5. Safety Considerations, Explicit Definitions

The ACOM 03AT Automatic HF Antenna Tuning Unit is a Safety Class I unit, i.e. the third grounding lead of its mains cord, and the grounding studs on both units (the RCU and the remote unit), marked GND (GROUND), must be connected to the station's grounding system for safe operation. The AATU is designed to meet international safety standards and complies with CE safety and electromagnetic compatibility requirements, as well as FCC regulations.

This operating manual contains information, precautions, indications for cautions and warnings which must be followed by the user to ensure safe operation and to keep the ACOM 03AT in safe operating condition.

PRECAUTIONS:

The EXPLICIT DEFINITIONS described below apply to this operating manual:

WARNING notes call attention to a procedure which, if not correctly performed, could result in personal injury, fire hazard or electric shock.

CAUTION notes call attention to a procedure which, if not correctly performed, could result in equipment damage, not only in the AATU.

NOTE notes call attention to a procedure which, if not correctly performed, could result in inconvenience only.

WARNING HIGH VOLTAGE!

The AATU works with mains voltage 220-240VAC 50-60Hz and high DC voltage up to 300VDC, which are **LETHAL!** Also, for your safety pull the AATU power plug out of the mains wall outlet and **WAIT AT LEAST 3 minutes EACH TIME BEFORE you remove any cover!**

WARNING HIGH VOLTAGE!

Never allow anyone, ESPECIALLY CHILDREN, to push anything into holes in the case – this will cause electric shock. NEVER TOUCH AN ANTENNA OR ANTENNA INSULATORS during transmission – this may result in an electric shock or burn. The RF voltage on the antenna insulators may exceed 5000V! NEVER EXPOSE the RCU to rain, snow or any liquids. AVOID placing the RCU in excessively dusty environments or in direct sunlight.

WARNING

Do not undertake on your own repairs or changes in hardware or software of the AATU in order not to endanger your or other's health and life and not to damage the AATU and the equipment connected with it, not covered by warranty. The manufacturer is not liable for another's actions and responsibility shall be assumed by the doer.

CAUTION

To avoid damage (not covered under warranty) read the Installation – Section 2 of this operating manual carefully. If you have any doubts about the installation, operation or safeties of the AATU please consult your dealer.

2. INSTALLATION

2-1. Unpacking and Initial Inspection

CAUTION

Before you start any action on installing the AATU, thoroughly read this manual. First, carefully inspect all cardboard cartons and their contents for physical damage. If damage is noticed, notify your dealer immediately. Delay may infringe carrier's warranty conditions. Keep all packing for possible future transportation!

Take out the RCU, its mains power cable and the serial-control cables (option). Carefully check the RCU and the cables for any possible shipping damage. Leave them on the place where the RCU will be installed.

The remote (main) unit, together with the remaining installation accessories and both cartons with the 50m cables are intended for installation at the antenna area. Take them out of their cartons separately and check carefully for transportation injury. Return them back into their cartons after that in order to make it easy and safely to carry them to the remote-unit installation place (for instance, at the antenna base).

2-2. Line Voltage

CAUTION

To avoid damage (not covered under warranty), check carefully if the voltage for which the AATU is set corresponds to your mains nominal voltage.

Normally the AATU is supplied with Voltage Selector set for a nominal mains voltage of 230V. There might be exceptions in cases of special delivery.

2-3. Remote Unit Installation

NOTE

Before you start any action on installing the remote unit, make a plan about how the cables would be laid and where would they come through the wall on the premises where the RCU will be installed. Have in mind that there is a connector installed on the bottom end of the supply cable that needs a minimum of 22mm (7/8") diameter

hole. If you prefer a smaller hole, you should thread the whole cable length through the wall, beginning from its bared end and leaving the connector in the room. In such a case you would need only 8mm (5/16") for this cable and another hole of 7mm (9/32") diameter for the optic cable.

NOTE

The coaxial cable needed for a connection between the remote unit and the station is not supplied but you should foresee its installation, too (unless it has been installed previously). Normally you will need a 11mm (7/16") diameter hole or 20mm (25/32") should you want to thread the cable with the PL-259 connectors installed.

WARNING HIGH VOLTAGE!

To avoid disaster, the AATU installation and connection to the grounding and to the antenna should be carried out only in serene quiet and sunny weather, when no risk for thunders or atmospheric electricity activity exists. Not only a direct lightning hit but also nearby strokes, as well as electricity induced by storm-clouds or a dusty wind can cause voltages in either the antenna or the cables you are installing, that are **dangerous for life!**

WARNING HIGH VOLTAGE!

Do not begin installing the AATU before you have prepared a proper and safe **lightning grounding installation!** Never use the AATU unless it is grounded to guard you against lightning strokes! Do not use casual ground connections!

Installation of the remote unit must be accomplished in the order described below, before you connect the RCU and the cables to your station.

a) Mount the AATU installation console to the antenna mast at a height at least 80cm (2.6 feet). This is needed in order that winter snow cannot reach the height of the unit. Use both U-bolts M6 and the fixing screw M6x70mm (supplied) – see fig.2-1,a,b & 2-2,f,g. Do not miss the fixing screw that avoids turning the unit around the mast.

b) Place the remote unit on the installed console and orient it with the hood head upward and the connectors downward (see fig.2-1 and 2-2). You may need an assistant for the next operation.

CAUTION

When outdoors installed, the unit must be positioned with its hood head upward, and with the connectors and the cable glands – vertically down. Never install the remote AATU unit inclined to the vertical for outdoors usage in order to prevent it from precipitation-water leaking into the unit as this may lead to damage, not covered by warranty!

Settle carefully the unit onto the console and align its four installation blind holes (M6 threaded – see fig.2-4) to the corresponding console holes.

An assistant may be needed at this point to hold the unit steady while you screw in the four screws M6x16mm (fig.2-1,c) loosely. Tighten them properly using a 5mm (0,2") Allan key.

After having finished the above mount operations please check the strength and reliability of the installation.




Fig.2-1. Remote AATU unit on-mast installation and cables arrangement (bottom view).

c) Using a 5mm (0,2") Allan key unscrew all 10 captive screws M6 located on the bottom panel of the unit (see fig.2-1,d). Pull the metal hood upwards carefully and remove it. Using a "Philips 1" screwdriver, unscrew all 12 M3x8mm screws that hold the rear lid of the unit. Carefully slip it off in order to get access to the Printed Circuit Boards "Power Supply" and "Control". On the "Control" PCB find the two optic devices, marked U10 and U11 on the PCB, and having knurled plastic nuts, permanently installed on their optic connectors (a split-socket type to tighten the optic-cable cores) - see fig.2-2,a & 2-3. The black-case device is the photo detector receiver while the white-case is the optic emitter. For now, as the other cable end is still not connected, it is meaningless which core to which device shall be connected. Identifying is easy on the second end at the first power on see S.2-4(c).




Fig.2-2. Remote unit connections

d) Unscrew the plastic cable-gland cap (marked "OPTOLINK CONTROL" on the bottom panel - fig.2-1,e & 2-2,e) and thread it over the optic cable in such a direction as to be able to screw it onto the same cable gland later. Push the bared optic cable end into the cable-gland hole and direct it to both optic-device apertures (fig.2-2,a-b & 2-3).




Fig.2-3 The “Control” PCB and optic devices in the remote AATU unit.

Push 2-3cm (one inch) more cable length into the cable gland (so that not to stretch the inside cable length after having it connected to the optic devices (fig.2-2,a-b) and tighten the cable-gland cap using a wrench sized 22mm (7/8”). Use only enough force while tightening in order that the cable be tight and could not slip out when pulled occasionally (do not overdo it since a cable-gland destruction is likely).

CAUTION

The optic cable ends are supplied readily bared and prepared for installation. Nevertheless, check on each cable end whether the external sheath has been removed about 100mm (four inches), in order to move apart both fiber cores to both optic devices. In addition, each fiber face must be cut as smooth as possible and in a vertical section. Check whether the cut surface is clean of contamination and lucid.

Should you need to bare the cable once more again, first peel off the external cable sheath about 10-12cm (four inches) from the end. Be careful not to injure the cores under the sheath. Then cut small lengths (2-5mm, 0.1-0.2”) off each core end in order to expose a clean and lucid surface of the transparent light-guiding plastic fiber. Use a clean, sharp and smooth-surface knife. Keep track to make a precisely vertical section. The light loss and reflections depend strongly on this operation quality. To improve the cut performance we recommend to pre-heat the knife blade (to about 70-80 deg.C or 160-175F). Be careful not to contaminate the blade while heating and not to over-heat it.

Loose the split-socket-knurled nut of either optic device slightly (fig.2-3). Then push either core into the split socket, shove the core against the stop, and tighten carefully its knurled nut by hand. Keep track that no foreign matter is caught into the optic device aperture since this would obstruct the light beam.

Use only enough force while tightening in order that the cable be tight and could not slip out when pulled occasionally (do not overdo in order not to damage the plastic case or the optic device). Repeat the same operation with the second cable core and the other optic device. As mentioned above, identification of the channels transmit and receive will be made at first power on – see S.2-4(c).

e) Unscrew the metal cable-gland cap (marked “24VAC/3A” on the bottom panel (see fig.2-1,f) and thread it over the bared end of the four-core screened power-supply cable in such a direction as to be able to screw it onto the same place later. Take out the plastic insert from the cable gland housing. Thread the insert over the cable end in such a direction, that its split end be next to the metal cap, and the slender end – to the cable bared tag (see fig.2-4).




Fig.2-4 Power supply cable gland of the remote unit (bottom view).

Drag the detached (10-12mm or ½")-piece of the cable sheath towards the cable end in order to loose the shielding braid. Remove the cloth layer from the shield and carefully spread the braiding wires below it in a radial direction. Move the plastic insert towards the bared area until the insert face reaches the split braiding. Then bend the shielding wires back in order to lay them over the outside surface of the plastic insert (fig.2-5). Put them in order and arrange carefully around the insert periphery.




Fig.2-5 Screening braid shaped before to push into the cable gland.

Holding the plastic insert fixed to the cable, push all four cable cores into the gland housing and direct them towards the "Power Supply" PCB inside (fig.2-2,c-d). Use a small rotation around the insert axis in order to align its three guides to the corresponding grooves in the metal housing, then carefully shove the insert into the gland body, together with the shaped cable. Now, press the insert inwards in a manner that the back-folded braid touches the metal-housing head closely, and while holding it in this position, screw in the metal cap against stop. Finally, tighten the cap using a wrench size 20mm (25/32"). Use only enough force while tightening in order that the cable be tight and could not slip out when pulled occasionally (do not overdo in order not to damage the gland thread).

f) Inside the remote unit, direct the cable cores to both terminal pairs located on the “Power Supply” PCB, that are marked J1 & J2 (~24VAC) – see fig. 2-2,c-d and 2-6. The power supply is applied through each pair in parallel (each pair is one pole of the power supply).




Fig.2-6 Power-supply PCB: cable connection and fuses in the remote unit.

Using a flat-tip screwdriver 3x0,6mm (1/8”x0.02”) loose the terminal screws. Push the bared end of core nr.1 (marked white over the black core insulation as well as on the terminal block), into the bottom terminal, and tighten it properly. Above it connect core nr.2, then in an up-sequence - core nr.3, and at the top connect the yellow-plus-green colored core (to the terminal that is marked with “Y”).

g) Install the rear lid of the unit. Using a “Philips 1” screwdriver, screw in all 12 screws M3x8mm loosely. Then tighten properly but do not push strongly along screw axes in order not to push out any captive nut from the chassis.

Slip on the protective metal hood and lower it carefully downwards until it stops onto the bottom panel of the unit. Screw in loosely all 10 captive screws M6 (located on the bottom panel - see fig.2-1,d). Then tighten properly using a 5mm (0,2”) Allan key.

h) Connect the remote-unit grounding clamp, marked “GROUND” on the bottom panel, to the lightning-protection grounding system (see fig.2-1,g).

i) Connect the balanced antenna feeder to the terminals marked “BALANCED ANTENNA OUTPUT” on the bottom panel (see fig.2-1,l & 2-2,h). Shape its leads in an order not to permit accessing the AATU case or any grounded part of the installation.

j) Connect the RF coaxial cable to the coaxial connector marked “50Ω RF INPUT” on the bottom panel (see fig.2-1,i). Use cable type RG-213 or equivalent.

CAUTION

Using the “UNBALANCED ANTENNA OUTPUT” option is only permissible after having disconnected the internal connection between the matching circuit output and the BALUN transformer input, in order not to destroy the balun transformer. Contact your dealer or the factory for details.

k) Lay the cables along the route to the station premises, stabilize them and protect against damage in case of a movement, wind, snow or ice. Lead in the cable ends through the wall (if not done previously). Get measures against trickle water leaking through the building wall.

2-4. Connections to the Station

The connections of the AATU and its RCU to the station must be accomplished in the order described below, before you apply mains voltage to the RCU.

a) First connect the ground stud of the RCU marked "GND" to the station's grounding system – see the left yellow arrow at fig.2-7.



Fig.2-7 RCU rear panel, grounding terminal, and mains fuse.

b) Connect the remote-unit power supply cable to the 5-contact round connector on the rear panel, marked "24VAC/3A OUT".

c) Connect the mains power cord to the 3-spade IEC mains socket, marked "230V 50/60Hz". The optic cable is still not connected.

WARNING HIGH VOLTAGE!

Do not use non-standard mains power cords! If the power plug supplied is different from the standard in your country, the power plug must be replaced by a qualified electrician who must check whether the third grounding lead of the mains cord is properly connected.

CAUTION

To avoid damage (not covered under warranty), check carefully if the voltage for which the AATU is set corresponds to your mains nominal voltage (see S.2-2).

After following all instructions in S 2-3 & 2-4(a,b,c), make sure that the main switch POWER located on the rear panel is in OFF position (so that the red stripe on the switch is hidden) and then connect the power plug of the RCU to the wall mains outlet prepared for it.

Before you switch ON the POWER switch, take the optic cable tag and look carefully which one out of the two cable cores would glow with red pulsing light immediately after a turn ON. Now turn ON - in either core of the cable shall appear the mentioned red light. It will blink four times (about 0,5s each), and will stop after that. Note the blinking cable core and switch OFF. Mark this core using a sticking label or use another convenient method to recognize it – this is the cord incoming from remote-unit transmitter and it should be connected to the optic receiver device located on the "RCU control" PCB (see S.2-4,d).

Now disconnect the power plug from wall mains outlet.

d) Connecting the optic cable to the RCU.

WARNING HIGH VOLTAGE!

The AATU works with mains voltage 220-240VAC 50-60Hz and high DC voltage up to 300VDC, which are **LETHAL!** Also, for your safety pull the AATU power plug out of the mains wall outlet and **WAIT AT LEAST 3 minutes EACH TIME BEFORE you remove any cover!**

After pulling the power plug out of the mains wall outlet, using a “Philips 2” screwdriver unscrew all four side screws from the top cover of the RCU. You will see the PCB “RCU Control” installed horizontally and having two optic devices U3 and U4 of the same type like those you have seen yet in the remote unit (see fig.2-3). The operations on the optic cable connection at the RCU side are analogous to those from S.2-3(d).

Unscrew the spiral cap of the plastic cable gland marked “OPTOLINK” (see fig.2-7) and thread it onto the cable oriented with its thread towards the cable end. Push the cable into the RCU case through the cable gland and give it some margin in order that the cable cores freely access the optic devices without straining. Now screw in the spiral gland cap and tighten it using a wrench 15mm (19/32”). Use only enough force while tightening in order that the cable be tight and could not slip out when pulled occasionally (do not overdo in order not to damage the plastic gland thread).

Loose slightly the split-socket-knurled nut of the optic receiver device U3 (black housing). Then push the marked core (S.2-4,c) that comes from the remote-unit transmitter, into the split socket. Use tweezers on need. Shove the core against the stop, and tighten carefully its knurled nut by hand. Keep track that no foreign matter is caught into the optic device aperture since this would obstruct the light beam.

Use only enough force while tightening in order that the cable be tight and could not slip out when pulled occasionally (do not overdo in order not to damage the plastic case or the optic device).

Repeat the same operation with the non-marked cable core and the other optic device U4 (white plastic case).

Now install the top cover. Screw in loosely all four side screws, then make even the cover, and tighten the screws using a “Philips 2” screwdriver. Do not push strongly along screw axes in order not to push out any captive nut from the chassis.

e) Connect the RF coaxial cable that comes from the remote unit (with a PL-259 connector) to the transceiver output (or the amplifier or antenna selector when available).

f) If you have options supplied, connect also their cables (KEY-IN and KEY-OUT, serial control channels COM1, COM2 or RS422). The amplifier ACOM2000A connects via a “Null Modem” cable to the 9-contact connector COM2. In this way, the AATU will send a “go to STBY” command to the ACOM2000A each time when you press the TUNE button on the RCU. If the cable is not installed you should set the amplifier in STBY manually.

3. POWER ON, RCU CONTROLS AND MENU

CAUTION

To avoid damage (not covered under warranty), check carefully if the voltage for which the AATU is set corresponds to your mains nominal voltage (see S.2-2).

After following all instructions in S 2, you can turn ON the Main power switch on the rear panel. The LCD back-light and all five buttons must light (see fig. 3-1) and on the upper LCD row should appear the following message:

Connecting...

The self-test is accomplished in about 2s and then the AATU retrieves the power-on default setting – this will be explained later in S.4-2. Now it is best to get acquainted with the menu control. Press the **Esc** button twice to reach the main menu:



Fig.3-1 ACOM 03AT Remote Control Unit (RCU).

**BYPASS [OPERATE]
STATUS SWR-CHK**

On the menu are shown the four main functions that are available – BYPASS, OPERATE, STATUS, and SWR-CHK (SWR check).

The function OPERATE is shown selected between square brackets in the example above. If you wish to select another function, move the brackets in the required direction with the < (left) and > (right) arrow buttons, so that they enclose the desired item. The selected function would be activated if you press the button **Enter**. When the edge of the display is reached, future movement in the same direction will cause the brackets to scroll to the opposite row of the display. After that, you can move the brackets to the left or to the right using the corresponding arrow button.

For instance, press the button < (left) to select the function BYPASS:

**[BYPASS] OPERATE
STATUS SWR-CHK**

To exit from an item, press the **Esc** (Escape) button. If you press it repeatedly, you will escape from any menu level and you will eventually reach the main menu. When that menu is reached, the **ESC** button becomes inoperative and you have to select a function.

The purpose and use of these four functions is described in Section 4. To power off the AATU just switch the main switch POWER located on the RCU rear panel in OFF position (so that the red stripe on the switch is hidden).

4. OPERATION

Operation of the AATU is simplified a great deal due to the high degree of automation and intuitive control. You can start operation immediately after it is installed. However, to make full use of its possibilities and to fully configure to your local conditions, we recommend you thoroughly read the following information.

4-1. Function OPERATE and AUTO TUNE procedure

This is the main function of the AATU. When you select it from the menu, you will see the function inscription:

Mode: OPERATE
----_----

The bottom row of the LCD is intended to indicate the frequency segment where the AATU is tuned. Now you have to set the needed frequency on the transceiver and to select the needed antenna where the AATU will be tuned.

C A U T I O N

Before giving a tuning command, you have to stop any transmission and put the amplifier (when available) to bypass (STBY mode). Never apply more than 100W tuning power in order not to trip either AATU protection!

C A U T I O N

If you use more than one antenna you have to select the proper antenna corresponding to the needed frequency and/or desired direction.

a) **AUTO TUNE** procedure.

When the antenna is selected and with no RF applied to the AATU, you can start the auto-tune procedure pressing the button **AUTO TUNE** on the RCU:

Mode: AUTO TUNE .
Apply 10-100W RF ()

The AATU will then wait for you to apply between 10 and 100W continuous carrier (CW) signal with the desired frequency. If you leave the AATU waiting longer than 20s, then it will inform you:

Mode: AUTO TUNE
Timeout Expired

When you apply a tuning signal as needed, an asterisk will appear between two brackets at the right-low corner on the LCD. It will indicate the presence of a proper tuning signal:

Mode: AUTO TUNE .
Apply 10-100W RF (*)

The process of automatically matching the antenna impedance begins when the power remains constant within the needed boundaries. After about one second, tuning begins and the indication changes:

Mode: AUTO TUNE .
In Progress ... (*)

This way, the AATU reports that the essential matching process (via impedance measurements and assessment, and switching the relays) has been initiated in the remote unit. This takes various periods depending on the frequency and the antenna impedance for this frequency but never in excess of 8s (typically 2s). After the procedure has finished, the AATU will call to stop tuning power (for at least one second before starting transmission with a tuned AATU):

Mode: AUTO TUNE .
Stop RF

At last, after you stop the tuning power, you will be informed about the results:

Mode: OPERATE .
06970-07110 * OK *

b) Indication.

The frequency segment where the AATU is currently tuned is shown on the bottom line (kHz). It spans about $\pm 1\%$ around the tuning frequency that you have applied. Normally you can use this frequency segment with excellent results without a retune of the AATU.

To the right of the frequency-segment indication, you will see the procedure result as described below.

If for some reason matching cannot be accomplished successfully, the process ends up with a “**SWR>1.5**” or “**Unstable RF Power**” indication instead of the usual * **OK** *. This is a rare case caused for example by excessive antenna SWR or unstable tuning power).

When the SWR is above 1.5:1, the AATU stops at the best SWR achieved, so you could check whether it would be acceptable for your transceiver as a last resort (usually if below 2:1). We recommend, however, to make a correction or repair the antenna when needed, in order to improve its SWR.

Although the AATU is capable to match a much wider than the guaranteed impedance range, it is advisable that the antenna SWR be included in the range where the AATU matching capability is specified (see S.6-1,e).

CAUTION

If you give an **AUTO TUNE** command while RF is presently applied, you will see a “**Stop RF ...**” message and the operation will be rejected. Just stop transmitting, place the amplifier to bypass (STBY), and repeat the command.

CAUTION

If you occasionally interrupt the tuning power while the **AUTO TUNE** process is being executed, you will see a message “**Unstable RF Power**”. Just repeat the command.

NOTE

You can start the **AUTO TUNE** procedure directly from the main menu, as well as when either OPERATE, STATUS, or SWR-CHK function is active. You cannot start **AUTO TUNE** from BYPASS function. You will note that the **AUTO TUNE** button becomes dark while it is inoperative.

If you press the button **Enter** for the second time while in OPERATE, you will start the Memory sub-function which is explained in the next section. To exit, press the button **Esc** repeatedly until the main menu appears.

4-2. Using the Memory

This is a sub-function of the function OPERATE. To select it, while in OPERATE press the button **Enter** – you will see the function inscription:

```
Mode: Memory *12d
6970-7110 .
```

a) Indication.

To the right on the upper line is shown the current memory-cell number. The characters in front and behind the number can be missing as explained below.

If the memory cell appears marked with an asterisk * in front of the number, this means that the cell contents is in effect and it is identical with the tuning (relay settings) in the remote unit. If the asterisk is not present there, you are only looking at the cell contents (frequency segment), however it is not active. This means that the current relay status of the remote unit is different from what is written in the memory for that frequency segment.

If the letter “**d**” is shown behind the cell number, this means that this memory cell has been selected by the operator to be used as default setting at a power on. The selection method is described below.

The bottom row is intended to indicate the frequency segment the tuning has been written about in the memory cell shown. If no numbers are present on this line but only a “-----” appears, the current cell has been still not used.

b) Buttons operation.

The following commands are available for memory operation:

- using the buttons < or > you can decrease or increase the memory-cell number. You can look up the list of the frequency segments stored with a tuning in various memory-cells (or only the part of interest). The remote-unit relay status is not being changed while you are listing the memory unless you activate either cell contents.
- If you press and hold the button **Ent**, you will get access to the three commands that you can use concerning the currently displayed memory cell. The following screen will prompt you to give a command:

```
Mode: Memory *12d
DEF RCL STO .
```

Command abbreviations appear at the top of the three buttons from the left, namely:

DEF (Default) – above the button **Esc** – if you press it together with the **Ent** and release both buttons after that, the letter “**d**” will appear to the right of the memory-cell number. This mark denotes a default cell that will be used by default at a power on.

CAUTION

Before giving a **RCL** command, you have to stop any transmission.

RCL (Recall) – above the button **<** – if you press it together with the **Ent** and release both buttons after that, the contents of the current memory cell will be sent to the remote unit and it will become an active cell. Respectively, an asterisk will appear to the left of the cell number.

STO (Store) – above the button **<** – if you press it together with the **Ent** and release both buttons after that, the current relay settings and the tuning frequency of the remote unit will be memorized in the currently displayed memory cell. Respectively, an asterisk will appear to the left of the cell number (the cell content is equalized with the remote unit status i.e. it has become active). In addition, on the bottom row appears the new frequency segment for which the stored tuning will be valid.

You will see that after a command has been given, its inscription disappears from the screen – this will be a notice that the command has been accepted and done. You can give an arbitrary commands queue while you are holding the button **Ent**, as well as you can release it for each command.

c) Using the memory.

You can prepare AATU tunings for the frequencies that you use frequently and store them in different memory cells (with numbers 1 to 99) using the command **Ent+STO** (Store). The button **AUTO TUNE** is active also while using the memory and is to be used in the same manner as it was in the OPERATE function (see S.4-1). The button is not accessible only when a command selection is being expected (**DEF**, **RCL** or **STO** combined with **Ent**).

Once you have memorized the tunings for all the frequencies of interest, you can retrieve them in an arbitrary order from the memory using the command **Ent+RCL** (Recall), i.e. to get them active. The tunings do not disappear even after you switch off the power supply, i.e. the tunings memory is nonvolatile.

After you have activated a memory tuning via an **Ent+RCL** (Recall) command, you may write its content in another memory cell using the command **Ent+STO** (Store). You will be able to rearrange the memory cells via “relocating” them in new cells (without a retune) and then using the “vacated” cells to store new tunings there.

NOTE

Using too old tunings can exhibit high SWR (if the conditions at the antenna have changed significantly since the day the tunings have been stored). Should this happen, we recommend that you refresh these tunings using the **AUTO TUNE** procedure and then store new tunings via the **Ent+STO** (Store) command.

Once a memory cell gets activate, you can abandon the Memory sub-function temporarily by pressing the button **Esc** until you reach the main menu. Then, the remote unit tuning is not being changed since the current tuning status is being considered being operative. In this situation, you can use either function **BYPASS**, **STATUS** or **SWR-CHK** (for instance checking the ATU resource in use or the present SWR of an old tuning). If you have not made any **AUTO TUNE** meanwhile, at returning to the Memory sub-function you will have the same tuning status as it has been before you left it (even if you have used the **BYPASS** function).

Should you need changing the default power-on memory cell, select the new cell via the buttons **<** or **>** and then use the **Ent+DEF** (Default) command. You can do this at any time while using the Memory sub-function, as well as immediately before switching the power off.

4-3. Function BYPASS

CAUTION

Before giving a **BYPASS** command, you have to stop any transmission.

When you select the function **BYPASS** between the square brackets in the main menu and then press **Enter**, you will see the function inscription:

Mode: BYPASS

BROAD BAND

At a function selection all relays are switched off, thus the effect of the inductors and the capacitors on the remote-unit impedance transformation is eliminated. While the BYPASS function is active, the **AUTO TUNE** function is not accessible (the button is dark).

This way, you can operate without re-tuning the AATU provided the antenna SWR is acceptable in a certain frequency range.

CAUTION

Using a coaxial feeder at SWR above 3:1 is not recommended in the HF range. When the SWR is higher than 3:1 and you want to use this antenna at high RF power, you risk damaging the coaxial cable between the station and the antenna. The cause is increased current and voltage along the cable, as well as a large amount of heat they generate in the cable wires and insulation. We recommend you use AUTO TUNE in either OPERATE, STATUS, or SWR-CHK function in such conditions in order to use your cable safely as well as to increase the radiated power.

Besides operating, you may use this mode also for preventive checks of your antenna and feeder system. While in BYPASS, check the antenna SWR for several representative frequencies and compare with data copied providently while you have been confident the system was intact.

The function can be restarted via the button **Enter**. To exit, press the button **Esc** until the main menu appears.

4-4. Function STATUS

When you select the function STATUS between the square brackets in the main menu and then press **Enter**, you will see the function inscription:

```
CT=3E L=012 CA=00 CS
24% 3% 0% N
```

Various figures may appear in the example above. On the upper LCD line is shown the current position of the main RF-tuning blocks. They are configured in a standard low-pass Pi-circuit to perform the impedance matching in the remote unit. See fig.5-1 and S.5-3 for details. The following symbols are used:

CT – comprises a group of 8 capacitors connected in parallel to the transmitter input;

L – comprises a group of nine inductors connected in series between the transmitter input and the antenna output;

CA – comprises a group of six capacitors connected in parallel to the antenna output;

CS – a capacitor connected in series to the antenna.

To the right of each group symbol is shown a figure in hexadecimal code. Should one convert it in binary code, the figure would point to the elements in a group used (1) and not used (0) for the current tuning. For CS are used only Y (used) or N (not used). These figures are useful for preventive checks and troubleshooting of the AATU that can be accomplished by trained personnel.

On the bottom line, below each group symbol is shown the used percentage of the usable reactance (at that frequency) to achieve the current tuning. In other words, this is the used resource of the AATU matching circuit. It could give you a hint about at least two issues:

- what the margin is to keep achieving antenna match at antenna-impedance variations in the future (due to exterior influence - weather or antenna surroundings change, new or moved antennas or any massive objects etc);
- you may provisionally copy data about the resource used by the AATU in the frequency range and antennas or your interest. Eventual changes in the future would forewarn you when you may need any antenna- or feeder changes or repair in order to increase the margin, thus preventing possible problems.

NOTE

You can start the **AUTO TUNE** procedure while using STATUS function and return back to the STATUS by pressing the button **Enter**.

The function can be restarted via the button **Enter**. To exit, press the button **Esc** until the main menu appears.

4-5. Function SWR-CHK

CAUTION

Before giving an **SWR-CHK** command, you have to stop any transmission and put the amplifier (when available) to bypass (STBY mode). Never apply more than 100W tuning power in order not to trip either AATU protection!

When you select the function SWR-CHK between the square brackets in the main menu and then press **Enter**, you will see the function inscription:

```
Mode: SWR Check .  
Apply 10-100W RF ( )
```

The operation principle is the same as when using the **AUTO TUNE** function (see S.4-1). After you have applied RF power, the SWR is measured at the AATU input and then you have to stop the power:

```
Mode: SWR Check .  
Stop RF ... .
```

At last, you get the measurement result:

```
Mode: SWR Check .  
SWR > 1.5 No Good
```

or:

```
Mode: SWR Check .  
SWR < 1.5 * OK *
```

NOTE

You can start the **AUTO TUNE** procedure while using **SWR-CHK** function and return back to the **SWR-CHK** by pressing the button Enter.

The function can be restarted via the button **Enter**. To exit, press the button **Esc** until the main menu appears.

4-6. Using STATUS and SWR-CHK Functions for RF Path Diagnostics

Using both functions efficiently, you can estimate the status of the antenna and especially of the feeder.

a) If you select BYPASS and check the SWR for a given frequency where you certainly know the antenna has a bad SWR, but you can measure a good SWR instead, this is a symptom about high losses in the feeder.

For instance, moisture could be present below the cable sheath, the insulation could be soaked with water (unless it is dense) or shielding-braid corrosion could be present. Such a coaxial cable should be replaced since it will cause much power loss and instability in both transmission and reception modes.

b) If an *** OK *** is indicated after an AUTO TUNE but you find a bad SWR at the station end of the cable (for instance looking at the transceiver or the amplifier indication), the antenna and the AATU are OK but the coaxial cable has a problem (bad contact or short-circuiting at either connector is likely). Check the antenna switch if any.

c) If you frequently get a message "**Timeout Expired**" (although above 50W tuning power applied) and during the 20s-timeout period the SWR is OK at the station side, check the following:

- the coaxial cable losses might be so high that the RF power reaching the remote unit is insufficient to operate the AUTO TUNE function (below 10W);
- in the remote unit, the fuse F2 at the RF-impedance sensor output has blown for some reason. To replace it, see S.5-2(c) and fig.5-2.

d) If you frequently get a message "**Timeout Expired**" (although above 50W tuning power applied) and during the 20s-timeout period the SWR is very high at the station side, check the following:

- the coaxial cable could be torn or has a short circuit (most likely in either coaxial connector);
- in the remote unit, the fuse F1 at the RF-impedance sensor input has blown for some reason (then check F2 too). To replace them S.5-2(c) and fig.5-2.

5. MAINTENANCE

WARNING HIGH VOLTAGE!

The AATU works with mains voltage 220-240VAC 50-60Hz and high DC voltage up to 300VDC, which are **LETHAL!** Also, for your safety pull the AATU power plug out of the mains wall outlet and **WAIT AT LEAST 3 minutes EACH TIME BEFORE you remove any cover!**

5-1. CLEANING

CAUTION

Do not use solvents for cleaning – they may be dangerous both for you and for the RCU paint.

Do not open the units. Cleaning of the remote unit can be done with a piece of cloth well moistened with clean water. For the RCU surface, please use soft cotton lightly moistened with clean water.

5-2. FUSES REPLACEMENT

CAUTION

Use only standard fuses of the types shown below for replacement.

All fuses in the AATU are European size 5x20mm and could be glass or ceramic.

a) The AC line fuse is located on the RCU rear panel, inside the mains-cord socket. In order to access it, pull out the mains-cord power plug from the wall outlet and disconnect its second end from RCU (see fig.2-7 - the right yellow arrow – and fig.5-1). Find a plastic tooth at the center-top of the contact opening (the right yellow arrow on fig.5-1). Using a flat-tip screwdriver, catch the fuse lid (with a drawer inside), and pull it carefully towards outside.



Fig. 5-1 Pulling out the AC line fuse.

Inside the drawer, you will find two fuses. One of them is bare while the second is hidden in a groove. The bare fuse is the working one while the hidden is a spare. In case that you have no spare available, bring out the hidden one and install it at the working place. Do not miss to supply a new spare as soon as possible.

The AC line fuse must be slow blow type (antisurge, tardy or traeger), marked T or L), 0,5A/250V. It is available from Farnell, cat.nr. 898-892.

When installing, orient the plastic drawer with the tooth down, align it to the body groove in the socket and push it carefully inside against stop (its lid should flush with the socket frame). Then insert the power cord first in the RCU mains socket and make sure that the main switch POWER located on the rear panel is in OFF position (so that the red stripe on the switch is hidden). At last, connect the power plug of the RCU to the wall mains outlet.

Should the AC line fuse blow, most likely there is a short circuit in the 24VAC-power cable or its connector to the remote unit (it could be also a power-supply problem in either RCU or remote unit).

b) Besides the AC line fuse, there are four more fuses located in the remote unit. Two of the fuses are located on the "Power Supply" PCB (marked F1 & F2 on the PCB – see fig.2-6). They are connected in series to the (24VAC/3A) power-supply input of the remote unit. These fuses must be of the slow blow type too (antisurge, tardy or traeege), marked T or L), but for 3,15A nominal current. These are available from Farnell, cat.nr. 665-113 or from DIGI-KEY, cat.nr. F980-ND.

Should the "Power Supply" fuses blow in the remote unit, most likely there is a short circuit in the relay-coils supplying circuit - the Control-to-Coils cable harness (it could be also a power-supply problem in the proper Power Supply PCB).

c) The last two fuses in the remote unit are located on the "RF Sensor" PCB that is installed under a separate screen, located on the side closely to the RF input connector (look at the vertical cover at the left corner on fig.2-2). To access these two fuses you have to unscrew all 8 screws M3x8mm (fig.2-2,i) and to remove this screen. You will see the PCB "RF Sensor" under the screen with two fuses F1 & F2 on it (see fig.5-2).




Fig.5-2 Fuses on the PCB "RF Sensor".

The fuse F1 on the "RF Sensor" PCB must be of the ultra-rapid type or at least fast (quick blow or flink), marked FF or at least with one F). It is for 2A nominal current (when marked with only one F, it should be for 1.8A). The proper model could be supplied by Farnell, cat.nr. 532-782.

The fuse F2 on the "RF Sensor" PCB must be of the slow blow type (antisurge, tardy or traeege), marked T or L), for 400mA nominal current. It is available from Farnell, cat. nr. 898-880.

Should either F1 or F2 on the PCB "RF Sensor" blow, most likely a too high power has been applied to the AATU input (in excess of 150W) for tuning or SWR check. This can happen at operator's mistake and any casual protection trip omission, respectively any control problem.

If the AATU still does not work after you have replaced the fuses, we recommend that the repair be accomplished by trained personnel – contact your dealer or ACOM directly (see S.1-2).

5-3. ACOM 03AT Matching Circuit Schematic Diagram

The AATU ACOM 03AT comprises the following main units: RF Matching Circuit, RF Sensor, ATU Control, and ATU Power Supply – located in the remote ATU.

Look at Fig.5-1 – the RF matching circuit schematic diagram. All relay contacts are shown de-energized (no coil current). The matching RF circuit comprises:

- A block of 8 capacitors connected in parallel to the transmitter input (CT1 - CT8), that can be activated in the circuit and their capacitance can be accumulated via energizing the relays KCT1 - KCT8 (the normally open contacts are used). The capacitance for numbers one through eight increases from 27 up to 1800pF in a geometrical progression. This makes it possible to combine random capacitance values for CT using binary combinations between 00 and FF (0 – 255 decimally) in the range from 27 up to 4100pF with a resolution step of 27pF.
- A block of 9 inductors connected in series between the transmitter input and the antenna output – inductors L1 through L9 - can be activated in the circuit and their inductance can be accumulated via energizing the relays KL1 – KL9. The normally closed contacts are used in order to shunt an unused inductor when its relay is de-energized. The inductance for numbers one through nine increases from 0,065 up to 10uH in a geometrical progression. This makes it possible to combine random inductance values for the series L using binary combinations between 000 and 1FF (0 до 511 decimally) in the range from 0,065 up to 23uH with a resolution step of 0,065uH.
- A block of 6 capacitors connected in parallel to the antenna side (CA1 – CA6), that can be activated in the circuit and their capacitance can be accumulated via energizing the relays KCA1 – KCA6 (the normally open contacts are used). Similarly, to the groups described above, the capacitance for numbers one through six increases from 27 up to 680pF in a geometrical progression. This makes it possible to combine random capacitance values for CA using binary combinations between 00 and 3F (0 – 63 decimally) in the range from 27 up to 1400pF with a resolution step of 27pF.
- A single capacitor is connected in series to the antenna output (CSA) that can be activated in the circuit via energizing the relay KCSA. The normally closed contacts are used in order to shunt the capacitor when its relay is de-energized). In this way, a 250pF capacitor can be inserted in series to the antenna.

Besides the components mentioned above, there are two balanced transformers: TV2.1 and TV2.2 included between the matching-circuit output and the antenna. The first transformer is step-up 50:200 Ω and also provides for outputs balance for frequencies where the antenna impedance is higher than the nominal (200 Ω). The second transformer is 200:200 Ω and reduces the unbalance for frequencies where the antenna impedance is below 200 Ω .

In parallel to each antenna insulator is connected a standard metal-sphere spark gap to guard the AATU and correlated apparatus against atmosphere electricity during thunderstorms. A RF choke - RFC2 (80uH) is connected in parallel to the RF input in order to bleed eventual electrostatic charges from the connected antenna to the ground.

The input signal is fed to the connector “50 Ω RF INPUT” - J1 on the schematic diagram. The capacitor Cc*, that is connected in parallel to the input is adjusted to minimize the SWR of the input wiring for the higher band edge (it could be omitted).

Energizing the relays KAT1 and KAT2, the RF signal can be turned to the RF sensor input J2-Sin during a tuning, while the matching-circuit input is connected to the sensor output J3 – Sout. With both relays KAT1 & KAT2 de-energized, the input RF power is directly fed to the matching circuit input and the sensor input is grounded. Besides, a part of the input voltage on JP1 is taken by the capacitance divider Cu/C1 and is then detected by the diode D1. The DC voltage on its output “+inp” is a criterion about RF power presence at the input.

During a tuning procedure, the input RF power is fed to the “RF Sensor” PCB through J2 – Sin, F1, R4, C8, C9, F2, and then to the primary winding of the voltage transformer TV1. The RF power from TV1 secondary is split in two:

- through the current-transformer TA1 primary – to the matching circuit input;
- through the current-transformer TA2 primary – to the reference resistive load R10a,b (C10 serves for frequency-compensation of the load for higher frequency band edge).




Fig.5-1 RF matching circuit schematic diagram (plus partly RF Sensor)

ACOM 03AT - MATCHING CIRCUIT
Schematic diagram Sht. 1 of 1

Bottom View
IRF710
BEX84C7V5
BAS70-04
TOP VIEW

Two small-signal RF voltages $U(i'-i')$ and $U(u'-u')$ are produced on the low current-transformer secondary windings (low-resistive loaded). These voltages are proportional to the momentary voltage and current values fed to the matching-circuit input. The phase and amplitude relations between both voltages define positively the complex antenna impedance as seen through (or transformed by) the matching circuit.

Combining appropriate portions of the mentioned signals $U(i'-i')$ and $U(u'-u')$ and using several detector and DC comparators, the following logic signals are derived that are characteristic of the transformed impedance Z_t position on the complex-impedance plane, in respect to the “matching target” $(50+j0)\Omega$:

- “Rsensor” – a high level represents a high real part of the impedance $\text{Re}(Z_t) > 50\Omega$;
- “Gsensor” – a high level represents a high real part of the admittance $\text{Re}(1/Z_t) > 20\text{mS}$;
- “Ssensor” – a high level represents a high SWR $> 1.5:1$ (bad SWR of Z_t).

NOTE

Part of the RF Sensor as well as other AATU modules are not included here in order not to overcrowd the schematic diagram. Full schematic diagrams for each AATU module as well as PCB layouts are included in the Technical Supplement. Please contact your dealer for details.

Two fast CMOS limiters and a D-type trigger in the RF Sensor (not shown in this figure) are involved to detect the sign of the phase between both voltages mentioned above. These voltages are fractions from the input voltage and current of the matching circuit. This scheme produces the “PHsensor” signal. A high level represents that the input impedance is inductive (i.e. the input current lags behind the input voltage), respectively represents a capacitance (the voltage lags behind the current).

The four logic signals R, G, S, and PH mentioned above are the main information sources that the AATU uses during the automatic impedance-matching process. These are fed to the micro-controller in the “ATU Control” PCB, where also the operating algorithm is programmed.

The MOS-FET Q1, that is connected between the C8-C9 joint and ground, (fig.5-1) is normally saturated with positive voltage on its gate (signal *RFON), thus branching the RF current through its drain-source channel to the ground. In this situation nearly all the input RF power is being dissipated by the swamping resistor R4 ($30\Omega/100\text{W}$) and the input impedance is nearly good (input SWR is about $50/30=1,67:1$). In this way, via placing the *RFON control signal to a high level, the micro-controller can safely switch-over the matching-circuit relays with no danger for their contacts.

The tuning process runs in a discrete stepping way. For each step, the micro-controller has to alternatively enable and disable the RF power fed to the sensors and to the matching-circuit input. Thus, it can control the RF power as needed to read the sensors as well as to safely switch the relays.

On each relay switching, the micro-controller has to first let the RF power to the sensors for a while and then to read their refreshed output status. This is accomplished by setting a low level on the Q1 gate (*RFON = 0) thus the transistor is cut off and the RF power reaches the voltage transformer TV1. Respectively, the detectors on the Sensor PCB are being activated. This takes only several milliseconds until the sensor readings settle, and the micro-controller disables the RF again (*RFON = 1). Then it analyses the information read from the sensors R, G, S and PH in order to assess the current impedance position on the complex impedance plane, in respect to the target $(50+j0)\Omega$. No relays are switched during this process since RF voltage or current is present on their contacts.

After an impedance analysis based on the information read, the micro-controller provides for which relays to switch ON and which ones – OFF at the next execution step. The decision is determined according to a certain algorithm that is pre-programmed in the micro-controller program memory. The algorithm is composed so that it is convergent to the “SWR<1.5:1” circle (in respect to the 50Ω –target). This is done irrespective of a variety of antenna impedance expected in the whole frequency range, while using the inductance- and capacitor- resource of the remote unit at a possible maximum.

The matching process continues making a series of tries as for each switching the RF power is disabled, the new status is given to the relays and a certain pause is made until the given status is executed. A new sensor-reading pulse follows, and so on the process is continued until the impedance will reach the “SWR<1.5:1” circle. Alternatively, the inductors/capacitors resource might be run out (if the antenna SWR is too high), and the AATU could not manage to improve the SWR below 1,5:1. When the procedure ends up, the micro-controller reports the tuning result to the RCU and a “Stop RF ...” prompt appears on the LCD. After the operator will stop the tuning power, both relays KAT1 and KAT2 are de-energized and the AATU is ready for transmission.

The input SWR of the AATU is being ensured below 1,67:1 during a tuning procedure by the swamping resistor R4 when the MOS FET Q1 is saturated. When it is cut off, the SWR could not exceed 1.6:1 too since at a very low matching-circuit input impedance the SWR-situation is same as with a saturated transistor ($50/30 = 1,67$). Should the input impedance be very high, the maximum SWR is limited by the reference load R10a,b (50Ω) that is connected in parallel to the matching-circuit input, i.e. the maximum SWR in this case could be $(R4+R10)/50 = (30+50)/50 = 1,6$. So, the SWR presented to the transceiver is guaranteed below 1.67:1 regardless of the current position of the matching circuit and for all possible tries during a tuning procedure. It is clear that after de-energizing both relays KAT1 and KAT2 (after a tuning is finished), the AATU will present the tuned circuit input impedance directly to the AATU RF input connector. Normally the tuned-circuit SWR will be below 1.5:1 (1.2:1 typically) for the tuning frequency.

The RCU and remote unit control is made up by two separate control systems built based on micro-controllers from ATMEL. In the RCU, the AT90C8515 is employed at an 8MHz clock frequency while the remote unit utilizes the AT89C4051 micro-controller at a clock frequency of 24MHz. They both make the most of standard solutions that are clear from their schematic diagrams (see the Technical Supplement or contact your dealer for details).

5-4. Troubleshooting

The schematic diagrams as well as the PCB component layouts for all units in the RCU and remote unit of ACOM 03AT are shown in the Technical Supplement.

Should the RCU display indicate a problem, look up the message in the list below and before your contact the service of your dealer (see S.1-2), try the recommendations about this message. The messages are listed in an alphabetic order. After having performed the recommendations, try the function again.

In case of necessity of transportation, see S.6-3.

MESSAGE

*** Action cancelled *
Stop RF & Press Esc**

Ant.Voltage too High

ATU Disconnected
(the AATU RF input has been disconnected in an emergency due to damage risk for the RF Sensor)

ATU Not Responding

Cannot Disable RF

RECOMMENDATION

A tuning change has been rejected because of RF presence at the AATU input. Stop transmitting BEFORE giving either BYPASS, OPERATE or memory recall command that would need switching of relays in the remote unit.

Check antenna presence at the AATU output.
Check the antenna condition and its SWR with no AATU (BYPASS). Use another antenna. Reduce the RF power fed to the AATU input.

Stop RF power for at least one second after each tuning, prior to begin transmission. Reduce tuning power below 100W. Prior to start tuning be sure the amplifier is bypassed (STBY).

Check whether the optic and power-supply cables between the RCU and the remote unit are intact and if properly connected (see connection instructions in S.2-3 & 2-4).
Check whether the 24VAC-supply voltage is present in the remote unit. Check both fuses F1 & F2 (3.15A each – see S.5-2,b).

Reduce the tuning power below 100W. Any problem in the remote unit is probable. Turn OFF the power supply for five minutes and try again. If the problem would not disappear, the ribbon cable between "ATU Control" and "RF Sensor" PCBs should be examined. It is probable that the *RFON сигнал could not saturate the MOS FET Q1 on the "RF Sensor" PCB. Such a repair should be performed by a trained service technician.

DAMAGE RISK

Reduce the tuning power below 100W. Prior to start tuning be sure the amplifier is bypassed (STBY). If the asterisk (*) doesn't appear anymore when you apply tuning power, check the fuses F1 & F2 on the "RF Sensor" PCB in the remote unit (see S.5-2,c).

+27V too Low

Check the line AC voltage and compare it with the nominal (see S.2-2). Check the power supply cable between the RCU and the remote unit. Check if the contacts of the connector "24VAC/3A" on the RCU rear panel are clean and if it is tight. Check if all four wires are properly tightened in the terminals J1 & J2 (see S.2-3).

RF Power too High

Reduce the tuning power below 100W. Before to start tuning be sure the amplifier is bypassed (STBY).

Stop RF ...

Always stop transmitting and bypass the amplifier BEFORE tuning with the **AUTO TUNE** button. If you use an ACOM2000A amplifier, connect the serial control cable from RCU rear panel "COM2" to the amplifier's rear panel connector "RS232 INTERFACE" – the amplifier will automatically go to STBY (see S.2-4,f).

Temperature too high

Reduce the power fed to the AATU, stop transmitting or switch OFF the AATU until the remote unit will get cool.

Timeout Expired

Do not delay applying RF tuning power for more than 20s after you press the **AUTO TUNE** button.

Unstable RF Power

Do not interrupt the RF power during a tuning procedure until the AATU prompts with "Stop RF ...".

No user-made repair is foreseen other than fuses replacement and eventually cable repair. In case of necessity please ask the service of your dealer or the producer directly for a competent help – see S.1-2.

6. SPECIFICATIONS

6-1. PARAMETERS

- a) Frequency coverage: 1.8 - 16MHz continuously; extensions and/or changes on request.
- b) Maximum RF input power, PEP or CW, RTTY, FM, digital etc (no mode limit), 100% duty cycle:
- at antenna SWR up to 3:1 - 2500W;
up to 5:1 - 1600W;
up to 10:1 - 1000W;
up to 20:1 - 500W;
up to 50:1 - 200W;
above 50:1 - 100W.
- c) Efficiency:
- at antenna SWR up to 3:1 - 97%;
up to 5:1 - 95%;
up to 10:1 - 92%;
up to 20:1 - 85%;
up to 50:1 - 60%.

d) RF Input features:

- nominal input impedance: 50Ω unbalanced, connector type UHF/PTFE (SO239A);
- input SWR during **AUTO TUNE** procedure: 1.7:1 max;
- input SWR during OPERATE (matched): 1.5:1 max (1.2:1 typical)

e) Matching capability (minimum antenna-impedance range, SWR in respect to the nominal load impedance 200Ω balanced):

- 1.8 - 16MHz: SWR ≤ 10:1 (20Ω - 2kΩ)
- 3.0 - 14MHz: SWR up to 20:1 (10Ω - 4kΩ)
- 6.5 - 12MHz: SWR up to 50:1 (4Ω - 10kΩ)

Note: the option “Unbalanced Output” fitted to a 50Ω, type UHF/PTFE (SO239A) connector.

f) Outputs unbalance:

- below 5% @ SWR = 1:1 (in 2x100Ω balanced plus 200Ω center-to-ground loads);
- below 10% @ SWR ≤ 5:1 (in 2x510Ω balanced plus 1kΩ center-to-ground, as well as in 2x20Ω balanced plus 39Ω center-to-ground loads).

g) Matching time:

- 1.8-5MHz: ≤ 8s (2-4s typical);
- 5-16MHz: ≤ 4s (1-2s typical).

h) Power supply:

- RCU: 230V, +10% / -25% (172-253V), 50-60Hz, 80VA;
- Remote unit: fed by RCU output “24VAC/3A”.

i) Size & weight (operating):

- Remote unit: W 330mm (13”) x D 215mm (8.5”) x H 305mm (12”); 12kg (26.5 lb.)
- RCU: W 175mm (6.9”) x D 255mm (10”) x H 77mm (3”); 2.5kg (5.5 lb.)

j) Operating environments:

- Remote unit:
 - IP Protection Class: IP 53 (NEMA Type 3);
 - temperature range: -40 to +65 degs.Celsius; (-40... 150F);
 - relative humidity: up to 98% @ +40 degs.Celsius; (104F);
 - height: up to 3000m above sea level without output deterioration.
- RCU:
 - temperature range: 0 to +50 degs.Celsius; (23... 122F);
 - relative humidity: up to 95% @ +35 degs.Celsius; (95F).

6-2. FUNCTIONS

a) Antenna Impedance Matching Process: automated.

b) BYPASS Mode – excludes inductors and capacitors effect for broadband operation.

c) Options:

- unbalanced output fitted to a 50Ω, type UHF/PTFE (SO239A) connector;
- control to ACOM2000A automatic HF linear amplifier and ACOM2000S automatic antenna selector;

- PC control via serial ports RS232 or RS422;

d) Protections against:

- Remote-unit relays under-voltage;
- Remote-unit overheating;
- Excessive antenna voltage;
- Remote-unit relays “hot” switching;
- Excessive RF power during tuning;
- Atmospheric electricity via sphere spark gaps and a bleeder choke.

e) RCU for a distance up to 50m (164 feet) via optic link.

f) Resource-estimate function (STATUS) giving the percentage of inductors and capacitors involved to achieve a match. This offers a possibility for monitoring the condition of the RF path, thus to forewarn possible problems.

g) Input SWR Check function.

h) Nonvolatile memory for 99 different user’s tuning settings and selection of the power-on default.

6-3. STORAGE AND SHIPMENT

CAUTION

Should you need to transport the AATU, use the original packing as described below.

First pull the mains plug out of the mains outlet, afterwards disconnect all cables from the rear panel of the RCU (remove the ground connection last). Then remove the top cover of the RCU (use a Philips 2 screwdriver) and disconnect the optic cable via loosening both optic-device knurled plastic nuts (of the split sockets) and the strain relief on the rear panel.

Now uninstall the remote unit, observing the requirements of S.2-3 but in reverse order. At last, pack the RCU, remote unit, installation accessories and cables in their original cartons and put the smaller cartons in the bigger one.

a) Storage environments:

- temperature range: -40 to +70 degs.Celsius; (-40...158F)
- relative humidity: up to 75% @ +35 degs.Celsius; (95F)

b) Shipping Size and Weight:

- W 600mm (24”) x D 420mm (16.5”) x H 430mm (17”), 23kg (50.7 lb.)

c) Shipping environments: all types of transportation, including aircraft baggage section up to 12000 meters above sea level.