

## GROUP TAB LOCATOR

|            |  |  |
|------------|--|--|
| IN         | Introduction                           |  |
| <b>INa</b> | <b>Introduction</b>                    |  |
| 0          | Lubrication and Maintenance            |  |
| 2          | Suspension                             |  |
| 3          | Differential and Driveline             |  |
| 5          | Brakes                                 |  |
| 6          | Clutch                                 |  |
| 7          | Cooling System                         |  |
| 8A         | Battery                                |  |
| 8B         | Starting Systems                       |  |
| 8C         | Charging System                        |  |
| 8D         | Ignition System                        |  |
| 8E         | Instrument Panel Systems               |  |
| <b>8Ea</b> | <b>Instrument Panel Systems</b>        |  |
| 8F         | Audio Systems                          |  |
| 8G         | Horn Systems                           |  |
| 8H         | Speed Control System                   |  |
| 8J         | Turn Signal and Hazard Warning Systems |  |
| 8K         | Wiper and Washer Systems               |  |
| 8L         | Lamps                                  |  |
| <b>8La</b> | <b>Lamps</b>                           |  |

|            |                                 |  |
|------------|---------------------------------|--|
| 8M         | Passive Restraint Systems       |  |
| 8N         | Electrically Heated System      |  |
| 8O         | Power Distribution System       |  |
| 8Q         | Vehicle Theft/Security Systems  |  |
| 8U         | Chime/Buzzer Warning Systems    |  |
| 8W         | Wiring Diagrams                 |  |
| 9          | Engine                          |  |
| 11         | Exhaust System                  |  |
| 13         | Frame and Bumpers               |  |
| <b>13a</b> | <b>Frame and Bumpers</b>        |  |
| 14         | Fuel System                     |  |
| <b>14a</b> | <b>Fuel System</b>              |  |
| 19         | Steering                        |  |
| 21         | Transmission and Transfer Case  |  |
| 22         | Tires and Wheels                |  |
| 23         | Body                            |  |
| 24         | Heating and Air Conditioning    |  |
| 25         | Emission Control Systems        |  |
| <b>25a</b> | <b>Emission Control Systems</b> |  |
|            | Service Manual Comment Forms    |  |

# INTRODUCTION

## TABLE OF CONTENTS

|  | page |                                 | page |
|--|------|---------------------------------|------|
| <b>DESCRIPTION AND OPERATION</b>             |      | <b>FASTENER USAGE</b> . . . . . | 6    |
| VEHICLE IDENTIFICATION NUMBER . . . . .      | 1    | THREADED HOLE REPAIR . . . . .  | 6    |
| VEHICLE SAFETY CERTIFICATION LABEL . . . . . | 2    | METRIC SYSTEM . . . . .         | 6    |
| INTERNATIONAL SYMBOLS . . . . .              | 3    | TORQUE REFERENCES . . . . .     | 6    |
| FASTENER IDENTIFICATION . . . . .            | 3    |                                 |      |

## DESCRIPTION AND OPERATION

### VEHICLE IDENTIFICATION NUMBER

The Vehicle Identification Number (VIN) plate is located on the lower windshield fence near the left A-pillar. The VIN contains 17 characters that provide data concerning the vehicle. Refer to the VIN decoding chart to determine the identification of a vehicle.

The Vehicle Identification Number is also imprinted on the:

- Vehicle Safety Certification Label.
- Frame rail.

To protect the consumer from theft and possible fraud the manufacturer is required to include a Check Digit at the ninth position of the Vehicle Identification Number. The check digit is used by the manufacturer and government agencies to verify the authenticity of the vehicle and official documentation. The formula to use the check digit is not released to the general public.

### VEHICLE IDENTIFICATION NUMBER DECODING CHART

| POSITION   | INTERPRETATION              | CODE = DESCRIPTION                                       |
|------------|-----------------------------|--|
| 1          | Country of Origin           | 1 = United States  |
| 2          | Make                        | J = Jeep   |
| 3          | Vehicle Type                | 4 = MPV  |
| 4          | Gross Vehicle Weight Rating | E = 3001-4000 lbs.<br>F = 4001-5000 lbs.                 |
| 5          | Vehicle Line                | Y = Wrangler 4X4   |
| 6          | Series                      | 1 = Sport<br>2 = SE<br>4 = Sahara                        |
| 7          | Body Style                  | 9 = Open Body  |
| 8          | Engine                      | P = 2.5L Unleaded-Gasoline<br>S = 4.0L Unleaded-Gasoline |
| 9          | Check Digit                 |  |
| 10         | Model Year                  | Y=2000   |
| 11         | Assembly Plant              | P = Toledo #2  |
| 12 thru 17 | Vehicle Build Sequence      |  |

DESCRIPTION AND OPERATION (Continued)

**MFD BY: CHRYSLER CORPORATION**  
 DATE OF MFR: 1-96 GAWR: 1978 KG 4380 LB  
 GAWR FRONT: 0998 KG 2200 LB WITH P205/75R15 TIRES  
 15 X 8.0 RIMS AT 244 KPA (33 PS1) COLD  
 GAWR REAR: 1180 KG 2600 LB WITH P205/75R15 TIRES  
 15 X 8.0 RIMS AT 244 KPA (33 PS1) COLD



THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE.

VIN:XXXXXXXXXXXXXXXXX TYPE: MPV MDH:013012 315  
 VEHICLE MADE IN U.S.A. PAINT: PR4 TRIM: J6C3 4648508

80a53b5e

*Fig. 1 Vehicle Safety Certification Label—Typical*

**VEHICLE SAFETY CERTIFICATION LABEL**

A vehicle safety certification label (Fig. 1) is attached to every DaimlerChrysler Corporation vehicle. The label certifies that the vehicle conforms to all applicable Federal Motor Vehicle Safety Standards. The label also lists:

- Month and year of vehicle manufacture.
- Gross Vehicle Weight Rating (GVWR). The gross front and rear axle weight ratings (GAWR's) are based on a minimum rim size and maximum cold tire inflation pressure.

- Vehicle Identification Number (VIN).
- Type of vehicle.
- Bar code.
- Month, Day and Hour (MDH) of final assembly.
- Paint and Trim codes.
- Country of origin.

The label is located above the door hinge on the driver-side A-pillar.

DESCRIPTION AND OPERATION (Continued)

|   |   |   |   |   |   |
|---|---|---|---|---|---|
| <br>1  | <br>2  | <br>3  | <br>4  | <br>5  | <br>6  |
| <br>7  | <br>8  | <br>9  | <br>10 | <br>11 | <br>12 |
| <br>13 | <br>14 | <br>15 | <br>16 | <br>17 | <br>18 |
| <br>19 | <br>20 | <br>21 | <br>22 | <br>23 | <br>24 |

80be4788

|    |                                      |    |                            |
|----|--------------------------------------|----|----------------------------|
| 1  | High Beam                            | 13 | Rear Window Washer         |
| 2  | Fog Lamps                            | 14 | Fuel                       |
| 3  | Headlamp, Parking Lamps, Panel Lamps | 15 | Engine Coolant Temperature |
| 4  | Turn Warning                         | 16 | Battery Charging Condition |
| 5  | Hazard Warning                       | 17 | Engine Oil                 |
| 6  | Windshield Washer                    | 18 | Seat Belt                  |
| 7  | Windshield Wiper                     | 19 | Brake Failure              |
| 8  | Windshield Wiper and Washer          | 20 | Parking Brake              |
| 9  | Windscreen Demisting and Defrosting  | 21 | Front Hood                 |
| 10 | Ventilating Fan                      | 22 | Rear hood (Decklid)        |
| 11 | Rear Window Defogger                 | 23 | Horn                       |
| 12 | Rear Window Wiper                    | 24 | Lighter                    |

**INTERNATIONAL SYMBOLS**

**DESCRIPTION**

The graphic symbols illustrated in the following International Control and Display Symbols Chart are used to identify various instrument controls. The symbols correspond to the controls and displays that are located on the instrument panel.

**FASTENER IDENTIFICATION**

**DESCRIPTION**

**GRADE/CLASS IDENTIFICATION**

The SAE bolt strength grades range from grade 2 to grade 8. The higher the grade number, the greater the bolt strength. Identification is determined by the line marks on the top of each bolt head. The actual

bolt strength grade corresponds to the number of line marks plus 2. The most commonly used metric bolt strength classes are 9.8 and 10.9. The metric strength class identification number is imprinted on the head of the bolt. The higher the class number, the greater the bolt strength. Some metric nuts are imprinted with a single-digit strength class on the nut face. Refer to the Fastener Identification and Fastener Strength Charts.

DESCRIPTION AND OPERATION (Continued)

FASTENER IDENTIFICATION

**Bolt Markings and Torque - Metric**


Commercial Steel Class

9.8

10.9

12.9

Bolt Head Markings



| Body Size | Torque    |     |          |     |       | Torque    |       |          |       |     | Torque    |     |          |  |  |
|-----------|-----------|-----|----------|-----|-------|-----------|-------|----------|-------|-----|-----------|-----|----------|--|--|
|           | Cast Iron |     | Aluminum |     |       | Cast Iron |       | Aluminum |       |     | Cast Iron |     | Aluminum |  |  |
|           | Diam.     | N•m | ft-lb    | N•m | ft-lb | N•m       | ft-lb | N•m      | ft-lb | N•m | ft-lb     | N•m | ft-lb    |  |  |
| 6         | 9         | 5   | 7        | 4   | 14    | 9         | 11    | 7        | 14    | 9   | 11        | 7   |          |  |  |
| 7         | 14        | 9   | 11       | 7   | 18    | 14        | 14    | 11       | 23    | 18  | 18        | 14  |          |  |  |
| 8         | 25        | 18  | 18       | 14  | 32    | 23        | 25    | 18       | 36    | 27  | 28        | 21  |          |  |  |
| 10        | 40        | 30  | 30       | 25  | 60    | 45        | 45    | 35       | 70    | 50  | 55        | 40  |          |  |  |
| 12        | 70        | 55  | 55       | 40  | 105   | 75        | 80    | 60       | 125   | 95  | 100       | 75  |          |  |  |
| 14        | 115       | 85  | 90       | 65  | 160   | 120       | 125   | 95       | 195   | 145 | 150       | 110 |          |  |  |
| 16        | 180       | 130 | 140      | 100 | 240   | 175       | 190   | 135      | 290   | 210 | 220       | 165 |          |  |  |
| 18        | 230       | 170 | 180      | 135 | 320   | 240       | 250   | 185      | 400   | 290 | 310       | 230 |          |  |  |

**Bolt Markings and Torque Values - U.S. Customary**



SAE Grade Number

5

8

Bolt Head Markings

These are all SAE Grade 5 (3) line



Bolt Torque - Grade 5 Bolt



Bolt Torque - Grade 8 Bolt

| Body Size | Cast Iron |       | Aluminum |       | Cast Iron |       | Aluminum |       |
|-----------|-----------|-------|----------|-------|-----------|-------|----------|-------|
|           | N•m       | ft-lb | N•m      | ft-lb | N•m       | ft-lb | N•m      | ft-lb |
| 1/4 - 20  | 9         | 7     | 8        | 6     | 15        | 11    | 12       | 9     |
| - 28      | 12        | 9     | 9        | 7     | 18        | 13    | 14       | 10    |
| 5/16 - 18 | 20        | 15    | 16       | 12    | 30        | 22    | 24       | 18    |
| - 24      | 23        | 17    | 19       | 14    | 33        | 24    | 25       | 19    |
| 3/8 - 16  | 40        | 30    | 25       | 20    | 55        | 40    | 40       | 30    |
| - 24      | 40        | 30    | 35       | 25    | 60        | 45    | 45       | 35    |
| 7/16 - 14 | 60        | 45    | 45       | 35    | 90        | 65    | 65       | 50    |
| - 20      | 65        | 50    | 55       | 40    | 95        | 70    | 75       | 55    |
| 1/2 - 13  | 95        | 70    | 75       | 55    | 130       | 95    | 100      | 75    |
| - 20      | 100       | 75    | 80       | 60    | 150       | 110   | 120      | 90    |
| 9/16 - 12 | 135       | 100   | 110      | 80    | 190       | 140   | 150      | 110   |
| - 18      | 150       | 110   | 115      | 85    | 210       | 155   | 170      | 125   |
| 5/8 - 11  | 180       | 135   | 150      | 110   | 255       | 190   | 205      | 150   |
| - 18      | 210       | 155   | 160      | 120   | 290       | 215   | 230      | 170   |
| 3/4 - 10  | 325       | 240   | 255      | 190   | 460       | 340   | 365      | 270   |
| - 16      | 365       | 270   | 285      | 210   | 515       | 380   | 410      | 300   |
| 7/8 - 9   | 490       | 360   | 380      | 280   | 745       | 550   | 600      | 440   |
| - 14      | 530       | 390   | 420      | 310   | 825       | 610   | 660      | 490   |
| 1 - 8     | 720       | 530   | 570      | 420   | 1100      | 820   | 890      | 660   |
| - 14      | 800       | 590   | 650      | 480   | 1200      | 890   | 960      | 710   |

DESCRIPTION AND OPERATION (Continued)

FASTENER STRENGTH

HOW TO DETERMINE BOLT STRENGTH

|  | Mark  | Class |   | Mark   | Class |
|--|---|-------|---|--|-------|
| Hexagon head bolt                            |  <p>Bolt head No.</p> <p>4 — 4T<br/>5 — 5T<br/>6 — 6T<br/>7 — 7T<br/>8 — 8T<br/>9 — 9T<br/>10 — 10T<br/>11 — 11T</p> |       | Stud bolt   |  <p>No mark</p>   | 4T    |
|  |  <p>No mark</p>  | 4T    |   |  |       |
| Hexagon flange bolt<br>w/washer hexagon bolt |  <p>No mark</p>   | 4T    | Welded bolt   |  <p>Grooved</p> | 6T    |
| Hexagon head bolt                            |  <p>Two protruding lines</p>   | 5T    |   |  |       |
| Hexagon flange bolt<br>w/washer hexagon bolt |  <p>Two protruding lines</p>   | 6T    |  | 4T   |       |
| Hexagon head bolt                            |  <p>Three protruding lines</p>   | 7T    |   |  |       |
| Hexagon head bolt                            |  <p>Four protruding lines</p>  | 8T    |   |  |       |

## DESCRIPTION AND OPERATION (Continued)

## FASTENER USAGE

**WARNING: USE OF AN INCORRECT FASTENER MAY RESULT IN COMPONENT DAMAGE OR PERSONAL INJURY.**

Figure art, specifications and torque references in this Service Manual are identified in metric and SAE format.

During any maintenance or repair procedures, it is important to salvage all fasteners (nuts, bolts, etc.) for reassembly. If the fastener is not salvageable, a fastener of equivalent specification must be used.

## THREADED HOLE REPAIR

Most stripped threaded holes can be repaired using a Helicoil®. Follow the manufactures recommendations for application and repair procedures.

## METRIC SYSTEM

The metric system is based on quantities of one, ten, one hundred, one thousand and one million (Fig. 2).

|       |                  |       |                |
|-------|------------------|-------|----------------|
| Mega  | - (M) Million    | Deci  | - (D) Tenth    |
| Kilo  | - (K) Thousand   | Centi | - (C) Hundreth |
| Milli | - (m) Thousandth |       |                |

**Fig. 2 Metric Prefixes**

The following chart will assist in converting metric units to equivalent English and SAE units, or vise versa.

Refer to the Conversion Chart to convert torque values listed in metric Newton- meters (N·m). Also, use the chart to convert between millimeters (mm) and inches (in.)

## TORQUE REFERENCES

## DESCRIPTION

Individual Torque Charts appear at the end of many Groups. Refer to the Standard Torque Specifications Chart for torque references not listed in the individual torque charts.

## CONVERSION FORMULAS AND EQUIVALENT VALUES

| Multiply                         | By               | To Get                  | Multiply     | By                     | To Get           |
|----------------------------------|------------------|-------------------------|--------------|------------------------|------------------|
| in-lbs                           | x 0.11298        | = Newton-Meters (N·m)   | N·m          | x 8.851                | = in-lbs         |
| ft-lbs                           | x 1.3558         | = Newton-Meters (N·m)   | N·m          | x 0.7376               | = ft-lbs         |
| Inches Hg<br>(60°F)              | x 3.377          | = Kilopascals (kPa)     | kPa          | x 0.2961               | = Inches Hg      |
| psi                              | x 6.895          | = Kilopascals (kPa)     | kPa          | x 0.145                | = psi            |
| Inches                           | x 25.4           | = Millimeters (mm)      | mm           | x 0.03937              | = Inches         |
| Feet                             | x 0.3048         | = Meters (M)            | M            | x 3.281                | = Feet           |
| Yards                            | x 0.9144         | = Meters (M)            | M            | x 1.0936               | = Yards          |
| Miles                            | x 1.6093         | = Kilometers (Km)       | Km           | x 0.6214               | = Miles          |
| mph                              | x 1.6093         | = Kilometers/Hr. (Km/h) | Km/h         | x 0.6214               | = mph            |
| Feet/Sec.                        | x 0.3048         | = Meters/Sec. (M/S)     | M/S          | x 3.281                | = Feet/Sec.      |
| Kilometers/Hr.                   | x 0.27778        | = Meters/Sec. (M/S)     | M/S          | x 3.600                | = Kilometers/Hr. |
| mph                              | x 0.4470         | = Meters/Sec. (M/S)     | M/S          | x 2.237                | = mph            |
| <b>COMMON METRIC EQUIVALENTS</b> |                  |                         |              |                        |                  |
| 1 Inch                           | = 25 Millimeters |                         | 1 Cubic Inch | = 16 Cubic Centimeters |                  |
| 1 Foot                           | = 0.3 Meter      |                         | 1 Cubic Foot | = 0.03 Cubic Meter     |                  |
| 1 Yard                           | = 0.9 Meter      |                         | 1 Cubic Yard | = 0.8 Cubic Meter      |                  |
| 1 Mile                           | = 1.6 Kilometers |                         |              |                        |                  |

DESCRIPTION AND OPERATION (Continued)

METRIC CONVERSION CHART

in-lbs to N•m

N•m to in-lbs

| in-lb | N•m    | in-lb | N•m    | in-lb | N•m     | in-lb | N•m     | in-lb | N•m     | N•m | in-lb   | N•m | in-lb   | N•m  | in-lb    | N•m  | in-lb    | N•m  | in-lb    | N•m |
|-------|--------|-------|--------|-------|---------|-------|---------|-------|---------|-----|---------|-----|---------|------|----------|------|----------|------|----------|-----|
| 2     | .2260  | 42    | 4.7453 | 82    | 9.2646  | 122   | 13.7839 | 162   | 18.3032 | .2  | 1.7702  | 4.2 | 37.1747 | 8.2  | 72.5792  | 12.2 | 107.9837 | 16.2 | 143.3882 |     |
| 4     | .4519  | 44    | 4.9713 | 84    | 9.4906  | 124   | 14.0099 | 164   | 18.5292 | .4  | 3.5404  | 4.4 | 38.9449 | 8.4  | 74.3494  | 12.4 | 109.7539 | 16.4 | 145.1584 |     |
| 6     | .6779  | 46    | 5.1972 | 86    | 9.7165  | 126   | 14.2359 | 166   | 18.7552 | .6  | 5.3107  | 4.6 | 40.7152 | 8.6  | 76.1197  | 12.6 | 111.5242 | 16.6 | 146.9287 |     |
| 8     | .9039  | 48    | 5.4232 | 88    | 9.9425  | 128   | 14.4618 | 168   | 18.9811 | .8  | 7.0809  | 4.8 | 42.4854 | 8.8  | 77.8899  | 12.8 | 113.2944 | 16.8 | 148.6989 |     |
| 10    | 1.1298 | 50    | 5.6492 | 90    | 10.1685 | 130   | 14.6878 | 170   | 19.2071 | 1   | 8.8511  | 5   | 44.2556 | 9    | 79.6601  | 13   | 115.0646 | 17   | 150.4691 |     |
| 12    | 1.3558 | 52    | 5.8751 | 92    | 10.3944 | 132   | 14.9138 | 172   | 19.4331 | 1.2 | 10.6213 | 5.2 | 46.0258 | 9.2  | 81.4303  | 13.2 | 116.8348 | 17.2 | 152.2393 |     |
| 14    | 1.5818 | 54    | 6.1011 | 94    | 10.6204 | 134   | 15.1397 | 174   | 19.6590 | 1.4 | 12.3916 | 5.4 | 47.7961 | 9.4  | 83.2006  | 13.4 | 118.6051 | 17.4 | 154.0096 |     |
| 16    | 1.8077 | 56    | 6.3270 | 96    | 10.8464 | 136   | 15.3657 | 176   | 19.8850 | 1.6 | 14.1618 | 5.6 | 49.5663 | 9.6  | 84.9708  | 13.6 | 120.3753 | 17.6 | 155.7798 |     |
| 18    | 2.0337 | 58    | 6.5530 | 98    | 11.0723 | 138   | 15.5917 | 178   | 20.1110 | 1.8 | 15.9320 | 5.8 | 51.3365 | 9.8  | 86.7410  | 13.8 | 122.1455 | 17.8 | 157.5500 |     |
| 20    | 2.2597 | 60    | 6.7790 | 100   | 11.2983 | 140   | 15.8176 | 180   | 20.3369 | 2   | 17.7022 | 6   | 53.1067 | 10   | 88.5112  | 14   | 123.9157 | 18   | 159.3202 |     |
| 22    | 2.4856 | 62    | 7.0049 | 102   | 11.5243 | 142   | 16.0436 | 182   | 20.5629 | 2.2 | 19.4725 | 6.2 | 54.8770 | 10.2 | 90.2815  | 14.2 | 125.6860 | 18.5 | 163.7458 |     |
| 24    | 2.7116 | 64    | 7.2309 | 104   | 11.7502 | 144   | 16.2696 | 184   | 20.7889 | 2.4 | 21.2427 | 6.4 | 56.6472 | 10.4 | 92.0517  | 14.4 | 127.4562 | 19   | 168.1714 |     |
| 26    | 2.9376 | 66    | 7.4569 | 106   | 11.9762 | 146   | 16.4955 | 186   | 21.0148 | 2.6 | 23.0129 | 6.6 | 58.4174 | 10.6 | 93.8219  | 14.6 | 129.2264 | 19.5 | 172.5970 |     |
| 28    | 3.1635 | 68    | 7.6828 | 108   | 12.2022 | 148   | 16.7215 | 188   | 21.2408 | 2.8 | 24.7831 | 6.8 | 60.1876 | 10.8 | 95.5921  | 14.8 | 130.9966 | 20   | 177.0225 |     |
| 30    | 3.3895 | 70    | 7.9088 | 110   | 12.4281 | 150   | 16.9475 | 190   | 21.4668 | 3   | 26.5534 | 7   | 61.9579 | 11   | 97.3624  | 15   | 132.7669 | 20.5 | 181.4480 |     |
| 32    | 3.6155 | 72    | 8.1348 | 112   | 12.6541 | 152   | 17.1734 | 192   | 21.6927 | 3.2 | 28.3236 | 7.2 | 63.7281 | 11.2 | 99.1326  | 15.2 | 134.5371 | 21   | 185.8736 |     |
| 34    | 3.8414 | 74    | 8.3607 | 114   | 12.8801 | 154   | 17.3994 | 194   | 21.9187 | 3.4 | 30.0938 | 7.4 | 65.4983 | 11.4 | 100.9028 | 15.4 | 136.3073 | 22   | 194.7247 |     |
| 36    | 4.0674 | 76    | 8.5867 | 116   | 13.1060 | 156   | 17.6253 | 196   | 22.1447 | 3.6 | 31.8640 | 7.6 | 67.2685 | 11.6 | 102.6730 | 15.6 | 138.0775 | 23   | 203.5759 |     |
| 38    | 4.2934 | 78    | 8.8127 | 118   | 13.3320 | 158   | 17.8513 | 198   | 22.3706 | 3.8 | 33.6342 | 7.8 | 69.0388 | 11.8 | 104.4433 | 15.8 | 139.8478 | 24   | 212.4270 |     |
| 40    | 4.5193 | 80    | 9.0386 | 120   | 13.5580 | 160   | 18.0773 | 200   | 22.5966 | 4   | 35.4045 | 8   | 70.8090 | 12   | 106.2135 | 16   | 141.6180 | 25   | 221.2781 |     |

ft-lbs to N•m

N•m to ft-lbs

| ft-lb | N•m     | ft-lb | N•m     | ft-lb | N•m     | ft-lb | N•m      | ft-lb | N•m      | N•m | ft-lb   | N•m |
|-------|---------|-------|---------|-------|---------|-------|----------|-------|----------|-----|---------|-----|---------|-----|---------|-----|---------|-----|---------|-----|
| 1     | 1.3558  | 21    | 28.4722 | 41    | 55.5885 | 61    | 82.7049  | 81    | 109.8212 | 1   | .7376   | 21  | 15.9888 | 41  | 30.2400 | 61  | 44.9913 | 81  | 59.7425 |     |
| 2     | 2.7116  | 22    | 29.8280 | 42    | 56.9444 | 62    | 84.0607  | 82    | 111.1770 | 2   | 1.4751  | 22  | 16.2264 | 42  | 30.9776 | 62  | 45.7289 | 82  | 60.4801 |     |
| 3     | 4.0675  | 23    | 31.1838 | 43    | 58.3002 | 63    | 85.4165  | 83    | 112.5328 | 3   | 2.2127  | 23  | 16.9639 | 43  | 31.7152 | 63  | 46.4664 | 83  | 61.2177 |     |
| 4     | 5.4233  | 24    | 32.5396 | 44    | 59.6560 | 64    | 86.7723  | 84    | 113.8886 | 4   | 2.9502  | 24  | 17.7015 | 44  | 32.4527 | 64  | 47.2040 | 84  | 61.9552 |     |
| 5     | 6.7791  | 25    | 33.8954 | 45    | 61.0118 | 65    | 88.1281  | 85    | 115.2445 | 5   | 3.6878  | 25  | 18.4391 | 45  | 33.1903 | 65  | 47.9415 | 85  | 62.6928 |     |
| 6     | 8.1349  | 26    | 35.2513 | 46    | 62.3676 | 66    | 89.4840  | 86    | 116.6004 | 6   | 4.4254  | 26  | 19.1766 | 46  | 33.9279 | 66  | 48.6791 | 86  | 63.4303 |     |
| 7     | 9.4907  | 27    | 36.6071 | 47    | 63.7234 | 67    | 90.8398  | 87    | 117.9562 | 7   | 5.1629  | 27  | 19.9142 | 47  | 34.6654 | 67  | 49.4167 | 87  | 64.1679 |     |
| 8     | 10.8465 | 28    | 37.9629 | 48    | 65.0793 | 68    | 92.1956  | 88    | 119.3120 | 8   | 5.9005  | 28  | 20.6517 | 48  | 35.4030 | 68  | 50.1542 | 88  | 64.9545 |     |
| 9     | 12.2024 | 29    | 39.3187 | 49    | 66.4351 | 69    | 93.5514  | 89    | 120.6678 | 9   | 6.6381  | 29  | 21.3893 | 49  | 36.1405 | 69  | 50.8918 | 89  | 65.6430 |     |
| 10    | 13.5582 | 30    | 40.6745 | 50    | 67.7909 | 70    | 94.9073  | 90    | 122.0236 | 10  | 7.3756  | 30  | 22.1269 | 50  | 36.8781 | 70  | 51.6293 | 90  | 66.3806 |     |
| 11    | 14.9140 | 31    | 42.0304 | 51    | 69.1467 | 71    | 96.2631  | 91    | 123.3794 | 11  | 8.1132  | 31  | 22.8644 | 51  | 37.6157 | 71  | 52.3669 | 91  | 67.1181 |     |
| 12    | 16.2698 | 32    | 43.3862 | 52    | 70.5025 | 72    | 97.6189  | 92    | 124.7352 | 12  | 8.8507  | 32  | 23.6020 | 52  | 38.3532 | 72  | 53.1045 | 92  | 67.8557 |     |
| 13    | 17.6256 | 33    | 44.7420 | 53    | 71.8583 | 73    | 98.9747  | 93    | 126.0910 | 13  | 9.5883  | 33  | 24.3395 | 53  | 39.0908 | 73  | 53.8420 | 93  | 68.5933 |     |
| 14    | 18.9815 | 34    | 46.0978 | 54    | 73.2142 | 74    | 100.3316 | 94    | 127.4468 | 14  | 10.3259 | 34  | 25.0771 | 54  | 39.8284 | 74  | 54.5720 | 94  | 69.3308 |     |
| 15    | 20.3373 | 35    | 47.4536 | 55    | 74.5700 | 75    | 101.6862 | 95    | 128.8026 | 15  | 11.0634 | 35  | 25.8147 | 55  | 40.5659 | 75  | 55.3172 | 95  | 70.0684 |     |
| 16    | 21.6931 | 36    | 48.8094 | 56    | 75.9258 | 76    | 103.0422 | 96    | 130.1586 | 16  | 11.8010 | 36  | 26.5522 | 56  | 41.3035 | 76  | 56.0547 | 96  | 70.8060 |     |
| 17    | 23.0489 | 37    | 50.1653 | 57    | 77.2816 | 77    | 104.3980 | 97    | 131.5144 | 17  | 12.5386 | 37  | 27.2898 | 57  | 42.0410 | 77  | 56.7923 | 97  | 71.5435 |     |
| 18    | 24.4047 | 38    | 51.5211 | 58    | 78.6374 | 78    | 105.7538 | 98    | 132.8702 | 18  | 13.2761 | 38  | 28.0274 | 58  | 42.7786 | 78  | 57.5298 | 98  | 72.2811 |     |
| 19    | 25.7605 | 39    | 52.8769 | 59    | 79.9933 | 79    | 107.1196 | 99    | 134.2260 | 19  | 14.0137 | 39  | 28.7649 | 59  | 43.5162 | 79  | 58.2674 | 99  | 73.0187 |     |
| 20    | 27.1164 | 40    | 54.2327 | 60    | 81.3491 | 80    | 108.4654 | 100   | 135.5820 | 20  | 14.7512 | 40  | 29.5025 | 60  | 44.2537 | 80  | 59.0050 | 100 | 73.7562 |     |

in. to mm

mm to in.

| in. | mm    | in. | mm     | in. | mm     | in. | mm     | in. | mm     | mm  | in.    | mm |
|-----|-------|-----|--------|-----|--------|-----|--------|-----|--------|-----|--------|-----|--------|-----|--------|-----|--------|-----|--------|----|
| .01 | .254  | .21 | 5.334  | .41 | 10.414 | .61 | 15.494 | .81 | 20.574 | .01 | .00039 | .21 | .00827 | .41 | .01614 | .61 | .02402 | .81 | .03189 |    |
| .02 | .508  | .22 | 5.588  | .42 | 10.668 | .62 | 15.748 | .82 | 20.828 | .02 | .00079 | .22 | .00866 | .42 | .01654 | .62 | .02441 | .82 | .03228 |    |
| .03 | .762  | .23 | 5.842  | .43 | 10.922 | .63 | 16.002 | .83 | 21.082 | .03 | .00118 | .23 | .00906 | .43 | .01693 | .63 | .02480 | .83 | .03268 |    |
| .04 | 1.016 | .24 | 6.096  | .44 | 11.176 | .64 | 16.256 | .84 | 21.336 | .04 | .00157 | .24 | .00945 | .44 | .01732 | .64 | .02520 | .84 | .03307 |    |
| .05 | 1.270 | .25 | 6.350  | .45 | 11.430 | .65 | 16.510 | .85 | 21.590 | .05 | .00197 | .25 | .00984 | .45 | .01772 | .65 | .02559 | .85 | .03346 |    |
| .06 | 1.524 | .26 | 6.604  | .46 | 11.684 | .66 | 16.764 | .86 | 21.844 | .06 | .00236 | .26 | .01024 | .46 | .01811 | .66 | .02598 | .86 | .03386 |    |
| .07 | 1.778 | .27 | 6.858  | .47 | 11.938 | .67 | 17.018 | .87 | 22.098 | .07 | .00276 | .27 | .01063 | .47 | .01850 | .67 | .02638 | .87 | .03425 |    |
| .08 | 2.032 | .28 | 7.112  | .48 | 12.192 | .68 | 17.272 | .88 | 22.352 | .08 | .00315 | .28 | .01102 | .48 | .01889 | .68 | .02677 | .88 | .03465 |    |
| .09 | 2.286 | .29 | 7.366  | .49 | 12.446 | .69 | 17.526 | .89 | 22.606 | .09 | .00354 | .29 | .01142 | .49 | .01929 | .69 | .02717 | .89 | .03504 |    |
| .10 | 2.540 | .30 | 7.620  | .50 | 12.700 | .70 | 17.780 | .90 | 22.860 | .10 | .00394 | .30 | .01181 | .50 | .01969 | .70 | .02756 | .90 | .03543 |    |
| .11 | 2.794 | .31 | 7.874  | .51 | 12.954 | .71 | 18.034 | .91 | 23.114 | .11 | .00433 | .31 | .01220 | .51 | .02008 | .71 | .02795 | .91 | .03583 |    |
| .12 | 3.048 | .32 | 8.128  | .52 | 13.208 | .72 | 18.288 | .92 | 23.368 | .12 | .00472 | .32 | .01260 | .52 | .02047 | .72 | .02835 | .92 | .03622 |    |
| .13 | 3.302 | .33 | 8.382  | .53 | 13.462 | .73 | 18.542 | .93 | 23.622 | .13 | .00512 | .33 | .01299 | .53 | .02087 | .73 | .02874 | .93 | .03661 |    |
| .14 | 3.556 | .34 | 8.636  | .54 | 13.716 | .74 | 18.796 | .94 | 23.876 | .14 | .00551 | .34 | .01339 | .54 | .02126 | .74 | .02913 | .94 | .03701 |    |
| .15 | 3.810 | .35 | 8.890  | .55 | 13.970 | .75 | 19.050 | .95 | 24.130 | .15 | .00591 | .35 | .01378 | .55 | .02165 | .75 | .02953 | .95 | .03740 |    |
| .16 | 4.064 | .36 | 9.144  | .56 | 14.224 | .76 | 19.304 | .96 | 24.384 | .16 | .00630 | .36 | .01417 | .56 | .02205 | .76 | .02992 | .96 | .03780 |    |
| .17 | 4.318 | .37 | 9.398  | .57 | 14.478 | .77 | 19.558 | .97 | 24.638 | .17 | .00669 | .37 | .01457 | .57 | .02244 | .77 | .03032 | .97 | .03819 |    |
| .18 | 4.572 | .38 | 9.652  | .58 | 14.732 | .78 | 19.812 | .98 | 24.892 | .18 | .00709 | .38 | .01496 | .58 | .02283 | .78 | .03071 | .98 | .03858 |    |
| .19 | 4.826 | .39 | 9.906  | .59 | 14.986 | .79 | 20.066 | .99 | 25.146 | .19 | .00748 | .39 | .01535 | .59 | .02323 | .79 | .03110 | .99 | .03898 |    |
| .20 | 5.080 | .40 | 10.160 | .60 |        |     |        |     |        |     |        |     |        |     |        |     |        |     |        |    |

## DESCRIPTION AND OPERATION (Continued)

## TORQUE SPECIFICATIONS

## SPECIFIED TORQUE FOR STANDARD BOLTS

| Class | Diameter<br>mm | Pitch<br>mm | Specified torque  |        |            |                     |        |            |
|-------|----------------|-------------|-------------------|--------|------------|---------------------|--------|------------|
|       |                |             | Hexagon head bolt |        |            | Hexagon flange bolt |        |            |
|       |                |             | N•m               | kgf-cm | ft-lbf     | N•m                 | kgf-cm | ft-lbf     |
| 4T    | 6              | 1           | 5                 | 55     | 48 in.-lbf | 6                   | 60     | 52 in.-lbf |
|       | 8              | 1.25        | 12.5              | 130    | 9          | 14                  | 145    | 10         |
|       | 10             | 1.25        | 26                | 260    | 19         | 29                  | 290    | 21         |
|       | 12             | 1.25        | 47                | 480    | 35         | 53                  | 540    | 39         |
|       | 14             | 1.5         | 74                | 760    | 55         | 84                  | 850    | 61         |
|       | 16             | 1.5         | 115               | 1,150  | 83         | —                   | —      | —          |
| 5T    | 6              | 1           | 6.5               | 65     | 56 in.-lbf | 7.5                 | 75     | 65 in.-lbf |
|       | 8              | 1.25        | 15.5              | 160    | 12         | 17.5                | 175    | 13         |
|       | 10             | 1.25        | 32                | 330    | 24         | 36                  | 360    | 26         |
|       | 12             | 1.25        | 59                | 600    | 43         | 65                  | 670    | 48         |
|       | 14             | 1.5         | 91                | 930    | 67         | 100                 | 1,050  | 76         |
|       | 16             | 1.5         | 140               | 1,400  | 101        | —                   | —      | —          |
| 6T    | 6              | 1           | 8                 | 80     | 69 in.-lbf | 9                   | 90     | 78 in.-lbf |
|       | 8              | 1.25        | 19                | 195    | 14         | 21                  | 210    | 15         |
|       | 10             | 1.25        | 39                | 400    | 29         | 44                  | 440    | 32         |
|       | 12             | 1.25        | 71                | 730    | 53         | 80                  | 810    | 59         |
|       | 14             | 1.5         | 110               | 1,100  | 80         | 125                 | 1,250  | 90         |
|       | 16             | 1.5         | 170               | 1,750  | 127        | —                   | —      | —          |
| 7T    | 6              | 1           | 10.5              | 110    | 8          | 12                  | 120    | 9          |
|       | 8              | 1.25        | 25                | 260    | 19         | 28                  | 290    | 21         |
|       | 10             | 1.25        | 52                | 530    | 38         | 58                  | 590    | 43         |
|       | 12             | 1.25        | 95                | 970    | 70         | 105                 | 1,050  | 76         |
|       | 14             | 1.5         | 145               | 1,500  | 108        | 165                 | 1,700  | 123        |
|       | 16             | 1.5         | 230               | 2,300  | 166        | —                   | —      | —          |
| 8T    | 8              | 1.25        | 29                | 300    | 22         | 33                  | 330    | 24         |
|       | 10             | 1.25        | 61                | 620    | 45         | 68                  | 690    | 50         |
|       | 12             | 1.25        | 110               | 1,100  | 80         | 120                 | 1,250  | 90         |
| 9T    | 8              | 1.25        | 34                | 340    | 25         | 37                  | 380    | 27         |
|       | 10             | 1.25        | 70                | 710    | 51         | 78                  | 790    | 57         |
|       | 12             | 1.25        | 125               | 1,300  | 94         | 140                 | 1,450  | 105        |
| 10T   | 8              | 1.25        | 38                | 390    | 28         | 42                  | 430    | 31         |
|       | 10             | 1.25        | 78                | 800    | 58         | 88                  | 890    | 64         |
|       | 12             | 1.25        | 140               | 1,450  | 105        | 155                 | 1,600  | 116        |
| 11T   | 8              | 1.25        | 42                | 430    | 31         | 47                  | 480    | 35         |
|       | 10             | 1.25        | 87                | 890    | 64         | 97                  | 990    | 72         |
|       | 12             | 1.25        | 155               | 1,600  | 116        | 175                 | 1,800  | 130        |

# INTRODUCTION

## TABLE OF CONTENTS

|  |      |  |      |
|--|------|--|------|
|  | page |  | page |
| <b>DESCRIPTION AND OPERATION</b>             |      | <b>BODY CODE PLATE</b> . . . . .         | 2    |
| VEHICLE IDENTIFICATION NUMBER . . . . .      | 1    | <b>INTERNATIONAL VEHICLE CONTROL AND</b> |      |
| VEHICLE SAFETY CERTIFICATION LABEL . . . . . | 2    | <b>DISPLAY SYMBOLS</b> . . . . .         | 4    |

## DESCRIPTION AND OPERATION

### VEHICLE IDENTIFICATION NUMBER

#### DESCRIPTION

The Vehicle Identification Number (VIN) plate is located on the lower windshield fence near the left A-pillar. The VIN contains 17 characters that provide data concerning the vehicle. Refer to the VIN decoding chart to determine the identification of a vehicle.

The Vehicle Identification Number is also imprinted on the:

- Body Code Plate.
- Vehicle Safety Certification Label.
- Frame rail.

To protect the consumer from theft and possible fraud the manufacturer is required to include a Check Digit at the ninth position of the Vehicle Identification Number. The check digit is used by the manufacturer and government agencies to verify the authenticity of the vehicle and official documentation. The formula to use the check digit is not released to the general public.

#### VEHICLE IDENTIFICATION NUMBER DECODING CHART

| POSITION   | INTERPRETATION              | CODE = DESCRIPTION  |
|------------|-----------------------------|---|
| 1          | Country of Origin           | 1 = United States   |
| 2          | Make                        | J = Jeep  |
| 3          | Vehicle Type                | 4 = MPV   |
| 4          | Gross Vehicle Weight Rating | E = 3001-4000 lbs.<br>F = 4001-5000 lbs.                                    |
| 5          | Vehicle Line                | A = Wrangler 4X4 Left Hand Drive<br>4 = Wrangler 4X4 Right Hand Drive       |
| 6          | Series/Transmission         | 4 = Sport<br>5 = Sahara<br>N = 5 SPD. Manual - DDO<br>A = 3 SPD. Auto - DGA |
| 7          | Body Style                  | 9 = Open Body   |
| 8          | Engine                      | P = 2.5L Gasoline<br>S = 4.0L Gasoline                                      |
| 9          | Check Digit                 |   |
| 10         | Model Year                  | Y = 2000  |
| 11         | Assembly Plant              | P = Toledo #2   |
| 12 thru 17 | Vehicle Build Sequence      |   |

DESCRIPTION AND OPERATION (Continued)

**MFD BY: CHRYSLER CORPORATION**

|                             |                               |
|-----------------------------|-------------------------------|
| DATE OF MFR: 1-96           | GAWR: 1978 KG 4380 LB         |
| GAWR FRONT: 0998 KG 2200 LB | WITH P205/75R15 TIRES         |
|                             | RIMS AT 244 KPA (33 PS1) COLD |
| GAWR REAR: 1180 KG 2600 LB  | WITH P205/75R15 TIRES         |
|                             | RIMS AT 244 KPA (33 PS1) COLD |
|                             | 15 X 8.0                      |



THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE.

VIN:XXXXXXXXXXXXXXXXX TYPE: MPV MDH:013012 315  
 VEHICLE MADE IN U.S.A. PAINT: PR4 TRIM: J6C3 4648508

80a53b5e

**Fig. 1 Vehicle Safety Certification Label—Typical**

**VEHICLE SAFETY CERTIFICATION LABEL**

**DESCRIPTION**

A vehicle safety certification label (Fig. 1) is attached to every Chrysler Corporation vehicle. The label certifies that the vehicle conforms to all applicable Federal Motor Vehicle Safety Standards. The label also lists:

- Month and year of vehicle manufacture.
- Gross Vehicle Weight Rating (GVWR). The gross front and rear axle weight ratings (GAWR's) are based on a minimum rim size and maximum cold tire inflation pressure.
- Vehicle Identification Number (VIN).
- Type of vehicle.
- Bar code.
- Month, Day and Hour (MDH) of final assembly.
- Paint and Trim codes.
- Country of origin.

The label is located above the door hinge on the driver-side A-pillar.


**BODY CODE PLATE**

**DESCRIPTION**

A metal body code plate is attached to the floor pan under the drivers seat (Fig. 2). Disengage the snaps attaching the carpet to the floor pan to read the information. There are seven lines of information on the body code plate. Lines 4, 5, 6, and 7 are not used to define service information. Information reads from left to right, starting with line 3 in the center of the plate to line 1 at the bottom of the plate (Fig. 3).

The last code imprinted on a vehicle code plate will be followed by the imprinted word END. When two vehicle code plates are required, the last available spaces on the first plate will be imprinted with the letters CTD (for continued).

When a second vehicle code plate is necessary, the first four spaces on each row will not be used because of the plate overlap.



80a45084

**Fig. 2 Body Code Plate Location**

- 1 - SNAP
- 2 - REAR CARPET
- 3 - BODY CODE PLATE
- 4 - SNAP
- 5 - FLOOR PAN
- 6 - FRONT CARPET

**BODY CODE PLATE—LINE 3**

**DIGITS 1 THROUGH 12**

Vehicle Order Number

**DIGITS 13, 14, AND 15**

Roof


- VJN = Soft Top White
- VJU = Soft Top Spice
- VJX = Soft Top Black
- VKN = Hard Top White
- VKU = Hard Top Spice
- VKX = Hard Top Black

**DIGITS 16, 17, AND 18**

Car Line Shell

- TJJ = Wrangler (LHD)
- TJU = Wrangler (RHD)

## DESCRIPTION AND OPERATION (Continued)



80ad847a

**Fig. 3 Body Code Plate Decoding**

- 1 - PRIMARY PAINT
- 2 - SECONDARY PAINT
- 3 - ROOF
- 4 - CAR LINE SHELL
- 5 - ENGINE
- 6 - TRIM
- 7 - VIN
- 8 - MARKET
- 9 - TRANSMISSION
- 10 - PAINT PROCEDURE
- 11 - VEHICLE ORDER NUMBER

**DIGIT 19**

Price Class

- L = Wrangler (All)

**DIGITS 20 AND 21**

Body Type

- 77 = Wheel Base (93.4 in.)

**BODY CODE PLATE—LINE 2****DIGITS 1,2, AND 3**

Paint Procedure

**DIGIT 4**

Open Space

**DIGITS 5 THROUGH 8**

Primary Paint

Refer to Group 23, Body for color codes.

**DIGIT 9**

Open Space

**DIGITS 10 THROUGH 13**

Secondary Paint

**DIGIT 14**

Open Space

**DIGITS 15 THROUGH 18**

Interior Trim Code

**DIGIT 19**

Open Space

**DIGITS 20, 21, AND 22**

Engine Code

- EPE = 2.5 L 4 cyl. MPI Gasoline
- ERH = 4.0L 6 cyl. MPI Gasoline

**BODY CODE PLATE—LINE 1****DIGITS 1, 2, AND 3**

Transmission Codes

- DDQ = AX5 5-speed Manual
- DDO = AX15 5-speed Manual
- DGD = 30RH 3-speed Automatic
- DGG = 32RH 3-speed Automatic

**DIGIT 4**

Open Space

**DIGIT 5**

Market Code

- B = International

**DIGIT 6**

Open Space

**DIGITS 7 THROUGH 23**

Vehicle Identification Number (VIN)

Refer to Vehicle Identification Number (VIN) paragraph for proper breakdown of VIN code.

DESCRIPTION AND OPERATION (Continued)

**INTERNATIONAL VEHICLE CONTROL AND DISPLAY SYMBOLS**

used to identify various instrument controls. The symbols correspond to the controls and displays that are located on the instrument panel.

**DESCRIPTION**

The graphic symbols illustrated in the following International Control and Display Symbols chart are

*INTERNATIONAL CONTROL AND DISPLAY SYMBOLS*

|   |   |   |   |   |   |
|---|---|---|---|---|---|
| <br>1    | <br>2    | <br>3    | <br>4    | <br>5    | <br>6    |
| <br>7    | <br>8    | <br>9    | <br>10   | <br>11   | <br>12   |
| <br>13   | <br>14   | <br>15   | <br>16   | <br>17   | <br>18   |
| <br>19 | <br>20 | <br>21 | <br>22 | <br>23 | <br>24 |

80bdbd36

**Fig. 4**

# LUBRICATION AND MAINTENANCE

## TABLE OF CONTENTS

|                             |      |  |      |
|-----------------------------|------|--|------|
|                             | page |  | page |
| LUBRICANTS .....            | 1    | JUMP STARTING, HOISTING AND TOWING ..... | 8    |
| MAINTENANCE SCHEDULES ..... | 3    |  |      |

## LUBRICANTS

### TABLE OF CONTENTS

|                           |      |                                   |      |
|---------------------------|------|-----------------------------------|------|
|                           | page |                                   | page |
| <b>SERVICE PROCEDURES</b> |      | INTERNATIONAL SYMBOLS .....       | 1    |
| PARTS AND LUBRICANT       |      | CLASSIFICATION OF LUBRICANTS..... | 1    |
| RECOMMENDATIONS .....     | 1    | FLUID CAPACITIES .....            | 2    |

### SERVICE PROCEDURES

### PARTS AND LUBRICANT RECOMMENDATIONS

#### RECOMMENDATIONS

When service is required, DaimlerChrysler Corporation recommends that only Mopar® brand parts, lubricants and chemicals be used. Mopar provides the best engineered products for servicing DaimlerChrysler Corporation vehicles.

#### INTERNATIONAL SYMBOLS

DaimlerChrysler Corporation uses international symbols to identify engine compartment lubricant and fluid inspection and fill locations (Fig. 1).

#### CLASSIFICATION OF LUBRICANTS

Only lubricants bearing designations defined by the following organization should be used to service a DaimlerChrysler Corporation vehicle.

- Society of Automotive Engineers (SAE)
- American Petroleum Institute (API) (Fig. 2)
- National Lubricating Grease Institute (NLGI) (Fig. 3)

#### ENGINE OIL

##### SAE VISCOSITY RATING INDICATES ENGINE OIL VISCOSITY

An SAE viscosity grade is used to specify the viscosity of engine oil. SAE 30 specifies a single viscosity engine oil. Engine oils also have multiple viscosities. These are specified with a dual SAE vis-

|                             |                              |  |                         |
|-----------------------------|------------------------------|--|-------------------------|
| <b>CHRYSLER CORPORATION</b> |                              |  |                         |
|                             | ENGINE OIL                   |  | BRAKE FLUID             |
|                             | AUTOMATIC TRANSMISSION FLUID |  | POWER STEERING FLUID    |
|                             | ENGINE COOLANT               |  | WINDSHIELD WASHER FLUID |

9500-1

**Fig. 1 International Symbols**

cosity grade which indicates the cold-to-hot temperature viscosity range.

- SAE 30 = single grade engine oil.
- SAE 10W-30 = multiple grade engine oil.

DaimlerChrysler Corporation only recommends multiple grade engine oils.

#### API QUALITY CLASSIFICATION

This symbol (Fig. 2) on the front of an oil container means that the oil has been certified by the American Petroleum Institute (API) to meet all the lubrication requirements specified by DaimlerChrysler Corporation.

Refer to Group 9, Engine for gasoline engine oil specification.

SERVICE PROCEDURES (Continued)



9400-9

Fig. 2 API Symbol

GEAR LUBRICANTS

SAE ratings also apply to multiple grade gear lubricants. In addition, API classification defines the lubricants usage.

LUBRICANTS AND GREASES

Lubricating grease is rated for quality and usage by the NLGI. All approved products have the NLGI symbol (Fig. 3) on the label. At the bottom NLGI symbol is the usage and quality identification letters. Wheel bearing lubricant is identified by the letter "G". Chassis lubricant is identified by the latter "L". The letter following the usage letter indicates the quality of the lubricant. The following symbols indicate the highest quality.



9200-7

Fig. 3 NLGI Symbol

- 1 - WHEEL BEARINGS
- 2 - CHASSIS LUBRICATION
- 3 - CHASSIS AND WHEEL BEARINGS

FLUID CAPACITIES

FUEL TANK

Standard ..... 71.9 L (19.0 gal.)

ENGINE OILW/FILTER CHANGE

2.5L ..... 3.8 L (4.0 qts.)  
 4.0L ..... 5.7 L (6.0 qts.)

COOLING SYSTEM

2.5L ..... 8.5 L (9.0 qts.)  
 4.0L ..... 9.9 L (10.5 qts.)

AUTOMATIC TRANSMISSION

Dry fill capacity\*

32RH ..... 6.31 L (13.33pts.)  
 30RH ..... 4.67 L (9.86 pts.)

\*Depending on type and size of internal cooler, length and inside diameter of cooler lines, or use of an auxiliary cooler, these figures may vary. Refer to Group 21, Transmission for proper fluid fill procedure.

MANUAL TRANSMISSION

AX5 ..... 3.3 L (3.5 qts.)  
 AX15 ..... 3.15 L (3.32 qts.)

TRANSFER CASE

COMMAND-TRAC 231 ..... 1.0 L (2.2 pts.)

FRONT AXLE

181-FBI ..... 1.2 L (2.5 pts.)

REAR AXLE

194-RBI ..... 1.66 L (3.5 pts.)\*  
 216-RBI ..... 1.89 L (4.0 pts.)\*

\* When equipped with TRAC-LOK, include 4 ounces of Friction Modifier Additive.

POWER STEERING

Power steering fluid capacities are dependent on engine/chassis options as well as steering gear/cooler options. Depending on type and size of internal cooler, length and inside diameter of cooler lines, or use of an auxiliary cooler, these capacities may vary. Refer to Section 19 of the service manual for proper fill and bleed procedures.

# MAINTENANCE SCHEDULES

## TABLE OF CONTENTS

page

### SERVICE PROCEDURES

MAINTENANCE SCHEDULES ..... 3

### SERVICE PROCEDURES

#### MAINTENANCE SCHEDULES

There are two maintenance schedules that show proper service for the vehicle.

First is Schedule "A". It lists all the scheduled maintenance to be performed under "normal" operating conditions.

Second is Schedule "B". It is a schedule for vehicles that are operated under the conditions listed at the beginning of that schedule.

Use the schedule that best describes the driving conditions.

Where time and mileage are listed, follow the interval that occurs first.

#### **At Each Stop For Fuel**

- Check engine oil level, add as required.
- Check windshield washer solvent and add if required.

#### **Once A Month**

- Check tire pressure and look for unusual wear or damage.
- Inspect battery and clean and tighten terminals as required. Check electrolyte level and add water as needed.
- Check fluid levels of coolant reservoir, power steering, brake master cylinder, and transmission and add as needed.
- Check all lights and all other electrical items for correct operation.

#### **At Each Oil Change**

- Inspect exhaust system.
- Inspect brake hoses.
- Rotate the tires at each oil change interval shown on Schedule "A" (7,500 miles) or every other interval shown on Schedule "B" (6,000 miles).
  - Check coolant level, hoses, and clamps.
  - After completion of off-road operation, the underside of the vehicle should be thoroughly inspected. Examine threaded fasteners for looseness.

#### Schedule "A"

##### **7,500 Miles (12 000 km) or at 6 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

##### **15,000 Miles (24 000 km) or at 12 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

##### **22,500 Miles (36 000 km) or at 18 months**

- Change engine oil.
- Replace engine oil filter.
- Inspect brake linings.
- Lubricate steering linkage.

##### **30,000 Miles (48 000 km) or at 24 months**

- Change engine oil.
- Replace engine oil filter.
- **Replace engine air cleaner element.**
- **Replace spark plugs.**
- Inspect drive belt, adjust tension as necessary (2.5L only).
  - Lubricate steering linkage.
  - Drain and refill transfer case fluid.
  - Lubricate steering and suspension ball joints.

##### **37,500 Miles (60 000 km) or at 30 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage (4x4 only).
- Drain and refill automatic transmission fluid, change filter, and adjust bands.

##### **45,000 Miles (72 000 km) or at 36 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Flush and replace engine coolant at 36 months, regardless of mileage.
  - Lubricate steering and suspension ball joints.

## SERVICE PROCEDURES (Continued)

**52,500 Miles (84 000 km) or at 42 months**

- Change engine oil.
- Replace engine oil filter.
- Flush and replace engine coolant if not done at 36 months.
- Lubricate steering linkage (4x4 only).

**60,000 Miles (96 000 km) or at 48 months**

- Change engine oil.
- Replace engine oil filter.
- **Replace engine air cleaner element.**
- **Replace ignition cables.**
- **Replace spark plugs.**
- Inspect drive belt, adjust tension as necessary (2.5L only).
- Inspect drive belt and replace as needed (4.0L only).
- Lubricate steering linkage.
- Drain and refill transfer case fluid.
- Lubricate steering and suspension ball joints.

**67,500 Miles (108 000 km) or at 54 months**

- Change engine oil.
- Replace engine oil filter.
- Inspect brake linings.
- Lubricate steering linkage (4x4 only).

**75,000 Miles (120 000 km) or at 60 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Flush and replace engine coolant if it has been 30,000 miles (48 000 km) or 24 months since last change.
- Lubricate steering and suspension ball joints.
- Inspect drive belt and replace as needed (4.0L only).
- Drain and refill automatic transmission fluid, change filter, and adjust bands.

**82,500 Miles (133 000 km) or at 66 months**

- Change engine oil.
- Replace engine oil filter.
- Flush and replace engine coolant if it has been 30,000 miles (48 000 km) or 24 months since last change.
- Lubricate steering linkage (4x4 only).

**90,000 Miles (144 000 km) or at 72 months**

- Change engine oil.
- Replace engine oil filter.
- **Replace engine air cleaner element.**
- **Replace spark plugs.**
- Inspect drive belt, adjust tension as necessary (2.5L only).

- Inspect drive belt and replace as needed (4.0L only).
- Lubricate steering linkage.
- Drain and refill transfer case fluid.
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**97,500 Miles (156 000 km) or at 78 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage (4x4 only).

**105,000 Miles (168 000 km) or at 84 months**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Flush and replace engine coolant if it has been 30,000 miles (48 000 km) or 24 months since last change.
- Lubricate steering and suspension ball joints.
- Inspect drive belt and replace as needed (4.0L only).

**112,500 Miles (180 000 km) or at 90 months**

- Change engine oil.
- Replace engine oil filter.
- Inspect brake linings.
- Flush and replace engine coolant if it has been 30,000 miles (48 000 km) or 24 months since last change.
- Lubricate steering linkage (4x4 only).
- Drain and refill automatic transmission fluid, change filter, and adjust bands.

**120,000 Miles (192 000 km) or at 96 months**

- Change engine oil.
  - Replace engine oil filter.
  - **Replace engine air cleaner element.**
  - **Replace ignition cables.**
  - **Replace spark plugs.**
  - Inspect drive belt, adjust tension as necessary (2.5L only).
  - Lubricate steering linkage.
  - Drain and refill transfer case fluid.
  - Inspect drive belt and replace as needed (4.0L only).
  - Lubricate steering and suspension ball joints.
- Important:** Inspection and service should also be performed any time a malfunction is observed or suspected.

**Schedule "B"**

Follow this schedule if the vehicle is operated under one or more of the following conditions:

- Frequent short trips driving less than 5 miles (8 km)
- Frequent driving in dusty conditions

## SERVICE PROCEDURES (Continued)

- Frequent trailer towing
- Extensive idling
- More than 50% of driving is at sustained high speeds during hot weather, above 90°F (32°C)
  - Off-road driving
  - Desert operation

**3,000 Miles (5 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**6,000 Miles (10 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**9,000 Miles (14 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**12,000 Miles (19 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**15,000 Miles (24 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace if necessary.**
- Lubricate steering linkage.

**18,000 Miles (29 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**21,000 Miles (34 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**24,000 Miles (38 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill front and rear axles.‡

- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**27,000 Miles (43 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**30,000 Miles (48 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace if necessary.**
- **Replace spark plugs.**
- Inspect drive belt, adjust tension as necessary (2.5L only).
- Lubricate steering linkage.
- Drain and refill transfer case fluid.
- Lubricate steering and suspension ball joints.

**33,000 Miles (53 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**36,000 Miles (58 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**39,000 Miles (62 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**42,000 Miles (67 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**45,000 Miles (72 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace if necessary.**
- Lubricate steering linkage.
- Inspect drive belt and replace as needed (4.0L only).

## SERVICE PROCEDURES (Continued)

**48,000 Miles (77 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**51,000 Miles (82 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Flush and replace engine coolant.
- Lubricate steering linkage.

**54,000 Miles (86 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**57,000 Miles (91 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**60,000 Miles (96 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace as necessary.**
- **Replace ignition cables.**
- **Replace spark plugs.**
- Inspect drive belt, adjust tension as necessary (2.5L only).
- Inspect drive belt and replace as needed (4.0L only).
- Lubricate steering linkage.
- Drain and refill transfer case fluid.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.
- Drain and refill automatic transmission fluid, change filter and adjust bands.

**63,000 Miles (101 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**66,000 Miles (106 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**69,000 Miles (110 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**72,000 Miles (115 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**75,000 Miles (120 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace as necessary.**
- Lubricate steering linkage.
- Inspect drive belt and replace as needed (4.0L only).

**78,000 Miles (125 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**81,000 Miles (134 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Flush and replace engine coolant if it has been 3,000 miles (48 000 km) since last change.
- Lubricate steering linkage.

**84,000 Miles (134 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**87,000 Miles (139 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**90,000 Miles (144 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace as necessary.**

## SERVICE PROCEDURES (Continued)

- **Replace spark plugs.**
- Inspect drive belt, adjust tension as necessary (2.5L only).
- Inspect drive belt and replace as needed (4.0L only).
- Lubricate steering linkage.
- Drain and refill transfer case fluid.
- Lubricate steering and suspension ball joints.

**93,000 Miles (149 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**96,000 Miles (154 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.
- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**99,000 Miles (158 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**102,000 Miles (163 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**105,000 Miles (168 000 km)**

- Change engine oil.
- Replace engine oil filter.
- **Inspect engine air cleaner element, replace as necessary.**
- Lubricate steering linkage.
- Inspect drive belt and replace as needed (4.0L only).

**108,000 Miles (173 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Drain and refill automatic transmission fluid, change filter and adjust bands.

- Drain and refill front and rear axles.‡
- Inspect brake linings.
- Lubricate steering and suspension ball joints.

**111,000 Miles (178 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Flush and replace engine coolant if it has been 3,000 miles (48 000 km) since last change.
- Lubricate steering linkage.

**114,000 Miles (182 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.
- Lubricate steering and suspension ball joints.

**117,000 Miles (187 000 km)**

- Change engine oil.
- Replace engine oil filter.
- Lubricate steering linkage.

**120,000 Miles (192 000 km)**

- Change engine oil.
  - Replace engine oil filter.
  - **Inspect engine air cleaner element, replace as necessary.**
  - **Replace ignition cables.**
  - **Replace spark plugs.**
  - Inspect drive belt, adjust tension as necessary (2.5L only).
  - Inspect drive belt and replace as needed (4.0L only).
  - Lubricate steering linkage.
  - Drain and refill automatic transmission fluid, change filter and adjust bands.
  - Drain and refill transfer case fluid.
  - Drain and refill front and rear axles.‡
  - Inspect brake linings.
  - Lubricate steering and suspension ball joints.
- ‡Off-highway operation, trailer towing, taxi, limousine, bus, snow plowing, or other types of commercial service or prolonged operation with heavy loading, especially in hot weather, require front and rear axle service indicated with a ‡ in Schedule "B". Perform these services if the vehicle is usually operated under these conditions.

# JUMP STARTING, HOISTING AND TOWING

## TABLE OF CONTENTS

|                                   | page |                                    | page |
|-----------------------------------|------|------------------------------------|------|
| <b>SERVICE PROCEDURES</b>         |      | RECREATIONAL TOWING . . . . .      | 10   |
| JUMP STARTING PROCEDURE . . . . . | 8    | EMERGENCY TOW HOOKS . . . . .      | 10   |
| TOWING RECOMMENDATIONS . . . . .  | 8    | HOISTING RECOMMENDATIONS . . . . . | 10   |
| VEHICLE TOWING . . . . .          | 10   |                                    |      |

## SERVICE PROCEDURES

### JUMP STARTING PROCEDURE

**WARNING: REVIEW ALL SAFETY PRECAUTIONS AND WARNINGS IN GROUP 8A, BATTERY/STARTING/CHARGING SYSTEMS DIAGNOSTICS.**

**DO NOT JUMP START A FROZEN BATTERY, PERSONAL INJURY CAN RESULT.**

**DO NOT JUMP START WHEN BATTERY INDICATOR DOT IS YELLOW OR BRIGHT COLOR. BATTERY CAN EXPLODE.**

**DO NOT ALLOW JUMPER CABLE CLAMPS TO TOUCH EACH OTHER WHEN CONNECTED TO A BOOSTER SOURCE.**

**DO NOT USE OPEN FLAME NEAR BATTERY.**

**REMOVE METALLIC JEWELRY WORN ON HANDS OR WRISTS TO AVOID INJURY BY ACCIDENTAL ARCHING OF BATTERY CURRENT.**

**WHEN USING A HIGH OUTPUT BOOSTING DEVICE, DO NOT ALLOW DISABLED VEHICLE'S BATTERY TO EXCEED 16 VOLTS. PERSONAL INJURY OR DAMAGE TO ELECTRICAL SYSTEM CAN RESULT.**

**CAUTION: When using another vehicle as a booster, do not allow vehicles to touch. Electrical systems can be damaged on either vehicle.**

### TO JUMP START A DISABLED VEHICLE:

(1) Raise hood on disabled vehicle and visually inspect engine compartment for:

- Generator drive belt condition and tension.
- Fuel fumes or leakage, correct if necessary.
- Frozen battery.
- Yellow or bright color test indicator, if equipped.
- Low battery fluid level.

**CAUTION: If the cause of starting problem on disabled vehicle is severe, damage to booster vehicle charging system can result.**

(2) When using another vehicle as a booster source, turn off all accessories, place gear selector in park or neutral, set park brake or equivalent and operate engine at 1200 rpm.

(3) On disabled vehicle, place gear selector in park or neutral and set park brake or equivalent. Turn OFF all accessories.

(4) Connect jumper cables to booster battery. RED clamp to positive terminal (+). BLACK clamp to negative terminal (-). DO NOT allow clamps at opposite end of cables to touch, electrical arc will result (Fig. 1). Review all warnings in this procedure.

(5) On disabled vehicle, connect RED jumper cable clamp to battery positive (+) terminal. Connect BLACK jumper cable clamp to the engine as close to the ground cable connection as possible (Fig. 1).

**CAUTION: Do not crank starter motor on disabled vehicle for more than 15 seconds, starter will over-heat and could fail.**

(6) Allow battery in disabled vehicle to charge to at least 12.4 volts (75% charge) before attempting to start engine. If engine does not start within 15 seconds, stop cranking engine and allow starter to cool (15 min.), before cranking again.


### DISCONNECT CABLE CLAMPS AS FOLLOWS:

- Disconnect BLACK cable clamp from engine ground on disabled vehicle.
- When using a Booster vehicle, disconnect BLACK cable clamp from battery negative terminal. Disconnect RED cable clamp from battery positive terminal.
- Disconnect RED cable clamp from battery positive terminal on disabled vehicle.

### TOWING RECOMMENDATIONS

DaimlerChrysler Corporation recommends that a 4WD vehicle be transported on a flat-bed device. A Wheel-lift or front end attached Sling-type device can be used provided all the wheels are lifted off the ground using tow dollies (Fig. 2) and (Fig. 3).


SERVICE PROCEDURES (Continued)



9100-3

**Fig. 1 Jumper Cable Clamp Connections**


- 1 - BOOSTER BATTERY
- 2 - NEGATIVE JUMPER CABLE
- 3 - ENGINE GROUND
- 4 - DO NOT ALLOW VEHICLES TO TOUCH
- 5 - BATTERY NEGATIVE CABLE
- 6 - DISCHARGED BATTERY
- 7 - POSITIVE JUMPER CABLE



J9500-6

**Fig. 2 Tow Vehicles With Approved Equipment**

- 1 - SLING TYPE
- 2 - WHEEL LIFT
- 3 - FLAT BED



80ae0e87

**Fig. 3 Towing With Tow Dollies**

1 - TOW DOLLY

**SAFETY PRECAUTIONS**

- Secure loose and protruding parts.
- Always use a safety chain system that is independent of the lifting and towing equipment.
- Do not allow towing equipment to contact the disabled vehicle's fuel tank.
- Do not allow anyone under the disabled vehicle while it is lifted by the towing device.
- Do not allow passengers to ride in a vehicle being towed.
- Always observe state and local laws regarding towing regulations.
- Do not tow a vehicle in a manner that could jeopardize the safety of the operator, pedestrians or other motorists.
- Do not attach tow chains, T-hooks, J-hooks, or a tow sling to a bumper, steering linkage, drive shafts or a non-reinforced frame hole.

**GROUND CLEARANCE**

**CAUTION:** If vehicle is towed with wheels removed, install lug nuts to retain brake drums.

A towed vehicle should be raised until lifted wheels are a minimum 100 mm (4 in) from the ground. Be sure there is adequate ground clearance at the opposite end of the vehicle, especially when towing over rough terrain or steep rises in the road. If necessary, remove the wheels from the lifted end of the vehicle and lower the vehicle closer to the ground, to increase the ground clearance at the opposite end of the vehicle. Install lug nuts on wheel attaching studs to retain brake drums.

**FLAT-BED TOWING RAMP ANGLE**

If a vehicle with flat-bed towing equipment is used, the approach ramp angle should not exceed 15 degrees.

## SERVICE PROCEDURES (Continued)

## VEHICLE TOWING

**WARNING: WHEN TOWING A DISABLED VEHICLE AND THE DRIVE WHEELS ARE SECURED IN A WHEEL LIFT OR TOW DOLLIES, ENSURE THE TRANSMISSION IS IN THE PARK POSITION (AUTOMATIC TRANSMISSION) OR A FORWARD DRIVE GEAR (MANUAL TRANSMISSION).**

**DO NOT ATTACH SLING-TYPE TOWING EQUIPMENT TO THE REAR OF A TJ.**

## TOWING-FRONT END LIFTED (WHEEL LIFT)

(1) Raise the rear of the vehicle off the ground and install tow dollies under rear wheels.

(2) Attach the wheel lift to the front wheels.

## TOWING-REAR END LIFTED (WHEEL LIFT ONLY)

(1) Raise the front of the vehicle off the ground and install tow dollies under front wheels.

(2) Attach the wheel lift to the rear wheels.

## TOWING-FRONT END LIFTED (SLING-TYPE)


(1) Raise the rear of the vehicle off the ground and install tow dollies under rear wheels.

(2) Attach T-hooks to the access holes on the outboard side of the frame rails (Fig. 4).

(3) Before tightening the chain, position a protective pad between the chain and the bumper.


(4) Attach the safety chains to the vehicle (Fig. 5).

(5) Turn the ignition switch to the OFF position to unlock the steering wheel.



**Fig. 4 T-Hook Attachment**

- 1 - PROTECTIVE PAD
- 2 - BUMPER
- 3 - CHAIN
- 4 - T-HOOK
- 5 - ACCESS HOLE
- 6 - FRAME



**Fig. 5 Safety Chain Attachment**

1 - SAFETY CHAIN

## RECREATIONAL TOWING

Refer to the Owners Manual for towing procedures.

## EMERGENCY TOW HOOKS

**WARNING: REMAIN AT A SAFE DISTANCE FROM A VEHICLE THAT IS BEING TOWED VIA ITS TOW HOOKS. THE TOW STRAPS/CHAINS COULD BREAK AND CAUSE SERIOUS INJURY.**

Some Jeep vehicles are equipped with front emergency tow hooks. The tow hooks should be used for **EMERGENCY** purposes only.

**CAUTION: DO NOT** use emergency tow hooks for tow truck hook-up or highway towing.

## HOISTING RECOMMENDATIONS

Refer to the Owner's Manual for emergency vehicle lifting procedures.


## FLOOR JACK

When properly positioned, a floor jack can be used to lift a Jeep vehicle (Fig. 6). Support the vehicle in the raised position with jack stands at the front and rear ends of the frame rails.

**CAUTION: Do not attempt to lift a Jeep vehicle with a floor jack positioned under:**

- An axle tube.
- A body side sill.
- A steering linkage component.
- A drive shaft.
- The engine or transmission oil pan.
- The fuel tank.
- A front suspension arm.
- Transfer case.

SERVICE PROCEDURES (Continued)




**NOTE:** Use the correct sub-frame rail or frame rail lifting locations only.

**HOIST**

- A vehicle can be lifted with:
- A single-post, frame-contact hoist.
  - A twin-post, chassis hoist.
  - A ramp-type, drive-on hoist.

**NOTE:** When a frame-contact type hoist is used, verify that the lifting pads are positioned properly.

**WARNING:** THE HOISTING AND JACK LIFTING POINTS PROVIDED ARE FOR A COMPLETE VEHICLE. WHEN A CHASSIS OR DRIVETRAIN COMPONENT IS REMOVED FROM A VEHICLE, THE CENTER OF GRAVITY IS ALTERED MAKING SOME HOISTING CONDITIONS UNSTABLE. PROPERLY SUPPORT OR SECURE VEHICLE TO HOISTING DEVICE WHEN THESE CONDITIONS EXIST.



- |                     |                         |
|---------------------|-------------------------|
| DRIVE-ON HOIST      | TWIN POST CHASSIS HOIST |
| FRAME CONTACT HOIST | FLOOR JACK              |

80a4d237

**Fig. 6 Vehicle Lifting Locations**



# SUSPENSION

## TABLE OF CONTENTS

|                        | page |                       | page |
|------------------------|------|-----------------------|------|
| ALIGNMENT .....        | 1    | REAR SUSPENSION ..... | 14   |
| FRONT SUSPENSION ..... | 6    |                       |      |

# ALIGNMENT

## TABLE OF CONTENTS

|                                     | page |                                | page |
|-------------------------------------|------|--------------------------------|------|
| <b>DESCRIPTION AND OPERATION</b>    |      | WHEEL ALIGNMENT .....          | 4    |
| WHEEL ALIGNMENT .....               | 1    | <b>SPECIFICATIONS</b>          |      |
| <b>DIAGNOSIS AND TESTING</b>        |      | ALIGNMENT SPECIFICATIONS ..... | 5    |
| SUSPENSION AND STEERING SYSTEM..... | 3    |                                |      |
| <b>SERVICE PROCEDURES</b>           |      |                                |      |
| PRE-ALIGNMENT .....                 | 4    |                                |      |

## DESCRIPTION AND OPERATION

### WHEEL ALIGNMENT

#### DESCRIPTION

Wheel alignment involves the correct positioning of the wheels in relation to the vehicle. The positioning is accomplished through suspension and steering linkage adjustments. An alignment is considered essential for efficient steering, good directional stability and to minimize tire wear. The most important measurements of an alignment are caster, camber and toe position (Fig. 1).

**CAUTION:** Never attempt to modify suspension or steering components by heating or bending.

**CAUTION:** Components attached with a nut and cotter pin must be torqued to specification. Then if the slot in the nut does not line up with the cotter pin hole, tighten nut until it is aligned. Never loosen the nut to align the cotter pin hole.

**NOTE:** Periodic lubrication of the front suspension/steering system components may be required. Rubber bushings must never be lubricated. Refer to

**Group 0, Lubrication And Maintenance for the recommended maintenance schedule.**

#### OPERATION

- **CASTER** is the forward or rearward tilt of the steering knuckle from vertical. Tilting the top of the knuckle rearward provides positive caster. Tilting the top of the knuckle forward provides negative caster. Caster is a directional stability angle. This angle enables the front wheels to return to a straight ahead position after turns.


- **CAMBER** is the inward or outward tilt of the wheel relative to the center of the vehicle. Tilting the top of the wheel inward provides negative camber. Tilting the top of the wheel outward provides positive camber. Incorrect camber will cause wear on the inside or outside edge of the tire. The angle is not adjustable, damaged component(s) must be replaced to correct the camber angle.

- **WHEEL TOE POSITION** is the difference between the leading inside edges and trailing inside edges of the front tires. Incorrect wheel toe position is the most common cause of unstable steering and uneven tire wear. The wheel toe position is the **final** front wheel alignment adjustment.

DESCRIPTION AND OPERATION (Continued)

• **STEERING AXIS INCLINATION ANGLE** is measured in degrees and is the angle that the steering knuckles are tilted. The inclination angle has a fixed relationship with the camber angle. It will not change except when a spindle or ball stud is damaged or bent. The angle is not adjustable, damaged component(s) must be replaced to correct the steering axis inclination angle.

• **THRUST ANGLE** is the angle of the rear axle relative to the centerline of the vehicle. Incorrect thrust angle can cause off-center steering and excessive tire wear. This angle is not adjustable, damaged component(s) must be replaced to correct the thrust angle.



80b34eaf

**Fig. 1 Wheel Alignment Measurements**

- |                           |                     |
|---------------------------|---------------------|
| 1 - WHEEL CENTERLINE      | 5 - TRUE VERTICAL   |
| 2 - NEGATIVE CAMBER ANGLE | 6 - KING PIN        |
| 3 - PIVOT CENTERLINE      | 7 - VERTICAL        |
| 4 - SCRUB RADIUS          | 8 - POSITIVE CASTER |

## DIAGNOSIS AND TESTING

## SUSPENSION AND STEERING SYSTEM

| CONDITION   | POSSIBLE CAUSES  | CORRECTION   |
|---|--|--|
| FRONT END NOISE   | <ol style="list-style-type: none"> <li>1. Loose or worn wheel bearings.</li> <li>2. Loose or worn steering or suspension components.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Adjust or replace wheel bearings.</li> <li>2. Tighten or replace components as necessary.</li> </ol>   |
| EXCESSIVE PLAY IN STEERING  | <ol style="list-style-type: none"> <li>1. Loose or worn wheel bearings.</li> <li>2. Loose or worn steering or suspension components.</li> <li>3. Loose or worn steering gear.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Adjust or replace wheel bearings.</li> <li>2. Tighten or replace components as necessary.</li> <li>3. Adjust or replace steering gear.</li> </ol>  |
| FRONT WHEELS SHIMMY   | <ol style="list-style-type: none"> <li>1. Loose or worn wheel bearings.</li> <li>2. Loose or worn steering or suspension components.</li> <li>3. Tires worn or out of balance.</li> <li>4. Alignment.</li> <li>5. Leaking steering dampener.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Adjust or replace wheel bearings.</li> <li>2. Tighten or replace components as necessary.</li> <li>3. Replace or balance tires.</li> <li>4. Align vehicle to specifications.</li> <li>5. Replace steering dampener.</li> </ol> |
| VEHICLE INSTABILITY   | <ol style="list-style-type: none"> <li>1. Loose or worn wheel bearings.</li> <li>2. Loose or worn steering or suspension components.</li> <li>3. Tire pressure.</li> <li>4. Alignment.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Adjust or replace wheel bearings.</li> <li>2. Tighten or replace components as necessary.</li> <li>3. Adjust tire pressure.</li> <li>4. Align vehicle to specifications.</li> </ol>  |
| EXCESSIVE STEERING EFFORT   | <ol style="list-style-type: none"> <li>1. Loose or worn steering gear.</li> <li>2. Power steering fluid low.</li> <li>3. Column coupler binding.</li> <li>4. Tire pressure.</li> <li>5. Alignment.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Adjust or replace steering gear.</li> <li>2. Add fluid and repair leak.</li> <li>3. Replace coupler.</li> <li>4. Adjust tire pressure.</li> <li>5. Align vehicle to specifications.</li> </ol>                                 |
| VEHICLE PULLS TO ONE SIDE DURING BRAKING                                | <ol style="list-style-type: none"> <li>1. Uneven tire pressure.</li> <li>2. Worn brake components.</li> <li>3. Air in brake line.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Adjust tire pressure.</li> <li>2. Repair brakes as necessary.</li> <li>3. Repair as necessary.</li> </ol>  |
| VEHICLE LEADS OR DRIFTS FROM STRAIGHT AHEAD DIRECTION ON UNCROWNED ROAD | <ol style="list-style-type: none"> <li>1. Radial tire lead.</li> <li>2. Brakes dragging.</li> <li>3. Weak or broken spring.</li> <li>4. Uneven tire pressure.</li> <li>5. Wheel Alignment.</li> <li>6. Loose or worn steering or suspension components.</li> <li>7. Cross caster out of spec.</li> </ol> | <ol style="list-style-type: none"> <li>1. Cross front tires.</li> <li>2. Repair brake as necessary.</li> <li>3. Replace spring.</li> <li>4. Adjust tire pressure.</li> <li>5. Align vehicle.</li> <li>6. Repair as necessary.</li> <li>7. Align vehicle.</li> </ol>      |

## DIAGNOSIS AND TESTING (Continued)

| CONDITION                       | POSSIBLE CAUSES  | CORRECTION  |
|---------------------------------|--|---|
| KNOCKING, RATTLING OR SQUEAKING | <ol style="list-style-type: none"> <li>1. Worn shock bushings.</li> <li>2. Loose, worn or bent steering/suspension components.</li> <li>3. Shock valve.</li> </ol> | <ol style="list-style-type: none"> <li>1. Replace shock.</li> <li>2. Inspect, tighten or replace components as necessary.</li> <li>3. Replace shock.</li> </ol>           |
| IMPROPER TRACKING               | <ol style="list-style-type: none"> <li>1. Loose, worn or bent track bar.</li> <li>2. Loose, worn or bent steering/suspension components.</li> </ol>                | <ol style="list-style-type: none"> <li>1. Inspect, tighten or replace component as necessary.</li> <li>2. Inspect, tighten or replace components as necessary.</li> </ol> |

## SERVICE PROCEDURES

## PRE-ALIGNMENT

Before starting wheel alignment, the following inspection and necessary corrections must be completed. Refer to Suspension and Steering System Diagnosis Chart for additional information.

- (1) Inspect tires for size and tread wear.
- (2) Set tire air pressure.
- (3) Inspect front wheel bearings for wear.
- (4) Inspect front wheels for excessive radial or lateral runout and balance.
- (5) Inspect ball studs, linkage pivot points and steering gear for looseness, roughness or binding.
- (6) Inspect suspension components for wear and noise.
- (7) Road test the vehicle.

## WHEEL ALIGNMENT

Before each alignment reading the vehicle should be jounced (rear first, then front). Grasp each bumper at the center and jounce the vehicle up and down three times. Always release the bumper in the down position.

## CAMBER

The wheel camber angle is preset. This angle is not adjustable and cannot be altered.


## CASTER

Check the caster of the front axle for correct angle. Be sure the axle is not bent or twisted. Road test the vehicle and observe the steering wheel return-to-center position. Low caster will cause poor steering wheel returnability.

During the road test, turn the vehicle to both the left and right. If the steering wheel returns to the center position unassisted, the caster angle is correct. However, if steering wheel does not return toward the center position unassisted, a low caster angle is probable.

Caster can be adjusted by installing a cam bolts and rotating the cams on the lower suspension arm (Fig. 2).

**NOTE:** Changing caster angle will also change the front propeller shaft angle. The propeller shaft angle has priority over caster. Refer to Group 3, Differential and Driveline for additional information.



J9302-59

**Fig. 2 Cam Adjuster**

- 1 - ADJUSTMENT CAM
- 2 - AXLE BRACKET
- 3 - BRACKET REINFORCEMENT
- 4 - LOWER SUSPENSION ARM

## TOE POSITION


**NOTE:** The wheel toe position adjustment is the final adjustment. This adjustment must be performed with the engine running, if the vehicle is equipped with power steering.

## SERVICE PROCEDURES (Continued)

(1) Start the engine and turn wheels both ways before straightening the steering wheel. Center and secure the steering wheel.


(2) Loosen the adjustment sleeve clamp bolts (Fig. 3).

(3) Adjust the right wheel toe position with the drag link (Fig. 4). Turn the sleeve until the right wheel is at the correct positive TOE-IN position. Position the clamp bolts as shown (Fig. 3) and tighten to 49 N·m (36 ft. lbs.). **Make sure the toe setting does not change during clamp tightening.**



**Fig. 3 Drag Link and Tie Rod Clamp**

- 1 - TIE ROD CLAMP  
2 - DRAG LINK CLAMPS



**Fig. 4 Steering Linkage**

- 1 - COTTER PIN  
2 - DAMPENER  
3 - PITMAN ARM  
4 - WASHER  
5 - TIE ROD  
6 - DRAG LINK  
7 - NUT

(4) Adjust the left wheel toe position with the tie rod. Turn the sleeve until the left wheel is at the same TOE-IN position as the right wheel. Position the clamp bolts as shown (Fig. 3) and tighten to 27 N·m (20 ft. lbs.). **Make sure the toe setting does not change during clamp tightening.**

(5) Verify the right toe specifications and turn off the engine.

## SPECIFICATIONS

## ALIGNMENT SPECIFICATIONS

**NOTE:** Alignment specifications are in degrees.

| ANGLE                        | PREFERRED | RANGE   | MAX RT/LT DIFFERENCE |
|------------------------------|-----------|---------|----------------------|
| CASTER                       | + 7°      | ± 1.0°  | 0.65°                |
| CAMBER<br>(fixed angle)      | - 0.25°   | ± 0.63° | 1.0°                 |
| TOE-IN<br>(each front wheel) | + 0.15°   | ± 0.07° | 0.05°                |
| REAR SPECIFICATION           |           |         |                      |
| REAR CAMBER                  | - 0.25°   | ± 0.25° | NA                   |
| TOTAL TOE-IN                 | + 0.25°   | ± 0.25° | NA                   |
| THRUST ANGLE 0° ± 0.25°      |           |         |                      |

# FRONT SUSPENSION

## TABLE OF CONTENTS

|  | page |                            | page |
|--|------|----------------------------|------|
| <b>DESCRIPTION AND OPERATION</b>       |      |                            |      |
| FRONT SUSPENSION .....                 | 6    | COIL SPRING .....          | 8    |
| SHOCK ABSORBERS .....                  | 6    | STEERING KNUCKLE .....     | 8    |
| JOUNCE BUMPER .....                    | 6    | LOWER SUSPENSION ARM ..... | 9    |
| COIL SPRINGS AND ISOLATORS .....       | 6    | UPPER SUSPENSION ARM ..... | 9    |
| LOWER SUSPENSION ARMS AND BUSHINGS ... | 7    | FRONT AXLE BUSHING .....   | 9    |
| UPPER SUSPENSION ARMS AND BUSHINGS ... | 7    | STABILIZER BAR .....       | 10   |
| STABILIZER BAR .....                   | 7    | TRACK BAR .....            | 11   |
| TRACK BAR .....                        | 7    | HUB BEARING .....          | 11   |
| HUB/BEARING .....                      | 7    | WHEEL MOUNTING STUDS ..... | 11   |
| <b>DIAGNOSIS AND TESTING</b>           |      |                            |      |
| SHOCK DIAGNOSIS .....                  | 7    | <b>SPECIFICATIONS</b>      |      |
| <b>SERVICE PROCEDURES</b>              |      |                            |      |
| LUBRICATION .....                      | 8    | TORQUE CHART .....         | 12   |
| <b>REMOVAL AND INSTALLATION</b>        |      |                            |      |
| SHOCK ABSORBER .....                   | 8    | <b>SPECIAL TOOLS</b>       |      |
|  |      | FRONT SUSPENSION .....     | 13   |

## DESCRIPTION AND OPERATION

### FRONT SUSPENSION

The front suspension is a link/coil design comprised of:

- Shock absorbers
- Jounce Bumper
- Coil springs
- Upper and lower suspension arms
- Stabilizer bar
- Track bar

**CAUTION:** Components attached with a nut and cotter pin must be torqued to specification. Then if the slot in the nut does not line up with the cotter pin hole, tighten nut until it is aligned. Never loosen the nut to align the cotter pin hole.

**CAUTION:** Suspension components with rubber/urethane bushings (except stabilizer bar) should be tightened with the vehicle at normal ride height. It is important to have the springs supporting the weight of the vehicle when the fasteners are torqued. If springs are not at their normal ride position, vehicle ride comfort could be affected and premature bushing wear may occur.

## SHOCK ABSORBERS

### DESCRIPTION

The top of the shock absorbers are bolted to a frame bracket. The bottom of the shocks are bolted to the axle brackets.

### OPERATION

The shock absorbers dampen jounce and rebound motion of the vehicle over various road conditions and limit suspension rebound travel.

## JOUNCE BUMPER

### DESCRIPTION

The jounce bumpers are mounted under the frame rails inside of the coil springs.

### OPERATION

The jounce bumpers are used to limit suspension travel in compression.

## COIL SPRINGS AND ISOLATORS

### DESCRIPTION

The coil springs mount up in the wheelhouse which is part of the unitized body bracket. A rubber doughnut isolator is located between the top of the spring and the bracket. The bottom of the spring seats on a axle pad.

## DESCRIPTION AND OPERATION (Continued)

**OPERATION**

The coil springs control ride quality and maintain proper ride height. The isolators provide road noise isolation.

**LOWER SUSPENSION ARMS AND BUSHINGS****DESCRIPTION**

The lower suspension arms are steel and use bushings at one end of the arm. The arms mount to the frame rail bracket and the axle brackets.

**OPERATION**

The lower suspension arm bushings provide isolation from the axle. The arm and bushings provide location and react to loads from the axle. The lower suspension arms can be used to adjust caster and pinion angle by installing a cam bolt service package.

**UPPER SUSPENSION ARMS AND BUSHINGS****DESCRIPTION**

The upper suspension arms are steel and use rubber bushings at each end of the arm. The arms mount to the frame rail bracket and the axle brackets.

**OPERATION**

The arm and bushings provide location and react to loads from the axle. The bushings provide isolation from the axle.

**STABILIZER BAR****DESCRIPTION**

The spring steel bar extends across the top of the chassis frame rails. Links are connected from the bar to the axle brackets. The stabilizer bar and links are isolated by rubber bushings.

**OPERATION**

The stabilizer bar is used to control vehicle body roll during turns. The bar helps to control the vehicle body in relationship to the suspension.

**TRACK BAR****DESCRIPTION**

The bar is attached to a frame rail bracket with a ball stud and an axle bracket with a bushing. The bar is forged and has non replaceable isolator bushing and ball stud.

**OPERATION**

The track bar is used to control front axle lateral movement and provides cross car location of the axle assembly.

**HUB/BEARING****DESCRIPTION**

The bearing used on the front hub of this vehicle is the combined hub and bearing unit type assembly. This unit assembly combines the front wheel mounting hub (flange) and the front wheel bearing into a one piece unit. The wheel mounting studs are the only replaceable component of the hub/bearing assembly.

**OPERATION**

The hub/bearing assembly is mounted to the steering knuckle and is retained by three mounting bolts accessible from the back of the steering knuckle. The hub/bearing unit is not serviceable and must be replaced as an assembly if the bearing or the hub is determined to be defective.

**DIAGNOSIS AND TESTING****SHOCK DIAGNOSIS**

A knocking or rattling noise from a shock absorber may be caused by movement between mounting bushings and metal brackets or attaching components. These noises can usually be stopped by tightening the attaching nuts. If the noise persists, inspect for damaged and worn bushings, and attaching components. Repair as necessary if any of these conditions exist.

A squeaking noise from the shock absorber may be caused by the hydraulic valving and may be intermittent. This condition is not repairable and the shock absorber must be replaced.

The shock absorbers are not refillable or adjustable. If a malfunction occurs, the shock absorber must be replaced. To test a shock absorber, hold it in an upright position and force the piston in and out of the cylinder four or five times. The action throughout each stroke should be smooth and even.

The shock absorber bushings do not require any type of lubrication. Do not attempt to stop bushing noise by lubricating them. Grease and mineral oil-base lubricants will deteriorate the bushing.

## SERVICE PROCEDURES

### LUBRICATION

Periodic lubrication of the suspension system is required. Refer to Group 0, Lubrication And Maintenance for the recommended maintenance schedule.

The following component must be lubricated:


- Track bar

## REMOVAL AND INSTALLATION

### SHOCK ABSORBER

#### REMOVAL

(1) Remove the nut, retainer and grommet from the upper stud through engine compartment access hole (Fig. 1).



80632206

**Fig. 1 Coil Spring & Shock Absorber**

- 1 - RETAINER
- 2 - GROMMET
- 3 - SHOCK
- 4 - FRONT AXLE

(2) Remove the lower nuts and bolts from the axle bracket and remove the shock absorber.

#### INSTALLATION

(1) Position the lower retainer and grommet on the upper stud. Insert the shock absorber through the shock bracket hole.

(2) Install the lower bolts and nuts. Tighten nuts to 28 N·m (250 in. lbs.).

(3) Install the upper grommet and retainer on the stud and install the nut and tighten to 23 N·m (17 ft. lbs.).

### COIL SPRING

#### REMOVAL

(1) Raise and support the vehicle. Position a hydraulic jack under the axle to support it.

(2) Paint or scribe alignment marks on the cam adjusters and axle bracket for installation reference.

(3) Mark and disconnect the front propeller shaft from the axle.

(4) Remove the lower suspension arm nut, cam and cam bolt from the axle.

(5) Disconnect the stabilizer bar links and shock absorbers from the axle.

(6) Disconnect the track bar from the frame rail bracket.

(7) Disconnect the drag link from the pitman arm.

(8) Lower the axle until the spring is free from the upper mount and remove the spring.

**NOTE:** Left coil spring has a retainer and bolt which must be removed from the axle pad.

(9) Remove the jounce bumper if necessary from the upper spring mount.

#### INSTALLATION

(1) Position the coil spring on the axle pad.

**NOTE:** Install retainer and bolt on the left spring and tighten to 22 N·m (16 ft. lbs.).

(2) Install the jounce bumper.

(3) Raise the axle into position until the spring seats in the upper mount, then raise another 51 mm (2 in.).

(4) Connect the stabilizer bar links and shock absorbers to the axle bracket. Connect the track bar to the frame rail bracket.

(5) Install the lower suspension arm to the axle.

(6) Install the front propeller shaft to the axle.

(7) Install drag link to pit man arm.

(8) Remove the supports and lower the vehicle.

(9) Tighten all suspension components to proper torque.

### STEERING KNUCKLE


For service procedures on the steering knuckle and ball joints refer to Group 3 Differentials And Driveline.

## REMOVAL AND INSTALLATION (Continued)

## LOWER SUSPENSION ARM

## REMOVAL

- (1) Raise and support the vehicle.
- (2) If equipped with ABS brakes remove sensor wire from the inboard side of the arm.
- (3) If the vehicle is equipped with a cam bolt service package paint or scribe alignment marks on the cam adjusters and suspension arm for installation reference (Fig. 2).



**Fig. 2 Cam Bolt Service Package**

- 1 - ADJUSTMENT CAM
- 2 - AXLE BRACKET
- 3 - BRACKET REINFORCEMENT
- 4 - LOWER SUSPENSION ARM

(4) Remove the lower suspension arm nut and bolt from the axle (Fig. 3).


(5) Remove the nut and bolt/cam bolt from the frame rail bracket and remove the lower suspension arm (Fig. 3).

## INSTALLATION

(1) Position the lower suspension arm in the axle bracket and frame rail bracket.

**NOTE: Small holes in the side of the arm face inboard.**

- (2) Install the rear bolt and nut finger tighten.
- (3) Install bolt/cam bolt and new nut finger tighten in the axle and align the reference marks.
- (4) If equipped with ABS brakes install sensor wire to the inboard side of the arm with new clips.



**Fig. 3 Upper & Lower Suspension Arms**

- 1 - UPPER SUSPENSION ARM
- 2 - FRONT AXLE
- 3 - LOWER SUSPENSION ARM

- (5) Lower the vehicle.
- (6) Tighten axle bracket nut to 115 N·m (85 ft. lbs.).
- (7) Tighten frame bracket nut to 176 N·m (130 ft. lbs.).
- (8) Align vehicle to specifications.

## UPPER SUSPENSION ARM

## REMOVAL

- (1) Raise and support the vehicle.
- (2) Remove the upper suspension arm nut and bolt at the axle bracket (Fig. 3).
- (3) Remove the nut and bolt at the frame rail and remove the upper suspension arm.

## INSTALLATION

- (1) Position the upper suspension arm at the axle and frame rail.
- (2) Install the bolts and finger tighten the nuts.
- (3) Remove the supports and lower the vehicle.
- (4) Tighten the nut at the axle and frame brackets to 75 N·m (55 ft. lbs.).

## FRONT AXLE BUSHING


## REMOVAL

- (1) Remove the upper suspension arm from axle.
- (2) Position Spacer 7932-3 over the axle bushing on a 4x2 vehicle and right side on a 4x4 vehicle.
- (3) Place Receiver 7932-1 over flanged end of the bushing. (Fig. 4).
- (4) Place small end of Remover/Install 7932-2 against other side of the bushing.

## REMOVAL AND INSTALLATION (Continued)

(5) Install bolt 7604 through remover, bushing and receiver.

(6) Install Long Nut 7603 and tighten nut too pull bushing out of the axle bracket.



80b5cb7a

**Fig. 4 Bushing Removal**

- 1 - RECEIVER
- 2 - AXLE BRACKET
- 3 - BOLT
- 4 - REMOVER/INSTALLER
- 5 - LONG NUT

(7) Remove nut, bolt, receiver, remover and bushing.

**NOTE:** On 4x2 vehicle and right side of 4x4 vehicle, leave Spacer 7932-3 in position for bushing installation.

**INSTALLATION**

(1) Place Receiver 7932-1 on the other side of the axle bracket.

(2) Position new bushing up to the axle bracket, and large end of Remover/Install 7932-2 against the bushing (Fig. 5).

(3) Install bolt 7604 through receiver, bushing and installer.


(4) Install Long Nut 7603 and tighten nut to draw the bushing into the axle bracket.

(5) Remove tools and install the upper suspension arm.

**STABILIZER BAR****REMOVAL**

(1) Remove upper link nuts (Fig. 6) and separate the links from the stabilizer bar with Remove MB-990635.

(2) Remove front bumper valence, refer to Group 23 Body for procedure.



80b5cb79


**Fig. 5 Bushing Installation**

- 1 - REMOVER/INSTALLER
- 2 - AXLE BRACKET
- 3 - BOLT
- 4 - RECEIVER
- 5 - LONG NUT

(3) Remove stabilizer retainer bolts (Fig. 6) and remove retainers.

(4) Remove stabilizer bar.

(5) Remove lower link nuts and bolts and remove links (Fig. 6).



80a1380f

**Fig. 6 Stabilizer Bar**

- 1 - RETAINER
- 2 - STABILIZER BAR
- 3 - LINK
- 4 - BUSHING

**INSTALLATION**

(1) Center stabilizer bar on top of the frame rails and install retainers and bolts. Tighten bolts to 54 N-m (40 ft. lbs.).

## REMOVAL AND INSTALLATION (Continued)

(2) Position links on axle brackets and into the stabilizer bar. Install lower link bolts and nuts and tighten to 95 N·m (70 ft. lbs.).

(3) Install upper link nuts and tighten to 61 N·m (45 ft. lbs.).

(4) Install bumper valence.

## TRACK BAR


## REMOVAL

(1) Raise and support the vehicle.

(2) Remove the cotter pin and nut from the ball stud end at the frame rail bracket (Fig. 7).

(3) Use a universal puller tool to separate the track bar ball stud from the frame rail bracket.

(4) Remove the bolt and flag nut from the axle bracket (Fig. 7). Remove the track bar.



80632205

**Fig. 7 Track Bar**

- 1 - TRACK BAR  
2 - FRAME BRACKET  
3 - FRONT AXLE

## INSTALLATION

(1) Install the track bar at axle tube bracket. Loosely install the retaining bolt and flag nut.

(2) It may be necessary to pry the axle assembly over to install the track bar at the frame rail. Install track bar at the frame rail bracket. Install the retaining nut on the stud.

(3) Tighten the ball stud nut to 88 N·m (65 ft. lbs.) and install a new cotter pin.

(4) Remove the supports and lower the vehicle.

(5) Tighten the bolt at the axle bracket to 75 N·m (55 ft. lbs.).

(6) Check alignment if a new track bar was installed.

## HUB BEARING

## REMOVAL

(1) Raise and support the vehicle.

(2) Remove the wheel and tire assembly.

(3) Remove the brake caliper, rotor and ABS wheel speed sensor, refer to Group 5 Brakes.

(4) Remove the cotter pin, nut retainer and axle hub nut (Fig. 8).

(5) Remove the hub bearing mounting bolts from the back of the steering knuckle. Remove hub bearing from the steering knuckle and off the axle shaft.

## INSTALLATION

(1) Install the hub bearing and brake dust shield to the knuckle.

(2) Install the hub bearing to knuckle bolts and tighten to 102 N·m (75 ft. lbs.).

(3) Install the hub washer and nut. Tighten the hub nut to 237 N·m (175 ft. lbs.). Install the nut retainer and a new cotter pin.

(4) Install the brake rotor, caliper and ABS wheel speed sensor, refer to Group 5 Brakes.

(5) Install the wheel and tire assembly.

(6) Remove support and lower the vehicle.

## WHEEL MOUNTING STUDS

**CAUTION:** Do not use a hammer to remove wheel studs.

## REMOVAL

(1) Raise and support vehicle.

(2) Remove wheel and tire assembly.

(3) Remove brake caliper, caliper adapter and rotor, refer to Group 5 Brakes for procedure.

(4) Remove stud from hub with Remover C-4150A (Fig. 9).

## INSTALLATION

(1) Install new stud into hub flange.

(2) Install three washers onto stud, then install lug nut with the flat side of the nut against the washers.

(3) Tighten lug nut until the stud is pulled into the hub flange. Verify that the stud is properly seated into the flange.


(4) Remove lug nut and washers.

(5) Install the brake rotor, caliper adapter, and caliper, refer to Group 5 Brakes for procedure.

(6) Install wheel and tire assembly, use new lug nut on stud or studs that were replaced.

(7) Remove support and lower vehicle.


REMOVAL AND INSTALLATION (Continued)



J9302-43

**Fig. 8 Hub Bearing & Knuckle**

- |                  |                              |
|------------------|------------------------------|
| 1 - BRAKE SHIELD | 6 - HUB AND BEARING ASSEMBLY |
| 2 - WASHER       | 7 - STEERING KNUCKLE         |
| 3 - RETAINER     | 8 - BOLT                     |
| 4 - COTTER PIN   | 9 - TONE WHEEL (ABS)         |
| 5 - NUT          |                              |



**Fig. 9 Wheel Stud Removal**

- 1 - REMOVER  
2 - WHEEL STUD


SPECIFICATIONS

TORQUE CHART


| DESCRIPTION                 | TORQUE                 |
|-----------------------------|------------------------|
| <b>Shock Absorber</b>       |                        |
| Upper Nut                   | 23 N·m (17 ft. lbs.)   |
| Lower Nut                   | 28 N·m (250 in. lbs.)  |
| <b>Suspension Arm Lower</b> |                        |
| Axle Bracket Nut            | 115 N·m (85 ft. lbs.)  |
| Frame Bracket Nut           | 176 N·m (130 ft. lbs.) |
| <b>Suspension Arm Upper</b> |                        |
| Axle Bracket Nut            | 75 N·m (55 ft. lbs.)   |
| Frame Bracket Bolt          | 75 N·m (55 ft. lbs.)   |
| <b>Stabilizer Bar</b>       |                        |
| Retainer Bolts              | 54 N·m (40 ft. lbs.)   |
| Link Upper Nut              | 61 N·m (45 ft. lbs.)   |
| Link Lower Bolt             | 95 N·m (70 ft. lbs.)   |
| <b>Track Bar</b>            |                        |
| Ball Stud Nut               | 88 N·m (65 ft. lbs.)   |
| Axle Bracket Bolt           | 75 N·m (55 ft. lbs.)   |
| <b>Hub/Bearing</b>          |                        |
| Bolts                       | 102 N·m (75 ft. lbs.)  |
| Axle Nut                    | 237 N·m (175 ft. lbs.) |

SPECIAL TOOLS


FRONT SUSPENSION




*Remover/Installer Suspension Bushing 7932*



*Nut, Long 7603*



*Bolt, Special 7604*



*Remover C-4150A*

# REAR SUSPENSION

## TABLE OF CONTENTS

|  | page |                                 | page |
|--|------|---------------------------------|------|
| <b>DESCRIPTION AND OPERATION</b>             |      | <b>REMOVAL AND INSTALLATION</b> |      |
| REAR SUSPENSION . . . . .                    | 14   | SHOCK ABSORBER . . . . .        | 15   |
| SHOCK ABSORBERS . . . . .                    | 14   | COIL SPRING . . . . .           | 15   |
| COIL SPRINGS AND ISOLATORS . . . . .         | 14   | LOWER SUSPENSION ARM . . . . .  | 16   |
| JOUNCE BUMPERS . . . . .                     | 14   | UPPER SUSPENSION ARM . . . . .  | 16   |
| LOWER SUSPENSION ARMS AND BUSHINGS . . . . . | 14   | STABILIZER BAR . . . . .        | 16   |
| STABILIZER BAR . . . . .                     | 14   | TRACK BAR . . . . .             | 17   |
| TRACK BAR . . . . .                          | 15   | <b>SPECIFICATIONS</b>           |      |
| <b>DIAGNOSIS AND TESTING</b>                 |      | TORQUE CHART . . . . .          | 18   |
| SHOCK DIAGNOSIS . . . . .                    | 15   |                                 |      |

## DESCRIPTION AND OPERATION

### REAR SUSPENSION

The rear suspension is link/coil design comprised of:

- Shock absorbers
- Coil springs
- Upper and lower suspension arms
- Stabilizer bar
- Track bar

**CAUTION:** Suspension components with rubber/urethane bushings (except stabilizer bar) should be tightened with the vehicle at normal ride height. It is important to have the springs supporting the weight of the vehicle when the fasteners are torqued. This will maintain vehicle ride comfort and prevent premature bushing wear.

### SHOCK ABSORBERS

#### DESCRIPTION

The top of the shock absorbers are bolted to the frame. The bottom of the shocks are bolted to the axle brackets.

#### OPERATION

The shock absorbers dampen jounce and rebound motion of the vehicle over various road conditions and limit suspension rebound travel.

### COIL SPRINGS AND ISOLATORS

#### DESCRIPTION

The coil springs mount between the bottom of the frame rail and the top of the axle. A rubber doughnut

isolator is located between the top of the spring and the frame rail. A plastic isolator is located between the bottom of the spring and the axle.

#### OPERATION

The coil springs control ride quality and maintain proper ride height. The isolators are used to isolate road noise.

### JOUNCE BUMPERS

#### DESCRIPTION

The jounce bumpers are mounted inside the coil spring to the frame rail.

#### OPERATION

The jounce bumpers are used to limit suspension travel in compression.

### LOWER SUSPENSION ARMS AND BUSHINGS

#### DESCRIPTION

The lower suspension arms are steel and use bushings at each end of the arm. The arms are mounted from the frame to the axle brackets.

#### OPERATION

The bushings isolation axle and road noise. The arm and bushings provide location and react to loads from the axle.

### STABILIZER BAR

#### DESCRIPTION

The spring steel bar extends across the axle and mounts to bracket on the axle. Links are connected

## DESCRIPTION AND OPERATION (Continued)

from the bar to the side of the frame rail. The stabilizer bar and links are isolated by rubber bushings.

### OPERATION

The stabilizer bar is used to control vehicle body roll during turns. The bar helps to control the vehicle body in relationship to the suspension.

### TRACK BAR

#### DESCRIPTION

The bar is attached to a frame rail bracket and axle bracket. The bar has bushings at both ends.

#### OPERATION

The track bar is used to control rear axle lateral movement.

## DIAGNOSIS AND TESTING

### SHOCK DIAGNOSIS

A knocking or rattling noise from a shock absorber may be caused by movement between mounting bushings and metal brackets or attaching components. These noises can usually be stopped by tightening the attaching nuts. If the noise persists, inspect for damaged and worn bushings, and attaching components. Repair as necessary if any of these conditions exist.

A squeaking noise from the shock absorber may be caused by the hydraulic valving and may be intermittent. This condition is not repairable and the shock absorber must be replaced.

The shock absorbers are not refillable or adjustable. If a malfunction occurs, the shock absorber must be replaced. To test a shock absorber, hold it in an upright position and force the piston in and out of the cylinder four or five times. The action throughout each stroke should be smooth and even.


The shock absorber bushings do not require any type of lubrication. Do not attempt to stop bushing noise by lubricating them. Grease and mineral oil-base lubricants will deteriorate the bushing.

## REMOVAL AND INSTALLATION

### SHOCK ABSORBER

#### REMOVAL

- (1) Raise and support the vehicle and the axle.
- (2) Remove the upper mounting bolts (Fig. 1).
- (3) Remove the lower nut and bolt from the axle bracket. Remove the shock absorber.



80a13810

**Fig. 1 Shock Absorber**

- 1 - AXLE BRACKET  
2 - SHOCK

#### INSTALLATION

- (1) Install the shock absorber on the upper frame rail and install mounting bolts.
- (2) Tighten the upper bolts to 31 N·m (23 ft. lbs.).
- (3) Install lower bolt and nut finger tight.
- (4) Remove the supports and lower the vehicle.
- (5) Tighten the lower nut to 100 N·m (74 ft. lbs.).

#### COIL SPRING

#### REMOVAL

- (1) Raise and support the vehicle. Position a hydraulic jack under the axle to support it.
- (2) Disconnect the stabilizer bar links and shock absorbers from the axle brackets.
- (3) Disconnect the track bar from the frame rail bracket.
- (4) Lower the axle until the spring is free from the upper mount seat and remove the spring.

#### INSTALLATION

**NOTE: Springs can be install with either end up.**


- (1) Position the coil spring on the axle pad isolator.
- (2) Raise the axle into position until the spring seats on the upper isolator.
- (3) Connect the stabilizer bar links and shock absorbers to the axle bracket. Connect the track bar to the frame rail bracket.
- (4) Remove the supports and lower the vehicle.
- (5) Tighten the stabilizer bar links, shock absorbers and track bar to specified torque.

## REMOVAL AND INSTALLATION (Continued)

## LOWER SUSPENSION ARM

## REMOVAL

- (1) Raise and support the vehicle.
- (2) Remove the lower suspension arm nut and bolt at the axle bracket (Fig. 2).
- (3) Remove the nut and bolt at the frame rail mount (Fig. 3) and remove the lower suspension arm.




80a13815

**Fig. 2 Upper & Lower Suspension Arms**

- 1 - UPPER SUSPENSION ARM
- 2 - REAR AXLE
- 3 - LOWER SUSPENSION ARM

## INSTALLATION



80a13816

**Fig. 3 Upper & Lower Suspension Arms**

- 1 - FRAME MOUNT
- 2 - UPPER SUSPENSION ARM
- 3 - LOWER SUSPENSION ARM

- (1) Position the lower suspension arm in the axle bracket and frame rail mount.

- (2) Install the mounting bolts and finger tighten the nuts.


- (3) Remove the supports and lower the vehicle.

- (4) Tighten the lower suspension arm nuts to 177 N·m (130 ft. lbs.).

## UPPER SUSPENSION ARM

## REMOVAL

- (1) Raise and support the vehicle.
- (2) Remove the parking brake cable/bracket and ABS wiring bracket from the arm if equipped (Fig. 4).



80a1c39b

**Fig. 4 Parking Brake Cable/Bracket And Wiring Bracket**

- 1 - UPPER SUSPENSION ARM
- 2 - WIRING BRACKET
- 3 - PARKING BRAKE CABLE BRACKET

- (3) Remove the upper suspension arm nut and bolt from the axle bracket (Fig. 2).

- (4) Remove the nut and bolt from the frame rail bracket (Fig. 3) and remove the upper suspension arm.

## INSTALLATION

- (1) Position the upper suspension arm in the axle bracket and frame rail bracket.

- (2) Install the bolts and finger tighten the nuts.

- (3) Install the parking brake cable/bracket and ABS wiring bracket on the arm if equipped.

- (4) Remove the supports and lower the vehicle.

- (5) Tighten the upper suspension arm frame rail bracket bolt to 75 N·m (55 ft. lbs.).

- (6) Tighten the upper suspension arm axle bracket nut to 75 N·m (55 ft. lbs.).

## STABILIZER BAR


## REMOVAL

- (1) Raise and support the vehicle.

- (2) Remove the stabilizer bar link bolts from the frame mounts (Fig. 5).

REMOVAL AND INSTALLATION (Continued)


- (3) Remove the link bolts from the stabilizer bar.
- (4) Remove the stabilizer bar retainer bolts and retainers from the axle mounts (Fig. 6) and remove the bar.



80a13814

**Fig. 5 Stabilizer Bar Link**

- 1 - FRAME MOUNT
- 2 - LINK
- 3 - STABILIZER BAR



80a13813

**Fig. 6 Stabilizer Bar**

- 1 - LINK
- 2 - RETAINER
- 3 - STABILIZER BAR
- 4 - AXLE MOUNT

**INSTALLATION**

- (1) Install the stabilizer bar on the axle mounts and install the retainers and bolts.


**NOTE:** Ensure the bar is centered with equal spacing on both sides and is positioned above the differential housing (Fig. 6).

- (2) Tighten the retainer bolts to 54 N·m (40 ft. lbs.).
- (3) Install the links onto the stabilizer bar and frame mounts. Install the bolts and nuts finger tight.
- (4) Remove support and lower vehicle.
- (5) Tighten the link nuts/bolts to 54 N·m (40 ft. lbs.).

**TRACK BAR**

**REMOVAL**

- (1) Raise and support the vehicle.
- (2) Remove the bolt and nut from the frame rail bracket (Fig. 7).
- (3) Remove the bolt from the axle bracket (Fig. 7) and remove the track bar.



80a13811

**Fig. 7 Rear Track Bar**

- 1 - TRACK BAR
- 2 - FRAME BRACKET
- 3 - REAR AXLE

**INSTALLATION**

- (1) Install the track bar in the axle bracket and install the bolt loosely.
- (2) Install the track bar in the frame rail bracket and loosely install the bolt and nut.

**NOTE:** It may be necessary to pry the axle assembly over to install the track bar.

- (3) Remove supports and lower the vehicle.
- (4) Tighten the track bar nut/bolt at both ends to 100 N·m (74 ft. lbs.).

## SPECIFICATIONS

## TORQUE CHART

| DESCRIPTION                  | TORQUE                 |
|------------------------------|------------------------|
| <b>Shock Absorber</b>        |                        |
| Upper Bolts . . . . .        | 31 N·m (23 ft. lbs.)   |
| Lower Nut . . . . .          | 100 N·m (74 ft. lbs.)  |
| <b>Suspension Arm Lower</b>  |                        |
| Axle Bracket Nut . . . . .   | 177 N·m (130 ft. lbs.) |
| Frame Bracket Nut . . . . .  | 177 N·m (130 ft. lbs.) |
| <b>Suspension Arm Upper</b>  |                        |
| Axle Bracket Nut . . . . .   | 75 N·m (55 ft. lbs.)   |
| Frame Bracket Bolt . . . . . | 75 N·m (55 ft. lbs.)   |
| <b>Stabilizer Bar</b>        |                        |
| Retainer Bolts . . . . .     | 54 N·m (40 ft. lbs.)   |
| Link Nut/Bolt . . . . .      | 54 N·m (40 ft. lbs.)   |
| <b>Track Bar</b>             |                        |
| Frame Bracket Nut . . . . .  | 100 N·m (74 ft. lbs.)  |
| Axle Bracket Bolt . . . . .  | 100 N·m (74 ft. lbs.)  |

# DIFFERENTIAL AND DRIVELINE

## TABLE OF CONTENTS

|                        | page |                         | page |
|------------------------|------|-------------------------|------|
| PROPELLER SHAFTS ..... | 1    | 194 RBI AXLE .....      | 52   |
| 181 FBI AXLE .....     | 16   | 216 RBI REAR AXLE ..... | 91   |

## PROPELLER SHAFTS

### TABLE OF CONTENTS

|   | page |                                      | page |
|---|------|--------------------------------------|------|
| <b>DESCRIPTION AND OPERATION</b>        |      |                                      |      |
| PROPELLER SHAFT .....                   | 1    | REAR PROPELLER SHAFT .....           | 8    |
| PROPELLER SHAFT JOINTS .....            | 3    | <b>DISASSEMBLY AND ASSEMBLY</b>      |      |
| PROPELLER SHAFT JOINT ANGLE .....       | 3    | SINGLE CARDAN UNIVERSAL JOINT .....  | 9    |
| <b>DIAGNOSIS AND TESTING</b>            |      |                                      |      |
| VIBRATION .....                         | 4    | DOUBLE CARDAN JOINT .....            | 10   |
| UNBALANCE .....                         | 5    | <b>CLEANING AND INSPECTION</b>       |      |
| RUNOUT .....                            | 5    | SINGLE AND DOUBLE CARDAN JOINT ..... | 14   |
| <b>SERVICE PROCEDURES</b>               |      |                                      |      |
| DRIVELINE ANGLE MEASUREMENT             |      | <b>ADJUSTMENTS</b>                   |      |
| PREPARATION .....                       | 6    | AXLE PINION ANGLE ADJUSTMENT .....   | 15   |
| PROPELLER SHAFT ANGLE MEASUREMENT ..... | 6    | <b>SPECIFICATIONS</b>                |      |
| <b>REMOVAL AND INSTALLATION</b>         |      |                                      |      |
| FRONT PROPELLER SHAFT .....             | 8    | TORQUE .....                         | 15   |
|   |      | <b>SPECIAL TOOLS</b>                 |      |
|   |      | PROPELLER SHAFT .....                | 15   |

### DESCRIPTION AND OPERATION

#### PROPELLER SHAFT

##### DESCRIPTION

A propeller shaft (Fig. 2) is the shaft which connects the transmission/transfer case to the axle differential. This is the link through which the engine power is transmitted to the axle.

The propeller shaft is designed and built with the yoke lugs in line with each other which is called zero phasing. This design produces the smoothest running condition, an out-of-phase shaft can cause a vibration.

Tubular propeller shafts are balanced by the manufacturer with weights spot welded to the tube.


##### PRECAUTIONS

Use the exact replacement parts when installing the propeller shafts. The use of the correct replacement parts helps to ensure safe operation. All fasteners must be torqued to the specified values for safe operation.

Also make alignment reference marks (Fig. 1) on the propeller shaft yoke and axle, or transmission, yoke prior to servicing. This helps to eliminate possible vibration.

**CAUTION:** Do not allow the propeller shaft to drop or hang from any propeller shaft joint during removal. Attach the propeller shaft to the vehicle underside with wire to prevent damage to the joints.

DESCRIPTION AND OPERATION (Continued)



J9316-2

**Fig. 1 Reference Marks on Yokes**


1 - REFERENCE MARKS

**OPERATION**

The propeller shaft must operate through constantly changing relative angles between the transmission and axle when going over various road surfaces. It must also be capable of changing length while transmitting torque. The axle rides suspended by springs in a floating motion. This is accomplished through universal joints, which permit the propeller shaft to operate at different angles. The slip joints (or yokes) permit contraction or expansion (Fig. 2).

**Before undercoating a vehicle, the propeller shaft and the U-joints should be covered to prevent an out-of-balance condition and driveline vibration.**

**CAUTION:** Use original equipment replacement parts for attaching the propeller shafts. The specified torque must always be applied when tightening the fasteners.



80a53ac2

**Fig. 2 Propeller Shafts**

- 1 - FRONT AXLE
- 2 - FRONT PROPELLER SHAFT
- 3 - TRANSFER CASE
- 4 - BOOT


- 5 - REAR AXLE
- 6 - STRAP
- 7 - REAR PROPELLER SHAFT
- 8 - STRAP

DESCRIPTION AND OPERATION (Continued)

**PROPELLER SHAFT JOINTS**

**DESCRIPTION**

Two different types of propeller shaft joints are used in TJ vehicles (Fig. 3) and (Fig. 4). None of the joints are serviceable. If worn or damaged, they must be replaced as a complete assembly.



J9516-9

**Fig. 3 Single Cardan U-Joint**

- 1 - CROSS
- 2 - SEAL
- 3 - CAP AND NEEDLE BEARINGS

**LUBRICATION**

The factory installed universal joints are lubricated for the life of the vehicle and do not need lubrication. All universal joints should be inspected for leakage and damage each time the vehicle is serviced. If seal leakage or damage exists, the universal joint should be replaced.

**PROPELLER SHAFT JOINT ANGLE**


**DESCRIPTION**

When two shafts come together at a common joint, the bend that is formed is called the operating angle. The larger the angle, the larger the amount of angular acceleration and deceleration of the joint. This speeding up and slowing down of the joint must be cancelled to produce a smooth power flow.

**OPERATION**

This cancellation is done through the phasing of a propeller shaft and ensuring that the proper propeller shaft joint working angles are maintained.

A propeller shaft is properly phased when the yoke ends are in the same plane, or in line. A twisted shaft will make the yokes out of phase and cause a noticeable vibration.



- |                         |                 |                      |
|-------------------------|-----------------|----------------------|
| 1. LINK YOKE            | 6. SEAL         | 11. FRONT SPIDER     |
| 2. SOCKET SPRING        | 7. BEARING CAP  | 12. NEEDLE BEARINGS  |
| 3. SOCKET BALL RETAINER | 8. REAR SPIDER  | 13. THRUST WASHER    |
| 4. THRUST WASHER        | 9. SOCKET YOKE  | 14. DRIVE SHAFT YOKE |
| 5. NEEDLE BEARINGS      | 10. SOCKET BALL | 15. RETAINING CLIP   |

J9216-21

**Fig. 4 Double Cardan U-Joint**

DESCRIPTION AND OPERATION (Continued)

When taking propeller shaft joint angle measurements, or checking the phasing, of two piece shafts, consider each shaft separately.

Ideally the driveline system should have;

- Angles that are equal or opposite within 1 degree of each other.
- Have a 3 degree maximum operating angle.
- Have at least a 1/2 degree continuous operating (propeller shaft) angle.

Propeller shaft speed (rpm) is the main factor in determining the maximum allowable operating angle. As a guide to the maximum normal operating angles refer to (Fig. 5).

| PROPELLER SHAFT<br>R.P.M. | MAX. NORMAL<br>OPERATING ANGLES |
|---------------------------|---------------------------------|
| 5000                      | 3°                              |
| 4500                      | 3°                              |
| 4000                      | 4°                              |
| 3500                      | 5°                              |
| 3000                      | 5°                              |
| 2500                      | 7°                              |
| 2000                      | 8°                              |
| 1500                      | 11°                             |

**Fig. 5 Maximum Angles And Propeller Shaft Speed**

Driveline vibration can also result from loose or damaged engine mounts. Refer to Group 9, Engines, for additional information.

Propeller shaft vibration increases as the vehicle speed is increased. A vibration that occurs within a specific speed range is not usually caused by a propeller shaft being unbalanced. Defective universal joints, or an incorrect propeller shaft angle, are usually the cause of such a vibration.

DIAGNOSIS AND TESTING

VIBRATION

Tires that are out-of-round, or wheels that are unbalanced, will cause a low frequency vibration. Refer to Group 22, Tires and Wheels, for additional information.

Brake drums that are unbalanced will cause a harsh, low frequency vibration. Refer to Group 5, Brakes, for additional information.

DRIVELINE VIBRATION

| Drive Condition       | Possible Cause  | Correction   |
|-----------------------|---|--|
| Propeller Shaft Noise | 1) Undercoating or other foreign material on shaft.<br>2) Loose U-joint clamp screws.<br>3) Loose or bent U-joint yoke or excessive runout.<br>4) Incorrect driveline angularity.<br>5) Rear spring center bolt not in seat.<br>6) Worn U-joint bearings.<br>7) Propeller shaft damaged or out of balance.<br>8) Broken rear spring.<br>9) Excessive runout or unbalanced condition.<br>10) Excessive drive pinion gear shaft runout.<br>11) Excessive axle yoke deflection.<br>12) Excessive transfer case runout. | 1) Clean exterior of shaft and wash with solvent.<br>2) Install new clamps and screws and tighten to proper torque.<br>3) Install new yoke.<br>4) Measure and correct driveline angles.<br>5) Loosen spring u-bolts and seat center bolt.<br>6) Install new U-joint.<br>7) Install new propeller shaft.<br>8) Install new rear spring.<br>9) Re-index propeller shaft, test, and evaluate.<br>10) Re-index propeller shaft and evaluate.<br>11) Inspect and replace yoke if necessary.<br>12) Inspect and repair as necessary. |
| Universal Joint Noise | 1) Loose U-joint clamp screws.<br>2) Lack of lubrication.   | 1) Install new clamps and screws and tighten to proper torque.<br>2) Replace as U-joints as necessary.   |


## DIAGNOSIS AND TESTING (Continued)

## UNBALANCE

**NOTE:** Removing and re-indexing the propeller shaft 180° relative to the yoke may eliminate some vibrations.

If propeller shaft is suspected of being unbalanced, it can be verified with the following procedure:

- (1) Raise the vehicle.
- (2) Clean all the foreign material from the propeller shaft and the universal joints.
- (3) Inspect the propeller shaft for missing balance weights, broken welds, and bent areas. **If the propeller shaft is bent, it must be replaced.**
- (4) Inspect the universal joints to ensure that they are not worn, are properly installed, and are correctly aligned with the shaft.
- (5) Check the universal joint clamp screws torque.
- (6) Remove the wheels and tires. Install the wheel lug nuts to retain the brake drums or rotors.
- (7) Mark and number the shaft six inches from the yoke end at four positions 90° apart.
- (8) Run and accelerate the vehicle until vibration occurs. Note the intensity and speed the vibration occurred. Stop the engine.
- (9) Install a screw clamp at position 1 (Fig. 6).




**Fig. 6 Clamp Screw At Position 1**

- 1 - CLAMP  
2 - SCREWDRIVER

(10) Start the engine and re-check for vibration. If there is little or no change in vibration, move the clamp to one of the other three positions. Repeat the vibration test.

(11) If there is no difference in vibration at the other positions, the source of the vibration may not be propeller shaft.


(12) If the vibration decreased, install a second clamp (Fig. 7) and repeat the test.



RF488

**Fig. 7 Two Clamp Screws At The Same Position**

(13) If the additional clamp causes an additional vibration, separate the clamps (1/4 inch above and below the mark). Repeat the vibration test (Fig. 8).



RF489

**Fig. 8 Clamp Screws Separated**

1 - 1/2 INCH

(14) Increase distance between the clamp screws and repeat the test until the amount of vibration is at the lowest level. Bend the slack end of the clamps so the screws will not loosen.

(15) If the vibration remains unacceptable, apply the same steps to the front end of the propeller shaft.

(16) Install the wheel and tires. Lower the vehicle.

## RUNOUT

(1) Remove dirt, rust, paint, and undercoating from the propeller shaft surface where the dial indicator will contact the shaft.

(2) The dial indicator must be installed perpendicular to the shaft surface.

(3) Measure runout at the center and ends of the shaft sufficiently far away from weld areas to ensure

## DIAGNOSIS AND TESTING (Continued)

that the effects of the weld process will not enter into the measurements.

(4) Refer to Runout Specifications chart.

(5) If the propeller shaft runout is out of specification, remove the propeller shaft, index the shaft 180°, and re-install the propeller shaft. Measure shaft runout again.

(6) If the propeller shaft runout is now within specifications, mark the shaft and yokes for proper orientation.

(7) If the propeller shaft runout is not within specifications, verify that the runout of the transmission/transfer case and axle are within specifications. Correct as necessary and re-measure propeller shaft runout.

(8) Replace the propeller shaft if the runout still exceeds the limits.

## RUNOUT SPECIFICATIONS

|   |                     |
|---|---------------------|
| Front of Shaft  | 0.020 in. (0.50 mm) |
| Center of Shaft   | 0.025 in. (0.63 mm) |
| Rear of Shaft   | 0.020 in. (0.50 mm) |
| Measure front/rear runout approximately 3 inches (76 mm) from the weld seam at each end of the shaft tube for tube lengths over 30 inches. For tube lengths under 30 inches, the maximum allowed runout is 0.020 in. (0.50 mm) for the full length of the tube. |                     |

## SERVICE PROCEDURES

DRIVELINE ANGLE MEASUREMENT  
PREPARATION

Before measuring universal joint angles, the following must be done;

- Inflate all tires to correct pressure.
- Check the angles in the same loaded or unloaded condition as when the vibration occurred. Propeller shaft angles change according to the amount of load in the vehicle.
- Check the condition of all suspension components and verify all fasteners are torqued to specifications.
- Check the condition of the engine and transmission mounts and verify all fasteners are torqued to specifications.

## PROPELLER SHAFT ANGLE MEASUREMENT

To accurately check driveline alignment, raise and support the vehicle at the axles as level as possible. Allow the wheels and propeller shaft to turn.


(1) Remove any external bearing snap rings, if equipped, from universal joint so protractor base sits flat.

(2) Rotate the shaft until transmission/transfer case output yoke bearing is facing downward.

**Always make measurements from front to rear. Also, be sure to take all measurements while working from the same side of the vehicle.**

(3) Place Inclinator on yoke bearing (A) parallel to the shaft (Fig. 9). Center bubble in sight glass and record measurement.

**This measurement will give you the transmission or Output Yoke Angle (A).**



J9216-13

**Fig. 9 Front (Output) Angle Measurement (A)**

- 1 - SLIP YOKE BEARING CAP  
2 - SPECIAL TOOL 7663 (J-23498A)

(4) Rotate propeller shaft 90 degrees and place Inclinator on yoke bearing parallel to the shaft (Fig. 10). Center bubble in sight glass and record measurement. This measurement can also be taken at the rear end of the shaft.

**This measurement will give you the Propeller Shaft Angle (C).**

(5) Subtract smaller figure from larger (C minus A) to obtain Transmission Output Operating Angle.


(6) Rotate propeller shaft 90 degrees and place Inclinator on pinion yoke bearing parallel to the shaft (Fig. 11). Center bubble in sight glass and record measurement.

**This measurement will give you the pinion shaft or Input Yoke Angle (B).**

(7) Subtract smaller figure from larger (C minus B) to obtain axle Input Operating Angle.

Refer to rules given below and the example in (Fig. 12) for additional information.


SERVICE PROCEDURES (Continued)



J9216-9

**Fig. 10 Propeller Shaft Angle Measurement (C)**


- 1 - SHAFT YOKE BEARING CAP
- 2 - SPECIAL TOOL 7663 (J23498-A)



J9216-12

**Fig. 11 Rear (Input) Angle Measurement (B)**

- 1 - PINION YOKE BEARING CAP
- 2 - SPECIAL TOOL 7663 (J-23498A)



Horizontal Level

- (A) Output Yoke = 3.0° or 4.9°
- (C) Prop. Shaft = 4.9° or -3.0°

Transmission Output Operating Angle 1.9°

- (B) Axle Input Yoke = 3.2° or 4.9°
- (C) Prop. Shaft = 4.9° or -3.2°

Axle Input Operating Angle 1.7°

Trans. Output Operating Angle 1.9°  
 Axle Input Operating Angle -1.7°  
 Amount of U-Joint Cancellation 0.2°

J9316-3

**Fig. 12 Universal Joint Angle Example**

- 1 - 4.9° Angle (C)
- 2 - 3.2° Angle (B)
- 3 - Input Yoke
- 4 - 3.0° Angle (A)
- 5 - Output Yoke

## SERVICE PROCEDURES (Continued)


- Good cancellation of U-joint operating angles (within 1°).
- Operating angles less than 3°.
- At least 1/2 of one degree continuous operating (propeller shaft) angle.

## REMOVAL AND INSTALLATION

## FRONT PROPELLER SHAFT

## REMOVAL

- (1) Hoist and support vehicle on safety stands.
- (2) Remove the crossmember/skid plate as necessary to gain access to the propeller shaft.
- (3) Shift the transmission and transfer case, if necessary, into the Neutral position.
- (4) Using a suitable marker, mark a line across the yoke at the transfer case, the link yoke, and propeller shaft yoke at the rear of the front propeller shaft for installation reference (Fig. 13).
- (5) Mark a line across the propeller shaft yoke and the pinion shaft yoke for installation reference.



J9316-2


**Fig. 13 Reference Marks on Yokes**

1 - REFERENCE MARKS

- (6) Remove the U-joint strap bolts at the pinion shaft yoke (Fig. 14).
- (7) Remove bolts holding rear universal joint to the transfer case yoke.
- (8) Separate the rear universal joint from the transfer case yoke.
- (9) Push rear of propeller shaft upward to clear transfer case yoke.
- (10) Separate front universal joint from front axle.
- (11) Separate propeller shaft from vehicle.

## INSTALLATION

- (1) Position front propeller shaft under vehicle with rear universal joint over the transfer case yoke.



80a53482

**Fig. 14 Front Propeller Shaft**

- 1 - FRONT AXLE
- 2 - BOOT
- 3 - PROPELLER SHAFT
- 4 - CV-JOINT
- 5 - TRANSFER CASE
- 6 - BOOT
- 7 - SLINGER
- 8 - CLAMP
- 9 - YOKE


- (2) Place front universal joint into the axle pinion yoke.
- (3) Align mark on the rear link yoke and universal joint to the mark on the transfer case yoke (Fig. 13).
- (4) Loosely install bolts to hold universal joint to transfer case yoke.
- (5) Align mark on front universal joint to the mark on the axle pinion yoke.
- (6) Tighten the U-joint strap/clamp bolts at the axle yoke to 19 N·m (14 ft. lbs.) torque.
- (7) Tighten the universal joint to transfer case bolts to 27 N·m (20 ft. lbs.) torque.
- (8) Lower the vehicle.

## REAR PROPELLER SHAFT

## REMOVAL

- (1) Shift the transmission and transfer case into Neutral.
- (2) Hoist and support vehicle on safety stands.
- (3) Scribe alignment marks at the pinion shaft and at each end of the propeller shaft. These marks will be used for installation reference.
- (4) Remove the U-joint strap bolts at the pinion shaft yoke.
- (5) Pry open clamp holding the dust boot to propeller shaft yoke (Fig. 15).
- (6) Slide the slip yoke off of the transmission/transfer case output shaft and remove the propeller shaft (Fig. 16).


REMOVAL AND INSTALLATION (Continued)



**Fig. 15 Dust Boot Clamp**


- 1 - SLINGER
- 2 - BOOT
- 3 - AWL
- 4 - TRANSFER CASE

(4) Lower the vehicle.



**Fig. 17 Crimping Dust Boot Clamp**

- 1 - SPECIAL TOOL C-4975-A
- 2 - SLINGER
- 3 - BOOT
- 4 - CLAMP



**Fig. 16 Rear Propeller Shaft**

- 1 - CLAMP
- 2 - YOKE
- 3 - PROPELLER SHAFT
- 4 - AXLE YOKE
- 5 - CLAMP
- 6 - OUTPUT SHAFT
- 7 - BOOT

**INSTALLATION**

(1) Slide the slip yoke on the transmission/transfer case output shaft. Align the installation reference marks at the axle yoke and install the propeller shaft (Fig. 16).

(2) Tighten the U-joint strap/clamp bolts at the axle yoke to 19 N·m (14 ft. lbs.) torque.

(3) Crimp clamp to hold dust boot to propeller shaft yoke (Fig. 17).

**DISASSEMBLY AND ASSEMBLY**

**SINGLE CARDAN UNIVERSAL JOINT**

**DISASSEMBLY**

Individual components of cardan universal joints are not serviceable. If worn or leaking, they must be replaced as an assembly.

(1) Remove the propeller shaft.

(2) Using a soft drift, tap the outside of the bearing cap assembly to loosen snap ring.

(3) Remove snap rings from both sides of yoke (Fig. 18).

(4) Set the yoke in an arbor press or vise with a socket whose inside diameter is large enough to receive the bearing cap positioned beneath the yoke.


(5) Position the yoke with the grease fitting, if equipped, pointing up.

(6) Place a socket with an outside diameter smaller than the upper bearing cap on the upper bearing cap and press the cap through the yoke to release the lower bearing cap (Fig. 19).



(7) If the bearing cap will not pull out of the yoke by hand after pressing, tap the yoke ear near the bearing cap to dislodge the cap.

(8) To remove the opposite bearing cap, turn the yoke over and straighten the cross in the open hole. Then, carefully press the end of the cross until the remaining bearing cap can be removed (Fig. 20).

## DISASSEMBLY AND ASSEMBLY (Continued)

**Fig. 18 Remove Snap Ring**

1 - SNAP RING

**Fig. 20 Press Out Remaining Bearing**1 - CROSS  
2 - BEARING CAP**Fig. 19 Press Out Bearing**1 - PRESS  
2 - SOCKET

**CAUTION:** If the cross or bearing cap are not straight during installation, the bearing cap will score the walls of the yoke bore and damage can occur.

80a9539c

**ASSEMBLY**


- (1) Apply extreme pressure (EP) N.L.G.I. Grade 1 or 2 grease to inside of yoke bores to aid in installation.
- (2) Position the cross in the yoke with its lube fitting, if equipped, pointing up (Fig. 21).
- (3) Place a bearing cap over the trunnion and align the cap with the yoke bore (Fig. 22). Keep the needle bearings upright in the bearing assembly. A needle bearing lying at the bottom of the cap will prevent proper assembly.
- (4) Press the bearing cap into the yoke bore enough to install a snap ring.
- (5) Install a snap ring.
- (6) Repeat Step 3 and Step 4 to install the opposite bearing cap. If the joint is stiff or binding, strike the yoke with a soft hammer to seat the needle bearings.
- (7) Add grease to lube fitting, if equipped.
- (8) Install the propeller shaft.

**DOUBLE CARDAN JOINT****DISASSEMBLY**

Individual components of cardan universal joints are not serviceable. If worn or leaking, they must be replaced as an assembly.

- (1) Remove the propeller shaft.
- (2) Using a soft drift, tap the outside of the bearing cap assembly to loosen snap ring.


DISASSEMBLY AND ASSEMBLY (Continued)



J9316-22

**Fig. 21 Install Cross In Yoke**

- 1 - CROSS
- 2 - YOKE




J9316-5

**Fig. 23 Remove Snap Rings**

receive the bearing cap positioned beneath the link yoke.

(5) Place a socket with an outside diameter smaller than the upper bearing cap on the upper bearing cap and partially press one bearing cap from the outboard side of the link yoke enough to grasp the bearing cap with vise jaws (Fig. 24). Be sure to remove grease fittings that interfere with removal.




80a9539b

**Fig. 22 Install Bearing On Trunnion**

- 1 - BEARING CAP
- 2 - TRUNNION

(3) Remove all the bearing cap snap rings (Fig. 23).

(4) Set the joint in an arbor press or vise with a socket whose inside diameter is large enough to




J9316-6

**Fig. 24 Press Out Bearing**

(6) Grasp the protruding bearing by vise jaws. Tap the link yoke with a mallet and drift to dislodge the bearing cap from the yoke (Fig. 25).


## DISASSEMBLY AND ASSEMBLY (Continued)



J9316-7

**Fig. 25 Remove Bearing From Yoke**

(7) Flip assembly and repeat Step 4, Step 5, and Step 6 to remove the opposite bearing cap. This will then allow removal of the cross centering kit assembly and spring (Fig. 26).



J9316-8


**Fig. 26 Remove Centering Kit**

(8) Press the remaining bearing caps out the other end of the link yoke as described above to complete the disassembly.

**ASSEMBLY**

**During assembly, ensure that the alignment marks on the link yoke and propeller shaft yoke are aligned.**


- (1) Apply extreme pressure (EP) N.L.G.I. Grade 1 or 2 grease to inside of yoke bores to aid in installation.
- (2) Fit a cross into the propeller shaft yoke (Fig. 27).



J9316-9

**Fig. 27 Install Cross In Yoke**

(3) Place a bearing cap over the trunnion and align the cap with the yoke bore (Fig. 28). Keep the needle bearings upright in the bearing assembly. A needle bearing lying at the bottom of the cap will prevent proper assembly.




J9316-10

**Fig. 28 Install Bearing Cap**


DISASSEMBLY AND ASSEMBLY (Continued)

- (4) Press the bearing cap into the yoke bore enough to install a snap ring (Fig. 29).
- (5) Install a snap ring.




**Fig. 29 Press In Bearing Cap**

- (6) Flip the propeller shaft yoke and install the bearing cap onto the opposite trunnion. Install a snap ring (Fig. 30).



**Fig. 30 Press In Bearing Cap**


- (7) Fit the link yoke on the remaining two trunnions and press both bearing caps into place (Fig. 31).
- (8) Install snap rings.



J9316-13

**Fig. 31 Install Link Yoke**

- (9) Install the centering kit assembly inside the link yoke making sure the spring is properly positioned (Fig. 32).




J9316-14

**Fig. 32 Install Centering Kit**

## DISASSEMBLY AND ASSEMBLY (Continued)


(10) Place two bearing caps on opposite trunnions of the remaining cross. Fit the open trunnions into the link yoke bores and the bearing caps into the centering kit (Fig. 33).



J9316-15

**Fig. 33 Install Remaining Cross**

(11) Press the remaining two bearing caps into place and install snap rings (Fig. 34).




J9316-16

**Fig. 34 Press In Bearing Cap**

(12) Tap the snap rings to allow them to seat into the grooves (Fig. 35).


(13) Check for proper assembly. Flex the joint beyond center, it should snap over-center in both directions when correctly assembled (Fig. 36).

(14) Install the propeller shaft.



J9316-17

**Fig. 35 Seat Snap Rings In Groove**



J9316-18

**Fig. 36 Check Assembly**

## CLEANING AND INSPECTION

## SINGLE AND DOUBLE CARDAN JOINT

(1) Clean all the universal joint yoke bores with cleaning solvent and a wire brush.


(2) Inspect the yokes for distortion, cracks, and worn bearing cap bores.

## ADJUSTMENTS

### AXLE PINION ANGLE ADJUSTMENT

The pinion angle of the front axle can be adjusted by the use of adjustment cams in the lower suspension arms (Fig. 37). The primary function for the cams is to adjust the caster angle for the alignment of the front suspension. When using the cams to adjust the pinion angle, make sure that both cams are moved equally. After the pinion angle is adjusted, the front suspension alignment should be checked to ensure that side-to-side caster angles variance is within the acceptable range. Having the correct pinion angle does have priority over having the preferred caster angle.

A cam kit is available to be installed in the rear axle upper suspension arms in order to provide adjustability of the pinion angle. Follow the procedures supplied with the kit in order to ensure a safe installation.



J9302-59

**Fig. 37 Adjustment Cam**

- 1 - ADJUSTMENT CAM
- 2 - AXLE BRACKET
- 3 - BRACKET REINFORCEMENT
- 4 - LOWER SUSPENSION ARM


## SPECIFICATIONS

### TORQUE


| DESCRIPTION                        | TORQUE               |
|------------------------------------|----------------------|
| <b>Front Propeller Shaft</b>       |                      |
| <b>Bolts, Rear Yoke</b> . . . . .  | 27 N·m (20 ft. lbs.) |
| <b>Bolts, Front Yoke</b> . . . . . | 41 N·m (30 ft. lbs.) |
| <b>Rear Propeller Shaft</b>        |                      |
| <b>Bolts, Rear Yoke</b> . . . . .  | 19 N·m (14 ft. lbs.) |

### SPECIAL TOOLS

#### PROPELLER SHAFT



*Inclinometer—7663*



*Boot Clamp Installer—C-4975-A*

# 181 FBI AXLE

## TABLE OF CONTENTS

|                                      | page |   | page |
|--------------------------------------|------|---|------|
| <b>DESCRIPTION AND OPERATION</b>     |      | <b>DIFFERENTIAL</b> .....               | 30   |
| 181 FBI AXLE.....                    | 16   | <b>DIFFERENTIAL SIDE BEARINGS</b> ..... | 33   |
| LUBRICANT.....                       | 17   | <b>AXLE SHAFT OIL SEAL</b> .....        | 33   |
| STANDARD DIFFERENTIAL.....           | 17   | <b>PINION</b> .....                     | 33   |
| <b>DIAGNOSIS AND TESTING</b>         |      | <b>RING GEAR</b> .....                  | 38   |
| GENERAL INFORMATION .....            | 18   | <b>DISASSEMBLY AND ASSEMBLY</b>         |      |
| GEAR NOISE.....                      | 20   | STANDARD DIFFERENTIAL.....              | 39   |
| BEARING NOISE.....                   | 20   | FINAL ASSEMBLY .....                    | 40   |
| LOW SPEED KNOCK.....                 | 20   | <b>CLEANING AND INSPECTION</b>          |      |
| VIBRATION .....                      | 20   | CARDAN U-JOINT .....                    | 40   |
| DRIVELINE SNAP .....                 | 21   | AXLE COMPONENTS .....                   | 40   |
| <b>SERVICE PROCEDURES</b>            |      | <b>ADJUSTMENTS</b>                      |      |
| LUBRICANT CHANGE .....               | 21   | PINION GEAR DEPTH.....                  | 41   |
| <b>REMOVAL AND INSTALLATION</b>      |      | DIFFERENTIAL BEARING PRELOAD AND        |      |
| FRONT AXLE.....                      | 21   | GEAR BACKLASH.....                      | 43   |
| AXLE SHAFT—CARDAN U-JOINT .....      | 22   | GEAR CONTACT PATTERN ANALYSIS .....     | 47   |
| PINION SHAFT SEAL.....               | 23   | <b>SPECIFICATIONS</b>                   |      |
| COLLAPSIBLE SPACER.....              | 25   | 181 FBI AXLE.....                       | 49   |
| HUB BEARING AND AXLE SHAFT.....      | 27   | TORQUE .....                            | 49   |
| STEERING KNUCKLE AND BALL STUDS..... | 28   | <b>SPECIAL TOOLS</b>                    |      |
| AXLE BUSHING REPLACEMENT.....        | 30   | 181 FBI AXLE.....                       | 49   |

## DESCRIPTION AND OPERATION

### 181 FBI AXLE

#### DESCRIPTION

The 181 Front Beam-design Iron (FBI) axle consists of a cast iron differential housing with axle shaft tubes extending from either side. The tubes are pressed into the differential housing and welded.

The integral type housing, hypoid gear design has the centerline of the pinion set below the centerline of the ring gear.

The axle has a fitting for a vent hose used to relieve internal pressure caused by lubricant vaporization and internal expansion.

The axles are equipped with semi-floating axle shafts, meaning that loads are supported by the hub bearings. The axle shafts are retained by nuts at the hub bearings. The hub bearings are bolted to the steering knuckle at the outboard end of the axle tube yoke. The hub bearings are serviced as an assembly.

For vehicles with ABS brakes, the ABS wheel speed sensors are attached to the knuckle assemblies. The tone rings for the ABS system are pressed onto the axle shaft. **Do not damage ABS tone wheel or the sensor when removing axle shafts.**

The stamped steel cover provides a means for inspection and servicing the differential.

The 181 FBI axle has the assembly part number and gear ratio listed on a tag. The tag is attached to the housing cover by a cover bolt. Build date identification codes are stamped on the cover side of the axle shaft tube.

The differential case is a one-piece design. The differential pinion mate shaft is retained with a roll pin. Differential bearing preload and ring gear backlash is adjusted by the use of shims (select thickness). The shims are located between the differential bearing cones and case. Pinion bearing preload is set and maintained by the use of a collapsible spacer.

#### OPERATION

The axle receives power from the transfer case through the front propeller shaft. The front propeller shaft is connected to the pinion gear which rotates the differential through the gear mesh with the ring gear bolted to the differential case. The engine power is transmitted to the axle shafts through the pinion mate and side gears. The side gears are splined to the axle shafts.

DESCRIPTION AND OPERATION (Continued)

**LUBRICANT**

**DESCRIPTION**

A multi-purpose, hypoid gear lubricant which conforms to the following specifications should be used. Mopar® Hypoid Gear Lubricant conforms to all of these specifications.

- The lubricant should have MIL-L-2105C and API GL 5 quality specifications.
- Lubricant is a thermally stable SAE 80W-90 gear lubricant.
- Lubricant for axles intended for heavy-duty or trailer tow use is SAE 75W-140 SYNTHETIC gear lubricant.

The 181 FBI axle lubricant capacity is 1.2 L (2.5 pts.).

**CAUTION:** If axle is submerged in water, lubricant must be replaced immediately to avoid possible premature axle failure.

**STANDARD DIFFERENTIAL**

**DESCRIPTION**

The differential gear system divides the torque between the axle shafts. It allows the axle shafts to rotate at different speeds when turning corners.

Each differential side gear is splined to an axle shaft. The pinion gears are mounted on a pinion mate shaft and are free to rotate on the shaft. The pinion gear is fitted in a bore in the differential case and is positioned at a right angle to the axle shafts.


**OPERATION**

In operation, power flow occurs as follows:

- The pinion gear rotates the ring gear
- The ring gear (bolted to the differential case) rotates the case
- The differential pinion gears (mounted on the pinion mate shaft in the case) rotate the side gears
- The side gears (splined to the axle shafts) rotate the shafts

During straight-ahead driving, the differential pinion gears do not rotate on the pinion mate shaft. This occurs because input torque applied to the gears is divided and distributed equally between the two side gears. As a result, the pinion gears revolve with the pinion mate shaft but do not rotate around it (Fig. 1).


When turning corners, the outside wheel must travel a greater distance than the inside wheel to



**Fig. 1 Differential Operation—Straight Ahead Driving**

- 1 - IN STRAIGHT AHEAD DRIVING EACH WHEEL ROTATES AT 100% OF CASE SPEED
- 2 - PINION GEAR
- 3 - SIDE GEAR
- 4 - PINION GEARS ROTATE WITH CASE

complete a turn. The difference must be compensated for to prevent the tires from scuffing and skidding through turns. To accomplish this, the differential allows the axle shafts to turn at unequal speeds (Fig. 2). In this instance, the input torque applied to the pinion gears is not divided equally. The pinion gears now rotate around the pinion mate shaft in opposite directions. This allows the side gear and axle shaft attached to the outside wheel to rotate at a faster speed.



**Fig. 2 Differential Operation—On Turns**

- 1 - PINION GEARS ROTATE ON PINION SHAFT

## DIAGNOSIS AND TESTING

### GENERAL INFORMATION

Axle bearing problem conditions are usually caused by:

- Insufficient or incorrect lubricant.
- Foreign matter/water contamination.
- Incorrect bearing preload torque adjustment.
- Incorrect backlash.

Axle gear problem conditions are usually the result of:

- Insufficient lubrication.

- Incorrect or contaminated lubricant.
- Overloading (excessive engine torque) or exceeding vehicle weight capacity.

- Incorrect clearance or backlash adjustment.

Axle component breakage is most often the result of:

- Severe overloading.
- Insufficient lubricant.
- Incorrect lubricant.
- Improperly tightened components.
- Differential housing bores not square to each other.

### DIAGNOSTIC CHART

| Condition        | Possible Causes   | Correction  |
|------------------|---|---|
| Wheel Noise      | <ol style="list-style-type: none"> <li>1. Wheel loose.</li> <li>2. Faulty, brinelled wheel bearing.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Tighten loose nuts.</li> <li>2. Replace bearing.</li> </ol>   |
| Axle Shaft Noise | <ol style="list-style-type: none"> <li>1. Misaligned axle tube.</li> <li>2. Bent or sprung axle shaft.</li> <li>3. End-play in pinion bearings.</li> <li>4. Excessive gear backlash between the ring gear and pinion.</li> <li>5. Improper adjustment of pinion gear bearings.</li> <li>6. Loose pinion yoke nut.</li> <li>7. Scuffed gear tooth contact surfaces.</li> </ol> | <ol style="list-style-type: none"> <li>1. Inspect axle tube alignment. Correct as necessary.</li> <li>2. Inspect and correct as necessary.</li> <li>3. Refer to pinion pre-load information and correct as necessary.</li> <li>4. Check adjustment of the ring gear and pinion backlash. Correct as necessary.</li> <li>5. Adjust the pinion bearings pre-load.</li> <li>6. Tighten the pinion yoke nut.</li> <li>7. Inspect and replace as necessary.</li> </ol> |
| Axle Shaft Broke | <ol style="list-style-type: none"> <li>1. Misaligned axle tube.</li> <li>2. Vehicle overloaded.</li> <li>3. Erratic clutch operation.</li> <li>4. Grabbing clutch.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace the broken shaft after correcting tube mis-alignment.</li> <li>2. Replace broken shaft and avoid excessive weight on vehicle.</li> <li>3. Replace broken shaft and avoid or correct erratic clutch operation.</li> <li>4. Replace broken shaft and inspect and repair clutch as necessary.</li> </ol>   |

DIAGNOSIS AND TESTING (Continued)

| Condition                 | Possible Causes   | Correction   |
|---------------------------|---|--|
| Differential Cracked      | <ol style="list-style-type: none"> <li>1. Improper adjustment of the differential bearings.</li> <li>2. Excessive ring gear backlash.</li> <li>3. Vehicle overloaded.</li> <li>4. Erratic clutch operation.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Replace case and inspect gears and bearings for further damage. Set differential bearing pre-load properly.</li> <li>2. Replace case and inspect gears and bearings for further damage. Set ring gear backlash properly.</li> <li>3. Replace case and inspect gears and bearings for further damage. Avoid excessive vehicle weight.</li> <li>4. Replace case and inspect gears and bearings for further damage. Avoid erratic use of clutch.</li> </ol> |
| Differential Gears Scored | <ol style="list-style-type: none"> <li>1. Insufficient lubrication.</li> <li>2. Improper grade of lubricant.</li> <li>3. Excessive spinning of one wheel/tire.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace scored gears. Fill differential with the correct fluid type and quantity.</li> <li>2. Replace scored gears. Fill differential with the correct fluid type and quantity.</li> <li>3. Replace scored gears. Inspect all gears, pinion bores, and shaft for damage. Service as necessary.</li> </ol>  |
| Loss Of Lubricant         | <ol style="list-style-type: none"> <li>1. Lubricant level too high.</li> <li>2. Worn axle shaft seals.</li> <li>3. Cracked differential housing.</li> <li>4. Worn pinion seal.</li> <li>5. Worn/scored yoke.</li> <li>6. Axle cover not properly sealed.</li> </ol> | <ol style="list-style-type: none"> <li>1. Drain lubricant to the correct level.</li> <li>2. Replace seals.</li> <li>3. Repair as necessary.</li> <li>4. Replace seal.</li> <li>5. Replace yoke and seal.</li> <li>6. Remove, clean, and re-seal cover.</li> </ol>  |
| Axle Overheating          | <ol style="list-style-type: none"> <li>1. Lubricant level low.</li> <li>2. Improper grade of lubricant.</li> <li>3. Bearing pre-loads too high.</li> <li>4. Insufficient ring gear backlash.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Fill differential to correct level.</li> <li>2. Fill differential with the correct fluid type and quantity.</li> <li>3. Re-adjust bearing pre-loads.</li> <li>4. Re-adjust ring gear backlash.</li> </ol>  |
| Gear Teeth Broke          | <ol style="list-style-type: none"> <li>1. Overloading.</li> <li>2. Erratic clutch operation.</li> <li>3. Ice-spotted pavement.</li> <li>4. Improper adjustments.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace gears. Examine other gears and bearings for possible damage.</li> <li>2. Replace gears and examine the remaining parts for damage. Avoid erratic clutch operation.</li> <li>3. Replace gears and examine remaining parts for damage.</li> <li>4. Replace gears and examine remaining parts for damage. Ensure ring gear backlash is correct.</li> </ol>  |

## DIAGNOSIS AND TESTING (Continued)

| Condition  | Possible Causes   | Correction   |
|------------|---|--|
| Axle Noise | <ol style="list-style-type: none"> <li>1. Insufficient lubricant.</li> <li>2. Improper ring gear and pinion adjustment.</li> <li>3. Unmatched ring gear and pinion.</li> <li>4. Worn teeth on ring gear and/or pinion.</li> <li>5. Loose pinion bearings.</li> <li>6. Loose differential bearings.</li> <li>7. Mis-aligned or sprung ring gear.</li> <li>8. Loose differential bearing cap bolts.</li> <li>9. Housing not machined properly.</li> </ol> | <ol style="list-style-type: none"> <li>1. Fill differential with the correct fluid type and quantity.</li> <li>2. Check ring gear and pinion contact pattern.</li> <li>3. Replace gears with a matched ring gear and pinion.</li> <li>4. Replace ring gear and pinion.</li> <li>5. Adjust pinion bearing pre-load.</li> <li>6. Adjust differential bearing pre-load.</li> <li>7. Measure ring gear run-out. Replace components as necessary.</li> <li>8. Inspect differential components and replace as necessary. Ensure that the bearing caps are torqued to the proper specification.</li> <li>9. Replace housing.</li> </ol> |

**GEAR NOISE**

Axle gear noise can be caused by insufficient lubricant, incorrect backlash, tooth contact, worn/damaged gears, or the carrier housing not having the proper offset and squareness.

Gear noise usually happens at a specific speed range. The noise can also occur during a specific type of driving condition. These conditions are acceleration, deceleration, coast, or constant load.

When road testing, first warm-up the axle fluid by driving the vehicle at least 5 miles and then accelerate the vehicle to the speed range where the noise is the greatest. Shift out-of-gear and coast through the peak-noise range. If the noise stops or changes greatly:

- Check for insufficient lubricant.
- Incorrect ring gear backlash.
- Gear damage.

Differential side gears and pinions can be checked by turning the vehicle. They usually do not cause noise during straight-ahead driving when the gears are unloaded. The side gears are loaded during vehicle turns. A worn pinion mate shaft can also cause a snapping or a knocking noise.

**BEARING NOISE**

The axle shaft, differential and pinion bearings can all produce noise when worn or damaged. Bearing noise can be either a whining, or a growling sound.

Pinion bearings have a constant-pitch noise. This noise changes only with vehicle speed. Pinion bearing noise will be higher pitched because it rotates at a faster rate. Drive the vehicle and load the differential. If bearing noise occurs, the rear pinion bearing

is the source of the noise. If the bearing noise is heard during a coast, the front pinion bearing is the source.

Worn or damaged differential bearings usually produce a low pitch noise. Differential bearing noise is similar to pinion bearing noise. The pitch of differential bearing noise is also constant and varies only with vehicle speed.

Axle shaft bearings produce noise and vibration when worn or damaged. The noise generally changes when the bearings are loaded. Road test the vehicle. Turn the vehicle sharply to the left and to the right. This will load the bearings and change the noise level. Where axle bearing damage is slight, the noise is usually not noticeable at speeds above 30 mph.

**LOW SPEED KNOCK**

Low speed knock is generally caused by a worn U-joint or by worn side-gear thrust washers. A worn pinion shaft bore will also cause low speed knock.

**VIBRATION**

Vibration at the rear of the vehicle is usually caused by a:

- Damaged drive shaft.
- Missing drive shaft balance weight(s).
- Worn or out-of-balance wheels.
- Loose wheel lug nuts.
- Worn U-joint(s).
- Loose/broken springs.
- Damaged axle shaft bearing(s).
- Loose pinion gear nut.
- Excessive pinion yoke run out.
- Bent axle shaft(s).

## DIAGNOSIS AND TESTING (Continued)

Check for loose or damaged front-end components or engine/transmission mounts. These components can contribute to what appears to be a rear-end vibration. Do not overlook engine accessories, brackets and drive belts.

All driveline components should be examined before starting any repair.

Refer to Group 22, Wheels and Tires, for additional vibration information.

### DRIVELINE SNAP

A snap or clunk noise when the vehicle is shifted into gear (or the clutch engaged), can be caused by:

- High engine idle speed.
- Transmission shift operation.
- Loose engine/transmission/transfer case mounts.
- Worn U-joints.
- Loose spring mounts.
- Loose pinion gear nut and yoke.
- Excessive ring gear backlash.
- Excessive side gear to case clearance.

The source of a snap or a clunk noise can be determined with the assistance of a helper. Raise the vehicle on a hoist with the wheels free to rotate. Instruct the helper to shift the transmission into gear. Listen for the noise, a mechanics stethoscope is helpful in isolating the source of a noise.

## SERVICE PROCEDURES

### LUBRICANT CHANGE


- (1) Raise and support the vehicle.
- (2) Remove the lubricant fill hole plug from the differential housing cover.
- (3) Remove the differential housing cover and drain the lubricant from the housing.
- (4) Clean the housing cavity with a flushing oil, light engine oil or lint free cloth. **Do not use water, steam, kerosene or gasoline for cleaning.**
- (5) Remove the sealant from the housing and cover surfaces. Use solvent to clean the mating surfaces.
- (6) Apply a bead of Mopar® Silicone Rubber Sealant, or equivalent, to the housing cover (Fig. 3).

**Install the housing cover within 5 minutes after applying the sealant.**

(7) Install the cover and any identification tag. Tighten the cover bolts in a criss-cross pattern to 41 N·m (30 ft. lbs.) torque.

(8) Refill the differential with Mopar® Hypoid Gear Lubricant, or equivalent, to bottom of the fill plug hole. Refer to the Lubricant Specifications in this group for the quantity necessary.

(9) Install the fill hole plug and lower the vehicle. Tighten fill plug to 34 N·m (25 ft. lbs.).



J9302-30

**Fig. 3 Typical Housing Cover With Sealant**

- 1 - SEALING SURFACE  
 2 - CONTOUR OF BEAD  
 3 - BEAD THICKNESS 6.35MM (1/4")

## REMOVAL AND INSTALLATION

### FRONT AXLE

#### REMOVAL

- (1) Raise and support the vehicle.
- (2) Position a suitable lifting device under the axle.
- (3) Secure axle to device.
- (4) Remove the wheels and tires.
- (5) Remove the brake rotors and calipers from the axle. Refer to Group 5, Brakes, for proper procedures.
- (6) Disconnect the wheel sensor wiring harness from the vehicle wiring harness, if necessary.
- (7) Disconnect the vent hose from the axle shaft tube.
- (8) Mark the propeller shaft and yoke for installation alignment reference.
- (9) Remove propeller shaft.
- (10) Disconnect stabilizer bar links at the axle.
- (11) Disconnect shock absorbers from axle brackets.
- (12) Disconnect track bar.
- (13) Disconnect the tie rod and drag link from the steering knuckle. Refer to Group 2, Suspension, for proper procedures.
- (14) Disconnect the steering damper from the axle bracket.

## REMOVAL AND INSTALLATION (Continued)

(15) Disconnect the upper and lower suspension arms from the axle brackets.

(16) Lower the lifting device enough to remove the axle. The coil springs will drop with the axle.

(17) Remove the coil springs from the axle.

## INSTALLATION

**CAUTION:** The weight of the vehicle must be supported by the springs before suspension arms and track bar fasteners can be tightened. If the springs are not at their normal ride position, ride height and handling could be affected.

(1) Install the springs and retainer clips. Tighten the retainer bolts to 21 N·m (16 ft. lbs.) torque.

(2) Support the axle on a suitable lifting device and position axle under the vehicle.

(3) Raise the axle and align it with the spring pads.

(4) Position the upper and lower suspension arms in the axle brackets. Loosely install bolts and nuts to hold suspension arms to the axle brackets.

(5) Connect the vent hose to the axle shaft tube.

(6) Connect the track bar to the axle bracket. Loosely install the bolt to hold the track bar to the axle bracket.

(7) Install the shock absorbers and tighten the bolts to 23 N·m (17 ft. lbs.) torque.

(8) Install the stabilizer bar links to the axle brackets. Tighten the nut to 95 N·m (70 ft. lbs.) torque.

(9) Install the drag link and tie rod to the steering knuckles. Refer to Group 2, Suspension, for proper procedures.

(10) Install the steering damper to the axle bracket and tighten the nut to 75 N·m (55 ft. lbs.) torque.

(11) Install the brake rotors and calipers. Refer to Group 5, Brakes, for the proper procedures.

(12) Connect the wheel speed sensor wiring harness to the vehicle wiring harness, if necessary.

(13) Align the previously made marks on the propeller shaft and the yoke.

(14) Install the straps and bolts to hold the propeller shaft to the yoke.

(15) Check and fill axle lubricant. Refer to the Lubricant Specifications in this group for the quantity necessary.

(16) Install the wheel and tire assemblies.

(17) Remove the lifting device from the axle and lower the vehicle.

(18) Tighten the upper suspension arm nuts to 75 N·m (55 ft. lbs.) torque. Tighten the lower suspension arm nuts to 115 N·m (85 ft. lbs.) torque.

(19) Tighten the track bar bolt at the axle bracket to 100 N·m (74 ft. lbs.) torque.

(20) Check the front wheel alignment.

## AXLE SHAFT—CARDAN U-JOINT


Single cardan U-joint components are not serviceable. If defective, they must be replaced as a unit. If the bearings, seals, spider, or bearing caps are damaged or worn, replace the complete U-joint.

## REMOVAL

**CAUTION:** Clamp only the narrow forged portion of the yoke in the vise. Also, to avoid distorting the yoke, do not over tighten the vise jaws.

(1) Remove axle shaft.

(2) Remove the bearing cap retaining snap rings (Fig. 4).



J8902-15

**Fig. 4 Axle Shaft Outer U-Joint**

- 1 - SHAFT YOKE
- 2 - BEARING CAP
- 3 - SNAP RINGS
- 4 - BEARING CAP
- 5 - SPINDLE YOKE
- 6 - BEARING
- 7 - BEARING CAP
- 8 - SNAP RINGS
- 9 - BEARING CAP


**It can be helpful to saturate the bearing caps with penetrating oil prior to removal.**

(3) Locate a socket where the inside diameter is larger in diameter than the bearing cap. Place the socket (receiver) against the yoke and around the perimeter of the bearing cap to be removed.

(4) Locate a socket where the outside diameter is smaller in diameter than the bearing cap. Place the socket (driver) against the opposite bearing cap.

## REMOVAL AND INSTALLATION (Continued)

(5) Position the yoke with the sockets in a vise (Fig. 5).



J8902-16

**Fig. 5 Yoke Bearing Cap Removal**

- 1 - LARGE-DIAMETER SOCKET WRENCH  
2 - VISE  
3 - SMALL-DIAMETER SOCKET WRENCH

(6) Compress the vise jaws to force the bearing cap into the larger socket (receiver).

(7) Release the vise jaws. Remove the sockets and bearing cap that was partially forced out of the yoke.

(8) Repeat the above procedure for the remaining bearing cap.

(9) Remove the remaining bearing cap, bearings, seals and spider from the propeller shaft yoke.

## INSTALLATION

(1) Pack the bearing caps 1/3 full of wheel bearing lubricant. Apply extreme pressure (EP), lithium-base lubricant to aid in installation.

(2) Position the spider in the yoke. Insert the seals and bearings. Tap the bearing caps into the yoke bores far enough to hold the spider in position.

(3) Place the socket (driver) against one bearing cap. Position the yoke with the socket wrench in a vise.

(4) Compress the vise to force the bearing caps into the yoke. Force the caps enough to install the retaining clips.

(5) Install the bearing cap retaining clips.

(6) Install axle shaft.

## PINION SHAFT SEAL

## REMOVAL

(1) Raise and support the vehicle.

(2) Remove wheel and tire assemblies.

(3) Remove brake rotors and calipers. Refer to Group 5, Brakes, for proper procedures.

(4) Mark the propeller shaft and pinion yoke for installation reference.


(5) Remove the propeller shaft from the yoke.

(6) Rotate the pinion gear three or four times.

(7) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.

(8) Using Holder 6958 to hold the pinion yoke, remove the pinion nut and washer.

(9) Use Remover C-452 and Wrench C-3281 to remove the pinion yoke (Fig. 6).



J9102-31

**Fig. 6 Pinion Yoke Removal**

- 1 - SPECIAL TOOL C-3281  
2 - YOKE  
3 - SPECIAL TOOL C-452

(10) Use a suitable pry tool or a slide hammer mounted screw to remove the pinion seal.


## INSTALLATION

(1) Apply a light coating of gear lubricant on the lip of pinion seal. Install seal with Installer C-3972-A and Handle C-4171 (Fig. 7).

(2) Install yoke on the pinion gear with Installer W-162-D, Cup 8109, and Holder 6958 (Fig. 8).

**CAUTION:** Do not exceed the minimum tightening torque when installing the pinion yoke retaining nut at this point. Damage to collapsible spacer or bearings may result.


## REMOVAL AND INSTALLATION (Continued)



80a7e2be

**Fig. 7 Pinion Seal Installation**

- 1 - SPECIAL TOOL C-4171
- 2 - SPECIAL TOOL C-3972-A



80a7e2bf

**Fig. 8 Pinion Yoke Installation**

- 1 - PINION YOKE
- 2 - AXLE HOUSING


(3) Install the pinion washer and a new nut on the pinion gear. **Tighten the nut only enough to remove the shaft end play.**

(4) Rotate the pinion shaft using a (in. lbs.) torque wrench. Rotating torque should be equal to the reading recorded during removal, plus an additional 0.56 N·m (5 in. lbs.) (Fig. 9).

(5) If the rotating torque is low, use Holder 6958 to hold the pinion yoke (Fig. 10), and tighten the pinion shaft nut in 6.8 N·m (5 ft. lbs.) increments until proper rotating torque is achieved.

**CAUTION:** If the maximum tightening torque is reached prior to reaching the required rotating torque, the collapsible spacer may have been damaged. Replace the collapsible spacer.


(6) Align the installation reference marks on the propeller shaft and yoke and install the propeller shaft.



J9303-10

**Fig. 9 Check Pinion Rotation Torque**

- 1 - PINION YOKE
- 2 - INCH POUND TORQUE WRENCH



80a0c504

**Fig. 10 Tightening Pinion Shaft Nut—Typical**

- 1 - PINION FLANGE
- 2 - FRONT AXLE
- 3 - TOOL 6958

(7) Check and fill the gear lubricant. Refer to the Lubricant Specifications for gear lubricant requirements.


REMOVAL AND INSTALLATION (Continued)

- (8) Install the brake rotors and calipers. Refer to Group 5, Brakes, for proper procedures.
- (9) Install wheel and tire assemblies.
- (10) Lower the vehicle.

**COLLAPSIBLE SPACER**

**REMOVAL W/PINION INSTALLED**

- (1) Raise and support the vehicle.
- (2) Remove wheel and tire assemblies.
- (3) Remove brake rotors and calipers. Refer to Group 5, Brakes, for proper procedures.
- (4) Mark the propeller shaft and pinion yoke for installation reference.
- (5) Remove the propeller shaft from the yoke.
- (6) Rotate the pinion gear three or four times.
- (7) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.
- (8) Using Holder 6958 to hold the pinion yoke, remove the pinion nut and washer.
- (9) Use Remover C-452 and Wrench C-3281 to remove the pinion yoke (Fig. 11).
- (10) Use a suitable pry tool or a slide hammer mounted screw, remove the pinion seal.
- (11) Remove the front pinion bearing using a pair of suitable pick tools to pull the bearing straight off the pinion gear shaft. It may be necessary to lightly tap the end of the pinion gear with a rawhide or rubber mallet if the bearing becomes bound on the pinion shaft.
- (12) Remove the collapsible spacer.




**Fig. 11 Pinion Yoke Removal**

- 1 - SPECIAL TOOL C-3281
- 2 - YOKE
- 3 - SPECIAL TOOL C-452

**REMOVAL W/PINION REMOVED**

- (1) Raise and support the vehicle.
- (2) Remove wheel and tire assemblies.
- (3) Remove brake rotors and calipers. Refer to Group 5, Brakes, for proper procedures.
- (4) Mark the propeller shaft and pinion yoke for installation reference.
- (5) Remove the propeller shaft from the yoke.
- (6) Rotate the pinion gear three or four times.
- (7) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.
- (8) Remove differential assembly from axle housing.
- (9) Using Holder 6958 to hold yoke, remove the pinion nut and washer.
- (10) Using Remover C-452 and Wrench C-3281, remove the pinion yoke from pinion shaft (Fig. 11).
- (11) Remove the pinion gear from housing (Fig. 12). Catch the pinion with your hand to prevent it from falling and being damaged.
- (12) Remove collapsible spacer from pinion shaft.




**Fig. 12 Remove Pinion Gear**

- 1 - RAWHIDE HAMMER

**INSTALLATION**

- (1) Install a new collapsible preload spacer on pinion shaft (Fig. 13).
- (2) If pinion gear was removed, install pinion gear in housing.
- (3) Install pinion front bearing, if necessary.

## REMOVAL AND INSTALLATION (Continued)




J9302-66

**Fig. 13 Collapsible Preload Spacer**

- 1 - COLLAPSIBLE SPACER
- 2 - SHOULDER
- 3 - PINION GEAR
- 4 - OIL SLINGER
- 5 - REAR BEARING

(4) Apply a light coating of gear lubricant on the lip of pinion seal. Install seal with Installer C-3972-A and Handle C-4171 (Fig. 14), if necessary.




80a7e2be

**Fig. 14 Pinion Seal Installation**

- 1 - SPECIAL TOOL C-4171
- 2 - SPECIAL TOOL C-3972-A

(5) Install yoke with Installer W-162-D, Cup 8109, and holder 6958 (Fig. 15).

(6) If the original pinion bearings are being used, install differential assembly and axle shafts, if necessary.



80a7e2bf

**Fig. 15 Pinion Yoke Installation**

- 1 - PINION YOKE
- 2 - AXLE HOUSING

**NOTE:** If new pinion bearings were installed, do not install the differential assembly and axle shafts until after the pinion bearing preload and rotating torque are set.

(7) Install the pinion washer and a new nut on the pinion gear. Tighten the nut to 217 N·m (160 ft. lbs.) minimum. **Do not over-tighten.** Maximum torque is 353 N·m (260 ft. lbs.).

**CAUTION:** Never loosen pinion gear nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque is exceeded, a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(8) Using yoke holder 6958 and a torque wrench set at 353 N·m (260 ft. lbs.), crush collapsible spacer until bearing end play is taken up (Fig. 16). If more than 353 N·m (260 ft. lbs.) is needed to begin to collapse the spacer, the spacer is defective and must be replaced.

(9) Slowly tighten the nut in 6.8 N·m (5 ft. lbs.) increments until the rotating torque is achieved. Measure the rotating torque frequently to avoid over crushing the collapsible spacer (Fig. 17).


(10) Check rotating torque with an inch pound torque wrench (Fig. 17). The torque necessary to rotate the pinion gear should be:

- Original Bearings — The reading recorded during removal, plus an additional 0.56 N·m (5 in. lbs.).
- New Bearings — 1.5 to 4 N·m (15 to 35 in. lbs.).

(11) Install differential assembly and axle shafts, if necessary.


(12) Align marks made previously on yoke and propeller shaft and install propeller shaft.

## REMOVAL AND INSTALLATION (Continued)

**Fig. 16 Tightening Pinion Nut**

- 1 - PINION FLANGE  
2 - FRONT AXLE  
3 - TOOL 6958

80a0c504

**Fig. 17 Check Pinion Gear Rotation Torque—Typical**

- 1 - PINION YOKE  
2 - INCH POUND TORQUE WRENCH

J9303-10

(13) Install brake rotors and calipers. Refer to Group 5, Brakes, for proper procedures.

(14) Add gear lubricant, if necessary. Refer to Lubricant Specifications of this section for lubricant requirements.

(15) Install wheel and tire assemblies.

(16) Lower vehicle.

**HUB BEARING AND AXLE SHAFT**

If the axle shaft and hub bearing are being removed in order to service another component, the axle shaft and hub bearing can be removed as an assembly.


**REMOVAL**

- (1) Raise and support the vehicle.
- (2) Remove the wheel and tire assembly.
- (3) Remove the brake caliper and rotor. Refer to Group 5, Brakes, for proper procedures.
- (4) Remove ABS wheel speed sensor, if necessary. Refer to Group 5, Brakes, for proper procedures.
- (5) Remove the cotter pin, nut retainer, and axle hub nut (Fig. 18), if necessary.
- (6) Remove the hub to knuckle bolts (Fig. 19).
- (7) Remove the hub from the steering knuckle and axle shaft, if necessary.
- (8) Remove hub bearing and axle shaft assembly (Fig. 20), or axle shaft from axle. **Avoid damaging the axle shaft oil seals in the axle housing.**
- (9) Remove the brake rotor shield from the hub bearing or knuckle (Fig. 18).

**INSTALLATION**

- (1) Thoroughly clean the axle shaft (Fig. 18) and apply a thin film of Mopar® Wheel Bearing Grease, or equivalent, to the shaft splines, seal contact surface, and hub bore.
- (2) Install the brake rotor shield to the knuckle.
- (3) Install the hub bearing and axle shaft assembly, or axle shaft, into the housing and differential side gears. Avoid damaging the axle shaft oil seals in the axle housing.
- (4) Install the hub bearing, if necessary.
- (5) Install the hub to knuckle bolts and tighten to 102 N·m (75 ft. lbs.) torque.
- (6) Install the hub washer and nut, if necessary. Tighten the hub nut to 237 N·m (175 ft. lbs.) torque. Install the nut retainer and a new cotter pin (Fig. 18).
- (7) Install ABS wheel speed sensor, if necessary. Refer to Group 5, Brakes, for proper procedures.
- (8) Install the brake rotor and caliper. Refer to Group 5, Brakes, for proper procedures.
- (9) Install the wheel and tire assembly.
- (10) Remove support and lower the vehicle.


REMOVAL AND INSTALLATION (Continued)



J9302-43

**Fig. 18 Hub, Knuckle and Axle Shaft**


- |                  |                              |
|------------------|------------------------------|
| 1 - BRAKE SHIELD | 6 - HUB AND BEARING ASSEMBLY |
| 2 - WASHER       | 7 - STEERING KNUCKLE         |
| 3 - RETAINER     | 8 - BOLT                     |
| 4 - COTTER PIN   | 9 - TONE WHEEL (ABS)         |
| 5 - NUT          |                              |



80a7ae5b

**Fig. 19 Hub Bearing Bolts**

- |                 |
|-----------------|
| 1 - AXLE SHAFT  |
| 2 - AXLE        |
| 3 - KNUCKLE     |
| 4 - HUB BEARING |



80a7ae9c

**Fig. 20 Hub Bearing and Axle Assembly**

- |                 |
|-----------------|
| 1 - AXLE        |
| 2 - KNUCKLE     |
| 3 - HUB BEARING |
| 4 - AXLE SHAFT  |

**STEERING KNUCKLE AND BALL STUDS**

Ball stud service procedures below require removal of the hub bearing and axle shaft. Removal and

installation of upper and lower ball studs require the use of Tool Kit 6289.

REMOVAL AND INSTALLATION (Continued)

**KNUCKLE REMOVAL**

- (1) Remove hub bearing and axle shaft.
- (2) Disconnect the tie-rod or drag link from the steering knuckle arm. Refer to Group 2, Suspension, for proper procedures.
- (3) Remove the cotter pins from the upper and lower ball studs.
- (4) Remove the upper and lower ball stud nuts.
- (5) Strike the steering knuckle with a brass hammer to loosen knuckle from the ball studs. Remove knuckle from ball studs (Fig. 21).

**UPPER BALL STUD REPLACEMENT**


- (1) Position tools as shown to remove and install ball stud (Fig. 22).

**LOWER BALL STUD REPLACEMENT**

- (1) Position tools as shown to remove and install ball stud (Fig. 23).


**KNUCKLE INSTALLATION**

- (1) Position the steering knuckle on the ball studs.
- (2) Install and tighten the bottom retaining nut to 109 N·m (80 ft. lbs.) torque. Install new cotter pin.
- (3) Install and tighten the top retaining nut to 101 N·m (75 ft. lbs.) torque. Install new cotter pin.
- (4) Install the hub bearing and axle shaft.




**Fig. 21 Steering Knuckle Removal/Installation**

- 1 - AXLE YOKE
- 2 - UPPER BALL STUD
- 3 - LOWER BALL STUD
- 4 - STEERING KNUCKLE



**Fig. 22 Upper Ball Stud Remove/Install**

## REMOVAL AND INSTALLATION (Continued)

**Fig. 23 Lower Ball Stud Remove/Install**

- 1 - SPECIAL TOOL 6289-12
- 2 - SPECIAL TOOL 6289-4
- 3 - SPECIAL TOOL 4212F

- 4 - SPECIAL TOOL 4212F
- 5 - SPECIAL TOOL 6289-1
- 6 - SPECIAL TOOL 6289-3

80a7e2a8


(5) Connect the tie-rod or drag link end to the steering knuckle arm. Refer to Group 2, Suspension, for proper procedures.

**AXLE BUSHING REPLACEMENT**

Refer to Group 2, Suspension, for the proper axle bushing procedures.

**DIFFERENTIAL****REMOVAL**

- (1) Raise and support vehicle.
- (2) Remove the lubricant fill hole plug from the differential housing cover.
- (3) Remove the differential housing cover and allow fluid to drain.
- (4) Remove hub bearings and axle shafts.
- (5) Note the installation reference letters stamped on the bearing caps and housing machined sealing surface (Fig. 24).
- (6) Loosen the differential bearing cap bolts.
- (7) Position Spreader W-129-B, utilizing some items from Adapter Kit 6987, with the tool dowel pins seated in the locating holes (Fig. 25). Install the




J9003-92

**Fig. 24 Bearing Cap Identification**

- 1 - INSTALLATION REFERENCE LETTERS
- 2 - INSTALLATION REFERENCE LETTERS

holddown clamps and tighten the tool turnbuckle finger-tight.

## REMOVAL AND INSTALLATION (Continued)



80a534c5

**Fig. 25 Install Axle Housing Spreader**

- 1 - AXLE HOUSING
- 2 - DOWEL
- 3 - SAFETY HOLD DOWN
- 4 - SPECIAL TOOL  
W-129-B
- 5 - TURNBUCKLE

(8) Install a Guide Pin C-3288-B at the left side of the differential housing. Attach Dial Indicator C-3339 to guide pin. Load the lever adapter against the opposite side of the housing (Fig. 26) and zero the indicator.

**CAUTION:** Do not spread over 0.50 mm (0.020 in). If the housing is over-spread, it could be distorted or damaged.

(9) Spread the housing enough to remove the differential case from the housing. Measure the distance with the dial indicator (Fig. 27).

(10) Remove the dial indicator.

(11) While holding the differential case in position, remove the differential bearing cap bolts and caps.


(12) Remove the differential from the housing. Ensure that the differential bearing cups remain in position on the differential bearings (Fig. 28).

(13) Mark or tag the differential bearing cups to indicate which side of the differential they were removed from.

(14) Remove spreader from housing.

**INSTALLATION**


If replacement differential bearings or differential case are being installed, differential side bearing



80a534c6

**Fig. 26 Install Dial Indicator**

- 1 - SPECIAL TOOL  
C-3339
- 2 - DIAL INDICATOR
- 3 - LEVER ADAPTER
- 4 - SPECIAL TOOL  
W-129-B
- 5 - SPECIAL TOOL  
C-3288-B




80a534c7

**Fig. 27 Spread Axle Housing**

- 1 - SPECIAL TOOL  
C-3339
- 2 - SPECIAL TOOL  
W-129-B


shim requirements may change. Refer to the Differential Bearing Preload and Gear Backlash proce-

## REMOVAL AND INSTALLATION (Continued)



**Fig. 28 Differential Case Removal**

- 1 - AXLE HOUSING
- 2 - DIFFERENTIAL CASE
- 3 - BEARING CUPS



**Fig. 29 Install Axle Housing Spreader**

- 1 - AXLE HOUSING
- 2 - DOWEL
- 3 - SAFETY HOLD DOWN
- 4 - SPECIAL TOOL W-129-B
- 5 - TURNBUCKLE

dures in this section to determine the proper shim selection.

(1) Position Spreader W-129-B, utilizing some items from Adapter Kit 6987, with the tool dowel pins seated in the locating holes (Fig. 29). Install the holddown clamps and tighten the tool turnbuckle finger-tight.

(2) Install a Guide Pin C-3288-B at the left side of the differential housing. Attach Dial Indicator C-3339 to guide pin. Load the lever adapter against the opposite side of the housing (Fig. 26) and zero the indicator.

**CAUTION:** Do not spread over 0.50 mm (0.020 in). If the housing is over-spread, it could be distorted or damaged.

(3) Spread the housing enough to install the case in the housing. Measure the distance with the dial indicator (Fig. 27).

(4) Remove the dial indicator.

(5) Install differential case in the housing. Ensure that the differential bearing cups remain in position on the differential bearings. Tap the differential case to ensure the bearings cups are fully seated in the housing.


(6) Install the bearing caps at their original locations (Fig. 30).

(7) Loosely install differential bearing cap bolts.

(8) Remove axle housing spreader.

(9) Tighten the bearing cap bolts to 61 N·m (45 ft. lbs.) torque.

(10) Install the hub bearings and axle shafts.



**Fig. 30 Differential Bearing Cap Reference Letters**


- 1 - INSTALLATION REFERENCE LETTERS
- 2 - INSTALLATION REFERENCE LETTERS

## REMOVAL AND INSTALLATION (Continued)

## DIFFERENTIAL SIDE BEARINGS

## REMOVAL

- (1) Remove differential case from axle housing.
- (2) Remove the bearings from the differential case with Puller/Press C-293-PA, C-293-39 Adapter Blocks, and Plug SP-3289 (Fig. 31).




**Fig. 31 Differential Bearing Removal**

- 1 - SPECIAL TOOL C-293-39
- 2 - BEARING
- 3 - DIFFERENTIAL
- 4 - SPECIAL TOOL SP-3289
- 5 - SPECIAL TOOL C-293-PA

## INSTALLATION

If replacement differential side bearings or differential case are being installed, differential side bearing shim requirements may change. Refer to the Differential Bearing Preload and Gear Backlash procedures in this section to determine the proper shim selection.

- (1) Install differential side bearing shims onto differential case hubs.
- (2) Using Installer C-3716-A and Handle C-4171, install differential side bearings (Fig. 32).
- (3) Install differential in axle housing.



**Fig. 32 Differential Side Bearing Installation**

- 1 - SPECIAL TOOL C-3716-A
- 2 - SPECIAL TOOL C-4171

## AXLE SHAFT OIL SEAL

## REMOVAL

- (1) Raise and support vehicle.
- (2) Remove differential assembly.
- (3) Remove the inner axle shaft seals with a pry bar.

## INSTALLATION

- (1) Remove any sealer remaining from original seals.
- (2) Remove sealer from axle tube to housing junction, if necessary.
- (3) Install oil seals with Discs 8110 and Turnbuckle 6797 (Fig. 33). Tighten tool until disc bottoms in housing.
- (4) Install differential assembly.


## PINION

The ring gear and pinion are serviced as a matched set. Do not replace the pinion without replacing the ring gear.

## REMOVAL

- (1) Remove differential assembly from axle housing.
- (2) Mark pinion yoke and propeller shaft for installation alignment.
- (3) Disconnect propeller shaft from pinion yoke. Using suitable wire, tie propeller shaft to underbody.


REMOVAL AND INSTALLATION (Continued)



**Fig. 33 Axle Seal Installation**

- 1 - TURNBUCKLE 6797
- 2 - DISCS 8110

80a7e2aa




**Fig. 35 Pinion Yoke Removal**

- 1 - SPECIAL TOOL C-3281
- 2 - YOKE
- 3 - SPECIAL TOOL C-452

J9102-31


(4) Using Holder 6958 to the hold yoke, remove the pinion nut and washer (Fig. 34).

(5) Using Remover C-452 and Holder C-3281, remove the pinion yoke from pinion shaft (Fig. 35).



**Fig. 34 Pinion Yoke Holder—Typical**

- 1 - 1 in. PIPE
- 2 - PINION YOKE
- 3 - SPECIAL TOOL 6958
- 4 - LOWER CONTROL ARM




**Fig. 36 Remove Pinion**

- 1 - RAWHIDE HAMMER

J9302-25

## REMOVAL AND INSTALLATION (Continued)

(7) Remove the front pinion bearing cup, bearing, oil slinger, if equipped, and pinion seal with Remover C-4345 and Handle C-4171 (Fig. 37).



**Fig. 37 Front Bearing Cup Removal**

- 1 - REMOVER  
2 - HANDLE

(8) Remove the rear pinion bearing cup from axle housing (Fig. 38). Use Remover D-149 and Handle C-4171.

(9) Remove the collapsible preload spacer from pinion gear (Fig. 39).

(10) Remove the rear pinion bearing from the pinion with Puller/Press C-293-PA and Adapters C-293-39 (Fig. 40).


**Place 4 adapter blocks so they do not damage the bearing cage.**

(11) Remove the depth shim/oil slinger from the pinion shaft. Record the thickness of the depth shim/oil slinger.

## INSTALLATION


**NOTE:** A pinion depth shim/oil slinger is placed between the rear pinion bearing cone and the pinion head to achieve proper ring gear and pinion mesh. If the factory installed ring gear and pinion are reused, the pinion depth shim/oil slinger should not require replacement. Refer to Pinion Gear Depth to select the proper thickness shim/oil slinger before installing pinion.

(1) Apply Mopar® Door Ease, or equivalent, stick lubricant to outside surface of rear pinion bearing



**Fig. 38 Rear Bearing Cup Removal**

- 1 - DRIVER  
2 - HANDLE




**Fig. 39 Collapsible Spacer**

- 1 - COLLAPSIBLE SPACER  
2 - SHOULDER  
3 - PINION  
4 - PINION DEPTH SHIM  
5 - REAR BEARING

cup. Install the bearing cup with Installer D-146 and Driver Handle C-4171 (Fig. 41). Verify cup is correctly seated.


REMOVAL AND INSTALLATION (Continued)



**Fig. 40 Inner Bearing Removal**

- 1 - SPECIAL TOOL C-293-PA
- 2 - VISE
- 3 - ADAPTERS
- 4 - DRIVE PINION GEAR SHAFT

(2) Apply Mopar® Door Ease, or equivalent, stick lubricant to outside surface of front pinion bearing cup. Install the bearing cup with Installer D-130 and Handle C-4171 (Fig. 42).




**Fig. 42 Pinion Outer Bearing Cup Installation**

- 1 - INSTALLER
- 2 - HANDLE


(3) Install front pinion bearing, and oil slinger, if equipped.

(4) Apply a light coating of gear lubricant on the lip of pinion seal. Install seal with Installer C-3972-A and Handle C-4171 (Fig. 43).



**Fig. 41 Rear Pinion Bearing Cup Installation**

- 1 - INSTALLER
- 2 - HANDLE




**Fig. 43 Pinion Seal Installation**

- 1 - SPECIAL TOOL C-4171
- 2 - SPECIAL TOOL C-3972-A

## REMOVAL AND INSTALLATION (Continued)

(5) Install the rear pinion bearing and the pinion depth shim/oil slinger onto the pinion with Installer W-262 and a shop press (Fig. 44).



80be45fe

**Fig. 44 Rear Pinion Bearing Installation**

- 1 - PRESS
- 2 - INSTALLATION TOOL
- 3 - PINION DEPTH SHIM/OIL BAFFLE
- 4 - DRIVE PINION
- 5 - DRIVE PINION SHAFT REAR BEARING

(6) Install a new collapsible preload spacer on pinion shaft and install pinion in housing (Fig. 45).


(7) Install yoke with Installer W-162-B, Cup 8109, and Holder 6958 (Fig. 46).

(8) Install the pinion washer and a new nut onto the pinion. Tighten the nut to 216 N·m (160 ft. lbs.) minimum. **Do not over-tighten.** Maximum torque is 352 N·m (260 ft. lbs.).

**CAUTION:** Never loosen pinion nut to decrease pinion bearing rotating torque and never exceed specified preload torque. If preload torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(9) Using Holder 6958 and torque wrench (set at 352 N·m (260 ft. lbs.)), crush collapsible spacer until bearing end play is taken up (Fig. 47). If more than 353 N·m (260 ft. lbs.) is needed to begin to collapse the spacer, the spacer is defective and must be replaced.


(10) Slowly tighten the nut in 6.8 N·m (5 ft. lb.) increments until the rotating torque is achieved. Measure the rotating torque frequently to avoid over crushing the collapsible spacer (Fig. 48).



J9302-66

**Fig. 45 Collapsible Preload Spacer**

- 1 - COLLAPSIBLE SPACER
- 2 - SHOULDER
- 3 - PINION GEAR
- 4 - OIL SLINGER
- 5 - REAR BEARING



80a7e2bf

**Fig. 46 Pinion Yoke Installation**

- 1 - PINION YOKE
- 2 - AXLE HOUSING


(11) Check bearing rotating torque with an inch pound torque wrench (Fig. 48). The torque necessary to rotate the pinion should be:

- Original Bearings — 1 to 2 N·m (10 to 20 in. lbs.).

- New Bearings — 1.5 to 4 N·m (15 to 35 in. lbs.).

(12) Install differential assembly.


## REMOVAL AND INSTALLATION (Continued)



80a0c504

**Fig. 47 Tightening Pinion Nut—Typical**

- 1 - PINION FLANGE
- 2 - FRONT AXLE
- 3 - TOOL 6958



80a534a7

**Fig. 48 Check Pinion Rotation Torque**


- 1 - in. lbs. TORQUE WRENCH
- 2 - PINION YOKE

## RING GEAR

**NOTE:** The ring gear and pinion are serviced as a matched set. Do not replace the ring gear without replacing the pinion.

## REMOVAL

- (1) Remove differential from axle housing.
- (2) Place differential case in a suitable vise with soft metal jaw protectors. (Fig. 49)
- (3) Remove bolts holding ring gear to differential case.
- (4) Using a soft hammer, drive ring gear from differential case (Fig. 49).



J9202-76

**Fig. 49 Ring Gear Removal**


- 1 - CASE
- 2 - RING GEAR
- 3 - RAWHIDE HAMMER

## INSTALLATION


**CAUTION:** Do not reuse the bolts that held the ring gear to the differential case. The bolts can fracture causing extensive damage.

- (1) Invert the differential case and start two ring gear bolts. This will provide case-to-ring gear bolt hole alignment.
- (2) Invert the differential case in the vise.
- (3) Install new ring gear bolts and alternately tighten to 95–122 N·m (70–90 ft. lbs.) torque (Fig. 50).
- (4) Install differential in axle housing and verify gear mesh and contact pattern.

## REMOVAL AND INSTALLATION (Continued)

**Fig. 50 Ring Gear Bolt Installation**

- 1 - TORQUE WRENCH
- 2 - RING GEAR BOLT
- 3 - RING GEAR
- 4 - CASE

**Fig. 51 Mate Shaft Roll Pin Removal**

- 1 - DRIFT
- 2 - LOCKPIN
- 3 - MATE SHAFT

## DISASSEMBLY AND ASSEMBLY


## STANDARD DIFFERENTIAL

## DISASSEMBLY

- (1) Remove the ring gear.
- (2) Using a suitable roll pin punch, drive out the roll pin holding pinion gear mate shaft in the differential case (Fig. 51).
- (3) Remove the pinion gear mate shaft from the differential case and the pinion mate gears.
- (4) Rotate differential side gears and remove the pinion mate gears and thrust washers (Fig. 52).
- (5) Remove the differential side gears and thrust washers.


## ASSEMBLY

- (1) Install the differential side gears and thrust washers.
- (2) Install the pinion mate gears and thrust washers.
- (3) Install the pinion gear mate shaft. Align the roll pin holes in shaft and the differential case.
- (4) Install the roll pin to hold the pinion mate shaft in the differential case (Fig. 53).
- (5) Install the ring gear.
- (6) Lubricate all differential components with hypoid gear lubricant.

**Fig. 52 Pinion Mate Gear Removal**


- 1 - THRUST WASHER
- 2 - SIDE GEAR
- 3 - PINION MATE GEAR

## DISASSEMBLY AND ASSEMBLY (Continued)



**Fig. 53 Mate Shaft Roll Pin Installation**

- 1 - PUNCH
- 2 - PINION MATE SHAFT
- 3 - MATE SHAFT LOCKPIN



**Fig. 54 Typical Housing Cover With Sealant**

- 1 - SEALING SURFACE
- 2 - CONTOUR OF BEAD
- 3 - BEAD THICKNESS 6.35MM (1/4")

## FINAL ASSEMBLY

(1) Scrape the residual sealant from the housing and cover mating surfaces. Clean the mating surfaces with mineral spirits. Apply a bead of Mopar® Silicone Rubber Sealant, or equivalent, on the housing cover (Fig. 54).

**Install the housing cover within 5 minutes after applying the sealant.**

(2) Install the cover on the differential with the attaching bolts. Install the identification tag. Tighten the cover bolts to 41 N·m (30 ft. lbs.) torque.

**CAUTION: Overfilling the differential can result in lubricant foaming and overheating.**

(3) Refill the differential housing with gear lubricant. Refer to the Lubricant Specifications section of this group for the gear lubricant requirements.

(4) Install the fill hole plug.

## CLEANING AND INSPECTION

### CARDAN U-JOINT

Clean all the U-joint yoke bores with cleaning solvent and a wire brush. Ensure that all the rust and foreign matter are removed from the bores.

Inspect the yokes for distortion, cracks and worn bearing cap bores.

Replace the complete U-joint if any of the components are defective.

### AXLE COMPONENTS

Wash differential components with cleaning solvent and dry with compressed air. **Do not steam clean the differential components.**

Wash bearings with solvent and towel dry, or dry with compressed air. **DO NOT spin bearings with compressed air. Cup and bearing must be replaced as matched sets only.**

Clean axle shaft tubes and oil channels in housing. Inspect for;

- Smooth appearance with no broken/dented surfaces on the bearing rollers or the roller contact surfaces.
- Bearing cups must not be distorted or cracked.
- Machined surfaces should be smooth and without any raised edges.
- Raised metal on shoulders of cup bores should be removed with a hand stone.
- Wear and damage to pinion gear mate shaft, pinion gears, side gears and thrust washers. Replace as a matched set only.
- Ring and pinion gear for worn and chipped teeth.
- Ring gear for damaged bolt threads. Replaced as a matched set only.

CLEANING AND INSPECTION (Continued)


- Pinion yoke for cracks, worn splines, pitted areas, and a rough/corroded seal contact surface. Repair or replace as necessary.
- Preload shims for damage and distortion. Install new shims, if necessary.

ADJUSTMENTS

PINION GEAR DEPTH

GENERAL INFORMATION

Ring gear and pinion are supplied as matched sets only. The identifying numbers for the ring gear and pinion are etched into the face of each gear (Fig. 55). A plus (+) number, minus (-) number or zero (0) is etched into the face of the pinion gear head. This number is the amount (in thousandths of an inch) the depth varies from the standard depth setting of a pinion etched with a (0). The standard setting from the center line of the ring gear to the back face of the pinion is 92.08 mm (3.625 in.). The standard depth provides the best gear tooth contact pattern. Refer to Backlash and Contact Pattern Analysis paragraph in this section for additional information.




**Fig. 55 Pinion Gear ID Numbers**

- 1 - PRODUCTION NUMBERS
- 2 - DRIVE PINION GEAR DEPTH VARIANCE
- 3 - GEAR MATCHING NUMBER (SAME AS RING GEAR NUMBER)

Compensation for pinion depth variance is achieved with a select shim/oil slinger. The shim/oil slinger is placed between the rear pinion bearing and the pinion gear head (Fig. 56).

If a new gear set is being installed, note the depth variance etched into both the original and replacement pinion. Add or subtract the thickness of the original depth shims to compensate for the difference in the depth variances. Refer to the Depth Variance chart.



80a9834c

**Fig. 56 Shim Locations**

- 1 - COLLAPSIBLE SPACER
- 2 - DRIVE PINION GEAR DEPTH SHIM
- 3 - DIFFERENTIAL BEARING SHIM

Note where Old and New Pinion Marking columns intersect. Intersecting figure represents plus or minus the amount needed.

Note the etched number on the face of the drive pinion (-1, -2, 0, +1, +2, etc.). The numbers represent thousands of an inch deviation from the standard. If the number is negative, add that value to the required thickness of the depth shim/oil slinger. If the number is positive, subtract that value from the thickness of the depth shim/oil slinger. If the number is 0 no change is necessary.

**PINION DEPTH MEASUREMENT AND ADJUSTMENT**

Measurements are taken with pinion bearing cups and pinion bearings installed in the axle housing. Take measurements with Pinion Gauge Set 6774 and Dial Indicator C-3339 (Fig. 57).

(1) Assemble Pinion Height Block 6739, Pinion Block 6733, and rear pinion bearing onto Screw 6741 (Fig. 57).

(2) Insert assembled height gauge components, rear bearing and screw into axle housing through pinion bearing cups (Fig. 58).


(3) Install front pinion bearing and Cone-nut 6740 hand tight (Fig. 57).

(4) Place Arbor Disc 6732 on Arbor D-115-3 in position in axle housing side bearing cradles (Fig. 59). Install differential bearing caps on Arbor Discs and tighten cap bolts to 41 N·m (30 ft. lbs.).

ADJUSTMENTS (Continued)

PINION GEAR DEPTH VARIANCE

| Original Pinion Gear Depth Variance | Replacement Pinion Gear Depth Variance |        |        |        |        |        |        |        |        |
|-------------------------------------|--|--------|--------|--------|--------|--------|--------|--------|--------|
|                                     | -4                                     | -3     | -2     | -1     | 0      | +1     | +2     | +3     | +4     |
| +4                                  | +0.008                                 | +0.007 | +0.006 | +0.005 | +0.004 | +0.003 | +0.002 | +0.001 | 0      |
| +3                                  | +0.007                                 | +0.006 | +0.005 | +0.004 | +0.003 | +0.002 | +0.001 | 0      | -0.001 |
| +2                                  | +0.006                                 | +0.005 | +0.004 | +0.003 | +0.002 | +0.001 | 0      | -0.001 | -0.002 |
| +1                                  | +0.005                                 | +0.004 | +0.003 | +0.002 | +0.001 | 0      | -0.001 | -0.002 | -0.003 |
| 0                                   | +0.004                                 | +0.003 | +0.002 | +0.001 | 0      | -0.001 | -0.002 | -0.003 | -0.004 |
| -1                                  | +0.003                                 | +0.002 | +0.001 | 0      | -0.001 | -0.002 | -0.003 | -0.004 | -0.005 |
| -2                                  | +0.002                                 | +0.001 | 0      | -0.001 | -0.002 | -0.003 | -0.004 | -0.005 | -0.006 |
| -3                                  | +0.001                                 | 0      | -0.001 | -0.002 | -0.003 | -0.004 | -0.005 | -0.006 | -0.007 |
| -4                                  | 0                                      | -0.001 | -0.002 | -0.003 | -0.004 | -0.005 | -0.006 | -0.007 | -0.008 |




J9403-45

**Fig. 57 Pinion Gear Depth Gauge Tools—Typical**

- 1 - DIAL INDICATOR
- 2 - ARBOR
- 3 - PINION HEIGHT BLOCK
- 4 - CONE
- 5 - SCREW
- 6 - PINION BLOCK
- 7 - SCOOTER BLOCK
- 8 - ARBOR DISC

**NOTE:** Arbor Discs 6732 has different step diameters to fit other axles. Choose proper step for axle being serviced.

(5) Assemble Dial Indicator C-3339 into Scooter Block D-115-2 and secure set screw.



J9403-39

**Fig. 58 Pinion Height Block—Typical**


- 1 - PINION BLOCK
- 2 - PINION HEIGHT BLOCK

(6) Place Scooter Block/Dial Indicator in position in axle housing so dial probe and scooter block are flush against the rearward surface of the pinion height block (Fig. 57). Hold scooter block in place and zero the dial indicator face to the pointer. Tighten dial indicator face lock screw.

(7) With scooter block still in position against the pinion height block, slowly slide the dial indicator probe over the edge of the pinion height block.

(8) Slide the dial indicator probe across the gap between the pinion height block and the arbor bar with the scooter block against the pinion height block (Fig. 60). When the dial probe contacts the arbor bar, the dial pointer will turn clockwise. Bring dial pointer back to zero against the arbor bar, do not turn dial face. Continue moving the dial probe to the crest of the arbor bar and record the highest reading.

ADJUSTMENTS (Continued)




**Fig. 59 Gauge Tools In Housing—Typical**

- 1 - ARBOR DISC
- 2 - PINION BLOCK
- 3 - ARBOR
- 4 - PINION HEIGHT BLOCK

If the dial indicator can not achieve the zero reading, the rear bearing cup or the pinion depth gauge set is not installed correctly.

(9) Select a shim/oil slinger equal to the dial indicator reading plus the drive pinion depth variance number etched in the face of the pinion (Fig. 55). For example, if the depth variance is -2, add +0.002 in. to the dial indicator reading.




**Fig. 60 Pinion Gear Depth Measurement—Typical**

- 1 - ARBOR
- 2 - SCOOTER BLOCK
- 3 - DIAL INDICATOR

**DIFFERENTIAL BEARING PRELOAD AND GEAR BACKLASH**

**INTRODUCTION**

Differential side bearing preload and gear backlash is achieved by selective shims positioned behind the differential side bearing cones. The proper shim thickness can be determined using slip-fit dummy bearings D-348 in place of the differential side bearings and a dial indicator C-3339. Before proceeding with the differential bearing preload and gear backlash measurements, measure the pinion gear depth and prepare the pinion for installation. Establishing proper pinion gear depth is essential to establishing gear backlash and tooth contact patterns. After the overall shim thickness to take up differential side play is measured, the pinion is installed, and the gear backlash shim thickness is measured. The overall shim thickness is the total of the dial indicator reading and the preload specification added together. The gear backlash measurement determines the thickness of the shim used on the ring gear side of the differential case. Subtract the gear backlash shim thickness from the total overall shim thickness and select that amount for the pinion gear side of the differential (Fig. 61). Differential shim measurements are performed with axle spreader W-129-B removed.



**Fig. 61 Axle Adjustment Shim Locations**


- 1 - COLLAPSIBLE SPACER
- 2 - DRIVE PINION GEAR DEPTH SHIM
- 3 - DIFFERENTIAL BEARING SHIM

## ADJUSTMENTS (Continued)

## SHIM SELECTION

**NOTE:** It is difficult to salvage the differential side bearings during the removal procedure. Install replacement bearings if necessary.

- (1) Remove differential side bearings from differential case.
- (2) Remove factory installed shims from differential case.
- (3) Install ring gear on differential case and tighten bolts to specification.
- (4) Install dummy side bearings D-348 on differential case.
- (5) Install differential case in axle housing.
- (6) Install the marked bearing caps in their correct positions. Install and snug the bolts (Fig. 62).



80a534d1

**Fig. 62 Tighten Bolts Holding Bearing Caps**

- 1 - BEARING CAP
- 2 - AXLE HOUSING
- 3 - DIFFERENTIAL CASE

(7) Using a dead-blow type mallet, seat the differential dummy bearings to each side of the axle housing (Fig. 63) and (Fig. 64).

(8) Thread guide stud C-3288-B into rear cover bolt hole below ring gear (Fig. 65).

(9) Attach a dial indicator C-3339 to guide stud. Position the dial indicator plunger on a flat surface between the ring gear bolt heads (Fig. 65).


(10) Push and hold differential case to pinion gear side of axle housing (Fig. 66).

(11) Zero dial indicator face to pointer (Fig. 66).

(12) Push and hold differential case to ring gear side of the axle housing (Fig. 67).

(13) Record dial indicator reading (Fig. 67).


(14) Add 0.008 in. (0.2 mm) to the zero end play total. This new total represents the thickness of shims to compress, or preload the new bearings when the differential is installed.



80a534d2

**Fig. 63 Seat Pinion Gear Side Differential Dummy Side Bearing**

- 1 - MALLET
- 2 - AXLE HOUSING
- 3 - DIFFERENTIAL CASE



80a534d3

**Fig. 64 Seat Ring Gear Side Differential Dummy Side Bearing**

- 1 - AXLE HOUSING
- 2 - MALLET
- 3 - DIFFERENTIAL CASE

(15) Rotate dial indicator out of the way on the guide stud.


(16) Remove differential case and dummy bearings from axle housing.

(17) Install the pinion in the axle housing. Install the pinion yoke and establish the correct pinion rotating torque.

(18) Install differential case and dummy bearings D-348 in axle housing (without shims), install bearing caps and tighten bolts snug.


(19) Seat ring gear side dummy bearing (Fig. 64).

ADJUSTMENTS (Continued)



**Fig. 65 Differential Side play Measurement**

- 1 - DIFFERENTIAL CASE
- 2 - AXLE HOUSING
- 3 - SPECIAL TOOL C-3288-B
- 4 - SPECIAL TOOL C-3339




**Fig. 66 Hold Differential Case and Zero Dial Indicator**

- 1 - FORCE DIFFERENTIAL CASE TO PINION GEAR SIDE
- 2 - SPECIAL TOOL C-3288-B
- 3 - SPECIAL TOOL C-3339
- 4 - ZERO DIAL INDICATOR FACE

(20) Position the dial indicator plunger on a flat surface between the ring gear bolt heads. (Fig. 65).


(21) Push and hold differential case toward pinion gear (Fig. 68).

(22) Zero dial indicator face to pointer (Fig. 68).



**Fig. 67 Hold Differential Case and Read Dial Indicator**

- 1 - READ DIAL INDICATOR
- 2 - FORCE DIFFERENTIAL CASE TO RING GEAR SIDE
- 3 - AXLE HOUSING



**Fig. 68 Hold Differential Case and Zero Dial Indicator**

- 1 - ZERO DIAL INDICATOR FACE
- 2 - FORCE DIFFERENTIAL CASE TO PINION GEAR SIDE
- 3 - PINION GEAR
- 4 - AXLE HOUSING
- 5 - DIFFERENTIAL CASE


(23) Push and hold differential case to ring gear side of the axle housing (Fig. 69).

(24) Record dial indicator reading (Fig. 69).

(25) Subtract 0.002 in. (0.05 mm) from the dial indicator reading to compensate for backlash between ring and pinion gears. This total is the thickness shim required to achieve proper backlash.

(26) Subtract the backlash shim thickness from the total preload shim thickness. The remainder is

## ADJUSTMENTS (Continued)



**Fig. 69 Hold Differential Case and Read Dial Indicator**

- 1 - READ DIAL INDICATOR
- 2 - FORCE DIFFERENTIAL CASE TO RING GEAR SIDE
- 3 - PINION GEAR
- 4 - AXLE HOUSING
- 5 - DIFFERENTIAL CASE

the shim thickness required on the pinion side of the axle housing.

(27) Rotate dial indicator out of the way on guide stud.

(28) Remove differential case and dummy bearings from axle housing.

(29) Install side bearing shims on differential case hubs.

(30) Install side bearings and cups on differential case.

(31) Install spreader W-129-B, utilizing some items from Adapter Set 6987, on axle housing and spread axle opening enough to receive differential case.

(32) Install differential case in axle housing.

(33) Remove spreader from axle housing.

(34) Rotate the differential case several times to seat the side bearings.

(35) Position the indicator plunger against a ring gear tooth (Fig. 70).


(36) Push and hold ring gear upward while not allowing the pinion gear to rotate.

(37) Zero dial indicator face to pointer.

(38) Push and hold ring gear downward while not allowing the pinion gear to rotate. Dial indicator reading should be between 0.12 mm (0.005 in.) and 0.20 mm (0.008 in.). If backlash is not within specifications transfer the necessary amount of shim thickness from one side of the axle housing to the other (Fig. 71).


(39) Verify differential case and ring gear runout by measuring ring to pinion gear backlash at eight locations around the ring gear. Readings should not vary more than 0.05 mm (0.002 in.). If readings vary more than specified, the ring gear or the differential case is defective.

After the proper backlash is achieved, perform Gear Contact Pattern Analysis procedure.



**Fig. 70 Ring Gear Backlash Measurement**

- 1 - DIAL INDICATOR



**Fig. 71 Backlash Shim Adjustment**

## ADJUSTMENTS (Continued)

**GEAR CONTACT PATTERN ANALYSIS**

The ring gear and pinion teeth contact patterns will show if the pinion depth is correct in the axle housing. It will also show if the ring gear backlash has been adjusted correctly. The backlash can be adjusted within specifications to achieve desired tooth contact patterns.

(1) Apply a thin coat of hydrated ferric oxide, or equivalent, to the drive and coast side of the ring gear teeth.

(2) Wrap, twist, and hold a shop towel around the pinion yoke to increase the turning resistance of the pinion. This will provide a more distinct contact pattern.

(3) Using a boxed end wrench on a ring gear bolt, Rotate the differential case one complete revolution in both directions while a load is being applied from shop towel.

The areas on the ring gear teeth with the greatest degree of contact against the pinion teeth will squeeze the compound to the areas with the least amount of contact. Note and compare patterns on the ring gear teeth to Gear Tooth Contact Patterns chart (Fig. 72) and adjust pinion depth and gear backlash as necessary.

ADJUSTMENTS (Continued)











| <p>DRIVE SIDE OF RING GEAR TEETH</p> <p>HEEL TOE</p>  | <p>COAST SIDE OF RING GEAR TEETH</p> <p>TOE HEEL</p>  | <p>DESIRABLE CONTACT PATTERN. PATTERN SHOULD BE CENTERED ON THE DRIVE SIDE OF TOOTH. PATTERN SHOULD BE CENTERED ON THE COAST SIDE OF TOOTH, BUT MAY BE SLIGHTLY TOWARD THE TOE. THERE SHOULD ALWAYS BE SOME CLEARANCE BETWEEN CONTACT PATTERN AND TOP OF THE TOOTH.</p> |
|--|--|---|
|   |   | <p>RING GEAR BACKLASH CORRECT. <b>THINNER</b> PINION GEAR DEPTH SHIM REQUIRED.</p>  |
|   |   | <p>RING GEAR BACKLASH CORRECT. <b>THICKER</b> PINION GEAR DEPTH SHIM REQUIRED.</p>  |
|   |   | <p>PINION GEAR DEPTH SHIM CORRECT. <b>DECREASE</b> RING GEAR BACKLASH.</p>  |
|   |   | <p>PINION GEAR DEPTH SHIM CORRECT. <b>INCREASE</b> RING GEAR BACKLASH.</p>  |

Fig. 72 Gear Tooth Contact Patterns

SPECIFICATIONS

181 FBI AXLE


Axle Type ..... Hypoid  
 Lubricant ..... SAE Thermally Stable 80W-90  
 Lube Capacity ..... 1.2 L (2.5 pts.)  
 Axle Ratio ..... 3.07, 3.55, 3.73, 4.10  
 Differential Side Gear Clearance ... 0.12-0.20 mm  
 (0.005-0.008 in.)  
 Ring Gear Diameter ..... 18.09 cm (7.125 in.)  
 Backlash ..... 0-0.15 mm (0.005-0.008 in.)  
 Pinion Std. Depth ..... 92.1 mm (3.625 in.)  
 Pinion Bearing Rotating Torque .....  
 Original Bearings ..... 1-2 N·m (10-20 in. lbs.)  
 New Bearings ..... 1.5-4 N·m (15-35 in. lbs.)

TORQUE


| DESCRIPTION      | TORQUE                      |
|------------------|-----------------------------|
| Fill Hole Plug   | 34 N·m (25 ft. lbs.)        |
| Diff. Cover Bolt | 41 N·m (30 ft. lbs.)        |
| Bearing Cap Bolt | 61 N·m (45 ft. lbs.)        |
| Ring Gear Bolt   | 95-122 N·m (70-90 ft. lbs.) |
| Axle Nut         | 237 N·m (175 ft. lbs.)      |
| Hub Brg. Bolt    | 102 N·m (75 ft. lbs.)       |
| Lower Ball Stud  | 108 N·m (80 ft. lbs.)       |
| Upper Ball Stud  | 101 N·m (75 ft. lbs.)       |

SPECIAL TOOLS


181 FBI AXLE




**Puller—C-293-PA**




**Plug—SP-3289**




**Adapter—C-293-39**




**Puller—C-452**



**Wrench—C-3281**




**Dial Indicator—C-3339**




**Driver—C-3716-A**


SPECIAL TOOLS (Continued)




**Handle—C-4171**




**Installer—D-146**




**Remover—D-149**




**Installer—W-162-D**




**Cup—8109**




**Remover/Installer—6289**




**Installer—6761**



**Installer—6752**




**Installer Discs—8110**




**Turnbuckle—6797**


SPECIAL TOOLS (Continued)




**Tool Set, Pinion Depth—6774**




**Adapter Kit—6987**




**Gauge Block—6733**




**Pilot Stud—C-3288-B**




**Spanner—6958**




**Remover—C-4345**




**Installer—C-3972-A**



**Installer—D-130**



**Spreader—W-129-B**



**Installer—W-262**

# 194 RBI AXLE

## TABLE OF CONTENTS

|                                    | page |   | page |
|------------------------------------|------|---|------|
| <b>DESCRIPTION AND OPERATION</b>   |      |   |      |
| 194 RBI AXLE .....                 | 52   | DIFFERENTIAL .....                                      | 65   |
| LUBRICANT .....                    | 53   | DIFFERENTIAL SIDE BEARINGS .....                        | 68   |
| STANDARD DIFFERENTIAL .....        | 53   | PINION GEAR .....                                       | 68   |
| TRAC-LOK™ DIFFERENTIAL .....       | 54   | RING GEAR .....   | 73   |
| <b>DIAGNOSIS AND TESTING</b>       |      |   |      |
| GENERAL INFORMATION .....          | 54   | FINAL ASSEMBLY .....                                    | 73   |
| GEAR NOISE .....                   | 57   | <b>DISASSEMBLY AND ASSEMBLY</b>                         |      |
| BEARING NOISE .....                | 57   | STANDARD DIFFERENTIAL .....                             | 74   |
| LOW SPEED KNOCK .....              | 57   | TRAC-LOK™ DIFFERENTIAL .....                            | 75   |
| VIBRATION .....                    | 57   | <b>CLEANING AND INSPECTION</b>                          |      |
| DRIVELINE SNAP .....               | 58   | AXLE COMPONENTS .....                                   | 79   |
| TRAC-LOK™ DIFFERENTIAL NOISE ..... | 58   | TRAC-LOK™ .....   | 79   |
| TRAC-LOK™ TEST .....               | 58   | <b>ADJUSTMENTS</b>                                      |      |
| <b>SERVICE PROCEDURES</b>          |      |   |      |
| LUBRICANT CHANGE .....             | 58   | PINION GEAR DEPTH .....                                 | 80   |
| <b>REMOVAL AND INSTALLATION</b>    |      |   |      |
| REAR AXLE .....                    | 59   | DIFFERENTIAL BEARING PRELOAD AND<br>GEAR BACKLASH ..... | 82   |
| PINION SHAFT SEAL .....            | 60   | GEAR CONTACT PATTERN ANALYSIS .....                     | 85   |
| COLLAPSIBLE SPACER .....           | 61   | <b>SPECIFICATIONS</b>                                   |      |
| AXLE SHAFT .....                   | 64   | 194 RBI AXLE .....                                      | 85   |
| AXLE SHAFT SEAL AND BEARING .....  | 65   | TORQUE .....  | 85   |
|                                    |      | <b>SPECIAL TOOLS</b>                                    |      |
|                                    |      | 194 RBI AXLE .....                                      | 87   |

## DESCRIPTION AND OPERATION

### 194 RBI AXLE

#### DESCRIPTION

The 194 Rear Beam-design Iron (RBI) axle housing has an iron center casting (differential housing) with axle shaft tubes extending from either side. The tubes are pressed into and welded to the differential housing to form a one-piece axle housing.

The integral type, hypoid gear design, housing has the centerline of the pinion set below the centerline of the ring gear.

The axle has a vent hose to relieve internal pressure caused by lubricant vaporization and internal expansion.

The axles are equipped with semi-floating axle shafts, meaning that loads are supported by the axle shaft and bearings. The axle shafts are retained by C-clips in the differential side gears.

The cover provides a means for servicing the differential without removing the axle.


For vehicles equipped with ABS brakes, the axles have a tone ring pressed onto the axle shaft. Use care when removing axle shafts to ensure that the tone wheel or the wheel speed sensor are not damaged.

The 194 RBI axle has the assembly part number and gear ratio listed on a tag. The tag is attached to the differential housing by a cover bolt. Build date identification codes are stamped on the cover side of an axle shaft tube.

The differential case is a one-piece design. The differential pinion mate shaft is retained with a threaded pin. Differential bearing preload and ring gear backlash is adjusted by the use of selective spacer shims. Pinion bearing preload is set and maintained by the use of a collapsible spacer (Fig. 1).

Axles equipped with a Trac-Lok™ differential are optional. A Trac-Lok differential has a one-piece differential case, and the same internal components as a standard differential, plus two clutch disc packs.

DESCRIPTION AND OPERATION (Continued)



80a5037a

**Fig. 1 Shim Locations**

- 1 - PINION GEAR DEPTH SHIM
- 2 - DIFFERENTIAL BEARING SHIM-PINION GEAR SIDE
- 3 - RING GEAR
- 4 - DIFFERENTIAL BEARING SHIM-RING GEAR SIDE
- 5 - COLLAPSIBLE SPACER

**OPERATION**

The axle receives power from the transmission/transfer case through the rear propeller shaft. The rear propeller shaft is connected to the pinion gear which rotates the differential through the gear mesh with the ring gear bolted to the differential case. The engine power is transmitted to the axle shafts through the pinion mate and side gears. The side gears are splined to the axle shafts.

**LUBRICANT**

**DESCRIPTION**

A multi-purpose, hypoid gear lubricant which conforms to the following specifications should be used. Mopar® Hypoid Gear Lubricant conforms to all of these specifications.

- The lubricant should have MIL-L-2105C and API GL 5 quality specifications.
- Lubricant is a thermally stable SAE 80W-90 gear lubricant.
- Lubricant for axles intended for heavy-duty or trailer tow use is SAE 75W-140 SYNTHETIC gear lubricant.

Trac-lok differentials require the addition of 4 oz. of friction modifier to the axle lubricant. The 194 RBI axle lubricant capacity is 1.66L (3.50 pts.) total, including the friction modifier if necessary.

**CAUTION:** If axle is submerged in water, lubricant must be replaced immediately to avoid possible premature axle failure.

**STANDARD DIFFERENTIAL**

**DESCRIPTION**

The differential gear system divides the torque between the axle shafts. It allows the axle shafts to rotate at different speeds when turning corners.


Each differential side gear is splined to an axle shaft. The pinion gears are mounted on a pinion mate shaft and are free to rotate on the shaft. The pinion gear is fitted in a bore in the differential case and is positioned at a right angle to the axle shafts.

**OPERATION**

In operation, power flow occurs as follows:

- The pinion gear rotates the ring gear
- The ring gear (bolted to the differential case) rotates the case
- The differential pinion gears (mounted on the pinion mate shaft in the case) rotate the side gears
- The side gears (splined to the axle shafts) rotate the shafts

During straight-ahead driving, the differential pinion gears do not rotate on the pinion mate shaft. This occurs because input torque applied to the gears is divided and distributed equally between the two side gears. As a result, the pinion gears revolve with the pinion mate shaft but do not rotate around it (Fig. 2).



J9303-13


**Fig. 2 Differential Operation—Straight Ahead Driving**

- 1 - IN STRAIGHT AHEAD DRIVING EACH WHEEL ROTATES AT 100% OF CASE SPEED
- 2 - PINION GEAR
- 3 - SIDE GEAR
- 4 - PINION GEARS ROTATE WITH CASE

When turning corners, the outside wheel must travel a greater distance than the inside wheel to complete a turn. The difference must be compensated for to prevent the tires from scuffing and skidding through turns. To accomplish this, the differential allows the axle shafts to turn at unequal speeds (Fig. 3). In this instance, the input torque applied to the

## DESCRIPTION AND OPERATION (Continued)

pinion gears is not divided equally. The pinion gears now rotate around the pinion mate shaft in opposite directions. This allows the side gear and axle shaft attached to the outside wheel to rotate at a faster speed.



**Fig. 3 Differential Operation—On Turns**

1 - PINION GEARS ROTATE ON PINION SHAFT

## TRAC-LOK™ DIFFERENTIAL

### DESCRIPTION


In a standard differential, if one wheel spins, the opposite wheel will generate only as much torque as the spinning wheel.

In the Trac-lok™ differential, part of the ring gear torque is transmitted through clutch packs which contain multiple discs. The clutches will have radial grooves on the plates, and concentric grooves on the discs or bonded fiber material that is smooth in appearance.

### OPERATION

In operation, the Trac-lok™ clutches are engaged by two concurrent forces. The first being the preload force exerted through Belleville spring washers within the clutch packs. The second is the separating forces generated by the side gears as torque is applied through the ring gear (Fig. 4).

The Trac-lok™ design provides the differential action needed for turning corners and for driving straight ahead during periods of unequal traction. When one wheel loses traction, the clutch packs transfer additional torque to the wheel having the most traction. Trac-lok™ differentials resist wheel spin on bumpy roads and provide more pulling power when one wheel loses traction. Pulling power is provided continuously until both wheels lose traction. If both wheels slip due to unequal traction, Trac-lok™ operation is normal. In extreme cases of differences



**Fig. 4 Trac-lok™ Limited Slip Differential Operation**

- 1 - CASE
- 2 - RING GEAR
- 3 - DRIVE PINION
- 4 - PINION GEAR
- 5 - MATE SHAFT
- 6 - CLUTCH PACK
- 7 - SIDE GEAR
- 8 - CLUTCH PACK

of traction, the wheel with the least traction may spin.

## DIAGNOSIS AND TESTING

### GENERAL INFORMATION

Axle bearing problem conditions are usually caused by:

- Insufficient or incorrect lubricant.
- Foreign matter/water contamination.
- Incorrect bearing preload torque adjustment.
- Incorrect backlash.

Axle gear problem conditions are usually the result of:

- Insufficient lubrication.
- Incorrect or contaminated lubricant.
- Overloading (excessive engine torque) or exceeding vehicle weight capacity.

DIAGNOSIS AND TESTING (Continued)

- Incorrect clearance or backlash adjustment.
- Incorrect lubricant.
- Axle component breakage is most often the result of:
  - Severe overloading.
  - Insufficient lubricant.
  - Improperly tightened components.
  - Differential housing bores not square to each other.

DIAGNOSTIC CHART

| Condition            | Possible Causes   | Correction   |
|----------------------|---|--|
| Wheel Noise          | <ol style="list-style-type: none"> <li>1. Wheel loose.</li> <li>2. Faulty, brinelled wheel bearing.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Tighten loose nuts.</li> <li>2. Replace bearing.</li> </ol>  |
| Axle Shaft Noise     | <ol style="list-style-type: none"> <li>1. Misaligned axle tube.</li> <li>2. Bent or sprung axle shaft.</li> <li>3. End-play in pinion bearings.</li> <li>4. Excessive gear backlash between the ring gear and pinion.</li> <li>5. Improper adjustment of pinion gear bearings.</li> <li>6. Loose pinion yoke nut.</li> <li>7. Scuffed gear tooth contact surfaces.</li> </ol> | <ol style="list-style-type: none"> <li>1. Inspect axle tube alignment. Correct as necessary.</li> <li>2. Inspect and correct as necessary.</li> <li>3. Refer to pinion pre-load information and correct as necessary.</li> <li>4. Check adjustment of the ring gear and pinion backlash. Correct as necessary.</li> <li>5. Adjust the pinion bearings pre-load.</li> <li>6. Tighten the pinion yoke nut.</li> <li>7. Inspect and replace as necessary.</li> </ol>                                  |
| Axle Shaft Broke     | <ol style="list-style-type: none"> <li>1. Misaligned axle tube.</li> <li>2. Vehicle overloaded.</li> <li>3. Erratic clutch operation.</li> <li>4. Grabbing clutch.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace the broken shaft after correcting tube mis-alignment.</li> <li>2. Replace broken shaft and avoid excessive weight on vehicle.</li> <li>3. Replace broken shaft and avoid or correct erratic clutch operation.</li> <li>4. Replace broken shaft and inspect and repair clutch as necessary.</li> </ol>  |
| Differential Cracked | <ol style="list-style-type: none"> <li>1. Improper adjustment of the differential bearings.</li> <li>2. Excessive ring gear backlash.</li> <li>3. Vehicle overloaded.</li> <li>4. Erratic clutch operation.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Replace case and inspect gears and bearings for further damage. Set differential bearing pre-load properly.</li> <li>2. Replace case and inspect gears and bearings for further damage. Set ring gear backlash properly.</li> <li>3. Replace case and inspect gears and bearings for further damage. Avoid excessive vehicle weight.</li> <li>4. Replace case and inspect gears and bearings for further damage. Avoid erratic use of clutch.</li> </ol> |

## DIAGNOSIS AND TESTING (Continued)

| Condition                 | Possible Causes   | Correction  |
|---------------------------|---|---|
| Differential Gears Scored | <ol style="list-style-type: none"> <li>1. Insufficient lubrication.</li> <li>2. Improper grade of lubricant.</li> <li>3. Excessive spinning of one wheel/tire.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace scored gears. Fill differential with the correct fluid type and quantity.</li> <li>2. Replace scored gears. Fill differential with the correct fluid type and quantity.</li> <li>3. Replace scored gears. Inspect all gears, pinion bores, and shaft for damage. Service as necessary.</li> </ol>   |
| Loss Of Lubricant         | <ol style="list-style-type: none"> <li>1. Lubricant level too high.</li> <li>2. Worn axle shaft seals.</li> <li>3. Cracked differential housing.</li> <li>4. Worn pinion seal.</li> <li>5. Worn/scored yoke.</li> <li>6. Axle cover not properly sealed.</li> </ol> | <ol style="list-style-type: none"> <li>1. Drain lubricant to the correct level.</li> <li>2. Replace seals.</li> <li>3. Repair as necessary.</li> <li>4. Replace seal.</li> <li>5. Replace yoke and seal.</li> <li>6. Remove, clean, and re-seal cover.</li> </ol>   |
| Axle Overheating          | <ol style="list-style-type: none"> <li>1. Lubricant level low.</li> <li>2. Improper grade of lubricant.</li> <li>3. Bearing pre-loads too high.</li> <li>4. Insufficient ring gear backlash.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Fill differential to correct level.</li> <li>2. Fill differential with the correct fluid type and quantity.</li> <li>3. Re-adjust bearing pre-loads.</li> <li>4. Re-adjust ring gear backlash.</li> </ol>   |
| Gear Teeth Broke          | <ol style="list-style-type: none"> <li>1. Overloading.</li> <li>2. Erratic clutch operation.</li> <li>3. Ice-spotted pavement.</li> <li>4. Improper adjustments.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace gears. Examine other gears and bearings for possible damage.</li> <li>2. Replace gears and examine the remaining parts for damage. Avoid erratic clutch operation.</li> <li>3. Replace gears and examine remaining parts for damage.</li> <li>4. Replace gears and examine remaining parts for damage. Ensure ring gear backlash is correct.</li> </ol> |

**Thank you very much  
for your reading.**

**Please Click Here**

**Then            Get            More  
Information.**