

APPLICATION NOTE

AN425

Interfacing the PCF8584 I²C-bus controller
to 80C51 family microcontrollers

June 1994

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

DESCRIPTION

This application note shows how to use the PCF8584 I²C-bus controller with 80C51 family microcontrollers. One typical way of connecting the PCF8584 to an 80C31 is shown. Some basic software routines are described showing how to transmit and receive bytes in a single master system. An example is given of how to use these routines in an application that makes use of the I²C circuits on an I²C demonstration board.

The PCF8584 is used to interface between parallel microprocessor or microcontroller buses and the serial I²C bus. For a description of the I²C bus protocol refer to the I²C bus specification which is printed in the microcontroller user guide.

The PCF8584 controls the transmission and reception of data on the I²C bus, arbitration, clock speeds and transmission and reception of data on the parallel bus. The parallel bus is compatible with 80C51, 68000, 8085 and Z80 buses. Communication with the I²C-bus can be done on an interrupt or polled basis. This application note focuses on interfacing with 8051 microcontrollers in single master systems.

PCF8584

In Figure 1, a block diagram is shown of the PCF8584. Basically it consists of an I²C-interface similar to the one used in 84Cxx family microcontrollers, and a control block for interfacing to the microcontroller.

The control block can automatically determine whether the control signals are from 80xx or 68xxx type of microcontrollers.

This is determined after the first write action from the microcontroller to the PCF8584. The control block also contains a programmable divider which allows the selection of different PCF8584 and I²C clocks.

The I²C interface contains several registers which can be written and read by the microcontroller.

S1 is the control/status register. This register is accessed while the A0 input is 1. The meaning of the bits depends on whether the register is written to or read from. When used as a single master system the following bits are important:

PIN: Interrupt bit. This bit is made active when a byte is sent/received to/from the I²C-bus. When ENI is made active, PIN also controls the external INT line to interrupt the microcontroller.

ES0-ES2: These bits are used as pointer for addressing S0, S0', S2 and S3. Setting ES0 also enables the Serial I/O.

ENI: Enable Interrupt bit. Setting this bit enables the generation of interrupts on the INT line.

STA, STO: These bits allow the generation of START or STOP conditions.

ACK: With this bit set and the PCF8584 is in master/receiver mode, no acknowledge is generated by the PCF8584. The slave/transmitter now knows that no more data must be sent to the I²C-bus.

BER: This bit may be read to check if bus errors have occurred.

BB: This bit may be read to check whether the bus is free for I²C-bus transmission.

S2 is the clock register. It is addressed when A0 = 0 and ES0-ES2 = 010 in the previous write cycle to S1. With the bits S24-S20 it is possible to select 5 input clock frequencies and 4 I²C clock frequencies.

S3 is the interrupt vector register. It is addressed when A0 = 0 and ES0-ES2 = 001 in the previous write cycle to S1. This register is not used when an 80C51 family microcontroller is used. An 80C51 microcontroller has fixed interrupt vector addresses.

S0' is the own address register. It is addressed when A0 = 0 and ES0-ES2 = 000. This register contains the slave address of the PCF8584. In the single master system described here, this register has no functional use. However, by writing a value to S0', the PCF8584 determines whether an 80Cxx or 68xxx type microcontroller is the controlling microcontroller by looking at the $\overline{CS}$ and $\overline{WR}$ lines. So independent of whether the PCF8584 is used as master or slave, the microcontroller should always first write a value to S0' after reset.

S0 is the I²C data register. It is addressed when A0 = 0 and ES0-ES2 = 1x0. Transmission of a byte on the I²C bus is done by writing this byte to S0. When the transmission is finished, the PIN bit in S1 is reset and if ENI is set, an interrupt will be generated. Reception of a byte is signaled by resetting PIN and by generating an interrupt if ENI is set. The received byte can be read from S0.

The SDA and SCL lines have no protection diodes to V_{DD}. This is important for multimaster systems. A system with a PCF8584 can now be switched off without causing the I²C-bus to hang-up. Other masters still can use the bus.

For more information of the PCF8584 refer to the data sheet.

PCF8584/8031 Hardware Interface

Figure 2 shows a minimum system with an 8051 family controller and a PCF8584. In this example, an 80C31 is used. However any 80C51 family controller with external addressing capability can be used.

The software resides in EPROM U3. For addressing this device, latch U2 is necessary to demultiplex the lower address bits from the data bits. The PCF8584 is mapped in the external data memory area. It is selected when A1 = 0. Because in this example no external RAM or other mapped peripherals are used, no extra address decoding components are necessary. A0 is used by the PCF8584 for proper register selection in the PCF8584.

U5A is an inverter with Schmitt trigger input and is used to buffer the oscillator signal of the microcontroller. Without buffering, the rise and fall time specifications of the CLK signal are not met. It is also important that the CLK signal has a duty cycle of 50%. If this is not possible with certain resonators or microcontrollers, then an extra flip-flop may be necessary to obtain the correct duty cycle.

U5C and U5D are used to generate the proper reset signals for the microcontroller and the PCF8584.

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425




Figure 1. PCF8584 Block Diagram

SU00371

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425




Figure 2. PCF8584 to 80C31 Interface

Basic PCF8584/8031 Driver Routines

In the listing section (page 6), some basic routines are shown. The routines are divided in two modules. The module ROUTINE contains the driver routines and initialization of the PCF8584. The module INTERR contains the interrupt handler. These modules may be linked to a module with the user program that uses the routines in INTERR and ROUTINE. In this application note, this module will be called USER. A description of ROUTINE and INTERR follows.

Module ROUTINE

Routine Sendbyte (Lines 17-20)—

This routine sends the contents of the accumulator to the PCF8584. The address is such that A0 = 0. Which register is accessed depends on the contents of ES0-ES2 of the control register. The address of the PCF8584 is in variable 'PCF8584'. This must have been previously defined in the user program. The DPTR is used as a pointer for addressing the peripheral. If the address is less than 255, then R0 or R1 may be used as the address pointer.

Routine Sendcontr (Lines 25, 26)—

This routine is similar to Sendbyte, except that now $A0 = 1$. This

means that the contents of the accumulator are sent to the control register S1 in the PCF8584.

Routine Readbyte (Lines 30-33)—

This routine reads a register in the PCF8584 with A0 = 0. Which register depends on ES0-ES2 of the control register. The result of the read operation is returned in the accumulator.

Routine Readcontr (Lines 37-39)—

This routine is similar to Readbyte, except that now A0 = 1. This means that the accumulator will contain the value of status register S1 of the PCF8584.

Routine Start Lines (44-56)—

This routine generates a START-condition and the slave address with a R/W bit. In line 44, the variable IIC_CNT is reset. This variable is used as a byte counter to keep track of the number of bytes that are received or transmitted. IIC_CNT is defined in module INTERR.

Lines 45-46 increment the variable NR_BYTES if the PCF8584 must receive data. NR_BYTES is a variable that indicates how many bytes have to be received or transmitted. It must be given the correct value in the USER module. Receiving or transmitting is

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

distinguished by the value of the DIR bit. This must also be given the correct value in the USER module.

Then the status register of PCF8584 must be read to check if the I²C bus is free. First the status register must be addressed by giving ES0-ES2 of the control register the correct value (lines 47-48). Then the Bus Busy bit is tested until the bus is free (lines 49-50). If this is the case, the slave address is sent to data register S0 and the I2C_END bit is cleared (lines 51-53). The slave address is set by the user program in variable USER. The LSB of the slave address is the R/W bit. I2C_END can be tested by the user program whether an I2C reception/transmission is in progress or not.

Next the START condition will be generated and interrupt generation enabled by setting the appropriate bits in control register S1 (lines 54-55).

Now the routine will return back to the user program and other tasks may be performed. When the START condition, slave address and R/W bit are sent, and the ACK is received, the PCF8584 will generate an interrupt. The interrupt routine will determine if more bytes have to be received or transmitted.

Routine Stop (Lines 59-62) —

Calling this routine, a STOP condition will be sent to the I²C bus. This is done by sending the correct value to control register S1 (lines 59-61). After this the I2C_END bit is set, to indicate to the user program that a complete I²C sequence has been received or transmitted.

Routine I2C_Init (Lines 65-76)—

This routine initializes the PCF8584. This must be done directly after reset. Lines 67-70 write data to 'own address' register S0'. First the correct address of S0' is set in control register S1 (lines 67-68), then the correct value is written to it (lines 69-70). The value for S0' is in variable SLAVE_ADR and set by the user program. As noted previously, register S0' must always be the first register to be accessed after reset, because the PCF8584 now determines whether an 80Cxxx or 68xxx microcontroller is connected. Lines 72-76 set the clock register S2. The variable I2C_CLOCK is also set by the user program.

Module INTERR

This module contains the I²C interrupt routine. This routine is called every time a byte is received or transmitted on the I²C bus. In lines 12-15 RAM space for variables is reserved.

BASE is the start address in the internal 80C51 RAM where the data is stored that is received, or where the data is stored that has to be transmitted.

NR_BYTES, IIC_CNT and SLAVE were explained earlier. I2C_END and DIR are flags that are used in the program. I2C_END indicates whether an I²C transmission or reception is in progress. DIR indicates whether the PCF8584 has to receive or transmit bytes. The interrupt routine makes use of register bank 1.

The transmission part of the routine starts at line 42. In lines 42-43, a check is made whether IIC_CNT = NR_BYTES. If true, all bytes are sent and a STOP condition may be generated (lines 44-45).

Next the pointer for the internal RAM is restored (line 46) and the byte to be transmitted is fetched from the internal RAM (line 47). Then this byte is sent to the PCF8584 and the variables are updated (lines 47-49). The interrupt routine is left and the user program may proceed. The receive part starts from line 55. First a check is made if the next byte to be received is the last byte (lines 56-59). If true the ACK must be disabled when the last byte is received. This is accomplished by resetting the ACK bit in the control register S1 (lines 60-61).

Next the received byte may be read (line 62) from data register S0. The byte will be temporary stored in R4 (line 63). Then a check is made if this interrupt was the first after a START condition. If so, the byte read has no meaning and the interrupt routine will be left (lines 68-70). However by reading the data register S0 the next read cycle is started.

If valid data is received, it will be stored in the internal RAM addressed by the value of BASE (lines 71-73). Finally a check is made if all bytes are received. If true, a STOP condition will be sent (lines 75-78).

EXAMPLES

In the listing section (starting on page 10), some examples are shown that make use of the routines described before. The examples are transmission of a sequence, reception of I²C data and an example that combines both.

The first example sends bytes to the PCD8577 LCD driver on the OM1016 demonstration board. Lines 7 to 10 define the interface with the other modules and should be included in every user program. Lines 14 to 16 define the segments in the user module. It is completely up to the user how to organize this.

Lines 24 and 28 are the reset and interrupt vectors. The actual user program starts at line 33. Here three variables are defined that are used in the I²C driver routines. Note that PCF8584 must be an even address, otherwise the wrong internal registers will be accessed! Lines 37-42 initialize the interrupt logic of the microcontroller. Next the PCF8584 will be initialized (line 45).

The PCF8584 is now ready to transmit data. A table is made in the routine at line 61. For the PCD8577, the data is a control byte and the segment data. Note that the table does not contain the slave address of the LCD driver. In lines 51-54, variables are made ready to start the transmission. This consists of defining the direction of the transmission (DIR), the address where the data table starts (BASE), the number of bytes to transmit (NR_BYTES, without slave address!) and the slave address (SLAVE) of the I²C peripheral that has to be accessed.

In line 55 the transmission is started. Once the I²C transmission is started, the user program can do other tasks because the transmission works on interrupts. In this example a loop is performed (line 58). The user can check the end of the transmission during the other tasks, by testing the I2C_END bit regularly.

The second example program receives 2 bytes from the PCF8574P I/O expander on the OM1016 demonstration board. Until line 45 the program is identical to the transmit routine because it consists of initialization and variable definition. From line 48, the variables are set for I²C reception. The received bytes are stored in RAM area from label TABLE. During reception, the user program can do other tasks. By testing the I2C_END bit the user can determine when to start processing the data in the TABLE.

The third example program displays time from the PCF8583P clock/calendar/RAM on the LCD display driven by the PCD8577. The LED display (driven by SAA1064) shows the value of the analog inputs of the A/D converter PCF8591. The four analog inputs are scanned consecutively.

In this example, both transmit and receive sequences are implemented as shown in the previous examples. The main clock part is from lines 62-128. This contains the calls to the I²C routines. From lines 135-160, routines are shown that prepare the data to be transmitted. Lines 171 to 232 are the main program for the AD converter and LED display. Lines 239 to 340 contain routines used by the main program. This demo program can also be used with the I²C peripherals on the OM1016 demonstration board.

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Routines for PCF8584

LOC	OBJ	LINE	SOURCE
		1	\$TITLE (Routines for PCF8584)
		2	\$PAGELENGTH(40)
		3	;Program written for PCF8584 as master
		4	;
		5	PUBLIC READBYTE,READCONTR,SENDBYTE
			PUBLIC SENDCONTR,START,STOP
		6	PUBLIC I2C_INIT
		7	EXTRN BIT(I2C_END,DIR)
		8	EXTRN DATA(SLAVE,IIC_CNT,NR_BYTES)
		9	EXTRN NUMBER(SLAVE_ADR,I2C_CLOCK,PCF8584)
		10	;
		11	;Define code segment
		12	ROUTINE SEGMENT CODE
----		13	RSEG ROUTINE
		14	;
		15	;SENDBYTE sends a byte to PCF8584 with A0=0
		16	;Byte to be send must be in accu
0000:	R	17	SENDBYTE:
0000: 900000	R	18	MOV DPTR,#PCF8584 ;Register address
0003: F0		19	SEND: MOVX @DPTR,A ;Send byte
0004: 22		20	RET
		21	;
		22	;SENDCONTR sends a byte to PCF8584 with A0=1
		23	;Byte to be send must be in accu
0005:		24	SENDCONTR:
0005: 900001	R	25	MOV DPTR,#PCF8584+01H ;Register address
0008: 80F9		26	JMP SEND
		27	;
		28	;READBYTE reads a byte from PCF8584 with A0=0
		29	;Received byte is stored in accu
000A:		30	READBYTE:
000A: 900000	R	31	MOV DPTR,#PCF8584 ;Register address
000D: E0		32	REC: MOVX A,@DPTR ;Receive byte
000E: 22		33	RET
		34	;
		35	;READCONTR reads a byte from PCF8584 with A0=1
		36	;Received byte is stored in accu
000F:		37	READCONTR:
000F: 900001	R	38	MOV DPTR,#PCF8584+01H ;Register address
0012: 80F9		39	JMP REC
		40	;
		41	;START tests if the I2C bus is ready. If ready a
		42	;START-condition will be sent, interrupt generation
		43	;and acknowledge will be enabled.
0014: 750000	R	44	START: MOV IIC_CNT,#00 ;Clear I2C byte counter
0017: 200002	R	45	JB DIR,PROCEED ;If DIR is 'receive' then
001A: 0500	R	46	INC NR_BYTES ;increment NR_BYTES
001C: 7440		47	PROCEED:MOV A,#40H ; Read STATUS register of
			; 8584
001E: 120005	R	48	CALL SENDCONTR
0021: 12000F	R	49	TESTBB: CALL READCONTR
0024: 30E0FA		50	JNB ACC.0,TESTBB; Test BB/ bit
0027: E500	R	51	MOV A,SLAVE
0029: C200	R	52	CLR I2C_END ;Reset I2C ready bit
002B: 120000	R	53	CALL SENDBYTE ;Send slave address
002E: 744D		54	MOV A,#01001101B;Generate START, set ENI,
			;set ACK
0030: 120005	R	55	CALL SENDCONTR
0033: 22		56	RET
		57	;
		58	;STOP will generate a STOP condition and set the
			;I2C_END bit
0034: 74C3		59	STOP: MOV A,#11000011B

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

```

0036: 120005  R   60      CALL SENDCONTR ;Send STOP condition
0039: D200    R   61      SETB I2C_END   ;Set I2C_END bit
003B: 22      62      RET
                                63 ;
                                64 ;I2C_init does the initialization of the PCF8584
003C:          65 I2C_INIT:
                                66 ;Write own slave address
003C: E4      67      CLR A
003D: 120005  R   68      CALL SENDCONTR ;Write to control register
0040: 7400    R   69      MOV A,#SLAVE_ADR
0042: 120000  R   70      CALL SENDBYTE   ;Write to own slave
                                ;register
                                71 ;Write clock register
0045: 7420    72      MOV A,#20H
0047: 120005  R   73      CALL SENDCONTR ;Write to control register
004A: 7400    R   74      MOV A,#I2C_CLOCK
004C: 120000  R   75      CALL SENDBYTE   ;Write to clock register
004F: 22      76      RET
                                77 ;
0050:          78      END

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER I2C INTERRUPT ROUTINE

```

LOC   OBJ          LINE  SOURCE
                                1  $TITLE (I2C INTERRUPT ROUTINE)
                                2  $PAGELength(40)
                                3  ;
                                4      PUBLIC INT0_SRV
                                5      PUBLIC DIR,I2C_END
                                6      PUBLIC BASE,NR_BYTES,IIC_CNT,SLAVE
                                7      EXTRN  CODE(SENDBYTE,SENDCONTR,STOP)
                                8      EXTRN  CODE(READBYTE,READCONTR)
                                9  ;
                                9  ;Define variables in RAM
10    IIC_VAR SEGMENT DATA
----
11      RSEG IIC_VAR
0000:      R 12  BASE:  DS 1          ;Pointer to I2C table (till
                                13      ;256)
0001:      13  NR_BYTES: DS 1        ;Number of bytes to rcv/trm
0002:      14  IIC_CNT:DS 1          ;I2C byte counter
0003:      15  SLAVE:  DS 1          ;Slave address after START
                                16  ;
                                17  ;Define variable segment
18    BIT_VAR SEGMENT DATA BITADDRESSABLE
----
19      RSEG BIT_VAR
0000:      R 20  STATUS: DS 1        ;Byte with flags
0000      R 21  I2C_END BIT STATUS.0 ;Defines if a I2C
                                22      ;transmission is finished
                                23      ;'1' is finished
                                24      ;'0' is not ready
0000      R 24  DIR      BIT STATUS.3 ;Defines direction of I2C
                                25      ;transmission
                                26      ;'1':Transmit '0':Receive
                                27  ;
                                27  ;Define code segment for routine
28    IIC_INT SEGMENT CODE PAGE
----
29      RSEG IIC_INT
30  ;
31  ;Program uses registers in RB1
32      USING 1
33  ;
0000:      R 34  INT0_SRV:
0000: C0E0      35      PUSH ACC      ;Save acc. en psw on stack
0002: C0D0      36      PUSH PSW
0004: 75D008    37      MOV PSW,#08H  ;Select register bank 1
0007: 300016    R 38      JNB DIR,RECEIVE ;Test direction bit
                                39      ;8584 is MST/TRM
                                40
                                41  ;Program part to transmit bytes to IIC bus
000A: E502      R 42      MOV A,IIC_CNT ;Compare IIC_CNT and
                                43      ;NR_BYTES
000C: B50105    R 43      CJNE A,NR_BYTES,PROCEED
000F: 120000    R 44      CALL STOP   ;All bytes transmitted
0012: 8032      45      JMP EXIT
0014: A800      R 46  PROCEED:MOV R0,BASE ;RAM pointer
0016: E6        47      MOV A,@R0    ;Source is internal RAM
0017: 0500      48      INC BASE      ;Update pointer of table
0019: 120000    R 49      CALL SENDBYTE ;Send byte to IIC bus
001C: 0502      R 50      INC IIC_CNT  ;Update byte counter
001E: 8026      51      JMP EXIT
                                52  ;
                                53  ;
                                54  ;Program to receive byte from IIC bus
0020:      55  RECEIVE:
0020: E502      R 56      MOV A,IIC_CNT ;Test if last byte is to be
                                57      ;received
0022: 04        57      INC A

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

```

0023: 04          58          INC A
0024: B50105      R    59          CJNE A,NR_BYTES,PROC_RD
0027: 7448          60          MOV A,#01001000B;Last byte to be received.
                                ;Disable ACK
0029: 120000      R    61          CALL SENDCONTR ;Write control word to
                                ;PCF8584
002C: 120000      R    62  PROC_RD:CALL READBYTE ;Read I2C byte
002F: FC          63          MOV R4,A ;Save accu
                                ;If RECEIVE is entered after the transmission of
                                ;START+address then the result of READBYTE is not
                                ;relevant. READBYTE is used to start the generation
                                ;of the clock pulses for the next byte to read.
                                ;This situation occurs when IIC_CNT is 0
0030: E4          68          CLR A ;Test IIC_CNT
0031: B50202      R    69          CJNE A,IIC_CNT,SAVE
0034: 8006          70          JMP END_TEST ;START is send. No relevant
                                ;data in data reg. of 8584
0036: A800          R    71  SAVE:  MOV R0,BASE
0038: EC          72          MOV A,R4 ;Destination is internal RAM
0039: F6          73          MOV @R0,A
003A: 0500          R    74          INC BASE
003C: 0502          R    75  END_TEST:INC IIC_CNT ;Test if all bytes are
                                ;received
003E: E501          R    76          MOV A,NR_BYTES
0040: B50203      R    77          CJNE A,IIC_CNT,EXIT
0043: 120000      R    78          CALL STOP ;All bytes received
                                ;
0046: D0D0          80  EXIT:  POP PSW ;Restore PSW and accu
0048: D0E0          81          POP ACC
004A: 32          82          RETI
                                ;
004B:          84          END

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

```

ASM51  TSW  ASSEMBLER  Send a string of bytes to the PCD8577 on OM1016

LOC    OBJ          LINE  SOURCE
      1  $TITLE (Send a string of bytes to the PCD8577 on
      2             OM1016)
      3  $PAGELENGTH(40)
      4  ;
      5  ;This program is an example to transmit bytes via
      6  ;PCF8584
      7  ;to the I2C-bus
      8  ;
      9  PUBLIC  SLAVE_ADR,I2C_CLOCK,PCF8584
     10  EXTRN  CODE(I2C_INIT,INT0_SRV,START)
     11  EXTRN  BIT(I2C_END,DIR)
     12  EXTRN  DATA(BASE,NR_BYTES,IIC_CNT,SLAVE)
     13  ;
     14  ;
     15  ;Define used segments
     16  USER    SEGMENT CODE      ;Segment for user program
     17  RAMTAB  SEGMENT DATA      ;Segment for table in
     18  ;internal RAM
     19  RAMVAR  SEGMENT DATA      ;Segment for RAM variables
     20  ;in RAM
     21  ;
     22  ;
----
0000:          R     23          RSEG    RAMVAR
     24  STACK: DS 20              ;Reserve stack area
     25  ;
     26  ;
----
0000: 020000    R     27          CSEG AT 00H
     28  JMP MAIN                  ;Reset vector
     29  ;
     30  ;
----
0003: 020000    R     31          CSEG AT 03H
     32  JMP INT0_SRV              ;I2C interrupt vector
     33  ;(INT0/)
     34  ;
     35  ;
----
0055          R     36          RSEG USER
     37  ;Define I2C clock, own slave address and PCF8584
     38  ;hardware address
001C          39  SLAVE_ADR EQU 55H      ;Own slave address is 55H
0000          40  I2C_CLOCK EQU 00011100B ;12.00MHz/90kHz
     41  PCF8584 EQU 0000H      ;PCF8584 address with A0=0
     42  ;
0000: 7581FF    R     43  MAIN:  MOV SP,#STACK-1 ;Initialize stack pointer
     44  ;Initialize 8031 interrupt registers for I2C
     45  ;interrupt
0003: D2A8      46  SETB EX0          ;Enable interrupt INT0/
0005: D2AF      47  SETB EA          ;Set global enable
0007: D2B8      48  SETB PX0          ;Priority level '1'
0009: D288      49  SETB IT0          ;INT0/ on falling edge
     50  ;
     51  ;Initialize PCF8584
000B: 120000    R     52  CALL I2C_INIT
     53  ;
     54  ;Make a table in RAM with data to be transmitted.
000E: 120021    R     55  CALL MAKE_TAB
     56  ;
     57  ;Set variables to control PCF8584
0011: D200      58  SETB DIR          ;DIR='transmission'
0013: 750000    R     59  MOV BASE,#TABLE ;Start address of I2C-data
0016: 750005    R     60  MOV NR_BYTES,#05H ;5 bytes must be
     61  ;transferred
0019: 750074    R     62  MOV SLAVE,#01110100B ;Slave address PCD8577
     63  ; + WR/

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

```

001C: 120000    R    55          CALL START      ;Start I2C transmission
                    56 ;
                    57 ;
001F: 80FE      58 LOOP:     JMP LOOP          ;Endless loop when program
                                                ;is finished
                    59 ;
                    60 ;
0021:           61 MAKE_TAB:
0021: 7800      R    62          MOV R0,#TABLE    ;Make data ready for I2C
                                                ;transmission
0023: 7600      63          MOV @R0,#00         ;Controlword PCD8577
0025: 08        64          INC R0
0026: 76FC      65          MOV @R0,#0FCH       ;'0'
0028: 08        66          INC R0
0029: 7660      67          MOV @R0,#60H        ;'1'
002B: 08        68          INC R0
002C: 76DA      69          MOV @R0,#0DAH       ;'2'
002E: 08        70          INC R0
002F: 76F2      71          MOV @R0,#0F2H       ;'3'
0031: 22        72          RET
                    73 ;
                    74 ;
----           75          RSEG RAMTAB
0000:           R    76 TABLE: DS 10          ;Reserve space in internal
                                                ;data RAM
                                                ;for I2C data to transmit
                    77
                    78 ;
                    79 ;
000A:           80          END

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Receive 2 bytes from the PCF8574P on OM1016

LOC	OBJ	LINE	SOURCE
		1	\$TITLE (Receive 2 bytes from the PCF8574P on OM1016)
		2	\$PAGELENGTH(40)
		3	;
		4	;This program is an example to receive bytes via
			;PCF8584
		5	;from the I2C-bus
		6	;
		7	PUBLIC SLAVE_ADR,I2C_CLOCK,PCF8584
		8	EXTRN CODE(I2C_INIT,INT0_SRV,START)
		9	EXTRN BIT(I2C_END,DIR)
		10	EXTRN DATA(BASE,NR_BYTES,IIC_CNT,SLAVE)
		11	;
		12	;
		13	;Define used segments
		14	USER SEGMENT CODE ;Segment for user program
		15	RAMTAB SEGMENT DATA ;Segment for table in
			;internal RAM
		16	RAMVAR SEGMENT DATA ;Segment for RAM variables
			;in RAM
		17	;
		18	;
----		19	RSEG RAMVAR
0000:	R	20	STACK: DS 20 ;Reserve stack area
		21	;
		22	;
----		23	CSEG AT 00H
0000: 020000	R	24	JMP MAIN ;Reset vector
		25	;
		26	;
----		27	CSEG AT 03H
0003: 020000	R	28	JMP INT0_SRV ;I2C interrupt vector
			;(INT0/)
		29	;
		30	;
----		31	RSEG USER
		32	;Define I2C clock, own slave address and PCF8584
			;hardware address
0055		33	SLAVE_ADR EQU 55H ;Own slave address is 55H
001C		34	I2C_CLOCK EQU 00011100B ;12.00MHz/90kHz
0000		35	PCF8584 EQU 0000H ;PCF8584 address with A0=0
		36	;
0000: 7581FF	R	37	MAIN: MOV SP,#STACK-1 ;Initialize stack pointer
		38	;Initialize 8031 interrupt registers for I2C
			;interrupt
0003: D2A8		39	SETB EX0 ;Enable interrupt INT0/
0005: D2AF		40	SETB EA ;Set global enable
0007: D2B8		41	SETB PX0 ;Priority level '1'
0009: D288		42	SETB IT0 ;INT0/ on falling edge
		43	;
		44	;Initialize PCF8584
000B: 120000	R	45	CALL I2C_INIT
		46	;
		47	;Set variables to control PCF8584
000E: C200	R	48	CLR DIR ;DIR='receive'
0010: 750000	R	49	MOV BASE,#TABLE ;Start address of I2C-data
0013: 750002	R	50	MOV NR_BYTES,#02H ;2 bytes must be received
0016: 75004F	R	51	MOV SLAVE,#01001111B ;Slave address PCF8574
			; + RD
0019: 120000	R	52	CALL START ;Start I2C transmission
		53	;
		54	;
001C: 80FE		55	LOOP: JMP LOOP ;Endless loop when program
			;is finished

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

```

56 ;
57 ;
----
58 RSEG RAMTAB
0000:      R 59 TABLE: DS 10      ;Reserve space in internal
                                   ;data RAM
                                   ;for received I2C data
60
61 ;
62 ;
000A:      63      END
```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

```

LOC   OBJ           LINE  SOURCE
                                1  $TITLE (Demo program for PCF8584 I2C-routines)
                                2  $PAGELENGTH(40)
                                3  ;Program displays on the LCD display the time (with
                                ;PCF8583). Dots on LCD display blink every second.
                                5  ;On the LED display the values of the successive
                                ;analog input channels are shown.
                                7  ;Program reads analog channels of PCF8591P.
                                8  ;Channel number and channel value are displayed
                                ;successively.
                                9  ;Values are displayed on LCD and LED display on I2C
                                ;demo board.
                                10 ;
                                11      PUBLIC    SLAVE_ADR,I2C_CLOCK,PCF8584
                                12      EXTRN    CODE(I2C_INIT,INT0_SRV,START)
                                13      EXTRN    BIT(I2C_END,DIR)
                                14      EXTRN    DATA(BASE,NR_BYTES,IIC_CNT,SLAVE)
                                15 ;
                                16 ;
                                17 ;Define used segments
                                18 USER    SEGMENT CODE    ;Segment for user program
                                19 RAMTAB   SEGMENT DATA    ;Segment for table in
                                ;internal RAM
                                20 RAMVAR   SEGMENT DATA    ;Segment for variables
                                21 ;
                                22      RSEG RAMVAR
----
0000:      R  23  STACK: DS 20      ;Stack area (20 bytes)
0014:      24  PREVIOUS: DS 1      ;Store for previous seconds
0015:      25  CHANNEL:DS 1        ;Channel number to be
                                ;sampled
0016:      26  AN_VAL: DS 1        ;Analog value sampled
                                ;channel
0017:      27  CONVAL: DS 3        ;Converted BCD value sampled
                                ;channel
                                28 ;
                                29      CSEG AT 00H
0000: 020000  R  30      LJMP MAIN      ;Reset vector
                                31 ;
                                32      CSEG AT 03H      ;INT0/
0003: 020000  R  33      LJMP INT0_SRV  ;Vector I2C-interrupt
                                34 ;
                                35 ;
----
                                36      RSEG USER
                                37 ;Define I2C clock, own slave address and address for
                                ;main processor
0055      38  SLAVE_ADR EQU 55H      ;Own slaveaddress is 55h
001C      39  I2C_CLOCK EQU 00011100B ;12.00MHz/90kHz
0000      40  PCF8584 EQU 0000H      ;Address of PCF8584. This
                                ;must be an EVEN number!!
                                41 ;Define addresses of I2C peripherals
00A3      42  PCF8583R EQU 10100011B ;Address PCF8583 with Read
                                ;active
00A2      43  PCF8583W EQU 10100010B ;Address PCF8583 with Write
                                ;active
009F      44  PCF8591R EQU 10011111B ;Address PCF8591 with Read
                                ;active
009E      45  PCF8591W EQU 10011110B ;Address PCF8591 with Write
                                ;active
0074      46  PCD8577W EQU 01110100B ;Address PCD8577 with Write
                                ;active
0076      47  SAA1064W EQU 01110110B ;Address SAA1064 with Write
                                ;active
                                48 ;
0000: 7581FF  R  49  MAIN: MOV SP,#STACK-1 ;Define stack pointer

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

```

LOC   OBJ          LINE  SOURCE
                                50  ;Initialize 80C31 interrupt registers for I2C
                                51  ;interrupt (INT0/)
0003: D2A8          51      SETB EX0      ;Enable interrupt INT0/
0005: D2AF          52      SETB EA      ;Set global enable
0007: D2B8          53      SETB PX0      ;Priority level is '1'
0009: D288          54      SETB IT0      ;INT0/ on falling edge
                                55  ;Initialize PCF8584
000B: 120000        R      56      CALL I2C_INIT
                                57  ;
000E: 751500        R      58      MOV CHANNEL,#00 ;Set AD-channel
                                59  ;
                                60  ;Time must be read from PCF8583.
                                61  ;First write word address and control register of
                                62  ;PCF8583.
0011: D200          R      62      SETB DIR      ;DIR='transmission'
0013: 750000        R      63      MOV BASE,#TABLE ;Start address I2C data
0016: 750002        R      64      MOV NR_BYTES,#02H ;Send 2 bytes
0019: 7500A2        R      65      MOV SLAVE,#PCF8583W
001C: E4            66      CLR A
001D: F500          R      67      MOV TABLE,A      ;Data to be sent (word
                                68      ;address).
001F: F501          R      68      MOV TABLE+1,A      ; " (control
                                69      ;byte)
0021: 120000        R      69      CALL START      ;Start transmission.
0024: 3000FD        R      70  FIN_1: JNB I2C_END,FIN_1 ;Wait till transmission
                                71      ;finished
                                72  ;Send word address before reading time
0027: D200          R      72  REPEAT: SETB DIR      ;'transmission'
0029: 750000        R      73      MOV BASE,#TABLE ;I2C data
002C: 7500A2        R      74      MOV SLAVE,#PCF8583W
002F: 7401          75      MOV A,#01
0031: F500          R      76      MOV NR_BYTES,A      ;Send 1 byte
0033: F500          R      77      MOV TABLE,A      ;Data to be sent is '1'
0035: 120000        R      78      CALL START      ;Start I2C transmission
0038: 3000FD        R      79  FIN_2: JNB I2C_END,FIN_2 ;Wait till transmission
                                80      ;finished
                                81  ;
                                82  ;Time can now be read from PCF8583. Data read is
                                83  ;hundredths of sec's, sec's, min's and hr's
003B: C200          R      83      CLR DIR      ;DIR='receive'
003D: 750000        R      84      MOV BASE,#TABLE ;I2C table
0040: 750004        R      85      MOV NR_BYTES,#04; 4 bytes to receive
0043: 7500A3        R      86      MOV SLAVE,#PCF8583R
0046: 120000        R      87      CALL START      ;Start I2C reception
0049: 3000FD        R      88  FIN_3: JNB I2C_END,FIN_3 ;Wait till finished
                                89  ;
                                90  ;Transfer data to R2...R5
004C: 7800          R      91      MOV R0,#TABLE      ;Set pointers
004E: 7902          92      MOV R1,#02H      ;Pointer R2
0050: E6            93  TRANSFER:MOV A,@R0
0051: F7            94      MOV @R1,A
0052: 08            95      INC R0
0053: 09            96      INC R1
0054: D500F9        R      97      DJNZ NR_BYTES,TRANSFER
0057: ED            98      MOV A,R5      ;Mask of hour counter
0058: 543F          99      ANL A,#3FH
005A: FD           100      MOV R5,A
                                101  ;
                                102  ;Data must now be displayed on LCD display.
                                103  ;First minutes and hours (in R4 and R5) must be
                                104  ;converted from BCD to LCD segment data.The segment
                                105  ;data
                                106  ;will be transferred to TABLE. R0 is pointer to table

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

```

LOC   OBJ          LINE  SOURCE
005B: 7800      R   106      MOV R0,#TABLE
005D: 7600      R   107      MOV @R0,#00H      ;Control word for PCD8577
005F: 08        R   108      INC R0 0060: 120080      R   109      CALL CONV
110      ;
111      ;Switch on dp between hours and minutes
0063: 430301    R   112      ORL TABLE+3,#01H
113      ;If lsb of seconds is '0' then switch on dp.
0066: EB        R   114      MOV A,R3      ;Get seconds
0067: 13        R   115      RRC A      ;lsb in carry
0068: 4003      R   116      JC PROCEED
006A: 430101    R   117      ORL TABLE+1,#01H;switch on dp
118      ;
119      ;Now the time (hours,minutes) can be displayed on
        ;the LCD
006D:          R   120      PROCEED:
006D: D200      R   121      SETB DIR      ;Direction 'transmit'
006F: 750000    R   122      MOV BASE,#TABLE
0072: 750005    R   123      MOV NR_BYTES,#05H
0075: 750074    R   124      MOV SLAVE,#PCD8577W
0078: 120000    R   125      CALL START      ;Start transmission
126      ;
007B: 3000FD    R   127      FIN_4: JNB I2C_END,FIN_4
007E: 8026      R   128      JMP ADCON      ;Proceed with AD-conversion
        ;part
129      ;
130      ;*****
131      ;Routines used by clock part of demo
132      ;
133      ;CONV converts hour and minute data to LCD data and stores
134      ;it in TABLE.
0080: 90009C    R   135      CONV:  MOV DPTR,#LCD_TAB ;Base for LCD segment table
0083: ED        R   136      MOV A,R5      ;Hours to accu
0084: C4        R   137      SWAP A      ;Swap nibbles
0085: 120096    R   138      CALL LCD_DATA ;Convert 10's hours to LCD
        ;data in table
0088: ED        R   139      MOV A,R5      ;Get hours
0089: 120096    R   140      CALL LCD_DATA
008C: EC        R   141      MOV A,R4      ;Get minutes
008D: C4        R   142      SWAP A
008E: 120096    R   143      CALL LCD_DATA ;Convert 10's minutes
0091: EC        R   144      MOV A,R4
0092: 120096    R   145      CALL LCD_DATA ;Convert minutes
0095: 22        R   146      RET
147      ;
148      ;LCD_DATA gets data from segment table and stores it in TABLE
0096: 540F      R   149      LCD_DATA:ANL A,#0FH      ;Mask off LS-nibble
0098: 93        R   150      MOVC A,@A+DPTR ;Get LCD segment data
0099: F6        R   151      MOV @R0,A      ;Save data in table
009A: 08        R   152      INC R0
009B: 22        R   153      RET
154      ;
155      ;LCD_TAB is conversion table for LCD
009C:          R   156      LCD_TAB:
009C: FC60DA      R   157      DB 0FCH,60H,0DAH; '0','1','2'
009F: F266B6      R   158      DB 0F2H,66H,0B6H; '3','4','5'
00A2: 3EE0FE      R   159      DB 3EH,0E0H,0FEH; '6','7','8'
00A5: E6        R   160      DB 0E6H      ; '9'
161      ;

```

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

LOC	OBJ	LINE	SOURCE
		162	;*****
		163	;
		164	;
		165	;These part of the program reads an analog input-channel.
		166	;Displaying is done on the LED-display
		167	;On odd-seconds the channel number will be displayed.
		168	;On even-seconds the analog value of this channel is displayed
		169	;Then the next channel is displayed.
		170	;
00A6: EB		171	ADCON: MOV A,R3 ;Get seconds
00A7: 13		172	RRC A ;lsb to carry
00A8: 503C		173	JNC NEW_MEAS ;Even seconds; do a
			;measurement on the current channel
		174	;
		175	;Display and/or update channel
00AA: 33		176	RLC A ;Restore accu
00AB: B51402	R	177	CJNE A,PREVIOUS,NEW_CH ;If new seconds,
			;update channel number
00AE: 800A		178	JMP DISP_CH
00B0: 0515	R	179	NEW_CH: INC CHANNEL
00B2: E515	R	180	MOV A,CHANNEL ;If channel=4 then
			;channel:=0
00B4: B40403		181	CJNE A,#04,DISP_CH
00B7: 751500	R	182	MOV CHANNEL,#00
00BA: 8B14	R	183	DISP_CH:MOV PREVIOUS,R3 ;Update previous seconds
00BC: E515	R	184	MOV A,CHANNEL ;Get segment value of
			;channel
00BE: 900193	R	185	MOV DPTR,#LED_TAB
00C1: 93		186	MOVC A,@A+DPTR
		187	;
00C2: 7800	R	188	MOV R0,#TABLE ;Fill table with I2C data
00C4: 7600		189	MOV @R0,#00 ;SAA1064 instruction byte
00C6: 08		190	INC R0
00C7: 7677		191	MOV @R0,#77H ;SAA1064 control byte
00C9: 08		192	INC R0
00CA: F6		193	MOV @R0,A ;Channel number
00CB: E4		194	CLR A
00CC: 08		195	INC R0
00CD: F6		196	MOV @R0,A ;Second digit
00CE: 08		197	INC R0
00CF: F6		198	MOV @R0,A ;Third digit
00D0: 08		199	INC R0
00D1: F6		200	MOV @R0,A ;Fourth byte
		201	;
00D2: D200	R	202	SETB DIR ;I2C transmission of channel
			;number
00D4: 750000	R	203	MOV BASE,#TABLE
00D7: 750006	R	204	MOV NR_BYTES,#06H
00DA: 750076	R	205	MOV SLAVE,#SAA1064W
00DD: 120000	R	206	CALL START
		207	;
00E0: 3000FD	R	208	FIN_5: JNB I2C_END,FIN_5
00E3: 020027	R	209	JMP REPEAT ; Repeat clock and AD cycle
			; again
		210	;
		211	;

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

LOC	OBJ	LINE	SOURCE
		212	;Measure and display the value of an AD-channel
00E6:	120108	R 213	NEW_MEAS: CALL AD_VAL ;Do measurement
		214	;Wait till values are available
00E9:	3000FD	R 215	FIN_6: JNB I2C_END,FIN_6
		216	;Relevant byte in TABLE+1. Transfer to AN_VAL
00EC:	7801	R 217	MOV R0,#TABLE+1
00EE:	8616	R 218	MOV AN_VAL,@R0
00F0:	E516	R 219	MOV A,AN_VAL ;Channel value in accu for ;conversion
		220	;AN_VAL is converted to BCD value of the measured ;voltage.
		221	;Input value for CONVERT in accu
		222	;Address for MSByte in R1
00F2:	7917	R 223	MOV R1,#CONVAL
00F4:	120154	R 224	CALL CONVERT
		225	;Convert 3 bytes of CONVAL to LED-segments
00F7:	900193	R 226	MOV DPTR,#LED_TAB ;Base of segment table
00FA:	7817	R 227	MOV R0,#CONVAL
00FC:	12018A	R 228	CALL SEG_LOOP
		229	;Display value of channel to LED display
00FF:	12012C	R 230	CALL LED_DISP
0102:	3000FD	R 231	FIN_8: JNB I2C_END,FIN_8 ;Wait till I2C ;transmission is ended
0105:	020027	R 232	JMP REPEAT ;Repeat clock and AD cycle
		233	;
		234	;*****
		235	;Routines used for AD converter.
		236	;
		237	;AIN reads an analog values from channel denoted by ;CHANNEL.
		238	;Send controlbyte:
0108:	D200	R 239	AD_VAL: SETB DIR ;I2C transmission
010A:	7800	R 240	MOV R0,#TABLE ;Define control word
010C:	A615	R 241	MOV @R0,CHANNEL
010E:	750000	R 242	MOV BASE,#TABLE ;Set base at table
0111:	750001	R 243	MOV NR_BYTES,#01H ;Number of bytes to be ;send
0114:	75009E	R 244	MOV SLAVE,#PCF8591W ;Slave address PCF8591
0117:	120000	R 245	CALL START ;Start transmission of ;controlword
011A:	3000FD	R 246	FIN_7: JNB I2C_END,FIN_7 ;Wait until transmission is ;finished
		247	;Read 2 data bytes from AD-converter
		248	;First data byte is from previous conversion and not ;relevant
011D:	C200	R 250	CLR DIR ;I2C reception
011F:	750000	R 251	MOV BASE,#TABLE ;Bytes must be stored in ;TABLE
0122:	750002	R 252	MOV NR_BYTES,#02H; Receive 3 bytes
0125:	75009F	R 253	MOV SLAVE,#PCF8591R ;Slave address PCF8591
0128:	120000	R 254	CALL START
012B:	22	255	RET
		256	;
		257	;LED_DISP displays the data of 3 bytes from address ;CONVAL
012C:		258	LED_DISP:
012C:	431780	R 259	ORL CONVAL,#80H ;Set decimal point
012F:	7800	R 260	MOV R0,#TABLE
0131:	7917	R 261	MOV R1,#CONVAL
0133:	7600	262	MOV @R0,#00 ;SAA1064 instruction byte
0135:	08	263	INC R0

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

LOC	OBJ	LINE	SOURCE
0136:	7677	264	MOV @R0,#01110111B ;SAA1064 control byte
0138:	08	265	INC R0
0139:	7600	266	MOV @R0,#00 ;First LED digit
013B:	08	267	INC R0
013C:	120185	R 268	CALL GETBY ;Second digit
013F:	120185	R 269	CALL GETBY ;Third digit
0142:	120185	R 270	CALL GETBY ;Fourth digit
0145:	D200	R 271	SETB DIR ;I2C transmission
0147:	750000	R 272	MOV BASE,#TABLE
014A:	750006	R 273	MOV NR_BYTES,#06
014D:	750076	R 274	MOV SLAVE,#01110110B
0150:	120000	R 275	CALL START ;Start I2C transmission
0153:	22	276	RET
		277	;
		278	;CONVERT calculates the voltage of the analog value.
		279	;Analog value must be in accu
		280	;BCD result (3 bytes) is stored from address stored
			;in R1
		281	;Calculation: AN_VAL*(5/256)
0154:	75F005	282	CONVERT:MOV B,#05
0157:	A4	283	MUL AB
		284	;b2..b0 of reg. B : 2E+2..2E0
		285	;b7..b0 of accu : 2E-1..2E-8
0158:	A7F0	286	MOV @R1,B ;Store MSB (10E0-units)
015A:	09	287	INC R1
015B:	7700	288	MOV @R1,#00 ;Calculate 10E-1 unit
			;(10E-1 is 19h)
015D:	B41C02	289	TEN_CH: CJNE A,#19H+03H,V1 ;Check if accu <= 0.11
0160:	8002	290	JMP TENS ;accu=0.11; update tens
0162:	4006	291	V1: JC NX_CON ;accu<0.11; update hundreds
0164:	C3	292	TENS: CLR C ;Calculate new value
0165:	9419	293	SUBB A,#19H
0167:	07	294	INC @R1 ;Update BCD byte
0168:	80F3	295	JMP TEN_CH
		296	;Correction may be necessary. With 8 bits '0.1' is
			;in fact 0.0976.
		297	;A digit of '0A' may appear. Correct this by
			;decrementing the digit.
		298	;The intermediate result must be corrected
			;with 10*(0.1-0.0976)
		299	;This is 06H
016A:	B70A03	300	NX_CON: CJNE @R1,#0AH,PROC_CON ; If digit is '0A'
			;then correct
016D:	17	301	DEC @R1
016E:	2419	302	ADD A,#19H
0170:	09	303	PROC_CON:INC R1
0171:	7700	304	MOV @R1,#00 ;Calculate 10E-2 units
0173:	B40302	305	HUND: CJNE A,#03H,V2 ;Check if accu <= 10E-2
0176:	8002	306	JMP HUNS ;accu=10E-2; update hundreds
0178:	4006	307	V2: JC FINISH ;accu<10E-2; conversion
			;finished
017A:	C3	308	HUNS: CLR C ;Calculate new value
017B:	9403	309	SUBB A,#03H
017D:	07	310	INC @R1 ;Update BCD byte
017E:	80F3	311	JMP HUND
0180:	B70A01	312	FINISH: CJNE @R1,#0AH,FIN ;Check if result is '0A'.
			;Then correct.
0183:	17	313	DEC @R1
0184:	22	314	FIN: RET
		315	;
		316	;CALLBY transfers byte from @R1 to @R0
0185:	E7	317	GETBY: MOV A,@R1
0186:	F6	318	MOV @R0,A

Interfacing the PCF8584 I²C-bus controller to 80C51 family microcontrollers

AN425

ASM51 TSW ASSEMBLER Demo program for PCF8584 I2C-routines

```

LOC   OBJ           LINE   SOURCE
0187: 08           319      INC R0
0188: 09           320      INC R1
0189: 22           321      RET
          322      ;
          323      ;SEG_LOOP converts 3 values to segment values.
          324      ;R0 contains address of source and destination
          325      ;DPTR contains base of table
018A: 7903         326  SEG_LOOP: MOV R1,#03      ;Loop counter
018C: E6           327  INLOOP: MOV A,@R0      ;Get value to be displayed
018D: 93           328      MOVC A,@A+DPTR      ;Get segment value from
          329      ;table
          330      MOV @R0,A      ;Store segment data
018E: F6           329      INC R0
018F: 08           330      DJNZ R1,INLOOP
0190: D9FA         331      RET
0192: 22           332      ;
          333      ;
          334      ;LED_TAB is conversion table for BCD to LED segments
0193:           335  LED_TAB:
0193: 7D483E         336      DB 7DH,48H,3EH      ; '0','1','2'
0196: 6E4B67         337      DB 6EH,4BH,67H      ; '3','4','5'
0199: 734C7F         338      DB 73H,4CH,7FH      ; '6','7','8'
019C: 4F           339      DB 4FH          ; '9'
          340      ;
          341      ;
          342      ;*****
          343      ;
----          344      RSEG RAMTAB
0000:           R 345  TABLE: DS 10
          346      ;
000A:           347      END

```

Philips Semiconductors and Philips Electronics North America Corporation reserve the right to make changes, without notice, in the products, including circuits, standard cells, and/or software, described or contained herein in order to improve design and/or performance. Philips Semiconductors assumes no responsibility or liability for the use of any of these products, conveys no license or title under any patent, copyright, or mask work right to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described herein for any of these products are for illustrative purposes only. Philips Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

LIFE SUPPORT APPLICATIONS

Philips Semiconductors and Philips Electronics North America Corporation Products are not designed for use in life support appliances, devices, or systems where malfunction of a Philips Semiconductors and Philips Electronics North America Corporation Product can reasonably be expected to result in a personal injury. Philips Semiconductors and Philips Electronics North America Corporation customers using or selling Philips Semiconductors and Philips Electronics North America Corporation Products for use in such applications do so at their own risk and agree to fully indemnify Philips Semiconductors and Philips Electronics North America Corporation for any damages resulting from such improper use or sale.

Philips Semiconductors
811 East Arques Avenue
P.O. Box 3409
Sunnyvale, California 94088-3409
Telephone 800-234-7381

Philips Semiconductors and Philips Electronics North America Corporation
 register eligible circuits under the Semiconductor Chip Protection Act.
 © Copyright Philips Electronics North America Corporation 1996
 All rights reserved. Printed in U.S.A.