

# WARNING!!!!!!!!!!!!!!

IMPORTANT: INSTALLATION OF THIS ENHANCEMENT SHOULD ONLY BE PERFORMED BY QUALIFIED ELECTRONIC TECHNICIANS. PEAVEY ELECTRONICS WILL NOT BE RESPONSIBLE FOR EQUIPMENT DAMAGED AS A RESULT OF IMPROPER INSTALLATION OF THE PARTS. SHOULD YOU HAVE QUESTIONS REGARDING THIS INSTALLATION, PLEASE DO NOT HESITATE TO CONTACT OUR REPAIR ASSISTANCE DEPARTMENT HERE AT THE FACTORY.

PEAVEY

## NASHVILLE 400 TONE ENHANCEMENT KIT

FROM	TO	DESIGNATION	PEAVEY#
.1uf	2.2uf/35volt	C1	70320200
2.2uf	22uf/25volt	C5	70320012
2.2uf	22uf/25volt	C6	70320012
.1uf	2.2uf/35volt	C8	70320200
.022uf	.0082uf/100volt	C10	70340019
2.2uf	22uf/25volt	C11	70320012
.015uf	.0047uf/100volt	C12&C13	70330069
.10uf	.047uf/50volt	C14&C15	70340017
2.2uf	22uf/25volt	C26	70320012
2.2uf	22uf/25volt	C28	70320012
220k	1 Meg	R3	70240039
220k	100k	R10	70240034
15k	10k	R19	70240025
Replace U1-U6(4558) to OPA2604			c57000092

REASSEMBLE AMP IN REVERSE ORDER AND TEST.

**NOTE: MAKE SURE THAT YOU INSERT THE IC CHIPS IN CORRECTLY AND SEAT THEM PROPELY IN THE SOCKETS. THERE IS A NOTCH OF THE SOCKET AND AT THE END OF THE IC CHIP THAT SURE BE MATCHED WHEN INSTALLING.**

**6/1/2000**