

SPECIFICATIONS/FEATURES/FILTER SELECTOR CIRCUIT/ FILTER SWITCH OPERATIONS

SPECIFICATIONS

Speaker
Nominal max. Input 2 W
Impedance $\ldots \ldots \ldots 8 \Omega$
Frequency Characteristic \dots 100 Hz \sim 5 kHz
Filter Cut-off Frequency
LOW
HIGH 1 3 kHz / -3 dB
HIGH 2 1.5 kHz/ –3 dB
Filter Attenuation –6 dB / Oct
Size W 169 (169) mm
H 153 (167) mm
D 335 (348) mm
Figures in () are max. sizes includ- ing projected parts.
Weight 2.5 kg

FEATURES

- 1. Adoption of a graceful design which esthetically matches the TS-820 series.
- 2. Installation of band selector filter (attenuation possible by series insertion of L in high range and C in low range).
- Selection of 2 input systems (switching between IN-PUT A and B).
- 4. Feasibility of monitoring voice with a head-phone, after passing through the band-pass filter.

FILTER SELECTOR CIRCUIT

This speaker system is provided with a circuit which offers a filter effect by the characteristics shown below.



Each filter switch offers the following functions:

1. FILTERS (LOW)

FILTER ON makes attenuation at 400 Hz and below (400 Hz / -3 dB).

2. FILTERS (HIGH 1) FILTER ON makes attenuation at 3 kHz and above

(1 kHz / -3 dB).

3. FILTERS (HIGH 2)

FILTER ON makes attenuation at 1.5 kHz and above (1.5 kHz / -3 dB).

Combined use of these filter switches can make the following frequency characteristics:

FILTER SWITCH OPERATIONS

- 1. When LOW and HIGH 1 are pressed simultaneously, the resultant frequency band is 400 Hz \sim 3 kHz.
- 2. When LOW and HIGH 2 are pressed simultaneously, the frequency band is 400 Hz \sim 1.5 kHz,
- 3. When LOW, HIGH 1, and HIGH 2 are pressed simultaneously, the frequency band is 400 Hz \sim 1.5 kHz.

Suggestions for practical filter operations are obtainable from "Use of Filter" in the instruction manual.

SP-820

PARTS LIST/DISASSEMBLY

Ref. No.	Part No.	Description		Re- marks	Ref. No.	Part No.	Description	Re- marks
-	RS14AB3D8R2J	Metal film 8.2 Ω ±5%	2W		- 1- 1-	H01-2552-04	Carton case (inside) K,	N A
	RD14BB2E101J	Carbon $100\Omega \pm 5\%$	1/4W	1 I I I	-	H01-2553-04	Carton case (inside) T	☆
						H12-0434-02	Packing material X 2	\$
-	L79-0443-05	Filter		☆	1 - 1	H20-0276-03	Protection cover	
						H25-0049-03	Protection bag	. I
-	S42-2401-05	Push switch		\$			and the second s	1.1
						J02-0049-14	Foot X 6	
	T06-0011-05	Speaker		10.00		J32-1030-14	Round boss X 2	
						J61-0019-05	Vinyl tie X 2	
-	A01-0720-02	Case A		습				1.5
	A01-0721-02	Case B		슙	1000	K29-0166-04	Knob X 4	
	A20-2321-05	Panel	т	☆				
-	A20-2322-05	Panel	к, w		-	N10-2030-46	Nut X 2	
					-	N15-1040-46	Washer X 4	
-	B05-0705-04	Speaker grille cloth		☆	-	N30-3004-41	Round head screw X 6	
-	B46-0058-00	Warranty card	к			N30-3006-41	Round head screw X 6	
_	B50-2563-00	Operating manual		☆	-	N30-4008-46	Round head screw X 4	
					- 1	N30-4010-41	Round head screw X 2	
	E11-0044-25	Phone jack				N33-4008-45	Oval head screw X 4	
	E12-0001-05	Phone plug			- 1	N35-3008-41	Binder screw X 18	
3 	E13-0361-05	3P phono jack			-	N87-4012-41	Tap tight screw X 2	
-	E14-0101-05	1P phono plug X 2						
	E30-1610-05	Connector with lead wire						e
-	G53-0503-04	Packing X 4		4				
	G53-0504-04	Packing X 2		☆			6	
-	G53-0505-04	Packing X 6		\$				
							A	

DISASSEMBLY



3

BLOCK DIAGRAM



TRIO-KENWOOD COMMUNICATIONS, INC. 1111, WEST WALNUT STREET COMPTON CALIFORNIA 90220, U.S.A.

TRIO-KENWOOD COMMUNICATIONS, GmbH D-6374 STEINBACH-TS INDUSTRIESTRASSE, 8A WEST GERMANY.

TRIO-KENWOOD CORPORATION

■ 6-17, 3-CHOME, AOBADAI, MEGURO-KU, TOKYO, JAPAN.