




SCHEMATIC OF RECEIVER



I-F
455 Kc



POWER CONNECTOR (PIN VIEW)




SPEAKER CONNECTOR (HOLE VIEW)



NUMBERED LUGS ARE CONTACT LUGS AND TIE IN WITH NUMBERS ON DIAGRAM

VT-171 RMA TYPE IR5
VT-173 RMA TYPE IT4
VT-172 RMA TYPE IS5
VT-174 RMA TYPE 354

POWER SUPPLY SCHEMATIC



Downloaded by
RadioAmateur.EU

BATTERY CHARGER
CURRENT SUPPLY
CONNECTOR ON
MOUNTING FT-338-A

