

# This Trident manual was scanned by

## Ole Jensen

a big 'thank you' to him for allowing me to put it up at AnalogRules.com as another FREE DOWNLOAD!!!










#### EDGE CONNECTOR PIN REF


```
I. - +ive MIC INPUT
       -ive MIC INPUT
2. -
        PHANTOM +48V
3.
4.
 5.
 6.
        MIX AMP EARTH
        "I" MIX BUS
 7.
        "2"
8.
        "3" "
9.
        "4" "
10.
        "5"
II.
12.
        "6"
        "7"
13.
         "8"
              11
14.
        REMIX "LEFT" INPUT BUSS
I5. -
        REMIX "RIGHT" INPUT BUSS
16. -
        EARTH MIX AMP
I7. -
18.
19.
20.
21. -
         SUPPLY +I8V
         SUPPLY - I8V
22. -
23.
         +ive LINE INPUT
-ive LINE INPUT
24. -
25.
         INSERT SEND
26.
         MAIN ELECTRONIC EARTH
27.
         MAIN ELECTRONIC EARTH
28.
29.
30.
         P.F.L. MIX BUSS
AUX "4" " "
31. -
32.
         AUX "3" "
                       11
33. -
         AUX "2" "
34. -
         AUX "I" "
                       **
35.
         P.F.L. D.C. BUSS
 36.
 37.
38. -
39. -
         DIRECT OUTPUT
         - INSERT RETURN
40. - + INSERT RETURN
41. - +I5V
42. - L.E.D. +5V
 43.

    L.E.D. CASE EARTH
```









### This Manual or Schematic is a

### **FREE DOWNLOAD**

For everyone...

From the archives of

Analogrules.com

and

**AudioSchematics.com** 

If you have paid anything for this Manual or Schematic
You have been
RIPPED OFF

Demand your money back And let us know who is stealing our files and charging for our free downloads