

MIXING CONSOLE/POWER SUPPLY

M2000

PW2000M

SERVICE MANUAL

M2000/PW2000M

■ CONTENTS (目次)	
SPECIFICATIONS (総合仕様)	2/5
DIMENSIONS (寸法図)	8
PANEL LAYOUT (パネルレイアウト)	9
CIRCUIT BOARD LAYOUT & WIRING (ユニットレイアウトと基板結線図)	20
DISASSEMBLY PROCEDURE (分解手順)	22
LSI PIN DESCRIPTION (LSI端子機能表)	36
IC BLOCK DIAGRAM (ICブロック図)	37
INSPECTIONS (検査)	39/55
TEST PROGRAM (テストプログラム)	51/65
ERROR MESSAGES (エラーメッセージ)	54/67
MIDI IMPLEMENTATION CHART	68
CIRCUIT BOARD & CIRCUIT DIAGRAM (シート基板図と回路図)	69

PA 011225

19940320-1100000-16 19940320-1600000-32
19940320-1350000-24 19940320-1850000-40

YAMAHA CORP.
HAMAMATSU, JAPAN
2.65K-7601 © PRINTED IN JAPAN '94.04

IMPORTANT NOTICE

This manual has been provided for the use of authorized Yamaha Retailers and their service personnel. It has been assumed that basic service procedures inherent to the industry, and more specifically Yamaha Products, are already known and understood by the users, and have therefore not been restated.

WARNING: Failure to follow appropriate service and safety procedures when servicing this product may result in personal injury, destruction of expensive components and failure of the product to perform as specified. For these reasons, we advise all Yamaha product owners that all service required should be performed by an authorized Yamaha Retailer or the appointed service representative.

IMPORTANT: The presentation or sale of this manual to any individual or firm does not constitute authorization, certification, recognition of any applicable technical capabilities, or establish a principal-agent relationship of any form.

The data provided is believed to be accurate and applicable to the unit(s) indicated on the cover. The research, engineering, and service departments of Yamaha are continually striving to improve Yamaha products. Modifications are, therefore, inevitable and changes in specification are subject to change without notice or obligation to retrofit. Should any discrepancy appear to exist, please contact the distributor's Service Division.

WARNING: Static discharges can destroy expensive components. Discharge any static electricity your body may have accumulated by grounding yourself to the ground buss in the unit (heavy gauge black wires connect to this buss).

IMPORTANT: Turn the unit OFF during disassembly and parts replacement. Recheck all work before you apply power to the unit.

This product uses a lithium battery for memory back-up.

WARNING: Lithium batteries are dangerous because they can be exploded by improper handling. Observe the following precautions when handling or replacing lithium batteries.

- Leave battery replacement to qualified service personnel.
- Always replace with batteries of the same type.
- When installing on the PC board, solder using the connection terminals provided on the battery cells. Never solder directly to the cells. Perform the soldering as quickly as possible.
- Never reverse the battery polarities when installing.
- Do not short the batteries.
- Do not attempt to recharge these batteries.
- Do not disassemble the batteries.
- Never heat batteries or throw them into fire.

ADVARSEL!

Lithiumbatteri. Eksplosionsfare.
Udskiftning må kun foretages af en sagkyndig, og som beskrevet i servicemanualen.

WARNING: CHEMICAL CONTENT NOTICE!

The solder used in the production of this product contains LEAD. In addition, other electrical/electronic and/or plastic (where applicable) components may also contain traces of chemicals found by the California Health and Welfare Agency (and possibly other entities) to cause cancer and/or birth defects or other reproductive harm.

DO NOT PLACE SOLDER, ELECTRICAL/ELECTRONIC OR PLASTIC COMPONENTS IN YOUR MOUTH FOR ANY REASON WHAT SO EVER!

Avoid prolonged, unprotected contact between solder and your skin! When soldering, do not inhale solder fumes or expose eyes to solder/flux vapor!

If you come in contact with solder or components located inside the enclosure of this product, wash your hands before handling food.

■ WARNING

Components having special characteristics are marked Δ and must be replaced with parts having specifications equal to those originally installed.

Δ 印の部品は、安全を維持するために重要な部品です。交換をする場合は、安全のため必ず指定の部品をご使用下さい。

SPECIFICATIONS

General specifications (M2000)


Total Harmonic Distortion (Master output)	Less than 0.1% (THD+N) 20 Hz–20 kHz @ +14 dB output into 600 Ω
Frequency Response (Master output)	+1/–3 dB 20 Hz–20 kHz @ +4 dB output into 600 Ω
Hum & Noise*1 (40 ch)	–128 dB Equivalent Input Noise. –97 dB Residual Output Noise. –80 dB (84 dB S/N) GROUP OUT Master fader at nominal level and all Ch assign SW's off. –64 dB (68 dB S/N) GROUP OUT Master fader and one Ch fader at nominal level. –79 dB (83 dB S/N) STEREO OUT MASTER fader at nominal level and all Ch assign SW's off and all Group to ST SW's off. –79 dB (83 dB S/N) MONO OUT Master fader at nominal level and all Ch assign SW's off and all Group to MONO SW's off. –77 dB (81 dB S/N) AUX OUT Master level control at nominal level and all Ch AUX Mix controls at minimum level. –92 dB (96 S/N) MATRIX OUT Master level control at nominal level and all Matrix Mix controls at minimum level.
Crosstalk	–80 dB @ 1 kHz adjacent inputs. –70 dB @ 1 kHz input to output. (Ch input) –50 dB @ 1 kHz input to output. (Stereo input)
Maximum Voltage Gain	84 dB CH IN to GROUP OUT/ STEREO OUT (CH to ST)/MONO OUT (CH to MONO) 94 dB CH IN to STEREO OUT (Group to ST)/MONO OUT (Group to MONO) 104 dB CH IN to MONO OUT (Group to ST & ST TO MONO) 90 dB CH IN to MATRIX OUT (Group to MATRIX) 76 dB CH IN to AUX OUT (Pre Fader) 86 dB CH IN to AUX OUT (Post Fader) 70 dB CH IN to MONITOR OUT (CH IN CUE) 76 dB CH IN to DIRECT OUT 60 dB CH IN to CH INSERT OUT 44 dB ST IN to GROUP OUT/STEREO OUT (CH to ST)/MONO OUT (CH to MONO) 33 dB ST IN to AUX OUT (Pre Fader) 43 dB ST IN to AUX OUT (Post Fader) 30 dB ST IN to MONITOR OUT (ST IN CUE) 30 dB RETURN to GROUP OUT/STEREO OUT/MONO OUT 23 dB RETURN to AUX OUT 70 dB TALKBACK IN to GROUP OUT/STEREO OUT/MONO OUT 10 dB SUB IN to GROUP OUT/STEREO OUT/MONO OUT 6 dB SUB IN to AUX OUT/MONITOR OUT 20 dB 2TR IN to MONITOR OUT
Ch Input PAD	SW26 dB
Ch Input Gain control	44 dB variable

Stereo Input Gain control	30 dB variable
Ch Input High Pass Filter	12 dB/octave roll-off 80 Hz at –3 dB point.
Ch Input Equalization	±15 dB maximum HIGH 12 kHz (shelving) HIGH-MID 400 Hz – 8 kHz (peaking) LOW-MID 80 Hz – 1.6 kHz (peaking) LOW 80 Hz (shelving)
Stereo Input Equalization	±15 dB maximum HIGH 12 kHz (shelving) MID 300 Hz – 6 kHz (peaking) LOW 80 Hz (shelving)
Return Equalization	±15 dB maximum HIGH 12 kHz (shelving) LOW 80 Hz (shelving)
Channel Peak Indicator	Peak LED (red) turns on when post-EQ signal is above the level 3 dB lower than clipping level.
Channel Signal Indicator	Signal LED (green) turns on when post-EQ signal is above the level 10 dB lower than nominal level.
Scene Memory (with MIDI control)	Direct Scene recall switches (#1 – #8) Switchable Scene recall (#1 – #128)
VU Meters	(0 VU=+4 dB output @ 600 Ω load) 3 large, illuminated meters; 2 meters are switchable. L; STEREO L/CUE L R; STEREO R/CUE R MONO; MONO 8 smaller, illuminated meters; all switchable. #1; GROUP 1/MATRIX 1 A/AUX 1 #2; GROUP 2/MATRIX 2 A/AUX 2 #3; GROUP 3/MATRIX 3 A/AUX 3 #4; GROUP 4/MATRIX 4 A/AUX 4 #5; GROUP 5/MATRIX 1 B/AUX 5 #6; GROUP 6/MATRIX 2 B/AUX 6 #7; GROUP 7/MATRIX 3 B #8; GROUP 8/MATRIX 4 B
VU Meter Peak Indicator	Peak LED (red) built into each VU meter turns on when output signal is above the level 3 dB lower than clipping level.
Phantom Power	+48 V _{DC} is applied to balanced inputs for powering condenser microphones.
Dimensions	Height 223 mm Depth 785 mm Width 16 ch 970 mm 24 ch 1202 mm 32 ch 1434 mm 40 ch 1696 mm
Weight	16 ch 44 kg 24 ch 54 kg 32 ch 64 kg 40 ch 76 kg
Power consumption	300W

Accessory**Umbilical cable**

Multi-conductor cable with locking connectors to supply power to the M2000 console. Approx. 3m (10') long.

* Specifications subject to change without notice.

**Umbilical Connector Pin Assignments****Power Supply (PW2000M)****Options**

Monaural Input Module (MN2000M)
Stereo Input Module (ST2000M)
Output Transformer (Rack Mount Type)
Power Supply (PW2000M)

● 0 dB=0.775 Vrms.

*1 20 Hz–20 kHz, $R_s=150\ \Omega$, Input Gain=Max, Input Pad=OFF,
Input sensitivity = -60 dB

General specifications (PW2000M)**Dimensions (w × d × h)**

480 × 334.5 × 98 mm (18-7/8" × 13-3/16" × 3-1/2")

Weight

13kg (28.5 lb)

Secondary

±17V 2.5A

+12V 3.8A

+48V 0.3A

Power requirements


USA and Canadian models: 120VAC, 60Hz

British model: 240V, 50Hz

General model: 230VAC, 50Hz

PW2000M umbilical connector pin assignments

Pin	Function
1	E (+48V)
2	E (+12V)
3	E (±17V)
4	+48V
5	+12V
6	+17V
7	-17V
8	GND
9	DETECT A
10	DETECT B



Input/output specifications (M2000)

INPUT CHARACTERISTICS

Connection	PAD	Gain Trim	Actual Load Impedance	For Use with Nominal	Input Level*2			Connector in Mixer
					Sensitivity*5	Nominal	Max. before Clip	
CH IN (1-*ch*1) INPUT A, B	0	-60	A; 5 kΩ	50-600 Ω Mics & 600 Ω Lines	-80 dB (0.078 mV)	-60 dB (0.775 mV)	-40 dB (7.75 mV)	A; XLR-3-31 type (Balanced)
	26				-54 dB (1.55 mV)	-34 dB (15.5 mV)	-14 dB (155 mV)	
	0	-16	B; 10 kΩ		-36 dB (12.3 mV)	-16 dB (123 mV)	+4 dB (1.23 V)	B; Phone Jack [TRS] (Balanced)**4
	26				-10 dB (245 mV)	+10 dB (2.45 V)	+30 dB (24.5 V)	
ST IN (1, 2) [L, R] INPUT A, B		-20	10 kΩ	600 Ω Lines	-40 dB (7.75 mV)	-20 dB (77.5 mV)	0 dB (0.775 V)	A; Phone Jack (Unbalanced)
		+10			-10 dB (245 mV)	+10 dB (2.45 V)	+30 dB (24.5 V)	B; RCA Pin Jack (Unbalanced)
RETURN (1-4) [L, R]		-10	10 kΩ	600 Ω Lines	-26 dB (38.8 mV)	-10 dB (245 mV)	+10 dB (2.45 V)	Phone Jack (Unbalanced)
		+4			-12 dB (195 mV)	+4 dB (1.23 V)	+24 dB (12.3 V)	
TALKBACK IN			10 kΩ	50-600 Ω Mics	-66 dB (0.388 mV)	-50 dB (2.45 mV)	-24 dB (48.9 mV)	XLR-3-31 type (Unbalanced)
2TR IN (1, 2) [L, R]			10 kΩ	600 Ω Lines	-16 dB (123 mV)	-10 dB (245 mV)	+10 dB (2.45 V)	RCA Pin Jack (Unbalanced)
GROUP (1-8) SUB IN STEREO [L, R] SUB IN MONO SUB IN			10 kΩ	600 Ω Lines	-6 dB (388 mV)	+4 dB (1.23 V)	+24 dB (12.3 V)	Phone Jack (Unbalanced)
AUX (1-6) SUB IN MATRIX [L, R] SUB IN CUE [L, R] SUB IN			10 kΩ	600 Ω Lines	-2 dB (0.616 V)	+4 dB (1.23 V)	+24 dB (12.3 V)	Phone Jack (Unbalanced)
CH (1-*ch*1) INSERT IN			10 kΩ	600 Ω Lines	-20 dB (77.5 mV)	0 dB (0.775 V)	+20 dB (7.75 V)	Phone Jack [TRS] (Unbalanced)*3
GROUP (1-8) INSERT IN STEREO [L, R] INSERT IN MONO INSERT IN			10 kΩ	600 Ω Lines	-6 dB (388 mV)	0 dB (0.775 V)	+20 dB (7.75 V)	Phone Jack [TRS] (Unbalanced)*3

*1) M2000 -16; 16ch, -24; 24ch, -32; 32ch, -40C; 40ch

*2) 0 dB is referenced to 0.775 Vrms.

*3) Insert Phone Jacks; T=OUT, R=IN, S=GND

*4) CH INPUT B Jacks; T=HOT, R=COLD, S=GND

*5) Sensitivity is the lowest level that will produce an output of +4 dB (1.23 V), or the nominal output level when the unit is set to maximum level.

OUTPUT CHARACTERISTICS

Connection	Actual Source Impedance	For Use with Nominal	Output Level*2		Connector in Mixer
			Nominal	Max. before clip	
GROUP OUT (1-8) STEREO OUT [L, R] MONO OUT AUX OUT (1-6) MATRIX A OUT (1-4)	150 Ω	600 Ω Lines	+4 dB (1.23 V)	+24 dB (12.3 V)	XLR-3-32 type (Balanced)
MATRIX B OUT (1-4) MONITOR OUT [L, R]	75 Ω	600 Ω Lines	+4 dB (1.23 V)	+20 dB (7.75 V)	Phone Jack (Unbalanced)
REC OUT [L, R]	600 Ω	10 k Ω Lines	-10 dB (245 mV)	+10 dB (2.45 V)	RCA Pin Jack (Unbalanced)
CH DIRECT OUT (1-*ch*1)	600 Ω	10 k Ω Lines	0 dB (0.775 V)	+20 dB (7.75 V)	Phone Jack (Unbalanced)
CH INSERT OUT (1-*ch*1) GROUP INSERT OUT (1-8) STEREO INSERT OUT [L, R] MONO INSERT OUT	600 Ω	10 k Ω Lines	0 dB (0.775 V)	+20 dB (7.75 V)	Phone Jack [TRS] (Unbalanced)*3
PHONES OUT [L, R]	100 Ω	8 Ω Phones	1 mW	20 mW	Stereo Phone Jack (Unbalanced)
		40 Ω Phones	3 mW	75 mW	

*1) M2000 -16; 16ch, -24; 24ch, -32; 32ch, -40C; 40ch

*2) 0 dB is referenced to 0.775 Vrms.

*3) Insert Phone Jacks; T=OUT, R=IN, S=GND

■ 総合仕様

仕様 (M2000)

一般仕様

全高調波歪率	0.1%以下 (THD+N)
(Master output)	20 Hz — 20 kHz @ +14 dB, 600 Ω
周波数特性	+1/-3 dB 20 Hz — 20 kHz @ +4 dB, 600 Ω
(Master output)	
ハム & ノイズ*	-128 dB入力換算ノイズ
(40 ch)	-97 dB残留ノイズ
	-80 dB (84 dB S/N) GROUP OUT Master fader at nominal level and all Ch assign SW's off.
	-64 dB (68 dB S/N) GROUP OUT Master fader and one Ch fader at nominal level.
	-79 dB (83 dB S/N) STEREO OUT MASTER fader at nominal level and all Ch assign SW's off and all Group → ST SW's off.
	-79 dB (83 dB S/N) MONO OUT Master fader at nominal level and all Ch assign SW's off and all Group → Mono SW's off.
	-77 dB (81 dB S/N) AUX OUT Master level control at nominal level and all Ch AUX Mix controls at minimum level.
	-92 dB (96 S/N) MATRIX OUT Master level control at nominal level and all Matrix Mix controls at minimum level.
クロストーク	-80 dB 入力ch間
(@1 kHz)	-70 dB 入力ch — 出力ch間 (Ch input)
	-50 dB 入力ch — 出力ch間 (Stereo input)
最大電圧利得	84 dB CH IN → GROUP OUT/ STEREO OUT (CH → ST) / MONO OUT (CH → MONO)
	94 dB CH IN → STEREO OUT (G → ST) / MONO OUT (G → MONO)
	104 dB CH IN → MONO OUT (G → ST & ST → MONO)
	90 dB CH IN → MATRIX OUT (G → MATRIX)
	76 dB CH IN → AUX OUT (Pre Fader)
	86 dB CH IN → AUX OUT (Post Fader)
	70 dB CH IN → MONITOR OUT (CH IN CUE)
	76 dB CH IN → DIRECT OUT
	60 dB CH IN → CH INSERT OUT
	44 dB ST IN → GROUP OUT/STEREO OUT (CH → ST) / MONO OUT (CH → MONO)
	33 dB ST IN → AUX OUT (Pre Fader)
	43 dB ST IN → AUX OUT (Post Fader)
	30 dB ST IN → MONITOR OUT (ST IN CUE)
	30 dB RETURN → GROUP OUT/STEREO OUT/ MONO OUT
	23 dB RETURN → AUX OUT
	70 dB TALKBACK IN → GROUP OUT/STEREO OUT/ MONO OUT
	10 dB SUB IN → GROUP OUT/STEREO OUT/ MONO OUT
	6 dB SUB IN → AUX OUT/ MONITOR OUT
	20 dB 2TR IN → MONITOR OUT


PADスイッチ	26 dB
モノラルGAINコントロール	44 dB variable
ステレオGAINコントロール	30 dB variable
ハイパスフィルター	12 dB/octave roll-off 80 Hz at -3 dB point.
モノラルEQ	最大可変幅±15 dB
	HIGH 12 kHz (シェルピング)
	HIGH-MID 400 Hz-8 kHz (ピーキング)
	LOW-MID 80 Hz-1.6 kHz (ピーキング)
	LOW 80 Hz (シェルピング)
ステレオEQ	最大可変幅±15 dB
	HIGH 12 kHz (シェルピング)
	MID 300 Hz-6 kHz (ピーキング)
	LOW 80 Hz (シェルピング)
RETURN EQ	最大可変幅±15 dB
	HIGH 12 kHz (シェルピング)
	LOW 80 Hz (シェルピング)
PEAKインジケータ	クリッピングの3 dB手前で赤色点灯 (ポストEQ)
SIGNALインジケータ	ノミナルレベルの10 dB手前で緑色点灯 (ポストEQ)
SCENE MEMORY	DIRECTスイッチ (#1 — #8)
(with MIDI control)	リコール可能シーン数 (#1 — #128)
VUメーター	(0 VU=+4 dB output @ 600 Ω load)
	大型3連メーター、2つは切換式
	L; STEREO L/CUE L
	R; STEREO R/CUE R
	MONO; MONO
	小型8連メーター、すべて切換式
	#1; GROUP 1/MATRIX 1 A/AUX 1
	#2; GROUP 2/MATRIX 2 A/AUX 2
	#3; GROUP 3/MATRIX 3 A/AUX 3
	#4; GROUP 4/MATRIX 4 A/AUX 4
	#5; GROUP 5/MATRIX 1 B/AUX 5
	#6; GROUP 6/MATRIX 2 B/AUX 6
	#7; GROUP 7/MATRIX 3 B
	#8; GROUP 8/MATRIX 4 B
VUメーターPeakインジケータ	クリッピングレベルの3 dB手前で赤色点灯
ファントム電源	バランス型コンデンサー
	マイク用の+48 V電源

最大外形寸法	高さ	223 mm
	奥行	785 mm
	幅	16 ch 970 mm
	24 ch	1202 mm
	32 ch	1434 mm

重量	16 ch	44 kg
	24 ch	54 kg
	32 ch	64 kg
	40 ch	76 kg

消費電力	16 ch	160 W
	24 ch	180 W
	32 ch	210 W
	40 ch	230 W

付属品 パワーサプライケーブル
M2000に給電するためのロックコネクタ付き多芯コンダクターケーブル
3m 10ピン



ピン配置

パワーサプライ (PW2000M)

オプション モノラルインプットモジュール (MN2000M)
ステレオインプットモジュール (ST2000M)
出力トランス (ラックマウント型)
パワーサプライ (PW2000M)

● 0 dB=0.775 Vrms.

* @20 Hz — 20 kHz, $R_s=150\Omega$, INPUT GAIN=MAX, INPUT PAD=OFF (入力感度-60 dB)

M2000/PW2000M

仕様 (PW2000M)

最大外形寸法 (W×H×D)
480×98×334.5 mm


重量
13 kg

出力
±17 V 2.5 A
+12 V 3.8 A
+48 V 0.3 A

電源
100 V 50/60 Hz

専用コネクタ—接続一覧表

ピンNo.	信号名
1	+48 V GND
2	+12 V GND
3	±17 V GND
4	+48 V
5	+12 V
6	+17 V
7	-17 V
8	FRAME GND
9	電源リモート
10	電源リモート



入出力仕様 (M2000)

入力仕様

入力端子	PAD	Gain	入力 インピーダンス	ソース インピーダンス	入力レベル*2			使用コネクター
					感度*5	規定レベル	最大ノン クリップレベル	
CH IN (1-※ch*) INPUT A, B	0	-60	A; 5 kΩ	50-600 Ω Mics & 600 Ω Lines	-80 dB (0.078 mV)	-60 dB (0.775 mV)	-40 dB (7.75 mV)	A; XLR-3-31タイプ (バランス型)
	26				-54 dB (1.55 mV)	-34 dB (15.5 mV)	-14 dB (155 mV)	
	0	-16	B; 10 kΩ		-36 dB (12.3 mV)	-16 dB (123 mV)	+4 dB (1.23 V)	B; フォンジャック [TRS] (バランス型) *4
	26				-10 dB (245 mV)	+10 dB (2.45 V)	+30 dB (24.5 V)	
ST IN (1, 2) [L, R] INPUT A, B	-20	+10	10 kΩ	600 Ω Lines	-40 dB (7.75 mV)	-20 dB (77.5 mV)	0 dB (0.775 V)	A; フォンジャック (アンバランス型) B; RCAピンジャック (アンバランス型)
	+10				-10 dB (245 mV)	+10 dB (2.45 V)	+30 dB (24.5 V)	
RETURN (1-4) [L, R]	-10	+4	10 kΩ	600 Ω Lines	-26 dB (38.8 mV)	-10 dB (245 mV)	+10 dB (2.45 V)	フォンジャック (アンバランス型)
	+4				-12 dB (195 mV)	+4 dB (1.23 V)	+24 dB (12.3 V)	
TALKBACK IN			10 kΩ	50-600 Ω Mics	-66 dB (0.388 mV)	-50 dB (2.45 mV)	-24 dB (48.9 mV)	XLR-3-31タイプ (アンバランス型)
2TR IN (1, 2) [L, R]			10 kΩ	600 Ω Lines	-16 dB (123 mV)	-10 dB (245 mV)	+10 dB (2.45 V)	RCAピンジャック (アンバランス型)
GROUP (1-8) SUB IN STEREO [L, R] SUB IN MONO SUB IN			10 kΩ	600 Ω Lines	-6 dB (388 mV)	+4 dB (1.23 V)	+24 dB (12.3 V)	フォンジャック (アンバランス型)
AUX (1-6) SUB IN MATRIX [L, R] SUB IN CUE [L, R] SUB IN			10 kΩ	600 Ω Lines	-2 dB (0.616 V)	+4 dB (1.23 V)	+24 dB (12.3 V)	フォンジャック (アンバランス型)
CH (1-※ch*) INSERT IN			10 kΩ	600 Ω Lines	-20 dB (77.5 mV)	0 dB (0.775 V)	+20 dB (7.75 V)	フォンジャック [TRS] (アンバランス型) *3
GROUP (1-8) INSERT IN STEREO [L, R] INSERT IN MONO INSERT IN			10 kΩ	600 Ω Lines	-6 dB (388 mV)	0 dB (0.775 V)	+20 dB (7.75 V)	フォンジャック [TRS] (アンバランス型) *3

*1) M2000 -16; 16ch, -24; 24ch, -32; 32ch, -40C; 40ch

*2) 0 dB=0.775 Vrms.

*3) Insert フォンジャック; T=OUT, R=IN, S=アース

*4) CH INPUT B ジャック; T=HOT, R=COLD, S=アース

*5) 感度は、ノミナル出力レベルを最大位置にした状態で、規定レベル (+4 dB=1.23 V) を得るために必要な最低レベルです。

出力仕様

出力端子	出力インピーダンス	負荷インピーダンス	出力レベル*2		使用コネクタ
			規定レベル	最大ノン クリップレベル	
GROUP OUT (1-8) STEREO OUT [L, R] MONO OUT AUX OUT (1-6) MATRIX A OUT (1-4)	150 Ω	600 Ω Lines	+4 dB (1.23 V)	+24 dB (12.3 V)	XLR-3-32タイプ (バランス型)
MATRIX B OUT (1-4) MONITOR OUT [L, R]	75 Ω	600 Ω Lines	+4 dB (1.23 V)	+20 dB (7.75 V)	フォンジャック (アンバランス型)
REC OUT [L, R]	600 Ω	10 k Ω Lines	-10 dB (245 mV)	+10 dB (2.45 V)	RCAピンジャック (アンバランス型)
CH DIRECT OUT (1-*ch*)	600 Ω	10 k Ω Lines	0 dB (0.775 V)	+20 dB (7.75 V)	フォンジャック (アンバランス型)
CH INSERT OUT (1-*ch*) GROUP INSERT OUT (1-8) STEREO INSERT OUT [L, R] MONO INSERT OUT	600 Ω	10 k Ω Lines	0 dB (0.775 V)	+20 dB (7.75 V)	フォンジャック [TRS] (アンバランス型) *3
PHONES OUT [L, R]	100 Ω	8 Ω Phones 40 Ω Phones	1 mW 3 mW	20 mW 75 mW	ステレオフォンジャック (アンバランス型)


*1) M2000 -16; 16ch, -24; 24ch, -32; 32ch, -40C; 40ch

*2) 0 dB=0.775 Vrms.

*3) Insert フォンジャック; T=OUT, R=IN, S=アース

■ DIMENSIONS(寸法図)


● M2000



Unit : mm
(単位 : mm)

M2000/PW2000M


● PW2000M




Unit : mm
(単位 : mm)

■ PANEL LAYOUT(パネルレイアウト)

● M2000




● INPUT Module (INPUTモジュール)




- ① Channel assign switches (1-2, 3-4, 5-6, 7-8, ST, MONO)
- ② PAN control
- ③ Phase (polarity) reverse switch(ϕ)
- ④ +48V phantom power switch
- ⑤ A/B input selector switch
- ⑥ GAIN control
- ⑦ 26dB pad switch
- ⑧ PEAK and SIGNAL LED indicators
- ⑨ High-pass filter switch (/80)
- ⑩ HIGH, HI-MID, LO-MID and LOW controls
- ⑪ EQ switch
- ⑫ Channel AUX controls (1-4) and switches (1-2, 3-4)
- ⑬ Channel AUX control (5)
- ⑭ Channel AUX control (6) and DIRECT switch
- ⑮ ON/EDIT switch, and ON and CHECK indicators
- ⑯ Channel fader
- ⑰ CUE switch

- ① チャンネルアサインスイッチ(1-2, 3-4, 5-6, 7-8, ST, MONO)
- ② PANコントロール
- ③ 位相切り換えスイッチ (ϕ)
- ④ +48Vファントム電源スイッチ
- ⑤ A/B入力セレクトスイッチ
- ⑥ GAINコントロール
- ⑦ 26dB PADスイッチ
- ⑧ PEAKとSIGNALインジケータ
- ⑨ ハイパスフィルタースイッチ (/80)
- ⑩ EQコントロール(HIGH、HI-MID、LO-MID、LOW)
- ⑪ EQスイッチ
- ⑫ AUX1-4コントロールとPREスイッチ(1-2、3-4)
- ⑬ AUX 5コントロール
- ⑭ AUX 6コントロールとDIRECTスイッチ
- ⑮ ON/EDITスイッチとONおよびCHECKインジケータ
- ⑯ チャンネルフェーダー
- ⑰ CUEスイッチ




● ST CHANNEL Module (ST CH モジュール)



- ① Channel assign switches (1-2, 3-4, 5-6, 7-8, ST, MONO)
- ② Balance control (BAL/PAN)
- ③ L+R switch
- ④ A/B switch
- ⑤ GAIN A and GAIN B controls
- ⑥ PEAK and SIGNAL LED indicators
- ⑦ HIGH, MID and LOW controls
- ⑧ EQ switch
- ⑨ Channel AUX controls (1-5) and switches (1-2, 3-4)
- ⑩ Channel AUX control (6)
- ⑪ ON/EDIT switch, and ON and CHECK indicators
- ⑫ Channel fader
- ⑬ CUE switch

- ① チャンネルアサインスイッチ(1-2, 3-4, 5-6, 7-8, ST, MONO)
- ② バランスコントロール(BAL/PAN)
- ③ L+Rスイッチ
- ④ A/B入力セレクトスイッチ
- ⑤ GAIN AおよびGAIN Bコントロール
- ⑥ PEAKおよびSIGNAL LEDインジケータ
- ⑦ EQコントロール(HIGH, MID, LOW)
- ⑧ EQスイッチ
- ⑨ AUX1~5コントロールとPREスイッチ(1-2, 3-4)
- ⑩ AUX 6コントロール
- ⑪ ON/EDITスイッチとONおよびCHECKインジケータ
- ⑫ チャンネルフェーダー
- ⑬ CUEスイッチ



● Scene Memory Block (SCENE MEMORY ブロック)



- ① UTILITY button
- ② RECALL button
- ③ STORE button
- ④ MEMORY display
- ⑤ CHECK button
- ⑥ ▲/▼ buttons
- ⑦ DIRECT RECALL buttons (1-8)

- ① UTILITYスイッチ
- ② RECALLスイッチ
- ③ STOREスイッチ
- ④ MEMORYディスプレイ
- ⑤ CHECKスイッチ
- ⑥ ▲/▼スイッチ
- ⑦ DIRECT RECALLスイッチ(1~8)


• MASTER Module (MASTER モジュール)



• GROUP block (GROUP ブロック)

- ① Group to mono switch (TO MONO)
- ② Group PAN control
- ③ Group to stereo assign switch (TO ST)
- ④ ON/EDIT switch, and ON and CHECK indicators
- ⑤ Group fader
- ⑥ Group CUE switch


- ① TO MONOスイッチ
- ② PANコントロール
- ③ TO STスイッチ
- ④ ON/EDITスイッチおよびONとCHECKインジケーター
- ⑤ グループフェーダー
- ⑥ CUEスイッチ



• AUX SEND block (AUX SEND ブロック)

- ① LEVEL controls (master AUX SEND controls)
- ② AUX CUE switches


- ① LEVELコントロール(マスターAUX SENDコントロール)
- ② CUEスイッチ



• AUX RETURN block (AUX RETURN ブロック)

- ① RETURN assign switches (1-2, 3-4, 5-6, 7-8, ST, MONO)
- ② Balance control (BAL/PAN)
- ③ RETURN to AUX assign switches (AUX 1, AUX 2, AUX 3, AUX 4)
- ④ HIGH and LOW equalization controls
- ⑤ AUX RETURN LEVEL control
- ⑥ ON/EDIT switch, and ON and CHECK indicators
- ⑦ AUX RETURN CUE switch


- ① リターンアサインスイッチ(1-2, 3-4, 5-6, 7-8, ST, MONO)
- ② バランスコントロール(BAL/PAN)
- ③ AUXアサインスイッチ(AUX 1, AUX 2, AUX 3, AUX 4)
- ④ EQコントロール(HIGH, LOW)
- ⑤ LEVELコントロール
- ⑥ ON/EDITスイッチおよびONとCHECKインジケーター
- ⑦ CUEスイッチ



• MATRIX block (MATRIX ブロック)

- ① Matrix input level controls (SUB L,R, ST L,R, MONO, GROUP 1-8)
- ② LEVEL B control
- ③ Output B ON switch and indicator
- ④ LEVEL A control
- ⑤ Output A ON switch and indicator
- ⑥ MATRIX CUE switch


- ① 入力レベルコントロール(SUB L/R, ST L/R, MONO, GROUP 1-8)
- ② LEVEL B コントロール
- ③ B出力のONスイッチとインジケーター
- ④ LEVEL A コントロール
- ⑤ A出力のONスイッチとインジケーター
- ⑥ CUEスイッチ



• STEREO MASTER block (STEREO MASTER ブロック)

- ① TO MONO switch and balance control (BAL)
- ② ON/EDIT switch, and ON and CHECK indicators
- ③ Master faders
- ④ Master CUE switch


- ① TO MONOスイッチとバランスコントロール(BAL)
- ② ON/EDITスイッチおよびONとCHECKインジケーター
- ③ マスターフェダー
- ④ CUEスイッチ



• MONO block (モノブロック)

- ① ON/EDIT switch, and ON and CHECK indicators
- ② MONO fader
- ③ MONO CUE switch


- ① ON/EDITスイッチおよびONとCHECKインジケータ
- ② MONOフェーダー
- ③ CUEスイッチ



• TALKBACK and OSCILLATOR block (TALKBACKとOSCILLATOR ブロック)

- ① Talkback assign switches (1-2, 3-4, 5-6, 7-8, ST, MONO, AUX1-2, AUX3-4, AUX5-6)
- ② OSCILLATOR ON switch and indicator
- ③ Talkback INPUT connector
- ④ Talkback LEVEL control
- ⑤ Talkback ON switch and indicator

- ① アサインスイッチ(1-2, 3-4, 5-6, 7-8, ST, MONO, AUX1-2, AUX3-4, AUX5-6)
- ② OSCILLATORのONスイッチとインジケータ
- ③ TALKBACKのINPUTコネクター
- ④ TALKBACKのLEVELコントロール
- ⑤ TALKBACKのONスイッチとインジケータ



• MONITOR and METER block (MONITORとMETERブロック)


- ① METER 1-8 selector switches (GROUP, MATRIX, AUX)
- ② METER L-R ST HOLD switch
- ③ 2-track input switches (2TR IN 1 and 2)
- ④ INPUT CUE and MASTER CUE indicators
- ⑤ MASTER PFL switch
- ⑥ Monitor mono switch (L+R)
- ⑦ MONITOR LEVEL control, and ON switch and indicator
- ⑧ PHONES jack, and LEVEL control

- ① METER1～8セレクトスイッチ(GROUP, MATRIX, AUX)
- ② METER L-Rスイッチ(ST HOLD)
- ③ 2TR INスイッチ(1と2)
- ④ INPUT CUEとMASTER CUEインジケータ
- ⑤ MASTER PFLスイッチ
- ⑥ モニターモノラルスイッチ(L+R)
- ⑦ LEVELコントロールおよびONスイッチとインジケータ
- ⑧ PHONESジャックとLEVELコントロール

① METER 1-8 selector switches (GROUP, MATRIX, AUX)

Only one of these switches, which select which signals will appear on meters 1-8, can be depressed at a time. The large, illuminated VU meters will display as follows:

- ① METER 1～8セレクトスイッチ (GROUP、MATRIX、AUX)
どの信号をメーター1～8に反映するかを選択します。1度に押せるスイッチは1つです。各スイッチによって、VUメーターは以下の信号レベルを示します。




Meter Switch	1	2	3	4	5	6	7	8
GROUP	1	2	3	4	5	6	7	8
MATRIX	1A	2A	3A	4A	5A	6A	7A	8A
AUX	1	2	3	4	5	6	-	-

② METER L-R ST HOLD switch

Normally, whenever any CUE switch is operated, the L and R meters switch from indicating the main stereo output to indicating the monitor output. When the ST HOLD switch is depressed, however, the L and R meters will always indicate the main stereo output.


- ② METER L-Rスイッチ (ST HOLD)
通常、CUEスイッチをオンにすれば、LとRメーターはメインステレオ出力の表示からモニター出力の表示に切り換わります。このスイッチがオン(■)のとき、LとRメーターは常にメインステレオ出力を表示し続けます。



NOTE: The PEAK indicators light when the signal level reaches 3dB below clipping.

(注意: クリッピングレベルの3 dB手前でPEAKインジケータが点灯します。)

• Rear Panel (リアパネル)




- ① STEREO outputs
- ② MONO output
- ③ MONO INSERT connector
- ④ STEREO INSERT connectors
- ⑤ MONITOR outputs (L, R)
- ⑥ 2-track in connectors (2TR IN1&2)
- ⑦ REC outputs
- ⑧ GROUP INSERT connectors (1-8)
- ⑨ MATRIX outputs (A,B)
- ⑩ AUX RETURN connectors and level switches
- ⑪ MIDI jacks (IN, OUT, THRU)
- ⑫ SUB IN connectors (GROUP 1-8, STEREO L, R, MONO, AUX 1-6, CUE, MATRIX)
- ⑬ CUE CTRL
- ⑭ AUX SEND connectors (1-6)
- ⑮ GROUP OUT connectors (1-8)
- ⑯ DC power input connector
- ⑰ INPUT A (Unbalanced 1/4 inch phone jacks)
- ⑱ INPUT B (RCA connectors)
- ⑲ INPUT A (Balanced XLR connectors)
- ⑳ INPUT B (Balanced 1/4 inch phone jacks)
- ㉑ INSERT I/O
- ㉒ DIRECT OUT

- ① ST OUT(L,R)
- ② MONO OUT
- ③ MONO INSERT I/O
- ④ ST INSERT I/O
- ⑤ MONITOR OUT(L, R)
- ⑥ 2TR IN (1, 2)
- ⑦ REC OUT (L,R)
- ⑧ GROUP INSERT I/O (1-8)
- ⑨ MATRIX OUT (A, B)
- ⑩ AUX RETURN (1-4)とレベルスイッチ
- ⑪ MIDIジャック(IN, OUT, THRU)
- ⑫ SUB IN (GROUP, ST, MONO, AUX, CUE, MATRIX)
- ⑬ CUE CTRL
- ⑭ AUX OUT (1-6)
- ⑮ GROUP OUT (1-8)
- ⑯ DC POWER INPUT
- ⑰ ST INPUT A(アンバランス型1/4インチフォンジャック)
- ⑱ ST INPUT B (RCAコネクター)
- ⑲ INPUT A(バランス型XLRコネクター)
- ⑳ INPUT B(バランス型1/4インチフォンジャック)
- ㉑ INSERT I/O
- ㉒ DIRECT OUT


• DC power input connector pin assignments (DC POWER INPUT専用コネクターピン配列表)

Pin	Function
1	E (+48V)
2	E (+12V)
3	E ($\pm 17V$)
4	+48V
5	+12V
6	+17V
7	-17V
8	GND
9	DETECT A
10	DETECT B



■ PW2000M Panel Layout (PW2000Mパネルレイアウト)


● Front Panel (フロントパネル)



- ① Power switch (POWER)
② Operating monitor (OPERATION MONITOR)

- ① POWER (電源スイッチ)
② OPERATION MONITOR (+48、+12、+17、-17V)

● Rear Panel (リアパネル)




- ③ Umbilical connector (DC OUTPUT)
④ Main Fuse (FUSE)
⑤ Power cable


- ③ 専用コネクタ (DC OUTPUT)
④ FUSE
⑤ ACコード

PW2000M umbilical connector pin assignments (専用コネクタピン配列)

Pin	Function
1	E (+48V)
2	E (+12V)
3	E ($\pm 17V$)
4	+48V
5	+12V
6	+17V
7	-17V
8	GND
9	DETECT A
10	DETECT B



■ CIRCUIT BOARD LAYOUT & WIRING (ユニットレイアウトと基板結線図)



■ DISASSEMBLY PROCEDURE (分解手順)

- | | |
|--|-------------------------------------|
| 1 Meter Panel | 1 メーターパネル |
| 2 Front Pad | 2 フロントパッド |
| 3 INPUT Module | 3 INPUTモジュール |
| 4 ST CHANNEL Module | 4 ST-CHモジュール |
| 5 MASTER Module | 5 MASTERモジュール |
| 6 IN Circuit Board & Monaural Fader | 6 INシートとMONOフェーダー |
| 7 ST-IN Circuit Board & Stereo Fader | 7 ST-INシートとSTフェーダー |
| 8 RETURN Circuit Board & Monaural Fader | 8 RETURNシートとMONOフェーダー |
| 9 MATRIX1, MATRIX3 Circuit Boards & Monaural Fader | 9 MATRIX1 シートとMATRIX3 シートとMONOフェーダー |
| 10 ST1/2 Circuit Board & Monaural Fader | 10 ST1/2シートとMONOシートとフェーダー |
| 11 PS Circuit Board | 11 PSシート |
| 12 MIDI1/4 & MIDI2/4 Circuit Boards | 12 MIDI1/4シートとMIDI2/4シート |
| 13 MIDI3/4 Circuit Board | 13 MIDI3/4シート |
| 14 MIDI4/4 Circuit Board | 14 MIDI4/4シート |
| 15 ST2/2 Circuit Board | 15 ST2/2シート |
| 16 DISTRI1/2 Circuit Board | 16 DISTRI1/2シート |
| 17 DISTRI2/2 Circuit Board | 17 DISTRI2/2シート |
| 18 JK1/2 & JK2/2 Circuit Boards | 18 JK1/2シートとJK2/2シート |
| 19 BNC1/3, BNC2/3 & BNC3/3 Circuit Boards | 19 BNC1/3シートとBNC2/3シートとBNC3/3シート |
| 20 MTC Circuit Board | 20 MTCシート |
| 21 MTA4 Circuit Board | 21 MTA4シート |
| 22 Lithium Battery | 22 リチウム電池 |

1 Meter Panel

- 1-1 Remove the screws marked as [1110] in the figure, then you can open the meter panel. (Fig. 1)


- * The screws marked [1110] are
 five (5) on a M2000-16.
 six (6) on a M2000-24.
 seven (7) on a M2000-36.
 eight (8) on a M2000-40c

1 メーターパネル

- 1-1 [1110]のネジを外し、メーターパネルを開けます。(図1)

- * [1110]のネジは、
 M2000-16: 5本
 M2000-24: 6本
 M2000-32: 7本
 M2000-40C: 8本
 あります。

- [620]: Bind Head Tapping Screw-P (＋バインドPタイト) 3.0X8 ZMC2BL (EP630220)
 [630]: Bind Head Screw (＋バインド小ネジ) A4.0X8 FCM3BL (EL000320)
 [790]: Bind Head Tapping Screw-B (＋バインドBタイト) A4.0X8 ZMC2BL (VC688800)
 [810]: Bind Head Tapping Screw-B (＋バインドBタイト) A4.0X8 ZMC2BL (VC688800)
 [830]: Bind Head Tapping Screw-B (＋バインドBタイト) A4.0X8 ZMC2BL (VC688800)
 [1110]: Bind Head Screw (＋バインド小ネジ) A4.0X8 FCM3BL (EL000320)
 [1140]: Bind Head Screw (＋バインド小ネジ) A4.0X8 FCM3BL (EL000320)



(Fig. 1) Overall Assembly

2 Front Pad

2-1 Remove the screws marked [1140], then the front pad can be removed. (Fig. 1)

- * The screws marked [1140] are
 - five (5) on a M2000-16.
 - six (6) on a M2000-24.
 - seven (7) on a M2000-36.
 - eight (8) on a M2000-40c

3 INPUT Module

3-1 Open the meter panel. (See procedure 1)

3-2 Remove the front pad. (See procedure 2)

3-3 M2000-16/24/32: Remove the two (2) screws marked [940] and two (2) screws marked [1060A], then raise up earth bars. (Fig. 2-A)

M2000-40C: Remove the two (2) screws marked [940] and two (2) screws marked [1010], then raise up earth bars. (Fig. 2-B)

3-4 Remove the five (5) screws marked [790] holding the INPUT module that you would like to remove. (Fig. 1)

3-5 Remove the two (2) screws marked [1080A] tightening the GND wires that are concerned with the INPUT module. (Fig. 2-A and Fig. 2-B)

3-6 Disconnect the flat cable connector, then take out the INPUT module of the unit.

4 ST CHANNEL Module

4-1 Open the meter panel. (See procedure 1)

4-2 Remove the front pad. (See procedure 2)

4-3 M2000-16/24/32: Remove the two (2) screws marked [940] and two (2) screws marked [1060A], then raise up earth bars. (Fig. 2-A)

M2000-40C: Remove the two (2) screws marked [940] and two (2) screws marked [1010], then raise up earth bars. (Fig. 2-B)

4-4 Remove the four (4) screws marked [810]. (Fig. 1)

4-5 Remove the screw marked [1080B] tightening the GND wire. (Fig. 2-A and Fig. 2-B)

4-6 Disconnect the flat cable connector, then take out the ST CHANNEL module of the unit.

2 フロントパッド

2-1 [1140]のネジを外し、フロントパッド外します。(図1)

- * [1140]のネジは、

M2000-16:	5本
M2000-24:	6本
M2000-32:	7本
M2000-40C:	8本

 あります。

3 INPUTモジュール

3-1 メーターパネルを開けます。(1項参照)

3-2 フロントパッドを外します。(2項参照)

3-3 M2000-16/24/32: [940]のネジ2本と[1060A]のネジ2本を外し、アースバーを持ち上げます。(図2-A)

M2000-40C: [940]のネジ2本と[1010]のネジ2本を外し、アースバーを持ち上げます。(図2-B)

3-4 当該のINPUTモジュールを止めている[790]のネジ5本を外します。(図1)

[790]のネジは、リア側に3本とフロント側に2本あります。

3-5 アースバーに当該のINPUTモジュールからのアース線を止めている[1080A]のネジ2本を外します。(図2-Aと図2-B)

3-6 フラットケーブルのコネクターを外して、INPUTモジュールを本体から取り出します。

4 ST-CHモジュール

4-1 メーターパネルを開けます。(1項参照)

4-2 フロントパッドを外します。(2項参照)

4-3 M2000-16/24/32: [940]のネジ2本と[1060A]のネジ2本を外し、アースバーを持ち上げます。(図2-A)

M2000-40C: [940]のネジ2本と[1010]のネジ2本を外し、アースバーを持ち上げます。(図2-B)

4-4 [810]のネジ4本を外します。(図1)

[810]のネジは、リア側に2本とフロント側に2本あります。

4-5 アースバーにアース線を止めている[1080B]のネジ1本を外します。(図2-Aと図2-B)


4-6 フラットケーブルのコネクターを外して、ST-CHモジュールを本体から取り出します。

5 MASTERモジュール


- 5-1 メーターパネルを開けます。(1項参照)
- 5-2 フロントパッドを外します。(2項参照)
- 5-3 M200-16/24/32の場合は、[1060A]のネジ2本と[1060B]のネジ1本を外して、MASTERモジュール部分のアースバーを外します。(図2-A)
M200-40Cの場合は、[1060]のネジ4本を外して、MASTERモジュール部分のアースバーを外します。(図2-B)
- 5-4 MASTERモジュールを止めている[830]のネジ10本を外します。(図1)
[830]のネジは、リア側に8本とフロント側に2本あります。
- 5-5 フラットケーブルのコネクターを外します。
- 5-6 MIDI4/4シートのコネクターCN408とCN409を抜いて、MASTERモジュールを本体から取り出します。
- 5-7 アースバーにアース線を止めている[1080C]のネジ10本を外し、アースバーを外します。(図2-Aと図2-B)

5 MASTER Module

- 5-1 Open the meter panel. (See procedure 1)
- 5-2 Remove the front pad. (See procedure 2)
- 5-3 M2000-16/24/32: Remove the two (2) screws marked [1060A] and the screw marked [1060B], then remove the earth bar that is located on the MASTER module. (Fig. 2-A)
M2000-40C: Remove the four (4) screws marked [1060], then remove the earth bar that is located on the MASTER module. (Fig. 2-B)
- 5-4 Remove the ten (10) screws marked [830]. (Fig. 1)
- 5-5 Disconnect the flat cable connectors.
- 5-6 Disconnect the connectors CN408 and CN409 from the MIDI4/4 circuit board, then take out the MASTER module of the unit.
- 5-7 Remove the ten (10) screws marked [1080C] tightening the GND wire, then remove the earth bar. (Fig. 2-A and Fig. 2-B)



(Fig. 2-A) M2000-16/24/32



(Fig. 2-B) M2000-40C

[940]: Bind Head Screw (+バインド小ネジ) A4.0X8 FCM3BL (EL000320)

[1060]: Bind Head Screw (+バインド小ネジ) A4.0X8 FCM3BL (EL000320)

[1080]: Bind Head Screw (+バインド小ネジ) A4.0X8 FCM3BL (EL000320)


[1110]: Bind Head Screw (+バインド小ネジ) A4.0X8 FCM3BL (EL000320)

6 INPUT Circuit Board & Monaural Fader

- 6-1 Open the meter panel. (See procedure 1)
 6-2 Remove the front pad. (See procedure 2)
 6-3 Remove the INPUT module. (See procedure 3)
 6-4 After the two (2) screws marked [50] have been removed, then the monaural fader can be removed. (Fig. 3)
 6-5 Remove the four (4) screws marked [140]. (Fig. 3)
 6-6 Remove the eight (8) screws marked [120] and eight (8) screws marked [130], then the INPUT rear panel can be removed. (Fig. 3)
 6-7 Pull off knobs that are attached to the IN circuit board that you would like to remove.
 Remove the fourteen (14) hexagonal nuts marked [90], then the IN circuit board can be removed. (Fig. 3)

6 INシートとMONOフェーダー

- 6-1 メーターパネルを開けます。(1項参照)
 6-2 フロントパッドを外します。(2項参照)
 6-3 INPUTモジュールを外します。(3項参照)
 6-4 [50]のネジ2本を外すと、MONOフェーダーを外すことができます。(図3)
 6-5 [140]のネジ4本を外します。(図3)
 6-6 [120]のネジ8本と[130]のネジ8本を外し、リアパネルINを外します。(図3)
 6-7 当該チャンネルのツマミ類を外し、[90]の六角ナット14個を外してINシートを外します。(図3)



(Fig. 3) INPUT module


- [50]: Flat Head Screw (+皿小ネジ) 3.0X6 ZMC2BL (EC030030)
 [90]: Hexagonal Nut (特殊六角ナット) 9 ZMC2BL (VJ388000)
 [120]: Bonding Head Screw (BONDING小ネジ) 3.0X6 FCM3BL (VC082800)
 [130]: Bind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)
 [140]: Flat Head Screw (+皿小ネジ) B3.0X6 ZMC2BL (VS182000)
 [160]: Bind Head Tapping Screw-B (+バインドBタイト) A4.0X12 ZMC2BL (VD831800)

7 ST-IN Circuit Board & Stereo Fader

- 7-1 Open the meter panel. (See procedure 1)
- 7-2 Remove the front pad. (See procedure 2)
- 7-3 Remove the ST CHANNEL module. (See procedure 4)
- 7-4 After the two (2) screws marked [50] have been removed, then a stereo fader can be removed. (Fig. 4)
- 7-5 Remove the four (4) screws marked [150]. (Fig. 4)
- 7-6 Remove the two (2) screws marked [130] and two (2) screws marked [140], then the STCH rear panel can be removed. (Fig. 4)
- 7-7 Pull off knobs that are attached to the ST-IN circuit board that you would like to remove.
Remove the twelve (12) hexagonal nuts marked [90], then the ST-IN circuit board can be removed. (Fig. 4)

7 ST-INシートとST-INフェーダー

- 7-1 メーターパネルを開けます。(1項参照)
- 7-2 フロントパッドを外します。(2項参照)
- 7-3 ST-CHモジュールを外します。(4項参照)
- 7-4 [50]のネジ2本を外すと、STフェーダーを外すことができます。(図4)
- 7-5 [150]のネジ4本を外します。(図4)
- 7-6 [130]のネジ2本と[140]のネジ2本を外し、リアパネルSTCHを外します。(図4)
- 7-7 ツマミ類を外し、[90]の六角ナット12個を外してST-INシートを外します。(図4)



(Fig. 4) ST CHANNEL Module

- [50]: Flat Head Screw (＋皿小ネジ) 3.0X6 ZMC2BL (EC030030)
 [90]: Hexagonal Nut (特殊六角ナット) 9 ZMC2BL (VJ388000)
 [130]: Bind Head Tapping Screw-B (＋バインドBタイト) A3.0X6 ZMC2BL (VP157900)
 [140]: Bind Head Tapping Screw-P (＋バインドPタイト) 3.0X8 ZMC2BL (EP630220)
 [150]: Flat Head Screw (＋皿小ネジ) B3.0X6 ZMC2BL (VS182000)

8 RETURN Circuit Board & Monaural Fader

- 8-1 Open the meter panel. (See procedure 1)
- 8-2 Remove the front pad. (See procedure 2)
- 8-3 Remove the MASTER module. (See procedure 5)
- 8-4 After the two (2) screws marked [50A] have been removed, then the monaural fader can be removed. (Fig. 5)
- 8-5 Remove the two (2) screws marked [290]. (Fig. 5)
- 8-6 Remove the sixteen (16) screws marked [270] and eight (8) screws marked [280], then the MA1 rear panel can be removed. (Fig. 5)
- 8-7 Pull off knobs that are attached to the RETURN circuit board that you try to remove. Remove the six (6) hexagonal nuts marked [130], then the RETURN circuit board can be removed. (Fig. 5)

* When you replace the RETURN circuit board with a new one, you should set the internal switches of the new RETURN circuit board according to the channel. (Refer to the RETURN circuit board section on page C6.)

The RETURN circuit board provided as a service parts is set for the RETURN 1 channel.

9 MATRIX1 and MATRIX3 Circuit Boards & Monaural Fader

- 9-1 Open the meter panel. (See procedure 1)
- 9-2 Remove the front pad. (See procedure 2)
- 9-3 Remove the MASTER module. (See procedure 5)
- 9-4 After the two (2) screws marked [50B] have been removed, then the monaural fader can be removed. (Fig. 5)
- 9-5 Remove the twenty (20) screws marked [310] and four (4) screws marked [320], then the MA2 rear panel can be removed. (Fig. 5)
- 9-6 Pull off knobs that are attached to the MATRIX circuit board that you try to remove. Remove the hexagonal nuts marked [150], then the MATRIX circuit board can be removed. (Fig. 5)

* When you replace the MATRIX1 or MATRIX3 circuit board with a new one, you should set the internal switches of the new MATRIX1 or MATRIX3 circuit board according to the channel. (Refer to the MATRIX1 or MATRIX3 circuit board section on page C8 and C10.)

The MATRIX1 circuit board provided as a service parts is used for the MATRIX 1 and MATRIX 2 channels. It is set for the MATRIX 1 channel.

The MATRIX3 circuit board provided as a service parts is used for the MATRIX 3 and MATRIX 4 channels. It is set for the MATRIX 3 channel.

8 RETURNシートとMONOフェーダー

- 8-1 メーターパネルを開けます。(1項参照)
- 8-2 フロントパッドを外します。(2項参照)
- 8-3 MASTERモジュールを外します。(5項参照)
- 8-4 [50A]のネジ2本を外すと、MONOフェーダーを外すことができます。(図5)
- 8-5 [290]のネジ2本を外します。(図5)
- 8-6 [270]のネジ16本と[280]のネジ8本を外し、リアパネルMA1を外します。(図5)
- 8-7 当該チャンネルのツマミ類を外し、[130]の六角ナット6個を外してRETURNシートを外します。(図5)

* RETURNシート交換時は、使用チャンネルに応じてシート内の短絡ソケットの設定が必要です。詳細についてはRETURNシート基板図のページを参照して下さい。

サービス用部品として供給されるRETURNシートは、RETURN1チャンネル用です。

9 MATRIX1シートとMATRIX3シートとMONOフェーダー

- 9-1 メーターパネルを開けます。(1項参照)
 - 9-2 フロントパッドを外します。(2項参照)
 - 9-3 MASTERモジュールを外します。(5項参照)
 - 9-4 [50B]のネジ2本を外すと、MONOフェーダーを外すことができます。(図5)
 - 9-5 [310]のネジ20本と[320]のネジ4本を外し、リアパネルMA2を外します。(図5)
 - 9-6 当該チャンネルのツマミ類を外し、[150]の六角ナットを外してシートを外します。(図5)
- [150]の六角ナットは、MATRIX1シートで17個、MATRIX3シートで16個あります。(図5)

* MATRIX1シートとMATRIX3シートの交換時は、使用チャンネルに応じてシート内の短絡ソケットの設定が必要です。詳細についてはシート基板図のページを参照して下さい。

MATRIX1とMATRIX2チャンネル用として供給されるサービス用のMATRIX1シートは、MATRIX1チャンネル用です。

また、MATRIX3とMATRIX4チャンネル用として供給されるサービス用のMATRIX3シートは、MATRIX3チャンネル用です。

10 ST1/2 and MONO Circuit Boards & Faders

10-1 Open the meter panel. (See procedure 1)

10-2 Remove the front pad. (See procedure 2)

10-3 Remove the MASTER module. (See procedure 5)

10-4 After the two (2) screws marked [50] have been removed, then the monaural fader can be removed. (Fig. 5)

To remove a stereo fader, remove the two (2) screws marked [70]. (Fig. 5)

10-5 Remove the two (2) screws marked [370]. (Fig. 5)

10-6 Remove the six (6) screws marked [340], three (3) screws marked [350] and two (2) screws marked [360], then the MA3 rear panel can be removed. (Fig. 5)

10-7 Pull off knobs that are attached to the ST1/2 circuit board that you try to remove.

Remove the two (2) screws marked [200] and two (2) hexagonal nuts marked [190], then the ST1/2 circuit board can be removed. (Fig. 5)

The MONO circuit board can be removed by removing knobs and the two (2) hexagonal nuts marked [230]. (Fig. 5)

10 ST1/2シートとMONOシートとフェーダー

10-1 メーターパネルを開けます。(1項参照)

10-2 フロントパッドを外します。(2項参照)

10-3 MASTERモジュールを外します。(5項参照)

10-4 [50]のネジ2本を外すと、MONOフェーダーを外すことができます。(図5)


[70]のネジ2本を外すと、STフェーダーを外すことができます。(図5)

10-5 [370]のネジ2本を外します。(図5)

10-6 [340]のネジ6本と[350]のネジ3本と[360]のネジ2本を外し、リアパネルMA3を外します。(図5)

10-7 ST1/2シートはツマミ類を外し、[200]のネジ2本と[190]の六角ナット2個を外すと外すことができます。(図5)

MONOシートはツマミ類を外し、[230]の六角ナット2個を外すと外すことができます。(図5)



[50]: Flat Head Screw (＋皿小ネジ) 3.0X6 ZMC2BL (EC030030)

[70]: Flat Head Screw (＋皿小ネジ) 3.0X6 ZMC2BL (EC030030)

[130]: Hexagonal Nut (特殊六角ナット) 9 ZMC2BL (VJ388000)

[150]: Hexagonal Nut (特殊六角ナット) 9 ZMC2BL (VJ388000)

[190]: Hexagonal Nut (特殊六角ナット) 9 ZMC2BL (VJ388000)

(Fig. 5) MASTER Module

- [200]: Bonding Head Screw (BONDING小ネジ) 3.0X6 FCM3BL (VC082800)
- [230]: Hexagonal Nut (特殊六角ナット) 9 ZMC2BL (VJ388000)
- [270]: Bonding Head Screw (BONDING小ネジ) 3.0X6 FCM3BL (VC082800)
- [280]: Bind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)
- [290]: Flat Head Screw (+皿小ネジ) B3.0X6 ZMC2BL (VS182000)
- [310]: Bonding Head Screw (BONDING小ネジ) 3.0X6 FCM3BL (VC082800)
- [320]: Bind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)
- [340]: Bonding Head Screw (BONDING小ネジ) 3.0X6 FCM3BL (VC082800)
- [350]: Bind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)
- [360]: Bind Head Tapping Screw-P (+バインドPタイト) 3.0X8 ZMC2BL (EP630220)
- [370]: Flat Head Screw (+皿小ネジ) B3.0X6 ZMC2BL (VS182000)

11 PS Circuit Board


- * The PS circuit board is located on the right-side of the SCENE MEMORY panel.

- 11-1 Open the meter panel. (See procedure 1)
- 11-2 Remove the front pad. (See procedure 2)
- 11-3 Remove the MASTER module. (See procedure 5)
- 11-4 Remove the three (3) screws marked [750]. (Fig. 6)
- 11-5 Remove the four (4) screws marked [740], then remove the shield plate. (Fig. 7)
- 11-6 Remove the two (2) screws marked [620] and the screw marked [630] located on the rear panel. (Fig. 1)
- 11-7 Remove the two (2) screws marked [600] and two (2) screws marked [640], then the PS circuit board can be removed. (Fig. 8)

11 PSシート

- * PSシートは、シーンメモリーパネルに取り付けられています。

- 11-1 メーターパネルを開けます。(1項参照)
- 11-2 フロントパッドを外します。(2項参照)
- 11-3 MASTERモジュールを外します。(5項参照)
- 11-4 [750]のネジ3本を外します。(図6)
- 11-5 [740]のネジ4本を外し、シールドプレートを外します。(図7)
- 11-6 リアパネル上にある[620]のネジ2本と[630]のネジ1本を外します。(図1)
- 11-7 [600]のネジ2本と[640]のネジ2本を外し、PSシートを外します。(図8)



(Fig. 6)

[750]: Bind Head Tapping Screw-B (+バインドBタイト) A4.0X8 ZMC2BL (VC688800)

12 MIDI1/4 & MIDI2/4 Circuit Boards


- * The MIDI1/4 and MIDI2/4 circuit boards are located on the right-side of the SCENE MEMORY panel.

- 12-1 Open the meter panel. (See procedure 1)
- 12-2 Remove the front pad. (See procedure 2)
- 12-3 Remove the MASTER module. (See procedure 5)
- 12-4 Remove the three (3) screws marked [750]. (Fig. 6)
- 12-5 Remove the four (4) screws marked [740], then remove the shield plate. (Fig. 7)
- 12-6 Remove the three (3) screws marked [580], and then remove the MIDI1/4 circuit board from the spacers. (Fig. 8)
- 12-7 Remove the screw marked [500] and two (2) screws marked [510], then the MIDI2/4 circuit board can be removed. (Fig. 7 and Fig. 8)

12 MIDI1/4シートとMIDI2/4シート

- * MIDI1/4シートとMIDI2/4シートは、シーンメモリーパネルに取り付けられています。

- 12-1 メーターパネルを開けます。(1項参照)
- 12-2 フロントパッドを外します。(2項参照)
- 12-3 MASTERモジュールを外します。(5項参照)
- 12-4 [750]のネジ3本を外します。(図6)
- 12-5 [740]のネジ4本を外し、シールドプレートを外します。(図7)
- 12-6 [580]のネジ3本を外し、[330]のロッキングカードスペーサー3箇所からMIDI1/4シートを外します。(図8)
- 12-7 [500]のネジ1本と[510]のネジ2本を外し、MIDI2/4シートを外します。(図7と図8)




(Fig. 7) SCENE memory panel

[510]: Flat Head Screw (+皿小ネジ) B3.0X6 ZMC2BL (VS182000)

[740]: Flat Head Screw (+皿小ネジ) B3.0X6 ZMC2BL (VS182000)

Lithium battery (リチウム電池)

The lithium battery is not a part of the PS circuit board.
(リチウム電池は、PSシートの構成部品ではありません。)



(Fig. 8) SCENE memory panel

[500]: Blind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)

[580]: Blind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)

[600]: Blind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)

[640]: Blind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)

13 MIDI3/4 Circuit Board

- * The MIDI3/4 circuit board is located on the front-side of the ST CHANNEL module.

13-1 Remove the front pad. (See procedure 2)

13-2 Remove the screw marked [475A], then the MIDI3/4 circuit board can be removed. (Fig. 9)

14 MIDI4/4 Circuit Board

- * The MIDI4/4 circuit board is located on the front-side of the MASTER module.

14-1 Remove the front pad. (See procedure 2)

14-2 Remove the three (3) screws marked [475B], then the MIDI4/4 circuit board can be removed. (Fig. 9)

15 ST2/2 Circuit Board

- * The ST2/2 circuit board is located on the front-side of the MASTER module.

15-1 Remove the front pad. (See procedure 2)

15-2 Remove the two (2) screws marked [210], then the ST2/2 circuit board can be removed. (Fig. 9)

13 MIDI3/4シート

- * MIDI3/4シートは、ST-CHモジュール前部に取り付けられています。

13-1 フロントパッドを外します。(2項参照)

13-2 [475A]のネジ1本を外し、MIDI3/4シートを外します。(図9)

14 MIDI4/4シート

- * MIDI4/4シートは、MASTERモジュール前部に取り付けられています。

14-1 フロントパッドを外します。(2項参照)


14-2 [475B]のネジ3本を外し、MIDI4/4シートを外します。(図9)

15 ST2/2シート

- * ST2/2シートは、MASTERモジュール前部に取り付けられています。

15-1 フロントパッドを外します。(2項参照)

15-2 [210]のネジ2本を外し、ST2/2シートを外します。(図9)



(Fig. 9) Front side of the unit

[210]: Bind Head Tapping Screw-P (+バインドPタイト) 4.0X10 ZMC2BL (VC383800)

[475]: Bind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)

16 DISTRI1/2 Circuit Board

- * The DISTRI1/2 circuit board is located on the front-side of the INPUT module.

16-1 Remove the front pad. (See procedure 2)

16-2 Remove the two (2) screws marked [160A], then the DISTRI1/2 circuit board can be removed. (Fig. 3)

17 DISTRI2/2 Circuit Board

- * The DISTRI2/2 circuit board is located on the bottom-side of the INPUT module.

17-1 Open the meter panel. (See procedure 1)

17-2 Remove the front pad. (See procedure 2)

17-3 Remove the INPUT module. (See procedure 3)

17-4 Remove the two (2) screws marked [160B], then the DISTRI2/2 circuit board can be removed. (Fig. 3)

18 JK1/5 & JK2/5 Circuit Boards

18-1 Open the meter panel. (See procedure 1)

18-2 Remove the ten (10) screws marked [770A], then the JK1/5 circuit board can be removed. (Fig. 10)

The JK2/5 circuit board can be removed by removing the screw marked [770B]. (Fig. 10)

16 DISTRI1/2シート

- * DISTRI1/2シートは、INPUTモジュール前部に取り付けられています。

16-1 フロントパッドを外します。(2項参照)

16-2 [160A]のネジ2本を外し、DISTRI1/2シートを外します。(図3)

17 DISTRI2/2シート

- * DISTRI2/2シートは、INPUTモジュール下部に取り付けられています。

17-1 メーターパネルを開けます。(1項参照)

17-2 フロントパッドを外します。(2項参照)

17-3 INPUTモジュールを外します。(3項参照)


17-4 [160B]のネジ2本を外し、DISTRI2/2シートを外します。(図3)

18 JK1/5シートとJK2/5シート

18-1 メーターパネルを開けます。(1項参照)

18-2 [770A]のネジ10本を外し、JK1/5シートを外します。(図10)

[770B]のネジ1本を外し、JK2/5シートを外します。(図10)



(Fig. 10) Rear Panel

[770]: Bind Head Tapping Screw-B (+バインドBタイト) A3.0X6 ZMC2BL (VP157900)

19 BNC3/5シートとBNC4/5シートとBNC5/5シート

- * BNCシートは、ランプコネクターを取り付けているシートです。(図1)

- 19-1 メーターパネルを開けます。(1項参照)
 19-2 ハンダを取り除き、六角ナットを緩めてシートを外します。

20 MTCシート

- * MTCシートは、ST L, ST R, MONOメーターを取り付けているシートです。

- 20-1 メーターパネルを開けます。(1項参照)
 20-2 [40]のネジ2本を外し、メーターホルダーと共にMTCシートを外します。(図11)
 20-3 メーターのハンダを取り除き、[60]のネジ2本を外してMTCシートを外します。(図11)

21 MTA4シート

- * MTA4シートは、GROUP/MATRIX/AUXメーターを取り付けているシートです。

- 21-1 メーターパネルを開けます。(1項参照)
 21-2 [100]のネジ2本を外し、メーターホルダーと共にMTA4シートを外します。(図11)
 21-3 メーターのハンダを取り除き、[120]のネジ1本を外してMTA4シートを外します。(図11)

19 BNC3/5, BNC4/5 & BNC5/5 Circuit Boards

- * The BNC are circuit boards to connect the optional lamp assembly.

- 19-1 Open the meter panel. (See procedure 1)
 19-2 Remove solders and loosen the hexagonal nut, then the BNC circuit board can be removed.

20 MTC Circuit Board


- * There are ST L, ST R and MONO meters on the MTC circuit boards.

- 20-1 Open the meter panel. (See procedure 1)
 20-2 Remove the two (2) screws marked [40], then remove the MTC circuit board with a meter holder. (Fig. 11)
 20-3 Remove solders and remove the two (2) screws marked [60], then the MTC circuit board can be removed from the holder. (Fig. 11)

21 MTA4 Circuit Board

- * There are GROUP/MATRIX/AUX meters on the MTA4 circuit boards.

- 21-1 Open the meter panel. (See procedure 1)
 21-2 Remove the two (2) screws marked [100], then remove the MTA4 circuit board with a meter holder. (Fig. 11)
 21-3 Remove solders and remove the screw marked [120], then the MTA4 circuit board can be removed from the holder. (Fig. 11)



(Fig. 11) Meter Panel

- [40]: Bind Head Tapping Screw-B (＋バインドＢタイト) A4.0X8 ZMC2BL (VC688800)
 [60]: Bind Head Tapping Screw-B (＋バインドＢタイト) A3.0X6 ZMC2BL (VP157900)
 [100]: Bind Head Tapping Screw-B (＋バインドＢタイト) A4.0X8 ZMC2BL (VC688800)
 [120]: Bind Head Tapping Screw-B (＋バインドＢタイト) A3.0X6 ZMC2BL (VP157900)

22 Lithium Battery

- * If you would like to preserve the scene memory data, you should save the data to the data filer like a Yamaha MDF2.

22-1 Turn off the power.

22-2 Open the meter panel. (See procedure 1)

22-3 Remove the battery from the holder on the PS circuit board as shown in the illustration. (Fig. 12)


22 リチウム電池

- * 必要に応じ、MIDIのBULK機能を使用して、シーンメモリーのデータをヤマハMDF2のようなデータ・ファイラーに保存しておきます。

22-1 電源をOFFにします。

22-2 メーターパネルを開けます。(1項参照)

22-3 図に示すように、リチウム電池を指で挟んでバッテリーホルダーから外します。(図12)



(Fig. 12) Lithium Battery

LSI PIN DESCRIPTION (LSI 端子機能表)

HD63B03YP-N (XD245A00) CPU

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
1	Vss	I	Ground	33	Vcc	O	Power supply
2	XTAL	I	} Clock	34	A15	O	} Address bus
3	EXTAL	I		35	A14	O	
4	MP0	I	Mode program 0	36	A13	O	
5	MP1	I	Mode program 1	37	A12	O	
6	/RES	I	Initial clear	38	A11	O	
7	/STBY	I	Standby-mode signal	39	A10	O	
8	/NMI	I	Non-maskable interrupt	40	A9	O	} Ground
9	P20	I/O	} Port 2	41	A8	O	
10	P21	I/O		42	Vss	O	
11	P22	I/O		43	A7	O	} Address bus
12	P23	I/O		44	A6	O	
13	P24	I/O		45	A5	O	
14	P25	I/O		46	A4	O	
15	P26	I/O		47	A3	O	
16	P27	I/O	} Port 5	48	A2	O	} Data bus
17	P50	I/O		49	A1	O	
18	P51	I/O		50	A0	O	
19	P52	I/O		51	D7	I/O	
20	P53	I/O		52	D6	I/O	
21	P54	I/O		53	D5	I/O	
22	P55	I/O		54	D4	I/O	
23	P56	I/O	} Port 6	55	D3	I/O	
24	P57	I/O		56	D2	I/O	
25	P60	I/O		57	D1	I/O	
26	P61	I/O		58	D0	I/O	} Bus available Load instruction register Read/Write control Write control Read control Enable
27	P62	I/O		59	BA	O	
28	P63	I/O		60	/LIR	O	
29	P64	I/O		61	R/W	O	
30	P65	I/O		62	/WR	O	
31	P66	I/O		63	/RD	O	
32	P67	I/O		64	E	O	

M66008P (XM266A00) EXP. I/O


PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
1	DO	I	Not used	13	D12	O	Encode/Decode (CH4)
2	DI	I	Data	14	D11	O	Encode/Decode (CH3)
3	CLK	I	Clock	15	D10	O	Encode/Decode (CH2)
4	/CS	I	Chip select	16	D9	O	Encode/Decode (CH1)
5	Vcc	I	Power supply	17	D8	O	Monitor select (CH8)
6	/S	I	Set in	18	D7	O	Monitor select (CH7)
7	GND	I	Ground	19	D6	O	Monitor select (CH6)
8	D16	O	Encode/Decode (CH8)	20	D5	O	Monitor select (CH5)
9	D15	O	Encode/Decode (CH7)	21	D4	O	Monitor select (CH4)
10	D14	O	Encode/Decode (CH6)	22	D3	O	Monitor select (CH3)
11	D13	O	Encode/Decode (CH5)	23	D2	O	Monitor select (CH2)
12	GND	O	Ground	24	D1	O	Monitor select (CH1)

Note 1) Encode/Decode (CH1-CH8): When L=Recording signal, When H=Playback signal


Note 2) Monitor select (CH1-CH8): When L=Not return, When H=Return

IC BLOCK DIAGRAM (ICブロック図)


- SN74HC02N (IR000250)
Quad 2 Input NOR




- SN74HC04N (IR000450)
Hex Inverter




- SN74HC14N (IR001450)
Hex Inverter



- SN74HC32N (IR003250)
Quad 2 Input OR




- SN74HC74N (IR007450)
Dual D-Type Flip-Flop




INPUTS				OUTPUTS	
PR	CLR	CLK	D	Q	Q̄
L	H	X	X	H	L
H	L	X	X	L	H
L	L	X	X	H	H
H	H	↑	H	H	L
H	H	↑	L	L	H
H	H	L	X	Q _o	Q̄ _o


- HD74HC123AP (IR012310)
Dual Retriggerable Single Shot




- SN74HC138N (IR013850)
3 to 8 Demultiplexer




- SN74HC139N (IR013950)
Dual 2 to 4 Demultiplexer




- SN74HC273N (IR027350)
Octal D-Type Flip-Flop




- SN74HC368N (IR036850)
Hex 3-State Bus Inverter



- SN74HC541N (IR054150)
Octal 3-State Buffer




- TC4052BP (XA053A00)
Differential 4-Channel
Multiplexer/Demultiplexer




- NJM2068D-D (XA987A00)
- NJM072D (IG107000)
- NJM4556DD (XE803A00)
- BA4558-NK (XF128A00)
- NJM4560ED (IG040000)
- NJM4580DD (XM651A00)
- M5238AP (XM085A00)

Dual Operational Amplifier



- NJM2903 (IG031000)
Dual Single-Supply Comparator



■ INSPECTIONS

1 PREPARATIONS

Connect the M2000 and a PW2000M via the supplied DC power supply cable.

Activate the test program and execute the channel version settings. (Refer to the TEST PROGRAM section of this service manual.)

Unless specified, the signal applied should be an 1k Hz, -70 dBs sine wave and the impedance of the signal source should be 150 ohms.

The load resistance of each output terminal should be as follows:

PHONES(L, R).....	8 ohms (Greater than 5W)
INSERT OUT	10k ohms
DIRECT OUT	10k ohms
REC OUT (L, R).....	10k ohms
Other output	600 ohms

* The signal level referred to in these specifications is 0 dBs = 0.775 V.

Unless specified, set the controls and switches as follows:

1.1 MONO INPUT (1~16, 24, 32, 40)

ASSIGN switch	ON during measurement only, OFF at all other times.
PAN control	CENTER
+48V switch	OFF
ϕ (Phase) switch.....	OFF
A/B select switch.....	A
GAIN trim.....	MAX (-60 dB)
PAD(26dB) switch	OFF
HPF(80Hz) switch.....	OFF
HIGH, HI-MID, LO-MID, LOW EQ(Gain) controls.....	CENTER
HI-MID, LO-MID EQ(Freq.) controls	MIN
EQ switch	OFF
AUX 1~6 level controls.....	MAX for measuring CH only, MIN for all others.
AUX 1-2 PRE(Fader) switch.....	OFF
AUX 3-4 PRE(Fader) switch.....	OFF
DIRECT(AUX6 level control) switch.....	OFF
ON/EDIT switch	Only measuring CH ON, all others OFF.
CUE switch	Only measuring CH ON, all others OFF.
Fader	MAX

1.2 STEREO INPUT (1, 2)

ASSIGN switch	ON during measurement only.
BAL/PAN control	CENTER
L+R switch	OFF
A/B select switch.....	A
GAIN A trim	MAX (-20 dB)
GAIN B trim	MAX (-20 dB)
HIGH, MID, LOW EQ(Gain) controls	CENTER
MID EQ(Freq.)	MIN
EQ switch	OFF

AUX 1~6 level controls..... MAX for measuring CH only, MIN for all others.
 AUX 1-2 PRE(Fader) switch..... OFF
 AUX 3-4 PRE(Fader) switch..... OFF
 ON/EDIT switch Only measuring CH ON, all others OFF.
 CUE switch ON during measurement only, OFF at all other times.
 Stereo Fader..... MAX

1.3 RETURN (1~4)

ASSIGN switch ON during measurement only, OFF at all other times.
 BAL/PAN control CENTER
 AUX1, AUX2, AUX3, AUX4 switch..... ON during measurement only, OFF at all other times.
 HIGH, LOW EQ controls CENTER
 Level control MAX
 ON/EDIT switch ON during measurement only, OFF at all other times.
 CUE switch ON during measurement only, OFF at all other times.
 -4/-10dB switch (Rear Panel)..... +4dB

1.4 GROUP (1~8)

TO MONO switch ON during measurement only, OFF at all other times.
 PAN control CENTER
 TO ST switch ON during measurement only, OFF at all other times.
 ON/EDIT switch ON during measurement only, OFF at all other times.
 Fader MAX
 CUE switch ON during measurement only, OFF at all other times.

1.5 STEREO

TO MONO switch ON during measurement only, OFF at all other times.
 BAL control CENTER
 ON/EDIT switch ON during measurement only, OFF at all other times.
 L Fader MAX
 R Fader..... MAX
 CUE switch ON during measurement only, OFF at all other times.

1.6 MONO

ON/EDIT switch ON during measurement only, OFF at all other times.
 Fader MAX
 CUE switch ON during measurement only, OFF at all other times.

1.7 AUX (1~6)

Level control MAX
 CUE switch ON during measurement only, OFF at all other times.

1.8 MATRIX (1~4)

MIX level controls..... MAX during measurement only, MIN at all other times.
 OUT B level control..... MAX
 OUT B ON switch ON during measurement only, OFF at all other times.
 OUT A level control..... MAX
 OUT A ON switch MAX during measurement only, MIN at all other times.
 CUE switch..... ON during measurement only, OFF at all other times.

1.9 TALKBACK

ASSIGN switch ON during measurement only, OFF at all other times.
 AUX 1-2, AUX 3-4, AUX 5-6 switch..... ON during measurement only, OFF at all other times.
 OSCILLATOR ON switch ON during measurement only, OFF at all other times.
 TALKBACK level control..... MAX
 TALKBACK ON switch ON during measurement only, OFF at all other times.

1.10 MONITOR

2TR IN 1, 2TR IN 2 switch 2TR IN 1
 MASTER PFL switch OFF
 L+R switch OFF
 MONITOR level control..... MAX
 MONITOR OUT ON switch..... ON during measurement only, OFF at all other times.
 PHONES level control MAX

1.11 METER

METER 1~8 GROUP/MATRIX/AUX switch..... GROUP
 METER L, R STEREO HOLD switch OFF

2. GAIN**2.1. INPUT MODULE**

In status 1, the output levels should be within the range given in Tables 2.1 to 2.3.

Table 2.1 Input Terminal [INPUT CH 1 TO 16, 24, 32, 40]

Unit: dBs

Condition					Measured output				
Input terminal	Input level	Gain	26dB SW	PRE SW	GROUP, ST	MONO	AUX 1~4	AUX 5	AUX 6
☆ A	-70	MAX	OFF	OFF	+14±2.3	+14±2	+16±2	+16±2	+16±2
A	-70	MAX	OFF	ON	—	—	+6±2	—	—
A	-70	MAX	ON	OFF	-12±2.3* ¹	—	—	—	—
A	-36	MIN	OFF	OFF	+4±2.3* ¹	—	—	—	—
B	-36	MIN	OFF	OFF	+4±2.3* ¹	—	—	—	—
CH-INS	-10	MIN	OFF	OFF	+14±2.3* ¹	—	—	—	—

*1 Measuring can be performed at either one of GROUP 1 to 8, STEREO OUT (L, R).

- 1) In the condition shown by the ☆ mark, the level of DIRECT OUT should be 0 ± 2 dBs.
When the DIRECT switch is turned ON, no signal is obtained at AUX OUT 6, and the level of DIRECT OUT becomes $+6 \pm 2$ dBs.
- 2) When CUE switch of the INPUT module corresponding to each input channel in the condition shown by the ☆ mark is ON, the INPUT CUE LED of the MASTER module should light up and the levels of both the L and R outputs at MONITOR OUT should be 0 ± 2 dBs.
- 3) When the signal is applied to the B terminal, you should turn the A/B select switch to "B".
- 4) Only the ASSIGN switch that measures the output should be switched ON.
- 6) The difference in level between INPUT (CH 1 to 16, 24, 32, 40) of each output should be less than 2 dB.
- 7) The difference in level between GROUP 1 to 8, STEREO OUT (L, R), AUX OUT 1 to 6 and MONITOR OUT (L, R) should be less than 2 dB.
- 8) Check at least once that the output becomes zero when you minimize AUX level controls 1 to 6 and when turn off ASSIGN switch and ON/EDIT switch.

Table 2.2 MONO INPUT [1~16, 24, 32, 40]

Unit: dBs

Condition	Measured output					
	GROUP OUT		STEREO OUT		REC OUT	
INPUT						
PAN	1,3,5,7	2,4,6,8	L	R	L	R
LEFT	$+17 \pm 2.3$	No output	$+17 \pm 2.3$	No output	-7 ± 2.3	No output
RIGHT	No output	$+17 \pm 2.3$	No output	$+17 \pm 2.3$	No output	-7 ± 2.3

- 1) Only the ASSIGN switch that measures the output should be switched ON.
- 2) Check at least once that the output of REC OUT (L, R) is within the range given in the table 2.2 when the output is obtained at the STEREO OUT (L, R).

Table 2.3 Input Terminal MONO INPUT [1~16, 24, 32, 40]

Condition	Measured output
Input level	MONO INPUT INSERT OUT
-60	0 ± 2 [dBs]

2.2. ST CHANNEL MODULE

In status 1, the output levels should be within the range given in Tables 2.4 to 2.5.

Table 2.4 Input Terminal [STEREO INPUT 1, 2]

Unit: dBs

Condition					Measured output			
Input terminal	Input Level	Gain	PRE SW	L+R SW	GROUP, ST	MONO	AUX 1~4	AUX 5, 6
☆ A[L,R]	-30	MAX	OFF	OFF	$+14 \pm 2.3$	$+17 \pm 2$	$+19 \pm 2$	$+19 \pm 2$
	0	MIN	OFF	OFF	$+14 \pm 2.3$	—	—	—
	0	MIN	ON	OFF	—	—	$+9 \pm 2$	—
	0	MIN	ON	ON	$+17 \pm 2.3^{*1}$	—	—	—
B[L,R]	-30	MAX	OFF	OFF	$+14 \pm 2.3^{*1}$	—	—	—
	0	MIN	OFF	OFF	$+14 \pm 2.3^{*1}$	—	—	—

*1 Measuring can be performed at either one of GROUP 1 to 8 and STEREO OUT (L, R).

- 1) Apply the same signals to STEREO INPUT (L, R) inputs.
- 2) Only the ASSIGN switch that measures the output should be switched ON.

- 3) The difference in level between STEREO INPUT 1, 2 of each output should be less than 2 dB.
- 4) The difference in level between GROUP 1 to 8, STEREO OUT (L, R) and AUX OUT 1 to 6 should be less than 2 dB.
- 5) Check at least once that the output becomes zero when you minimize the AUX level control of ST CHANNEL module and when turn off the ASSIGN switch and ON/EDIT switch.
- 6) You should turn the A/B select switch to "B" when the signal is applied to the INPUT B.

Next, in the condition shown by the ☆ mark, check that the level of each output should be within the range given in the table 2.5.

Table 2.5 Input Terminal [STEREO INPUT 1, 2]

Unit: dBs

Input Terminal	Channel BAL/PAN	Measured output			
		G 1,3,5,7 L	G 2,4,6,8 R	MONITOR L	MONITOR R
A(L) ^{*1}	Left	+17±2.3	No output	0±2	No output
A(R)	Right	No output	+17±2.3	No output	0±2
B(L)	Left	+17±2.3	No output	0±2	No output
B(R)	Right	No output	+17±2.3	No output	0±2

*1 Insert a phone plug to INPUT R, which is shorted with a 150 ohm resistance.

- 1) Only the ASSIGN switch that measures the output should be switched ON.
- 2) When you try to measure the output at the MONITOR OUT (L, R), you should turn on the CUE switch of the ST CHANNEL module. At that time, check that the INPUT CUE LED of the MASTER module lights up.
- 3) The difference in level between MONITOR OUT (L, R) should be less than 2 dB.

2.3. RETURN

The output levels of Table 2.6 should be obtained in status 1.

Table 2.6 Input Terminal [RETURN 1~4]

Unit: dBs

Condition			Measured output					
Input terminal	Input level	PAD SW	G 1,3,5,7 L	G 2,4,6,8 R	MONO	AUX 1~4	MONITOR L	MONITOR R
L*1	-6	+4	+10±2.3	No output	7±2.3	3±2.3	0±2	No output
	-16	-10	+14±2.3 ^{*2}	—	—	—	—	—
R	-6	+4	No output	+10±2.3	7±2.3	3±2.3	No output	0±2
	-16	-10	—	+14±2.3 ^{*3}	—	—	—	—

*1 Connect a phone plug that shorts input at 150 ohms.

*2 Measuring can be performed at either one of GROUP 1, 3, 5, 7 or STEREO OUT L.

*3 Measuring can be performed at either one of GROUP 2, 4, 6, 8 or STEREO OUT R.

- 1) Only the ASSIGN switch that measures the output should be switched ON.
- 2) When measuring MONITOR OUT (L, R), you should turn on the CUE switch. At that time, check that the INPUT CUE LED of the MASTER module lights up.
- 3) Check at least once that the output becomes zero when you minimize RETURN level control and switch off the ASSIGN switch and ON/EDIT switch.
- 4) The difference in level between RETURN 1 to 4 of each output should be less than 2 dB.
- 5) The difference in output level between GROUP OUT 1 to 8, STEREO OUT (L, R), AUX OUT 1 to 4 should be less than 2 dB.

2.4 2 TR IN

The output levels of Table 2.7 should be obtained in status 1.

Table 2.7 INPUT 2TR IN 1, 2

Unit: dBs

Condition			Measured output			
Input terminal	Input level	L+R SW	MONITOR L	MONITOR R	PHONES L	PHONES R
2TR IN 1 L	-10	OFF	+10±2	No output	-12.5±2	No output
R	-10	OFF	No output	+10±2	No output	-12.5±2
R	-10	ON	+7±2	+7±2	—	—
2TR IN 2 L	-10	OFF	+10±2	No output	—	—
R	-10	OFF	No output	+10±2	—	—

- 1) When you apply a signal to the 2 TR INPUT 2, set the switch at 2 TR IN 2.
- 2) The difference in level between 2 TR IN 1, 2 of each output should be less than 2 dB.
- 3) Check at least once that the output becomes zero when you press the INPUT CUE switch and when press MASTER CUE switch.
- 4) Check that no signal is obtained when you minimize PHONES level control.

2.5 TALKBACK

The output levels of Table 2.8 should be obtained in status 1.

Table 2.8 TALKBACK IN

Unit: dBs

Condition		Measured output	
Input terminal	Input level	GROUP, ST, MONO	AUX1~6
TB IN	-60	10±2	6±2

- 1) Check at least once that the output level becomes zero when the TB OUT switch is turned OFF or when you minimize the TALKBACK level control.
- 2) The difference in output levels between GROUP OUT 1 to 8, STEREO OUT (L, R), AUX OUT 1 to 6 should be less than 2 dB.

2.6 MASTER INSERT IN

The output levels of Table 2.9 should be obtained in status 1.

Table 2.9 Input Terminal [MASTER INSERT IN]

Unit: dBs

Input terminal	Input level	Output level corresponding to input
GROUP INSERT IN	-10	+4±2
STEREO INSERT IN	-10	+4±2
MONO INSERT IN	-10	+4±2

- 1) The difference in output levels between GROUP OUT 1 to 8, STEREO OUT (L, R), MONITOR OUT should be less than 2 dB.

2.7 SUB IN

The output levels of Table 2.10 should be obtained in status 1.

Table 2.10 Input Terminal [SUB IN] Unit: dBs

Condition		Measured output		
Input terminal	Input level	INSERT OUT	MONITOR OUT [L,R]	
			PFL SW	
			OFF	ON
GROUP	+4	0 ± 2	$+20 \pm 2$	$+10 \pm 2$
STEREO L	+4	0 ± 2	$+20 \pm 2$	$+10 \pm 2$
STEREO R	+4	0 ± 2	$+20 \pm 2$	$+10 \pm 2$
MONO	+4	0 ± 2	$+20 \pm 2$	$+10 \pm 2$
AUX	+4	—	$+16 \pm 2$	$+10 \pm 2$
CUE L,R	+4	—	$+10 \pm 2$	—
MATRIX SUB	+4	—	$+16 \pm 2$	$+10 \pm 2$

- 1) The difference in output level between GROUP OUT 1 to 8, STEREO OUT (L, R) should be less than 2 dB.
- 2) The difference in output level between MONITOR OUT (L, R) of each SUB IN should be less than 2 dB.
- 3) When measuring MONITOR OUT (L, R), you should turn on the CUE switch. At that time, check that the MASTER CUE LED lights up.
- 4) Apply signals to the CUE SUB IN (L, R) and turn on the INPUT CUE or MASTER CUE switch, check that the output given in Table 2.10 is obtained.

Check that the output becomes zero when CUE switch remains OFF.

2.8 GROUP PAN

In status 1, switch ON each ASSIGN switch of the INPUT module installed as channel 1, then switch ON the GROUP TO ST and the GROUP TO MONO switches of the assigned GROUP master channel.

You should get the output levels of Table 2.11 at this stage.

However, only the ASSIGN switch that measures the output should be switched ON, and the input level should be -80 dBs. (Set the input level at -70 dBs if the oscillator cannot generate -80 dBs and decrease the INPUT module FADER by 10 dB.)

Table 2.11 Input Terminal [MONO INPUT ch1] Unit: dBs

Condition		Measured output		
Input level	GROUP PAN	STEREO		MONO
		L	R	
	CENTER	$+14 \pm 2.5$	$+14 \pm 2.5$	$+14 \pm 2.5$
ch 1	Left	$+17 \pm 2.5$	No output	—
-80dBs	Right	No output	$+17 \pm 2.5$	—

2.9 ST TO MONO

In status 1, switch ON only the ST of the ASSIGN switch of the INPUT module installed as channel 1, and switch ON the ST TO MONO of the STEREO master, you should check that the output levels of Table 2.12 are obtained at this stage.

The input level should be -80 dBs. (Set the input level at -70 dBs if the oscillator cannot generate -80 dBs and decrease the INPUT module FADER by 10 dB.)

Table 2.12 Input Terminal [MONO INPUT ch1] Unit: dBs

BAL control	MONO OUT
CENTER	$+17 \pm 2.5$
L	$+14 \pm 2.5$
R	$+14 \pm 2.5$

2.10 MATRIX OUT

In status 1, apply the signal to the INPUT channel 1, switch ON each ASSIGN switch of this module, and set only one of the MATRIX MIX controls of the assigned GROUP master at maximum. You should get the output levels of Table 2.13 at this stage.

The input level should be -80 dBs. (Set the input level at -70 dBs if the oscillator cannot generate -80 dBs and decrease the INPUT module FADER by 10 dB.)

Table 2.13 Input Terminal [MONO INPUT ch1] Unit: dBs

Input Terminal	Measure output			
	MATRIX		MONITOR [L,R]	
			PFL SW	
	A	B	OFF	ON
1ch A	$+10 \pm 2.3$	$+10 \pm 2.3$	$+16 \pm 2.3$	$+10 \pm 2.3$

- 1) Check at least once that the output becomes zero when the MATRIX ON switch is turned off or when MATRIX LEVEL controls A and B are minimized.
- 2) The difference between output levels of MATRIX A OUT 1 to 4, MATRIX B OUT 1 to 4 should be less than 2 dB.
- 3) The CUE SW should be switched ON when measuring MONITOR OUT (L, R).

3. FREQUENCY CHARACTERISTICS

If the applied signal frequencies are 20 Hz, 20k Hz in status 1, the output level of each output terminal should be within 0 ± 0.5 dB with 1k Hz used as reference.

4. EQ CHANGE CHARACTERISTICS

When each EQ control of INPUT module is operated in status 1, the output level of each frequency obtained in GROUP OUT 1 should fall within the range given in Table 4.1, with the output level when the GAIN control is set as a reference in the middle.

When you check the characteristics of the ST CHANNEL or RETURN module, apply signals each of L and R inputs and check that the output level of the Table 4.2 is obtained.

(You should measure the output of the GROUP OUT 2 when you apply a signal to the R input.)

Table 4.1 MONO INPUT EQ Characteristics [dBs]

Control	GAIN	f-VR	Applied frequency	Change in amplitude
LO	MAX	—	80 Hz	+12±2
	MIN			-12±2
LO MID	MAX	MIN	80 Hz	+15±2
	MIN			-15±2
	MAX	MAX	1.6 kHz	+15±2
	MIN			-15±2
HI MID	MAX	MIN	400 Hz	+15±2
	MIN			-15±2
	MAX	MAX	8 kHz	+15±2
	MIN			-15±2
HI	MAX	—	12 kHz	+12±2
	MIN			-12±2

Table 4.2 STEREO INPUT EQ Change Characteristics [dBs]

Control	GAIN	f-VR	Applied frequency	Change in amplitude
LO	MAX	—	80 Hz	+12±2
	MIN			-12±2
MID	MAX	MIN	300 Hz	+15±2
	MIN			-15±2
	MAX	MAX	6 kHz	+15±2
	MIN			-15±2
HI	MAX	—	12 kHz	+12±2
	MIN			-12±2

5. HPF CHANGE CHARACTERISTICS

In status 1, if the applied signal is 80 Hz and the HPF switch of INPUT module is turned ON, the output level of GROUP OUT 1 should be within -3 ± 2 dB, with the level when HPF is OFF as the reference.

6. SEPARATION

In status 1, if the ASSIGN switch 1-2 of the measured INPUT is switched ON and PAN control is rotated fully counterclockwise and the output level of GROUP OUT 1 is set at +20 dBs, the leakage level to GROUP OUT 2 should be less than -50 dBs. Also, if the PAN control is rotated fully clockwise and if the output level of GROUP OUT 2 is set at +20 dBs, the leakage level to GROUP OUT 1 should be less than -50 dBs.

Inspect for leakage between GROUP OUT 3-4, GROUP OUT 5-6, GROUP OUT 7-8 and STEREO OUT L-R in a similar manner.

In status 1, if the ASSIGN switch L-R of the measured INPUT is switched ON and PAN control is rotated fully counterclockwise and the output level of STEREO OUT L is set at +20 dBs, the leakage level to MONO OUT 2 should be less than -50 dBs.

Inspect for the separation of STEREO input in a similar manner with the leakage level is -30 dBs.

7. SIGNAL & PEAK LED LIGHT-UP LEVEL

When the signal in the Table 7 has been applied to the inputs of the INPUT and ST CHANNEL modules in status 1, the SIGNAL or PEAK LED should light up.

Table 7 Light-up Level		Unit: dBs
Input terminal	SIGNAL LED	PEAK LED
MONO INPUT	-70 ± 2	-43 ± 2
STEREO INPUT	-30 ± 2	-3 ± 2

8. DISTORTION FACTOR

Set each FADER and level controls to the NOMINAL POSITION of the INPUT and MASTER modules and apply signals to INPUT and ST CHANNEL module in status 1.

When a +14 dBs output is obtained at each output terminal of GROUP OUT 1 to 8, STEREO OUT (L, R), MONO OUT, AUX OUT 1 to 6, MATRIX OUT A, B 1 to 4 and MONITOR OUT (L, R), the distortion factor should be less than 0.1 %.

Also, when an output of -18.5 dBs is obtained at PHONES OUT (L/R), the distortion factor should be less than 0.1 %.

9. MAXIMUM OUTPUT

When a +24 dBs output is obtained at each output terminal of GROUP OUT 1 to 8, STEREO OUT (L, R), AUX OUT 1 to 6, MATRIX OUT A 1 to 4 in status 1, the distortion factor should be less than 1 %.

Also, the distortion factor should be less than 1 % when +20 dBs is obtained at each output terminal of DIRECT OUT, MATRIX OUT B 1 to 4 and MONITOR OUT (L, R).

Also, when -5 dBs output is obtained at PHONES OUT (L/R), the distortion factor should be less than 1 %.

10. VU METER

When the output level of GROUP OUT 1 to 8 is +4 dBs in status 1, the indication on the smaller VU meter should be 0 ± 1 VU.

When the meter selector switch is changed over to MATRIX, and when each output level of MATRIX OUT A, B 1 to 4 is +4 dBs, the smaller VU meter indication should be 0 ± 1 VU.

When the meter selector switch is changed over to AUX, and when each output level of AUX OUT 1 to 6 is +4 dBs, the indication of the smaller VU meters 1 to 6 should be 0 ± 1 VU and the indication of the smaller meters 7 and 8 should be less than -20 VU.

Check that the indication of the large VU meters is 0 ± 1 VU when the output levels of the STEREO OUT (L, R) and MONO OUT is +4 dBs.

Check that the indication of that is 0 ± 1 VU when the output of the MONITOR OUT (L, R) is +4 dBs. When the ST HOLD switch is turned ON, the output switches to STEREO OUT (L, R).

Also, check the built-in PEAK LED should light up when the output of GROUP OUT 1 to 8, STEREO OUT (L, R), MONO OUT, AUX OUT 1 to 6, MATRIX OUT A 1 to 4 is $+21 \pm 2$ dBs and the output of MATRIX OUT B 1 to 4 is $+17 \pm 2$ dBs.

11. NOISE LEVEL

When the HOT, COLD of the input of INPUT module is shorted with an 150 ohm in status 1, the noise level at GROUP OUT 1 should be less than -44 dBs.

* If the noise level is more than -44 dBs, find the noise level by input conversion. If this noise level is less than -128 dBs, then it is acceptable.

12. RESIDUAL NOISE

Set the FADER and AUX level controls of each INPUT and ST CHANNEL modules at MIN in status 1 and switch OFF the ASSIGN switch.

And then turn OFF each ON/EDIT switch of the MASTER module, check that when MASTER FADER and MASTER level control have been set at maximum or minimum, the noise level should fall within the levels shown in Table 12.

Table 12 Residual Noise Level

Unit: dBs

FADER & VR	GROUP(1~8)	STEREO L·R	MONO	AUX(1~6)	MATRIX A (1~4)	MATRIX B (1~4)	MONITOR L·R
MAX	-71	-71	-73	-73	-87	-87	-90
MIN	-97	-97	-97	-97	-99	-99	-99

13. PHASE

The signal phase applied to each input terminal and the signal phase obtained at each output terminal should be the same.

* Pin polarity of balanced type input / output terminal

PIN 1..... GND

PIN 2..... HOT (+)

PIN 3..... COLD (-)

14. OSCILLATOR

In status 1, switch ON the TALKBACK and OSCILLATOR, and turn ON only the GROUP 1-2 of the TALKBACK ASSIGN switch.

You should check that the output of $+20 \pm 2.5$ dBs, 1 ± 0.2 kHz, distortion 1 % or less is obtained at GROUP OUT 1.

15. CUE CONTROL

Check that the INPUT CUE LED would light up when the CUE CONTROL terminal is shorted to ground.

16. PHANTOM

Connect the input connector pins 1 and 2 of each INPUT module with a resistance (10k ohms, 1W or greater), and short pins 2 and 3. When the PHANTOM switch of the measuring INPUT module has been switched ON, a voltage of $+35 \pm 3$ V should be obtained at both ends of the load resistance.

17. STABILITY

17-1 Power Supply Voltage Fluctuation

Even a fluctuation of $\pm 10\%$ in the rated power supply voltage should pose no problems in the operations.

18. MEASURING EQUIPMENT

- * The output impedance of the oscillator should be less than 10 ohms.
- * The input impedance of the oscilloscope and the level meter should be more than 100k ohms.
- * Noise level should be measured using a 12.7 kHz, -6 dB/oct. low-pass filter.
- * We recommend that balanced input type measuring instruments are to be used. However, if usage of an unbalanced impedance input type measuring instrument is unavoidable, care should be taken because the maximum output level of the balance output terminal will drop.

■ PW2000M ADJUSTMENT (PW2000Mの調整)

After connecting the PW2000M and a M2000 via the supplied DC power supply cable, set the primary power voltage to the rated value.

Check that each output of the DC OUTPUT connector is as follows:

OUTPUT TERMINAL	TRIMMER POTENTIOMETER	OUTPUT VOLTAGE	RIPPLE VOLTAGE	CONDITION
Pin 6 - Pin 3(+17V)	VR201	+17 $\pm$ 0.1 V	less than 5 m Vp-p	UNIT ON 30 SECONDS
Pin 7 - Pin 3(-17V)	N/A	-17 $\pm$ 0.5 V	less than 5m Vp-p	UNIT ON 30 SECONDS
Pin 5 - Pin 2(+12V)	VR301	+12 $\pm$ 0.1 V	less than 5m Vp-p	UNIT ON 30 SECONDS
Pin 4 - Pin 1(+48V)	—	+48 $\pm$ 2 V	less than 10m Vp-p	UNIT ON 30 SECONDS

PW2000MとM2000を付属のケーブルで接続した後、PW200MのDC OUTPUT端子の各出力電圧が下表の範囲となるように調整します。

出力ピン	調整用半固定抵抗	出力電圧	リップル電圧	条件
6ピン-3ピン (+17V)	VR201	+17 $\pm$ 0.1 V	5m Vp-p以下	電源投入後 30秒以上後
7ピン-3ピン (-17V)	N/A	-17 $\pm$ 0.5 V	5m Vp-p以下	電源投入後 30秒以上後
5ピン-2ピン (+12V)	VR301	+12 $\pm$ 0.1 V	5m Vp-p以下	電源投入後 30秒以上後
4ピン-1ピン (+48V)	なし	+48 $\pm$ 2 V	10m Vp-p以下	電源投入後 30秒以上後

■ TEST PROGRAM

A. TEST PROGRAM

1. LED TEST Test number 1
2. SWITCH TEST Test number 2
3. SCANNING TEST Test number 3
4. DISTRIBUTION TEST Test number 4
5. MIDI TEST Test number 5
6. RETURN TO PLAY MODE Test number 6
7. CHANNEL VERSION SETTING TO 16 CHANNEL Test number 16
- CHANNEL VERSION SETTING TO 24 CHANNEL Test number 24
- CHANNEL VERSION SETTING TO 32 CHANNEL Test number 32
- CHANNEL VERSION SETTING TO 40 CHANNEL Test number 40
8. FACTORY SETTINGS Test number 7
9. EXIT Test number 99
10. ROM VERSION DISPLAY Test number 8

The test programs from number 1 to 6 are utilized for testing the MIDI circuit board. Others are used for testing the M2000 unit.


The battery check is automatically performed when the test program is initiated, and if an error is detected, the LED display will show "NG". The SRAM check is always performed when the power is applied to the unit on normal operation.

B. HOW TO ENTER THE TEST PROGRAM


While pressing the DIRECT RECALL switches 6, 7 and 8, turn on the POWER switch of the PW2000M connected with the testing M2000.

C. EXIT

Recall the test sequence number 99, and press the RECALL, then the system exits the test and then goes into normal operation.



When the programs from 1 to 5 have been performed without any error, initiating the test 6 will abort the test program and then the M2000 goes into normal operation.



Without performing tests from 1 to 5, and then execute the test 6, "NG" error message will appear on the LED display to indicate that you have not completely performed the test.

D. PROCEEDING THROUGH THE TESTS

Use the △ (UP) and ▽ (DOWN) switches to move through the various tests of the test program.


If you select the test number to be performed, you should press the RECALL switch to execute the test.

E. TEST RESULT

When the test is OK, "OK" will appear on the LED display, and if an error has occurred, "NG" appears.

1. LED TEST


Check that each LED blinks in succession.



- 1) The LED display will indicate "000", "111", "222" "888" in sequence.
- 2) The LEDs in the UTILITY and the CHECK switches will light up in succession.
- 3) The LEDs in the DIRECT switches 1 to 8 will light up in sequence.
- 4) All LEDs will turn to OFF.

2. SWITCH TEST

Press the switches consecutively from the UTILITY to the DIRECT RECALL 8 according to the order indicated on the LED display.



When "S1" message is shown on the LED display, press the UTILITY, then "S2" will appear, you should press the RECALL, and so on.

The switch pressing order is as follows:

UTILITY → RECALL → STORE → CHECK → UP → DOWN → DIRECT RECALL 1 to 8


If all switches are good, the LED display will indicate "OK".

If the wrong switch is pressed, and you won't be able to proceed to test the next switch.

When you would like to quit the switch test during the test, press the DIRECT RECALL 8.

3. SCANNING TEST


This test checks the circuit that is scanning to the channel distribution circuit.



The test result is indicated on the LED display.

4. DISTRIBUTION TEST


This test checks that the DISTR circuit board of the ST CHANNEL and MASTER modules works correctly.



The test result is indicated on the LED display.

5. MIDI TEST

After connecting the MIDI IN to MIDI OUT via a MIDI cable, execute the test.



The test result is indicated on the LED display.

6. CHANNEL VERSION SETTINGS

This test is utilized for setting the number of channels and checking each EDIT/ON switch of the MONO INPUT, STEREO INPUT, GROUP OUT 1 to 8, STEREO OUT, MONO OUT and RETURN 1 to 4.

For example, if the tested M2000 is 40-channels model, you should increase the number indicated on the LED display to "40" using the UP key to set, and then press the RECALL to activate the test. When the testing M2000 is 16-channels model, recall "16" to set the number of the channel.

40 → RECALL

(E.g. When checking 40-channels model)

Press the ON/EDIT switch according to the order indicated on the LED display.

The switch pressing order of a M2000-16/24/32 is as follows:

MONO INPUT → STEREO INPUT → GROUP OUT → MONO OUT → RETURN

The switch pressing order of a M2000-40 is as follows:

MONO INPUT 1 to 24 → STEREO INPUT → GROUP OUT → MONO OUT →

MONO INPUT 25 to 40 → RETURN

If you press the wrong switch, the system quits the test and goes in to the play mode.

When you want to exit the test during this program, you should press the RECALL switch.

TEST END

When the test ended without any error;

When all switches are good, the LED display will show "OK" and the test will end and all SCENE MEMORY will be set at OFF.

When an error has occurred;

If the width of the pulse is wrong when the ON/EDIT switch is pressed, "PUL" error message will appear on the LED display and the test will end.


Also, if you press the wrong switch during the test or the connection between circuit boards in the unit is wrong, "NG" will appear on the LED display and the test will end.

7. FACTORY SETTINGS

This test is used initialize the data listed below to the factory settings.

07 → RECALL → STORE

When the test is initiated, the following display will appear on the LED for a second.



Factory settings:

- ① Memory Protect..... [OFF]
- ② MEMORY INITIALIZE [ALL]
- ③ MIDI CH [C1]
- ④ MIDI Control Change..... [ON]
- ⑤ MIDI Program Change [ON]
- ⑥ Program Change Receive OMNI..... [OFF]

- ⑦ MIDI Echoback..... [OFF]
- ⑧ MIDI Bulk Dump Request..... [ALL]
- ⑨ SCENE MEMORY No.1~128..... [No Data]
- ⑩ All channel ON/EDIT [OFF]

8. ROM VERSION DISPLAY

In order to verify the ROM version of the tested M2000, you may want to initiate the version display mode. To initiate this mode, select the test number 8 and then you should press the RECALL, the version of the ROM will be displayed on the LED display. Press a panel switch to abort the test.



■ ERROR MESSAGES

• Normal error messages

Message	Description
$L\bar{o}$ Battery low	Appears briefly whenever UTILITY button is pressed. The voltage of the internal battery that retains the scene memories has dropped below 2.5V.
$P\bar{r}\bar{o}$ Memory protected	Appears after STORE button is pressed, or when a MIDI Bulk Dump is sent from another device. After 2 seconds, previous display returns. Indicates that the memory has been protected with utility 1. The store or Bulk Dump will not have any effect.
$n\bar{o}d$ No data	Appears after RECALL button is pressed. After 2 seconds, previous display returns. Indicates that there is no scene stored in the memory you tried to recall from. Also appears for 5 seconds after the power is turned on if there are no scenes stored in memory.
$E\bar{3}$	Appears after STORE button is pressed. After 2 seconds, previous display returns. Indicates that you did not select a memory with the $\blacktriangle/\blacktriangledown$ buttons into which to store the current scene.

• System error messages

When you switch on the M2000, a hardware check is performed. If any of the following errors occur, all channels will be turned on, the error numbers will be displayed as shown, and operations such as MIDI and changing scene memories will be impossible.

Message	Description
$E\bar{0}$	An internal computer error has occurred.
$E\bar{1}$	A problem has occurred in the hardware.
$E\bar{2}$	The RAM holding the scene memories has lost its data. This happens when the internal battery has become exhausted.

■ 検査

1 準備

- ・ コンソール本体と電源ユニット (PW2000M) を付属の接続ケーブルにより接続します。
- ・ テストプログラムを起動させて、チャンネルバージョンの設定を行います。(起動方法は、本サービスマニュアルのテストプログラムの項を参照。)
- ・ 指定ない場合、印可する信号は1 kHz、-70 dBs 正弦波・信号源インピーダンスは150 Ω としてINPUT Aに入力します。また、各出力端子の負荷抵抗は下記の指示に従って下さい。

PHONES [L,R]..... 8 Ω 5 W以上)

INSERT OUT..... 10 k Ω

DIRECT OUT..... 10 k Ω

REC OUT [L,R]..... 10 k Ω

その他出力..... 600 Ω

※ 本仕様書において取り扱う信号レベルは0 dBs = 0.775 Vです。

- ・ 特に指定のない場合、ツマミ類は1.1~1.11のように設定して下さい。

1.1 MONO INPUT (1~16, 24, 32, 40)

ASSIGN switch.....	測定時のみON、他はOFF
PAN control.....	CENTER
+48V switch.....	OFF
ϕ (Phase) switch.....	OFF
A/B select switch.....	A
GAIN trim.....	MAX (-60 dB)
PAD(26dB) switch.....	OFF
HPF(80Hz) switch.....	OFF
HIGH, HI-MID, LO-MID, LOW EQ(Gain) controls.....	CENTER
HI-MID, LO-MID EQ(Freq.) controls.....	MIN
EQ switch.....	OFF
AUX 1~6 level controls.....	測定CHのみMAX、他はMIN
AUX 1-2 PRE(Fader) switch.....	OFF
AUX 3-4 PRE(Fader) switch.....	OFF
DIRECT(AUX6 level control) switch.....	OFF
ON/EDIT switch.....	測定CHのみON、他はOFF
CUE switch.....	測定時のみON、他はOFF
Fader.....	MAX

1.2 STEREO INPUT (1, 2)

ASSIGN switch.....	測定時のみON
BAL/PAN control.....	CENTER
L+R switch.....	OFF
A/B select switch.....	A
GAIN A trim.....	MAX (-20 dB)
GAIN B trim.....	MAX (-20 dB)
HIGH, MID, LOW EQ(Gain) controls.....	CENTER
MID EQ(Freq.).....	MIN
EQ switch.....	OFF
AUX 1~6 level controls.....	測定CHのみMAX、他はMIN
AUX 1-2 PRE(Fader) switch.....	OFF

AUX 3-4 PRE(Fader) switch	OFF
ON/EDIT switch	測定CHのみON、他はOFF
CUE switch	測定時のみON、他はOFF
Stereo Fader	MAX

1.3 RETURN (1~4)

ASSIGN switch	測定時のみON、他はOFF
BAL/PAN control	CENTER
AUX1, AUX2, AUX3, AUX4 switch	測定時のみON、他はOFF
HIGH, LOW EQ controls	CENTER
Level control	MAX
ON/EDIT switch	測定時のみON、他はOFF
CUE switch	測定時のみON、他はOFF
+4/-10dB switch (Rear Panel)	+4dB

1.4 GROUP (1~8)

TO MONO switch	測定時のみON、他はOFF
PAN control	CENTER
TO ST switch	測定時のみON、他はOFF
ON/EDIT switch	測定時のみON、他はOFF
Fader	MAX
CUE switch	測定時のみON、他はOFF

1.5 STEREO

TO MONO switch	測定時のみON、他はOFF
BAL control	CENTER
ON/EDIT switch	測定時のみON、他はOFF
L Fader	MAX
R Fader	MAX
CUE switch	測定時のみON、他はOFF

1.6 MONO

ON/EDIT switch	測定時のみON、他はOFF
Fader	MAX
CUE switch	測定時のみON、他はOFF

1.7 AUX (1~6)

Level control	MAX
CUE switch	測定時のみON、他はOFF

1.8 MATRIX (1~4)

MIX level controls	測定時のみMAX、他はMIN
OUT B level control	MAX
OUT B ON switch	測定時のみON、他はOFF
OUT A level control	MAX
OUT A ON switch	測定時のみMAX、他はMIN

CUE switch.....測定時のみON、他はOFF

1.9 TALKBACK

ASSIGN switch.....測定時のみON、他はOFF

AUX 1-2, AUX 3-4, AUX 5-6 switch.....測定時のみON、他はOFF

OSCILLATOR ON switch.....測定時のみON、他はOFF

TALKBACK level control.....MAX

TALKBACK ON switch.....測定時のみON、他はOFF

1.10 MONITOR

2TR IN 1, 2TR IN 2 switch.....2TR IN 1

MASTER PFL switch.....OFF

L+R switch.....OFF

MONITOR level control.....MAX

MONITOR OUT ON switch.....測定時のみON、他はOFF

PHONES level control.....MAX

1.11 METER

METER 1~8 GROUP/MATRIX/AUX switch.....GROUP

METER L, R STEREO HOLD switch.....OFF

2 利得

2.1 MONO INPUT

1の状態では各出力端子には表2.1~2.3の出力レベルが得られることを確認します。

表2.1 入力端子 MONO INPUT [1~16, 24, 32, 40]

単位[dBs]

SWITCH, VOL条件					被測定出力				
入力端子	入力レベル	Gain	26dB S W	PRE SW	GROUP, ST	MONO	AUX 1~4	AUX 5	AUX 6
☆ A	-70	MAX	OFF	OFF	+14±2.3	+14±2	+16±2	+16±2	+16±2
A	-70	MAX	OFF	ON	—	—	+6±2	—	—
A	-70	MAX	ON	OFF	-12±2.3 ^{*1}	—	—	—	—
A	-36	MIN	OFF	OFF	+4±2.3 ^{*1}	—	—	—	—
B	-36	MIN	OFF	OFF	+4±2.3 ^{*1}	—	—	—	—
CH-INS	-10	MIN	OFF	OFF	+14±2.3 ^{*1}	—	—	—	—

*1 GROUP OUT 1~8、STEREO OUT [L,R]いずれか一つの出力端子で測定して下さい。

- ☆印の条件でDIRECT OUTに0±2 dBsの出力が得られること。また、DIRECT SWをONにしたときAUX 6 OUTの出力がなくなり、DIRECT OUTの出力が+6±2 dBsになることを確認します。
- ☆印の条件で各入力chに対応したCUE SWをONしたとき、MASTER部のINPUT CUE LEDが点灯しMONITOR OUT [L,R]共に0±2 dBsの出力が得られることを確認します。
- 入力がBのときは、A/B切り替えSWをBにして下さい。
- アサインSWは、必ず測定する出力のみONして下さい。
- 各出力のMONO INPUT (1~16, 24, 32, 40)間レベル差は、2 dB以内であることを確認します。
- GROUP OUT 1~8間、STEREO OUT [L,R]間、AUX OUT 1~6間、MONITOR OUT [L,R]間のレベル差が、2 dB以内であることを確認します。

- AUX level control 1~6を絞ったとき、アサインSW、ON/EDIT SWをOFFしたとき出力がなくなることを必ず一回は確認して下さい。

表2.2 MONO INPUT [1~16, 24, 32, 40]

単位[dBs]

条件	被測定出力					
INPUT	GROUP OUT		STEREO OUT		REC OUT	
PAN	1,3,5,7	2,4,6,8	L	R	L	R
左	+17±2.3	出力なし	+17±2.3	出力なし	-7±2.3	出力なし
右	出力なし	+17±2.3	出力なし	+17±2.3	出力なし	-7±2.3

- アサインSWは必ず測定する出力のみONして下さい。
- STEREO OUT [L,R]に出力が得られているとき、REC OUT [L,R]に上記の出力が得られることを必ず一回は確認して下さい。

表2.3 入力端子 MONO INPUT [1~16, 24, 32, 40]

入力条件	被測定出力
入力レベル	MONO INPUT INSERT OUT
-60	0±2 [dBs]

2.2 STEREO INPUT

1の状態では各出力に表2.4~2.5の出力が得られることを確認します。

表2.4 入力端子 STEREO INPUT 1, 2

単位[dBs]

☆	SWITCH, VOLの条件					被測定出力			
	入力 端子	入力レベル	Gain	PRE SW	L+R SW	GROUP, ST	MONO	AUX 1~4	AUX 5, 6
A[L,R]		-30	MAX	OFF	OFF	+14±2.3	+17±2	+19±2	+19±2
		0	MIN	OFF	OFF	+14±2.3	—	—	—
		0	MIN	ON	OFF	—	—	+9±2	—
		0	MIN	ON	ON	+17±2.3 ^{*1}	—	—	—
B[L,R]		-30	MAX	OFF	OFF	+14±2.3 ^{*1}	—	—	—
		0	MIN	OFF	OFF	+14±2.3 ^{*1}	—	—	—

*1 GROUP OUT 1~8、STEREO OUT [L,R]いずれかの端子にて測定して下さい。

- L, R共に同じ信号を入力して下さい。
- アサインSWは必ず測定する出力のみONして下さい。
- 各出力のSTEREO INPUT 1, 2間のレベル差が2 dB以内であることを確認します。
- GROUP OUT 1~8間、STEREO OUT [L,R]間、AUX OUT 1~6間のレベル差が2 dB以内であることを確認します。
- STEREO INPUTのAUX level controlを絞ったとき、アサインSW、ON/EDIT SWをOFFしたとき出力がなくなることを必ず一回は確認して下さい。
- Bにを入力したときはA/B切り替えSWはBにして下さい。

次に☆印の条件で表2.5の出力レベルが得られることを確認します。

表2.5 入力端子 STEREO INPUT 1, 2

単位[dBs]

入力端子	ch BAL/PAN	被測定出力			
		G 1,3,5,7 L	G 2,4,6,8 R	MONITOR L	MONITOR R
A(L) ^{*1}	左	+17±2.3	出力なし	0±2	出力なし
A(R)	右	出力なし	+17±2.3	出力なし	0±2
B(L)	左	+17±2.3	出力なし	0±2	出力なし
B(R)	右	出力なし	+17±2.3	出力なし	0±2

*1 150 Ω でショートしたフォーンプラグをR側に差し込んで下さい。

- ・アサインSWは必ず測定する出力のみONして下さい。
- ・MONITOR OUT [L,R]の出力を測定するときは、STEREO INPUTのCUE SWをONすること。このとき、MASTER部のINPUT CUE LEDが点灯することを確認します。
- ・MONITOR OUT [L,R]間レベル差が2 dB以内であることを確認します。

2.3 RETURN

1の状態では表2.6の出力が得られることを確認します。

表2.6 入力端子 RETURN 1~4

単位[dBs]

入力条件			被測定出力					
入力端子	INレベル	PAD SW	G 1,3,5,7 L	G 2,4,6,8 R	MONO	AUX 1~4	MONITOR L	MONITOR R
L*1	-6	+4	+10 $\pm$ 2.3	出力なし	7 $\pm$ 2.3	3 $\pm$ 2.3	0 $\pm$ 2	出力なし
	-16	-10	+14 $\pm$ 2.3*2	—	—	—	—	—
R	-6	+4	出力なし	+10 $\pm$ 2.3	7 $\pm$ 2.3	3 $\pm$ 2.3	出力なし	0 $\pm$ 2
	-16	-10	—	+14 $\pm$ 2.3*3	—	—	—	—

*1 150 Ω でショートしたフォーンプラグをRに差し込んで下さい。

*2 GROUP OUT 1, 3, 5, 7またはSTEREO OUT Lのいずれかの端子にて測定します。

*3 GROUP OUT 2, 4, 6, 8またはSTEREO OUT Rのいずれかの端子にて測定します。

- ・アサインSWは必ず測定する出力のみONして下さい。
- ・MONITOR OUT [L,R]の測定するときにはCUE SWをONすること。また、このときMASTER部のINPUT CUE L EDが点灯することを確認します。
- ・RETURN level controlを絞ったとき、アサインSW、ON/EDIT SWをOFFしたときに出力がなくなることを必ず一回は確認して下さい。
- ・各出力のRETURN 1~4間のレベル差が2 dB以内であることを確認します。
- ・GROUP OUT 1~8間、STEREO OUT [L,R]間、AUX OUT 1~4間の出力レベル差が2 dB以内であることを確認します。

2.4 2TR IN

表2.7の出力が得られることを確認します。

表2.7 INPUT 2TR IN 1, 2

単位[dBs]

測定条件			被測定出力			
入力端子	INレベル	L+R SW	MONITOR L	MONITOR R	PHONES L	PHONES R
2TR IN 1 L	-10	OFF	+10 $\pm$ 2	出力なし	-12.5 $\pm$ 2	出力なし
R	-10	OFF	出力なし	+10 $\pm$ 2	出力なし	-12.5 $\pm$ 2
R	-10	ON	+7 $\pm$ 2	+7 $\pm$ 2	—	—
2TR IN 2 L	-10	OFF	+10 $\pm$ 2	出力なし	—	—
R	-10	OFF	出力なし	+10 $\pm$ 2	—	—

- ・2TR IN 2に入力するときは2TR IN 2にSWを切り換えて下さい。
- ・各出力の2TR IN 1, 2の出力レベル差が2 dB以内であることを確認します。
- ・INPUT CUE SWを押したとき、MASTER CUE SWを押したときに出力が出ないことを必ず一回は確認して下さい。
- ・PHONES level controlを絞ったとき出力がなくなることを確認して下さい。

2.5 TALKBACK

1の状態では表2.8の出力が得られることを確認します。

表2.8 TALKBACK IN		単位[dBs]	
測定条件		被測定出力	
入力端子	入力レベル	GROUP, ST, MONO	AUX1~6
TB IN	-60	10±2	6±2

- TALKBACK ON SWをOFF、またはTALKBACK level controlを絞ったときに出力が出なくなることを必ず一回は確認して下さい。
- GROUP OUT 1~8間、STEREO OUT [L,R]間、AUX OUT 1~6間の出力レベル差が2dB以内であることを確認します。

2.6 MASTER INSERT IN

1の状態では表2.9の出力レベルが得られることを確認します。

表2.9 入力端子 MASTER INSERT IN		単位[dBs]
入力端子	入力レベル	入力に対応する出力レベル
GROUP INSERT IN	-10	+4±2
STEREO INSERT IN	-10	+4±2
MONO INSERT IN	-10	+4±2

- GROUP OUT 1~8間、STEREO OUT [L,R]間、MONO OUT間の出力レベル差が2 dB以内であることを確認します。

2.7 SUB IN

1の条件では表2.10の出力レベルが得られることを確認します。

表2.10 入力端子 SUB IN		単位[dBs]		
測定条件		被測定出力		
入力端子	入力レベル	INSERT OUT	MONITOR OUT [L,R]	
			PFL SW	
			OFF	ON
GROUP	+4	0±2	+20±2	+10±2
STEREO L	+4	0±2	+20±2	+10±2
STEREO R	+4	0±2	+20±2	+10±2
MONO	+4	0±2	+20±2	+10±2
AUX	+4	—	+16±2	+10±2
CUE L,R	+4	—	+10±2	—
MATRIX SUB	+4	—	+16±2	+10±2

- GROUP INSERT OUT 1~8間、STEREO INSERT OUT [L,R]間の出力レベル差が2 dB以内であることを確認します。
- 各SUB INのMONITOR OUT [L,R]間の出力レベル差が2 dB以内であることを確認します。
- MONITOR OUTの測定のときはCUE SWをONにすること。そのときMASTER CUE LEDが点灯することを確認します。
- 入力端子がCUE SUB IN[L,R]の場合で、INPUT CUEあるいはMASTER CUEがONされたとき上記の出力レベルが得られることを確認します。CUE SWを押していない状態には出力がなくなることを確認して下さい。

2.8 GROUP PAN

1の状態ではMONO INPUT ch1のアサインSWをそれぞれONにして、アサインされたMASTERのGROUP TO ST SWおよびGROUP TO MONO SWをONにします。そのとき、GROUP PAN controlをCENTER、左、右にしたとき表2.11の各出力レベルが得られることを確認します。但しアサインSWは測定する出力のみONにします。また、入力レベルは-80 dBsとします。（発振器が対応できないときは、入力レベルを-70 dBsにして、MONO INPUTのFaderを10 dB下げて下さい。）

表2.11 入力端子 MONO INPUT ch1 単位[dBs]

測定条件		被測定出力		
入力端子レベル	GROUP PAN	STEREO		MONO
		L	R	
	CENTER	+14±2.5	+14±2.5	+14±2.5
ch 1	左	+17±2.5	出力なし	—
-80dBs	右	出力なし	+17±2.5	—

2.9 ST to MONO

1の状態ではMONO INPUT ch1のSTEREO アサインSWのみをONにして、STEREO OUTのST TO MONO SWをONにして、BAL controlを回したとき表2.12の出力レベルが得られることを確認します。入力レベルは-80 dBsとして下さい。（発振器が対応できないときは、入力レベルを-70 dBsにして、MONO INPUTのFaderを10 dB下げて下さい。）

表2.12 入力端子 MONO INPUT ch1 単位[dBs]

BAL control	MONO OUT
CENTER	+17±2.5
L	+14±2.5
R	+14±2.5

2.10 MATRIX OUT

1の状態では、MONO INPUT ch1に入力を入れ、アサインSWをそれぞれONにした後アサインされた各々のMATRIX MIX level controlを一個だけMAXにします。そのとき、表2.13の出力レベルが得られることを確認します。入力レベルは-80 dBsとします。（発振器が対応できないときは、入力レベルを-70 dBsにして、MONO INPUTのFaderを10 dB下げて下さい。）

表2.13 入力端子 MONO INPUT ch1 単位[dBs]

入力端子	被測定出力			
	MATRIX		MONITOR [L,R]	
			PFL SW	
	A	B	OFF	ON
1ch A	+10±2.3	+10±2.3	+16±2.3	+10±2.3

- MATRIX ON SWをOFFした場合で、MATRIX level control A, Bを絞ったとき出力がなくなることを必ず一回は確認して下さい。
- MATRIX A OUT 1~4、MATRIX B OUT 1~4間の出力レベル差が2 dB以内であることを確認します。
- MONITOR OUT [L,R]を測定するときは、CUE SWを押して下さい。

3. 周波数特性

1の状態では、印可信号の周波数を20 Hz、20 kHzとしたとき、各出力端子の出力レベルは1 kHzを基準に $0^{+0.5}_{-2.5}$ dBの範囲にあることを確認します。

4 EQ変化特性

1の状態、MONO INPUTの各EQ controlをそれぞれ動かしたとき、GROUP OUT 1に得られる各周波数における出力レベルがGAIN controlセンター時の出力レベルを基準として、表4.1の範囲にあることを確認します。

STEREO INPUT、RETURNの場合はL、Rにそれぞれ信号を印可し、同様に表4.2のレベルが得られることを確認します。（R入力の場合、GROUP OUT 2の出力を測定して下さい。MIDはSTEREO INPUTのみ対象とします。）

表4.1 MONO INPUT EQ変化特性 [dBs]

ツマミ	GAIN	f-VR	印可周波数	変化幅
LO	MAX	—	80 Hz	+12±2
	MIN			-12±2
LO MID	MAX	MIN	80 Hz	+15±2
	MIN			-15±2
	MAX	MAX	1.6 kHz	+15±2
	MIN			-15±2
HI MID	MAX	MIN	400 Hz	+15±2
	MIN			-15±2
	MAX	MAX	8 kHz	+15±2
	MIN			-15±2
HI	MAX	—	12 kHz	+12±2
	MIN			-12±2

表4.2 STEREO INPUT EQ変化特性 [dBs]

ツマミ	GAIN	f-VR	印可周波数	変化幅
LO	MAX	—	80 Hz	+12±2
	MIN			-12±2
MID	MAX	MIN	300 Hz	+15±2
	MIN			-15±2
	MAX	MAX	6 kHz	+15±2
	MIN			-15±2
HI	MAX	—	12 kHz	+12±2
	MIN			-12±2

5 HPF変化特性

1の状態印可信号を80Hzとし、MONO INPUT chのHPF (／80) SWをONしたとき、GROUP OUT 1の出力レベルがSW OFF時のレベルを基準として-3±2 dBの範囲内にあることを確認します。

6 セパレーション

1の状態MONO INPUT chのアサインSW 1-2をONし、PAN controlを左方向に回しきります。そしてGROUP OUT 1の出力レベルを+20 dBsとしたとき、GROUP OUT 2への漏れレベルが-50 dBs以下であることを確認します。また、PAN controlを右方向に回しきり、GROUP OUT 2の出力レベルを+20dBsとしたとき、GROUP OUT 1への洩れレベルが-50 dBs以下であることを確認します。

GROUP OUT 3-4、GROUP OUT 5-6、GROUP OUT 7-8、STEREO OUT間の洩れについても同様に測定して下さい。

また、1の状態MONO INPUT chのアサインSW STをONし、PAN controlを左方向に回しきり、STEREO OUT Lの出力レベルを+20 dBsとしたとき、MONO OUTへの漏れレベルが-50 dBs以下であることを確認します。

STEREO INPUTのセパレーションは、洩れレベルを-30 dBsとして同様に測定します。

7 LED(SIGNAL、PEAK)点灯レベル

1の状態ではMONO INPUT、STEREO INPUTの入力に信号を印可したとき、表7の印可信号レベルでSIGNAL、PEAK LEDが点灯することを確認します。

表7 点灯レベル		単位[dBs]
入力端子	SIGNAL LED	PEAK LED
MONO INPUT	-70±2	-43±2
STEREO INPUT	-30±2	-3±2

8 歪率

1の状態ではINPUTおよびMASTERの各VR、FADERをNominal Positionとし、MONO INPUT、STEREO INPUTより信号を印可したときのGROUP OUT 1～8、STEREO OUT [L,R]、MONO OUT、AUX OUT 1～6、MATRIX OUT A, B 1～4、MONITOR OUT [L,R]の各出力端子に+14 dBsの出力が得られたときの歪率が0.1%以下であることを確認します。

また、PHONES OUT [L,R]に-18.5 dBsの出力が得られたときの歪率は0.1%以下であることを確認します。

9 最大出力

1の状態ではGROUP OUT 1～8、STEREO OUT [L,R]、MONO OUT、AUX OUT 1～6、MATRIX OUT A 1～4の各出力端子に+24 dBsの出力を得たときの歪率が1%以下であることを確認します。

また、DIRECT OUT、MATRIX B 1～4、MONITOR OUT [L,R]の各出力に+20 dBsを得たときの歪率が1%以下であることを確認します。

PHONES OUT [L,R]に-5 dBsの出力が得られたときの歪率は1%以下であることを確認します。

10 VUメーター

1の状態ではGROUP OUT 1～8の出力が+4 dBsのとき、small Meterの指示は0±1 VUであることを確認します。

METERセレクトSWをMATRIXに切り替え、MATRIX A, B 1～4の各出力レベルが4 dBsのとき、small Meterの指針は0±1 VUであることを確認します。

METERセレクトSWをAUXに切り替え、AUX 1～6の各出力レベルが4dBsのとき、small Meter 1～6の指針は0±1 VU、small Meter 7, 8の指針は-20 VU以下であることを確認します。

STEREO OUT [L,R]、MONO OUTの出力が+4 dBsのとき、large Meter指針は0±1 VUであることを確認します。

MONITOR OUT [L,R]の出力が+4 dBsのときLarge Meter 1, 2の指針は0±1 VUを示し、ST HOLD SWを押したときSTEREO OUT [L,R]の出力に切り替わることを確認します。

また、内蔵のPEAK LEDが点灯するのは、GROUP OUT 1～8、STEREO OUT [L,R]、MONO OUT、AUX OUT 1～6、MATRIX A OUT 1～4の各出力が+21±2 dBs、MATRIX B OUT 1～4の各出力が+17±2 dBsの範囲内のときであることを確認します。

11 ノイズレベル

1の状態ではMONO INPUTのHOT、COLD間を150 Ωで短絡したとき、GROUP OUT 1で得られるノイズレベルが-44 dBs以下であることを確認します。

* ノイズレベルが-44 dBs以上の場合は、入力換算でのノイズレベルを求め-128 dBs以下であれば可とします。

12 残留ノイズ

1の状態ですべてのMONO INPUT、STEREO INPUTのFADER、AUX level controlをMINに、アサインSWをOFFします。また、MASTERモジュール各出力のON/EDIT SWをONします。このとき、MASTER FADER、MASTER level controlを最大または最少にしたときのノイズレベルは表12のレベル以下であることを確認します。

表12 残留ノイズレベル

単位[dBs]

FADER & VR	GROUP(1~8)	STEREO L・R	MONO	AUX(1~6)	MATRIX A (1~4)	MATRIX B (1~4)	MONITOR L・R
MAX	-71	-71	-73	-73	-87	-87	-90
MIN	-97	-97	-97	-97	-99	-99	-99

13 位相

各入力端子に印可された信号と各出力端子で得られる信号は、同相であることを確認します。

- ・ バランス型入出力端子のピン配置

pin 1.....GND

pin 2.....+ (HOT)

pin 3.....- (COLD)

14 OSCILLATOR

1の状態ですべてTALKBACK SW、OSCILLATOR SWをONにし、TALKBACKアサインSWをGROUP 1-2のみONにします。このとき、GROUP OUT 1に出力レベル $+20 \pm 2.5$ dBs、周波数 1 ± 0.2 kHz、歪率1 %以下の信号が得られることを確認します。

15 CUE CONTROL

CUE CONTROL端子をGNDに接続したとき、INPUT CUE LEDが点灯することを確認します。

16 PHANTOM

各MONO INPUTの入力コネクタAのピン①-②間に負荷抵抗 $10 \text{ k}\Omega$ (1 W以上)を接続し、ピン②-③間を短絡します。

測定chのPHANTOM SWをONにしたとき、負荷抵抗両端に $+35 \pm 3$ Vの電圧が得られることを確認します。

17 安定度

17.1 電源電圧変動

電源電圧を規定の ± 10 %変化させても動作に異常のないことを確認します。

18 測定器

- ・ 発振器の出力インピーダンスは 10Ω 以下のこと。
- ・ オシロスコープ・レベル計等の入力インピーダンスは $100 \text{ k}\Omega$ 以上のこと。
- ・ ノイズレベルは12.7KHz、-6 dB/Oct. LOW PASS FILTERを用いて測定すること。
- ・ 測定器は、バランス入力型を用いることが望ましい。ただし、やむを得ずアンバランス入力型の測定器を用いる場合は、バランス入出力端子の最大出力レベルが低下するので注意して下さい。

* PW2000Mの調整については、50ページを参照して下さい。

■ テストプログラム

A. テストプログラムの内容

- | | |
|-----------------------------|--------------|
| (1) LEDの点灯チェック | シーケンスナンバー#1 |
| (2) スイッチの動作チェック | シーケンスナンバー#2 |
| (3) SCAN動作チェック | シーケンスナンバー#3 |
| (4) DISTRI動作チェック | シーケンスナンバー#4 |
| (5) MIDI I/Oチェック | シーケンスナンバー#5 |
| (6) テストプログラムから通常動作に戻る | シーケンスナンバー#6 |
| (7) チャンネルバージョンの設定 16ch..... | シーケンスナンバー#16 |
| 24ch | シーケンスナンバー#24 |
| 32ch | シーケンスナンバー#32 |
| 40ch | シーケンスナンバー#40 |
| (8) ファクトリーセット | シーケンスナンバー#7 |
| (9) テストプログラムからの脱出..... | シーケンスナンバー#99 |
| (10) ROMのバージョン表示 | シーケンスナンバー#8 |

- ・ (1)～(6)はMIDIシート単体の検査時に使用し、(7)～(8)は本体総合検査時に使用します。
- ・ テストプログラム起動時にバッテリーチェックを自動的に行います。バッテリーがない場合、または電圧が低い場合は7-SEG LEDに"NG"を表示します。
- ・ S-RAMのチェックは通常動作時のPOWER ONのときに行います。

B. テストプログラムの起動方法

DIRECT RECALL 6, 7, 8 Keyを押しながら電源をONするとテストプログラムが起動されます。

C. テストプログラムの終了

次の方法を実行すると、テストプログラムから通常動作に戻ることができます。

99	→	RECALL
----	---	--------

テスト5までのチェックが終了すると、次の方法で通常動作に戻ることができます。

06	→	RECALL
----	---	--------

チェック項目の途中で脱出した場合は、7-SEG LEDに"NG"が表示されます。

D. テストプログラム各シーケンスの選択方法

△、▽Keyにより希望のシーケンスナンバーを7-SEG LEDに表示させRECALL Keyにより確定します。

E. "OK"または"NG"の応答

7-SEG LEDには、下記のテスト結果が表示されます。

テストが"OK"のとき OK

テストが"NG"のとき NG

1. LED点灯チェック

MIDIシート内LEDが全部点灯するか否かをチェックします。

01	→	RECALL
----	---	--------

- 1) 7-SEG LEDが000、111、222、..... 888と順次点灯します。
- 2) UTILITY、CHECK Key内蔵のLEDが点灯します。
- 3) DIRECT RECALL Key内蔵のLEDが1～8の順に点灯します。
- 4) LEDが消灯します。

2. スイッチの動作チェック

KeyのON/OFFが正常に動作することを確認します。

02 → RECALL

- 1) 7-SEG LEDに"S1"が点滅表示されます。
- 2) UTILITY Keyを押すと表示が"S2"の点滅表示になります。
- 3) 以下同様に、RECALL Key、STORE Key、CHECK Key、△Key、▽Key、DIRECT RECALL Key 1～8の順に押していきます。
- 4) 全部押し終わると、処理結果を7-SEG LEDに表示します。
 - ・ 押す順番を間違えたときは、正しいKeyを押すまでは表示は変わりません。
 - ・ 途中で終了したいときは、DIRECT RECALL Key 8を押して下さい。

3. SCAN動作チェック

チャンネルディストリビュータへスキャンする部分の動作確認を行います。

03 → RECALL

起動後チェック結果が7-SEG LEDに表示されます。

4. DISTRI動作チェック

割基板、DISTRI(STEREO INPUT用、MASTER MODULE用)シートの動作チェックを行います。

04 → RECALL

起動後チェック結果が7-SEG LEDに表示されます。

5. MIDI IN/OUTチェック

MIDI IN、MIDI OUT、MIDI THRUの信号系の動作確認を行います。

05 → RECALL

起動後チェック結果が7-SEG LEDに表示されます。

6. チャンネルバージョンの設定

16ch、24ch、32ch、40chの設定を行うとともに、各MONO INPUT (1～16, 24, 32, 40)、STEREO INPUT (1, 2)、GROUP OUT 1～8、STEREO OUT [L,R]、MONO OUT、RETURN 1～4のON/EDIT SWの動作確認を行います。設定するチャンネルバージョンに応じて、16, 24, 32, 40を7-SEG LEDに表示してRECALL Keyを押します。(下記に40chバージョンの場合を示します。)

40 → RECALL

7-SEG LEDに表示される順番に従ってON/EDIT SWを押していきます。

- ・ 16ch～32chの場合
MONO INPUT、STEREO INPUT、GROUP OUT、STEREO OUT、MONO OUT、RETURN
- ・ 40chの場合
MONO INPUT 1～24、STEREO INPUT、GROUP OUT、STEREO OUT、MONO OUT、MONO INPUT 25～40、RETURN
- ・ 押す順番を間違えたときはテストプログラムは強制終了され、プレイモードとなります。
- ・ 途中で終了したいときは、RECALL Keyを押します。

・ 正常終了の場合

全部押し終わると7-SEG LEDの表示は"OK"となり、テストプログラムを終了します。終了時点では、SCENE MEMORY No.は全てOFFにセットされます。


・ 異常終了の場合

ON/EDIT SWを押したときのパルス幅が正規と異なっている場合は、7-SEG LEDに"PUL"を表示したのち強制終了します。


表示と異なるスイッチを押したり、内部配線の接続が違っている場合には、"NG"を7-SEG LEDに表示した後にテストプログラムを強制終了して、プレイモードとなります。

7. ファクトリーセット

工場出荷時のデータセットを行います。



7-SEG LEDの表示が下記のように1秒程度点灯します。




ファクトリーセットデータ

- ① Memory Protect [OFF]
- ② MEMORY INITIALIZE [ALL]
- ③ MIDI CH [C1]
- ④ MIDI Control Change [ON]
- ⑤ MIDI Program Change [ON]
- ⑥ Program Change Receive OMNI [OFF]
- ⑦ MIDI Echoback [OFF]
- ⑧ MIDI Bulk Dump Request [ALL]
- ⑨ SCENE MEMORY No.1~128 [No Data]
- ⑩ 全てのchannel ON/EDIT [OFF]

8. ROMのバージョン表示

ROMのバージョンを7-SEG LEDに表示します。



前面KEYを押すと、テストプログラムを終了します。

■ エラーメッセージ

L _o	内蔵電池の電圧が2.5 V以下になった。 (電源を入れたときとUTILITYスイッチを押しUTILITYモードになる前に表示)
P _r o	メモリーのストアやバルクダンプを受信したとき、メモリーにプロテクトがかかっている。 (2秒程度表示した後、元の表示に復帰)
n _o d	データがストアされていないメモリーをリコールした。 (2秒程度表示した後、元の表示に復帰) すべてのメモリーにデータがストアされていないとき。 (電源を入れたとき5秒程度表示)
E ₃	すべてのメモリーがストアされていない状態(MEMORYディスプレイの百の位右下のドットのみ点灯)で、シーンメモリー番号を選択せずにSTOREスイッチを押した。

本機の電源を入れたとき、CPUが関連するハードウェアに対して自動的にチェックを実行します。その結果エラーを検出すると、すべてのチャンネルがオフの状態になり、その後一切の操作とMIDIを受け付けなくなります。
システムエラーメッセージを次に示します。

E ₀	マイコン内部にエラーが発生した。
E ₁	周辺ハードウェアに問題が発生した。
E ₂	メモリーのデータが消失した。

なお、エラーメッセージ"E₂"は、前回電源を入れたときに"L_o"(バッテリー警告)がMEMORYディスプレイに表示されたにも関わらず、内蔵電池を交換しなかったとき起こります。

Function ...		Transmitted	Recognized	Remarks
Basic Default		: x	: 1 - 16, off	: memorized
Channel Changed		: x	: 1 - 16, off	:
Mode Default		: x	: OMNIoff/OMNIon	: memorized
Mode Messages		: x	: x	:
Mode Altered		: *****	: x	:
Note		: x	: x	:
Number : True voice		: *****	: x	:
Velocity Note ON		: x	: x	:
Note OFF		: x	: x	:
After Key's		: x	: x	:
Touch Ch's		: x	: x	:
Pitch Bender		: x	: x	:
1 - 70		: o	: o	: *1
Control		:	:	:
Change		:	:	:
: True #		: 0/127	:	:
Prog		: o	: o	: *2
Change : True #		: 1 - 40	:	:
System Exclusive		: o	: o	: Bulk Dump
System : Song Pos		: x	: x	:
: Song Sel		: x	: x	:
Common : Tune		: x	: x	:
System : Clock		: x	: x	:
Real Time : Commands		: x	: x	:
Aux : Local ON/OFF		: x	: x	:
: All Notes OFF		: x	: x	:
Mes- : Active Sense		: x	: x	:
sages:Reset		: x	: x	:
Notes: *1 See Control Change chart.				
: *2 Fof program 1 - 128, memory 1 - 128 is selected.				

Mode 1 : OMNI ON, POLY
 Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON, MONO
 Mode 4 : OMNI OFF, MONO

o : Yes
 x : No

MIXING CONSLE

M2000

POWER SUPPLY

PW2000M

PARTS LIST

■ CONTENTS (目次)

ELECTRICAL PARTS (電気部品) M2000	1
OVERALL ASSEMBLY (総組立) M2000	17
OVERALL ASSEMBLY (総組立) 1/5 M2000	20
OVERALL ASSEMBLY (総組立) 2/5 M2000	22
OVERALL ASSEMBLY (総組立) 3/5 M2000	24
OVERALL ASSEMBLY (総組立) 4/5 M2000	26
OVERALL ASSEMBLY (総組立) 5/5 M2000	28
INPUT MODULE (INPUTモジュール)	30
ST CHANNEL MODULE (ST CHモジュール)	33
MASTER MODULE (MASTERモジュール)	36
METER ASSEMBLY (メーターAss'y)	39
OVERALL ASSEMBLY (総組立) PW2000M	42
ELECTRICAL PARTS (電気部品) PW2000M	46

Notes) DESTINATION ABBREVIATION

J: Japanese model	A: Australian model
U: U.S.A model	E: European model
C: Canadian model	D: German model
X: General model	B: British model
M: South African model	I: Indonesian model
H: North European model	

■ WARNING

Components having special characteristics are marked Δ and must be replaced with parts having specifications equal to those originally installed.

Δ 印の部品は、安全を維持するために重要な部品です。交換をする場合は、安全のため必ず指定の部品をご使用下さい。

- The numbers with "pc." or "pcs" in "Remarks" show quantities for each unit.
- The parts with "--" in "Part No." are not available as spare parts.

- 部品価格ランクは、変更になることがあります。
- Remarks欄に記されている数字は、使用個数です。
- 部品No.が"--"の部品は、サービス用部品として準備されていません。

■ ELECTRICAL PARTS (電気部品) M2000

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ラング
		ELECTRICAL PARTS	電 気 部 品		
*	NX813720	Circuit Board	JK1/5	(VR30710)	
*	NX813730	Circuit Board	JK2/5	(VR30710)	
*	NX813740	Circuit Board	BNC3/5	(VR30720)	
*	NX813750	Circuit Board	BNC4/5	(VR30720)	
*	NX813760	Circuit Board	BNC5/5	(VR30720)	
*	NX813770	Circuit Board	DISTR11/2	(VR03170)	
*	NX813780	Circuit Board	DISTR12/2	(VR03170)	
*	VR030200	Circuit Board	IN		
*	VR031000	Circuit Board	MATRIX1		
*	VR031200	Circuit Board	MATRIX3		
*	NX813790	Circuit Board	MIDI1/4	(VR03040)	
*	NX813800	Circuit Board	MIDI2/4	(VR03040)	
*	NX813810	Circuit Board	MIDI3/4	(VR03040)	
*	NX813820	Circuit Board	MIDI4/4	(VR03040)	
*	VR031500	Circuit Board	MONO		
*	NX813830	Circuit Board	MTA4-1/4	(VR30550)	
*	NX813830	Circuit Board	MTA4-2/4	(VR30550)	
*	NX813830	Circuit Board	MTA4-3/4	(VR30550)	
*	NX813830	Circuit Board	MTA4-4/4	(VR30550)	
*	NX813870	Circuit Board	MTC1/2	(VR65770)	
*	NX813880	Circuit Board	MTC2/2	(VR65770)	
*	VR030500	Circuit Board	PS		
*	VR030600	Circuit Board	RETURN		
*	VR031400	Circuit Board	ST		
*	VR030300	Circuit Board	ST-IN		
*	NX813720	Circuit Board	JK1/5	(VR30710)	
*	NX813730	Circuit Board	JK2/5	(VR30710)	
*	NX813740	Circuit Board	BNC3/5	(VR30720)	
*	NX813750	Circuit Board	BNC4/5	(VR30720)	
*	NX813760	Circuit Board	BNC5/5	(VR30720)	
	FG612470	Ceramic Capacitor-B	470P 50V K		01
	FG651470	Ceramic Capacitor-SL	47P 50V J		
	FG644100	Ceramic Capacitor-F	0.0100 50V Z		01
	UJ837470	Electrolytic Cap.	47.00 16.0V		01
	UJ847100	Electrolytic Cap.	10.00 25.0V		01
	HF754470	Carbon Resistor	47.0 1/4 J		01
	HF755560	Carbon Resistor	560.0 1/4 J		01
	--	Carbon Resistor	3.6K 1/4 J	(HF75636)	
	HF756820	Carbon Resistor	8.2K 1/4 J		01
	--	Carbon Resistor	13.0K 1/4 J	(HF75713)	
	HF757150	Carbon Resistor	15.0K 1/4 J		01
	HF757180	Carbon Resistor	18.0K 1/4 J		01
	HF757470	Carbon Resistor	47.0K 1/4 J		01
	VB068300	Metal Film Resistor	27.0K 1/4 F		01
	VB068600	Metal Film Resistor	39.0K 1/4 F		01
	VB068900	Metal Film Resistor	51.0K 1/4 F		01
	XA987A00	IC	NJM2068D-D	OP AMP	01
	LB202600	Phone Jack	HLJ0520	GROUP1-8/SUB IN	02
	VB858100	Connector Base Post	PH- 2P SE		01
	VR633100	Header	HIF3BAG40PA2.54		
	VA078900	Jumper Wire	0.55		
	VG223500	Jack Holder	JACKアングル		02
	--	Connector Assembly	SAN&PH 4P 120L	(VP96450)	
*	NX813770	Circuit Board	DISTR11/2	(VR03170)	
*	NX813780	Circuit Board	DISTR12/2	(VR03170)	
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z		01
	--	Carbon Resistor	200.0K 1/4 J	(HF75820)	

* New Parts (新規部品)

ラング : Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
*	IR013850	IC	SN74HC138N	I C	05
	IR024100	IC	TC74HC241AP	I C	03
	VB389600	Connector Base Post	PH-11P SE	コネクタベースポスト	01
	VB389800	Connector Base Post	PH- 2P TE	コネクタベースポスト	01
*	VB994900	Connector	B09P-MQ	M Q コ ネ ク タ	01
	VR264100	Connector Base Post	PHD-20P TE	コネクタベースポスト	
	VA078900	Jumper Wire	0.55	ジャンパー線	
	--	Connector Assembly	SAN&PH 11P 60L	束線 # 2 8	(VR66560)
*	VR030200	Circuit Board	IN	I N シ ー ト	(XN288B0)
	UA353100	Mylar Capacitor	1000P 50V J	マイラコン	01
	UA353240	Mylar Capacitor	2400P 50V J	マイラコン	
	UA353620	Mylar Capacitor	6200P 50V J	マイラコン	
	UA654120	Mylar Capacitor	0.0120 50V J	マイラコン	01
	UA654300	Mylar Capacitor	0.0300 50V J	マイラコン	01
	UA654330	Mylar Capacitor	0.0330 50V J	マイラコン	01
	UA654390	Mylar Capacitor	0.0390 50V J	マイラコン	01
	UA654910	Mylar Capacitor	0.0910 50V J	マイラコン	01
	F6612220	Ceramic Capacitor-B	220P 50V K	セラコン B	01
	F6612470	Ceramic Capacitor-B	470P 50V K	セラコン B	01
	F6613100	Ceramic Capacitor-SL	1000P 50V K	セラコン B	01
	F6651220	Ceramic Capacitor-SL	22P 50V J	セラコン (S L)	01
	F6651330	Ceramic Capacitor-SL	33P 50V J	セラコン (S L)	01
	F6651470	Ceramic Capacitor-SL	47P 50V J	セラコン (S L)	
	F6651680	Ceramic Capacitor-SL	68P 50V J	セラコン (S L)	01
	F6651820	Ceramic Capacitor-SL	82P 50V J	セラコン (S L)	01
	F6652100	Ceramic Capacitor-SL	100P 50V J	セラコン (S L)	01
	F6644100	Ceramic Capacitor-F	0.0100 50V Z	セラコン F	01
	UJ828220	Electrolytic Cap.	220.00 10.0V	ケミコン	01
	UJ837470	Electrolytic Cap.	47.00 16.0V	ケミコン	01
	UJ847100	Electrolytic Cap.	10.00 25.0V	ケミコン	01
	UJ847220	Electrolytic Cap.	22.00 25.0V	ケミコン	01
	UJ848220	Electrolytic Cap.	220.00 25.0V	ケミコン	01
	UJ866100	Electrolytic Cap.	1.00 50.0V	ケミコン	01
	UJ877470	Electrolytic Cap.	47.00 63.0V	ケミコン	01
	VJ097400	Electrolytic Cap.	10.00 50.0V	ケミコン	01
	UJ819100	Electrolytic Cap.	1000 6.3V	ケミコン	01
	VN510800	Electrolytic Cap.-BP	2.20 50.0V	B P ケミコン	01
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半導体セラコン	01
	HF754100	Carbon Resistor	10.0 1/4 J	カーボン抵抗	01
	--	Carbon Resistor	22.0 1/4 J	カーボン抵抗	(HF75422)
	HF754470	Carbon Resistor	47.0 1/4 J	カーボン抵抗	01
	HF755100	Carbon Resistor	100.0 1/4 J	カーボン抵抗	01
	HF755220	Carbon Resistor	220.0 1/4 J	カーボン抵抗	01
	HF755560	Carbon Resistor	560.0 1/4 J	カーボン抵抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カーボン抵抗	01
	HF756160	Carbon Resistor	1.6K 1/4 J	カーボン抵抗	01
	--	Carbon Resistor	2.0K 1/4 J	カーボン抵抗	(HF75620)
	HF756240	Carbon Resistor	2.4K 1/4 J	カーボン抵抗	01
	--	Carbon Resistor	4.3K 1/4 J	カーボン抵抗	(HF75643)
	HF756470	Carbon Resistor	4.7K 1/4 J	カーボン抵抗	01
	--	Carbon Resistor	5.1K 1/4 J	カーボン抵抗	(HF75651)
	HF756560	Carbon Resistor	5.6K 1/4 J	カーボン抵抗	01
	HF756820	Carbon Resistor	8.2K 1/4 J	カーボン抵抗	01
	HF757100	Carbon Resistor	10.0K 1/4 J	カーボン抵抗	01
	HF757150	Carbon Resistor	15.0K 1/4 J	カーボン抵抗	01
	HF757180	Carbon Resistor	18.0K 1/4 J	カーボン抵抗	01
	HF757300	Carbon Resistor	30.0K 1/4 J	カーボン抵抗	01
	HF757330	Carbon Resistor	33.0K 1/4 J	カーボン抵抗	01
	HF757470	Carbon Resistor	47.0K 1/4 J	カーボン抵抗	01

* New Parts (新規部品)

ランク: Japan only

M2000/PW2000M

REF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	ランク
	HF758100	Carbon Resistor	100.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF758220	Carbon Resistor	220.0K 1/4 J	カ ー ボ ン 抵 抗		01
	--	Carbon Resistor	390.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75839)	
	--	Carbon Resistor	680.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75868)	
	HV755390	Flame Proof C. Resistor	390.0 1/4 J	不 燃 化 カ ー ボ ン 抵 抗		01
*	VB060800	Metal Film Resistor	20.0 1/4 F	金 属 被 膜 抵 抗		01
	VB064200	Metal Film Resistor	510.0 1/4 F	金 属 被 膜 抵 抗		01
	VA074100	Metal Film Resistor	4.7K 1/4 F	金 属 被 膜 抵 抗		01
	VB066300	Metal Film Resistor	2.2K 1/4 F	金 属 被 膜 抵 抗		01
	VB067300	Metal Film Resistor	6.8K 1/4 F	金 属 被 膜 抵 抗		01
	VB067400	Metal Film Resistor	8.2K 1/4 F	金 属 被 膜 抵 抗		01
	VB067900	Metal Film Resistor	18.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB068200	Metal Film Resistor	24.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB068800	Metal Film Resistor	47.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB069600	Metal Film Resistor	100.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB070400	Metal Film Resistor	220.0K 1/4 F	金 属 被 膜 抵 抗		01
	IG040000	IC	NJM4560ED	C	OP AMP	04
	IG107000	IC	NJM072D	C	OP AMP	04
	XA987A00	IC	NJM2068D-D	C	OP AMP	01
	IR000250	IC	SN74HC02N	C	NOR	03
	IR007450	IC	SN74HC74N	C	DFF	04
	IR012310	IC	HD74HC123AP	C	MULTI VIBRATOR	02
	IR036850	IC	SN74HC368N	C	BUS INVERTER	02
	VQ907900	Slide Switch	SSSU112-S06N-1	ス ラ イ ド S W	+48V	01
	VQ901600	Push Switch	SPUN60 2/2*6	プ ッ シ ュ S W 六 連	ASSIGN	06
	VQ901700	Push Switch	SPUN20 2/2*2	プ ッ シ ュ S W 二 連	φ A/B, 26dB/ 80	04
	VQ901900	Push Switch	SPUN19-2N-W	プ ッ シ ュ S W	PRE1-2, PRE3-4 DIRECT, EQ	03
	VQ902100	Push Switch	SPUN19-2N-W	プ ッ シ ュ S W	CUE	03
	VQ902900	Light Touch Switch	EVQ PB	ラ イ ト タ ッ チ S W	EDIT/ON	
	KC001900	Relay	DC RY12W	リ レ ー 1 2 V		07
	--	Style Pin	IMSA-6024-02E	ス タ イ ル ピ ン L = 2 5	(VR66580)	
	LB202700	Phone Jack	Stereo HLJ2305	ホ ー ン ジ ャ ッ ク	INPUT B	03
	LB606940	Phone Jack	Stereo HLJ2335	ホ ー ン ジ ャ ッ ク	INS I/O/DIRECT O	04
	VM651800	Cannon Connector	XLM-3-31PCH-L	キャ ノ ン コ ネ ク タ	INPUT A	13
	VL548500	Connector Housing	FJ-8P	F J ショ ー ト ブ ラ グ		01
	VI378700	Connector Socket	MQ-9P	MQ コ ネ ク タ ソ ケ ッ ト		01
	VK217100	Receptacle	FJ-8P	F J - リ セ プ タ ク ル		01
	VB858200	Connector Base Post	PH- 3P SE	コ ネ ク タ ベ ー ス ポ ス ト		01
	VR633100	Header	HIF3BAG40PA2.54	ヘ ッ ダ ー		
	VQ900600	Rotary Variable Resistor	5K	ロ ー タ リ ー V R	GAIN	03
	VQ900700	Rotary Variable Resistor	B50K	ロ ー タ リ ー V R	HIGH, LOW	03
	VQ900800	Rotary Variable Resistor	W20K	ロ ー タ リ ー V R	HM-GAIN, LM-GAIN	03
	VQ901000	Rotary Variable Resistor	A20K	ロ ー タ リ ー V R	AUX 1-6	03
	VQ900500	Rotary Variable Resistor	A20K+C20K	二 連 ロ ー タ リ ー V R	PAN	03
	VQ900900	Rotary Variable Resistor	C100Kx2	二 連 ロ ー タ リ ー V R	HM-f, LM-f	03
	IA093320	Transistor	2SA933S Q,R	ト ラ ン ジ ス タ		01
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ		01
	VB941200	Diode	1SS133, 1SS176	ダ イ オ ード		01
	VH325200	LED	GL2PR6 RE	L E D	PEAK	01
	VH325300	LED	GL2EG6 GR	L E D	SIGNAL, CHECK	01
	VJ471200	LED	GL2HY6 YE	L E D	ON	01
	VA078900	Jumper Wire	0.55	ジ ャ ン パ ー 線		
	VM485700	Jack Holder	x1	J A C K ア ン グ ル 単 連		05
	VR034000	Push Button	M.GY/S.GY	プ ッ シ ュ ボ タ ン	ASSGIN, φ A/B,	03
					26dB, AUX PRE, DIRECT	
	VR281300	Push Button	GR/S.GY	プ ッ シ ュ ボ タ ン	/80, EQ	
	VR281500	Push Button	RE/S.GY	プ ッ シ ュ ボ タ ン	ST	
	VR637000	Push Button	Y.BR/S.GY	プ ッ シ ュ ボ タ ン	MONO	

* New Parts (新規部品)

ランク : Japan only

ランク： Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	XA987A00	IC	NJM2068D-D	OP AMP	01
	XM651A00	IC	NJM4580DD	OP AMP	02
	IR000250	IC	SN74HC02N	NOR	03
	IR007450	IC	SN74HC74N	DFF	04
	IR012310	IC	HD74HC123AP	MULTI VIBRATOR	02
	IR036850	IC	SN74HC368N	BUS INVERTER	02
	XA053A00	IC	TC4052BP	MULTI PLEXER	03
	VA983800	Push Switch	SPUN	MRX CUE,AUX CUE	03
	VQ901900	Push Switch	SPUN19-2N-W	ON A, ON B, TO ST, TO MONO	03
	VQ902900	Light Touch Switch	EVQ PB	ON/EDIT	
	VR633200	Push Switch	SPUN19-2N-W	CUE	
	KC001900	Relay	DC RY12W		07
	---	Style Pin	IMSA-6024-02E	(VR66580)	
	LB606940	Phone Jack	Stereo HLJ2335	MTX B/GRP INS	04
	VP953100	Cannon Connector	XLM-3-32PCH-L	MATRIX A,GROUP, AUX	08
	VL549000	Connector Housing	FJ-14P		02
	VQ966000	Receptacle	FJ-14P		02
	VR984700	Short Connector	9206H-T 2P	短 絡 コ ネ ク タ	
	VB858100	Connector Base Post	PH- 2P SE	コネクタベースポスト	01
	VB858200	Connector Base Post	PH- 3P SE	コネクタベースポスト	01
	VB858800	Connector Base Post	PH- 9P SE	コネクタベースポスト	01
	VR633100	Header	HIF3BAG40PA2.54	ヘ ッ ダ ー	
	VR702100	Pin Header	9202 2P-4 TE	ピン ヘ ッ ダ ー	SW104-SW107
	VQ901000	Rotary Variable Resistor	A20K	ロータリー V R	SUB L,R, ST L,R MONO,GROUP1-8, LEVEL A,B AUX LEVEL
					03
	VQ900500	Rotary Variable Resistor	A20K+C20K	二連ロータリー V R	PAN
					03
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ	01
	VB941200	Diode	1SS133,1SS176	ダ イ オ ード	01
	VH325300	LED	GL2EG6 GR	L E D	CHECK
	VJ471200	LED	GL2HY6 YE	L E D	ON A,ON B,ON
	VA078900	Jumper Wire	0.55	ジャンパー 線	01
	VG223500	Jack Holder		J A C K ア ン グ ル	02
	VR281500	Push Button	RE/S.GY	プッシュボタン	TO ST
	VR637000	Push Button	Y.BR/S.GY	プッシュボタン	TO MONO
	VR637100	Push Button	S.GY/Y.BR	プッシュボタン	CUE
	VR667400	Knob	S.GY/RE	プッシュツマミ	ONA, ON B
	---	Connector Assembly	SUM GND	線 材 A s s y	(VR30140)
	VR031200	Circuit Board	MATRIX3	M A T R I X 3 シ ー ト	(XN293B0)
	UA654330	Mylar Capacitor	0.0330 50V J	マイラーコン	01
	FG612220	Ceramic Capacitor-B	220P 50V K	セラコン B	01
	FG612470	Ceramic Capacitor-B	470P 50V K	セラコン B	01
	FG651330	Ceramic Capacitor-SL	33P 50V J	セラコン (S L)	01
	FG651470	Ceramic Capacitor-SL	47P 50V J	セラコン (S L)	
	FG651680	Ceramic Capacitor-SL	68P 50V J	セラコン (S L)	01
	FG651820	Ceramic Capacitor-SL	82P 50V J	セラコン (S L)	01
	FG652100	Ceramic Capacitor-SL	100P 50V J	セラコン (S L)	01
	FG652150	Ceramic Capacitor-SL	150P 50V J	セラコン (S L)	01
	FG644100	Ceramic Capacitor-F	0.0100 50V Z	セラコン F	01
	UJ828100	Electrolytic Cap.	100.00 10.0V	ケ ミ コ ン	01
	UJ828220	Electrolytic Cap.	220.00 10.0V	ケ ミ コ ン	01
	UJ837470	Electrolytic Cap.	47.00 16.0V	ケ ミ コ ン	01
	UJ847100	Electrolytic Cap.	10.00 25.0V	ケ ミ コ ン	01
	UJ847220	Electrolytic Cap.	22.00 25.0V	ケ ミ コ ン	01
	UJ847470	Electrolytic Cap.	47.00 25.0V	ケ ミ コ ン	01
	UJ848100	Electrolytic Cap.	100.00 25.0V	ケ ミ コ ン	01

* New Parts (新規部品)

ランク : Japan only

REF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	ランク
	UJ848220	Electrolytic Cap.	220.00 25.0V	ケ ミ コ ン		01
	UJ866100	Electrolytic Cap.	1.00 50.0V	ケ ミ コ ン		01
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半 導 体 セ ラ コ ン		01
	HF754100	Carbon Resistor	10.0 1/4 J	カ ー ボ ン 抵 抗		01
	HF754470	Carbon Resistor	47.0 1/4 J	カ ー ボ ン 抵 抗		01
	---	Carbon Resistor	62.0 1/4 J	カ ー ボ ン 抵 抗	(HF75462)	
	HF754750	Carbon Resistor	75.0 1/4 J	カ ー ボ ン 抵 抗		01
	HF755100	Carbon Resistor	100.0 1/4 J	カ ー ボ ン 抵 抗		01
	HF755220	Carbon Resistor	220.0 1/4 J	カ ー ボ ン 抵 抗		01
	HF755560	Carbon Resistor	560.0 1/4 J	カ ー ボ ン 抵 抗		01
	HF756100	Carbon Resistor	1.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF756220	Carbon Resistor	2.2K 1/4 J	カ ー ボ ン 抵 抗		01
	---	Carbon Resistor	3.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75630)	
	HF756470	Carbon Resistor	4.7K 1/4 J	カ ー ボ ン 抵 抗		01
	HF756560	Carbon Resistor	5.6K 1/4 J	カ ー ボ ン 抵 抗		01
	---	Carbon Resistor	7.5K 1/4 J	カ ー ボ ン 抵 抗	(HF75675)	
	HF756820	Carbon Resistor	8.2K 1/4 J	カ ー ボ ン 抵 抗		01
	HF757100	Carbon Resistor	10.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF757120	Carbon Resistor	12.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF757150	Carbon Resistor	15.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF757180	Carbon Resistor	18.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF757200	Carbon Resistor	20.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF757300	Carbon Resistor	30.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF758100	Carbon Resistor	100.0K 1/4 J	カ ー ボ ン 抵 抗		01
	HF758220	Carbon Resistor	220.0K 1/4 J	カ ー ボ ン 抵 抗		01
	---	Carbon Resistor	680.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75868)	
	HV754100	Flame Proof C. Resistor	10.0 1/4 J	不 燃 化 カ ー ボ ン 抵 抗		01
	VA074400	Metal Film Resistor	10.0K 1/4 F	金 属 被 膜 抵 抗		01
	VA074500	Metal Film Resistor	11.0K 1/4 F	金 属 被 膜 抵 抗		01
	VA074600	Metal Film Resistor	15.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB067000	Metal Film Resistor	4.3K 1/4 F	金 属 被 膜 抵 抗		01
	VB067800	Metal Film Resistor	16.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB067900	Metal Film Resistor	18.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB068000	Metal Film Resistor	20.0K 1/4 F	金 属 被 膜 抵 抗		01
	VB068200	Metal Film Resistor	24.0K 1/4 F	金 属 被 膜 抵 抗		01
	XA987A00	IC	NJM2068D-D	I C	OP AMP	01
	XM651A00	IC	NJM4580DD	I C	OP AMP	02
	IR000250	IC	SN74HC02N	I C	NOR	03
	IR007450	IC	SN74HC74N	I C	DFF	04
	IR012310	IC	HD74HC123AP	I C	MULTI VIBRATOR	02
	IR036850	IC	SN74HC368N	I C	BUS INVERTER	02
	XA053A00	IC	TC4052BP	I C	MULTIPLEXER	03
	VA983800	Push Switch	SPUN	ブ ッ シ ュ S W	MRX CUE, ON A,B	03
	VQ901900	Push Switch	SPUN19-2N-W	ブ ッ シ ュ S W	TO ST, TO MONO	03
	VQ902900	Light Touch Switch	EVQ PB	ラ イ ト タ ッ チ S W	ON/EDIT	
	VR633200	Push Switch	SPUN19-2N-W	ブ ッ シ ュ S W	CUE	
	KC001900	Relay	DC RY12W	リ レ ー 1 2 V		07
	---	Style Pin	IMSA-6024-02E	ス タ イ ル ピ ン L = 2 5	(VR66580)	
	LB606940	Phone Jack	Stereo HLJ2335	ホ ー ン ジ ャ ッ ク	MTX B/GRP INS	04
	VP953100	Cannon Connector	XLM-3-32PCH-L	キ ャ ノ ン コ ネ ク タ	MATRIX A, GROUP, AUX	08
	VL549000	Connector Housing	FJ-14P	F J シ ョ ー ト プ ラ グ		02
	VQ966000	Receptacle	FJ-14P	F J - リ セ プ タ ク ル		02
	VR984700	Short Pin	9206H-T 2P	短 絡 コ ネ ク タ		
	VB858100	Connector Base Post	PH- 2P SE	コ ネ ク タ ベ ー ス ポ ス ト		01
	VB858200	Connector Base Post	PH- 3P SE	コ ネ ク タ ベ ー ス ポ ス ト		01
	VB858800	Connector Base Post	PH- 9P SE	コ ネ ク タ ベ ー ス ポ ス ト		01
	VR633100	Header	HIF3BAG40PA2.54	ヘ ッ ダ ー		
	VR702100	Pin Header	9202 2P-4 TE	ピ ン ヘ ッ ダ ー	SW104-SW107	
	VQ901000	Rotary Variable Resistor	A20K	ロ ー タ リ ー V R	SUB L,R, ST L,R	03

* New Parts (新規部品)

ランク : Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
*	VQ900500	Rotary Variable Resistor	A20K+C20K	ニ連ロータリーV R	MONO, GROUP1-8,
	IC174070	Transistor	2SC1740S R,S	トランジスタ	LEVEL A,B
	VB941200	Diode	1SS133,1SS176	ダイオード	PAN
	VH325300	LED	GL2EG6 GR	L E D	CHECK
	VJ471200	LED	GL2HY6 YE	L E D	ON A, ON B, ON
	VA078900	Jumper Wire	0.55	ジャンパー線	
*	VG223500	Jack Holder		J A C K アングル	
	VR281500	Push Button	RE/S.GY	プッシュボタン	TO ST
	VR637000	Push Button	Y.BR/S.GY	プッシュボタン	TO MONO
*	VR637100	Push Button	S.GY/Y.BR	プッシュボタン	CUE
	VR667400	Knob	S.GY/RE	プッシュツマミ	ON A, ON B
	--	Connector Assembly	SUM GND	線材 A s s y	(VR30140)
*	NX813790	Circuit Board	MIDI1/4	M I D I 1 / 4 シート	(VR03040)
	NX813800	Circuit Board	MIDI2/4	M I D I 2 / 4 シート	(VR03040)
	NX813810	Circuit Board	MIDI3/4	M I D I 3 / 4 シート	(VR03040)
*	NX813820	Circuit Board	MIDI4/4	M I D I 4 / 4 シート	(VR03040)
	UA654100	Mylar Capacitor	0.0100 50V J	マイラーコン	
	--	Ceramic Capacitor	27P 50V J	セラコン C H	(VK66320)
	UJ857100	Electrolytic Cap.	10.00 35.0V	ケミコン	
	UJ829100	Electrolytic Cap.	1000 10.0V	ケミコン	
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半導体セラコン	
	VQ252700	Carbon Resistor	0.0 J	カーボン抵抗	
	--	Carbon Resistor	30.0 1/4 J	カーボン抵抗	(HF75430)
	HF756100	Carbon Resistor	1.0K 1/4 J	カーボン抵抗	
	HF756270	Carbon Resistor	2.7K 1/4 J	カーボン抵抗	
	HF756330	Carbon Resistor	3.3K 1/4 J	カーボン抵抗	
	HF757100	Carbon Resistor	10.0K 1/4 J	カーボン抵抗	
	--	Carbon Resistor	51.0K 1/4 J	カーボン抵抗	(HF75751)
	--	Carbon Resistor	200.0K 1/4 J	カーボン抵抗	(HF75820)
	HF759100	Carbon Resistor	1.0M 1/4 J	カーボン抵抗	
	--	Carbon Resistor	4.7M 1/4 J	カーボン抵抗	(HF75947)
	VB065000	Metal Film Resistor	910.0 1/4 F	金属被膜抵抗	
	VB065900	Metal Film Resistor	1.5K 1/4 F	金属被膜抵抗	
	VB066400	Metal Film Resistor	2.4K 1/4 F	金属被膜抵抗	
	VE443500	Resistor Array	RGLD4X103J	抵抗アレイ	
	VE445200	Resistor Array	RGLD8X103J	抵抗アレイ	
	XM085A00	IC	M5238AP	I C	OP AMP
	XH970A00	IC	M62021L	I C	RESET
	IG031000	IC	NJM2903	I C	COMPARATOR
	IR000250	IC	SN74HC02N	I C	NOR
	IR000450	IC	SN74HC04N	I C	INVERTER
	IR001450	IC	SN74HC14N	I C	INVERTER
	IR003250	IC	SN74HC32N	I C	OR
	IR013850	IC	SN74HC138N	I C	DECODER
	IR013950	IC	SN74HC139N	I C	DECODER
	IR024100	IC	TC74HC241AP	I C	BUS BUFFER
	IR027350	IC	SN74HC273N	I C	DFF
	IR036850	IC	SN74HC368N	I C	BUS INVERTER
	IR054150	IC	SN74HC541N	I C	BUS DRIVER
	XD245A00	IC	HD63B03YP-N	I C	CPU
	XM266A00	IC	M66008P	I C	16BIT, EXP
	XK761A00	IC	HY6264ALP-10	I C	SRAM 64K
*	XP180A00	IC	M27C256B-12F1	I C	ROM 256K
	VK700800	Push Switch	SKHQAC	プッシュ S W	RECALL, STORE,
	--	--	--	--	SCENE MEM ▲, ▼
	VK701000	Push Switch	SKHQFM ORANGE	プッシュ S W	UTILITY
	VK701100	Push Switch	SKHQFN GREEN	プッシュ S W	CHECK

* New Parts (新規部品)

ランク: Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
*	VR266500	Push Switch	SPUJ 2/2*8	ブッシュ S W 八 連	
	VB389800	Connector Base Post	PH- 2P TE	コネクタベースポスト	01
	VB390000	Connector Base Post	PH- 4P TE	コネクタベースポスト	01
	VB390100	Connector Base Post	PH- 5P TE	コネクタベースポスト	01
	VB390500	Connector Base Post	PH- 9P TE	コネクタベースポスト	03
*	VB390600	Connector Base Post	PH-10P TE	コネクタベースポスト	01
	VR262300	Connector Base Post	PHD-18P SE	コネクタベースポスト	
	VR264100	Connector Base Post	PHD-20P TE	コネクタベースポスト	
	VR264200	Connector Base Post	PHD-20P SE	コネクタベースポスト	
	VL184700	IC Socket	DICF-28CS-E	I C ソ ケ ッ ト	02
	FZ006970	LC Filter	LS MT Y223NB	L C フィルター E M I	02
	QU008500	Ceramic Resonator	8M CSA8.00MTZ	セラミック振動子	03
	IC174070	Transistor	2SC1740S R,S	トランジスタ	01
	IG138700	Transistor Array	TD62506P	トランジスタアレイ	03
	VB941200	Diode	1SS133,1SS176	ダイオード	01
*	VP155700	LED	GL5HY40 YE	L E D	DIRECT RECALL
	VR266400	LED Display	LB-203VL	L E D ディスプレイ	MEMORY
	VD473200	Photo Coupler	6N137	フォトカプラ	05
	VN560100	LED Holder		L E D ホルダー 5 マル	03
	VR309400	LED Spacer	8SEG	L E D スペース	
	--	Connector Assembly	SAN&PH 11P 250L	束 線 # 2 4	(VR66920)
	--	Connector Assembly	SAN&PH 9P 60L	束 線 # 2 8	(VN37520)
*					
	VR031500	Circuit Board	MONO	M O N O シ ー ト	(XN295B0)
	UA355100	Mylar Capacitor	0.1000 50V J	マイラーコン	01
	UA654330	Mylar Capacitor	0.0330 50V J	マイラーコン	01
	F6612220	Ceramic Capacitor-B	220P 50V K	セラコン B	01
	F6612470	Ceramic Capacitor-B	470P 50V K	セラコン B	01
	F6613100	Ceramic Capacitor-B	1000P 50V K	セラコン B	01
	F6651330	Ceramic Capacitor-SL	33P 50V J	セラコン (S L)	01
	F6651470	Ceramic Capacitor-SL	47P 50V J	セラコン (S L)	
	F6651680	Ceramic Capacitor-SL	68P 50V J	セラコン (S L)	01
	F6652100	Ceramic Capacitor-SL	100P 50V J	セラコン (S L)	01
	F6644100	Ceramic Capacitor-F	0.0100 50V Z	セラコン F	01
	UJ828220	Electrolytic Cap.	220.00 10.0V	ケ ミ コ ン	01
	UJ837470	Electrolytic Cap.	47.00 16.0V	ケ ミ コ ン	01
	UJ847100	Electrolytic Cap.	10.00 25.0V	ケ ミ コ ン	01
	UJ847220	Electrolytic Cap.	22.00 25.0V	ケ ミ コ ン	01
	UJ847470	Electrolytic Cap.	47.00 25.0V	ケ ミ コ ン	01
	UJ848220	Electrolytic Cap.	220.00 25.0V	ケ ミ コ ン	01
	UJ866100	Electrolytic Cap.	1.00 50.0V	ケ ミ コ ン	01
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半 導 体 セ ラ コ ン	01
	HF754100	Carbon Resistor	10.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF754470	Carbon Resistor	47.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF754750	Carbon Resistor	75.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755100	Carbon Resistor	100.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755220	Carbon Resistor	220.0 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	270.0 1/4 J	カ ー ボ ン 抵 抗	(HF75527)
	HF755560	Carbon Resistor	560.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756160	Carbon Resistor	1.6K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756220	Carbon Resistor	2.2K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756240	Carbon Resistor	2.4K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756390	Carbon Resistor	3.9K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	4.3K 1/4 J	カ ー ボ ン 抵 抗	(HF75643)
	HF756470	Carbon Resistor	4.7K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756560	Carbon Resistor	5.6K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757100	Carbon Resistor	10.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757150	Carbon Resistor	15.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757160	Carbon Resistor	16.0K 1/4 J	カ ー ボ ン 抵 抗	01

* New Parts (新規部品)

ランク: Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	HF757180	Carbon Resistor	18.0K 1/4 J	(HF75724)	01
	HF757220	Carbon Resistor	22.0K 1/4 J		01
	--	Carbon Resistor	24.0K 1/4 J		
	HF757470	Carbon Resistor	47.0K 1/4 J		01
	HF758100	Carbon Resistor	100.0K 1/4 J		01
	HF758220	Carbon Resistor	220.0K 1/4 J	(HF75868)	01
	--	Carbon Resistor	680.0K 1/4 J		
	HV754100	Flame Proof C. Resistor	10.0 1/4 J		01
	VA074400	Metal Film Resistor	10.0K 1/4 F		01
	VA074500	Metal Film Resistor	11.0K 1/4 F		01
	VA074600	Metal Film Resistor	15.0K 1/4 F		01
	VB067000	Metal Film Resistor	4.3K 1/4 F		01
	VB067900	Metal Film Resistor	18.0K 1/4 F		01
	VB068000	Metal Film Resistor	20.0K 1/4 F		01
	VC731200	Metal Oxide Film Resistor	100.0 1W J		01
	XA987A00	IC	NJM2068D-D	OP AMP	01
	XE803A00	IC	NJM4556DD	OP AMP	03
	XM651A00	IC	NJM4580DD	OP AMP	02
	IR000250	IC	SN74HC02N	NOR	03
	IR007450	IC	SN74HC74N	DFF	04
	IR012310	IC	HD74HC123AP	MULTI VIBRATOR	02
	IR036850	IC	SN74HC368N	BUS INVERTER	02
	VA983800	Push Switch	SPUN	PFL, MONI ON	03
	VQ901900	Push Switch	SPUN19-2N-W	ST HOLD, CUE	03
	VQ902400	Push Switch	SPUN30 *3	GRP/MTRX/AUX	05
	VQ902500	Push Switch	SPUN20 2/2*2	2TR IN1/IN2	04
	VQ902900	Light Touch Switch	EVQ PB	ON/EDIT	
	VR633200	Push Switch	SPUN19-2N-W	L+R	
	KC001900	Relay	DC RY12W		07
	VL369700	Relay	DC RY5W-K		05
	--	Style Pin	IMSA-6024-02E	(VR66580)	
	VR312000	Pin Connector	YKC21-3088 4P	2TR IN L/R	
	LB202300	Phone Jack	HLJ1520	PHONES	02
	LB202600	Phone Jack	HLJ0520	MONITOR OUT L,R	02
	LB202700	Phone Jack	Stereo HLJ2305	MONO I/O	03
	VP953100	Cannon Connector	XLMM-3-32PCH-L	MONO OUT	08
	VL548500	Connector Housing	FJ-8P		01
	VK217100	Receptacle	FJ-8P		01
	VB858200	Connector Base Post	PH- 3P SE		01
	VB858800	Connector Base Post	PH- 9P SE		01
	VR633100	Header	HIF3BAG40PA2.54		
	FZ004070	LC Filter	LS MT X222MB		03
	VQ901400	Rotary Variable Resistor	A20Kx2	PHONES, MONI LVL	03
	IA077730	Transistor	2SA777 Q,R		02
	IA093320	Transistor	2SA933S Q,R		01
	IC174070	Transistor	2SC1740S R,S		01
	VB941200	Diode	1SS133,1SS176		01
	VH325300	LED	GL2EG6 GR	MASTER CUE,CHEC	01
	VJ471200	LED	GL2HY6 YE	MONITOR ON, INPUT CUE, CUE	01
	VA078900	Jumper Wire	0.55		
	VG223500	Jack Holder			02
	VM485700	Jack Holder	x1		05
	VR313300	Pin Jack Holder			
	VR034000	Push Button	M.GY/S.GY	GROUP, MATRIX,	03
				AUX, ST HOLD, 2TR IN 1,2, PLF, L+R	
	VR637100	Push Button	S.GY/Y.BR	CUE	
	VR667400	Knob	S.GY/RE	MONITOR ON	

* New Parts (新規部品)

ランク: Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	--	Connector Assembly	SUM GND	線 材 A s s y (VR30140)	
	NX813830	Circuit Board	MTA4-1/4	MTA 4 - 1 / 4 シート (VR30550)	
	NX813830	Circuit Board	MTA4-2/4	MTA 4 - 2 / 4 シート (VR30550)	
	NX813830	Circuit Board	MTA4-3/4	MTA 4 - 3 / 4 シート (VR30550)	
	NX813830	Circuit Board	MTA4-4/4	MTA 4 - 4 / 4 シート (VR30550)	
	FG644100	Ceramic Capacitor-F	0.0100 50V Z	セ ラ コ ン F	01
	U1537220	Electrolytic Cap.	22.00 16.0V	ケ ミ コ ン	01
	U1538100	Electrolytic Cap.	100.00 16.0V	ケ ミ コ ン	01
	U1547470	Electrolytic Cap.	47.00 25.0V	ケ ミ コ ン	01
	U1566100	Electrolytic Cap.	1.00 50.0V	ケ ミ コ ン	01
	HF755100	Carbon Resistor	100.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755220	Carbon Resistor	220.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755330	Carbon Resistor	330.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756470	Carbon Resistor	4.7K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756680	Carbon Resistor	6.8K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757100	Carbon Resistor	10.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757110	Carbon Resistor	11.0K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	13.0K 1/4 J	カ ー ボ ン 抵 抗 (HF75713)	
	--	Carbon Resistor	39.0K 1/4 J	カ ー ボ ン 抵 抗 (HF75739)	
	HF757560	Carbon Resistor	56.0K 1/4 J	カ ー ボ ン 抵 抗	01
	VB066200	Metal Film Resistor	2.0K 1/4 F	金 属 被 膜 抵 抗	01
	XF128A00	IC	BA4558-NK	イ ン テ ー ジ C	02
	VM672900	Lamp	8V 100mA	ラ ン プ	02
	VB858300	Connector Base Post	PH- 4P SE	コネクタベースポスト	01
	VB858400	Connector Base Post	PH- 5P SE	コネクタベースポスト	01
	VB858700	Connector Base Post	PH- 8P SE	コネクタベースポスト	01
	IA093320	Transistor	2SA933S Q,R	ト ラ ン ジ ス タ	01
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ	01
	VB941200	Diode	1SS133,1SS176	ダ イ オ ード	01
	VH325200	LED	GL2PR6 RE	Ｌ Ｅ Ｄ	01
	VA775300	LED Spacer	BL	Ｌ Ｅ Ｄ ス ペ ー サ ー	01
	VA078900	Jumper Wire	0.55	ジャンパー線	
	--	Connector Assembly	SAN&PH 5P 120L	束 線 # 2 8 (VM66630)	
	NX813870	Circuit Board	MTC1/2	M T C 1 / 2 シート (VR65770)	
	NX813880	Circuit Board	MTC2/2	M T C 2 / 2 シート (VR65770)	
	FG644100	Ceramic Capacitor-F	0.0100 50V Z	セ ラ コ ン F	01
	U1537220	Electrolytic Cap.	22.00 16.0V	ケ ミ コ ン	01
	U1538100	Electrolytic Cap.	100.00 16.0V	ケ ミ コ ン	01
	U1547470	Electrolytic Cap.	47.00 25.0V	ケ ミ コ ン	01
	U1566100	Electrolytic Cap.	1.00 50.0V	ケ ミ コ ン	01
	HF755100	Carbon Resistor	100.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755220	Carbon Resistor	220.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755330	Carbon Resistor	330.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756470	Carbon Resistor	4.7K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756680	Carbon Resistor	6.8K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757100	Carbon Resistor	10.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757110	Carbon Resistor	11.0K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	13.0K 1/4 J	カ ー ボ ン 抵 抗 (HF75713)	
	HF757150	Carbon Resistor	15.0K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	39.0K 1/4 J	カ ー ボ ン 抵 抗 (HF75739)	
	HF757560	Carbon Resistor	56.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF758100	Carbon Resistor	100.0K 1/4 J	カ ー ボ ン 抵 抗	01
	VB066200	Metal Film Resistor	2.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB066400	Metal Film Resistor	2.4K 1/4 F	金 属 被 膜 抵 抗	01
	XF128A00	IC	BA4558-NK	イ ン テ ー ジ C	02
	VM672900	Lamp	8V 100mA	ラ ン プ	02

* New Parts (新規部品)

ランク： Japan only

M2000/PW2000M

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	VB858200	Connector Base Post	PH- 3P SE	コネクタベースポスト	01
	VB858300	Connector Base Post	PH- 4P SE	コネクタベースポスト	01
	VB858400	Connector Base Post	PH- 5P SE	コネクタベースポスト	01
	VB858500	Connector Base Post	PH- 6P SE	コネクタベースポスト	01
	IA093320	Transistor	2SA933S Q,R	ト ラ ン ジ ス タ	01
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ	01
	VB941200	Diode	1SS133,1SS176	ダ イ オード	01
	VH325200	LED	GL2PR6 RE	L E D	01
	VA277900	LED Spacer		L E D スペーサー	01
	VA775300	LED Spacer	BL	L E D スペーサー	01
	VA078900	Jumper Wire	0.55	ジャンパー線	
	---	Connector Assembly	SAN&PH 5P 120L	束線 # 2 8	(VM66630)
	VR030500	Circuit Board	PS	P S シート	(XN291A0)
	UA355100	Mylar Capacitor	0.1000 50V J	マイラーコン	01
	FG612270	Ceramic Capacitor	270P 50V K	セラコン B	01
	UJ828220	Electrolytic Cap.	220.00 10.0V	ケ ミ コ ン	01
	UJ838220	Electrolytic Cap.	220.00 16.0V	ケ ミ コ ン	01
	UJ878100	Electrolytic Cap.	100.00 63.0V	ケ ミ コ ン	01
	VR641000	Electrolytic Cap.	1000.0 25.0	ケ ミ コ ン	01
	VF277000	Electrolytic Cap.	1000 16.0V	ケ ミ コ ン	01
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半 導 体 セラコン	01
	HF755220	Carbon Resistor	220.0 1/4 J	カーボン抵抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カーボン抵抗	01
	HF756330	Carbon Resistor	3.3K 1/4 J	カーボン抵抗	01
	HF756560	Carbon Resistor	5.6K 1/4 J	カーボン抵抗	01
	HF757470	Carbon Resistor	47.0K 1/4 J	カーボン抵抗	01
	VC758300	Metal Oxide Film Resistor	68.0 2W J	酸化金属被膜抵抗	01
	XJ141A00	IC	NJM78M09FA	I C	REGULATOR +9V
	XJ607A00	IC	NJM7805FA	I C	REGULATOR +5V
	VI466400	Connector	DINX3 YKF51-504	複 合 コ ネ ク タ	MIDI IN/OUT/THR
	LB933080	Base Post Connector	VH-8P SE	ベースポスト	01
	VB390700	Connector Base Post	PH-11P TE	コネクタベースポスト	01
	VB858100	Connector Base Post	PH- 2P SE	コネクタベースポスト	01
	VR633100	Header	HIF3BAG40PA2.54	ヘ ッ ダー	
	VN103600	Battery Holder		バッテリーホルダー	03
	FZ006970	LC Filter	LS MT Y223NB	L C フィルター E M I	02
	FZ006920	LC Filter	LS MT B271KB	L C フィルター E M I	01
	IA093320	Transistor	2SA933S Q,R	ト ラ ン ジ ス タ	01
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ	01
	VQ547400	Pair Transistor	A1837/C4793	ペアトランジスター	04
	VB941200	Diode	1SS133,1SS176	ダ イ オード	01
	VA078900	Jumper Wire	0.55	ジャンパー線	
	VI474400	Terminal Plate		ターミナル金具	01
	---	Connector Assembly	METER PS	線 材 A s s y	(VR30580)
	---	Connector Assembly	SAN&PH 6P 250L	束線 # 2 4	(VM76060)
	VR030600	Circuit Board	RETURN	R E T U R N シート	(XN292B0)
	UA353100	Mylar Capacitor	1000P 50V J	マイラーコン	01
	UA654330	Mylar Capacitor	0.0330 50V J	マイラーコン	01
	UA654390	Mylar Capacitor	0.0390 50V J	マイラーコン	01
	FG612220	Ceramic Capacitor-B	220P 50V K	セラコン B	01
	FG612470	Ceramic Capacitor-B	470P 50V K	セラコン B	01
	FG651330	Ceramic Capacitor-SL	33P 50V J	セラコン (S L)	01
	FG651470	Ceramic Capacitor-SL	47P 50V J	セラコン (S L)	01
	FG651680	Ceramic Capacitor-SL	68P 50V J	セラコン (S L)	01
	FG651820	Ceramic Capacitor-SL	82P 50V J	セラコン (S L)	01
	FG652100	Ceramic Capacitor-SL	100P 50V J	セラコン (S L)	01
	FG644100	Ceramic Capacitor-F	0.0100 50V Z	セラコン F	01
	UJ828220	Electrolytic Cap.	220.00 10.0V	ケ ミ コ ン	01

* New Parts (新規部品)

ランク: Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	UJ837470	Electrolytic Cap.	47.00 16.0V	ケ ミ コ ン	01
	UJ847100	Electrolytic Cap.	10.00 25.0V	ケ ミ コ ン	01
	UJ847220	Electrolytic Cap.	22.00 25.0V	ケ ミ コ ン	01
	UJ848100	Electrolytic Cap.	100.00 25.0V	ケ ミ コ ン	01
	UJ848220	Electrolytic Cap.	220.00 25.0V	ケ ミ コ ン	01
	UJ866100	Electrolytic Cap.	1.00 50.0V	ケ ミ コ ン	01
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半 導 体 セ ラ コ ン	01
	HF754100	Carbon Resistor	10.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF754470	Carbon Resistor	47.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF754750	Carbon Resistor	75.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755100	Carbon Resistor	100.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755220	Carbon Resistor	220.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755560	Carbon Resistor	560.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756220	Carbon Resistor	2.2K 1/4 J	カ ー ボ ン 抵 抗	01
	—	Carbon Resistor	3.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75630)
	HF756470	Carbon Resistor	4.7K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756560	Carbon Resistor	5.6K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756820	Carbon Resistor	8.2K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757100	Carbon Resistor	10.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757180	Carbon Resistor	18.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757330	Carbon Resistor	33.0K 1/4 J	カ ー ボ ン 抵 抗	01
	—	Carbon Resistor	43.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75743)
	HF758100	Carbon Resistor	100.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF758220	Carbon Resistor	220.0K 1/4 J	カ ー ボ ン 抵 抗	01
	—	Carbon Resistor	680.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75868)
	HV754100	Flame Proof C. Resistor	10.0 1/4 J	不 燃 化 カ ー ボ ン 抵 抗	01
	VA074400	Metal Film Resistor	10.0K 1/4 F	金 属 被 膜 抵 抗	01
	VA074500	Metal Film Resistor	11.0K 1/4 F	金 属 被 膜 抵 抗	01
	VA074600	Metal Film Resistor	15.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB067000	Metal Film Resistor	4.3K 1/4 F	金 属 被 膜 抵 抗	01
	VB067800	Metal Film Resistor	16.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB067900	Metal Film Resistor	18.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068000	Metal Film Resistor	20.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068200	Metal Film Resistor	24.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068500	Metal Film Resistor	36.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068900	Metal Film Resistor	51.0K 1/4 F	金 属 被 膜 抵 抗	01
	XA987A00	IC	NJM2068D-D	I C	OP AMP
	XM651A00	IC	NJM4580DD	I C	OP AMP
	IR000250	IC	SN74HC02N	I C	NOR
	IR007450	IC	SN74HC74N	I C	DFF
	IR012310	IC	HD74HC123AP	I C	MULTI VIBRATOR
	IR036850	IC	SN74HC368N	I C	BUS INVERTER
	XA053A00	IC	TC4052BP	I C	MULTIPLEXER
	VQ545800	Slide Switch	SSSF04	ス ラ イ ド S W	-10dB/+4dB
	VA983800	Push Switch	SPUN	ブ ッ シ ュ S W	AUX CUE, RTN CUE
	VQ901600	Push Switch	SPUN60 2/2*6	ブ ッ シ ュ S W 六 連	ASSIGN
	VQ901900	Push Switch	SPUN19-2N-W	ブ ッ シ ュ S W	TO ST, TO MONO
	VQ902200	Push Switch	SPUN40 2/2*4	ブ ッ シ ュ S W 四 連	AUX1-4
	VQ902900	Light Touch Switch	EVQ PB	ラ イ ト タ ッ チ S W	ON/EDIT
	VR633200	Push Switch	SPUN19-2N-W	ブ ッ シ ュ S W	CUE
	KC001900	Relay	DC RY12W	リ レ ー 1 2 V	
	—	Style Pin	IMSA-6024-02E	ス タ イ ル ピ ン L=2 5	(VR66580)
	LB202600	Phone Jack	HLJ0520	ホ ー ン ジャ ッ ク	RTN L, RTN R
	LB202700	Phone Jack	Stereo HLJ2305	ホ ー ン ジャ ッ ク	GRP INS I/O
	VP953100	Cannon Connector	XLM-3-32PCH-L	キ ャ ノ ン コ ネ ク タ	GROUP, AUX
	VL549000	Connector Housing	FJ-14P	F J シ ョ ー ト プ ラ グ	
	VQ966000	Receptacle	FJ-14P	F J ー リ セ プ タ ク ル	
	VR984700	Short Connector	9206H-T 2P	短 絡 コ ネ ク タ	
	VB858100	Connector Base Post	PH- 2P SE	コ ネ ク タ ベ ー ス ポ ス ト	

* New Parts (新規部品)

ランク : Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	VB858200	Connector Base Post	PH- 3P SE	コネクタベースポスト	01
	VB858300	Connector Base Post	PH- 4P SE	コネクタベースポスト	01
	VB858800	Connector Base Post	PH- 9P SE	コネクタベースポスト	01
*	VR633100	Header	HIF3BAG40PA2.54	ヘ ッ ダ ー	
*	VR702400	Pin Header	9202 2P-8 TE	ピ ン ヘ ッ ダ ー	SW704-SW707
*	VQ901000	Rotary Variable Resistor	A20K	ロ ー タ リ ー V R	AUX LEVEL
*	VQ900500	Rotary Variable Resistor	A20K+C20K	ニ 連 ロ ー タ リ ー V R	RTN BAL/PAN,PAN
*	VQ901200	Rotary Variable Resistor	B50Kx2	ニ 連 ロ ー タ リ ー V R	LOW,HIGH
*	VQ901400	Rotary Variable Resistor	A20Kx2	ニ 連 ロ ー タ リ ー V R	RTN LEVEL
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ	01
	VB941200	Diode	1SS133,1SS176	ダ イ オ ー ド	01
	VH325300	LED	GL2EG6 GR	L E D	RTN CHECK,CHECK
	VJ471200	LED	GL2HY6 YE	L E D	RTN ON, ON
	VA078900	Jumper Wire	0.55	ジャンパー線	
	VG223500	Jack Holder		J A C K ア ン グ ル	02
	VM485700	Jack Holder	x1	J A C K ア ン グ ル 単 連	05
*	VR034000	Push Button	M.GY/S.GY	プ ッ シ ュ ボ タ ン	03
*	VR281400	Push Button	BE/S.GY	プ ッ シ ュ ボ タ ン	ASSIGN
*	VR281500	Push Button	RE/S.GY	プ ッ シ ュ ボ タ ン	AUX1-4
*	VR637000	Push Button	Y.BR/S.GY	プ ッ シ ュ ボ タ ン	ST, TO ST
*	VR637100	Push Button	S.GY/Y.BR	プ ッ シ ュ ボ タ ン	MONO, TO MONO
	--	Connector Assembly	DIST RETURN	線 材 A s s y	CUE
	--	Connector Assembly	SUM GND	線 材 A s s y	(VR27790)
					(VR30140)
	VR031400	Circuit Board	ST	S T シ ー ト	(XN294B0)
	UA353100	Mylar Capacitor	1000P 50V J	マ イ ラ ー コ ン	01
	UA353270	Mylar Capacitor	2700P 50V J	マ イ ラ ー コ ン	
	UA353620	Mylar Capacitor	6200P 50V J	マ イ ラ ー コ ン	
	UA353750	Mylar Capacitor	7500P 50V J	マ イ ラ ー コ ン	
	UA654180	Mylar Capacitor	0.0180 50V J	マ イ ラ ー コ ン	01
	UA654330	Mylar Capacitor	0.0330 50V J	マ イ ラ ー コ ン	01
	UA654470	Mylar Capacitor	0.0470 50V J	マ イ ラ ー コ ン	01
	FG612220	Ceramic Capacitor-B	220P 50V K	セ ラ コ ン B	01
	FG612330	Ceramic Capacitor-B	330P 50V K	セ ラ コ ン B	01
	FG612470	Ceramic Capacitor-B	470P 50V K	セ ラ コ ン B	01
	FG613150	Ceramic Capacitor-B	1500P 50V K	セ ラ コ ン B	01
	FG651330	Ceramic Capacitor-SL	33P 50V J	セ ラ コ ン (S L)	01
	FG651470	Ceramic Capacitor-SL	47P 50V J	セ ラ コ ン (S L)	
	FG651680	Ceramic Capacitor-SL	68P 50V J	セ ラ コ ン (S L)	01
	FG651820	Ceramic Capacitor-SL	82P 50V J	セ ラ コ ン (S L)	01
	FG652100	Ceramic Capacitor-SL	100P 50V J	セ ラ コ ン (S L)	01
	FG644100	Ceramic Capacitor-F	0.0100 50V Z	セ ラ コ ン F	01
	UJ828100	Electrolytic Cap.	100.00 10.0V	ケ ミ コ ン	01
	UJ828220	Electrolytic Cap.	220.00 10.0V	ケ ミ コ ン	01
	UJ837470	Electrolytic Cap.	47.00 16.0V	ケ ミ コ ン	01
	UJ847100	Electrolytic Cap.	10.00 25.0V	ケ ミ コ ン	01
	UJ847220	Electrolytic Cap.	22.00 25.0V	ケ ミ コ ン	01
	UJ848100	Electrolytic Cap.	100.00 25.0V	ケ ミ コ ン	01
	UJ848220	Electrolytic Cap.	220.00 25.0V	ケ ミ コ ン	01
	UJ866100	Electrolytic Cap.	1.00 50.0V	ケ ミ コ ン	01
	VC694800	Semiconductive Cera. Cap.	0.1000 25V Z	半 導 体 セ ラ コ ン	01
	HF754100	Carbon Resistor	10.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF754470	Carbon Resistor	47.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF754750	Carbon Resistor	75.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755100	Carbon Resistor	100.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755150	Carbon Resistor	150.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF755220	Carbon Resistor	220.0 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	270.0 1/4 J	カ ー ボ ン 抵 抗	(HF75527)
	HF755560	Carbon Resistor	560.0 1/4 J	カ ー ボ ン 抵 抗	01
	HF756100	Carbon Resistor	1.0K 1/4 J	カ ー ボ ン 抵 抗	01

* New Parts (新規部品)

ランク: Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	HF756160	Carbon Resistor	1.6K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756180	Carbon Resistor	1.8K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	2.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75620)
	HF756220	Carbon Resistor	2.2K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756240	Carbon Resistor	2.4K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756330	Carbon Resistor	3.3K 1/4 J	カ ー ボ ン 抵 抗	01
	HF756470	Carbon Resistor	4.7K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757100	Carbon Resistor	10.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757150	Carbon Resistor	15.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757180	Carbon Resistor	18.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF757220	Carbon Resistor	22.0K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	24.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75724)
	HF757470	Carbon Resistor	47.0K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	51.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75751)
	HF758100	Carbon Resistor	100.0K 1/4 J	カ ー ボ ン 抵 抗	01
	HF758220	Carbon Resistor	220.0K 1/4 J	カ ー ボ ン 抵 抗	01
	--	Carbon Resistor	680.0K 1/4 J	カ ー ボ ン 抵 抗	(HF75868)
	HF759220	Carbon Resistor	2.2M 1/4 J	カ ー ボ ン 抵 抗	01
	HV754100	Flame Proof C. Resistor	10.0 1/4 J	不 燃 化 カ ー ボ ン 抵 抗	01
	VA074400	Metal Film Resistor	10.0K 1/4 F	金 属 被 膜 抵 抗	01
	VA074500	Metal Film Resistor	11.0K 1/4 F	金 属 被 膜 抵 抗	01
	VA074600	Metal Film Resistor	15.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB067000	Metal Film Resistor	4.3K 1/4 F	金 属 被 膜 抵 抗	01
	VB067800	Metal Film Resistor	16.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB067900	Metal Film Resistor	18.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068000	Metal Film Resistor	20.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068200	Metal Film Resistor	24.0K 1/4 F	金 属 被 膜 抵 抗	01
	VB068500	Metal Film Resistor	36.0K 1/4 F	金 属 被 膜 抵 抗	01
	XA987A00	IC	NJM2068D-D	I C	OP AMP
	XF128A00	IC	BA4558-NK	I C	OP AMP
	XM651A00	IC	NJM4580DD	I C	OP AMP
	IR000250	IC	SN74HC02N	I C	NOR
	IR007450	IC	SN74HC74N	I C	DFF
	IR012310	IC	HD74HC123AP	I C	MULTI VIBRATOR
	IR036850	IC	SN74HC368N	I C	BUS INVERTER
	VA983800	Push Switch	SPUN	ブ ッ シ ュ S W	CUE
	VQ901900	Push Switch	SPUN19-2N-W	ブ ッ シ ュ S W	OSC ON(1kHz)
					TB ON, TO MONO
	VQ902300	Push Switch	SPUN90 2/2*9	ブ ッ シ ュ S W 九 連	ASSIGN switch
	VQ902900	Light Touch Switch	EVQ PB	ラ イ ト タ ッ チ S W	ON/EDIT
	KC001900	Relay	DC RY12W	リ レ ー 1 2 V	07
	VL369700	Relay	DC RY5W-K	リ レ ー 5 V	05
	--	Style Pin	IMSA-6024-02E	ス タ イ ル ピ ン L=2 5	(VR66580)
	VM725600	Pin Connector	YKC21-3045	ピ ン ジャ ッ ク 2 P	REC OUT L/R
	LB606940	Phone Jack	Stereo HLJ2335	ホ ー ン ジャ ッ ク	ST INSERT I/O
	VM651800	Cannon Connector	XLM-3-31PCH-L	キャ ノ ン コ ネ ク タ	TB INPUT
	VP953100	Cannon Connector	XLM-3-32PCH-L	キャ ノ ン コ ネ ク タ	ST L, ST R
	VB858200	Connector Base Post	PH- 3P SE	コ ネ ク タ ベ ー ス ポ ス ト	01
	VB858700	Connector Base Post	PH- 8P SE	コ ネ ク タ ベ ー ス ポ ス ト	01
	VB858800	Connector Base Post	PH- 9P SE	コ ネ ク タ ベ ー ス ポ ス ト	01
	VR633100	Header	HIF3BAG40PA2.54	ヘ ッ ダ ー	
	VQ901000	Rotary Variable Resistor	A20K	ロ ー タ リ ー V R	TB LEVEL
	VQ900500	Rotary Variable Resistor	A20K+C20K	二 連 ロ ー タ リ ー V R	BAL
	IA093320	Transistor	2SA933S Q,R	ト ラ ン ジ ス タ	01
	IC174070	Transistor	2SC1740S R,S	ト ラ ン ジ ス タ	01
	VB941200	Diode	1SS133,1SS176	ダ イ オ ー ド	01
	VH325300	LED	GL2EG6 GR	L E D	01
	VJ471200	LED	GL2HY6 YE	L E D	01
	VA078900	Jumper Wire	0.55	ジャン パ ー 線	
	V6223500	Jack Holder		J A C K ア ン グ ル	02

* New Parts (新規部品)

ランク : Japan only

M2000/PW2000M

* New Parts (新規部品)

15

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	IR007450	IC	SN74HC74N	I C DFF	04
	IR012310	IC	HD74HC123AP	I C MULTI VIBRATOR	02
	IR036850	IC	SN74HC368N	I C BUS INVERTER	02
*	VQ901600	Push Switch	SPUN60 2/2*6	プッシュ S W 六 連 ASSIGN	06
*	VQ901900	Push Switch	SPUN19-2N-W	プッシュ S W EQ,PRE 1-2,3-4	03
*	VQ902000	Push Switch	SPUN20 2/2*2	プッシュ S W 二 連 L+R, A/B	04
*	VQ902900	Light Touch Switch	EVQ PB	ライトタッチ S W ON/EDIT	
*	VR633200	Push Switch	SPUN19-2N-W	プッシュ S W CUE	
	KC001900	Relay	DC RY12W	リレー 1 2 V	07
	--	Style Pin	IMSA-6024-02E	スタイルピン L=25 (VR66580)	
	VM725600	Pin Jack	YKC21-3045	ピンジャック 2 P	02
	LB202600	Phone Jack	HLJ0520	ホーンジャック	02
*	VL548700	Connector Housing	FJ-10P	FJショートプラグ	01
	VK217300	Receptacle	FJ-10P	FJ-リーセプタクル	01
	VB858500	Connector Base Post	PH-6P SE	コネクタベースポスト	01
	VB858800	Connector Base Post	PH-9P SE	コネクタベースポスト	01
	VR633100	Header	HIF3BAG40PA2.54	ヘッダー	
*	VQ901000	Rotary Variable Resistor	A20K	ロータリー V R AUX1-6	03
*	VQ900500	Rotary Variable Resistor	A20K+C20K	二連ロータリー V R BAL/PAN	03
*	VQ901100	Rotary Variable Resistor	C10Kx2	二連ロータリー V R GAIN A,B	03
*	VQ901200	Rotary Variable Resistor	B50Kx2	二連ロータリー V R LOW,HIGH	03
*	VQ901300	Rotary Variable Resistor	W20Kx2	二連ロータリー V R MID-GAIN	03
*	VQ901500	Rotary Variable Resistor	C100Kx4	四連ロータリー V R MID-f	06
	IA093320	Transistor	2SA933S Q,R	トランジスタ	01
	IC150930	Transistor	2SC1509 O,R	トランジスタ	01
	IC174070	Transistor	2SC1740S R,S	トランジスタ	01
	VB941200	Diode	1SS133,1SS176	ダイオード	01
	VH325200	LED	GL2PR6 RE	L E D PEAK	01
	VH325300	LED	GL2EG6 GR	L E D SIGNAL, CHECK	01
	VJ471200	LED	GL2HY6 YE	L E D ON	01
	VA078900	Jumper Wire	0.55	ジャンパー線	
	V6223500	Jack Holder		JACK アングル	02
*	VR034000	Push Button	M.GY/S.GY	プッシュボタン	03
	VR281300	Push Button	GR/S.GY	プッシュボタン	
*	VR281500	Push Button	RE/S.GY	プッシュボタン	
*	VR637000	Push Button	Y.BR/S.GY	プッシュボタン	
*	VR637100	Push Button	S.GY/Y.BR	プッシュボタン	
	--	Connector Assembly	SUM GND	線材 A s s y (VR30140)	
*	VR301300	CONNECTOR ASSEMBLY	PS	線材 A s s y	
	LB101710	Connector Assembly	SVH-21T-P1.1	圧着端子	01
	LB015080	Connector Pin	VH-8P	ハウジング	01
	LB605750	Connector Housing	SRCN PLUG 10P	丸型コネクタ	08
	--	Earth Plate		アース金具	(VR03890)
*	VR301500	Connector Assembly	MONO FADER1	線材 A s s y	
	VB936800	Connector Contact	SPH-002T-P0.5S	コンタクト	01
	VB304400	Connector Housing	PH-3P	コネクタハウジング	01
	--	Slide Variable Resistor	10.0K RSA0K11A	スライド V R 100mm	(VR28070)
*	VR301700	Connector Assembly	ST FADER	線材 A s s y	
	VB936800	Connector Contact	SPH-002T-P0.5S	コンタクト	01
	VB304700	Connector Housing	PH-6P	コネクタハウジング	01
	--	Slide Variable Resistor	D10KX2 RSA0K12A	二連スライド V R	(VR28110)

* New Parts (新規部品)

ランク : Japan only

OVERALL ASSEMBLY (総組立) M2000

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	---	OVERALL ASSEMBLY	総 組 立	16/24/32/40CH	
A	---	Connector Assembly	線 材 A s s y	2/2/3/3(VR27580)	
B	VR276300	Connector Assembly	線 材 A s s y	1pc.	
C	VR276400	Connector Assembly	線 材 A s s y	16CH	
D	VR276500	Connector Assembly	線 材 A s s y	24CH	
E	VR276600	Connector Assembly	線 材 A s s y	32CH	
F	VR276700	Connector Assembly	線 材 A s s y	40CH	
G	---	Connector Assembly	線 材 A s s y	1pc. (VR27680)	
H	VR277300	Connector Assembly	線 材 A s s y		
I	VR277500	Connector Assembly	線 材 A s s y	40CH	
10	VR035600	Main Chassis	メインシャーシ 16CH	16CH	
10	VR035700	Main Chassis	メインシャーシ 24CH	24CH	
10	VR035800	Main Chassis	メインシャーシ 32CH	32CH	
10	VR035900	Main Chassis	メインシャーシ 40CH	40CH	
20	CB806590	Foot	ア ン プ レ ッ グ	4/4/6/6pcs	01
30	VD831800	Bind Head Tapping Screw-B	A4.0X12 ZMC2BL	1pc.	01
40	VR169700	Side Chassis	L		
50	VR037500	Side Pad	L small		08
60	VR095400	Side Plate	L small		
70	VC383800	Bind Head Tapping Screw-P	4.0X10 ZMC2BL	2pcs	01
80	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	2pcs	01
90	VR037900	Side Pad	C		
100	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	6pcs	01
110	VR037300	Side Pad	L large		09
120	VR037700	Side Plate	L large		
130	VC383800	Bind Head Tapping Screw-P	4.0X10 ZMC2BL	4pcs	01
140	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	3pcs	01
150	VR604100	Connector Guard			
160	VD831800	Bind Head Tapping Screw-B	A4.0X12 ZMC2BL	1pc.	01
170	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	4pcs	01
180	VR169800	Side Chassis	R		
190	VR037600	Side Pad	R small		
200	VR095500	Side Plate	R small		
210	VC383800	Bind Head Tapping Screw-P	4.0X10 ZMC2BL	2pcs	01
220	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	2	01
230	VR037900	Side Pad	C		
240	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	6pcs	01
250	VR037400	Side Pad	R large		09
260	VR037800	Side Plate	R large		
270	VC383800	Bind Head Tapping Screw-P	4.0X10 ZMC2BL	4pcs	01
280	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	3pcs	01
290	VR604100	Connector Guard			
300	VD831800	Bind Head Tapping Screw-B	A4.0X12 ZMC2BL	1pc.	01
310	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	4pcs	01
320	VR036000	Frame	L		
330	VR302300	Support, PCB	KGLS-5RF	5pcs	
340	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	5pcs	01
350	VR036100	Frame	R		
360	VR604100	Connector Guard			
370	VD831800	Bind Head Tapping Screw-B	A4.0X12 ZMC2BL	40CH 1pc.	01
380	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	40CH 4pcs	01
390	VR036200	Cushion	S	40CH 6pcs	
400	VR036300	Cushion	L	7/9/11/13pcs	
410	VR036400	Rear Panel	16CH	16CH	
410	VR036500	Rear Panel	24CH	24CH	
410	VR036600	Rear Panel	32CH	32CH	
410	VR036700	Rear Panel	40CH	40CH	
420	VR604100	Connector Guard			
430	VD831800	Bind Head Tapping Screw-B	A4.0X12 ZMC2BL	2/2/2/3pcs	01
440	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	3/3/3/4pcs	01

* New Parts (新規部品)

ランク : Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
* 450	VR036800	Window	8SEG	ウィンドウ 8 S E G	09
460	VN053800	TB Escutcheon		T B エスカッション	07
* 470a	NX813790	Circuit Board	MIDI1/4	M I D I 1 / 4 シート (VR03040)	
* 470b	NX813800	Circuit Board	MIDI2/4	M I D I 2 / 4 シート (VR03040)	
* 470c	NX813810	Circuit Board	MIDI3/4	M I D I 3 / 4 シート (VR03040)	
* 470d	NX813820	Circuit Board	MIDI4/4	M I D I 4 / 4 シート (VR03040)	
475	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	4pcs
* 480	VR036900	Sheet Holder	8SEG	シートホルダー 8 S E G	01
500	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	4pcs
510	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿 小 ネ ジ	2pcs
* 520	VR984900	Push Button Assembly	<1> UTILITY	プッシュボタン大Assy	
* 530	VR985000	Push Button Assembly	<1> RECALL	プッシュボタン大Assy	
* 540	VR985100	Push Button Assembly	<1> STORE	プッシュボタン大Assy	
* 550	VR985200	Push Button Assembly	<1> CHECK	プッシュボタン大Assy	
* 560	VR985300	Push Button Assembly	<1> TRIANGL	プッシュボタン大Assy	2pcs
570	VN680200	Push Button Assembly	L	プッシュボタン (L)	8pcs
580	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	3pcs
* 590	VR037000	Heat Sink		ヒートシンク	
600	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	1pc.
* 610	VR030500	Circuit Board	PS	P S シート	01
615	VN103500	Lithium Battery	CR2032	リチウム電池	03
620	EP630220	Bind Head Tapping Screw-P	3.0X8 ZMC2BL	+ バインド P タイ	2pcs
630	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド 小 ネ ジ	1pc.
640	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	2pcs
* 650	VR037100	Trnsistor Holder		トランジスターホルダ	07
660	VC214100	Pan Head Screw	SP 3.0X16 ZMC2Y	+ ナベ小ネジ	2pcs
* 670	VR301300	Connector Assembly	PS	線材 Ass'y	
670a	LB605750	Connector	SRCN PLUG 10P	丸型コネクタ	08
680	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	4pcs
690	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド 小 ネ ジ	2pcs
700	--	Connector Assembly	SHUNT	線材 Ass'y (VR98480)	
710	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド 小 ネ ジ	2pcs
* 720	VR037200	Shield Plate		シールドプレート	11
730	VN141100	Support, PCB	KGPS-5RF	カードスパーサー	2pcs
740	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿 小 ネ ジ	4pcs
750	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+ バインド B タイ	3pcs
* 760	NX813720	Circuit Board	JK1/5	J K 1 / 5 シート (VR30710)	
* 760	NX813730	Circuit Board	JK2/5	J K 2 / 5 シート (VR30710)	
770	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインド B タイ	11pcs
* 780	VR272500	INPUT Module		I N P U T モジュール	4/6/8/10pcs
790	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+ バインド B タイ	20/30/40/50pcs
* 800	VR272600	ST CHANNEL Module		S T C H モジュール	
Notes) The MIDI3/4 circuit board and the connector assemblies are not included in the ST CHANNEL module. 注意) MIDI3/4シートと線材Ass'yは、ST CHモジュールの構成部品ではありません					
810	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+ バインド B タイ	4pcs
* 820	VR272700	MASTER Module		M A S T E R モジュール	
Notes) The MIDI4/4 circuit board and the connector assemblies are not included in the MASTER module. 注意) MIDI4/4シートと線材Ass'yは、MASTERモジュールの構成部品ではありません					
830	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+ バインド B タイ	10pcs
* 840	VR301800	Connector Assembly	MC08-16	線材 Ass'y	16CH
* 840	VR301900	Connector Assembly	MC08-24	線材 Ass'y	24CH
* 840	VR302000	Connector Assembly	MC08-32	線材 Ass'y	32CH
* 840	VR302100	Connector Assembly	MC08-40	線材 Ass'y	40CH
* 850	VR700500	Angle Bracket	(Earth bar)	アングル (アースバー)	1/1/1/2pcs
860	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド 小 ネ ジ	1/1/1/2pcs
* 870	VR268400	Spacer		スパーサー	3/3/3/4pcs
* 880	VR701300	Earth Bar	16IN	アースバー 1 6 I N	16CH
* 880	VR701400	Earth Bar	24IN	アースバー 2 4 I N	24CH/40CH
* 880	VR701500	Earth Bar	32IN	アースバー 3 2 I N	32CH
* 890	VR701100	Joint Plate	A	連結金具 A	

* New Parts (新規部品)


ランク: Japan only

REF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	ランク
* 900	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	1pc.	01
* 910	VR700600	Sub-plate	16IN	サブ金具 1 6 I N	16CH	
* 910	VR700700	Sub-plate	24IN	サブ金具 2 4 I N	24/40CH	
* 910	VR700800	Sub-plate	32IN	サブ金具 3 2 I N	32CH	
920	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	2pcs	01
930	VG513400	Insulation Bushing	4M PM2800M	絶 縁 ブ ッ シ ュ	2pcs	01
940	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	2pcs	01
* 950	VR701600	Earth Bar	40INR	アースバー 4 0 I N R	40CH	
* 960	VR701200	Joint Plate	B	連 結 金 具 B	40CH	
970	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	40CH	01
* 980	VR700900	Sub-plate	40INR	サブ金具 4 0 I N R	40CH	
990	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	40CH 2pcs	01
1000	VG513400	Insulation Bushing	4M PM2800M	絶 縁 ブ ッ シ ュ	40CH 2pcs	01
1010	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	40CH 2pcs	01
* 1020	VR701700	Earth Bar	MA	アースバー M A		
* 1030	VR701000	Sub-plate	MA	サ ブ 金 具 M A		
1040	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	2pcs	01
1050	VG513400	Insulation Bushing	4M	絶 縁 ブ ッ シ ュ	16/24/32CH	01
1060	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	3/3/3/4pcs	01
1070	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	2pcs	01
1080	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	19/23/27/31pcs	01
1090	--	Meter Assembly		メーター A s s y		
1100	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+ バインドBタイト	4/6/6/8pcs	01
1110	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	5/6/7/8pcs	01
* 1120	VR038400	Front Pad	16CH	フロントパッド 1 6 C H	16CH	
* 1120	VR038500	Front Pad	24CH	フロントパッド 2 4 C H	24CH	
* 1120	VR038600	Front Pad	32CH	フロントパッド 3 2 C H	32CH	
* 1120	VR038700	Front Pad	40CH	フロントパッド 4 0 C H	40CH	
* 1130	VR035200	Felt	16CH	フェルト 1 6 C H	16CH	03
* 1130	VR035300	Felt	24CH	フェルト 2 4 C H	24CH	03
* 1130	VR035400	Felt	32CH	フェルト 3 2 C H	32CH	03
* 1130	VR035500	Felt	40CH	フェルト 4 0 C H	40CH	04
1140	EL000320	Bind Head Screw	A4.0X8 FCM3BL	+ バインド小ネジ	5/6/7/8pcs	01
1170	--	Label	DC POWER INPUT	ラ ベ ル	(VR35720)	
		ACCESSORIES		付 属 品		
	VD028900	Power Cable	M2000-PW2000M	接 続 ケーブル		21
*	VR590400	Power Supply Unit	PW2000M	電 源 A s s y	J	
*	VR590500	Power Supply Unit	PW2000M	電 源 A s s y	U,C,V	
*	VR590600	Power Supply Unit	PW2000M	電 源 A s s y	H,W	
*	VR590700	Power Supply Unit	PW2000M	電 源 A s s y	B	

* New Parts (新規部品)



ランク: Japan only

OVERALL ASSEMBLY (総組立) 1/5 M2000



■ OVERALL ASSEMBLY (総組立) 2/5 M2000


This figure shows the main chassis, frame, side pads, etc. (Modules are not installed.)
(この図は、メインシャーシ、フレーム、サイドパッドなどの組立てを示しています。モジュールは組付けられていません。)




M2000/PW2000M

OVERALL ASSEMBLY (総組立) 3/5 M2000


[Section A - A]



[Section B - B]





[Section C - C]




16CH (VR27210) : x4
24CH (VR27220) : x4
32CH (VR27230) : x6
40CH (VR27240) : x6


■ OVERALL ASSEMBLY (総組立) 4/5 M2000





Underside of the meter panel
(メーターパネル下側 (1))
The earth bar has been removed.
(アースバー取外し後)



Underside of the meter panel
(メーターパネル下側 (2))




■ OVERALL ASSEMBLY (総組立) 5/5 M2000




Underside of the meter panel
(メーターパネル下側 (1))
The earth bar has been removed.
(アースバー取外し後)

Underside of the meter panel
(メーターパネル下側 (2))

Earth bar
(アースバー詳細)



■ INPUT MODULE (INPUTモジュール)



INPUT MODULE (INPUTモジュール)

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
* 10	VR272500	INPUT MODULE	INPUTモジュール		
* 20	VR033600	Module Panel, INPUT	IN パネル		05
* 30	VR033700	Escutcheon	エスカッションCUE		05
* 40	VR033800	Button	ボタンON/OFF	ON/EDIT	
* 40	VR301500	Connector Assembly	MONO FADER1	線材 Assy	
40a	—	Slide Variable Resistor	10.0K RSA0K11A	スライドVR100mm	FADER (VR28070)
50	EC030030	Flat Head Screw	3.0X6 ZMC2BL	+ 皿小ネジ	8pcs
* 60	VR034100	Sheet Holder	IN	シートホルダーIN	05
70	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿小ネジ	2pcs
* 80	VR030200	Circuit Board	IN	IN シート	4pcs
90	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	56pcs
* 100	VR033900	Rear Panel	IN	リアパネルIN	01
* 110	VR671000	Insulation Sheet	IN	絶縁シートIN	
120	VC082800	Bonding Head Screw	3.0X6 FCM3BL	BONDING小ネジ	8pcs
130	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	8pcs
140	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿小ネジ	4pcs
* 150a	NX813770	Circuit Board	DISTR11/2	DISTR11/2シート	
* 150b	NX813780	Circuit Board	DISTR12/2	DISTR12/2シート	
160	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	4pcs
170	VN938600	Knob	RE//S-GY (L)	ノブ (大)	PAN (4pcs)
180	VN938500	Knob	BL/M-G (L)	ノブ (大)	GAIN (4pcs)
190	VN563600	Knob	S-GY/GR (S)	ノブ (小)	HIGH, HM, LM, LOW
200	VQ193800	Knob	GR/S-GY (S)	ノブ (小)	HM-f, LM-f (8pc)
210	VQ453600	Knob	BL/BE (S)	ノブ (小)	AUX 1,2,3,4
220	VN695700	Knob	S-GY/BE (S)	ノブ (小)	AUX 5,6 (8pcs)
* 230	VR275600	Fader Knob	BL/S-GY	ノブ (フェーダー)	CH FADER (4pcs)

* New Parts (新規部品)

ランク: Japan only

M2000/PW2000M

ST CHANNEL MODULE (ST CHモジュール)

NOTE) The MIDI 3/4 circuit board is not a part of the ST CHANNEL module. (See page 26.)


注意) MIDI 3/4シートはST CHモジュールの構成部品ではありません。別添ご手配下さい。(26ページ参照)

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
* 10	VR272600	ST CHANNEL MODULE	ST CHモジュール		
* 20	VR034200	Module Panel	ST CH パネル		
* 30	VR033700	Escutcheon	エスカッションCUE		05
* 40	VR033800	Button	ボタンON/OFF	ON/EDIT	05
* 40a	VR301700	Connector Assembly	ST FADER	線材 Ass'y	2pcs
50	EC030030	Slide Variable Resistor	D10KX2 RSA0K12A	ニ連スライドVR	FADER (VR28110)
* 60	VR034400	Flat Head Screw	3.0X6 ZMC2BL	+皿小ネジ	4pcs
* 70	VS182000	Sheet Holder	ST CH	シートホルダST CH	
* 80	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+皿小ネジ	2pcs
* 90	VR030300	Circuit Board	ST-IN	ST-INシート	2pcs
* 100	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	24pcs
* 110	VR991600	Hexagonal Nut	7 ZMC2BL	管用ナット 7X11X2	2pcs
* 120	VR034300	Rear Panel	ST CH	リアパネルST CH	
* 130	VR671000	Insulation Sheet	IN	絶縁シートIN	
140	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+バインドBタイト	2pcs
150	EP630220	Bind Head Tapping Screw-P	3.0X8 ZMC2BL	+バインドPタイト	2pcs
* 180	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+皿小ネジ	4pcs
* 190	VR277700	Connector Assembly	DIST MATRIX	線材 Ass'y	
200	VN938600	Knob	RE/S-GY (L)	ノブ (大)	BAL/PAN (2pcs)
210	VN938500	Knob	BL/M-GY (L)	ノブ (大)	GAIN A (2pcs)
220	VN938700	Knob	BL/M-GY (S)	ノブ (小)	GAIN B (2pcs)
230	VM563600	Knob	S-GY/GR (S)	ノブ (小)	HIGH, MID, LOW
240	VQ193800	Knob	GR/S-GY (S)	ノブ (小)	MID-f (2pcs)
250	VQ453600	Knob	BL/BE (S)	ノブ (小)	AUX 1,2,3,4
260	VM695700	Knob	S-GY/BE (S)	ノブ (小)	AUX 5,6 (4pcs)
* 260	VR629500	Fader Knob	S-GY/BL	ノブ (フェーダー)	ST FADER (2pcs)

* New Parts (新規部品)



ランク: Japan only

■ ST CHANNEL MODULE (ST CHモジュール)



- **RETURN Circuit Board (Refer to page C6)**


A RETURN circuit board is utilized for RETURN1, RETURN2, RETURN3 or RETURN4.
The RETURN circuit board provided as a service part is set for RETURN1.
If you would like to replace the RETURN2, RETURN3 or RETURN4 with this board, you should attempt to change internal short connectors as shown below.
RETURNシートは、RETURN1、RETURN2、RETURN3、あるいはRETURN4シートとして使用します。
サービス用のRETURNシートは、RETURN1用ですが、これをRETURN2、RETURN3あるいはRETURN4シートとして使用する場合は、下記のように短絡ソケットの変更が必要となります。



• **MATRIX1 and MATRIX3 Circuit Board (Refer to page C8 and C10)**

A MATRIX1 circuit board is utilized for MATRIX1 or MATRIX2.
The MATRIX1 circuit board provided as a service part is set for MATRIX1.
If you would like to replace the MATRIX2 with this board, you should attempt to change internal short connectors as shown below.
MATRIX1シートは、MATRIX1あるいはMATRIX2シートとして使用します。
サービス用のMATRIX1シートは、MATRIX1用ですので、これをMATRIX2シートとして使用する場合は、下記のように短絡ソケットの変更が必要となります。

A MATRIX3 circuit board is utilized for MATRIX3 or MATRIX4.
The MATRIX3 circuit board provided as a service part is set for MATRIX3.
If you would like to replace the MATRIX4 with this board, you should attempt to change internal short connectors as shown below.
MATRIX1シートは、MATRIX3あるいはMATRIX4シートとして使用します。
サービス用のMATRIX3シートは、MATRIX3用ですので、これをMATRIX4シートとして使用する場合は、下記のように短絡ソケットの変更が必要となります。



• Knob (ノブ)
Example: BL / BE (S)
(例)
Index color (指標色) Knob color (ノブ本体色) Size (大きさ)

RE : Red (赤)
BL : Black (黒)
GR : Green (緑)
BE : Blue (青)
S-GY : Light Gray (ライトグレイ)
M-GY : Medium Gray (ミディアムグレイ)

• Size
(L) : large (大)
(S) : small (小)

NOTES) The MIDI 4/4 circuit board is not a part of the MASTER module. (See page 26.)


注意) MIDI 4/4シートはMASTERモジュールの構成部品ではありません。別添ご手配下さい。(26ページ参照)

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
* 10	VR272700	MASTER MODULE	MASTERモジュール		
* 20	VR034500	Module Panel	M A パネル		
* 30	VR033700	Escutcheon	エスカッションCUE	2pcs	05
* 35	VR033800	Button	ボタンON/OFF	ON/EDIT (3pcs)	05
* 40	VP498500	Insulation Sheet	METER	絶縁シート	03
* 40a	VR301500	Connector Assembly	MONO FADER1	線材 Assy	11pcs
50	EC030030	Slide Variable Resistor	10.0K RSA0K11A	スライドVR100mm	FADER (VR28070)
70	EC030030	Flat Head Screw	3.0X6 ZMC2BL	+ 皿小ネジ	18pcs
75	CB095100	Flat Head Screw	3.0X6 ZMC2BL	+ 皿小ネジ	4pcs
* 80	VR034700	Cord Binder	K-103G	コードキープ	01
* 90	VS182000	Sheet Holder	MA	シートホルダーMA	2pcs
* 100	VR313400	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿小ネジ	
* 110	VP157900	Angle Bracket	STMN	アングルSTMN	1pc
* 120	VR030600	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	01
130	VR030600	Circuit Board	RETURN	RETURNシート	4pcs
* 140	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	24pcs
* 150	VR031000	Circuit Board	MATRIX1	MATRIX1シート	2pcs
* 160	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	34pcs
* 170	VR031200	Circuit Board	MATRIX3	MATRIX3シート	2pcs
* 180	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	32pcs
* 190	VR031400	Circuit Board	ST	STシート	
* 200	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	2pcs
* 210	VC082800	Bonding Head Screw	3.0X6 FCM3BL	BONDING小ネジ	2pcs
* 220	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	2pcs
* 230	VR031500	Circuit Board	MONO	MONOシート	
* 240	VJ388000	Hexagonal Nut	9 ZMC2BL	特殊六角ナット	2pcs
* 250	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿小ネジ	1pc
* 260	VR671200	Rear Panel	MA1	リアパネルMA1	
* 270	VR671100	Insulation Sheet	MA	絶縁シートMA	
280	VC082800	Bonding Head Screw	3.0X6 FCM3BL	BONDING小ネジ	16pcs
290	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	8pcs
300	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿小ネジ	2pcs
310	VR671300	Rear Panel	MA2	リアパネルMA2	
320	VC082800	Bonding Head Screw	3.0X6 FCM3BL	BONDING小ネジ	20pcs
330	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	4pcs
340	VR671400	Rear Panel	MA3	リアパネルMA3	
350	VC082800	Bonding Head Screw	3.0X6 FCM3BL	BONDING小ネジ	6pcs
360	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+ バインドBタイト	3pcs
370	EP630220	Bind Head Tapping Screw-P	3.0X8 ZMC2BL	+ バインドPタイト	2pcs
400	VS182000	Flat Head Screw	B3.0X6 ZMC2BL	+ 皿小ネジ	2pcs
* 410	VR277700	Connector Assembly	DIST MATRIX	線材 Assy	2pcs
* 420	VR277800	Connector Assembly	DIST ST	線材 Assy	
* 430	VR302200	Connector Assembly	MC08-MASTER	線材 Assy	
* 440	VN938600	Knob	RE//S-GY (L)	ノブ (大)	BAL/PAN, PAN
* 450	VR690600	Knob	BE//S-GY (L)	ノブ (大)	RTN LEVEL
460	VM706600	Knob	S-GY/BE (L)	ノブ (大)	AUX LEVEL
470	VP094500	Knob	BL/S-GY (L)	ノブ (大)	LEVEL A,B
480	VN938500	Knob	BL/M-GY (L)	ノブ (大)	MONI, TB, PHONE
490	VM563600	Knob	S-GY/GR (S)	ノブ (小)	HIGH, LOW
500	VN938700	Knob	BL/M-GY (S)	ノブ (小)	SUB L,R, GRP1-4
510	VQ453500	Knob	BL/RE (S)	ノブ (小)	ST L,R
520	VQ453100	Knob	BL/Y-BR (S)	ノブ (小)	MONO
530	VM706800	Knob	S-GY/M-GY (S)	ノブ (小)	GRP 5-8
* 540	VR282600	Fader Knob	BL/M-GY	ノブ (フェーダー)	GRP FADER
* 550	VR282700	Fader Knob	BL/RE	ノブ (フェーダー)	ST FADER
* 550	VR629600	Fader Knob	BL/Y-BR	ノブ (フェーダー)	MONO FADER

* New Parts (新規部品)

ランク: Japan only

METER ASSEMBLY (メーターAss'y)




REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
	--	METER ASSEMBLY	メーターアッシー		
	--	Meter Assembly	メーターアッシー	(VR27280)	
	--	Meter Assembly	メーターアッシー	(VR27290)	
	--	Meter Assembly	メーターアッシー	(VR27300)	
	--	Meter Assembly	メーターアッシー	(VR27310)	
* 10	VR034800	Meter Panel	メーターパネル16CH	16CH	
* 10	VR034900	Meter Panel	メーターパネル24CH	24CH	
* 10	VR035000	Meter Panel	メーターパネル32CH	32CH	
* 10	VR035100	Meter Panel	メーターパネル40CH	40CH	
* 15	VS187800	Shade	遮光シート		
* 20	VR625000	Analog Meter	VU MG-113	アナログメーター	ST L,R, MONO
* 30	VR672000	Meter Holder	S/M	メーターホルダーS/M	
* 40	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+バインドBタイト	01
* 50a	NX813870	Circuit Board	MTC1/2	MTC1/2シート	(VR65770)
* 50b	NX813880	Circuit Board	MTC2/2	MTC2/2シート	(VR65770)
* 60	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+バインドBタイト	2pcs
* 80	VR625100	Analog Meter	VU MG-118	アナログメーター	GRP/MTRX/AUX
* 90	VM519600	Meter Holder	GRP	メーターホルダー	4pcs
* 100	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+バインドBタイト	8pcs
* 110a	NX813830	Circuit Board	MTA4-1/4	MTA4-1/4シート	(VR30550)
* 110b	NX813830	Circuit Board	MTA4-2/4	MTA4-2/4シート	(VR30550)
* 110c	NX813830	Circuit Board	MTA4-3/4	MTA4-3/4シート	(VR30550)
* 110d	NX813830	Circuit Board	MTA4-4/4	MTA4-4/4シート	(VR30550)
* 120	VP157900	Bind Head Tapping Screw-B	A3.0X6 ZMC2BL	+バインドBタイト	4pcs
* 140	VR625200	BNC Connector	31-10T	BNCコネクタ	LAMP (3pcs)
* 150a	NX813740	Circuit Board	BNC3/5	BNC3/5シート	(VR30720)
* 150b	NX813750	Circuit Board	BNC4/5	BNC4/5シート	(VR30720)
* 150c	NX813760	Circuit Board	BNC5/5	BNC5/5シート	(VR30720)
* 170	AA829940	Hinge	-	蝶番	4pcs
* 180	VC688800	Bind Head Tapping Screw-B	A4.0X8 ZMC2BL	+バインドBタイト	8pcs
* 190	VR035200	Felt	16CH	フェルト16CH	16CH
* 190	VR035300	Felt	24CH	フェルト24CH	24CH
* 190	VR035400	Felt	32CH	フェルト32CH	32CH
* 190	VR035500	Felt	40CH	フェルト40CH	16CH
* 200	CB095100	Cord Holder	K-103G	コードキープ	5pcs

* New Parts (新規部品)


ランク : Japan only

• Meter Assembly



	Length (mm)
M2000-16	888
M2000-24	1120
M2000-32	1352
M2000-40C	1614

OVERALL ASSEMBLY (総組立) PW2000M



ランク： Japan only

* New Parts (新規部品)

45

ELECTRICAL PARTS (PW2000M)

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
* * *	VR658000	ELECTRICAL PARTS	電 気 部 品	J (XN889B0)	
	VR658100	Circuit Board	D C シ ー ト	U,C,V (XN889B0)	
	VR658200	Circuit Board	D C シ ー ト	H,B,W (XN889B0)	
	EP630300	Bind Head Tapping Screw-C	＋ バ イ ン ド C タ イ ト		01
* * * * * *	UA353100	Mylar Capacitor	マ イ ラ ー コ ン		01
	FZ000650	Mylar Capacitor	マ イ ラ ー コ ン		02
	VE326000	Monolithic Mylar Capacitor	積 層 マ イ ラ ー コ ン		01
	FG644100	Ceramic Capacitor-F	セ ラ コ ン F		01
	FH223470	Ceramic Capacitor-E	セ ラ コ ン E		01
	UJ748470	Electrolytic Cap.	ケ ミ コ ン		01
* * * * * *	UJ778220	Electrolytic Cap.	ケ ミ コ ン		01
	UJ837100	Electrolytic Cap.	ケ ミ コ ン		01
	UJ837220	Electrolytic Cap.	ケ ミ コ ン		01
	UJ837470	Electrolytic Cap.	ケ ミ コ ン		01
	UJ847100	Electrolytic Cap.	ケ ミ コ ン		01
	UJ847470	Electrolytic Cap.	ケ ミ コ ン		01
* * * * * *	UJ848100	Electrolytic Cap.	ケ ミ コ ン		01
	UJ857100	Electrolytic Cap.	ケ ミ コ ン		01
	UJ857470	Electrolytic Cap.	ケ ミ コ ン		01
	UJ858100	Electrolytic Cap.	ケ ミ コ ン		01
	UJ896470	Electrolytic Cap.	ケ ミ コ ン		01
	UJ739100	Electrolytic Cap.	ケ ミ コ ン		01
* * * * * *	VA274100	Electrolytic Cap.	ケ ミ コ ン		07
	VI486600	Electrolytic Cap.	ケ ミ コ ン		09
	VR609200	Electrolytic Cap.	ケ ミ コ ン		01
	F1383220	Capacitor	規 格 認 定 コ ン	H,B,W	01
	F1383470	Capacitor	規 格 認 定 コ ン		01
	FR203220	Capacitor	規 格 認 定 コ ン		04
* * * * * *	GE901370	Coil	コ イ ル		05
	HF754100	Carbon Resistor	カ ー ボ ン 抵 抗		01
	--	Carbon Resistor	カ ー ボ ン 抵 抗	(HF75482)	
	--	Carbon Resistor	カ ー ボ ン 抵 抗	(HF75575)	
	HF756100	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF756220	Carbon Resistor	カ ー ボ ン 抵 抗		01
* * * * * *	HF756240	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF756270	Carbon Resistor	カ ー ボ ン 抵 抗		01
	--	Carbon Resistor	カ ー ボ ン 抵 抗	(HF75630)	
	HF756330	Carbon Resistor	カ ー ボ ン 抵 抗		01
	--	Carbon Resistor	カ ー ボ ン 抵 抗	(HF75636)	
	HF756470	Carbon Resistor	カ ー ボ ン 抵 抗		01
* * * * * *	HF756560	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF757100	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF757180	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF757200	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF757220	Carbon Resistor	カ ー ボ ン 抵 抗		01
	HF758100	Carbon Resistor	カ ー ボ ン 抵 抗		01
* * * * * *	HV754220	Flame Proof C. Resistor	不 燃 化 カ ー ボ ン 抵 抗		01
	VA074100	Metal Film Resistor	金 属 被 膜 抵 抗		01
	VA074600	Metal Film Resistor	金 属 被 膜 抵 抗		01
	VB067300	Metal Film Resistor	金 属 被 膜 抵 抗		01
	VB067600	Metal Film Resistor	金 属 被 膜 抵 抗		01
	VC740900	Metal Oxide Film Resistor	酸 化 金 属 被 膜 抵 抗		01
* * * * * *	VC746200	Metal Oxide Film Resistor	酸 化 金 属 被 膜 抵 抗		01
	VC748800	Metal Oxide Film Resistor	酸 化 金 属 被 膜 抵 抗		01
	HM052220	Wire Wound Resistor	セ メ ン ト 抵 抗		01
	HM052470	Wire Wound Resistor	セ メ ン ト 抵 抗		02
	HW914150	Fuse Resistor	ヒ ュ ー ズ 抵 抗		02
	IG107000	IC	I C	OP AMP	04
* * * * * *	XC721A00	IC	I C	REGULATOR -12V	02

* New Parts (新規部品)

ランク : Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	ランク
* ▲ ▲ ▲ ▲ ▲ ▲	XD706A00	IC	NJM7809FA	REGULATOR +9V	02
	XJ608A00	IC	NJM7812FA	REGULATOR +12V	02
	VF576000	Push Switch	ESB-8236V	POWER switch	03
	KB001280	Fuse	T 6.00A 250V	J	02
	KB001250	Fuse	T 6.00A 250V	U,C,V	02
	KB003070	Fuse	TR2.00A	H,B,W	01
	KB003570	Fuse	T 2.00A 250V	J,U,C,V	01
	KB003250	Fuse	TR6.30A	H,B,W	
	VJ102400	Relay	G4W1112TP-USTV8	リレーDC12V	
	VA855400	Terminal	PC用カラゲ端子		01
	LB932030	Base Post Connector	VH-3P TE	ベースポスト	01
	LB932060	Base Post Connector	VH-6P TE	ベースポスト	01
	VB389800	Connector Base Post	PH-2P TE	コネクタベースポスト	01
	LB201530	Fuse Holder	PC-FH1	ヒューズホルダ	01
	VA024800	Trimmer Potentiometer	B10.0K	半固定VR	+17V, +12v adj. 02
	IA093700	Transistor	2SA937 Q,R,S	トランジスタ	01
	VF163700	Transistor	2SA1265N R,O	トランジスタ	04
	IB056010	Transistor	2SB560V16MP E,F	トランジスタ	02
	IB059630	Transistor	2SB596 O,Y	トランジスタ	04
	IC1815M0	Transistor	2SC1815 Y,GR	トランジスタ	01
	IC202180	Transistor	2SC2021 Q,R,S	トランジスタ	01
	IC224030	Transistor	2SC2240 GR,BL	トランジスタ	01
	VC211000	Transistor	2SC3421 O,Y	トランジスタ	02
	VF163900	Transistor	2SC3182N R,O	トランジスタ	04
	ID043810	Transistor	2SD438-MP E,F	トランジスタ	01
	ID052630	Transistor	2SD526 O,Y	トランジスタ	04
	VB941200	Diode	1SS133,1SS176	ダイオード	01
	VE170000	Diode	1SR35-100A 52	ダイオード	01
	VB845300	Diode Stack	S1WB(A)60	ダイオードスタック	02
	VM622000	Diode Stack	GBPC2504	ダイオードスタック	07
	VQ272500	Zener Diode	MTZJ5.6C 5.6V	ツェナーダイオード	
	VQ555000	Zener Diode	MTZJ10C 10.0V	ツェナーダイオード	
	VQ556100	Zener Diode	MTZJ15C 15.0V	ツェナーダイオード	
	VQ556800	Zener Diode	MTZJ20C 20.0V	ツェナーダイオード	
	VQ557500	Zener Diode	MTZJ24B 24.0V	ツェナーダイオード	
	VQ558000	Zener Diode	MTZJ27D 27.0V	ツェナーダイオード	
	VQ558700	Zener Diode	MTZJ33D 33.0V	ツェナーダイオード	
	VH325300	LED	GL2EG6	LED	POWER,+17, -17, +12, +48 01
	IL000690	Insulation Sheet	CSSX-G509	放熱シート	01
	VA078900	Jumper Wire	0.55	ジャンパー線	
	VI474400	Terminal Plate		ターミナル金具	01
	BA808520	Heat Sink	T220M 25L	ヒートシンク	03
	VF660100	Transistor Spacer		トランジスタスペーサ	01
	VM679600	Diode Spacer	GBPC2504	ダイオードスペーサ	06
	--	Connector Assembly	PW DI	束線	(VR67170)
	--	Connector Assembly	PW DD	束線	(VR67190)
	--	Fuse Label	T2A L	ヒューズラベル	H,B,W (VQ50210)
	--	Fuse Label	T6.3AL	ヒューズラベル	H,B,W (VR72540)
▲ ▲ ▲	XA237B00	Power Transformer		電源トランス	J 09
	XA238C00	Power Transformer		電源トランス	U,C,V 09
	XA239B00	Power Transformer		電源トランス	H,B,W 09
* ▲ ▲ ▲	XN821A00	Power Transformer		電源トランス	J
	XN822A00	Power Transformer		電源トランス	U,C,V
	XN823A00	Power Transformer		電源トランス	H,B,W
▲ ▲	MG000610	AC Cord	2P 15A 2.1m	電源コード	J 06
	VD279600	AC Cord	3P 10A 2.5m	電源コード	U,C,V 08

* New Parts (新規部品)

ランク : Japan only

ランク： Japan only

■ CIRCUIT BOARD & CIRCUIT DIAGRAM (シート基板図と回路図)

● CONTENTS (目次)

BLOCK & LEVEL DIAGRAM	page C1
IN CIRCUIT BOARD	page C2
ST-IN CIRCUIT BOARD	page C4
RETURN CIRCUIT BOARD	page C6
MATRIX1 CIRCUIT BOARD	page C8
MATRIX3 CIRCUIT BOARD	page C10
ST CIRCUIT BOARD	page C12
MONO CIRCUIT BOARD	page C14
MIDI CIRCUIT BOARD (1/4, 2/4)	page C16
MIDI CIRCUIT BOARD (3/4, 4/4)	page C18
DISTRI & PS CIRCUIT BOARDS	page C20
DC CIRCUIT BOARD (PW2000M)	page C22
JK & BNC CIRCUIT BOARDS	page C24
MTC CIRCUIT BOARD	page C26
MTA4 CIRCUIT BOARD	page C28

■ M2000 BLOCK & LEVEL DIAGRAM

M2000/PW2000M



CH INSERT I/O
[0dB]

MONO IN
INPUT A (-20~+10dB)
INPUT B (-20~+10dB)
ST IN (1~2)
L (-20~+10dB)
R (-20~+10dB)

ST IN
L (-20~+10dB)
R (-20~+10dB)

SCENE MEMORY
UTILITY
RECALL
STORE
CHECK
UP
DOWN
DIRECT RECALL
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
7

IN CIRCUIT BOARD



Notes)

Circuit Board: IN (VR030200) XN288B0

1. IC

IC101: NJM072D (IG107000) OP AMP
IC102,103: NJM4560ED (IG040000) OP AMP
IC104,201,202: NJM2068D-D (XA987A00) OP AMP
IC301: SN74HC74N (IR007450) DFF
IC302: SN74HC02N (IR000250) NOR
IC303: SN74HC368N (IR036850) BUS INVERTER
IC304: HD74HC123AP (IR012310) MULTI VIBRATOR

2. Transistor

Q 101,102: 2SC2240 GR,BL (IC224030) or 2SC3329 GR,BL (VE415900)
Q 103,105,301-304: 2SC1740S R,S (IC174070)
Q 104,106: 2SA933S Q,R (IA093320)

3. Diode

D 101,301: 1SS133,1SS176 (VB941200)

4. LED

LED 101,301: GL2EG6 GR (VH325300) SIGNAL, CHECK
LED 102: GL2PR6 RE (VH325200) PEAK
LED 302: GL2HY6 YE (VJ471200) ON

5. Mylar Capacitor

C 118,119: 0.0910 50V J (UA654910)
C 126,127: 0.0390 50V J (UA654390)
C 128: 1000P 50V J (UA353100)
C 131: 2400P 50V J (UA353240)
C 132: 6200P 50V J (UA353620)
C 137: 0.0120 50V J (UA654120)
C 138: 0.0300 50V J (UA654300)
C 305: 0.0330 50V J (UA654330)

6. Ceramic Capacitor

C 106-109,157,209: B 470P 50V K (FG612470)
C 112: SL 82P 50V J (FG651820)
C 113: SL 33P 50V J (FG651330)
C 115,116,121,122,135,136,143,144,152, 205,206,216,217: F 0.0100 50V Z (FG644100)
C 129,133,139,202,203, 213,214: SL 100P 50V J (FG652100)
C 130,141,142,153,156, 210,215: SL 47P 50V J (FG651470)
C 134,140: SL 22P 50V J (FG651220)
C 158,159: SL 1000P 50V K (FG613100)
C 160,306: B 220P 50V K (FG612220)
C 204: SL 68P 50V J (FG651680)

7. Electrolytic Cap.

C 101: 47.00 63.0V (UJ877470)
C 102,103: 10.00 50.0V (VJ097400)
C 104,105: BP 2.20 50.0V (VN510800)
C 110: 1000 6.3V (UJ819100)
C 117,123,211,218: 47.00 16.0V (UJ837470)
C 124,145: 22.00 25.0V (UJ847220)
C 125,146-148,307: 1.00 50.0V (UJ866100)
C 149-150: 220.00 25.0V (UJ848220)
C 151,207: 220.00 10.0V (UJ828220)
C 201,208,212: 10.00 25.0V (UJ847100)

8. Semiconductive Cera. Cap.

C 301-304: 0.1000 25V Z (VC694800)
9. Carbon Resistor
R 108,153,155,161, 207,303,304: 100.0K 1/4 J (HF758100)
R 113-116,312: 10.0 1/4 J (HF754100)
R 129: 100.0 1/4 J (HF755100)
R 130,134,154,187,212,219: 220.0K 1/4 J (HF758220)
R 131,148,149,157,159, 163,165,216,217: 15.0K 1/4 J (HF757150)
R 132: 30.0K 1/4 J (HF757300)
R 133,150,211: 47.0 1/4 J (HF754470)
R 135,136,162,205,306, 307,309-311: 10.0K 1/4 J (HF757100)
R 137: 33.0K 1/4 J (HF757330)
R 138,220,301,302: 4.7K 1/4 J (HF756470)
R 139: 5.6K 1/4 J (HF756560)
R 140,141,144,145: 8.2K 1/4 J (HF756820)
R 142,143,146,147, 221: 5.1K 1/4 J (HF75651)
R 151,203,210: 47.0K 1/4 J (HF757470)
R 152,208,209,218: 560.0 1/4 J (HF755560)
R 156: 390.0K 1/4 J (HF75839)
R 158,164,186: 1.0K 1/4 J (HF756100)
R 160: 1.6K 1/4 J (HF756160)
R 166: 2.0K 1/4 J (HF75620)
R 201,202,213,214: 220.0 1/4 J (HF755220)
R 204: 4.3K 1/4 J (HF75643)
R 206: 22.0 1/4 J (HF75422)
R 215: 18.0K 1/4 J (HF757180)
R 305,308: 2.4K 1/4 J (HF756240)
R 313: 680.0K 1/4 J (HF75868)

10. Flame Proof Carbon Resistor

R 101: 390.0 1/4 J (HV755390)

11. Metal Film Resistor

R 102,103: 6.8K 1/4 F (VB067300)
R 104,105,117,118: 47.0K 1/4 F (VB068800)
R 106,107: 220.0K 1/4 F (VB070400)
R 109,110,126,127: 4.7K 1/4 F (VA074100)
R 111: 510.0 1/4 F (VB064200)
R 112: 100.0K 1/4 F (VB069600)
R 119,120: 2.2K 1/4 F (VB066300)
R 121: 20.0 1/4 F (VB060800)
R 122,123: 24.0K 1/4 F (VB068200)
R 124,125: 8.2K 1/4 F (VB067400)
R 167-185: 18.0K 1/4 F (VB067900)

12. Rotary Variable Resistor

VR 102: A20K+C20K (VQ900500) PAN
VR 103: 5K (VQ900600) GAIN
VR 104,109: B50K (VQ900700) HIGH, LOW
VR 105,107: C100Kx2 (VQ900900) HM-f, LM-f
VR 106,108: W20K (VQ900800) HM-GAIN, LM-GAIN
VR 110-115: A20K (VQ901000) AUX 1-6

13. Slide Switch

SW103: SSSU112-S06N-1 (VQ907900) +48V

14. Push Switch

SW101: SPUN60 2/2*6 (VQ901600) ASSIGN
1-2/3-4/5-6/7-8/ST/MONO
SW102,104: SPUN20 2/2*2 (VQ901700) ϕ /A/B, 26dB/80
SW105-107,110: SPUN19-2N-W (VQ901900) PRE1-2, PRE3-4, DIRECT, EQ
SW108: EVQ PB (VQ902900) EDIT/ON
SW109: SPUN19-2N-W (VQ902100) CUE

15. Relay

RY 301: DC RY12W (KC001900)

16. Phone Jack

JK 102: Stereo HLJ2305 (LB202700) INPUT B
JK 103: Stereo HLJ2335 (LB606940) INS I/O,DIRECT OUT

17. Cannon Connector

JK 101: XLM-3-31PCH-L (VM651800) INPUT A

18. Connector

CN 101: HIF3BAG40PA2.54 (VR633100)
CN 102,104: FJ-P 8P (VL548500)
CN 103,105: FJ-R 8P (VK217100)
CN 106: MQ-9P (VI378700)
CN 107: PH- 3P SE (VB858200)


19. Push Button

: M.GY/S.GY (VR034000) ASSGIN, ϕ , A/B, PRE, DIRECT
: GR/S.GY (VR281300) EQ,/80
: RE/S.GY (VR281500) ST
: Y.BR/S.GY (VR637000) MONO
: S.GY/Y.BR (VR637100) CUE


20. Knob

: RE (VJ859500) +48V

• SW103 installing (SW103の取付け)




• LED installing (LEDの取付け)





Component side (部品側)

3NA-VR03020

IN CIRCUIT BOARD




ST-IN CIRCUIT BOARD




- Notes)**
Circuit Board: ST-IN (VR030300) XN289B0
- 1. IC**
IC 101,102,104,201, 202: NJM2068D-D (XA987A00) OP AMP
IC 103,105: NJM4560ED (IG040000) OP AMP
IC 106: BA4558-NK (XF128A00) OP AMP
IC 301: SN74HC74N (IR007450) DFF
IC 302: SN74HC02N (IR000250) NOR
IC 303: SN74HC368N (IR036850) BUS INVERTER
IC 304: HD74HC123AP (IR012310) MULTI VIBRATOR
- 2. Transistor**
Q 101,103,302-304: 2SC1740S R,S (IC174070)
Q 102,104: 2SA933S Q,R (IA093320)
Q 301: 2SC1509 O,R (IC150930)
- 3. Diode**
D 101-105,301: 1SS133,1SS176 (VB941200)
- 4. LED**
LED 101,301: GL2EG6 GR (VH325300) SIGNAL, CHECK
LED 102: GL2PR6 RE (VH325200) PEAK
LED 302: GL2HY6 YE (VJ471200) ON
- 5. Mylar Capacitor**
C 124,126,154,156: 0.0390 50V J (UA654390)
C 125,155: 1000P 50V J (UA353100)
C 131,159: 3300P 50V J (UA353330)
C 132,160: 8200P 50V J (UA353820)
C 305: 0.0330 50V J (UA654330)
- 6. Ceramic Capacitor**
C 103,104,111,112,117, 128,133,140,141,148, 149,158,161,202,203, 210,214,215,222: SL 100P 50V J (FG652100)
C 105,113,116,118,142,150, 204,209,211,216,221, 223: SL 68P 50V J (FG651680)
C 106,107,119,120,129, 130,135,136,143,144, 164,165,170,205,206, 217,218: F 0.0100 50V Z (FG644100)
C 127,157: SL 47P 50V J (FG651470)
C 134,162: SL 22P 50V J (FG651220)
C 306: B 220P 50V K (FG612220)
- 7. Electrolytic Cap.**
C 101,109,115,138,146, 201,208,213,220: 10.00 25.0V (UJ847100)
C 102,110,139,147: 470.00 10.0V (UJ828470)
C 108,114,122,137,145, 151,152,163: 22.00 25.0V (UJ847220)
C 121,207,212,219, 224: 47.00 16.0V (UJ837470)
C 123,153,166-169, 307: 1.00 50.0V (UJ866100)
C 171,172: 220.00 25.0V (UJ848220)
C 173: 220.00 10.0V (UJ828220)
- 8. Semiconductive Cera. Cap.**
C 301-304: 0.1000 25V Z (VC694800)
- 9. Carbon Resistor**
R 101,109,137,145: 36.0K 1/4 J (HF757360)
R 102,110,138,146: 12.0K 1/4 J (HF757120)
R 103,111,139,147: 2.2K 1/4 J (HF756220)
R 104,112,140,148: 150.0 1/4 J (HF755150)
R 105,113,120,141,149,201,203, 211,216,218,226: 220.0 1/4 J (HF755220)
R 106,114,119,121,122, 126,129,142,150,154, 157,205,210,212,213, 220,225,227,228,306, 307,309-311: 10.0K 1/4 J (HF757100)
R 107,115,135,143,151, 163,206,221,312: 10.0 1/4 J (HF754100)
R 108,116,124,125,144, 152,153,207,215,222, 230: 220.0K 1/4 J (HF758220)
R 117,118,131,134,159, 162,208,209,223, 224: 8.2K 1/4 J (HF756820)
R 123,214,229: 47.0 1/4 J (HF754470)
R 127,155,301,302: 4.7K 1/4 J (HF756470)
R 128,156: 33.0K 1/4 J (HF757330)
R 130,158: 5.6K 1/4 J (HF756560)
R 132,133,160,161: 5.1K 1/4 J (HF75651)
R 136,164,202,217: 47.0K 1/4 J (HF757470)
R 165,167,169,175, 303,304: 100.0K 1/4 J (HF758100)
R 166,168: 330.0K 1/4 J (HF758330)
R 170: 390.0K 1/4 J (HF758390)
R 171,173,177,179: 15.0K 1/4 J (HF757150)
R 172,178,200: 1.0K 1/4 J (HF756100)
R 174: 1.6K 1/4 J (HF756160)
R 176: 13.0K 1/4 J (HF757130)
R 180: 2.0K 1/4 J (HF756200)
R 204,219: 4.3K 1/4 J (HF756430)
R 305,308: 2.4K 1/4 J (HF756240)
R 313: 680.0K 1/4 J (HF758680)
- 10. Metal Film Resistor**
R 181-199: 18.0K 1/4 F (VB067900)
- 11. Rotary Variable Resistor**
VR 102,103: C10Kx2 (VQ901100) GAIN A,B
VR 104,105: B50Kx2 (VQ901200) LOW,HIGH
VR 106: C100Kx4 (VQ901500) MID-f
VR 107: W20Kx2 (VQ901300) MID-GAIN
VR 108-113: A20K (VQ901000) AUX1-6
VR 114: A20K+C20K (VQ900500) BAL/PAN
- 12. Push Switch**
SW101: SPUN60 2/2*6 (VQ901600) ASSIGN
SW102: SPUN20 2/2*2 (VQ902000) L+R, A/B
SW103-105: SPUN19-2N-W (VQ901900) EQ,PRE 1-2,3-4
SW106: SPUN19-2N-W (VR633200) CUE
SW107: EVQ PB (VQ902900) ON/EDIT
- 13. Relay**
RY 301,302: DC RY12W (KC001900)
- 14. Pin Jack**
JK 103: YKC21-3045 (VM725600) INPUT B L/R
- 15. Phone Jack**
JK 101,102: HLJ0520 (LB202600) INPUT A L,R
- 16. Connector**
CN 101: HIF3BAG40PA2.54 (VR633100)
CN 102,104: FJ-P 10P (VL548700)
CN 103,105: FJ-R 10P (VK217300)
CN 106: PH- 6P SE (VB858500)
CN 107: PH- 9P SE (VB858800)
- 17. Push Button**
: M.GY/S.GY (VR034000) ASSIGN, L+R, A/B, PRE
: GR/S-GY (VR281300) EQ
: RE/S-GY (VR281500) ST
: Y-BR/S-GY (VR637000) MONO
: S-GY/Y-BR (VR637100) CUE

• LED installing (LEDの取付け)



3NA-VR03030

ST-IN CIRCUIT BOARD



- Notes
- Maraked (F): Metal film resistor
 - Marked (t): Ceramic capacitor
 - Marked (半t): Semiconductive ceramic capacitor
 - Marked (7): Mylar capacitor
 - VR101 is not a part of the IN circuit board.
 - Marked ○: Nominal level



*1 ST INPUT AUX (1/2/3/4) [Pre EQ/Post EQ] Jumper : factory set = Post EQ

KEC- 92062



MATRIX1 CIRCUIT BOARD

A MATRIX1 circuit board is utilized for MATRIX1 or MATRIX2.
The MATRIX1 circuit board provided as a service part is set for MATRIX1.
If you would like to replace the MATRIX2 with this board, you should attempt to change internal short connectors as shown below.
MATRIX1シートは、MATIRIX1あるいはMATRIX2シートとして使用します。
サービス用のMATRIX1シートは、MATRIX1用ですので、これをMATRIX2シートとして使用する場合は、下記のように短絡ソケットの変更が必要となります。



Notes)

- Circuit Board: MATRIX1 (VR031000) XN293B0
1. IC
- IC101-103,301: NJM2068D-D (XA987A00) OP AMP
- IC104-107: NJM4580DD (XM651A00) OP AMP
- IC302: TC4052BP (XA053A00) MULTI PLEXER
- IC401: SN74HC368N (IR036850) BUS INVERTER
- IC402: SN74HC02N (IR000250) NOR
- IC403: SN74HC74N (IR007450) DFF
- IC404: HD74HC123AP (IR012310) MULTI VIBRATOR
2. Transistor
- Q 401-404: 2SC1740S R,S (IC174070)
3. Diode
- D 401: 1SS133,1SS176 (VB941200)
4. LED
- LED 101,102,402: GL2HY6 YE (VJ471200) ON A, ON B, ON
- LED 401: GL2EG6 GR (VH325300) CHECK
5. Mylar Capacitor
- C 404: 0.0330 50V J (UA654330)
6. Ceramic Capacitor
- C 105,114,124,402: B 220P 50V K (FG612220)
- C 106,115,125: B 470P 50V K (FG612470)
- C 107,141: SL 82P 50V J (FG651820)
- C 108,109,117,118,122,127, 128,156,160,165,169,305, 306: F 0.0100 50V Z (FG644100)
- C 110,116,119,129: SL 47P 50V J (FG651470)
- C 111,304,311: SL 68P 50V J (FG651680)
- C 120,126,130,133,134,139, 140,302,303,309,310,313, 314: SL 100P 50V J (FG652100)
- C 135: SL 150P 50V J (FG652150)
- C 145,146,149,150,154, 155,158,159,163,164, 167,168: SL 33P 50V J (FG651330)
7. Electrolytic Cap.
- C 101,104,113,142,148,152, 157,161,166,170: 220.00 10.0V (UJ828220)
- C 102,103: 220.00 25.0V (UJ848220)
- C 112,131,137,312: 47.00 16.0V (UJ837470)
- C 121,144,153,162, 307: 22.00 25.0V (UJ847220)
- C 123: 100.00 10.0V (UJ828100)
- C 132,138,301,308, 315,316: 10.00 25.0V (UJ847100)
- C 136,143: 47.00 25.0V (UJ847470)
- C 147,151: 100.00 25.0V (UJ848100)
- C 403: 1.00 50.0V (UJ866100)

8. Semiconductive Cera. Cap.

- C 401,405-407: 0.1000 25V Z (VC694800)
9. Carbon Resistor
- R 104,110,141: 100.0 1/4 J (HF755100)
- R 108,114,145,151, 308,315: 47.0 1/4 J (HF754470)
- R 109,152,159,162,163, 309,316: 220.0K 1/4 J (HF758220)
- R 123,301,302: 1.0K 1/4 J (HF756100)
- R 128-140,142,147,154, 304,329: 18.0K 1/4 J (HF757180)
- R 143,144: 15.0K 1/4 J (HF757150)
- R 146,148,153,155,303, 305,310,312: 220.0 1/4 J (HF755220)
- R 149,150,306,307,403, 404,410,412,413: 10.0K 1/4 J (HF757100)
- R 156: 20.0K 1/4 J (HF757200)
- R 157,409: 10.0 1/4 J (HF754100)
- R 158,323: 7.5K 1/4 J (HF75675)
- R 160,161,407,408: 2.2K 1/4 J (HF756220)
- R 168,174,184,190, 196,200: 75.0 1/4 J (HF754750)
- R 169,175,185,191,197, 203,311,405,406: 100.0K 1/4 J (HF758100)
- R 204: 560.0 1/4 J (HF755560)
- R 205: 62.0 1/4 J (HF75462)
- R 317,319,401,402, 407,408: 4.7K 1/4 J (HF756470)
- R 318,320: 5.6K 1/4 J (HF756560)
- R 321,322: 8.2K 1/4 J (HF756820)
- R 324-326: 3.0K 1/4 J (HF75630)
- R 327: 12.0K 1/4 J (HF757120)
- R 328: 30.0K 1/4 J (HF757300)
- R 411: 680.0K 1/4 J (HF75868)
10. Flame Proof Carbon Resistor
- R 176-179: 10.0 1/4 J (HV754100)
11. Metal Film Resistor
- R 101-103,115-122,124-127,165,173, 181,188,193,202: 18.0K 1/4 F (VB067900)
- R 105: 24.0K 1/4 F (VB068200)
- R 106,112,113: 15.0K 1/4 F (VA074600)
- R 107: 16.0K 1/4 F (VB067800)
- R 111: 36.0K 1/4 F (VB068500)
- R 164,166,170,180,183,187, 192,194,198,314: 10.0K 1/4 F (VA074400)
- R 167,171,182,186, 195,199: 20.0K 1/4 F (VB068000)
- R 172,189,201: 11.0K 1/4 F (VA074500)
- R 313: 4.3K 1/4 F (VB067000)

12. Rotary Variable Resistor

- VR 101-115,301: A20K (VQ901000) SUB R,L, ST R,L, MONO, GROUP1-8, LEVEL A,B, AUX LEVEL
- VR 302: A20K+C20K (VQ900500) PAN
13. Push Switch
- SW101,301: SPUN (VA983800) MRX CUE, AUX CUE
- SW102,103,303, 304: SPUN19-2N-W (VQ901900) ON A, ON B, TO ST, TO MONO
- SW302: SPUN19-2N-W (VR633200) CUE
- SW401: EVQ PB (VQ902900) ON/EDIT

14. Pin Header

- SW104-107: 9202 2P-4 TE (VR702100) SW104-SW107

15. Short Connector

- : 9206H-T 2P (VR984700) for SW104-107

16. Relay

- RY 401: DC RY12W (KC001900)

17. Phone Jack

- JK 104: Stereo HLJ2335 (LB606940) MATRIX B/GROUP INS I/O

18. Cannon Connector

- JK 101-103: XLM-3-32PCH-L (VP953100) MATRIX A, GROUP, AUX

19. Connector


- CN 101,102: HIF3BAG40PA2.54 (VR633100)
- CN 103,104: FJ-P 14P (VL549000)
- CN 105: PH- 2P SE (VB858100)
- CN 301,302: FJ-R 14P (VQ966000)
- CN 303: PH- 3P SE (VB858200)
- CN 401: PH- 9P SE (VB858800)

20. Push Button

- : RE/S.GY (VR281500) TO ST
- : Y.BR/S.GY (VR637000) TO MONO
- : S.GY/Y.BR (VR637100) MATRX CUE, AUX CUE, CUE

21. Knob

- : S.GY/RE (VR667400) ON A, ON B




Notes
 Marked (7): Flame proof carbon resistor
 Marked (F): Metal film resistor
 Marked (t): Ceramic capacitor
 Marked (½t): Semiconductive ceramic capacitor
 Marked ○: Nominal level


- *1 GROUP to MATRIX [pre GROUP Fader / post GROUP Fader] Jumper : factory set = post GROUP Fader
- *2 GROUP to ST/MONO/MATRIX [pre ON sw. / post ON sw.] Jumper : factory set = pre ON sw.
- *3 GROUP 5/6/7/8 select switch
- *4 AUX 5/6 select switch
- *5 GROUP to MATRIX 5/6/7/8 select switch
- *6 MATRIX to METER 1A/2A/3A/4A select switch

MATRIX3 CIRCUIT BOARD

A MATRIX3 circuit board is utilized for MATRIX3 or MATRIX4.
The MATRIX3 circuit board provided as a service part is set for MATRIX3.
If you would like to replace the MATRIX4 with this board, you should attempt to change internal short connectors as shown below.
MATRIX1シートは、MATRIX3あるいはMATRIX4シートとして使用します。
サービス用のMATRIX3シートは、MATRIX3用ですので、これをMATRIX4シートとして使用する場合は、下記のように短絡ソケットの変更が必要となります。



- Notes)
- Circuit Board: MATRIX3 (VR031200) XN293B0
1. IC
- IC 101,103,301: NJM2068D-D (XA987A00) OP AMP
IC 104-106: NJM4580DD (XM651A00) OP AMP
IC 302: TC4052BP (XA053A00) MULTIPLEXER
IC 401: SN74HC368N (IR036850) BUS INVERTER
IC 402: SN74HC02N (IR000250) NOR
IC 403: SN74HC74N (IR007450) DFF
IC 404: HD74HC123AP (IR012310) MULTI VIBRATOR
2. Transistor
- Q 401-404: 2SC1740S R,S (IC174070)
3. Diode
- D 401: 1SS133,1SS176 (VB941200)
4. LED
- LED 101,102,402: GL2HY6 YE (VJ471200) ON A, ON B, ON
LED 401: GL2EG6 GR (VH325300) CHECK
5. Mylar Capacitor
- C 404: 0.0330 50V J (UA654330)
6. Ceramic Capacitor
- C 105,124,402: B 220P 50V K (FG612220)
C 106,125: B 470P 50V K (FG612470)
C 107,141: SL 82P 50V J (FG651820)
C 108,109,127,128,156,160, 305,306,313,314: F 0.0100 50V Z (FG644100)
C 110,129: SL 47P 50V J (FG651470)
C 111,311: SL 68P 50V J (FG651680)
C 126,130,133,134,139, 140,309,310: SL 100P 50V J (FG652100)
C 135: SL 150P 50V J (FG652150)
C 145,146,149,150,154, 155,158,159: SL 33P 50V J (FG651330)
7. Electrolytic Cap.
- C 101,104,142,148,152, 157,161: 220.00 10.0V (UJ828220)
C 102,103: 220.00 25.0V (UJ848220)
C 112,131,137,312: 47.00 16.0V (UJ837470)
C 123: 100.00 10.0V (UJ828100)
C 132,138,308,315, 316: 10.00 25.0V (UJ847100)
C 136,143: 47.00 25.0V (UJ847470)
C 144,153: 22.00 25.0V (UJ847220)
C 147,151: 100.00 25.0V (UJ848100)
C 403: 1.00 50.0V (UJ866100)
8. Semiconductive Cera. Cap.
- C 401,405-407: 0.1000 25V Z (VC694800)
9. Carbon Resistor
- R 104,141: 100.0 1/4 J (HF755100)
R 108,145,151,315: 47.0 1/4 J (HF754470)
R 109,152,159,162, 163,316: 220.0K 1/4 J (HF758220)
R 123,302: 1.0K 1/4 J (HF756100)
R 128-140,142,147, 154,329: 18.0K 1/4 J (HF757180)
R 143,144: 15.0K 1/4 J (HF757150)
R 146,148,153,155, 310,312: 220.0 1/4 J (HF755220)
R 149,150,403,404, 410,412,413: 10.0K 1/4 J (HF757100)
R 156: 20.0K 1/4 J (HF757200)
R 157,409: 10.0 1/4 J (HF754100)
R 158,323: 7.5K 1/4 J (HF75675)
R 160,161,407,408: 2.2K 1/4 J (HF756220)
R 168,174,184,190: 75.0 1/4 J (HF754750)
R 169,175,185,191, 311,405,406: 100.0K 1/4 J (HF758100)
R 204: 560.0 1/4 J (HF755560)
R 205: 62.0 1/4 J (HF75462)
R 304,307: Jumper wire
R 317,319,401,402: 4.7K 1/4 J (HF756470)
R 318,320: 5.6K 1/4 J (HF756560)
R 321: 8.2K 1/4 J (HF756820)
R 324-326: 3.0K 1/4 J (HF75630)
R 327: 12.0K 1/4 J (HF757120)
R 328: 30.0K 1/4 J (HF757300)
R 411: 680.0K 1/4 J (HF75868)
10. Flame Proof Carbon Resistor
- R 176-179: 10.0 1/4 J (HV754100)
11. Metal Film Resistor
- R 101-103,116,118,120,122,124-127, 165,173,181,188: 18.0K 1/4 F (VB067900)
R 105: 24.0K 1/4 F (VB068200)
R 106: 15.0K 1/4 F (VA074600)
R 107: 16.0K 1/4 F (VB067800)
R 164,166,170,180, 183,187,314: 10.0K 1/4 F (VA074400)
R 167,171,182,186: 20.0K 1/4 F (VB068000)
R 172,189: 11.0K 1/4 F (VA074500)
R 313: 4.3K 1/4 F (VB067000)
12. Rotary Variable Resistor
- VR 101-115: A20K (VQ901000) SUB R,L, ST R,L, MONO, GROUP1-8, LEVEL A,B A20K+C20K (VQ900500) PAN
- VR 302
13. Push Switch
- SW101: SPUN (VA983800) MATRIX CUE
SW102,103,303, 304: SPUN19-2N-W (VQ901900) ON A, ON B, TO ST, TO MON
SW302: SPUN19-2N-W (VR633200) CUE
SW401: EVQ PB (VQ902900) ON/EDIT
14. Pin Header
- SW104,106,107: 9202 2P-4 TE (VR702100)
15. Short Connector
- : 9206H-T 2P (VR984700) for SW104,106,107
16. Relay
- RY 401: DC RY12W (KC001900)
17. Phone Jack
- JK 104: Stereo HLJ2335 (LB606940) MTX B/GRP
18. Cannon Connector
- JK 101,102: XLM-3-32PCH-L (VP953100) MATRIX A, GROUP, AUX
19. Connector
- CN 101,102: HIF3BAG40PA2.54 (VR633100)
CN 103,104: FJ-P 14P (VL549000)
CN 105: PH- 2P SE (VB858100)
CN 301,302: FJ-R 14P (VQ966000)
CN 303: PH- 3P SE (VB858200)
CN 304: PH- 9P SE (VB858800)
20. Push Button
- : RE/S.GY (VR281500) TO ST
: Y.BR/S.GY (VR637000) SO MONO
: S.GY/Y.BR (VR637100) MATRIX CUE, CUE
21. Knob
- : S.GY/RE (VR667400) ON A, ON B



*5 MATRIX to METER 1A/2A/3A/4A select switch

■ ST CIRCUIT BOARD

Notes)

Circuit Board: ST (VR031400) XN294B0

1. IC

IC101: BA4558-NK (XF128A00) OP AMP
IC102-106: NJM2068D-D (XA987A00) OP AMP
IC107,108: NJM4580DD (XM651A00) OP AMP
IC301: SN74HC74N (IR007450) DFF
IC302: SN74HC02N (IR000250) NOR
IC303: SN74HC368N (IR036850) BUS INVERTER
IC304: HD74HC123AP (IR012310) MULTI VIBRATOR

2. Transistor

Q 101: 2SA933S Q,R (IA093320)
Q 301-304: 2SC1740S R,S (IC174070)

3. Diode

D 101-103,301: 1SS133,1SS176 (VB941200)

4. LED

LED 101,102,302: GL2HY6 YE (VJ471200) TB ON, OSC ON, ON
LED 301: GL2EG6 GR (VH325300) CHECK

5. Mylar Capacitor

C 115,123: 2700P 50V J (UA353270)
C 116,117: 1000P 50V J (UA353100)
C 120: 7500P 50V J (UA353750)
C 121: 6200P 50V J (UA353620)
C 122: 0.0180 50V J (UA654180)
C 128: 0.0470 50V J (UA654470)
C 305: 0.0330 50V J (UA654330)

6. Ceramic Capacitor

C 103: B 1500P 50V K (FG613150)
C 104: B 330P 50V K (FG612330)
C 105,113,207,213, 233,240: SL 68P 50V J (FG651680)
C 107-109,118,119,126, 127,205,206,214-216, 225,226,231,232,236, 249,250: F 0.0100 50V Z (FG644100)
C 111,112,211,212,238, 239: SL 100P 50V J (FG652100)
C 124,125,208,234: SL 47P 50V J (FG651470)
C 202,228,308: B 220P 50V K (FG612220)
C 203,229: B 470P 50V K (FG612470)
C 204,230: SL 82P 50V J (FG651820)
C 219-222,243-246: SL 33P 50V J (FG651330)

7. Electrolytic Cap.

C 101,106,110,132, 210,237: 10.00 25.0V (UJ847100)
C 102: 100.00 10.0V (UJ828100)
C 114,209,217,235, 241: 47.00 16.0V (UJ837470)
C 129,130: 220.00 25.0V (UJ848220)
C 131,201,223,224,227, 247,248,247,248: 220.00 10.0V (UJ828220)
C 218,242: 22.00 25.0V (UJ847220)
C 251,252: 100.00 25.0V (UJ848100)
C 307: 1.00 50.0V (UJ866100)

8. Semiconductive Cera. Cap.

C 301-304: 0.1000 25V Z (VC694800)

9. Carbon Resistor

R 101,102: 22.0K 1/4 J (HF757220)
R 103,104,202,231: 100.0 1/4 J (HF755100)
R 105: 150.0 1/4 J (HF755150)
R 106: 24.0K 1/4 J (HF75724)
R 107,115,128: 47.0 1/4 J (HF754470)
R 108,116,129,206,214,215, 235,243,244: 220.0K 1/4 J (HF758220)
R 109,130: 1.6K 1/4 J (HF756160)
R 110,111,208,209, 237,238: 220.0 1/4 J (HF755220)
R 112: 18.0K 1/4 J (HF757180)
R 113: 3.3K 1/4 J (HF756330)
R 114,306,307, 309-311: 10.0K 1/4 J (HF757100)
R 117,118,226,227, 255,256,303,304: 100.0K 1/4 J (HF758100)
R 119: 51.0K 1/4 J (HF75751)
R 120: 2.2M 1/4 J (HF759220)
R 121: 2.2K 1/4 J (HF756220)
R 122: 1.8K 1/4 J (HF756180)
R 123-126: 15.0K 1/4 J (HF757150)
R 127,228,257,265: 1.0K 1/4 J (HF756100)
R 148,149,301,302: 4.7K 1/4 J (HF756470)
R 205,213,234,242, 312: 10.0 1/4 J (HF754100)
R 207,236: 580.0 1/4 J (HF755560)
R 210,239: 47.0K 1/4 J (HF757470)
R 224,225,253,254: 75.0 1/4 J (HF754750)
R 229,258: 2.0K 1/4 J (HF75620)
R 268,269: 270.0 1/4 J (HF75527)

R 305,308: 2.4K 1/4 J (HF756240)
R 313: 680.0K 1/4 J (HF75868)

10. Flame Proof Carbon Resistor

R 266,267: 10.0 1/4 J (HV754100)

11. Metal Film Resistor

R 131-140,201,230: 24.0K 1/4 F (VB068200)
R 141,219,220,248,249, 259-264: 18.0K 1/4 F (VB067900)
R 142-147: 36.0K 1/4 F (VB068500)
R 203,232: 15.0K 1/4 F (VA074600)
R 204,233: 16.0K 1/4 F (VB067800)
R 211,240: 4.3K 1/4 F (VB067000)
R 212,216-218,241, 245-247: 10.0K 1/4 F (VA074400)
R 221,222,250,251: 20.0K 1/4 F (VB068000)
R 223,252: 11.0K 1/4 F (VA074500)

12. Rotary Variable Resistor

VR 101: A20K (VQ901000) TB LEVEL
VR 102: A20K+C20K (VQ900500) BAL

13. Push Switch

SW101: SPUN90 2/2*9 (VQ902300) ASSIGN switch
SW102-104: SPUN19-2N-W (VQ901900) OSC ON(1kHz), TB ON, TO MONO
SW105: SPUN (VA983800) CUE
SW106: EVQ PB (VQ902900) ON/EDIT

14. Relay

RY 101: DC RY5W-K (VL369700)
RY 301: DC RY12W (KC001900)

15. Pin Connector

JK 104: YKC21-3045 (VM725600) REC OUT L/R

16. Phone Jack

JK 105: Stereo HLJ2335 (LB606940) ST INSERT I/O L/R

17. Cannon Connector

JK 101: XLM-3-31PCH-L (VM851800) TB INPUT
JK 102,103: XLM-3-32PCH-L (VP953100) ST L, ST R

18. Connector

CN 101,102: HIF3BAG40PA2.54 (VR633100)
CN 103: PH- 9P SE (VB858800)
CN 104: PH- 8P SE (VB858700)
CN 105: SAN&PH 8P 200L (VP91350)
CN 106,107: PH- 3P SE (VB858200)


19. Push Button

: M.GY/S.GY (VR034000) ASSIGN
: BE/S.GY (VR281400) AUX 1-2, 3-4, 5-6
: RE/S.GY (VR281500) ST
: Y.BR/S.GY (VR637000) MONO, TO MONO
: S.GY/Y.BR (VR637100) CUE

20. Knob


: S.GY/RE (VR667400) OSC ON, TB ON

● ST 1/2 Circuit Board





*7 Send to MATRIX pre-/post-faders (See BLOCK DIAGRAM section)

● ST 2/2 Circuit Board




Component side (部品側)

● LED installing (LEDの取付け)



*6 Send to MONO & MATRIX pre-/post-on · off switch (See BLOCK DIAGRAM section)



Component side (部品側) ■ ST CIRCUIT BOARD



Notes
 Marked (F): Metal film resistor
 Marked (7): Flame proof carbon resistor
 Marked (t): Ceramic capacitor
 Marked (半t): Semi conductive ceramic capacitor
 VR103 and VR104 are not parts of the ST circuit board.
 Marked (O): Nominal level

*1 ST to MONO/MATRIX [pre ON sw./post ON sw.] Jumper : factory set = pre ON sw.
 *2 ST to MATRIX [pre ST L/R Fader/post ST L/R Fader] Jumper : factory set = post ST L/R Fader

MONO CIRCUIT BOARD



Notes

- Circuit Board: MONO (VR031500) XN295B0
1. IC
- IC101-104,106,107, 109: NJM2068D-D (XA987A00) OP AMP
- IC105,108: NJM4580DD (XM651A00) OP AMP
- IC201: NJM4556DD (XE803A00) OP AMP
- IC301: SN74HC74N (IR007450) DFF
- IC302: SN74HC02N (IR000250) NOR
- IC303: SN74HC368N (IR036850) BUS INVERTER
- IC304: HD74HC123AP (IR012310) MULTI VIBRATOR
2. Transistor
- Q 101,103: 2SA933S Q,R (IA093320)
- Q 102: 2SA777 Q,R (IA077730)
- Q 301-304: 2SC1740S R,S (IC174070)
3. Diode
- D 101-107,301: 1SS133,1SS176 (VB941200)
4. LED
- LED 101,102,302: GL2HY6 YE (VJ471200) MONITOR ON, INPUT CUE, CUE
- LED 103,301: GL2EG6 GR (VH325300) MASTER CUE, CHECK
5. Mylar Capacitor
- C 146,154: 0.1000 50V J (UA355100)
- C 305: 0.0330 50V J (UA654330)
6. Ceramic Capacitor
- C 105,112,117,124,129, 138,161,306: B 220P 50V K (FG612220)
- C 106,113,118,125,130, 139,148,149,156,157, 162,171,172,202,203, 209,210: SL 100P 50V J (FG652100)
- C 107,114,119,126,135, 144,150,158,167,173, 189,190,204,211: SL 68P 50V J (FG651680)
- C 108,109,120,121,132, 133,141,142,164,165, 170,174,175,193,194, 215: F 0.0100 50V Z (FG644100)
- C 131,140,163: B 470P 50V K (FG612470)
- C 134,143,166,188, 191: SL 47P 50V J (FG651470)
- C 178,180,183,184: SL 33P 50V J (FG651330)
- C 213,214: B 1000P 50V K (FG613100)
7. Electrolytic Cap.
- C 101,102,205,206: 220.00 25.0V (UJ848220)
- C 103,128,137,153,159,160, 181,185,207,212: 220.00 10.0V (UJ828220)
- C 104,111,116,123,147, 155,169,186,195-197, 201,208: 10.00 25.0V (UJ847100)

- C 110,115,122,127,177, 187: 22.00 25.0V (UJ847220)
- C 136,145,168,176, 192: 47.00 16.0V (UJ837470)
- C 151,152,179,182: 47.00 25.0V (UJ847470)
- C 307: 1.00 50.0V (UJ866100)
8. Semiconductive Cera. Cap.
- C 301-304: 0.1000 25V Z (VC694800)
9. Carbon Resistor
- R 101,103,109,111,117, 119,125,127: 22.0K 1/4 J (HF757220)
- R 102,104,110,112,118, 120,126,128,145,147, 152,154,177,179,201, 203,210,212: 220.0 1/4 J (HF755220)
- R 105,113,121,129: 4.3K 1/4 J (HF75643)
- R 106,114,122,130,148, 156,165,166,205,214, 306,307,309-311: 10.0K 1/4 J (HF757100)
- R 107,115,123,131,137, 143,175,182,233: 47.0 1/4 J (HF754470)
- R 108,116,124,132,138,144,176, 183,184,229,234: 220.0K 1/4 J (HF758220)
- R 134,140,172: 100.0 1/4 J (HF755100)
- R 146,153,202,211, 230: 18.0K 1/4 J (HF757180)
- R 149,155: 3.9K 1/4 J (HF756390)
- R 150,157,189,194: 75.0 1/4 J (HF754750)
- R 151,158,190,195, 209,216,303,304: 100.0K 1/4 J (HF758100)
- R 159,162,167: 1.6K 1/4 J (HF756160)
- R 160,161,163,164,204, 213,301,302: 4.7K 1/4 J (HF756470)
- R 168: 2.2K 1/4 J (HF756220)
- R 169: 5.6K 1/4 J (HF756560)
- R 170: 560.0 1/4 J (HF755560)
- R 178: 47.0K 1/4 J (HF757470)
- R 200: 1.0K 1/4 J (HF756100)
- R 217-222: 270.0 1/4 J (HF75527)
- R 227,228: 24.0K 1/4 J (HF75724)
- R 231: 16.0K 1/4 J (HF757160)
- R 232: 15.0K 1/4 J (HF757150)
- R 305,308: 2.4K 1/4 J (HF756240)
- R 312: 10.0 1/4 J (HF754100)
- R 313: 680.0K 1/4 J (HF75868)
10. Flame Proof Carbon Resistor
- R 206,207,223-226: 10.0 1/4 J (HV754100)


11. Metal Film Resistor
- R 133,139,171,187, 193,196-199: 18.0K 1/4 F (VB067900)
- R 135,136,141,142, 173,174: 15.0K 1/4 F (VA074600)
- R 180: 4.3K 1/4 F (VB067000)
- R 181,185,186,235: 10.0K 1/4 F (VA074400)
- R 188,192: 20.0K 1/4 F (VB068000)
- R 191: 11.0K 1/4 F (VA074500)
12. Metal Oxide Film Resistor
- R 208,215: 100.0 1W J (VC731200)
13. Rotary Variable Resistor
- VR 102,103: A20Kx2 (VQ901400) MONITOR LEVEL, PHONES
14. LC Filter
- : LS MT X222MB (FZ007070)
15. Relay
- RY 101-103: DC RY5W-K (VL369700)
- RY 301: DC RY12W (KC001900)
16. Push Switch
- SW101: SPUN30*3(VQ902400) GROUP/MATRIX/AUX METER SELECT
- SW102,108: SPUN19-2N-W (VQ901900) ST HOLD, CUE
- SW103: SPUN20 2/2*2 (VQ902500) 2TR IN1/IN2
- SW104,105: SPUN (VA983800) MASTER PFL, MONITOR ON
- SW106: SPUN19-2N-W (VR633200) L+R
- SW107: EVQ PB (VQ902900) ON/EDIT
17. Pin Connector
- JK 101: YKC21-3088 4P (VR312000) 2TR IN L/R
18. Phone Jack
- JK 102,106: HLJ0520 (LB202600) MONITOR OUT L,R
- JK 103: Stereo HLJ2305 (LB202700) MONO I/O
- JK 105: HLJ1520 (LB202300) PHONES
19. Cannon Connector
- JK 104: XLM-3-32PCH-L (VP953100) MONO OUT
20. Connector
- CN 101,102: HIF3BAG40PA2.54 (VR633100)
- CN 103,108: FJ-P 8P (VL548500)
- CN 104,109: FJ-R 8P (VK217100)
- CN 105,107: PH- 3P SE (VB858200)
- CN 106: PH- 9P SE (VB858800)
21. Push Button
- : M.GY/S.GY (VR034000) GROUP, MATRIX, AUX, ST HOLD, 2TR IN 1,2, MASTER PFL, L+R
- : S.GY/Y.BR (VR637100) CUE
22. Knob
- : S.GY/RE (VR667400) MONITOR ON

3NA-VR03150

MONO CIRCUIT BOARD

M2000 CIRCUIT DIAGRAM (MONO 1/2, MONO 2/2)

M2000/PW2000M



Notes

Marked (7): Flame proof carbon resistor
Marked (F): Metal film resistor
Marked 1P: Metal oxide film resistor

Marked (t): Ceramic capacitor

Marked (t): Semiconductive ceramic capacitor
VR101 is not a part of the MONO circuit board.
Marked O: Nominal level

*1 MONO to MATRIX [pre ON sw./post ON sw.]

Jumper: factory set = pre ON sw.

*2 MONO to MATRIX [pre MONO Fader/post MONO Fader]

Jumper: factory set = post MONO fader

M2000 CIRCUIT DIAGRAM (MONO 1/2, MONO 2/2) C15

M2000/PW2000M

■ MIDI CIRCUIT BOARD (1/4, 2/4)

Notes)

Circuit Board:	MIDI1/4 (NX813790) XN290B0
Circuit Board:	MIDI2/4 (NX813800) XN290B0
Circuit Board:	MIDI3/4 (NX813810) XN290B0
Circuit Board:	MIDI4/4 (NX813820) XN290B0

1. IC

IC 201, 401-404:	TC74HC241AP (IR024100) BUS BUFFER
IC 202, 307, 405-408:	SN74HC138N (IR013850) DECODER
IC 203, 409:	SN74HC368N (IR036850) BUS INVERTER
IC 301:	HD63B03YP-N (XD245A00) CPU
IC 302:	M27C256B-12F1 (XP180A00) ROM 256K
IC 303, 309-311:	SN74HC541N (IR054150) BUS DRIVER
IC 304:	HY6264ALP-10 (XK761A00) SRAM 64K
IC 305:	SN74HC139N (IR013950) DECODER
IC 308:	M66008P (XM266A00) 16BIT, EXP
IC 312:	SN74HC273N (IR027350) DFF
IC 314:	SN74HC14N (IR001450) INVERTER
IC 315:	NJM2903 (IG031000) COMPARATOR
IC 316:	M5238AP (XM085A00) OP AMP
IC 317:	SN74HC02N (IR000250) NOR
IC 318:	SN74HC32N (IR003250) OR
IC 319:	SN74HC04N (IR000450) INVERTER
IC 320:	M62021L (XH970A00) RESET

2. Transistor

Q 301-306:	2SC1740S R,S (IC174070)
------------	-------------------------

3. Transistor Array

IC 313:	TD62506P (IG138700)
---------	---------------------

4. Diode

D 101-106, 301-312:	1SS133, 1SS176 (VB941200)
---------------------	---------------------------

5. LED

LED 301-308:	GL5HY40 YE (VP155700) DIRECT RECALL 1-8
--------------	--

6. LED Display

LD 101:	LB-203VL (VR266400) MEMORY
---------	----------------------------

7. Photo Coupler

PC 301:	6N137 (VD473200)
---------	------------------

8. Mylar Capacitor

C 314:	0.0100 50V J (UA654100)
--------	-------------------------

9. Ceramic Capacitor

C 311, 312:	27P 50V J (VK66320)
-------------	---------------------

10. Electrolytic Cap.

C 303:	1000 10.0V (UJ829100)
C 307:	10.00 35.0V (UJ857100)

11. Semiconductive Cera. Cap.

C 201-203, 301, 302, 304-306, 309, 310, 313, 315-326, 401-409:	0.1000 25V Z (VC694800)
--	-------------------------

12. Carbon Resistor

FL 301-322:	0.0 J (VQ252700)
R 201:	200.0K 1/4 J (HF75820)
R 301, 312-316:	1.0K 1/4 J (HF756100)
R 302, 303:	3.3K 1/4 J (HF756330)
R 304, 305:	1.0M 1/4 J (HF759100)
R 306, 307, 325:	10.0K 1/4 J (HF757100)
R 311, 326:	4.7M 1/4 J (HF75947)
R 317:	2.7K 1/4 J (HF756270)
R 318-324:	30.0 1/4 J (HF75430)
R 401:	51.0K 1/4 J (HF75751)

13. Metal Film Resistor

R 308:	2.4K 1/4 F (VB066400)
R 309:	1.5K 1/4 F (VB065900)
R 310:	910.0 1/4 F (VB065000)

14. Resistor Array

RA 301-303, 305-309:	RGLD8X103J (VE445200)
RA 304:	RGLD4X103J (VE443500)

15. LC Filter

EM 301:	LS MT Y223NB (FZ006970)
---------	-------------------------

16. Ceramic Resonator

CL 301:	8M CSA8.00MTZ (QU008500)
---------	--------------------------


17. Push Switch

SW101:	SKHQFM ORANGE (VK701000) UTILITY
SW102, 103, 105, 106:	SKHQAC (VK700800) RECALL, STORE, SCENE MEMORY ▲, ▼
SW104:	SKHQFN GREEN (VK701100) CHECK
SPUJ 2/2*8 SW301:	SPUJ 2/2*8 (VR266500) DIRECT RECALL 1-8


18. Connector

CN 101, 102:	SAN&PH 9P 60L (VN37520)
CN 201:	PHD-20P TE (VR264100)
CN 202, 401-407:	PHD-18P SE (VR262300)
CN 203:	PH- 2P TE (VB389800)
CN 301:	SAN&PH 11P 250L (VR66920)
CN 302, 303:	PH- 9P TE (VB390500)
CN 304:	PHD-20P SE (VR264200)
CN 305, 409, 410:	PH-10P TE (VB390600)
CN 306:	PH- 5P TE (VB390100)
CN 408:	PH- 4P TE (VB390000)


• LED display installing (LED ディスプレイの取付け)




• LED installing (LEDの取付け)




• MIDI 2/4 Circuit Board



• MIDI 1/4 Circuit Board



■ MIDI CIRCUIT BOARD (1/4, 2/4)



■ MIDI CIRCUIT BOARD (3/4, 4/4)

Notes)

Circuit Board:	MIDI1/4 (NX813790) XN290B0
Circuit Board:	MIDI2/4 (NX813800) XN290B0
Circuit Board:	MIDI3/4 (NX813810) XN290B0
Circuit Board:	MIDI4/4 (NX813820) XN290B0

1. IC	
IC201,401-404:	TC74HC241AP (IR024100) BUS BUFFER
IC202,307,405-408:	SN74HC138N (IR013850) DECODER
IC203,409:	SN74HC368N (IR036850) BUS INVERTER
IC301:	HD63B03YP-N (XD245A00) CPU
IC302:	M27C256B-12F1 (XP180A00) ROM 256K
IC303,309-311:	SN74HC541N (IR054150) BUS DRIVER
IC304:	HY6264ALP-10 (XK761A00) SRAM 64K
IC305:	SN74HC139N (IR013950) DECODER
IC308:	M66008P (XM266A00) 16BIT, EXP
IC312:	SN74HC273N (IR027350) DFF
IC314:	SN74HC14N (IR001450) INVERTER
IC315:	NUM2903 (IG031000) COMPARATOR
IC316:	M5238AP (XM085A00) OP AMP
IC317:	SN74HC02N (IR000250) NOR
IC318:	SN74HC32N (IR003250) OR
IC319:	SN74HC04N (IR000450) INVERTER
IC320:	M62021L (XH970A00) RESET

2. Transistor	
Q 301-306:	2SC1740S R,S (IC174070)
3. Transistor Array	
IC313:	TD62506P (IG138700)
4. Diode	
D 101-106,301-312:	1SS133,1SS176 (VB941200)
5. LED	
LED 301-308:	GL5HY40 YE (VP155700) DIRECT RECALL 1-8

6. LED Display	
LD 101:	LB-203VL (VR266400) MEMORY

7. Photo Coupler	
PC 301:	6N137 (VD473200)

8. Mylar Capacitor	
C 314:	0.0100 50V J (UA654100)

9. Ceramic Capacitor	
C 311,312:	27P 50V J (VK66320)

10. Electrolytic Cap.	
C 303:	1000 10.0V (UJ829100)
C 307:	10.00 35.0V (UJ857100)

11. Semiconductive Cera. Cap.	
C 201-203,301,302,304-306, 309,310,313,315-326, 401-409:	0.1000 25V Z (VC694800)


12. Carbon Resistor	
FL 301-322:	0.0 J (VQ252700)
R 201:	200.0K 1/4 J (HF75820)
R 301,312-316:	1.0K 1/4 J (HF756100)
R 302,303:	3.3K 1/4 J (HF756330)
R 304,305:	1.0M 1/4 J (HF759100)
R 306,307,325:	10.0K 1/4 J (HF757100)
R 311,326:	4.7M 1/4 J (HF75947)
R 317:	2.7K 1/4 J (HF756270)
R 318-324:	30.0 1/4 J (HF75430)
R 401:	51.0K 1/4 J (HF75751)
13. Metal Film Resistor	
R 308:	2.4K 1/4 F (VB066400)
R 309:	1.5K 1/4 F (VB065900)
R 310:	910.0 1/4 F (VB065000)

14. Resistor Array	
RA 301-303, 305-309:	RGLD8X103J (VE445200)
RA 304:	RGLD4X103J (VE443500)

15. LC Filter	
EM 301:	LS MT Y223NB (FZ006970)


16. Ceramic Resonator	
CL 301:	8M CSA8.00MTZ (QU008500)
17. Push Switch	
SW101:	SKHQFM ORANGE (VK701000) UTILITY
SW102,103,105, 106:	SKHQAC (VK700800) RECALL, STORE, SCENE MEMEMORY ▲,▼
SW104:	SKHQFN GREEN (VK701100) CHECK
SW301:	SPUJ 2/2*8 (VR266500) DIRECT RECALL 1-8

18. Connector	
CN 101,102:	SAN&PH 9P 60L (VN37520)
CN 201:	PHD-20P TE (VR264100)
CN 202,401-407:	PHD-18P SE (VR262300)
CN 203:	PH-2P TE (VB389800)
CN 301:	SAN&PH 11P 250L (VR66920)
CN 302,303:	PH-9P TE (VB390500)
CN 304:	PHD-20P SE (VR264200)
CN 305,409,410:	PH-10P TE (VB390600)
CN 306:	PH-5P TE (VB390100)
CN 408:	PH-4P TE (VB390000)




- The MIDI 3/4 circuit board is located on the front-side of the ST CHANNEL module. But, it is not a part of the module.
- The MIDI 4/4 circuit board is located on the front-side of the MASTER module. But, it is not a part of the module.
- MIDI3/4シートは、STCHANNELモジュール前部に取付けられていますが、モジュールの構成部品ではありません。
- MIDI4/4シートは、MASTERモジュール前部に取付けられています が、モジュールの構成部品ではありません。

● MIDI 3/4 Circuit Board




Component side (部品側)

● MIDI 4/4 Circuit Board




M2000 CIRCUIT DIAGRAM (MIDI 3/4, MIDI 4/4)

M2000/PW2000M



Notes
Marked (#): Semiconductive ceramic capacitor



M2000 CIRCUIT DIAGRAM C19


(MIDI 3/4, MIDI 4/4)

M2000/PW2000M


■ DISTRI & PS CIRCUIT BOARDS

- Notes)
- Circuit Board: DISTRI1/2 (NX813770) XN298B0
Circuit Board: DISTRI2/2 (NX813780) XN298B0
1. IC
IC101: TC74HC241AP (IR024100) BUS BUFFER
IC201: SN74HC138N (IR013850) DECODER
2. Semiconductive Cera. Cap.
C 101,201: 0.1000 25V Z (VC694800)
3. Carbon Resistor
R 101: 200.0K 1/4 J (HF75820)
4. Connector
CN 101: PHD-20P TE (VR264100)
CN 102: PH-11P SE (VB389600)
CN 103: PH-2P TE (VB389800)
CN 201: SAN&PH 11P 60L (VR66560)
CN 202-205: B09P-MQ (VB994900)


● DISTRI 1/2 Circuit Board




● DISTRI 2/2 Circuit Board




- Notes)
- Circuit Board: PS (VR030500) XN291A0
1. IC
IC101: NJM78M09FA (XJ141A00) REGULATOR +9V
IC102: NJM7805FA (XJ607A00) REGULATOR +5V
2. Transistor
Q 101,105,106: 2SC1740S R,S (IC174070)
Q 102: 2SA933S Q,R (IA093320)
3. Pair Transistor
Q 103,104: C4793/A1837 (VQ547400)
4. Diode
D 101-103: 1SS133,1SS176 (VB941200)
5. Mylar Capacitor
C 109-112: 0.1000 50V J (UA355100)
6. Ceramic Capacitor
C 113,114: 270P 50V K (FG612270)
7. Electrolytic Cap.
C 101,102: 1000.0 25.0 RS (VR641000)
C 103: 1000 16.0V (VF277000)
C 104: 100.00 63.0V (UJ878100)
C 105,107: 220.00 16.0V (UJ838220)
C 106,108: 220.00 10.0V (UJ828220)
8. Semiconductive Cera. Cap.
C 115: 0.1000 25V Z (VC694800)
9. Carbon Resistor
R 101: 47.0K 1/4 J (HF757470)
R 102,103: 5.6K 1/4 J (HF756560)
R 104-108: 220.0 1/4 J (HF755220)
R 109,110: 3.3K 1/4 J (HF756330)
R 111,112: 1.0K 1/4 J (HF756100)
10. Metal Oxide Film Resistor
R 113,114: 68.0 2W J (VC758300)
11. LC Filter
EM 101,102: LS MT Y223NB (FZ006970)
EM 103-109: LS MT B271KB 270P (FZ006920)
12. DIN Connector
JK 101: DINx3 YKF51-504 (VI466400) MIDI IN/OUT/THRU
13. Connector
CN 101: HIF3BAG40PA2.54 (VR633100)
CN 102: VH-8P SE (LB933080)
CN 103: PH-11P TE (VB390700)
CN 104,105: PH-2P SE (VB858100)
CN 106: METER PS (VR30580)
CN 107: SAN&PH 6P 250L (VM76060)




DISTRI 1/2



DISTR 2/2



PS



Notes)
Marked 2P: Metal oxide film resistor
C101, C102 and C103 are electrolytic capacitor-RS

DC CIRCUIT BOARD (PW2000M)

Notes

- Circuit Board: DC (VR658000) J (XN889B0)
DC (VR658100) U,C,V (XN889B0)
DC (VR658200) H,B,W (XN889B0)
1. IC
IC 201: NJM7812FA (XJ608A00) REGULATOR +12V
IC 202: NJM7912FA (XC721A00) REGULATOR -12V
IC 203,204,301,302,401: NJM072D (IG107000) OP AMP
IC 205: NJM7809FA (XD706A00) REGULATOR +9V
2. Transistor
Q101,103: 2SC2021 Q,R,S (IC202180)
Q102: 2SA937 Q,R,S (IA093700)
Q201,202,301,302: 2SC1815 Y,GR (IC1815M0)
Q203,207,208,304,307,308: 2SD438-MP E,F (ID043810)
Q204,303,407: 2SD526 O,Y (ID052630)
Q205,206,305,306,402: 2SC3182N R,O (VF163900)
Q209,213,214: 2SB560V16MP E,F (IB056010)
Q210: 2SB596 O,Y (IB059630)
Q211,212: 2SA1265N R,O (VF163700)
Q401,404: 2SC3421 O,Y (VC211000)
Q403,405,406: 2SC2240 GR,BL (IC224030)
3. Diode
D101-103,207,209,307,402: 1SR35-100A 52 (VE170000)
D202-206,208,302-306: 1SS133,1SS176 (VB941200)
4. Diode Stack
D201,301: GBPC2504 (VM622000)
D401: SIWB(A)60 (VB845300)
5. Zener Diode
ZD101,102: MTZJ20C 20.0V (VQ556800)
ZD103,201: MTZJ15C 15.0V (VQ556100)
ZD301: MTZJ10C 10.0V (VQ555000)
ZD401: MTZJ33D 33.0V (VQ558700)
ZD402: MTZJ27D 27.0V (VQ558000)
ZD403,404: MTZJ5.6C 5.6V (VQ272500)
ZD405,406: MTZJ24B 24.0V (VQ557500)
6. LED
LED101-105: GL2EG6 (VH325300) POWER,+17,-17,+12,+48
7. Mylar Capacitor
C201-204,301-304: 0.0100 630V M (FZ000650)
C219,223,316,408: 1000P 50V J (JA353100)
8. Monolithic Mylar Capacitor
C306: 0.10 50V J (VE326000)
9. Ceramic Capacitor
C212,213,220,221,308,309,317,318,320,412: F 0.0100 50V Z (FG644100)
C401-404,407: E 0.0047 500V M (FH223470)
10. Electrolytic Cap.
C103: 1000 16.0V (UJ739100)
C205,206: 33000 35.0V (VI486600)
C207,208,214: 47.00 35.0V (UJ857470)
C209,210,322: 47.00 16.0V (UJ837470)
C211,307: 10.00 16.0V (UJ837100)
C215,216: 100.00 35.0V (UJ858100)
C217,218,409: 10.00 35.0V (UJ857100)
C222,225,319: 470.00 25.0V (UJ748470)
C224: 22.00 16.0V (UJ837220)
C305: 47000 25.0V (VR609200)
C310,312,321: 47.00 25.0V (UJ847470)
C311: 100.00 25.0V (UJ848100)
C314,315: 10.00 25.0V (UJ847100)
C405: 2200 80V (VA274100)
C410: 220.00 63.0V (UJ778220)
C411: 4.7 100.0V (UJ896470)
11. Capacitor
C101,102: 2200P 400V (FI383220)
C104: 0.220 250V (FR203220)
C105,106: 4700P 400V (FI383470) H,B,W

12. Carbon Resistor

- R101-103,106,107,210,211,224,225,310,311,416: 1.0K 1/4 J (HF756100)
R104,108,112,202,216,230: 3.3K 1/4 J (HF756330)
R105,109,113,201,206,207,301,306,307,410,414: 10.0K 1/4 J (HF757100)
R110,111: 750.0 1/4 J (HF75575)
R114-116,220,234,320,409,413: 2.2K 1/4 J (HF756220)
R203: 18.0K 1/4 J (HF757180)
R204,305: 2.4K 1/4 J (HF756240)
R205: 3.6K 1/4 J (HF75636)
R217,231,317,406: 100.0K 1/4 J (HF758100)
R219,233,235,319,408: 4.7K 1/4 J (HF756470)
R302: 82.0 1/4 J (HF75482)
R303: 20.0K 1/4 J (HF757200)
R304,418: 3.0K 1/4 J (HF75630)
R316,405,411,412: 5.6K 1/4 J (HF756560)
R323,415: 10.0 1/4 J (HF754100)
R401,402: 2.7K 1/4 J (HF756270)
R417: 22.0K 1/4 J (HF757220)

13. Flame Proof Carbon Resistor

- R218,232,318: 22.0 1/4 J (HV754220)

14. Metal Film Resistor

- R208,221: 12.0K 1/4 F (VB067600)
R209,222,309,322: 4.7K 1/4 F (VA074100)
R223,236: 15.0K 1/4 F (VA074600)
R308,321: 6.8K 1/4 F (VB067300)

15. Metal Oxide Film Resistor

- R403: 330.0 1W J (VC746200)
R404: 2.2 1W J (VC740900)
R407: 3.3K 1W J (VC748800)

16. Wire Wound Resistor

- R212,213,226,227,312,313: 0.22 5W K (HM052220)
R214,215,228,229,314,315: 0.47 5W K (HM052470)

17. Fuse Resistor

- FR201,202,301: FN11150J 15 1W (HW914150)

18. Trimmer Potentiometer

- VR201,301: B10.0K (VA024800) +17V adj, +12V adj.

19. Coil

- L101: SC-05-100 1.0mH (GE901370)

20. Push Switch

- SW101: ESB-8236V (VF576000) POWER switch

21. Relay

- RY101: G4W1112TP-USTV8 (VJ102400)


22. Fuse

- F201,301: T 6.00A 250V (KB001280) J
T 6.00A 250V (KB001250) U,C,V
TR2.00A (KB003070) H,B,W
T 2.00A 250V (KB003570) J,U,C,V
TR6.30A (KB003250) H,B,W


23. Connector

- CN101: VH-3P TE (LB932030)
CN102: VH-6P TE (LB932060)
CN103: PH-2P TE (VB389800)
PW DI (VR67170)
CN: PW DD (VR67190)


Power transistor installing (パワートランジスタの取付け)




D201, D301 installing




LED installing (LEDの取付け)




Heat sink (ヒートシンクの取付け)





DC 1/3



DC 3/3




DC 2/3



■ PW2000M OVERALL CIRCUIT DIAGRA

M2000/PW2000M

※ Japanese model



※ European model

※ U.S. and Canadian models

Notes)

Marked (7): Flame proof carbon resistor 1/4

Marked (F): Metal film resistor (±1%)

Marked 1W: Metal oxide film resistor

Marked 5W: Wire wound resistor

Marked (t): Ceramic capacitor

C306: Monolithic mylar capacitor

■ WARNING

Components having special characteristics are marked ⚠ and must be replaced with parts having specifications equal to those originally installed.

⚠印の部品は、安全を維持するために重要な部品です。交換をする場合は、安全のため必ず指定の部品をご使用下さい。


	T101	T102	F101	F201	F202	F301	F401
J	XNB21A0	XA237B0	6A 250V	6A 250V	6A 250V	6A 250V	2A 250V
U.C	XNB22A0	XA238C0	6A 250V	6A 250V	6A 250V	6A 250V	2A 250V
H.B	XNB23A0	XA239B0	T3. 15AL 250V	T6. 3AL 250V	T6. 3AL 250V	T6. 3AL 250V	T2AL 250V

JK & BNC CIRCUIT BOARDS

Notes)


- Circuit Board: JK1/5 (NX813720) XN297A0
- Circuit Board: JK2/5 (NX813730) XN297A0
- Circuit Board: BNC3/5 (NX813740) XN297A0
- Circuit Board: BNC4/5 (NX813750) XN297A0
- Circuit Board: BNC5/5 (NX813760) XN297A0
1. IC
- IC 201: NJM2068D-D (XA987A00) OP AMP
2. Ceramic Capacitor
- C 202,208: B 470P 50V K (FG612470)
- C 203,209: SL 47P 50V J (FG651470)
- C 205,206: F 0.0100 50V Z (FG644100)
3. Electrolytic Cap.
- C 201,207: 10.00 25.0V (UJ847100)
- C 204,210: 47.00 16.0V (UJ837470)
4. Carbon Resistor
- R 111-120: 15.0K 1/4 J (HF757150)
- R 122,137,138: 18.0K 1/4 J (HF757180)
- R 129-134: 13.0K 1/4 J (HF75713)
- R 201,206: 3.6K 1/4 J (HF75636)
- R 202,207: 8.2K 1/4 J (HF756820)
- R 203,205,210: 47.0 1/4 J (HF754470)
- R 204,209: 560.0 1/4 J (HF755560)
- R 208: 47.0K 1/4 J (HF757470)
5. Metal Film Resistor
- R 101-110: 39.0K 1/4 F (VB068600)
- R 121,135,136: 27.0K 1/4 F (VB068300)
- R 123-128: 51.0K 1/4 F (VB068900)
6. Phone Jack
- JK 101-122: HLJ0520 (LB202600) GROUP1-8,ST SUB IN L,R, MONO SUB IN, AUX SUB IN1-6, CUE SUB IN L,R, MATRIX SUB IN L,R
7. Connector
- CN 101: HIF3BAG40PA2.54 (VR633100)
- CN 102: SAN&PH 4P 120L (VP96450)
- CN 103-106: PH- 2P SE (VB858100)

• BNC 5/5 Circuit Board




• BNC 3/5 Circuit Board


• BNC 4/5 Circuit Board



• JK 2/5 Circuit Board



• JK 1/5 Circuit Board




M2000 CIRCUIT DIAGRAM

(JK 1/5, JK 2/5, BNC 3/5, BNC 4/5, BNC 5/5)

M2000/PW2000M


M2000/PW2000M



KEC-92070


Marked ○: Nominal level

JK 2/5




KEC-92070

BNC 3/5




KEC-92070

BNC 4/5



KEC-92070

BNC 5/5



KEC-92070

M2000 CIRCUIT DIAGRAM

(JK 1/5, JK 2/5, BNC 3/5, BNC 4/5, BNC 5/5)

C25

■ MTC CIRCUIT BOARD


Notes)

- Circuit Board: MTC1/2 (NX813870) XN994B0
Circuit Board: MTC2/2 (NX813880) XN994B0
1. IC
IC 101,201,202: BA4558-NK (XF128A00) OP AMP
2. Transistor
Q 101,103,201,203,
205: 2SC1740S R,S (IC174070)
Q 102,104,202,204,
206: 2SA933S Q,R (IA093320)
3. Diode
D 101-106,201-209: 1SS133,1SS176 (VB941200)
4. LED
LED 101,102,
201-203: GL2PR6 RE (VH325200)
5. Ceramic Capacitor-F
C 104,105: 0.0100 50V Z (FG644100)
6. Electrolytic Cap.
C 101,102,209,210,
215,216: 47.00 25.0V (UI547470)
C 103,106,109,110,201,202,
205,206,211,212: 1.00 50.0V (UI566100)
C 107,111,203,207,
213: 22.00 16.0V (UI537220)
C 108,112,204,208,
214: 100.00 16.0V (UI538100)


7. Carbon Resistor
R 101,112,203,206,213,
216,225,228: 10.0K 1/4 J (HF757100)
R 102,113,202,212,
224: 100.0 1/4 J (HF755100)
R 103,114: 1.0K 1/4 J (HF756100)
R 104,115: 11.0K 1/4 J (HF757110)
R 105,116: 56.0K 1/4 J (HF757560)
R 106,117: 39.0K 1/4 J (HF75739)
R 107,109,118,120,207,209,
217,219,229,231: 4.7K 1/4 J (HF756470)
R 108,119,208,218,
230: 220.0 1/4 J (HF755220)
R 110,121,210,220,
232: 13.0K 1/4 J (HF75713)
R 123,124,127,128,234,235,
238,239,242,243: 330.0 1/4 J (HF755330)
R 125,126,129,130,236,237,
240,241,244,245: 6.8K 1/4 J (HF756680)
R 201,205,211,215,223,
227: 100.0K 1/4 J (HF758100)
R 204,214,226: 15.0K 1/4 J (HF757150)
8. Metal Film Resistor
R 111,122: 2.0K 1/4 F (VB066200)
R 221,222,233: 2.4K 1/4 F (VB066400)

9. Lamp
LP 101,102: 8V 100mA (VM672900)
10. Connector Base Post
CN 101: PH- 5P SE (VB858400)
CN 102: PH- 4P SE (VB858300)
CN 201: PH- 3P SE (VB858200)
CN 202: PH- 6P SE (VB858500)
CN 203: SAN&PH 5P 120L (VM66630)


• LED1, LED2 installing
(LED1, 2の取付け)




• LED201-LED203 installing
(LED201~203の取付け)




• LP101, LP102 installing
(LP101, 102の取付け)



• MTC 1/2 Circuit Board




• MTC 2/2 Circuit Board




3NA-VR65770

■ MTC CIRCUIT BOARD

M2000 CIRCUIT DIAGRAM (MTC 1/2, MTC 2/2)



Notes)
Maraked (F): Metal film resistor
Marked O: Nominal level



Notes)
Maraked (F): Metal film resistor
Marked O: Nominal level

■ MTA4 CIRCUIT BOARDS

Notes)

- Circuit Board: MTA4-1/4 (NX813830) XK039C0
Circuit Board: MTA4-2/4 (NX813840) XK039C0
Circuit Board: MTA4-3/4 (NX813850) XK039C0

1. IC

IC1-3: BA4558-NK (XF128A00) OP AMP

2. Transistor

- Q 1,3,5,7,9,11: 2SC1740S R,S (IC174070)
Q 2,4,6,8,10,12: 2SA933S Q,R (IA093320)

3. Diode

D 1-18: 1SS133,1SS176 (VB941200)

4. LED

LED 1-6: GL2PR6 RE (VH325200)

5. Ceramic Capacitor-F

C 11,12,23,24,35,
36: 0.0100 50V Z (FG644100)

6. Electrolytic Cap.

- C 1,2,5,6,13,14,17,18,25,
26,29,30: 1.00 50.0V (UI566100)
C 3,7,15,19,27,31: 22.00 16.0V (UI537220)
C 4,8,16,20,28,32: 100.00 16.0V (UI538100)
C 9,10,21,22,33,34: 47.00 25.0V (UI547470)

7. Carbon Resistor

- R 1,13,24,35,46,57: 100.0 1/4 J (HF755100)
R 2,12,23,34,45,56: 10.0K 1/4 J (HF757100)
R 3,14,25,36,47,58: 1.0K 1/4 J (HF756100)
R 4,15,26,37,48,59: 11.0K 1/4 J (HF757110)
R 5,16,27,38,49,60: 56.0K 1/4 J (HF757560)
R 6,17,28,39,50,61: 39.0K 1/4 J (HF75739)
R 7,9,18,20,29,31,40,42,51,
53,62,64: 4.7K 1/4 J (HF756470)
R 8,19,30,41,52,63: 220.0 1/4 J (HF755220)
R 10,21,32,43,54,
65: 13.0K 1/4 J (HF75713)
R 68,69,72,73,76,77,80,81,
84,85,88,89: 330.0 1/4 J (HF755330)
R 70,71,74,75,78,79,82,
83,86,87,90,91: 6.8K 1/4 J (HF756680)

8. Metal Film Resistor

R 11,22,33,44,55,
66: 2.0K 1/4 F (VB066200)

9. Lamp


LP 1-7: 8V 100mA (VM672900)

10. Connector Base Post


- CN 2,8: PH- 4P SE (VB858300)
CN 3,6,9: PH- 5P SE (VB858400)
CN 4,7: SAN&PH 5P 120L (VM66630)
CN 5: PH- 8P SE (VB858700)

※MTA 4-4/4 is not used in a M2000.
(MTA 4-4/4シートは、M2000には使用されていません。)


• LED1-LED6 installing
(LED1~6の取付け)




• LP1-LP7 installing
(LP1~7の取付け)




• MTA4-2/4 Circuit Board



• MTA4-1/4 Circuit Board



• MTA4-3/4 Circuit Board



3NA-VR30550

■ MTA4 CIRCUIT BOARDS


■ M2000 CIRCUIT DIAGRAM (MTA4-1/4, MTA4-2/4, MTA4-3/4)

M2000/PW2000M

M2000/PW2000M

GROUP1/MATRIX1A/AUX1
VU

GROUP2/MATRIX2A/AUX2
VU




KEC-92071

MTA4-1/4

GROUP3/MATRIX3A/AUX3
VU

GROUP4/MATRIX4A/AUX4
VU



KEC-92071


MTA4-2/4

GROUP5/MATRIX1B/AUX5
VU

GROUP6/MATRIX2B/AUX6
VU

GROUP5/MATRIX1B/AUX5
PEAK

GROUP6/MATRIX2B/AUX6
PEAK



KEC-92071

MTA4-3/4

Notes

Marked (F): Metal film resistor

Marked O: Nominal level