


SERIES II & IIA

Farts CATALOGUE

FOR PETROL AND DIESEL MODELS



THE ROVER CO. LTD. · SOLIHULL · WARWICKSHIRE · ENGLAND

PART No. 4187

(•



Parts SERIES II & IIA CATALOGUE

FOR PETROL AND DIESEL MODELS



By Appointment to Her Majesty Queen Elizabeth II



Manufacturers of Land-Rovers

The Rover Company Ltd

THE ROVER CO LTD · SOLIHULL

· WARWICKSHIRE · EN


ENGLAND

Part No. 4187

January, 1958 2nd revision October, 1961



THE "LAND-ROVER 88"



THE "LAND-ROVER 109"

Please note that all prices and specifications are subject to alteration without notice

The Rover Co. Ltd.

SERVICE AND PARTS DEPT .: SOLIHULL, WARWICKSHIRE ENGLAND

Telephone:

Telegrams:

SHEldon 4242 Rovrepair, Solihull, England

Telex: 33-156

LONDON SERVICE STATION: SEAGRAVE ROAD, FULHAM LONDON S.W.6, ENGLAND

Telephone:

Telegrams:

FULham 1221

Rovrepair, Wesphone, London, England

3rd Edition

ALWAYS QUOTE TYPE AND NUMBER OF VEHICLE WHEN ORDERING

COMMENCING VEHICLE NUMBERS:

and a second control of the second second

PETROL MODELS

Series II Seri	141900001 141000001 141100001 24100001a 142900001 142000001 142100001 24200001a 143900001 143000001 143100001 24300001a 144909001 144100001 24400001a 145900001 145100001 24500001a
Export R.H.D. 142800001 142900001 142000001 142100001 24200001a Export R.H.D., C.K.D. 143800001 143900001 143000001 143100001 24300001a Export L.H.D. 144800001 144900001 144100001 24400001a	142900001 142000001 142100001 24200001a 143900001 143000001 143100001 24300001a 144909001 144100001 24400001a 145900001 145100001 24500001a
Export R.H.D., C.K.D 143800001 143900001 143000001 143100001 24300001a Export L.H.D 144800001 144900001 144000001 144100001 24400001a	143900001 143000001 143100001 24300001a 144909001 144100001 24400001a 145900001 145100001 24500001a
Export L.H.D 144809001 144909001 144000001 144100001 24400001a	144909001 144090001 144100001 24400001a 145900001 145100001 24500001a
4 47000004	145900001 145000001 145100001 24500001a
	1959 109 1960 109 1961 109 109
100	
	Series II Series II Series IIA
Home R.H.D 151800001 151900001 151000001 151100001 25100001a	151900001 151000001 151100001 25100001a
Export R.H.D 152800001 152900001 152000001 152100001 25200001a	152900001 152000001 152100001 25200001a
Export R.H.D., C.K.D 153800001 153900001 153000001 153100001 25300001a	153900001 153000001 153100001 25300001a
Export L.H.D 154890001 154909001 154000001 154100001 25400001a	154909001 154090001 154100001 25400001 ₈
Export L.H.D., C.K.D 155800001 155900001 155000001 155100001 25500001a	renovable to the second
1959 1960 1961	1959 1960 1961
~ · · · · · · · · · · · · · · · · · · ·	
Home R.H.D. 109 Station Wagon 161900001 161000001 161100001 26100001a	161900001 161000001 161100001 26100001a
Export R.H.D. 109 Station Wagon 162900001 162000001 162100001 26200001a	162900001 162000001 162100001 26200001a
Export R.H.D. C.K.D. 109 Station Wagon 163900001 163000001 163100001 26300001a	163900001 163000001 163100001 26300001
Export L.H.D. 109 Station Wagon 164900001 164000001 164100001 26400001a	10 to no need
Export L.H.D. C.K.D. 109 Station Wagon 165900001 165000001 165100001 26500001a	

DIESEL MODELS

	1958 88 Series II	1959 88 Series II	1960 88 Series II	1961 88 Series II	88 Series IIA
Home R.H.D	146800001	146900 0 01	146000001	146100001	27100001a
Export R.H.D	147800001	147900001	147000001	147100001	27200001a
Export R.H.D. C.K.D.	148800001	148900001	148000001	148100001	27300001a
Export L.H.D	149800001	149900001	149000001	149100001	27400001a
Export L.H.D. C.K.D.	150800001	150900001	150000001	150100001	27500001a
	1958 109	1959 109	1960 109	1961 109	109_
	Series II	Series II	Series II	Series II	Series IIA
Home R.H.D	156800001	156900001	156000001	156100001	27600001a
Export R.H.D	157800001	157900001	157000001	157100001	27700001a
Export R.H.D. C.K.D.	158800001	158900001	158000001	158100001	27800001a
Export L.H.D.	159800001	159900001	159000001	159190001	27900001a
Export L.H.D. C.K.D.	160800001	160900001	16000001	160100001	28000001a
		1959	1960	1961	
		Series II	Series II	Series II	Series IIA
Home R.H.D. 109 Station Wagon	,	166900001	166000001	166100001,//	28100001a
Export R.H.D. 109 Station Wagon	ı	167900001	167000001	167100001	28200001a
Export R.H.D. C.K.D. 109 Station	Wagon	168900001	168000001	168100001	28300001a
Export L.H.D. 109 Station Wagon	,	169900001	169000001	169100001	28400001a
Export L.H.D. C.K.D. 109 Station		170900001	170000001	170100001	28500001a

GENERAL EXPLANATION

This parts catalogue is to be used for all Series II and Series IIA Land-Rover vehicles, Petrol and Diesel models, to both Home and Export specifications.

The part number quoted is always common to all the models covered by the section in question unless otherwise stated, in which case differences are noted in the Remarks column.

NOMENCLATURE. As the list covers both Home and Export models, reference is made throughout the text to the "left-hand" (L.H.) and "right-hand" (R.H.) sides of the vehicle, rather than to "near-side" and "off-side". The "left-hand side" is that to the left hand when the vehicle is viewed from the rear; similarly, "left-hand drive" (L.H.D.) models are those having the driving controls on the left-hand side, again when the vehicle is viewed from the rear.

ASSEMBLIES are printed in CAPITALS, and all the parts comprising that assembly are shown by indenting the alignment of the description column, the indentation reverting to the original alignment when the assembly is complete. The indentation is clearly shown by the numbers 1, 2, 3, 4 at the top of each page.

An example, taken from Page 15, is given below:

1 2 3 4
ROCKER COVER, TOP, ASSEMBLY
Tappet clearance plate
Drive screw fixing plate
Joint washer for top rocker cover

It will be seen that the ROCKER COVER, TOP, ASSEMBLY includes the tappet clearance plate and drive screw fixing plate (indention 1), while the joint washer, by reverting to alignment with ROCKER, is excluded from the assembly.

In all cases where the entire assembly is required, quote only the assembly number.

SIZES AND THREADS OF BOLTS AND NUTS are stated, and the bolt lengths shown are the underhead dimension. Bolts which differ in any way from standard B.S.F., U.N.F., U.N.C., Whitworth or B.A. specification are indicated as "special"; in such cases common stock cannot be used for replacement.

UNIFIED THREAD BOLTS AND NUTS SHOULD ALWAYS BE USED FOR REPLACEMENT PURPOSES WHERE SPECIFIED.

PROPRIETARY PART NUMBERS. Where applicable, proprietary part numbers are listed in this Parts Catalogue. The first two or three letters of these part numbers are an abbreviation of the manufacturer's name as follows:

Prefix:	AC		AC Delco	KLG		KLG Ltd.
	BB	_	Borg and Beck	LU	_	Lucas
	CAV		CAV Ltd.	SM	—	Smith
	GI	_	Girling	SU	_	S.U.
	JA		British Jaeger	SX	_	Solex

WHEN ORDERING PARTS, ALWAYS:

- (1) Quote a PART or ASSEMBLY NUMBER, giving the NAME OF THE PART and the VEHICLE NUMBER for which it is required.
- (2) Order from the nearest authorised Rover Distributor or Dealer.
- (3) Specify how despatch is to be made.

INSTRUCTIONS GENERALES

Ce Catalogue des pièces de rechange doit être utilisé pour rechercher le numéro des pièces désirées pour toutes les Land-Rover de la Série II et IIA munis du moteur Diesel ou à essence, spécifications "Home" (Marché intérieur) et "Export" (Marché extérieur).

Le numéro de la pièce est commun à tous les modèles groupés sous la section en question, à moins que la pièce ne soit de désignation spéciale. En pareil cas, les différences sont notées dans la colonne des observations.

NOMENCLATURE. Dans ce catalogue, nous avons recours à la spécification droite et gauche, droite et gauche étant définis par rapport à la position qu'occupe le conducteur lorsque celui-ci est assis au volant de son véhicule.

Les ENSEMBLES sont imprimés en lettres MAJUSCULES et toutes les pièces comprises dans un ensemble sont indiquées en déplacant la désignation de ces pièces d'une colonne vers la droite par rapport à la position qu'occupe la désignation de l'ensemble. Lorsque cet ensemble est complet, la désignation de la pièce suivante est ramenée à l'alignement originel, c'est-à-dire vers la gauche. L'alignement des désignations est clairement montré par les numéros 1, 2, 3, 4, en haut de chaque page.

Un exemple pris à la Page 15 est donné ci-dessous:

1 2 3 4
ROCKER COVER, TOP, ASSEMBLY
Tappet clearance plate
Drive screw fixing plate
Joint washer for top rocker cover

L'on remarquera que l'ensemble "ROCKER COVER, TOP, ASSEMBLY" comprend les pièces "Tappet clearance plate" et "Drive screw fixing plate" (colonne 1), tandis que la pièce suivante "Joint washer for top rocker cover" est exclue de l'ensemble, la désignation de celle ci étant ramenée en ligne avec l'ensemble "ROCKER COVER, TOP, ASSEMBLY".

Lorsqu'un ensemble complet est désiré, il suffira d'indiquer le numéro de l'ensemble.

LES DIMENSIONS ET LE FILETAGE DES BOULONS ET ECROUS sont données. La dimension spécifiée pour chaque boulon représente la longueur du corps de ceux-ci. Les boulons qui diffèrent de la spécification standard B.S.F., U.N.F., U.N.C., Whitworth ou B.A., sont indiqués comme étant de désignation spéciale; dans ces cas particuliers, des boulons ordinaires ne peuvent être utilisés pour les remplacer.

LORS D'UN REMPLACEMENT N'UTILISEZ QUE DES VIS ET DES ECROUS DU FILETAGE UNIFIE OU CELUI EST INDIQUE.

NUMERO DES PIECES DES DIFFERENTES MARQUES. Toutes les fois qu'il a été possible, les numéros des pièces des différentes marques ont été portés dans ce catalogue. Les deux premières lettres de ces numéros représentent l'abréviation du nom du constructeur, comme suit:

Préfixe: AC — AC Delco KLG — KLG Ltd.

BB — Borg and Beck LU — Lucas

CAV — CAV Ltd. SM — Smith

GI — Girling SU — S.U.

JA — British Jaeger SX — Solex

DANS LA PASSATION DES COMMANDES, IL EST INDISPENSABLE DE:

- 1) Donner le NUMERO DE LA PIECE ou de L'ENSEMBLE, la DESIGNATION COMPLETE DE CHAQUE PIECE ainsi que le NUMERO DU VEHICULE à laquelle la pièce est destinée.
- 2) Spécifier le mode d'expédition désiré.
- 3) Placer la commande avec l'agent Rover le plus proche.

ALLGEMEINE BEMERKUNGEN

Dieser Ersatzteilkatalog ist für alle für den Inland- und Exportmarkt hergestellten LAND-ROVER der Serie II und IIA mit Diesel- und Benzinmotor zu verwenden.

Die Ersatzteilnummern sind, soweit nicht anders bemerkt, stets allen, in dem betreffenden Abschnitt angeführten Modellen gemeinsam. Ausnahmen sind in der Rubrik Remarks vermerkt.

BEZEICHNUNGEN: Der Text dieses Katalogs, der Inland- und Exportmodelle umfasst, nimmt Bezug auf die linke (LH) und rechte (RH) Seite des Fahrzeuges. Diese Bezeichnungen beziehen sich auf die Seiten des Wagens, wenn dieser von der Rücksuite betrachtet wird. Dementsprechend bedeutet LHD links-gesteuerte und RHD rechtsgesteuerte Modelle.

Aus mehreren Einzelheiten bestehende, GRÖSSERE ERSATZTEILSÄTZE sind in GROSS-BUCHSTABEN gedruckt und alle Teile eines solchen Satzes sind im Text eingerückt angeführt. Das Ende dieses Satzes ist dadurch angegeben, dass der nächstfolgende Ersatzteil wieder auf die ursprüngliche Spaltenbreite vorgerückt ist. Die Einrückung ist durch die am Kopfe jeder Seite befindlichen Ziffern 1, 2, 3, 4 deutlich angegeben.

Dies ist durch das folgende, Seite 15 entnommene Beispiel illustriert.

ROCKER COVER, TOP, ASSEMBLY
Tappet clearance plate
Drive screw fixing plate
Joint washer for top rocker cover.

Das bedeutet, dass der Satz "ROCKER COVER, TOP, ASSEMBLY" eine "tappet clearance plate" und "drive screw fixing plate" mit einschliesst (Rubrik 1), während der "joint washer", wie schon sein Vorrücken auf die Höhe von ROCKER anzeigt, nicht im Satze einbegriffen ist.

Bei Bestellung eines grösseren Ersatzteiles gebe man nur die Nummer des kompletten Ersatzteilssatzes an

Die Masse und Gewinde für SCHRAUBEN und MUTTERN sind angegeben. Die Schraubenlängen sind die Längen der Stifte unterhalb des Kopfes. Schrauben welche sich irgendwie von der Standardspezifikation B.S.F., U.N.F., U.N.C., Whitworth oder B.A. unterscheiden, sind mit "Special bezeichnet, und nicht durch gewöhnliche Schrauben zu ersetzen.

BEIM ERSETZEN VON SCHRAUBEN UND MUTTERN SOLLEN AUSSCHLIESSLICH SOLCHE MIT DEM ANGEGEBENEN GENORMTEN GEWINDE VERWENDET WERDEN.

EIGENTUMSRECHTLICH GESCHUTZTE ERSATZTEILE: Wo eigentumsrechtlich geschützte Ersatzteile verwendet werden, sind diese im Ersatzteilkatalog dadurch gekennzeichnet, dass die ersten zwei Buchstaben eine Abkürzung des Namens der Herstellerfirma darstellen:

Schlüsselbuchstaben: A	.c —	AC Delco	KLG	 .	KLG Ltd.
В	В —	Borg and Beck	LU		Lucas
· C	AV —	CAV Ltd.	SM		Smith
G	, I —	Girling	SU	—	S.U.
TA	Α _	British Jaeger	SX		Solex

BEI BESTELLUNGEN BEACHTE MAN STETS FOLGENDES:

- 1) Folgende Einzelheiten sind anzugeben: Die Nummer und Bezeichnung des Ersatzteiles oder Ersatzteilsatzes, und die Nummer des Fahrzeuges, für welches diese Teile gebraucht werden.
- 2) Man bestelle vom nächsten bevollmächtigten ROVER Händler oder Vertreter.
- 3) Man gebe die nötigen Versandvorschriften.

INSTRUCCIONES GENERALES

Este catálogo de piezas de repuesto debe ser empleado para todos los vehículos Land-Rover modelos Serie II y IIA dotados del motor Diesel o de gasolina, tanto en los modelos nacionales, como para la exportación.

El número de pieza citado es siempre común a todos los modelos a que se hace referencia en la sección, a menos que se indique de otra forma, en cuyo caso, dicha diferencia está anotada en la columna titulada "Remarks" (Observaciones).

NOMENCLATURA. Como la lista se refiere a modelos Nacionales y de Exportación, la referencia en el texto se hace a vehículos con volante a la izquierda (L.H.) y volante a la derecha (R.H.). El costado izquierdo del vehículo es aquél que queda situado a la mano izquierda cuando se ve el vehículo desde su parte posterior; los vehículos con volante a la izquierda son aquellos que tienen los mandos de la dirección a la izquierda, también cuando el vehículo se ve desde la parte posterior.

Los CONJUNTOS van impresos en MAYUSCULAS y todas las piezas que comprenden dicho conjunto quedan indicadas por espaciados o desplazamientos de la alineación de la columna descriptiva; el espaciado vuelve a la alineación primitiva cuando el conjunto queda terminado. El espaciado se aprecia con toda claridad por la numeración 1, 2, 3, 4 en la parte superior de cada página.

Como ejemplo tomemos la Página 15 en la que se indica:

ROCKER COVER, TOP, ASSEMBLY
Tappet clearance plate
Drive screw fixing plate
Joint washer for top rocker cover

Se podrá observar que el ROCKER COVER, TOP, ASSEMBLY incluye el "Tappet clearance plate" y el "Drive screw fixing plate" para la cubierta delantera (espaciado 1), mientras que la "joint washer", por volver a la alineación con la palabra ROCKER, queda excluída del conjunto.

En todos los casos donde se requiere un conjunto completo, cítese solamente el número del conjunto.

LOS TAMAÑOS Y ESPECIFICACIONES DE PERNOS Y TUERCAS son indicados; el tamaño del perno es el de la longitud del espárrago del mismo. Los pernos que varíen de los especificados por la B.S.F., U.N.F., U.N.C., Whitworth o B.A., son indicados como tipos "especiales"; en tales casos no se pueden emplear para el recambio los que haya en existencia.

SE DEBEN USAR SIEMPRE PERNOS Y TUERCAS CON FILETE UNIFICADO PARA REPUESTOS DONDE ESTA ESTIPULADO.

INDICACION DE LAS PIEZAS CON LAS LETRAS INICIALES.

Donde resulta posible, se indican los iniciales y los números de los fabricantes ó propietarios. Las primeras dos letras de los números de estas piezas son abrevaciones del nombre del fabricante, ó sea:

Prefijo: AC — AC Delco KLG — KLG Ltd.

BB — Borg and Beck LU — Lucas

CAV — CAV Ltd. SM — Smith

GI — Girling SU — S.U.

JA — British Jaeger SX — Solex

AL PEDIR PIEZAS DE REPUESTO, SIEMPRE:

- (1) Se citará el NUMERO DE LA PIEZA o NUMERO DEL CONJUNTO, dando el NUMERO DE LA PIEZA Y NUMERO DEL VEHICULO para el cual se precisa.
- (2) Colóquese el pedido con el Distribuidor Rover más próximo.
- (3) Especifiquese como se ha de efectuar el envío.

INSTRUÇÕES GERAIS

Este catálogo de peças sobressalentes destina-se aos veículos Land-Rover modelos série II e IIA com motor Diesel o de gasolina, tanto para os modelos do mercado interno, como para os de exportação.

O número indicado para cada peça é sempre comum a todos os modelos abrangidos pela parte do catálogo em questão, a não ser que se especifique o contrário, em cujo caso as excepções são anotadas na coluna de "Remarks" (Observações).

NOMENCLATURA. Como este catálogo se refere igualmente a modelos do Mercado Interno e de Exportação, faz-se sempre referência no texto aos lados esquerdo (L.H.) e direito (R.H.) do veículo, sendo o primeiro o que fica do lado da mão esquerda quando se olha para o veículo da parte traseira. Os veículos com volante à esquerda (L.H.D.) são aqueles que têm os comandos da direcção do lado esquerdo, também quando se olha para o veículo da parte de trás.

Os CONJUNTOS são impressos em letras MAIÚSCULAS e todas as peças que fazem parte de um conjunto são indicadas escrevendo os respectivos nomes afastados um espaço para a direita do alinhamento da coluna descritiva; logo que o conjunto esteja completo, deixa de dar-se esse espaço e volta-se ao alinhamento original. As mudanças de alinhamento são facilmente observadas por meio dos números 1, 2, 3, 4, escritos no topo de cada página.

Como um exemplo, tome-se a página 15, onde poderá ler-se:

ROCKER COVER, TOP, ASSEMBLY
Tappet clearance plate
Drive screw fixing plate
Joint washer for top rocker cover

Notar-se-à que o "ROCKER COVER, TOP, ASSEMBLY" inclui o "Tappet clearance plate" e a "Drive screw fixing plate" (coluna 1), ao passo que a "joint washer", já escrita por debaixo do alinhamento original da palavra "ROCKER", não pertence a esse conjunto.

Em todos os casos em que se pretenda um conjunto completo, é suficiente indicar apenas o número do conjunto.

Os TAMANHOS Y ESPECIFIÇÃOES DOS PERNOS E PORCAS são indiçãoes, sendo o tamanho do perno o comprimento do respectivo corpo sem cabeça. Os pernos que difiram de qualquer modo das especificações B.S.F., U.N.F., U.N.C., Whitworth, ou B.A., são indicados como de tipo "especial"; nestes casos não podem ser substituídos pelos que normalmente há em armazém.

DEVEM USAR-SE SEMPRE PARAFUSOS E PORCAS COM FILETE UNIFICADO PARA FIMS DE SUBSTITUIÇÃO ONDE ESTIPULADO.

NÚMEROS DE PEÇAS CON NOME DE PROPRIEDADE EXCLUSIVA. Onde resulta aplicável, os números de peças con nome de propriedade exclusiva são indicados neste cátalogo de peças. As duas primeiras letras dos números destas peças são uma abreviação dos nomes dos fabricantes, ou seja:

Prefixo: AC — AC Delco KLG — KLG Ltd.

BB — Borg and Beck LU — Lucas

CAV — CAV Ltd. SM — Smith

GI — Girling SU — S.U.

JA — British Jaeger SX — Solex

AO FAZER A ENCOMENDA DE PEÇAS SOBRESSALENTES, DEVE SEMPRE:

- (1) Indicar-se o NÚMERO DA PEÇA ou o NÚMERO DO CONJUNTO, dando ao mesmo tempo o NOME DA PEÇA e o NÚMERO DO VEÍCULO a que se destina;
- (2) Dirigir-se a encomenda ao Distribuidor Rover mais próximo;
- (3) Especificar-se como o despacho deve ser feito.

2 × 1

INDEX TO SECTIONS

	Description	Page		Description		Page
Δ	A.C./D.C. generator, 12 volt, 21 litre Petrol	464-469		Flywheel and clutch, 2¼ litre Petrol		76-77
	Accelerator lever and rods, 2 litre Petrol	222-223		Flywheel and clutch, 2 litre Diesel		114-115
	Accelerator lever and rods, 2 little Petrol	224-227		Flywheel and clutch, 2½ litre Diesel		148-149
		228-231		Four-wheel drive selectors and transfer gear lev		168-171
	Accelerator lever and rods, Diesel	220 25.		Fresh air heater, 2 litre Petrol L.H.D		438-441
D	Body cappings and sockets, 88	270-275		Fresh air heater, 2½ litre Petrol L.H.D		442-445
В		276-281		Front axle and propeller shaft		174-175
	Body cappings and sockets, 109	488-493		Front axie and propener shart		390-395
	Body panels and windows, 88 Station Wagon	536-537				396-401
	Body trim, 109 Station Wagon	198-199		Front capstan winch, 2½ litre Petrol and Diesel		22-23
	Brake pipes	192–193		Front cover, side cover and sump, 2 litre Petrol	l	56-57
	Brakes, foot, 10" brakes, 88	194-195		Front cover, side covers and sump, 2½ litre Pet	 l	94-95
	Brakes, foot, front, 11" brakes, 109	196–197		Front cover, side covers and sump, 2 litre Dies	EI	132-133
	Brakes, foot, rear 11" brakes, 109	190-197		Front cover, side covers and sump, 21 litre Die		162-163
С	Cab and tropical roof	358-361		Front output shaft housing		96-99
·	Camshaft and tensioner mechanism, 2 litre Petrol	16-17		Fuel injection system, 2 litre Diesel, 1958-60		100-105
	Camshaft and tensioner mechanism, 2 little Petrol	50-51		Fuel injection system, 2 litre Diesel, 1961		134-139
	Camshaft and tensioner mechanism, 2 litre Diesel	88-89		Fuel injection system, 2½ litre Diesel		310-315
	Camshaft and tensioner mechanism, 2 litre Diesel	126-127		Full length hood and fittings, 88	•···	320-323
	Carburetter, 2 litre Petrol	28-31		Full length hood and fittings, 109	••••	J20 J2J
	- · · ·	60-65				
	Carburetter, 2½ litre Petrol Centre seat and front squab, 109 Station Wagon	530-533	G	Gearbox, main casing		150-151
	Chassis frame, road springs and shock absorbers	208-215		Gearbox, selectors and levers		160-161
	Chassis frame, fuel tank, exhaust system and electrical	200 215		Gearbox, shafts and gears		156-159
	equipment, 109 Station Wagon	538-539		Gearbox, transfer casing		152-155
	Clutch and brake pedals and pipes	216-221		General electrical equipment		260-269
	Clutch withdrawal mechanism	164-165				
	Connecting rod and piston, 2 litre Petrol	12-13				202-203
	Connecting rod and piston, 2½ litre Petrol	46-47	н	Handbrake lever, L.H.D	****	200-201
	Connecting rod and piston, 2 litre Diesel	82-83		Handbrake lever, R.H.D.		204-207
	Connecting rod and piston, 21 litre Diesel	120-121		Handbrake, transmission	****	232-233
	Crankshaft, 2 litre Petrol	10-11		Hand control engine speed, Diesel		460-461
		44-45		Hand throttle, 2 litre Petrol	,	462-463
	Crankshaft, 2 litre Diesel	80-81		Hand throttle, 2½ litre Petrol		402 403
	Crankshaft, 21 litre Diesel	118-119		Hard top and tropical roof, 88, with fixed	1 side	328-335
	Cylinder block, 2 litre Petrol	8–9		Windows Hard top and tropical roof, 88, with sliding		
	Cylinder block, 2½ litre Petrol	42-43		windows		336-343
	Cylinder block, 2 litre Diesel	78-79		Hard top and tropical roof, 109, with fixed	l side	
	Cylinder block, 2½ litre Diesel	116-117		windows		344-353
	Cylinder head, 2 litre Petrol	14-15		Head, side and tail lamps		256-259
	Cylinder head, 2½ litre Petrol	48-49		Hood, three-quarter length, 88		316-319
	Cylinder head, 2 litre Diesel	84-87		Hood, three-quarter length, 109	****	324-327
	Cylinder head, 24 litre Diesel	122-125		Hydraulic front winch		402-407
	Cymider head, 24 mile 2 least in			Hydraulic front winch mechanism		408-417
D	Dash, windscreen and ventilator	304-309				
	De luxe trim for cab, upper	362-363	I	Instruments		252-255
	De luxe trim for doors and floor	364-365				
	Differential, front and rear	176177	1.7	Main gear lever		166-162
	Distributor and starter, 2 litre Petrol	34-37	IAT	Manifolds, 2 litre Petro'	,	32-33
	Distributor and starter, 21 litre Petrol	70 -7 3				66-69
	Dynamo and fixings, 2 litre Petrol	38-39		Manifolds, 2¼ litre Petrol Manifolds, 2 litre Diesel		108-10
	Dynamo and fixings, 21 litre Petrol	74-75				142-14
	Dynamo and fixings, 2 litre Diesel	112-113		Manifolds, 24 litre Diesel Miscellaneous optional equipment		474-48
	Dynamo and fixings, 21 litre Diesel	146-147		lynscenaneous opnonar equipment		
			*1	Numerical index		569-58
E		470-471	N	Numerical index		
	Eight-bladed fan and engine tie-rod, Diesel	472-473	_	on 1 av. P. J		418-42
	Engine governor, 2 litre Petrol	380-383	0	Oil cooler, 2 litre Petrol	***	426-43
	Engine governor, 21 litre Petrol	384-389		Oil cooler, 24 litre Petrol	****	422-42
	Exhaust system	234-239		Oil cooler, Diesel		24-2
				Oil filter and oil pipes, 2 litre Petrol		20-2
F	Fire tender	541		Oil pump, 2 litre Petrol		20-2 54-5
	Fire tender controls	546-557		Oil pump, 2½ litre Petrol		92-9:
	Fire tender pump	542-545		Oil pump, 2 litre Diesel		130-13
	Flashing indicators	456-459		Oil pump, 2½ litre Diesel		150-15 48
	Flywheel and clutch, 2 litre Petrol	40-41		Overhaul kits	****	-10

INDEX TO SECTIONS—continued

	Description		Page		Description	Page
P	Petrol pump Petrol and fuel tank, filter and pipes		250-251 244-249	T	Tailboard, doors and side screens Tools	298-30: 56
R	Radiator and fittings		240-243		Towing attachments	452-455 566-567
	Rear axle and propeller shaft		172-173		Trailer, axles, brakes and hubs	562-563
	Rear body, 109 Station Wagon		508-511		Trailer body, springs and road wheels	564-565
	Rear door, hard top, 88 and 109		354-35 7		Trailer, drawbar and handbrake	558-561
	Rear door, 88 Station Wagon		494-499		Trim, 88 Station Wagon	504-505
	Rear door, 109 Station Wagon		524-529			501 505
	Rear and centre, P.T.O. gearbox units		368-371	U	Universal joints and front hubs	178-181
	Rear P.T.O. drive section	****	372-377		Universal joint cover plates	448-449
	Rear P.T.O. pulley section		378-379			, ,
	Rear power take-off		367	v	Valve gear and rocker shafts, 2 litre Petrol	18-19
	Rear seats		446-447		Valve gear and rocker shafts, 2½ litre Petrol	52-53
	Rear seats and miscellaneous fittings, 88 S	tation	500-503		Valve gear and rocker shafts, 2 litre Diesel	90-91
	Rear seats, 109 Station Wagon		534-535		Valve gear and rocker shafts, 21 litre Diesel	128-129
	Rear side doors, 109 Station Wagon		518-523		Vehicle heater, front, 2 litre Petrol	432-433
	Roof and body side panels, 109 Station Wagon		512-517		Vehicle heater, front 2½ litre Petrol and Diesel Vehicle heater, rear, 2½ litre Petrol	434-435 436-437
S	Seat base, seats, front floor, front wings and bo	nnet	282-297	w	With the second	27 27
	Starter motor and solenoid, 2 litre Diesel		110-111	**	Water pump and thermostat 2 litre Petrol	2627 5859
	Starter motor and solenoid, 21 litre Diesel		144-145		Water pump and thermostat, 21 litre Petrol	
	Station Wagon, interim 88		485		Water pump and thermostat, 2 litre Diesel	106-107
	Station Wagon, 88		487		Water pump and thermostat, 21 litre Diesel	140-141
	Station Wagon, 109		507		Water temperature and oil pressure gauge, 2 litre Petrol	448-449
	Steering column		182-187		Water temperature and oil pressure gauge, 24 litre	
	Steering relay and linkage		188-191		Petrol and Diesel	450-451

INDEX


	Description	Page	Description	Page	Descriptio		ge
A	Accelerator bell crank	bracket.	Brake cylinder, wheel	193, 195, 197	Connecting rod bea	ring, 2 litre	2
	Diesel	231	Brake drum, foot	193, 195, 197	Diesel		33
	Accelerator pedal, Petrol	223, 225	Brake drum, hand	207	Connecting rod bear		21
	Accelerator pedal, Diesel	229	Brake, hand, L.H.D	203	Diesel		
	Accelerator pedal housing	, Petrol	Brake, hand, R.H.D.	201	Control box, voltage Control, mixture		
		223, 225	Brake, hand, trailer	559 201, 203	Control quadrant, en		-
	Accelerator pedal housing	, Diesel 229	Brake lever, hand	201, 205	Control quadrant, on	381, 38	35
	Accelerator shaft, Petrol	223, 225 229	Brake pedal Brake pipes	199, 219	Control quadrant,	hand, engine	
	Accelerator shaft, Diesel Adaptor for oil filter, oi		Brake shoe, foot	193, 195, 197	speed, Ďiesel		33
	Diesel	427	Brake shoe, hand	205	Control rod, engine s	speed, Diesel 23	
	Adjuster, timing chain, 2		Brake, transmission	205	Control valve, hydra	ulic winch 4	23
	Adjuster, timing chain, 21	litre Petrol 51	Brakes, foot		Cover, front, 2 litre		57
	Adjuster, timing chain, 2 l	itre Diesel 89	Brakes, trailer Bumper, front		Cover, front, 21 litre		95
	Adjuster, timing chain, 21	litre Diesel 127	Bumper, front	209	Cover, front, 2 litre l Cover, front, 2½ litre		33
	Air cleaner, Petrol				Cover, gearbox		89
	Air cleaner, Diesel	252			Cover plate, rear wat	er pipe. Z litre	9
	Ammeter Anchor plate, brake, foot				Cover plate, wing va	lance 2	93
	Anchor plate, brake, hand	1 205 (Cab	359	Cover, rocker side, 2	litre Petrol	23
	Axle, front	170	Cable clips	265, 267, 269	Cover, side, 24 litre	Petrol	57 95
	Axle, rear	150	Cable harness, dash	263	Cover, side, 2 litre D		33
	Axle, stub	101	Cable harness, dynamo	263	Cover, side, 21 litre Cover, rocker top, 2		15
	Axles, trailer	563	Cable harness, engine		Cover, rocker top, 2	****	49
			Cable harness, frame	263 263	Cover, rocker top, 2		85
			Cable harness, headlamp		Cover, rocker top, 2		23
			Cable harness, rear cross- Cable, speedometer	255	Cover plate, universa	aljoint 4	49
			Camshaft, 2 litre Petrol	17	Cowl, radiator, oil co	ooler, Z litre 4.	21
В	Back light, cab	359	Camshaft, 21 litre Petrol	51	Crankshaft, 2 litre P		!!
_	Back light, hard top	331, 349	Camshaft, Diesel	127	Crankshaft, 21 litre		45 81
	Back light, hood 311,	317, 321, 325	Camishan Dearing, 2 nac.	1 011 01	Crankshaft, 2 litre D Crankshaft, 21 litre	Diesel I	19
	Rack rest seat	289	Camshaft bearing, 24 litre		Crankshaft oil reta	iner 2 litre	• •
	Back rest, rear seat	447, 501, 535	Camshaft bearing, 2 litre		Petrol	micr, D mes	11
	Balance weight, road whe	el 215 261	Camshaft bearing, 21 litre Camshaft chain, 2 litre Pe	etrol 17	Crankshaft oil reta	iner, 21 litre	
	Battery, Petrol Battery, Diesel	261 261	Camshaft chain, 21 litre I	Petrol 51	Petrol		45
	Battery casing, Petrol	213	Camshaft chain, 2 litre D		Crankshaft oil reta	iiner, 2 litre	۰.
	Battery casing, Diesel		Camshaft chain, 2½ litre I	Diesel 127	Diesel		81
	Bearing camshaft, 2 litre	17	Camshaft chain adjuster	, 2 litre	Crankshaft bearing		45
	Bearing, camshaft, 21 litr	e 51	Petrol	17	Petrol Crankshaft bearing		7)
	Bearing, camshaft, 2 litre	Diesel 89	Camshaft chain adjuster,	, 24 litre	Diesel	on Sear, 2 nac	81
	Bearing, camshaft, 24 litr	e Diesel 127	Petrol	51	Crankshaft bearing of		-
	Bearing, connecting rod		Camshaft chain adjuster	89	Diesel	1	19
	Petrol	13 21. litro	Diesel Camshaft chain adjuster,		Cushion, seat	2	89
	Bearing, connecting rod Petrol	, 24 nure 47	Diesel	127	Cushion, seat, rear	4	H7
	Bearing, connecting roc	l. 2 litre	Cap. radiator	241	Cylinder block, 2 lit		9 43
	hecel	02	Capstan winch, front, 2 li	tre Petrol 391	Cylinder block, 21 1		79
	Bearing, gearbox	157	Capstan winch, front,	2¼ litre	Cylinder block, 2 lit Cylinder block, 2‡ l		117
	Bearing, main, 2 litre Pet	trol II	Petrol and Diesel	397	Cylinder block, 27 i Cylinder, brake, ma		217
	Bearing, main, 21 litre P		Carburetter, 2 litre Petro Carburetter, 2½ litre Petro Carburetter levers, 2 litre] 29 ol 61	Cylinder, brake, wh	eel 193, 195, I	97
	Bearing, main, 2 litre Die		Carburetter, 24 fitte Feur Carburetter levers, 2 litre	ol 01 Petrol 33	Cylinder head, 2 lit	re Petrol	10
	Bearing, main, 21 litre D	150	Carburetter levers, 24 litt	re Petrol 67	Cylinder head, 2½ li	tre Petrol	49
	Bearing, transfer box Belt, fan, 2 litre Petrol	27	Casing, transfer box		Cylinder head, 2 lit	re Diesel	85
	Belt, fan, 2½ litre Petrol	59	Centre cover panel	283	Cylinder head, 2 1 li	tre Diesel	123
	Belt, fan, 2 litre Diesel		Chaff guard	477	Cylinder liner, 2 lite		174 79
	Belt, fan, 21 litre Diesel	141	Chain, tailboard	477	Cylinder liner, 2 litt Cylinder liner, 2‡ l	re Diesel	"
	Bell housing	151	Chains, skid		2½ litre Petrol	4	474
	Board, floor, rear	200	Change speed lever, mair		24 mie i cator	,	
	Board, tail		Change speed lever, trans Chassis frame	200			
	Body mounting		Chassis frame, 109 Statio	n Wagon 538			
	Body panels, 88 Station Body panels, 109 Station		Check strap, front door	309			
	Body, rear		Clutch cylinder, master	217	D Damper, vibration,	engine 11, 81,	119
	Body, rear, 109 Station	Wagon 509	Clutch, 2 litre Petrol	<u>41</u>	Damper, vibration		วกร
	Rody repair kit	483	Clutch, 2½ litre Petrol	11	Diesel 109	,	205 205
	Body, sides	271, 277, 509	Clutch, Diesel	115, 149	Dash Differential, front		177
	Body trailer	559	Clutch dog, hydraulic wi		Differential, rear		177
	Bollard and shaft, front v		Clutch pedal	217	Dipper switch		185
	Bonnet	205	Clutch shaft Clutch slave cylinder		Dipstick, gearbox		151
	Bonnet striker Brace, wheel, divided rin	295 n.wheel 476	Clutch withdrawal		Dipstick, sump, 2 l	itre Petrol	23 57
	Bracket, accelerator be	ell crank.	Coil, ignition	261	Dipstick, sump, 27	litre Petrol	57
	Diesel	231	Connecting rod, 2 litre P	etrol 13	Dipstick, sump, 21	itre Diesel	95 133
	Bracket, engine lifting,	front, 21	Connecting rod, 21 litre	Petrol 47	Dipstick, sump. 21		71
	litre Petrol and Diesel	49, 85, 123	Connecting rod, 2 litre I		Distributor adaptor Distributor, 2 litre	r, 24 litre retroi Petrol	35
	Bracket, engine litting,	rear, 21	Connecting rod, 21 litre	Diesel 121	Distributor, 21 litre		71
	litre Petrol and Diesel	49, 85, 123	Connecting rod bearing		Distributor housing	z. 2 litre Petrol	21
	Brake band, hydraulic w	rinch 403	Petrol Connecting rod bearing		Distributor pump,	2 litre Diesel 9/,	101
	Brake and clutch, supply Brake cylinder, master	ytank 219 217	Petrol	47	Distributor pump,	21 litre Diesel	135
	DISKE CVIDGET, IDASKET	616	A WAR WAR 1777 177				

	Description	D	D constant	D	
	Door hinge	Page 299 -	PR	Page	Description Page
	Door light catch	480	Filter, fuel, 2½ litre Diesel	, 101 135	Gudgeon pin, 2 litre Diesel 83 Gudgeon pin, 2½ litre Diesel 121
	Door lock	301	Filter, oil external, 2 litre Petrol	25	Guide tappet, 21 litre Petrol 53
	Doors and fittings Door, rear, hard top 88 and 109	299 355	Filter, oil external, 2½ litre Petrol	49	Guide tappet, 2 litre Diesel 91
	Door, rear, 88 Station Wagon	495	Filter, oil external, 2 litre Diesel Filter, oil external, 24 litre Diesel	87 125	Guide tappet, 2½ litre Diesel 129
	Door, rear, 109 Station Wagon	525	Fire tender, controls	547	
	Door, rear side, 109 Station Wagon Drag link	. 51 9 191	Fire tender, pump Flange, P.T.O. drive	543 H 369	
	Drawbar, trailer	559	Flasher unit	457	Hand engine speed control, Diesel 233 Hand throttle, 2 litre Petrol 461
	Drive shaft, pump, hydraulic winch	409	Flasher unit Floor, rear 271, 277,	509	Hand throttle, 2½ litre Petrol 463
	Driving shaft, oil pump 21, 55, 9:	183	Flyscreen for dash vent Flywheel, 2 litre Petrol	482 41	Handle, hard top, rear lid 331, 339, 349
	Drum, foot brake 193, 195	5, 197	Flywheel, 21 litre Petrol	77	Handle, lifting 213 Hard top 329, 337, 345
	Drum, hand brake Dynamo, 2 litre Petrol	207 39	Flywheel, 2 litre Diesel Flywheel, 2½ litre Diesel	115	Harness, dash 263
	Durama 21 lisea Dassal	75	Flywheel, 24 litre Diesel Flywheel housing, 2 litre Petrol	149 41	Harness, frame 263 Harness, panel 253
	Dynamo, 2 litre Diesel	113	Flywheel housing, 27 litre Petrol	77	Harness, panel 253 Headlamp 257
	Dynamo, 21 litre Diesel	147	Flywheel housing, 2 litre Diesel	115	Heater plug, 2 litre Diesel 87
_			Flywheel housing, 2½ litre Diesel Follower, inlet valve, 2 litre Petrol	149 19	Heater plug, 2½ litre Diesel 123 Heater plug and starter switch,
E	Engine, 2 litre Petrol	9	Four-wheel drive selector	169	Diesel 253
	Engine, 2½ litre Petrol Engine, 2 litre Diesel Engine, 2½ litre Diesel	43 79	Frame harness Front bumper	263	Heater, vehicle front, 2 litre Petrol 433
	Engine, 21 litre Diesel	117	Front cover, 2 litre Petrol	209 23	Heater, vehicle, front, 2½ litre Petrol and Diesel 435
	Engine breather, side cover, 2 litre	23	Front cover, 21 litre Petrol	57	Heater, vehicle, fresh air, 2 litre
	Petrol Engine breather, side cover, 21 litre	23	Front cover, 2 litre Diesel Front cover, 2½ litre Diesel	95 133	Petrol 439
	Petrol	57	Front exhaust pipe	235	Heater, vehicle, fresh air, 2½ litre Petrol 445
	Engine breather, side cover, 2 litre Diesel	95	Front lifting and towing rings	455	Heater, vehicle, rear, 2½ litre Petrol 437
	Engine breather, side cover, 21 litre	9)	Front shock absorber	211 293	Heavy duty road springs 475 Heavy duty shock absorber 475
	_ Diesel	133	Front wing Fuel filter, 2 litre Diesel 97,	INI	Hinge, bonnet 295
	Engine breather, top cover, 2 litre	15	Fuel injector, 2 litro Diesel	135	ringe, door 299
	Engine breather, top cover, 21 litre		Fuel injector, 2 litre Diesel Fuel injector, 2 litre Diesel Fuel injector, 2½ litre Diesel Fuel injector, 2½ litre Diesel	137	Hinge, locker lids 283 Hood, full length 311, 321
	Petrol Engine breather, top cover, 2 litre	49	ruel injector pipe, 2 litre Diesel 99.	103	Hood, three-quarter length 317, 325
	Diesel	85	Fuel injector pipe, 2½ litre Diesel Fuel pump, 2 litre Diesel 97,	137 101	Hood socket 271, 277 Hood stick 311, 317, 321, 325
	Diesel Engine breather, top cover, 2½ litre		Fuel pump, 21 litre Diesel	135	Horn 261
	Engine governor, 2 litre Petrol	123 381	ruci pullip overnatii kit, 24 litre	10.1	Horn button 185
	Engine governor, 27 litre Petrol	385	Petrol and Diesel 97, 105, 139, Fuel pump repair kit, 2\frac{1}{4} litre	484	
	Engine lifting bracket, front 24	1.72	Petrol and Diesel 97, 105, 139.		Hot plug, 2 litre Diesel 85 Hot plug, 2½ litre Diesel 123
	litre Petrol and Diesel 49, 85 Engine lifting bracket, rear, 24 litre	, 123	E I	253	Housing, accelerator pedal, Petrol
	Petrol and Diesel 49, 85.	, 123	ruse box	263	Housing, accelerator pedal, Diesel 229
	Engine speed control rod, Diesel Engine stop control, Diesel	233 231			Housing, capstan winch, front 2
	Engine stop control, Diesel Engine support, front, 2 litre	231			litre Petrol 391 Housing, capstan winch, front, 2½
	Petrol Engine support, front, 2½ litre	9	G Gallery pipe, oil, 2 litre Petrol	9	litre Petrol and Diesel 398
	Petrol Petrol	43	Gasket kit, engine overhaul	484	Housing, clutch withdrawal 165
	Engine support, front, 2 litre	7.7	C 1 1 1 1	484 403	Housing, distributor, 2 litre Petrol 21 Housing, front output 163
	Diesel	79	Gearbox	151	Housing, P.T.O. gearbox drive 369
	Engine support, front, 21 litre Diesel	117		157 289	Housing, rear mainshaft bearing 153
	Engine support, rear	155		403	Housing, rear P.T.O 373 Housing, swivel pin 179
	Exhaust manifold, 2 litre Petrol Exhaust manifold, 21 litre Petrol	33 69	Gears, main gearbox	157	Housing, thermostat, 2 litre Petrol 27
	Exhaust manifold, 2 litre Diesel	109	Gears, transfer box Generator, A.C./D.C. 12 volt, 21	159	Housing, thermostat, 2½ litre Petrol 59 Housing, thermostat, 2 litre Diesel 107
	Exhaust manifold, 21 litre Diesel	143	litre Petrol	465	Housing, thermostat, 2½ litre Diesel 141
	Exhaust pipe, front Exhaust pipe, 109 Station Wagon	235 539		35 9 355	Housing, winch shaft, front winch,
	Exhaust silencer	235	Glass, rear door, Station Wagon		2 litre Petrol 393 Housing, winch shaft, front winch,
	Exhaust silencer, 109 Station	539	495.	525	21 litre Petrol and Diesel 399
	Exhaust valve, 2 litre Petrol	19	Glass, rear side door, 109 Station Wagon	519	Hub, front 181 Hubs, trailer 563
	Exhaust valve, 24 litre Petrol	53	Glass, rear end, hard top 329, 339,	347	riubs, trailer 563
	Exhaust valve, 2 litre Diesel Exhaust valve, 21 litre Diesel	91 129	Glass, rear end, Station Wagon 491, 5	517	
		127	Glass, rear, lid, hard top 331, 341, 3		Injector, fuel, 2 litre Diesel 99, 103
			Glass, side, fixed, hard top 329, 3		Injector, fuel, 21 litre Diesel 137
F	Fan, 2 litre Petrol	27	Glass, side, sliding, hard top 3 Glass, side, Station Wagon 491, 5	337 515	Injector pipe, damper, 2 litre Diesel
	Fan, 2½ litre Petrol	59	Glass, windscreen 3	307	99, 103 Injector pipe damper, 21 litre Diesel 137
	Fan, 2 litre Diesel Fan, 21 litre Diesel	107 141		881 185	Inlet manifold, 2 litre Petrol 33
	Fan belt, 2 litre Petrol	27	Governor, quadrant, 2 litre Petrol	385	Inlet manifold, 2½ litre Petrol 67 Inlet manifold, 2 litre Diesel 109
	Fan belt, 24 litre Petrol	59	381, 3		Inlet manifold, 21 litre Diesel 143
	Fan belt, 2 litre Diesel Fan belt, 2½ litre Diesel	107 141		79 241	Inlet valve, 2 litre Petrol 19
	Fan belt, engine governor 381,	387	Grommet, bell housing	51	Inlet valve, 2½ litre Petrol 53 Inlet valve, 2 litre Diesel 91
	Fastener, windscreen Filler cap, fuel	307 245	Grommet, rubber, electrical 2	69	Inlet valve, 21 litre Diesel 129
	Filler cap, ruel Filler cap, radiator, standard	24) 241		13 47	Inner tube 215 Instruments 253
	- ,			.,	Instruments 253

	Description	P_{age}		Description	Page		Description Page
L	Lamp, head	257		Oil pump driving shaft, 24 litre			Pump, water, 2 litre Petrol 27
L		259		Diesel	131		Pump, water, 21 litre Petrol 59
		259		Oil retainer, crankshaft, 2 litre			Pump, water, 2 litre Diesel 107
		257		Petrol	11		Pump, water, 21 litre Diesel 141
		259		Oil retainer, crankshaft, 21 litre			Push rod, inlet, 2 litre Petrol 19
	Lavshaft	157		Petrol	45		Push rod, tappet, 2½ litre Petrol 53
	Lead, heater plug, 2 litre Diesel.	87		Oil retainer, crankshaft, 2 litre	٠.		Push rod, tappet, 2 litre Diesel 91
	Lead, heater plug, 21 litre Diese	1 123		Diesel	81		Push rod, tappet, 24 litre Diesel 129
	Leak-off pipe, 2 litre Diesel	97, 101		Oil seal, crankshaft bearing, 21 litre			
		135		Petrol Oil seal, crankshaft bearing, 2 litre	45		
	Level unit, fuel tank	245			01		
	Lever, carburetter	33, 67		Diesel	81	0	Quadrant, governor control 381, 385
		167		Oil seal, crankshaft bearing, 21 litre	110	•	Quadrant, hand speed control,
	Lever, change speed, transfer	169		Diesel	119		Diesel 233
	Lever, clutch	221		Output shaft, four-wheel drive	163 484		
		201, 203		Overhaul gasket kit, engine	404		
	Lever, hand speed control, Diese	el 233		Overhaul kit, fuel pump, 2½ litre Petrol and Diesel 97, 105, 13	0 484		
		179 189		retroi and Dieset 37, 103, 13	7, 101	n	Radiator 241
	Lever, steering relay					R	
	Lifting and towing rings, front		P	Paint 56	6, 567		Radiator cap 241 Radiator cowl, oil cooler, 2 litre
	Lifting bracket, engine front,	85, 123	•	Panel harness	0.50		D . 1 421
	litre Petrol and Diesel 49, Lifting bracket, engine rear,	71		Panel, rear, cab	359		Radio suppressors 421
	litre Petrol and Diesel 49	, 8 5, 123			3, 225		Rear axle 173
	Lifting handle	213		Pedal, accelerator, Diesel			Rear axle casing 173
	Light, warning, instrument pane			Pedal, brake	217		Rear axle shaft 173
	Liner, cylinder, 2 litre Petrol			Pedal, clutch	014		Rear curtain, 88 311, 317
	Liner, cylinder, 2 litre Diesel			Pedal pads	477		Rear curtain, 109 321, 325
	Liner, cylinder, 24 litre Diesel a	nd		Petrol pipe	247		Rear lid, hard top 331, 339, 349
		474		Petrol pump			Rear panel, cab 359
		191		Petrol sediment bowl	247		Rear tow plate 455
	Lock, door	301		Petrol tank			Relay lever, steering 189
	Lock, hard top, rear lid 331,	, 339, 349		Petrol tank level unit			Relief valve, oil, 2 litre petrol 21
	Locking handles and catches	480		Pin, gudgeon, 2 litre Petrol	4=		Relief valve, oil, 24 litre petrol 55
	Longitudinal tube, steering	191		Pin, gudgeon, 21 litre Petrol			Relief valve, oil, Diesel93, 131
	_			Pin, gudgeon, 2 litre Diesel	101		Relief valve, oil cooler 419, 423, 427
M	Main bearing 11,4	5, 81, 119		Pin, gudgeon, 24 litre Diesel			Relief valve, hydraulic winch 411
	Mainshaft, bearing housing, rea	r 153		Pin, shackle	1=0		Repair kit, fuel pump, 21 litre
	Mainshaft, gearbox	157		Pin, swivel 19	1 79 99. 219		Petrol and Diesel 97, 105, 139, 484
	Manifold, exhaust, 2 litre Petrol	l 33		Pipe, brake 15	9		Ring, piston, 2 litre Petrol 13
	Manifold, exhaust, 21 litre Petro	ol 69		Pipe, oil gallery, 2 litre Petrol Pipe, fuel injector, 2 litre Diesel			Ring, piston, 21 litre Petrol 47
	Manifold, exhaust, 2 litre Diese	L 109		Pipe, fuel injector, 21 litre Diesel	137		Ring, piston, 2 litre Diesel 83
	Manifold, exhaust, 21 litre Dies	el 143		Pipe, leak-off, 2 litre Diesel	7, 101		Ring, piston, 2½ litre Diesel 121 Road spring, front 209
		33		Pipe, leak-off, 24 litre Diesel			
	Manifold, inlet, 21 litre Petrol	67		Pipe, mechanical pump to filter,			
	Manifold, inlet, 2 litre Diesel	109			97, 101		
	Manifold, inlet, 21 litre Diesel			Pipe, mechanical pump to filter,			Road wheel 215 Rocker cover, side, 2 litre Petrol 23
		217		2½ litre Diesel			Rocker cover, side, 2 litre Petrol 23 Rocker cover, side, 21 litre Petrol 57
		217		Piston, 2 litre Petrol	12		Rocker cover, side, 2 litre Diesel 95
	Mixture control, Petrol			Piston, 21 litre Petrol	47		Rocker cover, side, 24 litre Diesel 133
	Mounting, engine, Diesel and	213		Piston, 2 litre Diesel	. 83		Rocker cover, top, 2 litre Petrol 15
	Ltre Petrol Mounting, body	271, 277		Piston, 21 litre Diesel			Rocker cover, top, 2½ litre Petrol 49
	Mounting, body Motor unit, hydraulic winch	403		Piston ring, 2 litre Petrol			Rocker cover, top, 2 litre Diesel 85
	1410tol tillt, hydraulic which	105		Piston ring, 21 litre Petrol	. 47		Rocker cover, top, 2½ litre Diesel 123
	51 1 1.1	259		Piston ring, 2 litre Diesel			Rod, hand brake 205
N	Number plate lamp	239		Piston ring, 24 litre Diesel			Rod, track 189
				Plate support, front winch, 2 litre			Roof, cab 359
0	Oil cooler, 2 litre Petrol	419		Petrol			Roof, hard top 329, 337, 345
	Oil cooler, 24 litre Petrol	427		Plate, support front wich, 24 litre	200		Roof, tropical, hard top 335, 343, 353
	Oil cooler, Diesel	423		Petrol and Diesel	4		Roof, tropical, 88 Station Wagon 489
	Oil filter adaptor, oil cooler, Die	esel 423		Plate, tow	07		Roof, tropical, 109 Station Wagon 513
	Oil filter, external, 2 litre, Petro	ol 25 ol 49		Plug, heater, 21 litre Diesel Plug, heater, 21 litre Diesel	100		Roof, 88 Station Wagon 489 Roof, 109 Station Wagon 513
	Oil filter, external, 2½ litre Petro			Plug, hot, 2 litre Diesel	0.5		
	Oil filter, external, 2 litre Diese Oil filter, external, 21 litre Dies			Plug, hot, 21 litre Diesel	122		Rope, hood 311, 321 Rope, bracket, front winch, 2 litre
		9		Plug, sparking, 2 litre Petrol	25		Petrol 395
	Oil pressure gauge, 2 litre Petro			Plug, sparking, 2½ litre Petrol			Rope, bracket, front winch, 2½ litre
	Oil pressure gauge, 2 ¹ / ₄ litre Pel	trol		Propeller shaft, front	176		Petrol and Diesel 401
	and Diesel	451		Propeller shaft, P.T.O	0.50		Rubber grommet, electrical 269
	Oil strainer, 2 litre Petrol	21		Propeller shaft, rear	1,3		Rubber pedal pads 477
	Oil strainer, 2½ litre Petrol	55		P.T.O., centre	. 369		Rubber seal, cab 359
	Oil strainer, 2 litre Diesel	93		P.T.O. drive unit, hydraulic wind	h 409		Rubber seal, hard top 331, 337, 347
	Oil strainer, 2½ litre Diesel	131		P.T.O. gearbox, drive housing	369		Rubber tube, bleeding brakes 474
	Oil pressure switch	25, 49, 87		P.T.O. housing, rear			-
	Oil pump, 2 litre Petrol	21		Pulley, P.T.O.	. 379		
	Oil pump, 24 litre Petrol	55		Pump, distributor, 2 litre Diesel	97 [0]		
	Oil pump, 2 litre Diesel	93		Pump, distributor, 21 litre Diesel	135	~	or the Party
	Oil nump, 21 litre Diesel	131			97, 101	S	Sealing ring, cylinder liner, Diesel,
	Oil pump, oil cooler, 2 litre Pet	trol 421		Pump, fuel, 2½ litre Diesel	400		2 litre 79 Seal rubber, cab 359
	Oil pump driving shaft, 2 litre	e		Pump, hydraulic winch	31		
	Petrol	21		Pump, oil, 2 litre Petrol	EE		Seal rubber, hard top 331, 337, 347 Seat backrest 289
	Oil pump driving shaft, 24 li	itre		Pump, oil, 2¼ litre Petrol Pump, oil, 2 litre Diesel	0/2		Seat backrest 289 Seat, centre, 109 Station Wagon 531
	Petrol	55		Pump, oil, 21 litre Diesel Pump, oil, 21 litre Diesel	101		Seat cushion 289
	Oil pump driving shaft, 2 li			Pump, fuel	25		Seat, rear 447
	Diesel	93		r cumps recor			

Description P	nge Description	Page	Description	Page
	01 Support bracket, steering column	187	Trim, de luxe, cab	363
	35 Support, engine, front, 2 litre Petro		Trim, doors and floor	365
	A7 Support, engine, front, 21 litre		Trimming materials	566
Selector, four-wheel drive	69 Petrol	43	T 1 1	215
	61 Support, engine, front, 2 litre		I yre, road wheel	215
	Diesel	79		
	Support, engine, front, 2½ litre	117		
	21 Diesel 75 Support plate, front winch, 2 litre	117		
	61 Petrol	393 U	Universal joint cover plates	449
	63 Support, engine, rear	155	• • • • • • • • • • • • • • • • • • • •	
	75 Support plate, front winch, 2½ litre			
	75 Petrol and Diesel	399		
Shaft, propeller, rear	73 Support, spare wheel	479 V	Valve guide, exhaust, 2 litre Petrol	9
	73 Suppressors, radio	479	Valve guide, exhaust, 2½ litre Petrol	49
	Switch, lamps	253	Valve guide, exhaust, 2 litre Diesel	85
		19, 87 253	Valve guide, exhaust, 2½ litre Diesel	123
	11 Switch, panel lights 97 Switch, starter, Petrol	253 253	Valve guide, inlet, 2 litre Petrol	15 40
	55 Switch, starter, Petrol Switch, starter and heater plug,	617	Valve guide, inlet, 24 litre Petrol Valve guide, inlet, 2 litre Diesel	49 85
	57 Diesel	253	Valve guide, inlet, 2 litre Diesel Valve guide, inlet, 2½ litre Diesel	123
	45 Switch, stop lamp	199	Valve, non-return, fuel filter, Diesel	144
Side screen 3	01 Swivel pin	179	97, 101	
Silencer, exhaust 2	37 Swivel pin housing	179	Ventilator, windscreen	305
Silicone grease	79 Synchronising clutch	157	Vibration damper, engine, 2 litre	11
	76		Vibration damper, transmission,	
	21 65	•	Diesel 109	207
	11		Voltage control box	261
	45			
Sparking plug, 2 litre Petrol	35			
	71	w	Warning light, fuel, Diesel	253
Speedometer 2	55	**	Water hose, radiator	243
	78 T Tailboard	299	Water pump, 2 litre Petrol	27
	55 Tailboard chain 273	, 279	Water pump, 21 litre Petrol	59
Tari and in the control of the contr	79 Tail lamp	259	Water pump, 2 litre Diesel	107
	75 Tank, brake and clutch supply Tank, petrol	219	Water pump, 21 litre Diesel	141
0	10 T 1 (1 T): 1	245 245	Water temperature gauge, 2 litre	440
	Tank, fuel, 109 Station Wagon	538	Petrol 21 l'a	449
	Tappet guide, 24 litre Petrol	53	Water temperature gauge, 2½ litre Petrol and Diesel	451
	Tappet guide, 2 litre Diesel	9 <u>í</u>	Wedge block for re-boring, 2 litre	401
Starter motor, 2 litre Diesel	Tappet guide, 21 litre Diesel	129	Petrol	474
	Tappet push rod, 2 litre Petrol	19	Wheel brace, divided rim wheels	476
	Tappet push rod, 21 litre Petrol	53	Wheel cylinder, brake 193, 195,	. 197
C. 1 1 1 1 1 1	Tappet push rod, 2 litre Diesel	91	Wheel, road	215
	Tappet push rod, 2½ litre Diesel Thermostat, 2 litre Petrol	129	Wheels, road, trailer	565
	0 T1 21 P. D. 1	27 59	Wheel, steering	185
	Thermostat, 2 litre Petrol Thermostat, 2 litre Diesel,	107	Winch, capstan, front, 2 litre Petrol Winch, capstan, front, 21 litre	391
Stop lamp 2	79 Thermostat, 21 litre Diesel	141	Datas I am J Dianal	397
Stop lever, Diesel 2	Thermostat housing, 2 litre Petrol	27	Winch budgette from	403
Strainer, oil, 2 litre Petrol	Thermostat housing, 21 litre Petrol	59	Winch shaft housing, front winch	
	Thermostat housing, 2 litre Diesel	107	393,	
	Thermostat housing, 24 litre Diesel	141	Windscreen	307
Stainer, oil, 2½ litre Diesel 13 Strap, hood 311, 33		17 51	Windscreen fastener	307
C. 1 1 14	1 7" 1 1 1 1 1 1 1	51 89	Windscreen wiper	261
	2 T 1 1111 D: 1	127	Windscreen, ventilator Wing, front	305 293
	7 Tools	568	Wi	293
	Towing jaw	453	Withdrawal clutch	165
Sump, crankcase, 21 litre Diesel 13	3 Tow plate	455	Worm wheel, front winch, 2 litre	199
Sump, crankcase, oil cooler 421, 425, 42	9 Track rod	189	Petrol	391
	Trailer	559	Worm wheel, front winch, 21 litre	
	5 Transfer box casing	153	Petrol and Diesel	397
	3 Transmission brake	205 505	Wrench for capstan winch, 2 litre Wrench for capstan winch, 21 litre	395


.



CYLINDER BLOCK, PETROL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.		REMARKS	
10	ENGINE AND CLUTCH ASSEMBLY		269216 †			
1	CYLINDER BLOCK ASSEMBLY	1	242570			
•	Block, crankshaft, pistons, camshaft, valve gea		269335			
2	Insert for exhaust valve seat	4	09065			
3	Valve guide, exhaust	4	511833	•		
4	Core plug 1" dia	2	09191			
5	Stud, short \ For oil	12	213472			
6	Stud, long sump	3	57126			
7	Stud for bottom rocker cover	3	242830			
8	Stud, long	2	09207			
	Stud, medium > For exhaust manifold	Į	265086	6		
9	Stud, short	2	01291			
	Stud, short \(\) For oil filter	2	09207			
10	Stull, long Sadaptor	2	241275			
11	Set bolt for main bearing, front and interme	ediate 4	233608			
12	Set bolt for main bearing, rear	2	233607			
13	Special spring washer for set bolt	6	243419			
14	Dowel, locating bearing caps	6	501593			
15	Dowel, locating flywheel housing	2	52124			
16.	Oil gallery pipe	2	09034			
17	Plug for gallery pipe, front	, 1	03129			
18	Plug for gallery pipe, rear]	216933			
19	Joint washer for rear plug]	3803			
20	Set bolt (1" B.S.F. x 5" long) Fixing galle	-	237140			
21	Locker Spipe to bloo		2995			
22	Cup plug	4	525428			
23	Water pipe, front In	ļ	231220			
24 25	Water pipe, rear ∫ cylinder block	l 1	231221		-	
25	Cover plate for rear water pipe	J	231218			
26 27	Joint washer for cover plate	}	231219			
27 28	Spring washer See L. M. P. S. F 5" L 2" Fixing	2	3074			
20 29	Set bolt (1" B.S.F. x \(\frac{5}{8}\)" long) \(\int \) cover plate Seal for rear main bearing cap	2	237140 511350			
30	Oil ning contro main bearing	Z	241103	•		
31	Stud for culinder head	· 2	212332			•
32	Extension for drain ton	2	243185			
33	Drain tap for cylinder block	1	243237			
34	Joint washer for drain tap and extension	2	213959			
35	Engine front support bracket complete L.H.	1	230655		•	
36	Engine front support bracket complete R.H.	1	239449			
37	Locker Fixing brack		212430			
38	Set bolt (½" B.S.F. x 32" long) to cylinder b		215485			
	Decarbonising gasket kit	1	269365			
	Engine overhaul gasket kit	1	270568	-		
	-					


CRANKSHAFT, PETROL ENGINE, 2 LITRE, Series II



CRANKSHAFT, PETROL ENGINE, 2 LITRE, Series II


					DELLA	170
PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.	REMARI	KS
1	CRANKSHAFT ASSEMBLY		1	241893	•	
	CRANKSHAFT ASSEMBLY	7, .010" U.S.	1	243255		
	CRANKSHAFT ASSEMBLY	Y, .020" U.S.	1		Home only	
	CRANKSHAFT ASSEMBLY	Y, .030" U.S.	1	243257		
	CRANKSHAFT ASSEMBLY	Y, .040" U.S.	1	243258		
2	Dowel for flywheel		1	6395		
3	Main bearing, front and rear,	Std.	4	239829		
	Main bearing, front and rear,	.010" U.S.	4	239830		
	Main bearing, front and rear,		4	239831		
	Main bearing, front and rear,		4	239832		
	Main bearing, front and rear,		lves 4	239833		
4	Main bearing, centre, Std.		2	239824		
	Main bearing, centre, .010" U.	.s. [.	2	239825		
	Main bearing, centre, .020" U.		2	239826		
	Main bearing, centre, .030" U	I	2	239827		
	Main bearing, centre, .040" U		2	239828		
5	Thrust washer for crankshaft,		2	239839		
	Thrust washer for crankshaft,		2	239840		
	Thrust washer for crankshaft,		2	239841		
	Thrust washer for crankshaft,		2	239842		
	Thrust washer for crankshaft,	.010" O.S.	2	240386		
6	Chainwheel on crankshaft		1	59054		
7	Key locating chainwheel		1	52015	9 m	
8	Oil thrower on crankshaft		1	59053		
	VIBRATION DAMPER AS	SEMBLY	1	215935		
9	DAMPER FLYWHEEL A	AND BUSH				
	ASSEMBLY		1	215936		
10	Bush for flywheel		1	03188		
11	Driving flange		1	09017		
12	Rubber disc for damper	· ····	2	03017		
13	Shim	•••	As requi			
14	Retaining plate	•••	1	03018		
15	Set screw (4" B.S.F. x & ")	long) fixing plate	to to			
	flywheel		6	03093		
16	Starting dog		1	503665		
17	Lock washer for starting dog		1	03092		
18	Crankshaft oil retainer		2	275807		
19	Dowel, lower	Fixing retainer	2	519064		
20	Dowel, upper	to cylinder	2	246464		
21	Spring washer	block and rear	6	3074		
22	Bolt (‡" B.S.F. x 7 long)	bearing cap	6	237142		

CONNECTING ROD AND PISTON, PETROL ENGINE, 2 LITRE, Series II



CONNECTING ROD AND PISTON, PETROL ENGINE, 2 LITRE, Series II


PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y. Part No	o. REMARKS
1	CONNECTING ROD ASSEMBLY		4 26573	7
2	Gudgeon pin bush		4 273163	
3	Special bolt Fixing connecti	ng	8 0788	4
4	Castle nut (% B.S.F.) frod cap		8 2102	
5	Split pin fixing connecting rod cap		8 2392	2
6	Connecting rod bearing halves, Std		8 23983	
	Connecting rod bearing halves, .010" U.S.		8 23983	5
	Connecting rod bearing halves, .020" U.S.		8 23983	6
	Connecting rod bearing halves, .030" U.S.		8 23983	
	Connecting rod bearing halves, .040" U.S.		8 23983	3
7	PISTON ASSEMBLY, STD	••••	4 27837	
	PISTON ASSEMBLY, .010" O.S		4 278373	
	PISTON ASSEMBLY, .020" O.S		4 27837	
	PISTON ASSEMBLY, .030" O.S		4 278375	
	PISTON ASSEMBLY, .040" O.S		4 278370	
8	Piston ring, compression, Std.		8 23115	5
	Piston ring, compression, .010" O.S.		8 23617	3
	Piston ring, compression, .020" O.S.		8 23617	4
	Piston ring, compression, .030" O.S.		8 23617	5
	Piston ring, compression, .040" O.S.		8 23617	6
9	Maxilite scraper ring, Std		4 23481	
	Maxilite scraper ring, .010" O.S		4 23618	3
	Maxilite scraper ring, .020" O.S		4 23618	4
	Maxilite scraper ring, .030" O.S	••••	4 23618	5
	Maxilite scraper ring, .040" O.S	••••	4 23618	6
10	Gudgeon pin, Std	••••	4 26456	
	Gudgeon pin, .001" O.S	••••	4 26725	
	Gudgeon pin, .003" O.S	••••	4 26725	
11	Circlip for gudgeon pin	••••	8 23510	0



CYLINDER HEAD, PETROL ENGINE, 2 LITRE, Series II


	CYLINDER READ, FEI	NOL	EHOHIL,	
PLATE	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
REF.	CYLINDER HEAD ASSEMBLY	1	233430	
2	Valve guide and rubber ring, inlet	4	266924	
3	Rubber ring for inlet valve guide	4	233419	
4	Dowel, locating rocker brackets	6	59059	
5	Stud, short \ For rocker	3	9499	
6	Stud, long brackets	1	3604	
7	Stud for top rocker cover	3	6316	
8	Stud \ \ For inlet	6	212098	
9	Stud for centre branch smanifold	4	243531	
10	Rear end cover for cylinder head	1	213810	
11	Joint washer for rear end cover	1	213811	
12	Spring washer Fixing rear	4	3075	
13	Set bolt $(\frac{5}{16}"$ B.S.F. x \rightarrow end cover to			
	§" long) cylinder head	4		
14	Thermostat switch for choke warning light	1	213574	
15	Spring washer Fixing	2		
16	Set bolt (2 B.A. x ¾ long) ∫ switch	2		
17	Cylinder head gasket	1	269476	
18	Spring washer	2		
19	Special nut Fixing cylinder	2		
20	Special set bolt, short head to cylinder	4		
21	Special set bolt, medium block	4		
22	Special set bolt, long	6		
23	ROCKER COVER, TOP, ASSEMBLY	إ	246340	
24	Tappet clearance plate		213245	
25	Drive screw fixing plate	4	78001	
26	Joint washer for top rocker cover		267781	
27	Fibre washer Fixing top		3055	
28	Special nut \int \text{rocker cover}	1	3 279330 1 230996	
29	Breather filter for top cover—AC 7222264			
30	Set screw fixing breather	•	231144	

CAMSHAFT AND TENSIONER MECHANISM, PETROL ENGINE, 2 LITRE, Series II



CAMSHAFT AND TENSIONER MECHANISM, PETROL ENGINE, 2 LITRE, Series II


PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.	REMARKS
1	Camshaft		1	511036	
2	Bearing complete for camshaft, front		1	09091	
3	Bearing complete for camshaft, centre and rea	r	3	23307 2	
4	Dowel for camshaft bearing		8	09208	
5	Locking plate \(\) Fixing camshaft bearings		4	09205	
6	Special set screw to cylinder block		4	213251	•
7	Rear end cover for carnshaft		1	219914	
8	Joint washer for cover		1	219913	
9	Set bolt (4" B.S.F. x 5" long) fixing cover to bl	ock	3	237140	
10	Thrust plate for camshaft		1	277063	
11	Locker Fixing		3	2500	
12	Set bolt ($\frac{1}{4}$ " B.S.F. x $\frac{5}{8}$ " > thrust plate to				•
	long) cylinder block		3	237140	
13	Chainwheel for camshaft		1	09023	
14	Key locating camshaft chainwheel		1	230313	
15	Retaining washer Fixing		1	09093	
16	Locker >chain wheel		1	09210	
17	Set bolt (§ B.S.F. x § long) J to camshaft		1	237187	
18	Camshaft chain (% pitch x 78 links)	:	1	09156	
19	Pivot pin for chain adjuster arm	••••	1	212365	
20	Adjuster arm for timing chain		1	212363	
21	Circlip fixing adjuster arm to pivot pin	••••	1	09129	•
22	Pawl for tensioner arm		1	213600	
23	Pawl spring		1	213601	·
24	Pawl pin		1	213602	
25	Anchor pin for spring		1	214131	
26	Spindle for timing chain adjuster idler wheel	••••	1	212364	•
27	Idler wheel for timing chain		I	09075	
28	Steel washer \ Fixing idler wheel		2	09126	
29	Circlip		1	09128	
3 0	CYLINDER ASSEMBLY FOR TIMING				
	CHAIN ADJUSTER		1	265331	-
31	Steel ball (36") for non-return valve	••••	l	3746	
32	Spring retaining ball in cylinder	****	Ī	212339	
33	Retainer for steel ball	••••	1	219489	
34	Spring For timing		1	212340	
35	Piston Schain adjuster	•	j	219504	
36	Pivot pin for chain adjuster piston	••••	1	212341	• *
37	Steel washer Fixing chain adjuster	••••	1	210679	
38	Split pin fpiston to pivot pin		I	2555	



VALVE GEAR AND ROCKER SHAFTS, PETROL ENGINE, 2 LITRE, Series II


PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
1	Inlet valve		4	233427	
2	Exhaust valve		4	264137	
3	Valve spring, inner and outer		8	2 73 257	
4	Rubber sealing ring for valve, inlet		4	233419	
5	Valve spring cup, inlet	****	4	212137	•
6	Valve spring cup, exhaust	****	4	212137	
7	Split cone for valve, pair		8	09906	
8	VALVE ROCKER ASSEMBLY, INLE	ET L.H.	2	214351	
9	VALVE ROCKER ASSEMBLY, INLE	ET R.H.	2	214350	
10	Bush for inlet valve rocker		4	214348	•
11	Valve rocker, exhaust L.H		2	239547	
12	Valve rocker, exhaust R.H	••••	2	239546	
13	Inlet cam follower L.H		2	239545	
14	Inlet cam follower R.H		2	239544	
15	Tappet push rod, inlet	****	4	09122	
16	Tappet adjusting screw, inlet	****	4	236151	
17	TAPPET ADJUSTING SCREW ASSE	MBLY,			
	EXHAUST		4	506818	
18	Cap for exhaust tappet adjusting screw		4	212160	
19	Circlip fixing cap		4	212161	
20	Locknut for tappet adjusting screw		8	2842	
21	Valve rocker shaft, top		1	23105 7	
22	Rocker bracket, oil feed, top		1	212328	
23	Rocker bracket, intermediate, top		2	212329	
24	Rocker bracket, clamping, top		3	212330	
25	Spring for rocker shaft, top		4	502006	
26	Locating screw \ For rocker shaft		1	09004	
27	Locating plate \int at oil feed bracket		1	09005	
28	Nut $(\frac{5}{16}"$ B.S.F.) fixing rocker bracket to	cylinder			
	head		4	3490	•
29	Valve rocker shaft, bottom		2	239089	
30	Spring for rocker shaft, bottom		4	500610	
31	Thrust washer for rocker shaft, bottom		4	09159	
32	Locating plate \(\) Fixing bottom rocker		2	09005	
33	Locating screw shafts to cylinder bloc	k	2	09004	
34	End plug, rear For		1	3088	
35	Fibre washer for rear plug > bottom		1	3055	
36	End plug, front J rocker shaft		1	12455	

OIL PUMP, PETROL ENGINE, 2 LITRE, Series II




OIL PUMP, PETROL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	OIL PUMP ASSEMBLY	1	240651	
ī	OIL PUMP BODY ASSEMBLY	1	501253	
2	Bush for drive shaft	1	212309	•
3	Oil pump shield	1	09225	
4	Oil pump gear, driver	1	09027	
5	OIL PUMP COVER ASSEMBLY	1	234296	
6	Dowel locating body	2	52710	
7	Spindle for idler wheel	1	09050	
8	Self-locking nut (%") fixing spindle	1	265055	
9	Stud for oil strainer	1	234291	
10	OIL PUMP GEAR IDLER ASSEMBLY	7 1	212375	
11	Bush for idler gear	1	09049	
12	Bolt ($\frac{5}{18}$ " B.S.F. x $2\frac{1}{2}$ " long) \int Fixing cover	4	237170	
13	Self-locking nut $\binom{5}{18}$ \int to body	4	251321	
14	Oil strainer for pump	1	266900	
15	Castle nut (‡" B.S.F.) Fixing oil strainer	1	251600	
16	Split pin ∫ to pump	1	2422	
17	DISTRIBUTOR HOUSING ASSEMBLY	1	214047	
18	Bush for drive shaft	1	09025	
19	Cork washer for housing	1	522 7 8	
20	Oil pump drive shaft	1	235083	
21	Drive shaft for distributor	1	267829	
22	Oil pump driving gear	1	212308	
23	Taper pin, fixing gear to shaft	1	3005	
24	Steel ball	1	01035	
25	Plunger	1	245940	•
26	Spring For oil pressure	1	24264 8	
27	Adjusting screw release valve	1	242889	
28	Washer	1	230508	
29	Locknut	1	12028	
30	Special set screw \ Fixing oil pump	1	241267	
31	Locknut \int to cylinder block	1	2828	
3 2	Oil feed bolt, locating distributor housing	1	09052	
33	Locker for bolt	1	2504	




FRONT COVER, SIDE COVER AND SUMP, PETROL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
i	FRONT COVER ASSEMBLY	. 1	236018	
2	Dowel locating front cover	. 2	6395	
3	Oil seal for front cover	. 1	21 3744	
4	Mud excluder	. 1	236011	
5	Hammer drive screw fixing excluder	. 8	3936	
6	Joint washer for front cover	1	09102	
7	Spring washer Fixing	11	3075	
	Plain washer front cover	1	2550	
8	Set bolt $(\frac{5}{16}"$ B.S.F. x $1\frac{29}{32}"$ long) \Rightarrow and	10	250530	
9	Set bolt $(\frac{5}{16}"$ B.S.F. x $2\frac{1}{4}"$ long) water pipe to	1	250531	
10	Distance piece cylinder bloc	k 1	59155	
11	Rocker cover, side	1	236003	
12	Joint washer for rocker cover	1	267779	
13	Special nut fixing side rocker cover		268543	
14	Sealing washer for nut	3	267828	
15	Oil filler cap and breather filter—AC 7222073	- 1	236406	
16	Crankcase sump	1	246201	•
17	Drain plug for crankcase sump	1	3 088	
18	Washer for drain plug	1	230507	
19	Joint washer for crankcase sump	1	267780	
20	Rubber seal } For	1	231480	
21	Packing strip rear end of	1	23 147 9	
22	Distance piece crankcase sump	3		
23	Set bolt $(\frac{5}{16}$ Whit. x $\frac{11}{16}$ long) Fixing sump	2		
24	Spring washer \rightarrow to cylinder	17		
25	Nut (5 B.S.F.) J block	15		
26	Cover plate for breather aperture	1	236435	
27	Joint washer Fixing breather	1		
28	Spring washer pipe or cover pl			
29	Set bolt $(\frac{5}{16}"B.S.F. \times \frac{3}{4}" \text{long})$ to cylinder block	k 2		
30		[
31		J	210517	
32	Tube for oil level rod	1	236922	
33	_	[236393	
34	Bolt (2 B.A. x ½" long)	1	234603	
35	Spring washer Fixing bracket]	3073	
36	Nut (2 B.A.)	1	2247	
37	Double-ended union	1	236060	
38	Washer Fixing tube to	1	243958	
39	Olive cylinder block	1		
40	Union nut	1	236407	



OIL FILTER AND OIL PIPES, PETROL ENGINE, 2 LITRE, Series II


PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
1	Oil filter for engine, AC JF 1531078		1	240326	
2	Element, AC FF 24		1	246262	
3	Gasket, large >For o	il filter	1	246261	
4	Gasket, small AC 1530635		2	277611	
	Rubber washer for centre bolt—AC 15	31098	1	269889	
5	Joint washer for oil filter to adaptor		1	272839	
6	Bolt (7 Whit. x) Fixing filter				
	$1\frac{5}{32}$ long) \Rightarrow to adaptor on		2	240308	
7	Spring washer cylinder block		2	3077	
8	Adaptor for oil filter		1	241166	
9	Packing washer, top \(\) For oil filter adap	ptor	2	4095	
10	Joint washer, bottom fto cylinder block		1	268472	•
11	Spring washer \ Fixing adaptor to		4	3076	
12	Nut $\binom{3^n}{8}$ B.S.F.) \int cylinder block		4	2827	
13	Plug \(\) For adaptor		2	250978	
14	Joint washer ∫oil way		2	231577	
15	Oil pipe complete to cylinder head		1	267981	
16	Banjo bolt, oil pipe to cylinder head		1	500457	
18	Banjo bolt, oil pipe to cylinder block	•	1	233520	
19	Joint washer for banjo bolts		4	231575	•
20	Oil pressure switch	••••	1	519863	
21	Joint washer for switch		1	232039	



WATER PUMP AND THERMOSTAT, PETROL ENGINE, 2 LITRE, Series II

			ENGINE, 2 LITAE, Series II
PLATE REF.	1 2 3 4 DESCRIPTION Qty	. Part No.	REMARKS
	WATER PUMP ASSEMBLY 1	269974	<u> </u>
1	Water pump casing with washer 1	271572	ex 2 x
2	Water deflector washer 1	266985	
3	Pump spindle and bearing 1	213695~	
4	Hub for fan 1	213698 -	
5	Carbon ring and seal unit	239855	
6	Impeller for pump 1	242329	
7	Spring washer \(\) Locating \(\) 1	3074	
8	Set bolt (¼" B.S.F. x ¾" long) ∫ bearing casing 1	211064	
. 9	Joint washer for water pump 1	09118	
10	Spring washer Fixing water 8	3074	
11	Set bolt ($\frac{1}{4}$ " B.S.F. x $1\frac{1}{2}$ " long) > pump to 7	250518	
13	Set bolt (1" B.S.F. x 21" long) cylinder block	237150	
14	Inlet pipe for water pump i	277508	
15	Joint washer for inlet pipe 1	213724	•
16	Spring washer \(\) Fixing pipe 2		•
17	Set bolt $(\frac{5}{16}"$ Whit. $x + \frac{11}{16}"$ long) \int to water pump 2		
18	Rubber joint ring \(\) Connecting water pump 1	09170	
19	Copper tube \int to thermostat housing	09197	
20	THERMOSTAT HOUSING ASSEMBLY 1	263670	•
21	Stud for outlet pipe 3		
22	Stud for inlet pipe 2		
23	Joint washer for thermostat housing 1	213811	
24	Spring washer Fixing thermo- 1	3075	
25	Set bolt $(\frac{5}{16}"$ B.S.F. x $2\frac{19}{32}"$ long) > stat housing to 1	215180	
26	Set bolt (5 B.S.F. x 3 long) cylinder head 3		
27	Thermostat, AC 1572249 1	513649	
28	Fibre washer for thermostat 2	· ·	
29	Water outlet pipe, thermostat to radiator 1	263607	
3 0	Spring washer Fixing outlet pipe 3		
31	Nut (¼" B.S.F. ∫ to thermostat 3		
32	Water inlet elbow to thermostat	263630	
33	Joint washer for inlet elbow 1	210419	
34	Spring washer Fixing elbow to 2		
35	Nut (‡" B.S.F.) \int thermostat housing 2		
36	Water outlet pipe from manifold 1	242055	
37	Joint washer for outlet pipe 1	210419	•
38	Spring washer Fixing water outlet 2		
39	Nut (‡" B.S.F.) \int pipe to manifold 2		-,
40	Rubber hose Connecting water pipe	242056	
41	Clip for hose \int to inlet elbow 2		•
42	Fan pulley 1	230492	
43	Distance piece for fan pulley 1	501568 271569	
44 45	Fan blade l	271568 244317	
45 46	Reinforcing plate for fan blade 1		
46 47	Spring washer Fixing fan blade 4 San belt (1" P.S.F. of 1" been 1" b		
47 49	Set bolt (1" B.S.F. x 1" long) \int and pulley to hub 4		
48	Fan and dynamo belt 1	2107/0	


CARBURETTER, PETROL ENGINE, 2 LITRE, Series II



CARBURETTER, PETROL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIP			Part No.	
KET.	CARBURETTER COMP			· · · · · · · · · · · · · · · · · · ·	
	PB 1/2		1	264664	Carburetter and fittings are not included in the engine assembly
1	Carburetter body only, S	SX 10346	1	261584	
2	Throttle chamber only,	SX 10183	1	260700	
3	Spindle for throttle, SX	50269	1	260702	
4	Butterfly for throttle, SX	ζ 52194	1	260704	
5	Special screw fixing butt	erfly, SX 3947	2	260138	4
6	Plate, throttle abutment,	SX 4019	1	260139	••
7	Special screw, SX 4023	For slow runnir	ng 1	260140	
8	Spring, SX 4384	∫ adjustment	1	260141	
9	Special screw, SX 50537	₹ For throttle	1	260142	
10	Locknut, SX 3950	∫stop	. 1	260143	
11	Throttle lever, SX 10396	5	1	243920	X.
12	Nut fixing throttle lever,	SX 4024	1	260159	•
13	Lockwasher for nut, SX	1017	· 1	261 59 4	
14	Special screw, SX 1171	For mixture	1	260146	
15	Spring, SX 4384	control	1	260141	
16	Screwed union, SX 9879		1	260707	•
17	Olive, SX 5041	∫ pipe	1	260708	
18	Joint washer for throttle	chamber, SX 527	88 1	260754	
19	Special screw and wash		fixing		
	chamber to carburet	tter body	4	513174	
21	Starter body, SX 52778		1	261580	· ·
22	Starter valve complete, S		1	261581	
23	,	or starter	. 1	260155	
24	Spring, SX 51762 $\int v$			260156	4
25	Plug retaining starter				
	51274/1	1	I	261508	
26	Lever for starter, SX 98		l	261582	
27	Special washer for lever,		[261410	
28	Nut fixing starter lever,		1	260159	
29	Special bolt fixing starte			265495	
30	Special screw fixing star		2/12 4	262313	
31	Accelerator pump compl		I	261562	•
	Diaphragm for pump,		4	243394	
32	Joint washer for pump,		I	260739	
33	Special screw fixing pun		4	260737	
34	Choke tube (25), SX 528		I	262659	
35	Special screw fixing cho			260163	
36	Jet, economy (75)	 	I	261974 260734	
37	Fibre washer for jet, SX		l	268568	
38 20	Non-return valve (1.5 m Fibre washer for valve, 2			260734	
39 40	Jet (75) accelerator pum			262448	
40 41	Fibre washer for jet, SX		i	260734	
41 42	· · · · · · · · · · · · · · · · ·		l	260732	
42 43	Pump injector, SX 5295 Joint washer for pump,		l 5 1	261570	
43 44	Special screw fixing inje		1	260767	
45	Main jet (115), SX 5055		1	260173	
40	Iviani jet (117), SA 3033	Δ ₍ (0) 113	1	200175	

SEE PAGE 31 FOR SUB-STANDARD JETS




CARBURETTER, PETROL ENGINE, 2 LITRE, Series II

	CAMBORDITER, 121.				· · · · · · · · · · · · · · · · · · ·
PLATE ŘEF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
46	Bolt, main jet carrier, SX 50820		1	260180	•
47	Fibre washer for bolt, SX 50815		1	260181	
48	Correction jet (240), SX 51612/240		1	260266	
49	Emulsion tube, SX 52684		1	260743	
50	Pilot jet (55), SX 50797/4/55		1	260269	
51	Jet air bleed (1.5), SX 51274/15		1	260179	•
52	Starter jet, petrol (135), SX 52823/135		I	260752	*
53	Fibre washer for jet, SX 52825	•···	1	260734	
54	Starter jet, air (5.5), SX 50906/55		1	260719	
55	Float, SX 51638/1		1	260745	
56	Toggle for float, SX 52180		1	260753	
57	Spindle for toggle, SX 52204	, .	1	260747	
58	Needle valve complete, SX 51305/17		ı	260164	
59	Fibre washer for valve, SX 1019		ı	260165	
60	Top cover for carburetter, SX 9946		1	260721	
61	Joint washer for top cover, SX 52787		1	260749	
62	Special screw fixing top cover, SX 12869		3	512401	
63	Spring washer for screw, SX 971	•	3	260714	
64	Banjo union, SX 4120/5		!	260166	
65	Special bolt for union, SX 4122	•	ŀ	260167	
66	Filter gauze for union, SX 4123		1	260168	
67	Fibre washer, large, SX 4124 For		1	260169	
68	Fibre washer, small, SX 4124/1 Junion		1	260170	
6 9	Lever for accelerator pump rod, SX 10692	••••	1	261564	
70	Special washer for lever, SX 4031/1		I	261410	•
71	Nut fixing lever to spindle, SX 4024		I	260159	•
72	Control rod for accelerator pump, SX 0775		1	262312	
73	Split pin		2	3359	
74	Plain washer, SX 52760 For control rod		2	260771	
75	Spring, SX 11051		l	240689	WILL CO. C. Cu-I
	Spring, SX 2979/1		1	237774	When Engine Governor is fitted

CARBURETTER SETTINGS WHICH MAY BE ADVANTAGEOUS FOR HIGH ALTITUDES OR TROPICAL CONDITIONS


The state of the s			
Main jet (110), SX 50552/6/110 Air bleed jet (2.0), SX 51274/2.0	·····	 1	260274 260275 3,000 to 6,000 ft.
Main jet (107.5), SX 50552/6/107.5 Air bleed jet (2.0), SX 51274/2.0	••••	 1	261563 260275 6,000 to 10,000 ft.
Choke tube (26), SX 51210/26 Main jet (107.5), SX 50552/6/107.5 Air bleed jet (2.0), SX 51274/2.0 Correction jet (260), SX 51612/260		 1 1 1	262647 261563 260275 273788
Main jet (110), SX 50552/6/110	****	 1	260274 Tropical conditions

MANIFOLDS, PETROL ENGINE, 2 LITRE, Series II



MANIFOLDS, PETROL ENGINE, 2 LITRE, Series II


	WANII OLDS, I LII				
PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
1	CARBURETTER COMPLETE		1	264664	For component parts, see Pages 29 and 31
2	Joint washer for carburetter		2	212233	
3	Packing for carburetter		1	212232	
4	Spring washer \(\) Fixing carburetter		2	3075	
5	Nut ($\frac{5}{16}$ " B.S.F.) \int to manifold		2	2828	
. 6	Suction pipe complete, carburetter to distribu	tor	1	214231	
7	Nipple \ For suction pipe,		1	3787	
8	Nut ∫distributor end		Ī	3783	
9	Screwed union \ For suction pipe,		1	260707	
10	Olive \int carburetter end		1	260708	
11	Clip for suction pipe		1	214228	
12	Rubber grommet for clip		1	214229	
13	INLET MANIFOLD ASSEMBLY		1	218954	
14	Stud for carburetter		2	214054	
15	Stud for water outlet pipe		2	212104	
16	Dowel ring for carburetter		1	214019	
17	Joint washer, manifold to cylinder head		2	09179	-
18	Joint washer, water branch to cylinder head		1	210447	•
19	Spring washer \ Fixing manifold to		6	3075	
20	Nut (16" B.S.F.) \(\int \) cylinder head		6	2828	
21	Spring washer \(\) Fixing water branch		4	3074	
22	Nut (1" B.S.F.) to cylinder head		4	2823	
23	Spindle for carburetter bell crank and levers		1	240306	
24	CARBURETTER BELL CRANK ASSEMB	LY	1	240181	
25	CARBURETTER RELAY LEVER				
	ASSEMBLY		1	240180	
26	Bush for lever		1	240303	
27	Ball end for lever		1	1481	
28	Plain washer \(\) Fixing bell crank and		1	2210	•
29	Split pin Severs to spindle		1	2392	
30	ROD ASSEMBLY, BELL CRANK TO				
	CARBURETTER		1	231267	•
31	Ball joint complete		2	231261	
32	Locknut (1" B.S.F.) for ball joint		2	2823	
33	Spring washer \(\) Fixing rod to bell crank		2	3074	
34	Nut (1" B.S.F.) and carburetter		2	2823	
35	EXHAUST MANIFOLD ASSEMBLY		1	237978	
36	Stud for exhaust pipe		4	213472	
37	Joint washer for exhaust manifold		2	09184	
38	Clamp, centre \ For exhaust		1	09162	
39	Clamp, outer manifold		2	09161	
40	Spring washer \ For exhaust		3	3076	
41	Nut (3" B.S.F.) manifold clamps		3	2827	
42	Spring washer Fixing ends of		2	3075	
43	Nut (16" B.S.F.) exhaust manifold		2	2828	
44	Joint washer for exhaust pipe		1	213358	
45	Spring washer \ Fixing pipe		4	3075	
46	Nut (16" B.S.F.) to manifold		4	3771	



DISTRIBUTOR AND STARTER, PETROL ENGINE, 2 LITRE, Series II


	DISTRIBUTOR AND STARTI				
PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty. I	Part No.	REMARKS
	Distributor complete, LU 40504A		1	269240	
2	Distributor cap complete, LU 418871		1	245004	
3	Brush and spring for cap, LU 418856		1	262703	
4	Rotor arm, LU 400051		1	245005	÷
5	Contact breaker points, set, LU 423153		1	269987	
6	Condenser for distributor, LU 421267		1	269988	
7	Auto advance springs, set, LU 416159/S		1	245009	
8	Auto advance weight, LU 410033/S		1	262708	
9	Vacuum unit, LU 54411727		Ĺ	269989	
10	Cam for distributor, LU 496078		1	245008	
11	Shaft for distributor, LU 419689		1	269990	
12	Bush for distributor shaft, LU 419430	• • • • • • • • • • • • • • • • • • • •	1	245012	•
. 13	Driving dog for distributor, LU 410601		1	245014	
14	Clamping plate for distributor, LU 420151		1	245003	•
15	Clip for cover, LU 425765		2	245013	
	Sundry parts kit, LU 419644		1	245015	
16	Cork washer for distributor housing		1	52278	
17	Special set bolt		1	215758	
18	Spring washer Fixing distributor lever		1	3074	
19	Plain washer		1	3911	
	Rubber insulator for distributor L.T. lead,	LU			
	419882		1	246560	
20	Sparking plug, Lodge CLNH	•	4		Alternatives.
	Sparking plug, Champion N8		4		Check before ordering
21	Washer for sparking plug		4	40441	
22	Suppressor for sparking plug		4	240138	
23	Sparking plug cover		4	214262	
24	Rubber sealing ring for cover		4	213172	
25	Cable nut, LU 410600		4	214278	
26	Washer for cable nut, LU 185015	••••	4	214279	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1
,* 6.	Resistor for distributor lead		1	213646	
	H.T. Wire	Asre	equired	80603	• •
27	Starter motor complete, LU 25533D		1	236287	
28	Bracket for starter, commutator end, LU 256	748	1	244706	
29	Bracket, drive end, LU 256495		1	244713	
30	Armature, LU 255463		1	244715	
31	Bush, commutator end, LU 255491		1 .	242958	
32	Bush, pinion end, LU 270038		1	244714	·
33	Pinion and sleeve, LU 255194		1	244711	
34	Spring for pinion, LU 255728		1	244712	
35	Main spring for pinion, LU 270889		1	244710	, - -
36	Nut for pinion, LU 255851		1	244709	
37	Field coil for starter, LU 255625		1	2 44 716	
	·				

DISTRIBUTOR AND STARTER, PETROL ENGINE, 2 LITRE, Series II



DISTRIBUTOR AND STARTER, PETROL ENGINE, 2 LITRE, Series II


PLATE REF.	1 2 3 4 DESCRIPTI	ON ()ty.	Part No.	REMARKS
38	Brushes for starter motor,	set, LU 255659	2	260055	
39	Spring set for brushes, LU	238062	1	244708	
40	Bolt for bracket, LU 25545	9	2	244717	
41	Cover band, LU 255557		1	2 447 05	
42	Grease cap, LU 255854		1	243095	
	Sundry parts kit, LU 25676	62	1	2 447 18	
	Set boli 3" Whit. x 1" long))	1	215703	
43	Bolt (3" B.S.F. x 12" long)	Fixing starter to	1	250543	
44	Spring washer	flywheel housing	2	3076	
45	Nut (3" B.S.F.)	J	1	2827	



DYNAMO AND FIXINGS, PETROL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	Dynamo complete, LU 22258E	1	270095	
2	Bracket, commutator end, LU 227702	1	242669	
3	Armature for dynamo, LU 227693	1	242674	
4	Brushes for dynamo, set, LU 227305	1	261483	
5	Spring set for brushes, LU 228159	1	261238	•
6	Field coil for dynamo, LU 227291	1	262860	
7	Ball bearing for dynamo, LU 189307	1	242672	•
8	Bush, commutator end, LU 227818	1	271614	
9	Bracket, drive end, LU 227698	1	242673	
10	Oiler for dynamo, LU 227914	1	271615	
11	Bolt for dynamo, LU 228336	2	242675	
12	Terminal for dynamo, LU 227625	1	264436	
•	Sundry parts, set, LU 227726	1	242676	
13	Pulley for dynamo	i	236360	
14	Woodruff key (No. 5), LU 189340 Fixing	Ţ	240270	
15	Lock washer > pulley to	1	217781	
16	Special nut J dynamo	1	240271	
17	Support bracket for dynamo	2	210572	
18	Spring washer Fixing suppo	rt 2	3075	-
19	Set bolt $(\frac{5}{16}"$ B.S.F. $\times \frac{3}{4}"$ bracket to			•
	long) cylinder bloc	k 2	237325	
20	Bolt $\binom{5}{16}$ B.S.F. x $2\frac{13}{16}$ long) front	1	237333	
21	Distance piece, front Fixing	1	217780	
22	Bolt $\binom{5}{16}$ B.S.F. x $\binom{19}{32}$ long) rear \Rightarrow dynamo		237329	
23	Spring washer anchor	2	3075	
24	Nut $(\frac{5}{16}"$ B.S.F.) \int bracket	s 2	2828	
25	Adjusting link for dynamo	1	217767	
26	Special set bolt Fixing	1	253027	
27	Plain washer > adjusting link	1	3868	
28	Spring washer J to dynamo	1	3075	
29	Set bolt $(\frac{5}{16}" B.S.F. \times 2\frac{1}{4}" long)$ Fixing adju-	ısting 1	250531	
30	Spring washer blink to	1	3075	
31	Distance piece J cylinder bl	lock 1	210566	


FLYWHEEL AND CLUTCH, PETROL ENGINE, 2 LITRE, Series II



FLYWHEEL AND CLUTCH, PETROL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPT	ION	Qty.	Part No.	REMARKS
1	FLYWHEEL HOUSING A	ASSEMBLY	1	246338	
2	Stud (8" B.S.F.) \ Fixing		12	3650	
3	Stud ($\frac{5}{16}$ " B.S.F.) \int to bell	l housing	1	3200	
4	Stud (1" B.S.F.) fixing inst	pection cover .	2	3651	
5	Inspection cover plate		1	56140	
6	Joint washer for cover plate	···· ··· ·	1	50216	
7	Nut (\frac{1}{2}" B.S.F.) fixing cover 1	plate	2	2823	
8	Bolt (🖁 B.S.F. x 1🖁 long) 🗋		6	250542	
9	Bolt (3 B.S.F. x 13 long)	Fixing	2	237179	
10	Spring washer	≻flywheel housing	8	3076	
11	Plain washer	to cylinder block	6	2219	
12	Nut (₹" B.S.F.)		6	2827	
13	Indicator for ignition timing		1	239820	
14			1	3290	
15	FLYWHEEL ASSEMBLY		1	272661	
			1	246330	
16			6	237324	
17			6	265260	
18	Dowel locating clutch cover	-	2	502116	
19			1	08566	
20	Locker Fixing flyv		3	3674	
21	Special set bolt \int to cranksh		6	210211	,
	CLUTCH ASSEMBLY, BI]	231879	
22	Cover plate for clutch, BB		!	231888	
23	Pressure plate for clutch, E]	231880	
24	Release lever for clutch, Bl		3	242993	
25	Strut for release lever, BB		3	231884	
26	Eyebolt and nut for release		3	242996	
27	Pin for release lever, BB 42		3	231885	
28	Anti-rattle spring for release		3	231883	
29	Clutch spring (cream), BB		9	231881	Pale: a)
30	Clutch plate complete, BB 47		1	240404	Ferodo lining Alternatives
	Clutch plate complete, BB 47	•	1	511682	Mintex lining
	Lining package for clutch	•]	261921	Ferodo lining Alternatives
	Lining package for clutch	plate, BB,KL/5021	- 1	512706	Mintex lining


CYLINDER BLOCK, PETROL ENGINE, 21 LITRE, Series II and IIA



CYLINDER BLOCK, PETROL ENGINE, 21 LITRE, Series II and IIA


PLATE	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
REF.	ENGINE AND CLUTCH ASSEMBLY	1	524138 Series II models
	ENGINE AND CLUTCH ASSEMBLY	1	524848*†Series IIA models
1	CYLINDER BLOCK ASSEMBLY	1	500129 Series II models
•	CYLINDER BLOCK ASSEMBLY	1	518725* Series IIA models
2	Core plug 1½" dia	1	512412
3	Core plug 1" dia.	1	09191
4	Core plug 1½" dia.	2	250840
5	Cup plug	3	525428
6	Stud	1	247208 Series II models
7	Stud > For front cover and water pump	1	247869 Series 11 models
	Stud	1	514527* Series IIA models
8	Stud for distributor adaptor	3	252622
	Stud for sump	1	252621
9	Set bolt for main bearing	6	247755 Plain type
10	Special spring washer for set bolt	6	247758 set bolt Alternatives, check before ordering
	Set bolt for main bearings	6	504007 Waisted type
	Special plain washer for set bolt	6	504006∫ set bolt
11	Dowel, locating main bearing and bearing of	сар б	501593
12	Dowel, locating flywheel housing	2	52124
13	Dowel for timing chain adjuster	2	213700
14	Plug for oil gallery, front	1	247127
15	Plug for oil gallery, rear	1	250978
16	Joint washer for rear plug	1	243959
17	Plug for tappet feed gallery pipe, front	1	247861
18	Plug for tappet feed gallery pipe, rear]	273166
19	Joint washer for plug]	243968
20	Plug for redundant heater hole	1	277496
22	Packing for rear main bearing cap	2	524637
23	Drain tap for cylinder block	1	243237
24	Joint washer for drain tap	I	213959
25	Engine front support bracket complete, L.H.		268635 Up to engines numbered 151023739
26	Engine front support bracket complete, R.H.		271975 Cop to engines numbered 191029799 516136 From engines numbered
	Engine front support bracket complete, L.H.		516133 151023740 onwards
27	Engine front support bracket complete, R.H.	••••	212430 151025740 onwards
27	Locker Fixing bracket		255085
28	Set bolt (½" U.N.F. x 1" long) fo cylinder bl		501676)
	Decarbonising gasket kit Engine overhaul gasket kit	•	501677 Series II models
	Decarbonising gasket set	1	· · · · · · · · · · · · · · · · · · ·
	Engine overhaul gasket set	1	525857* 525856* Series IIA models
	Englic overnaut gasket set	1	J. 0.70 J

CRANKSHAFT, PETROL ENGINE, 21 LITRE, Series II and IIA




CRANKSHAFT, PETROL ENGINE, 21 LITRE, Series II and IIA

	CRANKSHAFI, PEIRUL	ENGIN	24	
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	CRANKSHAFT ASSEMBLY, STD.	1	514526	1
•	CRANKSHAFT ASSEMBLY, .010" U.S.		269912	
	CRANKSHAFT ASSEMBLY, .020" U.S.	1	269913	Series II models
	CRANKSHAFT ASSEMBLY, .030" U.S.	1	269914	
	CRANKSHAFT ASSEMBLY, .040" U.S.		269915	
	CRANKSHAFT ASSEMBLY, STD.	1	527167*	· ጎ
	CRANKSHAFT ASSEMBLY, 010" U.S.	1	525852*	·
	CRANKSHAFT ASSEMBLY, .020" U.S.	1	525853*	
	CRANKSHAFT ASSEMBLY, .030" U.S.	i	525854*	
	CRANKSHAFT ASSEMBLY, .040" U.S.	i	525855*	,
2	Dowel for flywheel	1	265779	
3	Main bearing, front and centre, Std.	2	523321	1
,	Main bearing, front and centre, .010" U.S.	2	523322	
	Main bearing, front and centre, .010 U.S.	2	523323	Series II models
	Main bearing, front and centre, .020 U.S.	2	523324	Series 11 moders
	*	2	523325	
	Main bearing, front and centre, .040" U.S.	. 2	518748*	. 5
	Main bearing, front and centre, Std.	2	518749*	
	Main bearing, front and centre, .010" U.S.	2	518750*	
	Main bearing, front and centre, .020" U.S.	2	518751*	
	Main bearing, front and centre, .030" U.S.	_ 2	518752*	
4	Main bearing, front and centre, .040" U.S.	- · · · · · <u>L</u>	523326	4
4	Main bearing, rear, Std.	1	523327	
	Main bearing, rear, .010" U.S.	1	523328	Series II models
	Main bearing, rear, .020" U.S.	Pairs 1	523329	Series 11 models
	Main bearing, rear, .030" U.S.	≻Pairs	523330	
	Main bearing, rear, .040" U.S.	l i		. <
	Main bearing, rear, Std.	1	518753*	1
	Main bearing, rear, .010" U.S.	1	518754* 518755*	
	Main bearing, rear, .020" U.S.	1		
	Main bearing, rear, .030" U.S.	1	518756*	E Company of the Comp
	Main bearing, rear, .040 U.S.	i 1	518757 * 523331	`₹
5	Thrust washer for crankshaft, Std.	1		
	Thrust washer for crankshaft, .0025" O.S.	1	523332	Series II models
	Thrust washer for crankshaft, .005" O.S.	1	523333	> Deries 11 models
	Thrust washer for crankshaft, .0075" O.S.	i 1	523334	
	Thrust washer for crankshaft, .010" O.S.	l t	523335	. 🗧
	Thrust washer for crankshaft, Std.	!	518758*	
	Thrust washer for crankshaft, .0025" O.S.	 	518759*	· •
	Thrust washer for crankshaft, .005" O.S.	1	518760*	!
	Thrust washer for crankshaft, .0075" O.S.	1	518761*	1
_	Thrust washer for crankshaft, .010" O.S.	1	518762*	
6	Crankshaft oil retainer	2	504844	Up to engines numbered 151123196
_	REAR BEARING OIL SEAL ASSEMBI	_	525927*	
~~ 7	Rear bearing split seal halves	2	523240*	•
- 8	Oil seal and garter spring	× 1	529365*	'
	Silicone grease, MS4, 1 oz. tube	I	270656	J .
9	Dowel, lower Fixing retaine		519064	
10	Dowel, upper seal to cylinde		246464	
11	Spring washer block and rear		3074	
12	Bolt (4" U.N.F. x 7 long) bearing cap	10	255208	
13	Chainwheel on crankshaft	1	235726	
14	Key locating chainwheel and pulley	2	235770	С . И 11
15	Fan driving pulley]	247676	Series II models
	Fan driving pulley	1		Series IIA models
16	Starting dog]	503665	•
17	Lock washer for starting dog	<u> l</u>	247771	



LATE REF.	NECTING ROD AND PISTON, PET 1 2 3 4 DESCRIPTION Q	ty.	Part No.	REMARKS	
1	CONNECTING ROD ASSEMBLY	4	247535 Series II models		
•	CONNECTING ROD ASSEMBLY	4	527164* Series IIA models		
2	Gudgeon pin bush	4	265170		
_	Complete set of bolts and nuts for connecting rod	1	522607		
3	Special bolt Fixing connect-	8	518468 Series II models		
4	Self-locking nut (3" U.N.F.) ing rod cap	8	277390]		
	Special bolt Fixing connect-	8	519440* Series IIA models		•
	Self-locking nut (¾" U.N.F.) ∫ ing rod cap	8	277390 J		
5	Connecting rod bearing, Std.	4	523336		
	Connecting rod bearing, .010" U.S.	4	523337		
	Connecting rod bearing, .020" U.S.	4	523338 Series II models		
	Connecting rod bearing, .030" U.S.	4	523339		
	Connecting rod bearing, .040" U.S. Pairs	4	523340 J		
-	Connecting rod bearing, Std.	4	524151*]		
	Connecting rod bearing, .010" U.S.	4	524152*		
	Connecting rod bearing, .020" U.S.	4	524153* Series IIA models		
	Connecting rod bearing, .030" U.S.	4	524154*		
	Connecting rod bearing, .040" U.S.	4	524155 * J		
6	PISTON ASSEMBLY, STD., GRADE 'Z'	4	500638		
	PISTON ASSEMBLY, STD., GRADE 'A'	4	500639	•	
	PISTON ASSEMBLY, STD., GRADE 'B'	4	500640		
	PISTON ASSEMBLY, STD., GRADE 'C'	4	500641		
	PISTON ASSEMBLY, STD., GRADE 'D'	4	500642		
	PISTON ASSEMBLY, .010" O.S	4	500140		
	PISTON ASSEMBLY, .020" O.S	4	500141		
	PISTON ASSEMBLY, .030" O.S	4	500142		
	PISTON ASSEMBLY, .040" O.S	4	500143		
7	Piston ring, compression, Std	8	278286		
	Piston ring, compression, .010" O.S.	8	500136		
	Piston ring, compression, .020" O.S	8	500137		
	Piston ring, compression, .030" O.S.	8	500138		
	Piston ring, compression, .040" O.S.	8	500139		*
8	Piston ring, scraper, Std	4	247512		1
	Piston ring, scraper, .010" O.S.	4	500132	•	
	Piston ring, scraper, .020" O.S	4	500133		•
	Piston ring, scraper, .030" O.S	4			
	Piston ring, scraper, .040" O.S	4			
9		4			
10	Circlip for gudgeon pin	8	265175		


CYLINDER HEAD, PETROL ENGINE, 21 LITRE, Series II and IIA



CYLINDER HEAD, PETROL ENGINE, 24 LITRE, Series II and IIA


PLATI	1 2 3 4 DESCRIPTION		ty.	Part No. REMARKS
REF.	CYLINDER HEAD ASSEMBLY		1	279573 Series II models
'	CYLINDER HEAD ASSEMBLY		i	525182* Series IIA models
2	Valve guide, inlet, and sealing ring		4	500144
3	Sealing ring for inlet valve guide		4	247186 Not included in cylinder head assembly
4	Valve guide, exhaust and sealing ring		4	500145
5	Sealing ring for exhaust valve guide		4	233419 Not included in cylinder head assembly
6	Core plug, 1" dia		4	09191
7	Core plug, 1 & dia		i	230250
8	0.11.7.7.11		7	252622 3 off when toe box heat shields are fitted
U	C. 16 'C110		4	252623 When toe box heat shields are fitted
11	D 1(1:1 1 1		2	213700
12		•	1	506794 Series II models
12			i	520039* Series IIA models
13	Special set bolt, short Fixing		4	273356
14	Special set bolt, medium > cylinder head to		9	247051
15	Special set bolt, long cylinder block		5	274174
16	ROCKER COVER, TOP, ASSEMBLY		1	274172 Series II models
10	ROCKER COVER, TOP, ASSEMBLY		1	524846* Series IIA models
17	Tappet clearance plate		1	247634
18			4	73350
19	7 . 7	,	1	274173
20			3	23203&
20	Sealing washer Rubber washer Fixing top		3	506069
22	Rubber washer Fixing top Cover for rubber washer > rocker cover		3	247624
	ľ		3	247121
23	Special nut		ر 1	247714 Series II models
24	Lifting bracket for engine, front	****	1	525131* Series IIA models
าฮ	Lifting bracket for engine, front	•	1	276501
25	Lifting bracket for engine, rear		4	3075
26	Spring washers Fixing brack			255026
2 7	Set bolt $(\frac{5}{16}" \text{ U.N.F. x } \frac{3}{4}" \text{ long}) \int \text{to cylinder } \frac{1}{16} \int \frac{1}$	ieaa	4	247631)
28	Breather filter for engine AC 7222264	•	1	268887 Not part of engine assembly
29	Sealing ring for filter		1	515291
30	Special set screw fixing breather filter	••••	1	232037
21	Sealing washer for set screw	••••	1	
31	Joint washer For heater valve hole		1	243959
32	Plug (§ B.S.F.) sin cylinder head		1	250978
33	Engine oil filter AC 1531477	••••	1	247530
34	Element for filter AC FF 50	****	1	248863
35	Gasket for filter AC 1530250	••••	1	272539
	Rubber washer for centre bolt AC 1531098	••••	1	269889 Not part of engine assembly
36	Joint washer for filter		1	272839 255068
37	Set bolt (78" U.N.F. x 14" long) Fixing filte	r to	2	l l
38	Spring washer \int \text{cylinder ble}	OCK	2	3077)
39	Oil pipe complete to cylinder head	••••	1	275679
40	Banjo bolt fixing oil pipe		2	504840
41	Joint washer for banjo bolts	••••	4	231575
42	Plug for thermometer hole in cylinder head	••••	 *	250978
43	Joint washer for plug	••••	1	243959
44	Oil pressure switch, AC 7954238	••••	1	519863 Series II models
,	Oil pressure switch		I 1	519864 Series IIA models Not part of engine assembly
45	Joint washer for switch	••••	l 1	243957
	Shakeproof washer for switch terminal	••••	!	70884
46	Thermostat switch for mixture warning light		!	275024 Series II models
	Thermostat switch for mixture warning light	• • • • •	!	503587* Series IIA models
47	Joint washer for switch	••••	I	236022
48	Set bolt (2 B.A. x \(\frac{3}{8}\)" long) \(\frac{1}{2}\) Fixing switch		3	250958
49	Spring washer \int \to head		3	3073

CAMSHAFT AND TENSIONER MECHANISM, PETROL ENGINE, 2½ LITRE, Series II and IIA



CAMSHAFT AND TENSIONER MECHANISM, PETROL ENGINE, $2\frac{1}{4}$ LITRE, Series II and IIA


PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	Camshaft	1	247709	
2	Bearing complete for camshaft, front	1	519054	
3	Bearing complete for camshaft, centre and rea	r 3	519055	•
4	Rear end cover for camshaft	1	247069	
5	Joint washer for cover	i	247070	
6	Set bolt (1" U.N.F. x 1" long) fixing cover to	block 3	255008	
7	Thrust plate for camshaft	1	247566	
8	Locker Fixing thrust	plate 4	2995	
9 .	Set bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long) \int \text{to cylinder bl}	ock 4	255207	
10	Chainwheel for camshaft	1	2 76133	
11	Key locating camshaft chainwheel	1	230313	
12	Retaining washer Fixing	1	09093	
13	Locker chainwheel	to I	09210	•
14	Set bolt ($\frac{3}{8}$ " U.N.F. x $\frac{7}{8}$ " long) camshaft	1	255046	
15	Camshaft chain (3" pitch x 78 links)	, İ	09156	
16	Ratchet for timing chain adjuster	1	247540	
17	Special bolt fixing ratchet and piston to block	:,. 1	247199	
18	Spring for chain adjuster ratchet	1	267451	
19	Piston for timing chain adjuster	1		Up to engines numbered 151017422
	Piston for timing chain adjuster	1		From engines numbered 151017423 onwards
20	Set bolt $(\frac{5}{16}"$ U.N.F. x $1\frac{1}{4}"$ long) \bigcap Fixing	2		off on late type piston
21	Stud piston to	1		Late type piston
22	Spring washer cylinder	2		
23	Nut $(\frac{5}{16}''$ U.N.F.) \int block	1	254811	Late type piston
24	Cylinder for timing chain adjuster	1	277388	
25	Steel ball $(\frac{7}{32}'')$ for non-return valve	1	3739	
26	Spring for chain tensioner	1	233326	
27	Retainer for steel ball	1	233328	Up to engines numbered 151017422
	Spring retainer for steel ball	1		From engines numbered 151017423 onwards
28	Idler wheel for timing chain	1	236067	
29	Vibration damper for timing chain	1	275234	
30	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) \int Fixing dam			From engines numbered 151017423 onwards
31	Locking plate \int to cylinder	block 2	278769	J



VALVE GEAR AND ROCKER SHAFTS, PETROL ENGINE, 2½ LITRE, Series II and IIA

PLATE REF.	1 2 3 4 DESCRIP	TION	Qty.	Part No.	REMARKS
1	Inlet valve		4	277593	
2	Exhaust valve		4	525372*	
3	Valve spring, inner and out	ter	8	276609	
4	Valve spring cup		8	268292	
5	Split cone for valve, halves		16	268293	
6	Valve rocker, exhaust L.H.		2	512207	
7	Valve rocker, exhaust R.H.		2	512208	
8	Bush for exhaust valve r	ocker	4	247614	
9	Valve rocker, inlet L.H.		2	512205	
10	Valve rocker, inlet R.H.		2	512206	
11	Bush for inlet valve rock	er ,	4	247614	
12	Tappet adjusting screw		8	506814	
13	Locknut for tappet adjusting	ng screw	8	254861	
14	Tappet push rod		8	279605	
15	Tappet, tappet guide, roller	r and set bolt assem		507829	
16	Tappet		8	507026	
17	Copper washer for tappet a	guide set bolt	8	232038	
18	Valve rocker shaft		2	274125	Series II models
19	Valve rocker shaft		1	524839*	Series IIA models
20	Spring for rocker shaft	••••	4	247040	_
21	Rocker bracket, inner	****	3	274068	
	Rocker bracket, rear	····	1	274069	> Series II models
22	Rocker bracket, front	••••	1	503746	J
23	Rocker bracket	****	5	524838*	
24	Washer for rocker bracket		6	525389*	J .
25	Locating dowel for rocker		3	277956	4 off on Series IIA models
26	Stud in rocker bracket for	_	3	502656	
27	Set bolt ($\frac{5}{18}$ " U.N.F. x $2\frac{3}{4}$ "	_			
	long)	rocker bracket to		525500	
2 8	Spring washer	cylinder head	5	3075	
29	Locating screw For rock		2	247730	Series II models
30		ed bracket	2	3075	J
	Locating screw For rock		2	525390*	Series IIA models
	Spring washer ∫at brack	et	2	3075	J


OIL PUMP, PETROL ENGINE, 21 LITRE, Series II and IIA



OIL PUMP, PETROL ENGINE, 21 LITRE, Series II and IIA

FLATE REF.	1 2 3 4 DESCRIPTION	ON	Qty.	Part No.		REMARKS	
REF.	OIL PUMP ASSEMBLY		1	247662	1958-59		
	OIL PUMP ASSEMBLY		1	513640	1960 onwards		
	Oil pump body		1	247663	1958-59		
1	Oil pump body		1	513641	1960 onwards		
2	Spindle for idler gear		1	502209	1960 onwards		
	Oil pump gear, driver		1	247659	1958-59		
3	Oil pump gear, driver		1	240555	1960 onwards		
	Oil pump gear, idler		1	237884	1958-59		
4	Oil pump gear, idler		1	278109	1960 onwards		
5	Bush for idler gear		1	214995	1960 onwards		
6	Steel ball		1	3748			
7	Plunger		1	273711			
8	Spring For oil pressu	re release valve	1	265623			
9	Washer		1	243970			
10	Plug J		1	265624	1040 40		
	Oil pump cover]	247658	1958-59		
11	Oil pump cover		l	513639	1960 onwards		
12	Set bolt $(\frac{5}{16}" \text{ U.N.F. } \times \frac{7}{8}" lo$	ong) \ Fixing co		255227			
13	Spring washer	∫ to body	4	3075			
14			I	247664			
15	Sealing ring Fixing oil fi		l ,	244488			·
16	Lock washer ∫ to oil pump		1	244487	1050 50		
_	Drive shaft for oil pump		J	247739	1958-59	,	
17	Drive shaft for oil pump		I	511680	1960 onwards		
18	VERTICAL DRIVE SHAF		, I	503266			
19	On only to a mine	****	l	247742	•		
20			l	247653			
21	Locating screw for drive shaft		I	279554 255028			
22	Set bolt (16" U.N.F. x 1" long	() [Fixing oil pu	mp 2				
23	Lock washer	∫to cylinder b	IOCK Z	247000			


FRONT COVER, SIDE COVERS AND SUMP, PETROL ENGINE, 2½ LITRE, Series II and IIA



FRONT COVER, SIDE COVERS AND SUMP, PETROL ENGINE, 2½ LITRE, Series II and IIA

	Series II	and IIA
PLATE REF.	1 2 3 4 DESCRIPTION Qty.	Part No. , REMARKS
1	FRONT COVER ASSEMBLY 1	510805 Series II models
	FRONT COVER ASSEMBLY 1	514451* Series IIA models
2	Dowel locating front cover 2	6395
3	Oil seal for front cover 1	213744
4	Stud \ Fixing 1	247595 For alloy type front cover Series II
5	Stud \int water pump 2	247159 3 off with cast iron type front cover \int models
	Stud fixing water pump 5	252500 Series IIA models
6	Mud excluder 1	247766
7	Hammer drive screw fixing excluder 8	78001
8	Joint washer for front cover	247564
9	Joint washer at water inlet 1	247537
10	Spring washer Fixing front	3075
11	Set bolt (** U.IN.F. x 3 long) > cover and water	256030 7 off on Series IIA models
10	Bolt (16" U.N.F. x 34" long) nump to evlinder 2	256031 Series IIA models
12	Set bolt (16 U.IN.F. x Z long) block	256226
13	Nut (U.N.F.)	254811 510730 N
14	Side cover and oil filler pipe for engine, front 1	510730 Not part of engine assembly
15	Baffle plate for side cover, front 1 loint washer for side cover, front 2	514423
15 16	CIDE COUED ACCEMBLY, DEAD	247555 247563
17		500792
18	Stud for fuel pump 2 Plain washer 2	2220
19	Nut $(\frac{1}{16}^{"} U.N.F.)$ Fixing stud 2	254911
20	Split pin 2	2 42 2
21	Joint washer for side cover, rear 1	247554
22	Spring washer Fixing rear side 6	3075
23	Set bolt $(\frac{5}{16}"$ U.N.F. x $1\frac{1}{8}"$ long) cover plate 6	255029
24	Spring washer Fixing front 7	3075
25	Set bolt (\frac{1}{18}" U.N.F. x \frac{2}{3}" long) \int \text{side cover plate 7}	255026
26	Crankcase sump 1	247522
27	Drain plug for crankcase sump 1	3088
28	Washer for drain plug !	230507
29	Joint washer for crankcase sump 1	247088
30	Set bolt $\binom{5}{16}$ U.N.F. $\times \frac{7}{8}$ long) Fixing sump to 19	255227 22 off with cast iron type front cover
31	Spring washer Scylinder block 19	3075
32	Set bolt $(\frac{5}{16}"$ U.N.C. $x \frac{3}{4}" long)$ Fixing sump to 3	253026 For use with alloy type front cover
33	Spring washer \int front cover 3	3075
34	Oil level rod 1	274154
35	Sealing ring for rod 1	210517
3 6	Tube for oil level rod 1	504032
37	Double-ended union	236060 Not part of engine assembly
38	Washer Fixing tube to 1	243958
39	Olive cylinder block	236408
40	Union nut	236407
41	Oil filler cap and breather filter AC 7222073 1	236406
	•	


WATER PUMP AND THERMOSTAT, PETROL ENGINE, 2½ LITRE, Series II and IIA



WATER PUMP AND THERMOSTAT, PETROL ENGINE, $2\frac{1}{4}$ LITRE, Series II and IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	WATER PUMP ASSEMBLY	1	501041 Series II mo	•
	WATER PUMP ASSEMBLY	1	530477* Series IIA r	
1	Water pump casing	1	501039 Series II me	
	Water pump casing	1	530478* Series IIA 1	nodels
2	Pump spindle and bearing	1	523354 —	
3	Hub for fan	1	244458 -	>Not part of engine
4	Carbon ring and seal unit	1	244207	assembly
5	Impeller for pump	1	247916	
6	Spring washer \ Locating	1	3074	
7	Special set bolt bearing casing	1	247078]
8	Joint washer for water pump	1	247919	
9	Spring washer \(\) Fixing water pump	3	3074 Series IIA	A models
10	Nut $(\frac{1}{4}$ U.N.F.) \int to front cover	3	254800	
	Joint washer for water pump	1	514450 * \(\)	
	Bolt $(\frac{5}{16}"$ U.N.F. x $3\frac{3}{4}"$ long) $)$ Fixing water	1	256233 Series IIA	A models
	Spring washer >pump to	5	3074	
	Nut $(\frac{5}{16}$ U.N.F.) front cover	5	254810	
11	Joint washer \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	ĺ	243959	
12	Plug (§ B.S.P.) in water outlet pipe	1	250978	
13	Thermostat	İ	513465	
14	'O' ring, thermostat to water outlet pipe	1	502832	
15	Water outlet pipe, thermostat to radiator	1	501031 > 1958-60	
16	SWT 1 C .1.	I	247874	
17	Washer for outlet pipe Set bolt $(\frac{1}{4}" \text{ U.N.F. } \times 2\frac{1}{2}" \text{ long})$ Fixing outlet	tnine 3	256209	
18	Spring washer to cylinder h		3074	
19	Hose for by-pass pipe		273789)
20	TT 1. ()	I	50318	
21	PT-1	Z	504736)	ļ.
22		l	516059	
	Thermostat housing	J	511957	•
23	Joint washer for thermostat housing, upper	1	511956 > 1961 onward	1_
24	Water outlet pipe, thermostat to radiator	l	<u>!</u>	us
25	Joint washer for thermostat housing, lower	1	247874	
26	Set bolt (4" U.N.F. Fixing thermostat house	_	357300	
	$\times 2\frac{1}{2}$ long) and outlet pipe to	3	256209	
27	Spring washer cylinder head	3	3074	11 11
28	Thermostat by-pass pipe	!	518818 1961 Series	
	Thermostat by-pass pipe	l	530476* Series IJA 1	l l
29	Joint washer for by-pass pipe	1	511958)	Not part of engine
30	Set bolt $(\frac{5}{16}"$ U.N.F. Fixing by-rass pipe	_	>1961 onward	ds assembly
•	x 1" long) to thermostat	2	255228	
31	Spring washer housing	2	3075	, ,
32	Fan pulley	}	247520 Series II m	· · · · · · · · · · · · · · · · · · ·
	Fan pulley	1	526151* Series IIA 1	models
33	Fan blade	1	276762	
34	Spring washer Fixing fan bla		3074	
35	Set bolt ($\frac{1}{4}$ " U.N.F. $x \frac{3}{4}$ " long) \int and pulley to	hub 4	255207	
36	Fan and dynamo belt	1	247920 Series II me	j.
	Fan and dynamo belt	1	524200* Series IIA	<u> </u>
		1	506003 Series II m	11
	Water pump overhaul kit	1	530590* Series IIA	


CARBURETTER, PETROL ENGINE, 21/4 LITRE, Series II and IIA



CARBURETTER, PETROL ENGINE, 21 LITRE, Series II and IIA

	CARBURETTER, PETROL	ENG	NE, 24 LITRE, Series II and IIA
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
	CARBURETTER COMPLETE, SX Type	40	
	PA 10-5 `	1	505898 Carburetter and fittings are not included in the engine assembly. Without starter heater element. Check before ordering
	CARBURETTER COMPLETE, SX Type B	40	·
	PA 10-6	1	524587* With starter heater element. Check before ordering. Note: Identification, Lucar connection adjacent to starter unit
1	Carburetter body only, SX 12860	1	503887 Alternative, check For carburetter without
	Carburetter body only, SX 13077	1	513506 \int \text{ before ordering} \text{ starter heater element.} \text{ Check before ordering}
	Carburetter body only, SX B 14108	1	528037* For carburetter with starter element. Check before ordering
2	Throttle chamber only, SX 12887	1	503888 For carburetter without starter heater element. Check before ordering
	Throttle chamber only, SX B 13894	1	529089 For carburetter with starter heater element. Check before ordering
3	Spindle for throttle, SX 50991	1	503889
4	D 0 (1 1 037 50170	1	503890
5		2	260138
6	4	1	503891 Alternative,
		1	260139 ∫ check before ordering
7	Special screw, SX 4023 For slow running	1	260140
8	Spring, SX 4384 Sadjustment	1	260141
9	Special screw, SX 50537 For throttle	1	260142
10	Locknut, SX 3950 \int stop	l 1	260143 504683
11	37 61 1 1 1 037 1007	I	260159
12 13	1 1 1 4 017 10700	I	504485
14	Special screw, SX 1171 \ For mixture	I 1	260146
15	Spring, SX 4384 Scontrol	· i	260141
16	Screwed union, SX 9879 For suction	i	260707
17	Olive, SX 5041 pipe	i	260708
18	Joint washer for throttle chamber, SX 9097	1	503893
19	Special screw, SX 12501 \ Fixing chamber t		512402
20	Spring washer, SX 971 carburetter body	4	260714
	Starter complete, SX 12836	1	503895 Without starter heater element. Check before ordering
	Ottailer compress, and a	1	527273* With starter heater element. Check before ordering
21	Starter body and valve complete, SX 12925	1	503896 For carburetter without starter heater element. Check before ordering.
22	Starter body and valve complete, SX B 13937	7 1	528039* For carburetter with starter heater element.
23		1	528053 Check before ordering
24	—	[503897
25	Ball, SX 51728 For]	260155
26	Spring, SX 51762 Starter valve	^% 1	260156
27	—	I	503898
28	Nut fixing starter lever, SX 4024	I	260159


CARBURETTER, PETROL ENGINE, $2\frac{1}{4}$ LITRE, Series II and IIA



CARBURETTER, PETROL ENGINE, 21/4 LITRE, Series II and IIA

	CARBURETTER, PETROL E		INE,		RE,	
PLATE REF.	1 2 3 4 DESCRIPTION Q	ty.	Part No	o		REMARKS
29	Special bolt fixing starter cable, SX 12056		265495			
30		4	262313			without starter heater element. ordering
	Special screw fixing starter body, SX 51384/PI	4	527272*	Check	before (with starter heater element. ordering
31	Accelerator pump complete, SX 52940/1	1	503899			without starter heater element. ordering
	Accelerator pump complete, SX B 13896	1	528041*			with starter heater element. ordering
	Diaphragm assembly for pump, SX 11314	1	503900			
32	Joint washer for pump, SX 51941/L1	1	503939			
33		4	503901			
34	Choke tube (30), SX 50459/2	1.	503902`) Alternativ	ve,	
74	Choke tube (28), SX 50459/2/28			check bef		lering
35	Special screw fixing choke tube, SX 50362		260163	•		
36	Non-return valve, SX 9829) Alternativ	ve.	·
90	Non-return valve, SX 12505			check bef		lering
37	Fibre washer for valve, SX 52825		260734	,		_
	Filter gauze for non-return valve, SX 52847		503903			
38 20	Jet (65) accelerator pump, SX 52200/65		503904			
39	Fibre washer for jet, SX 52825		260734			
40			503905	•		
41	Tump injectory with the control of t		261570			
42	Joint Marier for Family and and and		260767			
43	Decem seren ming injector, in a fe		503906			
44	Doorent, jos, and a comp		260734			
45	Joint washer for blank jet, SX 52825/1			\ Alternati	ve	
46	Wall jet (199), 622 90992/0/199			check be		dering
	Main jet (125) SX 50552/6/125		260180	,	tore ore	uoi mg
47	Bolt, main jet carrier, SX 50820	1	260181			
48	Fibre washer for bolt, SX 50815			Alternati	774	
49	Correction jet (175), SX 51612/175			check be		dering
	Correction jet (185), SX 51612/2/185			Alternati		detnig
50	Emulsion tube, SX 52043			check be		larina
	Emulsion tube, SX 52684	1				Tor carburatter without
51	Pilot jet (60), SX 50797/4/60	i	260216	Alternati	ve, che	starter heater element.
٥,	Pilot jet (50), SX 50797/4/50	1	'	before or		Check before ordering
	Pilot jet (55); SK 50797/4/55	1	260269	Check		with starter heater element. ordering
52	Jet air bleed (1.5), SX 51274/1/150	1	260179		-	
53	Starter jet, petrol (145), SX 52823/145	1	503910	Check	before	without starter heater element. ordering
	Starter jet, petrol (130), SX 52823/130	1	528038			r with starter heater element. e ordering
54	Fibre washer for jet, SX 52825	1	260734			•
55	Economy jet, high speed (150), SX 51274/L1			Alternati	ive,	
<i>)</i>	Economy jet, high speed (100), SX 51274/L1/100			check be		dering

CARBURETTER, PETROL ENGINE, 21 LITRE, Series II and IIA




CARBURETTER, PETROL ENGINE, 21/4 LITRE, Series II and IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS	
56	Float, SX 51785	1	503912		
57	Spindle for float, SX 51286	1	503913		
58	Copper washer for spindle, SX 51287	1	503914		
59	Needle valve complete, SX 51305/7	1	503940		
60	Fibre washer for valve, SX 1019	1	260165		
61	Top cover for carburetter, SX 12861	1	503915		
62	Joint washer for top cover, SX 52732	1	503916		
63	Screw, SX 1129 \ Fixing joint washer	2	503917		
64	Washer, SX 51149 ∫to top cover	2	503918		
65	Special screw fixing top cover, SX 9189	4	503919		
66	Spring washer for screw, SX 971	4	260714		
67	Banjo union, SX 4120/5	1	260166		
68	Special bolt for union, SX 4122	1	260167		
69	Filter gauze for union, SX 4123	1	260168		
70	Fibre washer, large, SX 4124 \ \ \ \ For	1	260169	•	
71	Fibre washer, small, SX 4124/1 \int union	t	260170		
72	Elbow for top cover, SX 12828	1	503920		
73	Distance piece, elbow to top cover, SX B 1	3934 1	527275	For carburetter with starter heater element. before ordering	Check
74	Screw fixing elbow to top cover, SX 9698	2	503921	For carburetter without starter heater. before ordering	Check
	Screw fixing elbow to top cover, SX 51421	/3 2	260157	For carburetter with starter heater element. before ordering	Check
75	Rubber sealing washer, elbow to starter of SX 12862	over,	503922		
7 6	Lever for accelerator pump rod, SX 12880		503923	•	
77	Special washer for levers, SX 4031/1	1	261410	, ·	
78	Nut fixing lever to spindle	2	260159		
79 79	Control rod for accelerator pump, SX 1267		503924		
80	Split pin	4	3359		
81	Plain washer, SX 52760 For control roo		260771		
82	Spring, SX 53010	. J	503925		
OL.	Spring, DA 55010	•	-	*	

CARBURETTER SETTINGS WHICH MAY BE ADVANTAGEOUS FOR HIGH ALTITUDES

Main jet (120), SX 50552/6/120	 1	260494	5,000 to 7,000 ft.
Main jet (117.5), SX 50552/6/117.5	 1	515314	7,000 to 9,000 ft.
Main jet (115), SX 50552/6/115	 1	260173) 9,000 to
Pilot jet (45), SX 50797/4/45	 1	260178	∫12,000 ft.
Main jet (112.5), SX 50552/6/112.5	 1	515313	12,000 to
Pilot jet (45), SX 50797/4/45	 1	260178	∫ 14,000 ft.


MANIFOLDS, PETROL ENGINE, $2\frac{1}{4}$ LITRE, Series II and IIA



MANIFOLDS, PETROL ENGINE, 21 LITRE, Series II and IIA


Carburetter complete	PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
Packing for carburetter		Carburetter complete	1	505898	
Spring washer Fixing 2 3076	2	Joint washer for carburetter	2	278163	
Nut (¾" U.N.F.) Carburetter 2 254812	3	Packing for carburetter	1.	278162	·
Suction pipe, complete, carburetter to distributor 279724 3787 8 Nut distributor end 3783 3783 9 Screwed union Suction pipe, 260707 260708 1 Clip for suction pipe 214228 1 24228 1 24228 1 24228 1 24228 1 24228 1 24229 1 2428 1 2429 1 2428 1 2428 1 2428 1 2428 1 2429 1 2428 1 2428 1 2428 1	4	Spring washer \ Fixing	2	3076	
Nipple Suction pipe, 3787 3787 3783 9 Screwed union Suction pipe, 260707 10 10 10 10 10 10 10	5	Nut (§" U.N.F.) carburetter	2	254812	
8 Nut	6	Suction pipe, complete, carburetter to distrib	utor l		
Screwed union Suction pipe, 260707	7	Nipple \ Suction pipe,	1		
10 Olive	8	Nut ∫distributor end	1		
Clip for suction pipe	9		1		
Rubber grommet for clip 1	10	Olive Scarburetter end	1		
13 Bolt (\$\frac{7}{\text{U.N.F. x \chisses}" long)}{\text{to rear}} Fixing clip to rear 1 3074 15 Plain washer Ititing 1 2213 16 Nut (\$\frac{7}{\text{U.N.F.}} bracket 1 254800 17 INLET MANIFOLD ASSEMBLY 1 278598 18 Stud for carburetter 2 252529 19 Liner for inlet manifold 1 278161 20 Spindle for carburetter bell crank 1 502900 Plain washer for spindle 1 2765 21 Spring washer Fixing 1 3076 22 Nut (\$\frac{7}{\text{U.N.F.}} spindle 1 254802 23 Spacer for spindle 1 502899 24 Torsion spring for bell crank 1 502992 25 Special washer for torsion spring 1 502898 26 Bracket for accelerator controls 1 503430 27 Bolt (\$\frac{1}{\text{6}}" \text{U.N.F.} \text{ 1" long} \text{ 5txing bracket to 2 255028 28 Plain washer Steering column 2 3830 29 Self-locking nut (\$\frac{1}{\text{6}}" \text{U.N.F.} \text{ 1" long} support bracket 2 252211 3 30 CARBURETTER BELL CRANK LEVER ASSEMBLY 504619 31 Bush for bell crank 1 277120 277120 32 CARBURETTER RELAY LEVER ASSEMBLY 504621 33 Ball end for lever 1 1481 3 3 3 34 Split pin fixing levers to spindle 2 2 2 2 2 35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 3 2 2 2 2 2 2 2 2	11	Clip for suction pipe	1		
1	12	Rubber grommet for clip	1		
Plain washer	13	Bolt (‡" U.N.F. x 5" long) } Fixing clip	1		
Nut (\frac{1}{2} \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \			1		
17		• • • • • • • • • • • • • • • • • • •	1		
18			1		
19 Liner for inlet manifold			1		ļ
Spindle for carburetter bell crank			2		
Plain washer for spindle			1		
Spring washer	20	<u>-</u>]		
22 Nut (§" U.N.F.) spindle 1 254802			1		
Spacer for spindle			1		Not part of engine assembly
24 Torsion spring for bell crank 1 502982 25 Special washer for torsion spring 1 502898 26 Bracket for accelerator controls 1 503430 27 Bolt (½ U.N.F. x 1" long) Fixing bracket to 2 255028 28 Plain washer 2 3830 R.H.D. 29 Self-locking nut (½ " U.N.F.) support bracket 2 252211 30 CARBURETTER BELL CRANK LEVER 1 504619 31 Bush for bell crank 1 277120 32 CARBURETTER RELAY LEVER ASSEMBLY I 504621 33 Ball end for lever 1 1481 34 Split pin fixing levers to spindle 1 2392 35 ROD ASSEMBLY, BELL CRANK TO 2 277633 36 Ball joint for rod 2 254800 38 Spring washer Fixing rod to bell crank 2 3074			1		
25 Special washer for torsion spring 1 502898]		
26 Bracket for accelerator controls 1 503430 27 Bolt (\(\frac{5}{16}\)" U.N.F. x 1" long) Fixing bracket to 2 255028 28 Plain washer steering column 2 3830 R.H.D. 29 Self-locking nut (\(\frac{5}{16}\)" U.N.F.) support bracket 2 252211 30 CARBURETTER BELL CRANK LEVER ASSEMBLY 1 504619 31 Bush for bell crank 1 277120 32 CARBURETTER RELAY LEVER ASSEMBLY 1 504621 33 Ball end for lever 1 1481 34 Split pin fixing levers to spindle 1 2392 35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (\(\frac{1}{2}\)" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074			1		
27 Bolt (\(\frac{5}{16}\)" U.N.F. x " long) Fixing bracket to 2 255028 28 Plain washer Steering column 2 3830 R.H.D. 29 Self-locking nut (\(\frac{5}{16}\)" U.N.F.) support bracket 2 252211 30 CARBURETTER BELL CRANK LEVER ASSEMBLY 504619 31 Bush for bell crank		-]		
Self-locking nut (\frac{5}{16}" U.N.F.) support bracket 2 252211		_			Ļ
29 Self-locking nut (½" U.N.F.) support bracket 2 252211 30 CARBURETTER BELL CRANK LEVER ASSEMBLY 504619 31 Bush for bell crank 277120 32 CARBURETTER RELAY LEVER ASSEMBLY 504621 33 Ball end for lever 1 481 34 Split pin fixing levers to spindle 1 2392 35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (½" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074		·			_
ASSEMBLY 1 504619 31 Bush for bell crank 1 277120 32 CARBURETTER RELAY LEVER ASSEMBLY 1 504621 33 Ball end for lever 1 1481 34 Split pin fixing levers to spindle 1 2392 35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (‡" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074				· ·	Э.
ASSEMBLY 504619 31 Bush for bell crank 277120 32 CARBURETTER RELAY LEVER ASSEMBLY 504621 33 Ball end for lever 1481 34 Split pin fixing levers to spindle 2392 35 ROD ASSEMBLY, BELL CRANK TO		Self-locking nut (16" U.N.F.) support brace		252211)	İ
31 Bush for bell crank	30		VER .	F04/10	
32 CARBURETTER RELAY LEVER ASSEMBLY 504621 33 Ball end for lever	٠.		[]
33 Ball end for lever 1 1481 34 Split pin fixing levers to spindle 1 2392 35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (½" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074					
34 Split pin fixing levers to spindle 1 2392 35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (½" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074			AIRLY !		
35 ROD ASSEMBLY, BELL CRANK TO CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (‡" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074			1		\
CARBURETTER 1 506210 36 Ball joint for rod 2 277633 37 Locknut for ball joint (‡" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074			1	2592	1
36 Ball joint for rod 2 277633 37 Locknut for ball joint (‡" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074	35		1	50(210	
37 Locknut for ball joint (‡" U.N.F.) 2 254800 38 Spring washer Fixing rod to bell crank 2 3074	27				Į.
38 Spring washer Fixing rod to bell crank 2 3074					
39 Not (4" LINE) Land carburetter / /34NB)					
57 Title (4 0.11.1.) Janu carburetter 2 251000	39	Nut ($\frac{1}{4}$ " U.N.F.) \int and carburetter	2	254800	}

MANIFOLDS, PETROL ENGINE, 21 LITRE, Series II and IIA



MANIFOLDS, PETROL ENGINE, 21 LITRE, Series II and IIA


PLATE REF.	1 2 3 4 DESCI	RIPTION	Q	—– t y.	Part No.		REMARKS
40	Exhaust manifold			1	501175	1958-60	
	Exhaust manifold			1	501422	1961 onwards	
	Butterfly valve			I	247811		
	Spindle for butterfly	valve	• • • •	1	279168		
41	Counterbalance weight			I	2 7 9169		
42	Set screw (2 B.A. x 3 lo	ong) fixing weight to spir	ndle	1	237119		
43	Stop pin for adjusting p	plate		1	247819		
44	Bi-metal spring for but	terfly		l	24 7 818		
45	Adjusting plate and pin	for spring	•	1	247815		Not part of engine assembly
46	Stud for inlet manifold	ļ. <u></u>		4	510315	R.H.D.	
	Special set bolt \ Fixing			2	256426)	L.H.D.	
	Special set bolt ∫exha	ust manifold		2	256429∫	Lilib.	
47	Stud for exhaust pipe		••••	3	247144		
48	Joint washer			1	247824		[·
49	Plain washer Fi	ixing inlet to exhaust		4	2550		1
50	Spring washer >m	anifold		4	I	≻R.H.D.	
51	Nut (# U.N.F.)			4	ر 254801		J
52	Joint washer for manife	old to cylinder head		1	274171		
53	Clamp for manifold	****		2	247836	Not part of engi	ne assembly
	Set bolt $(\frac{5}{16}"$ U.N.F. x			2	256029	•	
	Set bolt (5 " U.N.F. x	2" long) Fixing		2	256226		
54	Spring washer	>manifold	to	11	3075		
	Plain washer	cylinder h	nead	4	2550		
55	Nut (5" U.N.F.)	J		7	254811		



DISTRIBUTOR AND STARTER MOTOR, PETROL ENGINE, $2\frac{1}{4}$ LITRE, Series II and IIA

PLATE	1 2 3 4 DESCRIPTION		Part No.		REMARKS
PLATE REF.			277368	Series II models) TOTAL COLOR
1	DISTRIBUTOR COMPLETE LU 40609	, l		Series IIA models	·
	DISTRIBUTOR COMPLETE	1		Series IIA models	}
2	Distributor cap complete LU418865	J	502281		
3	Brush and springs for cap LU 418856		262703		Į
4	Rotor arm LU 400051		245005 269987		
5	Contact breaker points set LU 423153	set			
6	Contact breaker base plate LU 422318	l	502282 269988		
7	Condenser for distributor LU 421267	j	502285		
8	Auto advance springs set LU 54410187	l set	262708		 ≻Not part of engine assembly
9	Auto advance weight LU 410033/S	I	502286		Prot part of engine assembly
10	Vacuum unit LU 54410164	l	245008		
11	Cam for distributor LU 496078	l	269990		
12	Shaft for distributor LU 419689	l	245012		!
13	Bush for distributor shaft LU 419430	l	245012		
14	Driving dog for distributor LU 410601	l	502283		
15	Terminal bush and lead LU 422238	, l 1	245003	•	\
16 17	Clamping plate for distributor LU 420151	2	502287		
17	Clip for cover LU 421824 Sundry parts kit LU 419644		245015		
18		1	247672	-	,
19		I	247012		
20	Joint washer, adaptor to cylinder block Plain washer Fixing adaptor	1 3	3868	•	
21	Spring washer >to cylinder	3	3075		
22	Nut (\frac{5}{16}" U.N.F.) block	3	254801		
23	Dir ice Paga .	1	247806		
24	Cork washer for distributor, top	;	52278		
25	Plain washer Fixing	, I	3911		
26	Spring washer >distributor	1	3074		
20 27	Set bolt $(\frac{1}{4}" \text{ U.N.C. } \times \frac{9}{16}" \text{ long})$ to adaptor	1	253005		
28	Sparking plug, Lodge CLNH	4	262796	Alternatives.	
20	Sparking plug, Champion N8	4	512806	Check before order	ing
29	Joint washer for sparking plug	4	40441	J Chick before order	•••5
30	Suppressor for sparking plug	4	240138	٦	<u> </u>
31	Sparking plug cover	4	214262	Alternative to	
32	Sealing ring for plug cover	4	213172	3 lines below.	
33	C 11 111 410400	0	214278	Check before order	ring. Not part of
34	Washer for cable nut LU 185015	9	214279	Officer perote order	engine
74	Suppressor and cover for sparking plug	4	513694	Alternative to	assembly
	Rubber boot for suppressor	4	240408	>5 lines above.	
	Rubber boot for distributor cable nut	5	240408	Check before order	ring
35	Resistor for distributor lead	1	213646	· ·	
,	H.T. Wire	As required			
	11,1, 17 HC	, so roquired			J


DISTRIBUTOR AND STARTER MOTOR, PETROL ENGINE, 2½ LITRE, Series II and IIA



DISTRIBUTOR AND STARTER MOTOR, PETROL ENGINE, $2\frac{1}{4}$ LITRE, Series II and IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty	. Part No.	REMARKS
36	STARTER MOTOR COMPLETE, LU 25	533B	236287	
37	Bracket, commutator end LU 256748	1	244706	
38	Bracket, drive end LU 256495	1	244713	
39	Armature LU 255463		244715	
40	Bush, commutator end, LU 255491		242958	
41	Bush, pinion end, LU 270038		244714	
42	Pinion and sleeve, LU 255194		244711	
43	Spring for pinion LU 255728		1 244712	•
44	Main spring for pinion LU 270889		l 2 447 10	Not part of engine assembly
45	Nut for pinion LU 255851		l 244709	
· 46	Field coil for starter LU 255625	****	I 244 7 16	
47	Brushes for starter motor, set, LU 255659	9 2	2 260055	
48	Spring set for brushes LU 238062		1 244708	
49	Bolt for bracket LU 255459		244717	
50	Cover band LU 255557		1 2 447 05	
51	Grease cap LU 255854		243095	·
	Sundry parts kit LU 256762	****	ر244718	
52	Nut (3" U.N.F.) \ Fixing starter motor to	:	254802	
53	Spring washer \int flywheel housing	:	3076	· ·


DYNAMO AND FIXINGS, PETROL ENGINE, 21 LITRE, Series II and IIA



DYNAMO AND FIXINGS, PETROL ENGINE, 21 LITRE, Series II and IIA


	DINAMO	AND I	1111110	,				
PLATE REF.	1 2 3 4	DESCRIP	TION		Qty		<u> </u>	REMARKS
1	Dynamo comp	lete LU 222	58E		1	270095	Series II models	
	Dynamo comp	lete LU 540	21019		1	514893	Series IIA models	
2	Bracket, cor	nmutator en	d LU 22	7702	1	242669		
3	Armature fo	r dynamo L	.U 22 7 693	3	1	242 67 4		
4		dynamo, set			1	261483		
5	Spring set f	or brushes L	LU 22815	9	1	261238		Į
6		r dynamo L			1	262860		
7		, front LU			1	242672		
8	_	nutator end		18	1	271614		
9	Bracket, dri	ve end LU 2	227698		1	242673		Not part of engine assembly
10		mamo LU 2		****	1	271615		
11	_	cket LU 228			2	2 4267 5		
12	Terminal L				1	264436		·
		ts, set LU 2	27726		1	242676		
13	Pulley for dyn			****	1	247209	Series II models	1
14	Pulley for dyr				1	522913*	·] c · 114 11	
15	Fan for dynan				1	529303*	Series IIA models	
16	Woodruff key	_			i	1664		
17	Lock washer	Fixing p	ullev to o	lvnamo	1	2 177 81		
18	Special nut		,		1	3466		}
19	Anchor brack	ر et for dynam	no	****	1	247085	Series II models	
20	Support brack				1	277999`\	C . IIA 11	
21	Steady bracke				1	278000	Series IIA models	
22	Spring washer			Fixing	2	3075		
23	Set bolt $(\frac{5}{16}")$		· ·				Series II models	
24	Set bolt $(\frac{5}{16}")$	U.N.F. x 5"	long)	support b	racket 2	255225	la : 114 11	
25	Locking plate				}	501198	Series IIA models	
26	Bolt (# U.N				1	2 7327 1	•)
27	Shim washer			ing dynan	noto 3		Series II models	
28	Spring washer	,		hor brack		3075		İ
29	Nut (5 U.N		1		1	254801		
30	Bolt (5 " U.N	 l.F. x 1∛″ lor	ng)] F	ixing dyn	amo l	256421		
31	Self-locking n			front su	pport 1	252161		
32	Special stud	. (10	1 1		1	526225		
33	Shim washer		F	ixing dyn	amo Asr	equired 4148	Series IIA models	
34	Plain washer	÷		support		2550		
35	Self-locking n	ut (5″ U.N		racket	2]	Not part of engine assembly
36	Locknut (5 "		·] "		1	254811		
37	Adjusting link		ر	*-**	1	247523	Series II models	
38	Adjusting link				1	514472	Series IIA models	
39	Special bolt		xing		1	233568		
40	Plain washer		justing li	nk	1	2266		
41	Spring washe	,	dynamo		i	3075		
42	Set bolt $(\frac{5}{16})^{n-1}$			Fixing	1	253025	le e H	
43	Spring washe			adjusting	1	3075	Series II models	
44	Bolt (5 " U.N			link to	1	256031	C : 114 11	
45	Plain washer		٠. ا	front cove	er I	2266	Series IIA models	J
• • • • • • • • • • • • • • • • • • • •	- 44444 77666161		,		-	-	,	-

FLYWHEEL AND CLUTCH, PETROL ENGINE, 21 LITRE, Series II and IIA




FLYWHEEL AND CLUTCH, PETROL ENGINE, 21 LITRE, Series II and IIA

DI ATE	1001	DECEDIATIO	\	Qty.	Part No.		REMARKS	
PLATE REF.	1 2 3 4	DESCRIPTION		Qty.			TELIVII ITELE	<u> </u>
ŧ		HOUSING ASS			247526			
2		N.F.), fixing flywh	eel housing to		0.471.45			
	housing			12	247145			
3	·-	V.F.) fixing inspe		: 2	247146			
4		N.F.) for starter n		2	247145			
5	~ -	r flywheel housin	g	!	246169			
6	Inspection cov	-		I	56140			
7		r cover plate		2	50216			
9), fixing cover pla		2	254800			
10		$(x \mid \frac{3}{4}'' \mid \text{long}) $		2	256043			
11	- Bolt (₹" U.N.F	اخ (long گا x.x.	lywheel hous		255048			
12	Spring washer	I	:0	8	3076			
13	Plain washer	-	cylinder bl o cl	k 6	2219			
14	Indicator for e		•]	272784		*	
15	Drain plug for			!	3290			
		et for drain plug	•	1	276511			
.16		ASSEMBLY		1	247991			
	Ring gear fo		•	1	246330			
17		ng clutch cover p	olate	2	502116			
18	_	mary pinion		1	08566			
19	Set bolt fixing			6	255427			
20	Tab washer fo	_		6	265260			
21	Locker	Fixing flywho		4	3674			
22		t ∫to crankshaft		8	246115			
		SEMBLY BB 49		1	242130			
23		for clutch BB 454		, I	231888			
24		te for clutch BB 4		1	231880		•	
25		r for clutch BB 4		3	242993			
26		ease lever BB 426		3	231884		•	
27		nut for release le		3 3	242996			
28		ise lever BB 4260		3	231885			
29	Anti-rattle s	pring for release	lever BB 476	88 3	231883			
30		g (yellow and ligi		44780 9	243593	•		
31		omplete BB 4762		1	511681		,	
		age for clutch pla		1	261921	Ferodo lining	Alternatives	•
	Lining pack	age for clutch pla	ate BB KL 75	021 i	517026	Mintex lining	J	



	CILINDER BLOCK, DIE			
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
itta .	ENGINE AND CLUTCH ASSEMBLY	1	247796	<u>.</u>
1	CYLINDER BLOCK ASSEMBLY	1	269910	Does not include liners and pistons
-	Cylinder block, crankshaft, pistons and camshaft	1	271502	
2	LINER FOR CYLINDER WITH PISTONS	4	269911	For piston assembly part numbers see page 83
3	Sealing ring for liner	^	247746	
-	Shim for liner .002" thick	4		Required for first
	Shim for liner .004" thick	4		4000 engines
	E	1	270656	
4	_ 1 1 1 1	1	512412	•
5		1	09191	
	1	1	277496	
6	Stud \ For front cover	ì	247208	
7	Stud and water pump	1	247869	
-8		3	252624	
	Stud for sump	1	252621	
9	Set bolt for main bearings	6	504007	
10	Special plain washer for set bolt	6	504006	
11	Dowel, locating main bearing and bearing cap	6	501593	
12	Dowel, locating flywheel housing	2	52124	
13	Dowel for timing chain adjuster	2	213700	
15	I lug lot ou gamery, moust	1	247127	;
16	1 lug loi on gatter y, rear]	250978	
17	John Washer for rear prog]	243959	
18	I tig for tapper reed games, P.P.,]	247861	
	I lug lot tappet reed games) pipe,]	273166	
	Joint washer for prag]	243968	
19	I deking for rear main bearing or	2	505361	
20	Dialii tup for cymiaes orden	!	243237	
21	Jonit washer for drain tap	!	213959	
22	Linglife Hollt Support Bracket compress,]	277742	
23	Eligine front support bracket completely and	!	271975	
24	Locker Fixing brackets		212430	
25	Set bolt $(\frac{1}{2}^n \text{ U.N.F. } \times 1^n \text{ long}) \int \text{to cylinder bloc}$	1	255085	
	Decarbonishing Basices and]	272563	
	Engine overhaul gasket kit	<u> </u>	272564	


CRANKSHAFT, DIESEL ENGINE, 2 LITRE, Series II



CRANKSHAFT, DIESEL ENGINE, 2 LITRE, Series II

St. Lower					DEN	ALDIZO
PLATE REF.	1 2 3 4 DESCRIPT		Qty.	Part No.	REI	MARKS
1	CRANKSHAFT ASSEMB	LY, STD.	1	514526		
2	Dowel for flywheel		1	26 5779		
3	Main bearing, front and cent	re, Std.	2	523321		
4	Main bearing, rear, Std.		1	523326		
5	Thrust washer for crankshaf	t, Std.	1	523331		
	Thrust washer for crankshaf	t, .0025" O.S. كا	Pairs 1	523332		
	Thrust washer for crankshaf	t, .005" O.S.	1	523333		•
	Thrust washer for crankshaf	t, .0075" O.S.	1	523334		
	Thrust washer for crankshaf	t, .010" O.S.	1	523335		•
6	Crankshaft oil retainer		2	504844	Up to engines numbered:	
						156102153. 109
	REAR BEARING OIL SE	AL ASSEMBLY	Y 1	525927*		
7	Rear bearing split seal halv	ves	2	523240*	~	
8	Oil seal and garter spring		1	529365*		156102154. 109
	Silicone grease, M.S.4, 1 c	oz. tube	1	270656	J	onwards
9	Dowel, lower	Fixing retainer		519064		
10	Dowel, upper	seal to cylinder	2	246464		
11	Spring washer	block and rear	6	3074	•	
12	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{7}{8}$ " long)	bearing cap	6	255008		
13	Chainwheel on crankshaft		1	235726		
14	Key locating chainwheel and	vibration dampe	r 2	235770		
	VIBRATION DAMPER A	SSEMBLY	1	247154		
15	DAMPER FLYWHEEL	AND BUSH				
	ASSEMBLY		1	247094		
16	Bush for flywheel		2	236289		
17	Driving flange		1	247674		
18	Rubber disc for damper		2	03017		
19	Shim		As required			
20	Set bolt (‡" U.N.F. x §" lo	ong) \ Fixing	6	255006		
21	Double tab washer	∫ plate	3	247647		
22	Starting dog		1	503665		
23	Lock washer for starting dog		1	247771		
						9

CONNECTING ROD AND PISTON, DIESEL ENGINE, 2 LITRE, Series II



CONNECTING ROD AND PISTON, DIESEL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION C	ty.	Part No.	REMARKS
ī	CONNECTING ROD ASSEMBLY	4	518808	
2	Gudgeon pin bush	4	247583	
	Complete set of bolts and nuts for connecting rod	1	522607	
	Special bolt Trixing connec-	8	518468	
	Self-locking nut $(\frac{3}{8}$ U.N.F.) \int ting rod cap	8	277390	≻Alternative fixings
3	Special bolt Fixing connecting	8	273677	Check before ordering
4	Castle nut $\binom{3''}{8}$ U.N.F.) \int rod cap	8	247115	
5	Split pin fixing connecting rod cap	8	2392	
6	Connecting rod bearing pairs, Std	4	523336	
7	PISTON ASSEMBLY AND LINER	4	269911	NOTE—Oversize pistons are not supplied
8	Piston ring, compression, Std., chromed	4	247170	
9	Piston ring, compression, Std., tapered	8	247171	
10	Scraper ring, Std	4	247172	
11	Gudgeon pin, Std	4	248930	
12	Circlip for gudgeon pin	8	266945	




PLATE REF.	1 2 3 4 DESCRIPTI	ON	Qt	y. Part N	lo. REMARKS
1	CYLINDER HEAD ASSEN	MBLY		1 50458	88
2	Valve guide, inlet, and seal			4 27220	06 · · ·
3	Sealing ring for inlet valv			4 24718	86 Not included in cylinder head assembly
4	Valve guide, exhaust and se	aling ring		4 27555	52
	Sealing ring for exhaust	valve guide		4 23341	19 Not included in cylinder head assembly
	Packing washer for valve gu	uides	2	0 23006	62
5	Hot plug in cylinder head .	••••		4 50261	
6	Peg for hot plug .			4 27188	31
7	Push rod tube			8 51422	
8	"O" ring for push rod tube	e, large		8 24787	
9	"O" ring for push rod tube	e, small		8 2650	
10	Stud for injector, thread le			6 2478	į.
	Stud for injector, thread le	ngth 15″		2 2779	
	Stud for injector, thread le	ngth 2½″		3 52160	j
11	Stud, short \ For			5 24714	l l
12	Stud, long ∫ manifold			4 24714	
	Core plug, 7, dia.			3 25083	
13	Core plug, 1" dia.			7 0919	
14	Core plug, 1¾ dia.		••••	23025	
				4 27514	
15	,		••••	1 2476	
16	Special set bolt, short			2 2476	
17		Fixing		9 2470	
18	-	cylinder head		5 2477	
	\ ,	to cylinder block		2 50076	•
	Nut (½" U.N.F.)	•		2 25480	·
19	ROCKER COVER, TOP, A	ASSEMBLY		1 24755	·
20				1 2476.	
21			••••	4 7335	
22	Joint washer for top rocker co		••••	1 2476	
23	Sealing washer \ Fixing top			3 23203	
24	Special nut \int \text{rocker cover}			3 24712	
25	Lifting bracket for engine, fro		••••	1 2477	
26	Lifting bracket for engine, re			1 2477	
27	Spring washers	Fixing brace		4 30	
28	Set bolt (16" U.N.F. x 1 lon		head	4 2550	
29	Breather filter for engine, AC			1 2476	
3 0		 1 Cl.	****	1 2688	
31	Special set screw fixing breat		••••	1 51529	
00	Sealing washer for set screw			1 23203	
32		er valve hole		1 2439.	
33	Plug (¾" B.S.F.) ∫ in cylind	ier head		1 2509	70





PLATE REF.	1 2 3 4 DESCRIPTION (ty.	Part No.	REMARKS
34	Heater plug	4	510078*	
3 5	Heater plug lead, No. 1 to earth	1	247953	
36	Heater plug lead, No. 2 to No. 3	1	247952	
37	Heater plug lead, No. 1 to 2 and 3 to 4	2	247951	
3 8	Heater plug lead, No. 4 to resistor	1	271220	
	Shakeproof washer, large \(\) Fixing leads to	4	77626	
	Shakeproof washer, small \(\int \) heater plug	4	71082	
	Bolt (3" U.N.F. x) Fixing heater plug			
	5″ long) > earth lead to	1	523905*	
	Fan disc washer cylinder head	1	512305	
39	Engine oil filter AC 1531477	1	247530	
40	Element for filter AC FF 50	1	248863	
41	Gasket for filter AC 1530250	I	272539	
	Rubber washer for centre bolt, AC 1531098	1	269889	•
4 2	Joint washer for filter	1	272839	
43	Set bolt (7 U.N.F. x 1 long) Tixing filter to	2	255068	
44	Spring washer	2	3077	
45	.Oil pipe complete to cylinder head	1	274500	
46	Banjo bolt fixing oil pipe	2	500457	
47	Joint washer for banjo bolts	4	231575	
	Plug for thermometer hole in cylinder head	1	278164	
	Joint washer for plug	1	243972	
	Oil pressure switch, AC 7954238	1	519863	
	Joint washer	1	232039	


CAMSHAFT AND TENSIONER MECHANISM, DIESEL ENGINE, 2 LITRE, Series II



CAMSHAFT AND TENSIONER MECHANISM, DIESEL ENGINE, 2 LITRE, Series II

Camshaft 274711	PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y. Part No.		REMARKS
Bearing complete for camshaft Centre and rear 3 519055	1	Camshaft				
4 Rear end cover for camshaft	2	Bearing complete for camshaft, fro	ont	1 519054		
5 Joint washer for cover 1 247070	3	Bearing complete for camshaft, cer	ntre and rear	3 519055		
Set bolt (¼" U.N.F. x ¾" long) fixing cover to block 7 Thrust plate for camshaft	4	Rear end cover for camshaft		1 247069		
Thrust plate for camshaft Locker Set bolt (½" U.N.F. x ¾" long) ∫ to cylit der bleck Chainwheel for camshaft Key locating camshaft chainwheel Retaining washer Camshaft chain (¾" pitch x 78 links) Camshaft chain (¾" pitch x 78 links) Camshaft for timing chain adjuster Set bolt (½" U.N.F. x ¼" long) Spring for chain adjuster ratchet Set bolt (½" U.N.F. x ¼" long) Spring for chain adjuster ratchet Set bolt (½" U.N.F. x ¼" long) Spring for chain adjuster Set bolt (½" U.N.F. x ¼" long) Set bolt (½" U.N.F. x ¼" long) Set bolt (½" U.N.F.) Set bolt (½" U.N.F.) Spring washer Spring washer Spring washer Spring washer Spring for chain adjuster Set loal (½" U.N.F.) Spring washer Spring washer Spring washer Spring for chain adjuster Spring washer Spring washer Spring washer Spring washer Spring for chain adjuster Spring washer Spring for timing chain adjuster Spring washer Spring for chain tensioner Spring for chain	5					
Set bolt (\(\frac{1}{6}^* \) U.N.F. \(\frac{3}{4}^* \) long) to cylin der block 4 255207	6	Set bolt (‡" U.N.F. x 7" long) fixin:	g cover to block			
9 Set bolt (\(\frac{1}{8} \) U.N.F. x \(\frac{3}{8} \) long) to cylit der block 4 255207 10 Chainwheel for camshaft	7	Thrust plate for camshaft				
10 Chainwheel for camshaft 1 276133 11 Key locating camshaft chainwheel 1 230313 12 Retaining washer Fixing 1 09093 13 Locker Chainwheel to 1 09210 14 Set bolt (\frac{8}{3}'' U.N.F. \times \frac{7}{3}'' long) Camshaft 1 255246 15 Camshaft chain (\frac{8}{3}'' pitch \times 78 links) 1 09156 16 Ratchet for timing chain adjuster 1 247540 17 Special bolt fixing ratchet and piston to block 1 247199 18 Spring for chain adjuster ratchet 1 267451 19 Piston for timing chain adjuster 1 247912 20 Set bolt (\frac{1}{16}'' U.N.F. \times 1\frac{1}{4}'' long) Fixing 2 256220 1 off on late type fixing 21 Stud (\frac{1}{16}'' U.N.F.) block 1 247144 Late type fixing. Check before ordering 22 Spring washer 1 277388 23 Steel ball (\frac{3}{32}'') for non-return valve 1 3739 24 Spring for chain tensioner 1 233326 25 Retainer for steel ball 1 233328 26 Spring for chain tensioner 1 233328 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (\frac{1}{4}'' U.N.F. \times \frac{1}{2}'' long) Fixing damper to 2 255204 25 Spring damper to 2 255204 26 Spring for chain tensioner 1 23326 27 Retainer for steel ball 1 23326 28 Idler wheel for timing chain 1 275234 30 Set bolt (\frac{1}{4}'' U.N.F. \times \frac{1}{2}'' long) Fixing damper to 2 255204 30 Set bolt (\frac{1}{4}'' U.N.F. \times \frac{1}{2}'' long) Fixing damper to 2 255204 30 Set bolt (\frac{1}{4}'' U.N.F. \times \frac{1}{2}'' long) Fixing damper to 2 255204 30 Set bolt (\frac{1}{4}'' U.N.F. \times \frac{1}{2}'' long) Fixing damper to 2 255204 31 Steel ball 275234 27524 27524 27524 27524 27524 27524 27524 27524 27524 27524 27524 27524 27524 27524 27524 275	8 -	Locker \ \rightarrow \ \forall \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	ixing thrust plate	4 2995		
1	9	Set bolt (¼" U.N.F. x ¾" long)∫ to	cylir der block	4 255207		
12 Retaining washer Fixing 1 09093 13 Locker Chainwheel to 1 09210 14 Set bolt (\(\frac{8}{8}''\) U.N.F. \(x \frac{7}{8}''\) long) camshaft 1 255246 15 Camshaft chain (\(\frac{3}{8}''\) pitch \(x \text{78 links}\) 1 09156 16 Ratchet for timing chain adjuster 1 247540 17 Special bolt fixing ratchet and piston to block 1 247199 18 Spring for chain adjuster ratchet 1 267451 19 Piston for timing chain adjuster 1 247912 20 Set bolt (\(\frac{5}{6}''\) U.N.F. \(x \text{14}''\) long) Fixing 2 256220 1 off on late type fixing 21 Stud (\(\frac{5}{6}''\) U.N.F.) Fixing 2 256220 1 off on late type fixing 22 Spring washer 1 247144 Late type fixing. Check before ordering 23 Nut (\(\frac{5}{6}''\) U.N.F.) block 1 254811 Late type fixing. Check before ordering 24 Cylinder for timing chain adjuster 1 3739 25 Steel ball (\(\frac{1}{32}'''\)) for non-return valve 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (\(\frac{1}{4}''\) U.N.F. \(x \frac{1}{2}''\) long) Fixing damper to 2 255204					-	
Chainwheel to Chainwheel t	11	Key locating camshaft chainwheel				
Set bolt (\(\frac{8}{8}\)" U.N.F. x \(\frac{2}{8}\)" pitch x 78 links)		Retaining washer \(\) F	ixing .			
15 Camshaft chain (¾" pitch x 78 links) 1 09156 16 Ratchet for timing chain adjuster 1 247540 17 Special bolt fixing ratchet and piston to block 1 247199 18 Spring for chain adjuster ratchet 1 267451 19 Piston for timing chain adjuster 1 247912 20 Set bolt (⅓" U.N.F. x 1¼" long) Fixing 2 256220 1 off on late type fixing 21 Stud (⅓" U.N.F.) Fiston 1 247144 Late type fixing. Check before ordering 22 Spring washer 1 254811 Late type fixing. Check before ordering 23 Nut (⅓" U.N.F.) block 1 254811 Late type fixing. Check before ordering 24 Cylinder for timing chain adjuster 1 277388 25 Steel ball (⅓" U.N.F.) 1 3739 26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (¼" U.N.F. x ½" long) Fixing damper to 2 255204	13	_:				
16 Ratchet for timing chain adjuster 1 247540 17 Special bolt fixing ratchet and piston to block 1 247199 18 Spring for chain adjuster ratchet 1 267451 19 Piston for timing chain adjuster 1 247912 20 Set bolt (\(\frac{5}{16}\)'' U.N.F. x 1\(\frac{1}{4}\)'' long) Fixing 2 256220 1 off on late type fixing 21 Stud (\(\frac{5}{16}\)'' U.N.F.) Fixing 2 247144 Late type fixing. Check before ordering 22 Spring washer 1 247144 Late type fixing. Check before ordering 23 Nut (\(\frac{5}{16}\)'' U.N.F.) block 1 254811 Late type fixing. Check before ordering 24 Cylinder for timing chain adjuster 1 277388 25 Steel ball (\(\frac{7}{32}\)'') for non-return valve 1 3739 26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (\(\frac{4}\)'' U.N.F. x \(\frac{1}{2}\)'' long) Fixing damper to 2 255204						
17 Special bolt fixing ratchet and piston to block 1 247199 18 Spring for chain adjuster ratchet 1 267451 19 Piston for timing chain adjuster 1 247912 20 Set bolt (\(\frac{5}{16}\)^\tilde{\textit{"}}\) U.N.F. x 1\(\frac{1}{4}\)^\tilde{\textit{"}}\ long \right) Fixing 2 256220 1 off on late type fixing 21 Stud (\(\frac{5}{16}\)^\tilde{\textit{"}}\) U.N.F.) Fixing 2 256220 1 off on late type fixing 22 Spring washer 1 247144 Late type fixing. Check before ordering 23 Nut (\(\frac{5}{16}\)^\tilde{\textit{"}}\) U.N.F.) block 1 254811 Late type fixing. Check before ordering 24 Cylinder for timing chain adjuster 1 277388 25 Steel ball (\(\frac{7}{32}\)^\tilde{\textit{"}}\) for non-return valve 1 3739 26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (\(\frac{1}{4}\)^\tilde{\text{"}}\) U.N.F. x \(\frac{1}{2}\)^\tilde{\text{"}}\long \(\frac{1}{2}\) Fixing damper to 2 255204	15		:s)			
18 Spring for chain adjuster ratchet 1 267451 19 Piston for timing chain adjuster 1 247912 20 Set bolt (\frac{5}{16}" U.N.F. x 1\frac{1}{4}" long)	16					
Piston for timing chain adjuster 1 247912	17		on to block			
20 Set bolt (\(\frac{1}{16}\)" U.N.F. x 1\(\frac{1}{4}\)" long) Fixing 2 256220 1 off on late type fixing 2 247144 Late type fixing 2 247144 Late type fixing 2 247144 Late type fixing 2 3075 21 Stud (\(\frac{1}{16}\)" U.N.F.) block 1 254811 Late type fixing. Check before ordering 2 3075 22 Spring washer 2 254811 Late type fixing. Check before ordering 2 247144 Late type fixing. Check before ordering 2 25581 Late type fixing. Check before ordering 2 277388 23 Steel ball (\(\frac{3}{2}\)") for non-return valve 1 3739 233326 24 Spring for chain tensioner 1 233326 233328 Late type fixing. Check before ordering 2 233328 Late type fixing 2 277388 2 27738					•	
21 Stud (\frac{5}{16}" U.N.F.) 22 Spring washer 23 Nut (\frac{5}{16}" U.N.F.) 24 Cylinder for timing chain adjuster 25 Steel ball (\frac{7}{32}") for non-return valve 26 Spring for chain tensioner 27 Retainer for steel ball 28 Idler wheel for timing chain 29 Cylinder for timing chain 20 Set bolt (\frac{4}{4}" U.N.F. x \frac{1}{2}" long) Fixing damper to 21						
22 Spring washer to cylinder 2 3075 23 Nut (\frac{5}{16}" U.N.F.) block 1 254811 Late type fixing. Check before ordering 24 Cylinder for timing chain adjuster 1 277388 25 Steel ball (\frac{7}{32}") for non-return valve 1 3739 26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (\frac{1}{4}" U.N.F. x \frac{1}{2}" long) \frac{1}{2} Fixing damper to 2 255204			Fixing		• •	•
23 Nut (5 / 16 " U.N.F.) block 1 254811 Late type fixing. Check before ordering 24 Cylinder for timing chain adjuster 1 277388 25 Steel ball (₹ / 16 ") for non-return valve 1 3739 26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (‡ " U.N.F. x ½ " long) Fixing damper to 2 255204		, - -	/ ·		Late type fixing.	Check before ordering
24 Cylinder for timing chain adjuster 1 277388 25 Steel ball (\frac{7}{32}") for non-return valve 1 3739 26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (\frac{1}{4}" U.N.F. x \frac{1}{2}" long)) Fixing damper to 2 255204			_			
25 Steel ball (\frac{7}{32}") for non-return valve	23	Nut (5/16" U.N.F.)	block		Late type fixing.	Check before ordering
26 Spring for chain tensioner 1 233326 27 Retainer for steel ball 1 233328 28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (‡" U.N.F. x ½" long) Fixing damper to 2 255204		Cylinder for timing chain adjuster				
27 Retainer for steel ball	25	Steel ball $(\frac{7}{32}'')$ for non-return valv	e	1 3739		
28 Idler wheel for timing chain 1 236067 29 Vibration damper for timing chain 1 275234 30 Set bolt (‡" U.N.F. x ½" long) \(\) Fixing damper to 2 255204		Spring for chain tensioner	*****	1 233326		•
29 Vibration damper for timing chain 1 275234 30 Set bolt (½" U.N.F. x ½" long) \(\) Fixing damper to 2 255204						
30 Set bolt (‡" U.N.F. x ½" long) Fixing damper to 2 255204	28	Idler wheel for timing chain	****	1 236067		
	29			1 275234		
31 Locking plate ∫ cylinder block 2 278769	30	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) $\int F$	ixing damper to	2 255204		
	31	Locking plate \int cy	linder block	2 278769		


VALVE GEAR AND ROCKER SHAFTS, DIESEL ENGINE, 2 LITRE, Series II



VALVE GEAR AND ROCKER SHAFTS, DIESEL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION	Qty	7. Part No.	REMARKS
1	Inlet valve	4	247568	
2	Exhaust valve	4	513481*	t .
3	Valve spring, inner and outer	8	276609	
4	Valve spring cup	8	268292	·
5	Split cone for valve, halves	16	268293	
6	Valve rocker, exhaust L.H	2	274772	
7	Valve rocker, exhaust R.H	2		
8	Bush for exhaust valve rocker	4		
9	Valve rocker, inlet L.H	2		
10	Valve rocker, inlet R.H	2	274775	
11	Bush for inlet valve rocker	4		
12	Tappet adjusting screw	8		
13	Locknut for tappet adjusting screw	8		
14	Tappet push rod	8		
15	Tappet, tappet guide, roller and set bolt assem			
16	Tappet	8		
17	Copper washer for tappet guide set bolt	8		
18	Valve rocker shaft	2		
19	Spring for rocker shaft	4		
20	Washer for rocker shaft'	8		•
21	Rocker bracket	5		4 off on 1961 models
	Rocker bracket, centre	1	524806	1961 models
22	Locating dowel for rocker bracket	2		
23	Stud for rocker bracket	3	247607	
24	Set bolt (5 U.N.F. x 2") Fixing	_		
	long) rocker bracket to			
25	Spring washer cylinder head	5		
26	Locating screw \ For rocker shaft at	2		
27	Spring washer ∫oil feed bracket	2	2 3075	


OIL PUMP, DIESEL ENGINE, 2 LITRE, Series II



OIL PUMP, DIESEL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIP	TION	-		ty.	Part No.		REMARKS
REF.	OIL PUMP ASSEMBLY				1	247662	1958-59	
	OIL PUMP ASSEMBLY				i	513640	1960-61	
	Oil pump body				i	247663	1958-59	
1	Oil pump body				i	513641	1960-61	
2	Spindle for idler gear	••••			1	502209	1960-61	
L	Oil pump gear, driver				1	247659	1958-59	
3	Oil pump gear, driver				i	240555	1960-61	
J	Oil pump gear, idler				i	237884	1958-59	
4	Oil pump gear, idler	****	·		i	278109	1960-61	
5	Bush for idler gear	****		••••	i	214995	1960-61	
6	Steel ball	••••			i	3748		
7	Plunger				i	273711		
8	Spring For oil pres	eure rele	ase valve		i	265623		
. 9	Washer Toron pres	baro rere			1	243970	,	
10	Plug				1	265624		
10	Oil pump cover				ĺ	247658	1958-59	
11	Oil pump cover	****			1	513639	1960-61	
12	Set bolt ($\frac{5}{18}$ " U.N.F. x $\frac{7}{8}$	″ long)]	Fixing cove	r	4	255227		
13	Spring washer		to body		4	3075		
14	Oil filter for pump	ر			1	247664		
15	Sealing ring \(\) Fixing o	il filter			1	244488		
16	Lock washer to oil pu				1	244487		
•••	Drive shaft for oil pump				1	247739	1958-59	
17	Drive shaft for oil pump		****		1	511680	1960-61	
18	VERTICAL DRIVE SHA		SEMBLY		1	503266		
19	Circlip for drive shaft	****	****		1	247742		
20	Bush for drive shaft gear				1	247653		
21	Locating screw for drive sh	aft bush	ı		1	279554		
22	Set bolt (5 " U.N.F. x 1" l			mp	2	255228		
23	Lock washer		cylinder blo		2	247665		
		-						

FRONT COVER, SIDE COVERS AND SUMP, DIESEL ENGINE, 2 LITRE, Series II



FRONT COVER, SIDE COVERS AND SUMP, DIESEL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION		Qty		REMARKS
1	FRONT COVER ASSEMBLY		1	510805	
2	Dowel locating front cover		2	2 6395	
3	Oil seal for front cover			1 213744	
4	Stud \ Fixing			1 247595	For alloy type front cover
5	Stud water pump		2	2 247159	3 off with cast iron type front cover
6	Mud excluder			1 247766	
7	Drive screw fixing excluder		{	8 78001	
8	Joint washer for front cover	·····		1 247564	
9	Joint washer at water inlet	,		1 247537	
10	Spring washer)	1.		
11	Set bolt $(\frac{5}{16}$ " U.N.F. x 3" long)	Fixing front		9 256030	
12	Set bolt (5 U.N.F. x 2 long)	cover and		3 256226	
	Set bolt $(\frac{5}{16}"$ U.N.F. x $2\frac{1}{4}"$ long)	water pump		1 256027	
	Distance piece	to cylinder		1 2920	
	Plain washer	block		2249	
	Locking plate			1 501198	
13	Nut (5 " U.N.F.)	J		2 254801	
14	Side cover and oil filler pipe for			1 510730	
15	Joint washer for side front cover			1 247555	
16	SIDE COVER ASSEMBLY, F	REAR		247563	
17	Stud for fuel pump		****	2 500792	
18	Plain washer			2 2220	
19	Nut $(\frac{5}{16}$ " U.N.F.) \Rightarrow Fixing student	ıd		2 254911	
20	Split pin			2 24221 247554	
21	Joint washer for side cover, rear	`	••••		
22	Spring washer	Fixing			
23	Set bolt (18 U.N.F. x 18 long)	>rear side		5 255029 1 256020	
	Set bolt (5 U.N.F. x 1 1 long)			7 3075	
24	Spring washer	Fixing front		7 255026	
25	Set bolt (5 " U.N.F. x 3 long)		ile	1 247522	
26	Crankcase sump		****	1 3088	
27	Drain plug for crankcase sum		• • • • •	1 230507	
28	Washer for drain plug			1 247088	
29	Joint washer for crankcase sump Set bolt (5 U.N.F. x 7 long)		to	19 255227	
30	Spring washer	cylinder block	k '	19 3075	
31 32	Set bolt $(\frac{5}{16}"$ U.N.C. $\times \frac{3}{4}"$ long	Fixing sump	•		For use with alloy type front cover
33	Spring washer	to front cover	r	3 3075	
34	Oil level rod	, to mont cover	•	1 274154	
35	Sealing ring for rod	••••		1 210517	
36	Tube for oil level rod			504032	
37	Double-ended union	****		236060	
38		tube to cylinde	r	1 243958	
39	Olive block	-3		1 236408	
40	Union nut			1 236407	7
41	Oil filler cap and breather filter,	AC 7222073		1 236406	5
• • •	·· •				•

FUEL INJECTION SYSTEM, DIESEL ENGINE, 2 LITRE, Series II, 1958-60




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	Fuel pump, mechanical	1	501030	
	Sediment bowl, AC 1523620	1	236891	•
	Retainer for bowl, AC 5592050	1	268797	
	Filter for bowl, AC 854009	1	506796	
	Washer for bowl, AC 5593321	1	241225	
2	Joint washer, fuel pump to cylinder block	1	275565	
-	Repair kit for fuel pump AC 1524507	1	272069	
	Overhaul kit for fuel pump AC 7950463	1	524684	
3	Self-locking nut fixing fuel pump	2	252161	
4		, 2	247929	
5	Joint washer for inlet union	1	243967	
6	En (·)	1	50499	
	_	I	270115	
7	Nut Fixing elbow to	1		
8	Olive ∫ fuel pump	ì	270105	
9	Flexible fuel feed pipe complete to pump	l	276267	
10	Flexible fuel pipe complete, leak-off to tank	!	276382	
11	Clip fixing flexible fuel leak-off pipe		276627	
12	Distributor pump, CAV DPA 3240095	1	276407	Alternatives. Check
	Distributor pump, CAV DPA 3240097	1	513617	∫CAV number before ordering
	Accelerator control lever \(\subseteq \text{For} \)	1	277553	Use with distributor
	Stop lever ∫ distributor pu	ımp 1	277619	∫ pump DPA 3240095
	Accelerator control lever \(\) For	1	509009	Use with distributor
	Stop lever ∫ distributor pu	ımp 1	509011	∫ pump DPA 3240097
	Joint washer for injection pipe, distributor p	oump		
	end ,	6	247802	•
13	Joint washer for distributor pump	1	247212	
14	Plain washer Fixing	3	2920	
15	Spring washer >distributor pump	-3	3075	•
16	Nut $\binom{5}{16}$ U.N.F.) to cylinder block	3	254801	
	Sealing plugs for injection system	1 set	279702	For sealing unions in distributor pump
17	Fuel filter	1	515437)
18	Element for fuel filter	1	271479	
19	Gasket, large, for fuel filter	1	278282	
20	Check valve for filter, overall length 1½"	1	279810	Alternative to 528108.
	onon various in inter, overall longin va			Check before ordering
	Check valve and filter bolt, overall length	2 3 "		Should believe or dorling
	C.A.V. 711/269	1	528108	Alternative to 279810.
		*****	220100	Check before ordering
21	Copper washer for check valve	1	517976	Check before ordering
22	= <u>-</u>	1	278517	Not part of engine
44	Mounting bracket for fuel filter Bolt (\frac{8}{8}" U.N.F. x 1\frac{1}{8}" long) \cap Fixing	3	255048	
		3	3076	assembly
	Spring washer			\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
22	Nut (\frac{3''}{8} U.N.F.) \tag{to bracket}	3	254812	
23	Set bolt (\frac{3}{6}" U.N.F. x \frac{3}{4}" long) Fixing brack		255045	
24	Spring washer		3 076	
25	Adaptor in filter for distributor pump and		0.45550	
~	pipe	2	247778	
26	Joint washer In filter for	1	243957	
27	Union Sleak-off pipe	1	502776	
28	Restrictor for filter union]	272396	J
29	Leak-off pipe complete, injector to filter	1	274847	
30	Banjo bolt \(\) Fixing leak-off pipe	4	273521	•
31	Washer ∫to injector	8	273069	
32	Drain pipe complete, distributor pump to filt	ter l	2 73 070	· .
33	Pipe complete, mechanical pump to filter	1	277774	Not part of engine assembly
34	Joint washer \(\) Fixing pipe	2	247808	
35	Banjo bolt Sto filter	1	247774	J·
	1 2 2 4 ********************************			

FUEL INJECTION SYSTEM, DIESEL ENGINE, 2 LITRE, Series II, 1958-60





PLATE REF.	1 2 3 4 DESCRIPTION		Qı	t y .	Part No.	REMARKS
36	Grommet for fuel filter pipe			İ	272512	
37	Clip for grommet			1	232425	
38	Bolt (4" U.N.F. x 2" long) Fixing	grommet		1	255006	
39	Spring washer \rightarrow and clip	o to oil		1	3074	Not part of engine assembly
40	Nut (\frac{1}{a} U.N.F.) filler pi	pe		1	254800	
41	Pipe complete, filter to distributor pu	mp		1	277556	•
42	Banjo bolt \ Fixing pipe to			1	275266	
43	Washer ∫ distributor pump			2	275265	
44	Injector complete			4	273452	
45	Nozzle for injector			4	247726	
46	Joint washer for injector, copper		••••	4	247179	
47	Joint washer for injector, steel	****	••••	4	272474	
48	Clamping strip for injector			4	247213	
49	Spring washer \(\) Fixing injector			8	3075	
50	Nut $(\frac{5}{16}"$ U.N.F.) \int to cylinder head			8	254801	
	Injector pipe to No. 1 cylinder		••••	1	277766	
	Injector pipe to No. 3 cylinder	****		1	277768	
_	Injector pipe to No. 4 cylinder	••••		1	277769	
51	Injector pipe to No. 2 cylinder		• • • •	1	277767	
52	Damper for injector pipe			4	277838	·
53	Shroud for damper			2	277839	
54	Bracket for damper shroud	••••		•	277816	
55	Support strap for shroud			!	278002	
56	Steady strap for shroud		••••	1	278021	
57	Back plate for shroud		••••	1	277815	
58	Locknut (5/6" U.N.F.)			4	254851	
59	Plain washer	Fixing		4	2220	
60	Bolt, front (5" U.N.F. x 14" long)	≻shrouds,		1	256020 256222	
61	Bolt, rear (5 U.N.F. x 12 long)	dampers			3075	
62	Spring washer	brackets		2	254811	
63	Nut (1/6" U.N.F.) EXTRA FUEL FILTER CO	MPLETE	7	4	4.7 4 01 I	
	ASSEMBLY ON DASH		٠.	1	502583	Standard on Export models. Optional equipment
	ASSEMBLI ON DASH	.****	•••	'	302303	on Home models
	Rivnut for dash			2	501224	on a folio modelo
	First floor on deeb	****		ĩ	515437	•
	Adaptor for fuel filter outlet	••••		i	247778	
	Plug for fuel filter	••••		i	272224	
	Air bleed plug for filter			i	509513	
	Joint washer for plug			i	517976	
		ixing		3	255029	
		ter to		3	3075	
		ish		4	2249	
	Inlet pipe complete, flexible pipe t		••••	1	501251	
	Joint washer \ Fixing inlet pipe		••••	2	247808	
	Banjo bolt to filter			ī	247774	
				·	•	



1 2 3 4 5	Fuel pump, mechanical Filter for bowl, AC 854009	Qt	1	501030	
2 3 4 5	Filter for bowl, AC 854009			-	
3 4 5			1	506796	
4 5	Washer for bowl, AC 5593321		1	241225	
5	Sediment bowl, AC 1523620		1	236891	
	Retainer for bowl, AC 5592050		i 1	268797	İ
U	Joint washer, fuel pump to cylinder block		1	275565	· ·
7			2	252161	
	Self-locking nut fixing fuel pump Joint washer For mechanical pump		2	243967	Part of
8	•		2	247929	engine
9	Union Sinlet and outlet	,	<u> </u>	513617	assembly
10	Distributor pump, CA DPA 3240097	••••	1		assembly
11	Accelerator control lever For distributor		1	509009	
12	Stop lever J pump		J	509011	
13	Joint washer for injection pipe, distributor pu		_		
	end	••••	6	247802	
14	Joint washer for distributor pump		1	247212	
15	Plain washer		3	2920	
16	Spring washer > pump to		3	3075	
-17	Nut $(\frac{5}{16}"$ U.N.F.) cylinder block		3	254801	
	Sealing plugs for injection system		1 set	279702	For sealing unions in distributor pump
18	Fuel filter CAV type FS	,	1	517682	_
	Element for fuel filter, CAV 7111-296	****	1	517711	
	Seal for element, small, CAV 5855-30G		1	522937	
	Seal for element, large, CAV 5339-2568		2	522938	
	Special centre bolt for filter, CAV 7111-291		1	522939	·
	Washer for centre bolt, CAV 5936-188A		1	522940	
10		••••	1	517689	
19	Plug for filter, CAV Z 7111/312		1	517706	
20	Joint washer for plug, CAV Y 5936/58T	••••	า ว		
21	Bolt		2	256220	
22	Distance plate		ı	517683	
23	Spring washer Fixing filter to dash		2	3075	
24	Plain washer		2	2249	
25	Rivnut	,	2	501224	S
26	Non-return valve for filter		1	517707	Not required when additional
27	Joint washer for non-return valve		1	517706	fuel filter is fitted
28	Leak-off pipe complete	****	1	515980	· .
29	Banjo bolt \ Fixing leak-off pipe		4	273521	Part of engine assembly
30	Washer ∫ to injector		8	273069	J
31	Fuel pipe, spill return to tank		1	509909	
32	Banjo bolt \ Fixing spill return		1	505805	
33	Joint washer pipe to filter		2	517976	
34	Bracket for leak-off pipe		1	521584)
35	Locknut (16" U.N.F.) fixing bracket to injector	stud	2	254861	
36	Bolt (2 B.A. x 3" long) Tixing spill return		<u>-</u>	250961	Part of engine assembly
37	Spring washer to bracket on	h-h-	i	3073	
38	Nut (2 B.A.) injector stud		1	2247	· ·
			1	525168	•
39	Clip for spill return pipe	• · · · ·	í 1		₹ .
	Fuel pipe, mechanical pump to filter	••••	1 1	517687	· ·
	Nut Fixing pipe to		l 1	517690	N
	Olive Sfilter		1	270104	Not required when additional fuel filter is fitted
	Nut Fixing pipe to		!	270115	
	Olive mechanical pump		1	270105	1






PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y. Part No.	REMARKS
40	Fuel pipe, filter to distributor pump		1 517685	
41	Nut Fixing pipe		1 517690	
42	Olive to filter	j	270104	
43	Banjo bolt Fixing pipe to	-	275266	
44	Joint washer distributor pump	1	2 275265	
45	Clip, fixing pipe to distributor pump		1 8885 -	
46	Fuel pipe, distributor pump return to filter		517686	
47	Nut Fixing pipe to		1 517690	
48	Olive filter		1 270104	
49	Clip, fixing fuel pipe to dash		1 517684	•
50	Drive screw, fixing clip		2 78006	
51	Double pipe clip (fixing distributor pump fee	d and		
	return pipes together)		2 243395	
- 52	Bolt (2 B.A. x ½" long) Fixing pipes		234603	
53	Spring washer and		1 3073	
54	Nut (2 B.A.) clips		1 2247	
55	Injector complete, CAV D 5365501		4 273452	
56	Nozzle for injector		4 247726	
57	Joint washer for injector, copper	,	4 247179	1.5
5 8	Joint washer for injector, steel		4 272474	
59	Clamping strip f r injector		4 247213	
60	Spring washer \(\) Fixing injector		8 3075	
61	Nut $(\frac{5}{16}"$ U.N.F.) \int to cylinder head		8 254801	·
	Injector pipe to No. 1 cylinder		277766	
	Injector pipe to No. 3 cylinder		277768	
	Injector pipe to No. 4 cylinder		1 277769	
62	Injector pipe to No. 2 cylinder		1 277767	
63	Damper for injector pipe		4 277838	
64	Shroud for damper			Part of engine assembly
65	Bracket for damper shroud		1 277816	
66	Support strap for shroud		1 278002	
67	Steady strap for shroud		1 278021	
68	Blackplate for shroud		1 277815	
69	Locknut $(\frac{5}{16}"$ U.N.F.) \int Fixing straps to		4 254861	ļ
70	Plain washer \(\int \text{ injector studs} \)		4 2220	
71	Bolt, front $(\frac{5}{16}"$ U.N.F. x			1 .
	1½" long) Fixing shrouds	and	1 256020	
72	Bolt, rear $\binom{5}{16}$ U.N.F. x dampers to			
	$1\frac{1}{2}''$ long) \Rightarrow backplate, strap		1 256222	
73	Spring washer and support br		2 3075	
74	Nut $\left(\frac{5}{16}^{"}$ U.N.F.)		2 254811	J




				- 1011(OII	AL, 2 LITTLE, Delles II, 1901
PLATE REF.	1 2 3 4 DESCRIP	ΓΙΟΝ	Qty.	Part No.	REMARKS
	ADDITIONAL FUEL FILTE	R, COMPLE".	ΓE		
	ASSEMBLY		1	522756)
75	Fuel filter, CAV type FS		1	517682	
76	Element for fuel filter, CAV	7111-296	1	517711	
77	Seal for element, small, CA\	/ 5855-30G	1	522937	
78	Seal for element, large, CAV	7111-298	2	522938	
79	Special centre bolt for filter,	CAV 7111-29	1 1	522939	
80	Washer for centre bolt, CAV	⁷ 5936-188A	1	522940	
81	Plug for fuel filter		2	517689	
82	Joint washer for plug		2	517706	·
83	Plug for fuel filter, top, leak-off	, CAV Z/7111,	/311-1	517855	
84	Joint washer for leak-off plug		1	517976	
85	Transfer pipe, extra filter to ba		1	517692	Standard on Export models.
86	Nut \ \ \ \ Fixing pipe	:	2	517690	Optional equipment on Home models.
87	Olive ∫ to filter		2	270104	
88	Bolt (18" U.N.F. x 11 long))	2	256220	
89	Distance plate		1	517683	
90	Spring washer	Fixing filter	2	3075	
91	Plain washer	to dash	2	2249	
92	Rivnut (5 " U.N.F.)		2	501224	
93	Fuel pipe, mechanical pump to	twin filters	1	517860	
94	Nut \ \ Fixing pipe		1	517690	
95	Olive ∫ to filter		1	270104	
96	Nut Fixing pipe to		1	270115	~
97	Olive \int mechanical pump		1	270105)
	Repair kit for mechanical fuel pur	mp, AC 15245	07 1	272069	
	Overhaul kit for mechanical fuel	l pump,			
	AC 7950463	****	1	524684*	

WATER PUMP AND THERMOSTAT, DIESEL ENGINE, 2 LITRE, Series II




WATER PUMP AND THERMOSTAT, DIESEL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	WATER PUMP ASSEMBLY	1	501041	
1	Water pump casing	1	501039	
2	Pump spindle and bearing	1	523354 —	
3	Hub for fan	1	2 444 58 `	
4	Carbon ring and seal unit	1	244207	
5	Impeller for pump	1	247916/	
6	Spring washer \(\) Locating	1	3074	
7	Special set bolt ∫ bearing casing	l '	247078	
8	Joint washer for water pump	, 1	2 47 919	
9	Spring washer \(\) Fixing water pump	3	3074	-
10	Nut (½" U.N.F.) ∫ to front cover	3	254800	
11	Joint washer \(\frac{1}{2}\) For heater return	1	243959	
12	Plug ($\frac{3}{8}$ " B.S.P. \int in water outlet pipe	1	250978	
13	Thermostat, AC 1572270	1	513465)	
14	'O' ring, thermostat to water outlet pipe	1	502832	
15	Water outlet pipe, thermostat to radiator	1	501031 > 1958-60	·
16	Washer for outlet pipe	1	247874	
17		outlet pipe 3	3074	
18	Set bolt (1" U.N.F. x 21" long) f to cylin	der head 3	256009	·
19	Hose for by-pass pipe	1	273789	
20	Hose clip for by-pass pipe	2	50318	
21	Thermostat	1	504736)	•
22	Thermostat housing	1	516059	No.
23	Joint washer for thermostat housing, upp		511957	
24	Water outlet pipe, thermostat to radiator		511956	
25	Joint washer for thermostat housing, low-		247874	
26	Set bolt (# U.N.F.) Fixing thermostat			
	$x 2\frac{1}{2}'' \text{ long}$ > and outlet pipe to		256029 \> 1961	
27	Spring washer	3	3074	
28	Thermostat by-pass pipe	1	518818	
29	Joint washer for by-pass pipe	1	511958	
30	Set bolt (5 U.N.F. Fixing by-pass			
	x 1" long) pipe to	2	255228	
31	Spring washer J thermostat housi		3075	
32	Fan pulley	1	24 7 520	
33	Fan blade	1	271568	
34	Spring washer Fixing fa		3074	
35	Set bolt (¼" U.N.F. x ¾" long) ∫ and pulled	-	255007	
36	Fan and dynamo belt	1	511963	
	Water pump overhaul kit	1	506003	



MANIFOLDS, DIESEL ENGINE, 2 LITRE, Series II


PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	Inlet manifold	1	272376	A
2	EXHAUST MANIFOLD ASSEMBLY	1	247651	· ····································
. 3	Stud for exhaust pipe	4	252621	
4	Joint washer for inlet and exhaust manifold	1	247101	
5	Clamp for manifold	4	500961	
6	Plain washer	5	2550	
7	Spring washer \rightarrow and exhaust	9	3075	
8	Nut (18" U.N.F.)) manifold	9	254801	



STARTER MOTOR AND SOLENOID, DIESEL ENGINE, 2 LITRE, Series II

PLATE REF.	1 2 3 4 DESCRIPTION C)ty.	Part No.	REMARKS	
REF.	STARTER MOTOR COMPLETE				
1	LU M45G 26147A	1	277446		
2	Bracket for starter, commutator end LU 272845	1	279005		
3	Bush, commutator end LU 255491	i	242958		
	Spring set for brushes LU 270004	1	261239		
4	171070004	i	279006		
5	Thrust washer, commutator end LU 152380	i	279007		
6		i	279008		
7	Bracket for starter, drive end LU 272745	i	270243		
8	Bush for bracket LU 271364		279009		
9	Bracket for brake LU 272700	-	270245		
10	Bush for brake bracket LU 271733	!			
11	Field coil for starter LU 272394	!	279010		
12	Brushes for starter motor set LU 271735	ļ	270225		
13	Drive assembly for starter motor LU 292124		279011		
14	Rivet for pinion retaining ring (Lucas 291887)) <u> </u>	526258		
15	Return spring for starter pinion LU 292076	I	512889		
16	Bush, pinion end LU 292053	2	279012		
17	Clutch adjusting shim (0.006") LU 291374 As a	require	ed 270239		•
	Clutch adjusting shim (0.005") LU 291378 As a	require	ed 270240		
	Clutch adjusting shim (0.004") LU 291379 As a	require	ed 270241		
18	Clutch plates, set LU 291540	1	270238		
19	Circlip retaining clutch assembly LU 291560	1	270235		
20	Lock ring retaining clutch plates LU 291862	1	279013		
21	Brake shoe complete with springs LU 272701	1	279014		
22	Driving washer for brake shoe LU 272340	1	279015		
23	Lock ring retaining brake LU 272337	1	279016		•
24	Thrust washer, drive end LU 134950	1	279017		
25	Cover band for starter LU 272396	1	279018		
26	Belt for starter motor LU 272660	2	279019		
27	Lock washer for bolt LU 188382	2	279020		
28	Rubber grommet in drive end bracket				
20	LU 272552	1	279021		
29	Solenoid for starter motor LU 76458A	1	279022		
30	Contact plate complete for starter solenoid.	•			
. 50	LU 54330168	1	519004		
31	Base complete for starter solenoid, LU	·			
וכ	54330169	1	519005		
27	Gasket for starter solenoid, base, LU	•	317003		
32		1	519006		
22	765842 Terminal nut for starter solenoid, LU 170570	-	519007		
33		7	317001		
34	Terminal washer for starter solenoid, LU	4	519008		
	185062		717000		
35	Terminal screw for starter solenoid, LU		519009		
	121610	ì	217007	•	
36	Terminal connector for starter motor, LU	1	510010		
	272555	ı	519010		
37	Plunger spring for starter solenoid, LU	1	£10011		
	765866	!	519011		
	Sundry parts kit LU 271731	ŀ	270251		
38	Bolt $(\frac{7}{16}"$ U.N.C. x $1\frac{1}{4}"$ long) Fixing starter	Ĭ	253068		
39	Spring washer > motor	3	3077		
40	Nut (76" U.N.F.)	2	254803		


DYNAMO AND FIXINGS, DIESEL ENGINE, 2 LITRE, Series II



DYNAMO AND FIXINGS, DIESEL ENGINE, 2 LITRE, Series II

		· · · · · · · · · · · · · · · · · · ·			GINE, 2 LIIKE,	
PLATE REF.			Qty.	Part No.		REMARKS
1	DYNAMO COMPLETE, O	C45 PV6 LU 224	89 1	512249		•
2	Bracket, commutator end l	LU 239266	1	263394	For dynamo type PV5	
	Bracket, commutator end I	LU 54210057	1	512798	For dynamo type PV6	
3	Armature for dynamo LU	239 42 8	1	512800		
4	Brushes for dynamo, set L	U 238061	1	261256	For dynamo type PV5	
	Brushes for dynamo, set L	U 54212267	1	512797	For dynamo type PV6	
5	Spring set for brushes LU	238062	1	244708	For dynamo type PV5	
	Spring set for brushes LU	54210091	1	512799	For dynamo type PV6	
6	Field coil for dynamo LU	238820	1	264435		
7	Ball bearing, front	••••	1	260026		
8	Bush, commutator end LU		1	263395		٠
9	Bracket, drive end LU 239		1	264433		
10	Oiler for dynamo LU 2393		1	264431		
11	Bolt for bracket LU 23852		2	264437	For dynamo type PV5	
• •	Bolt for bracket LU 27266		2	279019	For dynamo type PV6	
12	Terminal LU 227625		1	264436		
	Sundry parts, set LU 2390		1	264438		
13	Pulley for dynamo		1	272704		
14	Woodruff key		1	1664		
15	Lock washer >Fixing pulle	ev to dynamo	i	03748		
16	Special nut	by to dynamic	1	3466	For dynamo tppe PV5	
10	Special nut		1	240271	For dynamo type PV6	
17	Support bracket for dynamo		1	277999	Tor dynamo type I vo	
18	Steady bracket for dynamo si		1	278000		•
19	Bolt $(\frac{5}{16}$ " U.N.F. x $1\frac{3}{8}$ " long)		1	256421		
21			ı	230421		
21	Self-locking nut	to support and	1	252161		
23	(5/ U.N.F.)	steady brackets	1 2	3075	•	
22 23	Spring washer	Fixing support	2	3073		
23	Set bolt (18" U.N.F. x	bracket to	2	255025		
24	§" long)	cylinder block	2			
2 4	Special stud fixing dynamo			278001		
25	Distance piece	Fixing dynamo	, I	272303		
26	Shim washer	to special stud	As require			
27	Self-locking nut (5 "U.N.F.)		. 1	252161		
28	Nut (16" U.N.F.)	Fixing dynamo		254801		
29	Self-locking nut (16" U.N.F.)	J special stud at fi	ront I	252161		
30	Strap for dynamo, rear		[277544		
31	Bolt (%" U.N.F. x 1%" long)		!	256221		
32	Self-locking nut (5 "U.N.F.)		l	252211		
33	Adjusting link for dynamo, re		I	277543	•	
34	Bolt (16" U.N.F. x 3" long)		_	255027		
35	Plain washer	>link to dynamo	İ	2266		
36	Self-locking nut (5 "U.N.F.)	_	1	252211	•	
37	Bolt (18" U.N.F. x 7" long)	Fixing adjusting	g 1	255027		
38	Self-locking nut	>link to engine				
	(5 " U.N.F.)	mounting foot	1	252211		
39	Adjusting link for dynamo, fr		1	274862		
40	Special set bolt Fixing from	nt	1	233568		
41	Plain washer adjusting l	ink	1	2550		
42	Spring washer J to dynamo	ı	1	3075		
43	Set bolt (18" U.N.C. x 3" long	g)] Fixing	1	253026		
44	Spring washer	adjusting link	: 1	3075		,
45	Distance washer	to front cover	r 1	2266		


FLYWHEEL AND CLUTCH, DIESEL ENGINE, 2 LITRE, Series II



FLYWHEEL AND CLUTCH, DIESEL ENGINE, 2 LITRE, Series II

PLATE	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS	 3
REF.	FLYWHEEL HOUSING ASSEMBLY	1	277531		··
2	Stud (§ U.N.F.) fixing flywheel housing		211751		
2	bell housing	12	247145		
3		2	247146		
4	Stud (7 U.N.F.) for starter motor	2	277532		
5	Sealing ring for flywheel housing	1	246169	•	
.6		1	56140		
7	Joint washer for cover plate	2	50216		
8	Nut (‡" U.N.F.) fixing cover plate	2	254800		
9	Bolt (\sum 'U.N.F. x 1\sum 'long) Fixing flywheel	2	256043		
10	Bolt (§" U.N.F. x 1 long) > housing to	6	255048		
11	Spring washer cylinder block	8	3076		
12	Indicator for engine timing	1	500597		
13	Drain plug for housing	1	329 0		
14	Stowage bracket for drain plug	1	276511		-
15	FLYWHEEL ASSEMBLY	1	247167		
	Ring gear for flywheel	1	510489		
16	Special fitting bolt fixing clutch cover plate	6	247166		•
17	Dowel locating clutch cover plate	2	231759		
18	Bush for primary pinion	1	08566		
19	Locker Fixing flywheel	4	3674		
20	Special set bolt ∫to crankshaft	8	247135		
	CLUTCH ASSEMBLY BB 45693/14	1	242130		
21	Cover plate for clutch BB 45481	1	231888		
22	Pressure plate for clutch BB 42652	1	231880	•	
23	Release lever for clutch BB 48234	3	242993		
24	Strut for release lever BB 42606	3	231884	,	
25	Eyebolt and nut for release lever BB 48508	3	242996		
26	Pin for release lever BB 42604	3	231885		
27	Anti-rattle spring for release lever BB 47688		231883		7
28	Clutch spring (yellow and light green) BB 4	_	243593	* *	
29	Clutch plate complete BB 47626/122	1	511682	The second secon	
	Lining package for clutch plate, BB 46627	l		Ferodo lining Alternatives.	- ordorina
20	Lining package for clutch plate, BB KL750		517026	Mintex lining ∫ Check before	e ordering
30	Self-locking nut (18" U.N.F.) fixing cover plan	te 0	252211	T	


CYLINDER BLOCK, DIESEL ENGINE, 21 LITRE, Series IIA



CYLINDER BLOCK, DIESEL ENGINE, 21 LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	ENGINE AND CLUTCH ASSEMBLY	1	520041*	
1	CYLINDER BLOCK ASSEMBLY	1	518725*	
	Cylinder block, crankshaft, pistons and camsl	haft l	528114*	
2	Core plug I" dia	2	09191	
	Core plug, 1½" dia	2	250840	
3	Cup plug	3	525428*	
4	Plug for immersion heater boss	1	277496	
5	Stud for front cover and water pump	1	514527*	
6	Stud for distributor pump	3	252624	
7	Stud for sump	1	252621	
8	Set bolt for main bearings	6	504007	
9	Special plain washer for set bolt	6	504006	
10	Dowel, locating main bearing and bearing		501593	
11	Dowel, locating flywheel housing	2	52124	
12	Dowel for timing chain adjuster	2	213700	
13	Plug for oil gallery, front	1	247127	
14	Plug for oil gallery, rear]	250978	
15	Joint washer for rear plug	1	243959	
16	Plug for tappet feed gallery pipe, front	1	247861	
17	Plug for tappet feed gallery pipe, rear	I	273166	
18	Joint washer for plug	1	243968	
19	Packing for rear main bearing cap	2	524637	•
20	Drain tap for cylinder block]	243237	
21	Joint washer for drain tap	1	213959	-
22	Engine front support bracket complete, L.H.		525481	•
23	Engine front support bracket complete, R.H.		271975	
24	Locker Fixing brack		212430	
25	Set bolt ($\frac{1}{2}$ " U.N.F. x " long) \int to cylinder b	olock 4	255085	
	Decarbonising gasket kit	1	525521*	
	Engine overhaul gasket kit	1	525520*	


CRANKSHAFT, DIESEL ENGINE, 21 LITRE, Series IIA



CRANKSHAFT, DIESEL ENGINE, 21 LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION Qty.	Part No.	REMARKS
1	CRANKSHAFT ASSEMBLY, STD 1	527167*	
•		525852*	
	CRANKSHAFT ASSEMBLY, .010" U.S. CRANKSHAFT ASSEMBLY, .020" U.S. CRANKSHAFT ASSEMBLY, .030" U.S. CRANKSHAFT ASSEMBLY, .040" U.S. 置 1	525853*	
	CRANKSHAFT ASSEMBLY, .020" U.S. 〉 質	525854*	
	CRANKSHAFT ASSEMBLY, .040" U.S.	525855*	
2	Dowel for flywheel 1	265779	•
3	Main bearing, front and centre, Std. 2	518748*	
	Main bearing, front and centre, .010" U.S. 2	518749*	
	Main bearing, front and centre, .020" U.S. 2	518750*	
	Main bearing, front and centre, .030" U.S. 2	518751*	
	Main bearing, front and centre, .040" U.S. 2	518752*	
4	Main bearing, rear, Std.	518753*	
	Main bearing, rear, .010" U.S.	518754*	
	Main bearing, rear, .020" U.S. Pairs 1	518755*	
	Main bearing, rear, .030" U.S.	518756*	
	Main bearing, rear, .040" U.S.	518757*	
5	Thrust washer for crankshaft, Std.	518758*	
	Thrust washer for crankshaft, .0025" O.S.	518759*	
	Thrust washer for crankshaft, .005" O.S.	518760*	
	Thrust washer for crankshaft, .0075" O.S.	518761*	
	Thrust washer for crankshaft, .010" O.S.	518762*	
	Rear bearing oil seal assembly 1	525927*	
6	Rear bearing split seal halves 2	523240*	
7	Oil seal and garter spring 1	529365	
	Silicone grease, M.S.4, 1 oz. tube 1	270656	
8	Dowel, lower Fixing split seal 2	519064	
9	Dowel, upper \rightarrow to cylinder block 2	246464	
10	Spring washer and rear 6	3074	•
11	Bolt $\binom{1}{4}$ U.N.F. x $\frac{7}{8}$ long) \int bearing cap 6	255008	
12	Chainwheel on crankshaft 1	235726	
13	Key locating chainwheel and vibration damper 2	235770	•
	VIBRATION DAMPER ASSEMBLY I	524203*	
14	DAMPER FLYWHEEL AND BUSH		
	ASSEMBLY 1	524204*	
15	Bush for flywheel 2	236289	·
16	Driving flange 1	247674	
17	Rubber disc for damper 2	03017	
18		uired 03020	
19	Set bolt $(\frac{1}{4}" \text{ U.N.F. } \mathbf{x} \frac{5}{8}" \text{ long})$ Fixing 6	255006	·
20	Double tab washer	247647	
21	Starting dog 1	503665	
22	Lock washer for starting dog I	247771	


CONNECTING ROD AND PISTON, DIESEL ENGINE, 21 LITRE, Series IIA



CONNECTING ROD AND PISTON, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	CONNECTING ROD ASSEMBLY	4	527169*	
2	Gudgeon pin bush	4	247583	
3	Special bolt Fixing connecting	8	519440*	·
4	Self-locking nut \(\int \colon \text{rod cap} \)	8	277390	
5	Connecting rod bearing, pairs, Std	4	524151*	
	Connecting rod bearing, pairs, .010" U.S.	4	524152*	
	Connecting rod bearing, pairs, .020" U.S.	4	524153*	•
	Connecting rod bearing, pairs, .030" U.S.	4	524154*	·
	Connecting rod bearing, pairs, .040" U.S.	4	524155*	
6	Piston assembly, Std., Low Grade	4	520237*	
	Piston assembly, Std., High Grade	4	520240*	
	Piston assembly, .010" O.S	4	520242*	
	Piston assembly, .020" O.S	4	520244*	
	Piston assembly, .030" O.S	4	520246*	
	Piston assembly, .040" O.S	4	520248*	
7	Piston ring, compression, Std., chromed	4	520977*	
	Piston ring, compression, .010" O.S.	. 4	520936*	
	Piston ring, compression, .020" O.S. Piston ring, compression, .030" O.S. Piston ring, compression, .040" O.S.	4	520937*	
	Piston ring, compression, .030" O.S.	4	520938*	
	riston ring, compression, .040 O.S.	4	520939*	
8	Piston ring, compression, Std., tapered	8	520978*	•
	Piston ring, compression, .010" O.S.	8	520940*	
	Piston ring, compression, .020" O.S.	8	520941*	
	Piston ring, compression, .020" O.S. Piston ring, compression, .030" O.S.	8	520942*	
	Piston ring, compression, .040" O.S.	8	520943*	
9	Scraper ring, Std	4	515677*	
	Scraper ring, .010" O.S	4	520952"	
	Scraper ring, .020" O.S	4	520953*	
	Scraper ring, .030" O.S	4	520954*	
	Scraper ring, .040" O.S	4	520955*	
10	Gudgeon pin	4	502029*	
11	Circlip for gudgeon pin	8	266945	
				·


CYLINDER HEAD, DIESEL ENGINE, 21 LITRE, Series IIA



CYLINDER HEAD, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA

DI ATE	·		LINGINE, 24 LITTLE, Series IIA
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	
1	CYLINDER HEAD ASSEMBLY	1	523208*
2	Valve guide, inlet and sealing ring	4	272206
3	Sealing ring for inlet valve guide	4	247186 Not included in cylinder head assembly
4	Valve guide, exhaust and sealing ring	4	275552
5	Sealing ring for exhaust valve guide	4	233419 Not included in cylinder head assembly
6	Packing washer for valve guides	20	230062
7	Insert for exhaust valve seat	4	512828*
8	Hot plug in cylinder head	4	524865 *
9	Peg for hot plug	4	271881
10	Push rod tube	8	514224
11	"O" ring for push rod tube, large	8	515573 *
- 12	"O" ring for push rod tube, small	8	515572*
13	Stud for injector, thread length 7	5	247883
14	Stud for injector, thread length $2\frac{1}{2}''$	· 3	521600 Not included in cylinder head assembly
15	Stud, short \ For	5	247144
16	Stud, long manifold	4	247143
17	Core plug, 🖁 dia	4	250830
18	Core plug, 1" dia	7	09191
19	Core plug, 13" dia	1	230250
20	Shroud for injector bore	4	524680*
21	Cylinder head gasket	1	523143*
22	Special set bolt, short	2	247683
23	Special set bolt, medium Fixing	9	247051
24	Special set bolt, long >cylinder head	- 5	247723
25	Stud ($\frac{1}{2}$ " U.N.F.) to cylinder bloc		518466*
26	Nut (½" U.N.F.)	2	254804
27	ROCKER COVER, TOP, ASSEMBLY		518719*
28	Tappet clearance plate	1	247634
29	Drive screw fixing plate	4	73350
30	Joint washer for top rocker cover	1	247606
31	Sealing washer \ Fixing top	3	232038
32	Special nut frocker cover	3	247121
33	Lifting bracket for engine, front	1	525131*
34	Lifting bracket for engine, rear	1	247715
35	Spring washers Fixing brace	ckets 4	3075
36	Set bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ long) \int to cylinder		255026
37	Breather filter for engine	1	514315*
38	Sealing ring for filter	1	268887
39	Special set screw fixing breather filter	1	515291
40	Sealing washer for set screw	1	232037
41	Joint washer \ For heater valve hole	1	243959
42	Plug (\frac{3}{8}" B.S.F.) \int in cylinder head	1	250978
43	Heater plug	4	510078*
44	Heater plug lead, No. 1 to earth	1	247953
45	Heater plug lead, No. 2 to No. 3	1	247952
46	Heater plug lead, No. 1 to 2 and 3 to 4	2	247951
47	Heater plug lead, No. 4 to resistor	1	-529972*
48	Shakeproof washer, large \ Fixing leads to	4	77626
49	Shakeproof washer, small heater plug	4	71082
50	Bolt (\frac{8}{8}" U.N.F. x \frac{8}{8}" long) Fixing heater of	-	253905
51	Fan disc washer Sead to cylinder		512305
			- · ·•


CYLINDER HEAD, DIESEL ENGINE, 21 LITRE, Series IIA



CYLINDER HEAD, DIESEL ENGINE, 21/4 LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
52	Engine oil filter AC 1531477	1	247530	
53	Element for filter AC FF 50	1	248863	
54	Gasket for filter AC 1530250	. 1	272539	
55	Rubber washer for centre bolt, AC 15	31098 1	269889	
56	Joint washer for filter	1	272839	
57	Set bolt $(\frac{7}{16}$ " U.N.F. x $1\frac{1}{4}$ " long) \int Fixi		255068	
58	Spring washer \(\int \cong \text{cylin} \)	nder block 2	3077	
59	Oil pipe complete to cylinder head	1	275679	
60	Banjo bolt fixing oil pipe	2	500457	
61	Joint washer for banjo bolts	4	231575	
62	Plug for thermometer hole in cylinder h	ead I	278164	
63	Joint washer for plug	1	243972	
64	Oil pressure switch, AC 7954238	1	519864*	
65	Joint washer	1	232039	


CAMSHAFT AND TENSIONER MECHANISM, DIESEL ENGINE, 21/4 LITRE, Series IIA



CAMSHAFT AND TENSIONER MECHANISM, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION C	ty.	Part No.	REMARKS
1	Camshaft	1	274711	
2	Bearing complete for camshaft, front	1	519054	
3	Bearing complete for camshaft, centre and rear	3	519055	
4	Rear end cover for camshaft	1	247069	
5	Joint washer for cover	1	247070	
6	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{7}{8}$ " long) fixing cover to block	3	255008	
- 7	Thrust plate for camshaft	1	2 7523 3	
8	Locker Fixing thrust plate	4	299 5	
9	Set bolt $(\frac{1}{4}"$ U.N.F. $x \frac{3}{4}"$ long) \int to cylinder block	4	255207	
10	Chainwheel for camshaft	1	276133	•
11	Key locating camshaft chainwheel	1	230313	
12	Retaining washer Fixing	I	09093	
13	Locker > chainwheel to	1	09210	
14	Set bolt ($\frac{3}{8}$ " U.N.F. x $\frac{7}{8}$ " long) \int camshaft	1	255246	
15	Camshaft chain (3" pitch x 78 links)	1	09156	
16	Ratchet for timing chain adjuster	1	247540	
17	Special bolt fixing ratchet and piston to block	1	247199	
18	Spring for chain adjuster ratchet	1	267451	
19	Piston for timing chain adjuster	1	247912	
20	Set bolt $(\frac{5}{16}$ U.N.F. x $\frac{11}{4}$ long) Fixing	1	256220	
21	Stud (5 U.N.F.) piston to	1	247144	
22	Spring washer cylinder	2	3075	
23	Nut (¾" U.N.F.) J block	1	254811	
24	Cylinder for timing chain adjuster	1	277388	
25	Steel ball $(\frac{7}{82}")$ for non-return valve	1	3739	
26	Spring for chain tensioner	1	233326	•
27	Retainer for steel ball	1	233328	
28	Idler wheel for timing chain	1	236067	•
29	Vibration damper for timing chain	1	275234	
30	Set bolt ($\frac{1}{4}$ " U.N.F. $x \frac{1}{2}$ " long) $\int Fixing damper$	2	255204	
31	Locking plate \int to cylinder block	2	278769	•


VALVE GEAR AND ROCKER SHAFTS, DIESEL ENGINE, 21 LITRE, Series IIA



VALVE GEAR AND ROCKER SHAFTS, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
1	Inlet valve	••••	4	527240*	
2	Exhaust valve		4	525975*	
3	Valve spring, inner and outer	****	8	276609	
4	Valve spring cup	****	8	268292	
5	Split cone for valve, halves		16	268293	
6	Valve rocker, exhaust L.H	••••	2	274772	
7	Valve rocker, exhaust R.H		2	274773	
8	Bush for exhaust valve rocker		4	247738	
9	Valve rocker, inlet L.H		2	274774	
10	Valve rocker, inlet R.H		2	274775	
11	Bush for inlet valve rocker		4	247737	
12	Tappet adjusting screw		8	506814	
13	Locknut for tappet adjusting screw		8	254861	
14	Tappet push rod	•	8	275573	•
15	Tappet, tappet guide, roller and set bolt	assembly	8	507829	
16	Tappet		8	507026	
17	Copper washer for tappet guide set bolt		8	232038	
18	Valve rocker shaft		1	524841*	
19	Spring for rocker shaft		4	247040	·
20	Washer for rocker shaft		8	247153	
21	Rocker bracket		5	523181*	
2 2	Locating dowel for rocker bracket		4	277956	
23	Stud for rocker bracket		3	247607	
24	Set bolt (5 U.N.F. x) Fixing			•	
	2" long) \rocker bracket	: to	5	256226	
25	Spring washer cylinder head		5	3075	
26	Locating screw \ For rocker shaft		2	525390*	
27	Spring washer \int at Lracket		2	3075	•


OIL PUMP, DIESEL ENGINE, 21 LITRE, Series IIA



OIL PUMP, DIESEL ENGINE, 21 LITRE, Series IIA


PLATE REF.	1 2 3 4 DESCRIP	TION	Qty.	Part No.	REMARKS
	OIL PUMP ASSEMBLY	7	1	513640	
1	Oil pump body	****	1	513641	
2	Spindle for idler gear		1	502209	
3	Oil pump gear, driver		1	240555	
4	Oil pump gear, idler		1	278109	
5	Bush for idler gear		1	21 499 5	
6	Steel ball		1	3748	
7	Plunger	•	1	273711	
8	Spring For oil pres	sure release valve	1	265623	•
9	Washer		1	2 4 3970	
10	Plug		1	265624	· .
11	Oil pump cover		1	513639	
12	Set bolt (5." U.N.F. x 78	″long) े Fixing c	over 4	255227	•
13	Spring washer	∫ to body	4	3075	
14	Oil filter for pump		1	247664	
15	Sealing ring \(\) Fixing o	oil filter	1	2 444 88	·
16	Lock washer ∫ to oil pu		1	244487	
17	Drive shaft for oil pump		1	511680	`
18	VERTICAL DRIVE SHA	AFT ASSEMBLY	′ 1	503266	
19	Circlip for drive shaft		1	247742	·
20	Bush for drive shaft gear	••••	1	247653	
21	Locating screw for drive sl	haft bush	1	524769	
22	Set bolt $(\frac{5}{16}"$ U.N.F. x 1" k		-	255228	
23	Lock washer	∫ to cylinder b	olock 2	247665	

FRONT COVER, SIDE COVERS AND SUMP, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA




FRONT COVER, SIDE COVERS AND SUMP, DIESEL ENGINE, 21 LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	FRONT COVER ASSEMBLY	1	514451*	
2	Dowel locating front cover	2	6395	
3	Oil seal for front cover	1	213744	•
4	Stud fixing water pump	5	252500	
5	Mud excluder	1	2 4776 6	•
6	Drive screw fixing excluder	8	78001	
7	Joint washer for front cover	1	247564	
8	Joint washer at water inlet	1	247537	
9	Set bolt (5 U.N.F. x 3" long)	7	256030	
10	Set bolt $(\frac{5}{16}"$ U.N.F. x 2" long) Fig.	king front 3	256026	
11		ver and 2	256031	
12	Set bolt $(\frac{5}{16}"$ U.N.F. x $3\frac{3}{4}"$ long) wa	ter pump 1	256233	
13	Spring washer to	cylinder 14	3075	
14	Nut (16" U.N.F.)	ock 2	254801	
15	Side cover and oil filler pipe for engine	e, front 1	510730	
16	Baffle plate for side cover, front	1	514423*	
17	•	2	247555	•
18	SIDE COVER ASSEMBLY, REAR	1	247563	•
19	Stud for fuel pump	2	500792	
20	Plain washer	2	2220	. "
21	Nut $(\frac{5}{16}$ U.N.F.) \gt Fixing stud	2	254911	
22	Split pin	2	2422	
23	•	1	247554	
24		xing 6	3075	
25	1=7	ır side 5	255029	
		ver plate l	256020	
26		ing front 7	3075	•
27	Set bolt $\binom{5}{16}$ U.N.F. $x \stackrel{3}{\cancel{4}}$ long) \int side	cover plate 7	255026	
28	•	1	247522	•
29		1	3088	
30		1	230507	
31	•	1	247088	
32	Set bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{7}{8}"$ long) \int Fixing		25522 7	•
33		der block 22	3075	
34	Oil level rod	1	274154	•
35	Sealing ring for rod	1 .	210517	
36	Tube for oil level rod	1	504032	
37	Double-ended union	1	236060	•
38	Washer Fixing tube to		243958	
39	Olive cylinder block	1	236408	
40	Union nut	1	236407	•
41	Oil filler cap and breather filter, AC 72	222073 1	236406	



Dr. tonor			SEL ENGINE, 24 LITRE, Series IIA
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	
1	Fuel pump, mechanical	1	501030
2	Filter for bowl, AC 854009	1	506796
3	Washer for bowl, AC 5593321	1	241225
4	Sediment bowl, AC 1523620	1	236891
5 1	Retainer for bowl, AC 5592050	1	268797
6	Joint washer, fuel pump to cylinder block	1	275565
7	Self-locking nut fixing fuel pump	2	252161
8	Joint washer \ For mechanical pump	2	243967 Part of
9	Union inlet and outlet	2	247929 >engine
10	Distributor pump, CAV DPA 3242 L1586	1	516092* assembly
11	Accelerator control lever \ For distributor	1	509009
12	Stop lever pump	. 1	509011
13	Joint washer for injection pipe, distributor pu	mp	
	end	6	247802
14	Joint washer for distributor pump	1	247212
15	Plain washer Fixing distributor	3	2920
16	Spring washer >pump to	3	3075
17	Nut (5" U.N.F.) cylinder block	3	254801
••	Sealing plugs for injection system	_	set 279702 For sealing unions in distributor pump
18	Fuel filter CAV type FS	1	517682
10	Element for fuel filter, CAV 7112-296	1	517711
	Seal for element, small, CAV 5855-30G	1	522937
	Seal for element, large, CAV 5339-2568	2	522938
	Special centre bolt for filter, CAV 7111-291	2	522939
	Washer for centre bolt, CAV 5936-188A	I	522940
19	Plug for filter, CAV Z 7111/312	1	517689
20	Joint washer for plug, CAV Y 5936/58T	1	517706
21	Bolt $(\frac{56}{16}"$ U.N.F. x $1\frac{1}{4}"$ long)	2	256220
22	Distance plate Fixing	. 2	517683
23	Spring washer Spring washer	2	3075
24	Plain washer to dash	2	22 49
25	Rivnut $\left(\frac{5}{16}''$ U.N.F.)	2	501224
26	N 1 (C)	. 2	
27	Joint washer for non-return valve	I	517707) Not required when additional 517706 fuel filter is fitted
28	1 1 4 1 1.	I	515980) ruei niter is nitted
20 29	Banjo bolt \(\) Fixing leak-off pipe	I	273521 > Part of engine assembly
30	Washer to injector	4	273069
31	Fuel pipe, spill return to tank	8	509909*
32		1	
	· · · · · · · · · · · · · · · · · · ·	1	505805 517074
33 34	Joint washer Spipe to filter	2	517976 521584)
	Bracket for leak-off pipe	l	521584) 354941
35 36	Locknut ($\frac{5}{16}$ " U.N.F.) fixing bracket to injector s		254861 250061 Port of consistency will
36 27	Bolt (2 B.A. x ¾ long) Fixing spill return p	ipe !	250961 Part of engine assembly
37 20	Spring washer to bracket on	1	3073
38 30	Nut (2 B.A.) j injector stud	1	2247
39	Clip for spill return pipe		525168
	Fuel pipe, mechanical pump to filter	1	517687
	Nut Fixing pipe	Į.	517690
	Olive \int to filter		270104 Not required when additional fuel filter is fitted
	Nut Fixing pipe to]	270115
	Olive of mechanical pump	I	270105)



DE ATTE	TORE AGEOTION BIBIEN,			GIVE, 24 EXTRE, Selies IIA
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
40	Fuel pipe, filter to distributor pump	1	517685	
41	Nut Fixing pipe	1	517690	
42	Olive S to filter	1	270104	
43	Banjo bolt Fixing pipe to	1	275266	
44	Joint washer \int \distributor \text{pump}	2	275265	
45	Clip, fixing pipe to distributor pump	1	8885	
46	Fuel pipe, distributor pump return to filter	1	517686	•
47	Nut Fixing pipe to	1	517690	
48	Olive Sfilter	1	270104	
49	Clip, fixing fuel pipe to dash	1	517684	
50	Drive screw, fixing clip	2	78006	
51	Double pipe clip (fixing distributor pump feed			
	return pipes together)	2	243395	
52	Bolt (2 B.A. x ½" long) Fixing pipes	1	234603	
53	Spring washer and	1	3073	
54	Nut (2 B.A.) J clips	1	2247	
55	Injector complete, CAV 5345902	4	515552*)
56	Nozzle for injector	4	247726	
57	Joint washer for injector, copper	4	247179	
58	Joint washer for injector, steel	4	272474]
59	Clamping strip for injector	4	247213	
60	Spring washer Fixing injector	8	3075	}
61	Nut $(\frac{5}{16}"$ U.N.F.) \int to cylinder head	8	254801	
	Injector pipe to No. 1 cylinder	1	513926*	
	Injector pipe to No. 3 cylinder	1	513928*	1
	Injector pipe to No. 4 cylinder]	513929*	•
62	Injector pipe to No. 2 cylinder	1	513927*	
63	Damper for injector pipe	4	277838	
64	Shroud for damper	2	277839	Part of engine assembly
65	Bracket for damper shroud	1	277816	•
66	Support strap for shroud	!	278002	
67	Steady strap for shroud	1	278021	
68	Backplate for shroud	1	277815	
69	Locknut (5" U.N.F.) Fixing straps to	4	254861	
70	Plain washer Sinjector studs	4	2220	
71	Bolt, front (5 U.N.F. x	_		
=4	l ¹ / ₄ " long) Fixing shrouds an	ıd 1	256020	
7 2	Bolt, rear (5 U.N.F. x dampers to	_		
	1½" long) backplate, strap as		256222	
73	Spring washer support bracket	2	3075	
74	Nut (5" U.N.F.)	2	254811	J
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) Fixing bracket	1	255204	
	Plain washer for damper shro	ud 1	39 4 6	•
	Spring washer to oil	1	3074	
	Nut (¼" U.N.F.) filler pipe	1	254810	
	· ·			






PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
	ADDITIONAL FUEL FILTER	R. COMPLETE			
	ASSEMBLY	****	1	522756)
75	Fuel filter, CAV type FS		1	517682	
76	Element for fuel filter, CAV	7111-296	1	517711	
77	Seal for element, small, CAV	7 5855-30G	1	522937	
78	Seal for element, large, CAV		2	522938	
79	Special centre bolt for filter,	CAV 7111-291	1	522939	
80	Washer for centre bolt, CAV	7 5936-188A	1	522940	
81	Plug for fuel filter	****	2	517689	
82	Joint washer for plug		2	517706	
83	Plug for fuel filter, top, leak-off,	, CAV Z/7111/311	1	517855	
84	Joint washer for leak-off plug		1	517976	·
85	Transfer pipe, extra filter to ba	sic filter	1	517692	Standard on Export models
86	Nut \ Fixing pipe		2	517690	Optional equipment on Home models
87	Olive \int to filter		2	270104	
88	Bolt $(\frac{5}{16}'' \text{ U.N.F. x } 1\frac{1}{4}'' \text{ long})$)	2	256220	,
89	Distance plate		1	51 76 83	
90	Spring washer	Fixing filter	2	3075	
91	Plain washer	to dash	2	2249	
92	Rivnut $\left(\frac{5}{16}^{"} \text{U.N.F.}\right)$)	2	501224	
93	Fuel pipe, mechanical pump to	twin filters	1	517860*	
94	Nut \(\int\)Fixing pipe		1	517690	
95	Olive ∫ to filter		1	27 0104	
96	Nut \(\) Fixing pipe to		1	270115	
97	Olive \int mechanical pump		1	270105	J
	Repair kit for mechanical fuel pu		İ	272069	
	Overhaul kit for mechanical fue	l pump,			
	AC 7950463		1	524684	



WATER PUMP AND THERMOSTAT, DIESEL ENGINE, 21 LITRE, Series IIA

		,		
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	WATER PUMP ASSEMBLY	1	530477*	
1	Water pump casing	1	530478*	
2	Pump spindle and bearing	1	523354	
3	Hub for fan	1	515729	
4	. Carbon ring and seal unit	1	244207	
5	Impeller for pump	1	247916	
6	Spring washer \(\) Locating	1	3074	
7	Special set bolt ∫ bearing casing	1	247078	
8	Joint washer for water pump	1	514450 *	
9.	Spring washer \(\) Fixing water pump	5	3074	
10	Nut $(\frac{1}{4}$ " U.N.F.) \int to cylinder block	5	254800	
11	Joint washer \(\) For heater return in	1	243959	
12	Plug (3" B.S.P.) fthermostat by-pass pipe	1	250978	
13	Thermostat	1	504736*	
14	Thermostat housing	1	516059*	
15	Joint washer for thermostat housing, upper	1	511957*	
16	Water outlet pipe, thermostat to radiator	1	511956	
17	Joint washer for thermostat housing, lower	1	247874	
18	Set bolt, $\frac{1}{4}$ " U.N.F.) Fixing thermostat housing	ng		
	$\mathbf{x} \ 2\frac{1}{2}'' \ long) $ and outlet pipe to	3	256209	
19	Spring washer cylinder head	3	3074	
20	Thermostat by-pass pipe	1	530476 *	
21	Joint washer for by-pass pipe	1	511958	
22	Set bolt (16" U.N.F.) Fixing			
	x 1" long) by-pass pipe to	2	255228	
23	Spring washer	2	3075	
24	Hose for by-pass pipe	1	273789	
25	Hose clip for by-pass pipe	2	50318	
26	Fan pulley	1	526151*	•
27	Fan blade	1	515090*	
28	Spring washer \(\) Fixing fan ble	ade 4	3074	
29	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long) \int and pulley to	hub 4	255007	
30	Fan and dynamo belt	1	524200*	
	Water pump overhaul kit	1	530590*	


MANIFOLDS, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA



MANIFOLDS, DIESEL ENGINE, 21/4 LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	Inlet manifold	1	518281*	
2	Plug for inlet manifold	1	10713	
3	Joint washer for plug	1	243960	≥ 500°
4	EXHAUST MANIFOLD ASSEMBLY	1	247651	<u> </u>
5	Stud for exhaust pipe	4	252621	•
6	Joint washer for inlet and exhaust manifold	1	247101	
7	Clamp for manifold	4	500961	
8	Plain washer Fixing inlet	5	2550	
9	Spring washer \rightarrow and exhaust	9	3075	
10	Nut $\binom{5}{16}$ U.N.F.) manifold	9	254801	


STARTER MOTOR AND SOLENOID, DIESEL ENGINE, 21 LITRE, Series IIA



STARTER MOTOR AND SOLENOID, DIESEL ENGINE, 21 LITRE, Series IIA

PLATE		CDIDTION			Dittill, i	DEMADES	
PLATE REF.		CRIPTION	Qty.			REMARKS	<u> </u>
	STARTER MOTOR			529971*			
2	Bracket, commutat			532568*			
3		or end LU 255491	!	242958			
4		ushes LU 54251042	2 1	532569*			
5	Armature LU 5425		1	532570*			
6	Thrust washer, cor			279007			
7	Bracket for starter,		52532 1	532571*			
8	Bush for bracket		1	532572*			
9	Bracket for brake I			532573*			
10		racket LU 5425249	94 1	532574*			
11	Field coil for starte		1	279010			
12	Brushes for starter			270225			
13	Drive assembly for	starter motor LU	292124 1	279011			
14	Rivet for pinion	retaining ring LU	291887 1	526528			
15	Return spring fo	r starter pinion LU		532575*			
16	Bush, pinion end		2	279012			
17	Clutch adjusting	shim (0.006") LU 2	291374 As requi	red 270239		·	
	Clutch adjusting	shim (0.005") LU 2	.91378 As requi	red 270240			
	Clutch adjusting	shim (0.004") LU 2	.91379 As regui:	red 270241			
18	Clutch plates, se	t, LU 291540	1	270238			•
19	Circlip retaining	clutch assembly L	U 291560 1	270235	•		
20	Lock ring retain	ng clutch plates Ll	U 291862 1	279013			
21	Brake shoe comple	te with springs LU	272701 1	279014			
22	Driving washer for	brake shoe LU 272	2340 1	279015			
23	Lock ring retaining	brake LU 272337	1	279016			
25	Cover band for sta	rter LU 272396	1	279018			
26	Bolt for starter mo	tor LU 54250580	2	532576*	•		
27	Lock washer for bo	olt LU 272773	2	532577*			
28	Rubber grommet in	drive end bracket	LU 272552 1	279021			
29	Solenoid for starter	motor LU 76490	1	532578*			
30	Contact plate o	omplete for starte:	r solenoid				
	LU 5433016	8	1	519004			
31	Base complete fo	r starter solenoid				•	
	LU 5464066	5	1	532579*			
32	Gasket for star	ter solenoid base L	U 765842 1	519006			
33	Terminal nut f	or starter solenoid L	.U156456 4	532580*			
34		her for starter sole		•			
	185062		4	519008			•
35	Terminal scre	w for starter sole	enoid LU				
	12 1610		1	519009			
36	Terminal conne	ctor for starter m	otor, LU				
	27 2555		1	519010			
37	Plunger spring	for starter soler	noid LU				
	7 65866		•	519011			
	Sundry parts ki	t, LU 271731	1	270251			
38	Bolt (7 U.N.C. x 1;		1	253068			
	Set bolt (7 U.N.F.	'	g I	256064			
39	Spring washer	1	r motor 3	3077			
40	Nut (7/ U.N.F.)	j	. 2	254803			
	,	_					


DYNAMO AND FIXINGS, DIESEL ENGINE, 21 LITRE, Series IIA



DYNAMO AND FIXINGS, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION Qt	y. Part No.	REMARKS
1	DYNAMO COMPLETE, C40/1 LU 54021019	1 514893	
2	Bracket, commutator end LU 54211125	1 514195	
3	Armature for dynamo LU 277987	1 514194	
4	Brushes for dynamo, set LU 227541	1 514193	
5	Spring set for brushes LU 227542	1 514192	
6	Field coil for dynamo LU 229362	1 514191	
7	Ball bearing, front LU 189307	1 242672	
8	Bush, commutator end LU 227818	1 271614	
9	Bracket, drive end LU 54211095	1 514190	
10	Oiler for dynamo LU 54211097	1 514189	
11	-	2 242675	
12	Terminal LU 54211608	532566*	•
	Sundry parts, set LU 54211894	1 532567*	
13	Pulley for dynamo	1 522913	
14	Fan for dynamo	1 529303	
15	Woodruff key	1 . 1664	
16	Lock washer Fixing pulley to dynamo	1 217781	
17	Special nut	1 240271	
18	Support bracket for dynamo	1 277999	
19	Steady bracket for dynamo support bracket	1 278000	
20	Locking plate for steady bracket	1 501198	
21		1 256421	
	>to support and		
22		1 252161	,
23		2 3075	
	> bracket to	_	
24	1	2 255025	
25	Special stud fixing dynamo	526225*	•
26	Shim washer Fixing dynamo As re	equired 4148	
	≻to special stud	•	
27	Self-locking nut $(\frac{5}{16}" \text{ U.N.F.})$ at rear	1 252161	•
28	Nut (5 U.N.F.) Fixing dynamo to	1 254801	
29	Self-locking nut (5 "U.N.F.) special stud at front	1 252161	
30	Strap for dynamo, rear	1 524207*	
31	Bolt $(\frac{5}{16}"$ U.N.F. x $1\frac{3}{8}"$ long) \bigcap Fixing strap	1 256021	
32	Self-locking nut $(\frac{5}{16}"$ U.N.F.) to dynamo	1 252211	
33	Adjusting link for dynamo, rear	1 524210*	
34	Bolt $(\frac{5}{16}"$ U.N.F. $x \frac{7}{8}"$ long) Fixing adjusting	1 255027	
35	Plain washer Slink to dynamo	1 2266	
36	Self-locking nut $(\frac{5}{16}" \text{ U.N.F.})$ strap	1 252211	
37	Bolt (5 U.N.F. x 7 long) Fixing adjusting	1 255027	
	link to engine		
38	Self-locking nut $(\frac{5}{16}" \text{ U.N.F.})$ mounting foot	252211	
39	Adjusting link for dynamo, front	1 514472*	
40	Special set bolt Fixing front	1 233568	
41	Plain washer > adjusting link	1 2550	
42	Spring washer to dynamo	1 3075	
43	Set holt (5" IIN C x 3" long)	1 253026	
44	Spring weeher rixing adjusting	1 3075	
45	Distance washer link to	1 2266	
46	Nut $(\frac{5}{16}$ U.N.F.) front cover	1 254811	
	-		*


FLYWHEEL AND CLUTCH, DIESEL ENGINE, 21 LITRE, Series IIA



FLYWHEEL AND CLUTCH, DIESEL ENGINE, $2\frac{1}{4}$ LITRE, Series IIA

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	FLYWHEEL HOUSING ASSEMBLY	1 🌉	515086*	
2	Stud (3" U.N.F.) fixing flywheel housing	to	ĺ	
	bell housing	12	247145	
3	Stud (‡" U.N.F.) fixing inspection cover	2	247146	
4	Stud ($\frac{7}{16}$ " U.N.F.) for starter motor	1	277532	
5		1	246169	
6	Inspection cover plate	1	56140	
7	Joint washer for cover plate	2	50216	
8	\4	2	254800	
9	Bolt ($\frac{3}{8}$ " U.N.F. x $1\frac{3}{4}$ " long) \bigcap Fixing flywheel		256043	
10	Bolt $(\frac{3}{8}$ U.N.F. x $1\frac{1}{8}$ long) housing to	6	255048	
11	Spring washer J cylinder block	8	3076	
12	5 5]	500597	
13	Drain plug for housing]	3290	
14	Stowage bracket for drain plug]	276511	
15		1	516082*	
• .	Ring gear for flywheel]	510489	
16		6	247166	
17	Dowel locating clutch cover plate	2	231759	
18	Bush for primary pinion	!	08566	
19	Locker Fixing flywheel	4	3674	•
20	Special set bolt \(\int \text{to crankshaft} \)	8	247135	
21	CLUTCH ASSEMBLY BB45693/14	I	242130	
21	Cover plate for clutch BB 45481	[231888	
22	Pressure plate for clutch BB 42652	3	231880	
23 24	Release lever for clutch BB 48234 Strut for release lever BB 42606		242993	
			231884	
25 26	Eyebolt and nut for release lever BB 48508 Pin for release lever BB 42604	3	242996 231885	•
26 27				
21 28	Anti-rattle spring for release lever BB 47688 Clutch spring (yellow and light green) BB 447		231883 243593	
26 29		0U Y 1	243393 511682	
47	Clutch plate complete BB 47626/122 Lining package for clutch plate BB KL75012	I	517026	
30	Self-locking nut ($\frac{5}{16}$ " U.N.F.) fixing cover plate		252211	
20	Sen-locking nut (16 O.I.v.r.) inxing cover plate	e 6	404411	

GEARBOX, MAIN CASING



GEARBOX, MAIN CASING

		GLANDON,	IATLETIA	CADING
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	GEARBOX COMPLETE ASSE	MBLY 1	248361	2 litre Petrol model
	GEARBOX COMPLETE ASSE	MBLY 1	277914	88 Diesel and 21 litre Petrol models
	GEARBOX COMPLETE ASSE		275772	109 Diesel model
1	GEARBOX CASING ASSEMBI	LY 1	269960	
	Stud for top cover	2	3319	
2	Stud for top cover and gear cha	nge plate 2	3236	
	Stud, long \(\) For transfer	2	55778	
3	Stud, short \(\int \) casing	3	3238	
4	Stud for bell housing	1	231341	
5	Dowel locating top cover	2	07289	
6	Dowel locating transfer casing	2	55636	
7	Top cover for gearbox	1	06417	Not supplied separately
8	Spring washer \ Fixing	4	3076	
9	Nut $(\frac{3}{8}$ B.S.F.) \int top cover	4	2827	
10	Inspection cover plate for selectors	ı 1	05843	
11	Set screw ($\frac{1}{4}$ Whit. x $\frac{7}{16}$ long) fix	ing cover plate 2	52246	
12	Oil filler cap	1	500645	
13	Joint washer for cap	1	506706	
14	Plug for retaining spring	1	59720	
15	Retaining spring for cap	1	06419	
16	Plain washer \(\) Fix	ting spring	2213	
17	Set bolt ($\frac{1}{4}$ " Whit. x $\frac{7}{16}$ " long) \int to	plug l	215769	
18	Oil level dipstick Oil level plug, § B.S.P.	1	239192	\ Alternatives
	Oil level plug, 3" B.S.P.	1	3291	Check before ordering
19	Drain plug for gearbox	1	241110	
20	Washer for plug	1	515599	
21	BELL HOUSING ASSEMBLY		248719	2 litre Petrol model
	BELL HOUSING ASSEMBLY	1	277961	21 litre Petrol and Diesel models
22	Stud for withdrawal race housing	ng 3	269413	
24	Joint washer, bell housing to gear	box 1	07118	
25	Fitting bolt \(\)\(\)\(\) Fixing ge	arbox casing 3	248720	
26	Self-locking nut $(\frac{1}{2}'')$ \int to bell ho	using 4	251324	,
27	Top cover for bell housing		06846	2 litre Petrol models
28	Rubber seal for top cover	1	232606	2 little Fetroi models
	Top cover for bell housing	1	512237	$\int_{1}^{\infty} 2\frac{1}{4}$ litre Petrol
	Rubber seal for top cover	1	512238	sand Diesel models
29	Centre for dust cover	1	232647	
30	Grommet for bell housing hole	1	232604	
31	Grommet for bell housing shaft	1	236281	
	Plain washer	9	2210	
	Plain washer	1	2550	
	Nut (3" B.S.F.) Fixing gearbo	ox 12	2827	>2 litre Petrol models
	Nut (5 B.S.F.) to engine	1	2828	J ·
	Nut (§" U.N.F.)	12	254802	Except 2 litre Petrol model
	-			




PLATE	1 2 3 4 DESCRIPTION				Part No.	DEMARKS
REF.		MDLV	Qi	ty.		REMARKS
1	TRANSFER BOX CASING ASSE	MBLY	••••		507315	
2	Stud for intermediate shaft			!	217778	
3	Stud for speedometer housing, shor		••••	5	3650	
	Stud for speedometer housing, long			1	237251	•
4	Stud for mainshaft housing			6	3650	
5	Stud for top cover plate			4	217978	
	Stud, long For transfer	• • • •		1	232497	,
6	Stud, short ∫ shaft housing			6	3200	
7	Stud for engine mounting			8	217976	
8		••••	Ì	0	212104	
9	Dowel locating speedometer housing	g		4	55636	- -
10	Bush for shaft guide	••••	••••	1	217448	
11	HOUSING ASSEMBLY FOR SPE	EDO-			-	
				1	522318*	·
12	Insert for pinion			1	232846	
13	Stud for transmission brake			4	217973	
14	Mudshield, inner \(\) For		-	1	522319*	¢ .
	Mudshield, outer \int \text{housing}	_		1	522297*	τ
	Shim .003"		As rec	juired	235455	•
	Shim .005" >For speedometer		As rec	juired	217622	
15	Shim .010" pinion housing		As req	uired	217623	
	Shim .015" J		As req	uired	217620	
16	Spring washer \ Fixing housing			6	3076	
17	Nut (3" B.S.F.) to transfer box		1	6	2827	
	HOUSING COMPLETE ASSEMBI	LY. RE.	AR			
	MAINSHAFT BEARING			1	230696)	
18	HOUSING ASSEMBLY, REAL	R MAI	N-			, -
	CHAPT DEADING			1	217844	
19	D., I. f., I.					Not required when rear power take-off or centre
20	Descining place in an				217523	power take-off is fitted
21	Paradia at face and distribute				217478	power take on is need
. 22	Datamina plata autor				217523	
23	Circlin Criss Larrison				217525	
24	Table 1 of 1				217680	•
25	Spring washer \ Fixing housing to	••••		5	3076	
26	Nut (§" B.S.F.) transfer box		ì	_	2827	
27	Cover plate for P.T.O. selector			•		Not required when rear power take-off or centre
	Cover place for 1.1.0. selector			•	217770	power take-off is fitted
28	Joint washer for cover plate		1		230140	power take-off is fitted
29	Spring washer Fixing cover plate			י 4	3075	
30	Nut (5 B.S.F.) to transfer box		-	1	2828	
31			. 1	? I	230021	
32						•
33	d • • • • • • • • • • • • • • • • • • •		i	1	219995	
34		g	-)	3074	
35			4		215594	
36	Cover plate, bottom, for transfer box.		1		218259	
37	_	•••	I		218270	
38	Spring washer Fixing		10		3074	
39	Nut (1" B.S.F. Scover		10		2823	
<i>3</i> 9 40		•••	2		241110	
40	_ -	•••	2	2	515599	A1.
41	Oil level plug, ½" gas]			Alternatives.
	Oil level plug, ‡" B.S.P	•••	l		3290 J	Check before ordering





PLATE REF.	1 2 3 4 DESCRIPTI	ON	Qty.	Part No.	REMARKS
	Rear mounting foot complete	L.H	1	263456)	
	Rear mounting foot complete	R.H	1	234643	
42	Rear mounting foot L.H.		1	263455	
43	Rear mounting foot R.H.	***	1	234641	≻ 2 litre petrol models
44	Adjuster for mounting foot		2	234612	•
45	Plain washer	₹ For	4	2217	
46	Self-locking nut (5 " B.S.F	.) adjuster	4	251321	•
	Engine rear support bracket F	λ.Н	1	272184 \	Diesel and 2½ litre
	Engine rear support bracket I	H	1		Petrol models
47	Locking plate \(\) Fixing feet	or support	4	241839	
48	Nut $\binom{7}{16}$	transfer box	8	2836	
49	Joint washer, transfer box to	gearbox	1	267795	•
50	Bolt (3" B.S.F. x 13" long)	Ì	• 1	250544	
51	Spring washer	Fixing transfer	3	3076	
52	Nut (3" B.S.F.)	box to gearbox	3	2827	
	Self-locking nut (3" B.S.F.)	j	3	50526	
53	Bolt (5 B.S.F. x 129 long)	Fixing	2	215170	,
54	Spring washer	transfer box to	2	3075	
55	Nut (5 " B.S.F.)	gearbox top co	ver 2	2828	•


GEARBOX SHAFTS AND GEARS



GEARBOX, SHAFTS AND GEARS

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.		
1	Primary pinion and constant gear	1	518473	
2	Shield for primary pinion	1	01017	
3	Ball bearing for primary pinion	1	55714	
4	Lockwasher \ Fixing bearing	1	08250	
5	Locknut to pinion	i	213416	
6	Retaining plate Fixing	i	213666	
7	Extension stud > bearing to	4	214090	
8	Self-locking nut (5 B.S.F.) bell housing	4	251321	
9	Layshaft	i	09917 —	
10	Mainshaft	. 1	264250	
11	Peg for 2nd gear thrust washer	1	06405 —	
12	Peg for mainshaft distance sleeve	1	09561	
	Thrust washer .125"	1	267572)	
13	Thrust washer .128" >For	1	267573 ≻As	
	Thrust washer .130" 2nd speed gear	1	267574 required -	
	Thrust washer .135"	1	267575	
14	1st speed layshaft gear	i	217388	
15	lst speed mainshaft gear	1	501617	
16	2nd speed layshaft and mainshaft gear	1	245766	
17	Split ring for 2nd speed layshaft gear	1	239272 -	
18	3rd speed layshaft and mainshaft gear	1	245767	
19	Distance sleeve for mainshaft	1	239706 -	
"	Thrust washer .125"	1	08188)	
20	Thrust washer .128" > For 3rd speed	1	50702 \As	
20	Thrust washer .130" mainshaft gear	1	50703 required	
	Thrust washer .135"	i	231737	
21	Spring ring fixing 2nd and 3rd mainshaft gear	s I	06402	
22	Sleeve for layshaft		263878	
23	Bearing for layshaft, front	i	09962 —	
24	Plain washer	1	08185	
25	Slotted nut Fixing bearing to layshaft	1	09932	
26	Split pin	1	2980	
27	BEARING PLATE ASSEMBLY FOR		,	
	LAYSHAFT	1	214792	
28	Stud for bearing cap	3	213417	•
	Distance piece 312"	1	241649	
29	Distance piece .332" > For layshaft	1	241650 As required	
	Distance piece .352"	1	241651	
30	Retaining plate for layshaft front bearing	1	213419	
31	Lock washer \(\) Fixing cap and bearing	1	09931	
32	Nut (5" B.S.F.) to bell housing	3	2828	
33	Bearing for layshaft, rear	1	55715 🕶	
34	Synchronising clutch	1	239160 —	
35	Detent spring for clutch	3	06395	
火36	Roller bearing for mainshaft	l-	06397	
37	Ball bearing for mainshaft	1	1645 🗨	-
38	Housing for mainshaft bearing, rear	1	217811	
39	Peg, housing to casing	1	09927 -	
40	Circlip, bearing to housing	1	09960 _.	
41	Circlip, housing to casing	1 .	09961 —	
	·			


GEARBOX, SHAFTS AND GEARS



GEARBOX, SHAFTS AND GEARS

		OL# IXX	<i></i>	N/4 44 NA	1,0 1111			
PLATE REF.	1 2 3 4	DESCRIPTION		Qty.	Part No.	•	REMARKS	
42	Oil seal for rea	r of mainshaft		1	236305 -			
43	Oil thrower for			1	232415	•		
44		rear of mainshaft		1	502482			
45	-	for transfer box		1	218244			
46	Lock washer)		1	217476-			
40	Shim washer	Fixing gear to mai	nehaft	i	501501-			
47	Special nut	Tixing gear to mar	mana	· i	217477			
48	Shaft for rever	J		i	06424			
49		se gear HEEL ASSEMBLY	••••	, i	217389	•*		
50	Bush for rev			1	56854			
51			****	l	219468			
52	Gear, intermed			2	219466			
53		for intermediate gear	••••	^	219469		·	
54		-			217 4 07 ed 234835		4	
		mediate gear						
55 57	Shaft for inter		••••	J	278025~			
56		r intermediate shaft	••••	,, I	267828	-		,
57 50	Retaining plate	_			217484			
58	Spring washer	Fixing plate		 	3076			•
59	Nut (3" B.S.F.				2827			
60	Low gear whee			, I	235438	•		
61	High gear whe		****	I	218243	_		
62	Output shaft,		••••		235985			
63		for high gear wheel		I	217488			
64		washer to shaft		,,,, I	217489			
65	_	tput shaft, front			217490			•
56	Circlip fixing l		••••	}	217526			
67	_	tput shaft, rear		I	217512			
68	Oil seal for ou	_	••••	1	236417			
69	-	vorm complete	••••	I	237247			
7 0		put shaft, rear drive		1	275238			
71	Mudshield for	_		1	236074	D. 1 100 D' 1	1.1	•
7 2		brake drum		6	217564	Petrol and 88 Diesel	models	
		r brake drum		6	275629	>109 Diesel model		
	Dowel for flan			2	55705 J			
73		e for brake drum bolts	•		217568	Dane: 1		CL 1.1.6
74	Fitting bolt for	r propeller shaft		4	217565		tive to U.N.F.	Check before
	Eissine helt for	propeller shaft		4	512701	ordering U.N.F. fixing, altern	ative to BSF	Check before
	riting boil to	propener snart		4	712701	ordering	alive to B.b.i .	Chicer before
7 5	Circlin rataini	ng bolts and flange		1	217546	ordering		
76	Plain washer	ig noirs and namige	••••	1	3300			
70 77		 ≻Fixing flange to outpo	at chafe	1	3259			
7 8	Split pin	Traing hange to outpo	at SHAIL	i	2428			
70 79	Speedometer p	oinion			237982			
80	Retaining plate			1	232565			
81		late to housing	••••	2	2529			•
82	Sleeve for pini	-	••••	1	268791			
83	Sealing ring fo		••••	1	267828			
84	Joint washer for			2	267782			
85	Oil seal for pin		••••	1	211502			
0,7	On scar for pir	nion	•…		211702			

GEARBOX, SELECTORS AND LEVERS




GEARBOX, SELECTORS AND LEVERS

PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y. Part No.	REMARKS
1	Selector fork, 3rd and 4th speed		1 06422	
2	Shaft for fork, 3rd and 4th speed		1 213636	
3	Selector fork, 1st and 2nd speed		06421	
4	SHAFT ASSEMBLY FOR FORK, 1st and 2n	d		
	SPEED	1	213637	
5	Interlocking pin	1	55697	·
6	Peg fixing interlocking pin		i 55775	
7	Selector fork, reverse		1 217391	
8	Shaft for fork, reverse		1 502201	
9	Set bolt (5" B.S.F. x 1" long) fixing forks to sha	afts :	3 237160	•
10	Stop for 2nd speed	1	21020 3	
11	Locker \(\)\(\)\(\) Fixing stop to)	1 210204	
12	Set bolt ($\frac{1}{4}$ " B.S.F. $x \frac{5}{8}$ " long) \int selector shaft		1 250693	
13	Interlocking plunger	2	2 5563 8	
14	Steel ball for selectors	:	3 1643	
15	Selector spring, forward	2	2 03649	•
16	Selector spring, reverse		56102	
17	Retaining plate L.H.	1	05853	·
18	Retaining plate R.H. For selector springs, side	e	1 05854	•
19	Rubber grommet	2	2 05852	
20	Spring washer Fixing	4	4 3074	
21	Set bolt (\frac{1}{4}" Whit. x \frac{1}{2}" long) \int retaining plates		4 215758	
22	Sealing ring, forward selector shaft	2	2 272596	
23	Sealing ring, reverse selector shaft	•••	1 272597	•
24	Retaining plate for sealing ring	2	2 241598	
25	Spring washer \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	4		
26	Set bolt (1" Whit. x 76" long) fretaining plate	4	1 215769	
27	Set bolt (2 B.A. $x \frac{9}{16}$ " long) \int In cover for	i	3697	
28	Locknut (2 B.A.) $\int 2nd$ gear stop	1	2247	
29	Adjustable stop for reverse selector shaft	1	231033	
3 0	Locknut (‡" B.S.F.) for stop	1	2823	

FRONT OUTPUT SHAFT HOUSING






FRONT OUTPUT SHAFT HOUSING

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	OUTPUT SHAFT HOUSING ASSEMBLY	1	268849	
2	Stud for oil seal retainer	6	217978	
3	FRONT OUTPUT SHAFT ASSEMBLY	[243611	
4	Bush for shaft	I	234534	
5	Oil thrower for output shaft	2	243873	
6	Bolt (2 B.A. $x \frac{1}{2}$ long) \int Fixing oil thrower to	2	234603	
7	Self-locking nut (2 B.A.) \int front output shaft	2	251335	
8	Bearing for front output shaft	1	21 73 25 	
9	Oil seal for shaft	1	236417	
10	Retainer for oil seal	1	236541	
11	Mudshield for retainer	1	236548	
12	Joint washer for retainer	1	234525	
13	Spring washer \(\) Fixing	6	3075	
14	Nut $(\frac{5}{16}" B.S.F.) \int$ retainer	6	2828	
15	Locking dog, four wheel drive	1	233241	
16	Flange for transfer shaft	1	23 7 912	
17	Mudshield for flange	1	236074	
18	Plain washer	1	3300	
19	Slotted nut Fixing flange to transfer shaft	1	3259	
20	Split pin	1	2 4 28	
21	Joint washer for transfer housing	1	233448	
22	Spring washer \(\) Fixing housing to	7	3075	
23	Nut $\binom{5}{16}$ B.S.F.) \int transfer box	7	2828	
24	Dust cover plate for selector shafts	1	266956	
25	Spring washer \(\bigcap \text{Fixing dust cover}\)	3	3074	
26	Bolt ($\frac{1}{4}$ " Whit. x $\frac{7}{16}$ " long) \int to housing	3	215 7 69	


CLUTCH WITHDRAWAL MECHANISM



CLUTCH WITHDRAWAL MECHANISM

PLATE	1 A A A DECORIDEION		B 11	
PLATE REF.		ty.	Part No.	REMARKS
1	CLUTCH WITHDRAWAL RACE HOUSING			
	ASSEMBLY	1	231071	
2	Bush for cross shaft, large	1	214793	
3	Bush for cross shaft, small	2	214 79 4	
4	Dowel locating housing	2	213700	
5	Bush for withdrawal race sleeve	1	231075	
6	Clutch withdrawal sleeve	1	231074	
. 7	Withdrawal race thrust bearing	1	214797	
8	Operating fork for clutch	1	264807	
9	Spring for operating fork	1	264806	
10	Cross shaft for clutch operation	1	231943	
11	Thrust washer for cross shaft	1	213660	
12	Oil seal for cross shaft	1	214787	
13	Cover plate for cross shaft	1	213661	
14	Joint washer for cover plate or housing	1	213662	
15	Spring washer Fixing cover	2	3074	
16	Set bolt (½" Whit. x ½½" long) plate or oil seal	2	215593	
	housing	4	213373	
17	Joint washer for clutch withdrawal housing	1	213663	
18	Self-locking nut (1" B.S.F.) Fixing withdrawal	3	251320	
		٠.		
19	Self-locking nut (15" B.S.F.) bell housing	4	251321	


MAIN GEAR LEVER



MAIN GEAR LEVER

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
	MAIN GEAR CHANGE LEVER ASSEMBLY	1	509939 Suitable for both R.H.D.
1	Gear change lever	1	509884 ∫ and L.H.D.
2	"O" ring for gear change lever	1	509233*
3	Housing for lever	1	219714
4	Locating pin for lever ball	1.	507447
5	Spherical seat for gear lever	1	219721
6	Retaining spring for lever	1	219723
7	Retaining plate for spring	1	219722
8	Circlip fixing retaining plate	Ī	219 797
9	Knob for lever	1	217735
10	Locknut (½" B.S.F.) for knob	1	3905
11	Mounting plate for gear change	1	232608
12	Set bolt $(\frac{5}{16}$ Whit. $x \frac{13}{16}$ long) Fixing housing	4	215647
13	Locker ∫ to mounting plat	e 4	2499
14	Spring washer Fixing mounting	2	3074
15	Set bolt $(\frac{1}{4}"$ Whit. $x \frac{21}{32}"$ long) \int plate to bell housing	2	215593
16	Reverse stop hinge complete	1	502202
17	Adjusting screw \ For	1	76653
18	Locknut (2 B.A.) ∫ hinge	1	2247
19	Bracket for reverse stop spring	1	502205
20	Spring for reverse stop	2	514650
21	Set bolt(4"B.S.F. x 3" long) Fixing hinge and	1	237138
22	Locker bracket to reverse	2	3421
	selector shaft	_	er tom t


FOUR WHEEL DRIVE SELECTORS AND TRANSFER GEAR LEVER



FOUR WHEEL DRIVE SELECTORS AND TRANSFER GEAR LEVER

		TOOK	TV LELLEL L	MAT	اظلنال		IND WIND	IMMIDTER	GEAR 1	TE A ETC
2 Selector fork complete, four wheel drive	PLATE REF.	1 2 3 4	DESCRIP	ΓΙΟΝ		Qty	. Part No.		REMAR	KS
Spring for selector fork 2 217521		Selector sha	ft, four wheel d	rive			233416			
Spring for selector fork 2 217521	2				ive					
Spring for selector shaft						2				
5 Block for selector shaft 23406 6 Special scree Fixing block 23409 7 Castle nut (% B.S.F.) to selector 251601 8 Split pin 5 shaft 2422 9 Selector shaft, transfer gear change 1 233308 10 Sealing ring for transfer gear change 1 235308 11 Selector fork, transfer gear change 1 217584 12 Set bolt & B.S.F. & Y. long) fixing fork 1 237160 13 Distance (tube for transfer selector shaft 1 233438 14 Locating bush for selector shaft 1 233437 15 Spring for gear change selector shaft 1 233436 16 Connector, gear change to pivot shaft 1 233406 18 Special screw Fixing block 1 233406 18 Special screw Fixing block 1 233406 19 Castle nut (% B.S.F.) to selector 1 251601 20 Split pin Shaft 1 2422 21 Pivot shaft for selector shafts 1 233407 22 Coupling, selector shafts to pivot 1 233407 23 Special screw Fixing 1 23425 24 Castle nut (% B.S.F.) to coupling to 1 251601 25 Split pin Pivot shaft 2422 26 Shakeproof washer Fixing pivot shaft 2422 27 Nut (% B.S.F.) to connector 2827 28 Plunger for transfer selector shaft 23241 29 Spring for plunger 1 56102 29 Spring for plunger 1 56102 20 Split pin Selector shaft 1 23340 21 Link for selector shaft 1 23341 23 Shakeproof washer Fixing plink to 1 77626 24 Spring for four wheel drive lever 1 23264 25 Shakeproof washer Fixing plink to 1 77626 26 Special bolt, lever to housing 1 23341 25 Lake proof plunger 1 23341 26 Shaft proof plunger 1 23341 27 Special nut 1 2862000 28 Special bolt, lever to housing 1 23664 29 Spring for four wheel drive lever 1 23264 30 Special bolt, lever to housing 1 23669 31 Special bolt, lever to housing 1 23464 32 Salaging ring for four wheel drive lever 1 2389 33 Split pin pin to lever 1 2389 4 Spring for selector rod								•		
6 Special screw Fixing block 233409 7 Castle nut (⅓ B.S.F.) × to selector 251601 8 Split pin shaft 2422 9 Selector shaft, transfer gear change 1 233308 10 Sealing ring for transfer gear change 1 217584 11 Selector fork, transfer gear change 1 217584 12 Set bolt ⅓ B.S.F. x 1' long) fixing fork 1 237160 13 Distance (tube for transfer selector shaft 1 233438 14 Locating bush for selector shaft 2 33437 15 Spring for gear change selector shaft 1 233436 16 Connector, gear change to pivot shaft 1 233406 17 Block for selector shaft 1 233406 18 Special screw Fixing block 1 233409 19 Castle nut (⅙ B.S.F.) Shaft 2 422 10 Split pin Shaft 2 422 11 Pivot shaft for selector shafts to pivot shaft 2 23425 12 Pivot shaft for selector shafts to pivot 2 33407 12 Special screw Fixing pivot 2 33408 12 Castle nut (⅙ B.S.F.) Shaft 2 422 12 Pivot shaft for selector shafts to pivot 2 33407 12 Special screw Fixing pivot 2 34252 12 Pivot shaft 2 422 13 Split pin Fixing pivot shaft 2 422 14 Shaleproof washer Fixing pivot shaft 2 3325 15 Shakeproof washer Fixing pivot shaft 2 33340 16 Shakeproof washer Fixing pivot shaft 2 33417 17 Pivot shaft 2 33417 2 33417 18 Special nut selector shaft 2 33417 19 Spring for plunger 1 23441 1 23441 1 2442 10 Spring for plunger 1 23441 1 23441 1 2442 1 2444 1						1				
Castle nut (\frac{h}' B.S.F.) to selector 251601						1				
Spit pin		-	£ .		-1	,				
9 Selector shaft, transfer gear change 1 233398 10 Sealing ring for transfer gear change 1 265019 11 Selector fork, transfer gear change 1 217584 12 Set bolt ½ B.S.F. x 1' long) fixing fork 2 237160 13 Distance (tube for transfer selector shaft 1 233438 14 Locating bush for selector shaft spring 233437 15 Spring for gear change selector shaft 1 217445 16 Connector, gear change selector shaft 1 233406 17 Block for selector shaft 1 233406 18 Special screw Fixing block 1 233406 19 Castle nut (½ B.S.F.) 1 to selector 1 251601 20 Split pin 1 2422 21 Pivet shaft for selector shafts to pivot 1 233407 23 Special screw Fixing 1 234252 24 Castle nut (½ B.S.F.) 2 51601 25 Split pin 2 2422 26 Shakeproof washer Fixing pivot shaft 2422 27 Nut (½ B.S.F.) 2 to connector 2 2827 28 Plunger for transfer selector shaft 2 2341 29 Spring for plunger 1 56102 29 Plug training plunger 1 233441 31 Link for selector shaft 2 23829 32 Shakeproof washer Fixing link to 77626 33 Special nut 5 selector shaft 1 3764 34 LEVER ASSEMBLY, FOUR WHEEL DRIVE 2 28847 35 Bush for lever 2 23086 36 Special both, lever to housing 2 33410 37 Locking pin, four wheel drive lever 2 23046 38 Split pin pin to lever 2 23046 39 Split pin pin to lever 1 23342 40 Split pin pin to lever 1 23340 41 Selector rod, four wheel drive lever 1 23464 42 Seling ring for four wheel drive lever 1 23464 43 Sealing ring for four wheel drive lever 1 23840 44 Seling ring for four wheel drive lever 1 23840 45 Split pin pin to lever 1 2389 46 Control knob for rod 1 268848 47 Spring for selector rod 1 26894 48 Spring for selector rod 1 26894 49 Spring for transfer gear change lever 1 243714 40 Knob for gear change lever 1 243714 40 Knob for gear change lever 1 243714 41 Locknob for gear change lever 1 243714 42 Knob for gear change lever 1 243714 43 Knob for gear change lever 1 243714 44						1				
Sealing ring for transfer gear change shaft 265019										
Selector fork, transfer gear change 237584 Set bolt & B.S.F. x 1" long) fixing fork 237160 Distance (tube for transfer selector shaft 233438 Locating bush for selector shaft spring 123437 Spring for gear change selector shaft 1233436 Connector, gear change to pivot shaft 1233436 Block for selector shaft 1233406 Special screw Fixing block 233409 Gastle nut (& B.S.F.) to selector 251601 Split pin shaft 12422 Pivot shaft for selector shafts 123408 Coupling, selector shafts to pivot 233407 Special screw Fixing 123425 Special screw Fixing 123425 Coupling, selector shafts to pivot 233407 Special screw Fixing 123425 Castle nut (& B.S.F.) coupling to 1251601 Split pin pivot shaft 2422 Castle nut (& B.S.F.) coupling to 1251601 Split pin pivot shaft 2422 Castle nut (& B.S.F.) to connector 2827 Plunger for transfer selector shaft 235416 Spring for plunger 123441 Link for selector shaft 123329 Spring for plunger 1233441 Link for selector shaft 123329 Shakeproof washer Fixing link to 77626 Special lut selector shaft 123340 Spring for plunger 1233410 Split pin pin to lever 123086 Special post Fixing locking 12346 Septial pin for lever 12346 Selector of, four wheel drive lever 12346 Selector of, four wheel drive lever 123442 Clevis complete for rod 1215808 Split pin for clevis 12389 Split pin for clevis 12389 Split pin for selector rod 126884 Spring for selector rod 126884 Spring for selector rod 126884 Spring for selector rod 126884 Spring for selector rod 126884 Spring for selector rod 126894 Spring for stransfer gear change lever 1234714 Skipp for transfer gear change lever 1243714 Sk			_	_						
12 Set bolt & B.S.F. x I long) fixing fork 1 237160 3 Distance (tube for transfer selector shaft 1 233438 4 Locating bush for selector shaft 1 233437 5 Spring for gear change selector shaft 1 217445 6 Connector, gear change to pivot shaft 1 233436 7 Block for selector shaft 1 233406 8 Special screw Fixing block 233409 9 Castle nut (\(\frac{1}{8} \) B.S.F. \) to selector 251601 9 Split pin Shaft 1 2422 1 Pivot shaft for selector shafts to pivot 1 233407 2 Special screw Fixing 1 234252 2 Castle nut (\(\frac{1}{8} \) B.S.F. \) coupling to 251601 2 Split pin Split pin 1 2422 2 Castle nut (\(\frac{1}{8} \) B.S.F. \) to connector 2827 2 Shakeproof washer Fixing pivot shaft 2422 2 Shakeproof washer Fixing pivot shaft 233416 2 Spring for plunger 1 23416 2 Spring for plunger 1 23416 2 Spring for plunger 1 23441 3 Link for selector shaft 233441 3 Lever Assembly, Four Wheel Lorive 28847 4 Lever Assembly, Four wheel drive lever 230086 3 Special both, lever to housing 233410 3 Locking pin, four wheel drive lever 2389 4 Split pin pin to lever 2389 5 Selector rod, four wheel drive lever 2389 5 Selector rod, four wheel drive lever 2389 5 Selector rod, four wheel drive lever 2389 5 Selector rod, four sheel drive lever 2389 5 Selector rod, four sheel drive lever 2389 5 Selector rod, four sheel drive lever 2389 5 Selector rod 23845 6 Control knob for rod 23845 7			_	-		,				
Distance (tube for transfer selector shaft 233438				_						
14 Locating bush for selector shaft spring 233437 15 Spring for gear change selector shaft 1 217445 16 Connector, gear change to pivot shaft 1 233436 17 Block for selector shaft 233406 18 Special screw Fixing block 233409 19 Castle nut (\frac{1}{8} \text{ B.S.F.}) to selector 251601 20 Split pin Shaft 2422 21 Pivot shaft for selector shafts 1 233408 22 Coupling, selector shafts to pivot 233407 23 Special screw Fixing pivot shaft 23425 24 Castle nut (\frac{1}{8} \text{ B.S.F.}) to coupling to 251601 25 Split pin Pivot shaft 73352 26 Shakeproof washer Fixing pivot shaft 23242 27 Nut (\frac{1}{8} \text{ B.S.F.}) to connector 2827 28 Plunger for transfer selector shaft 233441 29 Spring for plunger 56102 20 Plug retaining plunger 1 233441 21 Link for selector shaft 23329 22 Shakeproof washer Fixing link to 77626 23 Special nut selector shaft 3764 24 LEVER ASSEMBLY, FOUR WHEEL DRIVE 268847 35 Bush for lever 230086 36 Special bolt, lever to housing 233410 37 Locking pin, four wheel drive lever 23342 38 Sealing ring for four wheel drive lever 23342 40 Split pin pin to lever 23389 41 Selector rod, four wheel drive 23342 42 Clevic complete for rod 268848 43 Special bush for spring 1 234658 44 Spring for selector rod 268848 45 Special bush for spring 1 234658 46 Control knob for rod 23281 47 Locknut (\frac{1}{8} \text{ B.S.F.}) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 59 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 243714 50 Knob for gear change lever 1 243714 50 Knob for gear change lever 1 243714 50 Knob for gear change lever 1 243714 50 Knob for gear change lever 1 243714 50 Knob for gear change lever 1 243714 50 Knob f										
15 Spring for gear change selector shaft 1 217445										
16 Connector, gear change to pivot shaft		-		-	_	1				
17 Block for selector shaft 1 233406 18 Special screw Fixing block 1 233409 19 Castle nut (fk' B.S.F.) shaft 1 2422 12 Pivot shaft for selector shafts						1				
18 Special screw Fixing block 1 233409 19 Castle nut (** B.S.F.) to selector 1 251601 20 Split pin shaft 2422 21 Pivot shaft for selector shafts 1 233408 22 Coupling, selector shafts to pivot 1 233407 23 Special screw Fixing 1 234252 24 Castle nut (** B.S.F.) coupling to 251601 25 Split pin pivot shaft 1 2422 26 Shakeproof washer Fixing pivot shaft 1 23527 27 Nut (** B.S.F.) to connector 2 2827 28 Plunger for transfer selector shaft 1 235416 29 Spring for plunger 1 56102 20 Plug retaining plunger 1 56102 20 Plug retaining plunger 1 238329 32 Shakeproof washer Fixing link to 1 77626 33 Special nut selector shaft 1 3764 34 LeVer ASSEMBLY, FOUR WHEEL DRIVE 268847 35 Bush for lever 1 230086 36 Special bolt, lever to housing 1 233410 37 Locking pin, four wheel drive lever 1 230086 38 Sealing ring for four wheel drive locking pin 266992 39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 2389 41 Selector rod, four wheel drive 1 2389 42 Spring for selector rod 1 268848 43 Special bush for spring 1 268848 44 Special bush for spring 1 232813 45 Locknut (** B.S.F.) for knob and clevis 2 2823 46 Control knob for rod 1 232813 47 Locknut (** B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 219521			-,	NYOL SIIGH		1				
19 Castle nut (\frac{1}{16}\) B.S.F. to selector 1 251601			_	ving block						
Split pin					Α.	1				
21 Pivot shaft for selector shafts						1				
Coupling, selector shafts to pivot 233407						ì				
23 Special screw Fixing 234252						1				
24 Castle nut (_	••••	1				
25 Split pin						i				•
Shakeproof washer Fixing pivot shaft 73352						1				
27 Nut (*§ B.S.F.) Sto connector 2827 28 Plunger for transfer selector shaft 1 235416 29 Spring for plunger 1 56102 30 Plug retaining plunger 1 233441 31 Link for selector shaft 1 238329 32 Shakeproof washer Fixing link to 1 77626 33 Special nut Selector shaft 1 3764 34 LEVER ASSEMBLY, FOUR WHEEL DRIVE 268847 35 Bush for lever 1 230086 36 Special bolt, lever to housing 1 233410 37 Locking pin, four wheel drive lever 1 232464 38 Sealing ring for four wheel drive locking pin 1 266992 39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 23349 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Lockunt (\frac{1}{4}''' B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521					aft	1				-
Plunger for transfer selector shaft						i				
29 Spring for plunger	28	Plunger for	transfer selector			1	235416			
1 233441 238329 23848eproof washer Fixing link to 1 77626 33 Special nut Selector shaft 1 3764 34 LEVER ASSEMBLY, FOUR WHEEL DRIVE 268847 35 Bush for lever 1 230086 36 Special bolt, lever to housing 1 233410	29	Spring for p	olunger			1	56102			•
32 Shakeproof washer Fixing link to 1 77626 33 Special nut Selector shaft 1 3764 34 LEVER ASSEMBLY, FOUR WHEEL DRIVE 268847 35 Bush for lever 1 230086 36 Special bolt, lever to housing 1 233410 233410 233440 232464 37 Locking pin, four wheel drive lever 1 232464 38 Sealing ring for four wheel drive locking pin 1 266992 39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 2389 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 1 215808 43 Split pin for clevis 1 1 2389 44 Spring for selector rod 1 1 268848 45 Special bush for spring 1 1 234658 46 Control knob for rod 1 1 232813 47 Locknut (‡ B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 1 243714 50 Knob for gear change lever 1 1 219	3 0	Plug retaini	ng plunger		****	1	233441	•		
33 Special nut selector shaft 1 3764 34 LEVER ASSEMBLY, FOUR WHEEL DRIVE 1 268847 35 Bush for lever 1 230086 36 Special bolt, lever to housing 1 233410— 37 Locking pin, four wheel drive lever 1 232464 38 Sealing ring for four wheel drive locking pin 1 266992 39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 2389 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 232813 46 Control knob for rod 1 232813 47 Locknut (‡" B.S.F.) for knob and clevis 2 2823 48 T	31	Link for sel	ector shaft	****		1	238329	•		
34 LEVER ASSEMBLY, FOUR WHEEL DRIVE 1 268847 35 Bush for lever 1 230086 36 Special bolt, lever to housing 1 233410 37 Locking pin, four wheel drive lever 1 232464 38 Sealing ring for four wheel drive locking pin 266992 39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 2389 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 2389 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (‡" B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 243714 50	32	Shakeproof	washer \Fixing	link to		1	77626			
35 Bush for lever	33					1	3764			
36 Special bolt, lever to housing 1 233410— 37 Locking pin, four wheel drive lever 1 232464 38 Sealing ring for four wheel drive locking pin 1 266992 39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 2389 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 2389 45 Special bush for spring 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (½" B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521		LEVER AS	SEMBLY, FO	UR WHE	EL DRIV	/E 1	2688 47			
37 Locking pin, four wheel drive lever 1 232464 38 Sealing ring for four wheel drive locking pin 1 266992 39 Plain washer Fixing locking 1 2876 40 Split pin					••••	1				
38 Sealing ring for four wheel drive locking pin 1 266992 39 Plain washer Fixing locking 1 2876 40 Split pin		-		_	••••	1		•		.
39 Plain washer Fixing locking 1 2876 40 Split pin pin to lever 1 2389 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (* B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521					••••	1				
40 Split pin ∫ pin to lever 1 2389 41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (♣ B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 219521			-		ing pin	1				\$ ⁵
41 Selector rod, four wheel drive 1 233442 42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (‡" B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521			> -	_		1				
42 Clevis complete for rod 1 215808 43 Split pin for clevis 1 2389 44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (½" B.S.F.) for knob and clevis 2 2823 48 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521						1				
43 Split pin for clevis				ve	••••	1				
44 Spring for selector rod 1 268848 45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (½" B.S.F.) for knob and clevis 2 2823 48 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521		-		••••	••••	1				
45 Special bush for spring 1 234658 46 Control knob for rod 1 232813 47 Locknut (½" B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521				••••]				
46 Control knob for rod 1 232813 47 Locknut (‡" B.S.F.) for knob and clevis 2 2823 48 Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521				•]				
47 Locknut (‡" B.S.F.) for knob and clevis 2 2823 48 .Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 219521					••••]				
48 .Transfer gear change lever 1 504659 49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1. 219521										
49 Spring for transfer gear change lever 1 243714 50 Knob for gear change lever 1 1 219521				b and clev		1				
50 Knob for gear change lever 1 219521				 1.		1				
U D		_	_	-	••••	I				
JI LOCKNUT IOF KNOD 1 3/04		_	_	•	••••	I				
	ונ	LOCKNUT IOF	K110D	••••	••••	I	3/04			


FOUR WHEEL DRIVE SELECTORS AND TRANSFER GEAR LEVER



FOUR WHEEL DRIVE SELECTORS AND TRANSFER GEAR LEVER

PLATE REF.	1 2 3 4 DESCRIPTIO	ON C	ty.	Part No.		REMARKS
52	Bracket for gear change lever		1	219709		
53	Distance piece for bracket, 3" l	ong	2	266955		
54	Bolt (5 B.S.F. x 132 long)	Fixing	2	215170		
55	Spring washer	≻bracket to	2	3075		
56	Nut (5 / B.S.F.)	bell housing	2	2828		
5 7	Clevis pin \ Fixing transfer go	ear	1	216421		
58	Split pin Sever to bracket		1	2392	Alternative fixings.	Check
	Bolt (16" U.N.F. x 18" long)	Fixing transfer gear	1	256221	before ordering	
	Nut $(\frac{5}{16}"$ U.N.F.)	lever to bracket	1	ر 252161		

REAR AXLE AND PROPELLER SHAFT




<u> 1437</u>

REAR AXLE AND PROPELLER SHAFT

DI ATTIC		PEGGDIDEIO	7		D . M		DEMARKS
PLATE REF.	1 2 3 4	DESCRIPTION		Qty.	Part No.	~~	REMARKS
		ASSEMBLY 4.7]	279629	88	~
		ASSEMBLY 4.7		1	276320	109	Series II models
	REAR AXLE	ASSEMBLY 4.7	RATIO	1	531894*		Series IIA models
1	Rear axle ca	sing complete	••••	i 1	279633	88	
	Rear axle ca	sing complete		1	508591	109	
2	Special bo	olt, short 🤾 Fixing	differentia	1 4	01565		
3		olt, long housing			01564		
4		ating differential l		2	55705		•
5		nplete for rear axl		1	515845		
6		for rear axle casing		1	235592		
7		r for drain plug	·	1	230509		
8	Rear axle sh		••••	1	507681		
9	Rear axle sh			1	507682		40 du
10		earing sleeve	••••	2	273886	-> M	anchorrouport the mayour
		r, bearing sleeve to	axle casing		500978		
11		B ASSEMBLY		2	217423		
12		road wheel		10	217240		
13	Hub bearing			2	217269	->	Suport de mayour intoniem Fernature hometique (Jaint apri
14		inner bearing		2	239422		Franture hometique / Jaint ori
15	Hub bearing			2	217270)
16	Key washer		••••	2	217352	•	
17	Special nut		aring	4	217355		
18	Locker	Tixing nuc be	u6	. 2	217353		•
19		mber for rear hub		2 -	512887		
20		r for driving mem		2	231505		
21		for driving membe		2	276039		
22		r for filler plug		2	232038		
23		rear axle shaft	••••	2	501412		
25 24		B.S.F. x 1 18 7] I	 (1919)	2	201712		
24	long)		lriving men	nber 12	215331		
25			o rear hub	12	3076		•
25 26	Spring wash	_	o rear mub	2	3300		•
20 27	Slotted nut	_		2	3259		
28	Split pin	driving meml	207	2	2428		
20 29		,		2	219098		
30	Hub cap, re	R SHAFT ASSE	MRIV DE		236398	88	•
50	PROPERTIES	R SHAFT ASSE	MRIV RE	AD 1	502516		
21		l) For propeller	MDLI, INC	AX 1	262468	107	
31	•	shaft		2	262469		
32 33	Flange	nplete for propelle	r cheft	1	43023		
33 34	-	or journal		8	242522		
	-	•	••••	•	232557	Lot	ff on 109 at rear only
35		ple for journal	 nal front	1	502559	١	
		ase nipple for jour		I	502560	► 11 M	
		special grease nip		I	234532		
24		ple for shaft sleeve		l	276201)	
36	• •	ple for shaft sleeve		I	261428	> 11174	
37	Washer for		****	1	503269		, required when fitting 502559 as a service
	Adaptor for g	rease nipple, front	••••	1	202209		
20	D. J. /8# TINT	E = 13"1 \) <u>r:-:</u> -	4	509045	. 1	eplacement
38			Fixing		509751		
39	Self-locking r	nut (§ U.N.F.)	propeller	Silatt O	707771		

FRONT AXLE AND PROPELLER SHAFT




FRONT AXLE AND PROPELLER SHAFT

				DEMARKS
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	FRONT AXLE ASSEMBLY 4.7 ratio	1	2 723 05 †	R.H.D. \ 88, Standard
	FRONT AXLE ASSEMBLY 4.7 ratio	1	2 78 018 †	L.H.D. \int type
	FRONT AXLE ASSEMBLY 4.7 ratio	1	501 472†	R.H.D. \ 88, Reinforced Pendant
	FRONT AXLE ASSEMBLY 4.7 ratio	1	50 1473 †	L.H.D. \ type. Optional \type
	FRONT AXLE ASSEMBLY 4.7 ratio	1	277627 †	R.H.D. \ 109, Standard ball
	FRONT AXLE ASSEMBLY 4.7 ratio	1	278474 †	L.H.D. \(\) type joints
	FRONT AXLE ASSEMBLY 4.7 ratio	1	501474 †	R.H.D. \ 109, Reinforced
÷	THOM THE TENED	1	501475 †	L.H.D. \(\) type. Optional \(\)
	FRONT AXLE ASSEMBLY 4.7 ratio	1	519248**	> 1
	FRONT AXLE ASSEMBLY 4.7 ratio	1	519249 *†	L.H.D. \ type
	FRONT AXLE ASSEMBLY 4.7 ratio	1	519252*†	R.H.D. \(\) 88, Reinforced
	FRONT AXLE ASSEMBLY 4.7 ratio	1	519253*†	
	FRONT AXLE ASSEMBLY 4.7 ratio	1	519250 *†	
	I ROM AREE REELINEES IN	1	-	
	I NOIT I BEEL I RESERVED	1	519254 *†	
	FRONT AXLE ASSEMBLY 4.7 ratio	1	519255 *†	
1	I folit axic casing some	1	269829	Standard type
	I folic divis coming company	!	501471	Reinforced type. Optional
2	Special bolt, short \ Fixing differential	4	01565	
3	Special bolt, long \int housing to axle casing	; 6	01564	
4	Dowel locating differential housing	2	55705	·
5	Oli Scal III date desiring	2	217400	
6	Dieather complete for from and	1	515845	·
7	On thici pieg, metti,	1	3294	
8	Diam pieg ter ment and b	l	235592	
9	John washer for an area Pand	1	230509	wr.1 1'
10	PROPELLER SHAFT ASSEMBLY, FRONT			With spline grommet
, 11	Splined shaft \ For	1	262468	·
12	Flange ∫propeller shaft	2	262469	
13	J	2	43023	
14	Official for formal	8	242522	
15	Grease implies for Journal	2	232557	`
16	Circust inppre	1	276201	Angled type nipple Alternatives
17	Washer for nipple	1	401440	Alternatives
	Grease implies to state	1		Straight type nipple J
18	Bolt (\frac{2}{8}" U.N.F. x 1\frac{1}{8}" long) Fixing	4	509045	
	Bolt $(\frac{3}{8}"$ U.N.F. x $ \frac{7}{32}"$ long) propeller	4	509046	
19	Self-locking nut (3" U.N.F.) shaft	8	509751	D (515724
20	Rubber grommet set for propeller shaft splines.	1	276484	Part of 515734

^{*} Asterisk indicates a new part which has not been used on any previous model.


DIFFERENTIAL, FRONT AND REAR



DIFFERENTIAL, FRONT AND REAR

OI ATT	DIFFERENTIA			DEMARKS
PLATE REF.	1 2 3 4 DESCRIPTION		art No.	REMARKS
	DIFFERENTIAL ASSEMBLY 4.7 ratio	2	502280	
1	Crown wheel and bevel pinion	2	504869	
2	Differential casing	2	273441	
3	Set bolt (🐉 x 1 🖁 long) Fixing	16	272855	
	Special fitting bolt crown wheel	4	272934	
4	Locker, double type J to differential casin	g 10	272922	
5	Differential wheel	4	06735	
6	Differential pinion	4	40760	
7	Spindle for pinion	2	11378	
8	Plain pin \ For	2	11379	
9	Split pin ∫spindle	2	23 96	
	Thrust washer .040"	4	07902	
10	Thrust washer .045" > For differential wheel	ls 4	07904	As required
	Thrust washer .050"	4	50139	
11	Bevel pinion housing complete	2	219635	
12	Special set bolt fixing bearing cap	8	40742	
13	Taper roller bearing for differential	4	41045	
14	Serrated nut \ For	4	40756	
15	Lock tab Searing adjustment	4	40758	
16	Split pin fixing lock tab	4	2766	
17	Bearing for bevel pinion, pinion end	2	219544	
	Shim .003"	As required	230438	
18	Shim .005" > For bearing adjustment,	As required	230439	
	Shim .010" pinion end	As required	230440	
	Shim .020"]	As required	233678	
19	Bearing for bevel pinion, flange end	2	219550	
	End washer for bearing shim	4	502248†	T
	Shim .003")	As required	219547	
20	Shim .005" >For bearing adjustment,	As required	219548	
	Shim .010" flange end	As required	219549	
	Shim .020" J	As required		
21	Washer for pinion bearing	2	231242	
22	Retainer for oil seal	2	2 3 6547	
23	Oil seal for pinion	2	217507	
24	Mudshield for retainer	2	236546	
25	Joint washer for oil seal retainer	2	233473	•
26	Special bolt \ Fixing oil	12	237544	
27	Locker ∫ seal retainer	6	41049	
28	Driving flange for bevel pinion	2	236632	
29	Mudshield for driving flange	2	236072	
30	Plain washer Fixing	2	504433	
31	riain wasner driving flange to	2	5134541	tt
	Special nut bevel pinion	2	3259	
32	Split pin	2	2428	
33	Oil filler plug	2	05366	
34	Joint washer for plug	2	06009	
35	Joint washer, differential to axle casing	2	07316	
36	Spring washer \(\) Fixing differential	20	3076	
37	Nut $\binom{3''}{8}$ \int to axle casing	20	282 7	
	•			

1 2 3	4	* Aste	risk indicates a r	new part which has not been used on any pre	vious model.	
† Up to axles numbered:			151903126 154901272	†† From axles Front: numbered:	144902375	154901273 onwards
	D	1.41007742	151005004	Door.	141007744	151905087 onwards



	UNIVERSAL JOINT		IND I	
PLATE REF.	1 2 3 4 DESCRIPTION Qt	<u> </u>	art No.	REMARKS
	Half shaft complete for front axle R.H.		269265	
	Half shaft complete for front axle L.H		269266	
1	Half shaft only, R.H		276719	
	Half shaft only, L.H.		276720	
2	_ · · · · · · · · · · · · · · · · · · ·		242520	
3	,		242521	
4			242522	
5	Troubling for College Party College		234789	
6	- Notation Production		244151	
7	200.00		244150	
8	* * * * * * * * * * * * * * * * * * *		217398	
. 9	Joseph Walter Lat Landing		232413	
	Execution stop for june		519206	sur: 1 1 1 1 '
10	2010 (8 21212 111 14 12 12 13)	0	237340	With standard axle casing
11	Bolt (3" B.S.F. x 13" long) housing	2		10 off with reinforced axle casing
	2011 (8 210101112 11 8)	2	237342	With reinforced axle casing
12	Don realing 1124 (8 /	12	50526	
	HOUSING ASSEMBLY FOR SWIVEL PIN,		00/504	
	L.H.	ì	236534	For axles with pendant type ball joints
13	HOUSING ASSEMBLY FOR SWIVEL PIN,		00/505	
	R.H	. 1	236535	4
	HOUSING ASSEMBLY FOR SWIVEL PIN,	1	504074 *	r 1 ol
	LH EOD CHUTL DIN	Į	52 4874*	For axles with non-pendant
	HOUSING ASSEMBLY FOR SWIVEL PIN,		524075 *	type ball joints
	R.H	1	524875 * 508153	8 off for axles with non-pendant type ball joints
14	Special stud for steering lever and bracket	2		8 off for axles with non-pendant type ball joints
15	Stud for steering lever	6	508152 236070	of for axies with non-pendant type ban joints
16	Drain plug for housing	2	230511	
17	Joint washer for drain plug	2		R.H.D.
10	Swivel pin and steering lever complete, R.H	1	274145 274147	1
18	Swivel pin and steering lever complete, L.H.	1	274146	<u> </u>
	Swivel pin and steering lever complete, R.H.	1	274148	, · · ·
	Swivel pin and steering lever complete, L.H	1	502710*	
•	Swivel pin and steering lever complete, R.H.	1	502711*	· ·
	Swivel pin and steering lever complete, L.H Swivel pin and steering lever complete, R.H	¦.		L.H.D. type ball joints
		 -		L.H.D.
	Strike bur min ordering sever transports, and	2	239017	L.I I.D.)
		2	50453	•
		2	231251	For axles with non-pendant type ball joints
10		2	230858	1 or union with home pointaint type ban jointo
19 20	Cone seat for swivel pin, top	2	238553	
20	Cone bearing for swivel pin, top	2	242742	
21	Spring for cone bearing Bearing for swivel pin, bottom	2	217268	
22 23		2	217421	For axles with pendant type ball joints
25		2	502714	For axles with non-pendant type ball joints
_	Swivel pin and bracket complete	-	J027 (3	To whom their tion boundary albe age laure







PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.	REMARKS
	Shim .003"		As required	230007	
24	Shim .005" >For swivel pin		As required	217453	
	Shim .010" bearing		As required	217454	
	Shim .030" J		As required	217455	
25	Set bolt (% x 1% long) Fixing		8	250542	For axles with pendant type ball joints
26	Locker >swivel pin to	0	8	270287	
27	Nut (3" B.S.F.) swivel pin h	ousing	8	282 7	16 off when non-pendant ball joints are fitted
28	Oil seal for swivel pin bearing housing		2	502406	
29	Retainer for oil seal		2	235968	
30	Spring washer		10	3074	
31	Set bolt (½" x ¾" long Fixing		10	237138	
32	Adjustable lock stop bolt >retainer to	0	2	250696	
33	Locknut (1") for stop bolt swivel pir			2823	4 off on 109 and when 7.00 x 16, or 8.20 x 15
					tyres are fitted
34	Lock stop plate		2	508175	
35	Oil filler plug for swivel pin housing		2	3292	
	SWIVEL PIN CONVERSION KIT		1	532268*	To convert cone and spring
	0 1 1 1		2	528443*	
	Swivel bearing housing and bush co	_	2	532267*	(
36			2	217422	J unit till utt (1 utt) (1 utt
37	D 1 (1 · · · 1 · 6	••••	2	217354	
38		••••	2	217351	
39	Joint washer, stub axle to swivel pin h		2	277289	
) E:.:		ام		λ_{\bullet}
40	Set bolt (* D.S.r. X I long) to swi	vel pin	14	237339	
41	Locker housin	-	6	277311	
42	PRONT LIED ACCEMBLY		2	217423	
43	6. 16 1 1 1	••••	10	217360-	. Goupon de rone
44	D 2 (. f 1 1 1 1	••••	2	217269~	Surject interior de no year (Rome Pement
45	01 16 1 1	••••	2	239422 -	Gouges de rene Suffert interior de noyeux (nomfement Joint spi Empert exterior de magex (foulement) Rondelfi De 1000 hois
46	Day to the form 1.1. The same		2	217270-	Europe exterious de mayer (factement
47	Key washer	••••·	2	217352	Rondelli
48	Locker Fixing front hub bearing	V.	2	217353	. Rondelle frein Ecron special
49	Special nut	אַי	- 4	217355	Eczon special
50	Driving member complete for front hu	.L	-	512887	
50	Joint washer \(\) For driving	ID	2	232038	
	Oil filler plug member		2	276039	
6.1	I			231505	
51 52	•		2 2	501412	
22	Oil seal for stub shaft	 :]::		201412	
53	Onting washer	ing drivi	^{ing} 12	3076	
54	Set bolt (8" BSE = 119" long) (mer	nber to	12	215331	
CE	יווו ל	nt hub	า	2200	
55 57	Plain washer Fixing		2	3300	,
56	Slotted nut driving member		2	3259	
57 50	Split pin to driving shaft		2	2428	
58	Hub cap, front	···· .	2	219098	




מיני מיני		2010	COLO	
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	STEERING UNIT ASSEMBLY	1	509449	R.H.D.
	STEERING UNIT ASSEMBLY	1	509448	L.H.D. With centre horn push
1	STEERING BOX ASSEMBLY	1	515508	BHUĮ
	STEERING BOX ASSEMBLY	1	515509	L.H.D. Dowel type
2	Bush for rocker shaft	1	261850	
3	Outer column	1	271364	
4	Joint washer, steel	As required		
5	Joint washer, paper	As required		
	Joint washer, paper	As required		
6	Bolt (元 U.N.C. x 器 long) \ Fixing oute		271380	
7	Spring washer column	4	3075	
8	Inner column	1	271367	R.H.D.\ Models with side horn push.
	Inner column	1		L.H.D. Check before ordering
	Inner column	1		R.H.D. Models with centre horn push.
	Inner column	1	518677	L.H.D. Check before ordering
9	Bush for inner column	1	501245	i Tarangan Kabupatèn Kabupatèn Kabupatèn Kabupatèn Kabupatèn Kabupatèn Kabupatèn Kabupatèn Kabupatèn Kabupatèn
10	Spring ring for inner column bush	1	501246	S.Port of 7/136/1
11	Dust shield for inner column	1		Models with side horn push
12	MAIN NUT ASSEMBLY	i	261862	
	MAIN NUT ASSEMBLY	1	261865-	
13	Set bolt (2 B.A. x ½" long) Fixing	2	234603	Lat i.D.
14	Lock washer for bolt retainer	2	261868	
15	Steel ball (3") for main nut	12	1643	
16	Roller for main nut	1	261869	
17	Adjustable ball race	2	271384	
18	Steel balls (.280") for adjustable race	20	260823	
19	Rocker shaft	1	271372	
20	Adjuster screw for rocker shaft	i	261873	
21	Locknut for adjuster screw	i	261874	
22	Oil seal for rocker shaft	1	261851	
23	Washer for rocker shaft oil seal	1	271377	
24	End plate	1	271378	
25	Joint washer, steel	As required		
26	Joint washer, paper	As required		
	Joint washer, paper	As required		
27	Bolt (5 " U.N.C. x 29 " long) \ Fixing	4		
28	Spring washer Send plate	4	3075	
29	Side cover plate	1	272181	 .
30	Joint washer for side cover plate	i	261880	Plain type Alternatives.
	Side cover plate	1	515848	Check before ordering
	Joint washer for side cover plate	1	515849	Dowel type
31	Bolt (5" U.N.C. x 118" long) } Fixing side		271382	,
3 2	Spring washer cover plate		3075	
33	Oil filler plug	1	271386	
34	Special nut \ Fixing	i i	254877	
35	Lock washer drop arm	i	4115	
36	Steering drop arm	İ	517507	
37	Rubber seal for steering column	i	303995	
3 8	Cover for steering column seal	1	303997	
39	Screw (2 B.A. x \(\frac{3}{4}\)" long)	2	77861	•
40	Special washer Fixing cover and	2	303996	
41	Spring washer seal to dash	2	3073	
42	Nut (2 B.A.)	2	2247	
		_	##J/	



DI ATTE	DIEER		COLO	
PLATE REF.	1 2 3 4 DESCRIPTION C	Įty.	Part No.	REMARKS
43	Steering wheel	1	512322	
44	Bolt $\binom{5}{16}$ U.N.F. x 2" long) \bigcap Fixing	1	256226	
4 5	Plain washer >steering	1	2550	
46	Nut (5 U.N.F.) wheel	1	254811	
47	Steering wheel centre cover	1	268284	
48	Horn push bracket	1	271496	
49	Clip for horn push bracket	1	277560	
50	Yoke assembly for horn push bracket	1	270724	
51	Nut (1" B.S.F.) Fixing horn	1	2823	en en en en en en en en en en en en en e
52	Shakeproof washer push bracket	i	,	Models with side horn push
53	Horn push	i	217279	Check before ordering
54	Special screw LU 153564) Fixing	2	3279	·
55	Spring washer horn push	2	3072	
56	Nut (5 B.A.) to bracket	2	4011	
57	Lead, horn push to junction box	1	270961	
58	Horn push and centre cover for steering wheel	i	512352)
59	D . 11	i	512359	·
٠,٠	Screw (2 B.A. $\times \frac{5}{16}$ " long) Tixing dust cover	2	67184	Models with centre horn push.
	Shakeproof washer to steering wheel	2	74236	Check before ordering
6 0	CP 1 L C L	1	519753	Check before ordering
61	1 . 1 . 1	1	519755	Saria II and
62	C.111	1	240431	Series II only . J
63	ו י יו	1	232026	
64	Screw (2 B.A. x ½" long)	2		1059 60 E 21 lb D 1 LLD 1 1
65		2	3073	>1958-60. Except 2½ litre Petrol L.H.D. models when toe box heat shields are fitted
66	Spring washer Nut (2 B.A.)	2	3823	when toe box heat shields are fitted
00	Heat protection cover for dip switch	1	332199)	
	Bolt (2 B.A. x 5 long)	2	237121	
	Plain washer Fixing protection	2		-L.H.D. 1958-60 models. Not applicable when
	Spring washer cover	2	3073	toe box heat shields are fitted
	Nut (2 B.A.)	2	3823	toe box heat shields are litted
	D' '-1 111210004	1	502087	
	Marming place for discountry	i	514790	•
	Screw (No. 10 U.N.F. x 1" long) Fixing	2	78325	
	Spring washer dip switch to	2	3073	
	Nut (No. 10 U.N.F.) mounting plate	2	257011	
	Bolt (No. 10 U.N.F. $x \frac{1}{2}$ " long) Fixing	2		- 1958-60 2½ litre Petrol LH.D. models when toe box
	Spring washer mounting plate	2	3073	heat shields are fitted
	Nut (No. 10 U.N.F.)	2	257011	near sinclus are inteu
		1	514827	
	C . C 1 12 . 1 . 0	1	236389	
	C11 P 1 1	i	8885	
67	Dt. 5.1	1	502087	
68	Screw (10 U.N.F. x 1" long) Fixing	2	,	>1961 models
69	Spring washer >dip	2	3073	onwards
70	Nut (10 U.N.F.)	2	257011	OHWALUS
71	I and the maintain in the firm	1		Except 21 litre Petrol L.H.D. models when toe box
/ 1	Lead, dip switch to junction box	1	JUJ9ZQ	heat shields are fitted
	Lead	1	519638	R.H.D.
	Lead, LU 54946221 Dip switch to	1	514827	L.H.D. \ 1961 Series II models
	Lead junction box	1.		R.H.D.
	Lead Junction Box	1	531501*	
72	Crammat for lead in the land of	1		1961 models onwards
12	Crommet for lead in toe box floor	1	£J0307	1701 models offwards



Di Amer				COLUMN	
PLATE REF.			Qty.	Part No.	REMARKS
73	Clip fixing dip switch lead to	floor	2	8885)	-
74	Screw		2	L	n L.H.D.
75	Spring washer Fixing clip	1	2	3073	
76	Nut (2 B.A.)		2	ر 2247	•
77	Support bracket on dash	en	1	302986	
78	Bolt $(\frac{5}{16}" \text{ U.N.F. } \times \frac{5}{8}" \text{ long})$)	. 4	255025	
79	Plain washer, smali	Fixing	2	3868	
	Plain washer, large	>support bracket	2	3662	
80	Spring washer	to dash	4	3075	
81	Nut (18" U.N.F.)	J	4	254801	
82	Support bracket for steering		1	303701	
83	Packing piece for steering col	umn support brac	ket 1	332729	
84	Clip for steering column		1	300715	
85	Rubber strip for clip	<u></u>	1	300716	
86	Bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long)	Fixing	2	25520 7	
87	Spring washer	clip to	2	3074	
88	Nut (<u>1</u> " U.N.F.)	support bracket	2	254800	
89	Bolt (16" U.N.F. x 3" long)]	2	255227	
00	Bolt (15" U.N.F. x 3" long)	Fixing support	2	255226	
90	Plain washer	bracket to	2	3966	
91	Spring washer	dash bracket	4	3075	
92	Nut (18" U.N.F.)	, ,	4	254801	•
. 02	Support bracket R.H. For		1	277294	
93	Support bracket L.H. Son o	hassis	1	277295	
94	Bolt (5 " U.N.F. x 33" long)	_E , .	6	256233	•
95	Plain washer, thin	Fixing	6	3830	+
ne	Plain washer, thick	brackets to	6	3898	3
96 97	Spring washer	chassis frame	6	3075	
98	Nut (5" U.N.F.))	6	254811 504376 PALE	•
70	Stiffener bracket for steering l Stiffener bracket for steering l		I	504276 R.H.D.	
	Bolt (½" U.N.F. x ½" long)	Fixing	I	504272 L.H.D. 255005')	<u> </u>
	Plain washer	stiffener bracket	4	> Altowart	ives to line below
99	Bolt plate	to front	4 2	30 4 0,)	
100	Spring washer	face of			ive to 2 lines above R.H.D.
101	Nut (¼" U.N.F.)	toe box	4	3074 254810	*
102	Bolt (\frac{1}{2}" U.N.F. x 1" long)	roe nox	1	_	J
103	Plain washer	Fixing stiffener	1	255009 3840 >3 off on	LUD
104	Spring washer	bracket to	1	3074 S on on	L.U.D.
105	Nut (‡" U.N.F.)	top face of	ī	254810	
106	Shim washer		s required	504279 R.H.D.	
	Shim washer		s required	504275 L.H.D.	
	Bolt (5 " U.N.F. x 13" long)	٦ .	2	256021	
	Set bolt (\frac{5}{16}" U.N.C. x \frac{3}{4}" long) Fixing	1		09 L.H.D.
	Set bolt ($\frac{5}{16}$ " U.N.C. $\times \frac{7}{8}$ " long		1	253027 109 L.H	
	Locking plate	to chassis	ī	517877*	.L.,
107	Set bolt (\frac{3}{8}" U.N.C. x \frac{7}{8}" long)		1	253046	
	Locking plate	bracket	1	517878*	
109	Self-locking nut (5 " U.N.F.)		2	252211	·
		J			



		DIMERUIO			
PLATE REF.	1 2 3 4 DESCR	IPTION	Qty.	Part No.	REMARKS
	STEERING RELAY C	OMPLETE ASSEM	IBLY I	232693	
1	Housing for relay shaf	t	1	230757	
2	Shaft for steering relay		1	230762	
3	Split bush for housing		· 2	230758	
4	Washer for spring		2	230760	
5	Spring for brushes	1	1	230759	
6	Thrust washer for shad	ft	2	241388	
7	Distance piece for shall	t	2	230184	
8	Oil seal for shaft		2	213340	
9 .	Retainer for oil seal		2	230294	
10	Joint washer for retain		2	230295	
11	Special bolt \ Fixin		8	231299	
12	Spring washer ∫ to ho	using	8	3074	•
13	Plug for oil hole		2	237138	
14	Joint washer for plug	••••	2	3052	
15	Relay lever, upper]	263807	
16	Bolt (7 U.N.F. x 21 le		i i	256465	
17	Spring washer	>lever to	1	3077	
18	Nut (7/2 U.N.F.)) shaft	l l	254823	
19	Bolt (5 " U.N.F. x 3½" lo		2	256432	
20	Spring washer	housing to	2	3075	
21	Nut (1/6" U.N.F.)	chassis fram		254801	•
22	Flange plate for relay mo	_	1	217694	
23	Set bolt (1" U.N.F. x 5"			255007	
0.4	long)	flange plate to	4	255006	
24	Spring washer	J chassis frame	4	3074	For pendant type ball joints. Check before ordering
25	Relay lever, lower	****	I		For non-pendant type ball joints. Check before
	Relay lever, lower			302713	ordering
26	Bolt (76" U.N.F. x 21" lo	ong)] Fixing	1	256465	ordering
27	Spring washer	>lever	1	3077	
28	Nut (7 U.N.F.)	to shaft	i	254823	
29	STEERING TRACK F		•	25 1025	
27	(length between cent		<i>₊</i> ″) 1	269267	For pendant type ball joints. Check before
	Steering track rod only			269269	ordering
	STEERING TRACK F				j
	(length between cen		§")	526993*	For non-pendant type ball joints. Check before
	Steering track rod only			526994*	1 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
3 0	BALL JOINT ASSE			231183	,
31	BALL JOINT ASSE			231184	
32	Rubber cover for ba		2	214649	•
33	Spring ring, cover to	-	2	214685	
34	Spring ring Cover		2	214684	•
J.1	Retainer to bal		2	214662	
35	Plain washer	-	2	3680	·
36	j j	ng ball joints to leve		2822	
37	Split pin	,0.1110 10 1040	2	2393	
	~h h		<u> </u>	-7	





PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
38	Clip for ball joint	2	518437	
39	Bolt ($\frac{1}{4}$ " x $1\frac{1}{2}$ " long) \(\) Fixing ball	2	250517	
40	Self-locking nut (¼") ∫ joint clips	2	251320	
41	STEERING DRAG LINK ASSEMBLY	Ī	269268	
	Steering drag link only	1	269270	
42	BALL JOINT ASSEMBLY, R.H. THRI	EAD 1	231183	
43	BALL JOINT ASSEMBLY, L.H. THRI	EAD 1	231184	
44	Rubber cover for ball joint	2	214649	
45	Spring ring, cover to body	2	214685	
46	Spring ring \ Cover	2	214684	
47	Retainer ∫to ball	. 2	214662	
48	Plain washer	2	3680	
49	Castle nut Fixing ball joints to lever		2822	
50	Split pin	2 2	2393	
51	Clip for ball joint		518437	•
52	Bolt (1" x 11 long) > Fixing ball joint clip		250517	· •
53	Self-locking nut (½")	2	251320	
54	LONGITUDINAL STEERING TUBE			
	ASSEMBLY	1	276785	
	Longitudinal steering tube only	1	276784	
55	BALL JOINT ASSEMBLY, R.H. THRI	EAD 1	231183	· · · · · · · · · · · · · · · · · · ·
56	BALL JOINT ASSEMBLY, L.H. THRI	EAD 1	231184	
57	Rubber cover for ball joint	2	214649	
58	Spring ring, cover to body	2	214685	
59	Spring ring Cover	2	214684	•
60	Retainer ∫to ball	2	214662	
61	Plain washer Fixing	2	3680	
62	Castle nut >ball joints	2	2822	
63	Split pin J to levers	2	2393	
64	Clip for ball joint Fixing	2	518437	
65	Bolt (¼″ x 1½ long) >ball joint	2	250517	
66	Self-locking nut (1/1) dlips	2	251 3 20	
	•			


BRAKES, FOOT, 10", 88 MODELS



BRAKES, FOOT, 10", 88 MODELS

	BRAKES,	FOOI,	10, 88	MODELS
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	BRAKE ANCHOR PLATE ASSEMBLY	Y, L.H.,		
	GI 64270176	2	515406	
l	BRAKE ANCHOR PLATE ASSEMBL	Y, R.H.		
	GI 64270177	2	515405	
2	Anchor pin for brake shoe, GI GB 4397	74 4	243294	
3	Spring washer, GI 40-S-35 \ Fixing	4	218 97 0	Up to front axles numbered 141001222 and
4	Special nut, G 30-BS-5 anchor pi	n 4	218971	>144000935; up to rear axles numbered 141002007
5	Shoe steady post, GI GB 37991	8	219620	
6	Locknut for steady post, GI 30-BS-32	8	212835	
. 7	Set bolt (\frac{3}{8}" x 1" long) Fixing front and	hor 12	237339	
8	Locker plate to axle case		232416	•
	Bolt (\frac{8}{2}" x 1\frac{8}{2}" long) \frac{1}{2} Fixing	12	250542	•
	Spring washer rear anchor plate	12	3076	
	Nut $\binom{\$''}{\$}$ to axle case	12	2827	
	BRAKE SHOE ASSEMBLY L.H. I	BOXED)
	PAIRS, FRONT AND REAR	2	505675	Bonded type linings
9	BRAKE SHOE ASSEMBLY R.H. I	BOXED		
	PAIRS, FRONT AND REAR	2	505676	J
	Linings complete with rivets, for brak	e shoe,		
	GI GB 35484 BG	8	241090	For early type shoe with riveted linings. Check before ordering
10	Linings complete with rivets, for bral	e shoe,		
	GI GB 35484 CQ	8	504577	Riveted type lining for replacement of bonded originals on export models
12	Spring post for brake shoe, GI GB 37769	4	232074	Part of brake shoe
15	Anchor for brake shoe, GI GB 42600	4	236993	
16	Special set screw fixing anchor, GI 25-BS	-72 8	238542	
17	Locking plate for bolt, GI GB 42620	· 4	236995	
18	Pull-off spring for brake shoe, GI GB 367	41 4	218983	
19	Pull-off spring for leading shoe, GI GB 10	6337 4	503981	
	WHEEL CYLINDER ASSEMBLY,	L.H.		
	FRONT, GI 390073 W	1	243297	
20	WHEEL CYLINDER ASSEMBLY,	R.H.		•
	FRONT, GI 390072 W	1	243296	
	WHEEL CYLINDER ASSEMBLY,	L.H.		
	REAR, GI 390015 W	1	243303	
	WHEEL CYLINDER ASSEMBLY,	R.H.		
	REAR, GI 390014 W	1	2433 02	
21	Spring for piston, front, GI 378868	2	212919	
	Spring for piston, rear, GI 378860	2	212943	
22	Washer for spring, front, GI 378109	4	232107	
	Washer for spring, rear, GI 378108	4	242117	
23	Bleed screw, GI 377655	4	234176	•
24	Steel ball for bleed screw, GI 27240	4	3746	
25	Special nut \ Fixing	8	2 433 01	
26	Spring washer \int wheel cylinder	8	219025	
27	Brake drum	4	218149	
28	Set screw fixing brake drum	12	1510	
				•


BRAKES, FOOT, FRONT, 11", 109 MODELS



BRAKES, FOOT, FRONT, 11", 109 MODELS

DI ATT		
PLATE REF.	1 2 3 4 DESCRIPTION Qty.	
1	Brake anchor plate, L.H., front, GI GB 44635 1	246565
	Brake anchor plate, R.H., front, GI 44636 1	246566
	Set bolt (§ x 1" long) \ Fixing anchor plate 12	237339
	Locker \int to axle case 6	232416
2	Steady post for brake shoe 4	234192
3	Bush for steady post, GI GB 41423 4	234888
4	Special nut fixing steady post 4	254861
5	BRAKE SHOE ASSEMBLY, BOXED PAIR,)
	L.H. FRONT 1	512415 Bonded type linings.
	BRAKE SHOE ASSEMBLY, BOXED PAIR,	
	R.H. FRONT 1	512416 J
	Lining complete with rivets, for brake shoe,	
	GI GB 41298 B6 4	246569 For early type shoe with riveted linings. Chec before ordering
6	Lining complete with rivets, for brake shoe,	
	GI GB 41298 CQ 4	510573 Riveted type linings for replacement of bonder originals on export models
8	Pull-off spring for brake shoe, GI 41429 4	234889
9	WHEEL CYLINDER ASSEMBLY, L.H.	
	FRONT, GI 390360 W 2	243743
	WHEEL CYLINDER ASSEMBLY, R.H.	
	FRONT, GI 390361 W 2	243744
10	Spring, GI 378845 4	233211
11	Air excluder, GI 317051 4	242463
12	Sealing ring for cylinder, GI GB 41043 4	234191
13	Bleed screw, GI 377655 2	248909
14	Steel ball for bleed screw, GI 27240 2	3746
15	Spring washer Fixing wheel 8	3075
16	Special nut, GI 30-BS-62 ∫cylinder 8	233879
17	Connecting pipe for wheel cylinder, GI 394500 W 2	233122
18	Brake drum 2	
19	Set screw fixing brake drum 6	1510


BRAKES, FOOT, REAR, 11", 109 MODELS



BRAKES, FOOT, REAR, 11", 109 MODELS

	DRAKES, FUUI, REA	111, 11,	
PLATE REF.	1 2 3 4 DESCRIPTION Qty.	Part No.	REMARKS
1	Brake anchor plate L.H., rear, GI 42841 1	237710	Series II models
	Brake anchor plate R.H., rear, GI 42842 1	237711	Series II models
	Brake anchor plate, L.H., rear, GI 64270811 1	531888*	Series IIA models
	Brake anchor plate, R.H., rear, GI 64270812 1	531889*	Series TIA models
	Bolt $(\frac{3}{8}'' \times 1\frac{3}{8}'' \text{ long})$ Fixing rear	250542	
	Spring washer anchor plate 12	3076	•
	Nut $(\frac{3}{8}'')$ J to axle case 12	2827	
2	Steady post for brake shoe, GI GB 40038 4	234192	
3	Bush for steady post, GI GB 41423 4	234888	Series II models
4	Special nut for steady post 4	254861	J
5	BRAKE SHOE ASSEMBLY, REAR, BOXED	F10115	
	PAIRS 2	512417	Series II models. Bonded type linings
	Lining complete with rivets, for brake shoe,	0/07/3	
	GI GB 47095 4	268763	For early type shoe with riveted linings.
	DRIVE CLOCK ACCEMBLY DEAD DOVED		Series II models. Check before ordering
	BRAKE SHOE ASSEMBLY, REAR, BOXED	E22044 *	S : IIA 11 D 111 Male
,	PAIRS 2	532044*	Series IIA models. Bonded type linings
6	Lining complete with rivets, for brake shoe 4	510575	Riveted type linings for replacement of bonded
11	C : 1: 1 CI CD 2452) 2	42210	originals on export models
11	Spring, adjuster end, GI GB 2453 2 Spring, wheel cylinder end, GI GB 39757 For 2	42318 242905	Series II models
12	Spring, wheel cylinder end, GI GB 39757 For 2 Spring, abutment end, GI 64377119 brake 2	531893*	₹ .
	Spring, wheel cylinder end, GI 64377118 shoe 2	531892*	Series IIA models
13	Adjuster housing, GI GB 41321 2	234901	₹
14	Spring washer Fixing adjuster 4	3076	
15	Special set bolt, GI GB 41442 housing 4	234908	
16	Plunger L.H., GI 41322 2	234902	
17	Plunger R.H., GI 41323 2	234903	
18	Cone for adjuster, GI GB 3D 2	04965	Series II models
19	WHEEL CYLINDER ASSEMBLY, L.H., GI	•	1
	64673536 1	521543	
	WHEEL CYLINDER ASSEMBLY, R.H., GI		
	64673537 1	521544	
20	Spring, GI 378845 2	233211	
21	Air excluder, GI 317261 4	248240	J
	WHEEL CYLINDER ASSEMBLY, L.H., GI)
	390072W 1	243296	
	WHEEL CYLINDER ASSEMBLY, R.H., GI		Series IIA models
	390073W 1	243297	
	Spring for piston, GI 378868 2	212919	
	Washer for spring, GI 378109 4	232104	J
22	Bleed screw, GI 377655 2	234176	
23	Steel ball for bleed screw, GI 27240 2	3746	
24	Brake shoe abutment plate, GI 378133 2	248248	
25	Retainer for brake shoe abutment plate, GI 487143 2	234960	•
26	Screw, GI 13112 Fixing retainer 8	234962	
27	Shakeproof washer, GI 12437 and abutment plate 8	234963	
28	Dust cover plate for brake wheel cylinder, GI GB	249247	
20	42106 2	248247	\
29 20	Spring washer Fixing wheel 6 Self Labina and CLOB 5222 Collins In the Clob 5222 Fixing wheel 6	2284	Series II models
30	Self-locking nut, GI GB 5232 \(\) cylinder 6 Special nut \(\) Fixing wheel 4	235222 243301	≺
	Special nut Fixing wheel 4 Spring washer Cylinder 4	243301 219025	Series IIA models
31	D. I. I	245156	J
32	C. C: 1 1 1 (1510	
JL	Det screw fixing brake drum 0	טוענ	


BRAKE PIPES



BRAKE PIPES

		//21/7T	11112	•
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
T	Bracket for 5-way piece	I	241676	
2	Drive screw fixing bracket	2	72626	
3	5-way piece for brake pipes	1	279412	
4	Bolt (4" U.N.F. x 14" long)	1	256001	
5	Spring washer Fixing 5-way pi	ece 1	3074	•
6	Nut (‡" U.N.F.)	1	254800	
7	Stop lamp switch, GI 398000	1	268963	Series II models
	Stop lamp switch	1	502097	Series IIA models
8	Brake pipe, GI 3406612W \ Master cylinder to	1	508148	R.H.D.
	Brake pipe, GI 3310610W 5-way piece	1	512838	L.H.D.
9	Brake pipe, 5-way to L.H. front	1	277922	
10	Brake pipe, 5-way to R.H. front	1	277923	
••	Bracket for L.H. front brake pipe	i	508566)	
	Bolt (\frac{5}{18}" U.N.F. x \frac{2}{4}" long) \frac{1}{18} Fixing	1	255226	
	Plain washer bracket to	i	3830	>2½ litre Petrol and 2½ litre Diesel models
	Shakeproof washer hose bracket on	i	70822	24 Interest and 24 Interest models
	Nut (\frac{15}{16}" U.N.F.) chassis frame	i	254811	
	Clip for L.H. front brake pipe	i	508565	
	Bolt (2 B.A. x ½" long)	1	,	>2½ litre Petrol, 2 litre and 2½ litre Diesel models
	Plain washer Fixing clip	1	2226	24 nue i ettoi, 2 nue and 24 nue Diesei models
	Nut (2 B.A.)	1	2247	
11	Hose complete for front wheels, GI 3700628W	2	268341	
12	Hose complete to rear axle, GI 3700628W	1	268341	88
12	Hose complete to rear axle, GI 3700631W	1	235208	109
13	Joint washer for hoses, GI 378702	2	233220	107
14	Shakeproof washer, GI 76-BS-27 \ Fixing hos		233305	
15	Special nut Special nut		254852	
16	"T" piece on rear axle, GI 353201 W	1	234928	
17	Nut (16" U.N.F.)	1	254801	
18	Spring washer Fixing "T" p	iece 1	3075	
19	Set bolt $(\frac{1}{16}"$ U.N.F. $\times \frac{3}{4}"$ long)	1	255026	
20	Brake pipe to rear hose, GI 3408432W	1	279418	88
20	Brake pipe to rear hose	1	279452	109
21	Brake pipe, L.H. rear to "T" piece, GI 3307310	/ NY/ I	241696	88
22	Brake pipe, R.H. rear to "T" piece, GI 3304210		241695	88
2,20	Brake pipe, L.H. rear to "T" piece, GI 3404410	100/1		109)
	Brake pipe, R.H. rear to "T" piece, GI 3307510	\\ \ \\	246233	Series II models
	Brake pipe, L.H. rear to "T" piece, GI 3307510	NY 1	F0100F4	11005
	Brake pipe, R.H. rear to "T" piece, GI 3304410	NY 1	531906*	Series IIA models
23	Clip, brake pipes to chassis frame		a 41379	107)
25 25	Clip, brake and clutch pipes to dash		d 503204	I UD
23	Clip fixing pipe to steering box stiffener bracke		513940	R.H.D.
		As require		K.11.D.
	Screw (2 B.A. x ½ long) > Fixing clips	As require	_	
	Shakeproof washer	=		L.H.D.
	Nut (2 B.A.)	As required	- 1	CL.11.L.
26		As required	_	
20	Clip on rear axle for L.H. pipe Clip Fixing brake pipe	I	11820 56666	
		i 1	06860	
	_			
	Bolt (2 B.A. x 1½" long) > cylinder to 5-way Plain washer piece to dash	1	234603	
	• · · · · · · · · · · · · · · · · · ·	1	2678	
	Spring washer when no bleed	1.	30 7 3	
	Nut (2 B.A.) J screw is fitted	1	2247	


HAND BRAKE LEVER, R.H.D.



HAND BRAKE LEVER, R.H.D.

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
-	HAND BRAKE LEVER ASSEMBLY	1	500249	Straight type
	HAND BRAKE LEVER ASSEMBLY	1	508581	Cranked type
1	Hand brake lever	· 1	500253	Straight type >Alternative types.
	Handbrake lever	1	503468	Cranked type Check before ordering
2	Plunger rod	1	500252	Straight type
	Plunger rod	1	503467	Cranked type
3	Washer for plunger spring	1	242109	
4	Spring for plunger rod	1	58702	
5	Plunger	1	242108	
6	Split pin fixing rod to catch	1	2388	
7	Ratchet for hand brake	1	218382	
8	Locating plate	1	01384	
9	Bolt (¾ x 1¾ long) Fixing	1	237179	
10	Plain washer > locating plate and	1	2210	
11	Nut $\binom{3''}{8}$ lever to ratchet	Ī	2827	
12	Brake catch	1	50235	
13	Pin	1	07164	
14	Plain washer > Fixing catch to lever	3	2210	
15	Split pin J	1	2392	
16	Fulcrum pin for hand brake	1	231318	
17	Spring washer Fixing	Ī	2290	
18	Plain washer pin to ratchet	Ī	2218	
19	Split pin J and lever	Ī	2974	
20	Bolt (3" U.N.F. x 3" long) Fixing	2	255046	
21	Spring washer hand brake	2	3076	
22	Nut (§" U.N.F.) J lever	2	254812	


HAND BRAKE LEVER, L.H.D.



HAND BRAKE LEVER, L.H.D.

					DIVAIN	_		, L.II.D.	
PLATE REF.	1 2 3 4	DESCRIPT	ION		Qt	у.	Part No.		REMARKS
_	HAND BRAK				22.	1	500250	Straight type	}
	HAND BRAK	Œ LEVER A	SSEMI	3LY	****	1	508582	Cranked type	
	Hand brake	lever and cros	s shaft			1	500461	Straight type	Alternative types.
	Hand brake	lever and cros	s shaft			1	503471	Cranked type	Check before ordering.
l	Hand brak	ke lever			****	1	500254	Straight type	
	Hand brak	ke lever		••••		1	503469	Cranked type	J
2	Cross shaf	t for hand bra	ıke			1	218402		•
3.	Pin fixing	lever to shaft		•		1	50472		_
4	Plunger rod	****				1	500252	Straight type	Alternative types.
	Plunger rod					1	503467	Cranked type	∫ Check before ordering.
5		olunger spring	Ī			1	242109		-
6	Spring for pl	lunger rod				1	58702		
7	Plunger	••••	· •			Ī	242108		
8		ng rod to cate	:h	•:		ĺ	238 8		
9	Ratchet for h			•••	•	Ī	218407		
10	-	cross shaft be	-	•-		2	217983		
11		aring for cross				1	217984		
12	Felt ring for			••••		2	217985		
13	Distance pied		ixing			2	218410		
14	Spring washe		earing a			2	3075		
15		x 7 long) h	ousing i	to rate	het 2	2	237161		
16	Locating plat			••••	****	!	01384		
17	Bolt (\frac{3}{8}" x 1\frac{1}{8}		xing		1	1	237179		
18 19	Plain washer Nut (§")		ating pla		1	1	2210 282 7		
20		between lever	er to rat			1	2310		
21	Brake catch	berween teve	r and ra	tcnet		! !	50235		
22	Pin			••••	,	1 1	07164		
23		Fixing cate	h to leve	a e *		3	2210		•
24	Split pin	Tixing cate	n to ieve	-1	•) 1	2392		
25		ر brake adjuste	er rod			1	218408		
26		Fixing pin		••••		1	2208		
27		cross shaft				1	2392		
28	Support plate f			z hous	ing	1	218409		
29	Bolt (3" x 3" lo			,		2	237178		
30	Spring washer					2	3076		
31	Nut (3")		sis fram			2	2827		
32	Housing for cre					2	217983		
3 3	Spherical beari	ng for cross sl	haft			1	217984	-	
34	Felt ring for be	earing				2	217985		
35	Distance piece) F	ixing l	housing 2	2	218410		
3 6	Spring washer					2	3075		
3 7	Set bolt (5 " U					2	250523		
3 8	Bolt (¾" U.N.F	. x 7/ long)	_			2	255046		
39	Spring washer		≻hand l	orake		2	3076		
4 0	Nut (3" U.N.F	ر (:)	lever		•	2	254802		
		_							


HAND BRAKE, TRANSMISSION



HAND BRAKE, TRANSMISSION

PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
KEF.	Spindle for hand brake relay lever		1	240829	88
•	Spindle for hand brake relay lever		1	267193	109
2	Bolt (\frac{3}{8}" U.N.F. x 4" long) \rightarrow Fixing		2	256253	
2	Plain washer >spindle to		2	2210	
3	Nut (¾" U.N.F.) chassis frame		2	252162	
4	RELAY LEVER ASSEMBLY FOR HAI	ND			
,	BRAKE		1	238180	
5	Bush for relay lever		1	218386	
6	Plain washer \ Fixing lever		1	3299	
7	Circlip to spindle		1	09203	
8	Brake rod, relay to hand brake lever		1	277921	R.H.D.
	Brake rod, relay to hand brake lever		1	278020	L.H.D.
9	Cl ()		1	275199	
	Clevis pin complete Fixing brake rod		1	216421	
10	Lackmut (5" LINE) to relay and		3	254801	
11	Split pin hand brake lever		2	2392	
12	Anchor plate, transmission brake		1	219002	
13	Spring washer \ Fixing anchor plate to		4	3076	
14	Nut (\frac{3}{8}") \int \text{speedometer housing}		4	2827	
15	BRAKE SHOE ASSEMBLY, BOXED PAI	R	1	264374	
16	Lining complete with rivets, for shoe, GI 34	920	2	219007	
17	Pull-off spring for brake shoe, GI GB 2478	••••	2	219023	
18	Adjuster housing, GI GB 1398		1	219010	
19	Spring washer \ Fixing		2	219025	
20	Set bolt \int \int \text{adjuster housing}		2	219024	
21	Plunger R.H., GI GB 1399		1	219011	Up to gearboxes numbered:
22	Plunger L.H., GI GB 1399 A	•	1	219012	· 146000565
23	Adjuster cone, GI GB 522		1	219013	156000430
24	Expander housing	••••	1	230741	151005187
25	Special washer		2	219022	
26	Spring washer Fixing expander housing		2	219027	
27	Simmonds nut		2	232361	
28	Expander cone, GI GB 1404]	219021	
29	Pin fixing cone to brake rod, GI GB 67	••••	1	219017	
30	Roller for expander, GI GB 535	••••	2	219018	
31	Plunger for expander, GI GB 1403		2	219019	
3 2	Split pin fixing plunger		4	219020	
33	Brake rod, expander to relay lever		1	218391 <i>]</i> 515365	
34 25	Anchor plate, transmission brake GI 64270168	·	1	3076	
35 36	Spring washer Fixing anchor plate to Nut (\frac{3}{3}" B.S.F.) Speedometer housing		4	2827	
36		ID	4	2023	
37	BRAKE SHOE ASSEMBLY, BOXED PA GI GB47989AY	111,	1	516031	From gearboxes numbered:
38	GI GB4/989AY Lining complete with rivets for shoe GI GB4	7602		515455	146000566
39	Pull-off spring, expander end		_	J 1 J T J J	- 156000431
27		ake	1	515464	151005188 onwards
40	Return spring, adjuster end GI GB40655 sh		i	515465	151005100 OHARIUS
41	ADJUSTER UNIT ASSEMBLY, GI GB49		1	515925	
71	Repair kit for adjuster unit GI SP1856		i	515924	•
42	Nut $(\frac{1}{4}"$ U.N.F.) \(\begin{array}{c}\) Fixing	••	2	254800	
43	Shakeproof washer adjuster unit		2	515463	
1.5	Summing of transfer of the same		_		,

HAND BRAKE, TRANSMISSION



HAND BRAKE, TRANSMISSION

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS	
44	EXPANDER UNIT ASSEMBLY GI 64270170) 1	515366	
		1	515923	
45		1	515927 From gearboxes numbered:	
46	Brake rod, expander to relay lever GI 64270172	2 1	515926 } 146000566	
47	Dust cover for expander unit GI GB46278	1	515466 156000431	
	Packing plate	1	515470 151005188 onwards	
49	Locking plate Fixing expander unit	1	515467	
50	Retaining spring	1	515468	
51	Clevis complete Fixing	1	215809	
52	Locknut $\binom{5}{16}$ brake rod to	1	2828	
53	Split pin relay lever	1	2392	
54	Dust cover for brake rod, GI GB 2501	1	219028	
55	Return spring for brake rod	1	59663	******
56	Anchor for spring	2	240708 1 off from gearboxes numbered 14 156000431, 151005188 onwards	6000566,
57	Anchor for spring, on transfer box	1	267412 From gearboxes numbered 146000566, 1 151005188 onwards	56000431,
58	Brake drum	1	274423	
59	Self-locking nut (5 B.S.F.) fixing brake drun and damper		251321	
60	Transmission damper at rear end of gearbox .		275239 109 Diesel	




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
REF.	Chassis frame		278666 88
'		I	278664 109
1	Chassis frame	1	273585
2	Front bumper Bolt (\frac{3}{8}" U.N.F. x 4" long) \int \text{Fixing front}	1 4	256253
		8	3822
	Plain washer Self-locking nut (\frac{3}{8}" U.N.F.) chassis frame		252162
	Bolt (\(\frac{8}{2}\)" U.N.F. x 2\(\frac{1}{2}\)" long) \(\frac{1}{2}\) Fixing towing	=	256323
	Nut ($\frac{8}{8}$ " U.N.F.) attachment by		254816
Á	Road spring complete, front, Driver's	1	229207)
4	Road spring complete, front, Driver's Road spring complete, front, Passenger's	I	238208 88 Petrol models, 2 litre
	Road spring complete, front, Priver's	1	2/12835
	Road spring complete, front, Passenger's	1	242863 88 Petrol models, 21 litre
	Road spring complete, front, Priver's	I	265627)
	Road spring complete, front, Passenger's	1	264563 109 Petrol and 88 Diesel models
	Road spring complete, front, Driver's	1	276024)
	Road spring complete, front, Passenger's	1	265627 109 Diesel models
5	Main leaf \ For front	2	2/21217
6	2nd leaf spring	2	243122 88 Petrol models, 2 litre
U	Main leaf \ For front	2	2/3125
	2nd leaf spring	2	243126 88 Petrol models, 2½ litre
	Main leaf \ For front	2	245.450)
	2nd leaf spring	2	265460 109 Petrol and Diesel, and 88 Diesel models
. 7	Bush for front spring	4	233573
8	Dowel and nut for front spring	2	243129 88 Petrol models, 2 litre
Ť	Dowel and nut for front spring	2	243131 88 Petrol models, 2½ litre
	Dowel and nut for front spring	2	265461 109 Petrol and Diesel and 88 Diesel models
9	Bolt $(\frac{3}{8}'' \times 3\frac{1}{2}'' \text{ long}) $ For	2	250551
	Nut $\binom{3}{8}$	2	2827
10	Road spring complete, rear, Driver's	1	241445† > 88 models
	Road spring complete, rear, Passenger's	1	241446† 500 models
	Road spring complete, rear, Driver's	1	517588 †† \
	Road spring complete, rear, Passenger's	1	51/589 TT
	Road spring complete, rear, Driver's	1	279678 109
	Road spring complete, rear, Passenger's	1	2/96/9)
11	Main leaf	2	243123
12	2nd leaf ∫spring	2	243124)
	Main leaf \ For rear	2	501390
	2nd leaf ∫spring	. 2	501391)
13	Bush for rear spring	4	
14	Dowel for rear spring	2	
	Dowel for rear spring	2	
15	Bolt $(\frac{3}{4}$ " x $3\frac{1}{2}$ " long) For	4	
17	Nut $\binom{8}{8}$ \int spring clip	4	
16	Shackle plate, tapped For front	2 2	
17	Shackle plate, plain Springs	2	
18 19	Shackle plate, tapped \ For rear Shackle plate, plain \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	2	
17	Shackle plate, plain springs Shackle plate, tapped For rear	2	279969)
	Shackle plate, plain springs	2	
20	D. I. S. C. L. C. L. C. L. L. L. L. L. L. L. L. L. L. L. L. L.	4	
21	Bush in chassis frame, rear	2	
ا ک	radii iii dimoso iimiid, idai ,	2	

Note: Part numbers of road springs are stamped on underside of 3rd or bottom leaf.





PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
22	01 11 1 6 1 1 6	2	270741
23	~ 1 11	4	233625
2 <i>3</i> 24	0.1(1.1) . (1/0.1)	4	251324
2 4 25			236969
		2	270741
26 27		,	251324
27	2 //	1 1	2640227
20		l 1	264023 88 Petrol models
28	200000 Prints 111 111 11 11 11 11 11 11 11 11 11 11	I	261466
		1	264467 109 Petrol and Diesel and 88 Diesel models
20	,	l	531080*
29	"U" bolt	1	526812* >88 Petrol models
30	"U" bolt "U" bolt	2	531082* 66 1 etroi models
		- 3	526812 ★ う
	"U" bolt "U" bolt >Fixing front springs to axle	ر ۱	526811* \ \ 88 Diesel models
		3	526812 * ∫
	"U" bolt "U" bolt	i	526811* > 109 Petrol and Diesel models
21	L L	4	234734
31	Locker	8	2836
32	Nut $(\frac{7}{16}'')$	1	264020)
22		I	264020 264021 \}
33	Bottom plate for rear spring, R.H.	2	265642 109
24	Bottom plate for rear spring		526810*
34 ac	"U" bolt Fixing	4 4	234734
35	Locker rear springs	8	2836
36	Nut $(\frac{7}{16}'')$ to axle	1	243038
27		1	243039
37	F-1 - 7	2	06860
38	2	2	56666
39		2	234603
	Bolt (2 B.A. x ½" long)	2	3073
	Spring washer Fixing clip to shield	2	2247
40	Nut (2 B.A.)	1	237100 \ 20
40	Check strap for rear axle, R.H.	1	274469 \ 88
	Check strap for rear axle, L.H.	/	270,000 1059,00 1.1
	Check strap for rear axle, R.H.	I	278698 2 off on 1961 models onwards
41	Check strap for rear axle, L.H.	1	219574
41	Plate for check strap Set bolt (\frac{2}{3}" U.N.F. x \frac{2}{3}" long)\ Fixing check st	4 tran 8	255245
42 43	Spring washer to chassis fram		3076
45 44		4	241380
44 45	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long) Fixing buffers	8	255007
	Self-locking nut (4" U.N.F.) to chassis frame	_	252210
46	Shock absorber, front	2	501444) 00
48	Shock absorber, rear	2	501445 (88
+10	Shock absorber, front	2	502532
	Shock absorber, rear	2	276937 \ 109
49	Rubber bush for shock absorbers	16	243057 12 off on 109
50	D. I. (7" IINE - 61" lang)	4	253817 2 off on 109
JU	Bolt (4" IINF x 71" long) Fixing	2	253826 109
51	Plain washer Snock	4	243022
52	Self-locking nut $(\frac{7}{16}"$ U.N.F.) absorbers	4	252163
JL	Plain washer Fixing shock absorber	4	264024)
	Split pin Sat bottom	4	264024 4063 2 off on 109
	Opin pin g at bottom	7	.500)



ĎI ATTE	CHASSIS FRANCE, ROAD	SI KII	"
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
	Guide washer	4	508895
	Retainer for washer Fixing rear	4	500746 \ \ 109
	Rubber pad shock absorber		508896
	Self-locking nut ($\frac{1}{2}$ " U.N.F.) \int at bottom	2	252164)
53	Lifting handle, rear	2	300816
54	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ long) Fixing	8	255226
55	Spring washer handles to	8	3075
56	Nut (5" U.N.F.) chassis frame	8	254801
57	Battery casing and air cleaner support]	267022 2 litre Petrol models
	Battery casing and air cleaner support]	509867 2 litre Diesel and 21/4 litre Petrol models
	Battery casing and air cleaner support]	526756 2½ litre Diesel models
	Battery carrier, L.H]	273598 1958 2 litre Diesel 88
	Battery carrier, L.H.]	500999 1959-61 2 litre Diesel 88
	Battery carrier, L.H	1	501006 2 litre Diesel 109
58	Rubber strip for battery	4	77630 8 off on Diesel models
	Bolt (\frac{1}{4}" U.N.F. x \frac{5}{8}" long \rightarrow Fixing	5	255206
	Fan disc washer battery casing	2	510170
	Spring washer and support	4	3074
	Nut (¼" U.N.F.) to chassis frame	5	254810
	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ long) Fixing	3	255026
	Plain washer L.H. battery	3	2249
	Shakeproof washer carrier to	4	70822
	Nut $\binom{5}{16}$ "U.N.F.) \int chassis frame	3	254801 271155 98 2 1 1 1 1 1
	Valance for battery support, L.H.	1	271155 88 > 2 litre Diesel models - 279800 109
	Valance for battery support, L.H	I	234603
	Bolt (2 B.A. x ½" long) Fixing Plain washer valance to	4 4	2226
	Plain washer Nut (2 B.A.) valance to battery support	4	2227
59	Battery cover at frame or seat base	i	236986 2 off on 2½ litre Diesel models
22	Wing nut for air cleaner support	I	250431
60	Battery fixing rod	2	270420
61	Wing nut Fixing	2	250431
01	Plain washer battery	2	2876
	Battery fixing rod, seat base	2	526769* 2½ litre Diesel models
	Battery cover, L.H. of frame	1	271163 \
	Battery fixing rod, L.H. of frame	2	271163 2 litre Diesel models
	Nut (½" B.S.F.) Fixing battery,	2	2823)
	Wing nuts \L.H. of frame	2	250431 > Diesel models
	Plain washer or seat base	2	2876
	Engine mounting, front, R.H.	1	272506
	Engine mounting, rear, L.H.	1	272498
	Engine mounting, rear, R.H	1	272501
	Bolt (% U.N.F. x % long) Fixing	2	255045
•	Plain washer front mounting	2	2251
	Spring washer to chassis	2	3076 Diesel and 21 litre Petrol models
	Nut (3" U.N.F.) frame	2	254802
	Bolt (3" U.N.F. x 1" long) \(\) Fixing	4	255047
	Plain washer rear mounting	4	2251
	Spring washer to chassis	4	3076
	Nut (₹ U.N.F.) ∫ frame	4	254802
	Suspension rubber for engine, front	2	277513 Diesel models
			·





PLATE	1224 DECOMPTON				D . NT		DEL CARICO
PLATE REF.			Qt	•	Part No.	n	REMARKS
62	Suspension rubber for engine, fro	nt	2		526777	Petrol models	1011 5 1
	Plain washer, large Fixing	1.1		4	2851		1 2½ litre Petrol models
	Plain washer, small suspension	rubber		2	2251	Diesel and 2½ litre	Petrol models
	Spring washer to engine			4	3076		
	Nut $\binom{3''}{8}$ and chassis		4		2827		
	Suspension rubber for engine, rea			2	272191	D: 1 1011:	D. 1 11
	Self-locking nut (3" B.S.F.) fixing	rear suspen			25 1222	Diesel and 21 litre	Petrol models
62		••••	4		251322		
63 64	Bolt $(\frac{7}{16}"$ B.S.F. x $3\frac{1}{4}"$ long) rear Plain washer, top			2 2	274997 04799		
65	Rubber washer	Fixing		2	50052		
66	Distance tube	engine unit			274996		
67	Top rubber	≻to chassis		2		-2 litre Petrol mode	do
68	Bottom rubber	frame at		2	04788	2 mie i enoi mode	:18
69	Shim	front and	As regi		•		
70	Special nut	rear		2	240418		
-0	Split pin			2	2981		
	Road wheel, well base rim type		5		231601		
	Tyre 6.00" x 16", Dunlop R.K.3				239742	-88	,
	Inner tube 6.00" x 16"		5		232122		•
	Road wheel, well base rim type		5		272309		
	Tyre, 7.50" x 16" Dunlop R.K.3 of	or Avon T.M			278434	-109	
	Inner tube, 7.50" x 16"	•••	5	5	270324		
	Road wheel, well-base rim type 5.	50" x 16"	5	5	2723091	•	
	Road wheel, detachable rim type	****	5	5	217267		
	Special bolt and nut for detact	chable rim t	type		}	Optional on 88 mo	dels
	wheel		8	3	243471		
	Rim band for detachable rim type		5	5	232053		
	Tyre 6.00" x 16", Dunlop T 28 tr		5	5	232121		
	Tyre 6.50" x 16", Dunlop "Cross	country", T		_			
	tread		5	5	232559		
	Tyre 7.00" x 16", Dunlop "Cross	country, T		_	0.400 (1.1		
	tread		5		242861	0 .: 1 .00	1 1
	Tyre 7.00" x 16", Dunlop curved b					Optional on 88 mo	dels
	Tyre 7.00" x 16", Dunlop RK3 or	Avon 1 IVI	5	, :	248806		
	Tyre 7.00" x 16", Dunlop "Fort" Sand tyre 7.00" x 16"	• • • •	🤉	,	233041 244298		
	I (#0# 1/#		5		232560		
	Inner tube 6.50" x 16", Dunlop "I	Fort"	5		233042		
	Tyre 7.50" x 16" Dunlop RK3 or		-		278434 † †	.	
		Avon Tivi			270324 †		
	Tyre, 7.50" x 16", Michelin XY	****			511878*	· `	
	Inner tube		. 5		511879*	Optional Extra o	on 109 models
	Tyre, 7.50" x 16", Dunlop "Roadt				272310	,	
	Tyre, 7.50" x 16", Dunlop T29A		5			Optional on 109 m	odels
	Tyre, 7.50" x 16", Dunlop Gold S				502526	- p	
	Sand tyre 8.20" x 15"	-	-		264643)	
	Inner tube 8.20" x 15" \ For		5		264644	Optional	
	Road wheel sand tyre	.	5		502026*	j .	
	Balance weight for road wheel		e As requ	uired	263142	-	
		rim type					
		road wheel	As requ		3850		
	Nut for road wheel		20)	217361		

^{1 2 3 4}


^{*} Asterisk indicates a new part which has not been used on any previous model.

[†] Optional on 88 models when Dunlop RK3 or Avon TM 7.50" x 16" tyres are fitted.

⁷⁷ Optional on 88 models when road wheels 272309 are fitted.



	CLOTCH AND	DIVINE	TEDALS AND THES
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
-	BRAKE PEDAL AND BRACKET ASSE	MBLY 1	272737 All 109. Up to vehicles numbered on 88:
			141102873, 142101568, 144103476 Petrol models
			146100972, 147100215, 149100343 Diesel models
	BRAKE PEDAL AND BRACKET ASSEM	MBLY 1	523916* 88 From vehicles numbered:
			141102874, 142101569, 144103477 onwards
			Petrol models
			146100973, 147100216, 149100344 onwards
			Diesel models
	Bracket for brake pedal	1	272632) All 109. Up to vehicles numbered on 88:
	Brake pedal and bushes	1	272845 \(\) 141102873, 142101568, 144103476 Petrol models
			146100972, 147100215, 149100343 Diesel models
	Bracket for brake pedal	1	523695* \ 88. From vehicles numbered:
	Brake pedal and brushes	1	523696* \$\int 141102874, 142101569, 144103477 onwards
		•	Petrol models
	•		146100973, 147100216, 149100344 onwards
			Diesel models
	Bush for pedal	2	272714
	Grommet for brake pedal bracket	1	509970
	Distance piece for pedal trunnion	1	269783
	Trunnion for pedal	1	269784
	Shaft for pedal	1	272712
	Pin locating pedal shaft	1	50446
	Oil plug	4 ₍	255202
	Joint washer for oil plug	1	3052
	CLUTCH PEDAL AND BRACKET		
	ASSEMBLY	1	272738 R.H.D.
	CLUTCH PEDAL AND BRACKET		
_	ASSEMBLY] -	272737 L.H.D.
2	Bracket for clutch pedal	I	272632
3	Clutch pedal and bushes	!	272846 R.H.D.
	Clutch pedal and bushes	I	272845 L.H.D.
4	Bush for pedal	2	272714
5	Distance piece for pedal trunnion	.,,, I	269783
6	Trunnion for pedal	I	269784
7	Shaft for pedal	l	272712
8 9	Pin locating pedal shaft Oil plug	1	50446 255202
10	Link and how for all along	I	3052
11	D.1 1 1 CL (40/7720	, 1	·520849 88
''	D 1 . 1: 1 CI (40(772)	1	520850 109
	End cap and spacer for brake master cylin	dor I	516410 88
	End cap and spacer for brake master cylin		523084 109
12	Clutch master cylinder, GI 3110366W	1	.274841
13	Nut for master cylinder push rod	4	254801
	Plain washer for push rod	4	4148
14	Bolt (5 U.N.F. x 13 long) Fixing mast		255029
15	Plain washer >cylinder to	4	2249
16	Self-locking nut (% U.N.F.) pedal bracke		252211
17	Bolt (‡" U.N.F. x ‡" long) \ In bracket for	2	255007
18	Nut (‡" U.N.F.) pedal stop	2	254800
		. –	



ATE EF.	1 2 3 4 DESCRIPTION Qu	ty.]	Part No. REMARKS
9	Gasket for pedal bracket top cover	2	272819
0.	Top cover for pedal bracket	1	272713
21		1	277840 All 109. Up to vehicles numbered on 88: 141102873, 142101568, 144103476 Petrol model 146100972, 147100215, 149100343 Diesel model
	Pedal bracket top cover and reservoir tank support	1	517907 88. From vehicles numbered: 141102874, 142101569, 144103477 onwards Petrol models
			146100973, 147100216, 149100344 onwards
			Diesel models
2	Drive screw fixing top cover to bracket 1		78227
3	Gasket for pendant pedal brackets	2	272820
4		1	272730
5	Bolt $(\frac{5}{16}"$ U.N.F. x $\frac{2}{8}"$ long) \int Fixing pedal 1	2	255027
6	Plain washer >bracket and 1	2	2223
7	Spring washer Janchor to dash 1	2	3075
8	Clutch and brake pedal return spring	2	272729
	Clutch and brake reservoir tank and pipe	1	504135** R.H.D.
	Clutch and brake reservoir tank and pipe	1	504136** L.H.D.
9	Clutch and brake reservoir tank, GI 64047214	1	504105††
	Filter for clutch and brake tank GI 64473410	1	518682††
	Sealing washer for filter GI 362920	1	264767††
	Filler cap for supply tank GI 378434	1	500201††
)	Clip for reservoir tank	1	217636
1	Screw (2 B.A. x 2" long) Fixing clip	1	78214
2	Nut (2 B.A.) to tank	1	2247
3	Bolt (1" U.N.F. x 3" long) \(\) Fixing	1	255006
4	Spring washer >tank clip to	1	3074
5	Nut (1" U.N.F.) mounting bracket	1	254800
6	Pipe complete, reservoir tank to brake master		
	cylinder	1	504106†
	Banjo, GI 352201W	1	216909†)
	Banjo bolt, GI 376207W Fixing pipe to brake	1	267601† }L.H.D.
	Gasket, small, GI 378700 master cylinder	1	216914†
	Gasket, large, GI 1378731	1	504104†]
7	Pipe complete, reservoir tank to clutch master		
	cylinder	Ĭ	277929 R.H.D.
	Pipe complete, reservoir tank to clutch master		
	cylinder	i	278471 L.H.D.
3	Pipe complete, clutch master cylinder to hose	1	277930 R.H.D.
	Pipe complete, clutch master cylinder to hose	1	512839 L.H.D.
9	Hose, pipe to clutch slave cylinder GI 3700627W	1	268493
0	Gasket for hose at slave cylinder GI 378711		233220
1	Mounting bracket for hose		277303
2			234603
3	and the second of the second o	2	3073
4		2	2247
5	Shakeproof washer Fixing hose		233305
6	Special nut GI 10233 to bracket		254852
			•

	1 2 3 4	4	Asterisk indicates a new part which has not been used on any previous model.						
**	Up to vehicles	numbered:			# From vehicles	numbered:			
	141800001	146800001	151800001	156800001	141800001	146800001	151800001	156800001	
	144800271	149800059	154800036	159800007	1 44800272	149800060	154800037	159800008	
	142800375	147800125	152800114	157800018	142800376	147800126	1 52800115	157800019	

For vehicles prior to these supply part number 504135 for R.H.D. models and part number 504136 for L.H.D. models.





PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
47	Support bracket for clutch slave cylinder	1	272487	2 litre Petrol models
	Support bracket for clutch slave cylinder	1	509856*	Except 2 litre Petrol models
48	Clutch slave cylinder GI 3010228W	1	266694	•
49	Bolt $(\frac{5}{16}"$ U.N.F. x 1" long) \int Fixing slave	2	255028	
50	Spring washer >cylinder to	2	3075	
51	Nut (16" U.N.F.) support bracket	2	254801	
52	Push rod for clutch slave cylinder GI 399402W	1	502032	
53	Clevis for push rod	1	275199	
54	Locknut (5 U.N.F.) for push rod	1	254801	
55 -	Shaft and operating lever for clutch	1	273061	2 litre Petrol models
	Shaft and operating lever for clutch	1	273077	Except 2 litre Petrol models
56	Spherical bearing	1	217984	•
57	Housing for spherical bearing	2	217983	
58	Felt ring for spherical bearing	2	217985	
59	Bolt ($\frac{5}{16}$ " U.N.F. x $\frac{3}{4}$ " long) Fixing spherical		255026	
60	Spring washer bearing to	2	3075	
61	Nut (16" U.N.F.) support bracket	2	254801	
62	Clevis pin, lever to fork end	1	216421	
63	Split pin for clevis pin	1	2392	
64	<u> </u>	1	217979	
65	Pin Fixing tube to	2	521771	
66	Plain washer >clutch cross and	2	10882	
67	Split pin Joperating shafts	2	2422	
68	Return spring for clutch operating lever	1	278690	
	Anchor plate for return spring at slave cylind	ler		
	support bracket	1	272920	Except 2 litre Petrol models


ACCELERATOR LEVER AND RODS, 2 LITRE PETROL



ACCELERATOR LEVER AND RODS, 2 LITRE PETROL

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	Housing for accelerator shaft and pedal stop		277103	
2	Bolt (1" U.N.F. x 1" long) Fixing housing	2	255204	
3	Spring washer and pedal stop	2	3074	
4	Nut (†" U.N.F.) to dash	2	254800	
5	Bracket for accelerator pedal shaft	. 1	272804	
6	Bolt (1" U.N.F. x 5" long)	2	255006 R.H.D.	·
	Bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long) \rightarrow Fixing bracket	2	255007 L.H.D.	
7	Spring washer to dash	2	3074	
8	Nut (‡" U.N.F.)	2	254800	•
9	Shaft for accelerator pedal	. 1	236658	
10	Accelerator pedal	. 1	500257	
	Pad for accelerator pedal	. 1	509463* L.H.D.	
11	Bolt (5 U.N.F. x 7 long) Tixing pedal	1	255027	
12	Nut $\binom{5}{16}$ U.N.F.) \int to shaft	1	254801	
13	Bolt ($\frac{5}{16}$ " U.N.F. x $2\frac{1}{2}$ " long)	1	255038	
14	Plain washer > Pedal stop in floor		2258	
15	Nut $\left(\frac{6}{16}^{\circ} \text{ U.N.F.}\right)$	2	254801	
16	Bracket for accelerator cross shaft		236665 R.H.D.	
	Bracket for accelerator cross shaft		236998 L.H.D.	
17	Bolt (½" U.N.F. x §" long) \rightarrow Fixing	2	255006)	_
18	Spring washer bracket	2	3074 >4 off on L.H.	D.
19	Nut (‡" U.N.F.) to dash	2	254800	
20	Cross shaft for accelerator	1	277153 R.H.D.	
	Cross shaft for accelerator	1	277154 L.H.D.	
	Stop clip for cross shaft	. 2	269132 L.H.D.	
21	Distance washer for lever	. 2	3680	
22	LEVER ASSEMBLY FOR ACCELERATOR	2	277105	
23	Ball end for lever	. 2		
24	Bolt (‡" U.N.F. x 1\frac{1}{8}" long) \int Fixing levers and		256000) 25 4000 > 4 off on L.H.	.D.
25	Nut (4" U.N.F.) Stop clip to shaft	2	254800 J	
26	LEVER ASSEMBLY FOR CROSS SHAFT	. 1	278079	
27	Ball end for lever	l	1481	
28	Bolt (\frac{1}{4}" U.N.F. x 1\frac{1}{8}" long) \int \text{Fixing lever}	!	256000	
29	Nut (4" U.N.F.)	!	254800	
3 0	Control rod pedal shaft to cross shaft		509556	
31	Control rod, cross shaft to engine	4	277983	
32	Ball joint socket for rods		1659	
33	Locknut for socket	4	2247	
34	Return spring for throttle	-	272729 277455	
35	Return spring for pedal	1	411 4 33	


ACCELERATOR LEVER AND RODS, 21 LITRE PETROL



ACCELERATOR LEVER AND RODS, 21 LITRE PETROL

	<u> </u>	7111	o kods, 24	THINE	FEIROL
PLATE REF.	1 2 3 4 DESCRIPTION Q	ty.	Part No.		REMARKS
1	Housing for accelerator shaft and pedal stop	1	277103		
2	Bolt $\binom{1}{4}$ U.N.F. x $\frac{1}{2}$ long) Fixing housing	2	255004		
3	Spring washer and pedal stop	2	3074		
4	Nut (¼" U.N.F.)	2	254800		
5	Bracket for accelerator pedal shaft	1	272804		
6	Bolt (½" U.N.F. x ½" long)	2	255006		
_	Plain washer Fixing bracket	2	2224		
7	Spring washer to dash	2	3074		
8	Nut (‡" U.N.F.)	2	254800		
9	Shaft for accelerator pedal	1	236658 R.H.D.		
	Shaft for accelerator pedal	1	277153 L.H.D.		
	Special washer On accelerator	1	508962		
10	Plain washer		2257		
10	Accelerator pedal ACCELERATOR PEDAL RESTRICTOR KIT	1	500257 516057	`	
	Accelerator restrictor lever complete	1	509407		
	Spring, accelerator restrictor	1	264362		÷
	Control rod, pedal shaft to cross-shaft	1	509556		
	Control rod, relay shaft to engine	1	509558		
	Stop clip for relay shaft	i	269132)	88 model	s. From vehicles numbered:
	Bolt (\frac{1}{4}" U.N.F. x 1\frac{1}{8} long) \frac{1}{8} Fixing clip	1	256000 > R.H.D.	} "	141001495
	Nut $\binom{1}{4}''$ U.N.F.) \int to shaft	1	254800		142000991
	Anchor plate for restrictor spring	1	240708		144002270 onwards
	Bolt $(\frac{5}{16}"$ U.N.F. $x \frac{1}{2}"$ long) Fixing anchor	1	255223		
	Spring washer plate to	1	3075 ≻R.H.D.		
	Nut $(\frac{5}{16}$ U.N.F.) toe board	1	254801)		•
	Bolt $\binom{1}{4}''$ U.N.F. x $\binom{1}{4}''$ long) \int Lever stop	1	255211		
	Nut ($\frac{1}{4}$ " U.N.F.) \int on toe board	2	254800	J'	
11	Bolt (16" U.N.F. x 7" long) Fixing pedal	1	255027		
12	Nut $(\frac{5}{16}"$ U.N.F.) \int to shaft	1	254801		
13	Bolt (5 U.N.F. x 18 long) Pedal	1	255029		
14	Plain washer stop in	2	2258		
15	Nut $\binom{5}{18}$ U.N.F.) floor	2	254801		
16	Bracket for accelerator cross shaft	2	236998 R.H.D.		
17	Bracket for accelerator cross shaft	2	236665 L.H.D.		
17	Bolt ($\frac{1}{4}$ " U.N.F. $x \frac{5}{8}$ " long) Fixing	4	255006		
18	Spring washer bracket	4	3074 >2 off on	L.H.D.	
19	Nut (‡" U.N.F.) to dash	4	254800		
20	Cross shaft for accelerator	1	277154 R.H.D.		
21	Cross shaft for accelerator	1	277153 L.H.D.		
21 22	Distance washer for lever LEVER ASSEMBLY FOR ACCELERATOR	2	3680 277105		
23	Ball end for lever	2	277105 1481		
25 24	Bolt (½" U.N.F. x 1½" long)	2	256001		
47	Plain washer Fixing levers	4	3911		•
25	Nut (‡" U.N.F.) to shaft	2	254800		
	11mt (4 C/11m1)	_	277000		

ACCELERATOR LEVER AND RODS, $2\frac{1}{4}$ LITRE PETROL



ACCELERATOR LEVER AND RODS, 21 LITRE PETROL

PLATE REF.	1 2 3 4 DESCRI	PTION	Qty.	Part No.	o. REMARKS
26	LEVER ASSEMBLY FO	OR CROSS SHAFT	. 1	277106	6
27	Ball end for lever		1	1481	1
28	Bolt (1" U.N.F. x 11" long	g)]	1	256001	1
	Plain washer	Fixing lever to	2	3911	1
29	Nut (‡" U.N.F.)	cross shaft	1	254800	0
3 0	Control rod, pedal shaft to	o cross shaft	1	509556	6
31	Control rod, cross shaft to	engine	1	503434	4
3 2	Ball joint socket for rods		4	1659	9
33	Locknut for socket		4	2247	7
34	Return spring for pedal		1	277455	5
	Return spring for throttle	••••	1	272729	9 88




PLATE REF.	1 2 3 4 DESCRIPTION	(ty.	Part No.	REMARKS
1	Housing for accelerator shaft and pedal stop		ī	277103	
2	Bolt (\frac{1}{4}" U.N.F. x \frac{1}{2}" long) \frac{1}{2} Fixing housing		2	255004	
3	Spring washer and pedal stop		2	3074	
4	Nut (4" U.N.F.) to dash		2	254800	
5	Bracket for accelerator pedal shaft		ĩ	272804	
6	Bolt (\frac{1}{4}" U.N.F. \times \frac{5}{8}" long)	••••	2	255006	
ŭ	Plain washer Fixing bracket		2	2224	
7	Spring washer to dash		2	3074	
8	Nut (½" U.N.F.)		2	254800	•
9	CLCC 1 - 11		1	236658	R.H.D.
,	Shaft for accelerator pedal Shaft for accelerator pedal		Ť	277153	L.H.D.
	Special washer \ On accelerator	•	1	508962	L.H.D.
	Plain washer shaft		i	2257	
10	. , , , , , , , , , , , , , , , , , , ,		1	500257	
11	Accelerator pedal Solt $\binom{5}{15}''$ U.N.F. x $\frac{7}{5}''$ long) \bigcap Fixing pedal		1	255027	
12	Nut $\binom{56}{15}$ U.N.F.) to shaft		1	254801	
13	Bolt $(\frac{16}{16}"$ U.N.F. x $2\frac{1}{2}"$ long) Pedal		1	255038	
14			1	2258	
	1 -		2		
15 16	Nut (1/6" U.N.F.) floor LEVER ASSEMBLY FOR ACCELERAT	ΩD	Z	254801	
10	ON PEDAL SHAFT	UK	1	277105	
17		•	1	277105	
17	Ball end for lever	••••	1	1481	
18	Bolt (¼" U.N.F. x 1¼" long) Plain weeker Fixing lever		1	256001	
10	to shaft		2	3911	
19	Nut (‡" U.N.F.)		ļ	254800	
20	Return spring for pedal		1	231393	•
21	Anchor for return spring		1	277592	
22	Bracket for accelerator cross shaft		2	236998	
23	Bolt (4" U.N.F. x 5" long) Fixing		4	255006	
24	Spring washer brackets		4	3074	
25	Nut (1" U.N.F.) j to dash		4	254800	
26	Accelerator cross shaft		ļ	277154	A 4 1 11 10 11
27	Stop clip for cross shaft	••••	1	269132	2 off on L.H.D.
28	Accelerator lever on cross shaft from pedal	• • • • • • • • • • • • • • • • • • • •	ı	277472	
29	Distance washer for cross shaft		2	3680	4 4 4 4 4 4 7 1
30	Bolt (¼" U.N.F. x 1¼" long) Fixing levers an	d.	3		4 off on L.H.D.
	Plain washer stop clip to		6	3911	8 off on L.H.D.
31	Nut (¼" U.N.F.) cross shaft		3	254800	4 off on L.H.D.
3 2	Control rod, pedal shaft to cross shaft	••••	Į	509556	
33	Ball joint socket For		2	1659	
34	Locknut (2 B.A.) \(\int \text{rod} \)		2	2247	
35	Control rod, bell crank to accelerator lever		1	277779	
36	Ball socket		2	1659	
37	Nut (2 B.A.) For bell crank control rod		2	2247	
38	Adjuster nut		ı	277778	
39	Return spring for accelerator and stop levers		_	05550	
	distributor pump			277502	
	Anchor for return spring		_	277565	
40	Accelerator lever on cross shaft to engine	••••	. [277612	
41	Ball end Fixing		ļ	273964	
42	Spring washer ball end to		1	3073	
43	Nut (2 B.A.) Jaccelerator lever]	2247	
44	Control rod, cross shaft to bell crank	•	1	504699*	
45	Ball joint For		2	1659	
46	Locknut (2 B.A.) ∫control rod		2	2247	






PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
47	Accelerator control lever on distributor pump	1	277553	
48	Stop lever complete on distributor pump	1	277619	
49	Swivel clamp for stop lever	1	219582	
50	Bracket for bell crank on distributor pump	1	501018	
51	Spring washer \ Fixing bracket to	4	3073	
52	Nut (2 B.A.) distributor pump	4	2247	
53	Bell crank complete on distributor pump	1	277450	
54	Bush for bell crank	1	277453	
55	Ball end for bell crank	2	1481	
56	Pin for bell crank	1	277454	,
57	Shakeproof washer \ Fixing pin to bell	1	78114	•
58	Nut ($\frac{1}{4}$ " U.N.F.) \int crank bracket	1	254800	
59	Plain washer \ Fixing bell crank	1	2208	
60	Split pin	, 1	2423	
61	"Engine stop" control	1	277478	
62	Clip Fixing control	1	239673	
63	Screw (2 B.A. x 5 long) outer cable to	1	75940	Alternatives to 3 lines below. Check before ordering.
	Bolt (2 B.A. x 7 long) Sabutment bracket	1	250962)	
	Spring washer on distributor	1	3073	Alternatives to line above. Check before ordering.
	Nut (2 B.A.) pump	1	2247	
	-		-	

HAND CONTROL, ENGINE SPEED, DIESEL




HAND CONTROL, ENGINE SPEED, DIESEL


PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y.	Part No.	REMARKS
-}	Housing for governor control quadrant		1	275706	· ·
2	Lever and ball end for control		1	275709	
3	Bush for lever		1	275714	
4	Washer for lever		1	275715	
5	Bolt $(\frac{5}{16}$ U.N.F. x 1" long) \bigcap Fixing		1	255028	
6	Plain washer control lever		1	2223	
7	Self-locking nut (5 U.N.F.) to housing		1	252211	
8	Knob for lever		1	219512	•
9	Special screw \ Fixing knob		1	219673	
10	Nut (2 B.A.) ∫ to lever		1	2247	
11	Quadrant plate		Ī	275713	•
12	Special screw		2	278386	
	Plain washer Fixing quandrant plate		2	3840	
13	Spring washer to housing		2	3074	,
14	Nut (‡" U.N.F.) \(\)		2	254800	
15	Bolt (2 B.A. x ½" long)		2	234603	
16	Plain washer Fixing control		2	3685	
17	Spring washer to dash		2	3073	
18	Nut (2 B.A.)		2	2247	
19	Operating lever for hand engine speed control		1	276013	
20	Bolt (‡" U.N.F. x 1\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\				
	long) >lever to accelerator		1	256000	
21	Nut (1" U.N.F.) cross shaft		1	254800	
22	Control rod for engine speed control		I	276014	•
23	Nut (2 B.A.) \ For .		1	2247	
24	Ball socket ∫ control rod		i	1659	
25	Joint pin		1 .	276015	
26	Plain washer > For engine speed control rod		1	2208	
27	Split pin		1	3958	
28	Nut (2 B.A.) fixing control rod to joint pin		2	2247	



	LAHAUS	1 2121	ENAT.
PLATE REF.	1 2 3 4 DESCRIPTION Qty	. Part No	REMARKS
1	Front exhaust pipe complete 1	505828	88 Diesel and 2 litre Petrol
	Front exhaust pipe complete 1	505855	
	Front exhaust pipe complete 1	505853	88 2½ litre Petrol 1958-60
2	Front exhaust pipe complete	517469	88 21 litre Petrol 1961 onwards
	Front exhaust pipe complete 1	505826	109 2½ litre Petrol 1958-60
	Front exhaust pipe complete	517632	109 24 litre Petrol 1961 onwards
3	Exhaust pipe heat shield, long 1	503310	· }
4	Exhaust pipe heat shield, short 1	503309	‡
5	Pipe clamp Fixing 4	503307	Except L.H.D. models when toe Not required on
	· • • • • • • • • • • • • • • • • • • •		box heat shields are fitted >1961 Petrol
6	Bolt (4" U.N.F. x 7 long) heat shield 8	255008	models onwards
7	Spring washer to front 8	3074	
8	Nut (4" U.N.F.) exhaust pipe 8	254810)
	HEAT SHIELD ASSEMBLY (TOE BOX) 1	516496	R.H.D. \ Also includes dipswitch lead, \
	HEAT SHIELD ASSEMBLY (TOE BOX) 1	516945	L.H.D. mounting plate and fixings
	Plain washer on rear manifold stud 1	2920	party and mange
9	Bracket exhaust manifold to heat shield 1	515506	
	Plain washer for manifold stud	2550	
10	Shield, exhaust manifold 1	515597	
11	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ long) \bigcap Fixing 1	255026	
12	Plain washer bracket to 1	2550	
13	Spring washer manifold to 1	3075	
14	Nut $(\frac{5}{16}"$ U.N.F.) heat shield 1	254811	
	Support strip, heat shield to starter motor 1	515332)
	Bolt $(\frac{5}{16}"$ U.N.F. $x \frac{3}{4}"$ long) \int Fixing	255026	
	Plain washer support strip		} 1958-60 models
	Spring washer to heat 1	3075	1735 55 11352535
	Nut $\left(\frac{5}{16}$ U.N.F.) shield 1	254811	
15	Distance washer for heat shield 1	515505	
16	Steady strip for heat shield 1	515331	≻2 1 litre
17	Bolt $(\frac{5}{16}"$ U.N.C. x Fixing steady strip,		petrol
	la" long) heat shield and	253029	models
18	Plain washer distance washer	2550	Hiodels
19	Spring washer to manifold	3075	i
20	Bolt (16 " U.N.C. x) Fixing		ì
	$\frac{7}{8}''$ long) \rightarrow heatshield and 1	253027	
21	Plain washer steady strip 1	2550	·
22	Spring washer to manifold	3075	
23	Bolt (1" U.N.F. x 78" long) \(\) Fixing 1	255003	
24	Plain washer heat shield to 1	3840	
25	Spring washer steady strip	3074	
	Heat shield for exhaust pipe	515598)	
	Bolt (\frac{1}{2}" U.N.F. x \frac{5}{8}" long \rightarrow Fixing 2	255006	
	Plain washer > exhaust pipe 2	,	≻1958-60 models
	Spring washer shield to 2	3074	
	Nut (‡" U.N.F.) manifold shield 2	254800	
	Heat shield between exhaust pipe and toe box	~	1958-60
	Pipe clamp, heat shield to pipe 2		L.H.D. models
	2 F 2 F 300 100 M		J




20	PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
23 Syring washer Fixing exhaust pipe 4 3075		· · · · · · · · · · · · · · · · · · ·			Diesel and 2 litre Petrol models
Nut (\(\hat{k}' \) E.S.F.) \(\) \(\) to manifold \(\) Spring washer \(\) Fixing exhaust pipe \(\) 1 244449 \(\) 88 Petrol models 1958 \(\) Object the models 1958 \(\) Intermediate exhaust pipe \(\) 1 26449 \(\) 88 Petrol models 1958 \(\) Object the models 1958 \(\) Intermediate exhaust pipe \(\) 1 26449 \(\) 88 2½ litre Petrol models 1958 \(\) Object the models 1958 \(\) Silencer complete \(\) 1 276141 \(\) 13 Silencer complete \(\) 1 276135 R.H.D. \(\) 13 Silencer complete \(\) 1 276135 R.H.D. \(\) 13 Spring washer \(\) Spring washer \(\) 1 Spring washer \(\) Nut (\(\hat{k}' \) U.N.F. \(\) 1 Spring washer \(\) 1 Spring washer \(\) 1 Spring washer \(\) 1 Spring washer \(\) 1 Spring washer \(\) 1 Self-locking mut (\(\hat{k}' \) U.N.F. \(\) 1 Solic (\(\hat{k}' \) U.N.F. \(\) 1 Solic (\(\hat{k}' \) U.N.F. \(\) 1 Solic (\(\hat{k}' \) U.N.F. \(\) 1 Solic (\(\hat{k}' \) U.N.F. \(\) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\(\hat{k}' \) U.N.F. \(\hat{k}' \) 1 Solic (\hat{k}' \) 1 Solic (\(\hat{k}' \) 1 Solic (\(\hat{k}' \) 1 Solic (\(\hat{k}' \) 1	27		e 4	_	
Spring washer Fixing exhaust pipe 3 253809 4 off on Diesel models 1958				,	>2 litre Petrol models
Nut (\(\frac{\cappa}{\cappa} \) Unit (\			е 3	3075 \	1 d 12
Intermediate exhaust pipe					>4 off on Diesel models
1			1		
Intermediate exhaust pipe	-00		•	0/4105	
30 Silencer complete 276135 R.H.D.	29]		
31 Silencer complete 276134 L.H.D.			}		
1 213558		<u>-</u>]		
Solit (fit "U.N.F. x 1" long) Fixing silencer to 4 255228			}		L.H.D.
Spring washer Intermediate pipe 4 3075					
36 Bolt (\frac{1}{8}' \text{U.N.F. x 1\frac{1}{2}' \text{long} \) Fixing intermediate exhaust pipe 3 254811 37 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209 Spring washer Spring pipe 1 255209					
Solicity Solicity					
Spring washer					
Nut (\frac{\chi}{\chi}'' \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \			-		
Flexible mounting, intermediate exhaust pipe 2 271465					
Clamp plate Distance piece Fixing 1 239715					
Distance piece Solt (\$\frac{1}{2}\text{U.N.F. x 1}\text{ long})			ıst pipe 2		
Bolt (\(\frac{1}{4}\)^2 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		· -	1		
Self-locking nut (\(\frac{1}{4} \) U.N.F. \) chassis 2 252220		•			
Plate for flexible mounting 2 239710					
Solt (\(\) \(\		· · · · · · · · · · · · · · · · · · ·			· .
Self-locking nut (\(\frac{1}{1} \) U.N.F. \(\frac{1}{1} \) I long Pipe clamp 2 239711					
Pipe clamp					
Bolt (\frac{\pi}{\pi} \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \					
Shakeproof washer Clamp to 2 72614					
Spring washer Spring washe					
Nut (\frac{1}{16}" U.N.F.)					
Solic (4" U.N.F. x 1" long) Fixing pipe 1 255209		• •			
Spring washer Sclamp to 1 3074				*.	
Nut (\(\frac{1}{4}'' \) U.N.F.)			-	1.	
Flexible mounting for silencer 2 271465					
Distance piece Packing plate, upper Packing plate, lower Clamp plate Bolt (\{\frac{1}{2}'' \text{ U.N.F. x 1\{\frac{1}{2}''}' \text{ long}\) Plain washer Self-locking nut (\{\frac{1}{2}''' \text{ U.N.F.}\) 55 Flexible mounting for tail pipe Clamp plate, upper Fixing flexible mounting to chassis and silencer 4 244009 chassis and silencer 4 255210 silencer 4 252220 55 Flexible mounting for tail pipe Clamp plate, upper Fixing flexible 1 239715 mounting to 2 239715 Fixing flexible mounting to 2 239715 Fixing flexible mounting to 2 239715 Fixing flexible 1 239715 mounting to 1 245926 chassis frame 1 274870 and clamp 1 239715 bracket 4 3840 Fixing flexible 1 239715 mounting to 2 239715 Fixing flexible 1 239715 mounting to 2 239715 Fixing flexible 1 239715 mounting to 2 239715 Fixing flexible 1 239715 mounting to 2 239715 Fixing flexible 1 245926 Fixing flexible 1 245926 Fixing flexible 1 239715 Fixing flexible 1 245926 Fixing flexible 1 252220 Fixing flexible 1 245926 Fixing flexible 1 274870 Fixing flexible 1 252220 Fixing flexible 1 274870 Fixing flexible 1 252220 Fixing flexible 1 239715 Fixing flexible 1 245926 Fixing flexible 1 239715 Fixing	54	1-			
Packing plate, upper Packing plate, lower Clamp plate Bolt (\frac{1}{2}" U.N.F. x \frac{1}{8}" long) Plain washer Self-locking nut (\frac{1}{2}" U.N.F.) 55 Flexible mounting for tail pipe 56 Distance piece 57 Clamp plate, upper 58 Packing plate, upper 59 Packing plate, lower 60 Clamp plate, lower 60 Clamp plate, lower 61 Bolt (\frac{1}{2}" U.N.F. x \frac{1}{8}" long) 62 Plain washer 63 Self-locking nut (\frac{1}{2}" U.N.F.) Fixing flexible 1 274870 2 239715 2 271465 Fixing flexible 1 239715 2 271465 Fixing flexible 1 239715 2 271465					≻88
Packing plate, lower Clamp plate Bolt (‡" U.N.F. x 1½" long) Plain washer Self-locking nut (‡" U.N.F.) 55 Flexible mounting for tail pipe 56 Distance piece 57 Clamp plate, upper 58 Packing plate, upper 59 Packing plate, lower 60 Clamp plate, lower 60 Clamp plate, lower 61 Bolt (‡" U.N.F. x 1½" long) 62 Plain washer 63 Self-locking nut (‡" U.N.F.) 64 Pipe clamp bracket Fixing flexible nounting to 2 239715 4 255220 5 23716 5 L.H.D. chassis and 4 255220 4 252220 Fixing flexible nounting to 2 239715 4 252220 5 271465 6 244009 Fixing flexible nounting to 2 239715 5 244009 Fixing flexible nounting to 2 239715 5 244009 Fixing flexible nounting to 2 239715 5 244009 Fixing flexible nounting to 2 239715 5 244009 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 5 244009 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 239715 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 271465 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing flexible nounting to 2 244009 Fixing f			4		
Clamp plate Bolt (\frac{1}{2}" U.N.F. x \frac{1}{8}" long) Plain washer Self-locking nut (\frac{1}{2}" U.N.F.) Self-locking nut (\frac{1}{2}" U.N.F.) Self-locking nut (\frac{1}{2}" U.N.F.) Self-locking nut (\frac{1}{2}" U.N.F.) Self-locking nut (\frac{1}{2}" U.N.F.) Self-locking nut (\frac{1}{2}" U.N.F. x \frac{1}{8}" long) Self-locking nut (\frac{1}{2}" U.N.F. x \frac{1}{8}" long) Self-locking nut (\frac{1}{2}" U.N.F.			flexible 1		
Clamp plate Bolt (\frac{1}{4}" U.N.F. x \frac{1}{8}" long) Plain washer Self-locking nut (\frac{1}{4}" U.N.F.) 4 2552220 55 Flexible mounting for tail pipe 2 271465 56 Distance piece 4 244009 57 Clamp plate, upper 58 Packing plate, upper 59 Packing plate, lower 50 Clamp plate, lower 51 Bolt (\frac{1}{4}" U.N.F. x \frac{1}{8}" long) 56 Plain washer 4 3840 67 3840		racking plate, lower	ng to	L L	
Solf (\frac{1}{2}^* U.N.F. x 1\frac{1}{8}^* long) Plain washer Self-locking nut (\frac{1}{2}^* U.N.F.) Silencer		Clamp plate	and Z		·L.H.D.
Self-locking nut (\frac{1}{2}" U.N.F.)		Bolt (4" U.N.F. x 18" long)	r 4	i i	
55 Flexible mounting for tail pipe 2 271465 56 Distance piece 4 244009 57 Clamp plate, upper 58 Packing plate, upper 59 Packing plate, lower 60 Clamp plate, lower 61 Bolt (\frac{1}{2}" U.N.F. x 1\frac{1}{8}" long) 62 Plain washer 63 Self-locking nut (\frac{1}{4}" U.N.F.) 64 Pipe clamp bracket 1 239712 R.H.D.		Plain washer	4		
56 Distance piece 57 Clamp plate, upper 58 Packing plate, upper 59 Packing plate, lower 60 Clamp plate, lower 61 Bolt (\frac{1}{2}" U.N.F. x 1\frac{1}{8}" long) 62 Plain washer 63 Self-locking nut (\frac{1}{4}" U.N.F.) 64 Pipe clamp bracket 65 Distance piece 4 244009 66 Fixing flexible 1 239715 60 chassis frame 1 274870 and clamp 1 239715 bracket 4 255210 4 252220 64 Pipe clamp bracket 1 239712 R.H.D.					
57 Clamp plate, upper 58 Packing plate, upper 59 Packing plate, lower 60 Clamp plate, lower 61 Bolt (½" U.N.F. x 1½" long) 62 Plain washer 63 Self-locking nut (½" U.N.F.) 64 Pipe clamp bracket 65 Fixing flexible 66 1 239715 67 mounting to 68 1 245926 69 chassis frame 60 1 239715 60 and clamp 60 255210 60 4 255220 60 Pipe clamp bracket 61 239715 62 Plain washer 63 Self-locking nut (½" U.N.F.) 64 252220 65 Fixing flexible 66 245926 67 and clamp 68 255210 69 252220 60 Example 1 239715 60 245926 60 274870 60 239715 61 239715					
58 Packing plate, upper mounting to 1 245926 59 Packing plate, lower 1 274870 60 Clamp plate, lower 1 239715 61 Bolt (½" U.N.F. x 1½" long) bracket 4 255210 62 Plain washer 4 3840 63 Self-locking nut (½" U.N.F.) 4 252220 64 Pipe clamp bracket 1 239712 R.H.D.		-			• .
59 Packing plate, lower 60 Clamp plate, lower 61 Bolt (‡" U.N.F. x 1\frac{1}{8}" long) 62 Plain washer 63 Self-locking nut (\frac{1}{4}" U.N.F.) 64 Pipe clamp bracket 65 Plain washer 66 Self-locking nut (\frac{1}{4}" U.N.F.) 66 Pipe clamp bracket 67 Chassis frame 68 1 274870 69 and clamp 69 the clamp to the clamp of the clamp to th			•		
60 Clamp plate, lower 61 Bolt (‡" U.N.F. x 1\frac{1}{8}" long) 62 Plain washer 63 Self-locking nut (\frac{1}{4}" U.N.F.) 64 Pipe clamp bracket 65 Clamp plate, lower 66		""	•	•	
61 Bolt (‡" U.N.F. x 1\frac{1}{8}" long) 62 Plain washer 63 Self-locking nut (\frac{1}{8}" U.N.F.) 64 Pipe clamp bracket 65 Bolt (\frac{1}{2}" U.N.F.) 66 Plain washer 67 A 252220 68 Pipe clamp bracket 69 Bracket 60 A 252220 60 Pipe clamp bracket 60 Bracket 61 A 255210 62 Bracket 63 Bracket 64 Bracket 65 Bracket 66 A 255210 67 Bracket 68 Bracket 69 Bracket 60 A 252220 60 Plain washer 61 Bolt (\frac{1}{2}" U.N.F. x 1\frac{1}{8}" long) 62 Bracket 63 Bracket 64 Bracket 65 Bracket 66 Bracket 67 Bracket 68 Bracket 69 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 61 Bracket 62 Bracket 63 Bracket 64 Bracket 65 Bracket 66 Bracket 67 Bracket 68 Bracket 69 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 60 Bracket 61 Bracket 62 Bracket 63 Bracket 64 Bracket 65 Bracket 66 Bracket 67 Bracket 68 Bracket 68 Bracket 68 Bracket 69 Bracket 60 Bracket 61 Bracket		- · ·			
62 Plain washer 63 Self-locking nut (½" U.N.F.) 64 Pipe clamp bracket 65 Self-locking nut (½" U.N.F.) 66 Pipe clamp bracket 67 Jane 20 Jane			-		·
63 Self-locking nut (* U.N.F.) 4 252220 64 Pipe clamp bracket 1 239712 R.H.D.		·	et 4		
64 Pipe clamp bracket 1 239712 R.H.D.			4		
			4		2112
65 Pipe clamp bracket 1 239716 L.H.D.			1		,
	65	Pipe clamp bracket		259716	L.H.D. J



		EARAUSI	3131EW	
PLATE REF.	1 2 3 4 DESCRIPTION	ON Qty.	Part No.	REMARKS
	Saddle for clamp bracket	1	240087)	
	Bolt (5" U.N.F. x 1" long)	Fixing 2	255228 >88	
		exhaust pipe to 2	3075	
		clamp bracket 2	254811	
	Flexible mounting, intermedia	•	271465	٦
	Distance piece	Fixing 4	244009	1
	Packing plate, lower	flexible 1	274870	1
	Clamp plate	mounting 2	239715	İ
	Bolt ($\frac{1}{4}$ " U.N.F. x 1" long), upp	, ,	255209	1
	Bolt (\frac{1}{4}" U.N.F. x 1\frac{1}{8}" long), lo	·	255210	1
	Plain washer	clamp 2	3840	
	Self-locking nut (½" U.N.F.)	bracket 4	252220	1
	Clamp bracket	1	264886	·
	Saddle for pipe clamp bracket	••••	264889	
		saddle and clamp 2	255228	İ
		to intermediate 2	3075	•
	Nut $(\frac{5}{18}"$ U.N.F.) exhaust		254811	Ì
	Flexible mounting, intermedia	4 4	271465	
	Dictance piece	4	244009	İ
	Clamp plate upper	Fixing flexible	239715	†
	Plate for flexible mounting	mounting to 2	239710	
	Bolt (1" LINE v 1" long)	mounting plate 4	255209	İ
	Self-locking nut (‡" U.N.F.)	and chassis	252220	į.
	Pipe clamp	2	239711 > R.H.D.	
	Bolt (16" U.N.F. x 1" long)	Fixing pipe 1	255228	
	Shakeproof washer	clamp to 2	72614	
	Spring washer	mounting 1	3075	1
	Nut (5 " U.N.F.)	plate I	254811	≻ 109
		Fixing pipe clamp 1	255209	
	1	to exhaust	3074	<u>†</u>
	The state of the s	pipe 1	254810	
	Flexible mounting for silencer		271465	
	Distance piece	} 4	244009	
	Clamp plate	2	239715	
	Packing plate, lower	Fixing flexible 1	274870 > L.H.D.	1
	Packing plate, upper	>mounting to 1	245296	
	Bolt (4" U.N.F. x 18" long)	chassis and 2	255210	
	Plain washer	silencer 4	3840	1
	Nut (‡" U.N.F.)	2	252220	1.
	Flexible mounting for tail pipe	,	244316	
	Distance piece	Fixing flexible 4	244009	
	Clamp plate, upper	mounting to	239715	
	Bolt (4" U.N.F. x 1" long)	>chassis frame 4	255209	
	Plain washer	and mounting 4	3840	
	Self-locking nut (‡" U.N.F.)	plate 4	252220	1
	Plate for flexible mounting	2	2397 10	
	Pipe clamp	1	264865 1958-60	
	Pipe clamp	2	517567)	
	Bolt $(\frac{1}{4}$ U.N.F. $\times \frac{7}{8}$ long)	Lower fixing 1	255208 >1961 onwards	1
	Spring washer	for clamp	3074	
	Nut ($\frac{1}{4}$ " U.N.F.)	to tail pipe 1	254810	
		ատութաբե լ		1
	Bolt (5" LINE v 1" long)	Fixing clamp to 1	255 <i>22</i> 8	•
		Fixing clamp to 1 tail pipe and 1	255228 3075	

RADIATOR AND FITTINGS



RADIATOR AND FITTINGS

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	RADIATOR BLOCK ASSEMBLY	1	279848	
ı	RADIATOR BLOCK ASSEMBLY	i		2½ litre Series II > Petrol models
	RADIATOR BLOCK ASSEMBLY	•	526991	2½ litre Series IIA
	RADIATOR BLOCK ASSEMBLY	1		2 litre Diesel models
	RADIATOR BLOCK ASSEMBLY	l		24 litre Diesel models
2	0 16 6	I	269953	
Z		I		2½ litre Series Petrol models
	Cowl for fan	1	-	
	Cowl for fan	1		• • <i>J</i>
	Cowl for fan	I ·		2½ litre Series IIA
	Cowl for fan	l		2 litre Diesel models
•	Cowl for fan	I		2½ litre Diesel models
3	Drive screw fixing cowl to radiator block	10	77789	AH D 1 11
4	Filler cap for radiator, 4 lb. pressure		_	2 litre Petrol models
	Filler cap for radiator, 10 lb. pressure	1		Diesel and 2½ litre Alternatives
_	Filler cap for radiator, 9 lb. pressure	1		Petrol models Scheck before ordering
5	Chain for filler cap	1	230328	For 4 lb. or 10lb. pressure caps. Check before
	•			ordering
	Chain for filler cap	1		For 9 lb. pressure cap. Check before ordering
6	Retainer for chain	1		For 4 lb. or 10 lb. pressure caps. Check before
7	Joint washer for filler cap	1		ordering
	Shroud for fan cowl	1	506276	2½ litre petrol models
	Bolt (2 B.A. $x \frac{1}{2}$ long)	4	234603)	
	Nut (2 B.A.) - Fixing	4	251355	$\geq 2\frac{1}{4}$ litre Petrol models.
	Drive screw shroud	4	78153	Alternative fixings
	Spire nut	4	78237	
	Shroud for fan cowl	1	523693*	۲)
	Drive screw	3	78153	
	Spire nut	3	78237	$2\frac{1}{4}$ litre Diesel models
	Bolt (2 B.A. x 3 long) > Fixing shroud	1	237119	
	Spring washer	1	3073	
	Nut (2 B.A.)	1	2247	
8	RADIATOR GRILLE PANEL ASSEMBL	Y 1	330950*	
9	Bonnet rest strip, 35" long	1	300824	•
	Bifurcated rivet fixing strip	10	68087	•
10	Bolt (½" U.N.F. x ½" long) Fixing	13	255206)	
11	Spring washer radiator block	13		>11 off on 2 litre Petrol and 2 litre Diesel models
12	Nut (‡" U.N.F.) to grille panel	13	254800	
13	Rubber buffer Fixing		1 306465	
14	Bolt (5" U.N.F. x 1½" long) grille panel	3	256222	
15	Plain washer >and front apro	· · ·	2249	
16	Spring washer bracket to	3	3075	
17	Nut (16" U.N.F.) chassis frame	3	252161	
18	Front apron panel	1	332640	
	Canvas strip for front apron panel	1	332656	
	D' C' .	8	78226	
19		3	330457	
20	Special set bolt Fixing	3	78208	
21	Plain washer apron panel to	3	3900	
22	Spring washer securing brackets	3	3074	
LL	Spring master 2 securing prackets	J	J014	


1 2 3 4	* Asterisk indicat	es a new part whic	h has not been	used on any previo	ous model.
† Up to vehicles numbered	: *	1.1100000	†† From	vehicles numbered	in the Ser

Up to vehicles numbered: 141001046 151000499 142000827 152001284 144001674 154000997

161000025 162000237 164000265 † From vehicles numbered in the Serie 141001047 151000500 142000828 152001285 144001675 154000998


in the Series II range: 151000500 161000026 152001285 162000238 154000998 164000266 onwards

RADIATOR AND FITTINGS



RADIATOR AND FITTINGS

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	. Part No. REMARKS
23	Bolt (16" U.N.F. x 3" long) Fixing ap	oron 2	255026
24	Spring washer >panel to		3075
25	Nut $(\frac{5}{16}"$ U.N.F.) at front	. 2	254811
26	Grille for radiator	1	330149
27	"Land-Rover" nameplate, 73/ overall	1 1	332670
28	Drive screw \ Fixing nameplate and	2	78262
29	Spire nut Sgrille to grille panel	2	78237
	"Diesel" badge	I	320276)
	Fixing bracket for badge	1	、320333 ≯Diesel models
	Rivet \(\)\(\)\(\)\(\)\(\)\\\\\\\\\\\\\\\\\\	ge 2	78255
	Lock washer \int to grille	. 2	78256]
30	Drain tap for radiator	1	243237
31	Joint washer for drain tap	1	213959
32	Hose for radiator, top	1	268037 2 litre Petrol models
33	Hose for radiator, bottom	1	268038 \interpretation models
	Hose for radiator, top	1	247872 1958-60
	Hose for radiator, top	1	517613 1961 onwards $2\frac{1}{4}$ litre Petrol models
	Hose for radiator, bottom	1	278539 Series II
	Hose for radiator, bottom	1	530556 Series IIA
	Hose for radiator, top	1	508060 1958-60
	Hose for radiator, top	1	517613 1961 >2 litre Series II Diesel models
	Hose for radiator, bottom	1	278359
	Hose for radiator, top	1	517613 24 litre
	Hose for radiator, bottom	1	530556* ∫ Diesel models
34	Clip for radiator hoses	4	50315 2 litre Petrol models
	Clip \ For top and	2	50315 Discal models and 2k lites Patrol models
	Clip J bottom hose	2	50320 Diesel models and 21 litre Petrol models
	-		



	FEIR	OL ANI) FUEI	L 1.	AINE, FU	LIER AND FIFES
PLATE RFF.	1 2 3 4 DESCF	RIPTION	•	Qty	<u></u>	REMARKS
1	Petrol tank complete	••••	****	1	275016	Petrol models
	Fuel tank complete	••••		1	277765	Diesel models
2	Drain plug for petrol			1	235592	
3	Joint washer for drain	n plug		1	230509	
	Telescopic filler tube co	omplete	••••		277259	
4	Filler cap	****		I	l 277260)	·
5	Joint washer for cap			1	l 505244]	With ball valve
6	Chain for filler cap			l		≻in filler cap.
7	Filler tube	••••	•	1	1 277261	Alternatives to 5 lines below.
8	Extension tube for fil	ler		1	ر277262 ا	
	Filler cap		*	1	504655	
	Joint washer for cap	****		1	505244	With felt pad in filler cap.
	Chain for filler cap	****		1	231,190 }	Alternatives to 5 lines above.
	Filler tube			1	l 504657	
	Extension tube for fil	ler			l 504656	
9	Grommet for petrol or	fuel tank fill	er		500710	
10	Screw (2 B.A. x 3" long	9)		4		
11	Plain washer	Fixing		4	4030	
12	Spring washer	≻filler to		4	4 3073	
	Special nut	body sic	le ·	1	1 313385	
13	Nut (2 B.A.)	J		3	3 3823	
14	Hose, tank to filler tube	e			1 277263	
15	Anti-theft grid for filler	r			1 219687	
16	Clip for hose, bottom	••••			1 50328	•
17	Clip for hose, top				1 50343	
18	Breather hose for petro	l tank			1 277264	
19	Clip for breather hose	****		4	2 50302	
20	Rubber seal for filler pi	ipe			1 504233	
	Joint washer for fuel ta	ınk filler seal	••••		1 504673	2 off on Diesel models
21	Outlet elbow complete	for tank	••••		1 503492	
	Return elbow complete				1 271872	Diesel models
22	Joint washer for outlet	and return e	lbow		1 267837	2 off on Diesel models
23	Spring washer	∫ Fixing €	lbow		2 3101	VA off on I keep models
24	Screw (3 B.A. x * 18" lon	ıg)∫totank		- :	2 3972,	
25	Gauge unit for petrol to	ank			236017	
	Gauge unit for petrol to			• • • • •		Series IIA Petrol models
	Gauge unit for fuel tan				1 271230	Series II Diesel models
	Gauge unit for fuel tan					Series IIA Diesel models
26	Joint washer for gaug	ge unit	•		1 56398	•
27	Spring washer	∫Fixing a		(6 3101	•
28	Screw (3 B.A. x 9 lon				6 3972	
29	Bolt (18" U.N.F. x 3" l		_		6 255026	
30	Plain washer		or petrol	13	2 2249	
31	Spring washer	tank			6 3075	
32	Nut (5 " U.N.F.)	∫ chas	sis frame	. '1	6 254801	






PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	Petrol sediment bowl complete, AC 1524895	1	274323	7
33	Body only, AC 7950351	1	274881	
34	Bowl only, AC 1523620	1	236891	2 litre Petrol models
35	Gauze for bowl, AC 1524524	1	274880	Alternative to the 8 lines below.
36	Joint washer for bowl, AC 5593321	1	241225	Check carefully before ordering
37	Retainer for bowl, AC 5592050		261419	Check Carefully before ordering
3 8	Tap and gland complete, AC 1524897	I	241224	
3 9	0 11 (10 10 10 10 10 10 10 10 10 10 10 10 10	1	241224	
٠,	D. 1 11 .1 1 .	1	235682	₹
40	D 1 1	l	262278	
41	D11	I		21' P 1 - 1 1
42	Carren from bound	1	236896	2 litre Petrol models.
		I	236894	Alternative to the 8 lines above.
43	Joint washer for bowl	!	236895	Check carefully before ordering
44 45	Retainer for bowl	ļ	.240234	
45	Screw cap for retainer	I	240235	
46	Tap and gland complete	, l	240236	1
47	Bracket for sediment bowl	l	218468	,
48	Bolt (‡" U.N.F. x %" long) Fixing	3	255005	
49	Spring washer bracket	3	3074	
50	Nut ½" U.N.F.) to dash	3	254800	
51	Inlet adaptor for sediment bowl]	218471	
52	Special nut fixing adaptor and bowl to bracket	t 1	218470	
53	Outlet union for sediment bowl	1	218469	
54	Petrol pipe complete, tank to bowl	1	277898	>2 litre Petrol models
55	Nut \ Fixing pipe to	2	27 29	
56	Nipple ∫ tank and bowl	2	2728	
57	Petrol pipe complete, bowl to pump	1	240207	
58	Nut	1	2729	
59	Nipple >Fixing pipe to	1	2728	
60	Nut bowl and pump	1	50421	
61	Olive	. 1	3136	·
62	Flexible petrol pipe complete	1	276267	1958-60 Petrol models
63	Petrol pipe complete, flex to carburetter	1	218955)
64	Nipple]	1	2 7 28	
65	Nut Fixing pipe to flex	. 1	2729	2 litre Petrol models
66	Nut and carburetter	1	50421	
67	Olive	1	3136	
	Petrol pipe, nylon, pump to carburetter	1	507526	Series II
	Petrol pipe, nylon, pump to carburetter	1	527010*1	1
	Clip for pipe at distributor adaptor stud	1	219676	Series IIA
	Bracket for pipe clip	1	501428	
	Clip for pipe	1	232425	21 litre Petrol models
	Bolt (‡" U.N.F. x ½" long)	1	255004	24 mile i choi models
	Spring washer Fixing clip	1	3074	
	Nut (½" U.N.F.)	1	254800	
	Grommet for pipe	1	06860	
	Clip for nylon pipe		50637	٠
	Bolt (‡" U.N.F. x ½" long) Fixing clip to	l 1	255204	Series II models
	Spring washer oil filler pipe	1	3074	Series II models
	Nut (‡" U.N.F.)	1		
	support bracket	I	254800	<i>,</i>




		OL AM	D FUE	ي يا	AINE,		AND FIFES
PLATE REF.	1 2 3 4 DESCI	RIPTION		Q	ty. Part N	lo.	REMARKS
	Fuel feed pipe, complet	te, copper			1 2778	94)	
	Nut \ Fixing feed	l pipe to tan	k		2 2701	41 ≻2 litre	Diesel and 21/4 litre Petrol models, 1958-60
	Nipple ∫and flexibl	e pipe			2 2701	33]	, , ,
	Fuel feed pipe, nylon	****			1 5099	25)	
	Nut \(\) Fixing feed	d pipe to			1 2701	15 > Diesel	and 21 litre Petrol models, 1961 onwards
	Olive \int mechanical	pump, inlet	t		1 2701		•
	Fuel return pipe		•		1 2779	18)	
	Nut \ Fixing retu				2 2701	41 > Diesel	models, 1958-60
	Nipple ∫tank and fl				2 2701		
	Fuel pipe, spill return t				1 5099	09)	
	Bolt (2 B.A. $x \frac{3}{4}$ " long)] Fixing sp	ill return		1 2509	61	
	Spring washer	pipe to b	racket		1 30	73 >2 litre	Series II Diesel models, 1961
	Nut (2 B.A.)	on injecto	or stud		1 22	47	
	Grommet for spill retur	n pipe	****		1 2733	70)	
68	Fuel pipe retaining brace	cket	••••		1 2702	97	
69	Clip for fuel pipes	****			2 5094	12 Diesel	models
7 0	Clip for fuel pipes		****		1 501	83 Petrol	models, 1958-60
	Clip for fuel pipes		••••		2 21670	08) D	11 10/1
	Drive screw fixing clip	and pipe to	chassis		1 7262	26 \rightarrow Petrol	models, 1961 onwards
71	Bolt (2 B.A. x ½ long)	Fixing clip	o and		3 2346	03)	
7 2	Spring washer	bracket to	chassis		3 30	73 >All Die	esel and 1958-60 Petrol models
7 3	Nut (2 B.A.)	cross mem	ber		3 22	47 J	
74	Air cleaner, AC 722290	6	••••		1 2631	48 2 litre	Petrol models
	Air cleaner	••••			1 2796	52 2 1 litre	Petrol and 2½ litre Diesel models
	Air cleaner, AC 722345		••••	****	1 26913		Series II Diesel models
75	Oil container, AC 795	55536	•	••••	1 2647	77	
7 6	Washer for container				1 2647	78	
7 7	Toggle				3 2620		
7 8	Connection, air cleaner		er		1 2631	49 2 litre	Petrol models
	Connection, air cleaner				2752	50 2 litre	Series II Diesel models
	Connection, air cleaner	to manifold	••••				Series IIA Diesel models
7 9	Clip fixing connection		••••		2 50022		Petrol models
	Clip fixing connection		•			35 Diesel	models
	Clip, air cleaner connec	tion to rocke	er cover		1 5175	~ /≛ htv.	e Series IIA Diesel models
	Plain washer for clip	••••	****			17)	Derica IIA Diesei models
	Carburetter elbow	****			1 27965		
	Clip fixing elbow to con			••••	1 27969	,	
	Rubber seal, carburetter	r to elbow					Petrol models
	Clip fixing seal		••••		2 27187		
	Connection, elbow to ai	r cleaner			1 2795		
	Clip fixing connection	••••	••••		I 51758	35 J	

PETROL PUMP



PETROL PUMP


		**	IIIOL	LOM	•
PLATE REF.	1 2 3 4	DESCRIPTION	Qty.	Part No.	REMARKS
•-	Petrol pump	complete, SU AUA 79, 'L' type	1	268374	
1	Coil comple	ete, SU AUA 6001	1	262286	
2	Spring for	armature, SU AUA 1449	1	262304	
3	Diaphragm	complete, SU AUA 6011	1	260550	
4	Roller for c	liaphragm SU AUA 1433	11	260583	
5	Plate body,	SU AUA 4081/1	1	262299	
6	Joint washe	er for plate body, SU AUA 4082	1	262300	
7	Body, SU	AUA 4080/1	1	262287	
8		g coil housing to body, SU AUA		262301	
9	Special spri	ng washer, SU AUA 1863 € For		262303	
10		ew, SU AUA 878 ∫ term	ninal 1	262309	
11		SU AUA 1416	1	262288	
12		lve, SU AUA 839	2	262297	
13		retaining valve disc, SU AUA 8	340 1	262289	
14		valve cage, SU AUA 1479	1	262290	
15		n, SU AUA 1422	1	262294	
16		outlet union, SU AUA 1442	1	262293	
17		, SU AUA 887]	262296	
18	`	inlet union, SU AUA 1405]	262298	
19	Filter, SU		1		>2 litre Petrol models
20	-	ter, SU AUA 1421	1	262295	
21		filter plug, SU AUA 1442		262293	
22		complete, twin points, SU AUA		268674	
23	_	ew for contact blade, SU AUA 8		262310	
24 25		or end plate, SU AUA 1467	I	260585 262308	
25 24		g moulding, SU AUA 1459 crew, SU AUA 1468	2	262307	
26 27		nd plate, SU AUA 1466	1	234309	
28		ut, SU AUA 1661	I	262306	
29		minal, SU AUA 1662	I	262305	
30	Spring was		1	3073	4
31	Nut (2 B.A		1	262309	$f_{ij} = d$
32	,	mp, SU AUA 1478	2	50499	•
33	Olive \ Fixi	=	2	3136	
34	Nut to p	_	2	50421	• • •
35	Mounting pla		1	21255 7	
36	Rubber bush	Fixing electric petrol pump	2	212558	
37	Plain washer		2	2228	•
38	Special set bo	lt j	.2	212556	
39	Mechanical p	etrol pump complete AC 795041	4 1	501735	·]
40	Joint washe	er, pump to cylinder block	1	275565	
41	Self-locking r	aut ($\frac{5}{16}$ " U.N.F.) fixing fuel pum	р 2	252161	
42		et union for pump	2		\left(\) off on $\qquad \qquad \$ \right\rangle 2\frac{1}{4} \] litre Petrol models
43		or inlet and outlet union	2		Series IIA models
44	Elbow for inle	**************************************	2		1 off when
45	Nut \Fixi		2		nylon pipe
46	Olive fuel		2		is fitted
		petrol pump AC 1524507	1	272069	$2\frac{1}{4}$ litre Petrol and Diesel models
	Overhaul kit	for petrol pump AC 7950463	1	524684 _.	ag and a delot with proper introduce
				100	




						TILLIA I D	
PLATE REF.	1 2 3 4 DESCRIPT	ION		Q	ty.	Part No.	REMARKS
1	Instrument panel				1	302958	1958
	Instrument panel		****		1	332466	1959 2½ litre Petrol models onwards
	Instrument panel				1	332467	1959 Diesel model onwards
	Gauge and ammeter panel c	omplete,	JAPA 13	33	1	239566)	
2	Ammeter, SM AM 6200/1				i	239567	
3	Fuel gauge, SM FG 6237			•	1		Series II models
4	Warning light for headlan		SM 5333		1	239569	
•	Bulb for warning light,			/ -	1	232590	
	Gauge and ammeter panel c				i	519827	1
	Ammeter				i	519840*	
	t" 1			••••	i	519841*	1
	Fuel gauge Warning light for headlan	 on boom		••••	1	528950*	
		-		•···	1	232590	· L
ź	Bulb for warning light,			••••	1		J
5	Switch for panel lights	····			1	240908	C : II 11
6	Switch for lamps, LU 03136		••••		!		Series II models
	Switch for lamps, LU 03141		••••		!		America. Dollar area. Series II models
	<u>-</u>	****	****		1		Series IIA models
_	Switch for lamps				l		America. Dollar area. Series IIA models
7	Barrel lock for ignition or el	ectrical s	ervices	• • • •	1	59895	
8	Key for lock	••••	****		Ī		State key number when ordering
9	Socket for inspection lamp,				1	273937	
10	Socket for inspection lamp,	red, LU	305021		1	273936	
11	Warning light, charging, LU	J 38084A		****	1	238018	1958
	Warning light, charging		****		1	279115	1959-60
	Warning light, oil				1	519746 †	1961 Series II models
	Warning light, oil				1	519740	Series IIA models
12	Warning light, mixture or he	eater plus	z, LU 380	086A	1	238020	1958
	Bulb for warning light, L				2	232590	
	Warning light, mixture				1	279116	1959 21 litre Petrol models onwards. Flag eyelet
							type connector. Check before ordering
	Warning light, mixture				1	519744	Snap-in nipple type connector. Check before
					•		ordering
	Warning light, heater plug				1	501563	2 litre Diesel models
					i		2½ litre Diesel models
	Bulb for heater plug warn				i	507129	
13	Daniel harmon		****		i		1958 Petrol models
17	Panel harness, LU 864385	••••	•	••••	i	272743	1958 Diesel models
	Panel harness		•	••••	1	279400	1959-61 Series II models
	Lead for panel harness, LU	864386			1	272850 \	
1.4	-		 	 27	1	`	Series II models
14	Lead, ammeter to inspection		LU 02381		1	245815 J	
15	Bulb for panel light, LU 987				2	232590	
15	Set screw (2 B.A. x 3" long)	1			5	77941	
	Plain washer	Fixing	•		5	3885	
	Spring washer	ınstru	ment par	nel .	5	3073	
	Nut (2 B.A.)	j		,	2	2247	0 1 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
16	Starter switch, LUST 18		•	• • • • •	1		Series II Petrol models
	Starter switch				1		Series IIA Petrol models
	Starter-heater plug switch, I	LU 31629	E		1	277615	J
	Starter-heater plug switch				1	530071*	
	Key for starter switch, LU	J 312305			1	505798	≻Diesel models
	Warning light, fuel				1	279114	
	Warning light, fuel			••••	1	519742*	2¼ litre ∫

^{*} Asterisk indicates a new part which has not been used on any previous model.

1 2 3 4



	<u> </u>			DEL (1 DI/O
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.		REMARKS
17	Warning light, oil, LU WL 3/1. 38085 A	1	238019	1958
	Warning light, oil	1	=	1959-60
	Warning light, charging	1	-	1961 Series II models
	Warning light, charging	[-	Series IIA models
	Bulb for warning light, LU 987	2	232590	
18	Speedometer, miles, SM SN 3321/01	1	239564)	>88
	Speedometer, kilometres, SM SN 3321/02	1	239565∫	
	Speedometer, miles, SM SN 3321/03	1	279340`\	· ·
	Speedometer, kilometres, SM SN 3321/04	1	279341∫	are fitted
	Cable complete for speedometer, SM 1105/00	1	270716	
19	Cable, inner	1	270718	
20	Cable, outer	1	270717	
21	Retaining plate for cable	1	232566	
	Spring washer \(\) Fixing	3	3073	
	Set bolt (2 B.A. x ½" long) fretaining plate	. 3	250957	
	Felt washer for speedometer	1	241387	
22	Rubber grommet, in dash \(\) For speedomete	r 1	233243	
23	Rubber grommet, on cable \int cable	3	06860	
	Rubber grommet for speedometer cable at fuel p	ump 1	273370	Diesel and 21 litre Petrol models
24	Clip For	1	239600	
25	Clip speedometer	1	240407	
	Clip cable	. 2	278010	
	Clip J cable	1	240417	`
26	Bracket for mixture control	1	216380	
27	Switch for mixture warning light, LU 31109 A		214223	·
28	Bolt (2 B.A. $x \frac{1}{2}$ long) \int Fixing	2	234603	
29	Spring washer >switch	2	3073	
30	Nut (2 B.A.) to bracket	2	2247	
31	Mixture control complete	1	500571	Must be used with carburetter type Petrol
				without starter heater element. models
			·	Check before ordering
	Mixture control	1	523637	Must be used with carburetter type
				with starter heater element.
				Check before ordering
32	Shakeproof washer for control	1	233017	J



DI	nead, s		TALY.		LAMPS
PLATE REF.	1 2 3 4 DESCRIPTION	()ty.	Part No.	REMARKS
	Headlamp complete, LU 51780		2		R.H.D.
	Headlamp complete, LU 51781		2	2 7 25 7 7	L.H.D. Except Europe
	Headlamp complete, LU 58286		2	507198	L.H.D. Europe except France
	Headlamp complete, LU 58287		2	507199	France only
	Headlamp shell and connector, LU 51984		2	272580	America. Dollar area
I	Body for headlamp, LU 552943		2	274377	
2	Bulb for headlamp, LU 414		2	505196	R.H.D.
	Bulb for headlamp, LU 415		2	513314	L.H.D. Except Europe
	Bulb for headlamp, LU 410		2	505197	L.H.D. Europe except France
	Bulb for headlamp, LU 411		2	505198	France only
3	Adaptor for bulb, double contact, LU 55		2	274378	
	Adaptor for bulb, triple contact, LU 562	2303	2	261794	France only
4	Light unit, LU 553921		2	274783	R.H.D.
	Light unit, LU 555447		2	262342	L.H.D. Except Europe
		pattern''	2	262343	L.H.D. Europe except France
	Light unit, triple contact, lens				
	LU 553948		2	262269	France only
5	Rim complete for light unit, LU 554872		2	274379	
6	Special screw for light unit rim, LU 1		6	262100	
7	Rubber gasket for headlamp rim, LU 55	2906	2	262101	
8	Gasket for body, LU 554279		2	272595	
9	Special screw Lig		6	261940	
10	Spring for screw		6	261941	
11	Cup washer for screw, LU 552818 J adju	ustment		261943	
12	Rim for headlamp, chrome, LU 554439		2	272592	
13	Rim retaining screw, LU 198898		2	272594	
14	Spire nut for rim retaining screw, LU 18	87117	2	510469	
	Screw (2 B.A. x ½" long) Fixing		6	71164	·
	Spring washer headlamp to		6	3073	
	Nut (2 B.A.) front grille		6	2247	_
15	Side lamp complete		2	505144 †)
15	Rubber body for side lamp		2	500515	Sparto type.
16	Bulb for side lamp, LU 207	•	2	10211	Alternatives
17	Bezel for side lamp	•	2	500514	to Lucas.
18	Lens for side lamp, domed type		2		Alternative types. Check before
	Lens for side lamp, flat type	· ·	2		Check before ordering J ordering
	Side lamp complete, LU 52437	••••	2	510179	•
	Bulb holder interior, LU 553780		2	244700	
	Bulb for side lamp, LU 222		2	242491	1,
	Bezel for side lamp, LU 54570407		2	514148	Lucas type. Alternatives to Sparto.
	Special screw fixing bezel, LU 54127522		4	514149	Check before ordering
	Lens for side lamp, LU 54570404		2	514150	
	Sleeve for terminal, LU 555910	••••	2	514145	J
	Screw (4 B.A. x 3 long)		4	501679	Alternative to Check
	Spring washer Fixing side lam	p	4	3072	drive screw fixing before
	Special drive screw to front wing		4		Alternative to 4 B.A. fixing J ordering
	Nut (4 B.A.)		4		For side lamp 278190
	Nylon insert		4	505150	For side lamps 505144 and 510179

1 2 3 4 * Asterisk indicates a new part which has not been used on any previous model.										
† "Up to vehicles numbered"—			TT "From vehicles n	umbered"—						
141903513 1469014:	39 15 1900889	156900918	141903514	146901440	151900890	156900919				
142901597 1479001	75 152902901	157900456	142901598	147900176	152902902	157900457				
144903030 1499003	07 154901596	159900275	144903031	149900308	154901597	159900276 onwards				





PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	Stop tail lamp	2		·
19	Rubber body	2	500413	Sparto type.
20	Bulb for stop tail lamp, LU 361	2	264590	Alternative to Lucas.
21	Lens for stop tail lamp	2	500411	Check before ordering
22	Bezel for glass	2		
	Special screw fixing tail lamp to body	, 4		
	Stop tail lamp, LU 53783	2	510 17 6`	
	Lens for stop tail lamp, LU 54570677	2		
	Special screw fixing lens, LU 576396	4		
	Bulb for side lamp, LU 380	2	264590	·
	Bulbholder, interior, LU 573828	2		Check before ordering
	Sleeve for terminal, LU 555910	2		
	Gasket for lamp base, LU 576390	2		·
	Grommet for cable, LU 576401	2	514147	
	Drive screw, fixing tail lamp to body	4	7 8135	
23	Number plate lamp, LU 052448 D	1	234213	
24	Bulb for number plate lamp, LU 989	1	50689	
25	Glass, LU 572596	1	261919	
26	Rubber grommet for wire, LU 572039	1	261252	
27	Rubber gasket for lamp, LU 572042	1	261253	



Windstone horn	PLATE	1 2 3 4 DESCRIPTION		D. M. DEMARKS
Vindtone horn	PLATE REF.	· · · · · · · · · · · · · · · · · · ·	Qty.	
Contact set for windtone horn U 702687	ı		1	
Contact set for windtone horn Rubber grommet for Lucas type horn Rubber grommet for Lucas type horn Rubber grommet for Lucas type horn I 234041 Mounting bracket for windtone horn Bolt (¼' U.N.F. x ½' long) Spring washer Nut (¼' U.N.F. x ½' long) Fixing horn Spring washer Plain washer Spring washer Spring washer Spring washer Vindscreen wiper motor complete, LU 75334 Windscreen wiper motor complete Arm for wiper blade, stud fixing, LU 737673 Wiper blade, stud fixing, LU 737673 Rubber seal for escutcheon Spring washer Nut (½ B.A.) Spring washer Patient washer, LU 45054 Ignition coil Acorn nut, LU 408120 Rubber bot for coil acorn nut Split washer, LU 85015 Drive screw Shakeproof washer Voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Cover for regulator box Cover for regulator box LU 37180 Screw (2 B.A. x 1½' long) Spring washer Nut (2 B.A.) Drive screw Screw (2 B.A. x 1½' long) Spring washer Cover for regulator box Current-voltage regulator box Current-voltage regulator box Cover for regulator box Cover for regulator box LU 37180 Screw (2 B.A. x 1½' long) Spring washer Nut (2 B.A.) Drive screw Bolt (¾' U.N.F. x ½' long) Spring washer Nut (2 B.A.) Drive screw Bolt (¾' U.N.F. x ½' long) Spring washer Nut (2 B.A.) Drive screw Bolt (¾' U.N.F. x ½' long) Spring washer Nut (½ U.N.F. x ½' long) Spring washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Screw (2 B.A. x 1½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Nut (½ U.N.F. x ½' long) Shakeproof washer Screw (2 B.A. x 1½' long) Shakeproof washer Screw (2 B.A. x 1½' long) Shakeproof washer Screw (2 B.A. x 1½' long) Shakeproof washer Screw (2 B.A. x 1½' long) Shakeproof washer Screw (2 B.A. x 1½' long) Shakeproof washer Screw (·	1	**
Rubber grommet for Lucas type horn		the state of the s	1	
Mounting bracket for windtone horn			1	
Bolt (\$' U.N.F. x \$' long)	0			
Spring washer	2			•
Nut (½* U.N.F. x x y long) Fixing horn 2 254800 Set bolt (½* U.N.F. x x y long) Fixing horn 3 255006 Spring washer 5 to box 3 3074 Clip fixing horn lead to bonnet 1 240406 Sundacreen wiper motor complete 1 1 240406 Sundacreen wiper motor complete 1 1 1 240406 Sundacreen wiper motor complete 1 1 1 240406 Series II models Sundacreen wiper motor complete 1 1 1 240406 Series IIA models Sundacreen wiper motor complete 1 1 1 240406 Series IIA models Sundacreen wiper motor 2 310529 Sundacreen wiper motor 2 330529 Sundacreen wiper motor 2 330529 Sundacreen wiper motor 2 330529 Sundacreen wiper motor 2 330529 Sundacreen wiper motor 2 320987 Sundacreen wiper				
Set bolt (\forall^* U.N.F. x \forall^* long)		• •		
Plain washer Spring washer Clip fixing horn lead to bonnet 1 240406		· · · · · · · · · · · · · · · · · · ·		•
Spring washer				•
Clip fixing horn lead to bonnet 240406 277931 Series II models Windscreen wiper motor complete		· · · · · · · · · · · · · · · · · · ·		J
Windscreen wiper motor complete, LU 75334 1 277931 Series II models				
Windscreen wiper motor complete	•			
4 Arm for wiper blade, stud fixing, LU 735061	3	- · · · · · · · · · · · · · · · · · · ·		•
1	4			
6 Escutcheon for windscreen wiper motor 7 Rubber seal for escutcheon 8 Screw (2 B.A. x 1⅓* long) Spring washer Nut (2 B.A.) 8 Battery, dry, 12 volt, LU 4016417 1 278283 9 Ignition coil, LU 45054 Ignition coil Acorn nut, LU 408120 Rubber boot for coil acorn nut Split washer, LU 185015 Drive screw Fixing coil 1 235553 Shakeproof washer Shakeproof washer Surrent-voltage regulator box, LU 37188A Current-voltage regulator box, LU 37189 Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Cover for regulator box Co			1	
Rubber seal for escutcheon 2 302987 Screw (2 B.A. x 13 long) Fixing 2 78240 Spring washer 2 3073 redundant 2 3073 redundant 2 2247				
Screw (2 B.A. x 1½" long) Fixing 2 78240 Spring washer Yedundant 2 3073 Spring washer Yedundant 2 3073 Spring washer Yedundant 2 3073 Series II Sattery, dry, 6 volt 2 270598 Diesel models				
Spring washer Nut (2 B.A.) escutcheon 2 2247	1			
Nut (2 B.A.)				•
Battery, dry, 12 volt, LU 4016417				
Battery, dry, 6 volt				
Ignition coil LU 45054	ð			
Ignition coil	Λ		1	· · · · · · · · · · · · · · · · · · ·
Acorn nut, LU 408120 Rubber boot for coil acorn nut Split washer, LU 185015 Drive screw Shakeproof washer Voltage regulator box, LU 37138A Voltage regulator box, LU 37189 Current voltage regulator box, LU 37297 Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Scover for regulator box Cover for regulator box Current-voltage regulator box Screw (2 B.A. x 1½ long) Spring washer Nut (½ B.A.) Drive screw Bolt (½ U.N.F. x ½ long) Shakeproof washer Nut (½ U.N.F.) Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Series II Petrol models Petrol models Petrol models Petrol models Series II Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Petrol models Series II Petrol models Petrol models Petrol models Petrol models Series II Petrol models Pet	9		1	1
Rubber boot for coil acorn nut Split washer, LU 185015 Drive screw Split washer, LU 185015 Drive screw Shakeproof washer To dash Voltage regulator box, LU 37138A Solitage regulator box Current voltage regulator box, LU 37189 Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Solitage regulator box Current-voltage regulator box Solitage			1	
Split washer, LU 185015			יו	
Drive screw Fixing coil 2 72628 Shakeproof washer to dash 2 78114				1 /
Shakeproof washer			_	
Voltage regulator box, LU 37138A 1 235553 Series II Petrol models Voltage regulator box 1 514734 Series IIA Petrol models Current voltage regulator box, LU 37189 1 272546 2 litre Diesel models. Use with dynamo type PV5 Current-voltage regulator box, LU 37297 1 512251 2 litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. Use with dynamo type PV6 Current-voltage regulator box 1 530051* 2½ litre Diesel models. 2 B.A. screw type fixi		4 **		
Voltage regulator box	10		1	
Current voltage regulator box, LU 37189 Current-voltage regulator box, LU 37297 Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Current-voltage regulator box Cover for regulator box, LU 391600 Cover for regulator box Cover for regulator box Cover for regulator box Cover for regulator box, LU 54380178 Cover for regulator box, L	10			
Current-voltage regulator box, LU 37297				
Current-voltage regulator box			1	
Cover for regulator box, LU 391600 1 262859 Petrol models Cover for regulator box 1 500527 Diesel models. 2 B.A. screw type fixing Cover for regulator box, LU 54380178 1 513937 Diesel models. Drive screw fixing Screw (2 B.A. x 1½" long) Spring washer Nut (2 B.A.) Drive screw Bolt (½" U.N.F. x ¾" long) Shakeproof washer Nut (½" U.N.F.) Petrol models Check before ordering 1 262859 Petrol models 1 500527 Diesel models. 2 B.A. screw type fixing Check before ordering 1 202849 Series II Petrol models Pixing voltage 2 78443 Series IIA Petrol models Fixing voltage 3 255207 Shakeproof washer Nut (½" U.N.F.) Diesel models Diesel models Diesel models			1	
Cover for regulator box	11		1	
Cover for regulator box, LU 54380178 1 513937 Diesel models. Drive screw fixing Screw (2 B.A. x 1½" long) Spring washer Nut (2 B.A.) Drive screw Bolt (½" U.N.F. x ½" long) Shakeproof washer Nut (½" U.N.F.) Type fixing Diesel models. Drive screw fixing 2 77992 Series II Petrol models Fixing voltage 2 78443 Series IIA Petrol models regulator box 3 255207 Shakeproof washer Nut (½" U.N.F.) Diesel models Diesel models Diesel models	••		1	the contract of the contract o
Cover for regulator box, LU 54380178 1 513937 Diesel models. Drive screw fixing Screw (2 B.A. x 1½" long) Spring washer Nut (2 B.A.) Drive screw Bolt (½" U.N.F. x ½" long) Shakeproof washer Nut (½" U.N.F.) Scries II Petrol models 2 78443 Series IIA Petrol models 3 255207 3 70884 Diesel models Diesel models 2 1842 Series IIA Petrol models 3 255207 Diesel models 2 247 Diesel models 2 255207 Diesel models 2 255207 Diesel models 2 255207 Diesel models		COVER FOR TESTINATED FOR	1	
Screw (2 B.A. x 1½" long) 2 77992 Spring washer 2 3073 Series II Petrol models		Cover for regulator box 11154380178	1	· · · · · · · · · · · · · · · · · · ·
Spring washer 2 3073 Series II Petrol models 2 2247		-	1	fixing
Nut (2 B.A.) Drive screw				
Drive screw Bolt (½" U.N.F. x ½" long) Shakeproof washer Nut (½" U.N.F.) Fixing voltage 2 78443 Series IIA Petrol models regulator box 3 255207 3 70884 Diesel models 3 254800 2 litre				·
Bolt (½" U.N.F. x ½" long) regulator box 3 255207 Shakeproof washer 3 70884 Diesel models Nut (½" U.N.F.) 3 254800 2 litre				
Shakeproof washer 3 70884 Diesel models Nut (½" U.N.F.) 3 254800 2 litre		, ,		· · · · · · · · · · · · · · · · · · ·
Nut (‡" U.N.F.) 3 254800 2 litre				
				1.5
Kıv-nut 3 514929 2½ litre				
		Kıv-nut	3	514929 2½ litre




PLATE	1224 DESCRIPTION		<u> </u>		Part No. REMARKS
PLATE REF.	1 2 3 4 DESCRIPTION		Qt	y. •	
12	Fuse box, LU 37131			l •	219078 Series II models
	Fuse box		Ì	! •	530047* Series IIA models
13	Cover for fuse box, LU 291078]	261502
	Fuse, 35 amp			l	12738
	Special screw, LU 153564 Fixing			2	3279 Series II models
	Special nut, LU 167530 fuse bo	x		2	3280 J
	Drive screw, fixing fuse box			1	78152 Series IIA models
	Drive screw, locating fuse box			ł	093103
14	Junction box, LU 78266 A			1	03971
	Screw (2 B.A. x ½ long) Fixing			2	71164 > Series II models
	Spring washer junction			2	3073
	Nut (2 B.A.) box		2	2	2247
15	Resistor for heater plugs, KLG type	BRQI		1	512338 2 litre
	Resistor for heater plugs			1	529968* 2½ litre
	Bolt (2 B.A. x ¾ long) Fixing			2	237119 Diesel models
	Shakeproof washer resister			2	311373
	Nut (2 B.A.) J to dash		:	2	3823
16	Dash harness	****		1	501034 1958 88 Petrol models
	Dash harness			1	501032 1958 109 Petrol models
	Dash harness			1	501569 1959-61 Series II 21 litre Petrol models. For
					carburetter without starter heater element.
					Check before ordering
	Dash harness			1	519806 1961 Series II 21/4 litre Petrol models. For car-
					buretter with starter heater element. Check
					before ordering.
	Dash harness			1	519782* Series IIA 21/4 litre Petrol models
	Dash harness	****	•	1	501033 1958 Diesel models
	Dash harness			1	501570 1959-61 2 litre Diesel models
	Dash harness			1	529963* 2½ litre Diesel models
17	Head lamp and side lamp harness			1	501694 Except L.H.D. Diesel
	Head lamp and side lamp harness			1	278383 L.H.D. Diesel Series II models
18	Dynamo harness, LU 862980	****		1	267392 2 litre Petrol models
	Dynamo harness			1	279074 1958-60 Series II 24 litre Petrol models
	Engine harness, LU 54947090			1	514935* 1961 Series II 21/4 litre Petrol models. For car-
					buretter without starter heater element. Check
					before ordering
	Engine harness			1	519814 1961 Series II $2\frac{1}{4}$ litre petrol models. For car-
					buretter with starter heater element. Check
					before ordering
	Dynamo harness	****		1	526360* Series IIA 21 litre Petrol models
	Dynamo harness		****	1	529965* 2½ litre Diesel models
19	Frame harness, LU 835521			l	501602 88 T
	Frame harness, LU 835671			1	501693 109 Series II models
	Frame harness			1	51070/# 00 Š
	Frame harness			1	526440* 109 Series IIA models
20	Rear cross member harness, LU 8203	784		1	236137 Series II models
	Rear cross-member harness			1	519783* Series IIA models
	Extension harness for horn, LU 5494	6709		1	514895 1960-61 Series II. When horn is fixed to battery
					support
	Extension lead for stop light switch,	LU 8610	80	1	239282 L.H.D.
	Lead for engine thermostat	****		1	270517 21 line Daniel Jala)
	Lead for oil pressure switch			1	279517 24 little Fetrol models 1958-60 Series II
21	Lead, rear number plate lamp			1	500559
	Feed lead, dynamo harness to carbur			1	528931* Series IIA 2½ litre Petrol models. For carburetter
					with starter heater element.
	Lead, starter motor to earth			1	530083* 2½ litre Diesel models
-	Current to Current			<u>. </u>	





PLATE.				CAL EQUITMENT
PLATE REF.		<u>, (</u>	ty.	Part No. REMARKS
22	Cable, coil to distributor, LU 999152		1	502617 Series II Petrol models
-00	Cable, coil to distributor	• • • • •	1	528963* Series IIA 24 litre Petrol models
23	Cable, battery to earth, LU 812014		1	239558 Petrol models
24	Cable, battery to switch, LU 861081 A	• • • •	1	239559 2 litre Petrol models
	Cable, battery to switch	• • • •	!	501690 24 litre Petrol models
	Cable, battery to earth	••••	ļ	275371 2 litre Diesel models
	Cable, battery to earth	••••	!	530084* 2½ litre Diesel models
	Cable, battery to starter, LU 54941019A	• • • •	ı.	503982 \ 501355 \ 2 litre Diesel models
	Cable connecting batteries, LU 54940415		!	
	Cable, battery to starter		l	530085* 21 litre Diesel models
	Cable, connecting batteries		1	530086* 2½ litre Diesel models
25	Drive screw fixing battery cables, LU 186111		2	50552 4 off on Diesel models
25	Cable, switch to starter, LU 861082 A	,	1	501691 Petrol models
26	Cable clip fixing starter cable to flywheel hous	-	•	12743 2½ litre Petrol models
26	Cable, gearbox to earth, LU 999709	••••	1	219649
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) Fixing		1	255204
	Fan disc washer gearbox earth		2	510170
	Nut (# U.N.F.) cable to frame		1	254810
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{7}{8}$ " long) Fixing		1	255208
	Fan disc washer battery		2	510170
	Spring washer earth cable		1	3074
	Nut (\frac{1}{4}" U.N.F.) \tag{to frame}		10	254810 Series IIA 24 litre Diesel models
	Clip, battery cable to frame, LU 187051		10	56667
	Drive screw, fixing clip to frame		10	72626
	Clip, battery cable to frame, LU 862553		2	513223
	Grommet, for battery cable at seat base LU859		2	233566
	Lead, tank unit to dash harness, LU 863690		1	271225 2 litre Diesel models
	Lead, tank unit to dash harness		1	529966* 2½ litre Diesel models
27	Lead for petrol tank unit		1	528919* Series IIA Petrol models
21	Wiper feed lead, LU 861084 Earth lead for wiper motor		1	239687 Series II models
	Final Little Control of the Control	••••	1	239688 Series II models
28	Plug socket for leads on steering bracket, LU30	 5514	1	519899* Series IIA models
29	Cap for wiper feed socket, LU 572363	JJ14	1	233331 (Series II models
30			1	4082)
31	Clim for hottom to anital public	****	1	50640 > 88 Petrol models
32	Mounting plate for orble aline		1	267412 267412
22	Drive screw fixing clips to mounting plate		1	72626
33	Cable clip for frame harness, at dash R.H.	****	1	237279
22	Clim for horn load	•···	2	8885]
	Screw (2 B.A. x ½" long)) Fixing	**	2	77869 > 1 off on > Not required when horn is fixed
	Spring washer horn lead		2	3073 Diesel models to battery support
	Nut (2 B.A.) to dash		2	3823
	Drive screw fixing clip to dash		1	75454
35	Cable clip for frame harness, at junction box	•	1	233770
36	Cable alim at I U Loudland		i	3619
	Earthing clip for headlamp, LU 860019		i	236366
38	Earthing clip on rear cross-member, LU 8600	19	2	236366
,, ,	Bolt (2 B.A. $\times \frac{1}{2}$ " long) \cap Fixing		2	234603
	Shakeproof washer carthing		2	71082
	Fan disc washer clip to rear		2	513282
	Nut (2 B.A.) cross-member		2	2247
	Clip for rear cross-member harness		2	56666
	Cable clip for engine harness		2	219676 1961 Series II 2½ litre Petrol models
			_	The second of the second secon



	<u></u>	GENERAL	ELECIK	ICAL	EQUIPME	74.1
PLATE REF.	1 2 3 4 DESCR	IPTION	Qty.	Part No.	•	REMARKS
39	Cable clip fixing harness	to dash R.H.	1	56667	<u></u>	
40	Cable clip fixing harness	to dash and L.H.	toe box 5	50639		
41	Cable clip on wing valan	ce and toe box	4	56666	3 off on 88	
42	Cable clip fixing harness		3	278490		
	Screw		10	77846	9 off on 88	
	Plain washer Fixing	clips to dash	5	2226		Diesel models
	Spring washer and to		10	3073	9 off on 88	
	Nut (2 B.A.)		10	3823	9 off on 88	
43	Cable clip fixing harness	adjacent to juncti	on box 1	240429	Series II	•
44	Cable clip fixing dipper				ŀ	
	accelerator shaft bra		1	278489	1	
	Cable clip, for headlamp	and horn cable ha	rness 5	233770	. ,	
	Cable clip, fixing headlan			50642	Petrol models	
	Cable clip on wing valance	-	2	233770		
	Cable clip, lamp harness		2	50642		
45	Clip for rear cross memb		3	236365		
	Cable cleat, frame harness		J 941834 2	240429		
48	Cable clip, wiper feed lea		1	240406		
	Cable clip, stop lamp lead		1	236365	5 off on L.H.	D.
. 49	Cable clip on fan cowl to	p baffle	4	3622)	-
50	Clip fixing heater switch l	ead to engine spee	d con-		Diesel models	8
	trol quadrant		3	50637		
51	Cable clip at dash R.H.		1	233247		models
	Clip for tail lamp harness		4	50639		
	Screw (2 B.A. x 5" long)	Fixing clip	4	78177		
	Spring washer	to wheelarch bo	x 4	3073		
	Nut (2 B.A.)	at rear	4	2247		
	Clip, stop-tail lamp leads	to rear cross-men	nber 2	56666		
	Screw (2 B.A. $x \frac{1}{2}'' long$)	· ·	2	77869		
	Plain washer	Fixing clip to	2	3816		
	Spring washer	rear cross-mem	ber 2	3073		
	Nut (2 B.A.)	J	2	3823		
52	Bowden clip, starter cable	to solenoid	1	4200	Series II mod	lels
53	Cable cleat for engine har	ness	2	240430		
	Cable clip, battery to start	ter cable	3	56667		
	Cable cleat for lead and	side lamp harnes	ss and			
	dynamo lead to starte		2	240429		
	Cable clip harness to dash	, upper	1	240417	21 litre Petrol	and Diesel models
	Cleat, coil lead to dash ha	rness	1	240429		
	Cleat, dash harness upper	, centre and R.H.	2	240430		
	Cleat, harness adjacent to	fuse box	1	240431		
	Cable clip, harness to dash	h R.H. lower	1	278490		
		Fixing	1	237121		
	Shakeproof washer	clip and earth	2	71082		
	Nut (2 B.A.)	terminals	1		>21 litre Petrol	models
	Cable clip, starter switch l	eads	1	50639		
1	Cable clip, engine harness	leads	1	278490		
:	Screw (2 B.A. x ½" long) `	Fixing	2	77869		
	Plain washer	clips to	2	3816		
:	Spring washer	dash centre,	2	3073		
!	Nut (2 B.A.)	lower	2	3823		
	_		_)		




PLATE	1 2 2 4	DECOM	TION			- · · · · · · · · · · · · · · · · · · ·	EQUI MEN	
PLATE REF.	1 2 3 4	DESCRIP			ty.	Part No.		REMARKS
	-		dash L.H. lowe	r	!	3619	!	
	Bolt (‡" U.N.F	. x ½ long)			l		$>$ $2rac{1}{4}$ litre Petrol m	odels .
	Spring washer	• • •	to lower hea		!	3074		
	Nut (1" U.N.F) mounting ho	ole	1	254800	•	
	Clip, fixing dip				1	514721	L.H.D.	
	Cable cleat, fix	ing starter h	eater lead to fu	el pipe	2	240429		models when carburetter with
	C11 1: (1 .	DII. I		•	050 100	starter heater	element is fitted.
	Cable clip, fran		o K.H. toe box	****	3	278490		
	Screw (2 B.A.	x 🕏 long)	T3 1.		3	77869		
	Plain washer	ì	Fixing clips		3	3816		
	Spring washer		to toe box		3	3073		
	Nut (2 B.A.)	ر ,	11 1	,	3	3823		-
			arter cable and t	hermo-	, .	0.40.400		
			etrol pipe	••••	6	240429	10/1	>21 litre Petrol models
	Cleat at dash fo				ı	240431	1961 onwards	
	Clip, engine le			H. rear	_	1000		ļ
	side, lower			****	2	4020		
	Clip for coil an	id distributo				220/00		
	rear stud	 11 - 1 11 . 11			2	239600	4	
	_		butor leads toge		2	240429		
			and coil lead a	it rear	1	04040		(
	rocker cov			•		06860		
<i>.</i>	Grommet for d				1	06800		J
54	Rubber gromm		_			000011	1050 (0	
	LU 859341			1	ı	233244	1958-60	
	Rubber gromm			or lead,		022042	10/10 : 11	
	LU 859059				1	233243	1961 Series II m	·
E.E.	Rubber gromm				2	236389	Series IIA mode	ls
55	Rubber gromn	net, main i	harness, in das	h, LU		210(00)		
	858063			••••	2	219680		
	Rubber gromm LU 858063		np cable at fai	n cowl,	1	210000	≻Series II models	
56		,	1 1 7 7 7 6		2	219680		
56	Rubber gromm		-		2	233243	C ' HA I	1
	Rubber gromm		-		2	236389	Series IIA mode	ls
57	Rubber gromm				2	233243	4 off on 109	
)1	Rubber gromm Grommet for fi				2		88 Petrol models	
	Grommet for fi				2	276054	109 Petrol mode	
58					2	276053	Diesel models	
59	Rubber plug fo				2	73198	1 off on L.H.D.	
JŦ	Rubber cover for				1	263158		
	Rubber cover terminals		-		2	246241		
	terminais		•···		2	246241		





PLATE REF.	1 2 3 4 DESCRIPTION	Qty	. Part No.	. REMARKS	
	BODY FLOOR AND SIDES ASSEMBLY		330951		
1	Side and wheelarch complete, R.H	1	330214	•	
2	Side and wheelarch complete, L.H.	1	330215		
3	Rear floor complete	1	330267	•	
4		3			
5	Mounting pad for rear floor cross-member	6	332582		
		12	73979	·	
	Pop rivet \ Fixing cross-member	18			
	Rivet to rear floor	12			
6	Front panel for rear body	1	330301		
	Rivet fixing front panel to wheelarch	4	300789		
7	Capping for body front panel	1	330245		
8	Capping for body top, side, R.H	1	330832		
	Capping for body top, side, L.H	1	330833		
9	Corner strengthening angle	2			
	Rivet \ Fixing	12			
	Pop rivet Sangles	12		•	
	Rivet Fixing front	8			
	Pop rivet capping	8			
	Pop rivet, short Fixing side	16			
	Rivet >and front	16			
	Pop rivet, long corner cappings	2	300781		
	Bolt $\left(\frac{5}{16}^{"} \times 1^{"} \text{ long}\right)$	2	255228		
	Plain washer Fixing front	2	3899		
	Spring washer corner capping	2	3075		
	Nut $\left(\frac{5}{16}''$ U.N.F.)	2	254811		
10	Hood socket complete rear corner, R.H.		330315	•	
10	Hood socket complete rear corner, L.H.		330316	•	
	Rivet, fixing rear sockets at top	0	300783	·	
	Pop rivet, short \ Fixing rear socket	4	300919		
	Pop rivet, long at rear	4	300781		
11	Corner bracket and tailboard cotter, R.H		330233		
•••	Corner bracket and tailboard cotter, K.H		330234		
	Rivet Fixing	. 4	300783		
	Rivet corner brackets	2	300784		
12	Rear protection angle, R.H	1	330224	•	
12	Daniel and L. I. II	1	330225		
	Rivet, short	20	300783		
	Rivet, long Fixing rear protection angle	20	302186		
	Pop rivet Pop rivet	2	300781		
13	ו לי ו	-	330271		
14	Death of the	1	302811		
17	T	7	77707		
15		. ,	330204		
17			330205	·	
	Screw (2 B.A. x ½" long) Fixing cover panels		77869		
	Plain washer to rear	6	3816		
	Spring washer panel and	6	3073		
		6	2247		
16		1	303847		
17	The contract of the contract o		330208	· ·	
17			255206		
	Bolt (1" U.N.F. x 5" long) Fixing	8		C Shair W.	
	Plain washer reinforcement	8		Except Station Wagon	
	Spring washer bracket	8	3074		
10	Nut (1" U.N.F.)	8	254810		
18	Tie bar for spare wheel clamp		302933		



Plain washer, small Fixing 1 3842	DI AME	DOD!				DEMARKS
Plain washer, large Fixing 1 3842 Plain washer, large Fixing 1 2324 Self-locking nut {\f' U.N.F. x \f' long} \	PLATE REF.	1 2 3 4 DESCRIPTION	V Q	ty.	Part No.	REMARKS
Plain washer, large Spring washer Spring		•-)	1	The state of the s	
Spring washer Self-locking nut (\$\frac{1}{2}\$ U.N.F.)			Fixing	1		
Self-locking mut (3" U.N.F.)		Plain washer, large	≻tie bar to	1		
Plain washer Spring washer		Spring washer	pivot bracket	1		
Plain washer Spare wheel 1 3902		Self-locking nut $(\frac{1}{4}"$ U.N.F.)	J	1		Except Station Wagon
Spring washer Clamp 1 3076	19	Wing nut Fixing		1		
Rubbing strip for spare wheel		Plain washer > spare wheel		1		
Pop rivet fixing strip to top capping		Spring washer clamp		1	3076	
Pop rivet fixing strip to top capping	20	Rubbing strip for spare wheel		2	3302 12	
Rivet fixing sealing rubbers to rear body 10 302818				6	300781	
River fixing sealing rubbers to rear body 10 302818	21	Sealing rubber for tailboard		2	333972	
Rubber buffer for tailboard Screw (4 B.A. x ½ long) Fixing buffer A		_	rear body	10	302818	
Screw (4 B.A. \(\frac{1}{2} \) Fixing buffer 4 4023	22	= =		2	330419	
Nut (4 B.A.) Storear body 4 4023			xing buffer	4	77899	
Bracket for tailboard chain Bolt (4" U.N.F. x \$" long) Fixing bracket 4 255206		>		4	4023	
Bolt (\frac{1}{2} \text{ U.N.F. x \frac{1}{2} \text{ long}} \) Spring washer Plain washer Nut (\frac{1}{2} \text{ U.N.F.}) 4 254800	23		•			
Spring washer Plain washer Nut (\frac{1}{2}^* U.N.F.) 4 3840		_				·
Plain washer Nut (\$\frac{1}{4} \cdot \text{Nix} (\$\frac{1}{4} \cdot \text{Nix} \cdot \text{Vi.N.F.})			Fixing bracket			
Nut (\{ \begin{align*}{c} \text{U.N.F.} \) Chain to bracket 2 4042						
Pin			•• Doug			
Split pin Chain to bracket 2 330399	24					·
25	Δ1	<u> </u>				
Sleeve for chain	25					•
Staple for hood strap Screw (2 B.A. x \(\frac{3}{4}'' \) long Fixing 4 77758						\$ - * .
Screw (2 B.A. x 2" long Spring washer Nut (2 B.A.) to body 4 2247						•
Spring washer Nut (2 B.A.) Staples 4 3073 Nut (2 B.A.) Staples 4 2247 28	2.1	-				
Nut (2 B.A.) 1			-	-		
Clip for starting handle and jack handle						·
Pop rivet fixing clips	28					
Drive screw fixing clips	20.		CK Handle			Alternatives
Rear wing stay R.H. front			****			
29 Rear wing stay L.H. front			****			Check before ordering
Rear wing stay, rear Bolt (\(\frac{1}{4}'' \) U.N.F. \(\frac{5}{8}'' \) long) Spring washer Nut (\(\frac{1}{4}'' \) U.N.F. \(\frac{5}{8}'' \) long) Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{5}{8}'' \) long) Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{5}{8}'' \) long) 2 78208 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{5}{8}'' \) long) 2 78208 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{5}{8}'' \) long) 2 78208 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 2 78208 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 2 78208 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 2 78208 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 2 830366 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 4 255295 Diesel models Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 4 255204 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 5 1 2 2 3074 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 5 1 2 2 3074 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 5 1 2 2 3074 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}'' \) long) 5 1 2 3074 Screw (\(\frac{1}{4}'' \) U.N.F. \(\frac{1}{2}''' \) long) 5 1 2 3074 Screw (\(\frac{1}{4}''' \) U.N.F. \(\frac{1}{2}''' \) long) 5 1 2 3074 Screw (\(\frac{1}{4}''' \) U.N.F. \(\frac{1}{2}'''' \) long) 5 1 2 3074 Screw (\(\frac{1}{4}'''''' \) long) 5 1 3074 Screw (\(\frac{1}{4}'''''''' \) long) 5 1 3074 Screw (\(\frac{1}{4}''''''''''''''''''''''''''''''''''	20		****	-		
Bolt (\(\frac{1}{4}\)" U.N.F. x \(\frac{1}{2}\)" long) Spring washer Nut (\(\frac{1}{4}\)" U.N.F.) Bolt (\(\frac{1}{4}\)" U.N.F. x \(\frac{1}{2}\)" long) Screw (\(\frac{1}{4}\)" U.N.F. x \(\frac{1}{2}\)" long) 2 78208 31				-		•
Spring washer Nut (\frac{1}{2}' U.N.F.) Bolt (\frac{1}{4}'' U.N.F. x \frac{5}{6}'' long) Screw (\frac{1}{4}'' U.N.F. x \frac{5}{6}'' long) Screw (\frac{1}{4}'' U.N.F. x \frac{5}{6}'' long) 2 78208	50		••••			
Nut (\frac{1}{2}" U.N.F.)			E':	4		
Bolt (\frac{1}{3}" U.N.F. x \frac{5}{8}" long)		Spring wasner	rixing stays	U ∠		
Screw (\frac{1}{2}" U.N.F. x \frac{8}{2}" long)			-			
31 Cowl for fuel filler			and floor			
Rivet fixing cowl to body side Fuel instruction plate on fuel filler cowl 302222 Fuel instruction plate on fuel filler cowl 302222 Fuel instruction plate on fuel filler cowl 302225 Fuel instruction plate on fuel filler cowl 302225 Fuel instruction plate on fuel filler cowl 302225 Fuel instruction plate on fuel filler cowl 302226 Fuel instruction plate on fuel filler cowl 3030367 Bolt (\frac{1}{4}'' U.N.F. \times \frac{1}{4}'' long) Plain washer Nut (\frac{1}{4}'' U.N.F.) Screw (2 B.A. \times \frac{1}{2}'' long) Plain washer Spring washer Spring washer Nut (2 B.A.) Drive screw 9 302222 1 3030367 Alternatives to 4 lines below. Check before ordering Alternatives to 4 lines above. Check before ordering Alternatives to 4 lines above. Check before ordering Alternatives to 4 lines above. Check before ordering	21			<i>L</i>		
Fuel instruction plate on fuel filler cowl Cover plate for fuel filler	اد		****	١		
330367 330367 330367 330367 330367 330367 340 255204 3840 Alternatives to 4 lines below. Spring washer				9		D:11-1-
Bolt (\frac{1}{4}" U.N.F. x \frac{1}{2}" long)	40		er cowl	1		Liesel models
Plain washer 4 3840 Alternatives to 4 lines below.	32			1	_	•
Spring washer 4 3074 Check before ordering Nut (½" U.N.F.) Fixing cover plate 4 254810 Screw (2 B.A. x ½" long) to body side 4 77869 Plain washer 4 4030 Spring washer 4 3073 Nut (2 B.A.) 4 3823 Drive screw 2 78140				-		
Nut (¼" U.N.F.) Screw (2 B.A. x ½" long) Plain washer Spring washer Nut (2 B.A.) Drive screw String cover plate 4 254810 to body side 4 77869 4 4030 Alternatives to 4 lines above. Check before ordering 78140		l l				4
Screw (2 B.A. x ½" long)				-		1
Plain washer 4 4030 Alternatives to 4 lines above. Spring washer 4 3073 Check before ordering Nut (2 B.A.) 4 3823 Drive screw				4	_	•
Spring washer 4 3073 Check before ordering Nut (2 B.A.) 4 3823 Drive screw 2 78140			to body side	4		
Nut (2 B.A.) Drive screw 4 3823 2 78140		!				1 -
Drive screw 2 78140						
		1			_	J
33 "Land-Rover" nameplate, $7\frac{3}{16}$ " overall 1 332670						•
	33	"Land-Rover" nameplate, $7\frac{3}{16}$ " of	overall	1	33267 0	





PLATE REF.	1 2 3 4 DESCRIPTION	ON	Qty.	Part No.	REMARKS
34	Registration plate		1	239772	
	Pop rivet fixing plates		6	300919)
	Bolt (5 U.N.F. x 7 long))	12	255227	7
	Bolt (5 " U.N.F. x 3" long)	Fixing	2	255226	;
	Spring washer	body to	12	307 5	
	Shim washer	chassis	As require	d 3830)
	Nut (# U.N.F.)		18	254801	
	Nut (15" U.N.F.)	J	4	254811	



BODY COMPLETE ASSEMBLY, REAR Side and wheelarch complete, R.H. Side and wheelarch complete, L.H. Rear floor, complete Cross-member and pads for rear floor	y. Part No. 1 330958 1 330663 1 330664	
Side and wheelarch complete, R.H. Side and wheelarch complete, L.H. Rear floor, complete	1 330663	
Side and wheelarch complete, L.H Rear floor, complete	1 330664	
Rear floor, complete		
	1 330617	
	6 330265	
5 Mounting pad for rear floor cross-member 12		
Rivet fixing pad to cross-member 2		
Pop rivet Fixing cross-member 3		
Rivet to rear floor 2.		
	1 330243	
Rivet fixing front panel to wheelarch 12		
7 Capping for body, front panel	1 330245	
8 Capping for body top, side, R.H	1 330840	
Capping for body top, side, L.H	1 330841	
	2 330442	
9 9 9	2 300784	
	2 300781	
	8 300783	
> ~	6 300781	
Rivet Fixing side 2		
Pop rivet, short > and front 2		
- · · · · · · · · · · · · · · · · · · ·	2 300781	
	2 255228	•
110	2 3899	· · · · · · · · · · · · · · · · · · ·
	2 3075	
	2 254811	
, in (10)		
	1 330315	
	330316	
g	2 300783	
	4 300784	
	2 302186	
	4 300781	•
	4 300919	
Rear protection angle, R.H	330224	
***** F	1 330225	
1	300783	
	2 302186	
Jş	2 300781	
12 Corner bracket and tailboard cotter, R.H	1 330233	
· · · · · · · · · · · · · · · · · · ·	330234	
	4 300783	
14100) 212332	2 300784	
Protecting strip at rear of floor	1 330145	•
211/e eeren 1-1111B ett.b	7 77704	
14 Rear mounting angle	1 330468	
15 Cover panel R.H. for rear lamps	1 330204	
Cover panel L.H. for rear lamps	1 330205	
	6 77869	
/ , ,	6 3816	
1 0	6 3073	•
J	6 2247	
16 Strengthening member for spare wheel mounting		
(4)	3 255206	
(3 3900	
	3 3074	
17 Nut plate J capping	1 330824	<u> </u>




PLATE REF.	1 2 3 4 DESCRI	PTION	Qty.	Part No.		REMARK	is
18	Spare wheel housing		1	330602			
	Screw (2 B.A. $x \frac{3}{4}$ ")	Fixing spare wheel					
	long)	housing and	22	77887			
	Plain washer	strengthening meml	oer 22	3816			
	1	to body side and	22	3073			
		wheelarch box	22	2247			
19	Tie bar for spare wheel		1	302933			
	Bolt (¼" x 1½" long)	Fixing	1	256203			
	Plain washer	≻tie bar to	4	3968	•		
	Spring washer	strengthenin	· -	2284			
	Self-locking nut (‡" U.1	1 -	16 <u>2</u>	252220			
20	Clamp for spare wheel		i	303847			
20	Plain washer	****	1	3982			
21		g spare wheel clam	. 1	302934			
21	Spring washer	ig spare wheel clain	P 1	3076			
	Spare wheel rubbing str		2	332672			
			2				
	Rubbing strip			332674			
	Rivet fixing rubbing		4	78248			
22	Rivet fixing bracket to o		4	78248	-		
22	Cover plate for redunda			330616			
	Screw (2 B.A. x ¾ long	· •	20	77887			
	Plain washer	cover plate to	20	3816	• '		
	Spring washer	wheelarch	20	3073			
	Nut (2 B.A.)	J box	20	2247			
23	Sealing rubber for tailb		2	333972			
	Rivet fixing sealing rub		10	302818			
24	Rubber buffer for tailbo	_	2	330419			:
	Screw (4 B.A. $x \frac{1}{2}$ " long		4	778 99			
	Nut (4 B.A.)	∫ to rear body	4	4023			
25	Tailboard chain bracket		2	302825			
	Bolt (¼" U.N.F. x 🖁" loi	ng)] Fixing	4	255206			
	Spring washer	≻chain bracket	t 4	3074		•	
	Plain washer	to	4	3840			
	Nut (4" U.N.F.)	body	4	254800			• •
26	Chain for tailboard		2	330399			
2 7	Clevis pin \ Fixing cha	ain	2	302828			•
•	Split pin ∫to bracket	:	2	4042			
28	Sleeve for chain		4	330422			
29	Locker lid for wheelard	h box	2	304401			
30	Hinge for locker lid	1744	4	303875			
	Pop rivet fixing hinge to	o lid	8	300781			
	Bolt (1" U.N.F. x 8" lor		4	255206			
	Plain washer	hinge to	4	3968			
	Spring washer	wheelarch	4	3074	•		
	Nut (1" U.N.F.)	box	4	254800			
31	Hasp for locker lid	, DOR	2	303871		•	
	Rivet fixing hasp to lock		4	300789			
32	Turnbuckle for locker li		2	300851			
	Screw (2 B.A. x ½" long		6	77784	4		
	Spring washer	buckle to	6	3073			-
	Nut (2 B.A.)	wheelarch box	6	2247			
	rati (& D.M.)	J wheelarch box	U	LL*11			







PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
33	Tread plate, wheelarch box, top	4	304871	TITTAL MILES
34	Tread plate, vertical, front panel	4	330717	
35	Tread plate, horizontal, front panel	1	308206	
36	Tread plate for rear floor and wheelarch		330	
	sides	6	330615	
	Drive screw Fixing tread plates	62	78006	
	Rivet, long >to body	31	300783	
	Rivet, short J and floor	20	300789	
	Tread plate for locker floor	2	334179	
	Pop rivet fixing tread plate to locker floor	14	78248	
37	Clip for starting handle and jack handle	5	508035	
	Pop rivet fixing clips	5		Alternatives.
	Drive screw fixing clips	5		Check before ordering
	Bracket for starting handle	4	332736	
	Bracket for starting handle and jack handle	1		>109 Station Wagon
	Drive screw Fixing brackets to base	10	78153	
	Packing washer \int of centre seat	8	4171	
	Rear wing stay	2	332521	
	Stay R.H. Wheelarch panel	1	332453	
38	Stay L.H. \int to body	l 1	332454	
50	Cover plate for fuel filler	1	330366	Pr 1 11
	Fuel instruction plate on fuel filler cowl Rivet fixing cover plate to body side	1	502951	Diesel models
39	Rubber grommet for access hole in wheelarch	9	302222	
,,	الممامية	2	302954	
	Personal I d	2	331262	
	Rivet Fixing bracket to	12	302186	
	Pop rivet front panel capping	8	300782	
40	"Land-Rover" nameplate	1	332670	
41	Registration plate	1	239772	
	Pop rivet fixing plates	6	300919	
	Bolt (16" U.N.F. x 7" long)	18	255227	
	Drive screw	4	69310	
	Spring washer Fixing body	10	3075	
	Shakeproof washer to chassis	8	72614	•
	Shim washer	As required	3830	
	Nut (18" U.N.F.)	18	254801	




ar re-		ILO	OR, FROMI WINGS AND BONNEI
PLATE REF.		Qty.	Part No. REMARKS
1	Seat base and floor	1	333702 Two locker lid type
	Bolt plate for seat cushion support	1	330908
	Rivet fixing bolt plate	1	302581
2	Lid for tool locker	1	330342 For one locker lid type seat base Check before
	Lid for seat base, centre	. 1	332522 For two locker lid type seat base ordering
	Spire nut \ \rangle For	2	302532 Required when centre P.T.O. or hydraulic front
	Special screw centre lid	2	320045 winch is fitted to vehicle with two locker lid type
		₹	seat base
3	Cover panel for petrol tank	1	330352
4	Hinge for lids	2	303875
•	Pop rivet fixing hinges to lid	4	300781
	Set bolt (‡" U.N.F. x §" long) \ Fixing hinge		255206
	Spring washer to seat base	2	3074
	Nut (\frac{4}{4}\text{" U.N.F}) fixing hinge to seat base	2	
5	77 6 7 1 111	2	254810 Centre lid
,		1	303871
4	Rivet fixing hasp to lid	2	78248
6	Turnbuckle for locker lid	1	300851
	Screw (2 B.A. x ½" long) Fixing	3	77784
	Spring washer turnbuckle	3	3073
	Nut (2 B.A.) to heel board	3	2247
	Lid for seat base, outer	1	333698*)
	Hasp for locker lid	. 1	303871
	Pop rivet fixing hasp to lid	2	78248 For two locker lid type seat base. Check before
	Turnbuckle for locker lid	1	300851 ordering
	Pop rivet fixing turnbuckle to heelboard	2	78248
	Grommet for redundant holes in lid end panel	2	334044
7	Centre cover panel complete	1	For one locker lid type seat
	Centre cover panel complete	1	33088! When centre base. Check before
			P.T.O. is fitted ordering
	Set bolt (1" U.N.F. x 5" long) Tixing	6	255206
	Plain washer >panels to	6	3840 >12 off on one locker lid type
	Spring washer seat base	6	3074 Silver one locker ind type
	Cantro tool trov	1	332505*)
	Set screw (2 B.A. x ½" long) Fixing	4	77869
	Spring washer tool tray	4	3073
	Plain washer to seat base	4	3816
	Support strip for contro locker	1	333607*
	Pop rivet, fixing strip to heelboard	4	78248
	Reinforcement bracket, rear, for locker floor as		
	battery tray	1 1	332509* >2\frac{1}{4} litre Diesel
	Reinforcement bracket, front, for battery tray	I	332509* >2\frac{1}{4} litre Diesel 332518*
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long) \bigcap Fixing front brain	I akat 3	
	Spring washer to heelboard and		255206 3074
	Nut (‡" U.N.F.)		
		3	254810
	Reinforcement bracket, outer, for battery tray		332487*
	Bolt (\frac{1}{4}" U.N.F. \times \frac{5}{8}" long) \text{Fixing outer}	4	255206
	Spring washer bracket to	4	3074
	Nut (‡" U.N.F.) front bracket	4	254810
	Pivot bracket for battery tie rod	2	320055 * J




Stiffening angle for locker floor, front 2 332510* Bolt, ¼" U.N.F. x §" long) Spring washer Nut (¼" U.N.F.) Bolt (¼" U.N.F. x §" long) Spring washer Nut (¼" U.N.F. x Spring washer Nut (¼" U.N.F. x Spring washer Nut (¼" U.N.F.) Spring washer Nut (¼" U.N.F.) Bolt (¼" U.N.F.) Fixing outer reinforcement bracket 4 255206 Spring washer Nut (¼" U.N.F.) Bolt (¼" U.N.F.) Fixing outer reinforcement bracket 4 255206 to rear of 4 3074 Nut (¼" U.N.F.) Spring washer Nut (¼" U.N.F. x §" long) Fixing rear rein- Spring washer Nut (¼" U.N.F.) Journal of the property	REMARKS
Bolt, \(\frac{4}''\) U.N.F. x \(\frac{5}{8}''\) long) Spring washer Nut (\(\frac{1}{4}''\) U.N.F.) Bolt (\(\frac{1}{4}''\) U.N.F. x \(\frac{5}{8}''\) long) Spring washer Nut (\(\frac{1}{4}''\) U.N.F. x \(\frac{5}{8}''\) long) Spring washer Nut (\(\frac{1}{4}''\) U.N.F.) Bolt (\(\frac{1}{4}''\) U.N.F. x \(\frac{5}{8}''\) long) Spring washer Nut (\(\frac{1}{4}''\) U.N.F. x \(\frac{5}{8}''\) long) Fixing rear rein- forcement bracket to 2 3074 Nut (\(\frac{1}{4}''\) U.N.F.) Insulating pad, battery stowage 1 334617	
Spring washer Spring washer Nut (\frac{4}{''} U.N.F.) Spring washer Teinforcement brackets 12 3074	
Spring washer reinforcement brackets 12 3074	
Nut (\frac{1}{4}" U.N.F. x \\ \frac{8}{8}" long) \\ Spring washer \\ Nut (\frac{1}{4}" U.N.F. x) \\ \frac{1}{1000} \\ Spring washer \\ Nut (\frac{1}{4}" U.N.F.) \\ Spring washer \\ Nut (\frac{1}{4}" U.N.F. x \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
Bolt (\(\frac{1}{2}\)" U.N.F. x \\ \frac{8}{3}\" long\) \\ Spring washer \\ \text{Nut (\(\frac{1}{4}\)" U.N.F.\) \\ \left\) \\ locker floor \\ \text{Spring washer} \\ \text{Bolt (\(\frac{1}{2}\)" U.N.F. x \(\frac{8}{3}\)" long\) \\ \text{Fixing outer} \\ \text{litre Diesel} \\ \text{25206} \\ \text{Spring washer} \\ \text{Spring washer} \\ \text{Nut (\(\frac{1}{4}\)" U.N.F.\) \\ \text{forcement bracket to 2} \\ \text{3074} \\ \text{Nut (\(\frac{1}{4}\)" U.N.F.\) \\ \text{outer bracket} \\ \text{254810} \\ \text{Insulating pad, battery stowage} \\ 1 334617} \end{array}	
Spring washer Spring washe	
Spring washer to rear of 4 3074 2½ litre Diesel	
Nut (½" U.N.F.) locker floor	
Spring washer forcement bracket to 2 3074 Nut (‡" U.N.F.) outer bracket 2 254810 Insulating pad, battery stowage 1 334617	
Spring washer forcement bracket to 2 3074 Nut (‡" U.N.F.) outer bracket 2 254810 Insulating pad, battery stowage 1 334617	
Insulating pad, battery stowage 1 334617	
* · · · · · · · · · · · · · · · · · · ·	
Bifurcated rivet Fixing 2 73979	·
Plain washer pad 2 3851	
8 Extension panel R.H. at seat base end 1 330359 2 off on one locker lid	type
Extension panel, L.H., at seat base end 1 333693 For two locker lid type	
Bolt (‡" U.N.F. x \$" long) \(\) Fixing 9 255207	•
Plain washer > seat base 9 3840	
Spring washer to 9 3074	
Nut (‡" U.N.F.) rear body 9 254800	
Screw (1" U.N.F. x 3" long) For redundant 2 78215	
Spring washer \rightarrow holes in 2 3074	
Nut (½" U.N.F.) rear stiffener 2 254810	
9 Rubber cover for hand brake 1 330347	
10 Retainer for rubber cover \(\) Fixing cover \(1 \) 330348	
Drive screw ∫to heelboard 6 78417	
11 Cover plate for hand brake slot 1 330349	
Drive screw fixing retainer 6 78137	
Sill channel R.H. front 1 330380	
12 Sill channel L.H. front 1 330381	
13 Securing bracket for sill channel 4 330389	
Bolt (‡" U.N.F. x ¾" long) 8 255207	÷
Plain washer Fixing bracket 16 3821	
Spring washer to sill channel 8 3074	
Nut (‡" U.N.F.) 8 254810	
Bolt plate 2 332603	
Plain washer Fixing sill channel 4 3841	
Spring washer to dash 4 3075	
Nut (½" U.N.F.) 4 254811	· ·
14 Mounting bracket for sill channel to rear body 2 330387	
Bolt $(\frac{5}{16}" \text{ U.N.F. x } \frac{3}{4}" \text{ long})$ Fixing 4 255226	
Plain washer mounting 8 3841	
Spring washer bracket to 4 3075	
Nut $(\frac{5}{16}" U.N.F.)$ sill channel 4 254811	
Bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long) 4 255207	
Plain washer Fixing mounting 8 3840	
Spring washer bracket to body 4 3074	•
Nut (½" U.N.F.) 4 254810	




-	SEAT BASE, SEATS, PRONT	TLO	
PLATE REF.		Qty.	Part No. REMARKS
	Sill panel, R.H. front	1	330326
15	Sill panel, L.H. front	1	330327
	Sill panel, R.H. rear	1	330336) _{gg}
16	Sill panel, L.H. rear	1	330337 f 00
	Sill panel, R.H. rear	1	330585
	Sill panel, L.H. rear	1	330586 \(\)
	Bolt (1" U.N.F. x 5" long) Fixing sill panel	8	255206
	Plain washer >to bracket	16	3821
	Spring washer on sill	8	3074
	Nut (¼" U.N.F.) channel	8	254810
17	Fixing plate	2	330333
.,	Plain washer Fixing sill	4	3821
	Spring washer panels together	4	3074
	Nut (¼" U.N.F.)	4	254810
		10	255206 14 off on 109
	· · · · · · · · · · · · · · · · · · ·	20	3840 28 off on 109
	Plain washer sill panel		3074 14 off on 109
	Spring washer to wing	10	
10	Nut (\frac{1}{a}" U.N.F.) \text{and body}	10	254810 14 off on 109
18	Front floor complete	1	332968
	Grommet for gearbox cover	1	334189 2 off on 1961 models onwards
	Special bolt Fixing front floor	11	320045
	Plain washer, small to combon cover	7	3900
	Plain washer, large and beelboard	4	3817
	Spire nut	11	302532
	Special set bolt Fixing	5	78208
	Spring washer \rightarrow front floor	5	3074
	Plain washer J to dash	5	3900
*	Special bolt Fixing	4	78210
-	Plain washer > front floor	8	3900
	Spring washer to sill	4	3074
	Nut $\binom{5}{16}$ U.N.F.) channels	4	254810
19	Inspection cover for front floor	1	303829)
	Screw (1" U.N.F. x 3" long) Fixing	1	78212
	Plain washer inspection	3	3912
	Spring washer >cover	1	2284
	Nut (½" U.N.F.) to centre	1	254800
	Locknut (1" U.N.F.) cover panel	1	254850 >1958-60
20	Stud plate for inspection cover wing nut	1	303824
_0	Rivet fixing stud plate	2	3668
21	Wing nut	1	301074
	Plain washer, small >Fixing inspection cover	-	3976
	Plain washer, large	1	3817
22	Seal for transfer gear lever	1	303821
23	Retainer for transfer lever seal) Fixing	1	303817
وبت	Special bolt >seal to	3	320045
	Special nut Special nut	3	302532
21	D 11 17 1	1	301437
24 25	=:	1	303828
4)	Cover plate for operating rod	1 2	302533
	Special bolt	2	3821
	Plain washer Fixing cover plate	2	302532
	Special nut	Z	JUL/JL .




	SEAT BASE, SEATS, FRONT	110	JOR, FROM WINGS AND BONNET
PLATE REF.	1 2 3 4 DESCRIPTION	Qty	
26	Gearbox cover complete	1	330069
	Special bolt	Ď,	303750
	Plain washer >Fixing gearbox cover	4	3900
	Special nut	4	302532
27	Seat squab, trimmed, outer	2	331042 \ 00
	Seat squab, trimmed, centre	1	331049 \int \frac{60}{30000000000000000000000000000000000
	Seat squab, trimmed, driver's	1	331138
	Seat squab, trimmed, passenger's, outer	1	331126 > 109
	Seat squab, trimmed, centre	1	331127)
28	Spring case for outer squab	2	2 331022
	Spring case for centre squab	1	331023
29	Frame for outer squab, non-adjustable	2	331744* 1 off on 109
	Frame for outer sqab, adjustable	1	331689 109
	Frame for centre squab	1	331745*
	Plain washer) Fixing	9	
	Drive screw squab cover	9	
	Special stud Fixing squab		331170)
	Split pin >supports on	6	>4 off on UP
	Plain washer, thin, ¼" hole non-adjustab	_	
	Plain washer, 15" hole seats	2	
	Special bolt Fixing squab		_
	Plain washer, thin, ¼" hole >supports on	2	
	Plain washer, 5 hole adjustable	2	[
	Plain washer, thick seats	2	
	Strap retaining front squab	3	
	Strap retaining front squab, non-adjustable		
	Plain washer \ Fixing strap	3	
	Drive screw to squab	3	>
30	Buffer for seat squab, non-adjustable seat	4	2
20	Plain washer \ Fixing buffer	4	
	Drive screw to squab	4	
31	Seat cushion trimmed, outer, non-adjustable	2	
ار	Seat cushion trimmed, centre	2	331724 Metal base type
32	Spring case for outer cushion, non-adjustable	1 In 2	• • • • • • • • • • • • • • • • • • •
26	Spring case for outer cusmon, non-adjustable	IC 2	before ordering
	Spring case for outer cushion, non-adjustable	l. 2	
	Spring case for outer cusmon, non-adjustable	ie 2	before ordering
	Saring and for some audion	1	331031 For cushion with canvas base. Check before
	Spring case for centre cushion	1	ordering
	Saring and for anything	1	331728 For metal base type cushion. Check before ordering
33	Spring case for centre cushion	2	· · · · · · · · · · · · · · · ·
ככ	Frame for outer cushion, non-adjustable Frame for centre cushion		·
		1 2	<
	Base for outer cushion, non-adjustable Base for centre cushion	1	
		I	
,	Clip fixing cover to frame or base	58	
	Protective capping, R.H. For outer	6	> Kor metal bace time cuchion
	Protective capping, L.H.	6	- I hack before ordering
	Drive screw fixing capping J cushions	24	78140 16 off on 109



TE 1234 DESCRIPTION	ON	Qty.	Part No.	REMARKS
Strap retaining front cus	hion, outer, nor			
adjustable		2	331272	1 off on 109
Strap retaining front cushion	n, centre	1	331273	
Plain washer \(\) Fixing		3	4203 \	2 off
Drive screw strap		3	77704	on 109
Rubber buffer for seat cushi	ion	6	304125 ั้า)
Spire nut		6	,	>4 off on 109 → For metal base type cushion
Plain washer Fixing but	T er	6	4030	Check before ordering
Drive screw	101	6	78434	Shook Soloto Silaning
Seat cushion, adjustable, trimi	med outer driver	_		Metal base type
		5 I	331114	Wiciai base type
Spring case for driver's cusl		! 1		For cushion with canvas base. Check
Frame for driver's cushion		l		before ordering
Base for driver's cushion		أ	331720	Metal base type cushion. Check before
				ordering
Clip fixing cover to frame o	rbase	20	331071	
Rubber buffer		4	312027	
Plain washer \ Fixing buffe	er	4		For cushion with canvas base. Check
Drive screw \int to cushion		6	69310	before ordering
Protective capping, R.H., fr	ont)	1	331716	
Protective capping, L.H., fr		1	331717	
Protective capping, R.H., re		s 1	331718	Metal base type cushion. Check before >1
Protective capping, L.H., re		1	331719	ordering
Drive screw fixing capping	an Casanon	8	78140	
Front seat slide with control	J	1	_	R.H.D.
Front seat slide with control		1		L.H.D.
Front seat slide without control		I 1	331103	Lillip
_		I	78358	
Screw (¼" U.N.F. x ¾" long)	_		3833	ł
Plain washer	to seat supports	6	3074	
Spring washer	≻and seat	8		
Nut (1 U.N.F.)	box	8	254810	
Frame for adjustable seat cusl		I	331074	
Spring washer Fixing fra	me	4	3075	ł
Distance washer to		4	4094	Į.
Nut $\binom{5}{16}$ U.N.F.) seat slides		4	254811	†
Rubber stop for squab in fran		2	331083	J.
Stud for cushion and squab re	etaining straps	6	320345	
Screw (2 B.A. x 1" long)		3	78120	2 off on 109
Screw (2 B.A. x $1\frac{1}{4}$ " long) >1	Fixing studs to sea	ıt 3	77993	2 off on 109
	base and rear body		3073	4 off on 109
Nut (2 B.A.)	•	6	2247	4 off on 109
Grommet for redundant hole	in seat base	1	307220	109
Support for front seat cushion		1	331007	
Support for front seat cushion		1	331008	
5 Support for front seat, centre		2	331006	l off on 109
Retaining bracket for front se		6	331818	
Bolt (\frac{1}{4}" U.N.F. x \frac{5}{8}" long)		26	255207	· · · · · · · · · · · · · · · · · · ·
·- · · · · · · · · · · · · · · · · · ·	supports and	28		>17 off on 109
1		28	3074	l .
Spring washer Nut (‡" U.N.F.)	extension panels to seat base	26 28	254810	1



		ASE, SE		NON		OR, TRO	
PLATE REF.	1 2 3 4	DESCRIP	TION _		Qty.	Part No.	REMARKS
	Front wing, t	op, R.H.		••••	1	330424	R
36	Front wing, t	op, L.H.			1	<i>33</i> 0425 J	,
	Front wing, t	op, R.H.		****	1	330530 \ 10) 9
	Front wing, t				1	330531 J	
		l and number			ront l	330436	
37	Front pane	l and number	plate, L.H	·I. ∫ wing	1	330437	
	_	nt L.H. wing	valance fo	or redunda	ınt) .	
	exhaust			••••	1	L	961 models onwards
		ing cover plate		****	4	ر 78248	
	-	or front wing,			1	330426	
38	_	or front wing,	_		1	330427	
		.F. x 🖁 long)			11	255206	
	Plain washer		>wing or		22	2213	
	Spring washe		panel t		11	3074	
	Nut (‡" U.N.		J wing to		11	254810	
		lt (岳" U.N.F.	x §" long)) Fixing			lternatives to three lines below.
	Plain washer			wings	8		heck before ordering.
	Spring washe	r		}to	8	3075	
	Special bolt			scuttle		78392) A	Iternatives to two lines above.
	Plain washer			side	8	יישל עכסכ	heck before ordering.
	Spire nut		_	J pillar	8	ן כניכסו	
39		L.H. side, 2-b			1	330147 \ A	
		L.H. side, 3-b	olt type	Fixing	1		heck before ordering
-	Bolt (‡" U.N		,	wings to			off with 3-bolt fixing plate
	Spring washe			grille	8		off with 3-bolt fixing plate
	Plain washer,			panel	14		off with 3-bolt fixing plate
	Nut (‡" U.N.		ر ا	ļ	8		off with 3-bolt fixing plate
	• • • • • • • • • • • • • • • • • • • •	.F. x 5" long)		_	2	255206	
	Plain washer		valance		4	2215	
	Spring washe		steering	_	2	3074	
	Nut (1 U.N.			t bracket	2	254800	
4 0	Bottom panel	l for wing vala	nce, L.H.		1	330443 A	ll 88 Petrol and Series IIA 88 2½ litre Diese
						200524 4	models
	Bottom panel	l for wing vala	nce, L.H.	••••	1	330534 A	ll 109 21 litre Petrol and Series IIA 109 21 litre
						22.4422	Diesel models
		х ½″ long)] !		,	4	234603	
	Spring washe	I .	ottom pa		4		all petrol models and Series IIA 21 litre Diese
	Plain washer	I .	to L.H. w	ıng	8		nodels
	Nut (2 B.A.)		valance		4	3823	
		or front wing,					R.H.D.
		or front wing,					"H.D.
41		or front wing,		10-4	l		A.H.D.
		or front wing,	_		1		H.D.
	\-	.F. $x \frac{5}{8}$ long)	_		10	255206	
	Spring washe		≻mudsh		10	3074	
	Plain washer		to angl		13	3900	
	Nut (‡" U.N		on win	_	10 • •	254810 255204	
		$F. x \frac{1}{2}'' long)$		mudshield		255204	
	Spring washe	er	to dash		8 ·	3074	
	Plain washer	E. /	steerin	-	8 8	3817 254810	
	Nut (‡" U.N	.г.)	J cover l	OOX	8	254810	,



	SEAI	DASE,	SEA I	., r	KONI	LT	.UC	JK, FK	ONI	мписэ	AND	DUNNEI
PLATE REF.	1 2 3	4 DE	SCRIPTI	ON		Q	ty.	Part No.			REM	ARKS
42		ox for steer	ing unit, F	₹.H.			1	330459	R.H.D),		
		ox for steer	_				1	330460	L.H.D).		
		U.N.F. x }					1	255204				
	Plain wa	sher	`	Fixing	cover box	ĸ	1	4071				
	Spring v	washer		to mud	lshield		1	3074				
		U.N.F.)	J				Ţ	254810				
		U.N.F. x	『long) う	Fixing			1	255204				
	Spring		. "}	-cover b	ox to		1	3074				
		U.N.F.)	-	wing v	alance		1	254810				
43		front wing				****	2	332581				
	_	U.N.F. x	_	Fixing			4	255206				
	Spring		,	stay to	_		4	3074				
		U.N.F.)	Í	and da	_		4	254810				
		, R.H.) F	ر or rear				1	330067				•
44			wing				1	330068				
		U.N.F. x		Fixing			6	255206				
	Plain w		,5	≻rear en			12	2215				
	Spring			front v			6	3074				
	-	U.N.F.)		to brac	-		6	254810				
45	Fixing 1		۱ آ				2	330333				
	Plain w	-	Fixing b	rackets			4	3840				
	Spring	washer	to dash				4	3074				
		U.N.F.)	j				4	254810				
		complete	,				2	272244	1 off o	n Export mo	dels	
46		or only	••••			•	2	279880		•		
47		for mirror					2	262658				
	Nut ()				4	2827				
		washer, sm	all Fix	ing mir	ror to win	g	2	2219				
		washer, lar		~		Ü	2	2851			•	
48		top panel	·		****		1	330543	88 Sta	andard mode	l	
		top panel	****				1.	330126	De-lux	xe bonnet sta	andard on	all 109 models and 8
		• •								ion Wagon		
	Bonnet	top panel					1	330812		_	cessed for	spare wheel carrier.
										ional on 109		
49	Hinge f	or bonnet,	L.H.				1	330139	_			
50	-	or bonnet,					1	330138				
		'U.N.F. x		Fixing			8	255206				
	Spring			hinges	to		8	3074				
		'U.N.F.)		_	t panel		8	254810				
51		pin for bon	net catch		-		i	332625				
52		for bonnet					1	330548	88 Sta	andard mode	ls	
•	Bracket	for bonnet	striker				1	330132	For us	se with bonn	et 330126	
		for bonnet					1	330648		se with bonn		
	Plain w) Fix	king strike	er	4	383 0				
	Spring				cket to		4	3075		4		
		t (5″ U.N.	F. x ¾" lor		nnet		4	255226				
		114	*	J.J								




PLATE REF.	1 2 3 4 DESCRIPTI	ON C	ty.	Part No.	REMARKS
53	Control for bonnet		1	33 2401	
	Washer plate for bonnet control	ol	1	332400	
	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long)	Tixing control to	2	255206	
	Plain washer	∫radiator grille	2	3840	
54	Prop rod for bonnet	·	1	330599	
	Bolt (5 U.N.F. x 11 long))	1	255229	
	Plain washer	Fixing	2	344 6	•
	Plain washer	≻prop rod	1	3830	· .
	Spring washer	to bonnet	1	3075	
	Locknut (5 " U.N.F.) .		2	254861	
	Bolt (‡" U.N.F. x ‡" long)] [Tixing	2	255207	•
	Plain washer	prop rod to	4	2215	
	Spring washer	ving valance and	2	3074	
	Nut ($\frac{1}{4}$ " U.N.F.)	grille panel	2 .	254810	





PLATE	TAILBOARD, D		AND SIDE SCREENS
REF.	1 2 3 4 DESCRIPTION	Qty.	
1	TAILBOARD ASSEMBLY]	330952
2	Top capping for tailboard	1	330416
	Pop rivet, short Fixing tailboard	8	300919
	Pop rivet, long ∫top capping	8	300781
3	Tread plate for tailboard	4	304874
	Pop rivet \ Fixing	2	300781
	Rivet ∫ tread plate	14	300789
4	Sealing rubber, bottom, for tailboard	1	303975
	Rivet fixing sealing rubber to rear body	and	
	tailboard	8	302818
5	Hinge for tailboard, R.H	1	330411
6	Hinge for tailboard, L.H	1	330412
	Spring washer	1	2289
	Distance washer > Retaining tailboard	4	4171
	Plain washer hinge to chassis	j	3895
	Split pin	1	3896
	Set bolt $(\frac{1}{4}$ " U.N.F. x $2\frac{1}{8}$ " long Fixing	6	253887
	Plain washer	12	3 821
	Spring washer to	6	3074
	Nut (‡" U.N.F.) J tailboard	. 6	254810
•	Hook for tailboard chain, R.H.	1	3 32445
7	Hook for tailboard chain, L.H.	[33244 6
8	Locking plate for tailboard	2	330409
	Bolt (½" U.N.F. x 23" long) Fixing lock	_	253888
	Spring washer >plate and h		3074
	Nut (‡" U.N.F.)	1 4	254810
	FRONT DOOR ASSEMBLY, R.H	1	330076 Two-piece door
9	FRONT DOOR ASSEMBLY, L.H	1	330077 Full length door. Includes side window glasses
	FRONT DOOR ASSEMBLY, R.H	1	22411 Cand fivings on Pages 301 and 303
	FRONT DOOR ASSEMBLY, L.H	1	332412)
	Top capping for door, R.H	1	330122
10	Top capping for door, L.H	1	330123 Two-piece door only
	Pop rivet fixing cappings	18	78248)
	Pop rivet fixing door outer panel at top	6	300919
	Waist moulding, R.H]	333717
	Waist moulding, L.H ,	1	333718
	Special bolt	8	302533 Full length door
	Plain washer Fixing moulding to door	8	2630
	Special nut	8	302532
	Hinge complete, R.H. upper]	330115
11	Hinge complete, L.H. upper	l	330116
	Hinge complete, R.H. lower	l	330117
12	Hinge complete, L.H. lower]	330118
13	Special bolt	1.	330953
14	Cone bush	1	330954
15	Spring For door hinge	1	330955
16	Lockwasher	1	330956
17	Nut	1	330957
	Bolt (5 U.N.F. x 2" long)	8	256226
	Plain washer Fixing hing		3966 4 off on Station Wagon
	Spring washer to doors	8	3075
	Nut (16" U.N.F.)	8	254811 4 off on 109 Station Wagon
	Nut plate	. 2	333710 109 Station Wagon



<u> </u>	TAILBOARD, D		
PLATE RFF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
	DOOR LOCK AND MOUNTING		
	ASSEMBLY, R.H	1	330111
•	DOOR LOCK AND MOUNTING		
	ASSEMBLY, L.H	1	330112
18	Mounting plate for door lock	2	333080
	Door lock, R.H	1	330113
19	Door lock, L.H.	1	330114
20	Washer, handle to cover	4	302859
20	Handle, R.H	1	307977
21	Handle, L.H.	i	307978
22	Bracket for door handle	2	302854
LL	Screw (2 B.A. x ½" long)	12	- 313858
	Spring washer Fixing lock	12	3073
	Plain washer together	8	3685
	Nut (2 B.A.)	12	2247
	Rivet	8	302222
	Special bolt Fixing door lock	8	78216 4 off when screw retainer is fitted
	Screw retainer > mounting to door	4	332732
	Spring washer	8	3074
	Nut (4" U.N.F.)	8	254800
	Drive screw, fixing lock assembly to door	2	77903
24			330536
24	Seal for door, front upper	2 2	72626
	Drive screw Fixing seal Rivet to screen	6	302818
	<u> </u>	1	330898
25	Seal for door, front lower, dash R.H	[
25	Seal for door, front lower, dash L.H	I	330899
26	Seal for door, rear lower, body R.H	J	330539
26	Seal for door, rear lower, body L.H	1	330540
27	Seal for door, bottom, sill	2	330542
20	Rivet fixing lower and bottom seals	48	302818
28	Support bracket at door striker	2	330146 88
	Support bracket at door striker, R.H.	!	332484
	Support bracket at door striker, L.H.	I	332485 5 107
	Bolt (½" U.N.F. x ½" long)	8	255206
	Spring washer Fixing	. 8	3074
	Plain washer, small support bracke		3840 3900 109
	Plain washer, large to body	. 4	
20	Nut (<u>1</u> " U.N.F.)	8	254810
29	Striking plate for door lock	2	333140
	Bolt ($\frac{1}{4}$ " U.N.F. $x \frac{5}{8}$ " long)	4	255206
	Plain washer Fixing striking		3840
	Spring washer plate to body	4	3074
	Nut (‡" U.N.F.)	4	254800
20	SIDE SCREEN ASSEMBLY, R.H.	I	330157 Two-piece door only
30	SIDE SCREEN ASSEMBLY, L.H.	I	330158
31	Fixed window, front	2	330159
32	Retainer for window	2	330198
22	Drive screw fixing retainer	10	78140
33	Sliding window, rear	2	330160
34	Sealing rubber for front edge of sliding win		330660
35	Channel for sealing rubber	2	330661





PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
36	Buffer for sliding window at top	2	330162	
	Plain washer \(\) Fixing buffers and	2	3886	
	Drive screw Schannels to frame	2	78160	
37	Filler, top and bottom \ For	4	33 0202	
3 8	Filler, rear Swindows	2	330203	
39	Channel top	2	332749	
40	Channel, bottom	2	332750	
41	Channel, rear	2	332746	
	Drive screw fixing channel	26	77707	
42	Sealing strip for sidescreen	2	330163	
	Pop rivet Fixing	10	300781	
	Plain washer sealing strip	10	3912	Two-piece door only
	Plain washer Fixing	4	3843	
•	Spring washer >side screen	4	3077	·
	Nut $(\frac{7}{16}$ U.N.F.) to door	4	254813	
•	Set bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{2}{8}"$ long) Fixing door	- 8	255227	·
	Spring washer	sh 8	3075	

303



	DASH, WINDSCREE	M AND	VENTILATOR
PLATE REF.	1 2 3 4 DESCRIPTION Qt	y. Part No.	REMARKS
1	Dash complete	330000	
2	Panel for controls	332725	Petrol models
	Panel for controls	30799 2	Diesel models
	Screw (2 B.A. $\times \frac{1}{2}'' \log$)	77869	
	Spring washer Fixing panel	3073	
	Plain washer to dash	3685	
	Nut (2 B.A.)	2247	
3	Cover panel for steering cutout 1	304111	
	Rivet fixing cover plate 2	302222	
4	Cover plate for accelerator pedal hole	303990	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{8}$ " long) Fixing	2 - 255202	
	Spring washer cover plate	2 3074	
	Nut $(\frac{1}{4}" \text{ U.N.F.})$ to dash 2	254810	
5	Cover panel for governor cutout in dash 1	306421	
	Bolt ($\frac{1}{4}$ " U.N.F. $x \frac{5}{8}$ " long)	255006	Petrol models
		3074	
	Nut (½" U.N.F.)	ر 254800	•
	Cover panel on dash for hand speed control 1	2757427	Diesel models
	Grommet in dash for hand speed control rod 1	236389 J	Diesei models
6	Cover plate for pedal holes 1	330143	
	Rivet fixing plate 8		
7	Cover plate for dipswitch hole 1	i 30 7 909ັງ	
	Screw (2 B.A. x \ \frac{3}{8}" long) \ Fixing	,	≻1958-60 models
	Spring washer cover plate 2		
	Nut (2 B.A.) J to dash 2		
_	Drive screw, earth point on dash 1	72628	Series IIA models
8	Rubber plug, redundant accelerator holes 5		
9	Rubber grommet for demister holes 2		
10	Rubber plug, redundant accelerator stop hole	73198	
	Rubber grommet for filling redundant clip holes		2½ litre Petrol models. 1 off on Diesel models
	Buffer for bonnet panel on dash front 2		
	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{7}{8}"$ long) Fixing dash to		•
	Plain washer steering box 10		
11	Self-locking nut (\frac{16}{16}" U.N.F.) support brackets Manufacture and the formula of the support brackets		
11	Mounting plate for voltage regulator 1 Drive screw fixing plate at top 2		
	Drive screw fixing plate at top 2 Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long)		S : 11 11
		4	Series II models
	Plain washer Nut (\frac{1}{4}" U.N.F.) Fixing plate at bottom 1	3831 254810	
12	Tie bolt 2		
12	Plain washer >Fixing dash to chassis 4		•
	Nut $(\frac{1}{2}'')$ 2		
	Vancilatan kinan D.U. 1		
13	V111-U		
1.5	Ventilator ninge, L.H 2. Screw (2 B.A. $x \frac{1}{2}$ long)	,	For ventilator lids with hinges fixed by screws and
	Spring washer \Rightarrow Fixing hinges \Rightarrow		nuts. Check before ordering
	Plain washer to vent lid 16	,	nais. Once before ordering
	Nut (2 B.A.)	1	
	, tut (m , m, tas)	. 2271)	




PLATE REF.	1 2 3 4 DESCRI	PTION	Qty.	Part No.	REMARKS
REF.	Ventilator lid and hinge fe		1	334114	<u> </u>
14	Ventilator lid and hinge for		1	334115	
17	Hinge pin for ventilator li		1 4	334121	For ventilator lid with welded hinges. Check
	Timge pin for ventuator in	u	¬	JJ 1121	before ordering
15	Sealing rubber for ventila	tor lide	2	330621	before ordering
16	Ventilator control mechan		2	332326	Quadrant type
10	Knob and fixing screw	<u>-</u>		332327	For quadrant type ventilator control.
	MIOD and fixing screw	ioi ventilatoi contro	1 2	JJEJE1	Check before ordering
	Circlip for ventilator cont	zal kaob	2	320500	For screw type ventilator control. Check before
	Circup for ventuator cont	TOT KINOU	4	220200	ordering
	Drive screw	•	4	78153	-
	Spire nut		4	78237	
	Bolt (2 B.A. $\times \frac{1}{2}$ long)		8	234603	
	Plain washer, small	Fixing ventilator	4		For screw type ventilator control.
	Plain washer, medium	control	4	4034	Check before ordering
	Plain washer, large	>mechanism	4	3852	Check before ordering
	Spring washer	to dash	8	3073	·
	Nut (2 B.A.)	to dasii	8	3823	
	Drive screw		4	78436	
	Plain washer		4		For quadrant type ventilator. Check before
	Spire nut		4.	78237	! .
	Set bolt (2 B.A. $x \frac{1}{2}$ long	y)] Fixing	4	234603	, ••••••
	Plain washer	control to	4	3816	
	Spring washer	ventilator lid	4	3073	
17	Windscreen complete as	,	•	330665	
.,	Windscreen complete ass			330875	
18	Glass for windscreen, t	•	2	330666	
,•0	Glass for windscreen, l	_	2	330876	
	Glazing strip for glass		2	330914	
19	Retainer for windscree		1	330668	
• • •	Retainer for windscree		1	330669	•
20	Retainer for windscree	- -	2	330667	
21	Retainer for windscree		1	330486	
	Retainer for windscree	-		330487	
22	Cover for centre strip		; 1	330670	
	Drive screw fixing reta	iners and cover	37	78126	
23	Special bolt	Fixing	2	256280	
		>windscreen	4	3829	
24	Special self-locking nut	to dash	2	250004	
25	Rubber sealing strip for	windscreen	1	330877	
	End filler for windscreen	sealing strip	2	330850	
	Buffer for top of windscr	een	1		Only required when
	Pop rivet fixing buffer	****	4		∫ hood is fitted
	Fastener for windscreen,		1	332631	
26	Fastener for windscreen,	L.H. ∫wing nut	1	332632	
27	Wing nut for fastener	(5 " B.S.F.)	2		Alternatives
	Wing nut for fastener	(<u>5</u> " U.N.F.	2		Check before ordering
	Set bolt $(\frac{5}{16}$ " x $\frac{5}{8}$ " long)	Fixing	4	255225	
	Plain washer	fasteners	4	3841	
	Spring washer	to dash	4	3075	






PLATE REF	1 2 3 4 DESCRIPT	ION	Qty.	Part No.	REMARKS
	CHECK STRAP ASSEME	BLY	2	306474	
28	Rod for check strap		2	332715	
29	Buffer for check strap		2	306471	
30	Plain washer		4	4035	
	Spring washer Fixing	buffer	2	3074	
	Nut (‡" B.S.F.) to rod		4	3819`\	Alternatives.
	Nut (<u>1</u> " U.N.F.		2	254810 <i>f</i>	Check before ordering
	Check strap mounting brack	et, R.H	1	330393	· -
31	Check strap mounting brack	et, L.H	1	330394	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long))	8	255006	
	Plain washer	Fixing	8	3946	•
	Spring washer	mounting brack	et 8	3074	
	Plain washer	to dash	8	2213	
	Nut (‡" U.N.F.)	J .	8	254800	•
32	Clevis pin Fixing che	eck strap	2	306564	
33	Plain washer >rod to		4	3815	
	Split pin front door	-	2	3901	
34	Tie bar for dash support	••••	1	332588	
	Nut (🖁") fixing bar to dash	****	2	2827	
	Bolt $(\frac{5}{16}$ " x $\frac{7}{8}$ " long) \bigcap Fixin	g tie bar	1	255027	
	Spring washer >to su	pport bracket	1	3075	•
		assis frame	1	254801	•
	Licence holder	****	1	26470	

FULL LENGTH HOOD AND FITTINGS, 88



FULL LENGTH HOOD AND FITTINGS, 88

	I CEL ELIGIE	TIOOD	AND	F1111ING5, 88	
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.		REMARKS
1	HOOD COMPLETE, FULL LENGTH, PLA	ΙŅ	•	•	
	SIDES, GREEN	1	331110		
	HOOD COMPLETE, FULL LENGTH, PLA	IN			
	SIDES, BLUE	1	330982		
	HOOD COMPLETE, FULL LENGTH, WI'	TH	.)		
	SIDE WINDOWS, GREEN	1	331113	Export only	
	HOOD COMPLETE, FULL LENGTH, WI'	TH	ĺ		
	SIDE WINDOWS, BLUE	1	330983	•	
2	Rear curtain complete, green	1	331106		
_	Rear curtain complete, blue	1	330978		
3	Strap complete, hood support, front, green	i	331086	•	
	Strap complete, hood support, front, blue	1	330979		
4	Buckle	2	300953		
7	End cap For hood support st	_	300954		
	Eyelet for end cap	.1ap 2 4	300785		
	Strap complete, rear curtain to body, green	2	331105		
	Strap complete, rear curtain to body, green	2	330981	•	
	Buckle Tear curtain to body, blue	2	300953		
	End cap rear curtain to	2	300954		
	Eyelet for end cap body strap	4	300785	•	
		-	301332		
	Strap complete, retaining rear curtain, green		307199		
	Strap complete, retaining rear curtain, blue				
	End cap For rear curtain	2	300954		
	Eyelet for end cap \int retaining strap	4	300785	•	a
-	Buckle for rear curtain retaining strap	2	300953		
5 .	Strap complete, for extension flap, green	2	301332	•	
,	Strap complete, for extension flap, blue	2	307199		
6	End cap For extension	2	300954		
	Eyelet for end cap flap strap	4	300785		
7	Buckle for extension flap strap	2	300953		
	Strap complete for side curtain, green	4	301332	-	
	Strap complete for side curtain, blue	4	307199		
	End cap For side curtain	4	300954		
	Eyelet for end cap ∫ strap	8	300785		
8	Back light, plastic	1		3 off with	1
	Adhesive tape for back light	I	306375	side windows	
9	Rope hook for curtain side	2	304797		•
	Washer plate for rope hook	2	301343		
	Rivet fixing rope hook	6	3547		
10	Rope complete for side curtain lower edge,		331220		
11	Rope complete for hood top and sides, 116"	1	331222		
12	Rope complete for rear curtain, 88"	1	33 1221		•
	HOODSTICKS AND FIXINGS COMPLE	ETE I	330999		
13	Top rail for hood attachment	1	330575		
	Bolt (‡" U.N.F. x ‡" long) Tixing top ra		255207		
	Plain washer \rightarrow adjustment p	olate 8	3900		
	Self-locking nut ($\frac{1}{4}$ " U.N.F.) \int and windscre	en 4	252220		
	Rivet Fixing	11	300789		
	Pop rivet, long top rail to	7	300781		



Pop rivet fixing staple to top rail 4 Buffer for top of windscreen 1	2 300924 4 300781 1 332550 4 300782	REMARKS
Pop rivet fixing staple to top rail 4 Buffer for top of windscreen 1	4 300781 1 332550 4 300782	
Buffer for top of windscreen 1	1 332550 4 300782	
	4 300782	
Pop rivet fixing buffer	1 200550	
Front hook R.H. \ For	1 330578	
15 Front hook L.H. ∫hood rope 1	1 330579	•
Screw (2 B.A. x 5 long)	4 77758	
Plain washer Fixing hook to	4 3902	
Spring washer rear body	4 3073	
Nut (2 B.A.)	4 3823	
Staple for hood strap at tailboard corner 2	2 300924	•
Screw (2 B.A. x \(\frac{3}{4}\)" long) \(\) Fixing	4 77758	
Spring washer staple to	4 3073	•
Nut (2 B.A.) rear body	4 2247	
16 Hood stick, front	1 330551	
17 Hood stick, rear	1 330553	
18 Clamp arm for hood stick 4	4 304301	
Bolt $(\frac{5}{16}"$ U.N.F. x 1" long)	4 255228	
	4 3899	
	4 3075	
Nut $\left(\frac{5}{16}$ " U.N.F.)	4 254811	
19 Hood stick, intermediate 1	1 330557	·
Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long) Fixing inter-	4 255206	•
Plain washer > mediate hood 4	4 3900	
Self-locking nut (¼" U.N.F.) ∫ stick to tie bar 4	4 250000	
	2 330559	
Screw (4" U.N.F. x 15" long) Fixing tie tube 4	4 78303	
Square nut (4" U.N.F.) to front and rear 4	4 78205	
Self-locking nut (4" U.N.F.) hood sticks	4 252220	
Top drain channel for door, R.H 1	1 330567	
21 Top drain channel for door, L.H 1	1 330568	
Special bolt Fixing drain 2	2 78208	
	2 3900	
Self-locking nut (‡" U.N.F.) hood stick	252220	
Adjustment plate, R.H. \ For drain 1	l 330622	
22 Adjustment plate, L.H. schannel	I 330623	
Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long) \int Fixing 4	4 255207	
Plain washer adjustment plates 8	8 3900	
Self-locking nut (1" U.N.F.) to drain channels 4		
Sealing rubber, windscreen to top drain channel 2	332605	





PLATE REF.	1234	DESCRIPTION	Qty.	Part No.	REMARKS
-	Side drain cha	nnel for door, R.H.	1	330561	/
23	Side drain cha	innel for door, L.H	1	330562	
	Bolt (1 U.N.	F. x 5" long) 🧻 Fixir	ng 4	255206	
•	Plain washer	≻drair	n channel 8	3900	
	Self-locking n	ut (‡″ U.N.F.) ∫ to he	ood stick 4	252220	
24	Sealing rubbe	r for door, top	2	330541	
25	Sealing rubbe	r for door, rear top	2	330535	
	Rivet fixing ru	ibber to channel	22	308517	
	Strap retaining	side curtain in rolled-up	p position.)	•
	green		4	301332	·
	Strap retaining s	ide curtain in rolled-u	p position,	(Optional equipment
	blue		4	307199	
	Buckle for strap		4	300953	
	Curtain complet	e for rear of driver, gre	en 1	330990	•
	Curtain complete	e for rear of driver, blu	e 1	330991	•
	Hook		2	301005	
	Buckle		2	300953	Optional equipment
	End cap		2	300954	
	Eyelet	••••	4	300785	
	Buckle		2	300953	
	Plastic backlig	h t	1	306340	



			RIER LENGIN, 00
PLATE REF.	1 2 3 4 DESCRIPTION (Qty.	Part No. REMARKS
1	HOOD COMPLETE, THREE-QUARTER		
	LENGTH PLAIN SIDES, GREEN	1	331371
	HOOD COMPLETE, THREE-QUARTER		
	LENGTH PLAIN SIDES, BLUE	1	330986
	HOOD COMPLETE, THREE-QUARTER		
	LENGTH WITH SIDE WINDOWS,		
	GREEN	1	331372
	HOOD COMPLETE, THREE-QUARTER		
	LENGTH WITH SIDE WINDOWS,		
	BLUE	1	330987
2	Rear curtain complete, green	1	331106
	Rear curtain complete, blue	1	330978
	Strap complete, rear curtain to body, green	2	331105
1.	Strap complete, rear curtain to body, blue	2	330981
	Buckle For rear	2	300953
	End cap curtain to	2	300954
	Eyelet for end cap body strap	4	300785
	Strap complete, retaining rear curtain, green	2	301332
	Strap complete, retaining rear curtain, blue	2	307199
	End cap \ \ For rear curtain	2	300954
	Eyelet for end cap retaining strap	4	300785
	Buckle for rear curtain retaining strap	2	300953
3	Strap complete for extension flap, green	2	301332
_	Strap complete for extension flap, blue	2	307119
4	End cap For extension	2	300954
-	Eyelet for end cap flap strap	2	300785
5	Buckle for extension flap strap	2	300953
6	Backlight, plastic	ī	306340 3 off with
_	Adhesive tape for backlight	2	306375 side windows
7	Rope hook for curtain side	2	304797
	Washer plate for rope hook	2	301343
	Rivet fixing rope hook	6	3547
-8	Rope complete for side curtain lower edge, 60"	2	331316
. 9	Rope complete for hood top and sides, 116"	1	331222
10	Rope complete for rear curtain, 88"	1	331221
	HOODSTICKS AND FIXINGS COMPLETE	1.	33295 0
	Front hook R.H. \ For	1	330578
11	Front hook L.H. hood rope	i	330579
	Screw (2 B.A. x 5 long)	4	77758
	Plain washer Fixing hook	4	3902
	Spring washer to rear body	4	3073
	Nut (2 B.A.)	4	2247
	Staple for hood strap at tailboard corner	2	300924
	Screw (2 B.A. x ¾ long) Fixing	4	77758
	Spring washer staple to	4	3073
	Nut (2 B.A.) rear body	4	2247
12	Hoodstick, front	1	332465
13	Hoodstick, rear	1	330553
14	Clamp arm for rear hood stick	2	304301
	Bolt $(\frac{5}{16}$ U.N.F. x 1" long) \int Fixing	2	255228
	Plain washer >clamp arm	2	3899
	Spring washer to hood	2	3075
	Nut $(\frac{5}{16}"$ U.N.F.) socket	2	254811
	, , , , , , , , , , , , , , , , , , ,		







PLATE REF.	1 2 3 4	DESCRIPTION	Qty.	Part No. REMARKS	
	Bolt plate	Fixing	2	330908	
	Spring washer	front hoodstick	4	3074	
	Nut (1" U.N.F.)		4	254810	
15	Hood stick, inter		1	330557	
	Bolt (1" U.N.F. :		4	255206	
	Plain washer	intermediate	4	3900	
	Nut (1" U.N.F.)	hoodstick	4	250000	
	Locknut (‡" U.N	I.F.) to tie bar	4	254860	
16	Tie tube for hoo		2	332459	
	Screw (1" U.N.F		4	78303	
	Square nut (1" U	J.N.F.) front and r	ear 4	78205	
	Self-locking nut	(¼" U.N.F.) hood sticks	. 4	252220	
17	Frame for hood a	attachment to cab	· 1	331281	
	Bolt (1" U.N.F. :	x ¾" long)] Fixing	12	78210	
	Plain washer	frame	24	3900	
	Spring washer	to rear	12	3074	
	Nut (1" U.N.F.)	of cab	12	254810	
18	Drain channel fo	r rear of cab L.H. \Strap	p 1	331276 Alternatives to	
19	Drain channel fo	r rear of cab R.H. ∫ type	1	331275∫ six lines below	
		r rear of cab L.H. \Stud	. 1	331674	÷
		r rear of cab R.H. \int type	1	331673	
	Stud retaining he		2	320345 Alternatives to	
	Screw (2 B.A. x	$1\frac{1}{4}'' \text{ long}) $ Fixing stud	2	77993 two lines above	
	Spring washer	≻to drain	2	3073	
	Nut (2 B.A.)	channel لِ	2	3823)	
	Bolt (‡" U.N.F. :	$x \frac{3}{4}$ long) Fixing	6	78210	
	Plain washer	>channel	12	3900	
	Spring washer	to rear	6	3074	*
	Nut (1/2" U.N.F.)		6	254810	
	>	Retaining	.1	334245	
		hood	l	334246	
		hooks to cab capping	4	78248	
20	Hood retaining s	· · · · · · · · · · · · · · · ·		331349	
21		trip complete R.H. typ	_	331346	
22		strip complete L.H.)fixi		331347	
	Strap, fixing fi		2	331361 Alternatives to two lines below	
	End cap		2	331362	
		curtain strap	2	300785	
	_	rap to retaining strip	2	78313 J	
	Hood retaining s	<u> </u>	1	331675 Alternatives to	
	Hood retaining s	strip, side	2	331676∫ seven lines above	



	FULL LENGIN	поор	AND FILLIAM	33, 103
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	HOOD COMPLETE, FULL LENGTH, PL	AIN		
•	SIDES, GREEN	1	331259	
	HOOD COMPLETE, FULL LENGTH, PL.	AIN	55.457	
	SIDES, BLUE	1	330984	
	· · · · · · · · · · · · · · · · · · ·	! [T][JJ070 4	
	HOOD COMPLETE, FULL LENGTH, WI	1111	2212/07	
	SIDE WINDOWS, GREEN	1	331260	
	HOOD COMPLETE, FULL LENGTH, W	пн	Export only	<i>t</i>
	SIDE WINDOWS, BLUE	1	330985	
2	Rear curtain, complete, green	1	331106	•
	Rear curtain, complete, blue	1	330978	
3	Strap complete, hood support, front, green	1	331086	
	Strap complete, hood support, front, blue	1	330979	
4	Buckle	2	300953	
•	End cap > For hood support strap	2	300954	•
	Eyelet	4	300785	
	Strap complete for centre stick, green	1	331249	
	Strap complete, for centre stick, blue	,,,,, I 1	330980	
	Buckle	2	300953	
			300954	
	End cap For centre stick strap	2		
	Eyelet J	4	300785	
	Strap complete for side curtain, green	4	301332	·
	Strap complete for side curtain, blue	4	307199	
	End cap \ \ For side	4	300954	
	Eyelet for end cap \int curtain strap	8	300785	
5	Strap for extension flap, green	2	301332	
	Strap for extension flap, blue	2	307199	
	End cap \ For	2	300954	•
	Eyelet strap	4	300785	•
6	Buckle for extension flap strap	2	300953	
•	Strap, rear curtain to body, green	2	331105	
	Strap, rear curtain to body, blue	2	330981	•
	Buckle	2	300953	
	End cap > For rear curtain strap	2	300954	•
	- ·	4	300785	
	Eyelet J			
	Strap, rear curtain retaining, green	2	301332	
	Strap, rear curtain retaining, blue	2	307199	
	End cap For curtain	2	300954	
	Eyelet fretaining strap	4	300785	
	Buckle for rear curtain retaining straps	2	300953	
7	Rope hook for side curtain	2	304797	:
	Washer plate \(\right) Fixing rope hook	2	3 01343	
	Rivet \int to side curtain	6	3547	
8	Rope for curtain side, 100" long	2	331317	
9	Rope for rear curtain, 88" long	1	331221	
10	Rope for hood top and sides, 116" long	1	331222	
11	Back light, plastic	j	306340 \ 3 off with	
••	Adhesive tape for back light	1	306375 side window	ws.
	HOODSTICKS AND FIXINGS COMPL	FTF I	332951	
12	Top rail for hood attachment		330575	
ıΖ		****		
	Bolt (¼" U.N.F. x ¾" long) Fixing top r		255207	
	Plain washer adjustment	_	3900	
	Self-locking nut (1" U.N.F.) and windscr		252220	
	Rivet Fixing	.11	300789	
	Pop rivet, long top rail to	7	300781	
	Pop rivet, short J windscreen	6	300919	



		ENGIN			TITINGS,	107
LATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.		REMARKS
13	Staple for hood strap		2	300924		
	Pop rivet fixing staple to top rail	l	4	300781		
	Buffer for top of windscreen	****	1	332550		
	Pop rivet fixing buffer	****	4	300782	•	
	Front hook R.H. \) For		1	330578		
14	Front hook L.H. hood rope		1	330579		
	Screw (2 B.A. x ½" long)		4	77758		
		ng hook to	4	39 02		
	· · · · · · · · · · · · · · · · · · ·	body	4	3073		
	Nut (2 B.A.)	,	4	3823		
	Staple for hood strap at tailboard	corner	2	300924		
	Screw (2 B.A. x ¾ long) Fix		4	77758		
		ole to	4	3073		
		r body	4	2247		
16		bouy	1	330551		
15	Hood stick, front	****	[1	330553		
16	Hood stick, rear	****	I			
17	Clamp arm for hood stick		4	304301		
	Bolt (5 U.N.F. x 1" long)	· · 1	4	255228		•
		ixing clamp		3899	•	
		o hood socke		3075		
	Nut (18" U.N.F.)		4	254811		
18	Hood stick, intermediate	****	[330699		
	Bolt (# U.N.F. x Fixing		_			
	¾" long) > intermediat		4	255207		
	Nut plate J stick to boo	ly side	4	330830	•	
19	Tie tube		4	330896		
		Fixing	6	78303	•	
	Square nut ($\frac{1}{4}$ " U.N.F.)	tie tube to	6	7 8205		
	Self-locking nut (1" U.N.F.)		6	252220		
	Adjustment plate R.H. \ For d	rain	1	330622		
20	Adjustment plate L.H. Schann	el	1	330623		•
		ixing adjust-	. 4	255207		
		nent plates to	8	3900		
	Self-locking nut (‡" U.N.F.)	rain channels	s 4	252220		
	Top drain channel for door R.H.		1	330567	•	
21	Top drain channel for door L.H		1	330568		•
		Fixing	2	78208		
		drain channe		3900		
	Self-locking nut (‡" U.N.F.)		7	252220		
	Side drain channel for door R.H.		Ĩ	330561		
22	Side drain channel for door L.H.		i	330562		•
44		Fixing drain		255206		
	· · · · · · · · · · · · · · · · · · ·	channel to	8	3900		•
				252220		
22	~ ·	hoodstick	4	3305 41		
23	Sealing rubber for door, top		2			
24	Sealing rubber for door, rear top	•	: 2	330535 309517		
	Rivet fixing rubber to channel		22	308517		
	Strap retaining side curtain in roll	ed-up position		201222		
	green		4	301332		
	Strap retaining side curtain in roll	ed-up positio			Optional equipment	•
	blue		4	307199		
	Buckle for strap		4	300953		



	1100D, 11IKEE-QUA			100	
PLATE REF.	1 2 3 4 DESCRIPTION Qty	y.	Part No.		REMARKS
1	HOOD COMPLETE, THREE-QUARTER				
	LENGTH PLAIN SIDES, GREEN 1		331307		
	HOOD COMPLETE, THREE-QUARTER				
	LENGTH PLAIN SIDES, BLUE 1		330 997		
	HOOD COMPLETE, THREE-QUARTER				
	LENGTH WITH SIDE WINDOWS,				
	GREEN 1		331308		
	HOOD COMPLETE, THREE-QUARTER				
	LENGTH WITH SIDE WINDOWS,				
•	BLUE 1		330998		
2	Rear curtain complete, green 1	I	331106		
_	Rear curtain complete, blue 1		330978		
	Strap complete, rear curtain to body, green 2		331105		
	Strap complete, rear curtain to body, blue 2		330981		
	Buckle For rear 2		300953		
	End cap >curtain to 2		300954		
	Eyelet for end cap body strap		300785		
	Strap complete, retaining rear curtain, green 2	_	301332 .		
	Strap complete, retaining rear curtain, blue 2		307199		
	End cap For rear curtain 2		300954		·
	Eyelet for end cap retaining strap		300785		
	Buckle for rear curtain retaining strap 2		300953		
3	Strap complete for extension flap, green 2		301332		
,	Strap complete for extension flap, blue 2		307199		
4	End cap For extension 2		300954		
•	Eyelet for end cap flap strap		300785		
5	Buckle for extension flap strap 2		300953		
6	Destricte alexander		306340\ 3 off with		
U	A D () () () () () () () () () (306375 ∫ side windows	,	i v
7	Decade a la Companya de la Companya		304797		
•	Washer plate for rope hook 2		301343		
	Rivet fixing rope hook 6		3547		
8	Rope complete for side curtain lower edge, 93" 2		331318		
9	Rope complete for hood top and sides, 116" 1		331222		
10	Rope complete for rear curtain, 88" 1		331221		
,0	HOOD STICKS AND FIXINGS COMPLETE I		332952		
	Front hook R.H. \ For		330578		•
11	Front hook L.H. hood rope		330579		
• • •	Screw (2 B.A. x ½" long)	1	77758		
	Plain washer >Fixing hook 4	1	3902		
	Spring washer §" to rear body 4	1	3073		÷
	Nut (2 B.A.)	1	3823		
	Staple for hood strap at tailboard corner 2	-	300924		•
	Screw (2 B.A. x ¾ long) Tixing		77758		
	Spring washer Staple to		3073		
	Nut (2 B.A.) staple to		2247		
12	Handadah faran	-	330553		
13	11. 1.1.1.1		330553		
14	Cl f 1 1 2 1		304301		
17			255228		
		7 4	3899		
	Spring washer to hood 4		3075		
•	Nut $(\frac{1}{16}^{\circ} \text{U.N.F.})$ socket		254811		
	rut (16 Orivir) J Socket 4	•	TOTI		





PLATE REF.	1 2 3 4	DESCRIPTION	Qty.	Part No.	REMARKS
_===-	Bolt plate		2	330908	
	•	Fixing front hood	4	3074	
	Nut (1" U.N.F.)	stick to body	4	254810	
15	Hood stick, interme		1	330699	
	Bolt (1" U.N.F. x 5		4	255207	
	Spring washer	>intermediate	4	3074	
	Nut plate (‡" U.N.I	F.) hood stick	4	330830	
	Locknut (1" U.N.F.		4	254860	
16	Tie tube for hood st		2	330897	
17	Tie tube for hood st		2	330896	
	Screw (1" U.N.F. x	• •	4	78225	
	Screw (1" U.N.F. x		2	78303	
	Square nut (1" U.N		6	78205	•
	Self-locking nut (1"		6	252220	
18	Frame for hood atta	· · · · · · · · · · · · · · · · · · ·	, 1	331281	
	Bolt (1" U.N.F. x 3	_	- 11	78210	
	Plain washer	>frame to	22	3900	
	Spring washer	rear of	11	3074	
	Nut (‡" U.N.F.)	cab	11	254810	
19	Drain channel for re	ear of cab L.H. 🧎 Stra	np 1	331276 Alternatives to	
20	Drain channel for re		e 1	331275 ∫ six lines below	•
	Drain channel for re	ear of cab L.H. 🠧 Stu	d 1	331674)	
	Drain channel for re	ear of cab R.H. ∫typ:	e ĺ	331673	
	Stud retaining hood	l	2	320345 Alternatives to	
	Screw (2 B.A. x 11/4	long) Fixing stud	2	77993 two lines above	
	Spring washer	≻to drain	2	3073	
	Nut (2 B.A.)	channel	2	3823	
	Bolt (1" U.N.F. x 1	" long) Fixing	6	78210	•
	Plain washer	>channel	12	3900	
	Spring washer	to rear	6	3074	
	Nut (‡" U.N.F.)	of cab	6	254810	
	Hook R.H. Ret	aining	. 1	334245	
	Hook L.H. ∫hoo	od	1	334246	
	Pop rivet, fixing ho	oks to cab capping	4	78248	
21	Hood retaining strip	p, top } St	rap- 1	331349	
22	Hood retaining strip	p complete R.H.	pe l	331346	
23	Hood retaining strip	p complete L.H. 🔰 fix	ting I	331347	:
	Strap, fixing fron	t curtain	2	331361 > Alternatives to two	lines below
	End cap \ For	r front	2	331362	
	Eyelet ∫ cur	tain strap	2	300785	
	Rivet fixing strap to		2	78313)	
		p, top \Stud-type	1	331675 Alternatives to	
	Hood retaining strip	p, side ∫fixing	2	331676∫ seven lines above	



			HAKI) IOP	AND	TI	COPICA	L ROOF, 88	
HARD TOP COMPLETE ASSEMBLY	PLATE REF.	1 2 3 4	DESCRIPTION)N	(Įty.	Part No.	REMA	ARKS
HARD TOP COMPLETE ASSEMBLY		HARD TOP	COMPLETE A	SSEMBLY		1	330963	Without rear end windows	Plain
HARD TOP COMPLETE ASSEMBLY		HARD TOP	COMPLETE A	SSEMBLY		1		,	sides
HARD TOP COMPLETE ASSEMBLY		HARD TOP	COMPLETE A	SSEMBLY		1		-2	
ROOF ASSEMBLY						1			
Seal retainer for roof, rear 1 33215 Rivet fixing seal to retainer 9 77869 Serew (2 B.A. x * long) Plain washer Spring washer Nut (2 B.A.) Bolt (3' U.N.F. x * long) Plain washer Spring washer Nut (4' U.N.F.) Bolt (4' U.N.F. x * long) Plain washer Spring washer Nut (4' U.N.F.) Bolt (4' U.N.F. x * long) Plain washer Spring washer Nut (4' U.N.F.) Side Panel Assembly, R.H. 1 334001 Side Panel Assembly, R.H. 1 334002 Side Panel Assembly, R.H. 1 334707* Side Panel Assembly, R.H. 1 33470	1	ROOF ASS	SEMBLY	- 14	****	1		,	
Rivet fixing seal to retainer	2	Rubber se	eal for roof, rear			1	332149		
Screw (2 B.A. x \(\frac{1}{2} \) long Plain washer Spring washer Nut (2 B.A.) Bolt (\(\frac{1}{2} \) U.N.F. x \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. x \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Plain washer Pl	3					1			
Screw (2 B.A. x \(\frac{1}{2} \) long Plain washer Spring washer Nut (2 B.A.) Bolt (\(\frac{1}{2} \) U.N.F. x \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. x \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Nut (\(\frac{1}{2} \) U.N.F. y \(\frac{2}{2} \) long Plain washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Plain washer Pl				r	,	11			
Spring washer Nut (2 B.A.) 9 30.73 Bolt (3 U.N.F. x 2 long) 10 255207 Plain washer Spring washer Nut (4 U.N.F.) 10 254810 Bolt (4 U.N.F. x 2 long) 10 255207 Plain washer Spring washer Nut (4 U.N.F.) 10 254810 Bolt (4 U.N.F.) 10 254810 Bolt (4 U.N.F.) 10 254810 Bolt (4 U.N.F.) 10 254810 Side Pankel ASSEMBLY, R.H. 1 334001 Side Pankel ASSEMBLY, R.H. 1 334001 Side Pankel ASSEMBLY, R.H. 1 334707* Side Pankel ASSEMBLY, R.H. 1 334708* Side Pankel ASSEMBLY, R.H. 1 334708* Side Pankel ASSEMBLY, R.H. 1 334708* Side Pankel ASSEMBLY, R.H. 1 334708* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334714* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY, R.H. 1 334713* Side Pankel ASSEMBLY R.H. 1 334713* Side Pankel ASSEMBLY R.H. 1 334713* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334707* Side Pankel ASSEMBLY R.H. 1 334708* Sid			· _			9	77869		
Nut (\$\frac{3}{\cute} \text{ U.N.F. x \frac{3}{\cute} \text{ long}\) Plain washer Spring washer washer Spring washer Spring washer Spring washer Spring washer Spring washer Side Spring washer Side Spring washer S		Plain was	her	Fixing retai	iner	9	3902		
Bolt (\frac{1}{2} U.N.F. \times \frac{2}{3} long)		Spring wa	asher	to hard top		9	3073		
Plain washer Spring washer Spring washer Nut (\{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'Nut (\{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'Nut (\{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'Nut (\{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'Nut (\{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \times \{ 'V.N.F. \{ 'V.N.F. \times \{ 'V.N.F. \{ 'V.N.F. \times \{ 'V.N.		Nut (2 B.	A.) J			9	3823		
Spring washer Nut (\family U.N.F.) To sides 10 3074 254810 255207		Bolt (1 U.)	V.F. x ¾″ long) ∫		1	10	255207		
Nut (\$' U.N.F. x \$' long)		Plain washe	r	Fixing roof	· 1	14	3840		
Bolt (4" U.N.F. x 3" long) Plain washer Spring washer Nut (4" U.N.F.)		Spring wash	ier	to sides	1	01	3074		
Plain washer Spring washer Nut (¼" U.N.F.) SIDE PANEL ASSEMBLY, R.H. 1 334001 SIDE PANEL ASSEMBLY, L.H. 1 334002 SIDE PANEL ASSEMBLY, L.H. 1 334003 SIDE PANEL ASSEMBLY, R.H. 1 334707* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334704* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H.		Nut (¼" U.N	√.F.)		1	10	254810		
Spring washer Nut (\$\forall V.N.F.)		Bolt (‡" U.N	V.F. x ¾" long))	1	10	255207		
Nut (\frac{1}{2} \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		Plain washe	r	Fixing roc	of 1	01	3900		
SIDE PANEL ASSEMBLY, L.H. 1 334002 SIDE PANEL ASSEMBLY, L.H. 1 334702* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334713* Without rear end windows SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* With rear end windows Export only Side		Spring wash	ier	to windscr	een l	10	3074		
SIDE PANEL ASSEMBLY, L.H. 1 334002 SIDE PANEL ASSEMBLY, R.H. 1 334707* SIDE PANEL ASSEMBLY, L.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334004 SIDE PANEL ASSEMBLY, R.H. 1 334004 SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334714* With rear end windows Export only		Nut (¾" U.N	l.F.)	J	1	0	25 4 810		
SIDE PANEL ASSEMBLY, L.H. 1 334707*		SIDE PAN	EL ASSEMBLY	, R.H.		1	334001	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \)
SIDE PANEL ASSEMBLY, R.H. 1 334708* SIDE PANEL ASSEMBLY, R.H. 1 334003 SIDE PANEL ASSEMBLY, R.H. 1 334014* SIDE PANEL ASSEMBLY, R.H. 1 334714* SIDE PANEL ASSEMBLY, R.H. 1 334714* SIDE PANEL ASSEMBLY, L.H. 1 334714* SIDE PANEL ASSEMBLY, L.H. 1 334714* SIDE PANEL ASSEMBLY, L.H. 1 334714* With rear end windows Export only		SIDE PAN	EL ASSEMBLY	', L.H.		1	334002	without rear end windows	>Plain
SIDE PANEL ASSEMBLY, R.H. 1 334003 SIDE PANEL ASSEMBLY, R.H. 1 334004 SIDE PANEL ASSEMBLY, R.H. 1 334713* SIDE PANEL ASSEMBLY, R.H. 1 334714* SIDE PANEL ASSEMBLY, L.H. 1 334714* With rear end windows Export only		SIDE PAN	EL ASSEMBLY	', R.H.		1	334707*	With and and all a	sides
SIDE PANEL ASSEMBLY, L.H. 1 334004 SIDE PANEL ASSEMBLY, R.H. 1 334714* SIDE PANEL ASSEMBLY, L.H. 1 334714* 334714* With rear end windows Export only		SIDE PAN	EL ASSEMBLY	', L.H.		1	334708*	with rear end windows]
SIDE PANEL ASSEMBLY, R.H. 1 334713* 334713* SIDE PANEL ASSEMBLY, L.H. 1 334714* SIDE PANEL ASSEMBLY, L.H. 1 334714* 5 Class for side window 2 304234 6 Weather strip for glass 2 304235 Export only 5 Class for rear end window 2 332341 9 Weather strip for glass 2 306287 10 Filler strip for weather strip 2 306289 11 Mounting bracket, front. 2 332080 12 Mounting bracket, rear 2 332080 12 Mounting bracket, rear 2 2 332052 Bolt (\frac{1}{6}^* U.N.F. \times \frac{3}{4}^* long) Plain washer Plain washer Spring washer Spring washer Spring washer Spring washer Nut (\frac{1}{4}^* U.N.F.) 4 254810 254810 13 Nut plate 2 332081 14 Rubber seal for rear lid, side 2 332146 Drive screw Fixing 2 77932 77932 77932						1	334003	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Ĵ c:
SIDE PANEL ASSEMBLY, L.H. 334714* With rear end windows Export only						1	334004	without real end windows	_
Sible Farrich Asselvible Files Side Si						1	334713*	With room and windows	
6 Weather strip for glass 2 304235 7 Filler strip for weather strip 2 304236 8 Glass for rear end window 2 332341 9 Weather strip for glass 2 306287 10 Filler strip for weather strip 2 306289 11 Mounting bracket, front 2 332080 12 Mounting bracket, rear 2 332052 Bolt (½ U.N.F. x ¾ long) Bolt (¼ U.N.F. x ¾ long) Plain washer Plain washer Plain washer Spring washer Spring washer Nut (¼ U.N.F.) 13 Nut plate 14 Rubber seal for rear lid, side 2 332150 Rivet fixing seal 10 302818 15 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932				', L.H.	****	1	-	with real end windows	
Filler strip for weather strip 304236					****)	
Solass for rear end window 2 332341 Solass for rear end window 2 332341 Solass for rear end window 2 332341 Solass for rear end window 2 332341 Solass for rear end window 2 332687 Solass for rear end window 2 336287 Solass for rear end window 2 336287 Solass for rear end window 2 336287 Solass for rear end window 2 336287 Solass for rear end window 2 336287 Solass for rear end window 2 332080 Solass for rear end								Export only	
9 Weather strip for glass 2 306287 10 Filler strip for weather strip 2 306289 11 Mounting bracket, front 2 332080 12 Mounting bracket, rear 2 332052 Bolt (\frac{1}{16}'' U.N.F. x \frac{5}{8}'' long) Bolt (\frac{1}{4}'' U.N.F. x \frac{3}{4}'' long) Plain washer Plain washer Spring washer Spring washer Spring washer Nut (\frac{1}{4}'' U.N.F.) 13 Nut plate 14 Rubber seal for rear lid, side Rivet fixing seal 15 Rubber buffer for rear lid, side Drive screw Fixing 2 306289 2 332080 2 332052 2 332052 3 32052 4 255225 5 Fixing 4 255227 5 Fixing 4 255207 5 Fixing 4 3830 5 brackets to 4 3074 5 body sides 4 3075 4 254810 2 332081 3 302818 3 Rubber buffer for rear lid, side 2 332150 Rivet fixing seal 3 302818 3 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932	-			р			_	J	
10 Filler strip for weather strip 2 306289 11 Mounting bracket, front 2 332080 12 Mounting bracket, rear 2 332052 Bolt (\frac{5}{16}" U.N.F. x \frac{5}{8}" long) 4 255225 Bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long) 4 255207 Plain washer Fixing 4 3830 Plain washer Bring 4 3074 Spring washer Bring 5 306289 Plain washer Fixing 4 235225 Plain washer Bring 5 306289 Plain washer Fixing 4 255225 Plain washer Fixing 5 306289 Plain washer Fixing 5 302081 Plain washer Bring 6 3074 Bring 5 302081 Plain washer Bring 6 302818 Plain washer Bring 7 302818 Plain washer Bring 7 302818 Plain washer Bring 7 302818 Plain washer Bring 7 302818 Plain washer Fixing 7 30281									
Mounting bracket, front					••••				
Mounting bracket, rear 2 332052				p					
Bolt (\frac{5}{6}" U.N.F. \times \frac{8}{8}" long) Bolt (\frac{1}{4}" U.N.F. \times \frac{8}{3}" long) Bolt (\frac{1}{4}" U.N.F. \times \frac{3}{4}" long) Plain washer Plain washer Spring washer Spring washer Spring washer Nut (\frac{1}{4}" U.N.F.) 13 Nut plate 14 Rubber seal for rear lid, side Rivet fixing seal 15 Rubber buffer for rear lid, side Drive screw Fixing 4 255225 Fixing 4 3830 Fixing 4 3074 Body sides 4 3075 4 254810 2 332081 1 254810 2 332150 Rivet fixing seal 1 302818 2 332146 Drive screw Fixing 2 77932		_		••••		_			
Bolt (\frac{1}{4}" U.N.F. \times \frac{3}{4}" long)	12								
Plain washer Plai				'					
Plain washer Spring washer									
Spring washer Spring washe				_		-			
Spring washer body sides 4 3075 Nut (¼" U.N.F.) 4 254810 13					_	_			
Nut (¼" U.N.F.) 13 Nut plate 2 332081 14 Rubber seal for rear lid, side 2 332150 Rivet fixing seal 10 302818 15 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932				,					
13 Nut plate 2 332081 14 Rubber seal for rear lid, side 2 332150 Rivet fixing seal 10 302818 15 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932				body sid					
14 Rubber seal for rear lid, side 2 332150 Rivet fixing seal 10 302818 15 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932	12		.1N.F.)						
Rivet fixing seal 10 302818 15 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932			al for your lide of	ل اه					
15 Rubber buffer for rear lid, side 2 332146 Drive screw Fixing 2 77932	14		·						
Drive screw Fixing 2 77932	15		_						
,	1)		_	side					
Figure 4 delicits 2 3007			<u> </u>						
		i idili wasi	ici J bullets			۷	7007		





PLATE	1 2 3 4 DESCRIPTION	O	Davis MI.	DEMARKS	
PLATE REF.		Qty.	Part No.	REMARKS	
16	Rubber sealing strip, lower edge to body	2	333487		
17	Capping for front door rear seal, R.H.	l	332112		
17	Capping for front door rear seal, L.H.	1	332113		
18	Stud plate	2	332065		
	Screw (2 B.A. x ½" long) Fixing	6	77869		
	Plain washer cappings to	6	3852		
	Plain washer side panel	8	3885		
	Spring washer	14	3073		
	Nut (2 B.A.)	14	3823	•	
19	Seal for front door, upper, side	2	332152		
	Rivet fixing seal to capping	10	302818		
20	Rubber seal, roof to side	2	332154		
	Seal retainer for door top, R.H	1	330788		
21	Seal retainer for door top, L.H.	1	330789		
	Screw (2 B.A. x ½" long)	10	77869		
	Plain washer Fixing seal	10	. 3902		
	Spring washer retainer to roof	10	3073		
	Nut (2 B.A.)	10	3 82 3		
	Rubber seal at door pillar top and bottom	6	332215		
22	Sealing rubber for door top	2	330541		
	Rivet fixing seal to retainer	10	302818		
23	Sealing rubber, windscreen to roof	1	330878		
24	REAR LID ASSEMBLY	1	332181	Quadrant type fixing Alternatives)
	REAR LID ASSEMBLY	1	333467	Rod type fixing Check before	İ
				ordering	İ
25	Lock complete for rear lid	1	302164	<u>-</u>	1
26	Bolt end for lock	2	262798		1
	Screw (2 B.A. x ½" long)	4	77700		-
	Plain washer Fixing lock	4	3816		
	Spring washer to rear lid	4	3073		
	Nut (2 B.A.)	4	2247		1
27	Guide for rear lid lock	2	332097		Alternative
	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long) \int Fixing	4	255207		to rear
	Spring washer >guide to	4	3074	•	door
	Plain washer rear lid	4	3900		See also
28	Nut plate	2	332121		pages 355
29	Handle for rear lid, outer, locking	1	306461		and 357
	Screw (2 B.A. x ¾") \ Fixing	2	78171	·	Check
	Nut (2 B.A.) handle	- 2	2247		before
3 0	Handle for rear lid, inner	1	302207		ordering
31	Boss	1	320046		1
32	Coil spring >Fixing handle	1	313493		
33	Cap for coil spring	1	320047		
34	Locking pin	i	302262		}
35	Rubber seal for rear lid, bottom	i	332143		
36	Retainer for bottom seal	i	332122		
	Pop rivet fixing retaining strip	9	78257		
37	Glass for rear lid	1	332089		1
38	Weather strip for back light	1	302177		1.
39	Filler strip for weather strip	1	302178		
	court to the court of the	••••	242170		J



	HARD TOP AND		ROPICAL ROOF, 88	
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	Hinge leaf for rear lid, R.H	1	332040 For lid with quadrant	<u>)</u>
40	Hinge leaf for rear lid, L.H.	1	332041 type fixing	Alternatives
	Hinge leaf for rear lid	2	333468 For lid with rod type	
		-	fixing	ordering
	Plain washer	4	3830) or useg
	Spring washer	4	3075	·
	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ long) hinge leaf	4	255226	
41	Tapped plate to rear lid	2	332047	
42				
42	Pin for rear lid hinge	2	302165	
	Split pin Fixing	4	3901	
40	Plain washer \(\int \) hinge pin	4	3899	_
43	Stay for rear lid, R.H	1	332182	
	Stay for rear lid, L.H	I	332183	
	Plain washer Fixing	2	3899	
	Spring washer >stay to	2	2285]	
	Split pin J hinge leaf	2	2389 \Quadrant type fixing	
	Bolt (¼" U.N.F. x §" long)	4	255206	Alternative
	Plain washer Fixing stay	4	3946 [to rear
	Spring washer to body	4	3074	door
	Nut (¼" U.N.F.)	4	254810	See also
44	Stay for rear lid, R.H	1	332385]	>pages 355
	Stay for rear lid, L.H	1	332386	Alternatives and 357
45	Securing plate, R.H. \ For rear	1	332391*	Check Check
	Securing plate, L.H. ∫ lid stays	1	332392* Part of	before before
	Rivet fixing plate to rear lid	14	300783 > rear lid	ordering ordering
46	C 11 f 111 i	2	332398 333467	ordering
10	D ' , C ' I' , 1'1	2	78248	
47	Split pin Fixing rear lid Fixing rear lid	2	3901	
48			L L	1
49	Plain washer \int stay to support	2	2208 Rod type	
	Mounting bracket for stay support	2	332393 fixing	
50	Locking nut for rear lid stay	2	332397	
51	Screw (2 B.A. x 3 long) Retaining	2	77941	
52	Plain washer Slocking nut	2	2983	
	Bolt (\frac{1}{4}" U.N.F. \times \frac{5}{8}" long)	4	255206	
	Plain washer Fixing mounting	4	4071	
	Spring washer bracket to body	4	3074	
	Nut $\binom{1}{4}$ U.N.F.)	4	254810	J
	Socket for rear lid lock bolt, R.H	1	332083	ļ ·
53	Socket for rear lid lock bolt, L.H	1	332084	Į
	Bolt ($\frac{1}{4}$ " U.N.F. $\times \frac{5}{8}$ " long)	4	255206	j
	Plain washer Fixing sockets	4	3840 ·	.]
	Spring washer	4	3074	
	Nut (¼" U.N.F.)	4	254810)
	Bolt (5 U.N.F. x 7 long)	2	25522 7	
	Plain washer	4	3830	
	Spring washer	2	3075	
	Nut (5 " U.N.F.)	2	254811	
	Bolt (1" U.N.F. x 5" long)	4	255206	
	Plain washer Fixing	4	3840	
	Spring washer hard top	4	3074	
	Nut (‡" U.N.F.) to body	4	254810	
54	Mounting stud	4	332157	
J 1	Plain washer	4	3898	
	Special washer	2	332293	
	Spring washer	8	3075	
	- ·			
	Nut (5 U.N.F.)	8	254811	






PLATE REF.	1 2 3 4 DESCRIPTI	ON		Qty.	Part No.	REMARKS
	Support bracket, centre			. 2	332201	
	Bolt (¼" U.N.F. x ¾" long)] Fixing b	oracket	4	255207	•
	Plain washer	>to body	side	6	3900	
	Nut (‡" U.N.F.)	and cap	ping	4	254810	
55	Interior mirror			. 1	334000	
	Drive screw, trimmed vehic	les		2	77789	
	Bolt (2 B.A. $x \frac{1}{2}$ " long)			2	234603	
	Packing washer	Untrimmed	Fixing	2	3864	
	Spring washer	vehicles	mirror	2	3073	
	Nut (2 B.A.)	J		2	3823	·
	TROPICAL ROOF PANE	EL ASSEMI	3LY	. 1	330966	
56	Tropical roof panel			. 1	332025	
	Stiffener for roof panel			. 3	332028	·
	Drive screw \ Fixing sti			21	``	Alternatives
	Pop rivet ∫to hard to	o p		21		Check before ordering
	Screw (2 B.A. $x \frac{1}{2}$ long)	ì		8	77869	
	Plain washer	Fixing par	nel	16	3852	
57	Rubber washer	to roof at	end	8	302371	
	Shakeproof washer	of stiffener	r	8	71082	
	Nut (2 B.A.)	J		8	3823	·
	Screw ($\frac{1}{4}$ " U.N.F. x 2" los			8	78274	•
	Screw (1" U.N.F. x 21" los	ng)		2	78382	
	Plain washer			20	3900	
58	Distance piece	>Fixing	roof to	10	302372	
59	Rubber washer	panel a	nt sides	10	302373	
	Spring washer			10	3074	
	Nut (1/2" U.N.F.)	J		10	254810	
	Drive screw \ Fixing pa			45	•	Alternative
	Pop rivet ∫roof stiffe	ener		45	78248∫	Check before ordering


See Page 480 for locking handles and catches for front doors and sliding windows




HARD TOP COMPLETE ASSEMBLY WITH SLIDING SIDE WINDOWS 1 334190* Export only 332783		IARD TOP	AND	IROPICAL	KUUF,	56,	MIIH	PLIDING	SIDE	MINDOM2
HARD TOP COMPLETE ASSEMBLY WITH SLIDING SIDE WINDOWS 1 334190* Export only 332783	PLATE REF.	1 2 3 4	DE	SCRIPTION	Qty.	Part N	lo.		REM	ARKS
ROOF ASSEMBLY					VITH					
Rubber seal for roof, rear 1 332149 3 Seal retainer for roof, rear 1 332151 Rivet fixing seal to retainer 11 302818 Screw (2 B.A. x \frac{3}{2} long) Plain washer Spring washer S		SLIDING	SIDE W	VINDOWS	1	33419	0 * Expo	ort only		
Seal retainer for roof, rear Rivet fixing seal to retainer	l	ROOF ASSE	MBLY		1	33278	33			
Rivet fixing seal to retainer		Rubber sea	l for roof,	rear	1					
Screw (2 B.A. x ½" long) Plain washer Spring washer Nut (2 B.A.) Spring washer Nut (2 U.N.F. x ½" long) Plain washer Spring washer Nut (½" U.N.F. x ½" long) Plain washer Spring washer Nut (½" U.N.F. x ½" long) Plain washer Spring washer Nut (½" U.N.F. x ½" long) Plain washer Spring washer Nut (½" U.N.F. x ½" long) Plain washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Nut (½" U.N.F. x ½" long) Plain washer Spring washer Sp	3				1					
Plain washer Spring washer Tixing retainer 9 3852				_						
Spring washer Nut (2 B.A.) 9 3073			_		•					
Nut (2 B.A.) 9 3823				, -						
Bolt (\(\frac{4}'' \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \				to hard top						
Plain washer Spring washer		•	•	٠, إ						
Spring washer Nut (\frac{1}{4}" U.N.F.) 18 254810 255207 20 3900 255207 20 3900 255207 20 3900 255207 20 3900 255207 20 3900 255207 20 3900 255207 20 3900 255207 20 3900 255207 20 3000 254810 254810 255205			F.x¾″lo	1						
Nut (\frac{3}{\text{"}} \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \										
Bolt (\(\frac{1}{4}" \) U.N.F. \(\frac{3}{4}" \) long) Fixing roof 20 3900 Spring washer 10 3074 Nut (\(\frac{1}{4}" \) U.N.F.) 10 254810 SIDE PANEL ASSEMBLY, R.H. 1 332306 SIDE PANEL ASSEMBLY, L.H. 1 332307 Mounting bracket front 2 332080 Bolt (\(\frac{1}{16}"\) U.N.F. \(\frac{5}{8}"\) long) Fixing 4 255225 Plain washer Spring washer Fixing 4 255225 Bolt (\(\frac{1}{4}"\) U.N.F. \(\frac{3}{4}"\) long) Fixing 4 255207 Plain washer Support bracket at tailboard 2 332081 7 Support bracket at tailboard 2 332052 Bolt (\(\frac{1}{4}"\) U.N.F. \(\frac{3}{4}"\) long) Fixing 4 255207 Plain washer Support bracket 8 3840 Spring washer Attailboard 4 3074 Nut (\(\frac{1}{4}"\) U.N.F. \(\frac{5}{8}"\) long) Fixing 4 255206 Plain washer Spring washer Channel 4 3074 Nut (\(\frac{1}{4}"\) U.N.F. \(\frac{5}{8}"\) long) Fixing 4 255206 Plain washer Channel 4 3074 Nut (\(\frac{1}{4}"\) U.N.F. \(\frac{5}{8}"\) long) Fixing 4 255206 Plain washer Channel 4 3074 Nut (\(\frac{1}{4}"\) U.N.F. \(\frac{5}{8}"\) long) Fixing 4 254810 9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light rubber 2 330661				to sides						
Plain washer Spring washer Nut (\{\frac{1}{4}'' \text{U.N.F.}\) SIDE PANEL ASSEMBLY, R.H. 1 332306				ĹΫ						
Spring washer Nut (\frac{1}{2}" U.N.F.) 10 254810 SIDE PANEL ASSEMBLY, R.H. 1 332306 4 SIDE PANEL ASSEMBLY, L.H. 1 332307 5 Mounting bracket front 2 332080 Bolt (\frac{1}{2}" U.N.F. x \frac{5}{2}" long) Plain washer Spring washer Spring washer Nut (\frac{1}{2}" U.N.F. x \frac{3}{2}" long) Plain washer Spring washer Nut (\frac{1}{2}" U.N.F. x \frac{3}{2}" long) Plain washer Spring washer Nut (\frac{1}{2}" U.N.F. x \frac{3}{2}" long) Plain washer Spring washer Nut (\frac{1}{2}" U.N.F. x \frac{3}{2}" long) Plain washer Spring washer Sp			r.x∄″lo	I						
Nut (\frac{4}'' U.N.F.)				1 -						
SIDE PANEL ASSEMBLY, R.H. 1 332306				to windscre						
4 SIDE PANEL ASSEMBLY, L.H.		·-	-	MDIV DII	10					
5 Mounting bracket front	4				I					
Bolt (\frac{1}{16}" U.N.F. x \frac{5}{8}" long) Plain washer Spring washer Support bracket at tailboard Spring washer Support bracket at tailboard Spring washer Support bracket at tailboard Spring washer Spring washer Spring washer Support bracket Spring washer Support bracket Support br				•						
Plain washer Spring washer Spring washer Support bracket at tailboard Line Line Line Support bracket at tailboard Line Lin	,									
Spring washer Nut plate Support bracket at tailboard Support bracket at tailboard Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Nut (¼" U.N.F.) Bolt (¼" U.N.F.) Spring washer Nut (¼" U.N.F. x ¾" long) Plain washer Spring washer Nut (¼" U.N.F. x ¾" long) Plain washer Spring washer W			_		-					
6 Nut plate to body 2 332081 7 Support bracket at tailboard 2 332052 Bolt (\frac{1}{4}" U.N.F. \times \frac{3}{4}" long) Fixing 4 255207 Plain washer support bracket 8 3840 Spring washer A 1000					-					
7 Support bracket at tailboard 2 332052 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Nut (¼" U.N.F.) 8 Drain channel complete for side windows 2 332223 Bolt (¼" U.N.F. x ½" long) Plain washer Spring washer Spring washer Nut (¼" U.N.F. x ½" long) Plain washer Spring washer Nut (¼" U.N.F.) 9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 332230	6		ner		· -					
Bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long)				, ,						
Plain washer Support bracket 8 3840 at tailboard 4 3074 3074 254810	,									
Spring washer Nut (\frac{1}{4}" U.N.F.) at tailboard 4 3074			_	*						
Nut (½" U.N.F.) corner 4 254810 Bolt (½" U.N.F. x ½" long) Fixing 4 255206 Plain washer drain 4 4071 Spring washer channel 4 3074 Nut (½" U.N.F.) to body 4 254810 9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 330661				4						
8 Drain channel complete for side windows 2 332223 Bolt (¼" U.N.F. x ½" long) Fixing 4 255206 Plain washer drain 4 4071 Spring washer channel 4 3074 Nut (¼" U.N.F.) to body 4 254810 9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 330661										
Bolt (¼" U.N.F. x ½" long) Plain washer Spring washer Nut (¼" U.N.F.) Glass for side window, sliding 4 332217 Sealing rubber for sliding light 2 332230 Channel for sliding light rubber 2 330661	8		•	-						
Plain washer drain 4 4071 Spring washer channel 4 3074 Nut (½" U.N.F.) to body 4 254810 9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 330661			_							
Spring washer										
Nut (½" U.N.F.) to body 4 254810 9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 330661										
9 Glass for side window, sliding 4 332217 10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 330661										
10 Sealing rubber for sliding light 2 332230 11 Channel for sliding light rubber 2 330661	9		-							
11 Channel for sliding light rubber 2 330661	10				2					
	11				2	33066	51			
12 Channel for sliding light, top 4 332744	12	Channel for	r sliding l	ight, top	4	33274	14			
Channel for sliding light, bottom inner 2 332745		Channel for	r sliding l	ight, bottom inner	2	33274	45			
Channel for sliding light, bottom outer 2 332752						3327	52			
13 Channel for sliding light, sides 4 332746		Channel for	r sliding l	ight, sides	4	33274	16			
14 Packing strip for top channel 4 332216	14	Packing str	ip for top	channel	4	3322	16			
Drive screws fixing channels 76 77707					7 6	7770	07			
15 Catch for sliding glass, front 2 332324	15									
Catch for sliding glass, rear 2 332325				ss, rear		33232	25			
16 Washer for catch 16 340391	16					34039	91			
Screw (‡" U.N.F. x ¾" long) fixing rear catch 2 78401										
17 Screw (‡" U.N.F. x \(\frac{2}{8}\)" long) fixing front catch 2 78402					nt catch 2					
18 Tapped plate for catch 4 332329	18	Tapped pla	ite for cat	ch	4	33232	29			




	IARD TOP	AND	INOPICAL	KOOF,	00, 11	. 1 1 1	SEIDING		WILLD	71115
PLATE REF.			CRIPTION	Qty.	Part No			REM	IARKS	
19	Runner for s	liding catch	• ••••	4	330848					
	Rivet fixing	runner to di	rain channel	28	78248					
20	Glass for rea	r end windo	wc	2	332200					
	Glazing strip	for rear en	d window	2	332308					
	Retainer for	rear end gla	ıss, upper R.H.	1	332280					
21	Retainer for	rear end gla	ıss, upper L.H.	1	332281					•
22	Retainer for	rear end gla	iss, inner and oute	r 4	332282					
23	Retainer for	rear end gla	iss, lower L.H.	1	332284					
	Retainer for	rear end gla	ıss, lower R.H.	1	332283					
24	Rubber seal		side	2	330535					
	Rivet fixing			12	302818					
25	Rubber seali	ng strip, lov	ver edge to body	2	333487					
			rear seal, R.H.	1	332112					
2 6		front door i	rear seal, L.H.	1	332113					
27	Stud plate	••••		2	332065					
	Screw (2 B.A		1	6	78869					
	Plain washer		Fixing	6	3852					
	Plain washer		cappings to	8	3885					
	Spring wash		side panel	14	3073					
	Nut (2 B.A.)		J	14	3823			-		
28	Seal for fron			2	332152					
	Rivet fixing			10	302818					
29			ar top and bottom	4	332215					
30	Rubber seal,			2	332154					
	Seal retainer fo	_]	330788]				
31	Seal retainer fo		L.H	1	330789	,				
	Screw (2 B.A.			10	77869	_				
	Plain washer		Fixing seal	10		≻Part	of roof assembly	7		
	Spring washer		retainer to roof	10	3073]				
	Nut (2 B.A.)	, , J		10	3823			•		
32	Sealing rubber			2	330541					
	Rivet fixing sea			10	302818	J				
33	Sealing rubber			I	330878					
34	REAR LID A			1	333467					
35	Lock comple		lid	1	302164					
36	Bolt end f			2	262798					
	Screw (2 B.A			. 4	77700					
	Plain washer		Fixing lock	4	3816	ĺ				
	Spring wash		to rear lid	4	3073	A 1.				
27	Nut (2 B.A.)		J	4	2247	,	rnative to rear d			
37	Guide for re				332097	•	also pages 355 a			
	Set bolt (1"	_		4	255207 3074	Une	ck before orderi	ıŔ		
	Spring wash		>guide to	4	3900					
20	Plain washer	•	J rear lid	2						
38 20	Nut plate	 12.1		. 1	332121	1				
39	Handle for r			r 2	306461					
	Screw (2 B.A	_	>	2	78171 2247	}				
40	Nut (2 B.A.)		∫ handle	1	2247 302207	1				
40	Handle for r	ear iid, inne	er	1	<i>302207</i>)				



Boss Cal spring Fixing 1 320046 1 320047 1 32046 1 320047 1 32046 1 320047 1 32046 1 320047 1 32046 1 320262 1 32046 1 320262 1 32046 1 320262 1 32046 1 320262 1 32089 1 3208	I ATE	INIU IUI		OTICAL			II SLIDING		TIDOMS
Coll spring	LATE REF.	1 2 3 4	DESCRI	TION	Qty.	Part No.		REMAR	KS
Cap for coil spring	41				1)		_
Locking pin	42		, .		1				
Rubber seal for rear lid, bottom	43		ng handle	!	1		•		
1 332122 Pop rivet fixing retaining strip 9 78257	44	~ •	J		1				
Pop rivet fixing retaining strip	45			om	1				
Glass for rear lid	46	Retainer for bott	tom seal	••••	1,				
Weather strip for back light		Pop rivet fixing	retaining strip	···.	9				
Filler strip for weather strip	47	Glass for rear lie	ł	••••	1	332089		•	
Hinge leaf for rear lid	48	Weather strip fo	r back light	••••	1	302177			
Plain washer Spring washer Bolt (\(\frac{1}{6}\)'' U.N.F. x \(\frac{3}{4}\)' long Tapped plate 2 332047	49	Filler strip for w	veather strip		1	302178			
Spring washer Bolt (\(\frac{h}{a}^{\text{t}}\) U.N.F. \(x\) \(\frac{1}{a}^{\text{t}}\) U.N.F. \(x\) \(\frac{1}{a}^{\text{t}}\) U.N.F. \(x\) \(\frac{1}{a}^{\text{t}}\) U.N.F. \(x\) \(\frac{1}{a}^{\text{t}}\) Iong Tapped plate 2 332047 332385	50	Hinge leaf for re	arlid		2	333468			
Bolt (\(\frac{16}{16}\) \('\text{U.N.F. x \(\frac{3}{16}\) \('\text{U.N.F. x \(\frac{3}{16}\) \\ \text{Import palate} \\ Stay for rear lid, R.H		Plain washer	_)	4	3830	·		
Tapped plate		Spring washer		Fixing hing	ge leaf 4	3075			
Tapped plate		Bolt (5 " U.N.F	$x \frac{3}{4}$ long)		_	255226			
Stay for rear lid, R.H 1 332385 Stay for rear lid, L.H. 1 332385 Stay for rear lid, L.H. 1 332391 Securing plate, R.H. For rear 1 332392* Rivet fixing plate to rear lid 1 332392* Rivet fixing plate to rear lid 1 332392* Rivet fixing plate to rear lid 1 332392* Rivet fixing plate to rear lid 1 332392* Rivet fixing plate to rear lid 2 334073 Pop rivet, fixing clip to rear lid 2 334073 Pop rivet, fixing clip to rear lid 2 3901 Plain washer stay to support 2 2208 Mounting bracket for stay support 2 332393 Locking nut for rear lid stay 2 332397 Screw (2 B.A. x \(\frac{3}{6} \) long) Retaining 2 77941 Plain washer Fixing mounting 4 258206 Plain washer Fixing mounting 4 4071 Spring washer Fixing 4 3901 Plain washer hinge pin 2 3302165 Split pin Fixing 4 330283 Socket for rear lid lock bolt, R.H. 1 332083 Socket for rear lid lock bolt, L.H. 1 332084 Bolt (\frac{1}{4}'' U.N.F. \) 4 255207 Plain washer Spring washer			- -	}	2				
Stay for rear lid, L.H 1 332386	51		, R.H		1				
Securing plate, R.H. For rear 1 332391* Securing plate, L.H. Iid stays 1 332392* Rivet fixing plate to rear lid 14 300783 Spring clip for rear lid 2 78248 Pop rivet, fixing clip to rear lid 2 78248 Split pin Fixing rear lid 2 3901 Plain washer Stay to support 2 2208 Mounting bracket for stay support 2 332393 Locking nut for rear lid stay 2 332397 Screw (2 B.A. x \(\frac{3}{8}\)" long) Retaining 2 277941 Plain washer Socking nut 2 2983 Bolt (\(\frac{4}\)" U.N.F. x \(\frac{3}\)" long) Plain washer Spring washer Nut (\(\frac{4}\)" U.N.F.) 4 255206 Plain washer Fixing mounting 4 4071 Split pin Fixing 4 3001 Plain washer Split pin Fixing 4 3901 Plain washer Socket for rear lid lock bolt, R.H. 1 332084 Socket for rear lid lock bolt, L.H. 1 332084 Socket for rear lid lock bolt, L.H. 1 332084 Spring washer Fixing 4 3840 Spring washer				****	1				
Securing plate, L.H. Iid stays 1 332392* Rivet fixing plate to rear lid 14 300783 Spring clip for rear lid 2 334073 Pop rivet, fixing clip to rear lid 2 334073 Split pin Fixing rear lid 2 3901 Plain washer stay to support 2 2208 Mounting bracket for stay support 2 332393 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 332397 Locking nut for rear lid stay 2 2983 Bolt (\frac{1}{4}" U.N.F. x \frac{8}{8}" long) Fixing mounting 4 4071 Spring washer hinge pin 4 3901 Plain washer hinge pin 4 3901 Plain washer hinge pin 4 3899 Socket for rear lid lock bolt, R.H. 1 332084 Socket for rear lid lock bolt, L.H. 1 332084 Socket for rear lid lock bolt, L.H. 1 332084 Spring washer Spring			-	ear	1				
Rivet fixing plate to rear lid			>		1				
Spring clip for rear lid stay 2 334073 Pop rivet, fixing clip to rear lid 2 78248 Split pin Fixing rear lid 2 3901 Plain washer Stay to support 2 2208 Mounting bracket for stay support 2 332393 Locking nut for rear lid stay 2 332393 Locking nut for rear lid stay 2 332397 Screw (2 B.A. x \frac{3}{8}" long) Retaining 2 77941 Plain washer Spring washer Spring washer Spring washer Split pin Fixing 4 255206 Plain washer Split pin Fixing 4 3074 Mut (\frac{1}{4}" U.N.F.) Fixing 4 3901 Plain washer Split pin Fixing 4 3901 Plain washer Socket for rear lid lock bolt, R.H. 1 332084 Bolt (\frac{1}{4}" U.N.F. x \frac{3}{4}" long) Plain washer Spring washer Spring washer Support bracket, centre, body side 3074 Spring washer Spring was				-	14	300783			
Pop rivet, fixing clip to rear lid	52				2		Alternative to rea	r door	
Split pin			_	d					
Plain washer	53								
Mounting bracket for stay support 2 332393 Locking nut for rear lid stay 2 332397 Screw (2 B.A. x 3/8" long) Retaining 2 77941 Plain washer locking nut 2 2983 Bolt (3/4" U.N.F. x 5/8" long) Plain washer Spring washer bracket to body 4 3074 Nut (4" U.N.F.) 4 254810 Plain washer longe 2 302165 Split pin Fixing 4 3901 Plain washer hinge pin 4 3899 Socket for rear lid lock bolt, R.H 1 332083 Socket for rear lid lock bolt, L.H 1 332084 Bolt (3/4" U.N.F. x 3/4" long) Plain washer Spring washer Nut (4" U.N.F.) 4 254810 Support bracket, centre, body side 2 332201 Bolt (3/4" U.N.F. x 3/4" long) Plain washer Spring washer		· •	> '						
Locking nut for rear lid stay 2 332397	54								
Screw (2 B.A. x 3" long) Retaining 2 77941	55	-							
Plain washer	56	_							
Bolt (\(\frac{1}{4}'' \) U.N.F. \(x \frac{5}{6}'' \) long) Plain washer Spring washer Nut (\(\frac{1}{4}'' \) U.N.F.) B Pin for rear lid hinge Split pin Plain washer Split pin Plain washer Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, R.H.	57	-	· ·	-					
Plain washer Spring washer Spring washer Nut (¼" U.N.F.)									
Spring washer Nut (\frac{1}{4}" U.N.F.) Pin for rear lid hinge Split pin Plain washer Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, L.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid lock bolt, R.H. Socket for rear lid hinge 4 3899 Socket for rear lid lock bolt, R.H.				ixing mounti					
Nut (¼" U.N.F.) Pin for rear lid hinge 2 302165 Split pin Fixing 4 3901 Plain washer hinge pin 4 3899 Socket for rear lid lock bolt, R.H 1 332083 Socket for rear lid lock bolt, L.H 1 332084 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Nut (¾" U.N.F.) Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Spring washer Support bracket to 6 3900 Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer									-
Solit pin Fixing 4 3901					-				
Split pin	58		ر ige	••••	=				
Plain washer hinge pin 4 3899 Socket for rear lid lock bolt, R.H. 1 332083 Socket for rear lid lock bolt, L.H. 1 332084 Bolt (\frac{1}{4}" U.N.F. \times \frac{3}{4}" long) 4 255207 Plain washer 5 5 5 5 Nut (\frac{1}{4}" U.N.F.) 4 254810 Support bracket, centre, body side 2 332201 Bolt (\frac{1}{4}" U.N.F. \times \frac{3}{4}" long) 5 5 Plain washer 5 5 5 Support bracket, centre, body side 2 332201 Bolt (\frac{1}{4}" U.N.F. \times \frac{3}{4}" long) 5 5 Plain washer 5 5 6 3900 Spring washer 6 3900 Body side 4 3074	-	_	-						
Socket for rear lid lock bolt, R.H 1 332083 Socket for rear lid lock bolt, L.H 1 332084 Bolt (¼" U.N.F. x ¾" long)									
Socket for rear lid lock bolt, L.H 1 332084 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Nut (¼" U.N.F.) Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Spring washer Spring washer Fixing 4 255207 Plain washer Spring washer body side 4 3074				-I	1				
Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Nut (¼" U.N.F.) Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer Spring washer Bolt (¼" U.N.F. x ¾" long) Plain washer Spring washer A 255207 Fixing 4 255207 Fixing 4 255207 Bolt (¾" U.N.F. x ¾" long)	59				1		·		
Plain washer Spring washer Spring washer Socket 4 3074			-		4				
Spring washer socket 4 3074 Nut (¼" U.N.F.) 4 254810 D Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Fixing 4 255207 Plain washer bracket to 6 3900 Spring washer body side 4 3074				ixing	4				
Nut (¼" U.N.F.) Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Fixing 4 255207 Plain washer bracket to 6 3900 Spring washer body side 4 3074				-	4				
Support bracket, centre, body side 2 332201 Bolt (¼" U.N.F. x ¾" long) Fixing 4 255207 Plain washer body side 4 3074			1		4				•
Bolt (¼" U.N.F. x ¾" long) Fixing 4 255207 Plain washer bracket to 6 3900 Spring washer body side 4 3074	60		entre, body si	ide	=		,		
Plain washer bracket to 6 3900 Spring washer body side 4 3074	~ ~								
Spring washer body side 4 3074		·-							
								•	
Title 14 Cartary J and capping 7 257010				-					
		1401 (4 0.14.1.)	اه ر	ra cabbing	7	AJTOIU			



ATE REF.	1 2 3 4	DESCRI	PTION	Qty.	Part No.		REN	1ARKS
	Bolt (5 " U.N.F.	x 7 long))	.2	255227	**		
	Plain washer		1	4	3830			
	Spring washer]	2	3075			
	Nut (&" U.N.F.)		Ţ	2	254811			
	Bolt (1/2 U.N.F. x	k §″ long)]	4	255206			
	Plain washer		Fixing hard	top 4	3840			
	Spring washer		to body	4	3074			
	Nut (1" U.N.F.)		1	4	254810			
51	Mounting stud]	4	332157			
	Plain washer			6	3898			
	Special washer		1	2	332293			
	Spring washer]	8	3075			
	Nut (5" U.N.F.)	_	j	8	254811	•		
	Interior mirror			1	334000			
	Bolt (2 B.A. x ½" lor	ng)		2	234603			
	Packing washer	>Fixin	g	2	3864			
	Spring washer	mirro	or	2	3073			
	Nut (2 B.A.)	J		. 2	3823			
	TROPICAL ROOF	F PANEL A	ASSEMBLY	1	330966			
2	Tropical roof pan		****	1	332025			
	Stiffener for roof	panel	****	3	332028			
	Drive screw \ Fig		r	21	77704 🔪 .	Alternatives		
	Pop rivet ∫ to	hard top		21	7 8248 ∫	Check before orderi	ng	
	Screw (2 B.A. x ½	" long)		8	77869		-	
	Plain washer	F	ixing panel	16	3852			
3	Rubber washer	≻to	roof at end	8	302371			
	Shakeproof washe	r of	stiffener	8	71082			
	Nut (2 B.A.)	j		8	3823			
	Screw (1" U.N.F.)	8	78274			
	Screw (1" U.N.F.	x 2 1 ″ long)	1	2	78382			
	Plain washer			20	3900			
54	Distance piece		Fixing roof		302372			
5	Rubber washer		panel at sid	les 10	3023 7 3			
	Spring washer		Ī	10	3074			
	Nut (1" U.N.F.)		J	10	254810			
	Drive screw \ Fix		•	45	77704 \ A	Alternatives		
	Pop rivet ∫roc	of stiffener		45	78248 ∫ (heck before orderin	g	



		nako lor	AND	INOFICA	L ROOF, 105
PLATE REF.	1 2 3 4	DESCRIPTION	(Qty. Part No.	REMARKS
	HARD TOP COM	IPLETE ASSEMBL	Y	1 332977	Without rear end windows \ Plain
	HARD TOP COM	IPLETE ASSEMBL	Υ	1 334731*	With rear end windows sides
	HARD TOP COM	IPLETE ASSEMBL	Υ	1 332978	Without rear end windows 7 Fixed side windows
		IPLETE ASSEMBL			With rear end windows Export only
1	ROOF ASSEME			1 333819	<i>y</i> —- , ,
2	Rubber seal for		••••	1 332149	
3	Seal retainer fo		****	1 332151	•
	Rivet fixing sea			11 302818	
	_	$x \frac{1}{2}$ long) $fixing$		9 77869	
	Plain washer	retainer		9 3816	
	Spring washer	to		9 3073	
	Nut (2 B.A.)	hard top		9 3823	
	Bolt (\frac{1}{2}" U.N.F. >			28 255207	
	·-				22 .4
	Plain washer	Fixing h	_		32 off, with one-piece side panel
	Spring washer	roof to si	ides		
	Nut (½" U.N.F.)	SCEMBLY BU E	DONT	28 254810	.) DE :
		ASSEMBLY, R.H. F		I 333347	Plain
		ASSEMBLY, L.H. F		1 333348	Sides Two-piece side panels
		SSEMBLY, R.H. F		1 333349	Fixed side Check before ordering
		SSEMBLY, L.H. F		1 333350	\(\text{windows} \)
		SSEMBLY, R.H. R		1 333355	Plain
		SSEMBLY, L.H. R		1 333356	sides Two-piece side panels
		SSEMBLY, R.H. R		1 333357	Fixed side Check before ordering
		SSEMBLY, L.H. R	EAR	1 333358	\(\text{windows} \)
		SSEMBLY, R.H.	••••	1 334005*	One-piece side panel
		SSEMBLY, L.H.		1 334006*	f without rear end windows Plain sides
		SSEMBLY, R.H.		1 334719*	One-piece side panel
		SSEMBLY, L.H.		1 334720*	∫ with rear end windows
		SSEMBLY, R.H.		1 334007*	One-piece side panel
		SSEMBLY, L.H.	****	1 334008*	without rear end windows Fixed side
		SSEMBLY, R.H.	****	1 334725*	One-piece side panel windows
4		SSEMBLY, L.H.	••••		∫with rear end windows ∫
5	Mounting angle	tor side panel		6 332080	
	Bolt $(\frac{5}{16}"$ U.N.I	F. x $\frac{5}{8}''$ long)] Fixing	_	12 255225	
	Plain washer	≻moun		12 3830	
	Spring washer	angle	to	12 3075	
6	Nut plate	corner	r bracket	6 332081	
	Capping and se	al retainer for front d	oor R.H.	1 332112	
7	Capping and se	al retainer for front d	oor L.H.	1 332113	·
8	Stud plate, (2 B	i.A.)		2 332065	
	Spring washer			8 3073	
	Plain washer	Fixing		8 3885	
	Nut (B.A.)	front de	oor	8 2247	
	Screw (2 B.A. x	: ½″ long) >capping	g and	6 77869	
	Plain washer	retainei	-	6 3852	
	Spring washer	side pa	nel	6 3073	
	Nut (2 B.A.)	j		6 3823	
	. ,	,			





PLATE REF.	1 2 3 4 DESCRIPTION Qt	ty. Part No. REMARKS
9		2 332152
	Rivet fixing rubber to retainer 10	
	Rivet fixing rubber to retainer 10	rest Paration Paration
10	Rubber seal, side panel to body capping	2 333402
11	Rubber seal, side panel to body capping	2 333403
12		2 333404 With two-piece side panels
13	Rubber seal, side panel to roof	2 333405
14		2 333490 \(\text{With one-piece} \)
15		2 333983 Side panel
16		4 302174
17		4 302177
18		4 302178
19		2 332341
20		2 306287 ,
21		2 306289
22		2 332052
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long) \int Fixing 4	·
	Plain washer support bracket 8	
	Spring washer at tailboard 4	
22	Nut (1" U.N.F.) corner 4	· · · · · · · · · · · · · · · · · · ·
23	Buffer for rear lid 2	
	Plain washer Fixing 2	
24		2 77932
24	_	2 332150
	Rivet fixing seal 10	
	Bolt (½" U.N.F. x ¾" long) Fixing 6	——————————————————————————————————————
	Plain washer front and rear 12	1 W/sala 4 11
	Spring washer side panels 6	Charle before and arise
25	Nut(½" U.N.F.) together 6	234010
25	Protection strip at joint (inside) 2	
26	Seal retainer for door top R.H.	
20 27	Seal retainer for door top, L.H.	
41	Sealing rubber for door top 2	
	Rivet fixing seal to retainer 10 Screw (2 B.A. x ½" long) \(\) Fixing 10	
	· · · · · · · · · · · · · · ·	
	Nut (2 B.A.) J cant rail 10	3823



	HARD IV	DP AND	11/	ROPICAL ROOF, 105
PLATE REF.	1 2 3 4 DESCRIPTION	V	Qty.	Part No. REMARKS
28	Rubber seal, top and bottom, for	capping at		
	front door, rear		6	332215
29	Sealing rubber, windscreen to roof	****	1	330878
30	REAR LID ASSEMBLY		1	332181 Quadrant type fixing Alternatives.
	REAR LID ASSEMBLY		1	333467 Rod type fixing Check before
				ordering
31	Lock complete for rear lid		1	302164
32	Bolt end for lock		2	262798
	Screw (2 B.A. $x \frac{1}{2}$ long)		4	77700
		ng lock	4	3816
	ę.	ar lid	4	3073
	Nut (2 B.A.)		4	2247
33	Guide for rear lid lock		2	332097
	Set bolt (‡" U.N.F. x ¾" long)	Fixing	4	255207
	Plain washer	≻guide	4	3900
	Spring washer	to	4	3074
34	Nut plate	rear lid	2	332121
35	Handle for rear lid, outer, locking		1	306461
	Screw (2 B.A. x 3/ long) \ Fixin		2	78171
	Nut (2 B.A.) hand	-	2	2247
36	Handle for rear lid, inner		1	302207
37	Boss		1	320046 Alternative
38	Coil spring Fixing		1	313493 to rear
39	Cap for coil spring handle		1	320047 door
40	Locking pin		1	302262 See also
41	Rubber seal for rear lid, bottom		1	332143 >pages 355
42	Retainer for bottom seal		1	332122 and 357
	Pop rivet fixing retaining strip		- 9	78257 Check
43	Glass for rear lid		1	332089 before
44	Weather strip for glass			302177 ordering
45	Filler strip for weather strip		1	302178
	Hinge leaf for rear lid, R.H.		1	332040 For lid with quadrant Alternatives
4 6	Hinge leaf for rear lid, L.H.		1	332041 type fixing Check
	Hinge leaf for rear lid		2	333468 For lid with rod type before
				fixing ordering
	Set bolt $(\frac{5}{16}"$ U.N.F. $x \frac{3}{4}"$ long)	Fixing	4	255226
	Plain washer	hinge leaf	4	3830
	Spring washer	to	4	3075
47	Tapped plate	rear lid	2	332047
48	Pin for rear lid hinge		2	302165
	Split pin Fixing		4	3901
	Plain washer hinge pin		4	3899
	Socket R.H. for rear lid lock bolt	****	1	332083
49	Socket L.H., for rear lid lock bolt		1	332084
= =	Bolt (\frac{1}{4}" U.N.F. x \frac{5}{8}" long)	••••	4	255206
	v 0, (ng socket	4	3840
	· ·	ar pillar	4	3074
	Nut (¼" U.N.F.)	P	4.	254810
	- · (* -·····)		•	 ·····




PLATE REF.	1 2 3 4 DESCRI	PTION	Qty.	Part No.	L 1001, 103	REMARKS	
50	Stay for rear lid, R.H.	···	1	332182)	·		<u> </u>
	Stay for rear lid, L.H.		1	332183			
	Plain washer		2	3899			
		stay to hinge leaf	2	2285			
	Split pin	,,	2	•	Quadrant type fixing		
	Bolt (‡" U.N.F. x \frac{5}{8}" lo	ng)]	4	255206	Zanarani ripo namig		
	Plain washer	Fixing stay	4	3946	·		Ì
	Spring washer	to body	4	3074			
	Nut (½" U.N.F.)	10 5029	4	254810			•
51	Stay for rear lid, R.H.		Î	332385) j .	1	
	Stay for rear lid, L.H.		1	332386			
52	Securing plate, R.H.	For rear	1	332391*			Alternative
	Securing plate, L.H.	lid stays	1	332392*	Part of)	to rear
	Rivet fixing plate to rea		14	300783	rear lid		door
53	Spring clip for rear lid	stay	2	332398	333467		See also
	Pop rivet, fixing clip to		2	7 8248			pages 355
54		rear lid stay	2	3901	>Rod type	Alternatives	and 357
55	Plain washer ∫ to supp	ort	2	2208	fixing	Check	Check
56	Mounting bracket for s		2	332393*		before	before
57	Locking nut for rear lid		2	332397*		ordering	ordering
58	Screw (2 B.A. $x \frac{3}{8}$ " long		2	77941			
59	Plain washer	∫locking nut	2	2983		1	
	Bolt ($\frac{1}{4}$ " U.N.F. $x \frac{5}{8}$ " los	 	4	255206			
	Plain washer	Fixing mounting	-	4071			
	Spring washer	bracket to body	4	3074			
	Nut (4" U.N.F.)	J	4	254810	J .	J	
60	Mounting stud]	4	332157			
	Special washer	Fixing hard top	2	332293			
	Plain washer, medium	to body	2	3830			
	Plain washer, large	at front	4	3898			
	Plain washer, small	and rear	2	4047			
	Spring washer	corners	8	3075			
	Nut (18" U.N.F.)	, , , , , , ,	8	254811	•		
	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{2}{8}"$ lo			255227			
	Plain washer	to body	2	3830			
	Spring washer	at rear inner	2	3075	·		
	Nut (16" U.N.F.)	bracket	2	254811			
	Bolt ($\frac{1}{4}$ " U.N.F. $\times \frac{5}{8}$ " lor Plain washer	· , - ·		255227			
		to body	2	3830 3075			
	Spring washer Nut (5/10 U.N.F.)	at rear inner bracket	2 2	3075 254811			
	Bolt (1 U.N.F. x § lor	2		255206			
	Plain washer		4	3840			
	Spring washer	to body at rear	4	3074			
	Nut (½" U.N.F.)	inner gusset	4	254810			
	Bolt (# U.N.F. x # lor		10	255207			
	Plain washer	Fixing roof	10	2760			
	Spring washer	to windscreen	10	3074			
	Nut (‡" U.N.F.)	to whitisticen	10	254810			
	. Tut (4 U.1761.)	,	.0	AJTOIU			






PLATE REF.	1 2 3 4 DESCE	RIPTION	Qty.	Part No.	REMARKS
	Set bolt $(\frac{5}{16}" \times 1\frac{1}{4}" \text{ long})$]	4	255230	
	Plain washer, small	Fixing side panels	4	3830	
	Spring washer	≻to body	4	3075	
	Plain washer, large	at centre	12	3898	
61	Nut plate	}	4	333837	
62	TROPICAL ROOF PANE	L ASSEMBLY	1	332987	
63	Stiffener, front \ For		3	332028	
64	Stiffener, rear froof par	nel	3	333252	
	Drive screw \ Fixing stif	ffener –	33	77704 \ Altern	atives
	Pop rivet ∫ to hard to	р	33	78248∫ Check	before ordering
	Screw (2 B.A. $x \frac{1}{2}$ " long))	8	77869	
	Plain washer	Fixing panel	16	3852	
65	Rubber washer	to roof at	8	302371	
	Shakeproof washer	end of stiffener	8	71082	
	Nut (2 B.A.))	8	3823	
	Screw (‡" U.N.F. x 2" lon	g)]	16	78274	
	Plain washer	Fixing	32	3900	
66	Distance piece	≻roof to	16	302372	•
67	Rubber washer	panel at	16	302373	
	Spring washer	sides	16	3074	
	Nut (‡" U.N.F.)	J	16	254810	
	Drive screw \(\bar{\chi}\) Fixing pa	nel to	66	77704	
	Pop rivet ∫ roof stiffer	ner	66	78248	
6 8	Interior mirror		1	334000	
	Drive screw, trimmed vehicle	es	2	77789	
	Bolt (2 B.A. $x \frac{1}{2}'' \text{ long}$)		2	234603	
	Packing washer >Un	trimmed Fixing	2	3864	
	Spring washer vel	nicles mirror	2	3073	
	Nut (2 B.A.)	J	2	3823	•

REAR DOOR, HARD TOP, 88 AND 109



REAR DOOR, HARD TOP, 88 AND 109

PLATE	1 2 2 4 DESCRIPTION		D . N		
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No	. REMARKS	
	REAR DOOR KIT COMPLETE ASSE	MBLY I	516473)	
1	REAR DOOR COMPLETE	!	333415		
1	Rear door	1	333416		
2	Glass for rear door	1	333031		
3	Retainer for glass, vertical	2	333033		
4	Retainer for glass, bottom	!	333032		
5	Retainer for glass, top	1	333034		
6	Retainer for glass, corners	2	333035		
	Drive Screw fixing retainers	32	78140		
	DOOR LOCK, MOUNTING AND	,	222020		
7	HANDLE ASSEMBLY	I	333039	·	
7	Mounting plate for door lock	I	333080		
8	Door lock	!	333040		
9	Washer, handle to cover	!	302859		
10	Door handle with lock	I	332432		
11	Barrel lock	!	306036		
12	Key for barrel lock	!	307289	State key number when ordering	
12	Bracket for door handle		302854	·	
	Screw (2 B.A. x ½" long)	6	313858		
	Spring washer Fixing loc		3073	ļ	
	Plain washer together	4	3685	Alternati	
	Nut (2 B.A.)	6	2247	to rear li	ıd
	Rivet	4	302222	Check	
12	Special screw	4	78216	2 off when stud plate is fitted before	
13		xing	332732	ordering	
	* *	or lock 4	3074		
	Nut (‡" U.N.F.)	4	254800	ļ	
1.4	Drive screw, fixing lock assembly to de	oor 2	77903		
14	Locking pillar for catch	!	332434		
	Plain washer	1	2226		
	Spring washer Fixing catch to pilla	ur i	3073	·	
15	Nut (2 B.A.)	1	2247		
15	Waist rail lock handle protection strip	1	333037	 •	
	Bolt (1" U.N.F. x 3" long) Fixing	2	255207		
	Spring washer strip	2	3074	·	
10	Nut (1" U.N.F.) to door	1	254800		
16	Wheel stud plate]	333435	.]	
17	Clamp plate for spare wheel stud plate	: I	333446	}	
	Screw (1" U.N.F. x 3" Fixing	•	#0010		
	long) stud and	8	78210		
	Spring washer clamp plates		3074		
10	Nut (1" U.N.F.) to rear door	8	254810	· ·	
18	'U' bolt for spare wheel support	1	333447		
	Nut (½" U.N.F.) fixing 'U' bolt to doo	or 4	254814	J	



REAR DOOR, HARD TOP, 88 AND 109

		TEHR BOOK,	IIIII	101,	00 11112		
PLATE REF.	1 2 3 4 D	ESCRIPTION	Qty.	Part No.		REMARKS	
19	Retaining plate fo	r spare wheel	1	333439			
20	Hub nut fixing w	heel and retaining pla	te to				
	'U' bolt	****	6	217361			
21	Male dovetail for	rear end door	1	332942			
	Screw ($\frac{1}{4}$ " U.N.F.	x I" long] Fixing	2	78389			
	Spring washer	≻male dove	etail 2	3074			
-	Nut ($\frac{1}{4}$ " U.N.F.)	j to door	2	254810			
22	Rod for check stre	ър	1	333041			
23	Buffer for check s	trap, short	1	306295			
24	Buffer for check s	trap, long	1	333445			
25	Hinge for rear do	or, upper	1	333036			
26	Hinge for rear do	or, lower	1	330117			
	Bolt (5 " U.N.F.	x 2" long) Tixing	4	256226			
	Spring washer	≻hinge to	4	3075			
	Nut (5 "U.N.F.)	J door fram	ne 4	254811		•	
	Bolt (5" U.N.F. x	{" long)]	4	255227			
	Plain washer	>Fixing door	. 4	3830			
	Spring washer	hinges to be	ody 4	3075			
	Nut (5″ U.N.F.)	J	4	254811			
	Bolt (1 U.N.F. x 1	½" long)]	1	255251			
	Spring washer	Fixing	1	3074	Alternative to		
	Plain washer, thick	>check strap		4075	rear lid		
	Plain washer, thin	to floor	2	II.	≻Check		
	Nut (‡" U.N.F.)	J.	2	25 4 810	before		
27	Striking plate		1	333140	ordering		
	Bolt (‡" U.N.F. x 1"		2	255009			
	Plain washer	Fixing striki	_				
	Spring washer	plate to rear		3074			
	Nut (‡" U.N.F.)	∫ body	2	254800			
28	Female dovetail for		1	332147			
29	Spacer for female de		1	332943			
	•=	½" long), fixing doveta	_				
	spacer		2	78233			
	Screw (½" U.N.F. x	<u>:</u>	2	255207			
	Plain washer	Fixing space	er to 2	3900			
30	Shim	L.H. rear p		305232			
	Spring washer	J	2	3074			
31	Seal for door sides		3	330535			
32	Seal for door side, I]	332563			
33	End filler piece for		4	330850			
	Rivet fixing seals to		22	302818			
34	Rubber seal, door b	ottom	l	332564			
35	Seal retainer	•	I	332566			
	Drive screw fixing r	etainer	7	77707			






PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	CAB COMPLETE ASSEMBLY	1	330959 88	<u></u>
	CAB COMPLETE ASSEMBLY	1	330961 109	
1	CAB ROOF ASSEMBLY	i	332945	
2	Sealing rubber, door top	2	330541	
	Rivet fixing rubber to retainer	10	302818	
	Retainer for seal, R.H. \ For door	1	330788	
3	Retainer for seal, L.H. Stop	1	330789	
-	Screw (2 B.A. x ½" long) Fixing	10	77869	
	Plain washer > seal retainer	10	3902	
	Spring washer to	10	3073	
	Nut (2 B.A.) cab top	10	3823	
4	CAD DEAD DANIEL ACCUMULA	•	330769	
5	D 11 . 1 . (. 1 1 1 .	•	330780	
6	Rubber seal, back panel to rear body	1	333486	
7	Chilian Landhala	2	330768	
8	C. P 11 . C. 1 . 11 15	1		
9	Channel for mild or	1	330798	
10	Channel for rubber	2	330799 330744	
10	Channel, bottom For	2	332744 332745	
11	Channel, sides backlight			
• • •	Vertical finisher for L.H. side	2	332751	
	D' C' I I	1 14	332683	
	Catch for sliding backlight, R.H., overall	26	77707	
		1	22224	•
12	length 1½"	1 11	332324	
12	Catch for sliding backlight, L.H., over	ali 1	22222	
13	length 1"	1	332325	
כו	Screw (2 B.A. x ¾" long), L.H.	1	78223)	
14	Screw (2 B.A. x ² / ₈ " long), R.H.	1	78260 > 2 B.A. fixing. Alternat	ive to U.N.F.
15	Distance piece	3	340390 Check before ordering	
כו	Special washer Fixing	4	340391	
	Screw (‡" U.N.F. x ¾" long), L.H. catches	1	78401	
	Screw (¼" U.N.F. x ½" long), R.H.	l l	,	ternative to 2 B.A.
14	Special washer	8	340391 Check before ordering	
16 17	Tapped plate	2	332329	
12	Runner for sliding backlight catch	2	330848	
18	Pop rivet fixing runner	14	78248	•
19	Quarter light for cab, R.H.	l ,	330792	· ·
20	Quarter light for cab, L.H.	1	330793	
21	Weather strip For quarter	2	330790	
22	Sealing strip ∫ light	2	330791	
23	Sealing rubber, windscreen to roof	1	330878	
4.5	Sealing rubber, door side	2	330535	•
			302818	
	Bolt (‡" U.N.F. x ¾" long)	12	255207	
	Plain washer Fixing roof to	12	3900	
	Spring washer rear panel	12	3074	
24	Nut (‡" U.N.F.)	12	254810	
24	Mounting stud	2	330762	
	Plain washer, 5 I.D.	4	3898	
	Plain washer, ½" I.D. Fixing stud and cab	6	3829	
	Spring washer to rear body	4	3075	
	Nut (& U.N.F.)	4	254811	



		CAB AND	IKC	PICAL	ROUF			
PLATE REF.		ON	Qty.	Part No.		RE	EMARKS	
	Bolt $(\frac{1}{4}$ U.N.F. $x \frac{3}{4}$ long))	10	255207				
	Plain washer	Fixing cab to	10	3900				
	Spring washer	windscreen	10	3074				
	Nut (1" U.N.F.))	10	254810				
25	Mounting rail for cab		. 1	330750				
26	Support bracket for mounting	ng rail	. 1	330767				
	Bolt (¼" U.N.F. x ¾" long)	Fixing mounting	12	255207	-			
	Plain washer	rail and support	8	3900				
	Spring washer	bracket to	12	3074				
	Nut (¾" U.N.F.)	rear body	12	254810				
	Bolt (5 "U.N.F. x 15" long	Fixing	4	256223	88	:		
	Plain washer	≻cab to	4	3898		:		
	Spring washer	mounting	4	3075				
	Nut (5 U.N.F.)	rail	4	254811				
	Screw (2 B.A. x) Fixing:	seat		·]				
	$\frac{7}{8}''$ long) \Rightarrow strap st	uds to	3	77925				
	Packing washer J mounting		9	3851)				
27	Distance piece for cab moun		4	330782				
	Bolt (‡" U.N.F. x ½" long) `	Fixing distance	8	255204				
	Spring washer	>pieces to	8	3074				
	Nut (¼" U.N.F.)	rear body	8	254810 >	109			
	Set bolt ($\frac{5}{16}$ " U.N.F. x $\frac{3}{4}$ " los		4	255226				
	Spring washer	≻to distance	4	3075				
	Plain washer	J pieces	4	3898				
	Interior mirror		1	334000				
	Drive screw, trimmed vehicles	}	2	77789				
	Bolt (2 B.A. $x \frac{1}{2}'' \text{ long}$)		2	234603				
	~	mmed >Fixing	2	3864				
	Spring washer Vehic	eles mirror	2	3073				
	Nut (2.B.A.)	J	2	3823				
28	Tropical roof panel for cab		1	330894				
	Screw ($\frac{1}{4}$ " U.N.F. x 2" long)		10	78274				
20	Plain washer	T	20	3900				
29		Fixing tropical	10	302372				
30	Rubber washer	roof panel to	10	302373				
	Spring washer	cab roof	10	3074				
	Nut (¼" U.N.F.)		10	254810				

See Page 480 for locking handles and catches for front doors and sliding windows.


DE LUXE TRIM FOR CAB, UPPER



DE LUXE TRIM FOR CAB, UPPER

PLATE REF.	1 2 3 4 DESCRIPTION Oty.	Part No. REMARKS
KEF.	TRIM FOR CAB, UPPER, COMPLETE	TOTAL TOTAL
	ACCERTOL W	332956
1	D. C	
•		331581
	Drive screw, fixing roof trim 20	77704
2	Canopy trim panel complete 1	331416
	Drive screw Fixing panel 5	77704
_	Plain washer \(\int \text{ to roof} \)	3886
3	Lower member, R.H. Quarter trim	331556
	Lower member, L.H. ∫ panel	331557
4	Upper member, R.H. \ Quarter trim 1	331560
	Upper member, L.H. ∫ panel 1	331561
5	Outer member, R.H. \ Quarter trim	331553
	Outer member, L.H. ∫panel	331554
6	Inner member, R.H. Quarter trim	331549
	Inner member, L.H. panel 1	331550
7	Upper panel, R.H. Quarter	331564
	Upper panel, L.H. Strim	331565
8	Lower panel, R.H. Quarter	331567
	Lower panel, L.H. Strim	331568
9	Rear lower panel for backlight 1	331574
10	Inner panel, R.H. lower member \ Quarter 1	331570
	Inner panel, L.H. lower member trim 1	331571
11	Rear head trim, R.H. \ For	331578
12	Rear head trim, L.H. backlight 1	331579
13	Mounting bracket, quarter trim panel 4	331530
	Pop rivet fixing mounting bracket to front pillar 8	78257
	Trim clips securing panels 16	310599
	Drive screw Fixing 17	78126
	Plain washer Jouter panels 17	3925
14	Cant rail casing 2	331576
15	Bracket for cant rail casing 2	331150
	Drive screw fixing bracket to cant rail 2	77949
16	Lead for roof lamp]	245386 For lamp with integral switch
	Lead for roof lamp. roof portion, LU 862546 1	265482
	Lead for roof lamp, chassis portion, LU 862545	265481 Series II models For lamp with separate
	Lead for roof lamp, chassis portion 1	519876 Series IIA models switch
17	Grommet—roof lead to dash 1	233244
18	Cable clip Fixing lead to dash 2	41379
•••	Drive screw and windscreen 2	78116
	F 1	219078)
	Screw (5 B.A. $\times \frac{5}{8}$ " long) Fixing fuse box 2	3279 > Series II models
	Nut (5 B.A.) to dash 2	3280 Series 11 models
19	D(1	340704)
17	D II (TILL COO)	242491
	TO 11 11 1 6 (1)	
		332985 Lamp with integral switch. Alternative to type
	Drive screw Fixing lamp and 2 Drive screw packing block 2	77707 with separate switch. Check before ordering 77892
	Roof lamp complete, LU 56062/A Lucas type	265295 Alternatives J
	Roof lamp complete, Sparto type 1	Lamp with separate switch
	Bulb for roof lamp, LU 382 1 Switch for roof lamp 1	264591 Alternative to type with integral
	<u>-</u>	240908 switch
	Drive screw fixing lamp to bracket on roof trim	Check before ordering
	frame 2	77704 J

DE LUXE TRIM FOR DOORS AND FLOOR



DE LUXE TRIM FOR DOORS AND FLOOR

	<u> </u>					
PLATE REF.		DESCRIPTION		Qty.	Part No.	REMARKS
		OOR AND FLOOR	COMPLE'	TE		
	ASSEMB		••••	1	332958	R.H.D.
		OOR AND FLOOR	COMPLE'	TE		
	ASSEMB		••••	1		L,H,D,
1	Door casing	trimmed, R.H.		1	331702	
	Door casing	, trimmed, L.H.	****	1	331703	
2		t and upper casing ass	-			With integral armrest.
		and upper casing ass	embly, L.H			Alternative to separate armrest type.
3		or side armrest		2	_	Check before ordering
		casing assembly R.H.		1	331812)	
		casing assembly L.H.		1		With separate armrest.
		assembly R.H.	****	1	331810	Alternative to integral armrest type
		assembly L.H.		1	331811	Check before ordering.
		or side armrest		2	331807	
		Fixing armrest		8	77704	
	Plain washer			8	4032	5
4		rt, inner For dash		1	331166	Alternative to line below Check
5		rt, outer ftop casing		1	331163	שוויסטיק
		ate for dash top casing		2		Alternative to two lines above Jordering
,		fixing inner support to]	78140	
6	Top casing f			1	331780	R.H.D.
_	Top casing f]	331781	L.H.D.
7		ng at dash centre	••••		331456	DUD
8		ng at dash side R.H.		[331457	R.H.D.
		ng at dash side R.H.]	331526	L.H.D.
9		ng at dash side L.H.		1		R.H.D.
10		ng at dash side L.H.	••••]	331527	L.H.D.
IV		dash top casing R.H.		1	331411	R.H.D.
11		dash top casing R.H.	••••	1		L.H.D. R.H.D.
"		dash top casing L.H. dash top casing L.H.	••••	1	331402 331415	L.H.D.
12		floor covering at 'A' p			331400	L.H.D.
12		fixing retainers		10	78140	
13	Gearbox cov	-	****	1	331452	
14	Front floor	****	••••	1	331392	
15	Front floor	=		7	331393	4
16		or floor mats	••••	4	355847	
17	Drive screw		••••	8	77932	
	Front door p		••••	2	306460	
	Special nut	Fixing handle to		4	78319	•
	Drive screw	armrest casing	•	4	78121	
	Dille Scien) aimest casing		т	10121	

.

REAR POWER TAKE-OFF

ATE 1	2 3 4	DESCRIPTION	Qty.	Part No.	REMARKS
c	f rear pow	of parts of the various combination for take-off are supplied under firs listed below:—			
RË	AR POW ASSEME PULLEY	BLY, WITHOUT REAR	TE 1	241706	Comprises all standard items on pages 369 to 377
CE		POWER TAKE-OFF, LE E PULLEY	SS 1	261835	Comprises drive unit and selector unit on pages 369 and 371
RE	AR POW ASSEME 109	VER TAKE-OFF COMPLE BLY WITHOUT REAR PULLI		501680	Comprises all the standard items on pages 369 to 377 except those marked "88".




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	<u> </u>	REMARKS
	GEARBOX P.T.O. DRIVE ASSEMBLY	1	230855		
	GEARBOX P.T.O. DRIVE ASSEMBLY	1		Heavy-duty type	
1	HOUSING ASSEMBLY FOR DRIVE				
-	BEARING	1	219860		
. 2	HOUSING ASSEMBLY FOR DRIVE	1			
. ~	BEARING	1	235239	Heavy-duty type	-
3	Stud for oil seal housing	6	216986		
4	Shaft for P.T.O. drive	1	219744		
5	Shaft for P.T.O. drive	1		Heavy-duty type	
6	Bearing for gearbox mainshaft	i	217478	loury daily type	
7	Retaining plate for bearing	i	217523		
8	Circlip fixing retaining plate	İ	217525	•	
9	Bearing for drive shaft, front	i	55714		
10	Circlip, bearing to housing	1	217972		
11	Bearing for drive shaft, rear	1	217325		
12	Bearing for drive shaft, rear	1		Heavy-duty type	
13	Shim for bearing, .003"	As required		reavy-duty type	
1,5	Shim for bearing, .005"	As required			
14	Housing for oil seal	I	236543		
15	Mudshield for housing	i	236548		
16	Spring washer \(\) Fixing oil seal housing		3075		
17	Nut (\frac{16}{16}" B.S.F.) \int \text{ bearing housing}	6	2828		
18	Oil seal for drive shaft	1	236417		
19	Flange for P.T.O. drive shaft	1	237912		
20	Flange for P.T.O. drive shaft	1	235253		
21	Bolt (§ B.S.F. x 1 ½ long) for flange	4		Heavy-duty type	
22	Circlip retaining bolts	1	217546	reary-duty type	
23	Mudshield for flange	i	236074		
24	Plain washer	i	3300		
25	Slotted nut >Fixing flange to shaft	i	3259		
26	Split pin	1	2428		
27	Dog clutch for P.T.O. shaft	i	217522	•	
28	Joint washer for housing	1	217680		
29	Spring washer Fixing housing to	6	3076		
30	Nut (§" B.S.F.) transfer case	6	2827		
20	P.T.O. SELECTOR ASSEMBLY	Ť	230693)	
	P.T.O. SELECTOR ASSEMBLY	1		Heavy-duty type	
31	Housing for P.T.O. selector	1	217773	-7 7-75-	
3 2	Selector shaft and rod for P.T.O.	1	218171		
33	Selector shaft and rod for P.T.O.	i		Heavy-duty type	• •
34	Knob for rod	i	218050		With selector knob
35	Locknut (16") for knob	1	3764		under centre seat
36	Fork for selector shaft	1	217584		
37	Set bolt ($\frac{5}{16}$ " B.S.F. x 1" long) fixing fork to sl		237160		
3 8	Steel ball \ For selector	1	1643		
3 9	Spring shaft	i	214290		N.
40	Plug for spring	. i	217763		
10	a seed tot abstract and and and and		2.1105	,	





PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
41	Joint washer for plug	· 1	213960).
42	Cover plate for housing	1	217774	
43	Joint washer for plate	1	219995	With selector knob under centre seat
44	Set bolt (4" Whit. x 3" long) Fixing	4	215594	
45	Spring washer plate	4	3074	J
	P.T.O. SELECTOR ASSEMBLY	1	509076	<u></u>
	Housing for P.T.O. selector	1	217773	
	Selector shaft for P.T.O	1	506203	
	Fork for selector shaft	1	217584	·
	Set bolt $(\frac{5}{16}"$ B.S.F. x 1" long) fixing fork to	shaft l	237160	
	Steel ball \ For selector	1	1643	·
	Spring ∫ shaft	1	56 102	
	Plug for spring	1	217763	
	Joint washer for plug	1	213960	
	Cover plate for housing	1	217774	
	Joint washer for plate	1	219995	
	Set bolt $(\frac{1}{4}'')$ Whit. $x \frac{3}{4}''$ long) $\int Fixing cov$		215594	
	Spring washer	4	3074	With selector knob in front of seat
	Pivot piece	l	506205	
	Locknut (3" B.S.F.) for pivot piece	!	2323	·
	Stud for P.T.O. housing and pivot piece	!	506204	
	Lever for selector shaft	I	506206	
	Clevis pin and spring complete Fixing lev		216421	
	Split pin pivot piece	e 2	2423	
	and shaft	1	50/307	·
	Rod for lever	1	506207	
	Grommet for rod	I	508571	
	Knob for rod	l	218050	
	Locknut (78" B.S.F.) for knob	I	3764 230279	
	Clevis pin and spring complete Fixing lev Split pin to rod	er i 1	2422	
46	Joint washer for housing	1	217771	J
47	Spring washer \rightarrow Fixing housing to	1	3075	•
48	Nut (\frac{15}{6}" B.S.F.) \int transfer box	4	2828	
49	Pulley for centre power take-off	1	231636	
50	Bolt (§ B.S.F. x 1§ long)	4		When centre P.T.O. pulley only is fitted
51	Bolt (§ B.S.F. x 15 long) Fixing pulley	. 4		When rear P.T.O. is also fitted
52	Self-locking nut (§ B.S.F.)	4	251322	
	Cover for P.T.O. knob	i	301957)
	Spring clip for cover	1	301139	With selector knob under centre seat
	Plain washer \ Fixing spring clip	1	2869	
	Rivet to centre panel	ĺ	300783	
	J == F	=		

When centre power take-off is fitted, Part Nos. 230855 Gearbox power take-off drive assembly and 230693 Power take-off selector assembly are required; the pulley and bolts are normally supplied by the makers of any special equipment fitted.

When Part Nos. 230855 Gearbox power take-off drive assembly and 230693, 231853 or 509076 Power take-off selector assembly are fitted, the following parts, listed on page 153, are not required: 230696 Mainshaft bearing housing complete: 217970 Cover plate.



Propeller shaft, P.J. O., drive	PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y. Part No.	REMARKS
2 Splined end For 1 262468 3 Finge propeller shaft 2 4903 4 Journal complete for propeller shaft 2 4903 5 Circlip for journal 8 24252 6 Grease nipple for journal 2 23257 7 Grease nipple for propeller shaft 2 24352 8 Washer for nipple 1 261428 Propeller shaft, rear half 1 277139 Flange for shaft 1 43023 Girclip for journal 4 242522 Grease nipple for journal 4 242522 Grease nipple for journal 4 242522 Grease nipple for journal 4 242522 Grease nipple for journal 1 261775 Support tube and plate 1 261775 Support tube and plate 1 261776 Bott if B.S.F. x 2½ long) Stoel bush Fixing centre of 2 239919 Plain washer 1 261925 Nut (½ B.S.F. x 2½ long) 2 244360 Nut (½ B.S.F. x 1½ long) 2 2357 Flange for propeller shaft 2 3973 Spring washer 2 261925 Nut (½ B.S.F. x 1½ long) 2 22527 Flange for propeller shaft 2 249196 Split pin 2 428 Fropeller shaft, front half 1 26941 Splined end For 1 262468 Flange shaft 2 262469 Journal for shaft 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for popeller shaft 2 34932 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 3 24532 Grease nipple for journal 2 232557 Grease nipple for journal 2 232557 Grease nipple for journal 3 24532 Grease nipple for journal 3 24532 Grease nipple for journal 4 23048 Grease nipple for journal 5 24500 Grease nipple for journal 5 24500 Grease nipple for journal 5 24500 Grea	1		1	•	
Flange	,		1		
Journal complete for propeller shaft		<u>-</u>	2		
Crease nipple for journal		- 2			>88
Gresse nipple for journal 2 324532 Washer for nipple 1 261428 Propeller shaft, rear half 1 277139 Flange for shaft 1 43023 Circlip for journal 4 424522 Grease nipple for journal 4 4242522 Grease nipple for journal 1 43023 Circlip for journal 4 424522 Grease nipple for journal 1 232557 Dust shield 1 261774 Bearing for shaft 1 261775 Support tube and plate 1 261776 Bolt (¾ B.S.F. 2↓ long) Sixeel bush Plain washer 2 23591 Plain washer 3 2 3076 Nut (¾ B.S.F.) 5 2 2 15285 Spring washer 3 2 261924 Woodruff key 2 261925 Woodruff key 2 261925 Special castle nut 1 243196 Split pin 1 2428 Fropeller shaft, 1 236941 Splined end ∫ For 1 262468 Flange ∫ shaft 2 262469 Journal for shaft 2 43023 Grease nipple for journal 8 242522 Grease nipple for porpeller shaft 1 277140 Bolt (¾ U.N.F. ¾ long) Plain washer 8 2 261925 Washer for nipple masher 1 277149 Nut (¾ U.N.F.) 5 Special bolt (¾ B.S.F. x ¼ long) Fixing 2 277499 Nut (¾ U.N.F. x ¾ long) Plain washer 8 2 261925 Special bolt (¾ B.S.F. x ¼ long) Fixing 2 2213 Spring washer 1 277140 Bolt (¾ U.N.F. x ¾ long) Plain washer 8 50526 12 off on 109 ∫ fixing 4 255007 Plain washer 9 5 pecial bolt (¾ B.S.F. x ¼ long) Plain washer 8 50526 12 off on 109 ∫ fixing 4 255007 REAR POWER TAKE-OFF DRIVE ASSEMBLY, FOR P.T.O. 1 230288 2 Stud (2½ long for pulley housing or guard) 4 231432 14 HOUSING ASSEMBLY, FOR P.T.O. 1 230288 1 2 Stud for bearing housing 1 00 214054 Bearing for input shaft, front 1 1 217564					
7 Crease nipple for propeller shaft .250" dia. 1 .234532 8 Washer for nipple			7		
Reserve for nipple			1	i	
Propeller shaft, rear half			, 1		
Flange for shaft	O		1		
Journal for shaft		<u> </u>	1	i,	
Circlip for journal			1		
Crease nipple for journal			•	l l	
Dust shield			1		
Bearing for shaft			!		
Support tube and plate			1	· · · · · · · · · · · · · · · · · · ·	
Bolt (\frac{1}{8}" B.S.F. x 2\frac{1}{8}" long) 2 215285 5 5 5 5 5 5 5 5 5		_	1	L	
Steel bush Rubber bush Pixing centre of 2 235919 Plain washer 2 3076				· ·	
Rubber bush Plain washer Plain washer Spring washer Nut (\frac{1}{8}'' B.S.F.)					
Plain washer Spring washer Nut (\(\frac{3}{8}^*\) B.S.F.) Figure for propeller shaft 2 3933					
Spring washer 2 3076 Nut (§* B.S.F.) 2 2827		(~			
Nut (\$" B.S.F.)					
Flange for propeller shaft					
Woodruff key					
Special castle nut 1			,		Lina
Split pin		· ·		1	
Propeller shaft, front half		· ·			
Splined end For				l l	
Flange					
Journal for shaft		· >	-		
Grease nipple for journal					
Circlip for journal 8 242522 Crease nipple for spline 1 234532 Washer for nipple 1 234532 Washer for nipple 1 261428 Shim for propeller shaft centre bearing As required 232684 Intermediate support for propeller shaft 1 277140 Bolt (\frac{1}{2}'' \text{ U.N.F. x \frac{3}{4}''} \text{ long}) Fixing 2 2213 Spring washer					
Crease nipple for spline		= =		•	
Washer for nipple		• •			
Shim for propeller shaft centre bearing			1		
Intermediate support for propeller shaft 277140 Bolt (\frac{1}{a}' \ \text{U.N.F. x \frac{3}{a}'' \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \			As req	Į.	
Bolt (\frac{1}{8}' U.N.F. x \frac{3}{4}'' long)				1 277140	<u> </u>
Plain washer Fixing 2 2213					
Spring washer Locking plate Support to 2 277491 Special nut Chassis frame 2 277490 Nut (\frac{1}{4}" U.N.F.) 2 254800 9 Special bolt (\frac{3}{8}" B.S.F. \times 1\frac{1}{8}" long) Fixing 4 237341 Propeller 8 50526 12 off on 109 Fixing Special bolt (\frac{3}{8}" U.N.F. \times 1\frac{1}{8}" long) Self-locking nut (\frac{3}{8}" U.N.F.) Self-locking nut (\f		·	2	2 2213	•
Locking plate Support to 2 277491 Special nut Chassis frame 2 277490 Nut (½" U.N.F.) 2 254800 Special bolt (¾" B.S.F. x 1½" long) Fixing 4 237341 Self-locking nut (¾" B.S.F.) Propeller 8 50526 12 off on 109 Fixing Alternatives Special bolt (¾" U.N.F. x 1¾" long) Shaft to 4 509045 U.N.F. fixing Self-locking nut (¾" U.N.F.) drive flanges 8 509751 U.N.F. fixing Check before ordering Self-locking nut (¾" U.N.F.) REAR POWER TAKE-OFF DRIVE ASSEMBLY, SIX-SPLINE 1 230176 11 HOUSING ASSEMBLY FOR P.T.O. 1 230288 12 Stud for bearing housing 10 214054 13 Stud (2½" long) for pulley housing or guard) 4 231432 14 Input shaft for P.T.O. 1 217562 15 Bearing for input shaft, front 1 217504		,	4	4 3074	
Special nut Chassis frame 2 277490 Nut (\frac{1}{2}'' \text{ U.N.F.}) 2 254800 9 Special bolt (\frac{3}{3}'' \text{ B.S.F. x } \frac{1}{8}'' \text{ long}) Fixing 4 237341 B.S.F. 10 Self-locking nut (\frac{3}{3}'' \text{ U.N.F. x } \frac{1}{8}'' \text{ long}) shaft to 4 509045 Self-locking nut (\frac{3}{8}'' \text{ U.N.F.}) drive flanges 8 509751 U.N.F. fixing Check before ordering REAR POWER TAKE-OFF DRIVE 230176			2	2 277491	
9 Special bolt (\(\frac{3}{8}\)'' B.S.F. \(\times 1\frac{1}{8}\)'' long) \(\frac{7}{8}\) Fixing 4 237341 \(\frac{3}{8}\) B.S.F. \(\frac{3}{8}\)'' B.S.F.) \(\frac{3}{8}\)'' B.S.F.) \(\frac{3}{8}\)'' propeller 8 50526 12 off on 109 \(\frac{10}{9}\) fixing \(\frac{3}{8}\)'' U.N.F. \(\text{x} 1\frac{1}{8}\)'' long) \(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' long) \(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F.) \(\frac{1}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' U.N.F. \(\frac{1}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' ing Self-locking nut (\(\frac{3}{8}\)'' ing Self-locking nut (\(\frac{3}\)'' ing Self-lock		Special nut chassis frame	e 2	2 277490	
9 Special bolt (\(\frac{3}{8}"\) B.S.F. \(\times\) 1 \(\frac{3}{8}"\) B.S.F. \(\times\) 1 \(\frac{3}{8}"\) B.S.F. \(\times\) 1 \(\frac{3}{8}"\) B.S.F.		Nut (‡" U.N.F.)	2	2 254800	
Special bolt (\frac{3}{8}" U.N.F. x 1\frac{1}{8}" long) shaft to 4 509045 Self-locking nut (\frac{3}{8}" U.N.F.) drive flanges 8 509751 U.N.F. fixing	9		4	4 237341	``\ B.S.F. ```\
Self-locking nut (\frac{3}{8}" U.N.F.)	10		ler å	8 50526	12 off on 109 ∫ fixing ≻Alternatives
REAR POWER TAKE-OFF DRIVE ASSEMBLY, SIX-SPLINE		Special bolt ($\frac{3}{8}$ " U.N.F. x $1\frac{1}{8}$ " long) shaft to	, 4		
ASSEMBLY, SIX-SPLINE 1 230176 11 HOUSING ASSEMBLY FOR P.T.O 1 230288 12 Stud for bearing housing 10 214054 13 Stud (2½ "long) for pulley housing or guard) 4 231432 14 Input shaft for P.T.O 1 217562 15 Bearing for input shaft, front 1 217504		Self-locking nut ($\frac{3}{8}$ " U.N.F.) drive fl	langes 8	3 5,09 7 51 J	CO.IV.P. lixing
11 HOUSING ASSEMBLY FOR P.T.O 1 230288 12 Stud for bearing housing 10 214054 13 Stud (2½ "long) for pulley housing or guard) 4 231432 14 Input shaft for P.T.O 1 217562 15 Bearing for input shaft, front 1 217504				_	-
12 Stud for bearing housing 10 214054 13 Stud (2½ long) for pulley housing or guard) 4 231432 14 Input shaft for P.T.O 1 217562 15 Bearing for input shaft, front 1 217504					
13 Stud (2½" long) for pulley housing or guard) 4 231432 14 Input shaft for P.T.O 1 217562 15 Bearing for input shaft, front 1 217504					
14 Input shaft for P.T.O 1 217562 15 Bearing for input shaft, front 1 217504					
15 Bearing for input shaft, front 1 217504			uard) 🧸		
		-	••••		
			•••		
16 Circlip, bearing to housing 1 217566	16	Circlip, bearing to housing	••••	1 217566	




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
17	Retainer for oil seal \ For input	1	217663	,
18	Oil seal shaft	1	217508	
19	Joint washer for retainer	1	217664	
20	Screw (4" Whit. x 18" long) fixing retainer	5	55779	
	0 1 1 20 1	1	236301	Oul.,
21	•	[Only supplied in pairs
22	Bearing for input shaft, rear	I	217504	
	Shim .005"	As required		
23	Shim .010" > For rear input shaft bearing	As required		
	Shim .020" J	As required		
24	Circlip, bearing to housing	1	217566	
25	Housing for rear input shaft bearing	1	217661	
26	Joint washer for rear bearing housing	1	217662	
27	Spring washer \(\) Fixing bearing	5	3075	
28	Nut $\binom{5}{16}$ B.S.F.) \int housing to casing	5	2828	
29	Plain washer Fixing	1	3300	
30	Slotted nut rear bearing to	1	3259	
31	Split pin input shaft	1	2428	
32	Flange for P.T.O. input shaft	Ì	217667	
33	Special bolt for propeller shaft	4	217565	B.S.F. fixing \ Alternatives
22	Special bolt for propeller shaft	4	512701	U.N.F. fixing Check before ordering
34	C' - l'	1	217546	on the hand y check before ordering
35	Plain washer	1	3300	
36	Slotted nut Fixing flange to input shaft	1	3259	
37		1	2428	
38	Split pin Output shaft for P.T.O., six-spline	1	230098	
		I	217504	
39	Bearing for output shaft, rear	, 1		
40 41	Circlip for bearing	I	217566	•
41	Retainer for oil seal For output	1	217663	
42	Oil seal ∫ shaft	1	217508	
43	Joint washer for retainer	I	217664	•
44	Screw (1" Whit. x 18" long) fixing retainer	5	55779	
45	Gear wheel, 24 teeth		236301	Only supplied in pairs
46	Bearing for output shaft, front	1	217504	
4=	Shim .005" For front	As required		·
47	Shim .010" >output shaft	As required		
	Shim .020" bearing	As required		
48	Circlip, bearing to housing]	217566	
49	Housing for output shaft front bearing	1	217661	
50	Joint washer for bearing housing	l	217662	
51	Spring washer Fixing bearing	5	3075	
52	Nut $(\frac{5}{16}" B.S.F.) \int$ housing to casing	5	2828	
53	Plain washer Fixing	1	3300	•
54	Slotted nut \rightarrow front bearing to	I	3259	
55	Split pin Joutput shaft	1	2428	
56	Cover plate for bearings	2	217659	
57	Joint washer for cover plate	2	217660	
58	Set bolt (1" Whit. x 1" long) Fixing cover p		215758	
59	Spring washer	ings 12	3074	
60	Breather for casing	1	42431	
61	Filler plug	1	3292	,
62	Drain plug for casing	1	3088	
63	Fibre washer for plug	1	213960	





PLATE REF.	1 2 3 4 DESCRIPT	ION	Qty.	Part No.		REMARKS
64	Bolt (3" U.N.F. x 53" long)		2	253824	<u> </u>	·· ·
	Bolt (§" U.N.F. x 2¾" long)	1	1	256448		
65	Plain washer	Fixing P.T.O.	4	4067		•
66	Spring washer	assembly to chassis	3	3 076		
67	Nut (§" U.N.F.)	}	3	254810		
68	Guard for P.T.O. spline	···· ···· ····	1	230122		
69	Spring washer \ Fixing		4	3076		
70	Nut (§ B.S.F.) guard		4	2827		
	End cover for guard	**** **** ****	1	502037		
	Bracket for end cover	**** par. pag.	1	502039		
	Bolt (3" U.N.C. x 13" long))	1	253254		
	Plain washer, large		1	502044		
	Plain washer, small	Fixing	2	4067		
	Spring washer	guard to	1	3076		
	Nut (§ U.N.C.)	P.T.O. cover	1	256812		
	Wing nut	}	1	250046		
	Anchor for pintle hook	····	1	231498		
	Bolt (3" B.S.F. x 2" long)	Fixing anchor to	2	267431		
	Self-locking nut (3" B.S.F.)	chassis frame	2	234828		
	• '•	•		·		

REAR POWER TAKE-OFF PULLEY SECTION



REAR POWER TAKE-OFF PULLEY SECTION

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	POWER TAKE-OFF ASSEMBLY, PULL			A MANAGEMENT AND A MANA
	SECTION, SIX-SPLINE	1	230177	
1	HOUSING ASSEMBLY FOR P.T.O.		-	
	PINION	1	218846	
2	Stud for pulley drive housing	6	214054	
3	Stud for end plate	6	212103	
4	Pinion driving sleeve, six-spline	1	232960	
5	Bearing for sleeve]	217505	
6	Circlip, bearing to sleeve]	217567	
7 8	Oil seal for driving sleeve		217507	
. 0	Spiral bevel wheel and pinion	I	233377	•
9	Shim .005" For spiral bevel wheel	As required		
7	Shim .020" Shim .020"	As required		
10	וווויד. ב פ	As required	217505	•
11	Retaining plate for bevel wheel	1	217657	
12	Cork washer for retaining plate	1	217658	
13	Spring washer Fixing plat		3074	
14	Set bolt (¼" Whit. x ½" long) driving slee		237139	•
15	End plate for bevel wheel bearing	1	218841	
	Shim .005")	As required		
16	Shim .010" > For bevel wheel end plate	As required		
	Shim .020" J	As required	218844	:
17	Spring washer \(\) Fixing bearing end plate	6	3074	
18	Nut (¼" B.S.F.) ∫ to pinion housing	6	2823	
19	Breather for housing	1	42431	
20	Filler plug for housing	1	3292	
21	Plug for oil level]	215769	
22	Washer for plug]	232037	
23	Housing for pulley drive pinion	1	217650	
24	Shim .005" For Shim .010" > pulley drive	As required		•
24	Shim .020" pinion housing	As required		
25	Spring washer \(\) Fixing pulley drive	As required	3075	
26	Nut $\binom{18}{18}$ B.S.F.) \int housing to pinion housing		2828	
27	Bearing for pinion	2	217506	
28	Distance tube for bearings	1	217560	
	Shim .005"	As required		•
29	Shim .010" > For bevel pinion bearings	As required		
	Shim .020"	As required		
3 0	Oil seal for bevel pinion bearings	1	217507	
31	Pulley	1	217647	·
32	Plain washer	1	3300	
33	Slotted nut Fixing pulley to bevel pinion	n]	3259	
34	Split pin	1	2428	




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
2764 4	ENGINE GOVERNOR COMPLETE			
	ASSEMBLY	1	241708	
1	Engine governor complete	1	240628	
2	Lever, governor to quadrant	1	261515	
3	Lever, governor to bell crank	1	244339	
4	Spring blade for bell crank	Ì	263059	
5	Bolt (1" B.S.F. x 1" long) Fixing	2	237143	
6	Shakeproof washer Shevers to	2	70884	:
7	Nut (‡" B.S.F.) governor	2	2823	
8	Bearing, large \(\) For engine	1	262729	
	Bearing, small governor	1	262728	
9	Oil seal for pulley end	1	261573	
10	Pulley for governor	1	261517	
11	Woodruff key for pulley	1	261561	
12	Plain washer \(\) Fixing	1	3665	
13	Special self-locking nut pulley	1	261518	
14	Level plug for governor	1	261574	
15	Filler plug for governor	1	261575	
16	Set bolt (18" B.S.F. x 3" long) Fixing gov	ernor 3	237159	
17	Spring washer \(\) to bracket		3075	
18	Bracket for governor	1	219511	
19	Special nut \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	3	219508	
20	Shakeproof washer thermostat housing	3	73353	
21	Support for bracket	1	232610	
22	Bolt (5 B.S.F. x 3 long) Fixing	1	237159	
23	Spring washer support to	1	3075	
24	Nut (5 B.S.F.) bracket	1	2828	
25	Control rod, governor to bell crank	1	240490	
26	Ball joint complete for rod	2	231261	
27	Locknut (1" B.S.F.) for ball joint	2	2823	
28	Distance piece, bell crank lever end	1	231356	
29	Spring washer \ Fixing rod	2	3074	
30	Nut (½" B.S.F.) ∫ to levers	2	2823	
31	Belt for governor drive	1	219560	
	GOVERNOR CONTROL QUADRAN	Т		
	ASSEMBLY	1	240066	
32	Housing for governor control quadrant	1	219644	
33	Lever for control	1	235097	
34	Bush for lever	1	235098	
35	Washer for lever	1	219659	
36	Bolt $(\frac{5}{16}"$ B.S.F. x 1" long) Fixing	. 1	237160	
37	Plain washer >control	lever i	3662	
38	Self-locking nut (5 B.S.F.) to housi		50525	
39	Knob for lever	1	219512	
27	12000 for leact	1	21//12	





PLATE REF.	1 2 3 4 DESCRIPTION	Q	ty.	Part No.	REMARKS
40	Special screw \ Fixing knob		1	219673	
41	Nut (2 B.A.) \(\int \text{to lever}\)		1	2247	
42	Quadrant plate		1	219463	
43	Special screw Fixing		2	219675	
44	Spring washer rant plate		2	3074	
45	Nut $(\frac{1}{4}$ B.S.F.) to housing		2	2823	
46	Support for governor control		1	240065	
47	Bolt (2 B.A. $x \frac{1}{2}$ long) Fixing		1	250959	
48	Spring washer support to		1	3073	
49	Nut (2 B.A.) housing		1	2247	
50	Rubber draught excluder		1	231625	
51	Bolt (2 B.A. $x \frac{1}{2}$ long)		2	250959	
52	Plain washer Fixing control		2	3685	
53	Spring washer to dash		2	3073	
54	Nut (2 B.A.)		2	2247	
55	Operating rod, quadrant to governor		1	2 4 0410	`
`56	Ball joint for rod		2	219065	
5 7	Locknut (4" B.S.F.) for ball joint on rod		2	2823	
58	Spring washer \rightarrow Fixing operating rod to		2	3074	
59	Nut (4" B.S.F.) governor and control lev	er	2	2823	•
	Special stud for governor bracket		3	232955	
	Fan pulley and governor drive		1	218563	
	Distance washer for fan pulley	••••	1	233803	
	Spring for carburetter pump rod		1	237774	

ENGINE GOVERNOR, 21/2 LITRE PETROL, Series II



	ENGINE GOVERNOR	,	24 LILICE	retrol, Series II
PLATE REF.	1 2 3 4 DESCRIPTION C)ty	. Part No.	REMARKS
	ENGINE GOVERNOR COMPLETE			
	ASSEMBLY	1	506863	
1 -	Engine governor complete	1	512406	
2	Lever governor to quadrant	1	261515	
3	Lever governor to bell crank	ì	513428	
4	Spring blade for bell crank	1	263059	
5	Bolt (½" U.N.F. x 1" long) Fixing	2		
6	Shakeproof washer > levers to	2		•
7	Nut (½" U.N.F.) governor	2		·
8	Bearing, large \ For engine	ī	262729	
·	Bearing, small governor	i	262728	
9	Oil seal for pulley end	i	261573	
10	Pulley for governor	;	513429	
11	Woodruff key for pulley	i	261561	
12	Plain washer \ \ Fixing	i	3665	
13	Special self-locking nut pulley	i	261518	
14	Level plug for governor	i	261574	
15	Cillan ales	1	261575	
16	Set bolt (18" B.S.F. x 8" long) Fixing	3		
17	Spring washer Spring washer	3	3075	
18	Plain washer governor to bracket	3	2550	
19	Bracket for governor	ر 1	278540	
20	Special cylinder head bolt for mounting bracket	2	278553	
21				
22		2		
23				•
25 24	Spring washer See half (5 " LINE of 1" loop) Fining have been	2		•
2 4 25	Set bolt (\frac{5}{18}" U.N.F. x 1" long) \text{Fixing bracket} Spring washer \times to front of	2	255228	
26	• •	2	3075 2550	
	Plain washer cylinder head	8		
27 28	Control rod, governor to bell crank Ball end For	1	504287 277633	
20 29	_	2	277655 254850	
30	Locknut (\frac{1}{2}" U.N.F.) \int \control \control \control	1	3074	
	Spring washer Fixing control rod	1		
31	Nut (½" U.N.F.) \int to governor	1	254800 231256	
32	Distance washer Fixing control	1	231356	
33	Spring washer > rod to	1	3074	
34	Nut (‡" U.N.F.) bell crank lever	'	254800	
	GOVERNOR CONTROL QUADRANT	1	500/00	
25	ASSEMBLY	1	508690 270 7 94	
35 26	Housing for governor control quadrant	1	279786	
36 27	Lever for control	!	508692	
37 20	Bush for lever	1	235098	
38 20	Washer for lever	1	219659	
39	Bolt (18" U.N.F. x 11 long) Fixing	ļ	255029	
40	Plain washer	1	3662	
41	Self-locking nut (5" U.N.F.) housing	!	252161	
42 43	Knob for lever	I T	219512	
43	Screw (2 B.A. x 8" long) Fixing knob	1	219673	
44	Nut (2 B.A.) ∫ to lever	ļ	2247	•
45	Quadrant plate	Ĭ	508691	
46 47	Screw (‡" U.N.F. x ½" long) Fixing	2	278386	-
47	Spring washer >quadrant plate	_	3074	
48	Nut (‡" U.N.F.) J to housing	2	254800	




PLATE	1 2 3 4 DESCRIPTION	Qty.		REMARKS
REF	0	1	240065	ILLIAN HALL
50	Support for governor control Bolt (2 B.A. $x \frac{1}{2}$ " long) \bigcap Fixing	I	234603	
50 51	Spring washer > support to	1	3073	
51 52	Nut (2 B.A.)	- '1	2247	
52 53	TO 11 1 1. 11	1	231625	
54		2	234603	
55		2		
	Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer Spring washer	4		
56	L L	2		
57 50	Nut (2 B.A.) to dash			Alternatives
58	Operating rod, quadrant to governor, 19"			Check before ordering
50	Operating rod, quadrant to governor, 20"			Check before ordering
59	Locknut (1" U.N.F.) For	2 2		
60	Ball joint Soperating rod	2		
61 62	Spring washer Fixing operating rod to			
62	Nut (‡" U.N.F.) governor and control le	1	332725	
(2	Panel for control on instrument panel	1	2 7 8547	
63	Belt for engine governor	1	278546	
64	Fan belt	I	279100	
65	Jockey pulley	I	278552	
66	Shaft	1	235860	
67	Bearing For jockey pulley	1	235861	
68	Circlip J	1	278554	
69 70	Support plate for jockey pulley	1	- 410))4	
7 0	Set bolt (5 U.N.C. x Fixing	2	253027	
71	7 long) support plate to	2 2		
71 72	Spring washer J front cover	1	278542	
72 72	Belt adjusting plate	I	3077	
73	Spring washer Fixing jockey pulley	1	254803	
74 76	Nut $(\frac{76}{16}$ U.N.F.) \int shaft to plate	ا • م		
75 74	Bolt (18" U.N.F. x 18" long) Fixing	2 plate 2		
76	Spring washer adjusting p	piate 2 1		
77 7 8	Plain washer to		254811	
10	Nut (½ U.N.F.) support pla	ate 2	507845	
	Fan Fixing	!	3074	
	Spring washer Set bolt (¼" U.N.F. x ¾" long) fan	- 1	255207	
		4	503039	
	Fan pulley Set bolt (¼" U.N.F. x ¾" long) fixing fan p	ا 4ااا		
	C 116 H		278543	
	1 1 1 (1	J	247771	
	D 11	I	278545	
		, [1	217781	
	Lockwasher for dynamo pulley Spindle for carburetter bell crank	I 1	504282	
	Spindle for carburetter bell crank Bracket for bell crank spindle	I	504283	
	Shakeproof washer fixing spindle to brack	ا 1 دم	70822	
	Plain washer for spindle	1	2210	
	Plain washer, steering unit to support brace	і ket 4		L.H.D.
	Stud for inlet manifold	2		
	C 1	2		
	Lockwasher for carburetter lever	1	504485	
	Control rod, bell crank to carburetter leve		506210	
	Ball end For	2		
	Locknut (‡" U.N.F.) control rod	2		
	Locking (4 C.14.1.) Control lod		ムノサンびり	





PLATE 1 2 3 4 DESCRIPTION	N Qty.	Part No.	REMARKS
Tie rod for engine	1	504606	
Sleeve for engine tie rod	2	504607	
Rubber bush	4	07014	
Cup washer >For	4	07015	
Nut (5 U.N.F.) tie 1	rod 4	254801	·
Locknut (5 " U.N.F.)	4	254861	
Bracket for tie rod at bell hous	sing 1	504605	
Bolt (5 U.N.F. x 1" long)	Fixing 2	255228	
Spring washer	bracket to 2	3075	
Nut (18" U.N.F.)	bell housing 2	254801	
Bracket for tie rod at frame	1	508339	
Bolt (§" U.N.F. x 3\frac{1}{4}" long)	Fixing 1	256050	
Spring washer	bracket 1	3076	
Nut (¾" U.N.F.)	to frame 1	254812	



FRONT WINCH COMPLETE ASSEMBLY 501451 FRONT WINCH ASSEMBLY 209163 CASING ASSEMBLY FOR FRONT 208698 2	PLATE REF.	1 2 3 4 DESCRIPTION	Qty	, Part No.	REMARKS
CASING ASSEMBLY FOR FRONT WINCH		FRONT WINCH COMPLETE ASSEMBLY	1	501451	
WINCH		FRONT WINCH ASSEMBLY	1	269163	
Stud for bottom cover 10 212104	1		T		
Dowel for thrust washer		WINCH	1		
Bush for bollard shaft			10		
1 219696 Breather cup for housing 1 219564	3				
Breather cup for housing 1 219564	4		2		
BOLLARD AND SHAFT ASSEMBLY 234370	5		l		
Dowel for shaft 0956					
Pin for bollard, 0.265" diameter			!		
Pin for bollard, 0.328" diameter 1 506287 Check before ordering				_) AT
Plain washer	9		I		-
Spring washer	10	_	!		Check before ordering
Set bolt (\(\frac{1}{2}\) B.S.F. x \(\frac{1}{2}\) long \(\frac{1}{2}\) to shaft \(\frac{1}{2}\) 1 219089 \\ Thrust washer \(\frac{1}{2}\) bollard \(\frac{1}{2}\) As required 233324 \\ Cap for bollard \(\frac{1}{2}\) masher \(\frac{1}{2}\) to bollard \(\frac{3}{2}\) 3 219742 \\ Special screw \(\frac{1}{2}\) Fixing cap \(\frac{3}{2}\) 219742 \\ Spring washer \(\frac{1}{2}\) to bollard \(\frac{3}{3}\) 3076 \\ Worm wheel and worm complete \(\frac{1}{2}\) 234807 \\ Special key for worm wheel \(\frac{1}{2}\) 1 219125 \\ Circlip fixing worm wheel \(\frac{1}{2}\) 1 219691 \\ Roller bearing for worm \(\frac{1}{2}\) 1 235646 \\ Washer for bearing \(\frac{1}{2}\) 235647 \\ Ball bearing for worm shaft \(\frac{1}{2}\) 1 219088 \\ Distance piece for worm shaft \(\frac{1}{2}\) 1 21913 \\ Oil seal for worm shaft \(\frac{1}{2}\) 219624 \\ Retainer for oil seal \(\frac{1}{2}\) 21962 \\ Joint washer for oil seal retainer \(\frac{1}{2}\) 1 21919 \\ Set bolt (2 B.A. x \(\frac{1}{2}\) long) \(\frac{1}{2}\) Fixing oil seal re- \(\frac{1}{2}\) 219087 \\ Starting dog \(\frac{1}{2}\) 1 21918 \\ Juniversal joint sleeve \(\frac{1}{2}\) 12918 \\ Joint washer for bottom cover \(\frac{1}{2}\) 129116 \\ Spring washer \(\frac{1}{2}\) tainer to housing \(\frac{1}{2}\) 129118 \\ Joint washer for bottom cover \(\frac{1}{2}\) 129116 \\ Spring washer \(\frac{1}{2}\) Fixing bottom \(\frac{1}{2}\) 129116 \\ Spring washer \(\frac{1}{2}\) Fixing bottom \(\frac{1}{2}\) 10 2823 \\ Joint washer for bottom cover \(\frac{1}{2}\) 129116 \\ Spring washer \(\frac{1}{2}\) Fixing bottom \(\frac{1}{2}\) 10 3074 \\ Joint washer for bottom cover \(\frac{1}{2}\) 129116 \\ Spring washer \(\frac{1}{2}\) Fixing bottom \(\frac{1}{2}\) 10 3088 \\ Joint washer for drain plug \(\frac{1}{2}\) 10 3088 \\ Joint washer for drain plug \(\frac{1}{2}\) 10 3088		, –	!		
13		P B	i		
Shim			. 1		
1			. I		
16 Special screw Fixing cap 3 219742 17 Spring washer to bollard 3 3076 18 Worm wheel and worm complete 1 234807 19 Special key for worm wheel 1 219125 20 Circlip fixing worm wheel 1 219691 21 Roller bearing for worm 1 235646 22 Washer for bearing 2 235648 23 Circlip fixing bearing to casing 1 235647 24 Ball bearing for worm shaft 1 219088 25 Distance piece for worm shaft 1 219113 26 Oil seal for worm shaft 2 219624 27 Retainer for oil seal 1 219062 28 Joint washer for oil seal 1 219062 29 Set bolt (2 B.A. x ½" long) Fixing oil seal re- 4 250960 30 Spring washer tainer to housing 4 3073 31 Starting dog 1 219118 32 Universal joint sleeve 1 219087 32 Lock washer for starting dog 1 219118 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer Fixing bottom 10 3074 30 Nut (¾" B.S.F.) cover to casing 10 2823 39 Drain plug for front winch 1 3088 40 Joint washer for drain plug 1 230507		<i></i>			
17		•			
Worm wheel and worm complete		- > - ·	_		
Special key for worm wheel		· -	1		
Circlip fixing worm wheel			1		
Roller bearing for worm			1		
22 Washer for bearing 2 235648 23 Circlip fixing bearing to casing 1 235647 24 Ball bearing for worm shaft 1 219088 25 Distance piece for worm shaft 1 219113 26 Oil seal for worm shaft 2 219624 27 Retainer for oil seal 1 219062 28 Joint washer for oil seal retainer 1 219119 29 Set bolt (2 B.A. x ½" long) Fixing oil seal re- 4 250960 30 Spring washer fainer to housing 4 3073 31 Starting dog 1 219087 32 Lock washer for starting dog 1 219087 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116			1		
23 Circlip fixing bearing to casing		=	-		
24 Ball bearing for worm shaft 1 219088 25 Distance piece for worm shaft 1 219113 26 Oil seal for worm shaft 2 219624 27 Retainer for oil seal 1 219062 28 Joint washer for oil seal retainer 1 219119 29 Set bolt (2 B.A. x ½" long) Fixing oil seal re-4 250960 30 Spring washer f tainer to housing 4 3073 31 Starting dog 1 219087 32 Lock washer for starting dog 1 219118 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) cover to casing 10 2823 39		-	1		
25 Distance piece for worm shaft 1 219113 26 Oil seal for worm shaft 2 219624 27 Retainer for oil seal 1 219062 28 Joint washer for oil seal retainer 1 219119 29 Set bolt (2 B.A. x ½" long) Fixing oil seal re- 4 250960 30 Spring washer fainer to housing 4 3073 31 Starting dog 1 219087 32 Lock washer for starting dog 1 219118 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) cover to casing 10 2823 39 Drain plug for front winch 1 3088 40 Joint washer for drain plug 1 230507			1		
26 Oil seal for worm shaft			1	219113	
Joint washer for oil seal retainer 219119	26		2	219624	
29 Set bolt (2 B.A. x ½" long) Fixing oil seal re- 4 250960 30 Spring washer tainer to housing 4 3073 31 Starting dog 1 219087 32 Lock washer for starting dog 1 219118 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) ∫ cover to casing 10 2823 39 Drain plug for front winch i 3088 40 Joint washer for drain plug 1 230507	27	Retainer for oil seal	1	219062	·
30 Spring washer ∫ tainer to housing 4 3073 31 Starting dog	28	Joint washer for oil seal retainer	1	219119	
31 Starting dog 1 219087 32 Lock washer for starting dog 1 219118 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) ∫ cover to casing 10 2823 39 Drain plug for front winch 1 3088 40 Joint washer for drain plug 1 230507	29	Set bolt (2 B.A. $x \frac{1}{2}$ long) Fixing oil seal	re- 4		
32 Lock washer for starting dog 1 219118 33 Universal joint sleeve 1 219083 34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) Cover to casing 10 2823 39 Drain plug for front winch i 3088 40 Joint washer for drain plug 1 230507		Spring washer	ing 4		·
33 Universal joint sleeve			1		
34 Special pin fixing sleeve to worm 1 250362 35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer			1		
35 Bottom cover for winch casing 1 219117 36 Joint washer for bottom cover 1 219116 37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) ∫ cover to casing 10 2823 39 Drain plug for front winch 1 3088 40 Joint washer for drain plug 1 230507			1		
36			1		
37 Spring washer Fixing bottom 10 3074 38 Nut (¼" B.S.F.) cover to casing 10 2823 39 Drain plug for front winch i 3088 40 Joint washer for drain plug 1 230507					· · · · · · · · · · · · · · · · · · ·
38 Nut (¼" B.S.F.) ∫ cover to casing 10 2823 39 Drain plug for front winch i 3088 40 Joint washer for drain plug 1 230507					
39 Drain plug for front winch i 3088 40 Joint washer for drain plug i 230507		• -			
40 Joint washer for drain plug 1 230507					•
41 Filler plug and dipstick I 219179					
	41	Filler plug and dipstick		1 219179	·




PLATE REF.	1 2 3 4 DESCRIPTION	DN	Qty.	Part No.		REMARKS	· · ·
42	Special bolt Fixing	 ·	9	252120		TOLINIAN,	
43	Spring washer > front w	inch to	9	3075			
44	Nut $\binom{5}{16}$ "U.N.F.) suppor		9	254801			
45	Support plate for front winch	_	. Í	504246			
.,	Bolt $(\frac{5}{16}"$ B.S.F. $\times \frac{7}{8}"$ long)	 	5	250704			
46	Bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ long)	Fixing support	5	255026			
47	Plain washer	plate to cross-	5	2550			
48	Spring washer	member and	10	3075			
49	Nut (5 " U.N.F.)	front bumper	5	25480I			
	Riv-nut ($\frac{5}{16}$ " B.S.F.)	none bumper	5	268703			
5 0	Propeller shaft for front wind	·h	1	278061			
51	Plunger spring		2	55742			
52	Plunger For prope	ller shaft	2	219093			
53	Dust cover		2	219080			
54	Driving shaft for front winch	1	ī	269162			
5 5	WINCH SHAFT HOUSIN		i	219793			
56	Stud for support plate		. 2	212104			
57	Bush for winch driving sha		1	219104			
58	Bush for control shaft		~	219103			
59	Support plate for winch shaft			236511	•		
60	Spring washer \ Fixing hou		2	3074			
61	Nut $(\frac{1}{4}$ B.S.F.) to support		2	2823			
62	Bolt $(\frac{5}{16}$ " B.S.F. $\times \frac{3}{4}$ " long)		4	237159			
63		plate to bracket	4	3075		•	
64	I	on front cover	4	2828			•
65	Bracket for winch shaft supp		. 1	219074			
66	Bracket for winch shaft supp		. 1	236510			
67	Set bolt (5 B.S.F. x 2 long)				
	front cover		. 3	250530			
	Set bolt $\binom{5}{16}$ B.S.F. x \int Fixing	ing dynamo					
	2¼″ long) ≻adjı	isting strap	1	250331			
	Distance piece J to f	ront cover	1	2204			
68	Driving flange for front winc	h	. 1	263356			
69	Winch driving plate		. 1	218549			
7 0 ·	Driving flange for fan pulley	****	. 1	218653			
71	Special plug \ Fixing drivin	g	1	218584			
7 2	Lock washer \int flange and pl	ate	1	218605			
73	Control shaft for driving flans	ge	. 1	219561		•	
74	Selector fork for control shaft		. 1	219562			
7 5	Spring washer \(\) Fixing for	ork	1	3074			
76	Nut $\binom{1}{4}$ B.S.F.) \int to shaft		1	2823			
77	Steel ball		1	3050			
78	Spring For contro	l shaft	1	211382			
79	Plug for spring		1	219101		•	
80	Grease nipple for control sha	ft	. 1	219696	2	•	
81	Clevis complete Fix	ing	1	215809	-		
82	5 1	trol rod	Ī	2828	711		
83	Split pin to s	haft	1	2392	, -	.*	
84	Control rod for winch	****	. 1	278059			
85	Eyebolt for winch control rod		1	219559	4.1		
86	Spring washer \(\begin{array}{c}\text{Fixing e}\)	yebolt to	1	3074			
87	Nut (4" B.S.F.) \int \text{winch su}	pport plate	1	2823			





PLATE REF.	1 2 3 4 DESCRIPTION	Qty	. Part No.	REMARKS
88	Knob for control rod	1	219558	
89	Locknut (8" B.S.F.) for knob	1	2827	
90	Plain washer for spring	2	2251	
91	Spring for control rod	1	212943	
92	ROPE GUIDE BRACKET ASSEME	3LY		
	R.H	1	219577	
93	ROPE GUIDE BRACKET ASSEME	3LY		
	L.H	1	219576	
94	Thrust washer	2	219241	
95	Bush for guide bar	2	219237	
96	Grease nipple for bush	2	219696	
97	Guide bar for winch rope	1	219214	
	Bolt ($\frac{3}{8}$ " U.N.F. x 1" long) \bigcap Fixing rope	2	255047	
98	Bolt (§ U.N.F. x 1 long) } guide to sup	port 4	255048	
99	Spring washer plate and	6	3076	
100	Nut (¾" U.N.F.) front bumpe	r 6	254802	
	Starting handle	1	234402	
	Wrench for bollard cap screw	1	237255	
	Front spring, driver's side	1	241283	
	Front spring, passenger's side	1	242863	



	FRUNI CAPSIAN	WINCH,	2 4	LIIKE	PEIRUL AND	DIESEL
PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.		REMARKS
	FRONT WINCH COMPLETE A	SSEMBLY	1	501453		,
	FRONT WINCH ASSEMBLY	1000	1	269163		
1	CASING ASSEMBLY FOR	FRONT				
	WINCH		1	268698		
2	Stud for bottom cover		10	212104		
3	Dowel for thrust washer		. 1	09561		
4	Bush for bollard shaft		2	219161		
5	Grease nipple for shaft			219696	•	
6	Breather cup for housing		Ī	219564		
7	BOLLARD AND SHAFT AS	SEMBLY	. 1	234370		
8	Dowel for shaft		. 1	09561		
9	Pin for bollard, 0.265" diame	ter	1	_	Alternatives	
	Pin for bollard, 0.328" diame		1	,	Check before ordering	
10	Plain washer	Fixing		8060	onoth botory ordering	
11	Spring washer	>bollard	1	3078		
12	Set bolt (½" B.S.F. x ½" long	l l	i	215767		
13	Thrust washer \ For	,, , to share	i	219089		
14	Shim bollard	Δ	s require	233324		
15	Cap for bollard		1	219115		
16	Special screw \ Fixing cap		3	219742		
17	Spring washer to bollard		3	3076		
18	Worm wheel and worm comple	te	ĺ	234807		
19	Special key for worm wheel		, I	219125		
20	Circlip fixing worm wheel		 1	219691		
21	Roller bearing for worm			235646		
22	Washer for bearing			235648	•	
23	Circlip fixing bearing to casing		1 .	235647		
24	Ball bearing for worm shaft		1	219088	•	
25	Distance piece for worm shaft			219113		
26	Oil seal for worm shaft		•	219624		
27	Retainer for oil seal			219062		
28	Joint washer for oil seal retainer		1.	219119		
29	Set bolt (2 B.A. x ½" long) \ Fix		- 4	250960		
30		ner to housin		3073		•
31	Starting dog		Î	219087		ė.
3 2	Lock washer for starting dog		1	219118		
33	Universal joint sleeve		. 1	219083		
34	Special pin fixing sleeve to wor			250362		
3 5	Bottom cover for winch casing		1	219117		
36	Joint washer for bottom cover			219116		
37	Spring washer Trixing both		10	3074		
38	Nut (\frac{1}{4}" B.S.F.) \int to casing		10	2823		
39	Drain plug for front winch			3088		
40	Joint washer for drain plug			230507		
41	Filler plug and dipstick			219179		
• '	. mer prag and dipanes	****	. •	<u> </u>		






PLATE	1 2 3 4 DESCRIPTION Q	ty.	Part No.	REMARKS
42			252120	
43	Spring washer > front winch to	9	3075	
44	Nut $\left(\frac{5}{16}$ U.N.F.) support plate		254801	
45	Support plate for front winch		504246	
46	Bolt $(\frac{5}{16}"$ B.S.F. x $\frac{7}{8}"$ long) $)$ Fixing support		250704	
. 47	Bolt (\(\frac{16}{16}\)" U.N.F. x \(\frac{3}{4}\)" long) plate to cross-		255026	
48		0	3075	
49	Nut (15" U.N.F.) front		254801	
50	Riv-nut (\frac{16}{16}" B.S.F.) bumper		268703	
51	Propeller shaft for front winch		278056	
52	Plunger spring	2	55742	
53	Plunger >For propeller shaft		219093	
54	Dust cover		219080	
55	Driving shaft for front winch		269162	
56	WINCH SHAFT HOUSING ASSEMBLY		504248	
57	Stud for support plate		212104	
58	Bush for winch driving shaft, overall length	_		
50	1,750"	1	219104	
	Bush for winch driving shaft, overall length	·		Alternatives. Check before ordering
	1.437"	1	504250	·
59	Bush for control shaft, overall length .375"			1 off on 1961 models onwards
~ ~	Bush for control shaft, overall length .625"			1961 models onwards
60	Support plate for winch shaft		268910	
61	Spring washer \ Fixing housing to	2	3074	
62	Nut (\frac{4}" B.S.F.) \int \text{ support plate}	2	2823	
63	Bolt ($\frac{5}{16}$ " U.N.F. x $\frac{7}{8}$ " long) \int Fixing		255227	
64	Spring washer support plate	4	3075	
•	Shim to bracket on As re			
65	Nut (\frac{5}{16}" U.N.F.) front cover		254811	·
66	Bracket for winch shaft support plate, R.H	i	268907	
67	Bracket for winch shaft support plate, L.H	1	268905	
68	Stud in front cover for brackets	4	252511	
69	Spring washer \ Fixing	4	3075	
70	Nut $\binom{5}{16}$ U.N.F.) \int brackets	4	254801	
71	Winch driving flange	1	268903	
72	Winch driving plate	1	268900	
73	Special plug \(\) Fixing	1	269461	
74	Shakeproof washer \int driving plate	1	78193	
75	Control shaft for driving flange, detents for steel		J	
	ball .437" apart	1	219561 >	Alternatives. Check before ordering
	Control shaft for driving flange, detents for steel		1	
	ball .687" apart	1	504253	
76	Selector fork for control shaft	1	219562	
77	Spring washer \(\) Fixing fork	1	3074	
78	Nut $(\frac{1}{4}" B.S.F.)$ fto shaft	1	2823	
79	Steel ball	1	3050	
80	Spring For control shaft	1	211382	
81	Plug for spring	1	219101	
82	Grease nipple for control shaft	1	219696	



		-, -	-4	
PLATE REF.	1 2 3 4 DESCRIPTION	Qt	y. Part No.	REMARKS
83	Clevis complete Fixing		1 215809	
84	Locknut ($\frac{5}{16}$ " B.S.F.) \gt control rod		1 2828	
85	Split pin J to shaft	_ 1	2392	
86	Control rod for winch	1	278054	
87	Eyebolt for winch control rod	1	269197	
88	Spring washer \(\) Fixing eyebolt to	1	3074	
89	Nut (4" B.S.F.) \int winch support plate	1	l 2823	
90	Knob for control rod	1	219558	
91	Locknut (3" B.S.F.) for knob	1	2827	
92	Plain washer for spring	2	2 2251	
93	Spring for control rod	1	212943	
94	ROPE GUIDE BRACKET ASSEMBLY			
	R.H	1	219577	
95	ROPE GUIDE BRACKET ASSEMBLY			
	L.H	1	219576	
96	Thrust washer	2	2 219241	
97	Bush for guide bar	2	2 219237	
98	Grease nipple for bush	2	219696	
99	Guide bar for winch rope	1	219214	
	Bolt (§ U.N.F. x 1" long) Fixing rope	2	2 255047	
100	Bolt ($\frac{3}{8}$ " U.N.F. x $1\frac{1}{8}$ " long) \(\rightarrow\) guide to suppose	ort 4	255048	
101	Spring washer plate and	6	3076	
102	Nut $\binom{3''}{8}$ U.N.F.) front bumper	ϵ	5 254802	
	Starting handle	1	2 344 02	
	Wrench for bollard cap screw	1	237255	



	ALL DIVIN			WEIQE
PLATE REF	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
TCD.	HYDRAULIC FRONT WINCH, COMPLE	ETE		
	ASSEMBLY	1	524135	88
	HYDRAULIC FRONT WINCH COMPLE			
	ASSEMBLY	1	524136	109
	HYDRAULIC WINCH ASSEMBLY	1	580001	•
1	Motor unit, complete, for winch	1	580038	
2	Bush 'B' for gear shafts	1	515510	
3	'O' ring for 'B' bushes	2	515511	
4	Gears and shafts	1	515512	
5	Bush 'A' for gear shafts	1	515513	
6	Sealing ring for 'A' bushes	2	515514	
7	'O' ring for housing	1	515515	
8	Special screw fixing body cover and bo	odv 8	515516	
9	Oil seal for shaft	1	515517	
10	Baffle for oil seal	1	515518	
11	Joint washer for motor unit	1	580007	
, ,	Plain washer Fixing motor	4	2765	
	Spring washer bunit to winch	4	3076	
	Nut (¾" U.N.F.) gearbox	4	254812	
12	Gearbox casing for winch	1	515549	
13	End plate for gearbox casing	1	580003	
14	Joint washer for gearbox casing	1	580004	
•	Plain washer Fixing end	6	2250	
	Spring washer cover to	6	3075	
	Nut $(\frac{5}{16}"$ U.N F.) gearbox casing	6	254801	
15	Oil filler plug	1	580133	
16	Joint washer for oil filler plug	1	06009	
17	Oil level and drain plug	2	515133	•
18	Joint washer for plug	2	2347	
19	Wormwheel, wormshaft and distance pie	ces 1	515550	
20	Bearing for wormshaft	2	580035	
	Shim for wormshaft .002"	As required	580139	
21	Shim for wormshaft .005"	As required	580138	
	Shim for wormshaft .010"	As required	580137	
22	Retaining cap for bearing	1	580042	
23	Brake drum for wormwheel shaft	1	580041	
24	Distance piece \(\) For	1	580067	
25	Key brake drum	1	580048	
26	Brake band	1	580044	
27	Plunger for brake band	1	580047	
28	Spring for plunger	1	509536	
29	Cover for brake drum	1	580043	
30	Joint washer for retaining cap and cover		580046	
	Set bolt (‡" U.N.F.) Fixing			
	x 2½" long) retaining cap	6	256008	
	Plain washer and cover to	6	2213	
	Spring washer gearbox casing	6	3074	
31	Coupling sleeve Connecting	1	580063	
32	Coupling dog > motor unit	1	580064	
33	Key to wormshaft	1	580031	
	, , , , , , , , , , , , , , , , , , ,			




PLATE REF.	1 2 3 4 DESCRIPTION Qty.	Part No.	REMARKS
34	Dog clutch for cable drum 1	580015	TELVI MAD
35	Key fixing dog clutch to worm and drum shaft 2	580017	
36	Selector lever for dog clutch 1	509446	
37	Knob for selector lever	219521	
38	Dett. t. C. L. L.		
<i>J</i> 0		580016	
	Plain washer Fixing	2765	
20	Split pin ∫ retaining pin 1	2392	
39	Shaft and key for worm wheel and drum	530621*	
40	Key Fixing worm	580036	Key with square ends Alternatives
	Key ∫to shaft	526768 *	Key with rounded ends Charle before and animal
	B 1 6 1 6		Part of 530621
41	Bearing for shaft, worm end 2	580033	
	Shim for wormwheel .002" As required	580136	
42	Shim for wormwheel .005" As required	580135	
	Shim for wormwheel .010" As required	580134	
43	Distance ring for shaft, worm end 1	580008	
44	Oil seal for shaft, worm end 1	580039	
45	Support bracket for worm and drum shaft		
	at dog clutch end 1	580022	
46	Bearing for worm and drum shaft, dog		
	clutch end 1	270604	
47	Cable drum	580010	
48	Friction disc for cable drum 1	580011	
49	Pad) For 2	580012	
50	Spring friction 2	03649	
51	Retaining plug disc 2	580140	
52	Thrust ring for cable drum 1	580009	
53	Crease nipple for askle January	234532	
54	Cleat for cable Fixing 1	580045	
٠,	Bolt $(\frac{5}{16}" \text{ U.N.F. } \times \frac{5}{8}" \text{ long})$ >cleat to 2	255025	
	Spring washer cable drum 2	3075	
55	Connecting tube, front Cable drum 2	580019	
56	Connecting tube, rear		
50	<u> </u>	580018	
		254804	
	Shakeproof washer \int tube to gearbox 2 Nut $(\frac{5}{8}" \text{ U.N.F.})$ For rear \Rightarrow casing and 2	73353	
-	011 4 5 2	254806	
	Shakeproof washer ∫ tube support 2	233017	
£7	bracket	F00000	
57 50	Rear mounting bracket 1	580020	
58	'U' bolt Fixing 2	580021	
	Spring washer rear mounting 4	3075	•
	Nut $(\frac{5}{16}"$ U.N.F.) \int bracket to winch 4	254801	
	Set bolt (5" U.N.F. x 11" long) Fixing winch 10	256220	
	Spring washer to chassis 10	3075	
	Riv-nut (§ U.N.F.) cross-member 10	501224	
	Bolt (§" U.N.F. x 2½" long) 4	256046	
	Plain washer Fixing winch to 4	2765	
	Spring washer front bumper 4	3076	
	Nut (₹" U.N.F.) 4	254812	•
59	Protection shield for motor unit 1	580141	
	Bolt $(\frac{5}{16}"$ U.N.F. $x \frac{5}{8}"$ long) \bigcap Fixing 2	255025	
	Bolt $\binom{3}{16}$ " U.N.F. $\times \frac{5}{8}$ " long) Fixing 2 Spring washer Shield to 2	255025 30 7 5	




PLATE REF.	1 2 3 4 DESCRIPTIO	N .	Qty.	Part No.	REMARKS
61	Anchor for cable hook		1	580132)	•
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long)		2	255006 >	1959-60 models
	Spring washer	Fixing anchor	2	3074	
	Nut (¼" U.N.F.)	_	2	254800 Ĵ	
62	Roller guide complete for wi	nch c a ble	1	580124	
	Bolt (%" U.N.F. x 1" long)	Fixing	3	255047	
	Plain washer	roller guide	3	2765	
	Spring washer	to	3	3076	
	Nut (3" U.N.F.)	front bumper	3	254812	
	'U' bolt Fixing		2	580152	
	Spring washer roller gu	iide	4	3075	·
	Nut (18" U.N.F) to wind	h	4	254801	




PLATE REF.	1 2 3 4 DESCRIPTION	Otr	/. Part No.	REMARKS
	SELECTOR UNIT ASSEMBLY,			
	MECHANICAL	1	509076	
1	Housing for selector	1	217773	
2	CH f. f . 1 .	1	506203	
3	ElC l.	1	217584	
,	Set bolt $(\frac{5}{16}"$ B.S.F. x 1" long) fixing for	! rb	217307	
	1 6	1	237160	
4	to shaft Ball For	1	1643	
5	Spring Selector	1	56102	
6	Plug for spring control		217763	
7	Joint washer for plug mechanism	1	217765	
8	Cover plate for selector housing	1	217774	
9	T		217774	
7	Joint washer for cover plate Set bolt (½" Whit.x ¾" long) \ Fixing cov	I er 4		
	Spring washer plate to ho			
10		· ·	217771	
11		, I	506204	
12	D' .f I . I	I	50620 4 506205	
12	I 1 . (3// D C E) ()	, I	2323	
13		l	506206	
14	Operating lever for shaft Clevis complete \(\) Fixing lever and pivot	I		
14		2		
16	Split pin ∫ to selector shaft			
15	Rod for operating lever	I	506207	
16	Clevis complete Fixing rod to	 	230279	•
17	Split pin	i	2422	
17	Grommet for rod	1	508571	
18	Knob for operating rod	[218050	
	Locknut (78" B.S.F.) for knob	I	3764	
	P.T.O. DRIVE UNIT WITH HYDRAU	ILIC 1	C0003/	
10	PUMP	I	580026	•
19	HYDRAULIC PUMP FOR P.T.O. UI		580030	
20	Bush 'A' for gear shafts	I	515519	
21	'O' ring for 'A' bushes	2		
22	Gears and shafts	I	515521	
23	Bush 'C' for gear shafts	I	515522	
24	Sealing ring for 'C' bushes	2		
25 24	Support ring for 'C' bushes	2		
26 27	Special dowel for body and bush	3		
27	'O' ring for housing	1	515515 515535	
28	'O' ring, body ports	2		
29	Special screw fixing body cover to body			
30	Oil seal for shaft	I	515517	
31	Baffle for oil seal	Ì	515518	
32	Adaptor for hydraulic pump	l	580027	
33	Joint washer for adaptor	I	217680	
	Spring washer Fixing adaptor to	6		
24	Nut (\frac{3}{8}" B.S.F.) \int \text{transfer housing}	6		
34	Drive shaft for hydraulic pump	I	580028	
35	Distance piece for shaft ball bearing		580029	
36	Ball bearing for shaft]	55714	
37	Circlip, large, fixing bearing to adaptor	!	217972	
38	Circlip, small, fixing bearing to shaft	1	214795	
39	Roller bearing for shaft	1	217478	




PLATE REF.	1 2 3 4 DESCRIPTION	Qty	. Part No.	. REMARKS
40	Retaining ring \ Fixing roller bearing	1	217523	
41	Circlip Sto shaft	1	217525	
42	Dog clutch for drive shaft	i	217522	
43	Coupling sleeve	1	580063	
44	Coupling dog Connectin		580064	
45	Key >hydraulic	· 6	58003T	
	Set bolt (\frac{1}{4}" U.N.F. x \frac{1}{2}" long) pump to	i	255204	
	Plain washer drive shaf	, , 1	2213	
	Spring washer	. i	3074	
46	Joint washer for hydraulic pump	1	580007	
	Bolt (§ B.S.F. x 1½ long) Fixing	4		
	Plain washer > hydraulic	4		
	Spring washer pump to	4		
	Nut (§ B.S.F.)	4		
47	CONTROL VALVE ASSEMBLY,	7	2027	
••	HYDRAULIC	1	580094	4
48	D:	I	515527	
49	Retaining ring for piston	1	515528	
50	Classic and the state of	2		
51	'O' (2		
52	W/L t 1 1	1	515531	
-	Set bolt (No. 10 U.N.F.) Fixing selector		717771	
	$x \frac{2}{4}$ long) > lever housing		515532	
	Spring washer to body	7	3073	
5 3	Distance and a dist	1	515534	
54	Spring for unloader piston	I	515535	
55	V-1 (. 1 1 1	1	515536	
56	י אים	i	515537	
57	S (1: (.)	1	515538	
58	'O' ring, relief valve housing to unload		212330	
	housing	1	515539	
	Special set bolt \ Fixing relief valve house	sing 4	515540	
	Spring washer to unloader housing	4	3075	
59		ż	515542	
60	'O'' . 11.1 1 1 1 1 1	1	515543	
61	'O' ring, small, for cover plate	1	515543	
62	'O' ' 1' ' 1.	2	515542	
63	'O' 1 (1.	1	515541	
66	6 11 16 16 1	2	515548	
67	Mounting plate Fixing	1	580095	
•	Set bolt (% U.N.F. x % long) control valve	e 4	255025	
	Spring washer to heelboard		3075	
68		1	580122	
69	Eller and for the latest	1	231189	
70	Filton accome for Clien	i	580123	
71	Oil files	i	03040	
7 2	laint weeker for all filter	1	3413	
73	Drain alog for all touls	1	235592	
74	Joint weeken for Justin -1	1	230509	
	Brooket ail toul flower to all along	i	509141	109
	Parling block oil souls to sub a low l	1	509140	
	Protection strip for took access help	1	334075	
	Grommet at L.H. rear wheelarch panel	1	334189	
		-	, .,	




PLATE REF.	1 2 3 4 DESCRIPTION)N	Qty.	Part No.	REMARKS
75	Bracket for mounting oil tan		1	580070	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long)		9	255006	
	Plain washer	bracket and	9	3840	∖ 88
	Spring washer	tank to rear	ģ	3074	
	Nut (½" U.N.F.)	wheelarch	ģ	254800	
	Bracket, upper \ For mo	/	í	580108	•
	Bracket, lower oil tank	_	i	580109	
	Bolt (¼" U.N.F. x ¾" long)	Fixing bracket	7	255207	109
	Plain washer	>and tank	7	3840	
	Spring washer	to rear	7	3074	1
	Nut (‡" U.N.F.)	wheelarch	7	254800	
76	Protection panel for oil tank	•	1	332313	,
70		, L	1	78248	
77	Pop rivet fixing panel to bod	-	6		00
"	Cover plate for oil tank filler	****]	580142	(00
	Special bolt Fixing		3	320045	1
	Plain washer cover plate t	0	3	2213	
70	Special nut J wheelarch		3	302532	
78	Stay for rear wing		1	580071	}
	Protection panel for oil tank	٠]	334074	
	Bolt $\binom{1}{4}$ U.N.F. $x \frac{5}{8}$ long)		5	78208	100
	Plain washer	Fixing panel	5	3840	۱۱۵ ۹
	Spring washer	to body	5	3074	
- 0	Nut (¼" U.N.F.)	J	5	254810	J
79	Flexible pipe, control valve t			580090	
80	Flexible pipe, control valve t			580091	
81	Elbow for flexible pipe on m	_	2	580084	>1 off on 1961 models onwards
82	'O' ring	Fixing	2	580085	
	Set bolt (18" U.N.F. x 11" le	-	4	256220	>2 off on 1961 models onwards
	Spring washer) motor	4	3075	J
83	Adaptor on elbow on motor	••••	2	580086	
84	Special seal for adaptor		2	580087	
85	Adaptor Fixing flexi		2	580092	
86	Special seal ∫ to control v		2	580093	
87	Flexible pipe, pump to contr			580104	
88	Connection for pipe, pump	to control valve,	on	400000	
00	pump	·	[580089	•
89	'O' ring	Fixing	1	267828	
	Set bolt (15 U.N.F. x 1" lon	~ ,		255228	
	Spring washer	to pump	2	3075	
90	Adaptor For pipe, pun		Į.	580092	
91	Special seal ∫ valve, on cont		<u>l</u>	580093	
92	Rubber connection, pump to ta			517577	
93	Elbow on pump for rubber o		[580088	
94	'O' ring	Fixing	1	267828	
	Set bolt (fg" U.N.F. x 1" lor		2	255228	
	Spring washer	∫ to pump	2	3075	
95	Pipe, steel, front		1	580113	88
	Pipe, steel, front Pump to	•	1	580101	109
96	Pipe, steel, rear tank		1	580114	88
	Pipe, steel, rear		1	580100	109
97	Rubber connection, front to	rear pipe and re			
	pipe to tank	4	2	580098	




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
98	Hose clip for rubber connections, pump to tank	6	50314	
99	Pipe, steel, front	1	580111	88
	Pipe, steel, front Control valve	1	580103	109
100	Pipe, steel, rear to tank	1	580112	88
	Pipe, steel, rear	1	580102	109
101	Adaptor, brass, on control valve for tank pipe	1	580096	
102	Joint washer for adaptor	1	3425	
103	Rubber connection, front to rear pipe and rear			
	pipe to tank	2	580099	·
104	Hose clip for rubber connection, control valve			•
	to tank	4	50310	
105	Oil exhaust pipe from motor	1	580106	
106	Banjo complete for exhaust pipe on motor	1	580105	
107	Union for exhaust pipe at rear	1	580107	
108	Clip at front winch bolt	1	580128	
110	Clip at steering base bracket	1	580119	
111	Clip at body mounting bracket	1	580117 þ	>1959-60 models
112	Clip at tapped hole, hydraulic pump	1	580121	
113	Clip at bump rubber bracket	1	580118	
114	Clip at chassis frame	2	215791	
	Drive screw fixing clip	2	72626	_
	Clip, large diameter \(\) Fixing tank pipes to	1 .	523707*	. }109
	Clip, small diameter \int chassis cross-member	1	523708*	5 107
	Drive screw fixing clip	4	72626	
1 15	Clip for steel pipe \(\int \text{At rear floor,} \)	2	580110	88
	Clip for steel pipe ∫above axle	1	580127	109
	Clip fixing steel pipes together	ĺ	580126	109
	Clip for steel pipe, rear	1	580125	109
	Drive screw	6	72626	4 off on 109
	Bolt (5 U.N.F. x 5 long)	1	255025	
	Plain washer	1	2550	
	Spring washer Fixing	1	3075	·
	Nut (5 U.N.F.) clips	1	254801	
	Bolt (¼" U.N.F. x ¾" long)	2	. 255207	
	Spring washer	2	II.	-109
	Nut (¼" U.N.F.)	2	رِ 254800	
	Connection, high pressure hose to hydraulic	_)	
	motor]	580089	
	'O' ring Fixing	I	II.	>1961 models onwards
	Spring washer connection	2	3075	
	Set bolt $(\frac{5}{16}"$ U.N.F. x 1" long) \int to motor	2	255228	
	Clip, single, high pressure hose to bumper	1	580120	





PLATE REF.	1 2 3 4 DESCRIPTION	ON	Qty.	Part No.	REMARKS
	Bolt (1" U.N.F. x 5" long)	Fixing	1	255206	
	Spring washer	clip to	1	3074	
	Nut (¼" U.N.F.)	bumper	1	254810	
	Clip, single, high pressure he	ose to R.H. chassis			
	side member		2	517836	
	Riv-nut (5 " U.N.F.)	Fixing clip to	2	501224	
	Spring washer	R.H. chassis	2	3075	
	Set bolt $(\frac{5}{16}"$ U.N.F. $\times \frac{3}{4}"$ lor	ng) ∫ side member	2	255226	
	Clip, double, high pressure he	oses to R.H. chassis		(>1961 models onwards
	side member		1	517837	
	Clip, double, high pressure he	oses to R.H. chassis			
	side member	· · · · · · · · · · · · · · · · · · ·	1	517838	
	Bolt (¼" U.N.F. x ¾" long)		1	255207	
		Clamping clip	1	3074	
	Nut (1/2" U.N.F.)	517838	1	254810	•
	Clip, double, high pressure	hoses to R.H. rear			
	engine mounting		1	517839	
]	Exhaust silencer complete		1	523655	109 Station Wagon 1961 onwards Not part of
					assembly 524136
j	Road spring, complete, front, d	lriver's	1		88 Petrol models
	Road spring, complete, front, p	-	1	~	Not part of assembly 524135 > 1961 models
1	Road spring, complete, front, o	lriver's	1		109 Petrol models onwards
1	Road spring, complete, front, p	oassenger's	1	265627 J	Not part of assembly 524136


OIL COOLER, 2 LITRE PETROL



OIL COOLER, 2 LITRE PETROL

PLATE REF	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
REF	OIL COOLER COMPLETE ASSEMBLY	Qiy.	504080	ILLIVIANA.
1	Oil cooler complete	1	232212	
2	Bolt (4" U.N.F. x 13" long)	1 4	256002	
3	Spring washer Fixing	4	3074	•
4	· · ·	2	278766	
4	Spacer Soil cooler Shim to radiator	6	504299	
5	Nut (¼" U.N.F.)	4	254800	•
5 6	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) \(\frac{1}{4}\) Fixing oil	4	255204	
7	Spring washer Spring washer	•	3074	
8	Tapping plate for oil cooler	2	270605	
9	Drive screw fixing plate to frame	4	78167	
10	Union for oil return pipe	T	232141	
11		1	269178	
12	Oil return pipe complete Union nut) For oil	2	2338	
13	'	2	2337	
14	Nipple ∫ return pipe Clip for oil return pipe		216708	
15	Screw (2 B.A. x ½" long)	 	71164	
16		1	3073	
17	Spring washer Fixing clip Nut (2 B.A.)	1	2247	
17	Bolt (2" U.N.F. x \{\}" long) \rightarrow For	1	255206	
	Spring washer > earthing clip	ī	3074	
	Nut $\binom{1}{4}$ U.N.F.) calculating cup on radiator	1	254810	
18	Flexible oil pipe, return to sump	i	232180	
19	Banjo centre \(\) Fixing flexible	I	232349	
20	Joint washer pipe to sump	2	232042	
21	Clip for flexible pipe	1	50690	
22	Duraling Consulting	1	232351	
23	Screw (2 B.A. x ½" long)	I	71164	
24	Spring washer Fixing clip	į	3073	
25	Nut (2 B.A.)	i	2247	
2,	OIL RELIEF VALVE ASSEMBLY	i	232145	
26	Oil union	1	232141	
27	Joint washer for union	1	231577	
28	Body >For oil relief va	lve I	232143	
29	Plunger	i	232144	
30	Spring for plunger	ì	232142	
31	Oil pipe, union to flexible pipe	1	264527	
32	Oil pipe to relief valve	1	5025 2 3	
33	Clip for pipe, union to flexible pipe	1	264528	
34	Union for oil pipe On oil filter	1	264529	
35	Joint washer for union adaptor	i	231577	
36	Thermometer pocket complete	i	232339	
42	Bolt (2 B.A. x 5 long) Fixing	2	250960	
43	Spring washer pocket to	2	3073	
44	Nut (2 B.A.) wing valance	2	2247	
45	Flexible oil pipe, pump to pocket	1	232181	
46	Oil temperature gauge	1	500555	
47	Mounting bracket for gauge	1	503147	
	J 0 0			

OIL COOLER, 2 LITRE PETROL



OIL COOLER, 2 LITRE PETROL

PLATE REF.	1 2 3 4 DESCRIPTION	ON (Qty.	Part No.	REMARKS
48	Bolt (2 B.A. x ½" long)		1	234603	
49	Spring washer		1	3073	
50	Nut (2 B.A.)	Fixing	1	2247	
	Bolt ($\frac{1}{4}$ " U.N.F. $\times \frac{1}{2}$ " long)	mounting bracket	1	255204	
	Plain washer	to dash	1	3840	
	Spring washer		1	3074	
	Nut (1 U.N.F.))	1	254810	
53	Grommet for pipe in dash		1	311200	
54	Union for gauge bulb		1	218512	
55	Joint washer for union		1	3055	·
56	Locker for union		1	217321	
57	Joint washer for gauge bulb		1	218751	
58	Panel light adaptor complete	e, LU.39024B	1	273714	
59	Bulb for adaptor, LU.207		1	10211	
60	Grommet for panel light lea	d, LU.859341	1	233244	R.H.D.
	Oil pump gear, driver		1	214996	
	OIL PUMP COVER ASS	EMBLY	1	234297	
	Dowel locating body		2	52710	
	Spindle for idler wheel		1	234307	
	Castle nut $(\frac{3}{8}'')$ fixing spin	dle	1	251602	
	Split pin for nut		1	2556	
	OIL PUMP IDLER GEA	R ASSEMBLY	1	214994	
	Bush for idler wheel		ì	214995	
	Special bolt		4	234838	
	Castle nut $(\frac{5}{16}")$ Fixing oil	pump cover	4	251601	
	Split pin		4	2555	
	Split pin fixing strainer		1	2 4 22	
	Crankcase sump		1	263332	
	Plunger for oil release valve		1	09038	•
	Adjusting screw \ For oil p		1	232245	
	Spring ∫ relief val	ve	1	232244	
	Fan complete		1	245654	
	Radiator block complete		1	279847	
	Cowl for radiator block		1	269952	
	Filler cap for radiator, 10 lb	s	1	242399	






PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
142,11	OIL COOLER COMPLETE ASSEMBLY		504766 2 litre models	
	OIL COOLER COMPLETE ASSEMBLY		531875* 2.1 litre models	
1	Oil cooler	1	232212	
2	Tapping plate	2	270605	
3	Drive screw fixing plate to frame	4	78167	
4	Set bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) \ Fixing cool		255204	
5	Spring washer $\int chassis fram$		3074	
6	Bolt (‡" U.N.F. x 13" long) Fixing		256002	
7		4	3074	
8	Spring washer cooler to	4		
0	Spacer radiator	2	278766	
0	Shim and grille	6	504299	
9	Nut (¼" U.N.F.) panel assem	bly 4	254800	
10	Oil return pipe	I	270074	
11	Union for return pipe	I	232141	
12	Flexible oil pipe, return to sump		232180	·
13	Banjo centre Fixing flexible oil	<u> </u>	232349	
14	Joint washer J pipe to sump	2	232042	
15	Clip for flexible oil pipe]	50690	
16	Bracket for clip		232351	
17	Screw (2 B.A. $x \frac{1}{2}$ long) Fixing return	1	71164	
18	Spring washer pipe clip	1	3073	
19	Nut (2 B.A.) J to bracket	1	2247	
20	Clip for oil return pipe	1	216708	
21	Adaptor for engine oil filter	1	247753	
22	Joint washer for adaptor	1	272839	
23	Bolt $(\frac{7}{16}"$ U.N.F. x $2\frac{7}{8}"$ long) fixing adaptor		253921	
	OIL COOLER RELIEF VALVE ASSEME	BLY I	232145	
24	Oil union]	232141	
25	Joint washer	l	231577	
26	Body]	232143	
27	Plunger		232144	
28	Spring for plunger	l	232142	
29	Oil pipe, union to flexible pipe]	527442	
30	Union for oil pipe]	264529	
31	Joint washer for union]	243959	
32	Bracket for clip	1	500556	
33	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long) Fixing	1	255007	
34	Plain washer bracket to		2213	
35	Spring washer front engine	1	3074	
36	Nut (¼" U.N.F.) ∫ lifting bracke	t I	254800	
37	Clip for union to flexible oil pipe	1	264528	
38	Bolt $(\frac{1}{4}'' \text{ U.N.F. } \times \frac{5}{8}'' \text{ long})$ Fixing	1	255006	
39	Spring washer >clip to	1	3074	
40	Nut (¼" U.N.F.) J bracket	1	254800	
41	Oil pipe to relief valve	1	502521	
42	Thermometer pocket complete	1	232339	
43	Bolt (2 B.A. $x \frac{1}{2}$ " long) Fixing	2	234603	
44	Spring washer thermometer poo		3073	•
45	Nut (2 B.A.) J to valance	2	2247	
46	Flexible oil pipe, pump to pocket	1	232181	
47	Clip fixing flexible pipe to L.H. battery sur	pport	56667	



Pi ATE	DESCRIPTION OF		ar, meser
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
48	Oil temperature gauge	1	500555
49	Mounting bracket for gauge	1	503147
50	Bolt (2 B.A. $x \frac{1}{2}'' \text{ long}$)	1	234603
51	Spring washer	i	3073
52	Nut (2 B.A.) Fixing mounti	ing I	2247
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) \Rightarrow bracket to glow	ve 1	255204
	Plain washer box and dash	1	3840
	Spring washer	1	3074
	Nut (‡" U.N.F.)	1	254810
55	Union for gauge bulb	1	218512
56	Joint washer for union	1	3055
57	Joint washer for gauge bulb	1	218751
58	Rubber grommet	1	311200
59	Locker	1	217321
	Cleat, gauge pipe to tie-rod	2	240429
60	Panel light adaptor complete, LU.39024B	1	273714
61	Bulb for adaptor, LU.207	1	10211
62	Grommet for panel light lead, LU 859341	1	233244 R.H.D. 1958-60 models
	Grommet for panel light lead, LU 859059	1	233243 R.H.D. 1961 models onwards
	C1	1	269611
	\mathbf{F}_{cons} , $\phi(\mathbf{t}, \mathbf{f}) = \mathbf{f}_{\text{cons}}$	1	279551 2 litre Alternatives.
	Francisk Calculate (12)	1	502723 models Check before ordering
	For complete	1	523410* 2½ litre models
	Plug retaining oil relief spring in pump	1	500427
	Inite and the face the	1	243970
	Vibration dominar accomble	1	500199 2 litre models
	Vibration domnor assamble	1	530305* 2½ litre models
	I ask analyse for exercise days	1	247771
	For mullow with faving hales of favor		277687 2 litre Alternatives.
	For muller mich Coince Units at 111		502729 models Check before ordering
	For puller	1	530304* 2½ litre models
	Demana mullan	1	277686 2 litre models
	Demomo nullou]	530132* 2½ litre models
	Look weeker for dynama mulley	1	03748
	Fan halt mair		512501 2 litre models
	For helt pair		530303* 2½ litre models
	Set bolt $(\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long)		255008 Alternative to two lines below
	Set bolt (\(\frac{1}{4}\)" U.N.F. \(\chi \frac{5}{8}\)" long) \(\sigma \) Fixing fan		255006 Alternative to line above
	Spring washer	4	3074 Check before ordering
	Tie rod for engine	1	504606
	Sleeve for engine tie rod	2	504607
	Rubber bush	4	07014
	Cup washer >For	4	07015
	Nut $(\frac{5}{16}$ U.N.F.) tie rod	4	254801
	Locknut (16" U.N.F.)	4	254861
	Bracket for tie rod at bell housing	i	504605
	Bolt (5 "U.N.F. x 1" long) Fixing	2	255228
	Spring washer bracket to	2	3075
	Nut $\left(\frac{5}{16}''$ U.N.F.) bell housing	2	254801
	Bracket for tie red at frame	1	508339
	Bolt (\(\frac{8}{8}\)" U.N.F. \(\times 2\frac{1}{4}\)" long) \(\cap \) Fixing	1	256050
	Spring washer bracket	1	3076
	Nut (\frac{3}{8}" U.N.F.) \text{ to frame}	1	254812
	J. to name	•	EJ IVIL


OIL COOLER, $\mathbf{2}_{4}^{1}$ LITRE PETROL



OIL COOLER, 21 LITRE PETROL

		4 , 2 4		
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	OIL COOLER COMPLETE ASSEMBLY	1	504922 Series II models	
	OIL COOLER COMPLETE ASSEMBLY	1	531879* Series IIA models	
1	Oil cooler	1	232212	
2	Tapping plate	2	270605	
3	Drive screw fixing plate to frame	4	78167	
4	Set bolt (‡" U.N.F. x ½" long)	4	255204	
5	Spring washer	4	3074	
6	Bolt (‡" U.N.F. x 1\frac{2}{8}" long) \rightarrow Fixing	4	256002	
7	Spring washer cooler to	4	3074	
8	Spacer >radiator and	2	278766	
_	Shim for oil cooler spacer grille panel	6	504299	
9	Nut ($\frac{1}{4}$ " U.N.F.) \int assembly	4	254800	
10	Oil return pipe]	270074	
11	Union for return pipe]	232141	
12	Flexible oil pipe, return to sump	l	232180	
13	Banjo centre Fixing flexible oil	1	232349	
14	Joint washer J pipe to sump	2	232042	
15	Clip for flexible oil pipe]	50690	
16	Bracket for clip	1	232351	
17	Screw (2 B.A. x ½" long) Fixing return	2	71164	
18	Spring washer pipe clip	2	3073	
19	Nut (2 B.A.) J to bracket	. 2	2247	
20	Clip for oil return pipe]	216708	
21	Adaptor for engine oil filter	1	247753	
22	Joint washer for adaptor	1	272839	
23	Bolt (76" U.N.F. x 27" long) fixing adaptor		253921	
0.4	OIL COOLER RELIEF VALVE ASSEMBI	LYI	232145	
24	Oil union	!	232141	
25	Joint washer	i 1	231577	en en en en en en en en en en en en en e
26	Body For relief valve	I *	232143	
27	Plunger	 	232144	
28	Spring for plunger	!	232142	
29	Oil pipe, union to flexible pipe	I	527442	
30 31	Union for oil pipe	!	264529	•
32	Joint washer for union	1	243959	
37	Bracket for clip	1	523500	
38	Clip for union flexible oil pipe Bolt (‡" U.N.F. x \$" long) \text{\text{Fixing}} Fixing	!	264528 255006	
39		1	3074	•
40	Spring washer	1	254800	
40	Bracket for pipe clip	1	500625	
	Bolt (2 B.A. x § long) Fixing	2	250960	
	Plain washer bracket to	2	3557	•
	Spring washer L.H. wing	2	3073	
	Nut (2 B.A.) L.H. wing valance	2	22 47	
41	Oil nine to relief unless	. 1	502521	
71	On pipe to rener valve	1	JVLJL1	


OIL COOLER, $2\frac{1}{4}$ LITRE PETROL



OIL COOLER, $2\frac{1}{4}$ LITRE PETROL

PLATE REF	1 2 3 4 DESCRIPTION Qty.	Part No. REMARKS
42	Thermometer pocket complete 1	232339
43	Bolt (2 B.A. $x \frac{5}{8}'' \text{ long}$) Fixing 2	250960
44	Spring washer thermometer pocket 2	3075
45	Nut (2 B.A.) to valance 2	2247
	Bracket for thermometer pocket 1	279811
	Bolt (2 B.A. $\times \frac{5}{8}'' \text{ long}$) Fixing 2	250960
	Plain washer bracket 2	3557
	Spring washer to wing 2	3073
	Nut (2 B.A.) valance 2	2247
46	Flexible oil pipe, pump to pocket 1	232181
47	Clip for flexible pipe 1	56667
",	Bolt (2 B.A. x ½" long) Tixing	234603
	Spring washer >clip to 1	3073
	Nut (2 B.A.) bracket 1	2247
48	0.1.	500555
49	Mounting bracket for gauge 1	503147
50	Bolt (2 B.A. x ½" long) 1	234603
51	Spring washer	3073
52	Nut (2 B.A.) Fixing 1	2247
)2	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) mounting 1	255204
	Plain washer bracket to 1	3840
	Spring washer glovebox 1	3074
	Nut (‡" U.N.F.) and dash	254810
55	Union for gauge bulb	218512
56	Joint washer for union 1	3055
57	1.1.4	218751
58	Rubber grommet for oil gauge pipe 1	311200
59	Locker for gauge union 1	217321
3,	Cleat, gauge pipe to tie-rod 2	240429
60	Panel light adaptor, complete, LU. 39024B 1	273714
61	Bulb for adaptor, LU. 207 1	10211
62	Grommet for panel light lead, LU 859341 1	233244 R.H.D. 1958-60
٠.	Grommet for panel light lead, LU 859059 1	233243 R.H.D. 1961 onwards
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long) $\frac{1}{2}$ For earthing	255206
	Spring washer clip on 1	3074
	Nut (¼" U.N.F.) radiator 1	254810
	Crankcase sump 1	269611
	Fan 1	507845 Series II models
	Fan 1	530511* Series IIA models
	Plug retaining oil relief spring in pump 1	500427
	Crankshaft pulley 1	278543 Series II models
	Crankshaft pulley 1	530130* Series IIA models
	Lock washer for starting dog 1	247771
	Joint washer for plug retaining oil relief valve	
	spring 1	243970
	Fan pulley 1	503039 Series II models
	Fan pulley 1	530304* Series IIA models


OIL COOLER, 21 LITRE, PETROL



OIL COOLER, $2\frac{1}{4}$ LITRE PETROL

PLATE	1.2.2.4 DECCRIPTION	0:	D AL DEMARKS
PLATE REF.	1 2 3 4 DESCRIPTION	Qty	
	Dynamo pulley	1	501019 Series II models
	Dynamo pulley	1	530132* Series IIA models
	Lock washer for dynamo pulley	1	217781
	Fan belt, pair	1	503041 Series II models
	Fan belt, pair	1	530303* Series IIA models
	Set bolt (‡" U.N.F. x 5" long) \ Fixing	4	255006
	Spring washer \int fan	4	3074
	Tie rod for engine	1	. 504606
	Sleeve for engine tie rod	2	504607
	Rubber bush	4	07014
	Cup washer >For	4	07015
	Nut (5 " U.N.F.) tie rod	4	254801
	Locknut (8 U.N.F.)	4	254861
	Bracket for tie rod at bell housing	1	504605
	Bolt $(\frac{5}{16}$ " U.N.F. x 1" long) \bigcap Fixing	2	255228
	Spring washer > bracket to	2	3075
	Nut (\frac{5}{16}" U.N.F.) bell housing	2	254801
	Bracket for tie rod at frame	1	508339
	Bolt (\frac{3}{3}" U.N.F. x 3\frac{1}{4}" long) \frac{1}{3} Fixing	1	256050
	Spring washer bracket	1	3076
	Nut (3" U.N.F.) to frame	1	254812


RECIRCULATING VEHICLE HEATER, FRONT, 2 LITRE PETROL



RECIRCULATING VEHICLE HEATER, FRONT, 2 LITRE PETROL

PLATE REF.	1 2 3 4 DESCRIPTIO	N	Q	ty.	Part No.	REMARKS
	FRONT HEATER UNIT COM	MPLETE WITI	Н			
	DEMISTER			1	330976	
1	Heater only, front, SM 620			1	304326	•
2	Bracket for heater unit			3	320009	
3	Blanking cap			l	302672	
4	Special nut Fixing blanking	ng-off cap .		2		Not required when demister is fitted.
5	Drive screw		:	2	304099	
6	Switch for heater, LU 540330	70		1	519726*	
	Knob for heater switch			1	519725*	
7	Feed wire for heater, LU.8611	1 67		1	240649	•
8	Grommet for heater leads			1	70742	
9	Inlet pipe for water pump			I	277509	
10	Joint washer for inlet pipe			1	213 7 24	
11	Reducing union for heater out	:let pipe .		1	213276	
12	Valve for heater water supply			1	214264	
13	Joint washer for union and va	lve	2	2	213961	
14	Water outlet pipe complete			1	264631	
15	Water inlet pipe complete			1	264629	
16	Union nut fixing pipes			2	2132 7 5	
17	Hose for water pipes			2	240639	
18	Clip for hose		4	4	50306	
1 9	Rubber seal for pipes			1	304327	
*	Bracket for pipe clip			1	264575	
	Saddle for pipe clip bracket			1	213513	
	Bolt (¼" U.N.F. x ¾" long)			1	255007	
		to bracket		1	252210	
	Thermostat housing assembly	••••		1	263695	
	Plug Blanking			1	3088	
	Fibre washer \int thermostat	housing]	3055	
	Joint washer for thermostat		••••	!	213811	
	Joint washer, water inlet to th		_		210419	
20	Junction box for demister tub			1	304348	
21	Set screw (4 B.A. x ½" long)			2	78149	
22		box to heater		2	3072	
23	Tube for demister, R.H.			l •	304345	
24	Tube for demister, L.H.		• • • • • • • • • • • • • • • • • • • •	1	304346	
25	Nozzle for demister, R.H.			1	332558	
26	Nozzle for demister, L.H.	••••		1	332558	
27	Drive screw fixing nozzle	,,,,,	••••	4	77789	


RECIRCULATING VEHICLE HEATER, FRONT, $2\frac{1}{4}$ LITRE PETROL AND DIESEL



RECIRCULATING VEHICLE HEATER, FRONT, 21 LITRE PETROL AND DIESEL


PLATE REF.	1 2 3 4 DESCRIPTION	Qty	Part No. REMARKS
REA".	FRONT HEATER UNIT COMPLETE WIT	ГН	
	DEMISTER	1	330988
1	Heater only, front	1	307838
2	Bracket for heater unit	3	320009
3	Switch for heater, LU 54033070	1	5 19726*
	Knob for heater switch	1	519725*
4	Feed wire for heater	1	24064 9
	Connector for feed lead, fuse unit to switch	1	510119 Series IIA models
5	Grommet for heater leads	1	70742
6	Valve for heater water supply	1	269562
7	Joint washer for valve	2	•
8	Water outlet pipe complete	1	500880
9	Water inlet pipe complete	1	269567
10	Hose for outlet pipe to heater	1	234063
	Hose for outlet pipe to pump	1	242358 1958-60 models
	Hose, outlet pipe to pump	1	509754 1961 models onwards
11	Pipe clip for outlet pipe, steel	2	
12	Clip for hose and inlet pipe	6	
13	Rubber seal for pipes	1	304327
14	Adaptor for return pipe hose	1	269565
15	Joint washer for adaptor	1	213960
16	Junction box for demister tubes	1	304348
17	Set screw (4 B.A. x ½" long) \ Fixing juncti		
18	Spring washer \int box to heater	r 2	· · · · · · · · · · · · · · · · · · ·
19	Tube for demister, R.H	1	304345
20	Tube for demister, L.H	1	304346 Handed type nozzle
21	Nozzle for demister, R.H	1	332558 Alternatives
22	Nozzle for demister, L.H	1	332558 Check before ordering
	Tube for demister, short]	302677
	Tube for demister, long	1	333479* Non-handed type
	Nozzle for demister	2	
23	Drive screw fixing nozzle	4	77789

RECIRCULATING VEHICLE HEATER, REAR, $\mathbf{2}^{\scriptscriptstyle{1}}_{\scriptscriptstyle{4}}$ LITRE PETROL



RECIRCULATING VEHICLE HEATER, REAR, $2\frac{1}{4}$ LITRE PETROL

PLATE REF.	1 2 3 4 DESCRIPTION	ON ·	Qty.	Part No.	REMARK	S
	REAR HEATER UNIT, CO	MPLETE	1	320502	Must be used in conjunction	with front heater,
					Part No. 330988	
1	Heater only, rear		1	306426		
2	Bracket for heater unit		3	304331		
3	Switch for heater, rear		1	519726*		
4	Knob for heater switch		1	519725		
5	Feed wire for heater, rear, 9		1	264837		
6	Grommet for heater leads		1	70742		
7	Cleat fixing heater leads		5	240429		
8	Hose, outlet pipe to junction	ı	1	234063		
9	Hose, inlet, tap to junction	••••	1	242358		
10	Junction for heater pipes		2	516318		
11	Hose, junction to front heat	er	2	231896		
12	Clip for hose	·· ····	4	50304	·	
13	Hose, junction to front pipe	s	2	240639		
14	Clip for hose		4	50306		
15	Pipe, front, for rear heater		2	248831	-	
16	Pipe, rear, for rear heater		2	248826		
17	Hose, front to rear pipes		2	240639		
18	Clip for hose	,	4	50306		
19	Hose, rear heater pipe		2	246778	-	
20	Hose at rear heater		2	246778		
21	Clip for hose		8	50306		
22	Clip for front pipe		2	213513		
23	Bolt $\binom{1}{4}$ B.S.F. $x \frac{5}{8}$ long)		1	237140		
24	Plain washer	≻Fixing front pi	ре 1	3946		
25	Spring washer	clips together	1	3074		
26	Nut (¼" B.S.F.)		1	2823		
27	Support bracket for front pi	ipe clip	2	248822		
28	Drive screw fixing support	bracket to chass	is 4	78436		
29	Clip for rear pipe		2	213513		
30	Bolt $(\frac{1}{4}$ B.S.F. $x \frac{5}{8}$ long)		2			
31	Plain washer	Fixing rear pip				
32	Spring washer	clips to suppor				
33	Nut (¼" B.S.F.)	bracket	2	2823		



		VIII IIIVI			I LIKOL,	L.11.17;	
PLATE REF.	1 2 3 4 DESCF	RIPTION	Qty.	Part No.		REMARKS	3
	HEATER COMPLETE AS	SEMBLY		332965	}		
1	Heater blower and fan cor	mplete	1	320251			
2	Blower volute and shroud		1	332551			
3	Sealing rubber, volute to v	wing duct	1	320174			
4	Sealing rubber, volute and	-	hov I	320198			
•	-	g volute, dash air		3840	·		
	1	and sealing rubbe		3074			
	Nut (\frac{1}{2}" U.N.F.) to day		4	254810			
5	Grommet in blower shrou		1	233243			-
6	Switch for heater, LU 540		I	519 7 26*			
U	Knob for heater switch		1	519725 *		è	
	Feed wire for heater		! 1	240649			
7	Heater box assembly	****	I	332531			
8	Air duct assembly at dash		1	332540	! !		
0			1	320273			
	Coil spring Fixing		2	2678			
	Plain washer \(\int \control \)	spinale	2	3939			
	Split pin Fixing	1	4	78153		•	
	Drive screw control p		4	78237			
0	Spire nut J to air du		1	332545	}		
9	Air duct assembly at wing			332343. 320175			•
10	Air duct mesh		I	78208	ļ		
	- ,	mesh and	2	3900			
	Plain washer air du		2 2	3074		-	
	-	valance	2	254810			
	Nut (1" U.N.F.) J at from		2	255007	L,HD		
	Bolt (½" U.N.F. x ½" long	-		2213	ע ח,גוק		
	Plain washer	duct support	2 2	3074			
	Spring washer	bracket to		254800			
11	Nut (‡" U.N.F.)	J dash toe box	1	320197			
11	Sealing rubber at air intal Drive screw \ Fixing das		1 4	78153			
	> -		4	78237			
	Spire nut \int to heater b Bolt ($\frac{1}{4}$ " U.N.F. $\times \frac{5}{8}$ " long		4	255207		•	
	Plain washer		•	3900	1		
•		Fixing heater box to dash	3	3074		•	
	Spring washer Nut (‡" U.N.F.)	DOX to dasn	3	254810			
12	Demister tube R.H.	J	1	304345	1		
13	Demister tube, L.H.	••••	I	304346	}		
14	Demister tube, L.Fl. Demister nozzle		2	332558			
14	Drive screw fixing nozzle	••••		77789			
15	Valve for water heater		1	214264			
16	Reducing union	****	I	213276			
17	Joint washer for union an	d valva	2	213961			
18	Heater water outlet pipe		1	278500	1		
19	Heater water inlet pipe		I	264629			
20	Union nut for pipes		2	213275			
21	Hose, water inlet		1	278702			
22	Hose, water outlet		1	278702			
23	Clip, ½" diameter \ For	••••	2	279630	1	•	
24	Clip, ⁷ / ₈ " diameter hoses		2	50306			-
74	outh 8 marrierer 3 noses	•	4	,,,,,,,,	J		





PLATE REF.	1 2 3 4 DESCRI	PTION	Qty.	Part No.	REMARKS
25	Pipe clip bracket		1	264575	
26	Saddle for pipe clip bracket		1	213513	
	Bolt (1" U.N.F. x 5" long)	Fixing saddle	1	255007	
	Self-locking nut	>and water pipe	s		1
	(½" U.N.F.)	to bracket	1	252210	
	Thermostat housing		1	263695	
	Plug \ \ For therm	nostat	1	3088	
	Joint washer housing		1	3055]
	Tube, thermo housing to wa	ater pump	1	09197	
	Joint washer, water outlet p		1	210419	L.H.D.
	Joint washer, thermostat hou			213811	}
27	Water pump inlet pipe		1	277509	
28	Joint washer for inlet pipe	> P = 4	1	213724	
	Transfer gear change lever of	complete	1	279331	
	Check strap assembly		1	332553	1
	Check strap mounting brack	et	1	332552	·
29	Mud shield for front wing F	R.H	1	332555	
30	Rubber seal on R.H. mud sl		1	332556	
31	Retaining plate for rubber se	eal	1	332557	
	Screw (2 B.A. x ½" long)		6	77869	
		plate to R.H.	6	30 7 3	
	(mud shield	6	2247	J


FRESH AIR HEATER, $2\frac{1}{4}$ LITRE PETROL, L.H.D.



FRESH AIR HEATER, $2\frac{1}{4}$ LITRE PETROL, L.H.D.

DI ATT			, 2	<u> </u>	TEIROL,	L:11.1/.	
PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.		REMARKS	
	HEATER COMPLETE ASSEMBI	_Y	1	332973	<u> </u>		
1	Heater blower and fan complete		1	320251			
2	Blower volute and shroud		1	332551	1		
3	Sealing rubber, volute to wing duc	t	1	320174			
4	Sealing rubber, volute and duct to		ov 1	320198			
	Plain washer Fixing volute,		4	3840	1		
	Spring washer duct and sealin		4	3074			
	Nut (‡" U.N.F.) to dash toe box		4	25 4 810			
5	Grommet in blower shroud for lead		i	233243			
6	Switch for heater, LU 54033070		I	519726 *		•	
•	Knob for heater switch		I	519725*			
	Feed wire for heater		l 1		1		
	Eyelet for feed wire		I	240649			
7	LL	••••	I	243380			
8	Air duct assembly at dash		I	332531			
Ū			l	332540	1		
			2	320273	Į.		
	Plain washer Scontrol spindle		2	2678			
	Split pin Fixing		2	3939	{	•	
	Drive screw control plate		4	78153	l		
9	Spire nut J to air duct Air duct assembly at wing		4	78237	(
10	Air duct assembly at wing Air duct mesh	•	[332545			
	Special bolt Fixing mesh	• • • •	I	320175	ļ		
	Plain washer and air duct		2	78208			
	Spring washer to wing valance		2	3900 2074			
	Nut (½" U.N.F.) at front		2 2	3074			
			2	254810	≻L.H.D.		
				255007	ĺ		
	Spring washer brack	support	2 2	2213 3074			
		toe box	2	254800			
11	Sealing rubber at air intake		1	320197			
	Drive screw \ Fixing dash air	••••	I	78153			
	C		4	78237			
	Bolt (‡" U.N.F. x \ \frac{1}{2}" long)	••••	4	255207			
		g heater	4	3900	1		
		o dash	3	3074			
	Nut (½" U.N.F.)	o uasii	3	254810			
12	Demister tube R.H.		1	304345			
13	Demister tube L.H		l l	304346			
14	Demister nozzle		2	332558			
	Drive screw fixing nozzle		4	77789			
15	Adaptor for hose, return pipe to			,,,,,,			
-	housing		- 1	269565			
16	Joint washer for adaptor		1	213960			
17	Hose, return pipe to thermostat hou			242358		•	
18	Pipe, heater water return	ising	,	500880			
19	Clip for return pipe		2	278891			
20	Hose, return pipe to heater		1	501081			
21	Hose valve to heater		1	269567			
22	Clip for hoses	****		279630			
			•	21,7000			


FRESH AIR HEATER, $2\frac{1}{4}$ LITRE PETROL, L.H.D.



FRESH AIR HEATER, $2\frac{1}{4}$ LITRE PETROL, L.H.D.


PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
23	Valve, for heater water	1	269562]
24	Joint washer for valve	2	213960	
	Transfer gear change lever complete	1	279331	i
	Check strap assembly	1	332553	
	Check strap mounting bracket	1	332552	
25	Mud shield for front wing R.H	1	332555	⟩L.H.D.
26	Rubber seal on R.H. mud shield	1	332556	i e
27	Retaining plate for rubber seal	1	332557	
	Screw (2 B.A. $x \frac{1}{2}$ long) Fixing seal and	6	77869	
	Spring washer > plate to R.H.	6	3073	
	Nut (2 B.A.) J mud shield	6	2247	J

REAR SEATS



REAR SEATS

PLATE REF.	1 2 3 4 DESCRIPT	ION_	Qty.	Part No.	REMARKS
	REAR SEAT COMPLETE		2	330969	Up to four seats may be fitted in the body of the 109
	REAR SEAT FRAME A	SSEMBLY	. 2	331228	
1	Rear seat back frame	,	. 2	331229	•
-	Securing clip for backres	st R.H	. 1	331314	
	Securing clip for backre	st L.H	. 1	331315	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " lon		8	255206	
	Spring washer	>to backrest	8	3074	
	Nut (‡" U.N.F.)	frame	8	254 810	
2	Hinged base for rear sea	t	. 2	301489	
3	Bolt (¼" U.N.F. x ¾" lor	g) Fixing	4	255207	
4	Plain washer	>base to	12	3821	
5	Nut (¼" U.N.F.)	back frame	4	254810	
6	Seat strap complete		. 2	302648	
7	Hook for strap		. 2	301005	
8	Plain washer \ Fixing s	strap to	4	3816	
9	Pop rivet hinged	base	2	300782	·
	Rubber buffer		4	304125	
	Screw (2 B.A. x 1" long)		4	78120	
	Packing washer	Fixing buffer	4	3898	×109
	Plain washer	to seat frame	8	4030	
	Nut (2 B.A.)		4	2247	
10	Bolt (‡" U.N.F. x ¾" long))	4	255207	
11	Plain washer	Fixing	4	3821	
12	Spring washer	seat frame to	4	3074	
13	Nut (‡" U.N.F.)	wheel arch box	4	254 810	
	Packing washer		8	2228	109
	REAR SEAT BACK I	REST TRIMMED			
	ASSEMBLY, GREY	· ···· · ···	. 2	320084	
14	Back rest panel		. 2	301470	
15	Retaining rod for pad		. 4	301476	
16	Pad for back rest	·	. 2	302647	
17	Bolt (1" U.N.F. x 1" long)	Fixing	12	255204	•
18	Spring washer	>back rest	12	3074	
19	Nut (‡" U.N.F.)) to frame	12	254810	
20	REAR SEAT CUSHION	ASSEMBLY, GRE	Y 2	320085	
21	Pad for rear cushion		. 2	302655	




WATER TEMPERATURE AND OIL PRESSURE GAUGE, 2 LITRE PETROL

** .	illi illi limi oi			ALLOS OILL		
PLATE REF.	1 2 3 4 DESCRIPTI	ON	Qty.	Part No.		REMARKS
	WATER TEMPERATURE	AND OIL PR	ES-			
	SURE GAUGE COMPL	ETE ASSEME	BLY 1	241713		
1	Water temperature and o	il pressure ga	uge,			
	JA TO 10		1	233480		
2	Mounting bracket for gauge	1194	1	503147		
3	Bolt (2 B.A. x ½" long))	1	234603		
4	Spring washer		1	3073		
5	Nut (2 B.A.)	Fixing	1	2247		
	Bolt (¼" U.N.F. x ½" long)	>mounting bra	icket 1	255204		
	Plain washer	to dash	1	3840		
	Spring washer		1	3074		
	Nut (¼" U.N.F.)	J	1	254 810		
8	Union for thermometer bull	6, JA WA/8/P/7	059 1	218512		
9	Locker for union		1	217321		
10	Washer for union		1	3 055		
11	Washer for thermometer bu	lь, JA WA/8/Р,	/9423 1	218751		
12	Bracket supporting thermon	neter pipe	1	234059		
13	Clip for thermometer pipe	****	6	41379		
14	Screw (2 B.A. x $\frac{1}{2}$ long)		6	71164		
15	Spring washer	Fixing clips	6	3073		
16	Nut (2 B.A.)		6	2247		
17	Oil pipe for gauge		1	275377		
18	Grommet for pipe in dash		1	311200		
	Clip for flexible pipe		1	50642		
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long))	1	255004		
	Spring washer	Fixing clip to	dash I	3074		
	Nut (‡" U.N.F.)	J	1	254800	•	
19	Union for oil pipe		1	270938		
21	Washer for union		1	232039		
	Panel light adaptor, LU.390		1	273714		
	Bulb for panel light, LU.		1	10211		
	Grommet for panel light lea		1	2 33 2 44		•
	THERMOSTAT HOUSIN		Y 1	263695		
	Plug, large Blanking		1	10713		
	Fibre washer \(\int \tapping in	n housing	1	213961		
	Plug for oil light hole		1	274897		

UNIVERSAL JOINT COVER PLATES, ALL MODELS


PLATE REF.	1 2 3 4 DESC	RIPTION	Qty.	Part No.	REMARKS
	UNIVERSAL JOINT	COVER PLATE			
	COMPLETE ASS	SEMBLY	1	261829	
22	Cover plate for joint	at differential housings	2	233071	
23	Top strap for cover p	olate	2	233068	
24	Bolt (1"B.S.F. x 7" lor	ng)) Fixing cover plates	to 4	237142	
25	Nut (1" B.S.F.)	differential housings	4	2823	
26	Shield for joint at tra	insfer box	1	233073	
27	Bolt (2 B.A. x ½" lon	8)]	2	234603	
28	Spring washer	>Fixing	2	3073	
29	Nut (2 B.A.)	shield	2	2247	
30	Drive screw		2	77926	

WATER TEMPERATURE AND OIL PRESSURE GAUGE, $2\frac{1}{4}$ LITRE PETROL AND DIESEL



WATER TEMPERATURE AND OIL PRESSURE GAUGE, $2\frac{1}{4}$ LITRE PETROL AND DIESEL

		AND	التاكنايل	
PLATE REF.	1 2 3 4 DESCRIPTION	Qty	. Part No.	REMARKS
	WATER TEMPERATURE AND OIL			4
	PRESSURE GAUGE COMPLETE	1	525590	~
1	Water temperature and oil pressure gauge	1	502961	No red marking on dial
	Water temperature and oil pressure gauge	1	523683	With dial marked in red at 100°C to 120°C
2	Mounting bracket for gauge	1	503147	
3	Bolt (2 B.A. x ½" long)	1	234603	
4	Spring washer	1	3073	
5	Nut (2 B.A.) Fixing	1	2247	
	Bolt (1" U.N.F. x 1" long) > mounting by	racket 1	255204	
	Plain washer to dash	1	3840	
	Spring washer	1	3074	
	Nut (½" U.N.F.)	1	254810	
8	Union for thermometer bulb	1	218512	2½ litre Petrol models
	Union for thermometer bulb	1	2 7 8165	Diesel models
9	Joint washer for gauge bulb	1	218751	
	Joint washer \(\) Union to	1	243959	2½ litre Petrol models
	Joint washer ∫cylinder head	2	243972	Diesel models
10	Support bracket for pipe clip	1	279861	24 litre Petrol models
	Support bracket for pipe clip	1	279783	Diesel models
11	Bolt (2 B.A. $x \frac{1}{2}$ long) Fixing	2	234603	
12	Spring washer > bracket	2	3073	
13	Nut (2 B.A.) to dash	2	2247	
14	Clip for thermometer pipe	1	41379	
15	Screw (2 B.A. $x \frac{1}{2}$ long) Fixing pipe	1	71164	
16	Spring washer >clip to	- 1	3073	
17	Nut (2 B.A.) support bracke	et 1	2247	
18	Oil pipe for gauge	<u>, 1</u>	279785	
	Banjo for oil pipe	1	502655	
	Adaptor for oil pipe	1	502653	
	Joint washer for oil pipe and filter	2	232039	
20	Joint washer for union	2	231575	1958-59
21	Grommet for oil pipe in dash	1	311200	
22	Clip for pipe, L.H. side of dash	1	4020	•
23	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{1}{2}$ " long) \bigcap Fixing clip	1	255004	
24	Spring washer \rightarrow to L.H. side	: 1	3074	
25	Nut $\binom{1}{4}$ U.N.F.) of dash	1	254800	
	Clip for oil pipe, R.H. side of dash	2	50640	
	Bolt (2 B.A. $x \frac{1}{2}$ long) \int Fixing clips	2	234603	
	Spring washer >on R.H. side	2	3073	
	Nut (2 B.A.) of dash	2		
26	Panel light adaptor, LU.39024B	1	273714	
27	Bulb for panel light, LU.207	1	10211	•
28	Grommet for panel light lead, LU.859341	l J	233244	1958-60
	Grommet for panel light lead, LU 859059	The second secon	233243	1961 onwards



	10111	10 11	I ACIIII		 .
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS	5
	TOWING JAW, COMPLETE ASSEM	BLY,]
	STANDARD TYPE	1	518674		
1	TOWING JAW ASSEMBLY	1	517489		
2	Pintle pin, chain and ring complete	1	524134		
3	Spring for pin	1	269598	_	
5	Spring clip for chain	1	235268	€ Alternatives.	
	Locking ring for chain	1	517773	Part of 524134	Standard
				ordering	equipment
	Bolt (5" U.N.F. x 5" long)	2		Alternatives	on all Export
6	Bolt $(\frac{5}{8}$ U.N.F. x $5\frac{1}{2}$ long) Fixing bra			Check before	models and
	Bolt $(\frac{5}{8}$ U.N.F. x 6' long) 514651 or	2		ordering	all 10 9
7	Plain washer, small towing jaw	2		Alternatives.	Station
	Distance piece 518674 to	1		Check before ordering	Wagons
8	Plain washer, large cross-mem	ber 4		2 off when distance piece is fitted	Optional
9	Nut $\binom{5''}{8}$ U.N.F.)	4	254816		equipment
	Bolt $(\frac{5}{8}$ U.N.F. x $2\frac{1}{2}$ long) \bigcap Fixing tow			Alternatives.	on other
	Bolt $(\frac{5''}{8}$ U.N.F. x 3" long) > jaw to attack	ch- 2	518362	Check before ordering	Home models
	Nut $\binom{5}{8}$ U.N.F.) \int ment brack		254816		J
	TOWING BRACKET ASSEMBLY FOR	}			l
	STANDARD TOWING JAW	1	514651		
10	Bracket for towing jaw	1	508412		
11	Bolt $(\frac{3}{8}$ " U.N.F. x $4\frac{3}{4}$ " long) \(\) Fixing	2	256256		ŀ
12	Plain washer, thin bracket to	2	4094		
	Plain washer, thick rear	2	4067		
13	Nut $\binom{3''}{8}$ U.N.F.) \int cross-member		254812	•	j
	TOWING JAW COMPLETE ASSEMBL	.Y 1	232493		
14	Towing jaw	1	232474		
15	Pin for towing jaw	1	232484		
16	Chain for towing jaw pin	1		Except 109 Station Wagon	
17	Bolt (3" B.S.F. x 43" long)	4	273483		
18	Plain washer Fixing jaw	8	4067		
19	Spring washer to chassis	4	3076		
20	Nut $(\frac{3}{8}"$ B.S.F.)	8	3485		
	TOW BAR ANCHOR ASSEMBLY,				
	STANDARD	1	231213		
21	Tow bar anchor	1	219684		
22	Bolt (¾" B.S.F. x 2" long) \ Fixing ancho		267431		
23	Self-locking nut $\binom{3}{4}$ B.S.F.) \int to rear draw	bar 2	234828		
	TOW BAR ANCHOR ASSEMBLY,				
	COMBINE HARVESTER	1	231214		
24	Tow bar anchor	1	230123		
25	Bolt (3" B.S.F. x 2" long) Fixing anchor		267431		
26	Self-locking nut $(\frac{3}{4}^{\prime\prime} B.S.F.) \int$ to rear draw	bar 2	234828		
27	Extension plate for standard towing jaw	1	231498		
28	Bolt (3" B.S.F. x 2" long) Fixing extensi			Only required when Power Take-o	off is fitted
29	Self-locking nut (¾" B.S.F.) ∫ plate to rear dr	aw bar 2	234828		





PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.	REMARKS
	REAR TOW PLATE ASSEMB	LY	1	501683	
30	Rear tow plate)	1	502125	
31	Set bolt (§ "U.N.F. x 🖁 "long)		3	255046	
32	Locking plate	Fixing	3	235731	
33	Bolt (🖁 " U.N.F. x 1 " long)	tow plate	4	255047	
34	Plain washer, small	to rear	4	2219	
35	Plain washer, large	cross-member	4	3040	
36	Nut (🖁 " U.N.F.)		2	254802	
	Self-locking nut (3" U.N.F.)		2	252162	
37	Locking plate	J	4	235730	
	FRONT LIFTING AND TO	VING RINGS			
	ASSEMBLY		1	26 79 50	
38	Lifting and towing ring	****	2	242139	
39	Bolt (§ U.N.F. x 1½ long)	Fixing towing	4	255249	
40	Plain washer	≻ring to	4	4094	
41	Self-locking nut (§" U.N.F.)	front bumper	4	252212	
42	Bolt ($\frac{3}{8}$ " U.N.F. x $4\frac{1}{2}$ " long)	Fixing towing	4	256255	
43	Plain washer	ring and bum-	8	4094	
44	Self-locking nut (⅔" U.N.F.) ∫	per to frame	4	252212	
	TOWING HOOK ASSEMBLY		1	332974)	
45	Towing hook	****	1	246109	
46	Bolt $(\frac{1}{2}$ " B.S.F. x $2\frac{1}{4}$ " long) $\int F$	ixing	4	273881	
47		wing hook	8		Except 109 Station Wagon
48	Adaptor plate for towing hook		1	245599	
49	Bolt (§ B.S.F. x 5" long)] Fix	ing adaptor	4	273484	
50	ι -	te to rear	8	4067	
51	Nut (§" B.S.F.)	ss-member	8	3485	•

FLASHING INDICATORS




FLASHING INDICATORS

PLATE REF.	1 2 3 4 DESCRIPTION		Qty.	Part No.	REMARKS
	FLASHING INDICATOR CO	MPLETE			
	ASSEMBLY		1	501684	With flasher switch on dash. Check before
					ordering
	FLASHING INDICATOR COM	MPLETE)
	ASSEMBLY		1	522646	<u>,</u>
	FLASHING INDICATOR COM	MPLETE			steering column.
	ASSEMBLY	****	1	531945*	Series IIA models J Check before ordering
1	Flasher unit, LU FL5 35010A		1	271459	Series II models
	Flasher unit	****	1	502096	Series IIA models
2	Drive screw fixing flasher unit		1	7 2628	-
3	Self-cancelling switch for flash	-		271108	Switch on dash. Check before ordering
4	Self-cancelling switch for flasher			519672	Series II models
	Self-cancelling switch for flasher			519866*	Series IIA models
5	Bulb, 12v. 1.8w. for flasher s	witch, Magi	natex		Switch on steering column.
	G.B.P		1	519705	Check before ordering
6	Wheel for flasher switch	****	1	522882) .
7	Mounting plate for flasher swite	h	1	500229)	
8	Screw (2 B.A. x ½" long)		1	77869	
9		king	1	77941	
10	(unting plate		3073	
11	Plain washer		2	J	With flasher switch on dash.
12	Nut (2 B.A.)		2	2247	Check before ordering
13	Warning light for flasher, LU.3			264429	
14	Bulb for warning light, LU 9	37	I	232590	
15	Green lens for warning light	****	l	271915	
16	Harness for flasher	****	1	ر 500227	_
	Harness for flasher			519671	Series II models With flasher switch on
	Feed lead for flasher switch		1	519865*	Series IIA models > steering column.
					Check before ordering
17	Grommet for flasher harness, L	U 859059	1	233243	With flasher switch on dash. Check before ordering
	Front flasher lamp		2	505145 †	')
18	Bulb for flasher lamp, LU 38.		2	264591	Sparto type.
	Bulb holder, interior (Sparto	12207)	2	524497	Alternative to Lucas.
19	Lens for flasher lamp	••••	2	500837	Check before ordering
20	Rubber body for flasher lamp	••••	2	500515	
21	Bezel for flasher lamp	••••	2	500514	,
22	Front flasher lamp, LU 52438		2	510178 †	T
23	Lens for flasher lamp, LU 54		2	514151	
24 25	Special screw fixing lens, LU		4	514149	Lucas type.
25 26	Bulb for flasher lamp, LU 38		2	264591	Alternative to Sparto.
26	Bulb holder, interior, LU 573		2	514144	Check before ordering.
27	Bezel for flasher lamp, LU 54	5/0407	2	514148	J
28	Nylon insert		4	505150	2
29	Screw (4 B.A. $\times \frac{3}{8}$ long) $\int_{0}^{\infty} F_{1}$		4	501679	Alternatives.
30	1	sher lamp	4	3072	Check before ordering
31		front wing	4	75805	J
32	Fixing plate for front flasher larr	ıp	2	50 4 048	Not required when special screw and nylon insert is
					fitted

1 2 3 4 * Asterisk indicates a new part which has not bee	n used on any previous model.
† Up to vehicles numbered: †† From vehicles numbered:	nicles numbered:
141903513 146901439 151900889 156900918 1419035	14 146901440 151900890 156900919
142901597 147900175 152902901 157900456 1429015	98 147900176 152902902 157900457
144903030 149900307 154901596 159900275 1449030	31 149900308 154901597 159900276 onwards

457

FLASHING INDICATORS



FLASHING INDICATORS

Rear flasher lamp	
Bulb holder, interior (Sparto 12208) 2 524498 Sparto type. 34 Lens for flasher lamp 2 500838 Alternative to Luca: 35 Rubber body for flasher lamp 2 500413 Check before orderi	
Bulb holder, interior (Sparto 12208) 2 524498 Sparto type. 34 Lens for flasher lamp 2 500838 Alternative to Luca: 35 Rubber body for flasher lamp 2 500413 Check before orderi	
34 Lens for flasher lamp 2 500838 Alternative to Luca 35 Rubber body for flasher lamp 2 500413 Check before orderi	
	ng
36 Rezel for flasher lamp 2 500412	
Dezer for hasher lamp 2 Jov-12	
Special screw fixing rear flasher lamp to body 4 500414	
38 Rear flasher lamp, LU 53806 2 510177**	
39 Lens for flasher lamp, LU 54570563 2 514142	
40 Special screw fixing lens, LU 576396 4 514143 \Lucas type.	
41 Bulb for flasher lamp, LU 382 2 264591 Alternative to Spart	o. Check before ordering
42 Bulb holder, interior, LU 573832 2 514144	_
43 Sleeve for terminal, LU 555910 2 514145	
44 Drive screw fixing rear flasher lamp to body 4 78135	
45 Snap connector, 4-way, LU 850641 2 3626 Series II models	
46 Cleat, flasher to dash harness, LU 941833 1 240430 Series 11 models	
47 Earthing clip on rear chassis cross-member,	
LU 860019A 2 236366	
Clip for flasher harness on R.H. wing valance 2 240406	LUD
Clip for flasher harness to horn lead 1 233771 Series II models	.H.D.
48 Clip for number plate harness 2 50639 Series II models	
Clip for lamp and flasher harness to wing valance 1 3621 Diesel	
49 Cleat for flasher harness, at tie bar and rear	
cross-member, LU 941834 5 240429 Series II models	
50 Clip for flasher harness 1 233770 With flasher switch or	steering column.
Check before ordering	


1234	* Asterisk indica	tes a new part	which has not been used	on any previo	us model.
† Up to vehicles numbered: 141903513 14690143	9 151900889	156900918	†† From vehicles 141903514	numbered: 146901440	15190089

 141903513
 146901439

 142901597
 147900175

 144903030
 149900307


HAND THROTTLE, 2 LITRE PETROL



HAND THROTTLE, 2 LITRE PETROL

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	HAND THROTTLE COMPLETE ASSEMBL	Y 1	241715	
1	Hand throttle control	. 1	239016	
2	Cork washer	1	2320 9 5	
3	Plain washer > For hand throttle	1	2218	
4	Circlip	1	232097	
5	Spindle for carburetter bell crank	1	219499	
6	Split pin for spindle	1	2392	
7	BELL CRANK LEVER ASSEMBLY	1	231289	
8	Bush for levers	1	231290	
9	RELAY LEVER ASSEMBLY	1	231291	
10	Ball end for lever	1	1481	
11	HAND THROTTLE LEVER ASSEMBLY	1	231292	
12	Swivel clamp for wire	1	219582	
13	Abutment bracket for hand throttle	1	239531	
14	Plain washer Fixing abut-	1	2550	
15	Spring washer >ment bracket	: 1	3075	
16	Set bolt $(\frac{5}{16}"$ Whit. x $\frac{11}{16}"$ long) \int to manifold	1	215647	
17	Cable clip Tixing hand	1	219501	
18	Screw (2 B.A. x ½" long) \rightarrow throttle cable	1	71164	
19	Spring washer to abutment	1	3073	
20	Nut (2 B.A.) bracket	1	2247	


HAND THROTTLE, $2\frac{1}{4}$ LITRE PETROL



HAND THROTTLE, 21 LITRE PETROL

PLATE REF.	1234	DESCRIPTION		ty.	Part No.	REMARKS
REF.		TLE COMPLETE		1	503033	
1		complete hand spee		i	275706	
2		nd speed control co		•	2,7100	
_	ball end	control co	inpicto will	1	275709	
3	Bush	••••	••••	1	275714	
4	Washer	ີ້		1	275715	
5	Bolt	Fixing lever		i	255028	
6	Plain washer	to housing		1	2223	
7	Self-locking no	1		1	252211	
8	Knob, for leve	_		1	219512	•
9	Screw \ Fixin			1	219673	
10	Nut ∫to lev			1	2247	
11	Quadrant plate			1	275713	•
12	Screw)		2	278386	
13	Spring washer	Fixing quadrant	plate	2	3074	
14	Plain washer	to housing		2	3840	
-	Nut			2	254800	
15	Bolt	<u> </u>		2	234603	•
16	Plain washer	Fixing speed co	ntrol to	2	3685	
17	Spring washer	dash (Upper fix)	ings)	2	3073	
18	Nut	J		2	2247	
	Stop clip			1		L.H.D.
19		drant control rod		Ī	276013	
20		F. x $1\frac{1}{4}$ " long) \int Fix		1	256001	2 off on L.H.D.
	Plain washer	>leve		2	3911	3 off on L.H.D.
21	Nut (‡" U.N.I		shaft	1	254800	2 off on L.H.D.
22		ever to accelerator sl	aft	1	276014	
23	Nut, for ball s	ocket		1	2247	·
24	Ball socket			1	1659	•
25		ever on accelerator r	elay	1	276015	
26		Fixing joint pin		1	2208	
27		∫ to lever		Ì	2388	
28		ntrol rod to joint pin		2	2247	
		t dash for hand spee		1	275742	•
		celerator relay shaft		2	236998`	1 .
	Bolt ($\frac{1}{4}$ " U.N.		ing	4	255006	· ·
	Spring washer	•	cket	4		L.H.D.
	Nut (1/2" U.N.	•	dash	4	254800	
	Accelerator re	lay shaft	••••	I	277154	J


A.C./D.C. GENERATOR, 12 VOLT, 21/4 LITRE PETROL, Series II



A.C./D.C. GENERATOR, 12 VOLT, 21 LITRE PETROL, Series II

DI ATT	DESCRIPTION		D . N	DEMARKS
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	A.C./D.C. GENERATOR, COMPLETE	_		
	ASSEMBLY, 12 VOLT]	514304	
1	Generator complete, 12 volt, LU 2 AC 23500		507147	
	Special bolt, fixing bracket, LU 244130	3	516475	
	Generator bracket complete, LU 54210635		516476	
	Brush box, set, for generator, LU 54211		516477	•
	Brushes for generator, set, LU 244018	i 1	516478	
	Spring, set, for brushes, LU 54210582	2 1	516 4 79	
	Shield for terminal, LU 54210037	1	516480	
	Condensor for generator, LU 425823	1	516481	
	Anode base diode, LU 49074	3	516482	
	Cathode base diode, LU 49073	3	516483	
	Stator complete for generator, LU 5421022	21 1	516484	
	Bracket, drive end, LU 54211974	1	516 4 85	
	Bearing, drive end, LU 189275	17	516486	
:	Special nut for shaft, LU 180620	1	516487	
	Rotor and slip ring complete, LU 5441044	8 / 1	516488	
	Bearing, slip ring end, LU 189212	1	516489	
	Sundry parts set, LU 54211976	1	516490	
2	Fan for generator	1	514296	
3	Pulley for generator, driven	1	518712	
4	Set bolt (½" U.N.F. x 4½" long), fixing gener	ra-		
	tor bracket and cylinder head	2	278553	
5	Bracket for generator, top	1	507308	•
6	Set bolt, front (16" U.N.F.) Fixing	•	307300	
Ū	$x \frac{3}{4}$ long) bracket	1	255426	
7	Set bolt, rear (5" U.N.F. > to bolt on	•	255 120	
,	x §" long) cylinder	1	255425	
8	Spring washer head	2	30 7 5	
9	Bracket for generator, front	1	507300	
10			507311	
11	Packing piece Fixing brace Set bolt (\frac{5}{16}" U.N.F. x 1" long) to cylinder	жет і 2	255428	
12			3075	•
13	Spring washer head, front	2 1	507312	
	Yoke for generator	!	207312	
14	Bolt $(\frac{5}{16}"$ U.N.F. x $1\frac{1}{2}"$ long) for \int Fixing	1	256.422	
	yoke and bracket yoke	'	256422	
	Bolt (16" U.N.F. x 1" long) for and		255220	
12	bracket generator		255228	
15 14	Spring washer to	2	3075	
16	Nut (5" U.N.F.) bracket	2	254801	
17	Set bolt Fixing	i	233568	
18	Spring washer > yoke to	Į.	3075	
19	Plain washer generator, upper	l -	2550	
20	Adjusting link for yoke	<u>I</u>	247523	
21	Bolt (18" U.N.F. x 8" long) Fixing adjusti	ng 2	255427	
22	Plain washer blink to yoke	I	2550	
23	Spring washer and front	2	3075	
24	Nut $(\frac{5}{16}$ U.N.F.) \int bracket	2	2548 01	
25	· · · · · · · · · · · · · · · · · · ·	1	277999	
26	Anchor bracket, front	1	278000	


A.C./D.C. GENERATOR, 12 VOLT, 21 LITRE PETROL, Series II



A.C./D.C. GENERATOR, 12 VOLT, 21 LITRE PETROL, Series II

PLATE REF.	1 2 3 4 DESCRIPTIO	N (Qty.	Part No.	REMARKS
27	Set bolt $(\frac{5}{16}"$ U.N.F. x 3" long) Fixing front	2	256030	
28	Locking plate	anchor bracket	1	501198	
29	Set bolt $(\frac{5}{16}"$ U.N.F. $\mathbf{x} \frac{5}{8}"$ long		2	255425	
30	Spring washer	anchor bracket	2	3075	1
31	Bracket, for idler body		1	500212	
32	Bolt $(\frac{5}{16}"$ U.N.F. x $1\frac{1}{4}"$ long)	Pivot for	1	256220	
33	Bolt (5" U.N.F. x 3\frac{1}{4}" long)	idler	1	256033	
34	Shim washer	pulley	5	3815	
35	Self-locking nut (5 " U.N.F.)	-	2	252161	
36	Set bolt $\binom{5}{16}$ U.N.F. $\times \frac{3}{4}$ lon		4	255026	
37	Plain washer	bracket to	4	2249	
38	Spring washer	idler body	4	3075	
39	Idler wheel body		1	500209	
40	Spindle for idler wheel		i	521488	
••	Circlip for spindle		1	241999	
41	Ball bearing, outer \) For		1	235860	
42	Ball bearing, inner spindl	e	1	500388	
43	Circlip, fixing outer bearing t		1	235861	
44	Plug (½" B.S.F.) Closing	,	1	10713	
45	Joint washer body end		1	243960	
46	Set bolt $(\frac{5}{16}"$ U.N.F. $x \frac{3}{8}"$ lon	g)) For	1	255021	
47	Joint washer	grease hole .	1	232038	
48	Pulley for generator, driver	,	1	513989	
49	Circlip, fixing pulley to spind		1	230255	
50	Adjusting link for idler pulley		1	500213	# ¹
51	Set bolt $(\frac{5}{16}"$ U.N.F. $x \frac{5}{8}"$ lon		1	255025	
52	Spring washer	≻to idler	1	3075	
5 3	Plain washer	pulley body	1	3868	
54	Belt for generator		1	515987*	•
	Belt for fan		1	515986	
	Mounting bracket for ammet	e r	1	503147	
	Bolt (2 B.A. $x \frac{1}{2}'' \log$) \bigcap Fig.	king bracket	1	234603	
	Spring washer >to	dash	1	307 3	
	Nut (2 B.A.) bo	ttom rail	1	2247	
	Bolt (\frac{1}{4}" U.N.F. x \frac{1}{2}" long)	Fixing	1	255204	
	Plain washer	bracket ·	1	3840	
	Spring washer	to dash	1	3074	
	Nut (¼" U.N.F.)	centre panel	1	254810	
	Ammeter 60-0-60 (CAV Y 55	539/233/E)	.1	500907	
	Dash harness, LU 54944702		1	512385	
	Feed lead, ammeter to fuse b	ox	1	514934	Required when roof lamp is fitted
	Lead for engine thermostat		1	279517	
	Lead for oil pressure switch		1	279518	
	Relay (LU 340950 SB 60)		1	2665 10	
-	Drive screw \(\) Fixing		2	78417	
	Shakeproof washer \int to das	h .	2	311373	
	Cover for relay, LU 340931		1	266509	
	Clip for generator leads, LU	187052	4	50639	
	Screw (2 B.A. $x \frac{1}{2}$ long)		4	77869	•
		ixing clips to	4	3816	*
		H. wing valance	4	3073	
	Nut (2 B.A.)		4	3823	


A.C./D.C. GENERATOR, 12 VOLT, 21/4 LITRE PETROL, Series II



A.C./D.C. GENERATOR, 12 VOLT, $2\frac{1}{4}$ LITRE PETROL, Series II

TE F.		Qty.	Part No.	REMARKS
	Voltage regulator box, transistorised, LU 372991	3	-	
	2 TR	. 1	507172	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long) \int Fixing	3	255006	
	Shakeproof washer regulator box to	3	70884	
	Nut (½" U.N.F.) mounting plate	3	254800	
	Plug for warning light hole	1	513193	
	Blanking plate for redundant ammeter hole	. 1	520098	
	Clip for generator leads at dash	1	233770	
	Clip for harness at steering box blanking plate,			
	LU 187079	1	50639	
	Screw (2 B.A. x \(\frac{5}{8}''\) long)	1	75940	
	Plain washer Fixing clip to	1	3816	
	Spring washer blanking plate	i	3073	
	Nut (2 B.A.)	i	3823	
	Cleat, generator leads to horn lead, LU 941834	i	240429	
	Cleat for harness at control box mounting plate		240431	
	Grommet for ammeter leads in glove box	1	233243	
1	BATTERY CHARGING CONVERSION KIT	. 1	4334 4 3	
		,	E231E4*	M . 1 1 1 2 2 2 20 10 10 10
	12 VOLT A.C./D.C. GENERATOR	. 1	22Z120 *	Must be used in conjunction with 12 volt
			600007	A.C./D.C. Generator
	Ammeter	. !	500907	
	Panel assembly for ammeter	.	530012	
	Name plate, "Vehicle" amps	. 1	508493	
	Name plate, "Radio" amps	. !	508499	
	Terminal bracket assembly	. 1	528968	
	Bolt (10 U.N.F. $x \frac{1}{2}$ long) Fixing terminal	6	257017	
	Spring washer bracket to	6	3073	
	Nut (10 U.N.F.) \(\) L.H. rear body	6	257023	
	Grommet, in body for relay cable	. 1	276053	
	Relay 7 RA	. 1	519979	•
	Insulating base for relay	. 1	528959	
	Bracket for relay	. 1	528957	
	Drive screw \(\rightarrow\) Fixing relay and	1	72628	
	Fan disc washer ∫ bracket to dash	1	510170	
	Drive screw fixing relay bracket to dash	. 2	78417	
	Bolt $(\frac{1}{4}$ " U.N.F. $\times \frac{1}{2}$ " long) \bigcap For	1	255204	
	Shakeproof washer relay bottom	1	70884	
	Nut (‡" U.N.F.) fixing	1	254810	
	Cable assembly, auxiliary ammeter to junction	1	- F	
	box	. 1	531643*	
	Cable assembly, auxiliary ammeter to 7 RA relay	, 1	528953*	
	Cable assembly, junction box to earth	1	528987*	
	Cable assembly, SB60 relay to 7 RA relay	1	528955*	
	C 11 11 7 D 4 1		528956*	
	0.11 11		531637*	
	Cable assembly, ammeter to 7 RA relay		531636*	
	Polystrip, fixing relay to cable and main harnes		531642*	
	Clip, fixing cable, ammeter to junction box		56667	
	Screw (2 B.A. $x \frac{1}{2}$ long)	3	77869	
	Spring washer Fixing clips to bod		3073	
	Nut (2 B.A.) Drive screw, fixing clips to chassis	3	3823	
		. 3	78436	


EIGHT-BLADED FAN AND ENGINE TIE-ROD, $2\frac{1}{4}$ LITRE PETROL



EIGHT-BLADED FAN AND ENGINE TIE-ROD, $\mathbf{2}_{4}^{1}$ LITRE PETROL

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
	EIGHT-BLADED FAN AND ENGINE TIE-			
	ROD ASSEMBLY	1	525205 Series II models	
	EIGHT-BLADED FAN AND ENGINE TIE-			
	ROD ASSEMBLY	1	531881* Series IIA models	
1	Fan complete	1	507845 Series II models	
	Fan complete	i	530511* Series IIA models	
2	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long) \int Fixing	4	255006	
3	Spring washer \int fan	4	3074	
4	Fan pulley	1	503039 Series II models	
	Fan pulley	1	530304* Series IIA models	
5	Dynamo pulley	1	501019 Series II models	
	Dynamo pulley	1	530132* Series IIA models	
6	Lock washer for dynamo pulley	1	217781	
7	Crankshaft pulley	1	278543 Series II models	
	Crankshaft pulley	1	530130* Series IIA models	
8	Lock washer for starting dog	1	247771	
9	Fan belt, pair	1	503041 Series II models	
	Fan belt, pair	1	530303* Series IIA models	
10	Bracket for tie rod at bell housing	1	504605	
11	Bolt (16" U.N.F. x 1" long)	2	255228	
12	Spring washer Fixing bracket	2.	30 7 5	
13	Nut $\left(\frac{5}{18}^{"}$ U.N.F.)	2	254801	
14	Tie-rod for engine	. 1	504606	
15	Sleeve for engine tie-rod	2	504607	
16	Rubber bush	4	07014	
17	Cup washer Fixing tie-rod	4	07015	
18	Nut (5 U.N.F.)	4	254801	
19	Locknut (5 U.N.F.)	. 4	254861	
20	Bracket for tie-rod at frame	. 1	508339	
21	Bolt (¾" U.N.F. x 3½" long)	1	256050	
22	Spring washer Fixing bracket	1	3076	
23	Nut (§" U.N.F.)	1	254812	

EIGHT-BLADED FAN AND ENGINE TIE-ROD, DIESEL



EIGHT-BLADED FAN AND ENGINE TIE-ROD, DIESEL

PLATE REF.	1 2 3 4 DES	CRIPTION	Qty.	Part No.	REMARKS
	EIGHT-BLADED FAN	AND ENGINE	TIE-		
	ROD ASSEMBLY		1	511871 2 litre models	
	EIGHT-BLADED FAN	AND ENGINE	ΓIE-		
	ROD ASSEMBLY		1	531877* 2½ litre models	
Ī	Fan complete		1	502723 2 litre models	
	Fan complete		1	523410* 2½ litre models	
2	Bolt (¾" U.N.F. x §" lo	ng) \ Fixing	4	255006	
3	Spring washer	∫fan	4	3074	
4	Fan pulley	****	1	502729 2 litre models	
	Fan pulley		1	530304* 2½ litre models	
5	Dynamo pulley	••••	1	277686 2 litre models	
	Dynamo pulley		1	530132* 2½ litre models	
6	Lock washer for dynam	o pulley	1	03748	
7	Vibration damper		1	500199 2 litre models	
	Vibration damper		1	530305* 2½ litre models	
8	Lock washer for startin	g dog	1	247771	
9	Fan belt, pair	••••	1	512501* 2 litre models	
	Fan belt, pair		1	530303* 2½ litre models	
10	Bracket for tie rod at be		1	504605	
11	Bolt (16" U.N.F. x 1" l		2	255228	
12	Spring washer	bracket to	2	3075	
13	Nut (# U.N.F.)	bell housing	, 2	254801	
14	Tie rod for engine]	504606	
15	Sleeve for engine tie ro	d	2	504607	
16	Rubber bush	1_	4	07014	
17	Cup washer	For	4	07015	
18	Nut (#" U.N.F.)	tie rod	4	254801	
19	Locknut (16" U.N.F.)		4	254861	
20	Bracket for tie rod at ch		!	508339	
21	Bolt (\frac{3}{3}" U.N.F. x 3\frac{1}{2}" le	-	ļ	256050	
22 23	Spring washer	bracket to	 1	3076	
23	Nut (§" U.N.F.)	J chassis	1	254812	

ΓE F.	1234	DESC	RIPTIO	DN	Q	ty.	Part No.	. REMARKS
	Cylinder liner, sl	naped		****		4	246762	2 litre Petrol
	Cylinder liner	• • • • • • • • • • • • • • • • • • • •		••••		4	503160	$2\frac{1}{4}$ litre Petrol and $2\frac{1}{4}$ litre Diesel
	Wedge block for	re-boring	****			1	261287	2 litre Petrol
	Immersion heater)	
		****				1	511302 }	Diesel and 2½ litre Petrol
	Immersion heater	r for cylind	ler block,	, 100-125	volts,		j	
	400 watt					1	511303	
	Thermostat, open	ns at 90°C				1	516853	21/4 litre Petrol, North America 1958-60
	THERMOSTAT	COMPL	ETE A	SSEMBL	Υ)	
	(Opens at 1	65°F)		****		1	525588	
	Thermostat					1	522651	Diesel and 2½ litre Petrol
	Joint washer	for thermo	stat			1	522923	Note: When fitting to Diesel models, Part I
	Joint washer, o	outlet pipe	to hous	ing		1	522872	525590, water temperature and oil pr
	Water outlet p			••••		1	522870	sure gauge, must also be supplied.
	Sealing washer					1	503922	
	Carburetter st			iter eleme	nt	1	527280	
	Cable, green				1	-	357072	
	Cable, white/b				3			Conversion kit for Land-Rover 21 litre petrol
	Cable, white/b				6		527328	models, to fit starter unit with heater
	4 B.A. eyelet		••••			1	527270	element to prevent icing-up of the car-
	2 B.A. eyelet			••••		1	527271	buretter
	Snap-in conne			••••		3	3632	
	Snap connecto			••••	••••	ī	3549	
	Lucar connect					i	510697	
	Lucar sleeve			•		i	260345	
	Cleat			••••	••••	4	240429	
			*				· · · · · ·	·
	Rubber gromme	t set for p	ropeller s	shaft splir	nes	1	276484	
	Gaiter set for fro	ont axle sw	rivel hou	sing		1	276954	•
	Rubber tube for	bleeding l	brakes	•···		1	2618 44	

MISCELLANEOUS	Or	TIONAL	EQUII	MENI
PLATE 1 2 3 4 DESCRIPTION	Qty.	Part No.		REMARKS
MUDSHIELD ASSEMBLY FOR FRON	Ī			
	1	528162* ~)	
Mudshield	4	508863	İ	
Rivet fixing mudshield to anchor plate	40	2910		
Joint washer for driving member	4	231505		·
Locker	4	217353	≻88	
Oil seal > For front and rear hubs	4	501412		
Split pin	4	2428		
Locker for front hub	6	277311	ì	
Locking plate for trailing shoe anchor	4	236995	ļ	
MUDSHIELD ASSEMBLY FOR FRONT	Γ	_	•	
AND REAR BRAKE	1	528163* `	ì	
Mudshield	4	277144	İ	
Rivet fixing mudshield to brake anchor plate	40	2910		
	4	231505	≻109	•
Locker	4	217353		
Oil seal For front and rear hubs	4	501412		
Split pin J	4	2428		
Locker for front hub	6	277311		•
Front spring, passenger's side	1	242863)
Front spring, driver's side	1	241283	88	
Main leaf for front spring	. 2	I	≻2 litre	
Second leaf for front spring		243126	Petrol	
Dowel for front spring	_	243131	I CHOI	
Rear spring, passenger's side	· -	265989		
Rear spring, driver's side	- 1	241285		
Main leaf for rear spring	2	243127	88	
Second leaf for rear spring	^	243128	2 litre	
Dowel for rear spring		į.	and	Heavy duty road springs and shock
"U" bolt for R.H. rear spring	1	531081*	2½ litre	> absorbers.
Shock absorber, front	2	512102	Petrol	Must be fitted in complete sets when
Shock absorber, rear	2	512086	- 60001	replacing standard equipment.
Rear spring, driver's side	. 1	241285		replacing standard equipment.
Rear spring, passenger's side	. 1	265989		
Main leaf for rear spring	2	243127		
Second leaf for rear spring	2		-88	
Dowel for rear spring	2	243132	Diesel	
"U" bolt for R.H. rear spring	1	531081*	10000	
Shock absorber, front	2	512102		
Shock absorber, rear	-	512086		
Rear spring, driver's side	1	272967		
Rear spring, passenger's side	1	,	-109	
Shock absorber, front	2	508033		
Shock absorber, rear	2	508034		
		, ,	,	

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
	TRAILER PLUG AND SOCKET ASSEMB	LY 1	502501
	Trailer socket and leads on vehicle	1	510081
	Trailer plug and leads on trailer, LU 82056A	i 1	500669
	Dummy socket on rear cross-member, 5-way		501270
	Bracket for dummy socket	1	273276
	Drive screw fixing bracket to cross-member	2	72628
	Grommet in rear cross-member for lead	1	77918
	Flasher plug and lead	1	510127
	Tail light bridge lead, LU 54940524	1	500695
	Snap connector	3	3549
	Earth clip	2	236366
	Skid chains, set	1	262247 6" tyres only
	Wheel brace, divided rim wheels	1	237421
	Undershield assembly	1	246543
	Rivnut $\binom{5}{16}$ "U.N.F.) fixing shield to chassis	4	501224
	Undershield support bracket	2	504616
	Set bolt (5 U.N.F. x 1 long) Fixing branch		255228
	Plain washer to underside		2223
	Spring washer J side-memb		3075
	Clamping plate	1	238707 Swiss 109 vehicles only
	Special bolt $(\frac{5}{16}"$ U.N.F.) Clamp fixing	3	252084
	Spring washer front end to	3	3075
	Nut (5/16" U.N.F.) No. 4 cross-meml		254801
	Set bolt (5" U.N.F. x 1" long)	4	255228
	Plain washer	4	2550
	Spring washer	4	3075
	Nut (1/8" U.N.F.)	4	25 48 11.J
	Front mudflap kit	1	332962
	Front mudflap	2	
	Support bracket for L.H. mudflap	!	508392
	Support bracket for R.H. mudflap	I	508393
	Strengthening strip for front mudflap	2	278964
	Rivet Fixing mudflap and	8	
	Boss cap strengthening strip to support	8	78429
	Rear mudflap kit	1	332963
	Rear mudflap	2	
	Strengthening strip for rear mudflap]	1
	Rivet Fixing	8	
	Boss cap strengthening strip	8	66299 Except 109 Station Wagon
	Mudflap retainer, R.H	1	332960
	Mudflap retainer, L.H	1	332961
	Bolt (2 B.A. $x \frac{1}{2}'' \text{ long}$) Fixing	6	
	Spring washer > mudflap	6	
	Nut (2 B.A.) J retainers	6	5 3823J

	MISCL	PERMITOR	, 01	LICITE	LQCH MENT	
PLATE REF.	1 2 3 4 DESCRIPTION	N	Qty.	Part No.	REMAR	KS
	Rubber pad for brake and clutc	h pedals	2	278166	•	
	Chaff guard for radiator		1	332440		
	AIR CLEANER, CENTRIF	UGAL INTAK	E			
	TYPE AT WINDSO		_ 1	517057	-)
	Air cleaner support and batte		1	517869		1
	Packing piece, air cleaner		1	509510		
	Air cleaner		1	509482		
	Air intake elbow	****	1	509476		
	Set bolt (1" UNF x 5" long))	3	255206		
	Plain washer	Fixing elbow to	0 3	3665		
	Spring washer	wing panel out		3074		
	Nut (1" UNF)]	3	254800		
	Connection hose, intake elboy	v to cleaner	1	279519		
	Clip, elbow to connection		1	279653		
	Clip, connection to air cleane	r	1	517585		
	Air intake pipe		1	509481		
	Bracket for intake pipe		1	517868		
	Bolt (2 B.A. x ¾ long) Fix	ing	2	237119		
	Spring washer >bra	cket to	2	3073		>21 litre petrol
	Nut (2 B.A.) jint	ake pipe	2	2247		models
	Drive screw, pipe to windscre	en	2	7 2626		
	Hose, intake pipe to elbow		1	276426		
	Clip for hose	****	2	271870		
	Centrifugal air cleaner	••••	1	509483		
	Hose, centrifugal cleaner to in	ıtake	1	276426		
	Clip for hose	****	2	271870		
	ENGINE BREATHER SYST	EM, OIL BATI	-1			
	TYPE		1	517055	Must be used in conjunction with 517057	
	Carburetter elbow		1	512897		
	Side cover and oil filler pipe		1	516399		
	Oil bath breather and filler ca	p	1	512896		
	Top rocker cover breather		1	512891		
	Hose elbow to breather		1	2 69274		
	Clip for hose	****	2	50302		J
	Locking hasp for fuel filler		1	504697		•
	Screw fixing hasp (2 B.A. x ½" l	ong)	2	77869		

1234

					OI.	LIONAL	EQUIPIVI	
PLATE REF.	1 2 3 4	DESCI	RIPTION	1	Qty.	Part No.		REMARKS
	Speedometer, w	ith trip, M.I	P.H., SM	SN 5328/00) [240426`\	00	
	Speedometer, w	-		•		240427	88	
	Speedometer, w					2703425	100	
	Speedometer, w	-		-		279343	109	
	Speedometer, no	_		•		279340	88	
	Speedometer, no	-		•	i			o" tyres are fitted.
	DP COLUMN TO THE PARTY OF THE P	p,	, 2.,, 2		•	277511)	When 1.50 k it	tyres are netect.
	'Hourmeter', SN	M ATFC 2	68/1		. 1	521027*	Instrument for c	alculating running time
	Mounting brack	et for gauge	R.H.	••••	. 1	529443* 1		n additional instrument is fitted to
	WINDSCREEN	N WIPER A	ASSEMBI	LY	. 1	502830)
	Windscreen w		****	•••	1	277931		
	Arm for wipe	_			 1	261503		
	Blade for arm		••••		i	272306		<u>.</u>
	Grommet)		****		 1		1958-60	
	Grommet				1		1961 onwards	Series II models
	Cable clip, fe		ach.		i	240406	1701 Oliwards	Series II models
	Socket for wi		1371	••••		233531		
	Cap for socke	-		,.	!	240408		
	Feed lead, gar		 - 111952	 በ20	1	240408		
	Wiper motor			020	. !			
	WINDSCREEN				I 1	233533		.
					. 1	531947*		
	Windscreen w		••••		I	519900*		
	Arm for wipe			****		261503		
	Blade for arm			••••	!	272306	Series IIA mo	odels
	Feed lead for	_			. ا	526432*		
	Earth lead for				I	519899*	ļ	,
	Grommet for			••••	4	236389		
	Cable clip, fe	ed lead to de	ash	••••	1	240406	J	
	WINDSCREEN	N WASHER	R KIT		1	526358		
	Pump for scre	een washer			1	526426		
	Reservoir for		er		. 1	526427		
	Bracket, reser				. 1	526428		
	Bolt (2 B.A. 2		Fixing	•	4	234603		
	Spring washe		>reservoir		4	3073		
	Plain washer	·	bracket t		4	2678		
	Nut (2 B.A.)	1	dash	•	4	2247		
	Screen washe	ر r iet	44011		2	526429		
	Tubing for je	•	reservoir	101 ft lon		526353		
	Clip for tube				ັ່າ	526354		
	Clip for jet or				2	526355		
	Tee junction	_	****		1	526430		
	Clip for tubir	_	••••		0	519602		
	Drive screw	ig on dasn	`	•••	6	77704		
	Screw (4 B.A	- 5" l\	Cinina .	L:	_			
	Spring washe		Fixing to	_	2	77902		
		ı	clips to	casn	2	3072		
	Nut (4 B.A.)	1.1.6	Į.		2	4023		
	Grommet in				3	236389		
	Bracket for so				Į	526357		
	Screw (2 B.A		1		!	77869		
	Screw (2 B.A		Fixing	1 .	Ĭ	79941		
	Spring washe	r	>pump b		2	3073		
	Plain washer		to dash		2	3816		
	Nut (2 B.A.)		<u> </u>		2	2247		

		MIDCI	FLEAMEOOD	OI	HOINA	L EQUITIMEN	<u> </u>
ATE EF.	1 2 3 4	DESCRIPTION		Qty.	Part No.		REMARKS
	Suppressor, coi	l dynamo, pum	p and wiper motor	r 4	50693		
		iper motor, LU		1	243380		
	Cap for suppre	ssor on wiper m	notor	1	278420		
	Drive screw			t	78155		
	Plain washer	>		1	3851		
	Bolt (2 B.A. x			1	234603		
	Plain washer	- 1	ng coil	1	3851	Radio interference :	suppressors, 2 litre Petrol
	Shakeproof was		pressor	i	74236		-
	Nut (2 B.A.)	nici Jupi	pressor	 1	2247		•
		tributor lead		i	213646		
		nel pump and co		2	232990		
				Z	232991		
	lerminal for a	ynamo, LU 189		'	434,771)		
	RADIO SUPE	RESSOR KIT	•	1	332991		
			and wiper motor	3	50693		
		enser on wiper		1		≻Series II, 2‡ litre P	etrol models
	=	Fixing wiper		i	514416	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
		suppressor t		1	3851		
		RESSOR KIT		1	531951 *	<u> </u>	-
				2	50693	1	•
		or coil and wipe			531539 *		
	Suppressor f	-		1	278420	,	ra Patral madala
		ressor on wiper		!		Series IIA, 2½ lit	re retroi models
	Drive screw	> -	per suppressor	1	514416		
	Plain washer			į	3851		
		oil suppressor le		!	510119	J	
		RESSOR KIT		!	332992		
		or dynamo and		2	50693		
	Cap for cond	lenser on wiper	motor	1		≻Series II, 2 litre Di	esel models
	Drive screw	→ Fixing wipe	r	-1	51 44 16		
	Plain washer	∫ suppressor t	o screen	1	3851	_	
	RADIO SUPP	RESSOR KIT		1	531949	٠.)	
	Suppressor f	or wiper motor		1	50693		
	Suppressor 1	or dynamo		1	5315394	x	
		oressor on wiper	r motor	1	278420	≻Series IIA, 2½ lit	re Diesel models
	-	\ Fixing wipe		1	514416		
		to windscre		1	3851	J	•
		-					
			R SPARE WHEE		330971	88 No locking de	evice
			R SPARE WHEE		330972	109)	
			R SPARE WHEE		332971	88 With locking	device
	SUPPORT AS	SEMBLY FOR	R SPARE WHEE	L 1	332972	ַ נעטו	
	Support for	spare wheel on	bonnet	1	330600	No locking device	
	Support for	spare wheel	on bonnet, welde	d			
	dowel			1	332700	88 and 109 with	
						locking device	<u> </u>
	Support for	spare wheel o	on bonnet, screwe	d		_	
	dowel		.,	1	333458		
	Dowel for lo			1	333459		88 and 109. When fitting spar
	Screw (1" U	N.F. x % long))] Fixing	2	255208	≻With locking	wheel to 109 models, bonne
	Plain washer		≻dowel to	2	3840	device	330812, and bracket, 33064
	Spring wash		spare wheel	2	3074	1	must also be supplied.
	Rivnut (½" U		support	2	514929	J	
	Rivet fixing		-	9	300783		j
	Clamp for s			2			İ
	•	for spare wheel		2	307234		
	Split pin for		· ~········· ·	2	3707		i
	Phur bin ior	DOIL		2			<u>/</u>

	MISCI	LLLANEOUS	UP	HONA	L EQUIPMENT	
PLATE REF.	1 2 3 4 DESCRIPT	ION	Qty.	Part No	o. REMARK	S
	Rubber support block for sp	are wheel	4	304434		
	Special screw for support		8	77869		
	Plain washer, small		8		>88, also 109 without locking device	
	Plain washer, large	Fixing supports	8	3987	, 60, 600	
	Spring washer	to bonnet top	8	3073		
	Nut (2 B.A.)		8	2247		
				,		
	BONNET LOCKING DEVI		1	332969	De luxe bonnet	
	BONNET LOCKING DEVI	CE COMPLETE	1	332970	Plain bonnet	
	Hasp for bonnet locking		1	332614	De luxe bonnet	
	Hasp for bonnet locking		1	332611	Plain bonnet	
	Pop rivet \ Fixing hasp		2	300781		
	Pop rivet ∫ to bonnet		2	300783		•
	Turnbuckle	****	1	300851		
	Screw (2 B.A. $\times \frac{1}{2}$ long) $\int I$	ixing	3	77784		
	Spring washer	urnbuckle to	3	3074		
	Nut (2 B.A.)	rille panel	3	2247		
	Wing mirror, 'boomerang' type	•	1	516495		
	wing mirror, boomerang type			JIUTS		
	LOCKING HANDLES AND	CATCHES			*	
	ASSEMBLY	• • • • • • • • • • • • • • • • • • • •	1	330974		1
	Door handle R.H. with lock	****	1	332432		1
	Barrel lock	****	1	306036		
	Locking pillar for catch		1	332434		
	Plain washer Fixing		1	2226		1
	Spring washer >catch		i	3073		ł
	Nut (2 B.A.) to cover		i	2247		1
	Safety catch for L.H. door lo	ck	i	333272	٦	\ ≻With
	Plain washer		i	4034	İ	barrel lock
	Screw (2 B.A. x §" long)		i	313860		
		ixing safety catch	i	3902	Models with pivot type catch.	on R.H. door
		L.H. door	i	3073	Check before ordering	K.1 I. GOOR
	Nut (2 B.A.)		2	2247	Check before ordering	l l
	Locknut (2 B.A.)		ī	25996		
	Safety catch for L.H. door lo	ck	i		Models with spring loaded type catch	
	Catch for door sliding windo	и	2	332435	wioders with spring loaded type catch	ĺ
	Pop rivet fixing catch		4	300781		
	LOCKING HANDLES AND	CATCHES	7	200701	=	₹
	ASSEMBLY, L.H.		1	332007		1
	Door handle, L.H. with lo	 ~L	1	332997		
	Barrel lock		1	332317		
	I - 12. 11 f . 1		1	332999		
	Plain washer	****	1	332434		
		atch to cover	1	2226		1
	Nut (2 B.A.)	aten to cover	i	3073		
	Safety catch for R.H. door lo	ale	1	2247		197.
	Plain washer	ск	1	333271		With
			1	4034		barrel lock
	Screw (2 B.A. x 5 long)		1	313860	36.11	on
		ixing safety catch	1		Models with pivot type catch.	L.H. door
		R.H. door	1		Check before ordering	}
	Nut (2 B.A.)		2	2247		
	Locknut (2 B.A.)	1	1	25996	** · · · · · · · · · · · · · · · · · ·	ļ
	Safety catch for R.H. door lo		Ì	334873*	Models with spring loaded type catch.	l
	Catch for door sliding window	v		332435]
	Pop rivet fixing catch		4	300781		<u> </u>
400	1004				· · · · · · · · · · · · · · · · · · ·	

	MSCEED HIZOUS		TOWN DOOR WENT
1011		Qty.	Part No. REMARKS
	ASSEMBLY FOR SIDE		
DOORS		2	515835)
SIDE STEP ASS	EMBLY	2	508947
Rubber mat)	2	508957 ≻4 off on 109 Station Wagon
Capping, rear	>For step	2	508958
Capping, front	İ	2	508959)
Capping, side]	4	245136 8 off on 109 Station Wagon
	and capping to step	28	4022 56 off on 109 Station Wagon
Step support brack		2	508950 4 off on 109 Station Wagon
Bolt (1" U.N.F. x 1	1" 1 \ \ \ \	8	255209)
Plain washer	rixing step	8	3900 ≻16 off on 109 Station Wagon
Spring washer	support bracket	8	3074
Nut (‡" U.N.F.)	to body sill	8	254810
•-	bracket (no fuel tank under		
seat)		2	508952 4 off on 109 Station Wagon
• • • • • • • • • • • • • • • • • • •	bracket (when fuel tank is	_	
fitted under seat)		1	509950
Bracket, for stay, to o		i	508953
Bolt (½" U.N.F. x	Fixing	•	
i' long)	bracket to stay	4	255208)
Spring washer	and stay to step	4	3074 ≻8 off on Station Wagon
Nut (\frac{1}{2}" U.N.F.)	support bracket	4	254810)
Bolt (‡" U.N.F. x	Fixing	•	2.0.09
3" long)	rear side step	4	255207
Spring washer	support stays and	4	3074 > 109 Station Wagon only
Nut (‡" U.N.F.)	brackets to chassis	4	254810
Bolt (‡" U.N.F. x	Fixing	•	2 0.00
1½" long)	>front side step	4	255211
Spring washer	support stays and	4	3074
Riv-nut (½" U.N.F.	,	4	514929
Hinge pin for step		2	509120 4 off on 109 Station Wagon
Plain washer	\	4	3833 8 off on 109 Station Wagon
Spring washer	Fixing hinge pin	2	2286 4 off on 109 Station Wagon
Split pin	Tixing imige pin	4	2395 8 off on 109 Station Wagon
Same to a second	,	2	264362)
D 11 .1 d .		2	304125
Screw (2 B.A. x 5"		2	77758
Plain washer, small		2	3867 ≻4 off on 109 Station Wagon
Plain washer, large	-	2	3816
Spring washer	to body panel	2	3073
Nut (2 B.A.)	to body paner	2	3823
Rubber buffer on s	J ton	2	312027) 4 off on
· ·	long) \ Fixing buffer to	2	77758 > 109 Station > Part of assembly 515835
Plain washer	underside of step	2	3867 Wagon
r mil washer) underside of step	2	John J. Wagon J.
Waist moulding, R.H	front door	1	332660)
Waist moulding, K.H		i	332661
Acme bolt	. front door	8	302533 For one-piece doors
1	ng mouldings to doors	8	2630 To one-piece doors
Spire nut	uk monumika to noots	8	302532
Spire nut		o	JOLIJE

		WIISCELLA	71500	<u> </u>	IIOMAL	EQUI MENT
ÎE.	1 2 3 4	DESCRIPTION		Qty.	Part No.	REMARKS
-		ASSEMBLY FOR	R DASH	[
	VENTS			1	332995	
	Fly screen for	dash vent, inner	••••	2	332402	
	Fly screen for	dash vent, outer		2	332403	
	Drive screw fix	ring screen to dash		20	77932	
	Fire extinguisher			1	501025	
	•	§" long) │ Fixing		5	75940	
	Spring washer	> bracket		5	3073	
	Nut (2 B.A.)) to dash		5	2247	
	Interior sun visor	complete assembly		2	332642	
	Exterior sun viso	r complete assembly	,	1	503979	
		for rear of driver,]	330990	
		for rear of driver, l	olue	1	330991	
	Hook	••••		2	301005	
	Buckle	****		2		For full length hood 88
	End cap		••••	2	300954	
	Eyelet	****		4	300785	
	Buckle	****	****	2	300953	
	Plastic backligh	nt		1	306340	·
	Roof luggage rac	k complete	****	1	320532 * A	Applicable to Station Wagons and Hard T
	Glass for rear end	d window		2	332341)	venicles
	Weather strip for		****	2		38 and 109 Hard Top, to convert early models
	Filler strip for we	-	••••	•	306289	o and 107 hard 10p, to convert early models
	The stip of we	camer surp	****	2	3002093	
	Bracket, cant rail		****	4	331168)	
		No. 6, fixing bracket	to cant ra	il 8	77704	
	Roof trim, front 1	portion		1	331491	
	Drive screw, ½" N	No. 6 Fixing		9	77704	
	Plain washer	>roof frame		5	3886	
	Plain washer) to bracket		4	3852	
	Centre bracket, c	anopy panel	****	1	331391	
	Outer bracket, ca			2		Canadian vehicles
	Canopy trim pan			1	331492	
	Canopy trim pan			1	331493	
	Plain washer	Fixing trim		4	3852	
		No. 6 to brackets	Lavor	4	77704	
		se, front and sides		1	331648	
	Cover for seat ba			I	331652	
		•		2	331655	
	CATAL TANK					
	Cover for tank/Io Cover for lower o		****	1	331658	

LATE REF.	1 2 3 4	DESCRI	TION	Qty.	Part No.	REMARKS
	Floor mat, front .			1	330992	R.H.D.
	Floor mat, front .			1	330993	L.H.D.
	Floor mat, rear body	y		1	330994	88
	Floor mat, rear body	<i>y</i>		1	330995	109
	Wrench for winch b	ollard scre	w	1	237255	Front winch
	ROVER BODY RE	PAIR KI	Т	1	314000	
	Demon welding b	lowpipe co	mplete with n	ozzles 1	314001	
	Rubber hose, red	·		1	314002	
	Rubber hose, blac	k		1	314003	
	Tubular container	for weldir	ng rod	2	314004	
	Birmabright weldi	ing rod, .08	30" x 23" long	100 sticks	13605	
	Birmabright weldi	ing rod, 12	25" x 23" long	50 sticks	13606	
	Sheets of coated B	Birmabrigh	t	12	13604	
	Welding flux .			2 tins	13607	
-	Filzall rods for fill	ling body p	oanels	100 sticks	13608	
	Electric paddle, 24	40v		1	314005)	
	Electric paddle, 1	10 v.		1	313998	Please state voltage when ordering
	Element for ele	ctric paddl	e, 240v.	1	314006	
	Element for ele	ctric paddl	e, 110v.	1	313999	
	Wooden paddle, s	mall		1	314007	
	Wooden paddle, n	nedium		1	314008	
	Wooden paddle, la	arge		1	314009	
	Lubricant for woo		e	1 tin	13609	•
	Steel wool .			2 rolls	99710	
	Glass paper, No. 3	2		6 sheets	97188	

OVERHAUL KITS

PLATE REF.	1234	DESC	RIPTIO	N	Qty	у.	Part No.	REMARKS
	Engine overhaul	_			1			2 litre Petrol
	Engine overhaul	gasket kit			1		501677	Series II 2½ litre Petrol models
	Engine overhaul	gasket kit			1		525856*	Series IIA 21 litre Petrol models
	Engine overhaul	gasket kit			1	1	272564	2 litre Diesel
	Engine overhaul	gasket kit			1	İ	525520*	2½ litre Diesel
	Gasket set, decar	bonising			1		269365	2 litre Petrol
	Gasket set, decar	bonising			1			Series II 2½ litre Petrol models
	Gasket set, decar	bonising	****		1			Series IIA 24 litre Petrol models
	Gasket set, decar	bonising			1			2 litre Diesel
	Gasket set, decar	-			1		525521*	2½ litre Diesel
	Brake wheel cylin	nder overh	aul kit, fr	ont	1		275744	88
	Brake wheel cylin				1			109
	Brake wheel cylin				1			88
	Brake wheel cylin					l		109 With steel dust cover 7 Series II models
	Brake wheel cyli							Alternatives.
	2103)	••••			1		523164	109 With rubber dust cover \int \text{Check before} \text{ordering}
	Brake wheel cylin	der overha	ul kit rea	r(CLS	SP2051) I		275744	109 Series IIA models
	Brake master cyli				1		502333 8	
	Brake master cyli				1		503754 10	
	Diano master cyn	nidel over	iddi Ait		••••		יו דכינכטכ	07
	Clutch master cy			• • • • •	1		276176	
	Clutch slave cylin	nder overh	aul kit		1		502335	
	Repair kit for ac	ljuster uni	t (transm	ission	brake)		1	From gearboxes numbered:
	GI SP 1856	• • • • • • • • • • • • • • • • • • • •			1		515924 >	146000566
	Repair kit for ex	pander uni	t (transm	nission			į	156000431
	GI SP 1807			****	1		515923	151005187 onwards
	White brake grea	se, tube	****		1		514577	
	Red brake rubber				1		514578	
		. 5. ozoo, su		****			31 1370	
	Repair kit for fue	l pump. A	C 152450	7	` 1		272069)	2½ litre Petrol and
	Overhaul kit for				1		524684	Diesel models
٠	Swivel pin overh	aul kit			1		266752	
	Water pump over	rhaul kit		****	1		265255	2 litre Petrol
	Water pump over		****	****	1			Series II 24 litre Petrol and 2 litre Diesel models
	Water pump over				1			Series IIA Petrol and Diesel models
	Carburetter overl	naul kit			1		266693	2 litre Petrol
	Carburetter overl				1			2½ litre Petrol
	Carburetter gaske				1			2 litre Petrol
	Carburetter gaske		• • • • • • • • • • • • • • • • • • • •		I			2 litre Petrol
	Baske	~ RIL		••••	1		JULUTJ	24 mg i cuoi

484



88 INTERIM STATION WAGON

GENERAL EXPLANATION

The Interim Station Wagon is mounted on a standard 88 chassis with a modified body. The majority of spare parts are, therefore, the same as those required for the basic vehicle.

The optional and additional equipment listed below is also required:-

Hard top with side windows (i)	See Pages 329 and 331			
Plain bonnet with spare whee		See Pages 295, 479 and 480			
Flasher equipment					See Pages 457 and 459
Half length doors and sidescre	eens				See Pages 299 to 303
Locking handles and security	catches	****			See Page 480
Rear seats					See Page 447
Extra driving mirror			****		See Page 295
Floor mats and fixing	****			****	See Page 365
Rear door complete					See Pages 495 to 499

. . .




88 STATION WAGON

GENERAL EXPLANATION


The Station Wagon is mounted on a standard 88 chassis with a modified body. The majority of spare parts are, therefore, the same as those required for the basic vehicle. The following pages 489 to 505 inclusive, list the parts which are peculiar to the Station Wagon.

The optional and additional equipment listed below is also required:-


De-luxe bonnet with spare wheel carri	ier		 See Pages 295, 479 and 480
Flasher equipment			 See Pages 457 and 459
Full length doors			 See Page 299
Locking handles and security catches		••••	 See Page 480
De-luxe trim for floors and doors			 See Page 365



		WAGON,	DODI	LAMELS	AND	мпирома
PLATE REF.	1 2 3 4 DESCRIP	TION	Qty.	Part No.		REMARKS
1	ROOF AND TROPICAL	ROOF PAN	EL			
	ASSEMBLY	****	1	332937		
2	Tropical roof panel		1	332194		·
•	Pop rivet \(\) Roof panel to		45	78248 Altern	native	
•	Drive screw stiffeners		45	77704 ∫ fixing		
	Screw (1" U.N.F. x 2" long))	10	78274		
	Plain washer	Fixing	20	3900		
3	Distance piece	>tropical	10	302372		
4	Rubber washer	roof panel	10	302373		
	Spring washer	to roof	10	3074		
	Nut (‡" U.N.F.)	and sides	10	254810		
		ixing tropical	8	77869		
		of panel to	16	3852		
5	Rubber washer	of at end	8	302371		
		stiffeners	8	71082		
	Nut (2 B.A.)		8	3823		
	Roof ventilator, rear	****	2	333836		
6	Roof ventilator, front		2	333835		
	Drive screw, fixing ventilator	to roof	36	77932		,
7	Side light for roof	****	2	308070		•
8	Weather strip for side light	••••	2	302177		
9	Filler strip for weather strip		2	302178		
	SIDE PANEL ASSEMBLY, I		1	332306		
	SIDE PANEL ASSEMBLY, I	L.H	1	332307		
П	Mounting bracket front	****	2	332080		
	Bolt $(\frac{5}{16}$ U.N.F. $\times \frac{5}{8}$ long)	Fixing	4	255225		
	Plain washer	mounting	4	3830		
	Spring washer	bracket	4	3075		
12	Nut plate	to body	2	332081		
	Support bracket at tailboard	••••	2	332052		
.*		Fixing	4	255207		
		support				
		bracket at	8	3840		
		tailboard	4	3074		
		corner	4	254810		
14	Capping for front door rear se]	332112		
14 15	Capping for front door rear se	al L.H.		332113		
13	Stud plate	1111	2	332065		
	Screw (2 B.A. $x \frac{1}{2}$ long)		6	78869		- '
		xing cappings	6	3852		
	and the same of th	side	8	3885		
		nels	14	3073		
16	Nut (2 B.A.)	1 1	14	3823		
10	Drain channel complete for sie Bolt (‡" U.N.F. x §" long)		2	332223		
		Fixing drain		255206		
		drain channel	4	4071 2074		
		cnannei to body	4 4	3074		
	1141 (4 0.14.1.)	to body	4	254810		



D/ 1	oo BIAHON WAGON,		FANELS AND WINDOWS
PLATE REF.		Qty.	Part No. REMARKS
17	Glass for side window, sliding	4.	332217
18	· · · · · · · · · · · · · · · · · · ·	2	332230
19	Channel for sliding light rubber	2	330661
20	Channel for sliding light—top	4	332744
	Channel for sliding light—bottom inner	2	332745
	Channel for sliding light—bottom outer	2	332752
21	Channel for sliding light—sides	4	332746
22	Packing strip for top channel	4	332216
	Drive screws fixing channels	76	77707
23	Catch for sliding glass, front, overall length	$1\frac{1}{2}$ " 2	332324
	Catch for sliding glass, rear, overall length 1		332325
24	Distance piece for catch	6	340390)
25	Washer for catch	8	340391 > 2 B.A. fixing. Alternative to \(\frac{1}{4}''\) U.N.F.
	Screw (2 B.A. x ¾ long)	2	78223 Check before ordering
26	Screw (2 B.A. x 7 long) Fixing	2	78260
	Washer for catch	16	340391
	Screw ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long)	2	78401 \\ \daggerup \dagger
	Screw (4" U.N.F. x 7" long)	2	78402 Check before ordering
27	Tapped plate for catch	4	332329 Sheek select ordering
28	Runner for sliding catch	4	330848
	Rivet fixing runner to drain channel	28	78248
29	Glass for rear end window	2	332200
	Retainer for rear end glass upper R.H.	1	332280
30	Retainer for rear end glass upper L.H.	1	332281
31	Retainer for rear end glass inner and outer	4	332282
32	Retainer for rear end glass lower L.H.	1	332284
	Retainer for rear end glass lower R.H.	1	332283
	Drive screw fixing retainer	36	78126
33	Seal for front door, upper side	2	332152
34	Seal at top and bottom for front door, up		
	side	6	332215
	Rivet fixing rubber to retainer	10	302818
35	Sealing rubber, lower edge to body	2	333487
36	Sealing rubber, roof to side	2	332154
	Retainer for front door seal top R.H	1	330788
37	Retainer for front door seal top L.H.	1	330789
38	Seal for front door top	2	330541
	Rivets, fixing door seal to retainer	10	302818
	Screws (2 B.A. x ½" long) Fixing	10	77869
	Spring washer >seal	10	3073
	Plain washer retainer	10	3902
	Nut (2 B.A.) to roof	10	3823
39	Rubber seal for canopy		330878
	Support bracket, centre, body side		332201
	Bolt (½" U.N.F. x ¾" long)) Fixing		255207
	Plain washer bracket to	6	3900
	Spring washer body side	4	3074
	Nut (‡" U.N.F.) and capping		254810
	>		



88 STATION WAGON, BODY PANELS AND WINDOWS

	00 517	11101	· WAGOII,	202		
PLATE REF.	1 2 3 4	DESCF	RIPTION	Qty.	Part No.	REMARKS
41	Mounting stud	<u> </u>		4	332157	
	Plain washer (large)	1		8	3898	
	Plain washer (small)	>Fixi	ng body at front	2	3830	
	Special washer	and	rear corners	2	332293	
	Spring washer	ĺ		8	3075	
	Nut (5 " U.N.F.)	j		8	254811	
	Bolt (1" U.N.F. x 5"	long)	Fixing	4	255206	
	Plain washer		body at	4	3840	
	Spring washer		rear inner	4	3074	
	Nut (‡" U.N.F.)		gusset	4	254810	
	Bolt (1" U.N.F. x 1"	long) ⁵	Fixing	10	255207	
	Plain washer		windscreen	20	3900	
	Spring washer		to cant	10	3074	·
	Nut (¼" U.N.F.)	_	rail	10	254810	
	Bolt $(\frac{1}{4}$ " x $\frac{3}{4}$ " long)	In roo	f for fixing	22	255207	
	Plain washer	≻at rear	corners,	22	3840	
	Spring washer	sides a	nd rear	22	3074	
	Nut $(\frac{5}{16}")$			22	254810	
42	"Station Wagon" na	me plate	e, front and rear	2	306407	
	Backing plate for nar	me plate	, front]	306408	
	Screw (2 B.A. $\times \frac{1}{2}$ le	ong)] l	Tixing	2	77700	·
	Plain washer	≻ 1	name plate	2	2260	
	Spring washer		o radiator	2	3073	
	Nut (2 B.A.)	_	grille	2	2247	•
	Pop rivet fixing name			. 2	300919	
	Rear corner protection]	333253	
	Rear corner protection	on angle	, L.H	l	333254	




PLATE REF.	1 2 3 4 DESCRIPTION)ty.	Part No.	. REMARKS
RE.F.	REAR DOOR COMPLETE ASSEMBLY		1	333415	
1	Rear door		i	333416	
2	Glass for rear door		1	333031	
3	Retainer for glass, vertical	••••	2	333033	
4	Retainer for glass, bottom		ī	333032	
5	Retainer for glass, top		1	333034	
6	Retainer for glass, corners		2	333035	
·	Drive screw fixing retainers		32	78140	
	DOOR LOCK, MOUNTING AND HAN				
	ASSEMBLY		1	333039	
7	Mounting plate for door lock		1	333080	
8	Door lock		1	333040	
9	Washer, handle to cover		1	302859	
10	Door handle with lock		1	332432	
11	Barrel lock		1	306036	
	Key for barrel lock		1	307289	State key number when ordering
12	Bracket for door handle		1	302854	
	Screw (2 B.A. $x \frac{1}{2}$ long)		6	313858	
	Spring washer Fixing lock		6	3073	•
	Plain washer together		4	3685	
	Nut (2 B.A.)		6	2247	
	Rivet		4	302222	
-	Special screw Fixing		4	78216	2 off when stud plate is fitted
13	Stud plate, door lock, bottom >door		1	332732	
	Spring washer lock		4	3074	
	Nut (½" U.N.F.)		4	254800	
	Drive screw, fixing lock assembly to door		2	77903	
. 14	Locking pillar for catch		1	332434	
	Plain washer		1	2226	
	Spring washer Fixing catch to pillar		1	3073	
	Nut (2 B.A.)		1	2247	
15	Waist rail lock handle protection strip		1	333037	
	Bolt (¼" x ¾" long)		2	255207	
	Spring washer Fixing strip to door		2	3074	0.
	Nut (‡" U.N.F.)		1	254800	
16	Wheel stud plate	****	1	333435	
17	Clamp plate for spare wheel stud plate		Ì	333446	
	Screw (1" U.N.F. x 1" long) Fixing stud		8	78210	
	Spring washer clamp plates	to	8	3074	
•0	Nut (4" U.N.F.) rear door		8	254810	
18	'U' bolt for spare wheel support	••••	1	333447 254814	
10	Nut (½" U.N.F.) fixing 'U' bolt to door	••••	4	333439	-
19	Retaining plate for spare wheel		i	JJJ 1 J7	
20	Hub nut fixing wheel and retaining plate to		6	217361	
	bolt	••••	1	333438	1958-59
	Male dovetail		1	332942	1960 onwards
	Screw (\frac{1}{2}" U.N.F. x 1" long) \frac{1}{2} Fixing		2	78389	1700 OITHALAS
	Spring washer Trixing Fixing Spring washer	1	2	3074	
	Nut (‡" U.N.F.) to door	•	2	254810	
22	Rod for check strap		1	333041	
23	Buffer for check strap, short		i	306295	
24	Buffer for check strap, long		i	333445	
		••••	-		

495




PLATE. REF.	1234 DEC	CDIDTION	Ob-		LAK DOOK	DEMADUS	
		CRIPTION	Qty.	Part No). 	REMARKS	
25	Hinge for rear door, up	-		333036			
26	Hinge for rear door, lov		1	330117			
	Bolt (1/16" U.N.F. x 2" lo		_	256226			
	Spring washer	≻to door	4	3075			
	Nut (5 U.N.F.)	∫ frame	4	254811			
	Bolt (18" U.N.F. x 7" long		4	255227			
	Plain washer	Fixing	4	3830			
	Spring washer	door hinges	4	3075			
	Nut (# U.N.F.)	∫ to body	4	254811			
	Bolt (1" U.N.F. x 11" long		ļ	255251			
	Spring washer	Fixing	ļ	3074			
	Plain washer, thick	check strap	2	4075			
	Plain washer, thin	rod to floor	2	3947			
27	Nut (1" U.N.F.)	J	2	254810			
27	Striking plate			333140	•		
	Bolt (‡" U.N.F. x 1" long)		2	255009			
	Plain washer	striking	As required				
	Spring washer	plate to	2	3074			
	Nut (½" U.N.F.)	rear of body	2	254800	1050 50		
20	Female dovetail For re		l l	333440	1958-59		
28	Female dovetail for boo	ly		332147	1960 onwards		
20	Spacer For female		1	333444	1958-59		
29	Spacer Sdovetail	\ C : 1 . 1	- 1	332943	1960 onwards		
	Screw ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " lo	ong) fixing dovetail		70222			
	spacer	17	2	78233			
	Screw (‡" U.N.F. x ‡" lon Plain washer	·	2	255207			
30	Shim	Fixing spacer to		3900			
<i>J</i> 0		L.H. rear pillar		305232 3074			
31	Spring washer Seal for door sides	J	2				
32	Seal for door side, L.H. be		3	330535 332563			
33	End filler piece for seals		4	330850			
,	Rivet fixing seals to body	****	21	302818			
34	Rubber seal, door, bottom		22	332564			
35	Seal retainer, door bottom		1	332566		•	
	Drive screw fixing retainer		7	77707			
36	Seal for rear door, top	••••	/	332149			
-	Rivet fixing seal		11	302818			
37	Retainer for rear door seal	ton	1	332151			
	Screw (2 B.A. x ½" long)	, top	9	77869			
	Plain washer	Fixing retainers	ý	3902			
	Spring washer	to roof panel	9	3073			
	Nut (2 B.A.)		9	3823			
38	REAR STEP COMPLET	TE	Í	501053			
39	Rubber mat for step	••••	1	245137			
40	Retainer for rear step, si		2	245136			
41	Retainer for rear step m		1	245135	4		
42	Retainer for rear step m		1	245134	No. 1		
	Rivets fixing mat end ca		16	4022	•		
43	Hinge centre for rear step		2	245131			
	Bolt (%" U.N.F. x 4" long)	Fixing hinge cen	tre 2	256253			*
	Locknut (§ U.N.F.)	fo rear step	4	254852			
		_					




PLATE REF.	1 2 3 4 DESCRIPTI	ON	Qty.	Part No.	REMARKS
	Bolt (%" U.N.F. x 18" long))	2	255048	
	Bolt (3" U.N.F. x 7" long)	Fixing hinge	2	255046	
	Locker	centre to	2	235731	•
	Plain washer	rear cross	2	2251	
	Packing washer	member	2	500588	
	Shakeproof washer Fixing	hinge centre	2	73352	
	Self-locking nut >to rear	cross	2	252212	
	(∛g" U.N.F.) ∫ memb	er			
44	Spring for rear step		2	264362	
45			1	304125	
	Plain washer \ Fixing buffer	to	1	3867	
	Drive screw frear cross me	mber	1	78142	,




PLATE	1 2 2 4	DESCRIPTION	<u></u>	Part No.	REMARKS
PLATE REF.	1234		Qty.		REWIARAS
I	Rear seat backrest o		4	331149	
2	Pad for rear seat l		4	304054	
	Bolt (1" U.N.F. x 12		20	255204	·
	Set bolt (4" U.N.F.		4	255208	
	Plain washer	backrests	24	3912	
	Spring washer	to supports		3074	
3	Support for backres		4	331291	
	Support for backres		4	331292	
	Bolt (1" U.N.F. x 8		6	255206	
	Plain washer, small	.		3912	
	Plain washer, large	support to	6	3842	
	Spring washer	body capping	6	3074	·
4	Rear seat cushion co		4	331148	·
5	Rubber interior fo	or seat cushion	4	303809	
6		**** **** ****	4	306316	
7	Fastener stud		4	243618	
÷	Plain washer		4	3557	
	• •	ixing stud	4	3073	
	Nut (2 B.A.)		4	2247	
8	Rubber buffer for re		4	312028	
	Woodscrew \ Fixin		8	20034	
	Cup washer ∫ seat		8	73962	
9	Front finishers for r		4	307418	
10	Side finishers for re		4	307419	
11	Side finishers for re		4	307420	
	Woodscrew ∫Fixir	_	8	20138	
	Woodscrew ∫ front		16	20147	
12		mplete for seat cushion	4	306326	
	Special nut \ Fixing		4	313484	
	Special bolt ∫ strap		4	78296	•
	Cushion pivot brack		8	331122	
14	Support tube bearing		8	306199	
15	Support tube	∫ cushion	4	306200	
		(" long) Fixing cushion		255208	
		$\frac{1}{4}'' \log$ >ot bracket and		256201	
	Plain washer	_		3912	
-	Spring washer	to seat cushion	1 32	3074	•
		J frame	**	055001	
	Bolt (1 x 5 long)	Fixing cushion	28	255206	
	Plain washer	>pivot bracket	28	3900	
	Spring washer	to wheelarch box	28	3074	
	Nut (‡" U.N.F.)	J.,	28	254810	
	Packing block for re			332985	Alternatives.
	Mounting pad for 1]	308461	Suitable for Lucas type lamp only Check
	Mounting pad for r	roof lamp	1	334111	Suitable for Lucas and Sparto type before before ordering
	Roof lamp complete	ie	1	265295	Lucas Alternative types.
	Roof lamp complete		1	514900	Sparto Check before ordering
	Bulb for roof lan		1	264591	, , , , , , , , , , , , , , , , , , ,
	Drive screw, fixing		2		Alternatives.
		lamps and mounting pac	l 2		Check before ordering





PLATE REF.	1 2 3 4 DESCRIPTIO	N	Ç	ty.	Part No.	REMA	RKS
	Lead for roof lamp, LU. 861618	****		i	245386	Alternative to two lines belo Check before ordering	w
	Lead for roof lamp, roof portion			1	265482	_	
	Lead for roof lamp, chassis portion			1	265481	Series II models	
	Lead for roof lamp, chassis portion			1	519876	Series IIA models	
	Grommet for roof lamp lead			1	312856		
	Grommet for lead, LU. 859341	••••	••••	2	233244		•
	Cable clip \(\) Fixing roof			2	41379		
	Drive screw lamp lead			2	78155		40°
	Fuse box, LU./SF5/237131			1	219078		**** 1
	Special screw, LU. 153564 \ For			2	3279 \	Series II models	· 12
	Special nut, LU. 167530 fuse b	ЭX		2.	3280		
16	Interior mirror		****	1	334000		
	Drive screw fixing mirror		,:	2	7778 9		<u> </u>
17	Rubber mat for rear body floor			1	331401		
18	Protection strip for floor mat	****		1	332565		·. ·
	Drive screw fixing protection strip		••••	7	77707	•	

88 STATION WAGON TRIM



88 STATION WAGON TRIM

PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
1	Roof trim, front portion	1	331491	
2	Bracket, cant rail to roof frame	4	331168	
	Drive screw (1/2 No. 6) fixing bracket to cant:	rail 8	77704	•
	Drive screw (½" No. 6) Fixing	9	77704	
	Plain washer, rear > roof frame	5	3886	
	Plain washer, front to bracket	4	3852	
3	Centre bracket, canopy panel	1	331391	
4	Outer bracket, canopy panel	2	331390	
5	Canopy trim panel R.H	1	331492	
6	Canopy trim panel L.H.	1	331493	
	Plain washer \(\bigcap \) Fixing trim panel	4	3852	
	Drive screw ($\frac{1}{2}$ " No. 6) \int to brackets	4	77704	
7	Head cloth, rear portion	1	331508	
8	Fixing strip, head cloth, front and rear	2	331203	
	Drive screw (½" No. 6) Fixing	6	77704	
	Plain washer	6	3886	
	Retainer for roof trim	4	332240	·
	Spire nut Fixing retainer to ve		314394	
^	Drive screw	24	77932	
9	Side rail, head cloth, rear portion	2	331196	
	Plain washer Fixing	2	3925	
	Drive screw (½" No. 6) \int side panel	2	77704	
	Bolt (10 U.N.F. x 3 long) Fixing	2	257015	
	Plain washer side panel to	2	3902	
10	Nut (10 U.N.F.) roof at rear	2	257023	
10	Fixing bracket, R.H., sidelight casing, front	3	331192	
11	Fixing bracket, L.H., sidelight casing, front	3	331193	
11	Sidelight casing, trimmed R.H. front	, I	331186	
	Sidelight casing, trimmed L.H. front	[331187	
	Drive screw Fixing casing Plain washer to bracket	6	77704	
12	Sidelight casing, trimmed R.H. rear	6	3886 331179	
12	C*11'1. * . * 11 TT	I	331180	
	Drive screw (½" No. 6) Fixing casing	2	77704	
	Plain washer to panel	2	3886	
13	Roll trim for cant rail, R.H.	1	331497	
•	Poll tring for some trail I II	1	331498	
	Drive screw (½" No. 6) fixing roll trim to body	I	77704	
14	Rear door trim casing	']	331638	
•	Drive screw (½" No. 6) fixing lock casing to de		77704	
15	Door pull handle	1	306460	
-	Drive screw (5" No. 10) fixing handle to door		78167	
	, , , , , , , , , , , , , , , , , , , ,			

•
· · ·



109 STATION WAGON


GENERAL EXPLANATION

The 109 Station Wagon is mounted on a modified Land-Rover 109 chassis; the majority of spare parts are, however, the same as those required for the basic vehicle.


The following pages, 509 to 539 inclusive, list the parts which are peculiar to the 109 Station Wagon.

The optional equipment listed below is also fitted:-


Private locks	See Page 480
Full length doors on early models. Later models are fitted with	
the standard two piece doors	See Page 299
De Luxe bonnet with spare wheel carrier	See Page 295, 479 and 480
Flasher equipment	See Pages 457 and 459
Front door and floor trim	See Page 365



PLATI REF.	E 1 2 3 4 DESCRIPTION	Otre	Part No.	REMARKS
REF.			i art ivo,	KLIVIAIKKS
	LOWED		222002	
1		, I	332983	
1	Body side and wheelarch complete, R.H.	I	333562	
2	Body side and wheelarch complete, L.H.	İ	333452	
	Rear floor	J	333176	
4	Cross-member and pads for rear floor	4	330265	
5	Mounting pad for rear floor cross-member		332582	
,	Rivet fixing pad to cross-member	16	73979	
6	Rear mounting angle	I	333159	
7	Rear corner capping, R.H]	333266	
	Rear corner capping, L.H	I	333267	
	Pop rivet, long	4	300782	•
	Pop rivet, short Fixing capping to body	4	300919	
_	Rivet	-8	300783	
8	Capping for body top side, R.H	1	333234	
	Capping for body top side, L.H	1	333235	
	Pop rivet \ Fixing cappings to	26	300919	
_	Rivet ∫ rear body sides	18	300789	r,
9	Rear corner protection angle, R.H	1	333253	
	Rear corner protection angle, L.H	1	333254	:
	Rivet, medium Fixing	20	300783	
	Rivet, short protection angle	2	300781	-
	Rivet, long J to body	2	302186	
10	Lid for rear tool locker	1	304401	
11	Hinge complete	2	303875	
	Pop rivet, fixing hinge to lid	4	300781	
	Hasp complete	1	303871	
	Rivet fixing hasp to lid	2	300789	
	Packing washer	2	3968	
	Bolt ($\frac{1}{4}$ " U.N.F. $x \frac{5}{8}$ " long) Fixing hinge		255206	
	Spring washer wheelarch box		3074	
	Nut (¼" U.N.F.)	2	254800	
	Turnbuckle for locker lid	1	300851	
	Rivet fixing turnbuckle to wheelarch box	3	78248	
12	Retainer for floor mat, rear end	1	332756	
	Drive screw fixing retainer	13	77704	
13	"Land-Rover" nameplate	1	332670	
14	"Station Wagon" nameplate	1	306407	
	Pop rivet, fixing nameplates	4	300919	
15	Intermediate floor for rear body	1	333189	
	Special bolt Fixing floor	10	320045	
	Plain washer to rear heelboard	10	3817	
	Special nut J and toe panel	10	302532	
	Bolt (½" U.N.F. x ¾" long)	6	78210	
	Plain washer Fixing floor	12	3900	
	Spring washer to sill	6	3074	
.,	Nut (\frac{1}{2}" U.N.F.)	6	254810	
16	Cover plate for fuel tank, front	1	333201	
17	Cover plate for fuel tank, rear	1	333202	
	Special bolt	4	307339	
	Plain washer Fixing cover plate to floor	4	3900	
	Special nut J	4	302532	



D1					
PLATE REF.	1 2 3 4 DESCRIPT		Qty.	Part No.	REMARKS
	Bolt $(\frac{5}{16}" \text{ U.N.F. x } 1\frac{1}{4}" \text{ long})$		4	255211	
	Shakeproof washer	rear body to	4	72614	
	Shim	chassis at rear	10	305232	
	Nut (16" U.N.F.)	J heelboard	4	254811	
18	Tread plate, long		3	333183	
19	Tread plate, short		1	33318 4	
	Pop rivet fixing tread plates	to floor	36	78248	
	Tread plate for locker floor	••••	1	33417 9	
	Pop rivet fixing tread plate	to locker floor	7	78248	
20	Toe panel complete		1	333097	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{3}{4}$ " long))	9	255207	
	Plain washer	Fixing toe panel	9	3840	
	Spring washer	to seat base	9	3074	
	Nut (½" U.N.F.)	J	9	254810	•
	Bolt ($\frac{1}{4}$ " U.N.F. $\times \frac{5}{8}$ " long))	4	255206	
	Plain washer	Fixing	4	3840	
	Spring washer	>panel gusset	4	3074	
	Nut (‡" U.N.F.)	to 'BC' post	4	254810	
	Drive screw	J	4	72628	Alternative to nut plate and fixing below
	Nut plate) ·	2	333714	
	Bolt ($\frac{1}{4}$ " U.N.F. x $\frac{5}{8}$ " long)	Fixing panel guss	set 4	255206	Alternatives to drive screw, Part Number 72628
	Plain washer	to 'BC' post	4	3840	
	Spring washer	J	4	3074	J
	Bolt ($\frac{1}{4}$ " U.N.F. $x \frac{5}{8}$ " long)	Fixing seat box	4	255206	
	Plain washer	end panel to	4	3840	
	Spring washer	'BC' post	. 4	3074	
21	Sealing rubber, 'BC' post to	toe panel	2	333745	
22	Sealing rubber, 'D' post to	wheelarch front flan	ige 2	333263	•
	Sill panel, rear R.H.		1	333160	
23	Sill panel, rear L.H.	****	1	333161	
	Bolt (1/2" U.N.F. x 5/8" long)	Fixing	4	255206	
	Plain washer	≻sill panel to	8	3821	
	Spring washer	bracket on	4	3074	
	Nut (‡" U.N.F.)	∫ sill channel	4	254810	
	Fixing plate		2	330333	
	Plain washer Fixing s	ill panels	4	3821	
	Spring washer together		4	3074	
	Nut (‡" U.N.F.)		4	254810	
	Bolt (‡" U.N.F. x 5" long))	2	255206	
	Plain washer	Fixing rear sill pa	anel 4	3840	
	Spring washer	to body, side	2	3074	
	Nut (4" U.N.F.)	J	2	254810	
	Body side lower front exten	sion, R.H.	I	333243	
24	Body side lower front exten	sion, L.H.	1	333244	
1	Rivet, panel to rear pillar		18	7 8248	
	Rivet, front to rear panel		4	78248	



TTA 19		<u> </u>	<u>-</u>	NOO1	_		DEMADIZO
PLATE REF.	1 2 3 4	DESCRIPTIO	N N	Qty.	Part No.		REMARKS
1	ROOF COMP			1	333211		
2		ROOF_PANEL .	ASSEMBLY	1	332987		
3	Stiffener, fro	``		3	332028		
4		r ∫roof panel		3	333252		
		Fixing stiffene	er .	33		Alternatives, check	
		∫ to roof		33		before ordering	
		$\lambda \cdot \mathbf{x} \cdot \frac{1}{2}^n \text{ long}$		8	77869		
	Plain washer	,	ixing panel	16	3852		
5	Rubber wash	i	o roof at end	. 8	302371		
	Shakeproof v		f stiffeners	8	71082		
	Nut (2 B.A.)		_	8	3823		
		N.F. x 2" long))	12	78274		
		N.F. x 2¼″ long)) [2	78382		
	Plain washer			28	3900		
6	Distance pied		>Fixing roof		302372		
7	Rubber wash		panel at side		302373		
	Spring washe			14	3074		
	Nut (1" U.N	- 1	J	14	254810		
	Drive screw	Fixing panel		66		Alternatives, check	
	Pop rivet	∫roof stiffener		66		before ordering	
8	Roof ventilator		****	4	333836		•
_	Drive screw		••••	32	77932		
9		of trim at ventila		4	332240		
		ing retainer to v	ent	24	77932		
10	Roof side light	_		2	308070		
11	Weather strip f			2 .	302177		
12	Filler strip for			2	302178		
13	•	for roof to wind	screen	I	330878		
	Bolt (1" U.N.F	1		10	255207		
	Plain washer		ixing roof	10	3900		
	Spring washer	,	windscreen	10	3074		
	Nut (½" U.N.F.		c	10	254810		
1.4		r door top, R.H.]	330788		
14		r door top, L.H.	tront	1	330789		
15	Seal for retaine			2	330541		
	Kivet fixing sea	l to retainer	****	10	302818		
	Screw (2 B.A.	1		10	77869		
	Plain washer		ing seal retainer		3852		
	Spring washer	to r	oot	10	3073		
	Nut (2 B.A.)	371		10	3823		,
	Bolt (½" U.N.F		•••	30	255207		
	Plain washer		ixing roof	34	3840		
	Spring washer		sides	30	3074		
	Nut (1" U.N.F	, ,		30	254810		





PLATE REF.	1 2 3 4 DESCRIPTIO	N	Qty.	Part No.	REMARKS
KEr.	SIDE PANEL ASSEMBLY,		1	332306	
16	SIDE PANEL ASSEMBLY,		1	332307	
17	Mounting bracket front		2	332080	• .
• • •	Bolt ($\frac{5}{16}$ " U.N.F. x $\frac{5}{8}$ " long)		4	255225	
	Plain washer	mounting	4	3 830	
-	Spring washer	bracket	4	3 0 7 5	
18	Nut plate	to body	2	332081	
10	Capping for 'D' post, R.H.	•	ī	332112	
19	Capping for 'D' post, L.H.	****	1	332113	
20	Stud plate		2	332065	
20	Screw (2 B.A. $x \frac{1}{2}$ long)	****	6	77869	
		Fixing	6	3852	
		_	8	3885	
		cappings to	14	3073	
		side panels	14	3823	•
21	Nut (2 B.A.)			3023	
21	Sealing rubber at top and bo			332215	
22	'D' post pillar		6		
22	Door sealing rubber at 'D' po			332152	
-00	Rivet fixing seal		10	78321	
23	Support bracket at tailboard		2	332052	
	Bolt $(\frac{1}{4}"$ U.N.F. $\times \frac{3}{4}"$ long),		4	255207	
	fixing support	support	4	255207	
	Plain washer	>bracket at	8	3840	
	Spring washer	tailboard	4	3074	
	Nut (‡" U.N.F.)	corner	4	254810	
24	Drain channel complete for	side window	2	332223	
	Bolt (¼" U.N.F. x ½" long)		4	255206	
	Plain washer	Fixing drain	4	4071	
	Spring washer	channel to bo	-	3074	
	Nut (¼" U.N.F.)		4	254810	
25	Glass for side window, slidin	_	4	332217	
26	Sealing rubber for sliding lig		2	332230	
27	Retainer for sliding light rub		2	330661	
28	Channel for sliding light, top		4	332744*	
= 4	Channel for sliding light, bot		2	332745*	•
29	Channel for sliding light, bot		2	332752	
30	Channel for sliding light, sid		4	332746*	
31	Packing strip for top channel		4	332216	
	Drive screw fixing channel		76	77707	
32	Catch for sliding glass, front			332324	
	Catch for sliding glass, rear,	overall length		332325	
33	Distance piece for catch		6	340390	0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
34	Washer for catch	1	8		2 B.Atype fixing. Alternative to ¼" U.N.F.
	Screw (2 B.A. $x \frac{3}{4}'' \text{ long}$)		2	78223	Check before ordering
35	Screw (2 B.A. $x \frac{7}{8}$ long)	>Fixing	2	78260	
	Washer for catch	catches	16	340391	CARTINET OF ALL OF ADDA
	Screw (1/2 U.N.F. x 1/2 long)		2		\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
	Screw (4" U.N.F. x 7" long)	Į.	2	78402	
36	Tapped plate for catch	J	4	332329)



					2022 5151		
PLATE REF.	1 2 3 4 DESCRIPT	ION	Qty.	Part No.		REMARKS	
37	Runner for sliding catch		4	330848			
	Rivet fixing runner to drain	n channel	28	78248			
38	Glass for rear end window	4431	2	332200			
	Glazing strip for glass		2	332308			
	Retainer for rear end glass,	upper R.H.	1	332280		•	
39	Retainer for rear end glass,	upper L.H.	1	332281			
40	Retainer for rear end glass,	inner and outer	4	332282			
41	Retainer for rear end glass,	lower L.H.	1	332284			
	Retainer for rear end glass,	lower R.H.	1	332283			
	Drive screw fixing retainer		36	78126			
42	Sealing rubber, upper to lo	wer body side	2	333487			
43	Sealing rubber, body side (coroof	2	332154			
44	Rubber seal, 'BC' post to r	oof,	2	333257			
45	Support bracket, centre body	side	2	332201			
	Bolt (¼" U.N.F. x ¾" long)	Fixing	4	255207			
	Plain washer	bracket to	6	3900			
	Spring washer	body side	4	3074			
	Nut $\binom{1}{4}$ U.N.F.)	and capping	4	254810			
46	Mounting stud (5 U.N.F.))	4	333268			
	Plain washer	Fixing upper	6	3898			
	Special washer	≯to lower body		332293			
	Plain washer	at front and	2	3830			
	Spring washer	rear corners	8	3075			
	Nut (5 " U.N.F.)	J .	8	254811			
	Bolt (5 U.N.F. x 7 long)	Fixing	2	255227			
	Plain washer	>upper to lower		3830			
	Spring washer	body at rear	2	3075			
	Nut (5 " U.N.F.)	inner bracket	2	254811			
	Bolt ($(\frac{1}{4}" \text{ U.N.F. } \times \frac{5}{8}" \text{ long})$)	Fixing upper	4	255206			
	Plain washer	to lower body	4	3840			
	Spring washer	at rear	4	3074			
	Nut ($\frac{1}{4}$ " U.N.F.)	inner gusset	4	254810			





PLATE REF.	1 2 3 4 DESCRIPTIO	N	Qty.	Part No.	REMARKS
NEF.	REAR SIDE DOOR ASSEM		1	333044	ALLINI HALL
1	REAR SIDE DOOR ASSEM		I	333045	
•	DOOR LOCK, MOUNTIN) F	CFOCCC	
	ASSEMBLY, R.H	O WIND INVINE	1	333083	
	DOOR LOCK, MOUNTIN	C AND HANI		כטטכככ	
	ASSEMBLY, L.H	G AND HAN		332627	
2	Mounting plate for door lo	, ماد	2	333080	
2	Door handle complete, R.F		1	307977	
3	Door handle complete, K.I.		J		
4	Bracket for door handle, or		2	307978	
7		•	1	302854	
5	Door lock complete, R.H.	****	[330113	
5	Door lock complete, L.H.	••••	I	330114	
6	Sealing washer, handle to o	over	2	302859	
	Screw (2 B.A. x ½" long)	г	8	313858	•
	Spring washer	Fixing lock,	12	3073	
	Nut (2 B.A.)	brackets and	12	2247	
	Plain washer	cover together	_	3685	
	Screw (2 B.A. x ¾ long)		4	314203	
-	Locking catch, R.H		[333271	
7	Locking catch, L.H	****	I	333272	
	Screw (2 B.A. x ½" long)		2	313860	
	Plain washer, large	T	2		Models with pivot type catch.
	· · · · · · · · · · · · · · · · · · ·	·Fixing catches		3902	Check before ordering
	Spring washer		2	3073	
	Nut (2 B.A.)		4	2247	
	Locknut (2 B.A.)		2	25996	
-	Locking catch, R.H	****			Models with spring-loaded type catch.
	Locking catch, L.H	•			Check before ordering.
	Rivet fixing door lock cover t	-	8	302222	
	Screw (½" U.N.F. x ¾" long)	_	8		Alternative to 2 lines below
	Screw retainer, R.H.	lock assembli			Alternative to
	Screw retainer, L.H.	to door	2	332733	∫ line above
	Spring washer	lock cover	8	3074	
	Nut	J _. , ,	8	254800	
	Drive screw, fixing lock assen	ably to door	2	77903	
0	Door hinge, upper R.H	****	1	330115	
8	Door hinge, upper L.H	••••]	330116	
	Door hinge, lower R.H]	330117	
9	Door hinge, lower L.H.		[330118	
	Bolt (5 " U.N.F. x 2" long)		8	256226	
	Spring washer	door hinge to		3075	
10	Nut (5" U.N.F.)	door frame	8	254811	
10	Fixed window for sides reen		2	333093	•
11	Retainer for sidescreen, fixed		2	333033	
10	Drive screw (\frac{3}{8}" No. 6) fix ug			78140	
12	Filler, top and bottom, for the	le screen	4	333081	
13	Filler, rear, for sidescreen		2	330203	
	Packing strip, for glass chann		2	333082	· ·
14	Sliding window with knob for	side screen	2	333089	
15	Sliding light channel, rear		2	332746	
16 -	Sliding light channel, top and		4	332747	
	Drive screw $(\frac{1}{2}^n \text{ No. 6})$ fixing	slidi. 🕔 channel	28	77707	



71					
PLATE REF.	1 2 3 4 DESCRIPTION	_	y.	Part No.	REMARKS
17	Buffer for sidescreen sliding window at top	••••	2	330162	
	Plain washer \(\int \) Fixing		2	3886	
	Drive screw \int buffer		2	7 81 6 0	
18	Sealing rubber for sliding glass		2	330660	
19	Retainer for sliding glass sealing rubber		2	330661	
20	Sliding window catch	• •	2	332435	
	Pop rivet fixing catch		4	300781	•
	Rod for check strap, R.H.	••••	1	333041	
21	Rod for check strap, L.H		1	333204	
22	Buffer for check strap, short		2	306295	
	Buffer for check strap, long		2	333445	
	Door check bracket, R.H., for rear side door		1	333095	
23	Door check bracket ,L.H., for rear side door		l	333096	
	Bolt $(\frac{5}{16}"$ U.N.F. x $1\frac{1}{8}"$ long)		4	255210	
	Bolt (5 U.N.F. x 1 long)		4	255209	
	Shakeproof washer Fixing bracke	ts to	8	72614	
	Shim chassis frame		8	305232	
	Nut (% U.N.F.)		8	254811	
24	Clevis pin		2	302828	
	Plain washer, small Fixing door check rod		4	3947	
. :	Plain washer, large to bracket		2	3840	•
÷.,	Split pin		2	4042	
,	Bolt, top (\frac{5}{16}" U.N.F. x 2\frac{1}{2}" long)		4	256228	
	Bolt, bottom (5 U.N.F. x 3" long) Fixing	door	4	256230	
	Plain washer >hinge t		8	3966	4 off when nut plate is used
	Spring washer 'BC' po		8	3075	•
	Nut (16" U.N.F.) at botto		8	254811	4 off when nut plate is used
	Nut plate		2	333710	•
25	Striking plate for rear side door locks		2	333140	
	Bolt (¼" U.N.F. x ½" long)		4	255226	
	Plain washer Fixing striking p	olate	4	3840	
	Spring washer to 'D' post		4	3074	•
26	Nut plate		2	333137	
	Waist moulding, rear side door R.H		I	332658	
27	Waist moulding, rear side door, L.H.		1	333720	
	Special bolt		6	302533	
	Plain washer Fixing mouldings to doors	1		2630	
	Spire nut	1		302532	
	Seal retainer for rear side door, R.H. top		1	333410	-
28	Seal retainer for rear side door, L.H. top		1	333411	
29	Rubber seal for retainer		2	333228	
	Rivet fixing seal to retainer	1		78321	
	Screw (2 B.A. x ½" long)		8	77869	
	Plain washer Fixing seal and		8	3902	
	Spring washer retainer to cant rai		8	3073	
	Nut (2 B.A.)		8	3823	




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
30	Door sealing rubber for upper vertical 'D' post	t 2	332152	
	Rivet fixing seal to 'D' post	10	78321	
	Door sealing rubber for lower vertical 'D' post, I	R.H. 1	333261	
31	Door sealing rubber for lower vertical 'D' post, I	L.H. 1	333262	
	Rivet fixing seal to 'D' post	10	78321	
32	Door sealing rubber for sloping 'D' post	2	332152	
	Rivet fixing seal to 'D' post	8	78321	
33	Door sealing rubber at rear side sills, bottom	2	333233	
	Rivet fixing seal to sill	8	78321	
34	Door sealing rubber at 'C' post	2	333229	
	Rivet fixing seal at 'C' post	22	78321	
	Door sealing rubber at 'B' post, lower R.H.	1	330539	
35	Door sealing rubber at 'B' post, lower L.H.	1	330540	
	Rivet fixing seal to "B' post	12	78321	
36	Door sealing rubber at 'B' post, upper	2	332152	
	Rivet fixing seal to 'B' post	10	78321	
37	Filler piece for 'B' post seal	2	330850	
	Frame for front and rear side doors, R.H.	1	333100	
38	Frame for front and rear side doors, L.H.	1	333101	
	Bracket, sill channel to panel	6	330389	
	Bolt (‡" U.N.F. x ¾" long)	12	255207	
	Plain washer Fixing brackets	24	3821	
	Spring washer to sill channels	12	3074	
	Nut (¼" U.N.F.)	12	254810	
	Bolt plate	2	332603	
	Plain washer Fixing sill channels	4	3841	
	Spring washer to dash pillar	4	3075	
	Nut (휴" U.N.F.)	4	254811	
	Bracket for sill, rear end, R.H	1	333259	
	Bracket for sill, rear end, L.H	1	333260	
	Bolt $(\frac{5}{18}"$ U.N.F. x $\frac{7}{8}"$ long) \bigcap Fixing bracket	8	255227	
	Plain washer >to sill and	16	3841	
	Spring washer chassis	8	3075	
	Nut $\binom{5}{16}$ U.N.F.) frame	8	254811	
	Plug for redundant hole on 'BC' post, bottom	2	265683	






PLATE REF.	1 2 3 4 DESCRIPTION	0	ty.	Part No.	REMARKS
REF.	REAR DOOR COMPLETE ASSEMBLY	Ų	1	333415	MANI MAN
1	n 1		1	333416	
2	C1 (1	• • • • •	1	333031	
3	Detail of the second		2	333033	
4	D		1	333032	
5		•	1	333034	
6			2	333035	
U	Retainer for glass, corners		32	78140	
	Drive screw fixing retainers DOOR LOCK, MOUNTING AND HANI)	70140	
	ASSEMBLY		1	333039	
7	Mr 1 . 2 . 1 . 2 . 1	••••	1	333080	
	5 1 I		i T	333040	
8		****	1	302859	
9 10	Washer, handle to cover	••••	1	332432	
10	Door handle with lock Barrel lock		!	306036	·
11			ł T	307289	State key number when ordering
12	Key for barrel lock		1		State key number when ordering
12	Bracket for door handle		1 4	302854 313858	
	Screw (2 B.A. $\times \frac{1}{2}^{n} \log$)		6		
	Spring washer Fixing lock		6	3073 3685	
	Plain washer together		4		
	Nut (2 B.A.)		6	2247 302222	
	Rivet		4		2 of ohomound alers in found
10	Special screw Fixing	,	4	78216	2 off when stud plate is fitted
13	Stud plate, door lock, bottom door lo		1	332732*	
	Spring washer to cove	r	4	3074 254800	
	Nut (½" U.N.F.)		4	77903	
1.4	Drive screw, fixing lock assembly to door		2	332434	
14	Locking pillar for catch		1	2226	
	Plain washer		1	3073	
	Spring washer Fixing catch to pillar		1	2247	
16	Nut (2 B.A.)		1	333037	
15	Waist rail lock handle protection strip	•···•	1	255207	
	Bolt (1" U.N.F. x 3" long) Fixing		2	3074	
	Spring washer strip to		2		
17	Nut (½" U.N.F.) door		1	254800	
16	Wheel stud plate		1.	333435	
17	Clamp plate for spare wheel stud plate		1	333446 78210	
	Screw (¼" U.N.F. x ¾" long) Fixing stud &		8	78210 3074	
	Spring washer clamp plates		8	3074 254810	
10	Nut (‡" U.N.F.) to rear door		8		
18	'U' bolt for spare wheel support		1	333447	
10	Nut (½" U.N.F.) fixing 'U' bolt to door	••••	2	254814	
19	Retaining plate for spare wheel	 •T T•	I	333439	
20	Hub nut fixing wheel and retaining plate to			217241	
	bolt	••••	6	217361	1059 50
21	Male dovetail For rear		1		· 1958-59
21	Male dovetail Send door		1	332942	1960 onwards
	Screw (½" U.N.F. x §" long) Fixing	1	2	78233	
	Spring washer >male dovetai	1	2	3074	
22	Nut J to door		2	254810	
22	Rod for check strap	••••	[1	333041	
23	Buffer for check strap, short	••••	1	306295	
24	Buffer for check strap, long	••••	I	333445	



		103 DIATIO		.011, 10	
PLATE REF.	1234 D	ESCRIPTION	Qty.	Part No.	REMARKS
25	Hinge for rear o	loor, upper	1	333036	
26	Hinge for rear o	loor, lower	1	330117	
	Bolt (5 " U.N.F		4	256226	
	Spring washer	≻hinge to	4	3075	
	Nut (5 " U.N.F	door frame	e 4	254811	•
	Bolt (5 "U.N.F.:		4	255227	
	Plain washer	Fixing door	. 4	3830	
	Spring washer	hinges to bo	dy 4	3075	
	Nut (5" U.N.F.)		4	254811	•
	Bolt (1" U.N.F. x	14" long) \(\)	1	255251	
	Spring washer	Fixing	1	3074	
	Plain washer, thic	1 -	rod 2	4075	
	Plain washer, thin		2	3947	
	Nut (‡" U.N.F.)		2	254810	
27	Striking plate		1	333140	
	Bolt (‡" U.N.F. x	1" long)	2	255209	
	Plain washer	Fixing strikin	g As require		
	Spring washer	plate to rear	-	3074	
	Nut (½" U.N.F.)		2	254800	
	Female dovetail	For rear door	1	333440	1958-59
28	Female dovetail	on body	1	332147	1960 onwards
	Spacer \ For fe	, .	1	3334 44	1958-59
29	Spacer doveta		1	332943	1960 onwards
		. x §" long) fixing dovet	ail to		
	spacer		2	78233	
	Screw (‡" U.N.F.	x l" long) Tixing	2	78387	
	Spring washer	>male dovet		3074	
	Nut (‡" U.N.F.)	to door	2	254810	
	Set bolt (‡" U.N.!	J_	2	255207	
	Plain washer	Fixing spa		3900	
30	Shim	L.H. rear		305232	
•	Spring washer		2	3074	
31	Seal for door side	s	3	330535	
32	Seal for door side		1	332563	
33	End filler piece for		4	330850	
	Rivet fixing seals		22	302818	
	-	or rear door, bottom	1	333203	•
34	Seal for rear door		1	332564	
35		al to rear door, bottom	1	332756	
		No. 6) fixing seal and reta	iner to		
	floor		13	77704	
36	Seal for rear door		1	332149	
	Rivet fixing seal	,	11	302818	
37	Retainer for rear		1	332151	
	Screw (2 B.A. x }		9	77869	-
	Plain washer	Fixing retainers	, 9	3902	•
	Spring washer	to roof panel	9	3073	
	Nut (2 B.A.)		9	3823	
	(,			



109 STATION WAGON, REAR DOOR

DI ATTE				
PLATE REF.	1 2 3 4 DESCRIPTION	Qty		REMARKS
38		1	501053)
39	•	i	245137	
4 0	Retainer for rear step, side	2	245136	
41	Retainer for rear step mat, front	1	245135	
4 2		1	245134	
		16		
43	•	2		Overall width $19\frac{1}{2}$ ".
	Bolt (¾ U.N.F. x 4" long) ∫ Fixing hinge cent	re 2	256253	>
	Locknut ($\frac{3}{8}$ " U.N.F.) \int to rear step	4	254852	Alternative to the 11½" step below
	Bolt (3" U.N.F. x 7" long) \ Fixing hinge cent	re 2	255046	
	Locker	nber 2	235731	Check before ordering
44	Spring for rear step	2	264362	
45		1	304125	
	Plain washer \(\) Fixing buffer to	1	3867	
	Drive screw \int rear cross-member	1	78142	J
		1	508947)
	<u>-</u>	1	508957	
		2	245136	
		1	508959	
	• •	1	508958	
	Rivet fixing mat end cappings	14	4022	Overall width $11\frac{1}{2}$ ".
		1	264362	
		1	304125	Alternative to the $19\frac{1}{2}$ step, above
	Plain washer \(\) Fixing buffer to	1	3867	
	Drive screw frear cross-member	. 1	78142	Check before ordering
	Rubber buffer for underside of rear step	1	304125	
	Plain washer \(\) Fixing buffer	ì	3867	
	Screw (2 B.A. $x \frac{5}{8}'' \text{ long}$) $\int \text{to step}$	1	77758	
		1	509120	
	Plain washer \ Fixing	2		
	Split pin ∫ hinge pin	2	2395	J
	•			-




PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No.		REMARKS
REF.	CENTRE SEAT COMPLETE ASSEMB		333526		* TO A THE BAD OF THE
1	CENTRE SEAT COMPLETE ASSEMBLE CENTRE SEAT SQUAB ASSEM		02/ررز		
1	TRIMMED		333527		
2		I	308173		
2	No-sag seat spring	1/	308310		
•	Wire for seat springs	I	308144		
3	Interior for centre squab	I			
4	Trim board for centre seat squab	I	308156		
	Drive screw Fixing trim board	15	77903		
	Plain washer \int \to \text{frame}	15	3886		
_	Trim clip, fixing squab cover	38	315264		
5	CENTRE SEAT CUSHION ASSEM	IBLY,	222520		
_	TRIMMED	!	333528		
6	No-sag seat springs	17	308173		
	Wire for seat springs]	308310		
7	Interior for centre cushion	1	308155		
	Trim clip fixing cushion cover	38	315264		•
	Hinge R.H. \ For	!	308136		
8	Hinge L.H. \int seat squab	. 1	308137		
	Set bolt $(\frac{5}{16}"$ U.N.F. $)$ Fixing hinge to				
	$x \frac{5}{8}$ long) \rightarrow cushion and	8	255225		
	Spring washer J support tube	8	3075		
	Support link, R.H	1	308713		
9	Support link, L.H	1	308714		
10	Special set bolt ($\frac{5}{18}$ " U.N.F.) \ Fixing lin		331708		
	Plain washer ∫ centre sq	uab 2	3830		
11	Centre seat support tube	1	333507		
		centre 2	255232		
	Plain washer >seat to		3899		
		rt tube 2	3075		
	Bolt $(\frac{5}{16}^{"}$ U.N.F. $\times \frac{5}{8}^{"}$ long) \int Fixing	2	255225		
	Spring washer centre sea		3075		
	Nut $(\frac{5}{16}"$ U.N.F.) \int to wheeland		254 811		
	Bolt $(\frac{5}{16}$ U.N.F. $\times \frac{3}{4}$ long)	. 6	255226		
	Plain washer Fixing centr	е б	3830		
	Spring washer seat to floor	6	3075		
	Nut (5 U.N.F.)	6	254811	_	•
12	Bracket and locking screw for squab support		333277		
13	Locking screw (5/16" U.N.F.)	2		≻Riveted type	
	Pop rivet fixing bracket to capping	8	78248	j	
	Locking plate and screw for squab support		334174*		Alternatives.
	Locking screw $\binom{5}{16}$ "U.N.F.)	2	334176*		Check before ordering
	Bolt (¼" U.N.F. x 1 ½" long)	4	255205	≻Bolted type	
	Spring washer	4	3074		
	Nut plate $(\frac{1}{4}"$ U.N.F.)	2	334177	J	
	Strap for rear centre seat	2	331707		
	Stud for strap	2	320245		
	Screw (2 B.A. x ½" long)	2	77993		
	Spring washer Fixing stud	2	3073		
	Nut (2 B.A.)	2	3823		
	-				





PLATE REF.	1 2 3 4 DESCRIP	TION	Otv.	Part No.	REMARKS
14	Cover for rear centre toe p		1	331616	
15	Retainer, cover to seat base		1	331532	
.,	Drive screw $(\frac{1}{2}"$ No. 6) fixing		-	77704	
16	Grab rail between 'BC' p	-		7,701	
	seat		1	333395	
	Set bolt (16" U.N.F. x 3" 1	****	4	255226	
	Plain washer	>grab rail to	4	3830	
	Spring washer	'BC' post	4	3075	
	Front squab, trimmed, driv		1	331784	
	Front squab, trimmed, pass		1	332357	
	Front squab, trimmed, cen		1	332340	
17	Retaining clip Fixing n		4	333399	Clip type fixing
18	Packing rubber >front sea	•	4		Alternative to strap
	Drive screw to grab i		8	72628	
	Retaining strap, non-adjus		grab	5	
	rail	****	4	332355	
	Spire nut Fixing stra	p to	8	78237	
	Plain washer >non-adjust		8	4034	Strap type fixing. Alternative to clip
	Drive screw front seat		8	78438	Check before ordering
	Stud for retaining strap		4	320345	
	Drive screw, fixing stud to	grab rail	4	78412	
	Packing rubber		2	333400	
	Plain washer		4	3840	Alternative to three lines below
	Drive screw Fixing o	n ·	4	7 2628 <i>)</i>	Check before ordering
	Spire nut adjustab	le front seat	2	78237	
	Plain washer		2	3885	Alternative to two lines above
	Drive screw		2	78438	Check before ordering
	Grab rail behind centre sea		1	333510	
	Set bolt $(\frac{5}{16}"$ U.N.F. $x \frac{5}{8}"$ l		2	255225	
	Spring washer	∫grab rail	2	3075	
	Clip for starting handle and	d jack handle	5	508035	
	Bracket for starting handle		4	332376	
	Bracket for starting handle		1	332377	
	Rivet fixing clips to bracke		5	78248	
	Drive screw $(\frac{1}{2}" \text{ No. } 10)$	_		78153	
	Packing washer	of centre seat cushi	on 8	4171	


109 STATION WAGON, REAR SEATS



109 STATION WAGON, REAR SEATS

PLATE REF.	1 2 3 4 DESCRIPT	ION	Qty.	Part No.	REMARKS
	REAR SEAT FRAME AS	SEMBLY, R.H	. 1	331646	
	REAR SEAT FRAME AS		. 1	331647	
1	Rear seat back frame		. 2	331229	
2	Hinged base for rear seat	****	. 2	320521	
3	Bolt (4" U.N.F. x 3" long) Fixing seat	4	255207	
4	Plain washer	base to	12	3821	
5	Nut (1" U.N.F.)	frame back	4	254810	,
	Backrest securing clip, R.	н́.	. 1	333293	
	Backrest securing clip, L.		. 1	333294	
	Backrest securing clip		. 2	333295	
	Bolt (‡" U.N.F. x §" long)] Fixing	8	255206	
	Spring washer	clips to	3	3074	
	Nut (‡" U.N.F.)	frame	8	254180	
	Buffer	··· ··· ···	. 2	331699	
	Screw (2 B.A. x 7 long)	Fixing	2	77925	
	Plain washer	>buffer to	4	4030	
	Nut (2 B.A.)	seat frame back	2	3823	
6	Strap for seat	,	. 2	302648	
7	Hook for strap	****	. 2	301005	
	Plain washer \ Fixing str	ap to	4	3816	
	Pop rivet hinged ba		2	300782	
8	Bolt (1" U.N.F. x 3" long))	4	255207	
9	Plain washer	Fixing seat frame	4	3821	
10	Spring washer	to wheelarch box	4	3074	
	Packing washer		8	2228	
11	Nut (1" U.N.F.)	J	4	254810	
	REAR SEAT BACKRES	T TRIMMED			
	ASSEMBLY, GREY	****	. 2	320084	
12	Back rest panel	****	. 2	301470	
13	Retaining rod for pad		. 2	301476	
14	Pad for back rest	****	. 2	302647	
15	Bolt (1" U.N.F. x 1" long)	Fixing	12	255204	
16	Spring washer	back rest	12	3074	
17	Nut (1/2" U.N.F.)	to frame	12	254800	
	REAR SEAT CUSHION	ASSEMBLY, GREY	Y 2	320085	
18	Pad for rear cushion	,	. 2	302655	

109 STATION WAGON, BODY TRIM



109 STATION WAGON, BODY TRIM

PLATE REF.	1 2 3 4 DESCRIPTION	Qt	ty.	Part No.		•	RE	MARKS	
REF.	Bracket, cant rail to roof frame		4	331168					
•	Drive screw (½" No. 6) fixing bracket to cant ra		8	77704					
2	Roof trim, front portion		ĭ	331491					
	Plain washer Fixing roof trim		9	3886					
	Drive screw (½" No. 6) to bracket		ý.	77704					
3	Centre bracket for canopy trim panel		í	331391					
4			i	331607					
7	Plain washer Fixing trim panel		3	3852					
	Drive screw (½" No. 6) to centre bracket		3	77704					
5	Headcloth, intermediate		1	331610					
			2	331216					
6 7			2	331203					
,	Fixing strip for intermediate headcloth	1		77704					
Q	, ,		l	331605					
8	· · · · · · · · · · · · · · · · · · ·		2	331547					
9	Side strip for rear headcloth		5						
10	Drive screw (½" No. 6) fixing strip to roof		フ 1	77704	•				
10	Fixing bracket, R.H. sidelight casing, front	••••	1	331192					
11	Fixing bracket, L.H. sidelight casing, front		1	331193					
11	Sidelight casing, front, R.H.		1	331186					
	5	·	1	331187					
	Drive screw (½" No. 6) Fixing casing		6	77704					
	Plain washer		6	3886					
12	Sidelight casing, rear, R.H	••••	ļ	331179					
	Sidelight casing, rear, L.H.	• • • •	Ī	331180					
	Drive screw (½" No. 6) Fixing casing		2	77704					
	Plain washer		2	3886					
13	Roll trim, cant rail, R.H. front		1	331589					
	Roll trim, cant rail, L.H. front		l	331590					
	Drive screw (½" No. 6) fixing roll trim to body		6	77704					
14	Roll trim, cant rail, R.H. rear		ı	331497					
	Roll trim, cant rail, L.H. rear		Ī	331498					
	Drive screw (½" No. 6) fixing roll trim to body		4	77704					
15	Door trim upper, centre, R.H.		i	33159 9					
	Door trim upper, centre, L.H.		1	331600					
		1	0	77704					
16	Door trim, centre, R.H		1	331213					
	Door trim, centre, L.H		1	331214					
17	Door pull handle for rear side door		2	306460					
	Drive screw (§" No. 10) fixing handle to door		4	7 816 7					
	Captive nut for drive screw		4	78319					
18	Rear door trim casing		1	331638					
	Drive screw (½" No. 6) fixing door casing		5	77704					
19	Door pull handle for rear door		1	306460					
	- C - C - C - C - C - C - C - C - C - C		2	78167					
20	Intermediate floor rubber mat		1	331481					
21	Retainer for floor mat, intermediate		2	331480					
22	Rear floor rubber mat		1	331670					
23	Retainer for rear floor mat, front end		1	331669					
	Pop rivet fixing retainer		7	78248					
24	Retainer for seal and rear floor mat, rear end		1	332756					
25	Protection strip for rear door, bottom		1	333203					
26	Sealing rubber for rear door, bottom		1	332564					
	Drive screw fixing retainer, strip and seal to flo		3	77704					
	union mining remainer, our p und deal to lit	I	-	,,,,,		-			

109 STATION WAGON, CHASSIS FRAME, FUEL TANK, EXHAUST SYSTEM, ELECTRICAL EQUIPMENT

		EQUI MENT
PLATE 1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
Chassis frame	1	278665
Fuel tank complete	1	500429 Petrol model
Fuel tank complete	1	500817 Diesel model
Joint washer for drain plug	1	230509
Drain plug	1	235592
Bolt ($\frac{3}{8}$ " U.N.F. x $1\frac{3}{8}$ " long)	2	25604 0
Plain washer Fixing fuel	2	3109
Distance piece tank to	2	508544
Mounting rubber frame at	2	508545
Spring washer front	2	3076
Nut (3" U.N.F.)	2	254802
Bolt (3" U.N.F. x 2½" long)	2	256047
Distance piece, top	2	501070
Plain washer	4	3933
Spring washer Fixing	i	2286
Distance piece > fuel tank to	2	500446
Mounting rubber frame at rear	4	500447
Distance piece, bottom	2	500588
Self-locking nut (§ U.N.F.)	$\tilde{2}$	252162
Fuel tank gauge unit, SM FT 5300/89	1	501620 Series II Petrol models
Fuel tank gauge unit	i	519875* Series IIA Petrol models
Fuel tank gauge unit, SM FT 5340/06	1	501621 2 litre Diesel models
Fuel tank gauge unit	i	529970* 2¼ litre Diesel models
Spring washer Fixing	6	3101
Set screw (3 B.A. x ½" long) gauge unit	6	3100
Earth lead for fuel tank gauge unit	1	239688)
Fan disc washer Fixing	1	519857 > 1961 models onwards
Drive screw earth lead	1	72626 7261 models onwards
Fuel tank elbow and pipe	i	500432 Petrol model
Fuel tank elbow and pipe	1	500818 Diesel model
Tring and have found allower	I	267837
Spring washer Fixing elbow	1 , 2	3101
Set screw (3 B.A. $\times \frac{9}{16}$ " long) \int to tank	2	3972
Fuel pipe, copper, tank to flexible pipe	1	500438 1958-60 Diesel and Petrol models
Fuel pipe (nylon), tank to pump	I	509926)
Nut Fixing fuel pipe	I	270115 Diesel and 2½ litre Petrol models, 1961 onwards
Olive to pump inlet	1	270105 Diesei and 24 little Fettol models, 1901 onwards
Fuel nine flow to tend return	i	500821 Diesel model, 1958-60
Final mine and managers and	I	509910)
Bolt (2 B.A. x \(\frac{3}{4}\)" long) \(\cap \) Fixing	I	250961
Distance piece Spill return pipe	1	509912 Diesel models, 1961 onwards
Spring washer bracket on	1	3073
Nut (2 B.A.) injector stud	1	2247
Grommet for spill return pipe	1	273370
T. 1	I	270297
Simula mine alim	I	50183 Petrol model, 1958-60
D 11 : 1:	J	243395
Ding alia	1	500823
Pina alin	1	500839 Diesel model
ripe clip	I	J000J7 j

109 STATION WAGON, CHASSIS FRAME, FUEL TANK, EXHAUST SYSTEM, ELECTRICAL EQUIPMENT

DI ATE	nno.	ALDERICA!					
PLATE REF.	 <u></u> 	RIPTION			Įty.	Part No.	REMARKS
	Pipe clip at check strap	_	••••		l	500445	1958-60 2 off on Diesel model
	Pipe clip at check strap				١	509413	1961 models onwards
	Bolt (2 B.A. x ½" long)				3	250959	
	Spring washer	clip to bra	cket		3	3073	
	Plain washer	on No. 3	_		1	2226	
	Nut (2 B.A.)	cross-mem	ber		3	2247	
	Pipe clip	Fixing			3	500833	D 1 11 1070 40
	Pipe clip	>fuel pipe			2	50183	Petrol model, 1958-60
	Drive screw $(\frac{3}{8}" \text{ No. 6})$		•		5	72626	
	Pipe clip fixing fuel pip		oss-memb	er	1	216708	todan talah
	Pipe clip fixing fuel pip		****	••••	3		≻1961 Petrol models onwards
	Drive screw fixing clip				3	72626	
	Intermediate exhaust p	_		••••	1	500289	
	Exhaust silencer, comp		••••	•	1	500290	B
	Exhaust silencer comple			••••	!	523655	Required when hydraulic front winch is fitted
	Hose, tank to filler tube	·		••••	1	500435	
	Hose clip, bottom		••••	••••	1	50328	
	Hose clip, top	••••	••••	••••	1	50343	
	Hose, tank to tank		••••	•	į.	500437	
	Breather hose for fuel t			••••	ļ	500436	
	Clip fixing breather and				4	50302	
	Gauge and ammeter pa	nel complete	1***		!	519873*	Same II/A modele
	Fuel gauge		••••		1	519874*	`J
	Frame harness					504684	Series II models
	Frame harness	•		•••	ļ		Series IIA models
	Grommet in chassis sid		•		2	276053	D: 1 11
	Lead, tank unit to warr	-		•	ļ	504685	Diesel models
	Lead for roof lamp, roo	_		••••	i 1	265482	6: 11 11
	Lead for roof lamp, cha	_		••••	ļ	265481	Series II models
	Lead for roof lamp, cha		••••	•	l		Series IIA models
	Cable clip Fixing	-				41379	
	Drive screw ∫ lead to				1	78116	
	Grommet in fuse box for	or lead	••••	••••	ŀ	233244	
	Fuse box			••••	l	219078	
	Screw (5 B.A). Fixing				2		Series II models
	Nut (5 B.A.) Sto da	sh			2	3280	•
	Interior mirror		••••		1	334000	
	Drive screw fixing mirr	or			2	77789	
	Switch for roof lamp			••••	ļ	240908	
	Roof lamp complete LU	J 56062/A			ı	265295	Lucas Alternative types.
	Roof lamp complete				1	514900	Sparto \int Check before ordering
	Bulb for roof lamp LU				1	264591	
	Mounting pad for roof	-			i	308461	Suitable for Lucas type lamp only
	Mounting pad for roof				Ì	334111	Suitable for Lucas and Sparto type lamps
	Drive screw fixing lamp				2	77892	
	Grommet for roof lamp	lead		••••	I	312856	•



FIRE TENDER

1958-61 PETROL MODELS ONLY

GENERAL EXPLANATION

The Fire Tender is mounted on a standard Land-Rover 88 or 109 chassis and body, and the spare parts are, therefore, the same as those required for the basic models. The following pages list the parts which are peculiar to the Fire Tender.

The extras and additional equipment listed below are also required:-

Centre power take-off	•••		 Listed on pages 369 and 371
Spare wheel carrier on bonnet			 Listed on page 295
Truck cab			 Listed on pages 359 to 361
Propeller shaft for pump			 Listed on page 373
Oil cooler, 2 litre			 Listed on pages 419 to 421
Oil cooler, 21 litre	••••		 Listed on pages 427 to 431
Engine governor, 2 litre		****	 Listed on pages 381 to 383
Engine governor, 24 litre	••••		 Listed on pages 385 to 389
Full length doors, 109 models			 Listed on page 299
Rear seat, 1 off, 109 models	****	****	 Listed on page 447
Private locks, 109 models			 Listed on page 480

But with the following differences:-

Engine governor, 2 litre, 243434 replacing 240628
Governor control quadrant, 2 litre, 265346 replacing 240066
Governor control quadrant, 2½ litre 265346 replacing 508690
Lever for quadrant, 2 litre, 265348 replacing 235097
Lever for quadrant, 2½ litre, 265348 replacing 508692
Washer for lever 265347 replacing 219659
Support for governor control 237549 replacing 240065

LESS	Operating rod	••••	•	 1	240410
	Ball joint	••••	••••	 2	219065

When universal joint covers are fitted a modified cover, part number 243547, must be fitted to prevent a foul with the oil cooler return pipe.

All parts normally painted body colour are painted red.

All seats are trimmed in red.




PLATE REF.	1234	DESCRIPTION			ty.	Part No.	REMARKS
KEP.	Pump complete			<u>`</u>	1	265200	
1	Oil filler tube				2	271751	
2	Mounting ring				1	271752	
3	Delivery valve				2	271754	
4	Joint washer for				2	271755	
5	Control wheel fo				2	271756	
6	Spindle and seal			••••	2	271757	
7	Rubber seal \ F			••••	2	271758	
8	Spring v				2	271759	
9	Circlip \ For				2	271760	
10	Seal spindl	e hody			2	271761	
11	Spindle body, fo				2	271762	
12			****		1	267623	
13	Washer \ For p		••••		i	_	When drain cock is fitted
14	Plug casing				i		to suction casing
15	Grub screw, seco				1	271763	•
16	Bush for shaft	_			i	271764	
17	Gasket for primi				i	271765	
18	_	rs with washers and			1	267615	
19	Priming impeller		, -		1	267620	
20	Suction casing				1	271766	·
21		11			1	267621	
22	Seal for shaft in	_			1	271768	
23	Suction pipe uni				1	240041	
24	Washer \ For	on mot aid	****		1		2 off when drain cock is fitted
25	Plug suctio	n casing			Ī		to priming casing
26	Drain cock in su				1		In priming casing on pumps numbered
27	Fibre washer for				1		from A745060 onwards
28					1	213959	
29	Cap and filter co			****	-1	271775	
30	Washer for cap		****		1	271776	
31		for priming casing			1	271777	
32		for pump shaft					
	impeller end				1	275385	
33	Suction impelle				1	267618	
34					Ţ	271778	
35		small pressure imp		••••	1	267621	
36	Distance piece f				1	271779	
37	Suction and pre		****		1	267619	
38	Main casing				1	271780	Up to pump number A745059
	Main casing wit		••••		1	514574	From pump number A745060
39		rge pressure impel	ler		1	267622	
40	Stationary sealir				1	271781	Up to pump number A745059
41	Stationary sealing				1	514575	From pump number A745060
42		stationary sealing			1	514560	Up to pump number A745059
43	-	stationary sealing r			1	514561	From pump number A745060
44	Screw) For		-		3	271782	
45	Washer sealin	g ring			3	271783	
46	Seal for shaft in				1	271784	
47		eal in main casing	•	••••	1	514563	
48	Sealing ring for				1	514561 J	Crioni bamb namber the 18000
	- -					-	





PLATE	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
PLATE REF.		1	240041
49	Union for delivery pipe, first aid	I	3057
50	Union for pressure gauge pipe	1 1	271787
51	Plug for main casing at side	I	271770
52 52	Washer for plug Oil drain plug for main casing at bottom	i	271770
53 54		, I	271770 > From pump number A745060
5 5	Joint washer for plug	! 1	514564 S
56	Extension tube for plug Grease nipple for main casing	I	271789
57	n 1	l	271772
58	Drain cock Fibre washer \(\right\) For drain	I 1	271773
59	Copper washer cock	1	213959
60	Extension for drain cock	1	514562 From pump number A745060
61	Mechanical seal, for shaft c/w rubber 'O'		51 1502 Trons pump manager in section
JI	and fibre washer	1	504062
62	Fibre washer for shaft	1	271790
63	Rubber 'O' ring for shaft	1	271 7 91
64	Circlip, front, fixing bearing	1	271793
65	Ball bearing for shaft	1	267616
66	Distance piece for bearing	1	271794
67	Circlip, rear, fixing bearing	1	271793
68	Joint washer for bearing cover	1	27 17 96
69	Bearing cover	1	271797
70	Seal for bearing cover	1	271798
71	Screw for cover	4	271799
72	Driving flange	1	271800
73	Key for flange	1	271801
74	Washer \ For	1	271802
7 5	Nut ∫flange	1	271803
7 6	Priming cock	1	271804
77	Joint washer for cock	1	271805
78	Exhaust pipe	1	271806
	Bolt (8" B.S.F. x 43" long)	3	237348
	Plain washer, small Fixing pum		3851
	Plain washer, large to chassis	3	2251
	Spring washer	3	3076
	Nut (8")	3	2827
	Support plate for pump Fixing	1	265051
	Bolt (# x 2# long)	. 2	237346
	Plain washer	As requi	
	Self-locking nut (§")	2	50526
	Bolt $\binom{3}{4}$ " x $2\frac{1}{8}$ " long) Fixing support	4	239906
	Plain washer >plate to	8	3299
	Self-locking nut $\binom{3}{4}$) towing plate	4	50531

2.3.3



	FIRE		CONTROL	<u></u>			MODELS		
ATE EF.	1 2 3 4	DESCI	RIPTION	Ç	ty.	Part No) .	REMARI	<u>ςs</u>
1	Water tank cor	nplete	••••	••••	1	504625			
2	Filler cap for v	vater tank	****	••••	1	307280			
3	Body for filter				1	307279			
	Filter for water	r tank	****		1	303610			
	Bolt (1 x 11)	long)			6	256200			
	Plain washer		ng filter body		6	3840			
	Spring washer		ater tank		6	3074			
	Nut (1/2")	}			6	254810			
	Rubber pad fo	r water tank	****	****	4	303661			
	Breather pipe		****		1	243229			
	Union nut pip		****	••••	1	4013			
	Clip for breath		****		1	50647			
	Strap fixing w				2	243677			
	Strap fixing wa			••••	2	303612			
	Bolt $(\frac{1}{4}'' \times \frac{1}{2}'')$ le				4	255204			
	Bolt (1 x 7 le		σ stran		4	255208			
	Spring washer		eelarch		8	3074			
	Nut $(\frac{1}{4}'')$	10			8	254800			
	Special bolt	Fixing			2	255238			
	-	strap ends			2	254811			
	Bolt (4" U.N.I		Fixing		6	253888			
	Plain washer		>water tank		6	2213			
	Spring washer		wooden stops		6	3074			
	Nut $(\frac{1}{4}"$ U.N.I		to floor		6	254800			
4	Hose reel com		<i>y</i> 10 11001	.,	1	277843			
•		ete with nozz	le	••••	. 1	303618			
	Bolt (\frac{3}{8}" x 1\frac{1}{4}"	_			12	255249			
	Spring washer		ng hose reel		12	3076			
	Plain washer		upport		12	4087			
	Nut $\left(\frac{3}{8}''\right)$	10 31	apport .		12	254800			
	Support for he	ose reel nine			1	277949			
	Clip for hose:			••••	1	266966			
	Set bolt (2 B.		Fixing clip and	••••	3	234603	_		•
	Spring washer		>support to hose		3		≻ 88		
	Plain washer		bobbin bracket		3	2630	L .		
6	Clip for hose	nozzle	, Dodam Diamet		1	72085			
v			ps to bobbin suppo	rt.	2	302222			
7	Bracket for he		ps to boopit suppo		1	243217			
,	Bolt $(\frac{1}{4}^n \times \frac{5}{8}^n)$	_		••••	8	25520€			
	Spring washer		in bracket		8	3074			
	Nut $\binom{1}{4}$	T T	pport		8	254800			
Ω			t and control box		1	500359			
υ			t and control box		1	503005			
	Packing plate,			••••	2	243682			
	Packing plate,	>			4	243071			
	Bolt (‡" U.N.				4	255210			
			>support to		4	3074			
	Spring washe		wheelarch box		4	254800		•	
	Nut $(\frac{1}{4}'')$		wileelarcii box		7	477000	•		

FIRE TENDER CONTROLS, PETROL MODELS ONLY, 1958-61




PLATE REF.	1 2 3 4	DESCRIPTION	Qty.	Part No.		REMAR K S
9	Bobbin for hos		2	268726	4 off on 109	
,		e, female half	2	268727 }	4 on on 107	
	Special bolt	Fixing	2	503417		
	Castle nut (5/8"		2	254911 >	4 off on 109	
	Split pin	to support	2	2555]		
	Bracket for hos		1	502997		
	Bolt (‡" U.N.F		8	255006		
	Bolt († U.N.F		8	255008		
	Plain washer	>to floor and	16	2215		
	Spring washer	seat base	16	3074		
	Nut (†" U.N.F	a 1	16	254800		
10	Control box at		1	264798		
10	Bolt (½" x ½" lo		4	255206		
	Spring washer	control box	4	3074		
	Nut (1/2)	to support	4	254800		
11	Panel for conti		1	264802		
• • •	Screw (\frac{1}{4}" \times \frac{3}{4}"		2	77936		
	Spring washer	>to	2	3074		
	Plain washer	control box	2	3840		
12		oard aperture	1	243596	88	
		oard aperture	1	503004	109	
	Drive screw fr	_	11	72626		
13		action tank to pump	1	240034		
		ressure pump to first aid hose	1	240035		
• • •		xing name plates	4	76833		
15		e, 200 lbs. sq. in	1	271732		
16	Vacuum and r	ressure gauge, 30" vacuum, 10	00 lbs.			
10	sq. in. press		1	271731		
	Screw (2 B.A.		6	78139		
	Spring washer	•	6	3073		
	Nut (2 B.A.)	to panel	6	2247		
17			1	237826	88	
• • •	Oil temperatu		1	271506	109	
	Union for gas		1	218512		
	Joint washer	_	1	3055		
	Lockwasher f		· 1	217321		
	Washer for ga		1	218751		
		mperature gauge pipe	8	41379		
	Drive screw f		8	72626		
		pressure gauge connection	1	265556		
		for pressure gauge tee piece	2	232044		
	Elbow at wat		2	268666		
		elbow to valves	3	231579		
	Distance piec		2	240109		
	Distance plec	C IOI CIDOW				





PLATE	1224 DESCRIPTION		
PLATE REF.	1 2 3 4 DESCRIPTION	Qty.	Part No. REMARKS
	Pipe, outlet valve to hose reel	. I	277781† } 88
	Pipe, outlet valve to hose reel	. I	308494* TT J
	Pipe, hose reel to union	. !	503010†
	Pipe, hose reel to union	. 1	508516 * †† > 109
	Double-ended union for pipe	. 1	240041
	Pipe, union to outlet valve	. 1	503461 J
	Pipe, tank to inlet valve	. 1	264969 88
	Pipe, tank to inlet valve	. 1	503008 109
	Pipe, outlet valve to pump	. 1	264963
18	Pipe, pump to inlet valve	1	264965
	Pipe complete, tee piece to vacuum gauge	. 1	264975
	Pipe complete, pump to pressure gauge	1	26497 3
	Double-ended union, for vacuum gauge pipe	i	3057
	Joint washer for union	1	213959
19	Water valve complete	2	240037
	Rubber grommet for water valves	. 2	303663
	Double ended union \) For water valves,	4	240041
	Washer for union pump and tank	5	243962
21	Support bracket for governor quadrant	1	237549
	Bolt (‡" U.N.F. x §" long)	2	255006
	Spring washer Fixing quadrant	2	3074
	Nut (¼" U.N.F.) to support bracket	2	254800
	Bolt (2 B.A. x ½" long)	1	234603
	Spring washer Fixing quadrant	1	3073
	Plain washer to control box	2	2630
	Nut (2 B.A.)	1	2247
	Governor unloading spring	i	218051
	Link plate \ For	 1	242928 > 2 litre models
	Wire link spring	i	242927 S and models
	Ball joint complete for governor control cable	i	219065
	Locknut (‡" B.S.F.) for ball joint	ำ	2823
	Spring washer \ Fixing ball joint	2	3074
	Nut (‡" B.S.F.) to quadrant	i	2823
	Special screwed adaptor for governor control cab	ا ام ا	504458
	Screwed extension rod for governor control cable		504459 88
	Screwed extension rod for governor control cable		240410 109
		1	504667
	Swivel coupling for control		73892
	Drive screw fixing swivel to frame	1	243668 88
	Conduit for control cable, connector to swivel		
	Conduit for control cable, connector to swivel		
	Conduit for control cable, connector to connecto		233102
`	Conduit for control cable, governor to connector	l 1	233103 2 litre models
	Conduit for control cable, governor to connector	1	506296 2½ litre models
	Clamp connector for conduit	2	500569
	Nipple	1	233093
	Split pin	l ,	2388
	Swivel complete Fixing	1	233094
	Bracket for overslider conduit to	1	233100 2 litre models
	Bracket for overslider overslider cable	ļ	506284 2½ litre models
	Shakeproof washer	- 1	233017
	Nut $(\frac{5}{8}$ B.S.F)	1	250407

^{1 2 3 4}


151001059 152003119 154002220 onwards

^{*} Asterisk indicates a new part which has not been used on any previous model.

FIRE TENDER CONTROLS, PETROL MODELS ONLY, 1958-61



	TIKE	יונינענויייו ו	CONTR	·OLD,		INOL	MODELS ONLI, 1990-01	
PLATE REF.	1 2 3 4	DESCRIPT	ION		Qty.	Part No		
	Overslider cable				1	244419		
	Bracket for cond		-	••••	1	237819	2 litre models	
	Bolt (16" Whit.	x ½ long)	Fixing cond	luit clip	1	215761		
	Spring washer		≻bracket to in	nlet	1	3075	•	
		J	manifold			_	_	
	Clip for conduit	t			5	237813	>4 off on /4 litra models	
	Drive screw fixi	ng clips	••••		5	72626	·) -	
	Nipple, conduit	to control ca	ble and swive	el	2	233093	_	
22	Hose box R.H.			••••	1	508227	388	
23	Hose box L.H.	****			ł	508228		
	Hose box R.H.	****			1	508283		
	Hose box L.H.				1	508284	J	
	Distance piece f				2	503410		
	Bolt $(\frac{1}{4}$ " x $\frac{5}{8}$ " lor				18	255206		
	Spring washer	>hose b			18	3074		
	Nut (‡")	J to bod			18	254800	_	
	Support bracket				3	506289	1	
	Support bracket				3	506290	3	
	Pop rivet fixing		-	apping	18	300781	4	
	Bolt (¼" U.N.F.	x 🖁 long)			6			
	Plain washer		≻support		6	2760	4	
	Spring washer		bracket to		6	3074	•	
	Nut (½" U.N.F.		wheelarch		6	254800		
	Reinforcement	•	F: *		2	500566	XXX	
	Bolt (½" x 1½" k		Fixing		4	256000		
	Bolt (‡" U.N.F.	. x 👸 long)	≻hose box to	1	4	255206	· ·	
	Plain washer		wheelarch a		4	3840	_	
	Spring washer	,	support bra	ckets	4	3074	> III Att on IIIV	
	Nut (½" U.N.F.	_	J J J.		4 8	254800 300781		
	Pop rivet fixing Cover plate for			L	2	503433		
	Pop rivet fixing			aren	20		.	
	Bolt access plate	_	and the second s		2	503448		
	Drive screw fixi	•		ate	8	72626		
24	Cover for hose				1	508239		
25	Cover for hose			••••	1	508257		
26	Hook assemb			••••	4	503169		
	Top strip for h				2	500399		
	Bottom strip fo				1	500400		
	Rivet fixing cov	er and strip			. 10	300784		
27	Hook catch 1		е		4	503163	•	
28	_ >.	box cover			4	243767		
	Rivet fixing hoo	ok catch to be	dy		8	300781		
	Bracket for from				. 1	303662	· ·	
	Bult (4 x 5 lo	ng)] Fixing	bracket to fr	ont	4	255206		
	Spring washer	bumpe	r and radiato	r	4	3074		
	Nut (½")	top ba	fle		4	254810		



		COMINO	LL, II.	INOL	MODELS ONLI,	1330-01
PLATE REF.	1 2 3 4 DESCRIPT	TION	Qty.		RE	MARKS
	Front cradle		1	243851		
	Bolt $(\frac{1}{4}^n \times \frac{3}{4}^n \text{ long})$ Fixing	g cradle	2	255207		
	Spring washer >to		2	3074		
	Nut $(\frac{1}{4}'')$ \int bracke	et	2	254810		
	Support strap for front crad	le	2	503015		4
	Bolt $(\frac{1}{4}^n \times \frac{3}{4}^n \text{ long})$ Fixing	g straps	2	255207		
	Spring washer >to		2	3074		
		bracket	2	254810		
29	Side cradle	****	2	303654	·	•
	Bolt (‡" x ½" long)] Fixing	side cradle	14	255206		
	Spring washer >to		14	3074		
	Nut (1/2) front v	wings	14	254800		
	Stiffener for front wing top		2	303658		
	Pop rivet fixing stiffener	****	6	300919		
	Support strap, for front crac	ile	1	243853		
	Rivet \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		2	305665		
	Plain washer ∫ cradle brack	æt	2	3816		
30	Strap for hose cradles, side		2	303650		
	Instantaneous buckle		2	303568		
	End cap		2	303954		
	Eyelet		2	300785		
	Rivet \(\bigcap \) Fixing strap	s	24	302186		
	Plain washer ∫ to cradle		24	3816		
31	Suction hose adaptor, 3" dia		1	265190	(3'') type. Alternative to $4''$	<u>`</u> .)
	Joint washer for adaptor,	3" diameter	1		Check before ordering.	
	Suction hose adaptor, 4" dia		1	509860		Optional equipment
	Cap for adaptor, 4" diameter		· 1	509861	>4" type. Alternative to 3"	. >to suit British
	Joint washer for cap, 4" d	iameter	1	509866	Check before ordering.	standard couplings
32	Delivery hose couplings	••••	2	265185		
	Joint washer for delivery hos	se couplings	4	266815		
	Suction hose spanner		1	268245		J
	Support for foam generator		1	244687		
	Support for foam generator	L.H	1	244688		
	Bolt (2 B.A. $x \frac{3}{8}$ long)		6	237119		
		ixing supports	6	2226		
	Special nut		6	4017	•	
	Rear step	••••]	273523		
	Rubber mat for step	****	1	273529		
	Retainer for mat, rear	••••]	273530		
	Retainer for mat, front	••••	1	273531		
	Retainer for mat, side	****	2	273532		
	Rivet fixing mat and retainer	r	16	78349		
	Bracket for rear seat	••••	2	502998		
	Support bracket for rear sea	t	2	503002		
	Bolt (½" U.N.F. x ½" long)		6	255008		
	Plain washer	Fixing bracket	6	2760		
	Spring washer	to frame	6	3074		
	Nut (½" U.N.F.)	j	6	254800		





PLATE REF.	1 2 3 4 DESCRIPT	ION		(Qty.	Part No.	REMARKS
	Rear seat base complete				1	273979	•
	Plain washer for seat base				2	3898	
	Bolt (1" U.N.F. x 1" long))			4	255008	
	Plain washer	Fixing s	eat base	to	4	2760	
	Spring washer	support	bracket		4	3074	
	Nut (‡" U.N.F.)				4	254800	
	Rear spring, driver's side				1	272967	
	Rear spring, passenger's side	.			1	272968	≻88
	15 17		••••		2	279762	
	'U' bolt for rear spring	,			4	242926	2 litre models
	Front spring, driver's and pa	assenger's			2	264563	2 litre models
	Front spring, driver's side				1	265627\	88, 2½ litre models
	Front spring, passenger's sic	le			1	264563	OO, 24 little models
	"U" bolt, long \ For fron				1	265068)	>88 models
	"U" bolt. short springs				3	ر 06694	oo modeis
	Shock absorber, front				2	512102)	≻88
	Shock absorber, rear		• • • •		2	512086 J	~00
	Tyre (7.00 x 16")				5	242861 \	>88
	Tube (7.00 x 16")		••••		5	233042 J	700
	Tyre (7.50 x 16")				5	502527	>109
	Tube (7.50 x 16")		••••		5	270324 J	



	IKAILEK, DKAWDAK	
PLATE REF.	1 2 3 4 DESCRIPTION Qty.	Part No. REMARKS
	TRAILER COMPLETE ASSEMBLY 1	502953
1	Drawbar frame 1	279419
2	Bolt (1" B.S.F. x 12" long) Fixing drawbar 2	250572
3	Spring washer to body 2	3078
4	Nut (½" B.S.F.) at front 2	2269
5	Bolt (½" B.S.F. x 1¾" long) Fixing drawbar 2	250572
6	Lock washer to body 4	279420
7	Nut (½" B.S.F.) at rear 4	251324
8		279421
9		279422
	Dottom place for monoring	217322
10		250579
	(½" B.S.F. x 3½" long) > plate to drawbar 4	251324
11	Nut (½" B.S.F.) J frame 4	
12	Pull pin l	279423
13	Pinch bolt (§" B.S.F. x 1" long) 1	250539
14	Over-run spring 1	232253
15	Thrust washer for spring 2	232254
16	Special split cotter, pull pin to housing	232255
17	Locking handle for tow ball	232256
18	Bolt (½" B.S.F. x 25" long) l	250576
19	Castle nut (½" B.S.F.) Fixing	2451
20	Split pin blocking handle	2425
21	Split pin J to pull pin 1	279424
22	Spring, locking handle 1	232257
23	Split pin fixing spring 2	3179
24	Safety catch for locking handle 1	279426
25	Special screw \ Fixing safety catch	232259
26	Spring Spring 1	279427
27	Gaiter for pull pin 1	279425
28	Towing ball 1	232264
29	Bolt (5" B.S.F. x 21" long) Fixing towing ball 2	273879
30	Nut ($\frac{5}{8}$ " B.S.F.) \int to chassis frame 4	219668
31	Hand brake lever	279428
32	Pawl for hand brake 1	279429
33	Bolt (18" B.S.F. x 11" long) Fixing pawl to	237163
34	Nut $(\frac{5}{16}" B.S.F.)$ handbrake lever 1	251321
35	Bolt (76" B.S.F. x 13" long) Fixing hand	250559
36	Plain washer brake lever 2	2257
37	Nut $(\frac{7}{16}$ B.S.F.) to drawbar	251323
38	Pull off spring for hand brake 1	232270
39	Bolt (\frac{1}{4}" B.S.F. x \frac{1}{2}" long) \frac{1}{2} Fixing spring	250517
40	Nut (‡" B.S.F.) to drawbar	251320
41	Swinging link for hand brake 1	232271
42	Bolt (\frac{3}{8}" B.S.F. x 1\frac{3}{4}" long) \tag{Fixing link}	250544
43	Distance piece > to 2	279450
44	Self-locking nut (\frac{3}{8}" B.S.F.) \int \text{drawbar} \tag{2}	251322
45	Tell locating man (6 Divisity) and the	279430
	~	279431
46 47		237163
47	2010 (16 = 1211 2 2 3	2827
48 40	1401 (18 15:511.)	251321
49	Nut (5 B.S.F.) J handbrake I	Mr 1.748 (





PLATE REF.	1 2 3 4 DE	SCRIPTION	Qty.	Part No.	REMARKS
50	Front protecting foot		1	232279	
51	Bolt (1" B.S.F. x 13")	ong)] Fixing foot	2	250572	
52	Spring washer	>to	2	3078	
53	Nut (½" B.S.F.)	drawbar drawbar	2	2269	
54	Supporting leg		1	279432	
55	Bracket for leg		1	232281	
56	Locking ring for leg		1	232282	
57	Handle, locking leg in	bracket	1	232283	
58	Split pin, retaining ha	ndle	1	2397	
59	Retaining chain for le	g	1	232284	
60	Bolt (3" B.S.F. x 11"	long)] Fixing bracket	3	250541	
	Bolt (3" B.S.F. x 13")	ong) >and retaining	1	250542	
61	Spring washer	chain to	4	3076	
62	Nut (3" B.S.F.)	drawbar drawbar	4	2827	


TRAILER, AXLES, BRAKES AND HUBS



TRAILER, AXLES, BRAKES AND HUBS

		I I I I I I I I I I I I I I I I I I I	,		
PLATE REF.	1 2 3 4	DESCRIPTION	Qty	. Part No.	 REMARKS
1	Axle complete		1	279433	 <u>-</u>
2	Anchor plate comple	ete	2	262973	
3	Grease nipple for		2	232287	
4	Bolt (%" B.S.F. x 118		nchor 4	237179	
. 5	Spring washer	>plate to	axle 4	3076	
6	Nut (§" B.S.F.)	fitting	4	2827	
7	Operating cam for b	rake shoe L.H.	1	262974	
8	Operating cam for b	rake shoe R.H.	1	262975	
9	BRAKE SHOE AS		4	500115	
10	Lining for brake	shoe	4	500116	
11	Rivet for lining		32	500117	·
12	Pull off spring for b	rake shoe	4	262977	
13	Operating lever for	brake shoe	2	262978	
14	Spring washer	Fixing lever	2		
15	Locknut (3" B.S.F.)	∫to cam	2	2827	
16	Brake drum		2	279434	
17	Bolt (%" B.S.F. x 17	" long) \ Fixing b	rake drum 8		
18	Spring washer	∫ to hub f	lange 8		
19	Brake rod		2	279435	
20	Compensating bar f	or brake linkage	1	232298	
21	Jaw for brake rod		4		•
22	Locknut (5 B.S.F	.) for jaw 🧎 Fixing	g brake rods 4		
23	Pin	>to ope	-		
24	Plain washer	L L	and com- 8		
25	Split pin		ting bar 8		
26	Double ended jaw		1	279436	
27	Pin) Fix	ing double ended j	aw 2		
28		ompensate bar and	l 4		
29		nging link	4		
30	HUB ASSEMBLY				
31	Stud for road wh	eel	10		
32	Nut for road wheel		10		•
33	Distance piece for h	ub	2		
34			2		
35	Roller bearing, inne		2		
. 36	Roller bearing, oute		2		
37	Castle nut ($\frac{5}{8}$ B.S.F		2		•
38	Split pin	∫ to axle	2		
39	Hub cap	····	2	279442	

TRAILER BODY, SPRINGS AND ROAD WHEELS



TRAILER BODY, SPRINGS AND ROAD WHEELS

PLATE	1 2 3 4 DESCRIPTION	Qty.	Part No.	REMARKS
REF.	BODY ASSEMBLY	1	232309	
1	Body complete	1	232310	
2	Tailboard complete	1	232311	
3	The 111 1	4	279443	
4	01 1 (1: 1	4	232313	
5	Bolt (¹ / ₄ " B.S.F. x ³ / ₄ " long) Fixing	4	237141	
6	Spring washer >chassis	4	3074	
7	Nut (½" B.S.F.) to body	4	2823	
8	Registration plate	i	232316	
9	Distance piece for plate	4	232315	
10	Screw (4" B.S.F. x 1" long) For redu	-	69215	
11	Spring washer holes in	4	3074	
12	Nut (½" B.S.F.) tailboard		2823	
13	n . 1	2	232317	
14	Special bolt Fixing stand	4	232318	
15	Spring washer >to	4	3076	
16	Nut (\frac{1}{8}" Whit.) body	4	232319	
17	Wing complete	2	232320	
18	Special bolt Fixing wing	20	232321	
19	Spring washer to body	20	3074	
20	Nut (1/4" Whit.) panel	20	2267	
21	Road spring complete	2	279444	
22	Top plate for spring	2	279445	
23	Bottom plate for spring	2	232326	
24	'U' bolt for spring	4	232327	
25	Nut (½" B.S.F.) \ For	8	251324	
26	Locking plate ('U' bolt	4	279446	
27	Spring shackle, shouldered	2	279447	
28	Spring shackle, plain	2	279448	
29	Spacing washer for front shackle	4	279449	
30	Shackle pin	6	250606	
	Grease nipple for shackle pin	6	512420	
31	Self-locking nut (1 B.S.F.) for shackle	pin 6	251326	
32	Road wheel	2	231601	
33	Tyre, 6.00" x 16"	2	239742	
	Inner tube, 6.00" x 16"	2	232122	•
34	Stop, tail lamp	2	503054	
	Bracket for lamp and reflector R.H.	1	502968	
35	Bracket for lamp and reflector L.H.	1	502969	•
	Bolt ($\frac{1}{4}$ " B.S.F. $x \frac{3}{4}$ " long) $\int Fixing$	4	237141	
	Spring washer bracket	4	3074	
	Nut (‡" B.S.F.) to body	4	2823	
36	Flasher lamp	2	502952	
37	Plug and cable for tail lamp	1	503174	
	Connector angle	2	3549	
38	Socket and cable for tail lamp on chassi		510081	·
39	Dummy socket	1	501270	
	Rubber grommet, small, for cable	1	232335	
40		2	232336	
	Earth bridge lead]	500696	
	Cover complete for trailer	1	261827	•

TRIMMING RAW MATERIALS

PLATE 1 2 3 4 DESCRIPTION	Qty. Part No.	DEMARKS
C-4 1 .1 72" ·1 11 1		REMARKS
	As required 91957	
Cotton duck, 72" wide, blue	As required 91899	
Sheet wadding, 36" wide open	As required 91341	
Cotton webbing, 32" x 1", khaki-green	As required 91878	•
Cotton webbing, § x 1", khaki-green	As required 91880	<u>.</u>
Cotton webbing, 54" x ½", khaki-green	As required 91879	
Cotton webbing, & x ½", blue	As required 91901	
Cotton webbing, \(\frac{1}{8} \) \times \(\frac{1}{8} \) \(\fra	As required 91902	
Cotton webbing, ½" x 1", blue	As required 91900	
Seaming cord	As required 91171	•
Thin plain cloth, 38" wide	As required 91829	
Black canvas, 54" wide	As required 91291	
Grey felt	As required 91414	
Black felt, 50" wide	As required 91819	
Leather cloth, grey, 50" wide	As required 91979	
Leather cloth, red	As required 91832	
Special leather cloth, white, 36" wide	As required 91911	•
White leather cloth, 50" wide	As required 91950	
Piping, green	As required 91857	
Thread, green, No. 18	As required 91814	
Thread, blue, No. 18	As required 91896	
Thread, blue, No. 25	As required 91894	
Thread, grey, No. 25	As required 91960	
Thread, green, No. 25	As required 91813	
Adhesive tape, 1" wide	As required 91928	
Thread, grey, 250 denier	As required 92042	
Thread, black, No. 50	As required 91256	
Thread, red, No. 25	As required 92046	
Plastic cloth, blue check, 54" wide	As required 91912	
Natural felt, 54" wide	As required 91890	
Felted leather cloth, white, 52" wide	As required 91970	
Felted plastic, blue, 52" wide	As required 91909	
Felted plastic, 52" wide, green	As required 91962	
Felted plastic, black	As required 91965	
Black cloth, 72" wide	As required 91913	•
Cotton webbing, ½" x 1", blue	As required 91900	
Fine fluted rubber matting, 36" wide	As required 261577	
Special paint, bronze green, 1 pint tin	As required 262069	
Special paint, bronze green, 1 gallon tin	As required 262072	
Special paint, ivory, 1 pint tin	As required 262643	
Special paint, ivory, I gallon tin	As required 262646	
Special paint, blue, 1 pint tin	As required 244272	
Special paint, blue, I gallon tin	As required 244275	
Special paint, poppy red, 1 pint tin	As required 244276	
Special paint, poppy red, I gallon tin	As required 244279	
· · · · · · · · · · · · · · · · · · ·		

TRIMMING RAW MATERIALS

PLATE 1 2 3 4 DESCRIPTION	Qty. I	Part No.	REMARKS
Special paint, light green, 1 pint tin	1	503927	
Special paint, light green, I gallon tin	1	503928	
Special paint, sand, 1 pint tin	1	503929	
Special paint, sand, 1 gallon tin	1	503930	
Special paint, dark grey, 1 pint tin	1	503931	
Special paint, dark grey, I gallon tin	Ī	503932	
Special paint, mid-grey, 1 pint tin	1	503933	•
Special paint, mid-grey, 1 gallon tin	1	503934	
Special paint, marine blue, I pint tin	T	503935	
Special paint, marine blue, I gallon tin	1	503936	
Special paint, off white, 1 pint tin	1	503937	
Special paint, off white, I gallon tin	1	503938	
Special paint, limestone, 1 pint tin	1	510032	
Special paint, limestone, 1 gallon tin	1	510033	
Aerosol paint spray, bronze green	1	507821	
Aerosol paint spray, sand	1	507822	
Aerosol paint spray, limestone	1	507823	
Aerosol paint spray, light green	1	507824	
Aerosol paint spray, marine blue	1	507825	
Aerosol paint spray, mid-grey	1	507826	
Aerosol paint spray, dark grey	1	507827	
Aerosol paint spray, poppy red	1	507828	
Thinners, 1 pint tin	As required	1 261906	
Thinners, I gallon tin	As required	261909	
Brake fluid, 1 pint tin	As required	260681	
Brake fluid, I quart tin	As required	262079	
₹" Welding rod (1 lb.)	As required	98018	

TOOLS

Lift	eel brace ting jack		_		•	ty.	Part No.	REMARKS
	ting iack			****		1	274433	
	ring Jucis	Shelley)		1	514623)
Han	ndle for jack	Snelley		Ratchet		1	514624	
Lift	ting jack	Metalli	f	type jack	ς .	1	513071	Alternatives. Check before ordering
	ndle for jack	J	racture	J		1	513072	
	ension for jac			r screw		1	261512	
Wo	oden handle	for extensio	n ∫typ	oe jack		1	261513	
	re pump					1	523638	k
C	Connection fo	r tyre pump)			1	524959	
	ase gun	****				1	503424	
	rting handle		٠,			1	218508	
	ol roll			••••		1	219704	
	nbination pli	ers				1	2703	
	ewdriver		••••			Ī	234619	•
	nner $\frac{3}{16}$ " x $\frac{1}{4}$ "					1	2705	
	nner $\frac{5}{16}$ " x $\frac{7}{16}$			****		1	230736	
	nner, single o		worth			1	277320	
	nner $\frac{7}{16}$ " x $\frac{1}{2}$ "			••••		1	276396	
	nner 116" x 3'			****		1	277217	
	nner $\frac{5}{8}$ " x $\frac{9}{16}$ "		• • • • •			l	276397	
	nner, single e		₹.			1	503125	For distributor pump bleed screw
	ustable spanr		•			!	2707	
	tributor screv					1	240836	
	rking plug sp			****		i	276322	
	ension for plu	ıg spanner	••••	****		1	276323	
	spanner		• • •	****		1 .	52485	
	nmy bar					1	1403	
	e pressure ga	uge		••••		1	277372	
Tyre	e lever					2	233261	Optional equipment

568

NUMERICAL INDEX

This list, in part number numerical order, gives the page on which the item will be found.

		i nis lis	at, in part m	ımbei	numen	cai order, g	ives in	e page (on winch th	C ICCIII	WIII DC	Tourier		
Part No.	Page	e No.	Part No.	Pag	e No.	Part No.	Pag	e No. 1	Part No.	Pag	e No.	Part No.	Pag	e No.
1403		568	2705		568	3485		453	3939		439	04799		215
1481		33	2707		568	3490		19	3946		137	04800		215
1510		193	2728		247	3549		476	3947		357	04965		197
1643		161	2729		247	3557		427	3958		233			
1645		157	2760		351				3960		289	05366		177
1659		223	2765		76	3604		15	3966		187	05843		151
1664		75	2766		177	3619		265	3968		279	05852	,	161
						3621		459	3972		245	05853		161
2102		13	2822		189	3622		267	3974		289	05854		161
2204		393	2823		27			459	3976		287			
2208		203	2827		25			474	3982		273	06009		177
2210		33	2828		21			41	407.1		105	06395	•	157
2213	••••	67	2836		155			41	4011		185	06397	• • • •	157
2215		293	2842		19	3662		187	4013		547 240	06402 06405		157 157
2217		155	2851	• • • • •	215	3665	•	261	4020	••••	269 529	06417	••••	151
2218	• • • • •	201	2869		371	3668	****	287	4022 4023	••••	273	06419	••••	151
2219		41	2876	••••	169	3674 3680		41 189	4030	• • • • • • • • • • • • • • • • • • • •	245	06421		161
2220		57	2010		475	3685	••••	233	4032	****	289	06422		161
2223	****	219 225	2910 2920		475 95	3697	****	161	4042		273	06424		153
2224		199	2920 2974		201	3091	••••	101	4047		351	06694		557
2226 2228		251	2980	****	157	3739		51	4063		211	06735		177
2247		23	2981		215	3746	****	17	4067		377	06800		269
2249		95	2983		341	3748	••••	55	4071		295	06846		151
2250		403	2995			3764		169	4075		357	06860		199
2251		213				3771		33	4082		265			
2257		225	3005		21	3783		33	4094		453	07014		389
2258		223	3040		455	3787		33	4095		25	07015		389
2260		493	3050		393							07091		215
2266		147	3052		189	3803		9	4115		183	07118		151
2267		565	3055		15	3815		467	4132		453	07164		201
2284		197	3057		545	3816		267	4148		75	07289		151
2285		351	3072		433	3817		357	4171		281	07316		177
2289		299	3073		15	3821		299	4200	••••	267	07884	••••	13
2290		201	3074		9	3823		185	4203	••••	291	07902 07904	••••	177 177
2299		5 63	3075		15	3828		455	4233 5667		453 265	07904		177
2210		202	3076	• • • •	25	3829		359 67	6316		15	08185		157
2310		203 371	3077		15 391	3830 3831	****	273	6395		ii	08188		. 157
2323 2337		419	3078 3088	••••	19	3833		291	7853	****	281	08250		157
2338		419	2000	****	. 17	3840		187	8060		391	08566	,	41
2347		403	3101		245	3841		285	8885		103			
2388		201	3136		247	3842		273	9499	••••	15	09004		19
2389		169	3179		559	3850		215				09005		19
2392		13	3200		41	3851		185	01017		157	. 09013		51
2393		189	3236		151	3852		337	01035	• • • • •	21	09017		11
2396		177	3238		151	3864		335	01291	••••	9	09023		17
2397		561	3259	• • • •	159	3867		347	01384	,	201	09025		21
			3279		185	3868		39	01564		173	09034		421
2422		21	3280		263	3885	****	253	01565		173	09038		421
2423		231	3289	••••	153	3886	••••	289	01645	• • • • •	27	09049 09050		21
2425	••••	559	3290	• • • •	41	3895		299 299	03017		11	09052		21 21
2428		159	3291	• • • • •	151	3896 3898	• · · •	187	03017	••••	ii	09065		9
2451	• • • •	559 167	3292	• • • • •	181	3899		271	03020		ii	09075		17
2499		167	3294 3299		175 205	1 3077 .	••••	١ ١ ۵	03040		411	09091		· i7
2500		17	J <u>477</u>		207	3900	****	241	03092		ii.	09093		iź
2504		21	3300		159	3901		289	03093		ii	"""		• •
2529		159	3319		151	3902		293	03129		9	09102		23
2550		23	3359		31	3905		167	03188		11	0 9 118	••••	27
2555		17	3413		411	3911		35	03649		161	09122		. 19
2556		421	3421		167	3912		287	03748		113	09126		17
			3425		415	3925		363	03971		263	09128		17
2678		199	3446		289	3933		373	0.4500		215	09129		17
2703	,	568	3466		75	3936		23	04788		215	09156	·	17

OBJOS 19 50235 245	Part No.	Pag	ge No.	Part No.	Pa	ge No.	Part No.	Pas	ge No.	Part No.	Pa	ge No.	Part No.	Pa	ge No.
OBIGIT 33 50302 245 70742 433 78171 339 91902 566 50070 27 50306 433 70822 199 78193 399 91911 566 566 50170 33 30310 415 70824 49 78205 313 31912 566 569 5	09159		19				•					-			
1997 1997 1998 1999		,								78171					
OBJECT STATE STA	09162			50304											
OBJ64		••••									****				
Oil 9			33					• • • • •			****				
09197							71082			78208		241			
09203										79210		207	91928		
09205							72003 72614								
O9207															
O9210															
09210	O9208		17												
09925							73198		269	78223					
09996 19 50499 97 73353 381 78227 219 2042 566 09977 157 50526 155 73962 551 78233 251 92042 566 09997 157 50526 155 73992 501 78237 221 197188 483 09950 157 50637 247 74236 185 78248 269 98018 567 09961 157 50640 265 75846 257 78256 243 09961 157 50642 265 75806 257 78256 243 10713 143 50690 419 76633 167 78256 243 1082 221 50690 449 776633 549 78260 233 210211 41 10813 50690 419 776630 91 78296 501 21011 42 11378 177 </td <td>09225</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>••••</td> <td></td> <td></td> <td></td> <td>327</td> <td></td> <td></td> <td></td>	09225							••••				327			
09917 157 50526 381 73892 551 78233 557 22946 566 09931 157 50526 255 738952 501 78237 241 97188 483 09931 157 50552 255 73979 271 78240 241 97188 483 09961 157 50639 267 75454 265 78255 243 99710 483 09961 157 50640 256 75805 257 78256 243 09962 157 50640 256 75805 257 78256 243 09962 157 50642 267 75940 167 267 267 267 267 267 267 267 267 267 2		••••					73352	****		78226	****				
157 50525 155 73962 501 78237 244 97188 483					••••			****			••••		92042		566
099931	09917							••••			••••				
099922 157 50637 247 74236 185 762485 229 99710 483 09961 157 50640 265 75805 257 78256 243 200961 157 50640 267 75940 199 78257 243 210203 161 109962 157 50642 267 75940 199 78257 243 210204 161 10211 257 50689 259 76833 167 78260 359 210211 41 10713 143 50690 419 77526 87 78260 359 210419 27 10882 221 50693 479 77526 87 78274 343 210419 27 11378 177 50703 157 77700 493 78203 313 210517 23 11379 177 177 277 78313 313 210572 39 <td>09931</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>73902 73070</td> <td></td> <td></td> <td>70227</td> <td></td> <td></td> <td></td> <td></td> <td></td>	09931						73902 73070			70227					
09960 157 50649 267 75454 265 78255 243 99710 483 09962 157 50640 265 75805 257 78255 243 210203 161 10211 257 50647 547 76633 167 78260 359 210201 161 10211 257 50690 419 776833 549 78260 359 210419 27 10882 221 50693 479 77626 87 78274 343 210419 27 11378 177 50702 157 77700 493 78333 313 2105617 23 11379 177 77700 473 78333 319 210572 39 11820 199 52015 11 77707 271 78313 319 210572 39 12028 21 52246 151 777784 279 78325 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>••••</td><td></td></t<>														••••	
09961													99710		483
1000 1000										78256					
10211	09962											341			
10882					••••		76653								
10882		••••					76833		549			359			
1378															
11378	1 0882		221		•			••••		78274	••••				
11379	1 1279		177					•			••••	501			
11820	1 1379			20102	••••	157						210	210572		
12028				52015		11	77707			78310		365			17
12028	020	••••	.,,							78321		515			
12455			21										211064		27
12738 263 52485 568 77816 267 78358 291 211502 159 12743 265 52710 21 77840 305 78382 343 13604 483 55636 151 77861 183 78392 293 212042 27 13605 483 55638 161 77869 185 78393 293 212008 15 13606 483 55636 151 77861 183 78392 293 212008 15 13606 483 55636 161 77887 279 78399 305 212104 27 13607 483 55705 159 77892 363 78401 337 212137 19 13608 483 55715 157 77899 273 78402 337 212160 19 13609 483 55715 157 77903 301 78417 285 212161 19 13609 483 55714 393 77918 476 78429 476 212232 33 20034 501 55775 161 77926 449 78436 307 212308 21 20147 501 55775 157 77932 273 273 2443 291 212233 33 20138 501 55778 151 77926 449 78436 307 212308 21 223326 89 77936 549 78869 339 212328 19 22596 480 56102 161 77941 187 212329 19 229979 253 56140 41 77949 363 86603 35 212309 21 23326 89 77936 549 78869 339 212328 19 40441 35 56666 199 77992 261 91171 566 212332 9 40441 35 56666 199 77993 291 91256 566 212334 15 40756 177 56657 267 27806 103 91414 566 212334 15 40760 177 576667 267 27806 103 91414 566 212334 17 40760 177 57126 9 78116 363 91814 566 212340 17 40760 177 59053 11 78120 291 91819 566 212365 17 41109 369 59054 11 78120 291 91819 566 212365 17 41109 369 59054 11 78120 291 91875 566 212365 17 41109 369 59054 11 78120 291 91879 566 212365 17 41131 369 59059 15 78126 289 91857 566 212365 17 41131 369 59059 15 78126 289 91857 566 212365 17 41139 199 59155 23 78130 273 91890 566 212356 251 42318 197 59663				52278						78331		293			
13604									267	78358			211502		159
13604	1 2743		265	52710		21	77840	•				343	·		
13605 483 55638 161 77869 185 78393 293 212103 379 13606 483 55697 161 77887 279 78399 305 212104 27 13607 483 55705 159 77892 363 78401 337 212137 19 13608 483 55714 157 77899 273 78402 337 212160 19 13609 483 55715 157 77903 301 78417 285 212161 19 55742 393 77918 476 78429 476 212232 33 20034 501 55775 161 77925 361 78434 291 212233 33 20138 501 55778 151 77992 273 78443 261 212308 21 23326 89 77936 549 78869 339 212328 <td< td=""><td>12404</td><td></td><td>402</td><td>EE (2)</td><td></td><td>161</td><td></td><td>••••</td><td></td><td></td><td>••••</td><td>357</td><td></td><td>•···</td><td></td></td<>	12404		402	EE (2)		161		••••			••••	357		•···	
13606 483 55697 161 77887 279 78399 305 212104 27 13607 483 55705 159 77892 363 78401 337 212160 19 13608 483 55714 157 77899 273 78402 337 212160 19 13609 483 55715 157 77903 301 78417 285 212161 19 20034 501 55775 161 77925 361 78434 291 212233 33 20138 501 55778 151 77926 449 78436 307 212308 21 20147 501 55779 375 77932 273 78443 261 212309 21 23326 89 25996 480 56102 161 77941 187 29979 253 56140 41 77949 363 80603 35 212330 19 40742 177 56667 267 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>••••</td> <td></td> <td></td> <td>••••</td> <td></td> <td></td> <td></td> <td></td>								••••			••••				
13607 483 55705 159 77892 363 78401 337 212137 19 13608 483 55715 157 77899 273 78402 337 212160 19 13609 483 55715 157 77903 301 78417 285 212161 19 20034 501 55775 161 77925 361 78434 291 212232 33 20147 501 55779 375 77932 273 78443 291 212338 21 23326 89 77936 549 78869 339 212328 19 25996 480 56102 161 77941 187 212329 19 29979 253 56140 41 77949 363 80603 35 212330 19 40742 177 56666 199 77993 291 91256 566 212332 9 40742 177 56657 267 978114 185 9181 <td>13606</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>70292 79200</td> <td></td> <td>293 205</td> <td></td> <td></td> <td></td>	13606									70292 79200		293 205			
13608 483 55714 157 77899 273 78402 337 212160 19 13609 483 55715 157 77903 301 78417 285 212161 19 55742 393 77918 476 78429 476 212232 33 20034 501 55775 161 77926 449 78434 291 212333 33 20147 501 55779 375 77932 273 78443 261 212308 21 20147 501 55779 375 77932 273 78443 261 212309 21 23326 89 77936 549 78869 339 212328 19 25996 480 56102 161 77941 187 29979 253 56140 41 77992 261 91171 566 212332 9 40742 177 56666 199 77993 291 91256 566 212334 15 <tr< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr<>															
13609												337			
20034	13609					157	77903		301	78417		285	212161		
20034 501 55775 161 77925 361 78434 291 212233 33 20138 501 55778 151 77926 449 78436 307 212308 21 20147 501 55779 375 77932 273 78443 261 212309 21 23326 89 77936 549 78869 339 212328 19 25996 480 56102 161 77941 187 212329 19 29979 253 56140 41 77949 363 80603 35 212330 19 40441 35 56666 199 77993 291 91256 566 212332 9 40742 177 56667 267 91291 566 212333 15 40756 177 56854 159 78001 15 91341 566 212334 15 40758				55742		393				78429			212232		
20147 501 55778 151 77926 449 78436 307 212308 21 23326 89 77936 549 78869 339 212328 19 25996 480 56102 161 77941 187 212329 19 29979 253 56140 41 77949 363 80603 35 212330 19 212329 212330 19 212329 212330 19 212329 212330 19 212329 212330 19 212329 212330 19 212339 212330 212334 15 212334 15 212334 15 212334 15 212334 15 212334 15 212334 15 212334							77925		361	78434			212233		
23326 89 77936 549 78869 339 212328 19 25996 480 56102 161 77941 187 212329 19 29979 253 56140 41 77949 363 80603 35 212330 19 40441 35 56666 199 77992 261 91171 566 212332 9 40742 177 56667 267 91291 566 212333 15 40756 177 56854 159 78001 15 91341 566 212334 15 40758 177 57126 9 78114 185 91813 566 212340 17 40760 177 58702 201 78116 363 91814 566 212341 17 41049 177 58702 201 7816 363 91814 566 212363 17 41030 369 59054 11 78120 291 91819 566 212365							7 7926					307	212308		21
25996	ZU147	•		55779		375		••••							
29979 253 56140 41 77949 363 80603 35 212330 19 40441 35 56666 77992 261 91171 566 212332 9 40742 177 56666 267 91291 566 212333 15 40756 177 56854 159 78001 15 91341 566 212339 17 40760 177 57126 9 78114 185 91813 566 212340 17 40760 177 58702 201 78116 363 91814 566 212340 17 41049 <	25006			54100		171		••••		78869		339	212328	••••	
40441										80602		25	212329		
40441 35 56666 199 77993 291 91256 566 212333 15 40742 177 56667 267 91291 566 212334 15 40756 177 56854 159 78001 15 91341 566 212339 17 40758 177 78006 103 91414 566 212340 17 40760 177 58702 201 78116 363 91813 566 212341 17 41049 177 58702 201 78116 363 91814 566 212363 17 41050 369 59054 11 78120 291 91819 <	-///	****	رري												
40742 177 56667 267 40756 177 56854 159 78001 15 91341 566 212334 15 40758 177 78006 103 91414 566 212340 17 40760 177 58702 201 78116 363 91814 566 212341 17 41045 177 58702 201 78116 363 91814 566 212363 17 41049 177 59053 11 78120 291 91819 566 212363 17 41050 369 59054 11 78121 365 91829 566 212365 17 41379 <	40441		35							91256			212333		
40756 177 56854 159 78001 15 91341 566 212339 17 40760 177 57126 9 78114 185 91813 566 212341 17 41045 177 58702 201 78116 363 91814 566 212363 17 41049 177 59053 11 78120 291 91819 566 212363 17 41050 369 59054 11 78121 365 91829 566 212365 17 41379 199 59155 23 78135 259 91857 566 212406 385 42318 197 59663 207 78137 <	40742		177	56667		267							212334		
40758 177 40760 177 57126 9 78114 185 91813 566 212340 17 41045 177 58702 201 78116 363 91814 566 212363 17 41049 177 59053 11 78120 291 91819 566 212363 17 41050 369 59054 11 78121 365 91829 566 212364 17 41131 369 59059 15 78126 289 91832 566 212365 17 41379 199 59155 23 78135 259 91857 566 212406 385 42318 197 </td <td>40756</td> <td></td> <td>177</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>91341</td> <td></td> <td></td> <td>212339</td> <td></td> <td></td>	40756		177							91341			212339		
40760				reto:		, i			103	91414		566	212340		17
41049 177 59053 11 78120 291 91819 566 212364 17 41050 369 59054 11 78121 365 91829 566 212365 17 41131 369 59059 15 78126 289 91832 566 212375 21 41379 199 59155 23 78135 259 91857 566 212406 385 42318 197 59663 207 78137 285 91878 566 212430 9 42431 375 59720 151 78139 549 91879 566 212556 251 43023 173 59895 253	40/60	•						••••			••••				17
41050	4 1040 4 1040										••••		212363		
41131													212364		
41379 199 59155 23 78135 259 91857 566 212406 385 42318 197 59663 207 78137 285 91878 566 212430 9 42431 375 59720 151 78139 549 91879 566 212556 251 43023 173 59895 253 78140 273 91880 566 212556 251 50052 215 66299 476 78149 433 91890 566 212558 251 50139 177 67184 185 78152 263 91896 566 212835 193 50183 249 68087 241 78153							70121 78126						212305 212275		
42318 197 59663 207 78137 285 91878 566 212430 9 42431 375 59720 151 78139 549 91879 566 212556 251 43023 173 59895 253 78140 273 91880 566 212556 251 50052 215 66299 476 78149 433 91890 566 212558 251 50139 177 67184 185 78152 263 91894 566 212835 193 50183 249 68087 241 78153 241 91899 566 212919 193 50216 41 69215 565 78155 503 91900 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>78120 78135</td> <td></td> <td></td> <td>71034 91857</td> <td></td> <td></td> <td>2122/) 212404</td> <td></td> <td></td>							78120 78135			71034 91857			2122 /) 212404		
42431 375 59720 151 78139 549 91879 566 212556 251 43023 173 59895 253 78140 273 91880 566 212556 251 50052 215 66299 476 78149 433 91890 566 212558 251 50139 177 67184 185 78152 263 91894 566 212702 15 50183 249 68087 241 78153 241 91899 566 212919 193 50216 41 69215 565 78155 503 91900 566 212043 193	42318												212400 212430		
43023 173 59895 253 78140 273 91880 566 212557 251 78142 499 91890 566 212558 251 50052 215 66299 476 78149 433 91894 566 212702 15 50139 177 67184 185 78152 263 91896 566 212835 193 50216 249 68087 241 78153 241 91899 566 212919 193 50216 41 69215 565 78155 241 91899 566 212919 193 50216 41 69215 565 78155 201 91900 566 212043 193	42431						78139						212556		
50052 215 66299 476 78142 499 91890 566 212558 251 50139 177 67184 185 78152 263 91896 566 212702 15 50183 249 68087 241 78153 241 91899 566 212919 193 50216 41 69215 565 78155 503 91900 566 212919 103	43023						7 81 4 0			91880			212557		
50052 215 66299 476 78149 433 91894 566 212702 15 50139 177 67184 185 78152 263 91896 566 212835 193 50183 249 68087 241 78153 241 91899 566 212919 193 50216 41 69215 565 78155 503 91900 566 212013 103	*00**					ı	78142			91890			212558		
50139 17 67184 185 78152 263 91896 566 212835 193 50183 249 68087 241 78153 241 91899 566 212919 193 50216 41 69215 565 78155 503 91900 566 212919 193		••••					7 81 4 9		433	91894		566	212702		
50216 41 69215 565 78155 503 91900 566 212042 103					••••							566	212835		193
30210 41 € 03213 500 € 78130 503 € 91900 566 € 212943 193															
	JU210	•	41	07213	*****	כסכ [70122	;***	DU3	71900	••••	566	212943	····	193

Part No.	Pag	e No.	Part No.	Pag	e No.	Part No.	Pag	e No.	Part No.	Pag	e No.	Part No.	Pag	e No.
213172	_	35	215180	-	27	217521		169	218259	-	153	219117		391
213245	••••	15	215191		27	217522		369	218270		153	219118		391
	••••	17	215285		373	217523		153	218382		201	219119		391
213251		433	215328		369	217525		153	218386		205	219125		391
213275	••••				173	217526		159	218391	••••	205	219161		391
213276	••••	433	215331	••••		217546		159	218402		203	219179		391
213340		189	215485		9		****		218407		203	219214		395
213358	****	33	215593	••	165	217553	••••	375		:		219237		395
213416		157	215594		153	217554	****	375	218408		203			
213417		157	215647		23	217555	••••	375	218409	••••	203	219241		395
213419		157	215703		37			0.00	218410		203	219463		383
213472		9	215758		35	217560	·	379	218468		247	219468		159
213513		433	215767		391	217562		373	218469		247	219469	••••	159
213574		15	215769		151	217564		159	218470		247	219489	••••	17
213600		17	215791		415	217565		159	218471		247	219499	••••	461
213601		17	215808		169	217566		373	218508		568	1		
213602		17	215809		207	217567		379	218512		421	219501		461
213636		161	215935		11	217568		159	218549		393	219504		17
213637		161	215936		11	217584		169	218563		383	219508	••••	381
213646		35				217588		209	218576		27	219511	••••	381
213010			216380		255	217589		209	218584		393	219512	,	233
213660		165	216421		171	217620		153	218605		393	219521		169
213661	••••	165	216708		249	217622		153	218653		393	219544		177
		165	216909		219	217623		153	218751		421	219547		177
213662		165	216914	****	219	217636		219	218841		379	219548	••••	177
213663			216933	••••	9	217647		379	218842		379	219549	••••	177
213666		157		•	369	217650	****	379	218843		379	219550		177
213695		27	216986		209		••••	379	218844		379	219558	••••	395
213698		27	217267		215	217651	•			****	379	219559		393
213700		43	217267		215	217652	••••	379	218846			219560	••••	
213724		27	217268	• • • • •	179	217653	••••	379	218954		33		****	381
213744		23	217269		173	217657	••••	379	218955	•	247	219561	••••	393
213810		15	217270		173	217658		379	218970	••••	193	219562	••••	393
213811		15	217279		185	217659	••••	375	218971		193	219564	••••	391
213959		9	217321	****	421		,		218983		193	219574		211
213960		371	217325	****	163	217660	****	375			20-	219576	••••	395
213961		433	217351		181	217661	****	375	219002		205	219577	****	395
			217352		173	217662		375	219007	****	205	219582	****	231
214019		33	217353		173	217663		375	219010		205	219620		193
214047		21	217354		181	217664		375	219011		205	219624		391
214054		33	217355		173	217667		375	219012		205	219635		177
214058		23	217360		173	217680		153	219013		205	219644		381
214090		157	217361		215	217694		189	219017		205	219649		265
214131		17	217388		157	217735	••••	167	219018		205	219659		381
214223	• • • •	255	217389		159	217763	****	369	219019		205	219668		559
214228		33	217391	••••	i 61	217767		39	219020	****	205	219673		233
214229		33	217398	•	179	217771		371	219021	****	205	219675		383
214231	••••	33	213370		177	217773		369	219022		205	219676		247
214221	••••	35	217400		175	217774	••••	371	219023		205			
214262	••••	433	217421	••••	179	217778		153	219024		205	219680		269
214264	•··•	35	217421	••••	181	217780	•	39	219025		193	219684		453
214278	••••						••••	39	219027		205	219687		245
214279		35	217423 217437		173 241	217781 217811		157	219028	••••	207	219691		391
214290		369			241	217843	••••	153	219062	••••	391	219696		391
214348	••••	19	217445	****	169		••••				383	219704		568
214350		19	217448	****	153	217844		153	219065 219074			219704	****	
214351		19	217453		181	217970		153		****	393		****	171
214649		189	217454		[8]	217972	•	369	219078	••••	263	219714	••••	167
214662	••••	191	217455		181	217973		153	212000		202	219721	••••	167
214684		189	217476	••••	159	217976		153	219080		393	219722		167
214685		189	217477		159	217978		153	219083	••••	391	219723	••••	167
214787		165	217478		153	217979		221	219087	•	391	219742	••••	391
214792	••••	157	217484		159	217983		203	219088		397	219744	••••	369
214793		165	217488		159	217984		203	219089		391	219793		393
214 7 94		165	217489		159	217985		203	219093		393	219797		167
214795		409	217490		159				219098		173	219860		369
214797		165	217504		373	218050		369	219101		393	219913		17
214994		421	217505		379	218051		551	219103		393	219914		17
214995		55	217506		379	218149		193	219104		393	219995		153
214996	••••	421	217507		177	218171	••••	369	219113		391			
2.1770	••••		217508		375	218243	••••	159	219115		391	230007		181
215170		155	217512		159			159	219116		391	230021	•	153
217170	••••													C 71

Part No.	Paç	ge No.	Part No.	Pag	ge No.	Part No.	Pas	ge No.	Part No.	Pac	ge No.	Part No.	Page No.
230062		85	231299		189	232270		559	233093		551	234297	
230086		169	231308		379	232271		559	233094		551	234307	421 421
230098	••••	375	231309		379	232279		561	233100	••••	551	234309	2611
			.231310		379	232281		561	233100		551	234370	
230122		377	231318		201	232282		561	233102		551	257570	391
230123		453	231341		151	232283		561	233122	••••	195	234402	395
230140		153	231356		381	232284		561	200122		173	234525	1/0
230176		373	231393		229	232287		563	233211		195	234532	1.70
230177		379				232298		563	233220		199	234534	170
230184		189	231432		373	232299		563	233241		163	234603	22.
			231478		23				233243		255	234612	155
2 3025 0		49	231479		23	232300		563	233244		269	234619	5/0
230255		467	231480		23	232309		565	233247		267	234641	155
230279	• • • •	3 7 1	231498		377	232310		565	233261		568	234643	155
230288		3 7 3	231505		173	232311		565	233305		199	234734	211
230294		189	231507		-369	232313		565	233324		391	234789	179
230295		189	231575		25	232315		565	233326		51	23 11 07	
230313	••••	17	231577		25	232316		565	233328		51	234807	391
230328		241	231579		549	232317		565	233377		379	234817	13
230329		241	l			232318		565	233397		169	234828	377
230438		177	231601		215	232319		- 565	233398	****	169	234835	159
230439		177	231625		383	232320	••••	565				234838	421
230440		177	231636		371	232321		565	233406		169	234888	195
230492		27	231737		157	232326		565	233407		169	234889	195
230507		23	231759		115	232327		565	233408		169	234901	197
230508		21	23 1853		369	232335		565	233409		169	234902	197
230509		173	231879		41	232336		565	233410		169	234903	197
230511		179	231880		41	232339		419	233416		169	234908	197.
230655	• • • •	9	231881	••••	41	232349		419	233419		15	234928	199.
230693	• • • •	369	231883		41	232351		419	233427		19	234960	197
230696		153	231884		41	232361		205	233430		15	234962	197
120727		F/0	231885		41	232413		179	233436		169	234963	197
230736		568	231888		41	232415		159	233437		169	-	
230741	••••	205	231896		437	232416		193	233438		169	235983	· 211
2207760		189	231943	••••	165	232425		. 99	233441		169	235097	381
		189	222024		105	232464		169	233442		169	235098	381
230 7 59 23 07 60	••••	189 189	232026	• • • • •	185	232474	••••	453	233448		163		13
230762		189	232037	• • • • •	49 40	232484		453	233449		169	235208	199
230855		369	232038 232039		49 25	232493		453	233473		177	235222	197
230858	••••	179	232042		25 419	232497		153	233480		449	235237	369
230 99 6		15	232044		549	232512	••••	453	233531	****	265	235239	369
250770		ا را	232053	• • • • •	215	232557 232559		173	233533	• • • • •	478	235240	369
231033	•	161	232074		193	232560		215	233566		265	235241	369
231057		19	232095		461	232565	****	215 159	233568	••••	147	235253	369
231071		165	232697		461	232566	••••	255	233607		9	235268	453
231074		165	232104		197	232590		253	233608 233573		200	235416	169
231075		165	232107		193	2,52,570		2))	233419	••••	209	235438	159
231144		15	232121		215	232604		151	233520	•	49 25	235455	153
231155		iá	232122		215	232606		151	233568	••••	75	235553	241
231183		189	232123		215	232608		167	233573		209	235592	261 173
231184		189	232141		419	232610		381	200010		207	235646	201
231189		411	232142		419	232647		151	233625		211	235647	201
231190		245	232143		419	232684		373	233677	****	177	235648	201
			232144		419	232693		189	233678		177	235682	. 0.45
231213		453	232145	****	419	232813		169	233770		265	235726	247 45
231214		453	232180		419	232846		153	233771		459	235730	455
231218		9	232181		419	232955		383	233803		383	235731	455
231219		9				232960		379	233879		195	235770	45
231220		9	232212		419	232990		479				235860	387
231221		9	232244		421	232991		479	234041		261	235861	387
231242		177	232245	1	421				234059		449	· 235919	373
231251		179	232253		559	233017		255	234176		193	235968	181
231261		33	232254		559	233041		215	234191		195	235985	159
231267		33	232255		559	233042		215	234192		195		
231289		461	232256		559	233068		449	234213		259	236003	23
231290	•	461	232257		559	233071		449	234252		169	236011	23
231291		461	232259		559	233072		17	234291		- 21	236017	245
231292		461	232264		559	233073		449	234296		<u>2</u> j	236018	23
572												· -	

Part No. Page No.	Part No. P	age No.	Part No.	Page	No.	Part No.	Page	No.	Part No.	Page	e No.
236022 49	227142	27	239547		19	240386		11	242399		241
236060 23	237143 237150	27	239558		265	210300			242463		195
236067 51	237159	23	239559		265	240404		41	242491		257
236070 179	237160	161	239564		255	240406		261	242520		179
236072 177	237161	15	239565		255	240407		255	242521		179
236074 159	237163	559	239566		253	240408		71	242522		173
236137 263	237170	21	239567		253	240410		383	0.40550		
236151 19	237178	203	239568		253	240417		255	242570	• • • •	9
236173 13	237179	41	239569		253	240418	• • • •	215	242648		21 39
236174 13	237183	411	239570		253	240426 240427		478 478	242669 242672		39
236175 13	237187	17	239600		255	240427	••••	267	242673		39
236176 13 236183 13	237247	159	239673		231	240430		267	242674		<u>3</u> 9
236183 13 236184 13	2372 4 7 237251	153	239687		265	240431		185	242675		39
236185 13	237255	395	239688		265	240490		381	242676	,	39
236186 13	237279	265	239706		157	240497		478	242742		179
250,000	237324	41	239710		237	246555		55	242830		9
236281 151	237325	39	239711		237				242861		215
236287 35	237329	39	239712		237	240628		381	242863		209
236289 81.	237333	39	239715		237	240649		433	242889		21
236301 375	237339	181	239716	•	237	240651		21	242905		197 557
236305 159	237340	179	239742		215	240689		31	242926 242927		551
236360 39	237341	373	239772	••••	275	240708 240714		207 253	242928	•••-	551
236365 267	237342 237343	177 179	239820		41	240829		205	242958		35
236366 265 236389 185	227244	371	239824		11	240836		568	242993		41
236393 23	237344 237345	15	239825		ii	240908		253	242996		41
236398 173	237348	545	239826		ii i	210700	••••				
250570 175	237421	476	239827		ii	241090		193	243022		211
236406 23			239828		11	241103		9	243038		211
236407 23	237540	253	239829 .		11	241110		151	243039		211
236408 23	237544	177	239830		11	241166		25	243057		211
236417 159	2.37549	551			11	241224		247	243071	• • • •	5 4 7
236435 23	237563	23			11	241225	••••	97	243095 243121		37 209
236510 393	237711	197			11	241226 241267	••••	247 21	243121		209
236511 393	237774	31 553	000000		13 13	241207	••••	9	243123		209
236534 179 236535 179	237813 237819	553 553	000000		13	241283	****	209	243124		209
007744	237819 237826	549			13	241285		475	243125		209
236541 163 236543 369	237884	55	239838		13	2200		,	243126		209
236546 177	237912	163	239839	****	11	241380		211	243127		475
236547 177	237978	33	239840		11	241387		255	243128		475
236548 163	237982	159	239841		11	241388		189	243129		209
<u> </u>			239842		11	241445		209	243130	• • • • • • • • • • • • • • • • • • • •	209
236632 177	238018	253	239855		27	241446		209	243131	• • • • •	209 475
236658 223	238019	255	240024		549	241598 241649		161 157	243132 243185		47) 9
236665 223	238020	253	240034		549 549	241650		157	243196		3 7 3
236891 97 236894 247	238180 238207	265 269	240035 240037		551	241651	****	157	243217		547
236894 247 236895 247	238207 238208	209	240037		543	241676	****	199	243229		547
236896 247	238329	169	240065		383	241695		199	243237	****	9
236922 23	238542	193	240066		381	241696		199	243255		- 11
236941 373	238553	179	240087		239	241706		367	243256	•	11
236969 211	238707		240102		261	241708		381	243257		11
236986 213	238723	253	240169	****	549	241713		449	243258 243294		11 193
236993 193	220017	47.1	240138		35	241715 241839		461 155	243294		193
236995 193	239016	170	240180		33 33	241893		11	243297		193
236998 223	239017 239089	10	240181		ככ	241999		467	1 2 12277		مدر ب
237006 391	000170	177	240207	****	247	1 - 11///		101	2 4 3301		193
237006 391 237100 211	239160 239192	171	240234		247	242055		27	243302		193
237110 197	239272		240235		247	242056		27	243303		193
237119 15	239282	0.00	240236		247	242108		201	243380		443
237119 15 237121 185	239422	181	240270		39	242109		201	243394	••••	29
237138 167	239449	9	240271		39	242117		193	243395		103
237139 379	239531		240303		33	242130	••••	77 455	243419		9 215
237140 9	239544		240306		33	242139	****	455 27	243471 243531		15
237141 565	239545	10	240308	****	25 25	242329	*	435	243593		77
237142 11	239546	19	240326		. 40	242358	,	・サンプ	・ ムマンフフン		"

Part No.	Рас	e No.	Part No.	Page	e No.	Part No.	Pag	e No.	Part No.	Pag	e No.	Part No.	D.,	N.
243596		549	245013		35	247208		43	247815			i e		ge No.
243611	•	163	245013	1	35	247208		75			69 60	2509 7 8		25
243618		501	245015	****	35	247212	••••	71	247818 247819	****	69 69	251320		145
243668		551	245131	• • • •	529	247212	****	99	247819	••••	69	251320 251321		165
243677		547	245134	•	497	247512	••••	47	247861	••••	43		••••	21
2436.82		547	245135	••••	497	247520		59	247869	••••	43	251322		215
213002	•	717	245136	••••	497	247522		57	247872	••••	243	251323 251324		. 559
243714		169	245137	••••	497	247523		75	247874		59	251326		151 565
243743		195	245156	****	195	247526		77	247877	****	85	251335	••••	565 163
243744		195	245296		239	247530	••••	49	247883	****	85	251355	****	163 2 4 1
243767		553	245386		363	247535	****	47	247912	****	51	251600	• ••••	21
243851		555	245599		455	247537		57	247916	••••	59	251601	••••	169
243853		555	245654		421	277777	****	<i>J1</i>	247919	••••	59	251602	• • • • • • • • • • • • • • • • • • • •	421
243873		163	245766		157	247540		51	247920	••••	59	251606		563
243920		29	245767		157	247554		57	247929	••••	97	2,51000		707
243957		49	245815		253	247555		57	247951		87	252084		476
243 95 8		23	245926		237	247558		85	247952		87	252120		393
243959		43	245940		21	247563		57	247953		′ 87	252161		75
243 96 0		143				247564		57	247991		77	252162		205
243962		551	246109		455	247566		51		*****		252163		211
243 967		97	246115		77	247568		91	248240		197	252164		213
243 96 8		43	246169		77	247583		83	248247		197	252180		221
243 97 0		55	246201		23	247595		57	248248	,	197	252210		211
243 97 2		87	246232		199	247606		85	248361		151	252211	,	67
			246233		199	247607		91	248719		151	252212		455
244009		237	246241		269	247614		53	248720		151	252220		237
2441 50		179	246261		25	247622		55	248806		215	252500		57
2441 51		179	246262		25	247624		49	248822		437	252511	••••	399
2441 62		209	246330		41	247631		49	248826		437	252529	••••	67
2441 63		209	246338		41	247634		49	248831		437	252611		117
244207		59	246340		15	247647		81	248863		49	252621		43
2 44 2 7 2		566	246464		11	247651		109	248909		195	252622		43
244275		566	246543		476	247653	••••	55	248930		83	252623		49
2442.76		566	246560		35	247658		55				252624		79
2442.79		566	246565		195	247659	••••	55	250000		313			
244298		215	246566		195	247662	****	93	250004		307	253005	****	71
2443 16	****	239	246569		195	247663	•	21	250046		377	253025		75
2443 17		27	246762		474	247664		55	250331		393	253026		57
244339		381	246778		437	247665		55	250362	****	391	253027		39
244380 244419		373	247040		50	247671	• • • • • • • • • • • • • • • • • • • •	85	250407	••••	551	253029		235
2 414 19 244449	••••	553	247040		53	247672	••••	71	250431	• • • • •	213	253046	••••	187
2 44445 8		237 59	247051	••••	49	247674		81	250517		191	253068		111
244487	:	55	247069 247070	••••	51	247676	****	45	250518	••••	27	253254		377
244488		55	247070	•	51 59	247683	• • • • •	85	250523	••••	203	253809		237
244687		555	247076		75	247709		61	250530	****	23	253817		211
244688	****	555	247088		57	247709	****	51 40	250531		23	253824		377
211000	****	ככב	247094	****	81	247715	****	49 85	250539 250541		559	253826	••••	211
244700		257	247101		109	247723	••••	85	250541		561	253887	••••	299
2 44 705		37	247115		83	247726	••••	99	250542 250543	••••	41 37	253888 253905	••••	299 123
244706		35	247121		49	247730	••••	53	250544	••••	155	253921	••••	423
244708		37	247127		43	247737		91	250551	••••	209	273721		42)
244709		35	247135		115	247738	••••	9i	250559		559	254800		59
244710		35	247143		85	247739		5 5	250572		561	254801	••••	95
244711		35	247144		51	247742		55	250576		559	254802	••••	151
2447 12		35	247145		77	247746	****	79	250579	••••	559	254803	•	145
2447 13		35	247146		77	247753		423	250606		565	254804	••••	85
2447 14		35	247153		91	247755		43	250693		161	254806	••••	405
2 44 715		35	247154		8i	247758		43	250696		181	254810		187
2 44 716		35	247159		57	247766		57	250704		393	254811		, 51
2 44 717		37	247166		115	247771		45	250731		563	254812		67
244718		37	247167		115	247774		97	250830		85	254813		303
						247778		97	250840		43	254814		355
245003		35	247170		83	247796		79	250957		255	254816		209
245004		35	247171		69				250958		49	254823		189
245005		35	247172		83	247802		97	250959		383	254850		287
245008		35	247179		99	247806		71	250960		391	254851		99
245009		35	247186		49	247808		97	250961	••••	101	254852		199
245012		35	247199	•…•	51 I	247811	••••	69	250962		231	254860		319

				_		D 3.7	В	NT I	D a Ma	D	N. I	Part No.	Page	No
Part No.	Page	No.	Part No.	Page	No.	Part No.	Page		Part No.	Page	183	262796	_	35
254861	•	53	256220	••••	51	260702 260704	••••	29 29	261865 261868		183	262798		331
254877	••••	183	256221		113 99	260707		29	261869		183	262859		261
254911	••••	57	256222 256223		361	260708		29	261873		183	262860		39
255003		235	256226		57	260714	****	31	261874		183	262973		563
255004		225	256228		521	260719		31	261850		183	262974		563
255005		187	256230		521	260721		31	261857	****	183	262975	••••	563
255006		81	256233	••••	59	260732	•	29	. 261858		183	262977		563 563
255007		107	256253	••••	205	260734	••••	29	261880		183 567	262978		707
255008	••••	51	256255	•	455	260737 260739		29 29	261906 261909	• • • • • • • • • • • • • • • • • • • •	567	263059		381
255009	**	187	256256	****	453 307	260743	••••	31	261919		259	263142		215
255021	**-*	467 113	256280 256323		209	260745		31	261921		41	263148		249
255025 255026		49	256333		453	260747		31	261924		373	263149		249
255027	••••	113	256335		453	260749	****	31	261925		373	263158	••••	269
255028		55	256421		75	260752		31	261940		257	263332	••••	421
255029		57	256422	••••	465	260753		31	261941		257	263354	****	209 393
255038		223	256426		69	260754	••••	29	261943 261974		257 29	263356 263394		113
255045		97	256429		69	260765		63 29	201974		2,	263395		113
255046		51	256432		189 377	260767 260771		31	262068		249	263455		155
255047	****	213 77	256448 256465	****	189	260823		183	262069		566	263456		155
255048 255068	••••	49	256812		377	200023			262072		566	263607		27
255085	••••	43	230012		J	261238		39	262079		567	263630		27
255202	••••	217	257005		185	261239		111	262100	•	257	263670		27
255204	••••	51	257011		185	261252		259	262101		257	263695	••••	433 261
255206	••••	213	257015		505	261253	••••	259	262247 262269		476 257	263732 263807		189
255207		51	257017	•••-	469	261256 261287		113 474	262278		247	263878		157
255208	****	45	240024		113	261410		29	262286		251	2050.0		
255209 255210		237 237	260026 260055		37	261419		247	262287	****	251	264020		211
255211	****	225	260138		29	261428		173	262288		251	264021		211
255223		225	260139	,	29	261470	••••	129	262289		251	264022	••••	211
255225		75	260140	****	29	261483	••••	39	262290	••••	251	264023		211
255226	••••	187	260141		29	261502	••••	263	262292		251 251	264024 264137		211 19
255227	****	55	260142		29	261503	••••	261 29	262293 262294	••••	251	264195		237
255228	. ****	93	260143	••••	29 29	261508 261512	••••	568	262295		251	264250		157
255229 255230	****	297 353	260146 260155	••••	29	261513		568	262296		251	264362		225
255238		547	260156		29	261515		381	262297		251	264374		205
255245		211	260157		65	261517		381	262299		251	264429	••••	457
255246		89	260159	••••	29	261518		381	262298	****	251	264431		113
255249		455	260163	****	29	261561		381	262300		251	264433 264435	••••	113 113
255251		357	260164	••••	31	261562		29	262301 262303	••••	251 251	264436		39
255425		465	260165	••••	31	261563 261564		31 31	262304	••••	251	264437		113
255426	••••	465	260166 260167	••••	31 31	261570	••••	29	262305		251	264438		113
255427 255428		77 465	260168	••••	31	261573		38Í	262306		251	264466		211
<i>233</i> 720		102	260169		31	261574	****	381	262307		251	264467		211
256000		223	260170		31	261575		381	262308	****	251	264569	••••	13
256001		199	260173		29	261577		566	262309	••••	251	264527 264528	•	419 419
256002		419	260178	••••	65	2/1500		20	262310		251	264529		419
256008	••••	403	260179		31	261580		29 29	262312		31	204327		117
256009		107	260180		31 31	261581 261582	••••	29	262313		29	264560		209
256020 256021	••••	95 147	260181 260216	••••	63	261584	••••	2 9	262342		257	264563		209
256026		133	260266	••••	31	261594		29	262343		257	264575	••••	433
256027		95	260268		63	261774		373	262448	,	29	264590	••••	259
256029		69	260269		31	261775		373	262468	•	173	264591	****	363
256030		57	260274	••••	31	261776		373	262469	****	173 566	264629 264631	• • • •	433 433
256031		57	260275	••••	31	261794	••••	257 565	262643 262646		566 566	264643		215
256033		467	260345		474	261827	••••	565 449	262647		31	264644		215
256043 256046		77 405	260494		65	261829 261835	•	367	262658		295	264664		29
256046 256050	••••	389	260550		251	261844		474	262659		29	264767	••••	219
256064		145	260583		25 i	261851		183	262703		35	264777	••••	249
J00001	****		260585		251	261857		183	262708	****	35	264778	••••	249
25 6203		279	260681		567	261858	****	153	262728	****	381 381	264782 264798		259 549
256209		59	260700	****	29	261862	••••	183	262729	****	וטכ	1 LU1/70		J47

Part No	. Pa	age No.	Part No.	. Pa	ge No.	Part No.	Pas	ge No.	Part No. P.	age No.	Part No.	Page No.
264802		549	267257		13	269216		9	270702			
264806		165	267258		13	269240		35	270717	189	271784	543
264807		165	267392		263				270716	255	271787	545
264837		437		• • • • •		269265		179	270717	255	271789	545
			267412	• • • • •	207	269266		179	270718	255	271790	545
264865		239	267431		377	269267	1114	189	270741	21 1	271791	545
264886	****	239	267451		.51	269268		191	270938	449	271793	545
264889		239	267572		157	269269		18 9	270961	185	271794	545
264963		551	267573		157	269270		191			271796	~ 45
264965		551	267574		157	269274		477	271108	457	271797	F.45
264969		551	267575	****	157	269335	****	9	271151	213	271798	
26 4973		551	267601		219	269365		9	271166	213	271799	545
264975		551	267615		543	269413		15Í	271162		271000	545
			267616		545	269461		399	271220	213		545
265019		85	267618		543	269476			271225	87		545
265051		545	267619	****	543	269562	****	15	271225	265	271802	545
265055		21	267620				****	435	271230	245	271803	545
265068					543	269565		435	271364	183	271804	545
		557	267621	••••	543	269567		435	271367	183	271805	545
265086		9	267622		543	269598		453	271368	183	051070	305
265169	•···	47	267623		543	269611		425	271372	183	27 18 7 0	249
265170	• • • • •	47	267779		23	269783		217	271377	183	3 001000	245
265174		·5 5 5	267780		23	269784		217	271378	183	071001	~ -
265175		47	267781		15	269829		175	271270	183	0-101-	
265185		555	267782		159	269889		25	271200	183		457
265190		555	267795	••••	155	269911		83	271202	183	271975	43
265200		543	267828		23	269952		421	271204		272040	07
265255		484	267829		21	269953		241	271207	183	272069	
265260		41	267837		245	269960		151	271380	173	272181	
265295		363	267950		455	269974	••••		271459	457	272184	
265331		17	267981	****	25			27	271465	237	272185	155
265459	**	209	207 901		23	269987		35	271479	97	272191	215
265461	• • • •		20027		242	269988		35	271496	185	272206	
265481		209	268037		243	269989		35	271500	261	272224	
		363	268038		243	269910		79	271502	79	272303	
265482		363	268245		555	269911		79	271506	549		175
265495	****	29	268284	• • • •	185	269912		45	271568	27		261
265623		93	268292		53	269913		45	271572	27	272309	
265624		93	268293			269914		45	271614	39	070010	215
265627	••••	417	268341			269915		45	271615	39	272376	
265495		63	268374		251	269990		35			272396	
265556		549	268472		25				271731	549	272474	99
265623		. 55	268493		219	270074		423	271732	549	272487	201
265624		55	268543		23	270095		39	271751	543	272498	
265627		209	268568		29	270104		101	271752	543	272601	212
26 56 42		211	268635		43	270105		97	271754	543	272506	213 213
265683	٠	523	268666		54 9	270115		97	271755	543	377617	00
26 5 7 37		13	268674		251	270133		249	271757	543	272520	40
26 577 9		45	268698		391	270141		249	271727	543		
26 5 98 9		475	268703		393	270225		Ĩij	051560 ""	543	272672	261
			268726		549	270235		iii	051550		272563	7 9
266509		467	268727		549	270238		iii 🛭	2717/0	543 i		79
266510		467	268763		197	270239		111	271771	543 542	272577	257
26 66 83	••••	484	268791		159	270240		iii	2717/2	543 543		257
266684		484	268797		97	270241		iii	271742	543	272581	257
266687		484	268847		169	270241	• • • •		27174	543	272592	257
266693		484	268848		169	270245	••••		271764	543	272594	257
266694		221	268849						271765	543		257
266 7 52	••••	484	268887	,	163	270251		111	271766	543		161
266815					49	270274	••••	185	271768	543	272597 .	161
266900	••••	555	268900		399	270287		181	271770	543	272632 .	217
266924		21	268903		399	270297		249	271771	543	272452	484
		15	268905	****	399	270323		215	271772	543	272661	41
266945		83	268907		399	270324		215	271773	543	272704	113
266955		171	268910		399	270420		213	271775	543	272712	217
266956		163	268963		199	270520		209	271776	543	272712	219
266966		547			ı	2705 21		209	271777	543	272714	217
266985		27	269132		223	270568		9	271778	543	272720	210
266 99 2		169	269132		229	270598		261	271779	543	272720	210
2/=0::			269162		. 393	270604		405	271780	543	ウフィフィフ	215
267016		183	269163		391	270605		419	271701	543	272720	0.15
267022		213	269178		419	270614		551	271782	543	272742	252
267 193		205	269197	****	401	270656		45	271783	543	171704	PT 49
576						•	•			J 10	<i>21</i> /2/04	
210												

Part No.	Page	No.	Part No.	Page	No.	Part No.	Page	: No.	Part No.	Page	No.	Part No.	Page	No.
272804		223	274500		87	276397		568	277615		253	278386		233
272819		219	274645		91	276407		97	277619		97	278420		479
272820	****	219	274683		9i .	276426		249	277627		175	278434		215
272839	****	25	274711		89	276484		175	277633		67	278471		219
272845	•	217	274715		233	276501		49	277686		425	278474		175
		217	274772		91	276511		77	277687		425	278489		267
272846			274773		91	276609		53	277742		79	278490		267
272850	. ••••	253			91			97	277765		245	278500		439
272855	. ••••	177	274774		91	276627 276719		179	277766	••••	99	278517		97
272920		221	274775					179	277767		99	278539	****	243
272922		177	274783	••••	257	276720		59	277768	• • • • •	99	278540		385
272934	• • • •	177	274841		217	276762	••••		277769		99	278542		387
272967	***-	475	274847		97	276784		191 191	277774	••••	97	278543		387
272968		475	274870		237	276785					229	278545	•	387
		221	274880		247	276937		211	277778		229	278546		387
273061		221	274881		247	276954	• • • •	474	277779		551	278547	****	387
273069		97	274895		484	0770/0		17	277781	••••		278552		387
273070		97	274897	****	449	277063		17	277815		99	278553		385
273077		221	274996	···· .	215	277103		223	277816		99	278554		387
273163		13	274997		215	277105	••••	223	277838		99		••••	
273166		43				277106	••••	227	277839		99.	278598 278664	••••	67 209
273257		19	275016		245	277120		67	277840		219			
273271		75	275024		49	277139		373	277843	••••	547	278665		538
273276	,	476	275143		85	277140		373	277894		249	278666		209
273341		177	275199		205	277144		475	277898		247	278690		221
273356		49	275233		89	277153	••••	223	277914		151	278698		211
273370		249	275234		51	277154		223	277918		249	278699		211
273452		99	275238		159	277217		568	277921		205	278702		439
273483		453	275239		207	277259		245	277922		199	278703	••••	439
273484		455	275250		249	277260		245	277923		199	278766		419
273521	****	97	275265		99	277261		245	277929		219	278769		51
273523		555	275266		99	277262		245	277930		219	278891		435
		555	275371		265	277263		245	277931		261	278964		476
273530		555	275377		449	277264		245	277949		547	278967		476
200001		555	275385		543	277289		181	277956		53	278968		476
050500		555	275552		85	277294		187	277961		151			
273585		209	275565		101	277295		187	277983		223	279005		111
273598		211	275573		91	277303		219	277996		85	279006		111
^-^/	****	83	275629		159	277311		181	277999		75	279007		111
273707		261	275679		49	277320		568	1			279008		111
273711		55	275706		233	277368		71	278000		75	279009	••••	111
273714		421	275709		233	277372		568	278001		113	279010		111
273788		31	275713		233	277388		51	278002		99	279011		111
273789		5 9	275714		233	277390		47	278010		255	279012		111
273879		559	275715		463	277446		111	278018		175	279013	****	111
273881		455	275742		305	277450		231	278020		205	279014		111
273886		173	275744		484	277453		231	278021		99	279015		111
273936		253	275772		151	277454		231	278025		153	279016		111
273937		253	275807		11	277455		223	278054		401	279017		111
273964		229				277472		229	278056		399	279018		111
273979		557	276013	,	233	277478		231	278059		393	279019	••••	111
			276014		233	277490		373	278061		393	279020		111
274068		53	276015		233	277491		373	278079		223	279021	•	111
274069		53	276034		209	277496		43	278109		55	279022		111
274125		53	276039		173	277502		229	278161		67	279068		399
274145		179	276053		269	277508		27	278162		67	279074		263
274146		179	276054		269	277509	• • • •	433	278163		67	279100		387
274147		179	276133		51	277513		213	278164		87	279114		253
274148		179	276134		237	277531		115	278165		451	279115		253
274154		57	276135		237	277532		115	278166		477	279116		253
274172		49	276141		237	277543	****	113	278282		97	279168		69
274173	, ****	49	276176	****	484	277544	****	113	278283		261	279169		69
274174		49	276201		173	277553		97	278286		47	279188		459
274323	. ****	247	276267	****	97	277556		99	278359		243	279330		15
274323 274377	••••	257	276317		259	277560		185	278372		13	279331		441
274378	••••	257	276320		173	277565		229	278373		13	279340		255
274379		257	276322		568	277592		229	278374		13	279341		255
274423		207	276323	••••	568	277593		53	278375		13	279342		478
274423 274433		568	276382	****	97	277611		25 25	278376		13	279343		478
274469		211	276396		568	277612		229	278383		263	279400		253
<i>‰1</i> 11 07		411	210770	,	200	2,1012		/	_, 0,00	••••				

Part No.	Pa	ge No.	Part No	. Pa	ige No.	Part No.	p,	ige No.	Part No.	D.	N.	I D. a. N.	D	N.T
279412		199	279969		209	303661		547	307199		age No. 311	Part No.		ige No.
279418		199	279970		209	303662		- 553	307220	•	291	320085 320174		447 439
2 7 9419		559	1			303663	****	551	307234		479	320175	••••	439
2 79 420		559	300715		187	303701		187	307235		479	320197		439
279421		559	300716		187	303729		215	307279		547	320198		439
2 7 9422 2 7 9423	• • • •	559 559	300781 300782		271	303750		289	307280		547	320245		531
279424	••••	559	300783		281 271	303809		501	307289	•	355	320251	••••	439
279425		559	300785	••••	311	303817 303821		287 287	307339 307418		509	320273	••••	439
279426		559	300789		271	303824	••••	287	307419	****	501 501	320276 320333	****	243
279427		559	300816		213	303828	****	287	307420	••••	501	320345	****	243 291
279428		559	300824	****	241	303829		287	307838		435	320500	••••	307
279429		559	300851	••••	279	303847		271	307909		305	320502	****	437
279430	••••	559	300919	••••	271	303871		279	307977		301	320521	,	535
2 79 431 2 79 432	••••	559 561	300924 300953		273	303875		2 7 9	307978		301	320532	••••	482
279433		563	300954		311 311	303907		305	307992		305	22222		
279434		563	J007J4	••••	ווכ	303954 303975		555 299	308070		400	330000	••••	305
279435		563	301005		315	303990		305	308136		489 531	330060 330061	••••	305
2 794 36		563	301074		287	303995		183	308137	••••	531	330067	•	305 295
27 9 437		563	301139		371	303996		183	308144		531	330068	••••	295
279438		563	301332		311	303997		183	308155		531	330069	••••	289
279439	••••	563	301343	••••	311				308156		531	330076		299
279440 279441	•	563	301437	••••	287	304054		501	308173		531	330077		299
279 44 1 279442	••••	563 563	301470 301476	••••	447	304098		433	308206	••••	281	330111	••	301
279443	•	565	301476	•	447 447	304099	••••	433	308310	••••	531	330112	•	301
279444	•	565	301879		271	304111 304125	• • • • •	305 291	308461 308517		539	330113	••••	301
279445	••••	565	301957		371	304234		329	308713		315 531	330114 330115	••••	301
279446		565			22.	304235		329	308714		531	330116	••••	299 299
279447		565	302164		331	304236	••••	329]	••••	221	330117	••••	299
279448		565	302165		333	304301	••••	313	310599		363	330118		2 99
2 794 49	••••	565	302174		347	304326		433	311200		421	330122		299
279450 279452	••••	559 199	302177	••••	331	304327		433	311373	••••	263	330123	••••	299
21 74)2	••••	199	302178 302186	••••	331 271	304331 304345		437	212027		200	330126	••••	295
2 79 517		263	302207		331	304346		433 433	312027 312028		289 501	330132	****	295
2 79 518		263	302222		273	304348		433	312856		503	330138 330139	••••	295 295
279519		249	302262		331	304401		279	312000	••••	,,0,,	330143	••••	305
279551	••••	425	302371		335	304434	••••	480	313385		245	330144	••••	293
279554		55	302372		335	304797		311	313484	••••	501	330145		277
279573 2 796 05	•	49	302373		335	304871	,	281	313493	••••	331	330146		301
279629	••••	53 173	302532 302533	•	283	304874		299	313858		301	330147		293
279630	••••	439	302581	••••	287 283	305192		247	313860		519	330149	••••	243
279633		173	302648		447	305232	••••	347 357	313959 313998	•	243	330157	••••	301
279651		249	302655		447	305665		555	313999	••••	483 483	330158 330159	••••	301 301
2 796 52		249	302672		433				3.3777	••••	107	330160		301
279653		249	302677		435	306036		355	314000		483	330162		303
279 6 78		209	302811	•	271	306039		495	314001		483	330163	•	303
270407	••••	209	302818	• • • •	273	306199		501	314002		483	330198		301
270400	••••	387 387	302825 302828	••••	273	306200 306287	••••	501	314003	••••	483	330202		303
270702	·····	97	302854	••••	273 301	306287 306289		329	314004		483	330203		519
270724		67	302859		301	306295		329 357	314005 314006		483 483	330204	••••	271
2 797 62		557	302933		271	306316	,	501	314007		483	330205 330208	••••	271 271
2 797 83		451	302934		273	306326		501	314008	••••	483	330212		273
		451	302954		281	306340		.311	314009	••••	483	330214		271
270000		385	302958	••••	253	306375	••••	311	314203		519	330215		27 i
270010	••••	213	302986		187	306407		509	314394		505	330224	••••	271
270011	····	97 4 29	303203		303	306408	••••	493	215264		£2.	330225		271
2700.47		241	303568	••••	555	305421 306426		305 437	315264	••••	531	330233	••••	271
2700.47		421	303610		547	306460	••••	437 365	320009		433	330234		271
279848 .		241	303612		547	306461		331	320045		283	330243 330245		277 271
279861		451	303618		547	20/4/5		241	320046		331	330265		271
		241	303650		555	306471		309	320047		331	330267		271
279880 .	•	295	303654	••••	555	306474		309	320055		283	330271		271
2 799 57 .	•••	241	303658	••••	555 I	306564		309	320084		447	330279		271

Part No. Page No. Part No. Page No. Part No. Page No. P.	Part No. Page No.	Part No. Page No.
	331166 365	331493 482
	331168 482	331497 505
	3311 7 0 289	331498 505
330315 271 330575 311 330954 299 33	331179 537	331508 505
	331180 505	331526 365
	331186 505	331527 365
330327 287 330585 287 330958 277 33	331187 505	331530 363
330333 287 330586 287 330959 359 33	331192 505	331532 533
330336 287 330599 297 330961 359 33	331193 505	331547 537
330337 287 330963 329 33	331196 505	331549 363
350512 1111 245 4411	331203 505	331550 363
350517 III 205 FFFFFF III TILL FFFFFF	331213 537	331553 363
350510 205 1 FEEEE T T	331214 537	331554 363
	331216 537	331556 363
35005	331220 311	331557 363 331560 363
3,00,00	331221 311 331222 311	221541 363
3,000	221220 447	221544 262
350500	221220 447	221545 262
330301	221222 201	2215/7 262
320200	221240 221	2215/0 2/2
220207 395 220662 277 220092 311 3	221250 221	221570 262
330307 1111 203	221260 221	201571 262
200	221262 201	331574 363
220204 200 220444 207 220095 321 3	331272 291	331576 363
220200 272 220667 207 220096 317 3	331273 289	331578 363
220/49 207 220007 217 2	331275 319	331579 363
220400 200 220440 207 220000 425 3	331276 319	331581 363
	331281 319	331589 537
	331291 501	331590 537
330416 299 330717 281 330992 483 3	331292 501	331599 537
330419 273 330718 277 330993 483		
330422 273 330750 361 330994 483 3	331307 325	331600 537
330424 293 330762 359 330995 299 3	331308 325	331605 537
330425 293 330767 361 330997 325 3	331314 447	331607 537
	331315 447	331610 537
324 (24	331316 317	331616 533
200	331317 321	331638 505 331646 535
SPORT IN THE STREET OF THE STREET	331318 325 331346 319	221747 525
220442 202 220790 221 221000 201 2	221247 210	221740 492
	331349 319	331652 482
220111	331356 365	331655 482
220447 202 220702 250 221029 290 3	331361 319	331658 482
220449 202 220703 250 231070 280 3	331362 319	331669 537
220457 241 220709 250 221020 290 3	331371 317	331670 537
	331372 317	331673 319
	331390 482	331674 319
330468 277 330824 277 331049 289 3	33 1 391 482	331675, 319
330480 307 330830 323 331071 289 3	331392 365	331676 319
330487 307 330832 271 331074 291 3	331393 365	331689 289
330507 323 330833 271 331083 291 3	331400 365	331699 535
330529 261 330840 277 331086 311 3	331401 503	331702 365
	331402 365	331703 365
550551 111 275 40404- 111	331403 365	331707 531
33 033 1 111	331408 289	331708 531
	331411 365	331713 289 331716 289
220,20	331415 365	
25 CS 27 CS 25 CS	331437 365	
220541 215 220001 202 221114 201 2	331438 365 331452 365	221710 201
201 42 201 220004 2/1 221122 501	201457 265	221720 201
330312	201.457 265	331720 291
	331457 305 331458 365	331724 289
220751 212 220000 201 221120 290	331471 289	331726 291
220552 212 220000 201 221149 501	331480 537	331727 289
	331481 537	331728 289
330559 313 330914 307 331150 363	331491 482	331730 289
330561 315 330950 241 331163 365	331492 482	331744 289

Part No.	Pa	ge No.	Part No	D.	ige No.	I Dank Nia	Ď.	NI	In . M		NI	1 D 37	_	
331745		289			_	Part No.	Pa	ge No.	Part No.	. Pa	age No.	Part No	. Р	age No.
	****		332324		337	332603		285	332999		480	333349		345
331776	••••	365	332325		337	332605		313				333350		345
331780		365	332326		307	332611		480	333031		355	333355		345
331781		365	332327		307	332614		480	333032	• • • • •	355	333356		345
331784		533	332329	****	337	332625		295	333033		355	333357		345
331807		365	332340		533	332627	,	519	333034		355	333358		345
331810		365	332341		329	332631		307	333035		355	333395		533
331811		365	332355		533	332632		307	333036		355	333399		533
331812		365	332357		533	332640		241	333037		355	122277		222
331813		365	332372		355	332642		482	333039		355	333400	****	533
331818	* *	291	332376		533	332647		305	333040		355	333401	****	347
			332377		281	332656		241	333041		357	333402		347
332000		329	332385		333	332658	****	521	333044		519	333403		347
332005		331	332386	****	333	332660		481	333045		5 <u>19</u>	333404		347
332025		335	332391		333	332661		481	333080		301	333410		521
332028		335	332392		333	332670		243	333081		519	333411		521
332040		333	332393		333	332672		279	333082	• • • • •	519	333415		355
332041		333	332397		333	332674		279	333083					
332047		333	332398		333	332683		359	333089	****	519	333416	• • • • •	355
332052		329		••••	222	332003	****	222	333093		519	333435	• • • • •	355
332065		339				332700		479	333095	• • • • •	519	333438	• • • • • • • • • • • • • • • • • • • •	495
332080		329	332400		297	332715		309		• ••••	521	333439		357
332081		329	332401		297	332725	****		333096		521	333440		497
332083		333	332402		482	332729	••••	305	333097		511	333444	• • • •	497
332084		333	332403		482	332732	••••	187	222100		= 00	333445		357
332089	••••	331	332411		299	332733		301	333100		523	333446		355
332097		331	332432		355			519	333101		523	333447		355
332098	• • • •	307	332434		355	332736	• • • • •	281	333137		521	333452		509
332070	• • • •	307	332435		480	332744	- • • •	337	333140		301	333458		479
332112		331	332440		477	332745		337	333159		509	333459		47 9
332113	• • • • •	331	332445		299	332746	• • • •	303	333160		511	333467		331
332115	****	349	332446		299	332747		519	333161		511	333468		333
332121		331	332453		281	332749		303	333176		509	333473		435
332122			332454		281	332750		303	333183		511	333479		435
332143		331	332459		319	332751	- * * -	359	333184		. 511	333486		359
332146	••••	331	332465	****	317	332752		491	333189		509	333487		331
332147	••••	329	332466		253	332756		509				333490		347
	• • • • •	357	332467		253	332783		337	333201		509	[
332149	••••	329	332484		301				333202		509	333507		531
332150	• • • •	329	332485	••••	301	332937		489	333203		527	333510		533
332151	••••	329	332487		283	332942		495	333204		521	333526		531
332152	••••	331	332492		357	332943		357	333211		513	333527		5 31
332154	• • • •	331	332493		497	332945		359	333228		521	333528		531
332157	****	333	332173		727	332950		317	333229		523	333562		509
332181 .		331	2225			332951		321	333233		523	333607		283
332182		333	332505		283	332952		325	333234		509	333693		285
332183	••••	333	332509		283	332956		363	333235		509	333698		283
332194		489	332510	••••	285	332958		365	333243		511			_03
332199		185	332518		283	332960		476	333244		511	333702		283
22.2200		222	332521		273	332961		476	333252		353	333710		299
332200		339	332522		283	332962		476	333253		493	333714		511
332201		335	332531		439	332963		476	333254		493	333717		299
332215		331	332540		439	332965		439	333257		517	333718		299
332216		337	332545		439	332968		287	333259		523	333720		52Í
332217	• • • •	337	332550		307	332969		480	333260		523	333745		511
332223		337	332551		439	332970		480	333261		523	222112		211
332230		337	332552		441	332971		479	333262		523	333819		345
332240		505	332553		441	332972		479	333263		511	333835	• • • •	489
332280		339	332555	****	441	332973		443	333266		509	333836		489
332281 .		339	332556		441	332974		455	333267		509	333837	••••	
332282 .		339	332557		441	332977		345	333268		517	333972		353 273
332283		339	332558		433	332978		345	333271	****	480	333983	****	273
33 22 84 .		339	332563		357	332983		509	333272		480	JJJ703		347
2271702		343	332564		357	332985		363	333277	• • • •		22.4000		225
			332565		503	332986		365	333280		531	334000		335
33 23 06 .		337	332566		357	332987		353	333293		531	334001	••••	329
33 23 07		337	332581		295	332991	••••	479	333294		535	334002		329
332308		339	332582		271	332992	••••	479	333295		535	334033		329
332313		413	332588		309	332995	•	482	333347		535	334004		329
227217		480	332589		293	332997	**	480	333348	*	345	334005		345
58A		. 3	- '				****		ノノノノナい		345	334006	••••	345

Part No. Page No.	Part No.	Page No.	Part No.	Page	No.	Part No.	Page	No.	Part No.	Page	No.
334007 345	500249	201	500880		435	502026		215	503005		547
334008 345	500250	203				502029		121	503008		551
334044 283	500252	201	500907		467	502032		221	503010		551
334073 341	500253	201	500961		109	502037		377	503015	****	555
334074 413	500254	203	500978		173	502039		377	503033	• • • •	463
334075 411	500257	223	500999	****	213	502044		377	503039		387
334111 501	500289	539	501006		213	502087 502096	••••	185 457	503041 503054		431 565
334114 307 334115 307	500290	539	501006 501018		231	502090		199	503125		568
334115 307 334121 307	500359	547	501019		431	502116		41	503147		419
334174 531	500388	467	501025		482	502125		455	503160	,	474
334176 531	500399	553	501030		97	502201		161	503163		553
334177 531			501031		59	502202		167	503169		553
334179 281	500400	553 [.]	501032	****	263	502205		167	503174		565
334189 287	500411	259	501033	••••	263	502209		.55	503204		199
334190 337	500412	259	501034		263	502248		177	503266		55 172
334245 319	500413	259	501039		59 50	502280		177 71	503269 503307	••••	173 235
334246 319	500414	459	501041	****	59 497	502281 502282		71	503309	••••	235
334617 285 334707 329	500427 500429	425 538	501053 501070	••••	538	502283		7i	503310		235
334707 329 334708 329	500423	· 538	501081		443	502285		źi	503410		553
334713 329	500435	539	501129		261	502286		7i	503417		549
334714 329	500436	539	501175		69	502287		71	503424		568
334719 345	500437	539	501198	****	7 5	502333		484	503428		185
334720 345	500438	538	501224	****	99	502335		484	503430		67
334725 345	500445	539	501245		183	502406		181	503433		553
334726 345	500446	538	501246		183	502482	••••	159	503434		227
334727 329	500447	538	501251	• • • • • • • • • • • • • • • • • • • •	99	500501		476	503448		553
334729 329	500457	25	501253	••••	21	502501 502516	••••	476 173	503461 503467		551 201
334731 345 334733 345	500461	203	501270 501355		476 265	502521		423	503468		201
334733 ··· 345 334873 ··· 480	500513	257	501389		209	502523		419	503469		203
334874 480	500514	257	501390	·	209	502526		215	503471		203
33 101 1 3 100	500515	257	501391		209	502527		557	503492		245
340390 359	500527	261	501412		173	502532		211	503587	·	49
340391 359	500555	419	501422		69	502559		173	503665		11-
340704 363	500556	423	501428		247	502560		173	503746		53
	500559	263	501444		211	502583		99 05	503747		79 70
355847 365	500566	553	501445		211	502615 502617		85 265	503748 503754	****	79 484
357072 ··· 474 357081 ··· 474	500569 500571	551 255	501451 501453		391 397	502653		451	503887		61
357081 474	500588	499	501471		175	502655		451	503888		61
500115 563	500597	115	501472		175	502656		53	503889		61
500116 563] 300371		501473		175	502710		179	503890		61
500117 563	500610	19	501474		175	502711		179	503891		61
500129 43	500625	427	501475		175	502712		179	503893		61
500132 47	500638	47	501501		159	502713		179	503895		61
500133 47	500639	47	501563	•	253	502714		179	503896		61
500134 47	500640	47	501568	*	27	502715	****	189 425	503897 503898	• • • • •	61 61
500135 47 500136 47	500641 500642	47 47	501569 501570		263 263	502723 502729		425	503899		63
500136 47 500137 47	500645	151	501593		205	502776		97	303077	****	0,5
500138 47	500669.	476	501617		157	502830		478	503900		63
500139 47	500695	476	501620		538	502832		59	. 503901		63
500140 47	500696	565	501621		538	502898		67	503902		63
500141 47			501676	· · · · · ·	43	502899		67	503903		63
500142 47	500710	245	501677	****	43	502900		67	503904	• • • • •	63
500143 47	500746	213	501679		257	502951		273 565	503905 503906	••••	63
500144 ·· 49 500145 ·· 49	500764 500792	85 57	501680 501683		367 455	502952 502953		565 559	503900	****	63 63
#00100 ADE	JUU174	7/	501684		457	502961		451	503908		63
500199 425	500817	538	501690		265	502968		565	503909		63
500201 219	500818	538	501691		265	502969		565	503910		63
500209 467	500821	538	501692		263	502982		67	503911		63
500212 467	500823	538	501693		263	502997		549	503912		65
500213 467	500833	539	501694		263	502998		555	503913		65
500225 249	500837	457	501735		251	502002		EEC	503914		65
500227 457	500838	459	#0200C		10	503002		555 549	503915 503916		65 65
500229 457	500839	538	502006		19	503004	••••	ノサブ	■ フリンタ10	• • • •	00

Part No.	Pag	ge No.	Part No.	Pa	ge No.	Part No.	Pa	ge No	Part No.	Pa	ge No.	Part No.	Pa	ge No.
5 0391 7	••••	65	504659		169	507681		173	509141		411	511681		77
503918		65	504667		551	507682		173	509217	-	241	511682	••••	41
503919	····	65	504673		245	507687		484	509233	••••	167	511833	••••	
503920		65	504683		61	507693		484	509407	••••	225	511871	****	472
503921		65	504684		539	507821		567	509412				•	473
503922	••••	65	504685		539	507822	••••	567			249	511878		215
503923		65	504697	••••	477	507823	••		509413		539	511879		215
503924	•	65	504699	••••				567	509414		539	511956	• • • •	59
503925		65	504736		229	507824		567	509446		405	511957		59
503927	••••		504750		59	507825	• • • •	567	509448	••••	183	511958		59
503928	****	567	504766		423	507826	••••	567	509449		183	5119 6 3	••••	107
503929	••••	567	504840		49	507828		567	509463	• • • •	223			
503930	••••	567	504844		45	507829	···· .	53	509476		477	512086		475
	••••	567	504869	•	177	507845		387	509481		477	512102		475
503931	••••	567	504922		427				509482		477	512105	****	63
503932	••••	567	505144			508033	****	475	509483	****	477	512106		63
503933	•…	567	505144		257	508034		475	5 09510	,	477	512107		63
503934	****	567	505145	• • • •	457	508035		27 3	509513		99	512205		53
503935		567	505150		257	508060		243	509536		403	512206		53
503936		567	505196		257	508148		199	509556		223	512207	••••	53
503937		567	505197		257	508152		179	509558		225	512208		53
503938	••••	567	505198		257	508153		179	509582		235	512237	••••	151
503939		63	505244		245	509175		181	509730		249	512238		isi
503940		65	505361		79	508227		553	509751		173	512249		113
503979		482	505675		193	508228		553	509754	****	435	512251	••••	261
503981		193	505676		193	508239		553	509765	****	241	512305	****	
503982		265	505701		63	508257	••••	553	509766	****	241	512322	****	87
			505798		253	508283	••••	553	509767			512338	****	185
504006		43	505805		101	508284	••••	553			241		••••	263
504007		43	505826		235	508339			509769	••••	241	512352	••••	185
504032		57	505828		235			389	509856	••••	221	512359	• • • • •	185
504048		457	505853	•	235	508390		453	509860	••••	555	512385	••••	467
504062	••••	545	505855	••••		508392	••••	476	-509861	••••	555	512401		31
504080	••••	419	505898	••••	235	508393	• • • • • • • • • • • • • • • • • • • •	476	509866		555	512402	****	61
504104	••••	219	202090	. ••••	61	508394	••••	476	509867	• • • • • • • • • • • • • • • • • • • •	213	512412	•	43
504105	• • • • • • • • • • • • • • • • • • • •		504002		50	508412		453	509871	••••	241	512415	****	195
504106	`	219	506003		59	508493		469	509884	****	167	512416		195
	****	219	506069	• • • • • • • • • • • • • • • • • • • •	49	508494		551	509909		101	512417		197
504130	••••	257	506203		371	508499	• • • •	469	509910		538	512420		565
504135		219	506204	•	371	508516		551	509912		538	512501	****	425
504136		219	506205	••••	371	508544		538	509925		249	5127 01	****	159
504233	••••	245	506206		371	5 38545		538	509926		538	512706		41
504246	••••	393	5 06207		371	508565		199	509939		167	512797	****	113
504248	•••	.399	506210		67	508566	••••	199	509950		481	512798	****	113
504250	•	399	506276		241	508571		371	509970		217	512799	****	113
504252		399	506284		551	508581		201				512800		113
504253		399	506287	****	391	508582		203	510127		476	512806		35
	• • • • • • • • • • • • • • • • • • • •	187	506289		553	508591		173	510119		435	512828	.	123
504275		187	506290		553	508690		385	510081		476	512838		199
504276		187	506296		551	508691		385	510078		87	512839	••••	219
504279		187	506679		261	508692	****	385	510032		567	512887	••••	173
504282		387	506706		151	508863		475	510033		567	512889	,	iii
504283		387	506794		49	508895		213	510170		213	512891	••••	477
504287		385	506796		97	508896		213	510176		259	512896	••••	477
50.4200		419	·506814		53	508947		481	510177	****	459	512897	****	477
50.4.422		177	506818		19	508950		481	510178	••••	457	J12077		477
50.445R		551	506863	••••	385	508952	••••	481	510179	••••	257	513071		549
504450		551		••••	302	508953		481	510315	•	69	513072	••••	568 540
50.4485		61	507026		53	508957	••••	481	510469	••••			••••	568
50.4577		193	507129	••••	253	508958		481		••••	257	513174	****	29
50.4588	••••	85	507147		465	508959	••••		510489	••••	115	513193	****	469
50.4605	••••	389	507172	••••	469	508962	••••	481	510573		195	513223	••••	265
50.4606		389	507198	****	257	JU070Z	••••	225	510575		197	513282		265
50.4607		389	507199	••••		500000		07	510697		474	513314		257
504616		476		•-••	257 465	509009	••••	97	510730	•	57	513428		385
50/4610			507300 507308		465	509011	••••	97	510805		57	513429		385
50/4621	••••	67	507308		465	509045		173			4-	513454		177
		67 547	507311		465	509046		175	511036		17	513465		59
	• • • • • • • • • • • • • • • • • • • •	547	507312		465	509076		371	511302		474	513481		91
	• • • •	245	507315	••••	153	509085		387	511303		474	513506		61
504657	•	245	507447	••••	167	509120		481	511350		9	513507		63
JUTUJI .	••••	245	507526		247	509140	****	411 I	511680		55	513617		97
f0.3														

Part No.	Pag	e No. 1	Part No.	Pag	e No.	Part No.	Pag	e No.	Part No.	Pag	e No.	Part No.	Page	e No-
513639		55	515086		149	515729		141	517706		101	519671		457
513640		55	515090		141	515734	••••	175	517707		101	519672	• • • • • • • • • • • • • • • • • • • •	457
513641		55	515133		403	515835		48 1	517711	••••	101	519705		457
513649		27	515291		49	515845	••••	173	517773		453	519725	• • • •	433
513694		71	515313		65	515848	****	183	517836		417	519726	• • • •	433.
513926		137	515314		65	515849	••••	183	517837	****	417	519740	••••	253
513927	****	137	515321		51	515923	••••	207	517838	••••	417	519742	••••	253
513928		137	515323	••••	51	515924	••••	205	517839	••••	417	519743	****	255
513929	• • • • •	137	515331	****	235	515925	****	205	517855	••••	105	519744	••••	253 253
513937	• • • • •	261	515332		235	515926	••••	207	517860	••••	105 477	519746 519753	••••	185
513940	•	199	515405	••••	193	515927 515980	••••	207	517868 517869	••••	477	519755	••••	185
513989	••••	467	515406 515437	••••	193 97	515986	• • • • •	101 467	517877	••••	187	519775	****	253
514142		459	515455	••••	205	515987	••••	467	517878	•	187	519782	****	263
514143	••••	459	515463	••••	205	717/01	****	707	517907	••••	219	519783	••••	263
514144	••••	457	515464		205	516031		205	517976	••••	97	519784	••••	263
514145	••••	259	515465		205	516057	••••	225	518281		143	519806	,,,,	263
514146	****	259	515466	****	207	516059		59	518362		453	519814	****	263
514147	••••	259	515467		207	516082	****	149	518363		453	519827	•	253
514148	****	257	515468		207	516092		135	518437	••••	191	519838	••••	245
514149	****	257	515470		207	516133		43	518466	****	123	519840	****	253
514150	••••	257		••••		516136	••••	43	518468		47	519841	••••	253
514151	****	457	515505	•	235	516318		437	518473		157	519857	••••	538
514152	••••	257	515506		235	516399	****	477	518674		453	519863	••••	25
514153	41	259	515508		183	516410		217	518676		183	519864	4	49
514189		147	515509	****	183	516473	****	355	518677	****	183	519865	*	457
514190		147	515510	••••	403	516475	****	465	518682	****	219	519866	****	457
514191	****	147	515511	••	403	516476		465	518712		465	519873	****	539
514192	••••	147	515512	••••	403	51 64 77	••••	465	518719		123	519874	****	539
514193	••••	147	515513	****	403	516478	****	465	518725	••••	43	519875	****	538
514194	****	147	515514		403	516479	••••	465	518748	•	45	519876	•	363
514195	••••	147	515515	••••	403	516480	••••	465	518750	••••	45	519899	•	265
514224	****	85	515516	****	403	516481	*	465	518751	••••	45 45	519900 519979	****	261 469
514296	****	465	51551 7 515518	•	403 403	516482 516483	•	465 465	518752 518 7 53	••••	45 45	520039	****	49
514304	****	465	515519	****	409	516484	****	465	518754	••••	45	520041	••••	117
514315 514416	****	123 479	515520	****	409	516485	****	465	518755	****	45	520098		469
514423	****	57	515521	••••	409	516486	••••	465	518756		45	520237	••••	121
514450	****	59	515522	••••	409	516487	****	465	518757		45	520240		121
514451	****	57	515523	••••	409	516488	****	465	518758	••••	45	520242	•	121
514472	****	75	515524		409	516489		465	518759		45	520244		121
			515525		409	516490		465	518760	••••	45	520246	••••	121
514526	****	45	515526		409	516495	****	480	518761	• ••••	45	520248	• • • •	121
514527	****	43	515527	••••	411	516496	****	235	518762	••••	45	520849		217
514560	••••	543	515528	****	411	516853	****	474	518808		83	520850	••••	217
514561	****	543	515529	••••	411	516914	••••	241	518818	• • • •	59	520936	.****	121
514562	••••	545	515530	••••	411	516945	••••	235	519004	••••	111	52093 7 520938		121 121
514563	••••	543	515531	••••	411	517026		7 7	519005 510006	••••	111 111	520939	P***4	121
514564 514574	****	545 543	515532 515534	••••	411 411	517026 51 7 055	••••	477	519006 519007	****	iii	520940	****	121
514574	••••		515535	••••	411	517057	••••	477	519008	•	iii	520941	••••	121
514575 514577	****	543 484	515536	••••	411	517469	••••	235	519009		iii	520942		121
514578	****	484	515537	••••	411	517489	••••	453	519010		iii	520943		121
514623	••••	568	515538		4 11	517502		249	519011		111	520952		121
514624	••••	568	515539		411	517507	****	183	519054		51	520953	****	121
514650	••••	167	515540		411	517567		239	519055		51	520954	••••	121
514651	••••	453	515541		411	517577		413	519064		11	520955		121
51 47 21	••••	269	515542		411	517585		249	519206		179	520977		121
514734	••••	261	515543		411	517613		243	519248		175	520978	•	121
514790		185	515548	••••	411	517632		235	519249	••••	175	521027		478
514827		185	515549	• • • •	403	517682	••••	101.	519250		175	521488	••••	467
514840		185	515550		403	517683		101	519251		175	521543	••••	197
514887	•	261	515552		137	517684	•	103	519252		175	521544	••••	197
514893	••••	75	515572	••••	123	517685		103	519253	****	175 175	521584 521600	••••	101 85
514895	••••	263 363	515573 515597	••••	123 235	517686 517687		103 101	519254 519255		175	521771		221
514900 514929	••••	261	515598		235	517689	••••	101	519440		47	522297		153
514929		467	515599	••••	151	517690		101	519602		478	522318		153
514935		263	515677		121	517692		105	519638		185	522319		153

Part No.	Päg	e Ńo.	Part No.	Pag	ge No.	Part No	o. Pa	ge No.	Part No	. Pa	ge No.	Part No.	Ра	ge No.
522607		47	524684		97	527271	• • • •	474	531501		185	580036		405·
522646		457	524769		131	527272		63	531518		261	580038		403
522651		474	524806	••••	91	527273		61	531530		253	580039		405 -
522756		105	524838		53	527275		· 65	531539	••••	479	580041		403
522870	• • • •	474	524839		53	527280		474	531636	••••	469	580042		403
522872	••••	474	524841	•-••	129	527281	٠	474	531637		469	580043		403
522882		457 75	524846		49	527328		474	531642		469	580044		403
522913	•	7 5 47 4	524848	••••	43	527442	****	423	531643		469	580045		405
522923 5 22 93 7		101	524860 524865		123 123	528037 528038	****	61	531875	• • • • • • • • • • • • • • • • • • • •	423	580046		403
		101	524874		179	528039		63 61	531877 531879	••••	473	580047		403
		101	524875	·	179	528041	••••	63	531881		427 471	580048 580063	***-	403 403
		iŏi	524959	·	568	528053		61	531888		197	580064		403
40000		217	525131		49	528108		9 7	531889		197	580067		403
		123	525168	٠	101	528114		117	531892		197	580070		413
	··	484	525182	٠	49	528162		475	531893		197	580071		413
		129	525205		471	528163	٠	475	531894		173	580084		413
	•	123	525327		53	528443	· · ·	181	531905		199	580085		413
	·	45	525389	*****	53 53	528900	٠	539	531906	·	199		···	413
523322	··· 	45 45	525390 525428	• • • • • • • • • • • • • • • • • • • •	53 9	528919	·	265	531945	••••	457		···	413
523323		45	525428 525481	•	117	528931 528950		263	531947	****	478			413
E00004		45	525500	·	53	528953	···	253 469	531949 531951		479 479	580089	`	413
523325		45	525520		117	528955		469	532044	*****	197	#00001		413. 413
		45	525521		117	528956		469	532156		469	580092		413
523327		45	525588		474	528957		469	532267		181	580093	·	413
523328		45	525590		451	528958		469	532268	****	181	500004		411
523329		45	525852	,	45	528963		265	532566		147	COCOCC		411
		45	525853	?	45	528968		4 69	532567	· ··	147	580096		415
523331	• • • • • • • • • • • • • • • • • • • •	45	525854		45	528987		469	532568		145			413
	·	45 45	525855	••••	45	529089	• • • • • • • • • • • • • • • • • • • •	61	532569	****	145	580099	· · ·	415
	· ·	4 5	525856		43	529303	* * *	75	532570		145	580100		413
F00000		47 47	525857 525927		43 45	529365		45 479	532571		145	590101	****	413
500000	`	47	525975		45 129	529443 529963	* **	478	532572		145			415
523340		47	526151		59	529965		263 263	532573 532574	****	145 145	500104	•	415
523354	•	59	526225		7 5	529966		265	532575	1111	145	500105	····	413 415
523385		257	526258		111	529968		263	532576		145	580106	·	415
523410	·	425	526353		478	529969		245	532577		145	580107		415
523500		427	526354		478	529970		538	532578		145	600100	· · · · · · · · · · · · · · · · · · ·	413
523637	·	255	526355		478	529971		145	532579		145			415
523638		568	526357	•	478	529972		123	532580		145	589111		415
523655 523683		417	526358		478	530012	· ··	469	533822		474	580112	·	415
F 2 2 7 6 2 2		451 241	526360 526426	****	263 478	530034 530047	****	253	580001		403		·	413
523695	·	217	526427	·	478 478	530047	*****	263 261	580003 580004		403		****	413
523696		217	526428	·	478	530071	·	253	580007		403 403	400440	···	415 415
ごつつ マハマ		415	526429	····	478	530073		261	580008		405		···	415
523708		415	526430	·	478	530083		263	580009		405	E00100		415
5 239 05		87	526432		478	530084		265	580010	··	405	4004	·	415
	·	217	52644 0		263	530085	'	265	580011		405	580122		411
524134	•	453	526528	·,	145	530086		265	580012	·	405	580123		411
524135	·	403	526756	•••••	211	530130		429	580015		405	580124	·	407
524136 524138		403 43	526768 526769	·	405 213	530132		425	580016		405	580125	·	415
524151	••••	47	526777	·	215	530135 530303	* - * •	387	580017		405	580126	****	415
524152		47	526810		211	530304	••••	425 425	580018 580019		405	580127		415
524153	•	47	526811		211	530305		425 425	580020		405 405	580128 580132	••••	415 407
524154	••••	47	526812		211	530476		59	580020	****	405	580133	••••	407 403
52 415 5		47	526991		241	530477		59	580022		405	580134	1	405
524200		59	526992		241	530478		59 ·	580026		409	580135		405
524203		119	526993		189	530511		429	580027		409	580136		405
524206		45	526994	• • • •	189	530556		243	580028		409	580137		403
£34310	••••	147	527010		247	530590	,	59	580029		409	580138		403
524407	••••	147	527164	••••	47	530621		405	580030		409	580139		403
534400	••••	457	527167 527160		45	530756	• • • •	71	580031		403	580140		405
534607	•	459 61	527169 527240		121 129	531080 531081		211	580032		405	580141	**	405
524427		43	527270	****	474	531082	i	475 211	580033 580035	· ·:	405 403	580142		413
J= 10J1	••••	-1J 1	J2121U	••••	7/7	- 100 <u>4</u>		411 •	, CCOOO	••••	403	580152		407