

Parts Change Notice

Model No. CF-72 Series

Please revise the original parts list in the Service Manual to conform to the change(s) shown herein.

If new part numbers are shown, be sure to use them ordering parts.

<i>Reason for change</i>		*The circled item indicates the reason. If no marking, see the Notes in the bottom column.	
1. Improve performance		1. When change item *1 or/and *2 on the below list, item *6 should be used new ones.	
2. Change of material or dimension		2. When change item *3 or/and *4 on the below list, item *6 should be used new ones.	
3. To meet approved specification		3. Don't use the removed screws of item *6 on the below list, because of quality.	
4. Standardization		4. Item *5 and *7 on the below list should be changed simultaneously.	
5. Addition			
6. Deletion			
7. Correction			
8. Other			

<i>Interchangeability Code</i>		**The circled item indicates the interchangeability. If no marking, see the Notes in the bottom column.	
Parts	Set Production		
A Original New	 Early Late	Original or new parts may be used in early or late production set. Use original parts until exhausted, then stock new parts.	
B Original New	 Early Late	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.	
C Original New	 Early Late	New parts only may be used in early or late production sets. Stock new parts.	
D Original New	 Early Late	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.	
E Other			

<i>Part Number</i>						
Model No.	Ref. No.	Original Part No.	New Part No.	Notes(**)	Part Name & Descriptions	Q'TY
CF-72(Q3G/TCJ)xxxx	E23	N3CABQD00001	N3CABQD00009	8, A	HDD, 30GB	1
CF-72TCxxxxx	E46	DFWV84A0209	DFWV84A0214	8, A	TOUCH SCREEN PANEL KIT	1
CF-72xCxxxxx	K80	DFBH1157ZA *1	DFBH1157YA	1, C	HINGE-L (CF-72xCxxxxx)	1
		DFBH1158ZA *2	DFBH1158YA	1, C	HINGE-R (CF-72xCxxxxx)	1
CF-72x3xxxxx	K80	DFBH1159ZA *3	DFBH1159YA	1, C	HINGE-L (CF-72x3xxxxx)	1
		DFBH1160ZA *4	DFBH1160YA	1, C	HINGE-R (CF-72x3xxxxx)	1
CF-72N3FxZxx	K126	DFHR8374ZA *5	--	6, B	DUMPER, SIDE, LCD	4→2
		DFHE5086ZA	DXSB26+6FNL	1, B	SCREW	6
CF-72xxxxxxx	K231	DXSB26+6FNL *6	--	--	SCREW	6
CF-72N3FxZxx	K960	-- *7	DFHR5885ZA	5, B	DUMPER SIDE 2, LCD	0→2
CF-72TCJWZxM CF-72(V/X)xxWxxM	E4(M) 	(DVD-ROM & CD-R/RW Drive CF-VDR721)				
		DFWV78A0149	DFWV78A0200	8, A	DRIVE, COMBO DRIVE	1
CF-72(V/X)xxWxxx	E4(Z) --  E,G,F,S,T,P	DFWV78A0150	DFWV78A0201	8, A	DRIVE, COMBO DRIVE	1

File this Parts Change Notice with your copy of the Service Manual.