

URV 3

RF MILLIVOLTMETER

10 kHz to 2 GHz 0.7 mV to 1050 V

	★ MILLIVOLTMETER - 10 kHz - 2 GHz - URV 3		R
	1 15 2 25 2 20 20 - 6 - 1 - 2 0 - 2 - 1 dBm 1 10 - 1 10 - 2 - 1 dBm 1 10 - 1 10 - 2 - 1 dBm 1 10 - 1 10 - 2 - 1 dBm 1 10 - 2 - 1 - 1 dBm 1 10 - 2 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	20 3 30 10 BATT AUS OFF EIN - DN C C C C C	
C		Street, a	

- Handy RF millivoltmeter for mobile and stationary use
- RF probe (C_{in} = 2.5 pF) can also be combined with 20-dB or 40-dB divider
- RF insertion units with defined characteristic impedances 50 and 75 Ω , RF voltage coverage up to 100 V
- RF measuring heads can be quickly exchanged thanks to secure plug-and-socket connection
- Small measuring error of 3% the RF measuring heads can be used with all voltmeters of the URV family
- Floating during battery and accumulator operation
- Universal powering system battery, accumulator, power supply unit or external source

URV 3

Characteristics

The URV 3 is a highly sensitive and accurate millivoltmeter for measuring RF voltages in the range from 10 kHz to 2 GHz (up to 3 GHz if used only as an indicator). A broad range of accessories (see photo below) and battery operation capability permit versatile stationary and mobile use of the voltmeter.

The URV 3 affords extremely constant indication and zero setting as well as easy reading of the measured values. Low capacitive and resistive loading by the RF probe minimize measuring errors introduced by detuning of resonant circuits, damping and unwanted phase shifts in feedback networks, etc. Mismatching is negligible thanks to the low reflection coefficient of the RF insertion units.

Measuring heads

The measuring heads are freely interchangeable within the URV family without degrading the error limits. The accuracy is exclusively determined by the matching of the characteristics of the diodes used in the measuring head. The RF probe is supplied with the URV 3, the other accessories are recommended extras.

RF probe alone:

700 μV to 10.5 V 100 kHz to 1 GHz (up to 2 GHz if only used as an indicator)

REproise + 20-dE divider:

7 mV to 105 V 2 to 500 MHz



70 mV to 1050 V

1 to 500 MHz

The capacitive dividers at the same time reduce the input capacitance and increase the input resistance.

REprobe + BNC adapter

(with or without divider):

RF voltage measurement in coaxial systems up to 350 V (probe + 40-dB divider + BNC adapter); limit dictated by the voltage rating of the BNC connecting cables.

RF probe + 75-Ω adapter:

700 μV to 10.5 V

100 kHz to 500 MHz

RF voltage measurement in coaxial 75- Ω systems (adaptable connectors, see page 6).

RF Insertion units:

RF voltage measurement in coaxial systems with low reflection coefficient; various connector systems (see page 6).

- 10-V insertion units (50 or 75 Ω):
 - 700 μV to 10.5 V
 - 10 kHz to 2 GHz
 - (up to 3 GHz if only used as an indicator) at 50 Ω
- 10 kHz to 1.6 GHz at 75 Ω
- 100-V insertion unit (50 Ω): 7 mV to 105 V, 1 MHz to 2 GHz

Appropriately terminated, the 100-V insertion unit is suitable for measurements on power stages up to 200 W.



RF Millivoltmeter URV 3 with measuring heads: 100-V insertion unit and 10-V insertion unit; case containing RF probe and accessories, all supplied with the URV 3. The case also accommodates the recommended extras: 20-dB divider, 40-dB divider, BNC adapter and 75-Ω adapter.

Uses

RF voltage measurements. High-impedance measurements with RF probe in broadband amplifiers, on resonant circuits of oscillators, narrowband amplifiers and filters; measurements with impedance-matched RF insertion unit at the outputs of transmitters and other coaxial systems. True rms value measurement possible up to 3 V and peak-value measurement from 1 V RF voltage.

Input impedance of RF probe

The input impedance of the RF probe is given by the input capacitance C_{in} and the parallel input resistance R_{p} ,



Adjustment to maximum, minimum or nominal value. Determination of the 3-dB points as a function of frequency.

Gain or attenuation measurement. Measurement of gain attenuation on passive or active four-terminal networks as a function of frequency (frequency response).

Level measurement. Measurement of level in dBm referred to 0 dBm = 1 mW into 50 Ω (0.2236 V), correction of level indication (according to relation 10 log $\frac{-50}{Z}$): -1.76 dB at Z = 75 Ω .

which is dependent on the test voltage, and, above 3 MHz, also on the frequency. See diagrams below.



Input resistance $R_{\rm po}$ for f <3 MHz as a typical function of the test voltage (sinewave).

Typical frequency function of the input resistance R_p relative to the input resistance R_{po} at low frequencies.

Waveform weighting

Rms-value measurement. The URV 3 measures and reads the rms value in the most sensitive measurement ranges. The curves below show the maximum permissible crest factor vs. test voltage for weighting errors of +2% and +5%.

Peak-value measurement. The URV 3 measures the peak-to-peak value at voltages above 1 V but reads out the value $\frac{V_{pp}}{2\sqrt{2}}$. This corresponds to readout of the rms value for sinusoidal voltages. The curves below show the maximum permissible crest factor vs. test voltage for weighting errors of -2% and -5%.

Alsoinum permissible prest factor 0

for rms-value measurement (left) and peak-value measurement (right)



In the transition region between rms-value and peak value measurement the reading is defined only for sinusoidal voltages.

Specifications

Test input

Parameters measured voltage (V, m)	/)/level (dBm)		
	Iz (choice of measu	uring heads)	
	0 V (with dividers)	0 /	
Level range	,		
Level reference 0 dBm corresp	onding to 1 mW into	o 50 Ω (0.2236 V)	
Range of indication \ldots \ldots \ldots \ldots \ldots \ldots 300 to 700 μ V			
Connection of measuring head three-pole soc	three-pole socket (for URV measuring heads)		
	20-dB and 40-dB d		
	er and 75- Ω adapte	r	
	unit (50, 75 Ω)		
100-V insertio			
Input impedance of RF probe $R_p > 80 \ k\Omega$ (
with 20-dB divider	up to 20 MHz), C _{in} =	= 1 pF	
with 40-dB divider			
Voltage rating V DC	V _{rms} (sinewave)		
RF probe	15 V	22 V	
with 20-dB divider	150 V	220 V	
with 40-dB divider			
up to 100 MHz 1000 V	1050 V	1500 V	
up to 500 MHz1000 V	210 V	1500 V	
10-V insertion unit	15 V	22 V	
100-V insertion unit	150 V	220 V	
75-Ω adapter ($P_{max} = 2 W$)	12 V	17 V	
		· · ·	

Deflection as afficients			Measuring head	10 Zo	kHz 100 kHz	1 MHz	10 MHz	100 MH:	z 2 5		I GH 1.6	Hz 2 6
Reflection coefficients	· · · · ·	•••	10-V insertion unit	50 Ω	Reflection coeffi in %	cient 1			2	5	10	15
				75 Ω		3			3	15	20	
			100-V insertion unit	50 <u>Ω</u>		1					2	
			75-Ω adapter	75 Ω		1.5		3	10			

Frequency ranges

. requerey rangee	
RF probe	. 100 kHz to 1 GHz
	(up to 2 GHz if only used as indicator)
with 20-dB divider	. 2 to 500 MHz
with 40-dB divider	. 1 to 500 MHz
10-V insertion unit, 50 Ω	. 10 kHz to 2 GHz
	(up to 3 GHz if only used as indicator)
10-V insertion unit, 75 Ω	. 10 kHz to 1.6 GHz
100-V insertion unit, 50 Ω	. 1 MHz to 2 GHz
75- Ω adapter	. 100 kHz to 500 MHz
Voltage ranges (level ranges $Z = 50 \Omega$)	
RF probe, 10-V insertion unit	. 700 μ V to 10.5/-50 to +33 dBm
RF probe with 20-dB divider,	
100-V insertion unit	. 7 mV to 105 V/-30 to +53 dBm
RF probe with 40-dB divider	
Subranges Voltage measurement	. 3/10/30/100 mV/0 3/1/3/10 V
Level measurement	$-40/-30/-20/-10/0/+10/+20/+30 \mathrm{dBm}$
Range setting	
-	5

RF MILLIVOLTMETER URV 3

Service life Battery (alkali-manganese cells)	 approx. 70 h 240 mm x 109 mm x 217 mm, 2.5 kg (with batteries)
Order designation	. ► RF Millivoltmeter URV 3 302.9014.02
without RF Probe URV-Z7	. 302.9014.12
Accessories supplied RF Probe URV-Z7	comprising earth cable 241.0620.00 with clip earth sleeve 241.0688.00 earth strip 243.9053.00 hook tip 265.4631.00 solder tip 265.4648.00
4 batteries, R-20, IEC	in case 219.5900.02 . 017.0015.00
Recommended extras	
Accessories URV-Z6	. 292.5364.02 comprising 20-dB divider 241.1510.00 40-dB divider 241.1710.00 BNC adapter URV-Z 241.1110.02 for RF probe (including reducing sleeve for dividers)
75-Ω Adapter URV-Z3	. 243.9118.70 comprising adapters from UNI-9 socket to 2.5/6 connector 243.9260.00 to 1.6/5.6 connector 243.9276.00 to BNC connector 243.9282.00
RF insertion units	
10-V Insertion Unit URV-Z2	
with connecting cable for buffer operation and charging Lead Storage Battery (6 V) EGT-Z	201.5414.00 . 201.5437.00