



A3 Attenuator circuit board

A4 Display circuit board

*See Parts List for
serial number ranges.

† Located on back of board.

‡ Selected component, refer to
maintenance section.

CKT NO	GRID LOC	CKT NO	GRID LOC	CKT NO	GRID LOC	CKT NO	GRID LOC	CKT NO	GRID LOC	CKT NO	GRID LOC
C112	K2	C214*	C3	DS510	I5	L195	E4	R116*†	L1	R216	F3
C118*	L1	C215*	D3	DS520	I5	L197	F5	R118*†	K1	R510	H5
C124	M2	C216	F3	DS530	I5	L200	E4	R174	C4	R520	H5
C170	D5	C218*	D3			L204	F4	R175	C5	R530	J5
C172	D5	C230	E3	L110	J3	L208	E3	R176	C4		
C180	D4	C232	D3	L112	J2	L212	E3	R177*‡	B2	S100	L2
C184	C4			L114	J1			R180	C4	S240	C2
C190	C5	CR200	E4	L116	K1	LR110	K3	R184	D4		
C192	E5	CR202	E4	L118	K1	LR112	K2	R190	D4	U225	D2
C194*	D4	CR216	C3	L120	L1	LR114	J2	R192	D5	U240	C3
C200	E4	CR218	D3	L122	M1	LR190	E4	R195	E4	U245	C2
C204	E3			L124	M2			R197	E5		
C208	E3	DS500	H5	L184	D4	Q180	C4	R204	F4	VR200	E5
C212	E2					Q190	D4	R212	F2	VR202	E5