NTSC-to-PAL format converter BA7045/BA7045FS

The BA7045 and BA7045FS are NTSC-to-PAL converter ICs. They include a sub-carrier frequency doubler circuit, balance modulator, half-H killer circuit, phase comparator circuit, voltage controlled oscillator circuit, burst-gate pulse generator circuit, 1/2 frequency divider, circuit 3dB and 12dB amplifiers circuit, and two switch circuits. The ICs convert NTSC chroma signals recovered from a 4.43MHz sub-carrier into PAL chroma signals. They can also convert 3.58MHz NTSC chroma signals into M-PAL chroma signals. In addition, by using external control to switch the internal analog switches, jumping compensation for PAL VTR EP mode is possible.

Applications


Video cassette recorders

Features

- 1)Low power dissipation.
- 2)Converts 4.43MHz NTSC to PAL.
- 3) Jumping compensation for PAL VTR EP mode.
- 4)Few external components required.

- 5)Adjustable balance modulator (BM) gain.
- 6) Adjustable burst gate pulse phase.
- 7) Compatible with M-PAL.

Block diagram





NTSC/PAL format converters


●Pin descriptions


Pin No.	Pin name	Function			
1	fsc In	Sub-carrier input			
2	GND	GND			
3	2fc Tank	For connection to frequency-doubling tank circuit.			
4	BGP Adj.	Burst gate pulse position adjustment			
5	VCO In.	VCO control input			
6	DET Out	Phase difference detector output			
7	SW CTL	Internal analog switch control			
8	C. Sync In	C. Sync input			
9	12dB Amp OUT	12dB amplifier output			
10	Vcc	Power supply			
11	12dB Amp In	12dB amplifier input			
12	B. M. Gain Adj.	Balance modulator gain adjustment			
13	SW2 Out	SW2 output			
14	3dB Amp In	-45° chroma signal input			
15	Buff Out	For connection to low-pass filter			
16	Chroma in	4.43MHz chroma signal input			


●Input / output circuits



















Input / output circuits




















NTSC/PAL format converters

●Absolute maximum ratings (Ta=25°C)

Parameter	Symbol	Limits	Unit
Applied voltage	VCC Max.	8.0	. v
Power dissipation	Pd	1100	mW
Operating temperature	Topr	-25~70	°C
Storage temperature	Tstg	-55~125	င

^{*} Reduced by 11.0mW for each increase in Ta of 1°C over 25°C.

●Recommended operating conditions (Ta=25°C)

Parameter	Symbol	Limits	Unit
Supply voltage	Vcc	4.5~5.5	V

●Electrical characteristics (Unless otherwise specified Ta=25°C and Vcc=5.0V)

Parameter	Symbol	Min.	Тур.	Max.	Unit	Conditions	
Quiescent current	lcc		24.0	36.0	mA		
Pin 13 DC level difference	ΔVO13	_	0	50.0	mV	ΔVC ₁₃ = CONV - NonCONV	
Pin 16 to pin 11 gain	G18-11	-7.8	6.8	-5.8	dB	f=4.43MHz, V _{IN18} =300mVpp	
Pin 16 to pin 9 gain	G16-9	5.2	6.2	7.2	dB -	f=4.43MHz, Vin16=300mVpp	
Pin 14 to pin 11 gain	G14-11	一6.7	-5.7	-4.7	dB	f=4.43MHz, V _{IN14} =300mVpp	
B.M. gain O	Bg - O	-1.0	0	1.0	dB	f=4.43MHz, V _{IN18} =300mVpp	
B.M. gain L	Bg - L	2.0	3.5	5.0	dB	f=4.43MHz, VIN1=500mVpp Bg=CONVGain - NonCONVGain	
B.M. gain H	Bg - H	-4.0	-2.5	-1.0	dB	Adjustable via pin 12	
Free-running frequency	frace	13.9	15.7	17.5	kHz	No signal on pin 8	
AFC lock confirm	fLO	_	15.734	-	kHz		
BGP width	ТВ	6.0	7.0	8.5	μsec		
BGP phase O	PhB - O	8.0	10.0	12.0	μ sec		
BGP phase L	PhB - L	16.0	21.0	26.0	μsec	Adjustable via pin 4	
BGP phase H	PhB - H	-4.9	0.1	5.1	μsec		
HHK operation confirmation 1	HHK1		15.7	_	kHz		
HHK operation confirmation 2	HHK2		15.7	. —	kHz		
Pin 8 switching level H	VTHB - H	2.1		5.0	V		
Pin 8 switching level L	Vтне - L	0	_	0.5	V	,	
SW switching voltage H	CTL - H	3.7	4.1	4.5	V		
SW switching voltage M	CTL - M	2.1	2.5	2.9	V	1	
SW switching voltage L	CTL - L	0.5	0.9	1.3	V	1	

O Not designed for radiation resistant.

●Guaranteed design items (Unless otherwise specified: Ta=25°C and Vcc=5.0V)

Parameter	Symbol	Min.	Тур.	Max.	Unit	Conditions
Dynamic range of 12dB amplifier	D11-9	2.0	2.5	_	V	f=1kHz, THD=5%
Capture range	∆ fcap	±2.0	±2.5	_	kHz	,
B.M. carrier leak	CLesk	_	_32	. –	dB	f=4.43MHz, Vin16=300mVpp f=4.43MHz, Vin1=500mVpp

Circuit operation

This IC is used to convert NTSC-format video tape recordings to PAL format for playback on PAL-format VCRs. The IC converts an NTSC chroma signal recovered from a 4.43MHz sub-carrier to a PAL chroma signal. With the PAL system, a color burst signal is repeated every 1H at phases of +45° and -45° with respect to the EB-Y axis. Therefore, to convert NTSC to PAL, the color burst signal at each 1H is shifted by +45° or -45° rela-

tive to the E_{B-Y} axis. The color signal that is shifted by -45° is used as is, but in the case of the color signal that is shifted by $+45^{\circ}$, the reflection of this signal across the E_{B-Y} axis is used.

With the BA7045, the signal prosessing indicated above is performed at each block. Also, the NTSC signal can be converted to a regular PAL signal.

BA7045 timing chart




Fig.1 Timing chart

●Control logic

SW CTL	SW1 position	SW2 position
High	1	1
Middle	1	2
Low	Auto	Auto

Application example

NTSC to PAL signal conversion (NTSC→PAL)




Fig. 2 NTSC to PAL conversion

NTSC to M-PAL signal conversion (NTSC→M-PAL)




Fig. 3 NTSC to M-PAL conversion

Operation notes

1. VCO free-running frequency and capture range

The free–running frequency of the VCO set by the $75\,\Omega$ resistor connected between pin 5 and GND. This resistor should have a tolerance of $\pm 2\%$ and a temperature coefficient of 100ppm or less. The capture range of the circuit is set by the values of the resistors and capacitor connected between pins 5 and 6.

The free-run frequency and capture range of the circuit are guaranteed for these component values, and we recommend that you use them.

2. Adjustment of the pin 3 tank circuit

Adjust the frequency fo of the tank circuit connected to pin 3 to 8.86MHz. If fixed-value components are used, adjustment is not necessary, but if you are using variable components and wish to adjust fo, do not connect the measuring instrument (frequency counter or oscilloscope) directly to pin three, as this will cause the frequency to change. Connect the measuring instrument via a transistor buffer circuit as shown in Fig. 4. Select the value of the Q damping resistor R so that the voltage on pin 3 is between 500mVP-P and 600mVP-P.




Fig. 4 Tank circuit

3. Adjustment of the color phase

The IC modulates the input signal by $-\text{COS2}\,\omega$ ST to generate a waveform that is symmetric about the Eb-Y axis. To generate this waveform, adjust the phase of the subcarrier signal on pin 1. To adjust the phase of the subcarrier signal, observe the signal burst angle using a vectorscope, and adjust the phase angle of the pin 1 sub-carrier signal to 90°.

4. Use in M-PAL systems

When using the IC in M-PAL systems (chroma sub-carrier 3.57561149MHz) use the following circuit constants:


- 1. Change the fo frequency of the tank circuit connected to pin 3 to 7.15MHz.
- 2. Change the values of the phase circuit components between pins 14 and 15 to 910 Ω and 30pF.
- Change the low-pass filter connected between pins 11 and 13 to ensure sufficient attenuation at 10MHz (3fsc).

5. Screen beat

If screen beat occurs, employ the following countermeasures:

Generation mechanism

Screen beat is caused by spectral components other than the 4.43MHz signal included in the chroma signal input to




Countermeasures

(1)Ensure sufficient attenuation for spectral components other than 4.43MHz in the BM output (5.06MHz and 5.69MHz) that is the pin 16 chroma signal input.

(2) Change the low-pass filter connected between pins 11 and 13 to a 4.43MHz band-pass filter to eliminate the effect of the 3.17MHz and 3.8MHz frequency components. When carrying out these countermeasures, use a spectrum analyzer to monitor the frequency spectrum at each pin.

●External dimensions (Units: mm)



Notes

- The contents described in this catalogue are correct as of March 1997.
- No unauthorized transmission or reproduction of this book, either in whole or in part, is permitted.
- The contents of this book are subject to change without notice. Always verify before use that the contents are the latest specifications. If, by any chance, a defect should arise in the equipment as a result of use without verification of the specifications, ROHM CO., LTD., can bear no responsibility whatsoever.
- Application circuit diagrams and circuit constants contained in this data book are shown as examples of standard use and operation. When designing for mass production, please pay careful attention to peripheral conditions.
- Any and all data, including, but not limited to application circuit diagrams, information, and various data, described in this catalogue are intended only as illustrations of such devices and not as the specifications for such devices. ROHM CO., LTD., disclaims any warranty that any use of such device shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes absolutely no liability in the event of any such infringement, or arising from or connected with or related to the use of such devices.
- Upon the sale of any such devices; other than for the buyer's right to use such devices itself, resell or otherwise dispose of the same; no express or implied right or license to practice or commercially exploit any intellectual property rights or other proprietary rights owned or controlled by ROHM CO., LTD., is granted to any such buyer.
- The products in this manual are manufactured with silicon as the main material.
- The products in this manual are not of radiation resistant design.

The products listed in this catalogue are designed to be used with ordinary electronic equipment or devices (such as audio-visual equipment, office-automation equipment, communications devices, electrical appliances, and electronic toys). Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of which would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers, fuel controllers, or other safety devices) please be sure to consult with our sales representative in advance.

Note when exporting

- It is essential to obtain export permission when exporting any of the above products when it
 falls under the category of strategic material (or labor) as determined by foreign exchange or
 foreign trade control laws.
- Please be sure to consult with our sales representatives to ascertain whether any product is classified as a strategic material.