


RECORD/PLAYBACK AMPLIFIER

—TOP VIEW—



PIN NO.	I/O	SIGNAL	PIN NO.	I/O	SIGNAL	PIN NO.	I/O	SIGNAL	PIN NO.	I/O	SIGNAL
1	I	Vcc1	13	I	PEAKI1	25	I	Vcc2	37	—	NC
2	—	GND	14	I	PS1	26	O	PBXOUT1	38	I	PEAKT2
3	—	NC	15	—	NC	27	O	PBYOUT1	39	I	RECI2
4	I/O	X2	16	I	RECIN1	28	—	NC	40	I	WCEVR2
5	I/O	Y2	17	—	NC	29	I	FBDUMP1	41	I	REC/PB2
6	—	GND	18	I	CLK1	30	I	PBIR1	42	—	NC
7	—	GND	19	—	NC	31	I	PBIR2	43	I	CLK2
8	I/O	Y1	20	I	REC/PB1	32	I	FBDUMP2	44	—	NC
9	I/O	X1	21	I	WCEVR1	33	—	NC	45	I	RECIN2
10	—	NC	22	I	RECI1	34	O	PBYOUT2	46	—	NC
11	—	GND	23	I	PEAKT1	35	O	PBXOUT2	47	I	PS2
12	I	Vcc1	24	—	NC	36	I	Vcc2	48	I	PEAKI2

