

ELECTRONIC VOLUME

- TOP VIEW -



INPUT

CE ; LATCH ENABLE

CLK ; SERIAL CLOCK

DATA ; SERIAL DATA

INIT ; SYSTEM RESET

INN1, INN2 ; OPERATIONAL AMPLIFIER NEGATIVE PHASE

INP1, INP2 ; OPERATIONAL AMPLIFIER POSITIVE PHASE

VCT ; CENTER POTENTIAL

VRIN1, VRIN2 ; VOLUME

OUTPUT

INAO1, INAO2 ; OPERATIONAL AMPLIFIER

OUT1, OUT2 ; VOLUME

VCT1, VCT2 ; VCT BUFFER

