


ELECTRONIC VOLUME

—TOP VIEW—



INPUT

CE ; LATCH ENABLE
CLK ; SERIAL CLOCK
DATA ; SERIAL DATA
INIT ; SYSTEM RESET
INN1, INN2 ; OPERATIONAL AMPLIFIER NEGATIVE PHASE
INP1, INP2 ; OPERATIONAL AMPLIFIER POSITIVE PHASE
VCT ; CENTER POTENTIAL
VRIN1, VRIN2 ; VOLUME

OUTPUT

INAO1, INAO2 ; OPERATIONAL AMPLIFIER
OUT1, OUT2 ; VOLUME
VCT1, VCT2 ; VCT BUFFER

