


EQUALIZER

—TOP VIEW—

**INPUT**

AIX : SERIAL X

AIY : SERIAL Y

LAJ : INPUT SIGNAL DETECT LEVEL ADJUST

OUTPUT

AGCL : DETECTOR LEVEL

AGCR : DETECTOR REFERENCE LEVEL

MON : EQUALIZED SIGNAL

SDT : INPUT SIGNAL DETECT

SX : SERIAL X

SY : SERIAL Y

OTHER

Vcc2 : FOR SERIAL OUTPUT

