


C-MOS 4 4 CROSSPOINT SWITCH -TOP VIEW-



INPUTS						SELECTED CHANNELS															
STROBE	D	C	B	A	DATA	Y0 X0	Y0 X1	Y0 X2	Y0 X3	Y1 X0	Y1 X1	Y1 X2	Y1 X3	Y2 X0	Y2 X1	Y2 X2	Y2 X3	Y3 X0	Y3 X1	Y3 X2	Y3 X3
0						NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	0	0	0	OFF	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	0	0	1	ON	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	0	1	0	NC	OFF	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	0	1	1	NC	ON	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	1	0	0	NC	NC	OFF	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	1	0	1	NC	NC	ON	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	1	1	0	NC	NC	NC	OFF	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	0	0	1	1	1	NC	NC	NC	ON	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC
1	1	1	1	1	0	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	OFF
1	1	1	1	1	1	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	NC	ON

0 ; LOW LEVEL
1 ; HIGH LEVEL
; DON'T CARE
NC ; NO CHANGE