


DIFFERENTIAL OUTPUT LINE DRIVER

—TOP VIEW—



INPUTS		ENABLE		OUTPUTS	
A		E		Y	Z
1		1		1	0
0		1		0	1
x		0		HI-Z	HI-Z

0 : LOW LEVEL
1 : HIGH LEVEL
x : DON'T CARE
HI-Z : HIGH IMPEDANCE