

LT1180ACS
IL08

RS232 DUAL DRIVER/RECEIVER

- TOP VIEW -



INPUT

C1+,C1-,C2+,C2- ; COMMUTATING CAPACITOR
TR1, TR2 IN ; RS232 DRIVER SIGNAL
ON/OFF ; TTL/CMOS COMPATIBLE OPERATING MODE CONTROL
REC1, REC2 IN ; RECEIVER

OUTPUT

V+ ; POSITIVE SUPPLY (RS-232 DRIVERS)
V- ; NEGATIVE SUPPLY (RS-232 DRIVERS)
TR1, TR2 OUT ; RS232 DRIVER SIGNAL (RS232 LEVELS)
REC1, REC2 OUT ; RECEIVER (TTL/CMOS VOLTAGE LEVELS)