



# Contents

Page	Section	Title
5	1.	Introduction
5	1.1.	Features of MSP 3407D and MSP 3417D
5	1.2.	Specific MSP 3417D Features
5	1.3.	Unsupported MSP 34x0D Functions
5	1.4.	MSP 34x0D Inputs and Outputs not included in the MSP 34x7D
6	2.	Basic Features of the MSP 34x7D
6	2.1.	Demodulator and NICAM Decoder Section
6	2.2.	DSP-Section (Audio Baseband Processing)
6	2.3.	Analog Section
7	3.	Application Fields of the MSP 34x7D
7	3.1.	NICAM plus FM/AM-Mono
7	3.2.	German 2-Carrier System (DUAL FM System)
10	4.	Architecture of the MSP 34x7D
10	4.1.	Demodulator and NICAM Decoder Section
10	4.1.1.	Analog Sound IF – Input Section
11	4.1.2.	Quadrature Mixers
11	4.1.3.	Lowpass Filtering Block for Mixed Sound IF Signals
12	4.1.4.	Phase and AM Discrimination
12	4.1.5.	Differentiators
12	4.1.6.	Lowpass Filter Block for Demodulated Signals
12	4.1.7.	High Deviation FM Mode
12	4.1.8.	FM-Carrier-Mute Function in the Dual Carrier FM Mode
12	4.1.9.	DQPSK-Decoder (MSP 3417D only)
12	4.1.10.	NICAM-Decoder (MSP 3417D only)
13	4.2.	Analog Section
13	4.2.1.	SCART Switching Facilities
13	4.2.2.	Standby Mode
13	4.3.	DSP-Section (Audio Baseband Processing)
13 14	4.3.1. 4.4.	Dual Carrier FM Stereo/Bilingual Detection
14	4.4. 4.5.	Audio PLL and Crystal Specifications Digital Control Output Pins
15	5.	I <sup>2</sup> C Bus Interface: Device and Subaddresses
16	5.1.	Protocol Description
17	5.2.	Proposal for MSP 34x7D I <sup>2</sup> C Telegrams
17	5.2.1.	Symbols
17 17	5.2.2.	Write Telegrams
17 17	5.2.3.	Read Telegrams
17 18	5.2.4. 5.3	Examples Start Un Sequence: Power Un and I2C-Controlling
18	5.3.	Start Up Sequence: Power Up and I <sup>2</sup> C-Controlling

# Contents, continued

Page	Section	Title
19	6.	Programming the Demodulator Section
19	6.1.	Autodetection, Short-Programming, and General Programming of the Demodulator Part
20	6.2.	Demodulator Write Registers: Table and Addresses
20	6.3.	Demodulator Read Registers: Table and Addresses
21	6.4.	Demodulator Write Registers for Short-Programming: Functions and Values
21	6.4.1.	Demodulator Short-Programming
22	6.4.2.	AUTO_FM/AM: Automatic Switching between NICAM and FM/AM-Mono (MSP 3417D only)
23	6.5.	Demodulator Write Registers for the General Programming Mode: Functions and Values
23	6.5.1.	Register 'AD_CV'
25	6.5.2.	Register 'MODE_REG'
26	6.5.3.	FIR-Parameter
28	6.5.4.	DCO-Registers
28	6.6.	Demodulator Read Registers: Functions and Values
29	6.6.1.	Autodetect of Terrestrial TV-Audio Standards
30	6.6.2.	C_AD_BITS (MSP 3417D only)
30	6.6.3.	ADD_BITS [10:3] (MSP 3417D only)
30	6.6.4.	CIB_BITS (MSP 3417D only)
30	6.6.5.	ERROR_RATE (MSP 3417D only)
31	6.6.6.	CONC_CT (for compatibility with MSP 3410B)
31	6.6.7.	FAWCT_IST (for compatibility with MSP 3410B)
31	6.6.8.	PLL_CAPS
31	6.6.9.	AGC_GAIN
31	6.7.	Sequences to Transmit Parameters and to Start Processing
33	6.8.	Software Proposals for Multistandard TV-Sets
33	6.8.1.	Multistandard Including System B/G or I (NICAM/FM-Mono only) or SECAM L (NICAM/AM-Mono only)
33	6.8.2.	Multistandard Including System B/G with NICAM/FM-Mono and German DUAL FM
33	6.8.3.	Satellite Mode
33	6.8.4.	Automatic Search Function for FM-Carrier Detection
35	7.	Programming the DSP Section (Audio Baseband Processing)
35	7.1.	DSP Write Registers: Table and Addresses
36	7.2.	DSP Read Registers: Table and Addresses
36	7.3.	DSP Write Registers: Functions and Values
36	7.3.1.	Volume Loudspeaker Channel
37	7.3.2.	Volume SCART1
37	7.3.3.	Channel Source Modes
37	7.3.4.	Channel Matrix Modes
38	7.3.5.	SCART Prescale
38	7.3.6.	FM/AM Prescale
39	7.3.7.	FM Matrix Modes
39	7.3.8.	FM Fixed Deemphasis
39	7.3.9.	FM Adaptive Deemphasis
39	7.3.10.	NICAM Prescale (MSP 3417D only)
39	7.3.11.	NICAM Deemphasis (MSP 3417D only)
39	7.3.12.	ACB Register
40	7.3.13.	Beeper
40	7.3.14.	Identification Mode

# Contents, continued

Page	Section	Title
40	7.3.15.	FM DC Notch
40	7.3.16.	Automatic Volume Correction (AVC)
41	7.4.	Exclusions for the Audio Baseband Features
41	7.5.	Phase Relationship of Inputs/Outputs
41	7.6.	DSP Read Registers: Functions and Values
41	7.6.1.	Stereo Detection Register
42	7.6.2.	Quasi-Peak Detector
42	7.6.3.	DC Level Register
42	7.6.4.	MSP Hardware Version Code
42	7.6.5.	MSP Major Revision Code
42	7.6.6.	MSP Product Code
42	7.6.7.	MSP ROM Version Code
43	8.	Specifications
43	8.1.	Outline Dimensions
44	8.2.	Pin Connections and Short Descriptions
44 46	8.2. 8.3.	Pin Connections and Short Descriptions Pin Configurations
	o	•
46	8.3.	Pin Configurations
46 47	8.3. 8.4.	Pin Configurations Pin Circuits
46 47 48	8.3. 8.4. 8.5.	Pin Configurations Pin Circuits Electrical Characteristics
46 47 48 48	8.3. 8.4. 8.5. 8.5.1.	Pin Configurations Pin Circuits Electrical Characteristics Absolute Maximum Ratings
46 47 48 48 49	8.3. 8.4. 8.5. 8.5.1. 8.5.2.	Pin Configurations Pin Circuits Electrical Characteristics Absolute Maximum Ratings Recommended Operating Conditions
46 47 48 48 49 52	8.3. 8.4. 8.5. 8.5.1. 8.5.2. 8.5.3.	Pin Configurations Pin Circuits Electrical Characteristics Absolute Maximum Ratings Recommended Operating Conditions Characteristics

#### **Multistandard Sound Processor**

Release Notes: The hardware description in this document is valid for the MSP 34x7D version B2 and following versions. Revision bars indicate significant changes to the previous edition.

#### 1. Introduction

The MSP 34x7D is designed as a single-chip Multistandard Sound Processor for applications in analog and digital TV sets, video recorders, and PC-cards. As derivate versions of the MSP 3400D and MSP 3410D, the MSP 34x7D combines all demodulator features of the MSP 34x0D with less I/O and reduced audio baseband processing.

The IC is produced in submicron CMOS technology, combined with high-performance digital signal processing. The MSP 34x7D is available in a PSDIP52 and in a PMQFP44 package.

**Note:** The MSP 34x7D version has reduced control registers and less functional pins. The remaining registers are software compatible to the MSP 34x0D. The pinning is compatible to the MSP 34x0D.

# 1.1. Features of MSP 3407D and MSP 3417D

- Analog Sound IF input
- No external filters required
- Stereo baseband input via integrated A/D converters
- Two pairs of D/A converters
- Two carrier FM
- AVC: Automatic Volume Correction
- Volume processing

- Demodulator short programming
- Autodetection for terrestrial TV-sound standards
- Improved carrier mute algorithm (as in MSP 34x0D)
- Digital control output pins D\_CTR\_OUT0/1
- Reduction of necessary controlling
- Less external components

# 1.2. Specific MSP 3417D Features

- All NICAM standards
- Precise bit-error rate indication
- Automatic switching from NICAM to FM/AM or vice versa
- Improved NICAM synchronization algorithm

# 1.3. Unsupported MSP 34x0D Functions

- Equalizer
- Bass, treble, loudness, spatial effects processing

# 1.4. MSP 34x0D Inputs and Outputs not included in the MSP 34x7D

- 2nd IF input
- 2nd, 3rd, and 4th SCART input
- 2nd SCART output
- 2nd SCART DA
- Headphone output
- Subwoofer output
- I2S Interface
- ADR interface




Fig. 1-1: Main I/O Signals MSP 34x7D

#### 2. Basic Features of the MSP 34x7D

#### 2.1. Demodulator and NICAM Decoder Section

The MSP 3417D is designed to simultaneously perform digital demodulation and decoding of NICAM-coded TV stereo sound, as well as demodulation of FM or AMmono TV sound. Alternatively, two carrier FM systems according to the German terrestrial specs can be processed with the MSP 3417D and MSP 3407D.

The MSP 34x7D facilitates profitable multistandard capability, offering the following advantages:

- Automatic Gain Control (AGC) for analog sound-IF input with the range: 0.10 – 3 Vpp
- integrated A/D converter for sound-IF input
- all demodulation and filtering is performed on chip and is individually programmable
- easy realization of all digital NICAM standards (B/G, I, L, and D/K, not for MSP 3407D)
- FM-demodulation of all terrestrial standards (including identification decoding)
- no external filter hardware is required
- only one crystal clock (18.432 MHz) is necessary
- high deviation FM-mono mode (max. deviation: approx. ±360 kHz)

### 2.2. DSP-Section (Audio Baseband Processing)

- flexible selection of audio sources to be processed
- performance of terrestrial deemphasis systems (FM, NICAM)
- digitally performed FM-identification decoding and dematrixing
- simple controlling of volume

#### 2.3. Analog Section

– analog audio baseband input (= SCART stereo input)
 input level: ≤2 V RMS,

input level:  $\leq$ 2 V RMinput impedance:  $\geq$ 25 k $\Omega$ 

- selectable analog mono input (i.e. AM sound): input level:  $\leq$ 2 V RMS, input impedance:  $\geq$ 15 k $\Omega$ 

– one high-quality A/D converter pairS/N-Ratio: ≥85 dB

 20 Hz to 20 kHz bandwidth for SCART-to-SCARTcopy facilities

 loudspeaker: one pair of four-fold oversampled D/Aconverters

 $\begin{array}{lll} \text{output level per channel:} & \text{max. } 1.4 \text{ VRMS} \\ \text{output resistance:} & \text{max. } 5 \text{ k}\Omega \\ \text{S/N-ratio at max. volume:} & \geq 85 \text{ dB} \\ \text{max. noise voltage in mute mode:} & \leq 10 \text{ }\mu\text{V} \\ \text{Bandwidth:} & 20 \text{ Hz } ...16 \text{ kHz} \\ \end{array}$ 

SCART-output: one pair of four-fold oversampled D/A

converters

output level per channel: max. 2 V RMS, output resistance: max. 0.5 k $\Omega$ ,

S/N-Ratio: (20 Hz...16 kHz) ≥85 dB

# 3. Application Fields of the MSP 34x7D

In the following sections, a brief overview about the two main TV sound standards, NICAM 728 and German FM-Stereo, demonstrates the complex requirements of a multistandard audio IC.

### 3.1. NICAM plus FM/AM-Mono

According to the British, Scandinavian, Spanish, and French TV-standards, high-quality stereo sound is transmitted digitally. The systems allow two high-quality digital sound channels to be added to the already existing FM/AM-channel. The sound coding follows the format of the so-called Near Instantaneous Companding System (NICAM 728). Transmission is performed using Differential Quadrature Phase Shift Keying (DQPSK). Table 3–2 gives some specifications of the sound coding (NICAM); Table 3–3 offers an overview of the modulation parameters.

In the case of NICAM/FM (AM) mode, there are three different audio channels available: NICAM A, NICAM B, and FM/AM-mono. NICAM A and B may belong either to a stereo or to a dual language transmission. Information about operation mode and about the quality of the NICAM signal can be read by the CCU via the control bus. In the case of low quality (high bit error rate), the CCU may decide to switch to the analog FM/AM-mono sound. Alternatively, an automatic NICAM-FM/AM switching may be applied.

# 3.2. German 2-Carrier System (DUAL FM System)

Since September 1981, stereo and dual sound programs have been transmitted in Germany using the 2-carrier system. Sound transmission consists of the already existing first sound carrier and a second sound carrier additionally containing an identification signal. More details of this standard are given in Tables 3–1 and 3–4. For D/K and M-Korea, very similar systems are used.

Table 3-1: TV standards

TV-System	Position of Sound Carrier [MHz]	Sound Modulation	Color System	Country
B/G	5.5/5.7421875	FM-Stereo	PAL	Germany
B/G	5.5/5.85	FM-Mono/NICAM	PAL	Scandinavia,Spain
L	6.5/5.85	AM-Mono/NICAM	SECAM-L	France
I	6.0/6.552	FM-Mono/NICAM	PAL	UK
D/K	6.5/6.2578125 D/K1 6.5/6.7421875 D/K2 6.5/5.85 D/K-NICAM	FM-Stereo FM-Mono/NICAM	SECAM-East	USSR Hungary
M M-Korea	4.5 4.5/4.724212	FM-Mono FM-Stereo	NTSC	USA Korea
Satellite Satellite	6.5 7.02/7.2	FM-Mono FM-Stereo	PAL PAL	Europe (ASTRA) Europe (ASTRA)

Table 3–2: Summary of NICAM 728 sound coding characteristics


Characteristics	Values
Audio sampling frequency	32 kHz
Number of channels	2
Initial resolution	14 bit/sample
Companding characteristics	near instantaneous, with compression to 10 bits/sample in 32-samples (1 ms) blocks
Coding for compressed samples	2's complement
Preemphasis	CCITT Recommendation J.17 (6.5 dB attenuation at 800 Hz)
Audio overload level	+12 dBm measured at the unity gain frequency of the preemphasis network (2 kHz)

Table 3–3: Summary of NICAM 728 sound modulation parameters

Specification	I	B/G	L		D/K		
Carrier frequency of digital sound	6.552 MHz	5.85 MHz	5.85 MHz		5.85 MHz		
Transmission rate			728 kBit/s				
Type of modulation	Diffe	rentially encoded	quadrature p	hase shift ke	ying (DQPSk	()	
Spectrum shaping		by means of Roll-off filters					
Roll-off factor	1.0	1.0 0.4 0.4				0.4	
Carrier frequency of	6.0 MHz			AM mono	6.5 MHz FM mono		
analog sound component	FM mono FM mono		terrestrial cable		1 W MONO		
Power ratio between vision carrier and analog sound carrier	10 dB	13 dB	10 dB	16 dB	13 dB		
Power ratio between	10 dB	7 dB	17 dB	11 dB	Hungary	Poland	
analog and modulated digital sound carrier					12 dB	7 dB	

Table 3-4: Key parameters for B/G, D/K, and M 2-carrier sound system

Sound Carriers		Carrier FM1		Carrier FM2			
	B/G	D/K	М	B/G	D/K	М	
Vision/sound power difference		13 dB			20 dB		
Sound bandwidth			40 Hz to	15 kHz			
Pre-emphasis	50	μs	75 μs	50	μs	75 μs	
Frequency deviation	±50	kHz	±25 kHz	±50	kHz	±25 kHz	
Sound Signal Components							
Mono transmission		mono		mono			
Stereo transmission	(L+I	R)/2	(L+R)/2	R		(L-R)/2	
Dual sound transmission	language A			language B			
Identification of Transmission Mo	de on Carri	er FM2					
Pilot carrier frequency in kHz				54.6	8875	55.0699	
Type of modulation					AM		
Modulation depth					50%		
Modulation frequency				stereo: 1	nmodulated 17.5 Hz 74.1 Hz	149.9 Hz 276.0 Hz	



#### 4. Architecture of the MSP 34x7D

Fig. 4–1 shows a simplified block diagram of the IC. Its architecture is split into three main functional blocks:

- 1. demodulator and NICAM decoder section
- 2. DSP (digital signal processing) section performing audio baseband processing
- 3. analog section containing two A/D-converters, four D/A-converters, and SCART-switching facilities.

#### 4.1. Demodulator and NICAM Decoder Section

### 4.1.1. Analog Sound IF - Input Section

The input pins ANA IN1+ and ANA IN- offer the possibility to connect sound IF (SIF) sources to the MSP 34x7D. The analog-to-digital conversion of the preselected sound IF signal is done by an A/D-converter, whose output can be used to control an analog automatic gain circuit (AGC), providing an optimal level for a wide range of input levels. It is possible to switch between automatic gain control and a fixed (setable) input gain. In the optimal case, the input range of the A/D converter is completely covered by the sound IF source. Some combinations of SAW filters and sound IF mixer ICs, however, show large picture components on their outputs. In this case, filtering is recommended. It was found, that the high pass filter formed by the coupling capacitor at pin ANA IN1+ (as shown in the application diagram) is sufficient in most cases.




Fig. 4-1: Architecture of the MSP 34x7D

#### 4.1.2. Quadrature Mixers

The digital input coming from the integrated A/D converter may contain audio information at a frequency range of theoretically 0 to 9 MHz corresponding to the selected standards. By means of two programmable quadrature mixers, two different audio sources; for example, NICAM and FM-mono, may be shifted into baseband position. In the following, the two main channels are provided to process either:

- NICAM (MSP-Ch1) and FM/AM mono (MSP-Ch2) simultaneously or, alternatively,
- FM2 (MSP-Ch1) and FM1 (MSP-Ch2).

NICAM is not possible with MSP 3407D.

Two programmable registers, to be divided up into Low and High Part, determine frequency of the oscillator, which corresponds to the frequency of the desired audio carrier. In section 6.2., format and values of the registers are listed.

# 4.1.3. Lowpass Filtering Block for Mixed Sound IF Signals

Data shaping and/or FM bandwidth limitation is performed by a linear phase Finite Impulse Response (FIR-filter). Just like the oscillators' frequency, the filter coefficients are programmable and are written into the IC by the CCU via the control bus. Thus, for example, different NICAM versions can easily be implemented. Two not necessarily different sets of coefficients are required, one for MSP-Ch1 (NICAM or FM2) and one for MSP-Ch2 (FM1 = FM-mono). In section 6.5.3., several coefficient sets are proposed.




Fig. 4-2: Demodulator architecture of MSP 34x7D

#### 4.1.4. Phase and AM Discrimination

The filtered sound IF signals are demodulated by means of the phase and amplitude discriminator block. On the output, the phase and amplitude is available for further processing. AM signals are derived from the amplitude information, whereas the phase information serves for FM and NICAM (DQPSK) demodulation.

#### 4.1.5. Differentiators

FM demodulation is completed by differentiating the phase information output.

# 4.1.6. Lowpass Filter Block for Demodulated Signals

The demodulated FM and AM signals are further lowpass filtered and decimated to a final sampling frequency of 32 kHz. The usable bandwidth of the final baseband signals is about 15 kHz.

# 4.1.7. High Deviation FM Mode

By means of MODE\_REG [9], the maximum FM-deviation can be extended to approximately ±360 kHz. Since this mode can be applied only for the MSP sound IF channel 2, the corresponding matrices in the baseband processing must be set to sound A. Apart from this, the coefficient sets 380 kHz FIR2 or 500 kHz FIR2 must be chosen for the FIR2. In relation to the normal FM-mode, the audio level of the high-deviation mode is reduced by 6 dB. The FM-prescaler should be adjusted accordingly. In high deviation FM-mode, neither FM-stereo nor FM-identification nor NICAM processing is possible simultaneously.

# 4.1.8. FM-Carrier-Mute Function in the Dual Carrier FM Mode

To prevent noise effects or FM identification problems in the absence of one of the two FM carriers, the MSP 34x7D offers a carrier detection feature, which must be activated by means of AD\_CV[9]. If no FM carrier is available at the MSP channel 1, the corresponding channel FM2 is muted. If no FM carrier is available at the MSP channel 2, the corresponding channel FM1 is muted.

# 4.1.9. DQPSK-Decoder (MSP 3417D only)

In case of NICAM-mode, the phase samples are decoded according the DQPSK-coding scheme. The output of this block contains the original NICAM-bitstream.

# 4.1.10. NICAM-Decoder (MSP 3417D only)

Before any NICAM decoding can start, the MSP must lock to the NICAM frame structure by searching and synchronizing to the so-called Frame Alignment Words (FAW).

To reconstruct the original digital sound samples, the NI-CAM-bitstream has to be descrambled, deinterleaved, and rescaled. Also, bit error detection and correction (concealment) is performed in this NICAM specific block.

To facilitate the Central Control Unit CCU to switch the TV-set to the actual sound mode, control information on the NICAM mode and bit error rate are supplied by the the NICAM-Decoder. It can be read out via the I<sup>2</sup>C-Bus.


An automatic switching facility (AUTO\_FM) between NI-CAM and FM/AM reduces the amount of CCU-instructions in case of bad NICAM reception.

### 4.2. Analog Section

## 4.2.1. SCART Switching Facilities

The analog input and output sections include full matrix switching facilities, which are shown in Fig. 4–3.

The switches are controlled by the ACB bits defined in the audio processing interface (see section 7. Programming the DSP Section).



**Fig. 4–3:** SCART-Switching Facilities (see 7.3.12.) Switch positions show the default configuration after Power On Reset. Note: SCART\_OUT is undefined after RESET!

### 4.2.2. Standby Mode

If the MSP 34x7D is switched off by first pulling STAND-BYQ low, and then disconnecting the 5 V, but keeping the 8 V power supply ('**Standby'-mode**), the switches S1 and S2 (see Fig. 4–3) maintain their position and function.

In case of power-on start or starting from standby, the IC switches automatically to the default configuration, shown in Fig. 4–3. This action takes place after the first I<sup>2</sup>C transmission into the DSP part. By transmitting the ACB register first, the individual default setting mode of the TV set can be defined.

### 4.3. DSP-Section (Audio Baseband Processing)

All audio baseband functions are performed by digital signal processing (DSP). The DSP functions are grouped into three processing parts: input preprocessing, channel source selection, and channel postprocessing (see Fig. 4–5 and section 7.).

The input preprocessing is intended to prepare the various signals of all input sources in order to form a standardized signal at the input to the channel selector. The signals can be adjusted in volume, are processed with the appropriate deemphasis, and are dematrixed if necessary.

Having prepared the signals that way, the channel selector makes it possible to distribute all possible source signals to the desired output channels.

All input and output signals can be processed simultaneously with the exception that FM2 cannot be processed at the same time as NICAM. FM-identification and adaptive deemphasis are also not possible simultaneously. If adaptive deemphasis is active, the ID-level in Stereo Detection Register is not valid.

### 4.3.1. Dual Carrier FM Stereo/Bilingual Detection

For the terrestrial dual FM carrier systems, audio information can be transmitted in three modes: Mono, stereo, or bilingual. To obtain information about the current audio operation mode, the MSP 34x7D detects the so-called identification signal. Information is supplied via the Stereo Detection Register to an external CCU.




Fig. 4-4: Stereo/bilingual detection




Fig. 4–5: Audio Baseband Processing (DSP-Firmware)

Table 4–1: Some examples for recommended channel assignments for demodulator and audio processing part

Mode	MSP Sound IF- Channel 1	MSP Sound IF- Channel 2	FM- Matrix	Channel- Select	Channel Matrix
B/G-Stereo	FM2 (5.74 MHz): R	FM1 (5.5 MHz): (L+R)/2	B/G Stereo	Speakers: FM	Stereo
B/G-Bilingual	FM2 (5.74 MHz): Sound B	FM1 (5.5 MHz): Sound A	No Matrix	Speakers: FM	Speakers: Sound A H. Phone: Sound B
NICAM-I-ST/ FM-mono	NICAM (6.552 MHz)	FM (6.0 MHz): mono	No Matrix	Speakers: NICAM	Speakers: Stereo H. Phone: Sound A
Sat-Mono	not used	FM (6.5 MHz): mono	No Matrix	Speakers: FM	Sound A
Sat-Stereo	7.2 MHz: R	7.02 MHz: L	No Matrix	Speakers: FM	Stereo
Sat-Bilingual	7.38 MHz: Sound C	7.02 MHz: Sound A	No Matrix	Speakers: FM	Speakers: Sound A H. Phone: Sound B=C
Sat-High Dev. Mode	don't care	6.552 MHz	No Matrix	Speakers: FM	Speakers: Sound A H. Phone: Sound A

# 4.4. Audio PLL and Crystal Specifications

The MSP 34x7D requires a 18.432 MHz (12 pF, parallel) crystal. The clock supply of the whole system depends on the MSP 34x7D operation mode:

# 1. FM-Stereo, FM-Mono:

The system clock runs free on the crystal's 18.432 MHz.

# 2. NICAM:

An integrated clock PLL uses the 364 kHz baud-rate, accomplished in the NICAM demodulator block, to lock the system clock to the bit rate, respectively, 32 kHz sampling rate of the NICAM transmitter. As a result, the whole audio system is supplied with a controlled 18.432 MHz clock.

# Remark on using the crystal:

External capacitors at each crystal pin to ground are required. See General Crystal Recommendations on page 50.

# 4.5. Digital Control Output Pins

The static level of two output pins of the MSP 34x7D (D\_CTR\_OUT0/1) is switchable between HIGH and LOW by means of the  $I^2$ C-bus. This enables the controlling of external hardware controlled switches or other devices via  $I^2$ C-bus (see section 7.3.12.)

#### 5. I<sup>2</sup>C Bus Interface: Device and Subaddresses

As a slave receiver, the MSP 34x7D can be controlled via  $I^2C$  bus. Access to internal memory locations is achieved by subaddressing. The demodulator and the DSP processor parts have two separate subaddressing register banks.

In order to allow for more MSP 34x7D ICs to be connected to the control bus, an ADR\_SEL pin has been implemented. With ADR\_SEL pulled to high, low, or left open, the MSP 34x7D responds to changed device addresses. Thus, three identical devices can be selected.

By means of the RESET bit in the CONTROL register, all devices with the same device address are reset.

The IC is selected by asserting a special device address in the address part of an I<sup>2</sup>C transmission. A device address pair is defined as a write address (80, 84, or 88<sub>hex</sub>) and a read address (81, 85, or 89<sub>hex</sub>) (see Table 5–1).

Writing is done by sending the device write address, followed by the subaddress byte, two address bytes, and two data bytes. Reading is done by sending the device write address, followed by the subaddress byte and two address bytes. Without sending a stop condition, reading of the addressed data is completed by sending the device read address (81, 85, or 89<sub>hex</sub>) and reading two bytes of data (see Fig. 5–1: "I<sup>2</sup>C Bus Protocol" and Section 5.2. "Proposal for MSP 34x7D I<sup>2</sup>C Telegrams").

Due to the internal architecture of the MSP 34x7D the IC cannot react immediately to an I<sup>2</sup>C request. The typical response time is about 0.3 ms for the DSP processor part and 1 ms for the demodulator part if NICAM processing is active. If the receiver (MSP) can't receive another complete byte of data until it has performed some other function; for example, servicing an internal interrupt, it can hold the clock line I<sup>2</sup>C\_CL LOW to force the transmitter into a wait state. The positions within a transmission where this may happen are indicated by 'Wait' in section 5.1. The maximum Wait-period of the MSP during normal operation mode is less than 1 ms.

I I<sup>2</sup>C-Bus error caused by MSP hardware problems: In case of any internal error, the MSPs wait-period is extended to 1.8 ms. Afterwards, the MSP does not acknowledge (NAK) the device address. The data line will be left HIGH by the MSP and the clock line will be released. The master can then generate a STOP condition to abort the transfer.

By means of NAK, the master is able to recognize the error state and to reset the IC via I<sup>2</sup>C-Bus. While transmitting the reset protocol (see Section 5.2.4. on page 17) to 'CONTROL', the master must ignore the not acknowledge bits (NAK) of the MSP.

A general timing diagram of the  $I^2C$  Bus is shown in Fig. 5–2 on page 17.

Table 5-1: I<sup>2</sup>C Bus Device Addresses

ADR_SEL	Low		Hig	gh	Left Open		
Mode	Write	Read	Write	Read	Write	Read	
MSP device address	80 <sub>hex</sub>	81 <sub>hex</sub>	84 <sub>hex</sub>	85 <sub>hex</sub>	88 <sub>hex</sub>	89 <sub>hex</sub>	

Table 5-2: I<sup>2</sup>C Bus Subaddresses

Name	Binary Value	Hex Value	Mode	Function
CONTROL	0000 0000	00	Write	software reset
TEST	0000 0001	01	Write	only for internal use
WR_DEM	0001 0000	10	Write	write address demodulator
RD_DEM	0001 0001	11	Write	read address demodulator
WR_DSP	0001 0010	12	Write	write address DSP
RD_DSP	0001 0011	13	Write	read address DSP

Table 5-3: Control Register (Subaddress: 00<sub>hex</sub>)

Name	Subaddress	MSB	14	131	LSB
CONTROL	00 <sub>hex</sub>	1 : RESET 0 : normal	0	0	0

# 5.1. Protocol Description

# Write to DSP or Demodulator

S	write device	Wait	ACK	sub-addr	ACK	addr-byte high	ACK	addr-byte low	ACK	data-byte high	ACK	data-byte low	ACK	Р
	address													

### Read from DSP or Demodulator

s	write device address	Wait	ACK	sub-addr	ACK	addr-byte high	ACK	addr-byte low	ACK	S	read device address	Wait	ACK	data-byte high	AC	data-by	te NA	K	Р
- 1	audiess										audiess				1	. "	1	/"	

# Write to Control or Test Registers

S	write device	Wait	ACK	sub-addr	ACK	data-byte high	ACK	data-byte low	ACK	Р
	address									

**Note:**  $S = I^2C$ -Bus Start Condition from master

 $P = I^2C$ -Bus Stop Condition from master

 $ACK = Acknowledge-Bit: LOW on I^2C_DA from slave (=MSP, gray)$ 

or master (=CCU, hatched)

NAK = Not Acknowledge-Bit: HIGH on I<sup>2</sup>C\_DA from master (= CCU, hatched) to indicate 'End of Read'

or from MSP indicating internal error state

Wait =  $I^2$ C-Clock line held low by the slave (=MSP) while interrupt is serviced (<1.8 ms)




Fig. 5–1: I<sup>2</sup>C bus protocol (MSI

(MSB first; data must be stable while clock is high)




Fig. 5–2: I<sup>2</sup>C bus timing diagram

# 5.2. Proposal for MSP 34x7D I<sup>2</sup>C Telegrams

# **5.2.1. Symbols**

daw	write device address
dar	read device address
<	Start Condition
>	Stop Condition
aa	Address Byte
dd	Data Byte

# 5.2.2. Write Telegrams

<daw 00<="" th=""><th>d0</th><th>00&gt;</th><th></th><th>write to CONTROL register</th></daw>	d0	00>		write to CONTROL register
<daw 10<="" td=""><td>aa</td><td>aa dd</td><td>dd&gt;</td><td>write data into demodulator</td></daw>	aa	aa dd	dd>	write data into demodulator
<daw 12<="" td=""><td>aa</td><td>aa dd</td><td>dd&gt;</td><td>write data into DSP</td></daw>	aa	aa dd	dd>	write data into DSP

# 5.2.3. Read Telegrams


<daw< th=""><th>11</th><th>aa</th><th>aa</th><th><dar< th=""><th>dd</th><th>dd&gt;</th><th>read data from demodulator</th></dar<></th></daw<>	11	aa	aa	<dar< th=""><th>dd</th><th>dd&gt;</th><th>read data from demodulator</th></dar<>	dd	dd>	read data from demodulator
<daw< td=""><td>13</td><td>aa</td><td>aa</td><td><dar< td=""><td>dd</td><td>dd&gt;</td><td>read data from DSP</td></dar<></td></daw<>	13	aa	aa	<dar< td=""><td>dd</td><td>dd&gt;</td><td>read data from DSP</td></dar<>	dd	dd>	read data from DSP

# 5.2.4. Examples

<80	00	80	00>		RESET MSP statically
<80	00	00	00>		clear RESET
<80	12	00	08 01	20>	set loudspeaker channel source
					to NICAM and Matrix to STEREO

# 5.3. Start Up Sequence: Power Up and I<sup>2</sup>C-Controlling

After power on or RESET (see Fig. 5–3), the IC is in an inactive state. The CCU has to transmit the required coefficient set for a given operation via the I<sup>2</sup>C bus. Initialization should start with the demodulator part. If required for any reason, the audio processing part can be loaded before the demodulator part.



Power-up reset: threshold and timing Note:  $0.7 \times DVSUP$  means 3.5 Volt with DVSUP = 5.0 Volt

Fig. 5-3: Power-up sequence

**Note:** The reset should not reach high level before the oscillator has started. This requires a reset delay of >2 ms

### 6. Programming the Demodulator Section

## 6.1. Autodetection, Short-Programming, and General Programming of the Demodulator Part

The Demodulator Part of the MSP 34x7D can be programmed in **two different modes**:

**1. Demodulator Short-Programming** provides a comfortable way to set up the demodulator for many terrestrial TV sound standards with one single I<sup>2</sup>C bus transmission. The coding is listed in section 6.4.1.. If a parameter doesn't coincide with the individual programming concept, it simply can be overwritten by using the General Programming mode. Some bits of the registers AD\_CV (see section 6.5.1.) and MODE\_REG (see section 6.5.2.) are not affected by the short-programming. They must be transmitted once if their reset status does not fit. The Demodulator Short-Programming is not compatible to MSP 3410B and MSP 3400C.

Autodetection for terrestrial TV-Standards is part of the Demodulator Short-Programming. This feature enables the detection and set-up of the actual TV sound standard within 0.5 s. Since the detected standard is readable by the control processor, the autodetection feature is mainly recommended for the primary set-up of a TV-set: After having once determined the corresponding TV-channels, their sound standards can be stored and programmed later on by the Demodulator Short-Programming (see Sections 6.4.1. and 6.6.1.).

2. General Programming ensures the software compatibility to other MSPs. It offers a very flexible way to apply all of the MSP 34x7D demodulator facilities. All registers except 0020<sub>hex</sub> (Demodulator Short-Programming) have to be written with values corresponding to the individual requirements. For satellite applications, with their many variations, this mode must be selected.

All transmissions on the control bus are 16 bits wide. However, data for the demodulator part have only 8 or 12 significant bits. These data have to be inserted LSB-bound and filled with zero bits into the 16-bit transmission word. Table 4–1 explains how to assign FM carriers to the MSP-Sound IF channels and the corresponding matrix modes in the audio processing part.

# 6.2. Demodulator Write Registers: Table and Addresses

 $\textbf{Table 6-1:} \ \ \textbf{Demodulator Write Registers; Subaddress: 10}_{hex}; \ \ \textbf{these registers are not readable!}$ 

Demodulator Write Registers	Address (hex)	Function				
Demodulator Short- Programming	0020	Write into this register to apply Demodulator Short Programming (see section 6.4.1.). If the internal setting coincidences with the individual requirements no more of the remaining Demodulator Write Registers have to be transferred.				
AUTO_FM/AM 0021 Only for NICAM (MSP 3417D): Automatic switching betw FM/AM in case of bad NICAM reception (see section 6.4						
Write Registers necessary for <b>General Programming Mode</b> only						
AD_CV 00BB		input selection, configuration of AGC, Mute Function and selection of A/D-converter, FM-Carrier-Mute on/off				
MODE_REG	0083	mode register				
FIR1 FIR2	0001 0005	filter coefficients channel 1 (6 $\cdot$ 8 bit) filter coefficients channel 2 (6 $\cdot$ 8 bit), + 3 $\cdot$ 8 bit offset (total 72 bit)				
DCO1_LO DCO1_HI	0093 009B	increment channel 1 Low Part increment channel 1 High Part				
DCO2_LO DCO2_HI	00A3 00AB	increment channel 2 Low Part increment channel 2 High Part				
PLL_CAPS 001F		switchable PLL capacitors to tune open-loop frequency; to use only if NICAM of MODE_REG = 0 normally not of interest for the customer				

# 6.3. Demodulator Read Registers: Table and Addresses

**Table 6–2:** Demodulator Read Registers; Subaddress: 11<sub>hex</sub>; these registers are not writeable!

Demodulator Read Registers	Address (hex)	Function		
Result of Autodetection	007E	see Table 6–13		
C_AD_BITS	0023	NICAM-Sync bit, NICAM-C-Bits, and three LSBs of additional data bits		
ADD_BITS	0038	NICAM: bit [103] of additional data bits		
CIB_BITS 003E		NICAM: CIB1 and CIB2 control bits		
ERROR_RATE	0057	NICAM error rate, updated with 182 ms		
CONC_CT	0058	only to be used in MSPB compatibility mode		
FAWCT_IST	0025	only to be used in MSPB compatibility mode		
PLL_CAPS	021F	Not for customer use.		
AGC_GAIN	021E	Not for customer use.		

Note: All NICAM relevant registers are "0" for MSP 3407D.

# 6.4. Demodulator Write Registers for Short-Programming: Functions and Values

In the following, the functions of some registers are explained and their (default) values are defined:

# 6.4.1. Demodulator Short-Programming

Table 6-3: MSP 34x7D Demodulator Short-Programming

		Demodula	tor Short-P	rogrammin	g 0020 <sub>hex</sub>						
	Autodetection for terrestrial TV-Standards										
Description	Description Code (hex) Internal Action										
Autodetection	Autodetection 0001 Detects and sets one of the standards listed below, if available. Results are to be read out of the demodulator read register "Result of Autodetection" (Section 6.6.1.)										
Standard Selection											
TV-Sound Stand	ard			Inter	nal Setting						
Description	Code (hex)	AD_CV <sup>2</sup> ) (see Table 6–5)	MODE_ REG <sup>2</sup> ) (see Table 6–8)	DCO1 (MHz)	DCO2 (MHz)	FIR1/2 Coefficients	Identifica- tion Mode				
M Dual-FM	0002	AD_CV-FM	M1	4.72421	4.5		Reset, then Standard M				
B/G Dual-FM	0003	AD_CV-FM	M1	5.74218	5.5	see Table 6–11: Terrestrial TV-	Reset, then Standard B/G				
D/K1 Dual-FM	0004	AD_CV-FM	M1	6.25781	6.5	Standards					
D/K2 Dual-FM	0005	AD_CV-FM	M1	6.74218	6.5		6/9				
	0006/ 0007	reserved for fu	uture Dual F	M Standards	3		AUTO_ FM/AM				
NI	CAM-Mod	des for MSP 34	17D only; N	ISP 3407D r	esponds w	th FM/AM Mono					
B/G-NICAM-FM	0008	AD_CV-FM	M2	5.85	5.5						
L-NICAM-AM	0009	AD_CV-AM	M3	5.85	6.5	see Table 6–11: Terrestrial TV-	1)				
I-NICAM-FM	000A	AD_CV-FM	M2	6.552	6.0	Standards	,				
D/K-NICAM-FM	000B	AD_CV-FM	M2	5.85	6.5						
	>000B reserved for future NICAM Standards										

 $<sup>^{1)}</sup>$  corresponds to the actual setting of AUTO\_FM (Address =  $0021_{hex}$ )

**Note:** All parameters in the DSP section (Audio Baseband Processing), except the identification mode register, are not affected by the Demodulator Short-Programming . They still have to be defined by the control processor.

<sup>&</sup>lt;sup>2)</sup> Bits of AD\_CV or MODE\_REG, which are not affected by the short-programming, must be transmitted separately if their reset status does not fit.

# 6.4.2. AUTO\_FM/AM: Automatic Switching between NICAM and FM/AM-Mono (MSP 3417D only)

In case of bad NICAM transmission or loss of the NICAM-carrier, the MSP offers a comfortable mode to switch back to the FM/AM-mono signal. If automatic switching is active, the MSP internally evaluates the ERROR\_RATE. All output channels which are assigned to the NICAM-source are switched back to the FM/AM-mono source without any further CCU instruction, if the NICAM-carrier fails or the ERROR\_RATE exceeds the definable threshold.

Note, that the channel matrix of the corresponding output-channels must be set according to the NICAM-mode and need not be changed in the FM/AM-fall-back case. An appropriate hysteresis algorithm avoids oscillating effects. Bit 11 of the Register C\_AD\_BITS (Addr:  $0023_{hex}$ ) informs about the actual NICAM-FM/AM-Status (see section 6.6.2.).

There are two possibilities to define the threshold deciding for NICAM or FM/AM-mono (see Table 6–4):

- default value of the MSP 3417D (internal threshold = 700<sub>dec</sub>, i.e. switch to FM/AM if ERROR\_RATE > 700)
- 2. definable by the customer (recommendable range: threshold = 50...2000, i. e. Bits [10...1] = 25...1000).

#### Note:

The auto\_fm feature is only active if the NICAM-bit of MODE\_REG is set.

Table 6-4: Coding of automatic NICAM-FM/AM switching; reset status: mode 0

Mode	Auto_fm [110] Addr. = 0021 <sub>hex</sub>	Selected Sound at the NICAM Channel Select	Threshold	Comment
0. default	Bit [0] = 0 Bits [111] = 0	always NICAM	none	Compatible to MSP 3410B, i.e. automatic switching is disabled
1.	Bit [0] = 1 Bit [111] = 0	NICAM or FM/AM, depending on ERROR_RATE	700 <sub>dec</sub>	automatic switching with internal threshold
2.	Bit [0] = 1 Bit [101] = 251000 int = threshold/2 Bit [11] = 0	NICAM or FM/AM, depending on ERROR_RATE	set by customer	automatic switching with external threshold
3.	Bit [11] = [0] = 1 Bit [101] = 0	always FM/AM	none	Forced FM-mono mode, i.e. automatic switching is disabled

# 6.5. Demodulator Write Registers for the General Programming Mode: Functions and Values

# 6.5.1. Register 'AD\_CV'

Table 6-5: AD\_CV Register; reset status: all bits are "0"

	AD_CV 00BB <sub>hex</sub>								
Bit	Meaning	Settings	AD_CV-FM	AD_CV-AM					
AD_CV [0]	not used	must be set to 0	0	0					
AD_CV [61]	Reference level in case of Automatic Gain Control = on (see Table 6–6). Constant gain factor when Automatic Gain Control = off (see Table 6–7).		101000	100011					
AD_CV [7]	Determination of Automatic Gain or Constant Gain	0 = constant gain 1 = automatic gain	1	1					
AD_CV [8]	not used	must be set to 0	not affected	not affected					
AD_CV [9]	MSP-Carrier-Mute Function	0 = off: no mute 1 = on: mute as described in section 4.1.8. on page 12	1	0					
AD_CV [1510]	not used	must be set to 0	0	0					

**Table 6–6:** Reference values for active AGC (AD\_CV[7] = 1)

Application	Input Signal Contains	AD_CV [6:1] Ref. Value	AD_CV [6:1] (decimal)	Range of Input Signal at pin ANA_IN1+
Terrestrial TV				
FM-Stereo	2 FM Carriers	101000	40	$0.10 - 3 V_{pp}^{1)}$
FM/NICAM	1 FM and 1 NICAM Carrier	101000	40	$0.10 - 3 V_{pp}^{1)}$
AM/NICAM	1 AM and 1 NICAM carrier	100011	35	0.10 – 1.4 V <sub>pp</sub>
				recommended: 0.10 – 0.8V <sub>pp</sub>
NICAM only	1 NICAM Carrier only	010100	20	0.05 – 1.0 V <sub>pp</sub>
SAT	1 or more FM Carriers	100011	35	0.10 – 3 V <sub>pp</sub> <sup>1)</sup>

<sup>&</sup>lt;sup>1)</sup> For signals above 1.4 Vpp, the minimum gain of 3 dB is switched, and overflow of the A/D converter may result. Due to the robustness of the internal processing, the IC works up to and even more than 3 Vpp, if norm conditions of FM/NICAM or FM1/FM2 ratio are supposed. In this overflow case, a loss of FM-S/N-ratio of about 10 dB may appear.

**Table 6–7:** AD\_CV parameters for constant input gain (AD\_CV[7]=0)

Step	AD_CV [61] Constant Gain	Gain	Input Level at pin ANA_IN1+
0	000000	3.00 dB	maximum input level: 3 V <sub>pp</sub> (FM) or 1 V <sub>pp</sub> (NICAM) <sup>1)</sup>
1	000001	3.85 dB	
2	000010	4.70 dB	
3	000011	5.55 dB	
4	000100	6.40 dB	
5	000101	7.25 dB	
6	000110	8.10 dB	
7	000111	8.95 dB	
8	001000	9.80 dB	
9	001001	10.65 dB	
10	001010	11.50 dB	
11	001011	12.35 dB	
12	001100	13.20 dB	
13	001101	14.05 dB	
14	001110	14.90 dB	
15	001111	15.75 dB	
16	010000	16.60 dB	
17	010001	17.45 dB	
18	010010	18.30 dB	
19	010011	19.15 dB	
20	010100	20.00 dB	maximum input level: 0.14 V <sub>pp</sub>

<sup>&</sup>lt;sup>1)</sup> For signals above 1.4 Vpp, the minimum gain of 3 dB is switched, and overflow of the A/D converter may result. Due to the robustness of the internal processing, the IC works up to and even more than 3 Vpp, if norm conditions of FM/NICAM or FM1/FM2 ratio are supposed. In this overflow case, a loss of FM-S/N-ratio of about 10 dB may appear.

# 6.5.2. Register 'MODE\_REG'

The register 'MODE\_REG' contains the control bits determining the operation mode of the MSP 34x7D; Table 6–8 explains all bit positions.

Table 6–8: Control word 'MODE\_REG'; reset status: all bits are "0"

		MODE_REG 0083 <sub>hex</sub>		Short	Set by -Progra	
Bit	Function	Comment	Definition	M1	M2	М3
[0]	not used		0 : strongly recommended	0	0	0
[1]	DCTR_TRI	Digital Control Outputs 0/1 active / tri-state	0 : active 1 : tri-state	Х	Х	Х
[2]	not used		1 : strongly recommended	Х	Х	Х
[3]	not used		0 : strongly recommended	Х	Х	Х
[4]	not used		0 : strongly recommended	Х	Х	Х
[5]	not used		1 : strongly recommended	Х	Х	Х
[6]	NICAM	Mode of MSP-Ch1 MSP 3407D: always FM	0 : FM 1 : Nicam	0	1	1
[7]	not used		0 : strongly recommended	0	0	0
[8]	FM AM	Mode of MSP-Ch2	0 : FM 1 : AM	0	0	1
[9]	HDEV	High Deviation Mode (channel matrix must be sound A)	0 : normal 1 : high deviation mode	0	0	0
[11:10]	not used		0 : strongly recommended	0	0	0
[12]	MSP-Ch1 Gain	see Table 6–11	0 : Gain = 6 dB 1 : Gain = 0 dB	0	0	0
[13]	FIR1-Filter Coeff. Set	see Table 6–11	0 : use FIR1 1 : use FIR2	1	0	0
[14]	not used		0 : strongly recommended	0	0	0
[15]	AM-Gain	Gain for AM Demodulation	0:0 dB (default. of MSPB) 1:12 dB (recommended)	1	1	1
					t affected	-

Table 6-9: Channel modes 'MODE\_REG [6, 8, 9]'

NICAM bit[6]	FM AM bit[8]	HDEV bit[9]	MSP-Ch1	MSP-Ch2
1	0	0	NICAM (undefined sound	FM1
1	1	0	for MSP 3407D)	AM
0	0	0	FM2	FM1
0	0	1	_	High Deviation FM

### 6.5.3. FIR-Parameter

The following data values (see Table 6–10) are to be transferred 8 bits at a time embedded LSB-bound in a 16-bit word.

The loading sequences must be obeyed. To change a coefficient set, the complete block FIR1 or FIR2 must be transmitted.

**Note:** For compatibility with MSP 3410B, IMREG1 and IMREG2 have to be transmitted. The value for IMREG1 and IMREG2 is 004. Due to the partitioning to 8-bit units, the values  $04_{\text{hex}}$ ,  $40_{\text{hex}}$ , and  $00_{\text{hex}}$  arise.

Table 6–10: Loading sequence for FIR-coefficients

FIR1	0001 <sub>hex</sub> (MSP-Ch1: N	VICAM/	/FM2)			
No.		Bits	Value			
NO.	Symbol Name	DITS	value			
1	NICAM/FM2_Coeff. (5)	8				
2	NICAM/FM2_Coeff. (4)	8				
3	NICAM/FM2_Coeff. (3)	8	ann Table 6 11			
4	NICAM/FM2_Coeff. (2)	8	see Table 6–11			
5	NICAM/FM2_Coeff. (1)	8				
6	NICAM/FM2_Coeff. (0)	8				
FIR2	0005 <sub>hex</sub> (MSP-Ch2: F	M1/AN	Л)			
No.	Symbol Name	Bits	Value			
1	IMREG1	8	04 <sub>hex</sub>			
2	IMREG1 / IMREG2	8	40 <sub>hex</sub>			
3	IMREG2	8	00 <sub>hex</sub>			
4	FM/AM_Coef (5)	8				
5	FM/AM_Coef (4)	8				
6	FM/AM_Coef (3)	8	ana Tabla 6 44			
7	FM/AM_Coef (2)	8	see Table 6-11			
8	FM/AM_Coef (1)	8				
9	FM/AM_Coef (0)	8				

Table 6-11: 8-bit FIR-coefficients (decimal) for MSP 34x7D; reset status: all coefficients are "0"

Coeffici	Coefficients for FIR1 0001 <sub>hex</sub> and FIR2 0005 <sub>hex</sub>													
	Terrestrial TV-Standards						FIR fil bandp	Satellite Iter corre pass with of B = 13	a band-			f <sub>c</sub> 1	requency	
	B/G-, D/K- I- L- B/G-,D/K-, NICAM-FM NICAM-AM M-Dual FM			130 kHz	180 kHz	200 kHz	280 kHz	380 kHz	500 kHz	Auto- search				
Coef(i)	FIR1	FIR2	FIR1	FIR2	FIR1	FIR2	FIR2	FIR2	FIR2	FIR2	FIR2	FIR2	FIR2	FIR2
0	-2	3	2	3	-2	-4	3	73	9	3	-8	-1	-1	-1
1	-8	18	4	18	-8	-12	18	53	18	18	-8	-9	-1	-1
2	-10	27	-6	27	-10	-9	27	64	28	27	4	-16	-8	-8
3	10	48	-4	48	10	23	48	119	47	48	36	5	2	2
4	50	66	40	66	50	79	66	101	55	66	78	65	59	59
5	86	72	94	72	86	126	72	127	64	72	107	123	126	126
MODE- REG[12]	(	)	(	)	(	)	0	1	1	1	1	1	1	0
MODE- REG[13]	(	)	(	)	(	)	1	1	1	1	1	1	1	0

For compatibility, except for the FIR2-AM and the Autosearch-sets, the FIR-filter programming as used for the MSP 3410B is also possible.

### 6.5.4. DCO-Registers

For a chosen TV standard, a corresponding set of 24-bit registers determining the mixing frequencies of the quadrature mixers, has to be written into the IC. In Table 6–12, some examples of DCO registers are listed. It is necessary to divide them up into low part and high part. The formula for the calculation of the registers for any chosen IF-Frequency is as follows:

 $INCR_{dec} = int(f/fs \cdot 2^{24})$ 

with: int = integer function f = IF-frequency in MHz

f<sub>S</sub> = sampling frequency (18.432 MHz)

Conversion of INCR into hex-format and separation of the 12-bit low and high parts lead to the required register values (DCO1\_HI or \_LO for MSP-Ch1, DCO2\_HI or LO for MSP-Ch2).

# 6.6. Demodulator Read Registers: Functions and Values

All registers except C\_AD\_BITs are 8 bit wide. They can be read out of the RAM of the MSP 34x7D.

All transmissions take place in 16-bit words. The valid 8 bit data are the 8 LSBs of the received data word.

To enable appropriate switching of the channel select matrix of the baseband processing part, the NICAM or FM-identification parameters must be read and evaluated by the CCU. The FM-identification registers are described in section 7.2. To handle the NICAM-sound and to observe the NICAM-quality, at least the registers C\_AD\_BITS and ERROR\_RATE must be read and evaluated by the CCU. Additional data bits and CIB bits, if supplied by the NICAM transmitter, can be obtained by reading the registers ADD\_BITS and CIB\_BITS.

Observing the presence and quality of NICAM can be delegated to the MSP 34x7D, if the automatic switching feature (AUTO FM, section 6.4.2.) is applied.

Table 6–12: DCO registers for the MSP 34x7D; reset status: DCO\_HI/LO = "0000"

	DCO1_LO 0093 <sub>hex</sub> , DCO1_HI 009B <sub>hex</sub> ; DCO2_LO 00A3 <sub>hex</sub> , DCO2_HI 00AB <sub>hex</sub>							
Freq. [MHz]	DCO_HI <sub>hex</sub>	DCO_LO <sub>hex</sub>	Freq. [MHz]	DCO_HI <sub>hex</sub>	DCO_LO <sub>hex</sub>			
4.5	03E8	000						
5.04 5.5 5.58 5.7421875	0460 04C6 04D8 04FC	0000 038E 0000 00AA	5.76 5.85 5.94	0500 0514 0528	0000 0000 0000			
6.0 6.2 6.5 6.552	0535 0561 05A4 05B0	0555 0C71 071C 0000	6.6 6.65 6.8	05BA 05C5 05E7	0AAA 0C71 01C7			
7.02	0618	0000	7.2	0640	0000			
7.38	0668	0000	7.56	0690	0000			

### 6.6.1. Autodetect of Terrestrial TV-Audio Standards

By means of autodetect, the MSP 34x7D offers a simple and fast (<0.5 s) facility to detect the actual TV-audio standard. The algorithm checks for the FM-mono and NICAM carriers of all common TV-Sound Standards. The following notes must be considered when applying the autodetect feature:

- Since there is no way to distinguish between AM and FM-carrier, a carrier detected at 6.5 MHz is interpreted as an AM-carrier. If video detection results in SECAM-East, the MSP result "9" of autodetect must be reinterpreted as "Bhex" in case of CAD\_BITS[0] = 1, or as "4" or "5" by using the demodulator short programming mode. A simple decision can be made between the two D/K FM-stereo standards by setting D/K1 and D/K2 using the short programming mode and checking the identification of both versions (see Table 6–13).
- The results are to be understood as static information, i.e. no evaluation of FM or NICAM identification concerning the dynamic mode (stereo, bilingual, or mono) are done.
- 4. Before switching to autodetect, the audio processing part should be muted. Do not forget to demute after having received the result.

Table 6-13: Result of Autodetection

	Result of Autodetect 007E <sub>hex</sub>						
Code (Data) hex	Detected TV-Sound Standard Note: After detection, the detected standard is set automatically according to Table 6–3.						
>07FF	autodetect still active						
0000	no TV Sound Standard was detected; select so	ound standard manually					
0002	M Dual-FM, even if only FM1 is available						
0003	B/G Dual-FM, even if only FM1 is available						
0008	B/G-FM-NICAM, only if NICAM is available (MSP 3417D only)						
	L_AM-NICAM, whenever a 6.5 MHz carrier is d If also D/K might be possible a decision has to						
		Video = SECAM_EAS	ST				
0009		CAD_BITS[0] = 0	CAD_BITS[0] = 1				
	Video = SECAM_L $\rightarrow$ no more activities necessary	To be set by m short program					
		D/K1 or D/K2 see section 6.6.1.	D/K-NICAM (standard 000B <sub>hex</sub> )				
000A	I-FM-NICAM, even if NICAM is not available						

**Note:** Similar as for the Demodulator Short-Programming, the Autodetection does not affect most of the parameters of the DSP section (Audio Baseband Processing): The following exceptions are to be considered:

- identification mode: Autodetection resets and sets the corresponding identification mode
- Prescale FM/AM & FM matrix and Deemphasis FM are undefined after Autodetection

# 6.6.2. C\_AD\_BITS (MSP 3417D only)

NICAM operation mode control bits and A[2...0] of the additional data bits.

#### Format:

MSB	C_AD_BITS 0023 <sub>hex</sub>								
11		7	6	5	4	3	2	1	0
Auto _FM		A[2]	A[1]	A[0]	C4	C3	C2	C1	S

**Important:** "S" = Bit[0] indicates correct NICAM-synchronization (S=1). If S = 0, the MSP 3417D has not yet synchronized correctly to frame and sequence, or has lost synchronization. The remaining read registers are therefore not valid. The MSP 3417D mutes the NICAM output automatically and tries to synchronize again as long as MODE\_REG[6] is set.

The operation mode is coded by C4-C1 as shown in Table 6–14.

**Table 6–14:** NICAM operation modes as defined by the EBU NICAM 728 specification

C4	C3	C2	C1	Operation Mode
0	0	0	0	Stereo sound (NICAMA/B), independent mono sound (FM1)
0	0	0	1	Two independent mono signals (NICAMA, FM1)
0	0	1	0	Three independent mono channels (NICAMA, NICAMB, FM1)
0	0	1	1	Data transmission only; no audio
1	0	0	0	Stereo sound (NICAMA/B), FM1 carries same channel
1	0	0	1	One mono signal (NICAMA). FM1 carries same channel as NICAMA
1	0	1	0	Two independent mono channels (NICAMA, NICAMB). FM1 carries same channel as NICAMA
1	0	1	1	Data transmission only; no audio
х	1	х	х	Unimplemented sound coding option (not yet defined by EBU NICAM 728 specification)

AUTO\_FM: monitor bit for the AUTO\_FM Status:

- 0: NICAM source is NICAM
- 1: NICAM source is FM

# 6.6.3. ADD\_BITS [10:3] (MSP 3417D only)

Contains the remaining 8 of the 11 additional data bits. The additional data bits are not yet defined by the NI-CAM 728 system.

### Format:

MSB		ADD_BITS 0038 <sub>hex</sub> LSB						
7	6	6 5 4 3 2 1						
A[10]	A[9]	A[8]	A[7]	A[6]	A[5]	A[4]	A[3]	

# 6.6.4. CIB\_BITS (MSP 3417D only)

Cib bits 1 and 2 (see NICAM 728 specifications)

### Format:

MSB		CIB_BITS 003E <sub>hex</sub> LSB						
7	6	5 4 3 2 1 0						
Х	х	х	х	х	х	CIB1	CIB2	

## 6.6.5. ERROR\_RATE (MSP 3417D only)

Average error rate of the NICAM reception in a time interval of 182 ms, which should be close to 0. The initial and maximum value of ERROR\_RATE is 2047. This value is also active, if the NICAM bit of MODE\_REG is not set. Since the value is achieved by filtering, a certain transition time (appr. 0.5 sec) is unavoidable. Acceptable audio may have error\_rates up to a value of 700<sub>dec</sub>. Individual evaluation of this value by the CCU and an appropriate threshold may define the fallback mode from NICAM to FM/AM-mono in case of poor NICAM reception.

The bit error rate per second (BER) can be calculated by means of the following formula:

BER = ERROR\_RATE \*  $12.3*10^{-6}$  /s

If the automatic switching feature (AUTO\_FM; section 6.4.2. on page 22) is applied, reading of ERROR\_RATE can be omitted.

ERROR_RATE	0057 <sub>hex</sub>
Error free	0000 <sub>hex</sub>
maximum error rate	07FF <sub>hex</sub>

# 6.6.6. CONC\_CT (for compatibility with MSP 3410B)

This register contains the actual number of bit errors of the previous 728-bit data frame. Evaluation of CONC\_CT is no longer recommended.

# 6.6.7. FAWCT\_IST (for compatibility with MSP 3410B)

For compatibility with MSP 3410B this value equals 12 as long as NICAM quality is sufficient. It decreases to 0 if NICAM reception gets poor. Evaluation of FAWCT\_IST is no longer recommended.

# 6.6.8. PLL\_CAPS

It is possible to read out the actual setting of the PLL\_CAPS. In standard applications, this register is not of interest for the customer.

PLL_CAPS	0021F <sub>hex</sub>	
minimum frequency	0111 1111	7F <sub>hex</sub>
nominal frequency	0101 0110 RESET	56 <sub>hex</sub>
maximum frequency	0000 0000	00 <sub>hex</sub>

# 6.6.9. AGC GAIN

It is possible to read out the actual setting of AGC\_GAIN in Automatic Gain Mode. In standard applications, this register is not of interest for the customer.

AGC_GAIN	0021E <sub>hex</sub>	
max. amplification (20 dB)	0001 0100	14 <sub>hex</sub>
min. amplification (3 dB)	0000 0000	00 <sub>hex</sub>

# 6.7. Sequences to Transmit Parameters and to Start Processing

After having been switched on, the MSP has to be initialized by transmitting the parameters according to the LOAD\_SEQ\_1/2 of Table 6–15. The data are immediately active after transmission into the MSP. It is no longer necessary to transmit LOAD\_REG\_1/2 or LOAD\_REG\_1 as it was for MSP 3410B. Nevertheless, transmission of LOAD\_REG\_1/2 or LOAD\_REG\_1 does no harm.

For NICAM operation, the following steps listed in 'NI-CAM\_WAIT, \_READ and \_Check' in Table 6–15 must be taken.

For FM-stereo operation, the evaluation of the identification signal must be performed. For a positive identification check, the MSP 34x7D sound channels have to be switched corresponding to the detected operation mode.

Table 6–15: Sequences to initialize and start the MSP 34x7D

LOAD_SEQ_1/2: General Initialization		
General Programming Mode	Demodulator Short Programming	
Write into MSP 34x7D:	Write into MSP 34x7D:	
1. AD_CV 2. FIR1 3. FIR2 4. MODE_REG 5. DCO1_LO 6. DCO1_HI 7. DCO2_LO 8. DCO2_HI	For example: Addr: 0020 <sub>hex</sub> , Data 0008 <sub>hex</sub> Alternatively, for terrestrial reception, the autodetect feature can be applied.	

### **AUDIO PROCESSING INIT**

Initialization of Audio Baseband Processing section, which may be customer dependant (see section 7.).

NICAM\_WAIT: Automatic Start of the NICAM-Decoder if Bit[6] of MODE\_REG is set to 1

1. Wait at least 0.25 s

**NICAM\_CHECK:** Read NICAM specific information and check for presence, operation mode, and quality of NICAM signal. DO NOT read and DO NOT evaluate Stereo Detection register.

Read out of MSP 34x7D (For MSP 3407D, all NICAM read registers contain "0"):

- 1. C AD BITS
- 2. CONC\_CT or ERROR\_RATE; if AUTO\_FM is active, reading of CONC\_CT or ERROR\_RATE can be omitted.

Evaluation of C\_AD\_BITS and CONC\_CT or ERROR\_RATE in the CCU (see section 6.6.).

If necessary, switch the corresponding sound channels within the audio baseband processing section.

FM\_WAIT: Automatic start of the FM-identification process if Bit[6] of MODE\_REG is set to 0.

- 1. Ident Reset
- 2. Wait at least 0.5 s

**FM\_IDENT\_CHECK:** Read FM specific information and check for presence, operation mode, and quality of dual carrier FM. DO NOT read and DO NOT evaluate NICAM specific information.

Read out of MSP 34x7D:

1. Stereo detection register (DSP register 0018<sub>hex</sub>, high part)

Evaluation of the stereo detection register (see section 7.6.1.)

If necessary, switch the corresponding sound channels within the audio baseband processing section

# LOAD\_SEQ\_1: Reinitialization of Channel 1 without affecting Channel 2

Write into MSP 34x7D:		Write into MSP 34x7D:
1. FIR1 2. MODE_REG 3. DCO1_LO 4. DCO1_HI	(6 · 8 bit) (12 bit) (12 bit)	For example: Addr: 0020hex, Data: 0003hex

PAUSE: Duration of "Pause" determines the repetition rate of the NICAM or the FM\_IDENT-check.


### 6.8. Software Proposals for Multistandard TV-Sets

To familiarize the reader with the programming scheme of the MSP 34x7D demodulator part, three examples in the shape of flow diagrams are shown in the following sections.

# 6.8.1. Multistandard Including System B/G or I (NICAM/FM-Mono only) or SECAM L (NICAM/AM-Mono only)

Fig. 6–1 shows a flow diagram for the CCU software, applied for the MSP 3417D in a TV set, which facilitates NICAM and FM/AM-mono sound. For the instructions, please refer to Table 6–15.

If the program is changed, resulting in another program within the same TV-sound system, no parameters of the MSP 3417D need be modified. To facilitate the check for NICAM, the CCU has only to continue at the 'NICAM\_WAIT' instruction. During the NICAM-identification process, the MSP 3417D must be switched to the FM-mono sound.



**Fig. 6–1:** CCU software flow diagram for NICAM/FM or AM mono with Demodulator Short Programming

# 6.8.2. Multistandard Including System B/G with NICAM/FM-Mono and German DUAL FM

Fig. 6–3 shows a flow diagram for the CCU software, applied for the MSP 3417D in a TV set, which facilitates all standards according to System B/G. For the instructions used in the diagram, please refer to Table 6–15.

After having switched on the TV-set and having initialized the MSP 3417D (LOAD\_SEQ\_1/2), FM-mono sound is available.

Fig. 6–3 shows that to check for any stereo or bilingual audio information, the sound standards  $0008_{hex}$  (B/G-NICAM) and  $0003_{hex}$  must simply be set alternately. If successful, the MSP 3417D must switch to the desired audio mode.

### 6.8.3. Satellite Mode

Fig. 6–2 shows the simple flow diagram to be used for the MSP 34x7D in a satellite receiver. For FM-mono operation, the corresponding FM carrier should preferably be processed at the MSP-channel 2.





Fig. 6-2: CCU software flow diagram: SAT-mode

# 6.8.4. Automatic Search Function for FM-Carrier Detection

The AM demodulation ability of the MSP 34x7D offers the possibility to calculate the "field strength" of the momentarily selected FM carrier, which can be read out by the CCU. In SAT receivers, this feature can be used to make automatic FM carrier search possible.

Therefore, the MSP has to be switched to AM-mode (MODE\_REG[8]), FM-Prescale must be set to 7F<sub>hex</sub>=+127<sub>dec</sub>, and the FM DC notch must be switched off. The sound-IF frequency range must now be "scanned" in the MSP-channel 2 by means of the programmable quadrature mixer with an appropriate incremental frequency (i.e. 10 kHz).



**Fig. 6–3:** CCU software flow diagram: Standard B/G with NICAM or FM stereo with Demodulator Short Programming Mode

After each incrementation, a field strength value is available at the quasi-peak detector output (quasi-peak detector source must be set to FM), which must be examined for relative maxima by the CCU. This results in either continuing search or switching the MSP 34x7D back to FM demodulation mode.

During the search process, the FIR2 must be loaded with the coefficient set "AUTOSEARCH", which enables small bandwidth, resulting in appropriate field strength characteristics. The absolute field strength value (can be read out of "quasi peak detector output FM1") also gives information on whether a main FM carrier or a subcarrier was detected, and as a practical consequence, the FM bandwidth (FIR1/2) and the deemphasis (50  $\mu$ s or adaptive) can be switched automatically.

Due to the fact that a constant demodulation frequency offset of a few kHz, leads to a DC-level in the demodulated signal, further fine tuning of the found carrier can be achieved by evaluating the "DC Level Readout FM1". Therefore, the FM DC Notch must be switched on, and the demodulator part must be switched back to FM-demodulation mode.

For a detailed description of the automatic search function, please refer to the corresponding Windows software.

**Note:** The automatic search is still possible by evaluating only the DC Level Readout FM1 (DC Notch On) as it is described with the MSP 3410B, but the above mentioned method is faster. If this DC Level method is applied with the MSP 34x7D, it is recommended to set MODE\_REG[15] to 1 (AM-Gain= 12 dB) and to use the new Autosearch FIR2 coefficient set as given in Table 6–11

# 7. Programming the DSP Section (Audio Baseband Processing)

# 7.1. DSP Write Registers: Table and Addresses

**Table 7–1:** DSP Write Registers; Subaddress: 12<sub>hex</sub>; if necessary these registers are readable as well.

DSP Write Register	Address (hex)	High/ Low	Adjustable Range, Operational Modes	Reset Mode/Value
Volume loudspeaker channel	0000	Н	[+12 dB –114 dB, MUTE]	MUTE
Volume / Mode loudspeaker channel		L	1/8 dB Steps	00 <sub>hex</sub>
Volume SCART1 channel	0007	Н	[00 <sub>hex</sub> 7F <sub>hex</sub> ],[+12 dB114 dB, MUTE]	00 <sub>hex</sub>
Volume / Mode SCART1 channel		L	[Linear mode / logarithmic mode]	linear mode
Loudspeaker channel source	0008	Н	[FM/AM, NICAM, SCART]	FM/AM
Loudspeaker channel matrix		L	[SOUNDA, SOUNDB, STEREO, MONO]	SOUNDA
SCART1 channel source	000A	Н	[FM/AM, NICAM, SCART]	FM/AM
SCART1 channel matrix		L	[SOUNDA, SOUNDB, STEREO, MONO]	SOUNDA
Quasi-peak detector source	000C	Н	[FM/AM, NICAM, SCART]	FM/AM
Quasi-peak detector matrix		L	[SOUNDA, SOUNDB, STEREO, MONO]	SOUNDA
Prescale SCART	000D	Н	[00 <sub>hex</sub> 7F <sub>hex</sub> ]	00 <sub>hex</sub>
Prescale FM/AM	000E	Н	[00 <sub>hex</sub> 7F <sub>hex</sub> ]	00 <sub>hex</sub>
FM matrix		L	[NO_MAT, GSTEREO, KSTEREO]	NO_MAT
Deemphasis FM	000F	Н	[OFF, 50 μs, 75 μs, J17]	50 μs
Adaptive Deemphasis FM		L	[OFF, WP1]	OFF
Prescale NICAM (MSP 3417D only)	0010	Н	[00 <sub>hex</sub> 7F <sub>hex</sub> ]	00 <sub>hex</sub>
ACB Register (SCART Switching Facilities)	0013	H/L	Bits [150]	00 <sub>hex</sub>
Beeper	0014	H/L	[00 <sub>hex</sub> 7F <sub>hex</sub> ]/[00 <sub>hex</sub> 7F <sub>hex</sub> ]	0/0
Identification Mode	0015	L	[B/G, M]	B/G
FM DC Notch	0017	L	[ON, OFF]	ON
Automatic Volume Correction	0029	Н	[off, on, decay time]	off

# 7.2. DSP Read Registers: Table and Addresses

Table 7–2: DSP Read Registers; Subaddress: 13<sub>hex</sub>

DSP Read Register	Address (hex)	High/Low	Output Range
Stereo detection register	0018	Н	[80 <sub>hex</sub> 7F <sub>hex</sub> ] 8 bit two's complement
Quasi peak readout left	0019	H&L	[00 <sub>hex</sub> 7FFF <sub>hex</sub> ] 16 bit two's complement
Quasi peak readout right	001A	H&L	[00 <sub>hex</sub> 7FFF <sub>hex</sub> ] 16 bit two's complement
DC level readout FM1/Ch2-L	001B	H&L	[8000 <sub>hex</sub> 7FFF <sub>hex</sub> ] 16 bit two's complement
DC level readout FM2/Ch1-R	001C	H&L	[8000 <sub>hex</sub> 7FFF <sub>hex</sub> ] 16 bit two's complement
MSP hardware version code	001E	Н	[00 <sub>hex</sub> FF <sub>hex</sub> ]
MSP major revision code	001E	L	[00 <sub>hex</sub> FF <sub>hex</sub> ]
MSP product code	001F	Н	[07 <sub>hex</sub> , 01 <sub>hex</sub> ]
MSP ROM version code	001F	L	[00 <sub>hex</sub> FF <sub>hex</sub> ]

# 7.3. DSP Write Registers: Functions and Values

Write registers are 16 bit wide, whereby the MSB is denoted bit [15]. Transmissions via I<sup>2</sup>C bus have to take place in 16-bit words. Some of the defined 16-bit words are divided into low [7...0] and high [15...8] byte, or in an other manner, thus holding two different control entities. All write registers are readable. Unused parts of the 16-bit registers must be zero. Addresses not given in this table must not be written at any time!

# 7.3.1. Volume Loudspeaker Channel

Volume Loudspeaker	0000 <sub>hex</sub>	[154]
+12 dB	0111 1111 0000	7F0 <sub>hex</sub>
+11.875 dB	0111 1110 1110	7EE <sub>hex</sub>
+0.125 dB	0111 0011 0010	732 <sub>hex</sub>
0 dB	0111 0011 0000	730 <sub>hex</sub>
-0.125 dB	0111 0010 1110	72E <sub>hex</sub>
-113.875 dB	0000 0001 0010	012 <sub>hex</sub>
–114 dB	0000 0001 0000	010 <sub>hex</sub>
Mute	0000 0000 0000 RESET	000 <sub>hex</sub>
Fast Mute	1111 1111 1110	FFE <sub>hex</sub>

The highest given positive 8-bit number  $(7F_{hex})$  yields in a maximum possible gain of 12 dB. Decreasing the volume register by 1 LSB decreases the volume by 1 dB. Volume settings lower than the given minimum mute the output. With large scale input signals, positive volume settings may lead to signal clipping.

The MSP 34x7D loudspeaker volume function is divided up in a digital and an analog section.

With **Fast Mute**, volume is reduced to mute position by digital volume only. Analog volume is not changed. This reduces any audible DC plops. Going back from Fast Mute should be done to the volume step before Fast Mute was activated.

The **Fast Mute** facility is activated by the  $I^2C$  command. After 75 ms (typ.), the signal is completely ramped down.

# 7.3.2. Volume SCART1

Volume Mode SCART1	0007 <sub>hex</sub>	[30]
linear	0000 RESET	0 <sub>hex</sub>
logarithmic	0001	1 <sub>hex</sub>

Linear Mode		
Volume SCART1	0007 <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
0 dB gain (digital full scale (FS) to 2 V <sub>RMS</sub> output)	0100 0000	40 <sub>hex</sub>
+6 dB gain (–6 dBFS to 2 V <sub>RMS</sub> output)	0111 1111	7F <sub>hex</sub>

Logarithmic Mode		
Volume SCART1	0007 <sub>hex</sub>	[154]
+12 dB	0111 1111 0000	7F0 <sub>hex</sub>
+11.875 dB	0111 1110 1110	7EE <sub>hex</sub>
+0.125 dB	0111 0011 0010	732 <sub>hex</sub>
0 dB	0111 0011 0000	730 <sub>hex</sub>
–0.125 dB	0111 0010 1110	72E <sub>hex</sub>
-113.875 dB	0000 0001 0010	012 <sub>hex</sub>
-114 dB	0000 0001 0000	010 <sub>hex</sub>
Mute	0000 0000 0000 RESET	000 <sub>hex</sub>

# 7.3.3. Channel Source Modes

Loudspeaker Source	0008 <sub>hex</sub>	Н
SCART1 Source	000A <sub>hex</sub>	н
Quasi-Peak Detector Source	000C <sub>hex</sub>	Н
FM/AM	0000 0000 RESET	00 <sub>hex</sub>
NICAM (MSP 3417D only)	0000 0001	01 <sub>hex</sub>
SCART	0000 0010	02 <sub>hex</sub>

# 7.3.4. Channel Matrix Modes

Loudspeaker Matrix	0008 <sub>hex</sub>	L
SCART1 Matrix	000A <sub>hex</sub>	L
Quasi-Peak Detector Matrix	000C <sub>hex</sub>	L
SOUNDA / LEFT / MSP-IF-CHANNEL2	0000 0000 RESET	00 <sub>hex</sub>
SOUNDB / RIGHT / MSP-IF-CHANNEL1	0001 0000	10 <sub>hex</sub>
STEREO	0010 0000	20 <sub>hex</sub>
MONO	0011 0000	30 <sub>hex</sub>

#### 7.3.5. SCART Prescale

Volume Prescale SCART	000D <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
0 dB gain (2 V <sub>RMS</sub> input to digital full scale)	0001 1001	19 <sub>hex</sub>
+14 dB gain (400 mV <sub>RMS</sub> input to digital full scale)	0111 1111	7F <sub>hex</sub>

## Comments for the FM/AM-Prescaling:

For the **High Deviation Mode**, the FM prescaling values can be used in the range from  $13_{hex}$  to  $30_{hex}$ . Please consider the internal reduction of 6 dB for this mode. The FIR-bandwidth should be selected to 500 kHz.

## 7.3.6. FM/AM Prescale

Volume Prescale FM (Normal FM Mode)	000E <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
Maximum Volume (28 kHz deviation <sup>1)</sup> recommended FIR- bandwidth: 130 kHz)	0111 1111	7F <sub>hex</sub>
Deviation 50 kHz <sup>1)</sup> recommended FIR-bandwidth: 200 kHz	0100 1000	48 <sub>hex</sub>
Deviation 75 kHz <sup>1)</sup> recommended FIR-bandwidth: 200 or 280 kHz	0011 0000	30 <sub>hex</sub>
Deviation 150 kHz <sup>1)</sup> recommended FIR-bandwidth: 380 kHz	0001 1000	18 <sub>hex</sub>
Maximum deviation 192 kHz <sup>1)</sup> recommended FIR- bandwidth: 380 kHz	0001 0011	13 <sub>hex</sub>
Prescale for adaptive deemphasis WP1 recommended FIR- bandwidth: 130 kHz	0001 0000	10 <sub>hex</sub>
Volume Prescale FM (High Dev Mode)	000E <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
Deviation 150 kHz <sup>1)</sup> recommended FIR-bandwidth: 380 kHz	0011 0000	30 <sub>hex</sub>
Maximum deviation 384 kHz <sup>1)</sup> recommended FIR- bandwidth: 500 kHz	0001 0100	14 <sub>hex</sub>
Volume Prescale AM	000E <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
SIF input level:		
0.1 Vpp – 0.8 Vpp <sup>1) 2)</sup> 0.8 Vpp – 1.4 Vpp <sup>1)</sup>	0111 1100	7C <sub>hex</sub> <7C <sub>hex</sub>
0.8 Vpp – 1.4 Vpp <sup>1)</sup> <7C <sub>hex</sub> <7C <sub>hex</sub> Note: For AM the bit MODE_REG[15] must be 1		

<sup>&</sup>lt;sup>1)</sup> Given deviations will result in internal digital full scale signals. Appropriate clipping headroom has to be set by the customer. This can be done by decreasing the listed values by a specific factor.

<sup>&</sup>lt;sup>2)</sup> In the mentioned SIF-level range, the AM-output level remains stable and independent of the actual SIF-level. In this case, only the AM degree of audio signals above 40 Hz determines the AM-output level.

#### 7.3.7. FM Matrix Modes

FM Matrix	000E <sub>hex</sub>	L
NO MATRIX	0000 0000 RESET	00 <sub>hex</sub>
GSTEREO	0000 0001	01 <sub>hex</sub>
KSTEREO	0000 0010	02 <sub>hex</sub>

NO\_MATRIX is used for terrestrial mono or satellite stereo sound. GSTEREO dematrixes [(L+R)/2, R] to [L, R] and is used for German dual carrier stereo system (Standard B/G). KSTEREO dematrixes [(L+R)/2, (L-R)/2] to [L, R] and is used for the Korean dual carrier stereo system (Standard M).

## 7.3.8. FM Fixed Deemphasis

Deemphasis FM	000F <sub>hex</sub>	Н
50 μs	0000 0000 RESET	00 <sub>hex</sub>
75 μs	0000 0001	01 <sub>hex</sub>
J17	0000 0100	04 <sub>hex</sub>
OFF	0011 1111	3F <sub>hex</sub>

#### 7.3.9. FM Adaptive Deemphasis

FM Adaptive Deemphasis WP1	000F <sub>hex</sub>	L
OFF	0000 0000 RESET	00 <sub>hex</sub>
WP1	0011 1111	3F <sub>hex</sub>

#### 7.3.10. NICAM Prescale (MSP 3417D only)

Volume Prescale NICAM	0010 <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
0 dB gain	0010 0000	20 <sub>hex</sub>
+12 dB gain	0111 1111	7F <sub>hex</sub>

#### 7.3.11. NICAM Deemphasis (MSP 3417D only)

A J17 Deemphasis is always applied to the NICAM signal. It is not switchable.

## **7.3.12. ACB Register** (see Fig. 4–3); [15:14] = 0!

## **Definition of Digital Control Output Pins**

ACB Register	0013 <sub>hex</sub>	[1514]
D_CTR_OUT0 low (RESET) high	x0 x1	
D_CTR_OUT1 low (RESET) high	0x 1x	

## **Definition of SCART-Switching Facilities**

ACB Register	0013 <sub>hex</sub> [130]
DSP IN Selection of Source: * SC1_IN_L/R MONO_IN Mute	xx xx00 xx00 0000 xx xx01 xx00 0000 xx xx11 xx10 0000
SC1_OUT_L/R Selection of Source: MONO_IN SCART1 via D/A SC1_IN_L/R Mute	xx 10xx x0x0 0000 xx 11xx x0x0 0000 xx 01xx x1x0 0000 xx 11xx x1x0 0000

\* = RESET position, which becomes active at the time of the first write transmission on the control bus to the audio processing part (DSP). By writing to the ACB register first, the RESET state can be redefined.

**Note:** After RESET, SC1\_OUT\_L/R is undefined!

**Note:** If "MONO\_IN" is selected at the DSP\_IN selection, the channel matrix mode of the corresponding output channel(s) must be set to "sound A".

#### 7.3.13. Beeper

Beeper Volume	0014 <sub>hex</sub>	Н
OFF	0000 0000 RESET	00 <sub>hex</sub>
Maximum Volume (full digital scale FDS)	0111 1111	7F <sub>hex</sub>
Beeper Frequency	0014 <sub>hex</sub>	L
16 Hz (lowest)	0000 0001	01 <sub>hex</sub>
1 kHz	0100 0000	40 <sub>hex</sub>

A squarewave beeper can be added to the loudspeaker channel. The addition point is just before volume adjustment.

#### 7.3.14. Identification Mode

Identification Mode	0015 <sub>hex</sub>	L
Standard B/G (German Stereo)	0000 0000 RESET	00 <sub>hex</sub>
Standard M (Korean Stereo)	0000 0001	01 <sub>hex</sub>
Reset of Ident-Filter	0011 1111	3F <sub>hex</sub>

To shorten the response time of the identification algorithm after a program change between two FM-stereo capable programs, the reset of the ident-filter can be applied.

# Sequence:

- 1. Program change
- 2. Reset ident-filter
- 3. Set identification mode back to standard B/G
- 4. Wait approx. 0.5 sec.
- 5. Read stereo detection register

#### 7.3.15. FM DC Notch

The DC compensation filter (FM DC Notch) for FM input can be switched off. This is used to speed up the automatic search function (see section 6.8.4.). In normal FM-mode, the FM DC Notch should be switched on.

FM DC Notch	0017 <sub>hex</sub>	L
ON	0000 0000 Reset	00 <sub>hex</sub>
OFF	0011 1111	3F <sub>hex</sub>

## 7.3.16. Automatic Volume Correction (AVC)

AVC	on/off	0029 <sub>hex</sub>	[15:12]
AVC	off and Reset of int. variables	0000 RESET	0 <sub>hex</sub>
AVC	on	1000	8 <sub>hex</sub>
AVC	Decay Time	0029 <sub>hex</sub>	[11:8]
8 sec 4 sec 2 sec 20 ms	(middle)	1000 0100 0010 0001	8 <sub>hex</sub> 4 <sub>hex</sub> 2 <sub>hex</sub> 1 <sub>hex</sub>

<sup>1)</sup> intended for quick adaptation to the average volume level after channel change


Different sound sources (e.g. Terrestrial channels, SAT channels or SCART) fairly often do not have the same volume level. Advertisement during movies usually have a higher volume level than the movie itself. This results in annoying volume changes. The AVC solves this problem by equalizing the volume level.

To prevent clipping, the AVC's gain decreases quickly in dynamic boost conditions. To suppress oscillation effects, the gain increases rather slowly for low-level inputs. The decay time is programmable by the AVC register bits [11:8].

For input signals ranging from -24 dBr to 0 dBr, the AVC maintains a fixed output level of -18 dBr. Fig 7-1 shows the AVC output level versus its input level. For prescale and volume registers set to 0 dB, a level of 0 dBr corresponds to full scale input/output. This is

- SCART in-, output 0 dBr = 2.0  $V_{rms}$
- Loudspeaker and Aux output 0 dBr = 1.4 V<sub>rms</sub>

40



To reset the internal variables, the AVC should be switched off and on during any channel or source change. For standard applications, the recommended decay time is 4 sec.

**Note:** AVC should not be used in any Dolby Pro Logic mode.

#### 7.4. Exclusions for the Audio Baseband Features

In general, all functions can be switched independently of the others. Exceptions:

- 1. NICAM cannot be processed simultaneously with the FM2 channel (MSP 3417D only).
- 2. FM adaptive deemphasis WPI cannot be processed simultaneously with the FM-identification.

## 7.5. Phase Relationship of Inputs/Outputs

The following diagram shows the phase relationship of all analog inputs and output.




Fig. 7-2: Phase diagram of MSP 34x7D

## 7.6. DSP Read Registers: Functions and Values

All readable registers are 16-bit wide. Transmissions via  $I^2C$  bus have to take place in 16-bit words. Single data entries are 8 bit. Some of the defined 16-bit words are divided into low and high byte, thus holding two different control entities.


These registers are not writeable.

## 7.6.1. Stereo Detection Register

Stereo Detection Register	0018 <sub>hex</sub> H	
Stereo/Bilingual Mode	Reading ID-level (two's complement)	
MONO	near zero	
STEREO	positive value (ideal reception: 7F <sub>hex</sub> )	
BILINGUAL	negative value (ideal reception: 80 <sub>hex)</sub>	

If FM Adaptive Deemphasis WP1 is active, the ID-level in Stereo Detection Register is not valid.

A control processor evaluating the content of the Stereo Detection Register (ID-level) should use the threshold recommendations shown in Fig. 7–3 for switching to Stereo/Bilingual and back to Mono mode.



**Fig. 7–3:** Recommended thresholds for Stereo/Mono/Bilingual switching

#### 7.6.2. Quasi-Peak Detector

Quasi-Peak Readout Left	0019 <sub>hex</sub>	H+L
Quasi-Peak Readout Right	001A <sub>hex</sub>	H+L
Quasi peak readout	[0 <sub>hex</sub> 7FFF <sub>hex</sub> ] values are 16 bit two's complement	

The quasi peak readout register can be used to read out the quasi peak level of any input source, in order to adjust all inputs to the same normal listening level. The refresh rate is 32 kHz. The feature is based on a filter time constant:

attack-time: 1.3 ms decay-time: 37 ms

## 7.6.3. DC Level Register

DC Level Readout FM1 (MSP-Ch2)	001B <sub>hex</sub>	H+L
DC Level Readout FM2 (MSP-Ch1)	001C <sub>hex</sub>	H+L
DC Level	[8000 <sub>hex</sub> 7FFF <sub>hex</sub> ] values are 16 bit two's complement	

The DC level register measures the DC component of the incoming FM signals (FM1 and FM2). This can be used for seek functions in satellite receivers and for IF FM frequencies fine tuning. A too low demodulation frequency (DCO) results in a positive DC-Level and vice versa. For further processing, the DC content of the demodulated FM signals is suppressed. The time constant  $\tau$ , defining the transition time of the DC Level Register, is approximately 28 ms.

## 7.6.4. MSP Hardware Version Code

Hardware Version	001E <sub>hex</sub> H
Hardware Version	[00 <sub>hex</sub> FF <sub>hex</sub> ]
MSP 34x7D – <b>A</b> 1	01 <sub>hex</sub>
MSP 34x7D – <b>B</b> 2	02 <sub>hex</sub>

A change in the hardware version code defines hardware optimizations that may have influence on the chip's behavior. The readout of this register is identical to the hardware version code in the chip's imprint.

#### 7.6.5. MSP Major Revision Code

Major Revision	001E <sub>hex</sub> L
MSP 34x7 <b>D</b>	04 <sub>hex</sub>

The MSP 34x7D is the fourth generation of ICs in the MSP family.

#### 7.6.6. MSP Product Code

Product	001F <sub>hex</sub> H
MSP 34 <b>07</b> D	07 <sub>hex</sub>
MSP 34 <b>17</b> D	11 <sub>hex</sub>

By means of the MSP-Product Code, the control processor is able to decide whether or not NICAM-controlling should be accomplished.

#### 7.6.7. MSP ROM Version Code

ROM Version	001F <sub>hex</sub> L
Major software revision	[00 <sub>hex</sub> FF <sub>hex</sub> ]
MSP 34x7D – A <b>1</b>	21 <sub>hex</sub>
MSP 34x7D – B <b>2</b>	22 <sub>hex</sub>

A change in the ROM version code defines internal software optimizations, that may have influence on the chip's behavior, e.g. new features may have been included. While a software change is intended to create no compatibility problems, customers that want to use the new functions can identify new MSP 34x7D versions according to this number.

To avoid compatibility problems with the MSPB series, an offset of  $20_{\text{hex}}$  is added to the ROM version code of the chip's imprint.

## 8. Specifications

## 8.1. Outline Dimensions




Fig. 8–1:
52-Pin Plastic Shrink Dual In Line Package (PSDIP52)
Weight approximately 5.5 g
Dimensions in mm




Fig. 8–2: 44-Pin Plastic Metric Quad Flat Package (PMQFP44) Weight approx. 0.4 g Dimensions in mm

# 8.2. Pin Connections and Short Descriptions

NC = not connected (**leave vacant** for future compatibility reasons)

TP = Test Pin (leave vacant; pin is used for production test only)


LV = leave vacant

X = obligatory; connect as described in application circuit diagram

PSDIP	n No.	Pin Name	Туре	Connection (if not used)	Short Description
52-pin	44-pin	TD	OUT	137	<b></b>
14	_	TP	OUT	LV	Test pin
13	-	TP	OUT	LV	Test pin
12	17	TP		LV	Test pin
11	16	TP	OUT	LV	Test pin
10	15	TP	IN/OUT	LV	Test pin
9	14	TP	IN/OUT	LV	Test pin
8	13	I <sup>2</sup> C_DA	IN/OUT	X	I <sup>2</sup> C data
7	12	I <sup>2</sup> C_CL	IN/OUT	X	I <sup>2</sup> C clock
6	11	STANDBYQ	IN	Х	Standby (low-active)
5	10	ADR_SEL	IN	Х	I <sup>2</sup> C Bus address select
4	9	D_CTR_OUT0	OUT	LV	Digital control output 0
3	8	D_CTR_OUT1	OUT	LV	Digital control output 1
2	_	NC		LV	Not connected
1	7	TP		LV	Test pin
52	6	XTAL_OUT	OUT	X	Crystal oscillator
51	5	XTAL_IN	IN	Х	Crystal oscillator
50	4	TESTEN	IN	Х	Test pin
49	_	NC		LV	Not connected
48	3	ANA_IN-	IN	LV	IF common
47	2	ANA_IN1+	IN	LV	IF input 1
46	1	AVSUP		Х	Analog power supply +5 V
45	44	AVSS		Х	Analog ground
44	43	MONO_IN	IN	LV	Mono input
43	42	VREFTOP		Х	Reference voltage IF A/D converter
42	41	SC1_IN_R	IN	LV	Scart input 1 in, right
41	40	SC1_IN_L	IN	LV	Scart input 1 in, left
_	39	NC		LV	Not connected
40	38	NC		LV	Not connected

Pin No.		Pin Name	Туре	Connection	Short Description
PSDIP 52-pin	PMQFP 44-pin			(if not used)	
39	37	NC		LV	Not connected
38	_	NC		LV	Not connected
37	_	NC		LV	Not connected
36	36	AGNDC		X	Analog reference voltage high voltage part
35	35	AHVSS		X	Analog ground
34	34	CAPL_M		Х	Volume capacitor MAIN
33	33	AHVSUP		X	Analog power supply 8.0 V
32	32	NC		LV	Not connected
31	31	SC1_OUT_L	OUT	LV	Scart output 1, left
30	30	SC1_OUT_R	OUT	LV	Scart output 1, right
29	29	VREF1		Х	Reference ground 1 high voltage part
28	28	TP		LV	Test pin
27	_	TP		LV	Test pin
26	_	NC		LV	Not connected
25	27	DACM_L	OUT	LV	Loudspeaker out, left
24	26	DACM_R	OUT	LV	Loudspeaker out, right
23	25	VREF2		X	Reference ground 2 high voltage part
22	24	TP		LV	Test Pin
21	23	TP		LV	Test Pin
20	22	RESETQ	IN	Х	Power-on-reset
19	_	NC		LV	Not connected
18	21	TP	IN	LV	Test pin
17	20	DVSS		Х	Digital ground
16	19	DVSUP		Х	Digital power supply +5 V
15	18	TP_CO	OUT	LV	Test pin (use this pin to define the capacitor size at crystal oscillator)

## 8.3. Pin Configurations







Fig. 8-4: 44-pin PMQFP package

## 8.4. Pin Circuits (pin numbers refer to PSDIP52 package)



**Fig. 8–5:** Input/Output Pins 7 and 8 (I<sup>2</sup>C\_DA, I<sup>2</sup>C\_CL)





Fig. 8-10: Input Pins 41 and 42 (SC1\_IN\_L/R)



**Fig. 8–6:** Input Pins 5, 6, and 20 (STANDBYQ, ADR\_SEL, RESETQ)




Fig. 8-11: Pin 36 (AGNDC)





Fig. 8–7: Input/Output Pins 51 and 52 (XTALIN/OUT)



**Fig. 8–12:** Capacitor Pin 34 (CAPL\_M)


300

80 k


≈ 3.75 V

(SC1\_OUT\_L/R)

Fig. 8-13: Output Pins 31, 30



**Fig. 8–8:** Input Pins 48, 47, and 43 (ANA\_IN-, ANA\_IN1+, VREFTOP)



**Fig. 8–14:** Output Pins 25, 24 (DACM\_L/R)




Fig. 8-9: Input Pin 44 (MONO\_IN)

#### 8.5. Electrical Characteristics

## 8.5.1. Absolute Maximum Ratings

Symbol	Parameter	Pin Name	Min.	Max.	Unit
T <sub>A</sub>	Ambient Operating Temperature	_	0	70 <sup>1)</sup>	°C
T <sub>S</sub>	Storage Temperature	_	-40	125	°C
V <sub>SUP1</sub>	First Supply Voltage	AHVSUP	-0.3	9.0	V
V <sub>SUP2</sub>	Second Supply Voltage	DVSUP	-0.3	6.0	V
V <sub>SUP3</sub>	Third Supply Voltage	AVSUP	-0.3	6.0	V
dV <sub>SUP23</sub>	Voltage between AVSUP and DVSUP	AVSUP, DVSUP	-0.5	0.5	V
P <sub>TOT</sub>	Package Power Dissipation PSDIP52 without Heat Spreader PMQFP44 without Heat Spreader	AHVSUP, DVSUP, AVSUP		1200 910 <sup>1)</sup>	mW
V <sub>Idig</sub>	Input Voltage, all Digital Inputs		-0.3	V <sub>SUP2</sub> +0.3	V
I <sub>Idig</sub>	Input Current, all Digital Pins	_	-20	+20	mA <sup>2)</sup>
V <sub>Iana</sub>	Input Voltage, all Analog Inputs	SC1_IN_s, <sup>3)</sup> MONO_IN	-0.3	V <sub>SUP1</sub> +0.3	V
I <sub>lana</sub>	Input Current, all Analog Inputs	SC1_IN_s, <sup>3)</sup> MONO_IN	<b>-</b> 5	+5	mA <sup>2)</sup>
I <sub>Oana</sub>	Output Current, all SCART Outputs	SC1_OUT_s	4), 5)	4), 5)	
I <sub>Oana</sub>	Output Current, all Analog Outputs except SCART Outputs	DACM_s <sup>3)</sup>	4)	4)	
I <sub>Cana</sub>	Output Current, other pins connected to capacitors	CAPL_M AGNDC	4)	4)	

<sup>1)</sup> For PMQFP44 package, max. ambient operating temperature is 65 °C.

Stresses beyond those listed in the "Absolute Maximum Ratings" may cause permanent damage to the device. This is a stress rating only. Functional operation of the device at these or any other conditions beyond those indicated in the "Recommended Operating Conditions/Characteristics" of this specification is not implied. Exposure to absolute maximum ratings conditions for extended periods may affect device reliability.

<sup>2)</sup> positive value means current flowing into the circuit

<sup>3) &</sup>quot;s" means "L" or "R"

<sup>4)</sup> The Analog Outputs are short circuit proof with respect to First Supply Voltage and Ground.

<sup>5)</sup> Total chip power dissipation must not exceed absolute maximum rating.

# 8.5.2. Recommended Operating Conditions

(at  $T_A = 0$  to 70 °C)

Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit
V <sub>SUP1</sub>	First Supply Voltage	AHVSUP	7.6	8.0	8.7 <sup>1)</sup>	V
V <sub>SUP2</sub>	Second Supply Voltage	DVSUP	4.75	5.0	5.25	V
V <sub>SUP3</sub>	Third Supply Voltage	AVSUP	4.75	5.0	5.25	V
V <sub>RLH</sub>	RESET Input Low-to-High Transition Voltage	RESETQ	0.7		0.8	DVSUP
V <sub>RHL</sub>	RESET Input High-to-Low Transition Voltage (see also Fig. 5–3 on page 18)		0.45		0.55	DVSUP
V <sub>DIGIL</sub>	Digital Input Low Voltage	ADR_SEL			0.2	V <sub>SUP2</sub>
V <sub>DIGIH</sub>	Digital Input High Voltage		0.8			V <sub>SUP2</sub>
V <sub>DIGIL</sub>	Digital Input Low Voltage	STANDBYQ			0.2	V <sub>SUP2</sub>
V <sub>DIGIH</sub>	Digital Input High Voltage MSP 34x7D version A1 MSP 34x7D verion B2 and later		0.8 0.5			V <sub>SUP2</sub> V <sub>SUP2</sub>
t <sub>STBYQ1</sub>	STANDBYQ Setup Time before Turn-off of Second Supply Voltage	STANDBYQ, DVSUP	1			μs
I <sup>2</sup> C-Bus Rec	commendations					
V <sub>IMIL</sub>	I <sup>2</sup> C-BUS Input Low Voltage	I <sup>2</sup> C_CL,			0.3	V <sub>SUP2</sub>
V <sub>IMIH</sub>	I <sup>2</sup> C-BUS Input High Voltage	I <sup>2</sup> C_DA	0.6			V <sub>SUP2</sub>
t <sub>I2C1</sub>	I <sup>2</sup> C START Condition Setup Time		120			ns
t <sub>I2C2</sub>	I <sup>2</sup> C STOP Condition Setup Time		120			ns
t <sub>l2C5</sub>	I <sup>2</sup> C-Data Setup Time before Rising Edge of Clock		55			ns
t <sub>I2C6</sub>	I <sup>2</sup> C-Data Hold Time after Falling Edge of Clock		55			ns
t <sub>I2C3</sub>	I <sup>2</sup> C-Clock Low Pulse Time	I <sup>2</sup> C_CL	500			ns
t <sub>I2C4</sub>	I <sup>2</sup> C-Clock High Pulse Time		500			ns
f <sub>IM</sub>	I <sup>2</sup> C-BUS Frequency				1.0	MHz
1) For MSP 3	34x7D-A1 version in PMQFP44 packag	e, only 8.4 V is allow	ved.		· · · · · ·	

Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit
General Cr	ystal Recommendations		_			
f <sub>P</sub>	Crystal Parallel Resonance Frequency at 12 pF Load Capacitance			18.432		MHz
R <sub>R</sub>	Crystal Series Resistance			8	25	Ω
C <sub>0</sub>	Crystal Shunt (Parallel) Capacitance			6.2	7.0	pF
C <sub>L</sub>	External Load Capacitance <sup>1)</sup>	XTAL_IN, XTAL_OUT	PSDIP PMQFI	_		pF pF
Crystal Red	commendations for FM / NICAM Appl	ications				
f <sub>TOL</sub>	Accuracy of Adjustment		-30		+30	ppm
D <sub>TEM</sub>	Frequency Variation versus Temp.		-30		+30	ppm
C <sub>1</sub>	Motional (Dynamic) Capacitance		15			fF
f <sub>CL</sub>	Required Open Loop Clock Frequency (T <sub>amb</sub> = 25 °C)	XTAL_IN, XTAL_OUT	18.4305		18.4335	MHz
Crystal Red	commendations for FM Application					
f <sub>TOL</sub>	Accuracy of Adjustment		-100		+100	ppm
D <sub>TEM</sub>	Frequency Variation versus Temp.		-50		+50	ppm
Amplitude	Recommendation for Operation with	External Clock Ir	nput (C <sub>load</sub>	after rese	et = 22 pF)	-
V <sub>XCA</sub>	External Clock Amplitude	XTAL_IN	0.7			$V_{pp}$

<sup>1)</sup> External capacitors at each crystal pin to ground are required. They are necessary to tune the open-loop frequency of the internal PLL and to stabilize the frequency in closed-loop operation.

Due to different layouts, the accurate capacitor size should be determined with the customer PCB. The suggested values (1.5...3.3 pF) are figures based on experience and should serve as "start value".

To define the capacitor size, reset the MSP without transmitting any further  $I^2C$  telegrams. Set MODE\_REG 0083hex Bit[14]=1. Measure the frequency at pin TP\_CO (see pin description in table on page 45). Change the capacitor size until the free running frequency at pin TP\_CO matches 6.144000 MHz (=18.432000 MHz / 3) as closely as possible. The higher the capacitors, the lower the resulting clock frequency.

Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit
Analog Inpu	ut and Output Recommendations					
C <sub>AGNDC</sub>	AGNDC-Filter-Capacitor	AGNDC	-20%	3.3		μF
C <sub>AGNDC</sub>	Ceramic Capacitor in Parallel		-20%	100		nF
C <sub>inSC</sub>	DC-Decoupling Capacitor in front of SCART Inputs	SC1_IN_s <sup>1)</sup>	-20%	330	+20%	nF
V <sub>inSC</sub>	SCART Input Level				2.0	V <sub>RMS</sub>
V <sub>inMONO</sub>	Input Level, Mono Input	MONO_IN			2.0	V <sub>RMS</sub>
R <sub>LSC</sub>	SCART Load Resistance	SC1_OUT_s	10			kΩ
C <sub>LSC</sub>	SCART Load Capacitance				6.0	nF
C <sub>VMA</sub>	Main Volume Capacitor	CAPL_M		10		μF
C <sub>FMA</sub>	Main Filter Capacitor	DACM_s <sup>1)</sup>	-10%	1	+10%	nF
Recommen	dations for Analog Sound IF Input S	ignal				
C <sub>VREFTOP</sub>	VREFTOP-Filter-Capacitor	VREFTOP	-20%	10		μF
	Ceramic Capacitor in Parallel		-20%	100		nF
F <sub>IF_FM</sub>	Analog Input Frequency Range		0		9	MHz
V <sub>IF_FM</sub>	Analog Input Range FM/NICAM		0.1	0.8	3	Vpp
V <sub>IF_AM</sub>	Analog Input Range AM/NICAM		0.1	0.45	0.8	Vpp
R <sub>FMNI</sub>	Ratio: NICAM Carrier/FM Carrier (unmodulated carriers) BG: I:		-20 -23	-7 -10	0 0	dB dB
R <sub>AMNI</sub>	Ratio: NICAM Carrier/AM Carrier (unmodulated carriers)		-25	-11	0	dB
R <sub>FM</sub>	Ratio: FM-Main/FM-Sub Satellite			7		dB
R <sub>FM1/FM2</sub>	Ratio: FM1/FM2 German FM-System	ANA_IN1+, ANA_IN–		7		dB
R <sub>FC</sub>	Ratio: Main FM Carrier/ Color Carrier		15	_	-	dB
R <sub>FV</sub>	Ratio: Main FM Carrier/ Luma Components		15	_	_	dB
PR <sub>IF</sub>	Passband Ripple		_	_	±2	dB
SUP <sub>HF</sub>	Suppression of Spectrum Above 9.0 MHz		15		_	dB
FM <sub>MAX</sub>	Maximum FM-Deviation (apprx.) normal mode high deviation mode				±192 ±360	kHz kHz

## 8.5.3. Characteristics

at  $T_A$  = 0 to 70 °C,  $f_{CLOCK}$  = 18.432 MHz,  $V_{SUP1}$  = 7.6 to 8.7 V,  $V_{SUP2}$  = 4.75 to 5.25 V for min./max. values at  $T_A$  = 60 °C,  $f_{CLOCK}$  = 18.432 MHz,  $V_{SUP1}$  = 8 V,  $V_{SUP2}$  = 5 V for typical values,  $T_J$  = Junction Temperature MAIN (M) = Loudspeaker Channel, AUX (A) = Headphone Channel

Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit	Test Conditions
f <sub>CLOCK</sub>	Clock Input Frequency	XTAL_IN		18.432		MHz	
D <sub>CLOCK</sub>	Clock High to Low Ratio		45		55	%	
t <sub>JITTER</sub>	Clock Jitter				50	ps	no Production verification
V <sub>xtalDC</sub>	DC-Voltage Oscillator			2.5		V	
t <sub>Startup</sub>	Oscillator Startup Time at VDD Slew-rate of 1 V/1 μs	XTAL_IN, XTAL_OUT		0.4	2	ms	
I <sub>SUP1A</sub>	First Supply Current (active) Analog Volume for Main and Aux at 0dB Analog Volume for Main and Aux at –30dB	AHVSUP	9.6 6.3	17.1 11.2	24.6 16.1	mA mA	
I <sub>SUP1S</sub>	First Supply Current (stby mode)		3.5	5.6	7.7	mA	STANDBYQ=low T <sub>j</sub> =27 °C
I <sub>SUP2A</sub>	Second Supply Current (active) MSP 34x7D version A1 MSP 34x7D version B2 and later	DVSUP	86 50	95 70	102 85	mA mA	
I <sub>SUP3A</sub>	Third Supply Current (active) MSP 34x7D version A1 MSP 34x7D version B2 and later	AVSUP	15 20	25 35	35 45	mA mA	
Digital Cont	trol Outputs						
V <sub>DCTROL</sub>	Digital Output Low Voltage	D_CTR_OUT0			0.4	V	I <sub>DCTR</sub> = 1 mA
V <sub>DCTROH</sub>	Digital Output High Voltage	C_CTR_OUT1	4.0			V	I <sub>DCTR</sub> = -1 mA
I <sup>2</sup> C Bus							
V <sub>I2COL</sub>	I <sup>2</sup> C-Data Output Low Voltage	I <sup>2</sup> C_DA			0.4	V	I <sub>I2COL</sub> = 3 mA
I <sub>I2COH</sub>	I <sup>2</sup> C-Data Output High Current				1.0	μΑ	V <sub>I2COH</sub> = 5 V
t <sub>l2COL1</sub>	I <sup>2</sup> C-Data Output Hold Time after Falling Edge of Clock	I <sup>2</sup> C_DA, I <sup>2</sup> C_CL	15			ns	
t <sub>12COL2</sub>	I <sup>2</sup> C-Data Output Setup Time before Rising Edge of Clock		100			ns	f <sub>I2C</sub> = 1 MHz
Analog Gro	und						
V <sub>AGNDC0</sub>	AGNDC Open Circuit Voltage	AGNDC	3.67	3.77	3.87	V	R <sub>load</sub> ≥10 MΩ
R <sub>outAGN</sub>	AGNDC Output Resistance		70	125	180	kΩ	3 V ≤ V <sub>AGNDC</sub> ≤ 4 V
Analog Inpu	ut Resistance		<u> </u>				
R <sub>inSC</sub>	SCART Input Resistance from T <sub>A</sub> = 0 to 70 °C	SC1_IN_s <sup>1)</sup>	25	40	58	kΩ	f <sub>signal</sub> = 1 kHz, I = 0.05 mA
R <sub>inMONO</sub>	MONO Input Resistance from T <sub>A</sub> = 0 to 70 °C	MONO_IN	15	24	35	kΩ	f <sub>signal</sub> = 1 kHz, I = 0.1 mA
Audio Analo	og-to-Digital-Converter						
V <sub>AICL</sub>	Effective Analog Input Clipping Level for A/D-Conversion	SC1_IN_s, <sup>1)</sup> MONO_IN	2.00		2.25	V <sub>RMS</sub>	f <sub>signal</sub> = 1 kHz
<sup>1)</sup> "s" mear	ns "L" or "R"						

Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit	Test Conditions
SCART Out	puts			•			
R <sub>outSC</sub>	SCART Output Resistance at T <sub>j</sub> = 27 °C from T <sub>A</sub> = 0 to 70 °C	SC1_OUT_s <sup>1)</sup>	200 200	330	460 500	Ω Ω	f <sub>signal</sub> = 1 kHz, I = 0.1 mA
dV <sub>OUTSC</sub>	Deviation of DC-Level at SCART Output from AGNDC Voltage		-70		+70	mV	
A <sub>SCtoSC</sub>	Gain from Analog Input to SCART Output	SC1_IN_s <sup>1)</sup> MONO_IN	-1.0		+0.5	dB	f <sub>signal</sub> = 1 kHz
f <sub>rSCtoSC</sub>	Frequency Response from Analog Input to SCART Output bandwidth: 0 to 20000 Hz	→ SC1_OUT_s <sup>1)</sup>	-0.5		+0.5	dB	with resp. to 1 kHz
V <sub>outSC</sub>	Effective Signal Level at SCART- Output during full-scale digital in- put signal from DSP	SC1_OUT_s <sup>1)</sup>	1.8	1.9	2.0	V <sub>RMS</sub>	f <sub>signal</sub> = 1 kHz
Main Outpu	ts			•			
R <sub>outMA</sub>	Main Output Resistance at $T_j = 27  ^{\circ}\text{C}$ from $T_A = 0$ to $70  ^{\circ}\text{C}$	DACM_s <sup>1</sup> )	2.1 2.1	3.3	4.6 5.0	kΩ kΩ	f <sub>signal</sub> = 1 kHz, I = 0.1 mA
V <sub>outDCMA</sub>	DC-Level at Main-Output for Analog Volume at 0 dB for Analog Volume at –30 dB		1.8	2.04 61	2.28	V mV	
V <sub>outMA</sub>	Effective Signal Level at Main-Out- put during full-scale digital input signal from DSP for Analog Vol- ume at 0 dB		1.23	1.37	1.51	V <sub>RMS</sub>	f <sub>signal</sub> = 1 kHz
Analog Perf	ormance		•	•		•	
SNR	Signal-to-Noise Ratio						
	from Analog Input to SCART Output	MONO_IN, SC1_IN_s <sup>1)</sup> → SC1_OUT_s <sup>1)</sup>	93	96		dB	Input Level = -20 dB, f <sub>sig</sub> = 1 kHz, equally weighted 20 Hz20 kHz
THD	Total Harmonic Distortion						
	from Analog Input to SCART Output	MONO_IN, SC1_IN_s <sup>1)</sup> $\rightarrow$ SC1_OUT_s <sup>1)</sup>		0.01	0.03	%	Input Level = -3 dBr, f <sub>sig</sub> = 1 kHz, equally weighted 20 Hz20 kHz
XTALK	Crosstalk attenuation		<u> </u>	<u> </u>	<u> </u>	<u> </u>	Input Level = $-3$ dB, $f_{sig}$ = 1 kHz, unused analog inputs connected to ground by Z < 1 k $\Omega$
	between left and right channel withi SCART Input/Output pair (L→R, R-						equally weighted 20 Hz20 kHz
	SC1_IN → SC1_OUT		80			dB	
1) "s" mear	s "L" or "R"						


Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit	Test Conditions
PSRR: reject	tion of noise on AHVSUP at 1 kHz0						
PSSR	AGNDC	AGNDC		80		dB	
	From Analog Input to SCART Output	MONO_IN, SC1_IN_s <sup>1)</sup> SC1_OUT_s <sup>1)</sup>		70		dB	
S/N <sub>FM</sub>	FM Input to Main/SCART Output	DACp_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	73			dB	1 FM-carrier 5.5 MHz, 50 μs, 1 kHz, 40 kHz de- viation; RMS, unweighted 0 to 15 kHz (for S/N);
THD <sub>FM</sub>	Total Harmonic Distortion + Noise of FM demodulated signal on Main/SCART output	DACp_s,1) SC1_OUT_s1)			0.1	%	full input range, FM-Prescale = 46h, Vol = 0 dB  → Output Level 1 Vrms at DACp_s; SPM = 3
S/N <sub>NICAM</sub>	Signal to Noise ratio of NICAM baseband signal on Main/SCART outputs	DACp_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	72			dB	NICAM: -6 dB, 1 kHz, RMS unweighted 0 to 15 kHz, NICAM-Pres- cale = 7Fh, Vol = 9 dB Output level 1 V <sub>RMS</sub> at DACp_s; SPM = 8
THD <sub>NICAM</sub>	Total Harmonic Distortion + Noise of NICAM baseband signal on Main/SCART output	DACp_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>			0.1	%	2.12 kHz, Modulator input level = 0 dBref SPM = 8
BER <sub>NI</sub>	NICAM: Bit Error Rate	_			1	10 <sup>-7</sup>	FM + NICAM, norm conditions
S/N <sub>AM</sub>	Signal to Noise ratio of AM base- band signal on Main/SCART out- puts	DACp_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	48			dB	SIF input range: 0.1–0.8 Vpp; AM = 70%, 1 kHz, RMS unweighted (S/N); 0 to 15 kHz,
THD <sub>AM</sub>	Total Harmonic Distortion + Noise of AM demodulated signal on Main/SCART output	DACp_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>			0.3	%	FM/AM-Presc. = 3Chex, Vol = 0dB → Output lev- el: 0.5 V <sub>RMS</sub> at DACp_s AM+NICAM, norm condi- tions; SPM = 9
R <sub>IFIN</sub>	Input Impedance	ANA_IN1+, ANA_IN–	1.5 10.5	2 14.1	2.5 17.6	kΩ kΩ	Gain AGC = 20 dB Gain AGC = 3 dB
DC <sub>VREFTOP</sub>	DC voltage at VREFTOP	VREFTOP	2.4	2.6	2.7	V	
DC <sub>ANA_IN</sub>	DC voltage on IF inputs	ANA_IN1+, ANA_IN–	1.3	1.5	1.7	V	
XTALK <sub>IF</sub>	Crosstalk attenuation	ANA_IN1+,	40			dB	f <sub>signal</sub> = 1 MHz
BW <sub>IF</sub>	3 dB Bandwidth	ANA_IN-	10			MHz	Input Level = −2 dBr
AGC	AGC Step Width			0.85		dB	
dV <sub>FMOUT</sub>	Tolerance of output voltage of FM demodulated signal	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	-1.5		+1.5	dB	1 FM-carrier, 50 μs, 1 kHz 40 kHz deviation; RMS
dV- NICAMOUT	Tolerance of output voltage of NICAM baseband signal	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	-1.5		+1.5	dB	2.12 kHz, Modulator input level = 0 dBref

<sup>1) &</sup>quot;s" means "L" or "R" "p" means "Loudspeaker (Main)" or "Headphone (AUX)" SPM : Short Programming Mode

Symbol	Parameter	Pin Name	Min.	Тур.	Max.	Unit	Test Conditions
fR <sub>FM</sub>	FM Frequency Response on Main/ SCART Outputs, Bandwidth 20 to 15000 Hz	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	-1.0		+1.0	dB	1 FM-carrier 5.5 MHz, 50 μs, Modulator input level = -14.6 dBref; RMS
fR <sub>NICAM</sub>	NICAM Frequency Response on Main/SCART Outputs, Bandwidth 20 to 15000 Hz	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	-1.0		+1.0	dB	Modulator input level = -12 dB dBref; RMS
SEP <sub>FM</sub>	FM Channel Separation (Stereo)	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	50			dB	2 FM-carriers 5.5/5.74 MHz, 50 μs, 1 kHz, 40 kHz deviation; RMS
SEP <sub>NICAM</sub>	NICAM Channel Separation (Stereo)	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	80			dB	
XTALK <sub>FM</sub>	FM Crosstalk Attenuation (Dual)	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	80			dB	2 FM-carriers 5.5/5.74 MHz, 50 μs, 1 kHz, 40 kHz deviation; RMS
XTALK- NICAM	NICAM Crosstalk Attenuation (Dual)	DACM_s, <sup>1)</sup> SC1_OUT_s <sup>1)</sup>	80			dB	

<sup>1) &</sup>quot;s" means "L" or "R"

## 9. Application Circuit



Note: Pin numbers refer to the PSDIP52 package, numbers in brackets refer to the PMQFP44 package.

## **Application Note:**

All ground pins should be connected to one low-resistive ground plane.

All supply pins should be connected separately with short and low-resistive lines to the power supply.

Decoupling capacitors from DVSUP to DVSS, AVSUP to AVSS, and AHVSUP to AHVSS are recommended as closely as possible to these pins. Decoupling of DVSUP and DVSS is most important. We recommend using more than one capacitor. By choosing different values, the frequency range of active decoupling can be extended. In our application boards we use: 220 pF, 470 pF, 1.5 nF, and 10  $\mu F$ . The capacitor with the lowest value should be placed nearest to the DVSUP and DVSS pins.

#### 10. Appendix A: MSP 34x7D Version History

#### **A1**

First hardware release MSP 3407D and MSP 3417D

#### **B2**

- digital input specification changed with version B2 and later versions (see Section 8.5.2. on page 49)
- supply currents changed as of version B2 and later (see Section 8.5.3. on page 52)
- max. analog high supply voltage AHVSUP 8.7 V

#### 11. Data Sheet History

- 1. Preliminary Data Sheet: "MSP 3407D, MSP 3417D Multistandard Sound Processors", Dec. 3, 1998, 6251-486-1PD. First release of the preliminary data sheet.
- Preliminary Data Sheet: "MSP 3407D, MSP 3417D Multistandard Sound Processors", Jan. 20, 2000, 6251-486-2PD. Second release of the preliminary data sheet. Major changes:
- specification for version B2 added
- Section 8.1.: Outline Dimensions for all packages changed

Micronas GmbH Hans-Bunte-Strasse 19 D-79108 Freiburg (Germany) P.O. Box 840 D-79008 Freiburg (Germany) Tel. +49-761-517-0 Fax +49-761-517-2174 E-mail: docservice@micronas.com Internet: www.micronas.com

Printed in Germany Order No. 6251-486-2PD All information and data contained in this data sheet are without any commitment, are not to be considered as an offer for conclusion of a contract, nor shall they be construed as to create any liability. Any new issue of this data sheet invalidates previous issues. Product availability and delivery are exclusively subject to our respective order confirmation form; the same applies to orders based on development samples delivered. By this publication, Micronas GmbH does not assume responsibility for patent infringements or other rights of third parties which may result from its use.

Further, Micronas GmbH reserves the right to revise this publication and to make changes to its content, at any time, without obligation to notify any person or entity of such revisions or changes.

No part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the express written consent of Micronas GmbH.