


POWER FACTOR CONTROLLER

—SIDE VIEW—

**INPUT**

OCp	: OVER CURRENT PROTECTION
OVP	: OVER VOLTAGE PROTECTION
REMOTE	: SWD ON/OFF CONTROL
SENSE1, SENSE2	: CURRENT COMPARATOR
V ADJ	: OUTPUT VOLTAGE CONTROL RESISTOR
V OUT SENSE	: OUTPUT VOLTAGE DETECT
V SENSE	: MULTIPLIER

OUTPUT

SWD	: SWITCHING ELEMENT DRIVING
-----	-----------------------------