


OCTAL DRIVER

—TOP VIEW—



01- 08 : OUTPUTS

I1 - I8 : INPUTS

