


C-MOS CPU FREQUENCY GENERATOR

—TOP VIEW—

**INPUT**

FS0 : FREQUENCY SELECTION INPUT

FS1 : FREQUENCY SELECTION INPUT, LSB

X1/ICLK : CRYSTAL CONNECTION / EXTERNAL CLOCK FREQUENCY INPUT

OUTPUT

CPUCLK : CLOCK OUTPUT

REFCLK : REFERENCE CLOCK OUTPUT

X2 : CRYSTAL CONNECTION

