


FENDER "BASS-MAN" LAYOUT

A-EE

NOTICE

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLTMETER.
VALUES SHOWN + OR - 20 %



FENDER "BASSMAN" SCHEMATIC
MODEL 5E6

A-EE

