Manual Supplement

Manual Title:	83,85,87 Service	Supplement Issue:	2
Part Number:	617826	Issue Date:	2/01
Print Date: Revision/Date:	January 1997	Page Count:	1

This supplement contains information necessary to ensure the accuracy of the above manual. Enter the corrections in the manual if either one of the following conditions exist:

- 1. The revision letter stamped on the indicated PCA is equal to or higher than that given with each change.
- 2. No revision letter is indicated at the beginning of the change.



Change #1

On pages 4-5, 4-11, and 4-17, add \triangle to F1 and F2, add the following footnote to the bottom of the table:

 \triangle To ensure safety, use exact replacement only.

On page 4-6, 4-12, and 4-18, add Λ near the callouts for F1 and F2.

Change #2

On page 3-11, Table 3-5, step 1, Display Reading:

From: 999.80 - 01000.2

To: 999.8 - 1000.2

On page 3-13, Table 3-9, Display Reading, change all three entries,

Step 2 From: 0.463 to 0.477

To: 0.462 to 0.478

Step 3 From: 0.0463 to 0.0477

To: 0.0462 to 0.0478

On page 3-14, Table 3-11, change AC Current for step 6,

From: 35.0 μA

Το: 3500 μΑ