0128



# **MAINTENANCE MANUAL**

FOR MODELS HTR 1005B-1S HTR 1005B-1ES HTR 1005B-1JS

HUNTRON INSTRUMENTS, INC. • 15123 Hwy. 99 North • Lynnwood, WA 98037 • (800)426-9265 • (206)743-3171 • Telex 152951

HUNTRON®

## TABLE OF CONTENTS

SPECIFICATIONS	2
----------------	---

CENEDAL	TION	į
GENERAL	1 ION	,

THEORY OF OPERATION	5
The Test Signal	
Testing Reactive Components	

#### CIRCUIT DESCRIPTION

Signal Section	10
Oscillator	12
Power Supply	
Cathode Ray Tube Circuit	

	ITERNAL SET UP AND ADJUSTMENTS	7
--	--------------------------------	---

#### TROUBLE SHOOTING

General Information	19
Power Supply	. 19
Signal Section	
CRT Section	. 24
Oscillator Section	
••••	

LIST OF REPLACEMENT PARTS
---------------------------

## 

© COPYRIGHT 1983 - HUNTRON® INSTRUMENTS, INC.

# HTR 1005B-1S, B-1ES, B-1JS

The information contained herein is the exclusive property of Huntron® Instruments, Inc. (except as otherwise indicated) and shall not be reproduced in whole or in part without written authorization from the company.

All information contained in this manual is the latest product information available at the time of printing. Huntron® Instruments, Inc. reserves the right to make changes at any time without notice.

## HUNTRON TRACKER® SPECIFICATIONS

POWER REQUIREMENTS:

HTR 1005B-1S	117VAC	60Hz
HTR 1005B-1ES	220/240VAC	50/60Hz
HTR 1005B-1JS	100VAC	50/60Hz

10 Watts Maximum

SIZE:

Width	3½ Inch
WEIGHT	pounds 5 oz.

AMBIENT TEMPERATURE:

Operating	50 deg C
Storage	60 deg C

#### SHOCK AND VIBRATION:

Will withstand shock and vibration encountered in commercial shipping and handling.

## TEST SIGNAL DATA:

All ratings, except P-P voltages, are conditions existing across a single silicon diode in the test terminals of the  $\mbox{TRACKER}^{\mbox{\tiny \ensuremath{\$}}}$  .

RANGE	OPEN-CIRCUIT	SHORT-CIRCUIT	POWER	POWER	SHORT-CIRCUIT
	P-P VOLTAGE	CURRENT	mW	mW	CURRENT
	VOLT	mA R.M.S.	R.M.S.	PEAK	mA PEAK
HIGH	120	0.29	0.26	0.52	0.8
MED.	40	0.27	0.23	0.45	0.7
LOW	20	64	81	161	170

#### TRACE COMPARISON MODE:

ALTERNATE MODE alternates display between two inputs at 0.8 Hz for Good/Bad comparison.

PROTECTION CIRCUIT:

The **HUNTRON TRACKER®** provides protection against damage caused by touching probes with line circuits.

WARNING . . . THE SYSTEM TO BE CHECKED MUST HAVE POWER TURNED OFF, AND HAVE HIGH VOLTAGE CAPACITORS DISCHARGED.

## GENERAL DESCRIPTION

The **HUNTRON TRACKER**<sup>®</sup> is a special type of CRT display and signal processing instrument that can be used to determine the quality of certain types of electronic components.

Components are tested with a two terminal system of test leads that are placed across the component under test. The test leads are inserted into the **TRACKER**<sup>®</sup> front panel. The **TRACKER**<sup>®</sup> is used to test components in a power-off condition, and can be used to test components mounted on printed circuit boards or other in-circuit conditions even with components bridged by various types of resistive values.

Devices that are normally tested by the **TRACKER**<sup>®</sup> include the following: semiconductor diodes, bipolar transistors, and field effect transistors; bipolar and MOS integrated circuits, including both analog and digital; certain types of capacitors and inductors.

Included as standard equipment with each **TRACKER**<sup>®</sup> is a set of **HUNTRON**<sup>®</sup> **MICRO PROBES**<sup>™</sup>. The **MICRO PROBE**<sup>™</sup> leads plug into the front panel test jacks. **MICRO PROBES**<sup>™</sup> have special tips so that they can be used to contact very small component terminals and small PCB etchings without the danger of shorting adjacent terminals and leads. Also included as standard equipment is a common test lead which is used with the **TRACKER**<sup>®</sup> in the "Compara-trace" mode (see **Figure 2**).

#### FRONT PANEL CONTROLS AND INDICATORS (Refer to Figure 1)

#### **DISPLAY CONTROLS:**

BRIGHT	. Controls the intensity of CRT display
VERT	. Controls the vertical position of CRT display
HORIZ	Controls the horizontal position of CRT display

#### **RANGE SELECTOR SWITCH:**

Three interlocking pushbutton switches select one of three ranges characterized below.

HIGH	Selects 120 V P-P sine wave test signal
MED	Selects 40 V P-P sine wave test signal
LOW	Selects 20 V P-P sine wave test signal

#### CHANNEL SELECT SWITCH:

Three position switch that selects the channel displayed. Top position selects CHANNEL A. Center position selects ALTERNATE MODE. Bottom position selects CHANNEL B. (ALTERNATE MODE alternates display between two inputs at 0.8 Hz for Good/Bad comparison.)

ON/OFF SWITCH	. 2-position pushbotton that turns the <b>TRACKER</b> <sup>®</sup> ON or OFF
	. CHANNEL A INPUT . CHANNEL B INPUT



The **HUNTRON TRACKER**<sup>®</sup> can alternate automatically between the displays of CHANNEL A and CHANNEL B inputs. This allows the user to directly compare the display of the suspect circuit to that of a known good circuit for QA or troubleshooting. **Figure 2** shows how a **TRACKER**<sup>®</sup> can be used to compare a known good board with a board under test.



COMPARING A KNOWN GOOD BOARD WITH A BOARD UNDER TEST



#### THEORY OF OPERATION

The **HUNTRON TRACKER**<sup>®</sup> applies a test signal across two terminals of the device being tested. This test signal causes a current to flow through the device and a voltage drop across its terminals.

The current flow is processed in such a way as to cause a vertical deflection of the scope trace, while the voltage across the test component causes a horizontal deflection of the scope trace.

#### THE TEST SIGNAL

This signal is an 80 Hz sine wave that alternately applies positive and negative voltages across the component being tested.

In an open circuit condition the positive half cycle generates the left side trace on the CRT, and the right side trace comes from negative half cycle. The 80 Hz test signal is generated on the Oscillator Board and presented at the front panel test terminals through a signal transformer. The transformer has the dual purpose of adjusting the test voltage level for the various ranges and selecting the impedance level of the various ranges.

The test signal, as presented at the front panel, electrically appears as though it is being originated by a voltage generator with a series output impedance. The open circuit voltage and generator impedance are both different for all three ranges.

**Figure 3** shows the electrical equivalent of the generator section and how the voltage across the terminals affects the horizontal and vertical deflection plates of the CRT. Shown is the symbolic representation of a voltage generator (GEN) with a series internal impedance (Z<sub>gen)</sub> and a current sensing point (I). Across these network elements are two test points A and COM.



An open circuit (such as that shown in **Figure 3**) has zero current flowing through the test leads and has maximum voltage across the test leads. In the HIGH and MEDIUM ranges this is represented by a straight horizontal trace from the maximum left to the maximum right of the CRT. In the LOW range, an open circuit condition is shown as a diagonal trace from the upper right to the lower left corner of the CRT. **Figure** 4a shows scope traces in HIGH, MEDIUM and LOW ranges.

When the test leads are shorted, maximum current flows in the leads and there is zero voltage across the lead. This is indicated by a vertical trace from the top to the bottom of the CRT on all ranges (see **Figure 4b**).



A pure resistance across the test leads would create both current flow in and voltage drop across the resistance which would appear on the CRT as a deflected straight trace. The HIGH and MEDIUM ranges would have the trace deflected clockwise around the center of the CRT from the horizontal position (open circuit), while the LOW range would have the trace deflected clockwise from the open circuit diagonal position. On all ranges the length of the trace is reduced because of the internal voltage drop across Z gen caused by the resistor load and the trace is rotated toward a more vertical position because of the increased current through the load. The amount of trace reduction and rotation depends upon the test resistance value and the range chosen for the test.

Since a pure resistance is a linear electrical element, the resulting trace will always be a straight line. Non-linear electrical elements that are not reactive do not give a straight line over the entire trace length. **Figure 5** shows the trace with a 33 kohm resistor across the test leads in the MEDIUM range. The resistor causes the horizontal deflection voltage to be reduced because of the current flow through the resistor. The vertical deflection voltage is proportional to the current flow and the resulting pattern is a clockwise rotated trace that is shorter than the open circuit trace. The peak current through the resistor is 320 microamps. The actual short circuit peak current is 730 microamps. The generator impedance in the HIGH range is 75 kohms, in the MEDIUM range is 27 kohms, and in the LOW range is 56 ohms.



RANGE=MEDIUM TEST= 33K RESISTOR

F1G. 5

A non-linear component such as a silicon diode would allow a large current to flow during the half cycle when it is forward biased and very little current to flow during the reverse biased half cycle. The voltage drop across the forward biased junction would be small (i.e. 0.7 V.), and this would appear as a near short causing a vertical trace to appear during that portion of the cycle. The reverse biased condition would cause very little current to flow and would look like an open circuit trace on the CRT.

Figure 6a shows a silicon diode junction being observed with the **TRACKER**<sup>®</sup> in the LOW range, while Figure 6b shows traces in HIGH and MEDIUM ranges.



**Figure 7** shows a 33 kohm resistor being shunted by a silicon diode. During the first half of the test signal the junction is forward biased and appears as a near short circuit to the test signal resulting in the vertical trace shown in the second quadrant of **Figure 7**. Then the test signal reverses polarity during the second half cycle and the diode becomes reverse biased. The reverse biased resistance of the diode is much greater than the 33 kohm resistance, so essentially all of the current flows through the 33 kohm resistor creating the CRT pattern shown in the fourth quadrant of **Figure 7**.



RANGE- MEDIUM TEST- 33K RESISTOR AND DIODE IN PARALLEL

**Figure 8** shows a silicon diode shunted by a 10 ohm resistor with the LOW range selected. During the first half of the cycle the junction is forward biased and in parallel with the 10 ohm resistor. The combined currents of the two devices in parallel is very high and causes a near vertical trace on the CRT.

A vertical line represents a short circuit (zero voltage drop) condition, and, since the junction does not have appreciable conduction until a forward voltage of approximately 0.7 Volts is generated, the vertical trace is displaced to the left by this amount. This is shown as the straight vertical portion of the trace in the second quadrant of **Figure 8**.

In the reverse direction the diode is essentially out of the circuit and all of the current flows through the resistor. This causes the trace in the fourth quadrant and part of the second quadrant of **Figure 8**.



TEST- IOA RESISTOR AND DIODE IN PARALLEL

F1G. 8

## **TESTING REACTIVE COMPONENTS**

**Figure 9** shows the trace from a 1uF capacitor in the MEDIUM range. The reactance of the capacitor is approximately 2 kohm at 80 Hz. This is appreciably less than the generator impedance of 27 kohm and causes a relatively high current flow with a fairly low voltage drop. Also, since the generator is resistive and the test component is reactive, the current (vertical) is 90 degrees out of phase with the voltage (horizontal). The above signal amplitudes when combined with this phase shift result in the display of a narrow vertical ellipse on the CRT.



When the vertical and horizontal signal amplitudes are equal and the current-voltage phase shift is 90 degrees, the result is a circular trace. In MEDIUM range this occurs when a 0.13uF capacitor is placed across the input terminals as shown in **Figure 10**.



RANGE- MEDIUM TEST-.I3uF CAPACITOR

**Figure 11** shows the CRT pattern that results from shunting a 0.13uF capacitor with a 20 kohm resistor in the MEDIUM range. The resistor across the capacitor alters the current-voltage phase angle in such a way that the circle narrows to an ellipse and there is a counterclockwise rotation of the ellipse from the vertical axis.

FIG 10



RANGE = MEDIUM TEST = .13uf CAPACITOR AND 20K RESISTOR IN PARALLEL

FIG.II

## CIRCUIT DESCRIPTION

#### SIGNAL SECTION:

Figure 12 is a basic circuit representation of the signal section of the  $TRACKER^{\circ}$ . The circuit is shown with a test diode in place.





During the half cycle portion when the horizontal side of the secondary is negative, the test diode is reverse biased so that very little current flows through the transformer secondary and resistor R8. The vertical end of the secondary is very close to ground potential because of R8, and a very small voltage appears on the vertical lead.

Since the impedance across the horizontal side of the secondary is very high relative to that appearing on the vertical side, most of the secondary voltage will appear on the horizontal side.

During the next half cycle the horizontal side will go positive and the test diode will clamp at approximately .7 Volt. Also current will flow through R8 creating a large voltage at the vertical side of the secondary. The voltage that appears across R8 is a direct representation of the current that flows through the test diode.

**Figure 13** is a more detailed circuit description with the HIGH range selected. R4 provides for a phase angle correction when the test points are shorted and compensates for CRT distortion.



R16 is the horizontal phase correction and compensates for the impedance of R21 going into the horizontal amplifier as well as CRT distortion. Referring back to **Figure 12**, it was shown that maximum voltage appears at the horizontal end of the secondary only when there is infinite impedance presented by R21 and IC1. R16 corrects for this difference.

Referring to **Figure 13**, R15 and R22 are the vertical and horizontal gain adjustments respectively. Transistors Q1, Q2, Q3, and associated components form the vertical amplifier, while Q4, Q5, Q6, and associated components form the horizontal amplifier. These amplifiers are temperature compensated to avoid drifting.

A positive or negative going signal at point  $\begin{pmatrix} 1 \\ \end{pmatrix}$  will be amplified, phase corrected, and placed on the vertical deflection plate of the CRT. A positive or negative signal at point (2) will be amplified, phase corrected, and placed on the horizontal deflection plate.

Vertical and horizontal positions are controlled by a variable DC voltage on the bases of transistors Q2 and Q5 respectively.

Signal transformer TR1 is designed to close tolerances so as to provide the proper secondary voltage and impedance levels.

#### OSCILLATOR:

Refer to **Figure 16** for schematic. The oscillator is a 2½ inch by 4 inch PCB module which plugs into a socket on the main PCB. It provides an 80 Hz sine wave test signal which has an output amplitude that is factory adjusted to 10 volts peak-to-peak. For adjustment details, see the section on Internal Set-Up and Adjustments.

#### POWER SUPPLY

Refer to Figure 14 for schematic, and Figure 15 for component layout.

The power supply section provides various operating voltages:

- -1350 Volt Regulated High Voltage.
   D3, D4, C9, C10, C11, C12, R46, R47, R48, and R49 form a voltage doubler; Q7 and IC2 provide linear voltage regulation. For adjustment details see Internal Set-Up and Adjustments Section.
- + 180 Volt Unregulated Deflection Voltage.
   Diodes D5, D6, D7, and D8 form a full wave bridge rectifier, and C14 is the filter capacitor.
   Bleeder resistor R57 discharges voltage in C14 to a safe level within 60 seconds after power is turned off.
- +6/-6 Volt Regulated Voltage.
   Diode D9, D10, D11, and D12 form a bridge rectifier; IC3 and IC4 provide regulation for +6 Volt and -6 Volt respectively.
- 6.3 Volt Filament Voltage.
   The power transformer supplies this voltage to the filament of the CRT.

Switch SR5 sets up power transformer TR2 for 220 Volt or 240 Volt environments in the European Economic Community.

#### CATHODE RAY TUBE CIRCUIT:

The CRT is a 7 cm diagonal, green phosphor, electrostatic type.

The high voltage is adjusted to -1350 Volts for normal operation.

INTENSITY ADJUST:	R40 is the CATHODE VOLTAGE CONTROL and controls CRT intensity via a front panel knob (BRIGHT). The cathode voltage can be adjusted from -1235 Volts to -1336 Volts.
FOCUS ADJUST:	R39 is the FOCUS CONTROL and has a voltage range of -1033 Volts to -1235 Volts.

ASTIGMATISM: R37 adjusts for astigmatism and has a voltage range of -22 Volts to + 180 Volts.

#### FRONT PANEL CONTROLS:

Refer to **Figure 18** for schematic. R1 and R2 control the vertical and horizontal CRT trace positions respectively.

The changes in trace positions are accomplished by varying the base voltages of transistors Q2 and Q5 in the differential amplifiers.

Switch SW6 selects the display of either Input A or Input B or alternating between display A and B.





Parts Location F1G.15





FIG. 17 Oscillator Parts Location



Adjustment Location FIG 20

## INTERNAL SET-UP AND ADJUSTMENTS

#### Refer to Figure 14 and Figure 20.

#### (A) **POWER SUPPLY SECTION:**

The High Voltage is factory adjusted to -1350 Volts, and **TRACKER**<sup>®</sup> users are advised not to re-adjust trim pot R51 unless it is absolutely necessary. The adjustment requires a digital voltmeter and a high voltage probe.

WARNING: HAZARDOUS HIGH VOLTAGE.

#### STEP-BY-STEP ADJUSTMENTS:

- (1) B-1ES models only set SW5. Factory set for 240V operation. Refer to Figure 20.
- (2) Connect probe common to ground point of main PCB.
- (3) Connect High Voltage Probe to Test Pin.
- (4) Turn power on.
- (5) Turn R51 until voltmeter reads -1350 Volts.

#### (B) OSCILLATOR SECTION:

Refer to Figure 16 and Figure 17. Trackers are factory adjusted to 80 Hz.

#### **STEP-BY-STEP ADJUSTMENTS:**

- (1) Turn power on.
- (2) Connect frequency counter to point 2.
- (3) Turn trim pot R15 fully clockwise.
- (4) Adjust R1 until frequency counter reads 80 Hz.
- (5) Adjust R15 until Oscillator output at  $\triangle$  is 10 Volts peak to peak.

#### (C) SIGNAL SECTION:

Refer to Figure 20 for main PCB Alignment drawing.

#### STEP-BY-STEP ADJUSTMENTS:

- (1) Turn all trim pots (R2, R3, R4, R7, R15, R16, R19, and R22) to their fully counterclockwise position.
- (2) Turn Horizontal and Vertical controls to the center of their range.
- (3) Turn front panel BRIGHT control fully counterclockwise.
- (4) Turn power on.
- (5) Set front panel switch to the HIGH range position.
- (6) Adjust intensity until a spot appears on the CRT.
- (7) Adjust Master Vertical Gain (R15) for vertical deflection of approximately 1/2 inch.
- (8) Adjust Focus (R39), and Astigmatism (R37) for sharpest trace. Check intensity for correct brightness.
- (9) Adjust Master Horizontal Tilt (R16) to the center of its range.
- (10) Adjust Master Horizontal Gain (R22) until trace fills out graticule.

- (11) Short Test Terminals.
- (12) Adjust Master Vertical Gain (R15) until vertical trace is 1-3/8 inch long.
- (13) Adjust HIGH Vertical Tilt (R4) until there is no vertical tilt.
- (14) Re-adjust Master Vertical Gain (R15) if necessary.
- (15) Remove Test Terminal short.
- (16) Adjust Master Horizontal Tilt (R16) until the horizontal trace has no tilt.
- (17) Switch to MEDIUM range position.
- (18) Short Test Terminals.
- (19) Adjust MEDIUM range Vertical Tilt (R3) until the trace has no vertical tilt.
- (20) Remove Test Terminal short.
- (21) Adjust MEDIUM Horizontal Tilt (R7) until the trace has no tilt.
- (22) Switch back and forth between HIGH and MED range, and observe the trace. It should have no horizontal tilt on either range, and the ends of the trace should be very close to the graticule, but not out of view. Both traces should be within 5% of each other in length.
- (23) Short Test Terminals, and switch back and forth between HIGH and MED ranges. Both vertical traces should be within 5% of each other in length.
- (24) Install a diode across the Test Terminals. You should see a trace as displayed in **Figure 21a.**
- (25) Final adjustments can be made on Horizontal and Vertical Gain, and Horizontal and Vertical Tilt for correct trace. The trace length difference should be less than 5%. The vertical and horizontal traces should have no tilt. Edge of trace should not go off screen.
- (26) Switch to the LOW range.
- (27) Short Test Terminals and adjust LOW range Vertical Tilt (R2).
- (28) Remove short from Test Terminals, and adjust LOW range Horizontal Gain (R19) so that trace looks like **Figure 21b**.
- (29) Insert Diode at Test Terminals.
- (30) Trace should look like Figure 21c.
- (31) Final focus and astigmatism adjustment can be made with diode in test terminals, and the range switch in HIGH or MEDIUM position.





## TROUBLESHOOTING

#### GENERAL INFORMATION

A defective **TRACKER**<sup>®</sup> should always receive a very careful visual inspection prior to any expensive symptomatic troubleshooting.

Burned components, fuses or darkened areas on the printed circuit boards indicate that excessive heat has been generated, and this is usually a pretty good clue that a component in the affected area is defective.

If a visual inspection on both sides of the printed circuit board fails to indicate an obvious problem, then proceed by power on testing for the following voltages. Refer to **Figure 14** for the main **TRACKER**<sup>®</sup> schematic.

(A) Check power transformer secondary winding AC Voltages.

WINDING	N3	VOLTAGES (Vrms)	6.1
	N4		11.1
	N5		11.1
	N6		138
	N7		570

The above readings correspond to nominal AC Input.

- (B) Check DC Voltages
  - (1) -1350 V Acceleration Voltage
  - (2)  $\pm$  6V Signal Voltage
  - (3) + 180 V Deflection Voltage

Any one of the above voltages listed in (A) and (B) should be within  $\pm 5\%$  tolerance. The source of a defective voltage should be located and corrected.

If the voltages as outlined above are all correct, then proceed with a complete check of the remaining voltages as shown on the main schematic and oscillator schematic.

A final check can be made with an oscilloscope to check the waveforms as shown by the triangular numbers on the main schematic. **Figure 22** and **Figure 23** list various waveforms appearing on the main PCB.

After a circuit correction has been made, refer to the section on INTERNAL SET-UP AND ADJUST-MENTS for proper CRT trace presentation.

The following symptomatic analysis will help isolate defective circuitry and locate specific defective components.

#### POWER SUPPLY

- SYMPTOM: DEAD UNIT: Front panel power indicator light not on when front panel power switch pushed in and power applied. No CRT trace.
- CONDITIONS: Test terminals open or shorted. All ranges.
- PROBABLE CAUSES: (a) Fuses F1 and F2 open.
  - (b) Power transformer TR2 defective.
  - (c) Power switch SW4 defective.
  - (d) Rectifiers D9, D10, D11 or D12 defective.
  - (e) Capacitors C15, C16, C17, C18, C19 or C20 shorted.
  - (f) Regulators IC3, IC4 defective.

F1G.22





WAVEFORM AT VARIOUS TEST POINTS ON MAIN PC BOARD TIME BASE: 5MS/DIV



SYMPTOM: DEAD UNIT: Front panel power indicator light on. No trace.

CONDITIONS: Test terminals open or shorted. All ranges.

PROBABLE CAUSES: (a) No high voltage -1350 volt.

- (b) Diode D3, D4, C9, C10, C11, C12 defective.
- (c) Transformer secondary winding N7 open.

SYMPTOM: Power indicator light on. Only a "dot" appears on CRT.

CONDITIONS: Test terminals open or shorted. All ranges.

PROBABLE CAUSES: (a) No plate deflection voltage.

- (b) D5, D6, D7, D8 defective.
- (c) C14 shorted.
- (d) Transformer secondary winding N6 open.

SYMPTOM: Acceleration voltage reads –1650 Volt, and adjusting trim pot R51 does not change voltage.

#### CONDITIONS: Test terminals open or shorted. All ranges.

- PROBABLE CAUSES:
- (a) Bad trim pot R51.
- (b) Defective IC2.
- (c) Defective transistor Q7.

#### SIGNAL SECTION

SYMPTOM: Dot in center of screen. No horizontal and vertical sweep.

CONDITIONS: Test terminals open or shorted. All ranges.

**PROBABLE CAUSES:** 

- AUSES: (a) No oscillator output (See oscillator section).
  - (b) Signal transformer TR1 defective.
  - (c)  $\pm$  6 Volt at Oscillator Module missing.
  - (d)  $\pm$  6 Volt plate deflection voltage missing.
- SYMPTOM: Dot in center of screen. No horizontal sweep.
- CONDITIONS: Test terminal open. HIGH and MED ranges.
- PROBABLE CAUSES: (a) IC1B defective.
  - (b) R22 shorted.

SYMPTOM:	Trace horizontally off screen. Trace off center of screen.
CONDITIONS:	Test terminals open or shorted. All ranges.
PROBABLE CAUSES:	<ul> <li>(a) Resistor R26, R33 changed value.</li> <li>(b) Q4, Q5, Q6, IC1B defective.</li> <li>(c) Resistor R43, R44 changed value.</li> <li>(d) Capacitors C4, C5 shorted.</li> </ul>
SYMPTOM:	Trace vertically off screen. Trace vertically off center of screen.
CONDITIONS:	Test terminals open or shorted. All ranges.
PROBABLE CAUSES:	<ul> <li>(a) Resistor R23, C29 changed value.</li> <li>(b) Q1, Q2, Q3, IC1A defective.</li> <li>(c) Resistor R43, R44 changed value.</li> <li>(d) Capacitors C4, C5 shorted.</li> </ul>
SYMPTOM:	Horizontal tilt trim pot does not change horizontal tilt.
CONDITIONS:	Open test terminals on HIGH and MED ranges.
PROBABLE CAUSES:	<ul> <li>(a) R12, R13, R14, R16, R17, R18 open.</li> <li>(b) Range select switch defective.</li> <li>(c) PCB etching open or shorted to ground.</li> </ul>
SYMPTOM:	Vertical tilt trim pot does not change vertical tilt.
CONDITIONS:	Test terminals shorted. The range that this condition occurs.
PROBABLE CAUSES:	<ul> <li>(a) Vertical tilt trim pot for the defective range open.</li> <li>(b) Broken wire on signal transformer.</li> </ul>
SYMPTOM:	Split trace.
CONDITIONS:	Open test terminals. All ranges.
PROBABLE CAUSES:	Signal transformer defective.
SYMPTOM:	Excessive motion at end of trace.
CONDITIONS:	Test terminals open or shorted. All ranges.
PROBABLE CAUSES:	<ul> <li>(a) Rectifier D9, D10, D11, D12 defective.</li> <li>(b) Filter capacitor C15, C16, C17, C18, C19, C20 defective.</li> <li>(c) ±6 Volt regulators defective.</li> <li>(d) Power line noise.</li> <li>(e) Power transformer defective.</li> <li>(f) TRACKER<sup>®</sup> in close proximity to high level 50 or 60 Hz transformer.</li> <li>(g) Line voltage drop to such a low level that it is out of high voltage regulation range.</li> </ul>

#### **CRT SECTION**

SYMPTOM:	Trace out of focus.	
CONDITIONS:	Test terminals open or shorted. All ranges.	
PROBABLE CAUSES:	<ul> <li>(a) R37, R38, R39, R40, R41 open or shorted.</li> <li>(b) C3 shorted.</li> <li>(c) -1350 Volt very low.</li> <li>(d) + 180 Volt very low.</li> <li>(e) CRT socket wires open or shorted.</li> </ul>	
SYMPTOM:	Intensity control has no effect.	
CONDITIONS:	Test terminals open or shorted. All ranges.	
PROBABLE CAUSES:	<ul> <li>(a) C3 shorted.</li> <li>(b) Intensity control pot R40 open.</li> <li>(c) -1350 Volt very low.</li> </ul>	
SYMPTOM:	No trace.	
CONDITIONS:	Test terminals open or shorted. All ranges.	
PROBABLE CAUSES:	<ul> <li>(a) + 180 Volt plate deflection missing.</li> <li>(b) -1350 acceleration voltage missing.</li> <li>(c) Filament voltage missing.</li> </ul>	
SYMPTOM:	Distorted Ellipse.	
CONDITIONS:	0.1 uF across test terminal on HIGH and MED range. 100 uF across test terminal on LOW range.	
PROBABLE CAUSES:	<ul> <li>(a) Line voltage low.</li> <li>(b) Distorted Oscillator output.</li> <li>(c) High voltage adjust trim pot R51 setting change.</li> </ul>	
OSCILLATOR SECTION	I	

Refer to Figure 16 and Figure 17.

SYMPTOM: No oscillator output.

CONDITIONS: Test terminals open or shorted. All ranges.

PROBABLE CAUSES: (a)  $\pm 6$  Volt missing.

- (a) ±6 Volt missing.
  (b) Transistor Q1, Q2, Q3, Q4 defective.
- (c) IC3 defective.

## LIST OF REPLACEMENT PARTS

This section contains a parts breakdown of the HTR 1005B-1S, B-1ES, B-1JS. Each component is designated alphanumerically, and can be referenced to assembly drawings or schematics.

#### HOW TO ORDER PARTS:

Components may be ordered directly from manufacturer by using manufacturer's part number, or from **HUNTRON® INSTRUMENTS, INC.,** or its authorized distributor, by **HUNTRON®** PART NUMBER.

For prompt and efficient handling of your order, please supply:

- 1. Model and Serial Number
- 2. Reference Designation
- 3. Part Description
- 4. HUNTRON<sup>®</sup> Part Number
- 5. Quantity

#### MAIN PCB ASSEMBLY:

(Refer to Figure 14 and Figure 15)

Unless otherwise specified:

All fixed resistors are 1/4W, 5%, carbon film

All resistor values are in ohms

REF. DES.	DESCRIPTION		HUNTRON® PART NO.
A1	Main PCB Assembly	117V	07-1031
A1	Main PCB Assembly	220V/240V	07-1032
A1	Main PCB Assembly	100V	07-1033
PCB1	Main PCB		07-7706
C1	Cap, Ceramic	0.001uF, 100V	03-3030
C2	Cap, Ceramic	0.001uF, 100V	03-3030
C3	Cap, Electrolytic	1.uF, 450V	03-3040
C4	Cap, Ceramic	0.001uF, 1400V	03-3023
C5	Cap, Ceramic	0.001uF, 1400V	03-3023
C6	Cap, Ceramic	0.02uF, 1000V	03-3004
C7	Cap, Electrolytic	1uF, 450V	03-3040
C8	Cap, Electrolytic	1uF, 450V	03-3040
C9	Cap, Electrolytic	1uF, 450V	03-3040
C10	Cap, Electrolytic	1uF, 450V	03-3040
C11	Cap, Electrolytic	1uF, 100V	03-3006
C12	Cap, Electrolytic	22uF, 250V	03-3043
C13	Cap, Electrolytic	1000uF, 16V	03-3024
C14	Cap, Electrolytic	1000uF, 16V	03-3024
C15	Cap, Tantalum	10uF, 25V	03-3011
C16	Cap, Tantalum	10uF, 25V	03-3011
C17	Cap, Electrolytic	2200uF, 6.3V	03-3045
C18	Cap, Electrolytic	2200uF, 6.3V	03-3045
C19	Cap, Ceramic	0.01uF, 2000V	03-3042

REF. DES.	DESCRIPTION		HUNTRON® PART NO.
D1 D2 D3 D4 D5 D6 D7 D8 D9 D10 D11	Diode, Signal Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier Diode, Rectifier	IN914 HV15F HV15F IN4005 IN4005 IN4005 IN4001 IN4001 IN4001 IN4001	04-4007 04-4010 04-4012 04-4012 04-4012 04-4012 04-4012 04-4006 04-4006 04-4006
F1	Fuse, 250V ¼ Amp AGX		02-2132
F2	Fuse, 250V ¼ Amp AGX		02-2132
F3	Fuse, 250V ¼ Amp AGX		02-2132
IC1	IC, Dual Op Amp	LM1458N	05-5012
IC2	IC, Op Amp	LM741CN	05-5009
IC3	IC, Pos. Reg., +6V	MC7806CT	05-5004
IC4	IC, Neg. Reg., -6V	MC7906CT	05-5005
J1	Jack		01-1070
L1	Line Cord, 110V/120V Line Cord, 220V/240V		01-1027 01-1049
MP1 MP2 MP3 MP4 (2) MP5 (2) MP6 (2) MP7 MP8 (6) MP9 MP10 MP11	Heat Sink Regulator Insulator Bushing Nylon Shoulder Screw, 4/40, 3/8 Inch Nut Hex, 4/40 Washer, Lock, Star, #4 Test Pin Fuse Clip Threaded Standoff 6-32 1 Screw, 6-32 3/8" Washer, Lock Star #6	"	07-7151 07-7084 07-7086 07-7087 07-7089 07-7153 02-2044 07-7156 07-7172 07-7171
PL1	Header, 6 Pin		07-7224
PL2	Header, Polarized, 12 Pin		07-7158
PL3	Header, Polarized, 12 Pin		07-7158
Q1	Transistor, NPN 300V	MPSA42	05-5003
Q2	Transistor, NPN 300V	MPSA42	05-5003
Q3	Transistor, NPN	PN2222	05-5013
Q4	Transistor, NPN 300V	MPSA42	05-5003
Q5	Transistor, NPN 300V	MPSA42	05-5003
Q6	Transistor, NPN	PN2222	05-5013
Q7	Transistor, NPN 400V	TIP 50	05-5016
R1	Resistor	6.8, 1W	02-2086
R2	Pot, Trimmer	5k	02-2090
R3	Pot, Trimmer	5k	02-2090
R4	Pot, Trimmer	5k	02-2090
R5	Resistor	220, ½W	02-2003
R6	Resistor	10, ½W	02-2077
R7	Pot, Trimmer	100k	02-2091

REF. DES.	DESCRIPTION		HUNTRON® PART NO.
R8	Res, Metal Film	86.6k, 1%	02-2136
R9	Res, Metal Film	42.2k, 1%	02-2122
R10	Res, Metal Film	681k, 1%	02-2123
R11	Res, Metal Film	1.96M, 1%	02-2150
R12	Thermistor	5k	02-2110
R13	Resistor	68k	02-2103
R14	Resistor	22k	02-2157
R15	Pot, Trimmer	50k	02-2085
R16	Pot, Trimmer	25k	02-2155
R17	Resistor	20K	02-2082
R18	Resistor	10k	02-2137
R19	Pot, Trimmer	500k	02-2058
R20	Res, Metal Film	196k, 1%	02-2153
R21	Resistor	590k, 1%	02-2154
R22	Pot, Trimmer	10k	02-2084
R23	Resistor	180k	02-2124
R24	Resistor	1k	02-2125
R25	Resistor	1.6k	02-2135
R26 R27	Resistor	180k 1k	02-2124
R28	Resistor Resistor	1.6k	02-2125 02-2135
R29	Resistor	180k	02-2135
R30	Resistor	1k	02-2125
R31	Resistor	180k	02-2124
R32	Resistor	1k	02-2125
R33	Resistor	16k	02-2134
R34	Resistor	3k	02-2126
R35	Pot, Trimmer, Cermet	1M	02-2070
R36	Res, High Voltage	5M, ½W	02-2088
R37	Pot, Trimmer, Cermet	1M	02-2070
R38	Pot, Control	500k	02-2095
R39 R40	Resistor Resistor	68k 4.7M	02-2103
R40 R41	Resistor	4.7 M	02-2127 02-2130
R42	Resistor	10M, ½W	02-2102
R43	Resistor	10M, ½W	02-2102
R44	Resistor	10M, 1/2 W	02-2102
R45	Resistor	10M, 1/2 W	02-2102
R46	Resistor	5M, 1⁄2 W	02-2088
R47	Pot, Trimmer	50k	02-2085
R48	Resistor	27K	02-2133
R49	Resistor	1k	02-2125
R50	Resistor	2.2M	02-2131
R51	Resistor	2.2k	02-2079
R52	Resistor	10k	02-2137
R53 R54	Resistor Resistor	200k 2.0M	02-2140 02-2129
		2.0141	
S01	Socket, 5 Pin		07-7149
SW1-SW4	Switch Assembly		07-7067
TB1	Terminal Block		07.7065
TR1	Transformer, Signal		06-6030
Z1	ZNR 130V ZNR 250V		02-2038 02-2061

# **OSCILLATOR PCB ASSEMBLY:**

# (Refer to Figure 16 and Figure 17)

Unless otherwise specified: All fixed resistors are 1/4W, 5%, carbon film All resistor values are in ohms

REF. DES.	DESCRIPTION		HUNTRON® PART NO.
A2	Oscillator PCB Assembly		07-1018
PCB2	Oscillator PCB		07-7730
C1 C2 C3 C4 C5 C6	Cap, Mylar Cap, Mylar Cap, Mylar Cap, Mylar Cap, Mylar Cap, Mylar	0.1uF, 250V, 5% 0.1uF, 250V, 5% 0.1uF, 250V, 5% 0.15uF, 250V, 5% 0.1uF, 250V, 5% 0.022uF, 250V, 5%	03-3026 03-3026 03-3026 03-3048 03-3026 03-3049
D1 D2 D3 D4 D5 D6	Diode, Signal Diode, Signal Diode, Signal Diode, Signal Diode, Signal Diode, Signal	IN914 IN914 IN914 IN914 IN914 IN914	04-4007 04-4007 04-4007 04-4007 04-4007 04-4007
IC1 IC2 IC3	IC, 2.5 Volt Ref. IC, 2.5 Volt Ref. IC, Dual Op Amp	LM336BZ-2.5 LM336BZ-2.5 LM1458N	05-5011 05-5011 05-5012
PL1	Header, 5 Pin		07-7152
Q1 Q2 Q3 Q4	Transistor, PNP, 300V Transistor, PNP, Power Transistor, NPN, 300V Transistor, NPN, Power	MPSA92 TIP 30 MPSA42 TIP 29	05-5015 05-5008 05-5003 05-5007
R1 R2 R3 R4 R5 R6 R7 R8 R9 R10 R11 R12 R13 R14 R15 R16 R17 R18 R19	Pot, Trimmer Resistor	10k 13k 68k 68k 120 2.2k 680 120 470 68 470 68 120 120 500 2.2k 680 10k 4.7k	02-2084 02-2160 02-2103 02-2103 02-2146 02-2079 02-2146 02-2098 02-2148 02-2098 02-2148 02-2148 02-2148 02-2147 02-2147 02-2079 02-2100 02-2137 02-2145

## FRONT PANEL CONTROL PCB ASSEMBLY:

#### (Refer to Figure 18 and Figure 19)

Unless otherwise specified: All fixed resistors are ¼W, 5%, carbon film All resistor values are in ohms

REF. DES.	DESCRIPTION		HUNTRON® PART NO.
A3	Control PCB Assembly		07-1034
PCB3	Control PCB		07-7707
C1 C2 C3	Cap, Mylar Cap, Electrolytic Cap, Electrolytic	0.1uF, 250V 47uF, 6.3V 47uF, 6.3V	03-3036 03-3041 03-3041
D1 D2 D3 D4	Diode, LED, Green Diode, LED, Red Diode Signal Diode, Signal	XC209G XC209R 1N914 1N914	04-4009 04-4000 04-4007 04-4007
IC1	IC, Timer	NE555	05-5006
MP1	Bushing		01-1059
R1 R2 R3 R4 R5 R6 R7 R8 R9 R10 RY1	Pot, Control Pot, Control Res Res Res Res Res Res Resistor Resistor Resistor	1K 1k 15k 470 470 10k 10M 470 1.8k 1.8k 835C-3 (Gordos)	02-2149 02-2149 02-2151 02-2098 02-2098 02-2137 02-2152 02-2098 02-2128 02-2128 02-2128
SO1	Socket, 6 Pin		07-7225

# FRONT PANEL ASSEMBLY:

(Refer to Figure 24)

REF. DES.	DESCRIPTION		HUNTRON® PART NO.
A3	Control PCB Assembly		07-1034
D3	Diode, LED, Green	XC209G	04-4009
J1 J2 J3	Banana Jack, Red Banana Jack, Black Banana Jack, Yellow		01-1030 01-1031 01-1032
K1 K2 K3	Knob Knob Knob		01-1060 01-1060 01-1060
MP1 MP2 MP3 MP4 MP5 MP6 MP7 MP8	Shaft, 5.9 Inch Coupler Spacer, Control Board Screw, Control Board Graticule Glass Lens Lens Gasket, Vertical Lens Gasket, Horizontal		07-7154 07-7147 01-1035 01-1036 01-2002 01-1006 01-1066 01-1067
SW6	Switch, Toggle, SPDT	(on-off-on)	07-7071



# CASE ASSEMBLY:

(Refer to Figure 25)		
REF. DES.	DESCRIPTION	HUNTRON® PART NO.
CRT 1	Cathode Ray Tube	07-7059
MP1 MP2 MP3 (2) MP4 (2) MP5 (2) MP6 MP7 MP8 MP9 (4) MP10 (4) MP11 MP12	Rear Extension Assembly B-1S, BIJS Models Rear Extension Assembly B1-ES Models Case, Top Assembly Screw, Yoke Spacer, Yoke Yoke Half Face Plate Handle Assembly Case, Bottom Assembly Case, Feet Screw, Case Shield, CRT Shield, Half	01-2127 01-2128 01-2117 01-1017 01-1116 01-1114 01-1068 01-2119 01-2129 01-2129 01-1020 01-1019 07-1000 07-1011



# INTERCONNECTION ASSEMBLY:

(Refer to Figure 26)

REF. DES.	DESCR	DESCRIPTION		
MP1 (2) MP2 MP3 (2) MP4 (2) MP5	Spacer, 1 Inch Washer, Lock Star #6 Spacer, ¼ Inch Screw, Yoke Screw, 3/8 Inch, 6/32		07-7157 07-7171 07-7163 01-1017 07-7172	
TR2	Transformer, Power CRT Harness	100 VAC 117 VAC 220/240 VAC	06-6033 06-6031 06-6032 07-1035	



#### HTR 1005B-1 INTERNAL SET-UP AND ADJUSTMENTS (REFER TO PAGE 37)

- 1. Adjust all Trim Pots (R1, R2, R3, R7, R9, R16, R19, R20, R30, R32). To their fully counterclockwise position.
- 2. Adjust front panel vertical and horizontal controls to the center of their range.
- 3. Turn front panel intensity control fully counterclockwise.
- 4. Turn power on.
- 5. Put front panel swith on HIGH range position.
- 6. Adjust intensity until spot appears on screen.
- 7. Adjust master vertical gain (R19) for vertical deflection of approximately .5 inch.
- 8. Adjust focus (R32) and astig (R30) for sharpest trace (check intensity for correct brightness).
- 9. Adjust master horizontal phase (R16) to the center of its range.
- 10. Adjust master horizontal gain (R20) until trace fills out screen.
- 11. Short output terminals.
- 12. Adjust master vertical gain (R19) until vertical trace is 1 3/8" long.
- 13. Adjust vertical phase hi range (R3) until no vertical tilt.
- 14. Readjust R19.
- 15. Remove output terminal short.
- 16. Adjust master horizontal phase (R16) until horizontal trace has no tilt.
- 17. Switch to MED range position
- 18. Short output.
- 19. Adjust MED range vertical phase (R2) until trace has no vertical tilt.
- 20. Remove short.
- 21. Adjust MED horizontal phase (R7) until trace has no tilt.
- 22. Switch back and forth between HIGH and MED range and observe trace. It should have no horizontal tilt on either range and ends of trace should be very close to tube mask but not out of view. Both traces should be within 5% of each other in length.
- 23. Short output and switch back and forth between HIGH and MED range. Both vertical traces should be within 5% of each other in length and approximately 1 3/8" in length.

24. Install diode at output terminals you should see trace as displayed in figure 11.



Figure 11

- 25. Final adjustments can be made on horizontal and vertical gain and horizontal and vertical phase for correct trace. The trace length difference should be less than 5%. Vertical and horizontal trace should have no tilt. Edge of trace should not go off screen.
- 26. Swith to LOW range.
- 27. Short output and adjust LOW range vertical phase (R1) for no vertical tilt.
- 28. Open output and adjust LOW range horizontal gain (R9) so that trace looks like figure 12.
- 29. Insert diode at output terminals.
- 30. Trace should look like figure 13.
- Final focus and astig adjustment can be made with diode in test terminals and range switch in HIGH or MED position.



Figure 12 Trace should not have full horizontal length.







TRIM POT CONTROL LOCATION MODEL HTR 1005 B-1