

PHILIPS



Cryogenic Equipment / Electro Chemistry / Electron Optics / Electronic Weighing / Industrial Data Systems / Numerical Control / Philips Pollution Measuring / Radiation Measuring Equipment / Test and Measuring Equipment / Welding Equipment / X-Ray Analytical Equipment

equipment for science and industry

802711

TEST AND MEASURING EQUIPMENT

OSC85

OSCILLOSCOPES PM3262 - PM3263

Subject : CRT with quick heating cathode (D14 - 302GH/93)

Starting with the PM3262/07 and the PM3263/03 CRT's with a quick heating cathode (D14 - 302GH/93) are mounted in the instruments.

If such CRT's are used as replacement tube for PM3262/01/..../06/ and for PM3263/01/02/ instruments, these instruments have to be modified in the following way.

- Wire on point 14 of the CRT socket must be disconnected from point 14 and soldered on point 13.
- A resistor R2090 of 1,96 Ω MR30 ½% must be added between the points 13 and 14 of the CRT socket (see figure)

