

045-0189-00

M70209

11301A FIRMWARE REPLACEMENT

For the following TEKTRONIX® instrument:

11301A All Serial Numbers

This kit contains parts and instructions that replaces the firmware in the 11301A Programmable Oscilloscope. The firmware is upgraded to version $\frac{2}{2}$.

Copyright © 1990 Tektronix, Inc. All Rights Reserved

19-FEB-90

page 1

KIT	PARTS LIST:			
Ckt	Number	Quantity	Part Number	Description
		1 ea	020-1718-XX	Component Kit:Ver 1.1
				Consisting of the following:
	U1330	1 ea	160-4204-10	Microckt, dgtl:NMOS, EPROM ver 1.1
	U1430	1 ea	160-4205-10	Microckt,dgtl:NMOS,EPROM ver 1.1
	U1400	1 ea	160-4206-10	Microckt,dgtl:NMOS,EPROM ver 1.1
	U1100	1 ea	160-4207-10	Microckt,dgtl:NMOS,EPROM ver 1.1
	U1200	1 ea	160-4208-10	Microckt,dgtl:NMOS,EPROM ver 1.1
	U1300	1 ea	160-4209-10	Microckt,dgtl:NMOS,EPROM ver 1.1
	U1000	1 ea	160-4294-10	Microckt,dgtl:NMOS,EPROM ver 1.1
	U1230	1 ea	160-4295-10	Microckt,dgtl:NMOS,EPROM ver 1.1

WARNING

Dangerous shock hazards may be exposed when the instrument covers are removed. Before proceeding, ensure the mainframe power switch is in the off position. Then, disconnect the instrument from the power source. Disassembly should only be attempted by qualified service personnel.

NOTE

These instructions assume a familiarity with the instrument. If additional assembly or disassembly details are required, refer to the 11301A Service Reference Manual.

CAUTION

Many components within the 11300 Series mainframe are extremely susceptible to staticdischarge damage. Service the instrument only in a static-free environment. Observe standard handling precautions for static-sensitive devices while installing this kit. Always wear a grounded wrist strap.





Run Enhanced Accuracy and Extended Diagnostics and verify that there are no other failures. Repair all failures before replacing firmware.

Turn the slotted fasteners on the top dust cover one quarter turn counter clockwise. Then remove the dust cover by lifting away from the instrument.

NOTE

Position the instrument with the bottom of the instrument (Time Base circuit board A14) is facing up towards the installer.

NOTE

Refer to Figure 1, while performing steps 2 through 10, in this section.

□ 2. Set number 2, number 4, and number 5 DIP switches on the Main Processor circuit board A11, to their closed positions.

NOTE

Be certain that pin 1 is positioned correctly when replacing EPROM's.

- 3. Replace U1000, U1100, U1200, U1230, U1300, U1330, U1400, and U1430 with the new EPROM's that are provided in this kit. Refer to Figure 2, for EPROM locations.
- 4. Turn the instrument POWER SWITCH to ON. Initially the PROCESSOR diagnostic (BBr Quick) test will fail; this will only occur during the first power-up sequence following the firmware installation.
- 5. Press the Display Adjust Menu button and wait for the screen message Diagnostics are complete.
- □ 6. Connect an RS-232-C terminal or a GPIB controller to the instrument.
- 7. Press the DISP ADJ button and set FOCUS, ASTIGMATISM, and TRACE ROT
- □ 8. Press the ENHANCED ACCURACY button twice.
 - □ a. If the instrument passes, proceed to the next step.
 - b. If the instrument fails to do an successful EA, run the GRAT-PREP procedure, Test List No. 24 in the CATS disk (Computer Aided Test Software).
 - c. If the instrument fails, try it again. If it still fails, refer to "Restoring Factory Calibration" and try it again. If it still fails, refer to the Main Processor board information in "Checks After FRU Replacement."

- 9. Turn the POWER SWITCH to OFF.
- □ 10. Set number 2, number 4, and number 5, DIP switches on the Main Processor circuit board A11 to there open positions.
- □ 11 Replace the top dust cover removed in step 1.
- □ 12. For future reference fasten the attached Manual Modification Insert in the Service Reference manual.

TEKTRONIX MANUAL MODIFICATION INSERT

11301A FIRMWARE REPLACEMENT

for

11301A Programmable Oscilloscope All Serial Numbers

This modification insert is provided to supplement the manual for the above listed product(s). The information given in this insert supersedes that given in the manual.

Copyright© 1990 by Tektronix, Inc., Beaverton, Oregon. Printed in the United States of America. All rights reserved. Contents of this inserts may not be reproduced in any form without the permission of the copyright owner.

GENERAL INFORMATION

This kit contained parts and instructions that replaces the firmware in the 11301A Programmable Oscilloscope. New firmware version 3.1 was installed with this upgrade. The following insert pages describes the new firmware features included with this upgrade.



made, and the signal that is being measured is too fast or too noisy, the following statements will appear. In the place of the rise time or fall time the statements **too fast** or **too noisy** will be displayed.





Selecting DLYL1C1 as argument will display the prop delay setup L1 TO C1.