

## 1945

HYDROGEN-SENSITIVE, IONIZATION TYPE

VACUUM-GAUGE TUBE

1	<u>.</u>	GENERAL	DATA						
1	Electrical:								
	Heater, for Unipotential Voltage Current	Cathode 6.3 0.75	: ± 10% •		. ac	or ••	dc • •	vol:	ts mp
þ	Mechanical:								
1	Mounting Position Maximum Overall Length . Maximum Diameter Tubulation Bulb Base	ВОТТОМ			Out Meta Wafer	1 Sh	1- Dr ell	5-3/8 5/16 awii MT8	6" ng 8G
	Pin 1 - Cathode Pin 2 - Heater Pin 3 - Ion Collector	<b>4</b>	5)	Pin 6 Pin 7 Pin 8	- Heat	er			
	Pin 4 - Cathode Pin 5 - Plate, Shell DO NOT USE FOR GETTER CONNECTION	<del>\</del>		Shell.	- Plat Conr to H Sect Tubu	nect Hexa Lion	ion gon of	al	
	_	EAK DET	ECTUR						
1 1									
1	Maximum Ratings, Absolute	Values	:		200			3	
F	PLATE VOLTAGE	Values	: 		300 -30			vol:	
F	PLATE VOLTAGE	Values	:  	. {	-30 -15	max min		vol:	ts ts
F	PLATE VOLTAGE		:	· { · { :	-30 -15 50 7	max		vol:	ts ts a.
F	PLATE VOLTAGE  ION-COLLECTOR VOLTAGE  PLATE CURRENT  PLATE DISSIPATION  PEAK HEATER-CATHODE VOLTA  Typical Operation:		:	· · { :	-30 -15 50 7	max min max max		volt volt ma watt	ts ts a.
F F N F F N F F F F F F F F F F F F F F	PLATE VOLTAGE  HON-COLLECTOR VOLTAGE  PLATE CURRENT  PLATE DISSIPATION  PEAK HEATER-CATHODE VOLTA  Typical Operation:  Plate Voltage  Hinimum Plate-Supply Volt  on-Collector Voltage.  Plate Current  Plate Dissipation  Plate Dissipation			Less	-30 -15 50 7 0 185 250 22.5 32 than 6	max min max max max		volt volt volt volt volt ma µan watt	ts ts a. ts ts ts ts
F F N F F N F F F F F F F F F F F F F F	PLATE VOLTAGE  ION-COLLECTOR VOLTAGE  PLATE CURRENT  PLATE DISSIPATION  PEAK HEATER-CATHODE VOLTA  Typical Operation:  Plate Voltage  Inimum Plate-Supply Volt  on-Collector Voltage  on-Collector Current  on-Collector Current			Less	-30 -15 50 7 0 185 250 22.5 32 than 6	max min max max max		volt volt volt volt volt ma µan watt	ts ts a. ts ts ts ts
F F N F F N F F F F F F F F F F F F F F	PLATE VOLTAGE  ION-COLLECTOR VOLTAGE  PLATE CURRENT  PLATE DISSIPATION  PEAK HEATER-CATHODE VOLTA  Typical Operation:  Plate Voltage  Minimum Plate-Supply Volt  on-Collector Voltage  Plate Current  on-Collector Current  Plate Dissipation  With no hydrogen in the gau  the gauge tube, the ion-col  in order to obtain a def  collector current, it is nec  fying dc currents of the or  The metal shell of the	age	hydrog urrent ding of use an 005 µam	Less en from may inc such sm amplifie p. an ind	-30 -15 50 7 0 185 250 22.5 32 than 6 minute rease rease irect	max min max max max oo.5	· · · · · · · · · · · · · · · · · · ·	volt watt volt volt ma pan watt enters than ion ion ted	ts ts a. ts ts ts ts
F F N F F N F F F F F F F F F F F F F F	PLATE VOLTAGE	age	hydrog urrent ding of use an 005 µam	Less en from may inc such sm amplifie p. an ind e made	-30 -15 50 7 0 185 250 22.5 32 than 6 minute rease all chricapa	max min max max max max max		volt wati volt volt volt ma µam watt es thin ion ampli ted um.	ts ts a. ts ts ts ts
F F N F F N F F F F F F F F F F F F F F	PLATE VOLTAGE  ION-COLLECTOR VOLTAGE  PLATE CURRENT  PLATE DISSIPATION  PEAK HEATER-CATHODE VOLTA  Typical Operation:  Plate Voltage  Minimum Plate-Supply Volt  on-Collector Voltage  Plate Current  on-Collector Current  Plate Dissipation  With no hydrogen in the gau  the gauge tube, the ion-col  in order to obtain a def  collector current, it is nec  fying dc currents of the or  The metal shell of the	ge. When fector coinite reaessary to der of 0.	hydrog urrent ding of use an 005 µam ntains a plat rs a vac	Less en from may inc such sm amplifie p. an ind e made the inr cuum-ti	-30 -15 50 7 0 185 250 22.5 32 than 6 mr caps irect poer et et et et et poer et	max min max max max max max lead by mange lead by ly—latta and coarrier arrival arriva		voltina wati voltina voltina voltina pam wati enters this voltina pam wati ted um.	ts ts a. ts ts ts ts

enclosure to be exhausted to a much better vacuum than





## VACUUM-GAUGE TUBE

(continued from preceding page)

normally exists in a vacuum system. However, when heated, the palladium plate serves as a permeable membrane which permits any hydrogen in the vacuum system to which the 1945 is connected to flow into the tube.

Practical application of the 1945 to locating a leak consists simply of connecting it to the vacuum system and of probing the system with a jet of gas containing a high percentage of hydrogen. If a leak is present, hydrogen enters the vacuum system at the point of leakage, passes through the hot palladium plate, and produces an increase in current to the ion-collector.

Because of its high vacuum, the 1945 can detect far smaller leaks than are detectable using conventional ionization gauges operating at the same pressure as the vacuum system. Actually, an increase in hydrogen pressure of less than  $10^{-7}$  mm of mercury ( $10^{-4}$  microns) can be detected by the 1946.

The 1945 can be connected to a hard-glass, soft-glass, or metal vacuum system.

Connection to a hard-glass system may readily be made by breaking off the tip of the glass tubulation (see Outline Drawing), and sealing the (Corning Code 772 Nonex) tubulation to the class system.

Connection to a soft-glass system requires a graded seal between the hard-glass tubulation of the 1945 and the soft glass of the system.

Connection to a metal system requires that the glass tubulation first be removed by pinching the glass with pliers at a point close to the Kovar seal. Then, the 1945 can be connected to a metal system by a straight pipe coupling which is necessary for clearance of the metal exhaust tubulation. Always apply the wrench to the hexagonal section and never to the metal shell. After the coupling has been tightened, it should be coated with Glyptal to insure that the joint is vacuum tight.

Suitable support should be provided for the 1945. In a glass system, it should be supported by a suitable clamp encircling the metal shell. The clamp should be lined with an asbestos pad so that the clamp does not place a strain on the welds. In a metal system, the 1945 can usually be supported by the pipe coupling.

For safety reasons, it is advisable to have the metal shell of the 1945 at ground potential (positive polarity).



## 18 X2

## **VACUUM-GAUGE TUBE**

