

**IMOS**

**MICROCOMPUTERS**

**TIM  
TERMINAL INTERFACE MONITOR  
MANUAL**



*Publication Number 6500-20*

## **MCS6500**

### **MICROCOMPUTER FAMILY**

### **TIM MANUAL**

**MARCH, 1976**

The information in this manual has been reviewed and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. The material in this manual is for informational purposes only and is subject to change without notice.

Second Edition  
© MOS TECHNOLOGY, INC. 1976  
"All Rights Reserved"

**MOS TECHNOLOGY, INC.**  
**950 Rittenhouse Road**  
**Norristown, PA. 19401**



## TABLE OF CONTENTS

I.	INTRODUCTION.....	1
II.	SYSTEM CONFIGURATION.....	3
III.	OPERATIONAL FEATURES OF TIM.....	6
	A.    TIM COMMANDS.....	6
	B.    TIM INTERRUPT AND BREAKPOINT SECTION.....	9
	C.    TIM MONITOR CALLS AND SPECIAL LOCATIONS.....	11
	D.    TIM MEMORY USAGE.....	12
IV.	TIM CHECKOUT PROCEDURE.....	13
APPENDIX A - MEMORY ADDRESS TEST.....		A-1
APPENDIX B - TIM PROGRAM LISTINGS.....		B-1



## I. INTRODUCTION

TIM is the Terminal Interface Monitor program for MOS Technology's 65XX microprocessors. It is supplied in read-only memory (ROM) as part of the MCS6530-004 multi-function chip. Because the TIM code is nonvolatile, it is available at system power-on and cannot be destroyed inadvertently by user programs. Furthermore, the user is free to use only those TIM capabilities which he needs for a particular program. Both interrupt types, interrupt request (IRQ) and nonmaskable interrupt (NMI) may be set to transfer control to TIM or directly to the user's program.


TIM communicates with the user via a serial full-duplex port (using ASCII codes) and automatically adjusts to the speed of the user's terminal. Any speed--even nonstandard ones--can be accommodated. If the user's terminal has a long carriage return time, TIM can be set to perform the proper delay. Commands typed at the terminal can direct TIM to start a program, display or alter registers and memory locations, set breakpoints, and load or punch programs. If available in the system configuration, a high-speed paper tape reader may be used to load programs through a parallel port on the MCS6530-004 chip. Programs may be punched in either of two formats--hexadecimal (assembler output) or BNPF (which is used for programming read-only memories). On loading or modifying memory, TIM performs automatic read-after-write verification to insure that addresses memory exists, is read/write type, and is responding correctly. Operator errors and certain hardware failures may thus be detected using TIM.

TIM also provides several subroutines which may be called by user programs. These include reading and writing characters on the terminal, typing a byte in hexadecimal, reading from high-speed paper tape, and typeing a carriage-return, line-feed sequence with proper delay for the carriage of the terminal being used. Program tapes loaded by TIM may also specify a start address so that programs may be started with a minimum of operator action.

## II. SYSTEM CONFIGURATION

Since TIM is a "program" resident in the MCS6530-004 it must be properly configured in a proper system environment.

Figure 2-1 represents a block diagram of a minimum system utilizing the TIM program. The MCS6502 is the controlling microprocessor with two pages of memory (pages 0 and 1) representing the minimum RAM requirement. These devices, as well as a representative schematic for the TTY, EIA interfaces, are shown in Figure 2-2 which is a detailed system schematic utilizing the MCS6530-004. Note that the TIM function select equations are found on this schematic.



\* Note that the TIM as sold consists only of the MCS6530-004 component accompanied by supporting information to build this system

TYPICAL MINIMUM CONFIGURATION  
FOR "TIM" SYSTEM

FIGURE 2-1




FIGURE 2-2

### “TIM” SYSTEM SCHEMATIC

### III. OPERATIONAL FEATURES OF TIM

#### A. TIM Commands\*

<u>Command</u>	<u>Description</u>
<u>V</u>	Set line speed. After RESET, a carriage return is typed to allow TIM to measure the line speed.
<u>.R</u>	Display user registers. The format is: PC P A X Y S where: PC is the program counter P is the processor status A is the A (accumulator) register X is the X (index) register Y is the Y (index) register S is the stack pointer low byte (high byte is always 01)
<u>.G</u>	Go. Begin execution at user PC location (see R command).
<u>.M</u> <u>addr</u>	Memory examine. TIM will display the eight bytes beginning at address <u>addr</u> .
<u>.:</u> <u>ADDR</u> <u>data</u>	Alter registers or memory. TIM allows the user to alter registers (if R command precedes) or memory (if M command precedes). Values for registers or memory locations which are not to be changed need not be typed

\* Characters typed by the user are underlined. All other characters are typed by the computer. ↴ means carriage-return.

—these fields may be skipped by typing spaces instead of data. The remainder of the fields in a line may be left unchanged by typing carriage return. The : command may be repeated to alter subsequent memory locations without the necessity of typing intervening M commands. Note that TIM automatically types spaces to separate data fields.

.LH

Load Hexadecimal. TIM responds with carriage return, line-feed and loads data in assembler output format from the terminal or high-speed paper tape reader. The format is:

Zero or more leading characters except ";" (usually blank leader)

Any number of records of the form:

;ccaaaadddd....ddssss

where:

cc is the number of bytes in the record in hex

aaaa is the hex address to store the first byte of data

dddd....dd is the data (two hex digits per byte)

ssss is the check-sum, which is the arithmetic sum, to 16 bits, of all the count, address and data bytes represented by the record

A terminating record of zero length,  
either: ;00 or ;}

Note that read-after-write and check-sum tests are performed. An error will result in a "?" being typed at the point the error occurred. Data from records with bad checksums is deposited in memory as received, prior to the error stop.

.H

High-speed/low-speed reader switch. This command switches the load device from the user's terminal to the high-speed reader or vice versa.

.WH addl addh\}

Write Hexadecimal. An assembler-format tape is generated at the user's terminal. Format is as described above in the LH command description. Note that the address range must be specified with the lower address first. As in the Alter command, TIM types the space between the address fields.

.WB addl addh\}

Write BNPF. A BNPF format tape is generated at the user's terminal. Format is one or more records as follows:

aaaa Bdddddddf Bdddddddf Bdddddddf Bdddddddf

where:

aaaa is the address of the first of the four bytes specified in the record.

(Note: BNPF conventions require that the letter "B" never occur in the address field. Blanks are substituted by TIM.)

B is the letter "B", meaning begin data.

dddddd is eight data bit —P for logical true, N for logical false.

F is the letter "F", meaning finish.

Note that the BNPF format is output as multiples of four bytes. Thus, a multiple of four bytes will always be punched even if a non-multiple of four bytes is specified.

Cancel Command. While typing any command, its further effect may normally be terminated by typing one or two carriage returns, as required.

During alter (:), carriage return means that no further bytes (or registers) are to be altered.

## B. TIM Interrupt and Breakpoint Action

### BRK

The BRK instruction causes the CPU to interrupt execution, save PC and P registers on the stack, and branch through a vector at locations FFFE and FFFF. TIM initializes this vector to point to itself on RESET. Unless the user modifies this vector, TIM will gain control when a BRK instruction is executed, print an asterisk "\*" and the registers (as in R command), and wait for user commands. Note that after a BRK which vectors to TIM, the user's PC points to the byte following the BRK; however, users who choose to handle BRK instructions themselves.

should note that BRK acts as a two-byte instruction, leaving the PC (on return via RTI) two bytes past the BRK instruction.

#### IRQ

Interrupt Request is also vectored through location FFFE. The CPU traps (as with BRK) through this vector when IRQ goes low, provided interrupts are not inhibited. Since this vector is the same as for BRK, TIM examines the BRK bit in the P register after this type of interrupt. If a BRK did not cause the interrupt, then TIM will pass control through the UINT vector. Users should normally put the address of their interrupt service routine in the UINT vector location. If an IRQ occurs and UINT has not been set by the user, TIM reports the unexpected interrupt in the same way as an NMI (see below).

#### NMI

Non-Maskable Interrupts vector through location FFFA. TIM initializes this vector at RESET to point to itself. If an NMI occurs, a pound-sign character  $\text{\#}$  precedes the asterisk and CPU registers printout. This action is the same for IRQ's if the user has not set this vector to point to his own routine.

#### RESET or POWER-UP

On RESET or POWER-UP, TIM takes control, initializes itself and the system, sets defaults for interrupt vectors and waits for a carriage-return input from the user to determine terminal line speed. After carriage-return is typed, control is passed to the user as in BRK.

C. TIM Monitor Calls and Special Locations

<u>Call</u>	<u>Address</u>	<u>Action</u>	<u>Arg.</u>	<u>Result</u>	<u>Notes</u>
JSR WRT	72C6	Type a character	A	None	A,X cleared Y preserved
JSR RDT	72E9	Read a character	None	A	X cleared Y not preserved
JSR CRLF	728A	Type CR-LF and delay	None	None	A,X cleared Y preserved
JSR SPACE	7377	Type a space character	None	None	A,X,Y preserved
JSR WROB	72B1	Type a byte in hex	A	None	A,X cleared Y preserved
JSR RDHSR	733D	Read a character from high-speed paper tape reader	None	X—char read A—char trimmed to 7 bits	Y preserved

<u>Function</u>	<u>Locations</u>	<u>Notes</u>
Start Address	00F6,00F7	Set with hex tape on load
CR-LF Delay	00E3	Set on load or with user program (in <u>bit times</u> , minimum of 1. Zero means 256 bits-time delay).
UINT	FFF8	User IRQ vector
NMI Vector	FFFA	Hardware NMI vector
RESET Vector	FFFC	Hardware RESET vector
IRQ Vector.	FFFE	Hardware IRQ vector

D. TIM Memory Usage

TIM uses the top  $29_{10}$  bytes of page zero (locations 00E3 through 00FF). The user is advised to avoid these locations, except as noted above, if return to TIM or use of TIM subroutines is required before RESETing the processor. TIM also uses the hardware stack when it is in control. Provided the user does not alter the stack pointer during a break, and provided the stack does not overflow, TIM will restore the stack to its original status before returning to the user's program. The user is advised to use page 1 (the stack page) cautiously, leaving at least  $20_{10}$  bytes for TIM use during a break or when using other TIM functions.

#### IV. TIM CHECKOUT PROCEDURE

The following step-by-step procedure assumes the user has built the TIM hardware system and is now ready to verify its functionality.

- ( ) 1. Turn power on, or if the power is on, perform a RESET operation. Type a carriage-return on the terminal. TIM should respond with:

\* 7052 30 18 FF 01 FF

(Exact values may vary, although the first and last values should be as shown). If no response or a garbled response occurs, RESET and try again. In case of continued trouble, refer to the diagnostic section of the MOS Hardware Manual.

The "\* 7052 30 18 FF 01 FF" printout is TIM's standard breakpoint message format. It consists of an asterisk "\*" to identify the breakpoint printout, followed by the CPU register contents in this order: PC, P, A, X, Y, and S, i.e., Program Counter, Processor Status, Accumulator, X index, Y index and Stack Pointer. Note that all TIM inputs and outputs are in base 16 which is referred to as hexadecimal, or just hex. In hexadecimal, the "digits" are 0, 1, 2, . . . , A, B, C, D, E, F. After printing the CPU registers, TIM is ready to receive commands from you, the operator. TIM indicates this "ready" status by typing the prompting character "." on a new line.

- ( ) 2. TIM's response to RESET is to wait for a carriage-return and then print the user's registers. TIM uses this carriage-return character to measure the terminal line speed. If you have a settable-rate terminal, change the

rate (any speed between 10 and 30 cps will work) and repeat Step 1. TIM should respond at the new terminal speed.

( ) 3. The user's CPU registers may also be displayed with the R command. Type an R. The monitor should respond as above, but without the asterisk. Presence of the asterisk indicates that an interrupt or break instruction caused the printout.

.R 7052 30 18 FF 01 FF

( ) 4. Displayed values may be modified using the Alter (:) command. To modify register contents, type a colon (:) followed by the new values. For example:

.R 7052 30 18 FF 01 FF  
.: 0100 00 00 00 00 FF  
.R 0100 00 00 00 00 FF

Notice that TIM automatically types spaces to separate data fields. (Note: Characters typed by you, the user, are underlined in this document for clarity. Everything else is typed by the computer.) Examine your registers (R command) to verify the changes.

Memory may be examined and modified, as above, using the M and : commands. Try this:

.M 0100 00 66 23 EE 01 A2 41 6E

The memory command (M) causes TIM to type the contents of the first eight bytes of memory. (Memory data will be random on startup). Alter and verify these bytes using the Alter command, as above:

```
.M 0100 00 66 23 EE 01 A2 41 6E  
.I 0100 00 01 02 03 04 05 06 07
```

If only part of a line is to be altered, items to be left unchanged can be skipped over by typing blanks, and carriage-return ( $\downarrow$ ). Try this:

```
.M 0100 00 01 02 03 04 05 06 07  
.I 0100 FF — FF FF  $\downarrow$   
.M 0100 FF 01 FF FF 04 05 06 07
```

( ) 5. Try to alter a location in TIM ROM:

```
.M 7000 85 F9 A9 23 D0 58 A9 16  
.I 7000 00?
```

TIM verifies all changes to memory. Since locations 7000 through 7007 are in read-only memory, alteration is not possible. TIM signals write failure with a question mark. Similarly, the monitor will notify you of an attempt to alter a non-existent location:

```
.M 9000 90 90 90, 90 90 90 90 90  
.I 9000 00?
```

Note that attempts to read non-existent memory will normally yield the high-order byte of the address read.

( ) 6. There are three hardware facilities which may be used to stop a running (or run-away) program without the program itself calling TIM. These are the hardware inputs RESET,

IRQ, and NMI. To test this feature enter the following program at location 0000:

<u>location</u>	<u>contents</u>	<u>instruction</u>
0000	4C	LOOP
0001	00	JMP
0002	00	LOOP

(Use the M and : commands.)

Now, set the program counter (PC) to this location using the R and : commands. Finally, tell TIM to start executing your program using the Go (G) command:

```
.M 0000 FF 11 11 11 91 91 71 91  
.E 0000 4C 00 00 ↓  
.M 0000 4C 00 00 11 91 91 71 91  
.R 0000 30 00 00 00 FF  
.E 0000 ↓  
.G
```

The computer should now be executing the program. It will continue to run until interrupted. Using the interrupt request line (IRQ), interrupt the processor. It should respond with:

```
* 0000 30 00 00 00 FF
```

Try the same experiment with non-maskable interrupt (NMI). The result should be the same except for a "#" character preceding, which identifies the NMI printout. Finally, try it with RESET. RESET, however, forces a CPU branch to TIM, losing the old PC and other register contents. Thus NMI is the preferred means for manually interrupting program execution. IRQ may also be

used unless it is required for other functions such as peripheral interrupts.

( ) 7. Use M and : to enter the following test program called CHSET because it prints the character-set on the terminal.

Note that Alter (:) commands may be repeated without intervening M commands to set sequential locations:

```
;CHECKOUT PROGRAM -- PRINT THE CHARACTER SET ON USER TERMINAL

CRLF    =$728A          ;ADDRESS OF TIM CRLF ROUTINE
WRT     =$72C6          ;ADDRESS OF TIM WRITE ROUTINE
;
;                                ;VARIABLE STORAGE IN PAGE ZERO
CHAR    =&=0+1           ;STORAGE FOR CHARACTER
;
;                                ;PROGRAM STARTS ON PAGE ONE
;
;                                ;CC CARRIAGE RETURN & LINE FEED
0100 20 8A 72  CHSET   JSR CRLF
0103 A9 20          LCA #$20
0105 E5 CC          STA CHAR
;
;                                ;INITIALIZE
0107 A5 00          LOPP   LCA CHAR
0109 C9 6C          CMP #$6C
0108 F0 08          BEQ CONE
;
;                                ;GET CHARACTER
;                                ;CHECK FOR LIMIT
;                                ;DONE IF 60
0110 20 C6 72        JSR WRT
0111 E6 0C          INC CHAR
0112 4C C7 01        JMP LOPP
;
;                                ;PRINT CHAR
;                                ;NEXT CHAR CCCE
;                                ;CONTINUE
0115 C0              CONE   BRK
;
;                                ;STOP & RETURN TO TIM MONITER
0116 4C 00 C1        JMP CHSET
;DO IT AGAIN
```

<u>.M</u>	<u>0100</u>	<u>20</u>	<u>8D</u>	<u>72</u>	<u>20</u>	<u>EC</u>	<u>72</u>	<u>8D</u>	<u>26</u>
<u>.I</u>	<u>0100</u>	<u>20</u>	<u>8A</u>	<u>72</u>	<u>A9</u>	<u>20</u>	<u>85</u>	<u>00</u>	<u>A5</u>
<u>.I</u>	<u>0108</u>	<u>00</u>	<u>C9</u>	<u>60</u>	<u>F0</u>	<u>08</u>	<u>20</u>	<u>C6</u>	<u>72</u>
<u>.I</u>	<u>0110</u>	<u>E6</u>	<u>00</u>	<u>4C</u>	<u>07</u>	<u>01</u>	<u>00</u>	<u>4C</u>	<u>00</u>
<u>.I</u>	<u>0118</u>	<u>01</u>	<u>↓</u>						

Now run the program. Do this by setting the PC to 0100 and using the G command. The listing should look like this:

```

•R 0000 30 00 00 00 FF
•I 0100 ↓
•G
!"#SZ&' ()*+,--./0123456789:;<=>?@ABCDEFGHIJKLMN@PQRSTUVWXYZ[\]^~
* 0116 33 60 00 00 FF

```

The program may be continued, causing it to execute again, by typing G:

```

•G
!"#SZ&' ()*+,--./0123456789:;<=>?@ABCDEFGHIJKLMN@PQRSTUVWXYZ[\]^~
* 0116 33 60 00 00 FF
•G
!"#SZ&' ()*+,--./0123456789:;<=>?@ABCDEFGHIJKLMN@PQRSTUVWXYZ[\]^~
* 0116 33 60 00 00 FF
•G
!"#SZ&' ()*+,--./0123456789:;<=>?@ABCDEFGHIJKLMN@PQRSTUVWXYZ[\]^~
* 0116 33 60 00 00 FF

```

The CHSET program uses two TIM monitor functions: CRLF is the TIM function which causes a carriage-return and line-feed to be typed on the terminal. WRT is the routine which prints the character whose code is in the A register at the time of the call.

( ) 8. Save the CHSET program on paper tape (if your

terminal has a punch) as follows: First, punch some leader tape with the terminal in local mode. Then return to line mode and enter:

.WH 0100 0118 }

Turn the punch on after typing the second address, but before typing carriage-return. Then type carriage-return to punch the tape. When punching stops, turn the terminal back to local and type:

;00

and some blank trailer. This is a zero-length record which terminates your tape. See Appendix II for more information on tape formats.

( ) 9. Try re-loading your program using the LH command:

.LH

Now start the reader to load the program. The tape will be read and printed simultaneously. Stop the tape when the end is reached. (Before loading, you may wish to destroy the program in memory to verify that loading from tape actually works.)

( ) 10. Use the M and : commands to load the following program:

```

;CHECKOUT PROGRAM -- PRINT BINARY OF TYPED CHARACTER
;

CCCC      :C=0          ;VARIABLE STORAGE IN PAGE ZERO
0000      :BINARY=$3+1 ;STORAGE FOR CHAR DURING DISSECTION
0001      :COUNT=$4+1   ;COUNT OF BITS REMAINING TO PRINT

0002      :$=$0100     ;PROGRAM BEGINS ON PAGE ONE

;
CRLF      :=$728A    ;TIM CRLF ROUTINE
WRT       :=$72C6    ;TIM WRITE ROUTINE
RDT       :=$72E9    ;TIM READ ROUTINE
SPACE     :=$7377    ;TIM SPACE ROUTINE

;
0100 20 8A 72 PEIN  JSR CRLF ;PRINT CARRIAGE RETURN & LINE FEED
103 20 E9 72         JSR RDT  ;GET A CHARACTER
106 85 CC           STA BINARY ;SAVE FOR DISSECTION
108 20 77 72         JSR SPACE ;PRINT A SPACE

;
0108 AS C8          LDA #8   ;INITIALIZE BIT COUNT
010D 85 01          STA COUNT

;
01CF AS 30          PBLCCP LDA #'0 ;ASSUME ZERO: LOAD ASCII "0"
0111 C6 00          ASL BINARY ;C=NEXT BIT
0113 80 02          BCS PRINT  ;PRINT ZERO

;
0115 AS 31          LDA #'1 ;LOAD ASCII "1"

;
C117 20 C6 72 PRINT JSR WRT ;PRINT BINARY DIGIT
C11A C6 01          DEC COUNT ;COUNT BIT PRINTED
C11C 10 F1          BPL PBLCCP ;DO NEXT BIT

;
011E 4C 00 01        JMP PEIN ;DO IT ALL AGAIN

```

```

.M 0100 20 8D 72 A9 20 85 00 A5
.:
.:
.:
.:
.:
.:

```

The purpose of this program is to print the binary representation of an ASCII input character on the terminal.

Run the program by starting it at location 0100. Try typing some characters:

```

.R 0116 33 60 00 00 FF
.:
.:
.G
U 101010101
B 101111011
L 110011101

```

There is obviously something wrong with the program. Bits which should be printed as 1's are 0's and vice versa. (Refer to your 6500 reference card for character codes.) Looking at the program, the problem is that the branch after PBLOOP goes the wrong way! It should be BCC, Branch if Carry Clear (or alternatively, the 1 and 0 loads could be interchanged). Thus, when a one-bit is shifted out of the character, a one should be printed.

Patch the program and try again (the code for BCC is 90).

```

.M  0113  B0  02  A9  31  20  C9  72  C6
.:  0113  90  ↓
.R  7052  31  FC  FF  01  FF
.:  0100  ↓
.G
U  010101010
B  010000100
I  001100010

```

There is, alas, still an error--one too many bits is being printed. The cause of this is a little less obvious. (Do you see it?) To investigate the problem, set a breakpoint at location 011E. Do this by replacing the instruction there with a BRK (code of 00). Then run the program:

```

.M  011E  4C  00  01  EF  4C  00  01  00
.:  011E  00  ↓
.R  7052  31  FC  FF  01  FF
.:  0100  ↓
.G
U  010101010
*  011F  B0  00  00  AA  FF

```

Once the break has occurred, you are free to investigate the state of the program using TIM. In particular, check the value in location COUNT:

```
.M  0000  00  FF  1B  2E  31  EA  FO  FA
```

Aha! Although COUNT starts out with a value of 8, it is going one step too far (FF is minus 1). This is because the test instruction, BPL PBLOOP is testing to see whether the count is

greater than or equal to zero. Replace it with BNE (code D0), replace your breakpoint with the original contents at that location, and try the program again.

```
.M  011C  10  F1 00  00  01  EF  4C
.+:  011C  D0  _  4C  \
.R  011F  B0  00 00  AA  FF
.+:  0100  \
.G
U  01010101
B  01000010
L  00110001
I  01001001
W  01010111
O  01001111
R  01010010
K  01001011
S  01010011
```

```

;CHECKOUT PROGRAM -- PRINT BINARY OF TYPED CHARACTER
;
;
;
;      * = 0          ;VARIABLE STORAGE IN PAGE ZERO
BINARY * = * + 1    ;STORAGE FOR CHAR DURING DISSECTION
CCOUNT * = * + 1     ;COUNT OF BITS REMAINING TO PRINT
;
;      * = $0100       ;PROGRAM BEGINS ON PAGE ONE
;
;      CRLF = $728A    ;TIM CRLF ROUTINE
;      WRT  = $72C6    ;TIM WRITE ROUTINE
;      RDT  = $72E9    ;TIM READ ROUTINE
;      SPACE = $7377   ;TIM SPACE ROUTINE
;
;      CC 20 8A 72    PBIN   JSR CRLF
;      0103 20 E9 72   JSR RDT
;      0106 85 00      STA BINARY
;      0108 20 77 72   JSR SPACE
;
;      010B A9 C8      LDA #8
;      010D 85 01      STA CCOUNT
;
;      010F A9 30      PBLCCP LDA #'0
;      0111 C6 C0      ASL BINARY
;      0113 90 C2      ECC PRINT
;
;      0115 A9 31      LDA #'1
;
;      C117 20 C6 72    PRINT  JSR WRT
;      C11A C6 01      DEC CCOUNT
;      C11C DC F1      BNE PBLCCP
;
;      011E 4C C0 01    JMP PBIN
;
```

CORRECTED PBIN PROGRAM

( ) 11. Save the corrected program using the WH command. Before punching the terminating record (as above in step 8), turn off the punch and set the PC to the start address of the program (0100). Then punch locations 00F6 and 00F7 on the tape, then the terminator (;00), and finally, some trailer:

```
.R 7052 30 37 FF 01 FF
.E 0100 \
.WH 00F6 00F7 \
;0200F6000101A2
.;00
```

The resulting tape can be loaded and then started as follows:

```
.LH
: (program loads in)
.G
```

Locations 00F6 and 00F7 contain the starting address for programs. You may assemble and load your starting address into these locations to make tapes which can be started with a minimum of operator action. The carriage-return delay time may also be set in this manner. See Appendix II.

( ) 12. It is also possible to punch BNPF-format tapes using TIM. BNPF is the format used by some ROM programmers. The command is similar to that for writing hex tapes:

```
.WB 0100 0127 \
```

This command would punch the corrected PBIN program in BNPF

format. Try punching a BNPF tape. (Note that TIM will not load tapes in this format--use hex format (WH) for saving programs for later loading into your 65XX.)

( ) 13. If you have a high-speed paper tape reader attached to your 65XX system, you can use it to load programs in hex format. The H command switches the load device to and from the high speed reader. If you have a high speed reader, try loading a tape as follows:

.H  
.uLH

Note that control will not return to the user terminal until a terminator record (;00) is read.

APPENDIX A

MEMORY ADDRESS TEST

CARD #	LCC	CCDE	CARD
1			;MEMORY ADDRESS TEST
2			;FCR EACH LCC IN TEST RANGE
3			;CLEAR WHOLE RANGE
4			;SET LOC TO \$FF
5			;VERIFY WHOLE RANGE \$00 EXCEPT (LCC)
6			;VERIFY (LCC) TC BE \$FF
7			;BREAK TC MONITOR ON ERROR WITH LOC IN (C,1)
8			;PRINT "P" ON COMPLETION OF PASS & REPEAT
9			;
10	0000		\$= \$0000 ;PAGE C
11			;
12		WRT = \$72C2	
13	0000	LCC \$= \$+2	;TEST CELL ADDR
14	0002	LCW \$= \$+2	;LOWER LIMIT OF TEST
15	0004	HIGH \$= \$+2	;UPPER LIMIT OF TEST+1
16	0006	PTR \$= \$+2	;POINTER TO CELL UNDER TEST
17		;	
18	0008	\$= \$0010 ;START ADDR	
19		;	
20	0010 A9 00	MAD LDA # \$00	;TYPE CR
21	0012 20 C2 72	JSR WRT	
22	0015 A9 CA	LDA # \$0A	;& LF
23	0017 20 C2 72	JSR WRT	
24		;	
25	001A 20 68 CC	JSR RSTLCC	;LCC=LCW
26	001D 20 71 CC	JSR RSTPTR	;PTR=LCW
27	0020 A2 00	LEX #0	
28		;	
29		;CLEAR MEMORY AREA UNDER TEST	
30	0022 A9 00	MLI LDA #0	
31	0024 81 C6	STA (PTR,X)	;STORE ZERO
32	0026 20 7A 00	JSR INCPTR	;INCREMENT & TEST
33	0029 00 F7	BNE MLI	;NEXT LCC
34		;	
35		;PUT \$FF IN SELECTED CELL	
36	0028 A9 FF	TEST LDA # \$FF	
37	002D 81 00	STA (LOC,X)	
38		;VERIFY ALL CELLS ZERO EXCEPT (LCC)	
39	002F 20 71 00	JSR RSTPTR	;PTR=LCW
40		;	
41	0032 A1 C6	VLCCP LDA (PTR,X)	;GET CELL
42	0034 FC 17	BEC NEXTC	;CK IF ZERO
43	0036 A4 06	LDY PTR	;NOT ZERO--IS THIS (LCC)?
44	0038 C4 00	CFY LCC	
45	002A FC C1	PEC CK1	
46	003C 00	BRK	;NOT (LCC)
47		;	
48	003D A4 C7	OK1 LDY PTR+1	

CARD #	LCC	CODE	CARD	
49	0C3F	C4 C1		CFY LCC+1
50	CC41	FC C1		BEQ CK2
51	0042	0C		BRK
52		;		;NOT (LCC)
53	CC44	C9 FF	CK2	CMP #\$FF
54	CC46	FG 01		BEQ GK3
55	CC48	CC		BRK
56		;		;
57	CC49	A9 00	GK3	LDA #0
58	CC4B	81 00		STA (LCC,X)
59		;		;
60	004D	20 7A 0C	NEXTC	JSR INCPTR
				;NEXT CELL
61	0050	0C EG		BNE VLOOP
62		;		;IF NOT AT LIMIT
63	0052	A5 CC		LDA LCC
64	0C54	C0 07		BNE NCSTAR
65	CC56	A5 2A		LDA #'2
66	0058	20 C2 72		JSR WRT
67	005B	A2 00		LDX #0
68		;		;FIX X AFTER NON CALL
69	005D	20 8B 0C	NGSTAR	JSR INCLOC
				;NEXT LCC
70	CC60	0C C9		BNE TEST
71		;		;
72	CC62	20 68 00		JSR RSTLCC
				;PASS COMPLETE
73	0065	4C 10 00		JMP MAD
74		;		;
75				;RESET LCC TO LOW
76	0068	A5 02	RSTLCC	LDA LCW
77	CC6A	E5 CC		STA LCC
78	0C6C	A5 C3		LDA LOW+1
79	CC6E	E5 C1		STA LCC+1
80	CC7C	EC		RTS
81		;		;
82				;RESET PTR TC LCW
83	CC71	A5 C2	RSTPTR	LDA LCW
84	0073	85 06		STA PTR
85	CC75	A5 C3		LDA LCW+1
86	CC77	85 C7		STA PTR+1
87	CC79	6C		RTS
88		;		;
89				;INCREMENT PTR & CHECK FOR LIMIT
90	007A	E6 06	INCPTR	INC PTR
91	CC7C	0C C2		;INCREMENT ENE INCL
92		;		;
93	CC7E	E6 C7		INC PTR+1
94		;		;
95	CC80	A5 04	INCL	LDA HIGH
96	CC82	C5 C6		CMP PTR
97	CC84	0C 04		BNE IPRET
				;NOT AT LIMIT

CARD #	LCC	CCCE	CARD
58			;
59	CC86	A5 C5	LDA HIGH+1
100	0088	C5 07	CMP PTR+1 ;Z=1 IF AT LIMIT
101			;
102	008A	60	IPRET RTS
103			;
104			;INCREMENT LCC & CHECK FOR LIMIT
105	0088	E6 CC	INCLOC INC LOC ;INCR
106	CC8D	CC 02	BNE INC2
107			;
108	008F	E6 01	INC LOC+1
109			;
110	CCS1	A5 C4	INC2 LDA HIGH ;CHECK
111	0093	C5 00	CMP LOC
112	CC95	DC C4	BNE ILRET
113	C097	A5 05	LDA HIGH+1
114	0099	C5 01	CMP LCC+1 ;Z=1 IF AT LIMIT
115			
116	009B	60	ILRET RTS

END OF MCS/TECHNOLOGY 6501 ASSEMBLY VERSION 3  
 NUMBER OF ERRORS = 0, NUMBER OF WARNINGS = 0

#### SYMBOL TABLE

SYMBOL	VALUE	LINE DEFINED	CROSS-REFERENCES									
HIGH	CCC4	15	95	59	110	113						
ILRET	009B	116	112									
INCLOC	CO88	105	69									
INCPTR	CG7A	50	32	60								
INC1	CO8C	55	51									
INC2	CCS1	110	106									
IPRET	CO8A	102	97									
LOC	CCCC	13	37	44	49	58	63	77	79	105	108	111
			114									
LCH	CO02	14	76	78	83	85						
MAC	CO1C	20	73									
ML1	CO22	30	33									
NEXTL	CO4E	60	42									
NCSTAR	CC5C	69	64									
CK1	CO3C	48	45									
CK2	CO44	53	50									
CK3	CC49	57	54									
PTR	CO06	16	31	41	43	48	84	86	90	93	96	100
RSTLLOC	CC6E	76	25	72								
RSTPTR	CO71	83	26	39								
TEST	CC28	36	70									
VLCOP	CO32	41	61									
WRT	72C2	12	21	23	66							

APPENDIX B

TIM PROGRAM LISTINGS

TIM VERSION 1.0 - MEM PAGE C  
 CARD # LCC CCDE CARD

```

2      ;  

3      ;      MOS TECHNOLOGY 650X TERMINAL INTERFACE MONITOR (TIM)  

4      ;      VERSION 1.0  AUGUST 31, 1975  

5      ;      COPYRIGHT 1975 MCS TECHNOLOGY  

6      ;      ALL RIGHTS RESERVED. UNAUTHORIZED USE  

7      ;      OF ALL OR PART STRICTLY PROHIBITED.  

8      ;-----  

9      ;  

10     ;      PROMPTING CHARACTER IS A PERIOD (.)  

11     ;-----  

12     ;  

13     ;  

14     ;      DISPLAY COMMANDS  

15     ;-----  

16     ;  

17     ;      .R      DISPLAY REGISTERS (PC,F,A,X,Y,SP)  

18     ;      .M      DISPLAY MEMORY ( 8 BYTES BEGINNING AT ADDR )  

19     ;  

20     ;  

21     ;      ALTER COMMAND (:)  

22     ;-----  

23     ;      :: DATA      ALTERS PREVIOUSLY DISPLAYED ITEM OR NEXT ITEM  

24     ;  

25     ;  

26     ;      PAPER TAPE I/O COMMANDS  

27     ;-----  

28     ;  

29     ;      .LH          LOAD HEX TAPE  

30     ;      .WB ADDR1 ADDR2      WRITE BNPF TAPE (FROM LOW ADDR1 TO HIGH ADDR2)  

31     ;      .WH ADDR1 ADDR2      WRITE HEX TAPE (FROM LOW ADDR1 TO HIGH ADDR2)  

32     ;  

33     ;      CONTROL COMMANDS  

34     ;-----  

35     ;  

36     ;      .G      GO, CONTINUE EXECUTION FROM CURRENT PC ADDRESS  

37     ;  

38     ;      .H      Toggles HIGH-SPEED-READER OPTION  

39     ;                  (IF ITS ON, TURNS IT OFF; IF OFF, TURNS ON)  

40     ;  

41     ;      BRK AND NMI ENTRY POINTS TO TIM  

42     ;-----  

43     ;  

44     ;      TIM IS NORMALLY ENTERED WHEN A 'BRK' INSTRUCTION IS  

45     ;      ENCOUNTERED DURING PROGRAM EXECUTION. AT THAT  

46     ;      TIME CPU REGISTERS ARE OUTPUT: PC F A X Y SP  

47     ;      AND CONTROL IS GIVEN TO THE KEYBOARD.  

48     ;      USER MAY ENTER TIM BY PROGRAMMED BRK OR INDUCED NMI. NMI  

49     ;      ENTRIES CAUSE A '*' TO PRECEDE THE '*' IN THE CPU REGISTER  

50     ;      PRINTOUT FORMAT  

51     ;  

52     ;      NON-BRK INTRO (EXTERNAL DEVICE) INTERRUPT HANDLING  

53     ;
  
```

## TIM VERSION 1.0 - MEM PAGE C

CARD #	LOC	CODE	CARD
54		;	
55		;	A NON-BRK INTREQ INTERRUPT CAUSES AN INDIRECT JUMP TO THE ADDRESS LOCATED AT 'UINT' (HEX FFF8). THIS LOCATION CAN BE SET
56		;	USING THE ALTER CMD, CR LOADED AUTOMATICALLY IN PAPER TAPE
57		;	FORM WITH THE LH CMD IF THE USER ASSIGNS HIS INTREQ INTERRUPT
58		;	VECTOR TO \$FFF8 IN THE SOURCE ASSEMBLY PROGRAM.
59		;	IF NOT RESET BY THE USER, UINT IS SET TO CAUSE EXTERNAL
60		;	DEVICE INTERRUPTS TO ENTER TIM AS NMI'S. I.E.,
61		;	IF A NMI OCCURS WITHOUT AN INDUCED NMI SIGNAL, IT IS
62		;	AN EXTERNAL DEVICE INTERRUPT.
63		;	
64		;	SETTING AND RESETTING PROGRAM BREAKPOINTS
65		;	-----
66		;	
67		;	BREAKPOINTS ARE SET AND RESET USING THE MEMORY DISPLAY
68		;	AND ALTER COMMANDS. BRK HAS A '00' OPERATION CODE.
69		;	TO SET A BREAKPOINT SIMPLY DISPLAY THE MEMORY LOCATION
70		;	(FIRST INSTRUCTION BYTE) AT WHICH THE BREAKPOINT IS
71		;	TO BE PLACED THEN ALTER THE LOCATION TO '00'. THERE IS
72		;	NO LIMIT TO THE NUMBER OF BREAKPOINTS THAT CAN BE
73		;	ACTIVE AT ONE TIME.
74		;	TO RESET A BREAKPOINT, RESTORE THE ALTERED MEMORY LOCATION
75		;	TO ITS ORIGINAL VALUE.
76		;	WHEN AND IF A BREAKPOINT IS ENCOUNTERED DURING EXECUTION,
77		;	THE BREAKPOINT DATA PRECEDED BY AN '#' IS DISPLAYED.
78		;	THE PROGRAM COUNTER VALUE DISPLAYED IS THE BRK
79		;	INSTRUCTION LOCATION + 1.
80		;	-----
81		;	
82		;	-----
83		;	
84		MDBK = %CCC1011C	; X,X,X,POR,DATA-AVAIL,GOT-DATA,SERIAL-OUT,IN
85		DAVAIL = \$08	
86		GOTCAT = \$C4	
87		ICPASE = \$6F00	
88		MPA = ICBASE+0	
89		MDA = IOBASE+1	
90		MPB = ICBASE+2	
91		MDB = ICBASE+3	
92		MCLK1T = IOBASE+4	
93		MCLKRD = ICBASE+4	
94		MCLKIF = IOBASE+5	
95		UINT = \$FFF8	
96		NCMDS = 7	
97		MPC = \$7000	
98		MP1 = \$7100	
99		MP2 = \$7200	
100		MP3 = \$7300	
101		;	
102		;	ZERO PAGE MONITOR RESERVE AREA
103		;	
104		CRDLY = 227	; DELAY FOR CR IN BIT-TIMES
105		WRAP = 228	; ADDRESS WRAP-AROUND FLAG

TIM VERSION 1.0 - MEM PAGE C

CARD #	LCC	CODE	CARD
106			DIFF = 229
107			HSPTR = 231
108			HSPCP = 232
109			PREVC = 233
110			MAJORT = 234
111			MINCRT = 235
112			ACMD = 236
113			TMPC = 238
114			TMP2 = 240
115			TMP4 = 242
116			TMP6 = 244
117			PCL = 246
118			PCH = 247
119			FLGS = 248
120			ACC = 249
121			XR = 250
122			YR = 251
123			SP = 252
124			SAVX = 253
125			TMPC = 254
126			TMPC2 = 255
127			RCNT = TMPC
128			LCNT = TMPC2
129		:	
130		;	64 BYTE RAM MONITER RESERVE AREA
131		;	
132		RAM64 = \$FFCC	
133	0000		*=RAM64

## MPO TIM PAGE 0

CARD #	LOC	CODE	CARD	
135			:	
136			:	
137			: TIM PAGE 0 (RELATIVE)	
138	FFC0		*=MPO	
139			:	
140	7000	85 F9	NMINT STA ACC	; SAVE A
141	7002	A9 23	LDA #'#	; SET A=# TO INDICATE NMINT ENTRY
142	7004	DC 55	BNE B3	; JMP B3
143			:	
144	7006	A9 16	RESET LCA #MDRK	; INIT DIR REG, PCR TO 1 RELOCATES
145			:	
146	7008	8D C3 6E	STA MDB	
147			:	
148	700B	A2 C8	LDX #8	; X=0
149	700D	BD F7 73	R1 LCA INTVEC-1,X	; INITIALIZE INT VECTORS
150	701C	9D F7 FF	STA UINT-1,X	
151	7013	CA	DEX	
152	7014	DO F7	BNE R1	
153			:	
154	7016	86 EA	STX MAJORT	; INIT MAJOR T COUNT TO ZERO
155	7018	86 E7	STX HS PTR	; CLEAR HS PTR FLAGS
156	701A	86 E8	STX HSRCP	
157	701C	CA	DEX	; X=FF
158	701D	9A	TXS	; SP=FF
159			:	
160			:	; COMPUTE BIT-TIME CONSTANT, X=FF
161			:	
162	701E	AC 01	LDY #1	; SET TC MEASURE 2 BITS
163	7020	84 E3	STY CRDLY	; INIT CR DELAY TIME PARAMETER
164	7022	AD C2 6E	R0 LCA MPB	; WAIT FOR FCR START
165	7025	4A	LSR A	
166	7026	9C FA	BCC R0	
167			:	
168	7028	8E 04 6E	R2 STX MCLK1T	; START CLOCK INITIALLY WITH FF
169	702B	AD 05 6F	R3 LCA MCLKIF	
170	702F	1C 04	BPL R4	
171	7030	E6 EA	INC MAJORT	; COUNT MAJOR T
172	7032	DC F4	BNE R2	; GC RESTART CLOCK WITH X = FF
173			:	
174	7034	98	R4 TYA	
175	7035	4D C2 6E	ECR MPB	
176	7038	29 01	AND #1	
177	703A	FC FF	REQ R3	; WAIT FOR Y BIT 0 AND SERIAL-IN NOT EQU
178	703C	88	DEFY	
179	703D	1C EC	PPL R3	; LOOP UNTIL START OF BIT 2
180			:	
181	703F	AD 04 6E	LCA MCLKRD	
182	7042	49 FF	ECR #\$FF	; COMPLEMENT RESIDUE
183	7044	4A	R5 LSR A	; HALF IT
184	7045	46 EA	LSR MAJORT	; HALF MAJOR
185	7047	9C 02	BCC R6	
186	7049	C9 80	ORA #\$80	; PROPAGATE HC TO LC

MPO TIM PAGE 0

CARD #	LOC	CODE	CARD	
187	704B	C8	R6	INY
188	704C	FC F6		BEG R5
189	704E	85 EB		STA MINORT
190		;		
191	7050	58		CLI
192	7051	CC		BRK
193		;		
194	7052	85 F9	INTRQ	STA ACC
195	7054	68		PLA
196	7055	48		PHA
197	7056	29 10		AND #\$10
198	7058	FC 27		BEG BX
199		;		
200	705A	CA		ASL A
201	705B	85 FE	B3	STA TMPC
202	705C	D8		CLD
203	705E	4A		LSR A
204		;		
205		;		
206	705F	86 FA		STX XR
207	7061	84 FB		STY YR
208	7063	68		PLA
209	7064	85 F8		STA FLGS
210	7066	68		PLA
211	7067	69 FF		ACC #\$FF
212	7069	85 F6		STA PCL
213	706B	68		PLA
214	706C	69 FF		ACC #\$FF
215	706E	85 F7		STA PCH
216	707C	EA		TSX
217	7071	86 FC		STX SP
218		;		
219	7073	20 8A 72	B5	JSR CRLF
220	7076	A6 FE		LDX TMPC
221		;		
222	7078	A9 2A		LCA #*
223	707A	20 CC 72		JSR WRTWO
224	707D	A9 52		LCA #*R
225	707F	DC 16		BNE SO
226		;		
227	7081	A5 F9	BX	LCA ACC
228	7083	6C F8 FF		JMP (UINT)
229		;		
230	7086	A9 00	START	LCA #0
231	7088	85 E7		STA HS PTR
232	708A	85 E4		STA WRAP
233	708C	20 8A 72		JSR CRLF
234	708F	A9 2E		LCA #*.
235	7091	20 C6 72		JSR WRCC
236	7094	20 E9 72		JSR RDOC
237		;		
238	7097	A2 06	SO	LDX #NCMDS-1
				; LOCK-UP CMD

MPO TIM PAGE 0

CARD #	LCC	CODE	CARD	
239	7099	DC 06 71	S1	CMP CMDS,X
240	7C9C	DC 19		BNE S2
241		:		
242	709E	A5 FD		LCA SAVX ; SAVE PREVIOUS CMD
243	70AC	85 E9		STA PREVC
244	7CA2	86 FD		STX SAVX ; SAVE CURRENT CMC INDEX
245	7CA4	A5 71		LCA #MP1/256 ; JMP INDIRECT TO CMC CODE
246	7CA6	85 ED		STA ACMD+1 ; ALL CMD CODE BEGINS ON MP1
247	7CA8	8C DC 71		LCA ADRS,X
248	7CAB	85 EC		STA ACMD
249	70AD	E0 03		CPX #3 ; IF :, R CR M (0, 1, CR 2) SPACE 2
250	70AF	P0 03		PCS IJMP
251	70B1	2C 74 73		JSR SPAC2
252		;		
253	7CB4	6C EC 00	IJMP	JMP (ACMD)
254		;		
255	7CB7	CA	S2	DEX
256	7CB8	1C DF		RPL S1 ; LOOP FOR ALL CMDS
257		;		
258	70BA	A9 3F	ERROPR	LCA #? ; OPERATOR ERR, TYPE '?', RESTART
259	70BC	20 C6 72		JSR WRCC
260	70BF	9C C5		BCC START ; JMP START (WRCC RETURNS CY=0)
261		;		
262	70C1	38	DCMP	SEC ; TMP2-TMPO DOUBLE SUBTRACT
263	70C2	A5 F0		LCA TMP2
264	70C4	F5 FE		SPC TMPO
265	70C6	85 E5		STA DIFF
266	70C8	A5 F1		LCA TMP2+1
267	70CA	E5 EF		SEC TMPO+1
268	70CC	A8		TAY ; RETURN HIGH ORDER PART IN Y
269	70CD	C5 E5		CRA DIFF
270	70CF	6C		RTS ; CR LC FOR EQU TEST
271		;		
272	7CDC	A5 FE	PUTP	LCA TMPO ; MOVE TMPO TO PCH,PCL
273	70D2	85 F6		STA PCL
274	70D4	A5 FF		LCA TMPO+1
275	70D6	85 F7		STA PCH
276	70D8	6C		RTS
277		;		
278	7CDS	A9 CC	ZTMP	LCA #C ; CLEAR REGS
279	70EB	95 EE		STA TMPC,X
280	7CDD	95 FF		STA TMPC+1,X
281	7CDF	6C		RTS
282		;		; READ AND STCRE BYTE. NO STORE IF SPACE OR RCNT=0.
283		;		
285	70EC	20 B3 73	BYTE	JSR RCOR ; CHAR IN A, CY=0 IF SP
286	70E3	9C 1C		RCC BY3 ; SPACE
287		;		
288	70E5	A2 00		LCA #C ; STORE BYTE
289	70E7	81 EE		STA (TMPO,X)
290		;		

## MPO TIM PAGE C

CARD #	LCC	CCDE	CARD	
291	7CE9	C1 FE	CMP (TMPO,X)	; TEST FCR VALID WRITE (RAM)
292	7CEB	F0 05	REQ BY2	
293	7CED	68	PLA	; ERR, CLEAR JSR ADR IN STACK
294	7CFF	68	PLA	
295	7CFF	4C BA 70	JMP ERRORPR	
296		;		
297	70F2	20 7C 72	BY2	JSR DADD
298	70F5	20 97 73	BY3	JSR INCTMP
299	70F8	C6 FE		DEC RCNT
300	70FA	60		RTS
301		;		
302	7CFB	A9 F8	SETR	LCA #FLGS
303	70FC	85 FE		STA TMPO
304	70FF	A9 00		LCA #0
305	71C1	85 FF		STA TMPO+1
306	7103	A9 05		LCA #5
307	71C5	60		RTS
308		;		
309	7106	3A	CMD\$	.BYTE ':'
310	7107	52		.BYTE 'R'
311	7108	4C		.BYTE 'M'
312	7109	47		.BYTE 'G'
313	710A	48		.BYTE 'H'
314	710B	4C		.BYTE 'L'
315	710C	57		.BYTE 'W' ; W MUST BE LAST CMD IN CHAIN
316	710D	3A	ADRS	.BYTE ALTER-MP1
317	71CE	14		.BYTE DSPLYR-MP1
318	71CF	1C		.BYTE DSPLYM-MP1
319	711C	5C		.BYTE GO-MP1
320	7111	6F		.BYTE HSP-MP1
321	7112	74		.BYTE LH-MP1
322	7113	C2		.BYTE WO-MP1

## MPI TIM PAGE 1

CARD #	LOC	CODE	CARD
324			;
325			;
326			; NOTE -- ALL CMD CODE MUST BEGIN ON MPI
327			;
328			; DISPLAY REG CMD - A,F,X,Y, AND SP
329			;
330	7114	20 A6 72	DSPLYR JSR WRPC ; WRITE PC
331	7117	2C FB 70	JSR SETR
332	711A	DC 07	BNE MC ; USE DSPLYM
333			;
334	711C	20 A4 73	DSPLYM JSR RDCA ; READ MEM ADR INTO TMPC
335	711F	90 16	BCC ERRS1 ; ERR IF NO ACCR
336	7121	A9 08	LDA #8
337	7123	85 FE	MO STA TMPC
338	7125	A0 0C	LDY #C
339	7127	2C 77 73	M1 JSR SPACE ; TYPE 8 BYTES OF MEM
340	712A	B1 EE	LDA (TMPO),Y ; (TMPO) PRESERVED FOR POSS ALTER
341	712C	20 B1 72	JSR WROB
342	712F	C8	INY ; INCR INDEX
343	7130	C6 FE	DEC TMPC
344	7132	D0 F3	BNE M1
345	7134	4C E6 7C	BEGS1 JMP START
346			;
347	7137	4C BA 7C	ERRS1 JMP ERRCPR
348			;
349			; ALTER LAST DISPLAYED ITEM (ADR IN TMPC)
350			;
351	713A	C6 E9	ALTER DEC PREVC ; R INDEX = 1
352	713C	D0 0D	BNE A3
353			;
354	713E	2C A4 73	JSR RDOA ; CY=C IF SP
355	7141	90 03	BCC A2 ; SPACE
356	7143	2C DC 7C	JSR PUTP ; ALTER PC
357	7146	20 FB 70	A2 JSR SETR ; ALTER R'S
358	7149	D0 C5	BNE A4 ; JMP A4 (SETR RETURNS ACC = 5)
359	714B	2C 9A 72	A3 JSR WROA ; ALTER M, TYPE ACR
360	714E	A9 08	LDA #8 ; SET CNT=8
361			;
362	7150	85 FE	A4 STA RCNT
363	7152	2C 77 73	A5 JSR SPACE ; PRESERVES Y
364	7155	2C E0 7C	JSR BYTE
365	7158	DC F8	BNE A5
366	715A	FC D8	A9 BEG BEGS1
367			;
368	715C	A6 FC	GO LDX SP
369	715E	9A	TXS ; CRIG CR NEW SP VALUE TO SP
370	715F	A5 F7	LCA PCH
371	7161	48	PHA
372	7162	A5 F6	LCA PCL
373	7164	48	PHA
374	7165	A5 F8	LCA FLGS
375	7167	48	PHA

## MPI TIM PAGE 1

CARD #	LCC	CODE	CARD	
376	7168	A5 F9		LDA ACC
377	716A	A6 FA		LDX XR
378	716C	A4 FB		LCY YR
379	716E	40		RTI
380			;	
381	716F	E6 E8	HSP	INC HSOP
382	7171	4C 86 70		JMP START
383			;	
384	7174	20 E9 72	LH	JSR RDCC
385	7177	2C 8A 72		JSR CRLF
386	717A	A6 E8		LDX HSOP
387	717C	86 E7		STX HS PTR
388	717E	2C E9 72	LH1	JSR RDCC
389	7181	C9 3B		CMP #' ;
390	7183	DC FS		BNE LH1
391			;	
392	7185	A2 04		LDX #4
393	7187	2C D9 70		JSR ZTMP
394	718A	2C B3 73		JSR RDOB
395	718C	DC 06		BNE LH2
396			;	
397	718F	A2 0C		LDX #0
398	7191	86 E7		STX HS PTR
399	7193	FC 9F		BEG BEQS1
400			;	
401	7195	85 FE	LH2	STA RCNT
402	7197	2C 7C 72		JSR DADD
403	719A	20 B3 73		JSR RDOB
404	719D	85 EF		STA TMP0+1
405	719F	2C 7C 72		JSR DADD
406	71A2	2C B3 73		JSR RDCC
407	71A5	85 EE		STA TMP0
408	71A7	2C 7C 72		JSR DADD
409			;	
410	71AA	2C EC 70	LH3	JSR BYTE
411	71AC	DC FB		BNE LH3
412	71AF	2C A4 73		JSR RDCC
413	71B2	A5 F2		LDA TMP4
414	71B4	85 FC		STA TMP2
415	71B6	A5 F3		LDA TMP4+1
416	71B8	85 F1		STA TMP2+1
417	71BA	2C C1 70		JSR DCMP
418	71BD	FC BF		BEG LH1
419	71BF	4C BA 70	ERRP1	JMP ERRORP
420			;	
421	71C2	2C E9 72	WD	JSR RDCC
422	71C5	85 FE		STA TMP2
423	71C7	2C 77 73		JSR SPACE
424	71CA	2C A4 73		JSR RDOA
425	71CC	2C 87 73		JSR T2T2
426	71CD	2C 77 73		JSR SPACE
427	71C3	2C A4 73		JSR RDOA

; TOGGLE BIT C  
; READ SECOND CMD CHAR  
; ENABLE PTR CPTION IF SET  
; FIND NEXT RCD MARK ( ; )  
; CLEAR CKSUM REGS TMP4  
; CLEAR HS RCR FLAG  
; FINISHED  
; RCNT  
; RCD LRGH TC CKSUM  
; SA HO TC TMP0+1  
; ADD TC CKSUM  
; SA LO TC TMP0  
; ADD TC CKSUM  
; BYTE SUB/R DECRS RCNT ON EXIT  
; CKSUM FRM HEX RCD TO TMP0  
; TMP4 TC TMP2 FOR DCMP  
; RD 2ND CMD CHAR  
; SA TC TMP2  
; SPACE BEFCRE NEXT ADDRESS

MP1 TIM PAGE 1

CARD #	LCC	CCDE	CARD	
428	71D6	2C 87 73	JSR T2T2	; SA TC TMP0, EA TC TMP2
429	71D9	20 E9 72	JSR RDOC	; DELAY FCR FINAL CR
430	71DC	A5 FE	LCA TMPC	
431		;		
432	71DE	C9 48	CMP #'H	
433	71EC	DC 59	BNE WB	
434		;		
435	71E2	A6 E4	WHO LDX WRAP	;IF ADDR HAS WRAPPED AROUND
436	71E4	DC 52	BNE BCCST	;THEN TERMINATE WRITE OPERATION
437		;		
438	71E6	2C 8A 72	JSR CRLF	
439	71E9	A2 18	LDX #24	
440	71EB	86 FE	STX RCNT	; RCNT=24
441	71ED	A2 04	LDX #4	; CLEAR CKSUM
442	71EF	20 D9 70	JSR ZTMP	
443		;		
444	71F2	A9 3B	LCA #'	
445	71F4	20 C6 72	JSR WROC	; WR RCD MARK
446		;		
447	71F7	2C C1 70	JSR DCMP	; EA-SA (TMPO+2-TMPO) DIFF IN LOC DIFF,+1
448	71FA	98	TYA	; MS BYTE OF DIFF
449	71FB	DC CA	PNE WH1	
450	71FD	A5 E5	LCA DIFF	
451	71FF	C9 17	CMP #23	
452	7201	BC C4	BCS WH1	; DIFF GT 24
453	7203	85 FE	STA RCNT	; INCR LAST RCNT
454	72C5	E6 FE	INC RCNT	
455	72C7	A5 FE	WH1 LCA RCNT	
456	7209	20 7C 72	JSR DADD	; ADD TO CKSUM
457	720C	20 B1 72	JSR WRCB	; RCC CNT IN A
458	720F	A5 EF	LCA TMPC+1	; SA HC
459	7211	20 7C 72	JSR CADD	
460	7214	20 B1 72	JSR WRCB	
461	7217	A5 EE	LCA TMPC	; SA LC
462	7219	20 7C 72	JSR CADD	
463	721C	20 B1 72	JSR WRCB	
464		;		
465	721F	AC CC	WH2 LDY #0	
466	7221	B1 EE	LDA (TMPO),Y	
467		;		
468	7223	20 7C 72	JSR CADD	; INC CKSUM, PRESERVES A
469	7226	20 R1 72	JSR WRCB	
470	7229	20 97 73	JSR INCTMP	; INC SA
471	722C	C6 FE	DEC RCNT	
472	722E	DC EF	BNE WH2	; LOOP FOR UP TO 24 BYTES
473		;		
474	723C	20 SE 72	JSR WRCA4	; WRITE CKSUM
475		;		
476	7233	20 C1 70	JSR DCMP	
477	7236	80 AA	BCS WHO	; LCCP WHILE EA GT CR = SA
478	7238	4C 86 70	BCCST JMP START	
479		;		

## MPI TIM PAGE 1

CARD #	LCC	CODE	CARD	
480			;	
481	723B	E6 FD	WB	INC SAVX ; SAVX TO = NCMDS FOR ASCII SUB/R
482	723D	A5 E4	WB1	LDA WRAP ; IF ADDR HAS WRAPPED ARCLINE
483	723F	00 F7		BNE BCCST ; THEN TERMINATE WRITE OPERATION
484			;	
485	7241	A9 04		LDA #4
486	7243	85 EC		STA ACMD
487	7245	2C 8A 72		JSR CRLF
488	7248	2C 9A 72		JSR WROA ; OUTPUT HEX ADR
489			;	
490	724B	2C 77 73	WBNPF	JSR SPACE
491	724E	A2 09		LDX #9
492	725C	86 FE		STX TMPC
493	7252	A1 E5		LDA (TMPC-9,X) ; LOOP CNT = 9
494	7254	85 FF		STA TMPC2 ; BYTE TO TMPC2
495	7256	A9 42		LDA #*B
496	7258	00 08		BNE WBF2 ; WRITE B
497			;	
498	725A	A9 5C	WBF1	LDA #*P
499	725C	C6 FF		ASL TMPC2
500	725E	BC C2		BCS WBF2
501	7260	A9 4E		LDA #*N
502			;	
503	7262	2C C6 72	WBF2	JSR WRCC ; WRITE N OR P
504	7265	C6 FE		DEC TMPC
505	7267	00 F1		BNE WBF1 ; LOOP
506	7269	A9 46		LDA #*F
507	726B	20 C6 72		JSR WROC ; WRITE F
508			;	
509	726E	2C 97 73		JSR INCTMP
510			;	
511	7271	C6 EC		DEC ACMD ; TEST FOR MULTIPLE OF FOUR
512	7273	00 D6		BNE WBNPF
513			;	
514	7275	2C C1 7C		JSR DCMP
515	7278	BC C3		BCS WB1 ; LOOP WHILE EA GT CR = SA
516	727A	9C BC		BCC BCCST
517			;	
518	727C	4F	DADD	PFA ; SAVE A
519	727D	18		CLC
520	727E	E5 F2		ADC TMP4
521	7280	85 F2		STA TMP4
522	7282	A5 F3		LDA TMP4+1
523	7284	69 00		ADC #0
524	7286	85 F3		STA TMP4+1
525	7288	6E		PLA ; RESTORE A
526	7289	6C		RTS
527			;	
528	728A	A2 0D	CRLF	LDX #\$0D
529	728C	A9 CA		LDA #\$0A
530	728E	20 C0 72		JSR WRTWC
531	7291	A6 E3		LDX CRDLY ; BIT-TIME COUNT FOR DELAY

MPI TIM PAGE 1

CARD #	LCC	CODE	CARD	
532	7293	20 1D 73	CR1	JSR DLY2 ;DELAY OF ONE BIT-TIME
533	7296	CA		DEX
534	7297	00 FA		BNE CR1
535	7299	6C		RTS
536		:		
537		:		; WRITE ADR FROM TMPC STORES
538		:		
539	729A	A2 01	WR0A	LDX #1
540	729C	00 0A		BNE WR0A1
541	729E	A2 05	WR0A4	LDX #5
542	72A0	00 06		BNE WR0A1
543	72A2	A2 07	WR0A6	LDX #7
544	72A4	00 02		BNE WR0A1
545	72A6	A2 09	WR0C	LDX #9
546	72A8	B5 ED	WR0A1	LCA TMPO-1,X
547	72AA	48		PHA
548	72AB	B5 EE		LCA TMPC,X
549	72AD	20 B1 72		JSR WR0B
550	72B0	68		PLA
551		:		
552		:		; WRITE BYTE - A = BYTE
553		:		; UNPACK BYTE DATA INTO TWO ASCII CHARS. A=BYTE; X,A=CHARS
554		:		
555	72B1	48	WR0B	PHA
556	72B2	4A		LSR A
557	72B3	4A		LSR A
558	72B4	4A		LSR A
559	72B5	4A		LSR A
560	72B6	20 58 73	JSR ASCII	; CONVERT TO ASCII
561	72B9	AA		TAX
562	72BA	68		PLA
563	72BB	29 CF		AND #\$0F
564	72BC	20 58 73	JSR ASCII	
565		:		
566		:		; WRITE 2 CHARS - X,A = CHAR
567		:		
568	72C0	48	WRTWO	PHA
569	72C1	8A		TXA
570	72C2	20 C6 72	JSR WRT	
571	72C5	6E		PLA
572		:		
573		:		; WRITE SERIAL OUTPUT
574		:		; A = CHAR TO BE OUTPUT
575		:		
576	72C6	20 1D 73	WRT	JSR DLY2
577	72C9	A2 09		LDX #9
578		WR0C	=WRT	
579	72CB	49 FF		FCR #\$FF ; COMPLEMENT A
580	72CD	38		SEC
581		:		
582	72CE	20 DA 72	WRT1	JSR CLT
583	72D1	20 1D 73		JSR DLY2

## MPI TIM PAGE 1

CARD #	LCC	CODE	CARD	
584	72D4	4A		LSR A
585	72D5	CA		DEX
586	72D6	DC F6		BNE WRT1
587	72D8	FC 3F		BEQ RDT5
588				; USE BNE?
589		;		
590	72DA	48	OUT	PHA ; SAVE A
591	72DB	AC 02 6E		LCA MPB ; OUTPUT BIT FROM CY
592	72DE	29 FD		AND #11111101
593	72EC	90 02		BCC OUT1
594	72E2	C9 02		ORA #00000010
595	72E4	8D C2 6E	OUT1	STA MPB
596	72E7	68		PLA ; RESTORE A
597	72E8	6C		RTS
598		;		
599		;		; OUTPUT RETURNS CHAR IN A
600		;		
601	72E9	A5 E7	RDT	LCA HS PTR ; TEST HS PTR CPTION
602	72FB	4A		LSR A
603	72EC	BC 4F		ECS RDHSR
604			RDOC	=RCT
605	72EE	A2 08		LDX #8
606		;		
607	72FC	AC C2 6E	RCT1	LCA MPB
608	72F3	4A		LSR A ; WAIT FOR START BIT
609	72F4	9C FA		BCC RDT1
610		;		
611	72F6	2C 20 73		JSR DLY1
612	72F9	20 DA 72		JSR CLT ; ECHO START BIT
613		;		
614	72FC	2C 1D 73	RCT2	JSR DLY2
615	72FF	AC C2 6E		LDA MPB ; CY = NEXT BIT
616	73C2	4A		LSR A
617	73C3	2C DA 72		JSR CLT ; ECHO
618		;		
619	73C6	C8		PHP ; SAVE ÈIT
620	73C7	98		TYA ; Y CONTAINS CHAR BEING FORMED
621	7308	4A		LSR A
622	73C9	28		PLP ; RECALL BIT
623	73CA	9C C2		BCC RDT4
624	730C	C9 80		ORA #\$80 ; ADD IN NEXT BIT
625	73CE	A8	RDT4	TAY
626	730F	CA		CEX
627	731C	DC EA		BNE RDT2 ; LOOP FOR 8 BITS
628	7312	49 FF		EOR #\$FF ; COMPLEMENT DATA
629	7314	29 7F		AND #\$7F ; CLEAR PARITY
630		;		
631	7316	2C 1D 73		JSR DLY2
632	7319	18	RDT5	CLC
633	731A	2C DA 72		JSR CLT ; AND DELAY 2 HALF-BIT-TIMES
634		;		
635	731D	2C 20 73	DLY2	JSR DLY1

## MPI TIM PAGE 1

CARD #	LOC	CODE	CARD	
636	7320	48	DLY1	PHA ; SAVE FLAGS AND A
637	7321	C8		PFP
638	7322	8A		TXA ; SAVE X
639	7323	48		PFA
640	7324	A6 EA		LCX MAJCRT
641	7326	A5 EB		LCA MINORT
642		;		
643	7328	8D C4 6E	DL2	STA MCLK1T
644		;		
645	732B	AC C5 6E	DL3	LCA MCLKIF 6F05
646	732E	10 FB		BPL DL3
647	7330	CA		DEX
648	7331	C8		PFP
649	7332	AD C4 6E		LCA MCLKRD 6F04
650	7335	28		PLP ; RESET TIMER INT FLAG
651	7336	10 F3		BPL DL3
652		;		
653	7338	68		PLA ; RESTORE REGS
654	7339	AA		TAX
655	733A	28		PLP
656	733B	68		PLA
657	733C	60	DLX	RTS
658		;		
659	733D	AC C2 6E	RDHSR	LCA MPB ; LCCP CN DATA AVAIL
660	7340	29 C8		AND #DAVAIL
661	7342	FC F9		BEC RDHSR
662		;		
663	7344	AE 00 6E		LCX MPA ; READ DATA
664	7347	AD C2 6E		LCA MPB ; SEND GCT-DATA PULSE
665	734A	C9 C4		ORA #GOTDAT
666	734C	8D C2 6E		STA MPB
667	734F	29 FB		AND #%11111011
668	7351	8D 02 6E		STA MPB
669	7354	8A		TXA
670	7355	29 7F		AND #\$7F
671	7357	60		RTS
672		;		
673	7358	18	ASCII	CLC
674	7359	69 06		ACC #6
675	735B	69 FC		ACC #\$FO
676	735D	90 C2		BCC ASC1
677	735F	69 C6		ACC #\$06
678		;		
679	7361	69 3A	ASCII	ACC #\$3A
680	7363	48		PFA
681	7364	C9 42		CMP #'B
682	7366	DC CA		BNE ASCX
683	7368	A5 FD		LCA SAVX
684	736A	C9 C7		CMP #NCMDS
685	736C	DC 04		BNE ASCX ; NOT WB CMD
686	736E	68		PLA
687	736F	A9 20		LCA #' ; FCR WB, BLANK B'S IN ADR

MP1 TIM PAGE 1

CARD #	LCC	CODE	CARD
688	7371	48	PFA
689	7372	68	ASCX PLA
690	7373	6C	RTS
691		:	
692	7374	20 77 73	SPAC2 JSR SPACE
693	7377	48	SPACE PFA ; SAVE A,X,Y
694	7378	6A	TYA
695	7379	48	PFA
696	737A	98	TYA
697	737B	48	PFA
698	737C	A9 20	LCA #1
699	737E	20 C6 72	JSR WRT ; TYPE SP
700	7381	68	PLA ; RESTCRE A,X,Y
701	7382	A8	TAY
702	7383	68	PLA
703	7384	AA	TAX
704	7385	68	PLA
705	7386	6C	RTS
706		:	
707	7387	A2 C2	T2T2 LDX #2
708	7389	B5 ED	T2T21 LCA TMPC-1,X
709	738B	48	PFA
710	738C	B5 FF	LCA TMP2-1,X
711	738E	95 ED	STA TMPC-1,X
712	7390	68	PLA
713	7391	95 FF	STA TMP2-1,X
714	7393	CA	DEX
715	7394	DC F3	RNE T2T21
716	7396	6C	RTS
717		:	
718			; INCREMENT (TMPC,TMPO+1) BY 1
719	7397	EE FF	INCTMP INC TMPO ;LCW BYTE
720	7399	FC 01	BEQ INCT1
721	739B	6C	RTS
722		:	
723	739C	EE EF	INCT1 INC TMPC+1 ;HIGH BYTE
724	739E	FC C1	BEQ SETWRP
725	73AC	6C	RTS
726		:	
727	73A1	E6 E4	SETWRP INC WRAP ;PCINTER HAS WRAPPED AROUND - SET FLAG
728	73A3	6C	RTS
729		:	
730			; READ HEX ACR, RETURN HO IN TMPO, LO IN TMPO+1 AND CY=1
731			; IF SP CY=0
732			;
733	73A4	20 B3 73	RDOA JSR RDCB ; READ 2 CHAR BYTE
734	73A7	9C C2	BCC RDOA2 ; SPACE
735		:	
736	73A9	85 EF	STA TMPO+1
737	73AB	20 B3 73	RDOA2 JSR RDDB
738	73AE	9C C2	BCC RCEXIT ; SP
739	73BC	85 EE	STA TMPO

MPI TIM PAGE 1

CARD #	LCC	CODE	CARD
740	73B2	6C	RDEXIT RTS
741		;	
742		;	READ HEX BYTE AND RETURN IN A, AND CY=1
743		;	IF SF CY=0
744		;	Y REG IS PRESERVED
745		;	
746	73B3	98	RDOC TYA ; SAVE Y
747	73B4	48	PHA
748	73B5	A9 00	LDA #0 ; SET DATA = 0
749	73B7	85 EC	STA ACMD
750	73B9	20 E9 72	JSR RDOC
751	73BC	C9 CD	CMP #\$0C ; CR?
752	73BE	DC C6	BNE RD0B1
753	73C0	68	PLA ; YES - GO TO START
754	73C1	68	PLA ; CLEANING STACK UP FIRST
755	73C2	68	PLA
756	73C3	4C 86 7C	JMP START
757		;	
758	73C6	C9 20	RCCB1 CMP #' ; SPACE
759	73C8	DC CA	BNE RCCB2
760	73CA	20 E9 72	JSR RDOC ; READ NEXT CHAR
761	73CD	C9 20	CMP #'
762	73CF	DC CF	BNE RCCB3
763	73D1	18	CLC ; CY=0
764	73D2	90 12	BCC RD0B4
765		;	
766	73D4	20 EB 73	JSR HEXIT ; TC HEX
767	73D7	CA	ASL A
768	73D8	CA	ASL A
769	73D9	CA	ASL A
770	73DA	CA	ASL A
771	73DB	85 EC	STA ACMD
772	73DC	20 E9 72	JSR RDOC ; 2ND CHAR ASSUMED HEX
773	73EC	20 EB 73	JSR HEXIT
774	73E3	C9 EC	ORA ACMD
775	73E5	38	SEC ; CY=1
776	73E6	AA	RDOB4 TAX
777	73E7	68	PLA ; RESTORE Y
778	73E8	A8	TAY
779	73E9	8A	TXA ; SET Z & N FLAGS FOR RETURN
780	73EA	6C	RTS
781		;	
782	73EB	C9 3A	HEXIT CMP #\$3A ; SAVE FLAGS
783	73EC	08	PHP
784	73EE	29 CF	AND #\$0F
785	73F0	28	PLP
786	73F1	90 C2	BCC HEX09 ; 0-9
787	73F3	69 C8	ADC #8 ; ALPHA ADD 8+CY=9
788	73F5	6C	HEXC9 RTS
789		;	
790	73F6		* = MP3+\$FE
791		;	

MP1 TIM PAGE 1

CARD #	LCC	CCDE	CARD	
792	73F8	00 70	INTVEC	•WCRD NMINT ; DEFAULT USER INTRQ TO NMINT
793	73FA	00 70		•WCRD NMINT
794	73FC	06 70		•WCRD RESET
795	73FE	52 70		•WCRD INTRQ
796			;	

END OF MCS/TECHNLOGY 6501 ASSEMBLY VERSION 3  
NUMBER OF ERRORS = 0, NUMBER OF WARNINGS = 0

## SYMBOL TABLE

SYMBOL	VALUE	LINE DEFINED	CROSS-REFERENCES						
ACC	00F9	120	140	194	227	376			
ACMD	00EC	112	246	248	253	486	511	749	714 774
ACRS	710D	316	247						
ALTER	713A	351	316						
ASCII	7358	673	560	564					
ASCX	7372	689	682	685					
ASC1	7361	679	676						
A2	7146	357	355						
A3	714B	359	352						
A4	7150	362	358						
A5	7152	363	365						
A9	715A	366							
BCCST	7238	478	436	483	516				
BEQS1	7134	345	366	399					
BY	7081	227	198						
BYTE	70E0	285	364	410					
BY2	70F2	297	292						
BY3	70F5	298	286						
B3	7C5B	201	142						
B5	7073	219							
CMD5	7106	309	239						
CRDLY	00E3	104	163	531					
CRLF	728A	528	219	233	385	438	487		
CR1	7293	532	534						
CADD	727C	518	297	402	405	408	456	459	462 468
CAVAIL	0008	85	660						
DCMP	70C1	262	417	447	476	514			
CIFF	00E5	106	265	269	450				
CLX	733C	657							
DLY1	732C	636	611	635					
DLY2	731C	635	532	576	583	614	631		
DL2	7328	643							
DL3	732B	645	646	651					
CSPLYM	711C	334	318						
CSPLYR	7114	330	317						
ERRORP	708A	258	295	347	419				
ERRP1	71PF	419							
ERRS1	7137	347	335						
FLGS	00F8	119	209	302	374				
GC	715C	368	319						
GOTDAT	CCC4	86	665						
H EXIT	73EB	782	766	773					
HEXC9	73F5	788	786						
HSP	71EF	381	320						
HS PTR	00E7	107	155	231	387	398	601		
HSROP	CCF8	108	156	381	386				
IJMP	70B4	253	250						
INCTMP	7397	719	298	470	509				
INCT1	739C	723	720						
INTRQ	7052	194	795						
INTVEC	73F8	792	149						

SYMBOL	VALUE	LINE DEFINED	CROSS-REFERENCES							
IOBASE	6ECC	87	88	89	90	91	92	93	94	
LCNT	0OFF	128								
LH	7174	384	321							
LH1	717E	388	390	418						
LH2	7195	401	395							
LH3	71AA	410	411							
MAJORT	COEA	110	154	171	184	64C				
MCLKIF	6E05	94	169	645						
MCLKRD	6EC4	93	181	649						
MCLK1T	6EC4	92	168	643						
MDA	6EC1	89								
MCB	6EC3	91	146							
MCBK	0016	84	144							
MINORT	COEB	111	189	641						
MPA	6EC0	88	663							
MPB	6EC2	90	164	175	591	595	607	615	659	664
MPC	70CC	97	138							
MP1	71CC	98	245	316	317	318	319	320	321	322
MP2	72CC	99								
MP3	73CC	100	790							
MC	7123	337	332							
M1	7127	339	344							
NCMDS	CCC7	96	238	684						
NMINT	70CC	140	792	793						
OUT	72DA	590	582	612	617	633				
CUT1	72E4	595	593							
PCH	COF7	118	215	275	370					
PCL	COFE	117	212	273	372					
FREVC	0CE9	109	243	351						
PUTP	70DC	272	356							
RAM64	FFCC	132	133							
RCNT	00FE	127	299	362	401	440	453	454	455	471
RDEXIT	73B2	74C	738							
RCFSR	733C	659	603	661						
RDCA	73A4	733	334	354	412	424	427			
RDOA2	73AB	737	734							
RCCB	73B3	746	285	394	403	406	733	737		
RDCB1	73C6	758	752							
RDCB2	73C4	766	759							
RCCB3	73EC	773	762							
RDOB4	73E6	776	764							
RCCC	72E9	6C4	236	384	388	421	429	75C	76C	772
RCT	72E9	6C1	604							
RCT1	72FC	6C7	6C9							
RCT2	72FC	614	627							
RCT4	73CE	625	623							
RCT5	7319	632	587							
RESET	7006	144	794							
RC	7022	164	166							
R1	70CC	149	152							
R2	7C28	168	172							
R3	7C2P	169	177	179						
R4	7034	174	17C							
R5	7044	183	188							

SYMBOL	VALUE	LINE DEFINED	CROSS-REFERENCES						
R6	7048	187	185						
SAVX	00FD	124	242	244	481	683			
SETR	7CFB	302	331	357					
SETWRP	73A1	727	724						
SP	C0FC	123	217	368					
SPACE	7377	693	339	363	423	426	490	692	
SPAC2	7374	692	251						
START	7086	230	260	345	382	478	756		
SC	7097	238	225						
S1	7099	239	256						
S2	7CB7	255	240						
TMPC	00FE	125	127	201	220	337	343	422	430
TMPC2	C0FF	126	128	494	499				
TMPG	C0FE	113	264	267	272	274	279	280	289
			340	404	407	458	461	466	493
									546
									548
									708
TMP2	C0FC	114	263	266	414	416	710	713	
TMP4	00F2	115	413	415	520	521	522	524	
TMP6	C0F4	116							
T2T2	7387	707	425	428					
T2T21	7389	708	715						
UINT	FFF8	95	150	228					
WE	7238	481	433						
WBF1	725A	498	505						
WBF2	7262	503	496	500					
WBNPF	7248	490	512						
WE1	723C	482	515						
WFC	71E2	435	477						
WF1	72C7	455	449	452					
WH2	721F	465	472						
WC	71C2	421	322						
WRAP	00E4	105	232	435	482	727			
WROA	729A	539	355	488					
WRC41	72A8	546	540	542	544				
WRC44	729E	541	474						
WROA6	72A2	543							
WRCB	72B1	555	341	457	460	463	469	549	
WROC	72C6	578	235	259	445	503	507		
WRPC	72A6	545	330						
WRT	72C6	576	570	578	699				
WRTWO	72C0	568	223	530					
WRT1	72CE	582	586						
XR	C0FA	121	206	377					
YR	C0FB	122	207	378					
ZTMP	70C9	278	393	442					

## INSTRUCTION COUNT

		1000-1010	1011-1020	1021-1030	1031-1040	1041-1050	1051-1060	1061-1070	1071-1080
ADC	9								
AND	9								
ASL	6								
BCC	15								
BCS	6								
BEQ	11								
BIT	0								
BMI	0								
BNE	33								
BPL	5								
BRK	1								
BVC	0								
BVS	0								
CLC	4								
CLD	1								
CLI	1								
CLV	0								
CMP	11								
CPX	1								
CPY	0								
DEC	6								
DEX	8								
DEY	1								
ECR	4								
INC	7								
INX	0								
INY	2								
JMP	9								
JSR	89								
LDA	65								
LCX	24								
LDY	4								
LSR	13								
NOP	0								
ORA	6								
PHP	18								
PHP	4								
PLA	23								
PLP	4								
RCL	0								
RTI	1								
RTS	19								
SBC	2								
SFC	3								
SED	0								
SEI	0								
STA	45								
STX	11								
STY	2								
TAX	4								
TAY	4								
TSX	1								
TXA	5								
TXS	2								
TYA	5								

