

The Harman Kardon

Model PA2200

STEREO POWER AMPLIFIER

Manual A

Technical Manual



The following marks found in the parts list of this manual identify the models as follows:

- BK : North America area model Black version**
- WB : World model Black version**
- IB : International model Black version**

harman/kardon

Service and Parts Department
240 Crossways Park West, Woodbury, N. Y. 11797
1112-PA2200-A P9401 1200 Printed in USA

SPECIFICATIONS**Continuous Average Power**

Per Channel (FTC), from 20 Hz to 20kHz, both Channels Driven

PA2200

8 Ohms 100 Watts @ < 0.08% THD

4 Ohms 100 Watts @ < 0.08% THD

8 Ohms 200 Watts @ < 0.08% THD

Bridged (FTC), from 20 Hz to 20kHz, Mono**Dynamic Power (IHF, 1kHz tone burst)**

High Voltage/High Current Mode:

8 Ohms 120 Watts

4 Ohms 190 Watts

2 Ohms 290 Watts

4 Ohms 120 Watts

2 Ohms 190 Watts

±80 Amperes

12dB

< 10Hz - 100kHz

0.1Hz - 250kHz

140 Volts/Sec

1.2 Sec 1.2 Sec

unmeasurable

100

118dB

0.8 volts/22kOhms

High Instantaneous Current Capability (HCC):**Negative Feedback:**

Power Bandwidth @ half-rated output, 8 Ohms

Frequency Response @ 1 Watt (+0/-3dB):**Slew Rate*:****Rise Time:****Transient Intermodulation Distortion (TIM):****Damping Factor:****Signal-to-Noise Ratio (ref rated power, A-Wtd):****Input Sensitivity/Impedance****Dimensions (W x H x D):**

inches: 173/8 x 53/8 x 145/8

mm: 443 x 137 x 372


LEAKAGE TEST (FOR SERVICE ENGINEERS IN THE U.S.A.)

Before returning the unit to the user, perform the following safety checks:

1. Inspect all lead dress to make certain that leads are not pinched or that hardware is not lodged between the chassis and other metal parts in the unit.
2. Be sure that any protective devices such as nonmetallic control knobs, insulating fishpapers, cabinet backs, adjustment and compartment covers or shields, isolation resistor-capacity networks, mechanical insulators, etc. which were removed for servicing are properly reinstalled.
3. Be sure that no shock hazard exists; check for leakage current using Simpson Model 229 Leakage Tester, standard equipment item No. 21641, RCA Model WT540A or use alternate method as follows: Plug the power cord directly into a 120-volt AC receptacle (do not use an Isolation Transformer for this test). Using two clip leads, connect a 1500 Ohm, 10-watt resistor paralleled by a 0.15 μ F capacitor, in series with all exposed metal cabinet parts and a known earth ground, such as a water pipe or conduit. Use a VTVM or VOM with 1000 Ohms per volt, or higher sensitivity to measure the AC voltage drop across the resistor (see diagram). Move the resistor connection to each exposed metal part having a return path to the chassis (antenna, metal, cabinet, screw heads, knobs and control shafts, escutcheon, etc.) and measure the AC voltage drop across the resistor. (This test should be performed with the power switch in both the On and Off positions.)

A reading of 0.35 volt RMS or more is excessive and indicates a potential shock hazard which must be corrected before returning the unit to the owner.

SIMPSON MODEL 229 ETC. FOR LEAKAGE TEST



DISASSEMBLY PROCEDURES

[1] CABINET TOP (131) REMOVAL

Remove 8 screws (A) and then remove the Cabinet Top (131).

[2] FRONT PANEL ASSEMBLY (AA) REMOVAL

1. Remove the Cabinet Top (131), referring to the previous step [1].
2. Remove 5 screws (B) and then remove the Front Panel Assembly (AA).

[3] CABINET BOTTOM (AC) REMOVAL

Remove 11 screws (C) and 2 washers (203), then remove the Cabinet Bottom (AC).

[4] MAIN P. C. BOARD (PCB-1) REMOVAL

1. Remove the Cabinet Top (131), referring to the previous step [1].
2. Remove 6 screws (G), then remove the Auto On/Off P.C. Board from the chassis.
3. Open the lid of connector (CN202) on the Auto On/Off P.C. Board (PCB-6), then disconnect lead wires (W202 and W203) from Main P.C. Board (PCB-1). Also open the lid of connector (CN403) on the Power Supply P.C. Board (PCB-2), then disconnect lead wires (JL403) from the Main P.C. Board (PCB-1).
4. Unsolder the lead wires (JL511, JL512, JL513 and JL514) from reference points (LCN511, LCN512, LCN513 and LCN514) on the Speaker P. C. Board (PCB-3).
5. Unsolder the lead wires (JL515, JL516, JL518, JL519 and JL527) from reference points (LCN515, LCN516, LCN518, LCN519 and LCN527) on the Power Supply P. C. Board (PCB-2). Also unsolder the lead wires (W201) from reference points (TM101, TM102 and TM103) on the Main P. C. Board (PCB-1).
6. Remove 1 screw (H), then remove Posistor (PT1) from HeatSink (181).
7. Remove 7 screws (D) and 2 spacers (198), then remove the Main P. C. Board (PCB-1) with HeatSink (181) from the chassis.

[5] POWER SUPPLY P.C. BOARD (PCB-2) REMOVAL

1. Remove 6 screws (G), then remove the Auto On/Off P.C. Board from the chassis.
2. Disconnect the connector with lead wire (CW221) from connector (CN221) on Auto On/Off P.C. Board (PCB-6).
3. Open the lid of connector (CN403) on the Power Supply P.C. Board (PCB-2), then disconnect lead wires (JL403) from the Main P.C. Board (PCB-1).
4. Disconnect the connector with lead wire (CW220) from connector (CN220) on the Led P.C. Board (PCB-7).
5. Unsolder the lead wires (JL515, JL516, JL518, JL519, JL524, JL525 and JL527) from reference points (LCN515, LCN516, LCN518, LCN519, LCN524, LCN525 and LCN527) on the Power Supply P. C. Board (PCB-2). Also unsolder the lead wires (JL522 and JL523) from reference points (TM104).

6. Remove 1 screw (H), then remove Posistor (PT1) from HeatSink (181).
7. Remove 5 screws (E), then remove the Power Supply P. C. Board (PCB-2) from the chassis.

[6] AUTO ON/OFF P.C. BOARD (PCB-6) REMOVAL

1. Remove the Cabinet Top (131), referring to the previous step [1].
2. Remove 6 screws (G), then remove the Auto On/Off P.C. Board from the chassis.
3. Open the lid of connector (CN202) on the Auto On/Off P. C. Board (PCB-6), then disconnect lead wires (W202 and W203) from Main P. C. Board (PCB-1).
4. Unsolder the lead wires (W201) from reference points (TM101, TM102 and TM103) on the Main P. C. Board (PCB-1).
5. Disconnect the connector with lead wire (CW205) from connector (CN205) on Led P. C. Board (PCB-7).
6. Disconnect the connector with lead wire (CW221) from connector (CN221) on Auto On/Off P. C. Board (PCB-6).

[7] LED P.C. BOARD (PCB-7) REMOVAL

1. Disconnect the connector with lead wire (CW205, CW206 AND CW220) from connector (CN205, CN206 and CN220) on Led P. C. Board (PCB-7).
2. Remove 2 screws (I), then remove the Led P. C. Board (PCB-7) from the chassis.

PROTECTION CIRCUIT

When the power switch is turned on, there will be no sound for about 8 seconds. This is the normal operation of the "Turn-on muting protection circuit" which protects the speaker systems from turn-on transients. After about 8 seconds, the amplifier will operate. It is suggested that the preamplifier volume control be set to a low level during the turn-on period. It is also advisable to turn on all other high fidelity components in the system before turning on the power amplifier. When a short circuit or a load of less than 2 ohms is placed across the speaker terminals for more than 4 milliseconds (4/1000 of a second), the protection circuit will activate and the amplifier will be muted for about 8 seconds. The muting will turn off and the amplifier will begin operating again after 8 seconds.

When the temperature of the internal heatsink rises too high, the protection circuit will activate and the amplifier will be muted. When the unit cools off, the amplifier will automatically become operational. However, unlike the turn-on and short circuit protection, the temperature protections may not restore operation in only 8 seconds because of the time required for the unit to cool off.

While you are connecting your power amplifier to the rest of your high fidelity system, please unplug the power cords of not only the power amplifier but all the components from the AC outlet.

AUTO-STANDBY FEATURE OPERATION

The PA2200 has a unique ability to sense when it is not receiving a music signal and it can automatically switch into a "Standby" mode. When this happens, the power amplifier circuitry completely shuts off and the front panel power indicator color changes from green (for "On") to amber (for "Standby"). When the amplifier again receives a music signal, it will return to the "On" state. The Auto-Standby feature instantly switches the amplifier "On", and switches it to "Standby" approximately 2 minutes after the incoming music signal stops. The 2 minute time before switching to "Standby" is to prevent the amplifier from unnecessarily switching between modes during use, or while the user is changing inputs or selecting software. This feature allows leaving the amplifier power switch in the "On" position when the amplifier is not in use. This can be a benefit in many systems and installations where the amplifier is not located within reach or is in another room. The "Auto-Standby" feature is also defeatable, for those customers that prefer the amplifier to behave in a conventional way. The "Auto-Standby" defeat switch is set in the "Off" position at the factory.


BRIDGED MONO OPERATION

This feature permits both amplifier channels to drive one 8Ω loudspeaker. To operate the amplifier in this way, set the $8\Omega/4\Omega$ switch in the 4Ω position, set the "Bridged Mono" switch in the "On" position and connect the amplifier's Left (Mono +) speaker terminal to the loudspeaker's "+" wire and the amplifier's Right (Mono -) speaker terminal to the loudspeaker's "-" wire.


Please note: The amplifier is not designed to drive a 4Ω speaker in the Bridged Mono mode.

POWER CORD REPLACEMENT (FOR SERVICE ENGINEERS OTHER THAN NORTH AMERICA)

In order to prevent fire or shock hazard when replacing the power cord, follow the procedure below to replace the parts with the standard supply parts.



GENERAL UNIT EXPLODED VIEW



GENERAL PARTS LIST

			Ref.No.	t No.	Description
AA	A443-PA2200B	FRONT PANEL ASSEMBLY BKWB	177	2. S-8350	METAL FITTING AC CORD PCB
AA	A443-PA2200C	FRONT PANEL ASSEMBLY WB			REAR (X2)
AB	A424-PA2200A	CABINET BACK ASSEMBLY BK	180	2222-7179	HEAT SINK, DRIVER (X2)
AB	A424-PA2200B	CABINET BACK ASSEMBLY WB	181	2222-7312	HEAT SINK, MAIN
AC	A423-PA2200A	CABINET BOTTOM ASSEMBLY BK	184	2222-7269	HEAT SINK, D1
AC	A423-PA2200B	CABINET BOTTOM ASSEMBLY WB	185	2222-7229	HEAT SINK, AUTO ON/OFF PCB
BA	B219-PA2200A	METAL FITTING ASSEMBLY BK	187	2240-7395	HOLDER, BRIDGE SW (X2)
BA	B219-PA2200B	METAL FITTING ASSEMBLY WB	188	2240-7359	HOLDER, 4/8 SWITCH
115	1751-01018	LABEL, BOTTOM (UL) BK	189	2240-R0101	HOLDER, WIRING (X20)
116	1756-11301	LABEL, FUSE CAUTION BK	191	2240-364	HOLDER, AC CORD
117	1756-R011N632	LABEL, 6.3A 125V BK	196	2360-7026	SPECIAL BOSS, LED PCB (X3)
119	1756-CSA	LABEL, CSA LABEL BK	198	2132-7136	SPACER, HEAT SINK METAL (X2)
131	1414-10401	CABINET TOP	200	2224-70900	INSULATOR, HEAT SINK METAL
133	1423-03101	CABINET BOTTOM	203	2401-0373	METAL WASHER, BOTTOM
134	1424-36601	CABINET BACK BK	204	2401-7373	METAL WASHER, BIAS PCB (X2)
134	1424-36603	CABINET BACK WB	206	2402-0374	PLASTIC WASHER, HEAT SINK (X4)
136	1443-14702	FRONT PANEL	210	2431-0151	FASTENER, BADGE (X2)
139	1714-02602	NAME PLATE, BADGE	213	2672-7018	LEVER, POWER SWITCH SHAFT
141	1562-08202	FRAME, L	217	224-7120	INSULATOR, AUTO ON/OFF PCB
142	1562-08702	FRAME, R	218	2459-3005511	PLASTIC RIVET, AUTO ON/OFF PCB
144	1732-08801	INDICATOR, POWER LED	220	2459-3003511	PLASTIC RIVET, AC CORD PCB (X2)
146	1662-66902	PUSH BUTTON, POWER	222	2347-R0140102	SPECIAL NUT, TRANS (X4)
154	1568-00301	FRAME, METAL (X2)	223	2327-R0126044	SCREW, BND+ (4X10 mm) (X4)
155	1742-08302	ORNAMENT, POWER	226	2327-R0130064	SCREW, BND+ (2.6X4 mm) (X4)
159	1319-03901	LEG, BOTTOM (X4)	229	2327-R0130062	SCREW, BND+ (3X6 mm) (X2)
161	2211-7324	CHASSIS, FRONT	231	2440-60	SCREW, BND+ (3X6 mm) (X2)
163	2219-8007	METAL FITTING, TRANS	232	2347-R0130102	NUT, SPECIAL
164	2219-8364	METAL FITTING, BOTTOM CENTER	234	2347-R0130062	SCREW, BND+ (3X10 mm)
165	2219-8009	METAL FITTING, RIGHT SIDE TOP	235	2347-R0130062	SCREW, BND T+ (3X6 mm) (X20)
166	2219-8010	METAL FITTING, TRANS SIDE	236	2347-R0130064	SCREW, BND T+ (3X6 mm) (X15)
167	2219-8011	METAL FITTING, RIGHT SIDE	237	2347-R0130082	SCREW, BND T+ (3X6 mm) (X9)
168	2219-8012	METAL FITTING, RIGHT INSIDE	238	2347-R0130084	SCREW, BND T+ (3X8 mm) (X11)
169	2219-8013	METAL FITTING, TRANS CENTER	240	2347-R0130102	SCREW, BND T+ (3X8 mm) (X10)
170	2219-8366	METAL FITTING, MAIN HEAT SINK	241	2347-R0140064	SCREW, BND T+ (3X10 mm) (X4)
171	2219-8367	METAL FITTING, MAIN HEAT SINK	242	2347-R0130062	SCREW, BND T+ (4X6 mm) (X6)
172	2219-8016	METAL FITTING, POWER SWITCH	244	2347-R0130062	SCREW, BND T+ (3X6 mm) (X4)
173	2219-8019	METAL FITTING, POWER SWITCH PCB	245	2347-R0130102	SCREW, BND T+ (3X6 mm) (X7)
175	2219-8365	METAL FITTING, POWER SUPPLY PCB	246	2347-R0130062	SCREW, BND T+ (3X10 mm) (X4)
176	2219-8349	METAL FITTING, AC CORD PCB SIDE	248	2557-300829	SCREW, B SPW+ (3X6 mm) (X2)
			249	2557-300829	SCREW, B SPW+ (3X8 mm) (X4)
			250	2557-301429	SCREW, B SPW+ (3X14 mm) (X8)

ALIGNMENT PROCEDURES**Conditions:**

Make the adjustment at a room temperature of 77F (25C).

DC BALANCE ADJUSTMENT

Step	Connection Equipments	Adjustment	For
1	Connect the Digital Volt Meter to TP405 and TP407.	VR401	0 ±10 mV
2	Connect the Digital Volt Meter to TP406 and TP407.	VR402	0 ±10 mV

IDLING CURRENT ADJUSTMENT

Step	Connection Equipments	Adjustment	For
1	Connect the Digital Volt Meter to TP401 and TP403.	VR401	33 mV
2	Connect the Digital Volt Meter to TP402 and TP404.	VR402	33 mV

DC BALANCE CONFIRMATION


Set the Speaker Operating Mode switch to the "4Ω" position.

Step	Connection Equipments	For
1	Connect the Digital Volt Meter to TP405 and TP407.	0 ±60 mV
2	Connect the Digital Volt Meter to TP406 and TP407.	0 ±60 mV


After the above adjustment, leave the unit with its power on for longer than 15 minutes and then repeat the same adjustment.


P.C. BOARDS (1)

PCB-2 Power Supply P.C. Board




PCB-1 Main P.C. Board







PCB-3 Speaker P.C.Board



4551-9130




PCB-4 Bias L P.C.Board



R80


PCB-5 Bias R P.C.Board




R80

P.C. BOARDS (2)

PCB-9 Power Switch P.C.Board




PCB-7 LED P.C.Board




PCB-1

51-915


PCB-6 Auto On/Off P.C.Board




Board




PCB-10 4/8 Switch P.C. Board

SPEAKER
OPERATING
MODE

PCB-11 Trans P.C. Board



PCB-8 Sub Power Supply P.C. Board



ELECTRICAL PARTS LIST

Ser. No.	Ref. No.	Part No.	Description	Ser. No.	Ref. No.	Part No.	Description
		PCB-1 MAIN PC BOARD		567	▲ R430	5102-5615116	RES, FUSE 560
				583	R431	5130-R030J562	RES, CBN 1/2P 5.6K
				583	R432	5130-R030J562	RES, CBN 1/2P 5.6K
				573	R433	5174-203381	RES, MTL 1/4P 20K
				573	R434	5174-203381	RES, MTL 1/4P 20K
				588	R435	5130-R030J123	RES, CBN 1/2P 12K
				588	R436	5130-R030J123	RES, CBN 1/2P 12K
		CAPACITORS		588	R437	5130-R030J123	RES, CBN 1/2P 12K
615	C25	5354-683J1HM	CAP, MYL .068μ	588	R438	5130-R030J123	RES, CBN 1/2P 12K
615	C26	5354-683J1HM	CAP, MYL .068μ	588	R439	5130-R030K222	RES, CBN 1/2P 2.2K
541	C401	5345-S19BM107	CAP, MINI ELE 100μ/10V	587	R440	5130-R030K222	RES, CBN 1/2P 2.2K
541	C402	5345-S19BM107	CAP, MINI ELE 100μ/10V	587	R441	5130-R030K222	RES, CBN 1/2P 2.2K
550	C403	5353-680534	CAP, MCA 68P	587	R442	5130-R030K222	RES, CBN 1/2P 2.2K
550	C404	5353-680534	CAP, MCA 68P	587	R443	5102-1815116	RES, FUSE 180
543	C405	5345-476D041	CAP, MINI ELE 47μ/25V	565	▲ R444	5102-1815116	RES, FUSE 180
543	C406	5345-476D041	CAP, MINI ELE 47μ/25V	565	▲ R445	5102-1815116	RES, FUSE 180
549	C407	5353-070934	CAP, MCA 7P	565	▲ R446	5102-1815116	RES, FUSE 180
549	C407	5353-070934	CAP, MCA 7P	565	▲ R447	5174-123381	RES, MTL 1/4P 12K
548	C409	5353-101534	CAP, MCA 100P	574	R448	5174-123381	RES, MTL 1/4P 12K
548	C410	5353-101534	CAP, MCA 100P	574	R449	5174-123381	RES, MTL 1/4P 12K
542	C411	5345-S19FM106	CAP, MINI ELE 10μ/50V	574	R450	5174-123381	RES, MTL 1/4P 12K
542	C412	5345-S19FM106	CAP, MINI ELE 10μ/50V	565	▲ R451	5102-1815116	RES, FUSE 180
544 ▲ C413		5345-337G0962	CAP, MINI ELE 330μ/63V	565	▲ R452	5102-1815116	RES, FUSE 180
544 ▲ C414		5345-337G0962	CAP, MINI ELE 330μ/63V	565	▲ R453	5102-1815116	RES, FUSE 180
544 ▲ C415		5345-337G0962	CAP, MINI ELE 330μ/63V	565	▲ R454	5102-1815116	RES, FUSE 180
544 ▲ C416		5345-337G0962	CAP, MINI ELE 330μ/63V	589	R455	5130-R030J151	RES, CBN 1/2P 150
542	C417	5345-S19FM106	CAP, MINI ELE 10μ/50V	589	R456	5130-R030J151	RES, CBN 1/2P 150
542	C418	5345-S19FM106	CAP, MINI ELE 10μ/50V	590	R457	5130-R030J391	RES, CBN 1/2P 390
547	C419	5354-104593	CAP, MYL .1μ	590	R458	5130-R030J391	RES, CBN 1/2P 390
547	C420	5354-104593	CAP, MYL .1μ	577	R459	5130-R030J131	RES, CBN 1/2P 130
547	C421	5354-104593	CAP, MYL .1μ	577	R460	5130-R030J131	RES, CBN 1/2P 130
547	C422	5354-104593	CAP, MYL .1μ	564	▲ R461	5102-2205711	RES, FUSE 22
		RESISTORS		564	▲ R462	5102-2205711	RES, FUSE 22
630	R27	5130-R030J472	RES, CBN 1/2P 4.7K	564	▲ R463	5102-2205711	RES, FUSE 22
630	R28	5130-R030J472	RES, CBN 1/2P 4.7K	564	▲ R464	5102-2205711	RES, FUSE 22
629	R29	5130-R030J472	RES, CBN 1/2P 4.7K	566	▲ R465	5102-1015116	RES, FUSE 100
629	R30	5130-R030J472	RES, CBN 1/2P 4.7K	566	▲ R466	5102-1015116	RES, FUSE 100
629	R31	5130-R030J472	RES, CBN 1/2P 4.7K	566	▲ R467	5102-1015116	RES, FUSE 100
629	R32	5130-R030J472	RES, CBN 1/2P 4.7K	566	▲ R468	5102-1015116	RES, FUSE 100
578	R33	5130-R030J223	RES, CBN 1/2P 22K	568	▲ R469	5102-2R25116	RES, FUSE 2.2
578	R34	5130-R030J223	RES, CBN 1/2P 22K	568	▲ R470	5102-2R25116	RES, FUSE 2.2
617	R35	5130-R030J152	RES, CBN 1/2P 1.5K	568	▲ R471	5102-2R25116	RES, FUSE 2.2
617	R36	5130-R030J152	RES, CBN 1/2P 1.5K	568	▲ R472	5102-2R25116	RES, FUSE 2.2
619	R37	5130-R030J105	RES, CBN 1/2P 1M	591	▲ R473	5102-1505116	RES, FUSE 15
619	R38	5130-R030J105	RES, CBN 1/2P 1M	591	▲ R474	5102-1505116	RES, FUSE 15
578	R41	5130-R030J223	RES, CBN 1/2P 22K	591	▲ R475	5102-1505116	RES, FUSE 15
578	R42	5130-R030J223	RES, CBN 1/2P 22K	591	▲ R476	5102-1505116	RES, FUSE 15
578	R45	5130-R030J223	RES, CBN 1/2P 22K	592	R477	5130-R030J100	RES, CBN 1/2P 10
578	R46	5130-R030J223	RES, CBN 1/2P 22K	592	R478	5130-R030J100	RES, CBN 1/2P 10
594	R401	5130-R030J102	RES, CBN 1/2P 1K	592	R479	5130-R030J100	RES, CBN 1/2P 10
594	R402	5130-R030J102	RES, CBN 1/2P 1K	592	R480	5130-R030J100	RES, CBN 1/2P 10
579	R403	5130-R030J223	RES, CBN 1/2P 22K	593	▲ R481	5102-6805116	RES, FUSE 68
579	R404	5130-R030J223	RES, CBN 1/2P 22K	593	▲ R482	5102-6805116	RES, FUSE 68
580	R405	5130-R030J683	RES, CBN 1/2P 68K	557	R483	5275-S040JR27	RES, CEM 5P .27
580	R406	5130-R030J683	RES, CBN 1/2P 68K	557	R484	5275-S040JR27	RES, CEM 5P .27
581	R407	5130-R030J122	RES, CBN 1/2P 1.2K	557	R485	5275-S040JR27	RES, CEM 5P .27
581	R408	5130-R030J122	RES, CBN 1/2P 1.2K	557	R486	5275-S040JR27	RES, CEM 5P .27
581	R409	5130-R030J122	RES, CBN 1/2P 1.2K	557	R487	5275-S040JR27	RES, CEM 5P .27
581	R410	5130-R030J122	RES, CBN 1/2P 1.2K	557	R488	5275-S040JR27	RES, CEM 5P .27
582	R411	5130-R030J181	RES, CBN 1/2P 180	557	R489	5275-S040JR27	RES, CEM 5P .27
582	R412	5130-R030J181	RES, CBN 1/2P 180	557	R490	5275-S040JR27	RES, CEM 5P .27
582	R413	5130-R030J181	RES, CBN 1/2P 180	558	R491	5173-150571	RES, MTL 2P 15
582	R414	5130-R030J181	RES, CBN 1/2P 180	558	R492	5173-150571	RES, MTL 2P 15
583	R415	5130-R030J562	RES, CBN 1/2P 5.6K	559	R493	5171-1R0572	RES, MTL 1P 1
583	R416	5130-R030J562	RES, CBN 1/2P 5.6K	559	R494	5171-1R0572	RES, MTL 1P 1
584	R417	5130-R030J331	RES, CBN 1/2P 330	595	R495	5130-R030J153	RES, CBN 1/2P 15K
584	R418	5130-R030J331	RES, CBN 1/2P 330	595	R496	5130-R030J153	RES, CBN 1/2P 15K
585	R419	5130-R030J393	RES, CBN 1/2P 39K	576	R497	5130-R030J223	RES, CBN 1/2P 22K
585	R420	5130-R030J393	RES, CBN 1/2P 39K	576	R498	5130-R030J223	RES, CBN 1/2P 22K
586	R421	5130-R030J473	RES, CBN 1/2P 47K	508	R499	5130-R030J181	RES, CBN 1/2P 180
586	R422	5130-R030J473	RES, CBN 1/2P 47K				
572	R423	5174-391381	RES, MTL 1/4P390				
572	R424	5174-391381	RES, MTL 1/4P390				
571	R425	5174-220381	RES, MTL 1/4P 22				
571	R426	5174-220381	RES, MTL 1/4P 22				
567 ▲ R427		5102-5615116	RES, FUSE 560				
567 ▲ R428		5102-5615116	RES, FUSE 560				
567 ▲ R429		5102-5615116	RES, FUSE 560				

Ser. No.	Ref. No.	Part No.	Description	Ser. No.	Ref. No.	Part No.	Description
TRANSISTORS							
604	Q9	5611-970(BL)	XISTOR, PNP R	538	L3	5597-35502	CORE, BEADS
604	Q10	5611-970(BL)	XISTOR, PNP R	538	L4	5597-35502	CORE, BEADS
605	Q401	5616-2SK364(V)	FET, N-CH	598	LCN511	5163-0130026	CONNECTOR W/W
605	Q402	5616-2SK364(V)	FET, N-CH	596	LCN512	4163-0130024	CONNECTOR W/W
511	Q403	5613-2240(BL)	XISTOR, NPN R	599	LCN513	4163-0130027	CONNECTOR W/W
511	Q404	5613-2240(BL)	XISTOR, NPN R	597	LCN514	4163-0130025	CONNECTOR W/W
511	Q405	5613-2240(BL)	XISTOR, NPN R	673	LCN515	4163-0120024	CONNECTOR W/W
511	Q406	5613-2240(BL)	XISTOR, NPN R	671	LCN516	4163-0120025	CONNECTOR W/W
515	Q407	5613-2320L(F)	XISTOR, NPN R	672	LCN518	4163-0120027	CONNECTOR W/W
515	Q408	5613-2320L(F)	XISTOR, NPN R	672	LCN519	4163-0120027	CONNECTOR W/W
515	Q409	5613-2320L(F)	XISTOR, NPN R	671	LCN527	4163-0120025	CONNECTOR W/W
515	Q410	5613-2320L(F)	XISTOR, NPN R	683	TM5	4214-11013	TERMINAL
517	Q411	5611-1145(Y)	XISTOR, PNP R	683	TM101	4214-11013	TERMINAL
517	Q412	5611-1145(Y)	XISTOR, PNP R	675	TM103	4214-11021	TERMINAL
514	Q413	5613-2240(BL)	XISTOR, NPN R	610	TP401	4214-132	TERMINAL
514	Q414	5613-2240(BL)	XISTOR, NPN R	610	TP402	4214-132	TERMINAL
512	Q415	5611-970(BL)	XISTOR, PNP R	610	TP403	4214-132	TERMINAL
512	Q416	5611-970(BL)	XISTOR, PNP R	610	TP404	4214-132	TERMINAL
513	Q417	5611-992(E)	XISTOR, PNP R	686		2240-Z032	HOLDER, JL403
513	Q418	5611-992(E)	XISTOR, PNP R				
514	Q419	5613-2240(BL)	XISTOR, NPN R				
514	Q420	5613-2240(BL)	XISTOR, NPN R				
535	Q421	5611-1285(F)	XISTOR, PNP R				
535	Q422	5611-1285(F)	XISTOR, PNP R				
516	Q423	5613-3245(F)	XISTOR, NPN R	634	C4	5352-1041957	CAP, MTL .1μ
516	Q424	5613-3245(F)	XISTOR, NPN R	634	C5	5352-1041957	CAP, MTL .1μ
535	Q425	5611-1285(F)	XISTOR, PNP R	640	△ C6	5341-002GM828	CAP, ELE
535	Q426	5611-1285(F)	XISTOR, PNP R	640	△ C7	5341-002GM828	CAP, ELE
516	Q427	5613-3245(F)	XISTOR, NPN R	640	△ C8	5341-002GM828	CAP, ELE
516	Q428	5613-3245(F)	XISTOR, NPN R	640	△ C9	5341-002GM828	CAP, ELE
520	Q429	5613-945(P)	XISTOR, NPN R	611	C10	5345-S19FM475	CAP, MINI ELE 4.7μ/50V
520	Q430	5613-945(P)	XISTOR, NPN R	612	C11	5345-S19CM336	CAP, MINI ELE 33μ/16V
518	Q433	5613-2235(Y)	XISTOR, NPN R	613	C12	5345-334593	CAP, MYL .33μ
518	Q434	5613-2235(Y)	XISTOR, NPN R	613	C13	5345-334593	CAP, MYL .33μ
519	Q435	5611-965(Y)	XISTOR, PNP R	616	C15	5359-3325851	CAP, PPP 3300P
519	Q436	5611-965(Y)	XISTOR, PNP R				
524	Q437	5611-1306(Y)	XISTOR, PNP R				
524	Q438	5611-1306(Y)	XISTOR, PNP R	621	R2	5130-R030J103	RES, CBN 1/2P 10K
521	Q439	5613-3298(Y)	XISTOR, NPN R	628	R3	5130-R030J472	RES, CBN 1/2P 4.7K
521	Q440	5613-3298(Y)	XISTOR, NPN R	625	R4	5130-R030J473	RES, CBN 1/2P 47K
527	Q441	5613-3907(O)	XISTOR, NPN R	624	R5	5130-R030J334	RES, CBN 1/2P 330K
527	Q442	5613-3907(O)	XISTOR, NPN R	622	R6	5130-R030J684	RES, CBN 1/2P 680K
529	Q443	5611-1516(O)	XISTOR, PNP R	627	R7	5130-R030J184	RES, CBN 1/2P 180K
529	Q444	5611-1516(O)	XISTOR, PNP R	623	R8	5130-R030J225	RES, CBN 1/2P 2.2M
527	Q445	5613-3907(O)	XISTOR, NPN R	620	R9	5130-R030J104	RES, CBN 1/2P 100K
527	Q446	5613-3907(O)	XISTOR, NPN R	620	R10	5130-R030J104	RES, CBN 1/2P 100K
529	Q447	5611-1516(O)	XISTOR, PNP R	621	R11	5130-R030J103	RES, CBN 1/2P 10K
529	Q448	5611-1516(O)	XISTOR, PNP R	620	R12	5130-R030J104	RES, CBN 1/2P 100K
512	Q449	5611-970(BL)	XISTOR, PNP R	625	R13	5130-R030J473	RES, CBN 1/2P 47K
512	Q450	5611-970(BL)	XISTOR, PNP R	626	R14	5130-R030J223	RES, CBN 1/2P 22K
				626	R15	5130-R030J223	RES, CBN 1/2P 22K
				625	R16	5130-R030J473	RES, CBN 1/2P 47K
				621	R17	5130-R030J103	RES, CBN 1/2P 10K
532	D401	5631-1S2473	DIODE, DET	626	R18	5130-R030J223	RES, CBN 1/2P 22K
532	D402	5631-1S2473	DIODE, DET	632	R21	5130-R030J822	RES, CBN 1/2P 8.2K
533	D403	5635-HZ15-1L	DIODE, ZENER	614	R25	5130-R030J152	RES, CBN 1/2P 1.5K
533	D404	5635-HZ15-1L	DIODE, ZENER	625	R26	5130-R030J473	RES, CBN 1/2P 47K
534	D405	5632-10DF2	DIODE, RECT	618	R39	5130-R030J332	RES, CBN 1/2P 3.3K
534	D406	5632-10DF2	DIODE, RECT	618	R51	5130-R030J332	RES, CBN 1/2P 3.3K
534	D407	5632-10DF2	DIODE, RECT	633	R227	5130-R030J104	RES, CBN 1/2P 100K
DIODES							
532	D401	5631-1S2473	DIODE, DET				
532	D402	5631-1S2473	DIODE, DET				
533	D403	5635-HZ15-1L	DIODE, ZENER				
533	D404	5635-HZ15-1L	DIODE, ZENER				
534	D405	5632-10DF2	DIODE, RECT				
534	D406	5632-10DF2	DIODE, RECT				
534	D407	5632-10DF2	DIODE, RECT				
534	D408	5632-10DF2	DIODE, RECT				
COILS							
537	L5	5991-7125	SPRING COIL	601	Q1	5613-1740S(S)	XISTOR, NPN R
537	L6	5991-7125	SPRING COIL	602	Q2	5611-933S(S)	XISTOR, PNP R
				601	Q3	5613-1740S(S)	XISTOR, NPN R
CONTROLS							
561	VR401	5101-S0801104	RES, SEMI FIX 100K, DC BALANCE	637	Q5	5613-1740S(S)	XISTOR, NPN R
561	VR402	5101-S0801104	RES, SEMI FIX 100K, DC BALANCE	602	Q7	5611-933S(S)	XISTOR, PNP R
562	VR403	5101-S0801102	RES, SEMI FIX 1K, IDLING CURRENT	603	Q8	5613-1845(E)	XISTOR, NPN R
MISCELLANEOUS							
751	CW205	4163-S0202751	CONNECTOR W/W	639	△ D1	5685-D5SB40	SILICON, BRIG
545	CW801	4163-S0202151	CONNECTOR W/W	608	△ D2	5636-1S2471	DIODE, SWITCH
545	CW802	4163-S0202151	CONNECTOR W/W	608	△ D3	5636-1S2471	DIODE, SWITCH
691	JL403	4242-R0503201	JUMPER LEAD	607	D4	5635-HZ6A2L	DIODE, ZENER
538	L1	5597-35502	CORE, BEADS	609	D5	5631-1S2473	DIODE, DET
538	L2	5597-35502	CORE, BEADS	641	D6	5631-1S2473	DIODE, DET
TRANSISTORS							
PCB-2 POWER SUPPLY PC BOARD							
CAPACITORS							
RESISTORS							
DIODES							
TRANSISTORS							
CONTROLS							
COILS							
MISCELLANEOUS							
DIODES							
TRANSISTORS							
PCB-2 POWER SUPPLY PC BOARD							
CAPACITORS							
RESISTORS							
DIODES							
TRANSISTORS							
CONTROLS							
COILS							
MISCELLANEOUS							
DIODES							
TRANSISTORS							
PCB-2 POWER SUPPLY PC BOARD							
CAPACITORS							
RESISTORS							
DIODES							
TRANSISTORS							
CONTROLS							
COILS							
MISCELLANEOUS							
DIODES							
TRANSISTORS							
PCB-2 POWER SUPPLY PC BOARD							
CAPACITORS							
RESISTORS							
DIODES							
TRANSISTORS							
CONTROLS							
COILS							
MISCELLANEOUS							
DIODES							
TRANSISTORS							
PCB-2 POWER SUPPLY PC BOARD							
CAPACITORS							
RESISTORS							

Ser. No.	Ref. No.	Part No.	Description	Ser. No.	Ref. No.	Part No.	Description				
MISCELLANEOUS											
681	CN403	4443-030185	CONNECTOR	728	△ R230	5102-1014713	RES, FUSE 100				
769	CW220	4163-S0203501	CONNECTOR W/W	719	R231	5130-R010J683	RES, CBN 1/6P 68K				
795	CW221	4163-S0203401	CONNECTOR W/W	719	R232	5130-R010J683	RES, CBN 1/6P 68K				
694	LCN524	4163-0117020	CONNECTOR W/W	726	R233	5130-R010J102	RES, CBN 1/6P 1K				
695	LCN525	4163-0125020	CONNECTOR W/W	725	R234	5130-R010J102	RES, CBN 1/6P 1K				
606	PT1	5192-010BD222	POSISTOR	726	R237	5130-R010J102	RES, CBN 1/6P 1K				
667	TM104	4214-11023	TERMINAL	732	R239	5130-R010J474	RES, CBN 1/6P 470K				
PCB-3 SPEAKER PC BOARD											
MISCELLANEOUS											
663	△ TM902	4214-241	TERMINAL, SPEAKERS	711	IC201	5652-TA75072P	IC, MONO				
				712	IC202	5653-BA335	IC, LINEAR				
PCB-4 BIAS L PC BOARD											
RESISTORS											
552	R802	5130-R030J222	RES, CBN 1/2P 2.2K	788	Q201	5614-1266(Q)	XISTOR, NPN A				
554	R804	5130-R030J122	RES, CBN 1/2P 1.2K	715	Q213	5611-933S(S)	XISTOR, PNP R				
				714	Q214	5613-1740S(S)	XISTOR, NPN R				
				713	Q215	5613-C144ES	XISTOR, NPN R				
				714	Q216	5613-1740S(S)	XISTOR, NPN R				
TRANSISTOR											
556	Q802	5613-2682(Q)	XISTOR, NPN R	737	D201	5635-HZ151L	DIODE, ZENER				
				716	D211	5631-1SS133	DIODE, DET				
				716	D212	5631-1SS133	DIODE, DET				
MISCELLANEOUS											
540	CN802	4443-0201140	CONNECTOR	716	D213	5631-1SS133	DIODE, DET				
				716	D214	5631-1SS133	DIODE, DET				
				716	D215	5631-1SS133	DIODE, DET				
				716	D216	5631-1SS133	DIODE, DET				
PCB-5 BIAS R PC BOARD											
RESISTORS											
551	R801	5130-R030J222	RES, CBN 1/2P 2.2K	740	CN202	4443-030185	CONNECTOR				
553	R803	5130-R030J122	RES, CBN 1/2P 1.2K	796	CN221	4443-0301140	CONNECTOR				
				739	HL201	2240-Z031	HOLDER				
				755	PJ201	4482-7128	2 PIN JACK, INPUT				
TRANSISTOR											
555	Q801	5613-2682(Q)	XISTOR, NPN R	757	SW202	4421-02601042	SLIDE SWITCH, AUTO STANDBY				
				758	SW203	4421-02602022	SLIDE SWITCH, BRIDGED MONO				
MISCELLANEOUS											
539	CN801	4443-0201140	CONNECTOR	PCB-7 LED PC BOARD							
669		2240-Z031	HOLDER	CAPACITOR							
PCB-6 AUTO ON/OFF PC BOARD											
CAPACITORS											
746	C203	5345-106D0961	CAP, MINI ELE 10μ/25V	771	R271	5130-R010J102	RES, CBN 1/6P 1K				
745	C204	5345-476C0961	CAP, MINI ELE 47μ/16V	772	R272	5130-R030J681	RES, CBN 1/2P 680				
718	C213	5359-S010J123	CAP, PPP .012μ	773	R273	5130-R030J104	RES, CBN 1/2P 100K				
718	C214	5359-S010J123	CAP, PPP .012μ	773	R274	5130-R030J104	RES, CBN 1/2P 100K				
747	C217	5345-475F0961	CAP, MINI ELE 4.7μ/50V	775	R275	5130-R030J473	RES, CBN 1/2P 47K				
747	C218	5345-475F0961	CAP, MINI ELE 4.7μ/50V	776	R276	5130-R030J473	RES, CBN 1/2P 47K				
744	C219	5345-226C0961	CAP, MINI ELE 22μ/16V	775	R278	5130-R030J473	RES, CBN 1/2P 47K				
745	C220	5345-476C0961	CAP, MINI ELE 47μ/16V	778	R279	5130-R010J104	RES, CBN 1/6P 100K				
718	C221	5359-S010J123	CAP, PPP .012μ	774	R280	5130-R030J154	RES, CBN 1/2P 150K				
742	C222	5354-104593	CAP, MYL .1μ	TRANSISTORS							
748	C223	5354-394593	CAP, MYL .39μ	762	Q271	5611-A124ES	XISTOR, PNP R				
745	C225	5345-476C0961	CAP, MINI ELE 47μ/16V	761	Q272	5613-C144ES	XISTOR, NPN R				
718	C226	5359-S010J123	CAP, PPP .012μ	760	Q273	5613-1740S(S)	XISTOR, NPN R				
717	C229	5345-337C041	CAP, MINI ELE 330μ/16V	761	Q274	5613-C144ES	XISTOR, NPN R				
745	C230	5345-476C0961	CAP, MINI ELE 47μ/16V	763	Q275	5611-933S(S)	XISTOR, PNP R				
C231		5345-105F0961	CAP, MINI ELE 1μ/50V	760	Q273	5613-1740S(S)	XISTOR, NPN R				
				761	Q277	5613-C144ES	XISTOR, NPN R				
				762	Q278	5611-A124ES	XISTOR, PNP R				
RESISTORS											
734	△ R200	5102-4704715	RES, FUS 47	DIODES							
734	△ R201	5102-4704715	RES, FUS 47	765	D270	5631-1S2473	DIODE, DET				
735	R202	5130-R030J822	RES, CBN 1/2P 8.2K	764	D271	5637-GL3ED8	LED, POWER				
727	R213	5130-R010J105	RES, CBN 1/6P 1M	765	D272	5631-1S2473	DIODE, DET				
727	R214	5130-R010J105	RES, CBN 1/6P 1M	766	D273	5631-1S133	DIODE, DET				
727	R215	5130-R010J105	RES, CBN 1/6P 1M	MISCELLANEOUS							
727	R216	5130-R010J105	RES, CBN 1/6P 1M	777	CN205	4443-0201140	CONNECTOR				
726	R221	5130-R010J102	RES, CBN 1/6P 1K	777	CN206	4443-0201140	CONNECTOR				
726	R222	5130-R010J102	RES, CBN 1/6P 1K	770	CN220	4443-0301140	CONNECTOR				
733	R223	5130-R030J104	RES, CBN 1/2P 100K								
724	R224	5130-R010J104	RES, CBN 1/6P 100K								
729	△ R225	5102-104713	RES, FUSE 100								
721	R226	5130-R010J473	RES, CBN 1/6P 47K								
720	R228	5130-R010J224	RES, CBN 1/6P 220K								
723	R229	5130-R010J224	RES, CBN 1/6P 220K								

FOR BK WB IB MODELS

 (also see **IB** addendum page 17)

PA2200

Ser. No.	Ref. No.	Part No.	Description	Ser. No.	Ref. No.	Part No.	Description
		PCB-8 LED PC BOARD		653	△ SW204	4464-00102022	SEESW SWITCH, SPEAKER OPERATING MODE
CAPACITORS							
783	C205	5345-107F041	CAP, MINI ELE 100μ/50V				
784	C206	5345-476C041	CAP, MINI ELE 47μ/16V				
RESISTORS							
787	R203	5130-R030J332	RES, CBN 1/2P 3.3K	666	△ P1	4161-71151	CORD W/PLUG BK
787	R204	5130-R030J332	RES, CBN 1/2P 3.3K	666B	△ P1	4161-7256	CORD W/PLUG WB
787	R205	5130-R030J332	RES, CBN 1/2P 3.3K	827	△ PCB-11	4551-9115	PC BOARD, TRANS
787	R206	5130-R030J332	RES, CBN 1/2P 3.3K	631	△ T1	5584-T0801	XFORMER, POWER BK
786	△ R207	5102-2205116	RES, FUSE 22	631B	△ T1	5584-T0803	XFORMER, POWER WB
786	△ R207	5102-2205116	RES, FUSE 22				
DIODES							
782	D202	5635-HZ12-2L	DIODE, ZENER	021		1756-06304	LABEL, 230V/50Hz WB
781	△ D205	5632-10DF2	DIODE, RECT	022		1756-03101	LABEL, (W)LABEL (X2) WB
781	△ D206	5632-10DF2	DIODE, RECT	027		1111-0370J152	OWNER GUIDE, VOLTAGE SELECTOR ADDENDUM WB
MISCELLANEOUS							
785	CW206	4163-S0202401	CONNECTOR W/W	107		1111-0670J152	OWNER GUIDE, IB
702	LCN200	4163-0114025	CONNECTOR W/W	108		1113-02501	OWNER CARD, REPLY CARD BK
703	LCN201	4163-0114027	CONNECTOR W/W	109		1116-03801	GUARANT CARD, WARRANTY BK
704	LCN203	4163-0114024	CONNECTOR W/W	110		1119-04501	ATTACH SHEET, SERVICE GUIDE BK
811	△ LCN204	4163-S5001130	CONNECTOR W/W BK			1119-01201	ATTACH SHEET, UL BK
811B	△ LCN204	4163-S5201300	CONNECTOR W/W WB			121	1241-R0123351
024B	LCN205	4163-S4901300	CONNECTOR W/W WB			122	1241-R0165751
023B	LCN206	4163-S5001300	CONNECTOR W/W WB			125	1221-897143
812	△ LCN207	4163-S4901130	CONNECTOR W/W BK			126	1222-7225
041B	△ SW205	4411-00501102	ROTARY SWITCH, VOLTAGE SELECTOR WB			127	1222-7226
						128	1223-R0420055

PCB-9 POWER SWITCH PC BOARD

			CAPACITORS
813	△ C201	5352-S010M103	CAP, MTL .01μ BK
813B	△ C201	5352-1030958	CAP, MTL .01μ WB
RESISTORS			
042B	△ R241	5130-R030J335	RES, CBN 1/2P 3.3M WB
MISCELLANEOUS			
812B	△ CN207	4163-S4901300	CONNECTOR W/W WB
636	△ F202	5732-632031	FUSE, 6.3A 125V BK
636B	△ F202	5732-01601312	FUSE, T3.15A 250V WB
804	△ HF201	4472-04501	FUSE HOLDER, F202
804	△ HF202	4472-04501	FUSE HOLDER, F202
651	△ SW201	4433-00401	SWITCH, PU-PW, POWER
779	△ TM201	4214-122	TERMINAL
779	△ TM202	4214-122	TERMINAL

PCB-10 4/8 SWITCH PC BOARD

			CAPACITORS
635	C250	5354-104593	CAP, MYL .1μ
635	C251	5354-104593	CAP, MYL .1μ
635	C252	5354-104593	CAP, MYL .1μ
635	C253	5354-104593	CAP, MYL .1μ
MISCELLANEOUS			
696	LCN250	4163-0114020	CONNECTOR W/W
697	LCN251	4163-0114021	CONNECTOR W/W
698	LCN252	4163-0114022	CONNECTOR W/W
699	LCN253	4163-0114023	CONNECTOR W/W
693	LCN522	4163-0125021	CONNECTOR W/W
700	LCN523	4163-0125023	CONNECTOR W/W

ABBREVIATIONS IN PARTS LIST
CAPACITORS

CAP, MINI ELE	: Electrolytic
CAP, CER	: Ceramic
CAP, PPP	: Polypropylene
CAP, MYL	: Mylar
CAP, MCA	: Mica
CAP, MINI BP	: Bipolar
CAP, ELE BP	: Electrolytic Bipolar
CAP, STY	: Polystyrene Film
CAP, SPE	: Special
CAP, TAN	: Tantalum
470μ	: 470μF
6800p	: 6800pF
.047μ	: 0.047μF

RESISTORS

RES, CBN 1/6P	: Carbon 1/6 W
RES, FUSE	: Fuse
RES, CEM 5P	: Cement 5W
RES, MTL 1P	: Metal 1W
2.2K	: 2.2KΩ
220	: 220Ω

TRANSISTORS

XISTOR	: Transistors
FET	: Field Effect Transistor

CONTROLS


RES, V CBN	: Variable Carbon Resistor
RES, SEMI FIX	: Semi-fixed Resistor

NOTE


△ SAFETY-RELATED COMPONENT. USE ONLY EXACT REPLACEMENT PART AS SPECIFIED.

P.C. BOARDS (1)



PCB-2 Power Supply P.C. Board





PCB-1 Main P.C. Board




PCB-3 Speaker P.C. Board



PCB-4 Bias L P.C. Board




PCB-5 Bias R P.C. Board




P.C. BOARDS (2)

PCB-9 Power Switch P.C. Board




PCB-7 LED P.C. Board




PCB-11



PCB-6 Auto On/Off P.C. Board




P.C. Board




PCB-10 4/8 Switch P.C. Board



PCB-8 Sub Power Supply P.C Board



GENERAL UNIT EXPLODED VIEW (B)



GENERAL UNIT PARTS LIST

Ser. No.	Ref. No.	Part No.	Description					
MISCELLANEOUS								
AA	A443-PA2200D	598C	LCN511	FRONT PANEL ASSEMBLY	4163-0122026	CONNECTOR W/W		
AB	A424-PA2200C	596C	LCN512	CABINET BACK ASSEMBLY	4163-0122024	CONNECTOR W/W		
AC	A423-PA2200C	693C	LCN522	CABINET BOTTOM ASSEMBLY	4163-0135021	CONNECTOR W/W		
BA	B219-PA2200C	700C	LCN523	METAL FITTG ASSEMBLY	4163-0135023	CONNECTOR W/W		
025	2219-8393	695C	LCN524	METAL FITTG	4163-0125020	CONNECTOR W/W		
026	2347-R0140082	045C	LCN622	SCREW, BND T+ (4x8mm)(X4)	4163-0130022	CONNECTOR W/W		
027	1756-21908	046C	LCN623	LABEL, DBP NO.	4163-0130020	CONNECTOR W/W		
117	1756-R01TS312	PCB-3 SPEAKER PC BOARD						
134	1424-36602	MISCELLANEOUS						
136	1443-14703	663C	△ TM902	159	1319-02301	4214-242	CABINET BACK	TERMINAL, SPEAKERS
184	2222-7269	PCB-6 AUTO ON/OFF PC BOARD						
203	2401-0473	CAPACITORS						
233	2347-R0130082	748	C223	5352-S110J394	5359-S010K151	5359-S010K151	SCREW, BND T+ (3X8mm) (X8)	CAP, MTL .39μ
236	2347-R0130064	047C	C425	5359-S010K151	5359-S010K151	5359-S010K151	SCREW, BND T+ (3X6mm) (X7)	CAP, PPP 150P
237	2347-R0130082	047C	C426	5359-S010K151	5359-S010K151	5359-S010K151	SCREW, BND T+ (3X8mm) (X12)	CAP, PPP 150P
238	2347-R0130084	RESISTORS						
248	2347-R0130082	048C	R217	5130-R030J561	5130-R030J561	5130-R010J101	SCREW, BND T+ (3X8mm) (X2)	RES, CBN 1/2P 560
249	2347-R0130082	048C	R218	5130-R030J561	5130-R030J561	5130-R010J101	SCREW, BND T+ (3X8mm)	RES, CBN 1/2P 560
		043C	R238	5130-R010J101	5130-R010J101	5130-R010J101	SCREW, BND T+ (3X8mm)	RES, CBN 1/6P 100

ELECTRICAL PARTS LIST**PCB-1 MAIN PC BOARD**

Ser. No.	Ref. No.	Part No.	Description	MISCELLANEOUS			
548	C409	5353-470534	CAP, MCA 47P	755	△ PJ201	4489-00103002	PIN JACK, MLT, INPUT

CAPACITORS

548	C410	5353-470534	CAP, MCA 47P
560	C431	5354-104593	CAP, MYL .1μ
560	C432	5354-104593	CAP, MYL .1μ

RESISTORS

594C	R401	5130-R030J561	RES, CBN 1/2P 560
594C	R402	5130-R030J561	RES, CBN 1/2P 560
579	R403	5130-R030J333	RES, CBN 1/2P 33K
579	R404	5130-R030J333	RES, CBN 1/2P 33K
585	R419	5130-R030J183	RES, CBN 1/2P 18K
585	R420	5130-R030J183	RES, CBN 1/2P 18K
572C	R423	5174-511381	RES, MTL 1/4P 510
572C	R424	5171-511381	RES, MTL 1/4P 510
588	R435	5130-R030J153	RES, CBN 1/2P 15K
588	R436	5130-R030J153	RES, CBN 1/2P 15K
588	R437	5130-R030J153	RES, CBN 1/2P 15K
588	R438	5130-R030J153	RES, CBN 1/2P 15K
574	R447	5174-153381	RES, MTL 1/4P 15K
574	R448	5174-153381	RES, MTL 1/4P 15K
574	R449	5174-153381	RES, MTL 1/4P 15K
574	R450	5174-153381	RES, MTL 1/4P 15K
595	R496	5130-R030J101	RES, CBN 1/2P 100
508	R499	5174-163381	RES, MTL 1/4P 16K

TRANSISTORS

605	Q401	5616-2SK366(V	FET, N-CH
605	Q402	5616-2SK366(V	FET, N-CH

MISCELLANEOUS

599C	LCN513	4163-0140027	CONNECTOR W/W
597C	LCN514	4163-0140025	CONNECTOR W/W

PCB-2 POWER SUPPLY PC BOARD

CAPACITORS			
640C	C6	5341-S33GM109	CAP, ELE 10000μ/63V
640C	C7	5341-S33GM109	CAP, ELE 10000μ/63V
640C	C8	5341-S33GM109	CAP, ELE 10000μ/63V
640C	C9	5341-S33GM109	CAP, ELE 10000μ/63V

DIODE

639C	△ D7	5685-D5SB40	SILICON, BRIG
------	------	-------------	---------------

Ser. No. Ref. No. Part No. Description

MISCELLANEOUS			
598C	LCN511	4163-0122026	CONNECTOR W/W
596C	LCN512	4163-0122024	CONNECTOR W/W
693C	LCN522	4163-0135021	CONNECTOR W/W
700C	LCN523	4163-0135023	CONNECTOR W/W
695C	LCN524	4163-0125020	CONNECTOR W/W
045C	LCN622	4163-0130022	CONNECTOR W/W
046C	LCN623	4163-0130020	CONNECTOR W/W
PCB-3 SPEAKER PC BOARD			
MISCELLANEOUS			
663C	△ TM902	4214-242	TERMINAL, SPEAKERS
PCB-6 AUTO ON/OFF PC BOARD			
CAPACITORS			
748	C223	5352-S110J394	CAP, MTL .39μ
047C	C425	5359-S010K151	CAP, PPP 150P
047C	C426	5359-S010K151	CAP, PPP 150P
RESISTORS			
048C	R217	5130-R030J561	RES, CBN 1/2P 560
048C	R218	5130-R030J561	RES, CBN 1/2P 560
043C	R238	5130-R010J101	RES, CBN 1/6P 100
PCB-8 SUB POWER SUPPLY PC BOARD			
MISCELLANEOUS			
702C	LCN200	4163-0115021	CONNECTOR W/W
703C	LCN201	4163-0115023	CONNECTOR W/W
704C	LCN203	4163-0115020	CONNECTOR W/W
024C	LCN205	4163-S4901300	CONNECTOR W/W
023C	LCN206	4163-S5001300	CONNECTOR W/W
041C	△ SW205	4411-00501102	ROTARY SWITCH, VOLTAGE SELECTOR
PCB-9 POWER SWITCH PC BOARD			
CAPACITOR			
813C	△ C201	5352-1030958	CAP, MTL .01μ
RESISTORS			
042C	△ R241	5130-R030J335	RES, CBN 1/2P 3.3M
MISCELLANEOUS			
636C	△ F202	5732-01601312	FUSE, T3.15A 250V
811C	△ LCN204	4163-S5201350	CONNECTOR W/W
812C	△ LCN207	4163-S4901160	CONNECTOR W/W
CHASSIS MISCELLANEOUS			
MISCELLANEOUS			
666C	△ P1	4161-09801192	CORD W/PLUG
631C	△ T1	5584-T0804	XFORMER, POWER
049C	C4	5352-1041957	CAP, MTL .1μ
049C	C5	5352-1041957	CAP, MTL .1μ
PACKAGE PARTS LIST			
DIODE			
1756-03108		LABEL, (I)LABEL (X2)	
1111-0680J152		OWNER GUIDE, IB	

ALIGNMENT PROCEDURES

■ Conditions:

Make the adjustment at a room temperature of 77F (25C).

■ DC BALANCE ADJUSTMENT

Step	Connection Equipments	Adjustment	For
1	Connect the Digital Volt Meter to TP405 and TP407.	VR401	-60 ±10 mV
2	Connect the Digital Volt Meter to TP406 and TP407.	VR402	-60 ±10 mV

■ IDLING CURRENT ADJUSTMENT

Step	Connection Equipments	Adjustment	For
1	Connect the Digital Volt Meter to TP401 and TP403.	VR403	40 mV
2	Connect the Digital Volt Meter to TP402 and TP404.	VR404	40 mV

■ DC BALANCE CONFIRMATION

Set the Speaker Operating Mode switch to the "4Ω" position.

Step	Connection Equipments	For
1	Connect the Digital Volt Meter to TP405 and TP407.	0 ±60 mV
2	Connect the Digital Volt Meter to TP406 and TP407.	0 ±60 mV

- After the above adjustment, leave the unit with its power on for longer than 15 minutes and then repeat the same adjustment.

A

1

C

1

1

SCHEMATIC DIAGRAM (1)

1

2

3

4


5

6

PCB-6 AUTO ON/OFF P.C.BOARD

Type	R1	R2
DTC144ES	47K	47K

Type	R1	R2
DTA124ES	22K	22K



**TO MAIN P.C.
BOARD(PCB-1)
SCHEMATIC
DIAGRAM(2)**

TO MAIN P.C.
BOARD(PCB-1)
SCHEMATIC
DIAGRAM(2)

PCB-7
LED P.C.BOAR





F

G

H

I

J

PCB-8**SUB POWER SUPPLY P.C. BOARD****PCB-10****4/8 SWITCH P.C. BOARD****PCB-9****POWER SWITCH P.C. BOARD****PCB-9****POWER SWITCH P.C. BOARD****NOTE:**

1. ALL RESISTANCES VALUES ARE IN Ω .
KD=1000 Ω , MD=1000 Ω .
2. THE WATTAGE OF RESISTORS IS 1/2W UNLESS OTHERWISE NOTED.
3. ALL CAPACITANCES VALUES ARE IN μF UNLESS OTHERWISE NOTED. P= μ F.
4. ...V DC VOLTAGE AT NO SIGNAL UNLESS OTHERWISE NOTED.
5. SAFETY REQUIREMENTS COMPONENTS IN ACCORDANCE WITH PRESENT SAFETY REGULATIONS. THESE COMPONENTS MUST ONLY BE REPLACED BY ORIGINAL PARTS.

FOR 1

A

B

C

D

E

SCHEMATIC DIAGRAM (1)

1

2



3

4

5

6


6




PCB-6 AUTO ON/OFF P.C.BOARD

Type	R1	R2
DTC144ES	47K	47K

Type	R1	R2
DTA124ES	22K	22K



PCB-7
LED P.C.B.



SCHEMATIC DIAGRAM (2)

A B C D E F G

PCB-1


MAIN P.C.B. BOARD

DC BALANCE ADJ. (Bch)

PCB-5

BIAS R.P.C. BOARD


六



N **M** **L** **K** **J** **I** **H** **G**


ENT ADJ. (Rch)

SPEAKER P.C.BOARD



NOTE:

1. ALL RESISTANCES VALUES ARE IN Ω .
 $KQ=1000Q$, $MQ=1000KQ$.
 2. THE WATTAGE OF RESISTORS IS $1/2W$ UNLESS OTHERWISE NOTED.
 3. ALL CAPACITANCES VALUES ARE IN μF UNLESS OTHERWISE NOTED. $P=\mu\mu F$.
 4. V:DG VOLTAGE AT NO SIGNAL UNLESS OTHERWISE NOTED.
 5. SAFETY REQUIREMENTS COMPONENTS IN ACCORDANCE WITH PRESENT



PCB-2


POWER SUPPLY P.C. BOARD

Mutina Protector

PCB-4


DING GIBBENT AD. I (I ch)

BIAS I PC BOARD



SAFETY REGULATIONS. THESE COMPONENTS MUST ONLY BE REPLACED BY ORIGINAL PARTS.

A small black triangle icon, likely a navigation or search symbol.



SCHEMATIC DIAGRAM (2)

A		B		C	D	E	F	G
---	--	---	--	---	---	---	---	---


PCB-1

MAIN P.C.BOARD

DC BALANCE ADJ. (Rch)

BIAS R P.C.BOARD



IDLING CURRENT ADJ. (Rch)




FOR ② MODEL

M L K J I H G

**PCB-3
SPEAKER P.C.BOARD**




CURRENT ADJ. (Rch)




NOTE:
1. ALL RESISTANCES VALUES ARE IN Ω.
2. KΩ=1000Ω. MΩ=10000Ω.


2. THE WATTAGE OF RESISTORS IS 1/2W UNLESS OTHERWISE NOTED.
3. ALL CAPACITANCES VALUES ARE IN μF UNLESS OTHERWISE NOTED. P=μμF.
4. ...V:DC VOL AGE AT NO SIGNAL UNLESS OTHERWISE NOTED.
5. SAFETY REQUIREMENTS COMPONENTS IN ACCORDANCE WITH PRESENT



5.  SAFETY REQUIREMENTS COMPONENTS IN ACCORDANCE WITH PRESENT SAFETY REGULATIONS, THESE COMPONENTS MUST ONLY BE REPLACED BY ORIGINAL PARTS.



WIRING DIAGRAM



3-2

CW220
(RED)LCN522
(RED)
TM104
(BLK) LCN524

(BLK) LCN525

LCN518
(WHT)
(RED)
(RED)
LCN516
(WHT)
LCN527

PCB-3

LCN513
(WHT)
(GRY)
(BLK)
(RED)LCN511
(WHT)LCN512
(BLK)LCN514
(RED)

PCB-6

W-201
(RED)
W-201
(BRN)
W-203
(WHT)
(GRY)
(BLK)
CN202
W-202
(BLU)
(GRY)
CN221
CW205
(RED)
(RED)

CW221

PCB-4

CN802
(RED) CW802
(RED)

PCB-1

CN802
(RED) CW802
(RED)

W-202 (GRY)


JL403



LCN514
(WHT)
(RED)LCN516
(WHT)
(RED)LCN518
(WHT)
(RED)LCN519
(WHT)
(RED)LCN527
(WHT)
(RED)LCN513
(WHT)
(RED)LCN515
(BLK)LCN511
(GRY)LCN512
(BLK)TM102 (RED)
(BRN)TM103
(WHT)TM5
(WHT)TM101
(GRY)W-203
(GRY)

PCB-5

CN801
(RED) CW801
(RED)


WIRING DIAGRAM






PCB 6

W-210 (BLK)



(E-103)



(E-107)

RED
CW 802

PCB 4

W-202 (GRY)

W-210 (BLK)

W-201 (BRN)

W-203 (GRY)

LCN 519 (WHT)
LCN 527 (RED)

MARK

LCN 518 (WHT)
LCN 516 (RED)

MARK

LCN 514 (RED)

MARK

LCN 513 (WHT)

MARK

LCN 515 (BLK)

MARK


TM102 (RED)

MARK

TM103

TM101 TM5 (WHT)

(E-105)



(E-107)

CW 801 (RED)

PCB 1