8051 family warm boot determinations

AN424

DESCRIPTION

For some classes of applications, it may be desirable to know if the application of the reset signal to a microcontroller is due to an initial power-on sequence, or is the result of an external signal such as an operator pressing a reset pushbutton, or the result of a watchdog timer or similar event.

While there are perhaps numerous hardware solutions that can be employed, a simple software solution can offer a high degree of confidence in making this determination. The task is to determine the differences in state of resources internal to the microcontroller that would occur as a result of these two types of reset conditions. With respect to the 80C51 family of microcontrollers, on-chip resources consist of the special function registers (SFRs) and the internal data memory (RAM). Most of the SFR locations are initialized as a result of a reset condition and thus cannot be used for this determination. The data memory contents are unaffected by reset. Thus, valid data loaded into the RAM of the 80C51 while executing a program would not be affected by the application of an external reset signal provided the power source for the microcontroller has not been removed (as is the case for a "warm boot").

The contents of data memory as a result of an initial application of power, however, is indeterminate. While this effect has not been extensively characterized, empirical observation suggests that it is highly random in nature. If it is assumed, for the moment, that the behavior of a given byte of data memory is such that it will power-up with a value that is totally random, then there is a one in eight chance that it will power-up with a predetermined value. If the assumption is extended to two bytes, a 16-bit number, then there is one in 2^{16} chance that both bytes will power-up with predetermined values. Extending this to four bytes results in a one in 2^{32} chance; a very small probability. This is the basis for the software determination of a warm or cold boot condition.

The technique consists of evaluating the contents of four consecutive bytes of data memory following a reset condition to determine whether these bytes had been previously loaded with known data values. If the contents of all four bytes match predetermined values, this is interpreted to be a warm boot condition. If there is no match, it is then interpreted to be a cold boot condition. At this point, it is necessary to load these four bytes with predetermined data to prepare for the possibility of a subsequent warm boot condition.

The software example included in this application brief can be used to perform this warm or cold boot determination.

The symbols WARM1 thorough WARM4 represent the predetermined values. The symbol WARM is the address of the first of the four consecutive bytes in data memory. It is set to 30H to avoid conflict with the four register banks, the stack, and the bit-addressable locations in data memory. The symbol WARMBT is a bit-addressable location used as a status bit. It is set as the result of a warm boot and cleared as a result of a cold boot.

The label START is the location of the first instruction to be executed following a reset (address = 0000H). An instruction is located here to jump into the main body of the program to bypass the interrupt vector locations.

The main program body begins by loading register R0 with the address of the first byte in data memory to be evaluated. The contents of this first byte is compared with the first predetermined value. If there is no match, the conclusion is that it is a cold boot. However, if a match is found, this does not imply that it is a warm boot since all four bytes must match, and therefore the remaining three bytes must also be evaluated. Register R0 is incremented to point to the second byte and then compared to the second predetermined value. Comparison of the bytes proceeds until either a no match condition is found or until all four bytes have been evaluated successfully. If all four bytes compared favorable, then a status bit (WARMBT) is set to indicate a warm boot and the remainder of the application program is completed.

An unsuccessful comparison results in branching to the label COLD. This section of code clears the status bit (WARMBT) to indicate a cold boot, and loads the four bytes of data memory with the predetermined values preparing the system for a subsequent possible warm boot. Program flow then continues with the remainder of the application program.

8051 family warm boot determinations

AN424

	1				
	1				
	2	/warni L	boot ap	plication example	
0.0.2.0	3 4	LIN DM	TIOU	2011	first leasting of the four buton in DAM
0030		WARM	EQU	30H	; first location of the four bytes in RAM
0055	5	WARM1	EQU	55H	first predetermined value
AA00	6	WARM2	EQU	OAAH	;second predetermined value
0033	7	WARM3	EQU	33H	;third predetermined value
00CC	8	WARM4	EQU	0CCH	;fourth predetermined value
0000	9	WARMBT	EQU	0	;warm boot status bit
	10				
0000	11		ORG	0	
	12				
0000 020026	13	START:	JMP	MAIN	;bypass interrupt vectors
	14				
0026	15		ORG	26H	
	16				
0026 7830	17	MAIN:	MOV	R0,#WARM	;pointer for first byte
0028 B65511	18		CJNE	<pre>@R0,#WARM1,COLD</pre>	;test first byte
002B 08	19		INC	R0	;pointer for second byte
002C B6AA0D	20		CJNE	@R0,#WARM2,COLD	;test second byte
002F 08	21		INC	R0	;pointer for third byte
0030 B63309	22		CJNE	<pre>@R0,#WARM3,COLD</pre>	;test third byte
0033 08	23		INC	R0	;pointer for fourth byte
0034 B6CC05	24		CJNE	<pre>@R0,#WARM4,COLD</pre>	;test fourth byte
0037 D200	25		SETB	WARMBT	;this is a warm start
0039 02004B	26		JMP	INIT	;continue with rest of application
003C C200	27	COLD:	CLR	WARMBT	;this is a cold boot
003E 7830	28		MOV	R0,#WARM	;pointer for first byte
0040 7655	29		MOV	@R0,#WARM1	;load the four bytes for future test
0042 08	30		INC	R0	;
0043 76AA	31		MOV	@R0,#WARM2	;
0045 08	32		INC	R0	;
0046 7633	33		MOV	@R0,#WARM3	;
0048 08	34		INC	R0	;
0049 76CC	35		MOV	@R0,#WARM4	;
004B	36	INIT:			;continue with the application
	37				
	38	END			
ASSEMBLY COMPLETE,	0 ERRORS	5 FOUND			
COLD		~	ADDR	003CH	
INIT			ADDR	004BH	
MAIN			ADDR ADDR	004BH 0026H	
MAIN			ADDR ADDR	0020H 0000H NOT USED	
WARM			NUMB	0030H NOI USED	
WARM			NUMB		
			NUMB	0055H 00AAH	
WARM2		• • •	NUMB	0022U	

 WARM3.
 .
 .
 .
 NUMB
 0033H

 WARM4.
 .
 .
 .
 .
 NUMB
 00CCH

 WARMBT
 .
 .
 .
 .
 .
 NUMB
 0000H