

BENCH BRIEFS

SERVICE INFORMATION FROM HEWLETT-PACKARD

4th Quarter 1987

Digital-to-Analog (DAC) Conversion

When a number is expressed in binary or binary-coded decimal and an analog voltage is to be produced to represent the number, the most practical way to perform this conversion is to add the currents having values proportional to the weights of the binary bits. Figure 1 represents a simplified binary weighted D/A converter. Switches S1 to SN represent the binary bits and connect either to ground or a reference voltage. Figure 1 shows switch S1 connecting R to the reference voltage and all other switches connected to ground; but since point A is a virtual ground, there is no current through 2R, 4R, up to $2^{N-1}R$. The amplifier has, therefore, a gain of $\frac{-5K}{10K} = -0.5$. If the reference voltage is -16V, the output voltages will be: R = 8V, 2R = 4V, 4R = 2V and for 8R = 1V. If S1 and S2 connect to the reference (the other switches to ground), the gain is $\frac{-5K}{6.66K} = 0.75$ and the output voltage 12V. The output is inversely proportional to the value of R.

The disadvantage of the circuit is high-value resistors representing low-weight bits. A better solution is a ladder configuration for groups of four bits as shown in Figure 2. Between each group of four resistors that represent weights of 1-2-4-8, there is a resistor that reduces the gain of the amplifier by 16 for binary and by 10 for BCD weights. This eliminates the need for high value resistors.

The D/A conversion is further simplified with the ladder circuit shown in Figure 3. Note that only values R and 2R are required.




Figure 1. Simplified DAC




Figure 2. Ladder configuration DAC

If the reference voltage itself is variable or controlled by another D/A converter, this circuit is referred to as a multiplying DAC. The output of such a combination is proportional to the product of the reference voltage and the digital input number.

A four-quadrant multiplying DAC refers to a circuit where the reference voltage as well as the number represented can be of either polarity, and

the output polarity obeys the rules of algebraic signs.

Figure 4 shows an inverted R/2R ladder DAC. The function is identical to Figure 3 but since the reference supply voltage is not switched, the specification of the switches can be relaxed. Figure 4 represents the configuration most often used in integrated circuit DACs.

Figure 5 is an example of a 3-digit BCD digital-to-analog converter with dual polarity output. The 3-digit number is stored in registers U2, U4 and U5. U5 drives the most significant bits. Because the on-resistance of U5 is high compared to the resistance values of the ladder network, buffer U7 is inserted. The U3 summing amplifier produces the negative output and U1 the positive output. Polarity switching is accomplished by FET switches Q6 and Q7. □




Figure 3. Ladder configuration DAC




Figure 4. Simplified ladder configuration DAC (reference voltage not switched)




Figure 5. Actual DAC circuit

READERS' CORNER

Third Grade Material?

The article on semiconductors in the 3rd Quarter 1987 issue of Bench Briefs was on a third grade level. This would be of no help to service technicians.

Those with only a military or trade school training may need such assistance, but such training is no longer acceptable to most firms. Two years of intensive college training leading to the Associate Degree are now required.

Many firms have examined the proper use of legitimate, degreed technicians, and have increased entry pay scales to more competitive levels.

Service technicians who must work on complex electronic equipment need a solid publication with advanced theory and troubleshooting information—NOT a third grade science lesson.

Glen W. Spielbauer
Texas

In years of correspondence with Bench Briefs' readers I have found wide and varied backgrounds, many with only the military or trade school training you mention. And, judging from the requests for article reprints and general comments on articles, I find that basic and fundamental topics generate the most interest. The common thread running through all correspondence is that in this highly specialized world we live in, a lot of the basic fundamentals have been forgotten.

It is impossible to write an article that will appeal to all readers. So I hope you will be patient and watch for something more to your liking.

Editor

The Rotary Pulse Generator

I must commend the author and inventor of the Rotary Pulse Generator (Bench Briefs 2nd Quarter 1987). I detest a noisy control and the scratch from an old phonograph record. Bet you are too young to remember the phonograph that played on a beam of light—built by Philco before WWII. No scratch!

But, I'm having some difficulty controlling the RPG. When I spin the control knob

(perhaps it has an inertia wheel) my mind's eye tells me I must put on the brakes and either advance some more or back up. This is not too bad I guess. However, I have another idea.

Mount a lamp in a cylinder or behind a disc having a wedge-shaped window. The first increment of rotation either right or left brings the light to shine on a phototransistor. The first contact of light increments the count up or down by one. Each phototransistor could serve as a gate for a pulse generator. The pulse generator frequency is to be controlled by the wedge-shaped beam of light by also falling on a photoresistor. The photoresistor will only "see" light after the control is moved past the first increment position.

I'll look for your comments in Bench Briefs.

Signed,

□ I²R-R+L²
Florida

It looks to me that the more detailed diagram of the RPG in the 3rd Quarter Bench Briefs is very close to the circuit you are describing. The main difference being your photoresistors determining speed. An interesting concept.

Editor

Replacement Part Cross Reference

When selecting replacement parts for your HP products, you may notice that many manuals list only an HP part number for the part, even though it appears that this part is manufactured by one of the large semiconductor manufacturers. Service personnel often ask why only HP part numbers are listed.

It is recommended that HP replacement parts be used to ensure that the original performance of the product will be obtained. While some parts used in HP instruments are identical to that which can be purchased at a local electronics distributor, many times parts will be selected for certain characteristics, such as gain, bandwidth, capacitance, etc. There may also be slight mechanical differences, such as the shaping or length of leads, and in

some cases special quality checks are employed to ensure that only the highest reliability parts are used.

Therefore, we suggest obtaining replacement parts from HP to maintain the quality that you have paid for in your instrument. There may be situations however, where HP replacement parts are not in stock and substituting parts will allow you to return the product to service immediately. In these cases it may be worthwhile to see if a substitute part will work in the circuit. Perhaps an HP part could be ordered and installed at some later date.

To help you in these situations, here is a cross-reference of HP integrated circuit part numbers to manufacturers "generic type" part numbers (whom in most cases is the originator

of the part). Even though the cross-reference only lists one manufacturer, there may actually be several approved sources for an HP part. While every attempt was made to ensure the accuracy of the list, it is advisable to compare the description of the device being replaced with the description of the substituted part. For example, if the service manual describes the device being replaced as a "dual J-K flip-flop", check this against the description of the replacement part.

NOTE

This is not a comprehensive list. If the part number you are looking for is not listed here, the semiconductor is made exclusively for Hewlett-Packard and there is no substitute—it must be replaced with the same HP part number. □

Manufacturers Code Number Cross Reference

No.	Manufacturer			No.	Manufacturer			
00039	NEC ELECTRONICS INC	MTN VIEW	CA US 94043S0545	8	05917	RIFA AB	STOCKHOLM	SW S-163C0633
00046	UNITRODE CORP	LEXINGTON	MA US 02173N171	3	05946	VALVO GMBH	HAMBURG	GM 2000D2540
00350	EXAR INTEGRATED SYSTEMS INC	SUNNYVALE	CA 9408652063	9	06121	SIEMENS AG	MUNICH	GM 8000
00575	WESTERN DIGITAL CORP	NEWPORT BEACH	CA 926252840	1	06338	SGS ATES	MILAN	IT A3500
01425	STANDARD MICROSYSTEMS CORP	HAUPPAUGE	NY	8	06344	FUJITSU MICROELECTRONICS INC	SANTA CLARA	CA US 95054S0167
01542	HF DIV 01 QED	SAN JOSE	CA US 9513128480	0	06347	HITACHI AMERICA LTD	SUNNYVALE	CA US 9408654013
01590	PLESSEY SEMICONDUCTORS	SANTA ANA	CA 9270552648	9	06354	TOSHIBA CORP	TOKYO	JP S0562
01698	TEXAS INSTRUMENTS INC	DALLAS	TX US 7526501295	0	06394	FERRANTI LTD ELECTRONICS DIV	OLDHAM LANCS	EG K1196
01876	HF DIV 02 SCD IC'S	SANTA CLARA	CA US 9505028480	2	06454	LAMBDA ELECTRONICS CORP	MELVILLE	NY 1174680103
01921	RCA CORP	NEW YORK	NY US 101213L585	6	06563	SIEMENS CORP COMPONENTS GROUP	SCOTTSDALE	AZ 852521954
01973	GE CO SEMICONDUCTOR PROD DEPT	AUBURN	NY US 1320103508	7	06861	MICRO NETWORKS CORP	WORCESTER	MA 0160650507
01991	TRANSITRON ELECTRONIC CORP	WAKEFIELD	MA 0188024046	9	06916	SONY CORP	TOYKO	JP 14 141 S0482
02023	ITW SWITCHES	CHICAGO	IL US 6063104426	0	07050	MICRO POWER SYSTEMS	SANTA CLARA	CA 9505054186
02037	MOTOROLA INC	ROSELLE	IL US 6019504713	0	07221	SUPERTEK INC	SUNNYVALE	CA 94086
02180	PRECISION MONOLITHICS INC	SANTA CLARA	CA US 9505406665	8	07371	SANYO ELECTRIC INC	TOKYO	JP
02237	FAIRCHILD SEMICONDUCTOR CORP	CUPERTINO	CA US 9501407263	6	07397	ENGINEERED COMPONENTS CO	SAN LUIS OBISPO	CA 93401
02290	RAYTHEON CO SEMICONDUCTOR DIV HQ	MOUNTAIN VIEW	CA 9404007933	5	08323	HP DIV 49 CICO	CUPERTINO	CA
02598	UNITRODE CORP	WATERTOWN	MA 0217212969	31	08507	INTERDESIGN	SCOTTS VALLEY	CA
02686	WATKINS-JOHNSON CO	PALO ALTO	CA US 9430414482	4	08565	COMPUTER LABS INC	GREENSBORO	NC
02713	GENERAL INSTRUMENT CORP (DIODE)	HICKSVILLE	NY US 1180214936	6	08608	SILICON SYSTEMS INC	TUSTIN	CA
02763	TELEDYNE SEMICONDUCTOR	MOUNTAIN VIEW	CA 9404315818	1	08661	TELARIS TELECOMMUNICATIONS INC	IRVING	CA
02838	DYNAMIC MEASUREMENTS CORP	WICHESTER	MA 0189017191	1	08810	ROCKWELL INTERNATIONAL	ANAHEIM	CA
02882	ZELTEK INC SUB OF REDCOR CORP	CONCORD	CA 9452017850	9	09161	MITEL SEMICONDUCTOR	KANATA OTTAWA	CN
02883	SILICONIX INC	SANTA CLARA	CA US 9505417856	7	09274	ANALOG SYSTEMS	TUCSON	AZ
02910	SIGNETICS CORP	SUNNYVALE	CA US 9408618324	8	09283	TOPAZ SEMICONDUCTOR	SAN JOSE	CA US 95132
03285	ANALOG DEVICES INC	NORWOOD	MA US 0206224355	4	10253	INTEGRATED DEVICE TECHNOLOGY, INC	SANTA CLARA	CA
03291	AVANTEK INC	SANTA CLARA	CA US 9505424539	2	10321	DATEL-INTERSIL	MANSFIELD	MA
03406	NATIONAL SEMICONDUCTOR CORP	SANTA CLARA	CA US 9505227014	6	10421	EPSON	TORRENCE	CA
03545	TELEDYNE PHILBRICK NEXUS	DEDHAM	MA 0202629832	1	10585	LINEAR TECHNOLOGY CORP	MILPITAS	CA US 95035
03677	AMERICAN MICRO SYSTEMS INC	SANTA CLARA	CA US 9505131471	2	10881	THOMSON-CSF	COURBEVOIE	FR
03688	ANALOGIC CORP	WAKEFIELD	MA 0188031814	9	11111	SEQ TECHNOLOGY INC	SAN JOSE	CA
03714	INTERSIL INC	CUPERTINO	CA CA 9501432293	3	11302	MAXIM INTEGRATED PRODUCTS	SUNNYVALE	CA
03755	HYBRID SYSTEMS CORP	BURLINGTON	MA 0180332356	X 6	11320	AT&T TECHNOLOGY	CHICAGO	IL
03780	INTECH INC	SANTA CLARA	CA 9505033967	4	11345	CYPRESS SEMICONDUCTOR CORP	SAN JOSE	CA US 95134
03793	SILICON GENERAL INC	SAN JOSE	CA US 9513434333	7	11452	ANAHÉIM AUTOMATION PRODUCTS DIV	ANAHÉIM	CA
03794	ADVANCED MICRO DEVICES INC	SUNNYVALE	CA US 9408634335	5	11561	RELIABILITY INC	TIPPERATY	IR
03799	HARRIS CORP	MELBOURNE	FL US 3290134371	4	11596	CIRCUIT TECHNOLOGY INC	FARMINGDALE	NY
03811	INTEL CORP	SANTA CLARA	CA US 9505434649	7	11604	COLMINAR CORP	LOVELAND	CO US 80537
03947	NCR CORP	DAYTON	OH US 4547942470	9	11668	ROCKWELL INT'L, SEMICONDUCTOR DIV.	NEWPORT BEACH	CA
04077	CERMETEK INC DIV REPUBLIC CORP	MOUNTAIN VIEW	CA 9404050077	4	11688	CALEX MANUFACTURING CO INC	PLEASANT HILL	CA US 94523
04078	MOSTEK CORP	CARROLLTON	TX US 7500650088	2	11825	ANALOG SOLUTIONS	CONCORD	CA US 94518
04092	MONOLITHIC MEMORIES INC	SANTA CLARA	CA US 9505450364	3	11943	SIERRA SEMICONDUCTOR	SAN JOSE	CA US 95132
04200	SPRAGUE ELECTRIC CO	LEXINGTON	MA US 0217356289	2	12125	SAMSUNG SEMICONDUCTOR INC	SANTA CLARA	CA US 95054
04507	TRW INC	CLEVELAND	OH US 4412471785	0	12147	TELMOS INC	SUNNYVALE	CA US 94086
05436	BURR-BROWN CORP	TUCSON	AZ US 857068175	1	12276	NIPPON GAKKI CO LTD	TOKYO	JP 438-0
05542	HONEYWELL INC	MINNEAPOLIS	MN US 5540891929	6				

HP P/N	Mfr.	Desc.
0960-0397	03285	ADC12QZ003
0960-0631	03285	DAC16QM/C-B
0960-0632	03285	DAC12QS/C-B
1813-0013	03285	40K
1813-0016	05436	3112/12C
1813-0034	03714	IHS010CPD
1813-0036	03755	DAC372-12-BCD
1813-0039	02882	ZD44
1813-0040	02882	ZD44
1813-0041	03406	LH0042CH
1813-0048	03285	751N
1813-0049	02763	2740CE
1813-0054	03406	AH0154D
1813-0057	03406	LH0242CH
1813-0058	03406	LH0021CK
1813-0082	00046	PIC646
1813-0083	00046	PIC601
1813-0084	00046	PIC611
1813-0092	05436	DAC80-CCD-V
1813-0093	02237	UA78H12SC
1813-0094	05436	DAC80-CBI-I (SEL'D)
1813-0098	05436	ADC80AG-12
1813-0100	02237	UA78H05SC
1813-0105	06861	DAC80-CBI-V
1813-0109	00046	PIC625
1813-0110	00046	PIC626
1813-0114	02598	PIC645
1813-0115	00046	PIC600
1813-0118	05436	DAC80-CBI-I (SEL'D)
1813-0123	02237	UA78HGK
1813-0124	02237	UA78H15KC
1813-0125	05436	DAC80-CBI-V (SEL'D)
1813-0127	02237	UA79HGK
1813-0132	06861	MNDAC71CSB-I
1813-0133	02838	7162
1813-0138	02037	MHW592
1813-0140	05436	SDM857KG
1813-0142	03285	ADS522BD
1813-0147	10321	DAC-HA12DC
1813-0150	03714	ICM7209IPA
1813-0151	05436	3527AM SELECTED
1813-0155	10321	ADC-H212BGC (SELECTED)
1813-0160	03406	DHO034CD
1813-0165	08565	MDMS-1101
1813-0168	08661	7516
1813-0177	03285	ADDA8C80-V
1813-0211	02037	MWA110
1813-0212	02037	MWA20
1813-0237	02037	MWA130
1813-0241	02037	MWA210
1813-0245	02037	MWA220
1813-0216	02037	MWA230
1813-0217	02037	MWA310
1813-0218	02037	MWA320
1813-0219	02037	MWA330
1813-0285	05454J	DAC71-CSB-I
1813-0291	05436	AD574AKD
1813-0264	05436	ADC80AGZ-12(PER HP DWG)
1813-0283	05436	DAC71-CSB-V
1813-0310	04077	CH1710-01
1813-0311	04077	CH1720-01
1813-0312	04077	CH1730-01
1813-0313	04077	CH1740-01
1813-0315	03291	GPD-1003
1813-0316	03291	UTO-507
1813-0317	03291	UTO-561
1813-0318	03291	GPD-410
1813-0319	03291	GPD-420
1813-0320	03291	GPD-331
1813-0321	07397	MDPM-TTL-35
1813-0322	05436	ADC76JG
1813-0361	02237	UA78P05SC
1813-0385	03291	GPD-430
1813-0410	03755	DAC9377-16-6
1813-0437	05436	OPIA11BM
1813-0479	03291	UTO-2012
1813-0444	03291	UTO-2024
1813-0445	03291	UTO-2023
1813-0446	03291	UTO-517
1813-0447	03291	UTO-533
1813-0450	05436	ADCT1KG
1813-0468	11596	CT1602
1813-0469	11596	CT3231
1813-0476	11604	CLC220AI-SCD
1813-0485	10421	RTC-58321
1813-0486	03285	HOS-100AH
1813-0489	11688	SD15..060
1813-0490	11688	S55..600
1813-0491	11688	SD12..075
1813-0495	11320	630AG
1813-0496	11320	606HM
1813-0501	00046	MN376
1813-0508	11604	CLC103AI
1813-0511	05436	ADC76KG
1813-0514	11561	VF5/5 (SELECTED)
1813-0515	11561	V12P5
1813-0516	03291	UTO-2027 (SELECTED)
1813-0517	05436	PWR-606A
1813-0544	06338	GS-R405S
1813-0553	00039	NEL-D32-46-2
1813-0562	05436	ADC84KG-12
1816-0934	02237	9403PC
1816-1536	04092	C67W01J1 RELAXED
1818-0093	02237	3341DC
1818-0094	00575	PR1472B-01
1818-0095	00575	PR1482B-01
1818-0277	03794	AM2813ADC
1818-0279	02237	3341ADC
1818-0422	02237	3551DC
1820-0001	01973	4JX19A555
1820-0006	01973	4JX19A519
1820-0010	01973	4JX19A581
1820-0013	02037	MC352G
1820-0044	01973	RA1A
1820-0046	01921	CA3005
1820-0047	01921	CA3010
1820-0050	02037	MC1531G
1820-0051	02237	702HC
1820-0052	02237	923HC
1820-0054	01698	SN7400N
1820-0055	01698	SN7400AN
1820-0056	01698	SN7492AN
1820-0058	02237	709HC
1820-0063	01698	SN7451N
1820-0065	01698	SN7470N
1820-0067	02910	SP631N
1820-0068	01698	SN7410N
1820-0069	01698	SN7420N
1820-0070	01698	SN7430N
1820-0071	01698	SN7440N
1820-0072	01698	SN7450N
1820-0074	01698	SN7454N
1820-0075	01698	SN7473N
1820-0076	01698	SN7476N
1820-0077	01698	SN7478N
1820-0078	02910	SP62ON
1820-0081	01698	SN7481N
1820-0083	01698	SN7510L
1820-0084	01698	SN7453N
1820-0085	01698	SN7460N
1820-0086	01698	SN1583ON
1820-0087	02037	MC850P
1820-0088	02037	MC851P
1820-0094	02037	MC846P
1820-0095	02037	MC848P
1820-0096	02037	MC832P
1820-0098	01876	A167A-0100
1820-0099	01698	SN7493AN
1820-0100	03406	DM7414AN
1820-0101	02037	MC1034P
1820-0102	02037	MC1013P
1820-0104	03406	LM201H
1820-0106	02037	MC816P
1820-0110	02237	959DC
1820-0111	02237	9301PC
1820-0113	01991	TA03709V
1820-0116	01876	A142A-0100
1820-0117	01876	A141A-0100
1820-0119	01876	A141A-0100
1820-0121	02910	N8790N
1820-0122	02037	MC853P
1820-0123	03406	LM300H
1820-0125	02237	UAT711C
1820-0127	02307	9002DC
1820-0128	02237	937DC
1820-0129	02307	9003DC
1820-0130	02237	9004DC
1820-0131	02237	9009DC
1820-0132	02237	9016DC
1820-0134	02237	9300PC
1820-0135	02237	9027DC
1820-0138	03454S	S52
1820-0140	02037	MC3026P
1820-0141	02037	MC3001P
1820-0142	02037	MC1004P
1820-0143	02037	MC1027P
1820-0144	02037	MC1018P
1820-0145	02037	MC1010P
1820-0146	02037	MC1017P
1820-0147	02037	MC1007P
1820-0157	0237	MC1023P
1820-0158	03406	LM302H
1820-0160	02037	MC1431P
1820-0162	02037	MC1046P
1820-0164	02037	MC1048P
1820-0165	02037	MC1050P
1820-0166	02037	MC1052P
1820-0167	02037	MC1054P
1820-0168	02037	MC1056P
1820-0169	02037	MC1058P
1820-0174	01698	SN7404N
1820-0175	01698	SN7405N
1820-0176	02037	MC1059P
1820-0177	02037	MC1060P
1820-0178	02037	MC1061P
1820-0179	02037	MC1062P
1820-0180	02037	MC1063P
1820-0181	02037	MC1433L
1820-0182	02037	MC1064P
1820-0183	02037	MC1065P
1820-0184	02037	MC1066P
1820-0185	02037	MC1067P
1820-0186	02037	MC1068P
1820-0187	02037	MC1069P
1820-0188	02037	MC1070P
1820-0189	02037	MC1071P
1820-0190	02037	MC1072P
1820-0191	02037	MC1073P
1820-0192	02037	MC1074P
1820-0193	02037	MC1075P
1820-0194	02037	MC1076P
1820-0195	02910	N8780N
1820-0196	02237	723HC
1820-0197	03406	LM709AH
1820-0200	02037	MC1030P
1820-0202	02037	MC1439G
1820-0203	02037	MC1020P
1820-0204	02037	MC3006P
1820-0205	02037	MC3003P
1820-0207	0237	9601PC
1820-0208	02910	N8826N
1820-0211	01698	TMS3002LR
1820-0212	02037	MC1020P
1820-0213	02037	MC1014P
1820-0214	01698	SN7442AN
1820-0216	02237	UAT71TC (SELECTED)
1820-0217	02237	UAT71TC (SELECTED)
1820-0218	02825	106A
1820-0223	03406	LM301AH
1820-0224	03406	LM3002CH
1820-0225	02037	MC1031P
1818-0093	02237	3341DC
1818-0094	00575	PR1472B-01
1818-0095	00575	PR1482B-01
1818-0277	03794	AM2813ADC
1818-0279	02237	3341ADC
1818-0422	02237	3551DC
1820-0001	01973	4JX19A555
1820-0006	01973	4JX19A519
1820-0010	01973	4JX19A581
1820-0013	02037	MC352G
1820-0044	01973	RA1A
1820-0046	01921	CA3005
1820-0047	01921	CA3010
1820-0048	01921	CA3010A
1820-0049	01921	CA3010B
1820-0050	01921	CA3010C
1820-0051	01921	CA3010D
1820-0052	01921	CA3010E
1820-0053	01921	CA3010F
1820-0054	01921	CA3010G
1820-0055	01921	CA3010H
1820-0056	01921	CA3010I
1820-0057	01921	CA3010J
1820-0058	01921	CA3010K
1820-0059	01921	CA3010L
1820-0060	01921	CA3010M
1820-0061	01921	CA3010N
1820-0062	01921	CA3010P
1820-0063	01921	CA3010Q
1820-0064	01921	CA3010R
1820-0065	01921	CA3010S
1820-0066	01921	CA3010T
1820-0067	01921	CA3010U
1820-0068	01921	CA3010V
1820-0069	01921	CA3010W
1820-0070	01921	CA3010X
1820-0071	01921	CA3010Y
1820-0072	01921	CA3010Z
1820-0073	01921	CA3010AA
1820-0074	01921	CA3010AB
1820-0075	01921	CA3010AC
1820-0076	01921	CA3010AD
1820-0077	01921	CA3010AE
1820-0078	01921	CA3010AF
1820-0079	01921	CA3010AG
1820-0080	01921	CA3010AH
1820-0081	01921	CA3010AJ
1820-0082	01921	CA3010AK
1820-0083	01921	CA3010AL
1820-0084	01921	CA3010AM
1820-0085	01921	CA3010AN
1820-0086	01921	CA3010AO
1820-0087	01921	CA3010AP
1820-0088	01921	CA3010AQ
1820-0089	01921	CA3010AR

HP P/N	Mfr.	Desc.	1820-0597 03406 DM74L78N	1820-0770 03406 MM5006H	1820-0940 01921 CD4044AE	1820-1089 01698 SN74279N
1820-0598	03406	DM74L86N	1820-0774 02910 SP374W	1820-0941 01921 CD4043AE	1820-1091 01698 SN5413J	
1820-0599	03406	DM74L95N	1820-0777 01698 SN74L42N	1820-0942 01921 CD4000AE	1820-1092 01698 SN5412J	
1820-0600	03406	DM74L90N	1820-0778 02327 93116PC	1820-0943 01921 CD4023UVE	1820-1093 01698 SN5400J	
1820-0601	03406	DM74L93N	1820-0780 03406 DS8881N	1820-0944 01921 CD4025UBE	1820-1094 01698 SN5410J	
1820-0602	03406	DM74L164AN	1820-0781 03714 IM5013CDC	1820-0945 01921 CD4037AE	1820-1095 01698 SN5474J	
1820-0603	03406	DM74L85N	1820-0782 01698 SN7427N	1820-0946 01921 CD4001UBE	1820-1096 01698 SN54196J	
1820-0604	02037	MC3025P	1820-0786 02037 MC7250P	1820-0947 01921 CD4030AE	1820-1097 01698 SN5404J	
1820-0605	01698	SN74H01N	1820-0788 01698 SN74174N	1820-0948 01921 CD4002UBE	1820-1098 02910 S8292F	
1820-0606	01698	SN74181N	1820-0789 02910 N8293N	1820-0949 01921 CD4011UBE	1820-1099 01698 SN5408J	
1820-0607	02037	MC4012P	1820-0790 02037 MC1660L	1820-0950 01921 CD4012UBE	1820-1100 01698 SN74298N	
1820-0608	02037	MC4006P	1820-0791 02037 MC1068P	1820-0951 01921 CD4019BE	1820-1101 01698 SN5402J	
1820-0609	02037	MC3061P	1820-0792 02037 MC1043P	1820-0952 02327 952DC	1820-1107 01698 SN74166N	
1820-0610	02037	MC8309P	1820-0793 02037 MC1674L	1820-0953 02327 953DC	1820-1108 02037 MC1648P	
1820-0611	01698	SN74182N	1820-0794 02037 MC1670L	1820-0954 02327 954DC	1820-1109 02037 MCW022P	
1820-0613	01698	SN74H05N	1820-0795 02037 MC1664L	1820-0955 02327 955DC	1820-1110 01698 SN75110AN	
1820-0614	02237	93L08PC	1820-0796 02037 MC1662L	1820-0956 02327 956DC	1820-1111 02237 93L40DC	
1820-0615	02037	MC8312P	1820-0797 02037 MC1672L	1820-0957 02327 957DC	1820-1112 01698 SN74LS74AN	
1820-0616	02237	9322PC	1820-0799 01698 SN7452BP	1820-0958 01921 CD4042AF	1820-1113 03406 DM8553N	
1820-0617	02037	MC3022P	1820-0801 02037 MC10101P	1820-0961 01921 CD4021AF	1820-1114 02037 MC14516BCP	
1820-0618	01698	SN7417N	1820-0802 02037 MC10102P	1820-0962 01921 CD4006AF	1820-1115 03406 DS8822N	
1820-0619	01698	SN74H22N	1820-0803 02037 MC10105P	1820-0963 01921 CD4031AE	1820-1116 01698 SN74109N	
1820-0620	01698	SN74153N	1820-0804 02037 MC10106P	1820-0964 02327 964DC	1820-1117 02237 9L86FC	
1820-0621	01698	SN7438N	1820-0805 02037 MC10107P	1820-0965 02327 965DC	1820-1119 02037 MC1648L	
1820-0622	01698	SN74151AN	1820-0806 02037 MC10109P	1820-0966 02327 966DC	1820-1120 04200 UHP-W02	
1820-0623	03406	DM8200N	1820-0807 02037 MC10110P	1820-0967 02327 967DC	1820-1121 03406 DM8093N	
1820-0625	02037	MC666P	1820-0808 02037 MC10111P	1820-0968 02327 968DC	1820-1122 02037 MC14518BCP	
1820-0626	02237	9314PC	1820-0809 02037 MC10115P	1820-0969 01921 CD4035AE	1820-1123 04078 MK5009N	
1820-0627	02237	931L01PC	1820-0810 02037 MC10116P	1820-0970 01921 CD4014AE	1820-1124 01698 SN7433N	
1820-0629	01698	SN74S112N	1820-0811 02037 MC10117P	1820-0971 02327 971DC	1820-1129 02763 334CJ	
1820-0630	02037	MC4044P	1820-0812 02037 MC10118P	1820-0972 02327 952DC	1820-1130 01698 SN74S133N	
1820-0631	01698	SN74H108N	1820-0813 02037 MC10119P	1820-0973 02327 953DC	1820-1131 03406 DM8160N	
1820-0634	01876	E091-0100	1820-0815 02037 MC10121P	1820-0974 02327 956DC	1820-1132 02037 MC1690L	
1820-0637	02910	N8875N	1820-0816 02037 MC10130P	1820-0975 02327 967DC	1820-1137 02037 MC1809P	
1820-0639	02037	MC4001P	1820-0817 02037 MC10131P	1820-0976 01921 CD4015BE	1820-1140 02910 N82S62N	
1820-0640	01698	SN74150N	1820-0818 02037 MC10133P	1820-0977 01921 CD4034AE	1820-1141 01698 SN74185AN	
1820-0655	01698	SN7425N	1820-0819 02037 MC10134L	1820-0978 01921 CD4007AE	1820-1142 01698 SN74L46N	
1820-0656	01698	SN74H98N	1820-0820 02037 MC10135P	1820-0979 01921 CD4009AF	1820-1143 03406 DM8552N	
1820-0657	02237	9318PC	1820-0821 02037 MC10136L	1820-0980 01921 CD4010AF	1820-1144 01698 SN74LS02N	
1820-0658	02237	93L12PC	1820-0822 02037 MC10137L	1820-0981 01921 CD4016AE	1820-1145 01921 CD4049UBE	
1820-0659	02237	93L00PC	1820-0823 02037 MC10141L	1820-0982 01921 C164B-0150	1820-1146 01921 CD4050BE	
1820-0661	01698	SN74S20N	1820-0826 02037 MC10160L	1820-0984 02307 MC0720P	1820-1148 03406 DM8090N	
1820-0665	02037	MC1814P	1820-0827 02037 MC10161P	1820-0985 02307 MC1800P	1820-1150 02037 MC14520BCP	
1820-0666	02037	MC1006P	1820-0828 02037 MC10162P	1820-0986 03406 DM86L75N	1820-1155 02910 N82S90N	
1820-0667	02037	MC1040P	1820-0829 02037 MC10164L	1820-0987 02327 93L18PC	1820-1156 02037 MC2257L	
1820-0668	01698	SN7407N	1820-0830 02037 MC10179L	1820-0989 02910 N8271N	1820-1157 02037 MC2259L	
1820-0669	02237	93L10PC	1820-0831 02037 MC10181L	1820-0990 02037 MC1W89AL	1820-1158 01698 SN74S51N	
1820-0681	01698	SN74S00N	1820-0832 03406 MH0007CH	1820-0992 01698 SN5490AN	1820-1162 03406 MM5057N	
1820-0682	01698	SN74S03N	1820-0833 02327 9334PC	1820-0993 04078 MW6036P	1820-1163 01698 SN74L153N	
1820-0683	01698	SN74S04N	1820-0834 02037 MC4038P	1820-0995 01698 SN7447AN	1820-1165 03406 MM5013N	
1820-0684	01698	SN74S05N	1820-0835 02910 N8267N	1820-0998 01698 SN74S153N	1820-1166 03406 DM85L51N	
1820-0685	01698	SN74S10N	1820-0836 02037 MC4010P	1820-0999 01698 SN74S181N	1820-1167 03406 DM81L23N	
1820-0686	01698	SN74S11N	1820-0837 02910 N8281N	1820-1002 01698 SN74104N	1820-1170 02037 MMH0026L	
1820-0687	01698	SN74S15N	1820-0839 01698 SN74175N	1820-1003 01876 E144C-0200	1820-1171 01698 SN74143N	
1820-0688	01698	SN74S20N	1820-0842 02037 MC4008P	1820-1004 02037 MC7040P	1820-1172 02237 5416DM	
1820-0689	01698	SN74S22N	1820-0843 02037 MC4002P	1820-1005 02327 9624DC	1820-1173 02037 MC10124L	
1820-0690	01698	SN74S40N	1820-0844 02037 MC426P	1820-1007 02910 N8T23N	1820-1174 01698 TMS424N	
1820-0691	01698	SN74S64N	1820-0846 03406 DM8094N	1820-1008 03811 C3207	1820-1175 02037 MC14522BCP	
1820-0692	01698	SN74S65N	1820-0847 01698 SN74H183N	1820-1009 02327 95H90DC	1820-1176 02037 MC14015BCP	
1820-0693	01698	SN74S74N	1820-0856 02327 7400DC	1820-1015 01698 SN74S158N	1820-1178 01698 TMS3122NC	
1820-0694	01698	SN74S86N	1820-0857 02327 7420DC	1820-1016 01698 SN75453BP	1820-1181 02037 MC14522BAL	
1820-0695	01698	SN74S113N	1820-0858 02327 7476DC	1820-1017 02327 93L21PC	1820-1183 02037 MC4016P	
1820-0696	01698	SN74S114N	1820-0859 02327 7477DC	1820-1019 01876 E144D-0200	1820-1184 01698 SN7428N	
1820-0697	01698	SN74S140N	1820-0860 02327 951DC	1820-1021 03406 DS8800H	1820-1185 01698 SN74L162N	
1820-0700	02037	MC3029P	1820-0861 02327 946DC	1820-1022 01698 SN5404N	1820-1186 01698 TMS3113NC	
1820-0701	02237	93L14PC	1820-0862 02327 948DC	1820-1023 02037 95H90DC	1820-1187 02910 SP380N	
1820-0702	02237	93L11PC	1820-0863 02327 9158DC	1820-1024 01698 SN54160N	1820-1188 01921 CD4046AF	
1820-0703	02910	N8292N	1820-0864 02327 7403DC	1820-1025 02037 MC1210L	1820-1189 02037 MC14510BCP	
1820-0704	01698	SN74L22N	1820-0865 02327 944DC	1820-1026 02037 MC1213L	1820-1190 03406 MM74C173N	
1820-0705	02237	9310PC	1820-0866 02327 949DC	1820-1027 01698 SN74195N	1820-1191 01698 SN74S175N	
1820-0706	02237	9324PC	1820-0867 02327 7404DC	1820-1030 02037 MC3007P	1820-1192 01698 SN74L173N	
1820-0707	01698	SN74L411N	1820-0868 02327 1801DC	1820-1031 02037 9521DC	1820-1193 01698 SN74L197N	
1820-0708	02237	93L09PC	1820-0869 02327 935DC	1820-1032 01698 SN74198N	1820-1194 01698 SN74L193N	
1820-0709	02237	93L28PC	1820-0870 02327 7408DC	1820-1036 02037 MC1019P	1820-1195 01698 SN74LS175N	
1820-0710	02237	93L22PC	1820-0875 02327 9600DC	1820-1037 01698 SN7446AN	1820-1196 01698 SN74LS174N	
1820-0713	01698	SN74L63N	1820-0876 02327 944DC	1820-1038 01698 SN7448N	1820-1197 01698 SN74LS00N	
1820-0714	01876	E144D-0200	1820-0879 02327 7404DC	1820-1042 01698 SN74165N	1820-1198 01698 SN74LS03N	
1820-0715	01698	SN74H106N	1820-0880 02327 92307	1820-1043 03406 DM5406N	1820-1199 01698 SN74LS04N	
1820-0716	01698	SN74J611N	1820-0888 02327 9305PC	1820-1044 02327 9621DC	1820-1200 01698 SN74LS05N	
1820-0717	03406	MM5052	1820-0899 01698 SN74160N	1820-1045 02327 9621DC	1820-1201 01698 SN74LS08N	
1820-0718	03406	DS0025CN	1820-0900 02910 SP370N	1820-1046 01698 SN74156N	1820-1202 01698 SN74LS10N	
1820-0719	02910	8242A	1820-0902 01698 SN74S450BN	1820-1047 03406 DM74L42AN	1820-1203 01698 SN74LS11N	
1820-0720	03406	DS8830N	1820-0903 01698 SN74L164N	1820-1048 02910 N8T20N	1820-1204 01698 SN74LS20N	
1820-0721	03406	DS8820AN	1820-0904 02327 93L24PC	1820-1049 03406 DM8097N	1820-1205 01698 SN74LS21N	
1820-0722	01698	SN75109N	1820-0906 03406 DM8214N	1820-1050 01698 SN75454BP	1820-1206 01698 SN74LS27N	
1820-0723	01698	SN75107AN	1820-0907 01698 SN7412N	1820-1052 02037 MC10125L	1820-1207 01698 SN74LS30N	
1820-0724	02037	MC4007P	1820-0908 02037 MC7479P	1820-1053 01698 SN7414N	1820-1208 01698 SN74LS32N	
1820-0726	01698	SN74199N	1820-0909 01698 SN74167N	1820-1056 01698 SN74132N	1820-1209 01698 SN74LS38N	
1820-0727	02237	9321PC	1820-0910 01698 SN74L853AN	1820-1057 03406 DM86L76N	1820-1210 01698 SN74LS51N	
1820-0729	01876	A110A-0100	1820-0911 01698 SN74L192N	1820-1060 01876 A14201	1820-12	

HP P/N	Mfr.	Desc.	1820-1241	02037	MC14512BCP	1820-1372	02237	74S109DC	1820-1502	02037	MC14015BCP	1820-1655	03406	MM74C906N
1820-1242	02037	MC12012L	1820-1243	01698	SN74LS151N	1820-1373	02237	93S101DC	1820-1503	02037	MC14007UBCP	1820-1656	03406	MM74C907N
1820-1243	01698	SN74LS151N	1820-1244	01698	SN74LS153N	1820-1374	03285	AD7510DIJN	1820-1504	02037	MC14016BCP	1820-1657	02037	MC14572UBCP
1820-1245	01698	SN74LS155AN	1820-1246	01698	SN74LS09N	1820-1375	02037	MC3103L	1820-1505	02037	MC14049UBCP	1820-1658	02037	MC14541BCP
1820-1247	01698	SN74L123N	1820-1249	02910	N82S33N	1820-1376	03406	DM76175N	1820-1506	02037	MC14024BCP	1820-1659	02037	MC14582BCP
1820-1250	01698	SN74136N	1820-1251	01698	SN74LS196N	1820-1377	02237	93L14DM	1820-1507	02037	MC14012UBCP	1820-1660	01921	CD4067BE
1820-1252	02883	LD110C	1820-1253	01698	SN54500J	1820-1378	01698	SN54192N	1820-1508	02037	MC14017BCP	1820-1661	01921	CD4089BE
1820-1254	03406	DM8095N	1820-1255	03406	DM8098N	1820-1379	01698	SN5408N	1820-1509	02037	MC14023UBCP	1820-1662	01921	CD4094BE
1820-1256	01698	SN7422N	1820-1257	01698	SN74159N	1820-1380	01698	SN5496N	1820-1510	01921	CD4053BF	1820-1663	01921	CD4095BE
1820-1258	01698	SN74178N	1820-1259	01698	SN74179N	1820-1381	01698	SN5432N	1820-1511	02037	MC14002UBCP	1820-1664	01921	CD4096BE
1820-1260	01698	SN74221N	1820-1261	01698	SN74283N	1820-1382	02037	MC10138L	1820-1512	02037	MC14028BCP	1820-1665	01921	CD4099BE
1820-1262	01698	SN74290N	1820-1263	01698	SN74H15N	1820-1384	01590	SP8674BDG	1820-1513	01921	CD4051BF	1820-1666	02037	MC14511BCP
1820-1264	01698	SN74293N	1820-1265	02037	MC14527BCP	1820-1385	02037	MC14502BCP	1820-1514	02037	MC14014BCP	1820-1667	01921	CD4060AE
1820-1266	03406	MM80C97N	1820-1267	01698	SN74184N	1820-1386	02037	MC14506BCP	1820-1515	01921	CD4556BE	1820-1668	01698	SN74LS742L
1820-1268	01698	SN74L85N	1820-1269	01698	SN74L157N	1820-1387	02037	MC14519BCP	1820-1516	01921	CD4555BE	1820-1669	01698	SN74S374N
1820-1270	01698	SN74L121N	1820-1271	01698	SN74143J	1820-1388	02037	MC14071CP	1820-1518	03406	DM74L00N	1820-1670	03046	DS75492N
1820-1272	01698	SN74LS33N	1820-1273	01698	SN74LS28N	1820-1389	02037	MC14583BCP	1820-1519	02037	MC663P	1820-1672	01921	CD4077BE
1820-1274	01698	SN74LS22N	1820-1275	01698	SN74S260N	1820-1390	03406	MM74C160N	1820-1520	02037	MC660P	1820-1673	01698	SN75322N
1820-1276	01698	SN74LS194AN	1820-1277	01698	SN74LS192N	1820-1395	03811	P3404	1820-1522	02037	MC3404AP	1820-1675	01921	CD4016AF
1820-1278	01698	SN74LS191N	1820-1279	01698	SN74LS190N	1820-1405	03794	AM2505PC	1820-1524	02037	MC6602L	1820-1676	01698	SN74S373N
1820-1280	01698	SN74LS181N	1820-1281	01698	SN74LS139AN	1820-1406	01921	CD4072BE	1820-1525	02037	MC14008BCL	1820-1677	01698	SN74S374N
1820-1282	01698	SN74LS139AN	1820-1283	01698	SN74LS109AN	1820-1407	01921	CD4075BE	1820-1526	02037	MC14028BCL	1820-1681	01698	TM6001NC
1820-1284	01698	SN74LS595N	1820-1285	01698	SN74LS545N	1820-1408	01921	CD4073BE	1820-1527	02037	MC14022BCL	1820-1682	05946	SAA1027
1820-1286	01698	SN74LS40N	1820-1287	01698	SN74LS37N	1820-1409	01921	CD4074BE	1820-1528	01921	CD4029BF	1820-1683	02037	MC14514BCP
1820-1288	02037	MMH0026CL	1820-1289	02910	N871W4N	1820-1410	01921	CD4075BE	1820-1530	01921	CD4027AF	1820-1685	02037	MC10195P
1820-1290	02237	93S12DC	1820-1291	03406	DM8554N	1820-1410	01921	CD4078BE	1820-1531	01921	CD4013AF	1820-1686	02037	MC10103P
1820-1292	03406	DM8520N	1820-1293	03406	DM8130N	1820-1410	01921	CD4073BE	1820-1532	01921	CD4044AF	1820-1687	02037	MC3443AP
1820-1294	03406	DM8123N	1820-1295	03406	DM8121N	1820-1411	01921	CD4082BE	1820-1533	01921	CD4043AF	1820-1688	01698	SN74LS247N
1820-1296	01698	SN74LS194AN	1820-1297	01698	SN74LS192N	1820-1412	02037	MC14556BCP	1820-1534	01921	CD4001AF	1820-1689	02037	MC3446AP
1820-1298	01698	SN74LS191N	1820-1299	01698	SN74LS190N	1820-1413	02037	MC14511BCP	1820-1535	01921	CD4025AF	1820-1693	02037	MC14508BCL
1820-1300	01698	SN74LS195AN	1820-1301	01698	SN74S257N	1820-1414	02037	MC14557BCP	1820-1536	01921	CD4030AF	1820-1699	03794	AM2505L17PC
1820-1302	01698	SN74S251N	1820-1303	01698	SN74S195N	1820-1415	02037	MC14511BCP	1820-1537	01921	CD4002AF	1820-1700	03794	AM25LS174PC
1820-1304	01698	SN74S194N	1820-1305	01698	SN74S182N	1820-1416	01698	SN74LS12N	1820-1538	01921	CD4011AF	1820-1702	03046	DM2505C
1820-1306	01698	SN74S134N	1820-1307	01698	SN74S132N	1820-1417	01698	SN74LS13N	1820-1539	01921	CD4012AF	1820-1721	02037	MC14559BCP
1820-1308	02037	MC10116L	1820-1309	01698	SN74S258N	1820-1418	01698	SN74LS42N	1820-1540	01921	CD4042AF	1820-1722	02037	MC14559BCP
1820-1310	01698	SN74S130N	1820-1311	01698	SN74S108N	1820-1419	01698	SN74LS85N	1820-1541	01921	CD4050AF	1820-1724	02037	DG184BP
1820-1312	01698	SN74S130N	1820-1313	01698	SN74S130N	1820-1420	01698	SN74LS92N	1820-1542	01921	CD4076BF	1820-1725	01698	SN74LS259N
1820-1314	01698	SN74S130N	1820-1315	01698	SN74S130N	1820-1421	01698	SN74LS96N	1820-1545	01921	CD4053BY	1820-1730	01698	SN74LS273N
1820-1316	01698	SN74S130N	1820-1317	01698	SN74S130N	1820-1422	01698	SN74LS120N	1820-1546	02037	MC14052BCL	1820-1731	01698	SN74L73N
1820-1318	01698	SN74S130N	1820-1319	01698	SN74S130N	1820-1423	01698	SN74LS123N	1820-1547	02037	MC14051BCL	1820-1732	03794	AM74LS138N
1820-1320	02037	MC10166A	1820-1321	01698	SN74S485N	1820-1424	01698	SN74LS161AN	1820-1548	01921	CD4066AY	1820-1733	03794	AM74LS175N
1820-1322	01698	SN74S485N	1820-1323	01698	SN74S430N	1820-1425	01698	SN74LS279AN	1820-1549	02037	MC14539BCL	1820-1735	03406	MC74C42N
1820-1324	01698	SN74S124N	1820-1325	01698	SN74S124N	1820-1426	01698	SN74LS164N	1820-1550	01921	CD4071BF	1820-1736	03406	DS8888AB
1820-1326	01698	SN74S124N	1820-1327	02037	MC14530BCP	1820-1427	01698	SN74LS156N	1820-1551	01921	CD4081BF	1820-1737	03406	DS8897AN
1820-1328	01698	SN74S124N	1820-1329	02037	MC14526BCP	1820-1428	01698	SN74LS158N	1820-1552	01921	CD4023BF	1820-1740	03406	DS8863N
1820-1330	01698	SN74S124N	1820-1331	01698	SN74S124N	1820-1429	01698	SN74LS160AN	1820-1553	01921	CD4019AF	1820-1745	02037	MC14001BCP
1820-1332	01698	SN74S124N	1820-1333	01698	SN74S124N	1820-1430	01698	SN74LS161AN	1820-1554	01921	CD4035AF	1820-1746	02037	MC14049UBCP
1820-1334	01698	SN74S124N	1820-1335	01698	SN74S124N	1820-1431	01698	SN74LS162AN	1820-1555	01921	CD4556BF	1820-1747	02037	MC14011BCP
1820-1336	02037	MC14526BCP	1820-1337	02037	MC14527BCP	1820-1432	01698	SN74LS163N	1820-1556	01921	CD4555BF	1820-1750	03406	DM5L8123J
1820-1338	02037	MC14530BCP	1820-1339	02037	MC14531BCP	1820-1433	01698	SN74LS164N	1820-1557	01921	CD4081BF	1820-1751	03677	S2350-2
1820-1340	02037	MC14538BCP	1820-1341	02037	MC14532BCP	1820-1434	01698	SN74LS165N	1820-1558	02037	MC14538BCL	1820-1755	03406	MM74C914N
1820-1342	02037	MC14532BCP	1820-1343	02037	MC14532BCP	1820-1435	01698	SN74LS166N	1820-1559	02037	MC14532BCL	1820-1757	03406	MM74C914N
1820-1344	02037	MC12040L	1820-1345	02037	MC14532BCP	1820-1436	01698	SN74LS167N	1820-1560	03046	MM74C165N	1820-1759	02037	MC14411P
1820-1346	01698	TMS3120NC	1820-1347	02237	9356PC	1820-1437	02237	93S161D	1820-1561	03046	MM74C221J	1820-1760	03046	MM74C221J
1820-1348	03406	MM5307N	1820-1349	03406	DM85514N	1820-1438	02037	MC14539BCP	1820-1562	03046	MM74C221J	1820-1761	03046	MM74C221J
1820-1350	03406	DM85514N	1820-1351	03714	B149A-0150	1820-1439	02037	MC12021P	1820-1563	02037	MC14502BCL	1820-1762	03046	MM74C154N
1820-1352	03406	DM85514N	1820-1353	03714	B149A-0150	1820-1440	01698	SN74LS90N	1820-1564	03046	MM74C220N	1820-1763	03046	MM74C220N
1820-1354	01876	D110C74	1820-1355	02037	MC14532BCP	1820-1441	02883	LD114CJ	1820-1565	03046	MM74C220N	1820-1764	03046	MM74C220N
1820-1356	02037	MC14532BCP	1820-1357	02037	MC14528BCP	1820-1442	02237	90098PC	1820-1566	03046	MM74C202N	1820-1765	03046	MM74C202N
1820-1358	02037	MC14053CD	1820-1359	02237	93L34PC	1820-1443	01698	MM74C221N	1820-1567	03046	MM74C221N	1820-1766	03046	MM74C221N
1820-1360	02037	MC10174P	1820-1361	02237	9374PC	1820-1444	02237	93S161D	1820-1568	03046	MM74C221N	1820-1767	03046	MM74C221N
1820-1362	03285	DAC12QZCB	1820-1363	03285	MM74C163N	1820-1445	03406	MM74C163N	1820-1569	03046	MM74C221N	1820-1768	03046	MM74C221N
1820-1364	03406	MM5313LN(75-)	1820-1365	03406	MM74C157N	1820-1446	02037	MC14040BCP	1820-1570	02037	MC140178P	1820-1769	03046	MM74C221N
1820-1366	03406	MM74C157N	1820-1367	01698	SN74S08N	1820-1447	02037	MC14013BCP	1820-1571	02037	MC14059BCP	1820-1770	03046	MM85973
1820-1368	03406	DM8096N	1820-1369	03406	DM8096N	1820-1448	02037	MC14001UBCP	1820-1572	02037	MC1405			

HP P/N	Mfr.	Desc.
1820-1865	03794	AM25LS08PC
1820-1866	03794	AM25LS07PC
1820-1867	03794	AM25LS09PC
1820-1868	01698	SN74S197N
1820-1869	01698	SN74S196N
1820-1870	03406	DS839N
1820-1871	01698	SN74S283N
1820-1872	03406	DM81LS96N
1820-1873	03406	DM81LS98N
1820-1874	03406	DM8556N
1820-1875	03406	DS8838N
1820-1876	03794	AM74M161N
1820-1877	03794	AM74S160N
1820-1878	01698	SN5423J
1820-1879	01698	SN54S00J
1820-1880	01698	SN54S27J
1820-1881	01921	CD4097BF
1820-1882	02037	MC10113L
1820-1884	02910	N8T97N
1820-1885	03406	DM74LS173N
1820-1887	01698	SN75361AP
1820-1888	02037	MC12013L
1820-1889	01698	SN74S26N
1820-1890	01698	SN74LS25BN
1820-1891	01698	SN74LS00N
1820-1892	01698	SN74LS367AN
1820-1897	01921	CD4024BF
1820-1898	01921	CD4021BF
1820-1899	02037	MC14516BL
1820-1900	02037	MC14520BCL
1820-1903	02327	9368PC
1820-1905	02910	74LS260N
1820-1906	03406	MM8098J
1820-1907	02037	MC14077BCL
1820-1908	02037	MC14070BCL
1820-1909	02037	MC14075BCL
1820-1910	02037	MC14073BCL
1820-1911	00575	TR1620B-05
1820-1912	02037	MC14042BCP
1820-1914	01698	SN74S174N
1820-1915	02037	MC1204L
1820-1917	01698	SN74S240N
1820-1918	01698	SN74LS241N
1820-1922	01698	SN74LS166AN
1820-1924	02910	N8T93N
1820-1925	01921	CD4040AF
1820-1927	02327	9541PC
1820-1930	02037	MC14078BCP
1820-1931	02037	MC14068BCP
1820-1932	02037	MC14538BCP
1820-1933	03406	MM74C74J
1820-1934	0180	DAC-08EQ
1820-1935	03406	MM74C905N
1820-1936	02037	MC14093BCL
1820-1937	03406	MM74C83J
1820-1941	03406	LF13201N
1820-1942	01698	SN74S163J
1820-1943	01698	SN74S169J
1820-1944	02037	MC10130L
1820-1945	02037	MC10115L
1820-1946	02037	MC10117L
1820-1947	02037	MC14909P
1820-1948	01698	TL607CP
1820-1949	01698	SN74S154N
1820-1950	02037	MC10212P
1820-1955	02037	MC14008BCP
1820-1956	02037	MC14042BCP
1820-1957	02037	MC14511BCP
1820-1958	02037	MC14016BCP
1820-1959	02037	MC14508BCP
1820-1960	02037	MC14012BCP
1820-1961	02037	MC14023BCP
1820-1962	02037	MC14028BCP
1820-1963	02037	MC14013BCP
1820-1964	02037	MC14027BCP
1820-1965	02037	MC14025BCP
1820-1967	08323	1AA6-6004
1820-1968	03794	AM93548PC
1820-1970	02037	MC14071BCP
1820-1971	02883	DG201CJ
1820-1973	01698	TL6041P
1820-1974	01698	SN74S181J
1820-1975	01698	SN74LS165AN
1820-1976	02037	MC14050BCP
1820-1977	02037	MC12061P
1820-1978	03794	AM25L04PC
1820-1979	02910	N8T757N
1820-1980	02910	N8S831N
1820-1981	03794	AM25S09PC
1820-1982	01698	SN75363N
1820-1984	03285	AD561KD
1820-1985	03406	DM85568J
1820-1986	03406	LF13202N
1820-1987	03794	AM74LS299N
1820-1988	03406	AHO019CD
1820-1989	02237	74LS393PC
1820-1990	02037	MC10100L
1820-1991	02237	74LS390PC
1820-1992	03794	AM25LS160APC
1820-1993	02037	MC10158L
1820-1994	01698	SN74LS243N
1820-1995	03285	AD7550D
1820-1997	03794	AM74LS374AP
1820-2001	03406	MM5307ABN
1820-2002	02237	9370PC
1820-2007	01698	SN74S365AN
1820-2008	02037	MC14015BCP
1820-2009	02237	4049BCP
1820-2013	02037	MC14051BCP
1820-2014	02037	MC14069UBCP
1820-2015	02037	MC14070BCP
1820-2016	02237	9401PC
1820-2017	01921	CD4085BF
1820-2018	01921	CD4086BF
1820-2019	02037	MC14584BCP
1820-2020	04200	UDN-5707A
1820-2021	02037	MC14520BCP
1820-2023	02037	MC10197P
1820-2024	01698	SN74LS244N
1820-2025	03714	IC7101CPL
1820-2026	01698	SN74LS640N
1820-2027	01698	SN75471P
1820-2028	02037	MC14021BCP
1820-2029	01921	CD4097BE
1820-2030	02327	4104PC
1820-2033	02037	MC14561BCP
1820-2035	03811	P3205
1820-2036	02037	MC6875L
1820-2037	02037	MC14081BCP
1820-2038	03406	MM74C00J
1820-2040	03406	MM5315N
1820-2041	03406	DS3612N
1820-2042	02037	MC140115D
1820-2043	01921	CD40115D
1820-2044	01698	SN74LS353N
1820-2047	01590	SP8620BDG
1820-2049	02237	74LS196PC
1820-2050	02037	MC14555BCP
1820-2051	02037	CD14528CL
1820-2053	03406	DM74LS154N
1820-2054	02037	MC14040BCCL
1820-2055	02037	MC14015BCCL
1820-2056	01698	SN74LS325N
1820-2071	03811	D4201
1820-2075	01698	SN74LS245N
1820-2076	03811	D3424
1820-2078	01698	SN74LS490N
1820-2079	02037	MC14002BCP
1820-2080	02037	MC14035BCP
1820-2082	01698	SN54LS242J
1820-2083	03406	CDU029BCN
1820-2084	02037	MC14018BCP
1820-2085	03406	CDU019BCN
1820-2086	02037	MC14006BCP
1820-2087	01698	SN74LS490N
1820-2089	02037	MC14023BCP
1820-2090	02037	MC14048BCP
1820-2091	02037	MC14075BCP
1820-2093	02237	F10010DC
1820-2094	02327	9316HDCD
1820-2095	02327	9627PC
1820-2096	01698	SN74LS393N
1820-2097	02037	MC14543BCP
1820-2098	03406	DM8099N
1820-2102	01698	SN74LS373N
1820-2103	03794	DS0056CN
1820-2104	01698	SN74LS242N
1820-2106	02237	F11C06DC
1820-2107	02237	74LS00PC
1820-2111	01698	SN75468N
1820-2112	01698	SN75467N
1820-2114	02327	FCM7002PC
1820-2117	02237	9636ATC
1820-2118	02237	96502PC
1820-2120	02037	MC145184N
1820-2121	01698	SN74LS348N
1820-2124	02037	MC14043BCP
1820-2125	02237	40163BCP
1820-2126	03406	DM5313N (7+)
1820-2127	01698	SN74276N
1820-2128	01698	SN75116N
1820-2129	04200	ULN-407
1820-2130	02037	MC14021PC
1820-2132	03714	ICM7218A
1820-2133	02037	MC14077PC
1820-2134	01698	SN75234N
1820-2136	03406	DS8973N
1820-2138	03406	DS8871N
1820-2140	02327	11C05DC
1820-2141	01698	SN75498N
1820-2144	02037	MC3486P
1820-2152	02037	MC14013PC
1820-2154	02037	MC3487P
1820-2156	03406	DS816PC
1820-2157	02037	MC3488P
1820-2159	01698	SN75117P
1820-2160	03794	AM74LS244N
1820-2161	03406	DS8835N
1820-2163	02910	2652I
1820-2164	01698	SN74LS20N
1820-2165	02037	MC3450P
1820-2166	02037	MC14412VP
1820-2168	01698	SN75117P
1820-2169	03794	AM5202PC
1820-2174	03406	DS3631N
1820-2178	03406	DS8640N
1820-2179	02910	2640F
1820-2180	01698	SN74LS244N
1820-2181	01698	SN75417NE
1820-2182	04092	SN74S373J
1820-2186	01698	SN75497N
1820-2187	03714	ICM7226AIDL
1820-2190	03794	AM25LS2518PC
1820-2193	02037	MC10176L
1820-2194	01698	SN74LS257BN
1820-2195	02910	26910
1820-2197	02327	9637ATC
1820-2199	02327	9638PTC
1820-2200	01698	SN74LS147N
1820-2201	01698	SN74LS322AN
1820-2202	02037	MC140115D
1820-2203	02037	MC10159L
1820-2204	02036	DS8676N
1820-2205	02237	9644TC
1820-2206	02327	74LS569PC
1820-2207	01698	SN75119P
1820-2208	03406	DM8131N
1820-2209	02037	MC10189P
1820-2210	02327	F10014PC
1820-2211	01698	SN75327N
1820-2216	02037	MC10198L
1820-2218	02037	MC10166P
1820-2231	02037	MC14059BCP
1820-2234	01698	SN74LS399N
1820-2235	02037	MC10189P
1820-2236	02327	9644TC
1820-2237	01698	SN74LS640N
1820-2239	02327	100101FC
1820-2241	02327	100102FC
1820-2242	02327	100103FC
1820-2243	02327	100104FC
1820-2244	02327	100105FC
1820-2245	02327	100106FC
1820-2246	02327	100107FC
1820-2247	02327	100108FC
1820-2248	02327	100109FC
1820-2249	02327	10010AFC
1820-2250	02327	10010BFC
1820-2251	02327	10010CFC
1820-2252	02327	10010DFC
1820-2253	02327	10010EFC
1820-2254	02327	10010FFC
1820-2255	02327	10010GFC
1820-2256	02327	10010HFC
1820-2257	02327	10010IFC
1820-2258	02327	10010JFC
1820-2259	02327	10010KFC
1820-2260	02327	10010LFC
1820-2261	02327	10010MFC
1820-2262	02327	10010NFC
1820-2263	02327	10010OFC
1820-2264	02327	10010PFC
1820-2265	02327	10010QFC
1820-2266	02327	10010RFC
1820-2267	02327	10010SFC
1820-2268	02327	10010TFC
1820-2269	02327	10010UFC
1820-2270	02327	10010VFC
1820-2271	02327	10010WFC
1820-2272	02327	10010XFC
1820-2273	02327	10010YFC
1820-2274	02327	10010ZFC
1820-2275	02327	100101FC
1820-2276	02327	100102FC
1820-2277	02327	100103FC
1820-2278	02327	100104FC
1820-2279	02327	100105FC
1820-2280	02327	100106FC

HP P/N	Mfr.	Desc.	1820-2803	02037	MC14001BCL	1820-3007	02037	MC74HC86N	1820-3213	01698	SN74LS647NT
1820-2587	01698	SN74LS86AJ	1820-2804	02037	MC14025BCL	1820-3008	03406	MM74HCU04N	1820-3215	03677	S1602P
1820-2588	01921	CD4060BE	1820-2805	02037	MC14017BCL	1820-3012	02237	74F534PC	1820-3216	02237	74F299PC
1820-2590	03793	SG3627	1820-2816	03811	DT250	1820-3013	03794	AM25LS2568DC	1820-3217	01698	SN74ALS569AN
1820-2592	01698	SN74LS320N	1820-2817	03811	DT242	1820-3014	03406	MM74HC139N	1820-3220	02237	74F139PC
1820-2593	01698	SN7407J	1820-2818	03811	DT230	1820-3015	06354	TC40H245P	1820-3221	02237	74F181PC
1820-2594	01698	AM26LS32ACN (SELECTED)	1820-2819	01698	SN74LS30N	1820-3018	01921	CD4029AE	1820-3222	02237	74F190PC
1820-2600	02237	96LS02PC	1820-2820	02910	PLS105F UNPRGMD	1820-3019	03794	AM29825DC	1820-3223	02237	74F243PC
1820-2606	03406	MM74C73N	1820-2821	02037	MC10159P	1820-3020	03794	AM29845DC	1820-3224	02237	74F245PC
1820-2610	01698	SN74LS686NT	1820-2822	02037	MC10H105P	1820-3022	01698	SN74LS599N	1820-3225	02237	74F251APC
1820-2611	02237	100101DC	1820-2823	02037	MC10H102P	1820-3058	03406	MM74HC174N	1820-3226	02237	74F253PC
1820-2613	01698	SN74LS356N	1820-2824	06354	TC40H373P	1820-3060	03714	ICM7217C1PI	1820-3227	02237	74F257PC
1820-2614	02237	100102DC	1820-2825	06354	TC40H374P	1820-3062	02237	100117DC	1820-3228	02237	74F350PC
1820-2621	01698	SN74S225N	1820-2826	03794	AM29665PC (SELECTED)	1820-3063	02237	100118DC	1820-3229	02237	74F353PC
1820-2622	01698	SN74LS624N	1820-2827	01698	NE555JG	1820-3065	02237	100124DC	1820-3230	02237	74F379PC
1820-2625	02713	AY-5-2376-006	1820-2830	03794	AM26LS32BPC	1820-3065	02237	100125DC	1820-3231	02237	74F381PC
1820-2626	01698	AC5947N	1820-2831	01698	SN75174N	1820-3066	02237	100141DC	1820-3232	02237	74F537PC
1820-2630	03406	MM74C941N	1820-2832	01698	SN74S341N	1820-3067	02237	100155DC	1820-3233	02237	74F539PC
1820-2634	01698	SN74ALS04BN	1820-2834	02037	MC10101L	1820-3068	02237	100158DC	1820-3234	02237	74F280PC
1820-2635	01698	SN74ALS08N	1820-2835	02037	MC10102L	1820-3069	02237	100160DC	1820-3235	03714	ICM75561PD
1820-2641	01698	SN74LS374N	1820-2836	02037	MC10104L	1820-3070	02237	100170DC	1820-3236	01698	SN74ALS1623N
1820-2644	03406	CD4050BCN	1820-2837	02037	MC10105L	1820-3071	02237	100171DC	1820-3237	01698	SN74ALS73NT
1820-2646	03714	ICM7227A1PI	1820-2838	02037	MC10106L	1820-3072	02237	100180DC	1820-3238	01698	SN74ALS1245A-1N
1820-2647	03714	ICM7227C1PI	1820-2839	02037	MC10107L	1820-3073	02237	100182DC	1820-3239	01698	SN74ALS1244A-1N
1820-2648	02237	100165DC	1820-2840	02037	MC10121L	1820-3074	02237	100183DC	1820-3240	01698	SN74ALS876NT
1820-2653	03794	AM25LS2569PC	1820-2841	02037	MC10188L	1820-3075	02037	MC10H116L	1820-3241	01698	SN74LS628N
1820-2654	02237	74F157PC	1820-2842	02037	MC10189L	1820-3076	02037	MC10H131L	1820-3243	04200	UGN-302T
1820-2655	01698	SN74LS625N	1820-2843	02037	MC10195L	1820-3077	03794	AM26S12PC SELECTED	1820-3244	01698	TM2510-4JD
1820-2656	01698	SN74ALS00AN	1820-2844	02037	MC10197L	1820-3078	03406	DM74LS168AN	1820-3245	01698	SN74ALS137N
1820-2657	01698	SN74ALS32N	1820-2845	02037	MC10211L	1820-3079	02037	MC74HC138N	1820-3246	08323	1AE7-6200
1820-2658	01921	CA161E	1820-2846	02037	MC10109L	1820-3080	02037	MC74HC20N	1820-3270	01698	SN74ALS03BN
1820-2662	01921	CD40116E	1820-2847	02037	MC10153P	1820-3081	02037	MC74HC74N	1820-3277	01698	74F399PC
1820-2664	02037	MC1678L	1820-2848	02037	MC10H116P	1820-3082	02037	MC74HC374N	1820-3279	02237	74F382PC
1820-2666	01698	SN74S37J	1820-2849	02037	MC10H131P	1820-3090	02237	74F161APC	1820-3280	02237	74F174PC
1820-2668	01698	SN75114N	1820-2850	01698	ST5473P	1820-3092	02237	74F538PC	1820-3281	02237	74F538PC
1820-2670	04092	PAL16L8A-2CJ UNPRGMD	1820-2860	02037	MC10H130P	1820-3097	03406	DM74LS168AN	1820-3282	03794	AM26S10PC
1820-2671	04092	PAL16H6C-2CJ UNPRGMD	1820-2861	02237	7F148PC	1820-3098	03406	MM74HC27N	1820-3283	03794	AM26LS34PC
1820-2672	01698	SN74LS623N	1820-2862	03406	DS3667N	1820-3100	01698	SN74ALS138N	1820-3287	01698	SN74ALS1245AN
1820-2675	01698	SN74LS646NT	1820-2863	03794	AM25LS191PC	1820-3102	02037	MC10H161L	1820-3289	04200	UCN-5800A
1820-2676	02237	74F64PC	1820-2864	02910	PLS153N UNPRGMD	1820-3104	01698	SN74ALS299N	1820-3291	04092	PAL16R6-2CJ UNPRGMD
1820-2677	04092	PAL10H8CJ UNPRGMD	1820-2866	09161	MD74SC245AC	1820-3105	01698	SN74ALS1002AN	1820-3292	04092	PAL16C1-2CJ UNPRGMD
1820-2678	04092	PAL14L4CJ UNPRGMD	1820-2875	02037	MC10H164P	1820-3106	01698	SN74ALS688N	1820-3293	01698	SN74ALS32N
1820-2679	04092	PAL16R6A-2CJ UNPRGMD	1820-2876	00575	BRI194M-06	1820-3118	01698	SN74ALS294N	1820-3295	02037	MC10H161
1820-2680	04092	PAL16R6A-2CJ UNPRGMD	1820-2877	02237	100151DC	1820-3120	06354	TC40H032P	1820-3297	02037	MC10H176L
1820-2681	04092	PAL16R4A-2CJ UNPRGMD	1820-2878	02237	100112DC	1820-3121	01698	SN74ALS245AN	1820-3298	02037	MC10H176L
1820-2682	04200	UDN-5703A	1820-2879	02037	MC145151P	1820-3122	00575	TR1865P-00	1820-3299	03406	MM74HC32N
1820-2683	04200	UDN-5706A	1820-2880	02037	MC145152P	1820-3124	02037	MC10124P	1820-3299	02037	MC74HC240N
1820-2684	02237	74F00PC	1820-2881	01698	SN74ALS27N	1820-3125	02037	MC10125P	1820-3300	01698	SN75154-01N
1820-2685	02237	74F02PC	1820-2882	01698	SN74ALS576N	1820-3126	02037	MC10136P	1820-3301	01698	SN74ALS480JS
1820-2686	02237	74F08PC	1820-2883	03794	AM74LS533PC	1820-3127	02037	MC10141P	1820-3302	01698	SN75157P
1820-2687	02237	74F10PC	1820-2884	03647	HD74LS390P	1820-3128	02037	MC10158P	1820-3303	01698	SN74ALS245AN
1820-2688	02237	74F11PC	1820-2887	02237	100112DC	1820-3129	02037	MC10164P	1820-3305	01698	SN74LS684W
1820-2689	02237	74F20PC	1820-2888	01698	SN74ALS21N	1820-3130	02037	MC10181P	1820-3306	03794	AM29824DC
1820-2690	02237	74F32PC	1820-2889	01698	SN74ALS11AN	1820-3133	02237	74F283PC	1820-3307	03794	AM2983DC
1820-2691	02237	74F74PC	1820-2891	02037	MC10H101P	1820-3134	00575	WD1943M-06	1820-3308	02037	SN74ALS39N
1820-2692	02237	74F86PC	1820-2892	04200	ULN2814A	1820-3135	02237	74F416PC	1820-3311	01698	SN74ALS640-1N
1820-2693	02237	74F109PC	1820-2897	02037	MC14515P	1820-3136	03406	MM74HC154N	1820-3312	02037	MC1489AP
1820-2694	02237	74F112PC	1820-2898	02237	100107DC	1820-3137	08323	1AHT-6202	1820-3313	02037	MC1488P
1820-2695	02237	74F158PC	1820-2899	01698	SN74ALS885NT	1820-3138	08323	1AHT-6201	1820-3314	02037	MC1489AP
1820-2696	02237	74F175PC	1820-2900	02037	MC10H109P	1820-3139	08323	1AD5-6101	1820-3315	02037	MC10H175N
1820-2697	02237	74F194PC	1820-2901	01590	SP8691A	1820-3140	08323	1AD5-6201	1820-3316	02037	MC10H176L
1820-2698	02237	74F240PC	1820-2902	03794	AM25LS299PC	1820-3141	03406	DP8408N-2	1820-3317	02037	MC10H176L
1820-2699	02237	74F241PC	1820-2907	03545	TQ40H138P	1820-3143	01698	SN74ALS74NT	1820-3318	03406	MM74HC245N
1820-2700	02237	74F373PC	1820-2908	03545	TQ40H000P	1820-3144	01698	SN74LS590N	1820-3319	03406	MM74HC245N
1820-2701	02237	74F74PC	1820-2909	03545	HD74LS91N	1820-3145	01698	SN74ALS244N	1820-3320	03406	SN74ALS244N
1820-2702	02037	MC14512BCL	1820-2913	02037	SN74ALS2568PC	1820-3146	02037	MC74HC175N	1820-3321	03406	SN74ALS123N
1820-2703	01698	SN75174N	1820-2914	01590	SP8691A	1820-3147	09161	MD74HTC373RC	1820-3322	03406	MC10H104P
1820-2710	01698	SN74LS540N	1820-2921	03406	MM74HC04N	1820-3148	01698	SN74ALS539N	1820-3323	03406	DP8408N-2
1820-2711	01698	SN74LS541N	1820-2922	02037	MC74HC009P	1820-3149	03406	MM74HC75N	1820-3324	02037	MC10H117P
1820-2712	03714	ICM721881J1	1820-2923	02037	MC74HC110N	1820-3150	02037	MC74HC85N	1820-3325	02037	MC10H119P
1820-2713	01698	SN74LS628N	1820-2924	02037	MC74HC02N	1820-3161	01698	SN74LS606N	1820-3326	02037	MC10H121P
1820-2715	01698	SN75447P	1820-2925	02037	MC74HC161N	1820-3165	04200	UCN-5801A	1820-3341	02037	MC10H210L
1820-2716	02037	MC14513BCL	1820-2926	03794	AM25LS2568PC	1820-3167	01698	SN74LS592N	1820-3342	02037	MC10H174L
1820-2719	04092	PAL74LS534N	1820-2928								

HP P/N	Mfr.	Desc.	1820-3405	02037	MC145146P	1820-3600	04092	PAL16R4A-2CN UNPRGMD	1820-3783	03794	AMPAL16R8APC UNPRGMD	1820-3938	06347	HD6350P
1820-3410	01590	MJ2841DP	1820-3601	04092	PAL20X3CSNS UNPRGMD	1820-3785	02037	MC74H0163N	1820-3939	02910	74F85N			
1820-3411	01698	SN74LS1575FN	1820-3602	04092	PAL16R8A-2CN UNPRGMD	1820-3786	01921	CD74HC670E	1820-3940	01921	CD74HCT174E			
1820-3412	01698	SN74LS214AFN	1820-3603	01698	SN74AS27N	1820-3787	03406	MM74H0640P	1820-3941	02910	SCN2641CC1N24			
1820-3413	01698	SN74ALS86FN	1820-3607	02037	SN74ALS24N	1820-3788	02037	MM74H058N	1820-3952	01698	SN74LS161AN			
1820-3416	01698	SN74ALS520N	1820-3608	01698	SN74AS0N	1820-3789	03406	MM74H0574N	1820-3953	01698	SN74S74W			
1820-3417	03406	DP8340N	1820-3609	03406	CD4048BCJ	1820-3790	03406	MM74H0573N	1820-3954	01698	SN74LS123N			
1820-3418	03406	DP8341N	1820-3610	03794	AMPAL16H8APC UNPRGMD	1820-3791	03406	MM74H0368N	1820-3956	01698	SN74LS122N			
1820-3421	04200	UDN-6118A	1820-3611	03794	AMPAL16H8D8APC UNPRGMD	1820-3792	03406	MM74H0367N	1820-3959	01698	SN74S74BP			
1820-3423	01698	SN74LS595N	1820-3612	03794	AMPAL16LD8APC UNPRGMD	1820-3793	01698	SN74H021N	1820-3960	01698	SN74LS596N			
1820-3426	03794	AM29863DC	1820-3613	04092	PAL20R4ACAP UNPRGMD	1820-3794	03406	MM74H0191N	1820-3961	03794	AM29841DC			
1820-3431	03406	DS75160AN	1820-3614	04092	PAL20R8ACNS UNPRGMD	1820-3795	03406	MM74H0113N	1820-3962	03794	AM29843DC			
1820-3435	02037	MC10H209L	1820-3615	04092	PAL20L8ACNS UNPRGMD	1820-3796	03406	MM74H0139N	1820-3963	02237	7WF148PC			
1820-3437	01698	SN74ALS1035N	1820-3616	03794	PAL22V10AOPC UNPRGMD	1820-3797	01698	SN74ALS1004FN	1820-3964	02037	MC12018P			
1820-3438	01698	SN74ALS257N	1820-3617	03794	AMPAL16R8LDC UNPRGMD	1820-3798	01698	SN74ALS04FN	1820-3965	03406	DP8451N			
1820-3439	01698	SN74ALS253N	1820-3619	04078	MK5089N	1820-3799	01698	SN74ALS1010AFN	1820-3971	01698	SN74AS64ON			
1820-3440	03794	AM29827DC	1820-3620	02037	MC10192L	1820-3800	01698	SN74ALS1020AFN	1820-3972	01698	SN74LS321N			
1820-3442	01698	SN74AS04AN	1820-3621	01698	SN74LS5467N	1820-3801	01698	SN74ALS05PN	1820-3973	01698	SN74ALS86N			
1820-3443	01698	SN74AS08AN	1820-3626	03406	MM74HCT241N	1820-3802	01698	SN74ALS27FN	1820-3975	03406	MM74HC541N			
1820-3445	03406	DS3487N	1820-3629	03406	MM74HCT04N	1820-3803	01698	SN74ALS08PN	1820-3977	03794	AM29826DC			
1820-3446	02037	MC10H164L	1820-3630	03406	MM74HCT240N	1820-3804	01698	SN74ALS1011AFN	1820-3982	01698	SN74ALS166N			
1820-3447	01698	SN74N064N	1820-3631	03406	MM74HCT688N	1820-3805	01698	SN74ALS1240FN	1820-3983	02910	7WF195N			
1820-3456	03406	MM74HCT244N	1820-3633	01698	SN74ALS1004N	1820-3806	01698	SN74ALS1244AFN	1820-3986	03794	AMPAL16R4APC UNPRGMD			
1820-3458	04092	C67L401N	1820-3634	01698	SN74ALS867NT	1820-3807	01698	SN74ALS74AFN	1820-3989	01698	SN74LS601N			
1820-3459	03406	DM74LS74N	1820-3637	04200	ULN-2069B	1820-3808	01698	SN74ALS112AFN	1820-3991	01698	SN74AS21N			
1820-3460	01698	SN74LS30N	1820-3638	01698	SN74ALS466AN	1820-3809	01698	SN74ALS138PN	1820-3993	01698	SN74ALS575ANT			
1820-3461	02037	MC10H115P	1820-3644	04200	UNG 3030U	1820-3810	01698	SN74ALS139FN	1820-3994	01698	SN74ALS243AN			
1820-3463	03406	MM74C76TN	1820-3645	02237	7F1610APC	1820-3811	01698	SN74ALS251FN	1820-3995	02910	PLS15M UNPRGMD			
1820-3465	01698	SN74ALS174N	1820-3646	02037	MC101205P	1820-3812	01698	SN74ALS253FN	1820-3996	01698	TIBPAL16L18-15CN UNPRGMD			
1820-3466	01698	SN74ALS175N	1820-3649	02237	7F1614PC	1820-3813	01698	SN74ALS165PN	1820-4025	01698	SN74AS575N			
1820-3467	01698	SN74ALS832N	1820-3650	01698	SN74LS545N	1820-3814	01698	SN74ALS299FN	1820-4026	01698	SN74AS280N			
1820-3468	01698	SN74ALS12AN	1820-3658	03406	DS3674N	1820-3815	01698	SN74ALS373FN	1820-4027	03406	MM74CH049N			
1820-3469	01698	SN74ALS538N	1820-3664	03406	MM74HCT00N	1820-3816	01698	SN74ALS160BFN	1820-4031	02237	7WF569PC			
1820-3471	01698	TMS2150-5JD	1820-3665	03406	MM74HCT245N	1820-3817	01698	SN74ALS161BFN	1820-4032	03714	ICL7667CPA			
1820-3472	01698	SN74ALS521N	1820-3666	02037	MC10115P	1820-3818	01698	SN74ALS168BFN	1820-4033	01698	SN74AS842NT			
1820-3473	01698	SN74LS645-1N	1820-3668	01698	SN74ALS642AN	1820-3819	01698	SN74ALS169BFN	1820-4034	03794	AMPAL22V10PC UNPRGMD			
1820-3475	01698	SN74LS132N	1820-3669	01698	SN74LS674N	1820-3820	01698	SN74AS74FN	1820-4044	01698	TIFPLA839NT UNPRGMD			
1820-3479	01698	SN74ALS28AN	1820-3670	03406	MM74HC133N	1820-3821	01698	SN74ALS112FN	1820-4050	01698	TIBPAL16R8-15CN UNPRGMD			
1820-3480	01698	SN74ALS1008AN	1820-3672	02037	MC74HC253N	1820-3822	01698	SN74AS168FN	1820-4051	01698	TIBPAL16R-15CN UNPRGMD			
1820-3481	01698	SN74ALS645AN	1820-3673	03406	MM74HC123AN	1820-3823	01698	SN74ALS169FN	1820-4052	01698	TIBPAL16R4-15CN UNPRGMD			
1820-3485	02037	MC12090L	1820-3674	03406	MM74HC125N	1820-3824	01698	SN74AS374FN	1820-4053	01698	SN74HC059			
1820-3486	03799	CP8282	1820-3675	03406	MM74HC30N	1820-3828	03794	AM7990DC/70	1820-4054	01698	SN74HC190N			
1820-3487	02037	MC14410P	1820-3676	03406	MM74HC237N	1820-3829	03794	AM7991ADC	1820-4055	02037	MC74HC162N			
1820-3489	01698	SN75407P	1820-3677	03406	MM74HC366N	1820-3830	04092	SN74AS373N	1820-4056	02037	MC74HC511N			
1820-3490	09161	MW8780BC	1820-3678	03406	MM74HC4050N	1820-3831	02037	MC10H174P	1820-4057	02910	7WF38N			
1820-3492	04092	PAL16R4ACN UNPRGMD	1820-3683	02037	MC74HC4017N	1820-3832	03406	MM58274N	1820-4059	01698	TIBPAL16R-15CN UNPRGMD			
1820-3493	01698	SN74AS747N	1820-3685	02883	DL69C	1820-3833	01698	SN74ALS680N	1820-4060	03794	AM29821DC			
1820-3495	01698	SN74LS279AN	1820-3686	02037	MC10H100P	1820-3837	01698	SN74LS164N	1820-4061	03794	AM29822DC			
1820-3496	01698	SN74LS51S	1820-3690	02037	SN74ALS377N	1820-3838	01698	SN74LS132N	1820-4062	03794	AM29828DC			
1820-3497	01698	SN74ALS645A-1N	1820-3691	02883	D169CJ	1820-3839	01698	SN74S08N	1820-4063	03794	AM29834DC			
1820-3498	01698	SN74ALS640A-1N	1820-3692	03406	MM74HC4053N	1820-3840	01698	SN74S02N	1820-4064	03794	AM29842DC			
1820-3499	03285	ADSP-1012AJD	1820-3693	03406	MM74HC4066N	1820-3841	01698	SN74AS168N	1820-4065	03794	AM29844DC			
1820-3500	09283	SP74HCT138N	1820-3694	01698	SN74LS174N	1820-3842	01698	SN74AS169N	1820-4066	03794	AM29846DC			
1820-3501	09283	SP74HCT244N	1820-3695	01698	SN74AS374N	1820-3843	01698	SN74AS645N	1820-4067	03794	AM29853DC			
1820-3502	02037	SP74HCT245N	1820-3696	01698	SN74ALS642AN	1820-3844	01921	CD74HCT173E	1820-4068	03794	AM29861DC			
1820-3504	02037	SP74HCT374N	1820-3699	02037	MC10H176P	1820-3846	02721	SN74CT563P	1820-4070	03794	AM29864DC			
1820-3505	01698	SN74ALS191N	1820-3700	02037	MC10H159P	1820-3847	03406	MM74HCT138N	1820-4075	01698	SN74ALS259N			
1820-3506	01698	SN74LS384N	1820-3701	02037	MC10H113P	1820-3848	03406	MM74HCT374N	1820-4076	01698	SN74ALS577NT			
1820-3512	04200	ULN-2061N	1820-3702	02037	MC10H188P	1820-3849	03406	MM74HCT373N	1820-4077	01698	SN74ALS580N			
1820-3513	03406	DS75161AN	1820-3703	02037	MC10H189P	1820-3852	03794	AMPAL16L8LDC UNPRGMD	1820-4078	02910	7WFCT257N			
1820-3511	02910	PLS153AN UNPRGMD	1820-3720	00575	WD1100-13	1820-3860	0347	HD44103CH	1820-4079	01698	SN74AS652NT			
1820-3516	01698	SN74LS597N	1820-3721	02037	MC15440UP SELECTED	1820-3870	01698	SN74ALS1245AFN	1820-4080	01698	SN74S414NT			
1820-3537	01921	CD74HCT74E	1820-3728	02237	7F4352PC	1820-3871	01698	SN74ALS273FN	1820-4082	01698	PAL20R6ACNS UNPRGMD			
1820-3538	02910	SCN2618AC1N40	1820-3729	01698	SN74AS02N	1820-3872	01698	SN74ALS574AFN	1820-4119	06354	TC74HC04F			
1820-3539	01698	SN75123N	1820-3730	01698	SN74AS08N	1820-3873	01698	SN74ALS190FN	1820-4120	0354	TC74HCT4F			
1820-3540	01698	SN75129N	1820-3731	01698	SN74AS110N	1820-3874	01698	SN74ALS257FN	1820-4121	0354	TC74HCT138F			
1820-3541	01698	SN74ALS244N	1820-3732	01698	SN74AS241N	1820-3875								

HP P/N Mfr. Desc.

1820-4196	03406	MM74HCT157N	1820-4367	02910	74LS04D	1820-4681	02037	MC10116P	1820-4995	06354	TC74HCK592P
1820-4197	02037	MC101H23P	1820-4368	02910	74LS175D	1820-4685	01590	SFS9131DG	1820-4997	06338	L293D
1820-4198	02037	MC101H60P	1820-4369	02910	74LS74AD	1820-4686	01425	FDC9229BTP	1820-4998	02910	74F32D
1820-4199	02037	MC101H32P	1820-4371	02910	74LS32D	1820-4687	02910	7WF02D	1820-5001	01698	SN74LS624D
1820-4200	02037	MC10807L	1820-4372	02910	74LS10D	1820-4688	11302	ICM7218A1PI	1820-5002	01698	SN74ALS374DW
1820-4201	02037	MC108H24P	1820-4373	02910	74F10D	1820-4690	03406	DS14C89AN	1820-5012	11345	FALC22V10-25PC UNPRGMD
1820-4202	02037	MC101H35P	1820-4374	01698	SN74LS612N	1820-4691	03406	DS14C88N	1820-5013	11345	FALC22V10-25PC UNPRGMD
1820-4203	02037	MC101H36P	1820-4375	01698	SN74AS286N	1820-4692	01698	SN74HC00D	1820-5014	02237	74F525DC
1820-4204	02037	MC101H350P	1820-4376	02910	74LS00D	1820-4693	01698	SN74HC08D	1820-5015	01698	SN74ALS747N
1820-4205	06338	L298	1820-4377	02910	74FOOD	1820-4694	01698	SN74ALS653NT	1820-5020	01698	SN74AS808BDW
1820-4206	02037	MC101H166P	1820-4391	01698	SN74ALS646NT	1820-4705	02037	MC74HC4351N	1820-5021	01698	SN74AS870NT
1820-4207	01698	SN74AS1036N	1820-4392	03406	MM74HC283N	1820-4706	03406	MM74HC4316N	1820-5023	01698	SN74HC652NT
1820-4208	01698	SN74HC377N	1820-4393	04092	PAL12L6-2CJ UNPRGMD	1820-4708	01698	SN74AS56N	1820-5024	03406	MM58274T
1820-4209	02037	MC10177P	1820-4401	03794	AM7929BCD	1820-4711	01698	SN74AS825NT	1820-5025	01698	SN74ALS488NT
1820-4211	01698	SN74ALS639N	1820-4402	01698	SN74AS1805N	1820-4716	01698	SN74ALS83NT	1820-5026	01698	SN7406D
1820-4212	02910	74HCT245N	1820-4433	03406	PAL1016P8JC UNPRGMD	1820-4719	01698	SN74HC805N	1820-5027	01698	TIBPAL16L8-25CFN UNPRGMD
1820-4215	02910	74HC138D	1820-4435	03794	AMPA1L6R4LPC UNPRGMD	1820-4720	01698	SN74ALS64AN	1820-5028	01698	TIBPAL16R8-25CFN UNPRGMD
1820-4216	02910	74HC240D	1820-4436	03794	AMPA1L6R8LPC UNPRGMD	1820-4721	02910	74HCT32N	1820-5029	02910	PLS168AN UNPRGMD
1820-4217	02910	HEP4076BT	1820-4437	02037	MC74HC4543N	1820-4724	01698	SN75173N	1820-5033	01698	SN74ALS35AN
1820-4218	02910	74HC85D	1820-4438	02037	MC10192P	1820-4735	01698	SN75172N	1820-5038	01698	SN74ALS1004AD
1820-4219	02910	74HC27D	1820-4439	02910	74F37N	1820-4737	01698	SN74HCT2410DW	1820-5040	02910	74F74D
1820-4220	02910	74HC32D	1820-4443	03455	TC74HC4094P	1820-4738	02237	7F4ACT74PC	1820-5041	02910	74F10D
1820-4222	06347	HD101031	1820-4444	01698	SN74AS299N	1820-4739	02910	7F5F79N	1820-5042	02910	74F157AD
1820-4223	02910	HEF7424BP	1820-4445	01698	SN74AS869NT	1820-4740	02037	MC10H423P	1820-5043	02910	74F175D
1820-4223	02037	MC74HC4078N	1820-4446	03406	LH0063CK	1820-4741	12125	KS74HCT64ON	1820-5045	02910	74F64D
1820-4223	01698	SN74ALS244A-1N	1820-4448	01590	SP16F60DG	1820-4748	12125	KS74HCT240N	1820-5050	02910	74F273D
1820-4224	02910	74F273N	1820-4449	02910	74S273N	1820-4749	12125	KS74HCT244N	1820-5051	02910	74F269D
1820-4224	01698	SN74ALS04BD	1820-4450	01698	SN74AS821NT	1820-4750	04092	PAL16R4BCD UNPRGMD	1820-5052	02910	74F151D
1820-4225	01698	SN74ALS05AD	1820-4454	02037	MC74HC126N	1820-4752	12125	KS74HCT259N	1820-5053	02910	74F125D
1820-4245	01698	SN74ALS11AD	1820-4459	01698	SN74AS1804N	1820-4753	12125	KS74HCT273N	1820-5054	03406	MM74HC123AM
1820-4246	01698	SN74ALS20D	1820-4461	01698	SN75176AP	1820-4754	12125	KS74HCT138N	1820-5055	02910	74HCT151N
1820-4247	01698	SN74ALS23D	1820-4465	02910	74HCT377N	1820-4755	03406	PAL16L8BNC UNPRGMD	1820-5056	02910	74HCT161N
1820-4248	01698	SN74ALS86D	1820-4469	01698	SN74LS603AN	1820-4756	03406	PAL16R8BNB UNPRGMD	1820-5058	02237	7AC04PC
1820-4249	01698	SN74ALS04BD	1820-4492	02910	74F27N	1820-4757	04092	PAL16R4BNB UNPRGMD	1820-5059	01698	MC346N
1820-4250	01698	SN74ALS05AD	1820-4493	04092	PAL16R6BCJ UNPRGMD	1820-4758	03406	PAL16R6BNB UNPRGMD	1820-5060	011302	ICM7218B1PI
1820-4251	01698	SN74LS1W4	1820-4494	04092	PAL16R8BCU UNPRGMD	1820-4760	10253	IDT74HCT245P	1820-5064	01698	SN74AS881ANT
1820-4252	01698	SN74ALS10AD	1820-4496	01698	SN74AS1808N	1820-4761	07371	LB1246	1820-5065	04092	PAL16L8A-4CN UNPRGMD
1820-4253	03406	DS1489AN	1820-4497	01698	SN74ALS678NT	1820-4770	03794	AM29843PC	1820-5066	01698	TMS2150-4NT
1820-4255	01698	SN74LS85D	1820-4498	01698	SN74AS858NT	1820-4776	01698	SN74AS243D	1820-5067	02237	7AC74PC
1820-4256	01698	SN74LS123D	1820-4500	04092	67W01N	1820-4777	02910	7F125N	1820-5068	02237	7AC373PC
1820-4257	01698	SN74ALS13D	1820-4501	04092	PAL16L2CN UNPRGMD	1820-4778	02910	7F4F51N	1820-5069	03406	MM74HC4051N
1820-4258	01698	SN74ALS139D	1820-4503	07314	ICM7218EIJL	1820-4779	02910	7F4F126N	1820-5070	01698	SN74AS1000AD
1820-4259	01698	SN74ALS251D	1820-4522	00039	UP7210	1820-4780	02910	7F4HTC175N	1820-5071	02910	74HCT132N
1820-4260	01698	SN74ALS253D	1820-4522	03799	HPL1-16RC6-9 UNPRGMD	1820-4781	12125	KS74HCT00N	1820-5074	02037	MC10H330P
1820-4261	01698	SN74ALS257D	1820-4523	03799	HPL1-16LC8-9 UNPRGMD	1820-4786	01698	SN74LS125AD	1820-5075	01698	SN74ALS20AD
1820-4262	01698	SN74ALS283D	1820-4524	03799	HPL1-16CR4-9 UNPRGMD	1820-4787	01698	SN74ALS240ADW	1820-5076	01698	SN74ALS153D
1820-4263	01698	SN74ALS259D	1820-4527	03406	DS3695N	1820-4788	01698	SN74ALS244ADW	1820-5077	01698	SN74HTS74DW
1820-4264	01698	SN74ALS73BD	1820-4531	01698	SN74HC7001N	1820-4789	01698	SN74ALS393D	1820-5078	04092	PAL20L8ACNL UNPRGMD
1820-4265	01698	SN74ALS164D	1820-4535	01698	SN74ALS41NT	1820-4790	01698	SN74ALS254DW	1820-5079	02237	7F403DC
1820-4266	01698	SN74ALS165D	1820-4537	02327	7F4676SDC	1820-4791	0350	XR-T5675CP	1820-5080	01698	SN74ALS14AN
1820-4267	01698	SN74LS194D	1820-4551	02910	74F30N	1820-4792	01542	HCTL-2000	1820-5081	01698	SN74ALS283D
1820-4268	01698	SN74LS168BD	1820-4553	01698	SN74LS598N	1820-4793	01698	SN75151N	1820-5082	01698	KS74HCT257N
1820-4269	01698	SN74ALS169BD	1820-4554	01698	THCT2000	1820-4794	04200	UDN-2585A	1820-5083	01698	KS74HCT258N
1820-4270	01698	SN74ALS190D	1820-4562	11111	8023A	1820-4794	03406	MN5848N	1820-5084	01698	SN75151N
1820-4271	01698	SN74ALS191D	1820-4565	01698	SN74AS876N	1820-4795	02910	7F4F35N	1820-5111	02910	74HCT21N
1820-4272	01698	SN74ALS240AFN	1820-4566	04092	PAL20L10ACJS UNPRGMD	1820-4797	02910	7F4F126N	1820-5112	01698	SN74ALS14AN
1820-4274	01698	SN74ALS244AFN	1820-4567	02910	74HCT259N	1820-4798	02910	7F4HTC175N	1820-5113	02910	74F138D
1820-4274	01698	SN74ALS245AFN	1820-4568	04200	UCN-5801A	1820-4799	02910	CD4044BF	1820-5114	01698	SN74ALS283D
1820-4275	01698	SN74ALS74AD	1820-4569	02037	MC74HC540N	1820-4801	02910	7F4F38D	1820-5115	01698	SN74ALS564DW
1820-4276	01698	SN74ALS112AD	1820-4574	02037	MC74HC4052N	1820-4802	01921	CD74HCT154E	1820-5116	01668	R8070F-22P
1820-4277	01698	SN74ALS273DW	1820-4575	01698	SN74LS253N	1820-4803	0237	7F4HTC210-100C	1820-5117	02910	7F4260N
1820-4279	01698	SN74ALS74ADW	1820-4576	01698	SN74HCT43NT	1820-4805	02910	SC22691AC1N24	1820-5118	01698	SN74ALS243AD
1820-4281	01698	SN74ALS08D	1820-4582	04092	PAL16L4A-4CJ UNPRGMD	1820-4807	03406	DP8451V-4	1820-5119	01698	SN74ALS845NT
1820-4281	01698	SN74ALS02D	1820-4583	02910	74HCT08N	1820-4808	01698	SN74ALS533N	1820-5119	02237	7F4F53PC
1820-4283	01698	SN74ALS32D	1820-4584	02910	74HCT251N	1820-4809	03406	PAL16L8A-2CN UNPRGMD	1820-5115	01668	ADSP321K1GN
1820-4284	01698	SN74ALS194D	1820-4585	02037	MC74HCT64N	1820-4809	01698	7F4HTC200N	1820-5116	01668	ADSP321K1GN
1820-4288	01698	SN74ALS169D	1820-4588	02910	74HCT86N	1820-4809	03406	DS8921N	1820-5117	01698	SN74ALS253DW
1820-4289	01698	SN74AS747D	1820-4590	03406	MM74HC43AN	1820-4809	03406	MM74HC373WM	1820-5118	01698	SN74ALS105AN
1820-4290	01698	SN74ALS112D	1820-4591	01698	SN74AS1034N	1820-4809	03406	MM74HC431DW	1820-5119	01698	SN74ALS419ANS
1820-4291	01698	SN74ALS00AD	1820-4592	01698	SN74ALS353N	1820-4809	04090	DP8392N	1820-5120	01698	SN74ALS67NT
1820-4310	02337	7F4193PC	1820-4593	01698	SN74ALS652NT	1820-4809	01698	SN74ALS109AD	1820-5121	02910	7F4HTC287NT
1820-4314	02337	MC10H173P	1820-4597	02337	7F4534SPC	1820-4809	01698	SN74ALS174D	1820-5122	01698	SN74ALS283AD
1820-4314	02337	MC10H181P									

HP P/N	Mfr.	Desc.	1826-0029 04200 ULN-2111A	1826-0181 03406 LM323K	1826-0328 02290 RV4558DE
1820-5276	06344	MB506-DIP-8	1826-0031 02237 UA726HC	1826-0182 03285 AD540J	1826-0329 03406 LM113-2H
1820-5285	01698	SN7438D	1826-0032 02037 MC1463R	1826-0183 02237 UA734HC	1826-0330 03406 LM299H
1820-5286	02910	PCF8576T	1826-0033 02037 MC1463G	1826-0184 02237 UA749DC	1826-0331 02037 XC79L12CG
1820-5287	03406	MM58242N	1826-0035 03406 LM308AH	1826-0185 01921 CA3080	1826-0332 02037 XC79L05CG
1820-5288	04092	PAL1618ACN UNPRGM	1826-0036 02037 MC1494L	1826-0188 02037 MC1408L-8	1826-0333 02237 78L12AHC
1820-5291	02037	MC74HC107N	1826-0037 02037 MC15900	1826-0189 02910 NE566H	1826-0334 02037 MC1445L
1820-5310	01698	SN74LS874BDW	1826-0038 02037 MC1436G	1826-0191 03406 LM319H	1826-0336 03406 LM13340-1N
1820-5311	01698	SN74LS39D0	1826-0040 02910 S5733A	1826-0192 03406 LM320H-15	1826-0338 03794 AM686HC
1820-5312	01698	SN74LS323DW	1826-0041 01921 CA3059	1826-0193 03714 IH5012CFE	1826-0340 03406 LF356H SELECTED
1820-5313	01698	SN74LS166AD	1826-0042 02037 MC14174I	1826-0194 02910 NE592N	1826-0342 02237 UA749DH
1820-5314	01698	SN74AS253D	1826-0043 03406 LM307H	1826-0195 02883 LD111CJ	1826-0343 02037 MC1436CC
1820-5315	01698	SN74AS28D0	1826-0044 02237 UA739DC	1826-0196 02290 RC4195TK	1826-0344 02037 MC7908CT
1820-5316	01698	SN74AS37D0	1826-0045 03406 LM201AH SELECTED	1826-0197 02180 DAC-100CQ3	1826-0345 02237 UA78M12UIC
1820-5317	01698	SN74AS374DW	1826-0047 02910 NE562B	1826-0198 02037 MFC4000B	1826-0346 03406 LM358N
1820-5318	01698	SN74ALS646DW	1826-0048 02037 MC14156	1826-0200 02037 MC1420G	1826-0347 01921 CA339E SELECTED
1820-5319	01698	SN74LS133D	1826-0049 02237 UA723DC	1826-0201 03406 LM312J	1826-0348 03406 LM377N
1820-5320	01698	SN74AS32BDW	1826-0051 02037 MC1414P	1826-0202 03406 LM320K-05	1826-0349 02237 UA78M06HC
1820-5321	01698	SN74AS05BDW	1826-0055 02237 UA711DC	1826-0203 02237 UA7815KC	1826-0353 03406 LM78L15ACH
1820-5322	01698	SN74AS21D	1826-0056 02237 UA740HC	1826-0204 02910 NE565N	1826-0354 03406 LM310H SELECTED
1820-5323	01698	SN74AS64DW	1826-0058 02910 NE501A	1826-0205 02910 NE566N	1826-0355 03406 LM555CN
1820-5324	01698	SN74LS126D	1826-0059 03406 LM201AH	1826-0206 03406 LM381N	1826-0356 03285 AD7530JD
1820-5325	01698	SN74AS244DW	1826-0060 02037 MC1438R	1826-0207 03406 LM318N	1826-0357 03406 LF357H
1820-5326	01698	AM26LS31D	1826-0061 03793 SG3501AJ	1826-0208 03406 LM310N	1826-0358 03406 LF256H, SEL NOISE
1820-5327	01698	AM26LS32ACD	1826-0063 02237 UA711HC SELECTED	1826-0209 03406 LM380N-8	1826-0360 02037 MC3431P
1820-5328	01698	SN7518BD	1826-0064 02237 UA733DC	1826-0210 03406 LM361N	1826-0361 02037 MC1204OP
1820-5329	01698	SN7518PD	1826-0065 03406 LM311N	1826-0212 02237 UA776TC	1826-0365 03799 HA2-2065-5
1820-5330	01698	SN751818FN	1826-0067 02910 NE531H	1826-0213 02910 NE521N	1826-0367 02037 MC78M05CG
1820-5333	02910	7WF1240D	1826-0068 03406 LM307N SELECTED	1826-0214 02037 MC7915CT	1826-0370 03406 LM340K-8
1820-5336	03406	DMPAL1618B2VC UNPRGM	1826-0069 03406 LM301AJ-14	1826-0215 02037 MC7905, 2CT	1826-0372 03406 LF256H
1820-5338	10858	LT1081-CN	1826-0070 02237 7WF1DC	1826-0217 02290 RC4558H	1826-0373 03406 LM555CN
1820-5339	03406	MM5450N	1826-0071 02037 MC1456G	1826-0218 01921 CA3100T	1826-0374 02237 UA96501DC
1820-5346	03811	D5C060-35	1826-0072 03406 LM208H	1826-0219 02910 NE567N	1826-0375 03406 LX5700H
1820-5366	06344	M887030	1826-0074 03285 AD503K(SEL)	1826-0220 03406 LM320H-05	1826-0377 03406 LM320T-18
1820-5371	03406	DS8922AN	1826-0075 01921 CA3079	1826-0221 02037 MC7912CT	1826-0382 02037 MC1355P
1820-5374	02237	7WF673APC	1826-0077 03406 LM311F	1826-0222 02290 RC4136DB	1826-0387 03714 ICL 8250 C PE
1820-5375	02910	7WF1616N	1826-0078 01921 CA3030	1826-0224 02910 SE555CT	1826-0388 03406 LH0071-1H
1820-5376	02237	7HAC157SC	1826-0079 03799 HA2-2625-5	1826-0225 03406 LM322N	1826-0390 03406 LM3911N
1820-5377	02910	7WF257AD	1826-0081 03406 LM318H	1826-0226 02237 UA78M12HC	1826-0391 03714 ICL741C-LN-TY
1820-5384	10421	RTC62421	1826-0082 03285 AD741LH	1826-0229 02180 OP-05CJ	1826-0392 03794 AM301AH
1820-5385	10253	IDT4C9640AG	1826-0086 02237 776HC	1826-0230 01921 CA3053	1826-0393 03406 LM317T
1820-5386	02237	7WF53P3C	1826-0087 01921 CA3004	1826-0231 02237 UA760HC	1826-0394 03406 LM7811OACH
1820-5387	01698	SN74AS11D	1826-0089 03799 HA2-2525-5 (SELECTED)	1826-0232 03406 LM224J	1826-0396 02237 7815UC
1820-5390	02037	MC101H25FN	1826-0090 03285 AD741HK(SEL)	1826-0233 03406 LM220K-15	1826-0397 03406 LM120K-5.0
1820-5392	03406	PAL16R6AVC UNPRGM	1826-0091 05663 DRAM 6.8B10	1826-0234 03406 LM321AH SELECTED	1826-0398 03406 LM271H
1820-5395	03406	MM74HC173M	1826-0094 01698 SN75235N	1826-0235 03406 LM220K-12	1826-0399 02037 MC3340P
1820-5396	10253	IDT74FTC191A	1826-0097 03406 LM210H SELECTED	1826-0237 03500 XR320	1826-0400 02910 SE555T
1820-5402	03406	PAL10L8A2VC UNPRGM	1826-0098 03406 LM211H	1826-0238 03406 LM325AS	1826-0401 02883 L144CJ
1820-5403	03947	NCR538-44PLCC	1826-0099 02237 UA7812UC	1826-0243 03406 LM1558H	1826-0402 06545 LAS-1515
1820-5404	01698	SN74LS29D2	1826-0100 02237 747DC	1826-0244 02910 NE529A	1826-0403 06545 LAS-1815
1820-5411	03406	DP834L	1826-0101 03406 LM565CH	1826-0245 03406 LM370N	1826-0404 02237 UA7952UC
1820-5417	04092	PAL11L4WCN UNPRGM	1826-0102 03406 LM312H	1826-0246 02037 MC7805CK	1826-0405 03406 LH0022CH
1820-5418	02037	MC14538BDW	1826-0103 02037 MC1445G	1826-0247 03780 A-4350	1826-0408 03714 ICL8212CPA
1820-5419	03406	MM74C906M	1826-0104 03406 LM371H	1826-0248 02037 MC1408L-6	1826-0409 02037 MC1723L
1820-5420	01698	TIBPAL16R4-12CN UNPRGM	1826-0105 02883 D6172BK	1826-0249 03285 AD504J	1826-0410 01698 TL084cN
1820-5421	06354	T7C74HC593P	1826-0106 02237 UA7815UC	1826-0251 03285 AD514K	1826-0411 02037 MC1456BCP
1820-5423	74AC00PC	1826-0108 03406 LH0062CH	1826-0252 03285 AD7520JN	1826-0412 03406 LM393N	
1820-5424	02910	7WF47540N	1826-0109 03799 HA2-2625-5 (SELECTED)	1826-0254 02037 MC1741SCP1	1826-0413 03799 HA2-2655-5
1820-5429	01698	TIBPAL20R6-15CN UNPRGM	1826-0110 03406 LM212H	1826-0256 02910 NE522N	1826-0414 02037 MC1458SP1
1820-5432	06347	HD74HCT449P	1826-0111 02037 MC14158G	1826-0258 03793 SG1502N	1826-0415 02910 SD5000B
1820-5436	02910	7WF4395D	1826-0112 03406 LM316AH	1826-0259 02037 MFC6070	1826-0416 03406 LF13331D
1820-5438	03406	DS3487M	1826-0113 03406 LM207H	1826-0261 01921 CA6741T SELECTED	1826-0417 03406 LF1333D
1820-5439	10253	IDT74FTC373P	1826-0114 02237 710HM	1826-0262 02237 UA7824KC	1826-0418 03406 LM320T-12
1820-5440	10253	7WF74CT374P	1826-0115 02910 NE526A	1826-0263 03285 AD5323D	1826-0419 03406 LM3909N
1820-5441	02910	7WF47540N	1826-0116 02180 CMP-01-CJ	1826-0264 03285 AD7520LN	1826-0420 02037 MC1458SP1
1820-5442	01698	TIBPAL20R8-15CN UNPRGM	1826-0117 02237 UA7812KC	1826-0265 02910 LM309H SELECTED	1826-0421 03285 AD536AJD
1820-5443	06347	7WF47540P	1826-0118 02037 MC14158G	1826-0266 02180 OP-05EJ	1826-0422 03406 LF298H
1820-5446	01698	TIBPAL20L8-15CN UNPRGM	1826-0119 02910 NE555T	1826-0267 02037 LM0062CD	1826-0423 03406 LM317K
1820-5449	02910	7WF47540N	1826-0120 03406 LM3900N	1826-0268 03406 LM208D	1826-0424 02037 MC3405P
1820-5450	01698	TIBPAL16R4-12CN UNPRGM	1826-0121 03406 LM3174	1826-0269 02910 NE566N	1826-0425 03799 HA2-2655-5
1820-5451	02910	7WF47540D	1826-0123 03406 LM320K-12	1826-0270 03799 HA-2005A	1826-0426 03406 AM687ADL
1820-5452	01698	TIBPAL16R4-12CN UNPRGM	1826-0124 02910 NE529H	1826-0271 03406 LM741CN	1826-0428 03793 SG3524J
1820-5453	02910	7WF47540D	1826-0125 02037 MC1514L	1826-0272 03406 LM361H	1826-0429 03799 H11-1818A-5
1820-5454	02910	7WF47540D	1826-0126 02237 7818KC	1826-0274 02037 MC78L15ACP	1826-0430 03285 AD559KD
1820-5455	02910	7WF47540D	1826-0127 02180 DAC-100BCQ3	1826-0275 02037 MC78L12ACP	1826-0431 02037 MC1443JL
1820-5456	02910	7WF47540D	1826-0128 02037 MC1468L	1826-0276 02037 MC78L05ACP	1826-0432 03714 ICL 8049 CC PE
1820-5457	02910	7WF47540D	1826-0129 03714 ICL8001CTZ	1826-0277 03406 LM320T-15	1826-0433 03406 LF356BN
1820-5458	10253	7WF47540D	1826-0130 02910 NE550L	1826-0281 02037 MC79L15ACP	1826-0434 03406 LM3909N
1820-5459	03638	L293B	1826-0141 03406 LM319J	1826-0282 02037 MC79L12ACP	1826-0435 03406 LM341P-8.0
1820-5479	11345	PAL22V10L-25PC UNPRGM	1826-0142 02037 MC1458CP1	1826-0283 02037 MC1306P	1826-0436 03406 LM341P-24
1820-5480	03794	AMPAL18P8BPC UNPRGM	1826-0143 02337 UA760DC	1826-0284 02037 MC79L06C	1826-0437 02037 MC1495L
1820-5481	01698	TIBPAL20R4-15CNT UNPRGM	1826-0144 02037 MC7805CT	1826-0285 02037 MC79L05ACP	1826-0438 03406 LM340LAH-12
1820-5482	04092	PAL16R6A-WCN UNPRGM	1826-0145 02037 MC7806CT	1826-0286 02037 CA207E	1826-0439 03406 LH-0053CG
1820-5491	01590	SP8685BDG	1826-0146 02037 MC1458P1	1826-0287 02037 MC3476G	1826-0440 02180 OP-01CJ
1820-5493	03794	AMPAL18P8QPC UNPRGM	1826-0147 02037 MC1468R	1826-0289 03406 LM324F	1826-0441 02237 UA79G11C
1820-5494	03348	L293B	1826-0148 02037 MC1468R	1826-0292 01921 CA3085	1826-0442 03714 IH5027CFPE
1820-5505	11345	PAL22V10L-25PC UNPRGM	1826-0149 02037 MC1458CP1	1826-0293 02037 MC1741SCG	1826-0443 02237 UA79GK
1820-5507	03794	AMPAL18P8LPC UNPRGM	1826-0150 02037 MC7805CT	1826-0294 02037 MC7905CT	1826-0444 02237 UA79GK
1820-5533	01698	PALC16L8L-25PC UNPRGM	1826-0151 02037 MC7806CT	1826-0295 03285 AD533JH	1826-0445 02237 UA7905UC
1820-5534	04092	PAL16R6B-WCNL UNPRGM	1826-0152 02037 MC7808CT	1826-0296 01921 CA207E	1826-0446 03714 ICL8052CPD
1820-5535	10253	IDT74FTC244AP	1826-0153 02037 UA7812UC	1826-0297 03406 LM320T-24	1826-0447 03406 LF257H
1820-5568	01698	SN75477D	1826-0154 02037 MC1409AT	1826-0300 02237 UA79M12AH	1826-0449 03406 LM320T-8.0
1826-0002	02037	MC1510G	1826		

HP P/N	Mfr.	Desc.	1826-0477	01698	TL610CP	1826-0610	02180	MUX-24FQ	1826-0747	03406	LM4250CN	1826-0888	03406	LF353AN
1826-0478	03406	LM7906T	1826-0611	03406	LM2904N	1826-0748	03406	LM2504 STEEL	1826-0748	03406	NE5533AF	1826-0889	02910	NE5533AF
1826-0479	01698	LM293P	1826-0616	02180	OP-11EY	1826-0750	03406	ADC0801LCN	1826-0890	03406	LM358AN	1826-0890	03406	LM358AN
1826-0480	03406	LF13333N	1826-0617	02237	UAT815UC (SELECTED)	1826-0751	03406	DAC1202HCD	1826-0891	03285	AD544JH SELECTED	1826-0891	03285	AD544JH SELECTED
1826-0481	03406	LH0033CG	1826-0619	03406	LF298H SELECTED	1826-0752	03285	AD7542BD	1826-0893	03285	AD536AJH (BURNED-IN)	1826-0893	03285	AD536AJH (BURNED-IN)
1826-0482	03799	HA2-2525-5	1826-0620	01698	UAT924CKC	1826-0753	02037	MC34004BL	1826-0894	03406	ADC0803LCN	1826-0894	03406	ADC0803LCN
1826-0483	02237	UA75MGU1C	1826-0621	02763	8702CN	1826-0754	06545	LAS1915	1826-0895	05338	L292	1826-0895	05338	L292
1826-0484	02237	UA78MGU1C	1826-0622	02180	REF-02HJ	1826-0755	02910	NE527N	1826-0896	03285	AD565JD	1826-0897	03285	AD565JD
1826-0485	03285	AD7530LN	1826-0623	03406	LM334Z	1826-0756	03406	ADC0804LCN	1826-0897	03285	AD517J	1826-0901	01698	TL094CN
1826-0486	02037	MC14052BCP	1826-0624	05436	VFC32KP	1826-0757	01698	TL170CLP	1826-0898	03285	AD7503JD	1826-0902	02290	RC3403ADB
1826-0487	03799	HA2-2625-5 (SELECTED)	1826-0625	02910	NE5553N	1826-0758	03285	AD534JH	1826-0903	02037	MC1372P	1826-0903	02037	MC1372P
1826-0488	03406	LM218H	1826-0626	01921	CA3130AS	1826-0759	03406	LM339J	1826-0904	03406	LM330T-5	1826-0904	03406	LM330T-5
1826-0489	03714	IH5028CPE	1826-0627	03285	AD542L	1826-0760	03406	LN353AZ	1826-0905	03793	SG3525AJ	1826-0906	03793	SG3525AJ
1826-0490	03714	IH5032CPE	1826-0628	02180	OP-11FY	1826-0761	03714	ICL7605CJN	1826-0907	02883	DG17660CPA	1826-0913	03285	DG17660CPA
1826-0491	03406	LP355N	1826-0629	02910	UA79M12CU	1826-0762	03406	LM261H	1826-0908	03714	LG153DCP	1826-0914	02037	MC1406BCP
1826-0492	03406	DS3630N	1826-0631	03406	LM350K	1826-0763	03406	LM137K	1826-0909	02883	DG308ACJ	1826-0915	02037	MC34001BU
1826-0493	03406	LM308AN	1826-0632	03406	LM143D	1826-0764	03285	AD590KF	1826-0909	03406	LM315BH	1826-0909	03406	LM11CH
1826-0495	02037	MC79L12ACG	1826-0633	02910	NE5532AT	1826-0765	03714	ICL7611BMTY	1826-0910	02290	LM336BZ	1826-0910	02290	LM336BZ
1826-0496	02037	MC79L05ACG	1826-0634	03406	LM343H	1826-0766	03406	LM236H	1826-0911	02237	CCD312A-4	1826-0911	02237	CCD312A-4
1826-0497	03406	LF311H	1826-0635	02180	OP-07CP	1826-0767	05436	3528AM	1826-0912	02037	MC1406BCP	1826-0913	02037	MC1406BCP
1826-0498	01698	SN7654N	1826-0636	03285	AD7525KN	1826-0768	03406	LM258AH	1826-0914	02037	AD589L	1826-0914	02037	AD589L
1826-0499	03406	LB0091CD	1826-0637	03793	SG3524 SELECTED	1826-0769	02883	DG303BP	1826-0915	02037	MC1406BCP	1826-0916	02037	MC1406BCP
1826-0500	03285	AD536AKD	1826-0638	03406	LM360N	1826-0770	01698	TL022CP	1826-0917	02237	AD589L	1826-0917	02237	AD589L
1826-0501	02037	MC14053BCP	1826-0639	03285	AD7524JN	1826-0772	02037	LM317L	1826-0918	02883	DG180BP	1826-0919	02037	MC34001BU
1826-0502	02037	MC14066BCP	1826-0640	01698	TL061CP	1826-0773	03406	LM10CH	1826-0919	02037	AD511DIK	1826-0919	02037	AD511DIK
1826-0503	03406	LF398H	1826-0641	02180	OP-07EY	1826-0774	03406	LM385BZ-1.2	1826-0920	03406	AD511DIK	1826-0920	03406	AD511DIK
1826-0504	03285	AD7530LD	1826-0642	02037	MC1405L	1826-0776	02883	DG302ACJ	1826-0921	03406	AH014CD	1826-0921	03406	AH014CD
1826-0505	02037	MC1714NCP1	1826-0643	01698	TL313JCLP	1826-0777	02883	DG303ACJ	1826-0922	03406	AH014CD	1826-0922	03406	AH014CD
1826-0506	01921	CA3140E	1826-0644	03793	SG2515-5	1826-0778	02883	DG300CJ	1826-0923	03406	AD513CD	1826-0923	03406	AD513CD
1826-0507	02037	SZA266	1826-0647	03285	AD7521LN (SEL)	1826-0779	03285	AD7502JN	1826-0924	03714	IH5108CJE	1826-0924	03714	IH5108CJE
1826-0508	03285	AD561JJD	1826-0648	03406	LM342P-12	1826-0780	01921	CA3054	1826-0925	02180	REF-01EJ	1826-0925	02180	REF-01EJ
1826-0509	02037	MC1658P	1826-0649	02237	UA79M12AUC	1826-0781	05047	TDC1014B7C	1826-0926	01921	CA101AE	1826-0926	01921	CA101AE
1826-0510	03406	LF1332N	1826-0650	03285	AD584KH	1826-0782	02910	NE5534AFE	1826-0927	02910	NE5118F	1826-0927	02910	NE5118F
1826-0511	02237	UA79M15AHC	1826-0651	01698	TL500ACN	1826-0784	06545	LAS1912	1826-0928	03406	LM336BZ	1826-0928	03406	LM336BZ
1826-0512	02237	UA78M15HC	1826-0653	01921	CA3240AE	1826-0785	02037	MC34002BU	1826-0929	03799	HAT-2645-5	1826-0929	03799	HAT-2645-5
1826-0513	03406	LM310H SELECTED	1826-0655	03406	LM3914N	1826-0786	01698	LM064CN	1826-0930	01921	CA3140AS	1826-0930	01921	CA3140AS
1826-0514	02180	OP-17FJ	1826-0656	02237	78H05A	1826-0787	02180	CMP-04GP	1826-0931	03793	SG323K SELECTED	1826-0931	03793	SG323K SELECTED
1826-0515	03406	ADC0800PCD	1826-0657	03285	AD584LH	1826-0788	03714	IH5020CPA	1826-0932	02180	OP-27FZ	1826-0932	02180	OP-27FZ
1826-0516	01921	CA3140H	1826-0658	01921	CD22100E	1826-0789	03406	LF398N	1826-0933	03285	AD636JD	1826-0933	03285	AD636JD
1826-0517	03406	TL071CP	1826-0659	01921	CD22100E	1826-0790	03406	LM103H-2.0	1826-0934	02180	OP-15FJ	1826-0934	02180	OP-15FJ
1826-0518	01698	TL072CP	1826-0661	03285	AD590KH	1826-0791	03406	LM129AH	1826-0935	03285	DG1210A-4	1826-0935	03285	DG1210A-4
1826-0519	02180	TL074CN	1826-0662	03799	HA2-2625-5 (SELECTED)	1826-0792	02037	HA2-2605-5 (SELECTED)	1826-0936	03406	AD5120H	1826-0936	03406	AD5120H
1826-0520	03406	LM323K	1826-0663	0285	AD518KH	1826-0793	02037	MC34001BN	1826-0937	03799	HAT-2645-5	1826-0937	03799	HAT-2645-5
1826-0521	01698	TL084BCN	1826-0664	03406	LM338K	1826-0794	02037	AD518KH	1826-0938	03799	SG3524N SELECTED	1826-0938	03799	SG3524N SELECTED
1826-0522	03406	LM317H	1826-0665	03406	LM347B	1826-0795	02180	OP-17FJ	1826-0939	03793	SG3524N SELECTED	1826-0939	03793	SG3524N SELECTED
1826-0523	03406	LM323K	1826-0666	03406	LM339AN	1826-0796	02180	SW-02FQ	1826-0940	03811	D2911A-2	1826-0941	03811	D2911A-2
1826-0524	01921	CA3080E	1826-0667	03406	DA1200HCD	1826-0797	03285	AD7514BD (SEL)	1826-0942	03811	D2910A-4	1826-0942	03811	D2910A-4
1826-0525	03406	LM340AK-5	1826-0668	01698	TL182CN	1826-0798	02910	NE5018F	1826-0943	03811	D2912-3	1826-0943	03811	D2912-3
1826-0526	03406	LM220K-5.2	1826-0669	01590	SL441A	1826-0799	01921	CA258AE	1826-0944	03799	HII-5044-5	1826-0944	03799	HII-5044-5
1826-0527	03406	LM338K	1826-0670	03406	LM338K	1826-0800	01921	CA3140AT	1826-0945	03406	LM109R	1826-0945	03406	LM109R
1826-0528	03406	LM317V	1826-0671	03406	LM570N	1826-0801	02180	SW-01FQ	1826-0946	03406	LM109R	1826-0946	03406	LM109R
1826-0529	01698	TL072ACP	1826-0672	03406	LM1102	1826-0802	02180	SW-01FQ	1826-0947	03406	AD589JH	1826-0947	03406	AD589JH
1826-0530	01698	TL074CN	1826-0673	03406	LM347B	1826-0803	02180	OP-15GJ	1826-0948	03406	AD589JH	1826-0948	03406	AD589JH
1826-0531	03406	LM320H-6	1826-0674	03406	LM347B	1826-0804	02180	OP-17FJ	1826-0949	03406	AD589JH	1826-0949	03406	AD589JH
1826-0532	02037	MLM101A	1826-0675	03406	LF353H	1826-0805	02180	OP-16E	1826-0950	03406	AD589JH	1826-0950	03406	AD589JH
1826-0533	02037	MC1458NG	1826-0676	03406	LF353N	1826-0806	02180	OP-16E	1826-0951	03406	AD589JH	1826-0951	03406	AD589JH
1826-0534	01921	CA3140H	1826-0677	03406	LF353N	1826-0807	02180	OP-16E	1826-0952	03406	AD589JH	1826-0952	03406	AD589JH
1826-0535	03406	LM320H-6	1826-0678	03406	LF353N	1826-0808	02180	OP-16E	1826-0953	03406	AD589JH	1826-0953	03406	AD589JH
1826-0536	02910	NE553JAT	1826-0679	03406	LM348J	1826-0809	02180	OP-16E	1826-0954	03406	AD589JH	1826-0954	03406	AD589JH
1826-0537	01698	TL084CN	1826-0680	02180	OP-01CP	1826-0810	02180	OP-01CP	1826-0955	03406	AD589JH	1826-0955	03406	AD589JH
1826-0538	03406	LM337K	1826-0681	03406	LM348J	1826-0811	02180	OP-01CP	1826-0956	03406	AD589JH	1826-0956	03406	AD589JH
1826-0539	03406	LM340AT-5	1826-0682	02										

HP P/N	Mfr.	Desc.	1826-1136	REF-02CP	1826-1161	02883	DG200AABK	1826-1285	02037	MC1403AU(SEL)	1826-1421	06121	TDA4601D
1826-1035	02180	DAC-08CP	1826-1162	03406	LP311N			1826-1286	01698	TLC272ACP	1826-1422	02037	MC34084P
1826-1036	02180	DAC-312PR	1826-1165	02180	OP-14EZ			1826-1287	03285	AD632AH	1826-1424	03285	AD667JN
1826-1037	02180	REF-02CP	1826-1166	03406	LM350T			1826-1288	03406	LM285H-2.5	1826-1425	03285	AD7224LN
1826-1038	03793	SG3731J	1826-1167	01085	LT01004CZ			1826-1289	03406	LPC339N	1826-1426	02180	OP-21SEZ
1826-1039	00046	UC494AJ	1826-1168	03714	IH-5042CTW			1826-1290	01698	TL074ACJ	1826-1427	10858	LT1031DCN8-5
1826-1040	03793	SG3526J	1826-1169	03285	AD7514ABQ			1826-1291	03799	H13-0201-5	1826-1431	10858	LT1021CCN8-5
1826-1042	01698	TL072BZCP	1826-1170	03285	AD7515BQ			1826-1292	03406	LM311N	1826-1432	03406	LF398AH
1826-1043	03285	AD581KH	1826-1171	02037	MC1436U			1826-1293	02037	MC79103ACP	1826-1433	10858	LT1007CH
1826-1044	03285	AD566AJD	1826-1172	02037	MC3458U			1826-1294	04507	TDC1018DAC	1826-1434	05436	3627AM
1826-1045	03799	HA7-2515-5	1826-1173	02180	MUX-24FP			1826-1295	08507	M0H3326	1826-1435	10858	LT1009CZ
1826-1046	03406	LM334H	1826-1174	02180	DAC-888FX			1826-1296	03285	AD574AJD	1826-1436	10858	LT1013ACJ8
1826-1047	02180	OP-16GZ	1826-1175	02037	MC1733G			1826-1297	03406	LM336BZ-5.0	1826-1437	10858	LT1021CCN8-10
1826-1048	02180	OP-07CZ	1826-1177	02180	MUX-16-FT			1826-1298	02180	OP-14CZ	1826-1438	03799	HII-0518-5
1826-1049	02180	OP-27GZ	1826-1178	03799	HA1-5320-5			1826-1299	03406	LM78M05CP	1826-1439	01698	TLG555CP
1826-1050	00046	UC3524A-N	1826-1179	02037	LM311H			1826-1300	03406	LF44WACN	1826-1440	03406	LF398AN
1826-1051	02910	NE5561N	1826-1180	03406	LF355H			1826-1303	03285	AD7525CD	1826-1441	02180	REF-01HZ
1826-1052	03406	LF156H	1826-1181	03406	MC140AK-15			1826-1304	02180	DAC-20CQ	1826-1442	03285	AD7534AD
1826-1053	03711	ICL7109IDL	1826-1182	03285	ADP0-07CH			1826-1305	03406	ADCO808LCN	1826-1443	03285	AD7549BD
1826-1054	02910	NE564N	1826-1184	03285	AD578KZD			1826-1307	07050	MP7507JN	1826-1445	03794	AM6685HL
1826-1055	02910	NE5018N	1826-1185	02180	OP-15EJ			1826-1308	00046	UC2834J	1826-1446	03793	SG3526N
1826-1056	02180	OP-02CZ	1826-1186	02180	SW-06GQ			1826-1309	03799	HA3-2625-5	1826-1447	03406	LH0041CG
1826-1057	03677	S3522P	1826-1187	03285	AD581JH			1826-1312	03285	AD624BD	1826-1450	05436	DAC800-CBI-I
1826-1061	02180	OP-14CP	1826-1188	03285	AD590IH			1826-1314	03285	AD637J	1826-1451	03285	AD7503KN
1826-1062	01698	TL783CKC	1826-1189	02180	KD2-01EP			1826-1315	03406	LM390N	1826-1453	03285	AD7543JN
1826-1063	03799	HII-0509A-5	1826-1190	03285	AD720BQ			1826-1316	10858	LT1007CN8	1826-1455	11302	ICL7109CPL
1826-1064	03799	HII-0508A-5	1826-1191	03285	AD524HD			1826-1317	10858	LT1037CN8	1826-1456	00575	WD2010A-PL05
1826-1065	03406	LM336Z-5.0	1826-1192	02180	OP-21FZ			1826-1319	02910	NE5533AN	1826-1458	02910	DAC-08ED
1826-1066	06121	TDA4700A	1826-1193	02180	DAC-88EX			1826-1320	02180	REF-02EZ	1826-1459	02180	OP-50FY
1826-1067	03406	LMH002CN	1826-1194	02037	MC14046BAL			1826-1321	03291	MSA-0370-21	1826-1460	10881	LM201ADP
1826-1068	03406	DAC0832LCN	1826-1195	03285	AD524CD			1826-1322	03291	MSA-0420	1826-1461	10881	TL071ACDP
1826-1069	02037	MC1404U6	1826-1196	03285	AD644JH			1826-1323	03291	MSA-0435	1826-1462	10858	LT1012CH
1826-1070	03799	AM6108	1826-1197	02180	OP-15EZ			1826-1324	03291	UTO-2013	1826-1463	03406	LM285BYZ-2.5
1826-1071	03406	LF111CH	1826-1198	03285	AD7581LN			1826-1326	01921	CA3189E	1826-1468	03406	AH5020C
1826-1072	02910	LM324D	1826-1199	06338	L296P			1826-1327	00046	UC3834N	1826-1470	02037	TDA3303
1826-1073	02037	MC3359P	1826-1201	03406	LM2930T-5.0			1826-1328	01698	NE5532P	1826-1471	02037	MC1377P
1826-1074	03406	LF441CN	1826-1202	03285	AD7533(SEL)			1826-1330	01698	TLC27M4CN	1826-1472	04507	TDC1048B6
1826-1075	03406	LF442CN	1826-1203	03406	LM340LAZ-5			1826-1331	03406	ADC0800LCJ	1826-1473	03406	LM35CAH
1826-1076	03406	LF444CN	1826-1204	03285	AD7528JN			1826-1332	03406	ADC0820BCN	1826-1474	01698	TL4311LP
1826-1077	03406	LF112ACH	1826-1205	02883	DG390CJ			1826-1333	02037	NE5929H	1826-1475	10858	LT1011CN8
1826-1078	02910	NE5037	1826-1206	03406	AD1006LCJ			1826-1334	03794	AM6012PC	1826-1476	05436	REF10JM
1826-1079	02598	PIC602	1826-1207	02910	HEF4066BT			1826-1336	08608	SSI117-4 CERPACK	1826-1477	03406	ADC0809CC
1826-1080	02598	PIC647	1826-1208	02037	MC34060P			1826-1337	03714	ICM7207/AIFD	1826-1478	02180	OP-15GZ
1826-1081	03406	LF111ACN	1826-1209	02883	DLG180-BA			1826-1338	01698	TL7705A	1826-1479	10858	LT1001ACH
1826-1082	03793	SG7812AC-K	1826-1210	01698	TL185CN			1826-1340	00046	UC384ON	1826-1480	03799	HII-0509-5
1826-1083	03793	SG7912AC-K	1826-1211	03794	ML1w8DC			1826-1341	03406	DAC1232LCD	1826-1483	03285	AD573KD
1826-1084	02180	OP-37EZ	1826-1212	02037	MC1776CD			1826-1342	03406	DAC1006LCN	1826-1484	02883	DGL133BP
1826-1085	03406	LF357BN	1826-1213	01698	TLC271ACD			1826-1343	01698	TL431CP	1826-1485	02037	MC3425P1
1826-1086	02180	SW-06GP	1826-1214	01698	TL2512ACD			1826-1346	03799	H13-201H5-5	1826-1486	03285	AD7224CQ
1826-1087	04200	ULN-3701ZV	1826-1215	01698	TL2527ACD			1826-1349	02180	OP-02CZ	1826-1487	02883	DG271CJ
1826-1088	03406	MP059H	1826-1216	01698	TLC350AT			1826-1350	03714	ICL7660CBA	1826-1488	03406	DAC1230LCJ (SELECTED)
1826-1089	03755	DAC9331-16-4	1826-1217	02180	KD2-01EZ			1826-1351	06121	DA7A414A	1826-1489	03406	DAC711KN
1826-1090	03406	LM2931CT	1826-1218	02037	MC7824CT			1826-1352	03793	SG524B	1826-1490	04200	UDN-2952W-2
1826-1092	02237	UA7885C (SELECTED)	1826-1219	03285	AD567KD			1826-1353	05436	DAC701KH	1826-1491	03406	LM201AJ
1826-1093	02180	OP-421HY	1826-1220	03799	HA7-2525-5			1826-1354	03406	LUH075CG	1826-1492	02180	OP-16EZ
1826-1094	03285	HDS1015EM	1826-1221	03406	LM311J-8			1826-1355	02290	RC4193NB	1826-1493	02180	REF-01EZ
1826-1095	02910	MC1496N	1826-1222	02037	MC34074AL			1826-1358	00046	UC3906N	1826-1494	11825	250647A
1826-1097	02180	OP-17FZ	1826-1223	03406	LM10BLH			1826-1359	03285	AD573JD	1826-1497	05436	DAC800-CBI-I-7
1826-1098	02180	OP-37GP	1826-1225	03406	LP339M			1826-1360	02883	AD7524C	1826-1498	02037	MC14681ACP
1826-1099	03406	LM337LZ	1826-1226	03794	AM6112DC (SELECTED)			1826-1361	02883	DG212CJ	1826-1499	06545	L-35-0V-5
1826-1100	03406	LT070-15C	1826-1227	01590	SP9670D16			1826-1362	03285	AD5929AN	1826-1499	02037	MC78L24CP
1826-1101	01698	TL780-15C	1826-1228	03285	AD7226BQ			1826-1363	03406	LU0702C	1826-1500	04200	ULN-8126A
1826-1102	03714	ICL8038BCJD (SELECTED)	1826-1229	03406	LM185BZ-2.5			1826-1370	03406	LP365N	1826-1501	01698	TL594IN
1826-1111	05436	DAC702KH	1826-1230	03406	CMX0052A			1826-1371	06394	AM7408C	1826-1502	02910	NE5150-F
1826-1112	04507	TDC1001J	1826-1232	05436	DAC667AD			1826-1373	03714	ICL7650CD	1826-1511	03714	ICL71091PL
1826-1113	03406	LM311H	1826-1233	03406	LM299AH			1826-1374	10858	LT1037CH	1826-1512	10858	OP-27EN8
1826-1114	03755	HS1320-C2	1826-1240	03875	AD567JD			1826-1375	03406	ADCO833BCJ	1826-1512	01698	TCM3105JE
1826-1115	01698	TL3131CP	1826-1241	03714	IH6108CPE			1826-1376	03714	ICL76501JA-1	1826-1513	02037	MC34002BU
1826-1116	02290	RC1456DB	1826-1242	03755	DAC9331-16-5			1826-1377	03780	RGB DAC4TD	1826-1514	10858	LT1021BCN8-10
1826-1118	03285	AD7524LN	1826-1243	03793	SG3527AJ			1826-1378	03794	AM6687DL	1826-1515	02883	SI7135CJ
1826-1119	03406	LM4042ZH	1826-1244	02180	SMP-118Y			1826-1379	03285	AD7226KN	1826-1516	03406	LF13007N
1826-1120	03285	AD624JH	1826-1251	03799	H11-507A-5			1826-1380					

HP P/N	Mfr.	Desc.	HP P/N	Mfr.	Desc.
1826-1568	02180	OP-37EZ	1826-1606	11668	R5311-18
1826-1569	03406	LM3524N	1826-1607	02037	MC14051BCD
1826-1571	01698	TLC27M4ID	1826-1608	10858	L1024ACN
1826-1572	02910	LM393D	1826-1609	02883	DG211DY
1826-1573	03688	MP260	1826-1610	01698	TLC555ID
1826-1574	03285	AD592BN	1826-1611	01698	TLC27L7CP
1826-1575	03406	LM110H	1826-1612	03291	MAS-0385
1826-1576	00046	UC3B46N	1826-1613	03291	MGA-0485
1826-1577	02910	TDA3047	1826-1614	02037	MWA0204
1826-1578	02180	OP-17EZ	1826-1616	02910	LM393AFE
1826-1579	03285	AD595AD	1826-1617	02883	DG509ABK
1826-1580	03406	MF10ACN	1826-1618	08608	SS1510-4-CSE
1826-1581	02037	MC34081AP	1826-1619	03285	AD7528JP
1826-1582	02037	MC34082AP	1826-1620	03285	AD7532KP
1826-1583	02883	SI7661CJ	1826-1621	02037	MC1496D
1826-1584	00046	UC2846N	1826-1622	01698	TLO74CD
1826-1585	10858	LT1033CK	1826-1623	03406	LM19M
1826-1586	03406	LM2935T	1826-1627	01698	TLO82CD
1826-1587	03794	AM6012ADC	1826-1628	03285	A625CD
1826-1588	02686	WJ-A19-1	1826-1631	02180	OP-227EV
1826-1590	10858	LT1014CN	1826-1632	10881	TSG85101P
1826-1591	03285	AD654JN	1826-1634	03799	HA3-2539-5
1826-1592	03285	AD7535AD	1826-1635	10858	OP-07CS8
1826-1593	03799	H1-674AKD-5	1826-1636	01698	TLO81CD
1826-1594	03406	LM311M	1826-1639	01698	TLC271ACP
1826-1595	12147	TM1L84	1826-1640	03406	LM360J
1826-1596	02883	DG15BP	1826-1641	02037	GAP-01FP
1826-1597	03406	LM2949CT-5.0	1826-1643	02037	TIL31ACD
1826-1600	01698	LM324D	1826-1644	02037	TL072BCD
1826-1601	01698	TL431CD	1826-1645	03285	AD7828KP
1826-1602	01698	TLCS55CD	1826-1646	03406	LP2950ACZ
1826-1603	11561	2VP509	1826-1649	05436	DA700KH
1826-1604	03285	AD585AQ	1826-1650	05436	OFA11AM
1826-1605	11668	R5310-25	1826-1651	01698	NE592D
			1826-1606	11668	R5311-18
			1826-1607	02037	MC14051BCD
			1826-1608	10858	L1024ACN
			1826-1609	02883	DG211DY
			1826-1610	01698	TLC555ID
			1826-1611	01698	TLC27L7CP
			1826-1612	03291	MAS-0385
			1826-1613	03291	MGA-0485
			1826-1614	02037	MWA0204
			1826-1616	02910	LM393AFE
			1826-1617	02883	DG509ABK
			1826-1618	08608	SS1510-4-CSE
			1826-1619	03285	AD7528JP
			1826-1620	03285	AD7532KP
			1826-1621	02037	MC1496D
			1826-1622	01698	TLO74CD
			1826-1623	03406	LM19M
			1826-1627	01698	TLO82CD
			1826-1628	03285	A625CD
			1826-1629	01698	TLC27EV
			1826-1630	10881	TSG85101P
			1826-1632	10881	TSG85101P
			1826-1634	03799	HA3-2539-5
			1826-1635	10858	OP-07CS8
			1826-1636	01698	TLO81CD
			1826-1639	01698	TLC271ACP
			1826-1640	03406	LM360J
			1826-1641	02037	GAP-01FP
			1826-1643	02037	TIL31ACD
			1826-1644	02037	TL072BCD
			1826-1645	03285	AD7828KP
			1826-1646	03406	LP2950ACZ
			1826-1649	05436	DA700KH
			1826-1650	05436	OFA11AM
			1826-1651	01698	NE592D
			1826-1652	02037	MC34084AP
			1826-1653	06338	MC14051BCD
			1826-1654	05436	OFA606KP
			1826-1655	02883	DG301ACJ
			1826-1656	03285	AD75478Q
			1826-1657	11604	CLC221AI
			1826-1666	03406	MF10CCM
			1826-1670	10858	L1T33AT
			1826-1672	07050	MFT684KD
			1826-1675	05436	DAC703CH
			1826-1676	02910	NE5568N
			1826-1677	06338	TDA8173
			1826-1678	03714	IHF149CPE
			1826-1679	03714	IHF151CPE
			1826-1683	03714	ICL7673CBA
			1826-1684	02910	RC4200ADE
			1826-1685	01698	TL7702ACD
			1826-1687	10858	LT1021DCS8-10
			1826-1688	03799	HA1-5190-2
			1826-1689	11604	CLC104AI
			1826-1690	10858	L1T022ACH
			1826-1691	03799	HA1-2539-5
			1826-1692	10858	LT1056CN8
			1826-1693	03406	ADC1205BCJ-1
			1826-1694	03799	HA3-5033-5
			1826-1695	05436	AD7225LP
			1826-1696	03406	DM3695TN
			1826-1701	03406	TL1056CN8
			1826-1702	10858	LT1055CN8
			1826-1703	11604	CLC203AI
			1826-1705	04507	TDC1016B7C8
			1826-1706	10858	LT1021BCN8-5
			1826-1708	02180	CMP-05FZ
			1826-1710	01698	SN75068P
			1826-1711	10858	LT1019ACH-5
			1826-1713	02037	MPC2014
			1826-1715	01921	CA3306E
			1826-1716	06338	L4922
			1826-1717	11302	MAX634CPA
			1826-1720	03406	LM675T
			1826-1722	03291	MSA-0185
			1826-1723	03291	MSA-0885
			1826-1725	03406	LM833N
			1826-1729	03406	LM386N-4
			1826-1730	03285	AD7578BD
			1826-1733	02883	DG221JC
			1826-1734	02037	MCT8M05CDT
			1826-1735	01085	LT1007CS
			1826-1736	02037	MCT7M12CDT
			1826-1737	02037	MCT9M05CDT
			1826-1738	02037	MCT9M12CDT
			1826-1739	03406	LM318M
			1826-1740	05436	OPA606LM
			1826-1741	03406	LM2935T0B
			1826-1742	05436	AD6673P
			1826-1743	03406	DAC2128LCD
			1826-1744	05436	OPA606LM
			1826-1745	01590	SL952
			1826-4236	11668	R5312
			1826-4237	11668	R5313
			1826-4238	11668	10464
			1902-0908	03406	LM399H
			1902-0928	03406	LM329
			1902-1331	03406	LM329D (SEL)

JDEC	Mfr.	HP P/N	JDEC	Mfr.	HP P/N		
10000DC	02237	1820-2398	02237	1818-0093	74F112PC	02237	1820-2694
100101DC	02237	1820-2611	02763	1820-1129	74F114PC	02237	1820-4343
100101FC	02237	1820-2390	02237	1818-0422	74F115PC	02237	1820-2688
100102DC	02237	1820-2614	05436	1813-0151	74F1240D	02910	1820-5333
100102FC	02237	1820-2391	0528AM	1813-0151	74F125D	02910	1820-5053
100107DC	02237	1820-2898	05436	1826-0767	74F125N	02910	1820-4777
100107FC	02237	1820-2392	0528BM	1826-0767	74F126N	02910	1820-4779
100112DC	02237	1820-2878	05436	1826-1134	74F132N SELECTED	02910	1820-4164
100112FC	02237	1820-2393	0516PC	1826-2154	74F132N	02910	1820-5130
100114DC	02237	1820-2515	04098PC	1826-2265	74F138D	02910	1820-2861
100117DC	02237	1820-3062	04104PC	1826-1844	74F138PC	02237	1820-3220
100118DC	02237	1820-3063	04111DC	1826-1336	74F139PC	02237	1820-3963
100122DC	02237	1820-2509	04112DC	1826-2125	74F148PC	02237	1820-3645
100124DC	02237	1820-3064	0427BDC	1826-1813	74F148PC	02237	1820-3645
100125DC	02237	1820-3065	0440BPC	1826-2009	74F151PC	02237	1820-2936
100131DC	02237	1820-2397	05084-0128	1826-0013	74F153PC	02237	1820-2769
100155DC	02237	1820-3067	0516DM	1826-0232	74F157AD	02910	1820-5375
100158DC	02237	1820-3068	5D12 .075	1826-1586	74F157PC	02237	1820-2654
100160DC	02237	1820-3069	5D15 .060	1826-1854	74F158PC	02237	1820-2695
100163DC	02237	1820-2511	5S5 .600	1826-0490	74F175D	02910	1820-5043
100164DC	02237	1820-2512	606HM	1826-0496	74F175PC	02237	1820-2696
100166DC	02237	1820-2408	613SS2	1826-1270	74F181PC	02237	1820-3221
100167DC	02237	1820-2768	67401N	1826-0495	74F182PC	02237	1820-2955
100170DC	02237	1820-3070	675376J	1826-0500	74F190PC	02237	1820-3222
100171DC	02237	1820-3073	702HC	1826-0511	74F191PC	02237	1820-2760
100179DC	02237	1820-2513	709HC	1826-0058	74F193PC	02237	1820-2697
100180DC	02237	1820-3072	710HC	1826-0321	74F194PC	02237	1820-3983
100181DC	02237	1820-2514	710HM	1826-0114	74F195N	02910	1820-4860
100182DC	02237	1820-3073	7162	1826-0864	74F20PC	02237	1820-2698
100183DC	02237	1820-3074	723BE	1826-0177	74F240PC	02237	1820-3226
10188N	02910	1820-2522	723HC	1826-0196	74F241PC	02237	1820-2699
1064	11668	1820-2540	725HC</td				

JDEC	Mfr.	HP P/N	AD624BD	03285 1826-1312	ADOP07CH	03285 1826-0844	AM74LS148N	03794 1820-1851
AD625CD			AD625JN	03285 1826-1628	ADOP07EH	03285 1826-0957	AM74LS175N	03794 1820-1733
AD625JN			AD632AH	03285 1826-1559	ADSP-1012AJD	03285 1820-3499	AM74LS24UN	03794 1820-2160
AD632AH			AD636JD	03285 1826-1287	ADSP1401KN	03285 1820-5155	AM74LS299N	03794 1820-1987
AD636JD			AD637J	03285 1826-0935	ADSP3210KG	03285 1820-5157	AM74LS374AP	03794 1820-1997
AD642JH			AD642JH	03285 1826-1314	ADSP3221KG	03285 1820-5156	AM74LS533PC	03794 1820-2883
AD642JH			AD642JH	03285 1826-0949	AF120CH	03406 1826-0469	AM74S160N	03794 1820-1877
AD644JH			AD644JH	03285 1826-1129	AF134-1CJ	03406 1826-0580	AM74S161N	03794 1820-1876
AD654JN			AD654JN	03285 1826-1196	AH0019CD	03406 1820-1988	AM74S24UN	03794 1820-2565
AD667AD			AD667AD	03285 1826-1591	AH0134CD	03406 1820-1370	AM7910DC	03794 1826-1363
AD667JN			AD667JN	03285 1826-1246	AH0140CD	03406 1826-0919	AM7911PC	03794 1820-5161
AD667JP			AD667JP	03285 1826-1424	AH0145CD	03406 1826-0920	AM7960	03794 1826-1388
AD7111KN			AD7111KN	03285 1826-1752	AH0152CD	03406 1820-1371	AM7990DC/70	03794 1820-3828
AD7118BD			AD7118BD	03285 1826-1489	AH0154D	03406 1813-0054	AM7991ADC	03794 1820-3829
AD7224CQ			AD7224CQ	03285 1826-1111	AH5010CN	03406 1826-1017	AM7992BCD	03794 1820-4401
AD7224LN			AD7224LN	03285 1826-1486	AH5020C	03406 1826-1468	AM8151DC	03794 1826-1547
AD7225LP			AD7225LP	03285 1826-1700	AM2502PC	03794 1820-2168	AM9354BPC	03794 1820-1968
AD7226BQ			AD7226BQ	03285 1826-1234	AM2505PC	03794 1820-2738	AMPAL16H8APC	03794 1820-3610
AD7226KN			AD7226KN	03285 1826-1379	AM25102DC	03794 1820-2990	AMPAL16H80APC	03794 1820-3611
AD7240BQ			AD7240BQ	03285 1826-1190	AM25104PC	03794 1820-1978	AMPAL16H8AADC	03794 1820-3556
AD741KH (SEL)			AD741KH (SEL)	03285 1826-0090	AM251S07PC	03794 1820-1866	AMPAL16L8APC	03794 1820-3355
AD7502JN			AD7502JN	03285 1826-0082	AM251S08PC	03794 1820-1865	AMPAL16L8AADC	03794 1820-3852
AD7503JD			AD7503JD	03285 1826-0779	AM251S09PC	03794 1820-1867	AMPAL16L8L8PC	03794 1820-3356
AD7503JN			AD7503JN	03285 1826-0898	AM251S14ADC	03794 1820-2120	AMPAL16L8L8APC	03794 1820-3612
AD7503KN			AD7503KN	03285 1826-0878	AM251S14APC	03794 1820-1609	AMPAL16R44ADC	03794 1820-3557
AD7506KD			AD7506KD	03285 1826-0602	AM251S160APC	03794 1820-1992	AMPAL16R44APC	03794 1820-3986
AD7506KN			AD7506KN	03285 1826-1401	AM251S161APC	03794 1820-2445	AMPAL16R44LDC	03794 1820-3359
AD7510DIJN			AD7510DIJN	03285 1820-1374	AM251S174PC	03794 1820-1700	AMPAL16R44LPC	03794 1820-4435
AD7511DIKN			AD7511DIKN	03285 1826-0916	AM251S175PC	03794 1820-1699	AMPAL16R6AADC	03794 1820-3554
AD7512DIJN			AD7512DIJN	03285 1826-0821	AM251S191PC	03794 1820-2863	AMPAL16R6APC	03794 1820-4082
AD7516KN (SEL)			AD7516KN (SEL)	03285 1826-0671	AM251S218PC	03794 1820-2190	AMPAL16R6L6DC	03794 1820-3358
AD7520JN			AD7520JN	03285 1826-0522	AM251S2520DC	03794 1820-2405	AMPAL16R6L6PC	03794 1820-4939
AD7520JN (SEL)			AD7520JN (SEL)	03285 1826-0541	AM251S2520PC	03794 1820-1610	AMPAL16R6ADC	03794 1820-3555
AD7520LN			AD7520LN	03285 1826-0264	AM251S2521PC	03794 1820-2311	AMPAL16R6APC	03794 1820-3783
AD7521LN (SEL)			AD7521LN (SEL)	03285 1826-0647	AM251S2538PC	03794 1820-2740	AMPAL16R6L8DC	03794 1820-3617
AD7522JN			AD7522JN	03285 1826-0729	AM251S2539PC	03794 1820-2262	AMPAL16R8LDM	03794 1820-3865
AD7522LN			AD7522LN	03285 1826-0857	AM251S2548PC	03794 1820-3588	AMPAL16R8LPC	03794 1820-4436
AD7523AD			AD7523AD	03714 1826-0944	AM251S2568DC	03794 1820-3013	AMPAL18B8PC	03794 1820-5480
AD7523JN			AD7523JN	03285 1826-0707	AM251S2568PC	03794 1820-2926	AMPAL18B8LPC	03794 1820-5507
AD7524AD			AD7524AD	03285 1826-0699	AM251S2569DC	03794 1820-2270	AMPAL22V10A0DC	03794 1820-4975
AD7524JN			AD7524JN	03285 1826-0639	AM251S2569PC	03794 1820-2653	AMPAL22V10A0PC	03794 1820-3616
AD7524LN			AD7524LN	03285 1826-1118	AM251S299PC	03794 1820-2906	AMPAL22V10L0DC	03794 1820-4974
AD7525CD			AD7525CD	03285 1826-1303	AM251S381PC	03794 1820-2999	AMPAL22V10L0PC	03794 1820-4034
AD7525KN			AD7525KN	03285 1826-0636	AM251S533PC	03794 1820-2784	AY-5-2376-006	02713 1820-2625
AD7528BQ			AD7528BQ	03285 1826-1107	AM25507DC	03794 1820-2454	B091-0100	01876 1820-0634
AD7528JN			AD7528JN	03285 1826-1204	AM25508PC	03794 1820-2375	B149A-0150	01876 1820-0736
AD7528JN			AD7528JN	03285 1826-1232	AM25509PC	03794 1820-1981	B149A-0150	01876 1820-1354
AD7528JP			AD7528JP	03285 1826-1619	AM25510PC	03794 1820-2458	B149A-0200	01876 1820-0557
AD7528KN			AD7528KN	03285 1826-1231	AM25518PC	03794 1820-2459	BR1941M-06	00575 1820-2876
AD7530JD			AD7530JD	03285 1826-0356	AM26L6S29PC	03794 1820-3878	C1402A	03811 1820-0733
AD7530JN			AD7530JN	03285 1820-1789	AM26L6S30DC	03794 1820-3755	C164A-0150	01876 1820-0753
AD7530LD			AD7530LD	03285 1826-0504	AM26L6S313D	03794 1820-3756	C164B-0150	01876 1820-0982
AD7530LN			AD7530LN	03285 1826-0485	AM26L6S31PC	03794 1820-2749	C3207	03811 1820-1008
AD7531JN			AD7531JN	03285 1826-0874	AM26L6S32ACD	03794 1820-5327	C67401J RELAXED	04092 1816-1536
AD7533 (SEL)			AD7533 (SEL)	03285 1826-1202	AM26L6S32ACN (SELECTED)	03794 1820-2594	C67LW01N	04092 1820-3458
AD7533AD			AD7533AD	03285 1826-1031	AM26L6S32BCP	03794 1820-2830	CA 3001	01921 1820-0192
AD7533CD			AD7533CD	03285 1826-0921	AM26L6S32PC	03794 1820-2203	CA101AE	01921 1826-0927
AD7533JN			AD7533JN	03285 1826-0838	AM26L6S34PC	03794 1820-3283	CA207E	01921 1826-0296
AD7533KP			AD7533KP	03285 1826-1620	AM26L6S38DC	03794 1820-4133	CA239AE	01921 1826-0814
AD7533LN			AD7533LN	03285 1826-0861	AM26S02PC	03794 1820-1782	CA258AE	01921 1826-0813
AD7534AD			AD7534AD	03285 1826-1442	AM26S10PC	03794 1820-3281	CA3000	01921 1820-0297
AD7534JN			AD7534JN	03285 1826-1399	AM26S11PC	03794 1820-4128	CA3002	01921 1820-0417
AD7535AD			AD7535AD	03285 1826-1592	AM26S12PC SELECTED	03794 1820-3077	CA3004	01921 1826-0087
AD7541A4			AD7541A4	03285 1826-1158	AM2813ADC	03794 1818-0277	CA3005	01921 1820-0046
AD7541ABQ			AD7541ABQ	03285 1826-1169	AM2960DC	03794 1820-2954	CA3010	01921 1820-0047
AD7541AKN			AD7541AKN	03285 1826-1386	AM2964BDC	03794 1820-2903	CA3012	01921 1820-0474
AD7541BD (SEL)			AD7541BD (SEL)	03285 1826-0684	AM2965PC	03794 1820-3528	CA3020	01921 1820-0298
AD7541BD (SEL)			AD7541BD (SEL)	03285 1826-0797	AM2966PC	03794 1820-2981	CA3023	01921 1820-0433
AD7541JN			AD7541JN	03285 1826-0697	AM2966FC (SELECTED)	03794 1820-2826	CA3028A	01921 1820-0306
AD7541KN			AD7541KN	03285 1826-0865	AM29821DC	03794 1820-4060	CA3028B	01921 1820-0137
AD7542BD			AD7542BD	03285 1826-0752	AM29822DC	03794 1820-4061	CA3029	01921 1820-0326
AD7543JN			AD7543JN	03285 1826-1453	AM29823DC	03794 1820-3307	CA3030	01921 1826-0078
AD7545BQ			AD7545BQ	03285 1826-1170	AM29824DC	03794 1820-3306	CA3051	01921 1820-0249
AD7545GLN			AD7545GLN	03285 1826-1407	AM29825DC	03794 1820-3019	CA3053	01921 1826-0230
AD7545JN (SEL)			AD7545JN (SEL)	03285 1826-1393	AM29826DC	03794 1820-3977	CA3054	01921 1826-0780
AD7546BD			AD7546BD	03285 1826-1400	AM29827DC	03794 1820-3440	CA3059	01921 1826-0041
AD7547TBQ			AD7547TBQ	03285 1826-1656	AM29831DC	03794 1820-4063	CA3075	01921 1826-0153
AD7548JN			AD7548JN	03285 1826-1284	AM29841DC	03794 1820-3961	CA3079	01921 1826-0075
AD7549BD			AD7549BD	03285 1826-1443	AM29842DC	03794 1820-4064	CA307T	01921 1826-1254
AD7550BD			AD7550BD	03285 1820-1995	AM29843DC	03794 1820-3962	CA3080	01921 1826-0185
AD7574JN			AD7574JN	03285 1826-0713	AM29843PC	03794 1820-4770	CA3080E	01921 1826-0534
AD7574KN			AD7574KN	03285 1826-0877	AM29844DC	03794 1820-4065	CA3085	01921 1826-0292
AD7578BD			AD7578BD	03285 1826-1730	AM29845DC	03794 1820-3020	CA3094AE	01921 1826-0946
AD7581LN			AD7581LN	03285 1826-1198	AM29846DC	03794 1820-4066	CA3094AT	01921 1826-0167
AD7828KP			AD7828KP	03285 1826-1645	AM29853DC	03794 1820-4067	CA3099E	01921 1826-0321
ADC-856C			ADC-856C	10321 1826-0881	AM29854DC	03794 1820-3888	CA3100T	01921 1826-0218
ADC-H212BGC (SELECTED)			ADC-H212BGC (SELECTED)	10321 1813-0155	AM29861DC	03794 1820-4068	CA3130AS	01921 1826-0626
ADC0800PCD			ADC0800PCD	03406 1826-0517	AM29862DC	03794 1820-4069	CA3130T	01921 1826-0307
ADC0801LC1			ADC0801LC1	03406 1826-0750	AM29863DC	03794 1820-3426	CA3140AE	01921 1826-1535
ADC0802LCN			ADC0802LCN	03406 1826-1552	AM29864DC	03794 1820-4070	CA3140AS	01921 1826-0930
ADC0803LCJ			ADC0803LCJ	03406 1826-0733	AM301AH	03794 1826-0392	CA3140AT	01921 1826-0679
ADC0803LCN			ADC0803LCN	03406 1826-0894	AM6012ADC	03794 1826-1587	CA3140E	01921 1826-0506
ADC0804LCN			ADC0804LCN	03406 1826-0756	AM6012APC	03794 1826-1236	CA3140T	01921 1826-0549
ADC0808CCN			ADC0808CCN	03406 1826-1248	AM6112DC (SELECTED)	03794 1826-0705	CA3141T	01921 1826-0465
ADC0809CCN			ADC0809CCN	03406 1826-1139	AM61012PC	03794 1826-1334	CA3161E	01921 1820-2658
ADC0816CCN			ADC0816CCN	03406 1826-1477	AM6070ADDC	03794 1826-1253	CA3162E	01921 1826-0854
ADC0820BCN			ADC0820BCN	03406 1826-0710	AM6080APC	03794 1826-0856	CA3189E	01921 1826-1326
ADC0833BCJ			ADC0833BCJ	03406 1826-1332	AM6080DC	03794 1826-1015	CA3199E	01921 1820-3704
ADC0833BCJ			ADC0833BCJ	03406 1826-1375	AM6080FPC	03794 1826-0832	CA3240AE	01921 1826-0653
ADC0844CCN			ADC0844CCN	03406 1826-1390	AM60801PC SELECTED	03794 1826-0659	CA3240E	01921 1826-0794
ADC1205BCJ-1			ADC1205BCJ-1	03406 1826-1693	AM6108			

CD4002AF	01921	1820-1537	CD4081BF	01921	1820-1551	DAC71-CSB-I	05436	1813-0251
CD4002UBE	01921	1820-0948	CD4082BF	01921	1820-1409	DAC71-CSB-V	05436	1813-0283
CD4006AF	01921	1820-0962	CD4085BF	01921	1820-2017	DAC80-CBI-I (SEL'D)	05436	1813-0094
CD4007AE	01921	1820-0978	CD4086BF	01921	1820-2018	DAC80-CBI-I (SEL'D)	05436	1813-0118
CD4008AF	01921	1820-0926	CD4089BE	01921	1820-1661	DAC80-CBI-V	06861	1813-0105
CD4009AF	01921	1820-0979	CD4093BE	01921	1820-1600	DAC80-CBI-V (SEL'D)	05436	1813-0125
CD40103BF	01921	1820-2241	CD4093BF	01921	1820-1577	DAC80-CD-V	05436	1813-0092
CD40106BE	01921	1820-2950	CD4094BE	01921	1820-1662	DAC800-CBI-I	05436	1826-1450
CD40109BE	01921	1820-3907	CD4094BF	01921	1820-2222	DAC800-CBI-I-7	05436	1826-1497
CD4010AF	01921	1820-0980	CD4095BE	01921	1820-1663	DAC800-CBI-V	05436	1826-1008
CD40115D	01921	1820-2048	CD4096BE	01921	1820-1664	DAC811AH	05436	1826-1406
CD40116E	01921	1820-2662	CD4097BE	01921	1820-2209	DAC9331-16-4	03755	1826-1089
CD4011AF	01921	1820-1538	CD4097BF	01921	1820-1881	DAC9331-16-5	03755	1826-1242
CD4011UBE	01921	1820-0949	CD4098BE	01921	1820-1650	DAC9377-16-6	03755	1813-0410
CD4012AF	01921	1820-1539	CD4099BE	01921	1820-1665	DG133BP	02883	1826-1484
CD4012UBE	01921	1820-0950	CD4099BF	01921	1820-2233	DG145BP	02883	1826-1596
CD4013AF	01921	1820-1531	CD4502BE	01921	1820-2945	DG172BK	02883	1826-0105
CD4013BE	01921	1820-0939	CD4512BF	01921	1820-2229	DG180-BA	02883	1826-1209
CD4014AE	01921	1820-0970	CD4551BCN	03406	1820-3516	DG180BP	02883	1826-0914
CD4015AF	01921	1820-1541	CD4555BE	01921	1820-1516	DG182BP	02883	1826-0669
CD4015BE	01921	1820-0976	CD4555BF	01921	1820-1556	DG184BP	02883	1820-1724
CD40163BCN	03406	1820-4166	CD4556BE	01921	1820-1515	DG200ABA	02883	1826-1020
CD4016AE	01921	1820-0981	CD4556BF	01921	1820-1555	DG200ABA	02883	1826-1161
CD4016AF	01921	1820-1675	CD74HCT170E	01921	1820-3786	DG200ACJ (SELECTED)	02883	1826-1518
CD4017AB	01921	1820-0933	CD74HCT154E	01921	1820-4862	DG200BA	02883	1820-1807
CD4018AF	01921	1820-0934	CD74HCT164E	01921	1820-4865	DG200BA	02883	1826-0154
CD4018AF	01921	1820-1529	CD74HCT173E	01921	1820-3844	DG201ABK	02883	1826-0606
CD4019AF	01921	1820-1553	CD74HCT174E	01921	1820-3940	DG201ABK	02883	1826-1019
CD4019BCN	03406	1820-2085	CD74HCT193E	01921	1820-4151	DG201ACJ	02883	1826-1018
CD4019BE	01921	1820-0951	CD74HCT174E	01921	1820-3537	DG201ACJ (SEL)	02883	1826-1123
CD4020BE	01921	1820-0935	CDR125BK	02883	1826-0152	DG201CJ	02883	1820-1840
CD4021AF	01921	1820-0961	CH1710-01	04077	1813-0310	DG201CJ	02883	1820-1971
CD4021BF	01921	1820-1898	CH1720-01	04077	1813-0311	DG211CJ	02883	1826-0850
CD4022BE	01921	1820-0929	CH1730-01	04077	1813-0312	DG211DY	02883	1826-1609
CD4023BF	01921	1820-1552	CH1740-01	04077	1813-0313	DG212CJ	02883	1826-1361
CD4023UBE	01921	1820-0943	CLC103AI	11604	1813-0508	DG221CJ	02883	1826-1733
CD4024BE	01921	1820-0936	CLC104AI	11604	1826-1689	DG243CK	02883	1826-1247
CD4024BF	01921	1820-1897	CLC203AI	11604	1826-1703	DG271CJ	02883	1826-1487
CD4025AF	01921	1820-1535	CLC220AI-SCD	11604	1813-0476	DG300CJ	02883	1826-0778
CD4025UBE	01921	1820-0944	CLC221AI	11604	1826-1664	DG301ACJ	02883	1826-1655
CD4026AE	01921	1820-0930	CMP-01-CJ	02180	1826-0116	DG301BA	02883	1826-0879
CD4027AF	01921	1820-1530	CMP-01CP	02180	1826-1122	DG302ACJ	02883	1826-0776
CD4027BE	01921	1820-0938	CMP-01CZ	02180	1826-1384	DG303ACJ	02883	1826-0777
CD4028AF	01921	1820-0927	CMP-02CJ	02180	1826-1272	DG303BP	02883	1826-0769
CD4029AE	01921	1820-1598	CMP-04GP	02180	1826-0787	DG308ACJ	02883	1826-0907
CD4029AE	01921	1820-3018	CMP-05FZ	02180	1826-1708	DG381CK	02883	1826-0951
CD4029BCN	03406	1820-2083	COM8116T	01425	1820-2960	DG390ACK	02883	1826-0950
CD4029BE	01921	1820-0931	CP82C82	03799	1820-3486	DG390CJ	02883	1826-1205
CD4029BF	01921	1820-1528	CT1602	11596	1813-0468	DG506BR	02883	1820-1841
CD4030AE	01921	1820-0947	CT3231	11596	1813-0469	DG508ABK	02883	1826-0605
CD4030AF	01921	1820-1536	CX20052A	06916	1826-1237	DG508ACJ	02883	1820-1725
CD4031AE	01921	1820-0963	CX20220A-1	06916	1826-1556	DG508ACJ	02883	1826-1021
CD4031BF	01921	1820-2231	CYTCW04-15PC	11345	1820-4160	DG509ABK	02883	1826-1617
CD4032AE	01921	1820-0925	D139BP	02883	1820-2345	DH0034CD	03406	1813-0160
CD4033AE	01921	1820-0932	D169CJ	02883	1820-3691	DH0035CG	03406	1820-1797
CD4034AE	01921	1820-0977	D169CK	02883	1820-3685	DH2504CN	03406	1820-1720
CD4035AE	01921	1820-0969	D2910A-4	03811	1826-0941	DH5406N	03406	1820-1043
CD4035AF	01921	1820-1554	D2911A-2	03811	1826-0940	DH541S123J	03406	1820-1750
CD4037AE	01921	1820-0945	D2912	03811	1826-0943	DH74193N	03406	1820-0233
CD4038AE	01921	1820-0924	D2912-3	03811	1826-0942	DH7441AN	03406	1820-0100
CD4040AF	01921	1820-1925	D2913	03811	1826-1030	DH744ALS373N	03406	1820-3378
CD4040BE	01921	1820-0937	D3242	03811	1820-2076	DH74L00N	03406	1820-0583
CD4041AE	01921	1820-0928	D3245	03811	1820-1758	DH74L30N	03406	1820-1518
CD4041UBF	01921	1820-2225	D4201	03811	1820-2071	DH74L402N	03406	1820-0584
CD4042AF	01921	1820-0958	D469CJ	02883	1820-3377	DH74L403N	03406	1820-0585
CD4042AF	01921	1820-1540	D58859N	03406	1820-2971	DH74L404N	03406	1820-0586
CD4043AE	01921	1820-0941	D5C060-35	03811	1820-5346	DH74L416AN	03406	1820-0587
CD4043AF	01921	1820-1533	D7230	03811	1820-2818	DH74L416UN	03406	1820-0602
CD4044AE	01921	1820-0940	D7234	03811	1820-4971	DH74L420N	03406	1820-0588
CD4044AF	01921	1820-1532	D7242	03811	1820-2817	DH74L430N	03406	1820-0589
CD4044BF	01921	1820-1876	D7245	03811	1820-4968	DH74L442AN	03406	1820-1047
CD4045AE	01921	1820-1318	D7250	03811	1820-2816	DH74L51N	03406	1820-0590
CD4045BF	01921	1820-2226	DAC-01CY	02180	1826-0020	DH74L54N	03406	1820-0591
CD4046AF	01921	1820-1188	DAC-08CP	02180	1826-1035	DH74L55N	03406	1820-0592
CD4047AE	01921	1820-1317	DAC-08ED	02910	1826-1458	DH74L71N	03406	1820-0593
CD4047BF	01921	1820-2230	DAC-08EN	03794	1826-0550	DH74L72N	03406	1820-0594
CD4048AE	01921	1820-1316	DAC-08EQ	02180	1820-1934	DH74L73N	03406	1820-0595
CD4048BCJ	03406	1820-3609	DAC-100ACQ3	02180	1826-0453	DH74L74N	03406	1820-0596
CD4049AF	01921	1820-1542	DAC-100BCQ3	02180	1826-0127	DH74L78N	03406	1820-0597
CD4049UBE	01921	1820-1145	DAC-100CCQ3	02180	1826-0197	DH74L85N	03406	1820-0603
CD4050AF	01921	1820-1543	DAC-100CCQ4	02180	1826-0577	DH74L86N	03406	1820-0598
CD4050BCN	03406	1820-2644	DAC-10FX	02180	1826-0938	DH74L90N	03406	1820-0600
CD4050BE	01921	1820-1146	DAC-20CQ	02180	1826-1304	DH74L93N	03406	1820-0601
CD4051BE	01921	1820-1315	DAC-210FX	02180	1826-1155	DH74L95N	03406	1820-0599
CD4051BF	01921	1820-1513	DAC-312R	02180	1826-1036	DH74LS154N	03406	1820-2053
CD4052BE	01921	1820-1314	DAC-888	02180	1826-1143	DH74LS168AN	03406	1820-3078
CD4053BE	01921	1820-1313	DAC-888FX	02180	1826-1174	DH74LS173N	03406	1820-1885
CD4053BF	01921	1820-1510	DAC-88EX	02180	1826-1193	DH74LS74N	03406	1820-3459
CD4053BY	01921	1820-1545	DAC-B9 (SEL)	02180	1826-0864	DH74S253N	03406	1820-2287
CD4054BE	01921	1820-1331	DAC-HA12DC	10321	1813-0147	DH76L75N	03406	1820-1376
CD4055BE	01921	1820-1646	DAC0800LCJ	03406	1826-1331	DH8090N	03406	1820-1148
CD4056BE	01921	1820-2487	DAC0802LCN	03406	1826-1385	DH8093N	03406	1820-1121
CD4059AD	01921	1820-1649	DAC0808LCN	03406	1826-1305	DH8094N	03406	1820-0846
CD4060AE	01921	1820-1667	DAC0832LCN	03406	1826-1068	DH8095N	03406	1820-1254
CD4060BE	01921	1820-2588	DAC1006LCJ	03406	1826-1206	DH8096N	03406	1820-1368
CD4066AE	01921	1820-1325	DAC1006LCN	03406	1826-1342	DH8097N	03406	1820-1049
CD4066AY	01921	1820-1548	DAC1136K	03285	1826-1032	DH8098N	03406	1820-1255
CD4067BE	01921	1820-1660	DAC1200HCD	03406	1826-0674	DH8099N	03406	1820-2098
CD4067BF	01921	1820-2221	DAC1202HCD	03406	1826-0751	DH8121N	03406	1820-1295
CD4068BE	01921	1820-1410	DAC1208LCD	03406	1826-1548	DH8123N	03406	1820-1294
CD4068BF								

DM8553N	03406	1820-1113	HA2-2625-5 (SELECTED)	03799	1826-0487	IH5020CPA	03714	1826-0790
DM8554N	03406	1820-1291	HA2-2625-5 (SELECTED)	03799	1826-0670	IH5024PA	03714	1820-1353
DM8555N	03406	1820-1857	HA2-2655-5	03799	1826-0425	IH5027CPF	03714	1826-0442
DM8556N	03406	1820-1874	HA2-2539-5	03799	1826-1634	IH5028CPF	03714	1826-0489
DM8570N	03406	1820-0294	HA2-2605-5	03799	1826-0721	IH5032CPF	03714	1826-0490
DM8590N	03406	1820-0262	HA2-2625-5	03799	1826-0736	IH5035CPA	03714	1820-1234
DM85L5LN	03406	1820-1166	HA2-2625-5 SELECTED	03799	1826-1309	IH5042CJE	03714	1826-1159
DM85L52N	03406	1820-1472	HA3-5002-5	03799	1826-1699	IH5108CJE	03714	1826-0924
DM85L5WN	03406	1820-1349	HA3-5033-5	03799	1826-1694	IH5149CPF	03714	1826-1678
DN85S68J	03406	1820-1985	HAT-2505-5	03799	1826-0735	IH5151CPF	03714	1826-1679
DM86175N	03406	1820-0986	HAT-2515-5	03799	1826-1045	IH6108CPF	03714	1826-1241
DM86L76N	03406	1820-1057	HAT-2525-5	03799	1826-1220	IH6216CPI	03714	1820-2183
DMPAL16L8B2VC UNPRGMD	03406	1820-5336	HAT-2645-5	03799	1826-0929	IM5013ACDD	03714	1820-1363
DP8304BN	03406	1820-2239	HAT-5130-5	03799	1826-1420	IM5013CDD	03714	1820-0781
DP8340N	03406	1820-3417	HCTL-2000	01542	1820-4792	IM6402-11PL	03714	1820-2204
DP8341N	03406	1820-3418	HD100112	06347	1820-3887	IM6402IDL	03714	1820-2087
DP8344	03406	1820-5411	HD100131	06347	1820-4228	INA010AM	05436	1826-1027
DP8392AN	03406	1820-4889	HD100150	06347	1820-3595	INA010SG	05436	1826-1519
DP8392N	03406	1820-4896	HD44102CH	06347	1820-3859	KST7AHCT00N	12125	1820-4781
DP8408N	03406	1820-3154	HD44103CH	06347	1820-3860	KST7AHCT02N	12125	1820-5147
DP8409N-2	03406	1820-3142	HD635OP	06347	1820-3938	KST7AHCT138N	12125	1820-4754
DP8451N	03406	1820-3969	HD74HCT449P	06347	1820-5432	KST7AHCT14W	12125	1820-5098
DP8451V-4	03406	1820-4877	HD74LS390P	06347	1820-2885	KST7AHCT240W	12125	1820-4748
DP8461N	03406	1820-3705	HDS1015EM	03285	1826-1094	KST7AHCT24W	12125	1820-4749
DP8464BV	03406	1820-4334	HEF1001BT	02910	1820-4333	KST7AHCT257N	12125	1820-5100
DQ8023A	11111	1820-4189	HEF1006UBT	02910	1820-432	KST7AHCT258N	12125	1820-5101
DRAM 6.8B10	06563	1826-0091	HEF1076BT	02910	1820-4217	KST7AHCT273N	12125	1820-4753
DS0025CN	03406	1820-0718	HEF1742BP	02910	1820-4229	KST7AHCT32N	12125	1820-5099
DS0026CG	03406	1820-1065	HI1-0201-4	03799	1826-1012	KST7AHCT64ON	12125	1820-4747
DS0026CN	03406	1820-1366	HI1-0508A-5	03799	1826-0983	L-35-0V-5	06545	1826-1498
DS0056CN	03794	1820-2103	HI1-0509A-5	03799	1826-1063	L14wCJ	02883	1826-0401
DS14c89AN	03406	1820-4253	HI1-0518-5	03799	1826-1438	L166CB	06338	1826-1132
DS14c88AN	03406	1820-4691	HI1-0539-5	03799	1826-1366	L165V	06338	1826-1124
DS3245N	03406	1820-4690	HI1-0562A-5	03799	1826-0860	L2-0V-12	06545	1826-0693
DS3487M	03406	1820-3769	HI1-1818A-5	03799	1826-0429	L2-0V-15	06545	1826-0692
DS3487N	03406	1820-5438	HI1-200-4	03799	1826-1102	L2-0V-20	06545	1826-0691
DS3611N	03406	1820-3445	HI1-303-5	03799	1826-1414	L2-0V-5	06545	1826-0694
DS3612N	03406	1820-1796	HI1-5042-5	03799	1826-0958	L292	06338	1826-0895
DS3630N	03406	1820-2041	HI1-5043-5	03799	1826-0740	L293B	06338	1820-5494
DS3631N	03406	1820-2174	HI1-507A-2	03799	1826-1503	L293D	06338	1820-4997
DS3632N	03406	1820-2290	HI1-507A-5	03799	1826-1252	L293E	06338	1826-1266
DS3649N	03406	1820-2234	HI1-508-5	03799	1826-1277	L297	06338	1826-1267
DS3658N	03406	1820-4185	HI1-509A-5	03799	1826-1276	L298	06338	1820-4205
DS3667N	03406	1820-2862	HI1-674WAKD-5	03799	1826-1593	L4922	06338	1826-1715
DS3669N	03406	1820-4186	HI2-0200-5	03799	1820-1781	L4962	06338	1826-1653
DS3674N	03406	1820-3658	HI3-0201-5	03799	1826-1282	L6-0V-5	06545	1826-0731
DS3686N	03406	1820-2973	HI3-0201-5	03799	1826-1291	L6-0V-5	06545	1826-0732
DS3687N	03406	1820-3581	HI3-0508A-5	03799	1826-1064	LAS-1515	06545	1826-0402
DS3695N	03406	1820-4527	HI3-0509-5	03799	1826-1482	LAS-1815	06545	1826-0403
DS3697N	03406	1826-1701	HI3-201HS-5	03799	1826-1346	LAS-19U	06545	1826-0591
DS75160AN	03406	1820-3431	HOS-100AH	03285	1813-0486	LAS15A15	06545	1826-0819
DS75161AN	03406	1820-3513	HPL1-16LC8-9 UNPRGMD	03799	1820-4523	LAS18A15	06545	1826-0820
DS75162AN	03406	1820-3518	HPL1-16RC4-9 UNPRGMD	03799	1820-4524	LAS1912	06545	1826-0784
DS7549N	03406	1820-1670	HPL1-16RC6-9 UNPRGMD	03799	1820-4522	LAS1915	06545	1826-0754
DS7549N	03406	1820-2254	HS3120-C2	03755	1826-1114	LB1246	07371	1820-4761
DS8640N	03406	1820-2178	ICL8013CC TZ	03714	1826-0455	LD110CJ	02883	1820-1252
DS8654N	03406	1820-2957	ICL8049 CC PE	03714	1826-0432	LD111CJ	02883	1826-0195
DS8800H	03406	1820-1021	ICL8250 C PE	03714	1826-0387	LD114CJ	02883	1820-1474
DS8820AN	03406	1820-0721	ICL7101CPL	03714	1820-2025	LD120CJ	02883	1826-0588
DS8822N	03406	1820-1115	ICL7107CPL	03714	1826-0876	LD121CJ	02883	1826-0587
DS8830N	03406	1820-0720	ICL7109CPL	03714	1826-0746	LD130CJ	02883	1826-0452
DS8831N	03406	1820-0780	ICL7109CPL	11302	1826-1455	LD150BD	03406	1826-0695
DS8835N	03406	1820-2161	ICL7109IDL	03714	1826-1053	LF13007N	03406	1826-1516
DS8836	03406	1820-2256	ICL7109IPL	03714	1826-1510	LF13201D	03406	1826-0582
DS8838N	03406	1820-1875	ICL741C-LN-TY	03714	1826-0391	LF13201N	03406	1820-1941
DS8839N	03406	1820-1870	ICL7605CJN	03714	1826-0761	LF13202D	03406	1826-0720
DS8859AN	03406	1820-1587	ICL76118MTY	03714	1826-0765	LF13202N	03406	1820-1986
DS8863N	03406	1820-1740	ICL7613BCTV	03714	1826-0963	LF1331D	03406	1826-0416
DS8867N	03406	1820-2363	ICL7650CPD	03714	1826-1373	LF1331LN	03406	1820-1795
DS8871N	03406	1820-2138	ICL7650IJA-1	03714	1826-1376	LF1332D	03406	1826-0846
DS8884AN	03406	1820-1738	ICL7650IJD	03714	1826-0968	LF1332N	03406	1826-0510
DS8897AN	03406	1820-1739	ICL7660CBA	03714	1826-1350	LF1333D	03406	1826-0417
DS88C20N	03406	1820-2417	ICL7660CPA	03714	1826-0851	LF1333N	03406	1826-0480
DS88C21N	03406	1820-4890	ICL7660CPA	03714	1826-0906	LF1350BD	03406	1826-0581
DS8922AN	03406	1820-5371	ICL7667CPA	03714	1820-4032	LF1350D	03406	1826-0590
DS8973N	03406	1820-2136	ICL7673CBA	03714	1826-1683	LF13741H	03406	1826-0552
E144C-0200	01876	1820-1003	ICL7673CPA	03714	1826-1526	LF156H	03406	1826-1052
E144D-0200	01876	1820-0714	ICL8001CTZ	03714	1826-0129	LF255H	03406	1826-0458
E144D-0200	01876	1820-1019	ICL8008CTY	03714	1826-0131	LF255N	02037	1826-0801
F10010DC	02237	1820-2093	ICL8038BCJD (SELECTED)	03714	1826-1109	LF256H	03406	1826-0371
F10014PC	02237	1820-2359	ICL8052CPD	03714	1826-0446	LF256H, SEL NOISE	03406	1826-0358
F10016DC	02237	1820-1788	ICL8069DCQ	03714	1826-0573	LF257H	03406	1826-0447
F11C06DC	02237	1820-2106	ICL8211CPA	03714	1826-0978	LF298H	03406	1826-0422
F135-0100	01876	1820-1226	ICL8211CTY	03714	1826-0540	LF298H SELECTED	03406	1826-0619
FCM7002PC	02237	1820-2114	ICL8211IPA (SELECTED)	03714	1826-1508	LF311H	03406	1826-0497
FDC9292BTP	01425	1820-4686	ICL8212CPA	03714	1826-0408	LF347BN	03406	1826-0665
GAP-01FP	02180	1826-1641	ICM7207AITPD	03714	1826-1337	LF351AH	03406	1826-0686
GPD-1003	03291	1813-0315	ICM7209IPA	03714	1820-3060	LF351H	03406	1826-0685
GPD-321	03291	1826-1147	ICM7217CIP1	03714	1820-2132	LF351N	03406	1826-0667
GPD-331	03291	1813-0320	ICM7218AIP1	03714	1820-4688	LF353AH	03406	1826-0741
GPD-410	03291	1813-0318	ICM7218B1J1	03714	1820-4983	LF353AN	03406	1826-0888
GPD-420	03291	1813-0319	ICM7218B1J1	03714	1820-2466	LF353BN	03406	1826-0843
GPD-430	03291	1813-0385	ICM7218B1PI	11302	1820-5060	LF353BN	03406	1826-0734
GS-R405S	06338	1813-0544	ICM7218E1JL	03714	1820-4503	LF356BH	03406	1826-0528
HA-2005A	03799	1826-0270	ICM7226AIDL	03714	1820-2187	LF353H	03406	1826-0704
HA1-2425-5	03799	1826-0840	ICM7227AIP1	03714	1820-2616	LF353N	03406	1826-0712
HA1-2539-5	03799	1826-1691	ICM7227CIP1	03714	1820-2647	LF355H	03406	1826-0304
HA1-4605-5	03799	1826-0532	ICM7228B1J1	03714	1820-4983	LF355H	03406	1826-1180
HA1-4741-5 (SELECTED)	03							

LF411ACH	03406 1826-1148	LM306H	03406 1820-0475	LM343H	03406 1826-0634
LF411ACN	03406 1826-1081	LM307H	03406 1826-0043	LM346J	03406 1826-0719
LF411CH	03406 1826-1071	LM307J	03406 1826-0989	LM348J	03406 1826-0557
LF411CN	03406 1826-0961	LM307N	03406 1820-0493	LM348N	03406 1826-0315
LF411CNA+ (SELECTED)	03406 1826-1726	LM307N SELECTED	03406 1826-0068	LM350K	03406 1826-0631
LF412ACH	03406 1826-1077	LM308AH	03406 1826-0035	LM350K SELECTED	03406 1826-0724
LF412ACN	03406 1826-1128	LM308AN	03406 1826-0493	LM350T	03406 1826-1166
LF412CH	03406 1826-1127	LM308H	03406 1820-0478	LM3524N	03406 1826-1569
LF412CN	03406 1826-0962	LM308N	03406 1826-0172	LM355-1H	03406 1826-0314
LF412CN	03406 1826-0997	LM309H	03406 1820-0429	LM358AH	03406 1826-0592
LF412CN (SELECTED)	03406 1826-0887	LM309H SELECTED	03406 1826-0265	LM358AN	03406 1826-0890
LF4141CN	03406 1826-1074	LM309K	03406 1820-0430	LM358H	03406 1826-0678
LF4142ACN	03406 1826-1405	LM310H	03406 1826-0021	LM358N	03406 1826-0346
LF4142CN	03406 1826-1075	LM310H SELECTED	03406 1826-0354	LM35CAH	03406 1826-1473
LF444ACN	03406 1826-1302	LM310H SELECTED	03406 1826-0515	LM35CZ	03406 1826-1365
LF444CN	03406 1826-1076	LM310J-8	03406 1826-0947	LM360J	03406 1826-1640
LH-0053CG	03406 1826-0439	LM310N	03406 1826-0208	LM360N	03406 1826-0638
LH0002CH	03406 1820-0224	LM311P	03406 1826-0077	LM361H	03406 1826-0272
LH0002CN	03406 1826-1067	LM311H	03406 1826-0026	LM361N	03406 1826-0210
LH0021CK	03406 1813-0058	LM311H	03406 1826-1113	LM370N	03406 1826-0245
LH0022CH	03406 1826-0405	LM311H	02037 1826-1179	LM371H	03406 1826-0104
LH0024CH	03406 1813-0057	LM311J-8	03406 1826-1221	LM377N	03406 1826-0348
LH0033CG	03406 1826-0481	LM311M	03406 1826-1594	LM380N	03406 1826-0709
LH0041CG	03406 1826-1449	LM311N	03406 1826-0065	LM380N-8	03406 1826-0209
LH0042CD	03406 1826-0459	LM311N	03406 1826-1292	LM381N	03406 1826-0206
LH0042CH	03406 1813-0041	LM312H	03406 1826-0102	LM385BZ-1.2	03406 1826-0774
LH0044ACH	03406 1826-0472	LM312J	03406 1826-0201	LM385BZ-2.5	03406 1826-1235
LH0044CH	03406 1826-0594	LM316AH	03406 1826-0112	LM385BZ-2.5	03406 1826-1251
LH0062CD	03406 1826-0267	LM317H	03406 1826-0539	LM386N-1	03406 1826-0682
LH0062CH	03406 1826-0108	LM317HVK	03406 1826-0687	LM386N-4	03406 1826-1729
LH0063CK	03406 1820-4446	LM317K	03406 1826-0423	LM388N	03406 1826-1016
LH0070-1H	03406 1826-0316	LM317K SELECTED	03406 1826-0722	LM3900N	03406 1826-0120
LH0070-1H	03406 1826-0826	LM317LZ	02037 1826-0772	LM3909N	03406 1826-0419
LH0070-2H	03406 1826-0414	LM317MP	03406 1826-1152	LM393N	03406 1826-1315
LH0071-1H	03406 1826-0388	LM317T	03406 1826-0393	LM3911N	03406 1826-0390
LH0071-2H	03406 1826-1130	LM318H	03406 1826-0081	LM3914N	03406 1826-0655
LH0075CG	03406 1826-1354	LM318J-8	03406 1826-1271	LM392N	03406 1826-1126
LH0091CD	03406 1826-0499	LM318M	03406 1826-1739	LM393AFAE	02910 1826-1616
LM103H-2.0	03406 1826-0812	LM318N	03406 1826-0207	LM393D	02910 1826-1572
LM104H	03406 1826-0016	LM318N	03406 1826-1034	LM393JG	01698 1826-1229
LM105H	03406 1826-0017	LM319D	02910 1826-1551	LM393N	03406 1826-0162
LM109H	03406 1826-0954	LM319H	03406 1826-0191	LM395K	03406 1826-0320
LM109K	03406 1826-0324	LM319J	03406 1826-0141	LM395T	03406 1826-0886
LM10BLH	03406 1826-1223	LM319M	03406 1826-1623	LM396K	03406 1826-0966
LM10CH	03406 1826-0316	LM319N	03406 1826-0175	LM3992Z	03406 1826-0825
LM10CN	03406 1826-1004	LM320H-05	03406 1826-0220	LM399AH (SEL)	10858 1826-1249
LM110H	03406 1826-1575	LM320H-12	03406 1826-0178	LM399H	03406 1902-0908
LM113-2H	03406 1826-0329	LM320H-15	03406 1826-0192	LM425CH	03406 1826-0165
LM117K	03406 1826-0673	LM320H-5.2	03406 1826-0179	LM425CN	03406 1826-0747
LM111CH	03406 1826-0909	LM320H-6	03406 1826-0568	LM555CN	03406 1826-0355
LM111CN	03406 1826-1133	LM320K-05	03406 1826-0202	LM555CN	03406 1826-0373
LM120K-15	03406 1826-1157	LM320K-12	03406 1826-0123	LM565CH	03406 1826-0101
LM120K-5.0	03406 1826-0397	LM320K-15	03406 1826-0169	LM675T	03406 1826-1720
LM129AH	03406 1826-0802	LM320K-5.2	03406 1826-0173	LM709AH	03406 1820-0197
LM13340-1N	03406 1826-0336	LM320LZ-5.0	03406 1826-1383	LM709H	03406 1820-0162
LM135AH	03406 1826-1138	LM320T-12	03406 1826-0418	LM725AH	03406 1826-0711
LM136H	03406 1826-1541	LM320T-15	03406 1826-0277	LM741CN	03406 1826-0271
LM137K	03406 1826-0763	LM320T-18	03406 1826-0377	LM747D	03406 1826-0135
LM138K (STEEL)	03406 1826-0837	LM320T-24	03406 1826-0299	LM78L10ACH	03406 1826-0394
LM145K-5.2	03406 1826-1026	LM320T-8.0	03406 1826-0449	LM78L15ACH	03406 1826-0353
LM1558H	03406 1826-0243	LM321AH SELECTED	03406 1826-0234	LM78M05CP	03406 1826-1299
LM161J	03406 1826-0548	LM321H	03406 1826-0162	LM7906T	03406 1826-0478
LM1875	03406 1826-1389	LM322N	03406 1826-0225	LM833N	03406 1826-1725
LM187N-9	03406 1826-0863	LM323K	03406 1826-0181	LP2905ACZ	03406 1826-1646
LM201ADP	10881 1826-1460	LM324AN	03406 1826-0524	LP311N	03406 1826-1162
LM201AH	03406 1826-0059	LM324D	02910 1826-1072	LP339M	03406 1826-1225
LM201AH SELECTED	03406 1826-0045	LM324D	01698 1826-1600	LP339N	03406 1826-1289
LM201AJ	03406 1826-1491	LM324F	03406 1826-0291	LP365M	03406 1826-1370
LM201AN	02037 1826-0311	LM324N	03406 1826-0161	LT1001ACH	10858 1826-1479
LM201H	03406 1820-0104	LM325AS	03406 1826-0238	LT1001CN8 (SELECTED)	10858 1826-1382
LM207H	03406 1826-0113	LM325H	03406 1826-0457	LT1002CN	10858 1826-1368
LM208AH	03406 1826-0025	LM325S	03406 1826-0283	LT1004WC	10858 1826-1167
LM208D	03406 1826-0268	LM326H	03406 1826-0533	LT1007CH	10858 1826-1433
LM208H	03406 1826-0072	LM329	03406 1902-0928	LT1007CN8	10858 1826-1316
LM210H SELECTED	03406 1826-0097	LM329D (SEL)	03406 1902-1331	LT1007CS	10858 1826-1735
LM211H	03406 1826-0098	LM329D	03406 1826-0585	LT1009CZ	10858 1826-1435
LM212H	03406 1826-0110	LM330T-5.0	03406 1826-0904	LT1011ACH	10858 1826-1539
LM218H	03406 1826-0488	LM333K STEEL	03406 1826-1415	LT1011CN8	10858 1826-1475
LM220K-12	03406 1826-0235	LM334H	03406 1826-1046	LT1012CH	10858 1826-1462
LM220K-15	03406 1826-0233	LM334Z	03406 1826-0623	LT1012CN8	10858 1826-1381
LM220K-5.2	03406 1826-0537	LM335AZ	03406 1826-0760	LT1013ACJ8	10858 1826-1436
LM224W	03406 1826-0232	LM335Z	03406 1826-0880	LT1013CN8	10858 1826-1409
LM236AH	03406 1826-0855	LM336BZ	03406 1826-0910	LT1014CN	10858 1826-1590
LM236H	03406 1826-0766	LM336BZ-5.0	03406 1826-1297	LT1014WD	10858 1826-1553
LM250K STEEL	03406 1826-0748	LM336Z-5.0	03406 1826-1065	LT1019ACH-5	10858 1826-1712
LM258AH	03406 1826-0768	LM337H	03406 1826-0558	LT1021BCN8-10	10858 1826-1514
LM258H	03406 1826-0745	LM337H-STEEL	03406 1826-0870	LT1021BCN8-5	10858 1826-1706
LM261H	03406 1826-0762	LM337K	03406 1826-0523	LT1021CCN8-10	10858 1826-1437
LM271H	03406 1826-0398	LM337K (SELECTED)	03406 1826-0690	LT1021CCN8-5	10858 1826-1431
LM285BYZ-1.2	03406 1826-1509	LM337LZ	03406 1826-0994	LT1021DCN8-10	10858 1826-1369
LM285BYZ-2.5	03406 1826-1464	LM337TT	03406 1826-1099	LT1021DCS8-10	10858 1826-1687
LM285H-2.5	03406 1826-1288	LM337T	03406 1826-0527	LT1022ACH	10858 1826-1690
LM2900N	03406 1826-0939	LM338K	03406 1826-0677	LT1024ACN	10858 1826-1608
LM2901N	03406 1826-1506	LM339AJ	03406 1826-0306	LT1028CJ8	10858 1826-1728
LM2904WN	03406 1826-0611	LM339AN	03406 1826-0666	LT1031DCN8	10858 1826-1429
LM2917N	03406 1826-0842	LM339J	03406 1826-0759	LT1032CN	10858 1820-4311
LM2930P-5.0TB	03406 1826-1005	LM339M	03406 1826-1528	LT1033CK	10858 1826-1585
LM2930T-5.0	03406 1826-1201	LM339N	03406 1826-0138	LT1037CH	10858 1826-1374
LM2931AZ-5.0	03406 1826-1397	LM339N SELECTED	01698 1826-1033	LT1037CN8	10858 1826-1317
LM2931CT	03406 1826-1090	LM340-12AT	03406 1826-1121	LT1039CN	10858 1820-4887
LM2935T	03406 1826-1586	LM340AK-15	03406 1826-1181	LT1055CN8	10858 1826-1702
LM2935T05B	03406 1826-1750	LM340AK-5	03406 1826-0536	LT1056CN8	10858 1826-1692
LM293P	01698 1826-0479	LM340AT-15	03406 1826-0607	LT1081-CN	10858 1820-5338
LM2940CT-5.0	03406 1826-1597	LM340AT-5	03406 1826-0551	LT317AT	10858 1826-1403
LM299AH	03406 1826-1239	LM340K-24	03406 1826-0559	LT318AN8 (SELECTED)	10858 1826-1265
LM299R	03406 1826-0330	LM340K-8	03406 1826-0370	LT337AK	10858 1826-1395
LM300H	03406 1820-0123	LM340LAH-12	03406 1826-0438	LT337AT	10858 1826-1670
LM301AH	03406 1820-0223	LM340LAZ-12	03406 1826-0554	LT338AR	10858 1826-1396
LM301AH_22V	03406 1820-0242	LM340LAZ-5	03406 1826-0555	LT350AT	10858 1826-1216
LM301AJ	03406 1826-1227	LM340LAZ-5	03406 1826-1203	LTC104WCN8	10858 1826-1529
LM301AJ-14	03406 1826-0069	LM341P-12	03406 1826-0435	LTC1052CJ	10858 1826-1562
LM301AN	03406 1820-0477	LM341P-24	03406 1826-0436	LK5700H	03406 1826-0375
LM302H	03406 1820-0158	LM341P-8.0	03406 1826-0434	M1403A	038

MC1408L-8	02037 1826-0188	MC1468R	02037 1826-0140	MC3468P	02037 1826-0475
MC14093BCL	02037 1820-1936	MC1469G	02037 1826-0006	MC3470P	02037 1826-0945
MC14114P	02037 1826-0051	MC1469R	02037 1826-0024	MC3476G	02037 1826-0289
MC14174BCP	02037 1820-2258	MC1488L	02037 1820-0509	MC3486P	02037 1820-2144
MC14175BCP	02037 1820-2279	MC1488P	02037 1820-3322	MC3487P	02037 1820-2145
MC14194BCP	02037 1820-3587	MC1489AL	02037 1820-0990	MC352G	02037 1820-0013
MC1420G	02037 1826-0200	MC1489AP	02037 1820-3321	MC4001P	02037 1820-0639
MC1431P	02037 1820-0160	MC1489L	02037 1820-0510	MC4002P	02037 1820-0843
MC1433G	02037 1820-0316	MC1494L	02037 1826-0036	MC4006P	02037 1820-0608
MC1433L	02037 1820-0181	MC1495L	02037 1826-0437	MC4007P	02037 1820-0724
MC1433P	02037 1820-0317	MC1496D	02037 1826-1621	MC4008P	02037 1820-0842
MC1436CG	02037 1826-0343	MC1496G	02037 1820-0427	MC4010P	02037 1820-0836
MC1436G	02037 1826-0038	MC1496L	02037 1826-0023	MC4012P	02037 1820-0607
MC1436U	02037 1826-1171	MC1496N	02910 1826-1095	MC4015P	02037 1820-0437
MC1437L	02037 1826-0019	MC1505L	02037 1826-1059	MC4016P	02037 1820-1183
MC1438R	02037 1826-0060	MC1510G	02037 1826-0002	MC4018P	02037 1820-1332
MC1439G	02037 1820-0201	MC1514L	02037 1826-0125	MC4022P	02037 1820-1109
MC1439L	02037 1826-0022	MC1531G	02037 1820-0050	MC4024P	02037 1820-0567
MC14410P	02037 1820-3487	MC1550G	02037 1826-0028	MC4038P	02037 1820-0834
MC14411P	02037 1820-1779	MC1590G	02037 1826-0037	MC4044P	02037 1820-0630
MC1442V	02037 1820-2166	MC1595L	02037 1826-0014	MC426P	02037 1820-0844
MC14433L	02037 1826-0431	MC1648L	02037 1820-1119	MC660P	02037 1820-1520
MC14447P	02037 1826-0884	MC1648P	02037 1820-1108	MC662P	02037 1820-0288
MC1445G	02037 1826-0103	MC1650L	02037 1820-0919	MC663P	02037 1820-1519
MC1445L	02037 1826-0334	MC1658P	02037 1826-0509	MC666P	02037 1820-0625
MC14490DW	02037 1820-5213	MC1660L	02037 1820-0790	MC667P	02037 1820-1606
MC14490FP	02037 1820-1947	MC1662L	02037 1820-0796	MC668P	02037 1820-1605
MC14490P	02037 1820-2306	MC1664L	02037 1820-0795	MC670P	02037 1820-2133
MC14500BCP	02037 1820-3360	MC1670	02037 1820-2429	MC672P	02037 1820-0287
MC14501UBCP	02037 1820-1079	MC1670L	02037 1820-0794	MC6875P	02037 1820-2036
MC14502BAL	02037 1820-1635	MC1672L	02037 1820-0797	MC6881P/MC3449P	02037 1820-2165
MC14502BCP	02037 1820-1385	MC1674L	02037 1820-0793	MC7250P	02037 1820-0786
MC14503BCP	02037 1820-2257	MC1678L	02037 1820-2664	MC7270P	02037 1820-0984
MC14504BCP	02037 1820-2326	MC1690L	02037 1820-1132	MC7404F	02037 1820-1004
MC14506BCP	02037 1820-1386	MC1692L	02037 1820-0920	MC7474P	02037 1820-0908
MC14507CP	02037 1820-1330	MC1694L	02037 1820-1334	MC74HC00N	02037 1820-2922
MC14508BCL	02037 1820-1693	MC1697P	02037 1820-1852	MC74HC02N	02037 1820-2924
MC14508BCP	02037 1820-1959	MC1723L	02037 1826-0409	MC74HC03N	02037 1820-3183
MC14510BCP	02037 1820-1189	MC1733G	02037 1826-1175	MC74HC107N	02037 1820-5291
MC14511BCP	02037 1820-1413	MC1741NCP1	02037 1826-0505	MC74HC109N	02037 1820-3172
MC14511BCP	02037 1820-1957	MC1741SCG	02037 1826-0302	MC74HC10N	02037 1820-2923
MC14512BCP	02037 1820-1241	MC1741SCP1	02037 1826-0254	MC74HC126N	02037 1820-4458
MC14513BCL	02037 1820-2716	MC1741SU	02037 1826-0743	MC74HC132D	02037 1820-4965
MC14513BCP	02037 1820-2462	MC1776CD	02037 1826-1212	MC74HC132N	02037 1820-3174
MC14514P	02037 1820-2897	MC1800P	02037 1820-0985	MC74HC137N	02037 1820-4084
MC145146P	02037 1820-3405	MC1801P	02037 1820-0441	MC74HC138N	02037 1820-3079
MC14514BCP	02037 1820-1683	MC1805P	02037 1820-0454	MC74HC157N	02037 1820-3177
MC145151P	02037 1820-2879	MC1806P	02037 1820-0273	MC74HC158N	02037 1820-3178
MC145152P	02037 1820-2880	MC1808P	02037 1820-0274	MC74HC160N	02037 1820-3179
MC14515BCP	02037 1820-1329	MC1809P	02037 1820-1137	MC74HC161N	02037 1820-2925
MC14516BCL	02037 1820-1899	MC1810P	02037 1820-0238	MC74HC162N	02037 1820-3187
MC14516BCP	02037 1820-1114	MC1812P	02037 1820-0418	MC74HC163N	02037 1820-3785
MC14517BCP	02037 1820-1959	MC1814P	02037 1820-0665	MC74HC165N	02037 1820-3181
MC14518BCL	02037 1820-1591	MC2257L	02037 1820-1156	MC74HC173N	02037 1820-3182
MC14518BCP	02037 1820-1122	MC2259L	02037 1820-1157	MC74HC174J	02037 1820-3564
MC14519BCP	02037 1820-1387	MC3001P	02037 1820-0141	MC74HC175N	02037 1820-3146
MC14520BCL	02037 1820-1900	MC3002P	02037 1820-0239	MC74HC194N	02037 1820-3186
MC14520BCP	02037 1820-1150	MC3003P	02037 1820-0205	MC74HC195N	02037 1820-3187
MC14520BCP	02037 1820-2021	MC3006P	02037 1820-0204	MC74HC20N	02037 1820-3080
MC14521BCP	02037 1820-2702	MC3007P	02037 1820-1031	MC74HC240N	02037 1820-3299
MC14522BAL	02037 1820-1181	MC3022P	02037 1820-0617	MC74HC241N	02037 1820-3374
MC14522BCP	02037 1820-1175	MC3025P	02037 1820-0604	MC74HC242N	02037 1820-3188
MC14526BCP	02037 1820-1328	MC3026P	02037 1820-0140	MC74HC243N	02037 1820-3189
MC14527BCP	02037 1820-1265	MC3029P	02037 1820-0700	MC74HC244N	02037 1820-3297
MC14528BCL	02037 1820-2051	MC3060P	02037 1820-0449	MC74HC253N	02037 1820-3672
MC14528BCP	02037 1820-1356	MC3061P	02037 1820-0609	MC74HC257N	02037 1820-3191
MC14530BCP	02037 1820-1327	MC3062P	02037 1820-0451	MC74HC266N	02037 1820-3192
MC14532BCL	02037 1820-1570	MC3103L	02037 1820-1375	MC74HC273N	02037 1820-3399
MC14532BCP	02037 1820-1355	MC3242AP	02037 1820-2742	MC74HC280N	02037 1820-3193
MC14534BCP	02037 1820-1855	MC3302P SELECTED	02037 1826-0174	MC74HC299N	02037 1820-3546
MC14536BCP	02037 1826-0411	MC3340P	02037 1826-0399	MC74HC356N	02037 1820-4608
MC14538BCL	02037 1820-1569	MC3359P	02037 1826-1073	MC74HC373N	02037 1820-2998
MC14538BCP	02037 1820-1932	MC34001BU	02037 1826-0915	MC74HC374J	02037 1820-3565
MC14538BDW	02037 1820-5418	MC34002BU	02037 1826-0785	MC74HC374N	02037 1820-3082
MC14539BCL	02037 1820-1549	MC34002BU	02037 1826-1513	MC74HC4002N	02037 1820-3196
MC14539BCP	02037 1820-1471	MC34004BL	02037 1826-0753	MC74HC4017N	02037 1820-3683
MC145406ACP	02037 1820-4666	MC3403P	02037 1826-0312	MC74HC4020N	02037 1820-3197
MC145406DW	02037 1820-5274	MC3405P	02037 1820-4600	MC74HC4024N	02037 1820-3198
MC14541BCP	02037 1820-1658	MC3405P	02037 1826-0424	MC74HC4040N	02037 1820-3199
MC14543BCP	02037 1820-2097	MC34060P	02037 1826-1208	MC74HC4052N	02037 1820-4574
MC145440P SELECTED	02037 1820-3721	MC34062P1	02037 1826-1255	MC74HC4060N	02037 1820-3200
MC14545BCP	02037 1820-1721	MC34063U	02037 1826-1256	MC74HC4075N	02037 1820-3201
MC14553BCP	02037 1820-1479	MC34072AU	02037 1826-1543	MC74HC4078N	02037 1820-4232
MC14555BCP	02037 1820-2050	MC34072P	02037 1826-1533	MC74HC42N	02037 1820-3169
MC14556BCP	02037 1820-1412	MC34074AL	02037 1826-1222	MC74HC4351N	02037 1820-4705
MC14557BCP	02037 1820-2344	MC34074P	02037 1826-1534	MC74HC4511N	02037 1820-4056
MC14558BCP	02037 1820-1573	MC34081AP	02037 1826-1581	MC74HC4514N	02037 1820-3202
MC14559BCP	02037 1820-1722	MC34081P	02037 1826-1544	MC74HC4538N	02037 1820-3203
MC14560BCP	02037 1820-1850	MC34082AP	02037 1826-1582	MC74HC4543N	02037 1820-4437
MC14561BCP	02037 1820-2033	MC34084AP	02037 1826-1652	MC74HC51N	02037 1820-3396
MC14562BCP	02037 1820-2444	MC34084P	02037 1826-1422	MC74HC533N	02037 1820-3194
MC14566BCP	02037 1820-1588	MC3410CL	02037 1826-0462	MC74HC534N	02037 1820-3195
MC14568BCP	02037 1826-0599	MC3410CP	02037 1826-0529	MC74HC540N	02037 1820-4569
MC14569BCP	02037 1820-2571	MC3420P	02037 1826-0526	MC74HC558N	02037 1820-3788
MC14569BCP	02037 1820-2383	MC3423P1	02037 1826-0468	MC74HC595N	02037 1820-3344
MC14566CG	02037 1826-0003	MC3425P1	02037 1826-1185	MC74HC597N	02037 1820-4355
MC14566G	02037 1826-0071	MC3431P	02037 1826-0360	MC74HC74D	02037 1820-4966
MC14572BCP	02037 1820-1657	MC3440AP	02037 1820-1522	MC74HC74N	02037 1820-3081
MC14581BCP	02037 1820-1666	MC3441AP	02037 1820-1588	MC74HC85N	02037 1820-3171
MC14582BCP	02037 1820-1659	MC3442P	02037 1820-1842	MC74HC86N	02037 1820-3007
MC14583BCP	02037 1820-1389	MC3443AP	02037 1820-1687	MC74HC87541N	02037 1820-4586
MC14584BCP	02037 1820-2019	MC3446AP	02037 1820-1689	MC74HC87640N	02037 1820-4587
MC14585BCP	02037 1820-1340	MC3446N	01698 1820-3329	MC75462P	02037 1820-2208
MC14585BCP1	02037 1826-0142	MC3446N	01698 1820-5059	MC7805CK	02037 1826-0246
MC14586G	02037 1826-0111	MC3447P	02037 1820-2424	MC7805CT	02037 1826-0144
MC14586NG	02037 1826-0556	MC3447P3	02037 1820-2461	MC7806CT	02037 1826-0145
MC14587P1	02037 1826-0139	MC3448AD	02037 1820-4892	MC7808CT	02037 1826-0146
MC14588SG	02037 1826-0866	MC3448AL	02037 1820-2058	MC7808CT	02037 1826-1387
MC14588SP1	02037 1826-0420	MC3450P	02037 1820-2157	MC7818CP	02037 1826-0149
MC14588U	02037 1826-0990	MC3452P	02037 1820-2158	MC7824CT	02037 1826-1218
MC146					

JDEC

Mfr.

HP P/N

MC78L24CP	02037	1826-1499	MM74C173N	03406	1820-1190	MM88C29N	03406	1820-2217
MC78M05CDT	02037	1826-1734	MM74C174N	03406	1820-1466	MM88C30N	03406	1820-2218
MC78M05CG	02037	1826-0367	MM74C175N	03406	1820-1562	MMH0026CL	02037	1820-1288
MC78M12CDT	02037	1826-1736	MM74C192N	03406	1820-1575	MMH0026L	02037	1820-1170
MC78M15CT	02037	1826-0464	MM74C193N	03406	1820-1561	MN376	00046	1813-0501
MC7902CT	02037	1826-0688	MM74C20N	03406	1820-1626	MNDAC71CSB-I	06861	1813-0132
MC7905..2CT	02037	1826-0215	MM74C221J	03406	1820-1612	MO13326	08507	1826-1295
MC7905CT	02037	1826-0294	MM74C221N	03406	1820-1485	MP260	03688	1826-1573
MC7908CT	02037	1826-0344	MM74C240N	03406	1820-2538	MP7507JN	07050	1826-1307
MC7912CT	02037	1826-0221	MM74C240N	03406	1820-2566	MP7533QN	07050	1826-1525
MC7915CT	02037	1826-0214	MM74C244N	03406	1820-2537	MP7683XKN	07050	1826-1417
MC79L03ACP	02037	1826-1293	MM74C30N	03406	1820-1674	MP7684KHD	07050	1826-1672
MC79L03C	02037	1826-0286	MM74C32N	03406	1820-2213	MPC2014	02037	1826-1713
MC79L05ACG	02037	1826-0496	MM74C373N	03406	1820-2215	MPY016KJ1C	04507	1820-1479
MC79L05ACP	02037	1826-0285	MM74C374N	03406	1820-2216	MSA-0185	03291	1826-1722
MC79L05CP	02037	1826-1281	MM74C42N	03406	1820-1735	MSA-0370-21	03291	1826-1321
MC79L06C	02037	1826-0284	MM74C73N	03406	1820-2605	MSA-0420	03291	1826-1322
MC79L12ACG	02037	1826-0495	MM74C74J	03406	1820-1933	MSA-0435	03291	1826-1323
MC79L12ACP	02037	1826-0282	MM74C74N	03406	1820-1753	MSA-0485	03291	1826-1613
MC79L15ACP	02037	1826-0281	MM74C76N	03406	1820-2606	MSA-0785	03291	1826-1724
MC79M05CDT	02037	1826-1738	MM74C83J	03406	1820-1937	MSA-0885	03291	1826-1723
MC79M12CDT	02037	1826-1737	MM74C83N	03406	1820-2343	MT8860XE	09161	1826-0824
MC815P	02037	1820-0325	MM74C85N	03406	1820-1806	MT8865XC	09161	1826-0823
MC816P	02037	1820-0106	MM74C86N	03406	1820-2276	MT8870BC	09161	1820-3490
MC817P	02037	1820-0411	MM74C901N	03406	1820-1651	MUX-08FP	02180	1826-1028
MC824P	02037	1820-0324	MM74C920N	03406	1820-1652	MUX-08FQ	02180	1826-0609
MC830P9	02037	1820-0610	MM74C903N	03406	1820-1653	MUX-16-FT	02180	1826-1177
MC8312P	02037	1820-0615	MM74C904N	03406	1820-1654	MUX-16ET	02180	1826-0998
MC832P	02037	1820-0096	MM74C905N	03406	1820-1935	MUX-24FP	02180	1826-1173
MC835P	02037	1820-0479	MM74C906M	03406	1820-5419	MUX-24FQ	02180	1826-0610
MC838P	02037	1820-0533	MM74C906N	03406	1820-1655	MUX-88FQ	02180	1826-0849
MC839P	02037	1820-0260	MM74C907N	03406	1820-1656	MWA204	02037	1826-1614
MC840P	02037	1820-0259	MM74C909N	03406	1820-2275	MWA110	02037	1813-0211
MC844P	02037	1820-0094	MM74C914N	03406	1820-1778	MWA120	02037	1813-0212
MC848P	02037	1820-0095	MM74C922N	03406	1820-2156	MWA130	02037	1813-0213
MC8500P	02037	1820-2297	MM74C923N	03406	1820-2309	MWA210	02037	1813-0214
MC8502P	02037	1820-2296	MM74C925N	03406	1820-2540	MWA220	02037	1813-0215
MC850P	02037	1820-0087	MM74C941N	03406	1820-2630	MWA230	02037	1813-0216
MC851P	02037	1820-0088	MM74HC04N	03406	1820-2921	MWA310	02037	1813-0217
MC852P	02037	1820-0258	MM74HC08N	03406	1820-3097	MWA320	02037	1813-0218
MC853P	02037	1820-0122	MM74HC112N	03406	1820-3173	MWA330	02037	1813-0219
MC857P	02037	1820-0257	MM74HC113N	03406	1820-3795	N7405F	02910	1820-2179
MC858P	02037	1820-0256	MM74HC111N	03406	1820-3184	N8162N	02910	1820-0457
MC8602L	02037	1820-1524	MM74HC123AM	03406	1820-3175	N8200N	02910	1820-1337
MC889P	02037	1820-0323	MM74HC123AN	03406	1820-3673	N8202N	02910	1820-0508
MCC1156	02037	1826-0048	MM74HC125N	03406	1820-3674	N8233N	02910	1820-0543
MCC1741	02037	1826-0042	MM74HC133N	03406	1820-3670	N8234N	02910	1820-0542
MD74HC1373RC	09161	1820-3147	MM74HC139N	03406	1820-3014	N8235N	02910	1820-0575
MD74SC241AC	09161	1820-2796	MM74HC147N	03406	1820-3175	N8243N	02910	1820-0569
MD74SC245AC	09161	1820-2943	MM74HC141N	03406	1820-3185	N8251N	02910	1820-0462
MDMS-1101	08565	1813-0165	MM74HC151N	03406	1820-3176	N8263N	02910	1820-0507
MDPGM-TTL-35	07397	1813-0321	MM74HC153N	03406	1820-3350	N8286N	02910	1820-0506
MF10ACM	03406	1826-1580	MM74HC164N	03406	1820-3136	N8267N	02910	1820-0835
MF10CCM	03406	1826-1666	MM74HC173M	03406	1820-3180	N8271N	02910	1820-0989
MF10CN	03406	1826-1250	MM74HC174N	03406	1820-5395	N8273N	02910	1820-1045
MFC4000B	02037	1826-0198	MM74HC191N	03406	1820-3058	N8280N	02910	1820-0322
MFC6070	02037	1826-0259	MM74HC192N	03406	1820-3794	N8281N	02910	1820-0400
MH0007CH	03406	1820-0832	MM74HC213AN	03406	1820-3204	N8284N	02910	1820-0536
MHW592	02037	1813-0138	MM74HC221AN	03406	1820-3205	N8288N	02910	1820-0455
MJ2818IDP	01590	1820-3410	MM74HC237N	03406	1820-3373	N8290N	02910	1820-0450
MK4501N-15	04078	1820-4085	MM74HC245N	03406	1820-3330	N8291N	02910	1820-0492
MK5007P	04078	1820-1239	MM74HC251N	03406	1820-3190	N8292N	02910	1820-0703
MK5009N	04078	1820-1123	MM74HC259N	03406	1820-3206	N8293N	02910	1820-0789
MK5009P	04078	1820-2322	MM74HC27N	03406	1820-3098	N82S31N	02910	1820-1980
MK50399N	04078	1820-2310	MM74HC283N	03406	1820-3673	N82S33N	02910	1820-1249
MK5089N	04078	1820-3619	MM74HC298N	03406	1820-3674	N82S42N	02910	1820-1073
MK6036P	04078	1820-0993	MM74HC30N	03406	1820-3675	N82S50N	02910	1820-1338
MLMC101A	02037	1826-0567	MM74HC32N	03406	1820-3298	N82S62N	02910	1820-1140
MM4503CD	03406	1820-1357	MM74HC365N	03406	1820-3933	N82S83N	02910	1820-1777
MM5006B	03406	1820-0770	MM74HC366N	03406	1820-3677	N82S90N	02910	1820-1155
MM5013N	03406	1820-1165	MM74HC367N	03406	1820-3792	N84U0N	02910	1820-0459
MM5035P	03406	1820-2416	MM74HC368N	03406	1820-3791	N8840N	02910	1820-0460
MM5040H	03406	1820-1236	MM74HC373W	03406	1820-4185	N8815N	02910	1820-0837
MM5050AH	03406	1820-1237	MM74HC390N	03406	1820-3207	N8816N	02910	1820-0458
MM5052	03406	1820-0717	MM74HC393N	03406	1820-3208	N8825N	02910	1820-0466
MM5057N	03406	1820-1162	MM74HC404N	03406	1820-1372	N8826N	02910	1820-0208
MM507	03406	1820-0410	MM74HC404N	03406	1820-4027	N8855N	02910	1820-0456
MM5307ABN	03406	1820-2001	MM74HC405N	03406	1820-3678	N8875N	02910	1820-0637
MM5307N	03406	1820-1318	MM74HC4051N	03406	1820-5069	N8880N	02910	1820-0461
MM5312N	03406	1820-1756	MM74HC4053N	03406	1820-3692	N8881N	02910	1820-0467
MM5313N (75-)	03406	1820-1364	MM74HC4066N	03406	1820-3693	N8885N	02910	1820-0923
MM5313N (76+)	03406	1820-2126	MM74HC423AN	03406	1820-4590	N8HT0N	02910	1820-0463
MM5315N	03406	1820-2040	MM74HC431N	03406	1820-3765	N8HT23N	02910	1820-1067
MM5369AA/N	03406	1820-2246	MM74HC511N	03406	1820-3975	N8HT24N	02910	1820-1030
MM5371N	03406	1820-1755	MM74HC564N	03406	1820-3781	N8HT09N	02910	1820-1084
MM5437N	03406	1826-1404	MM74HC573N	03406	1820-3790	N8T09N	02910	1820-1360
MM5450N	03406	1820-5339	MM74HC574N	03406	1820-3789	N8T13N	02910	1820-1080
MM5484N	03406	1820-4844	MM74HC604N	03406	1820-3787	N8T81N	02910	1820-1289
MM5505H	03406	1826-0156	MM74HC688N	03406	1820-3209	N8T20N	02910	1820-1048
MM58242N	03406	1820-5286	MM74HC75N	03406	1820-3170	N8T23N	02910	1820-1007
MM58274N	03406	1820-3834	MM74HCT00N	03406	1820-3664	N8T28N	02910	1820-1828
MM58274V	03406	1820-5024	MM74HCT04N	03406	1820-3629	N8T37N	02910	1820-1817
MM5837N	03406	1820-2721	MM74HCT05N	03406	1820-4601	N8T75N	02910	1820-1979
MM5873	02023	1820-1849	MM74HCT112N	03406	1820-4947	N8T80N	02910	1820-0195
MM74C00J	03406	1820-2783	MM74HCT138N	03406	1820-3847	N8T90N	02910	1820-0211
MM74C00N	03406	1820-2210	MM74HCT157N	03406	1820-3796	N8T93N	02910	1820-1924
MM74C02N	03406	1820-1627	MM74HCT240N	03406	1820-4196	N8T95N	02910	1820-1477
MM74C04N	03406	1820-2211	MM74HCT241N	03406	1820-3630	N8T96N	02910	1820-1476
MM74C08N	03406	1820-1603	MM74HCT244N	03406	1820-3456	N8X60N	02910	1820-3931
MM74C107N	03406							

NE522N	02910 1826-0256	PAL10L8A2V0 UNPRGMD	03406 1820-5402	RC4153DC	02290 1826-0922
NE526A	02910 1826-0115	PAL10L8C UNPRGMD	04092 1820-2780	RC4156NB	02290 1826-1116
NE527H	02910 1826-0454	PAL10L8NC UNPRGMD	03406 1820-3568	RC4193NB	02290 1826-1355
NE527N	02910 1826-0755	PAL12H6CJ UNPRGMD	04092 1820-2671	RC4195TK	02290 1826-0196
NE529A	02910 1826-0244	PAL12H6NC UNPRGMD	03406 1820-3570	RC4200ADE	02290 1826-1684
NE529H	02910 1826-0124	PAL12L10CN UNPRGMD	04092 1820-2996	RC4558H	02290 1826-0217
NE531H	02910 1826-0067	PAL12L6-2CJ UNPRGMD	04092 1820-4393	RC4558NB	02290 1826-0326
NE538FE	02910 1826-0803	PAL12L6CJ UNPRGMD	04092 1820-2574	REF-01CP	02180 1826-0708
NE538N3	02910 1826-0936	PAL12L6NC UNPRGMD	03406 1820-3597	REF-01EJ	02180 1826-0925
NE550L	02910 1826-0130	PAL14H4C UNPRGMD	04092 1820-2573	REF-01EZ	02180 1826-1493
NE550N	02910 1826-0137	PAL14H4NC UNPRGMD	03406 1820-3566	REF-01HJ	02180 1826-0853
NE5532AFE	02910 1826-0716	PAL14L4CJ UNPRGMD	04092 1820-2678	REF-01HZ	02180 1826-1441
NE5532AT	02910 1826-0633	PAL14L4CN UNPRGMD	04092 1820-5417	REF-02CP	02180 1826-1037
NE5532P	01698 1826-1328	PAL14L8CN UNPRGMD	04092 1820-3387	REF-02EZ	02180 1826-1320
NE5533AF	02910 1826-0889	PAL16C1-2CJ UNPRGMD	04092 1820-3292	REF-02HJ	02180 1826-0622
NE5533AN	02910 1826-1319	PAL16C1CJ UNPRGMD	04092 1820-2782	REF-02HP	02180 1826-0847
NE5534AD	02910 1826-1546	PAL16C1NC UNPRGMD	03406 1820-3596	REF10J	05436 1826-1476
NE5534AE	02910 1826-0783	PAL16H2CJ UNPRGMD	04092 1820-2679	RGE DAC LTD	03780 1826-1377
NE5534AN	02910 1826-0715	PAL16H2NC UNPRGMD	03406 1820-3567	RGEDAC3404	03780 1826-1536
NE5534AT	02910 1826-0569	PAL16L2CJ UNPRGMD	04092 1820-2781	RTC-58321	10421 1813-0185
NE5539N	02910 1826-1279	PAL16L2CN UNPRGMD	04092 1820-4501	RTC62421	10421 1820-5384
NE5553N	02910 1826-0625	PAL16L6CN UNPRGMD	04092 1820-3530	RV4558DE	02290 1826-0328
NE5555G	01698 1820-2827	PAL16L8-2CJ UNPRGMD	04092 1820-2670	S1602P	03677 1820-3215
NE5555N	02910 1826-0180	PAL16L8A-2CN UNPRGMD	01698 1820-4879	S2350-2	03677 1820-1754
NE5555T	02910 1826-0119	PAL16L8A-WCN UNPRGMD	04092 1820-5065	S2859P	03677 1820-2989
NE5560N	02910 1826-0806	PAL16L8ACN UNPRGMD	04092 1820-5288	S3522P	03677 1826-1060
NE5561N	02910 1826-1051	PAL16L8B-2CJ UNPRGMD	04092 1820-4857	S52	03545 1820-0138
NE5568N	02910 1826-1676	PAL16L8B-2CN UNPRGMD	04092 1820-4969	S5733A	02910 1826-0040
NE5569N	02910 1826-0205	PAL16L8B-WCNS UNPRGMD	04092 1820-5244	S8280F	02910 1820-0419
NE562B	02910 1826-0047	PAL16L8BCN UNPRGMD	04092 1820-4972	S8292F	02910 1820-1098
NE564N	02910 1826-1054	PAL16L8BCNC UNPRGMD	03406 1820-4755	SAA1027	05946 1820-1682
NE565N	02910 1826-0204	PAL16L8DCN UNPRGMD	04092 1820-5215	SC11001CN	11943 1826-1532
NE566H	02910 1826-0189	PAL16L8NC UNPRGMD	03406 1820-3571	SCC2691AC1N24	02910 1820-4859
NE566N	02910 1826-0269	PAL16R4-2CJ UNPRGMD	04092 1820-3291	SCN2611CC1N24	02910 1820-3941
NE567N	02910 1826-1651	PAL16R4-2CJ UNPRGMD	04092 1820-2681	SCN2672BC4N40	02910 1820-4177
NE570N	02910 1826-0703	PAL16R4A-2CN UNPRGMD	04092 1820-3600	SCN2681AC1N40	02910 1820-3538
NE587N	02910 1820-3395	PAL16R4A-WCN UNPRGMD	04092 1820-4582	SD5000B	02910 1826-0415
NE590F	02910 1820-2266	PAL16R4AC UNPRGMD	04092 1820-3492	SDA6020	06121 1826-1153
NE591F	02910 1820-2267	PAL16R4B-2CNS UNPRGMD	04092 1820-5158	SD8575KG	05436 1813-0140
NE592D	01698 1826-1651	PAL16R4BCN UNPRGMD	04092 1820-4750	SE555CT	02910 1826-0224
NE592H	02910 1826-0546	PAL16R4BCN UNPRGMD	03406 1820-4757	SE555T	02910 1826-0400
NE592K	02037 1826-1333	PAL16R6-2CJ UNPRGMD	04092 1820-3290	SE556N	02910 1826-1394
NE592N	02910 1826-0194	PAL16R6A-2CJ UNPRGMD	04092 1820-2680	SFC2308UC	10881 1826-1144
NEL-D32-46-2	00039 1813-0553	PAL16R6A-2CN UNPRGMD	04092 1820-3599	SG1502N	03793 1826-0258
NSC858N-4I	03406 1820-4886	PAL16R6A-WCN UNPRGMD	04092 1820-5482	SG1524J	03793 1826-0872
OP-01CJ	02180 1826-0440	PAL16R6ACN UNPRGMD	04092 1820-5162	SG1532J	03793 1826-0728
OP-02CJ	02180 1826-1058	PAL16R6AVC UNPRGMD	03406 1820-5392	SG323K SELECTED	03793 1826-0931
OP-02CJ (SEL'D)	02180 1826-0561	PAL16R6B-4CNL UNPRGMD	04092 1820-5534	SG342M SELECTED	03793 1826-0680
OP-02CZ	02180 1826-1349	PAL16R6BCJ UNPRGMD	04092 1820-4493	SG3501AJ	03793 1826-0061
OP-04EY	02180 1826-0974	PAL16R6BNC UNPRGMD	03406 1820-4758	SG3503Y	03793 1826-0544
OP-05CJ	02180 1826-0229	PAL16R8A-2CJ UNPRGMD	04092 1820-2575	SG3524 SELECTED	03793 1826-0637
OP-05CZ	02180 1826-1230	PAL16R8A-2CN UNPRGMD	04092 1820-3602	SG3524BN	03793 1826-1352
OP-05EJ	02180 1826-0266	PAL16R8ACN UNPRGMD	04092 1820-4639	SG3524J	03793 1826-0428
OP-07CJ SELECTED	02180 1826-0471	PAL16R8BB-4CNS UNPRGMD	04092 1820-5243	SG3524W SELECTED	03793 1826-0815
OP-07CP	02180 1826-0635	PAL16R8BCJ UNPRGMD	04092 1820-4494	SG3524W	03793 1826-0956
OP-07CS8	10858 1826-1635	PAL16R8BNC UNPRGMD	03406 1820-4756	SG3525AJ	03793 1826-0905
OP-07CZ	02180 1826-1048	PAL16R8NC UNPRGMD	03406 1820-5163	SG3526J	03793 1826-1040
OP-07EJ	02180 1826-0845	PAL20L10ACJS UNPRGMD	04092 1820-4566	SG3526N	03793 1826-1448
OP-07EY	02180 1826-0641	PAL20L10ACNS UNPRGMD	04092 1820-5207	SG3527AJ	03793 1826-1243
OP-07EZ	02180 1826-1149	PAL20L10CJ UNPRGMD	04092 1820-3325	SG353K-12	03793 1826-1014
OP-08FP	02180 1826-0986	PAL20L10CNS UNPRGMD	04092 1820-3388	SG3547N	03793 1826-0867
OP-08GJ (SELECTED)	02180 1826-0553	PAL20L10ACNS UNPRGMD	04092 1820-3615	SG3549M	03793 1826-0959
OP-11EY	02180 1826-0616	PAL20L10BCNS UNPRGMD	04092 1820-4970	SG3627	03793 1826-2590
OP-11FY	02180 1826-0628	PAL20L4RACJ UNPRGMD	04092 1820-4351	SG3731J	03793 1826-1038
OP-14CJ	02180 1826-0542	PAL20L4RAC UNPRGMD	04092 1820-3613	SG7812AC-K	03793 1826-1082
OP-14CZ	02180 1826-1061	PAL20R6ACJ UNPRGMD	04092 1820-3553	SG7912AC-K	03793 1826-1083
OP-14EZ	02180 1826-1298	PAL20R6ACNS UNPRGMD	04092 1820-4110	SI7135CJ	02883 1826-1515
OP-15EJ	02180 1826-1165	PAL20R8ACJ UNPRGMD	04092 1820-3324	SI7661CJ	02883 1826-1583
OP-15EZ	02180 1826-1185	PAL20R8ACNL UNPRGMD	04092 1820-5079	SI7661CJ (SELECTED)	02883 1826-1520
OP-15FJ	02180 1826-1197	PAL20R8ACNS UNPRGMD	04092 1820-3614	SL441A	01590 1826-0676
OP-15GJ	02180 1826-0937	PAL20R8BCNS UNPRGMD	04092 1820-4751	SL441C	01590 1826-1555
OP-15GZ	02180 1826-0828	PAL20X8CJ UNPRGMD	04092 1820-3323	SL952	01590 1826-1754
OP-16E	02180 1826-178	PAL20X8CNS UNPRGMD	04092 1820-3601	SM10105-1	05436 1826-1517
OP-16E	02180 1826-0576	PAL22V10L-25PC UNPRGMD	11345 1820-5505	SMC20	11452 1820-3864
OP-16EZ	02180 1826-1192	PALC16L8L-25PC UNPRGMD	01698 1820-5533	SMP-10EY	02881 1826-1145
OP-16FJ	02180 1826-0601	PALC16L8L-25PC UNPRGMD	11345 1820-5013	SMP-10FY	02881 1826-1140
OP-16FZ	02180 1826-1367	PALC22V10-35PC UNPRGMD	11345 1820-5012	SMP-11EY	02180 1826-1244
OP-16GG	02180 1826-1125	PBD3520	05917 1820-2446	SMP-11G	02180 1826-1029
OP-16GZ	02180 1826-1047	PCF8576T	02910 1820-5285	SMP-11Y	02180 1826-0988
OP-17EZ	02180 1826-1578	PCM53JG-V	05436 1826-1274	SMP-81FY	02180 1826-0727
OP-17FJ	02180 1826-0516	PGA102AG	05436 1826-1554	SN15830N	01698 1820-0086
OP-17FJ	02180 1826-0795	PIC1C600	00046 1813-0115	SN15845N	01698 1820-0308
OP-17FZ	02180 1826-1097	PIC1C602	00046 1813-0083	SN15862N	01698 1820-0310
OP-215EZ	02180 1826-1426	PIC1C611	00046 1813-0084	SN15840J	01698 1820-1093
OP-215FZ	02180 1826-1192	PIC1C625	00046 1813-0109	SN5400N	01698 1820-0448
OP-220GZ	02180 1826-1151	PIC1C626	00046 1813-0110	SN5402J	01698 1820-1101
OP-227EY	02180 1826-1631	PIC1C645	02598 1813-0114	SN5402N	01698 1820-0445
OP-227GY	02180 1826-1150	PIC1C646	00046 1813-0082	SN5404J	01698 1820-1097
OP-27EN8	10858 1826-1511	PIC1C647	02598 1826-1080	SN5404N	01698 1820-1022
OP-27EZ	07050 1826-1135	PIC1D	02598 1826-2736	SN5408J	01698 1820-1099
OP-27FZ	02180 1826-0932	PICD-01EP	02180 1826-1189	SN5408N	01698 1820-1379
OP-27GJ	02180 1826-1007	PICD-01EY	02180 1826-1217	SN5410J	01698 1820-1094
OP-27GZ	02180 1826-1049	PLS1100F UNPRGMD	02910 1820-2247	SN5410N	01698 1820-0447
OP-37EJ	02180 1826-1084	PLS1100N UNPRGMD	02910 1820-2457	SN54112J	01698 1820-1092
OP-37EZ	02180 1826-1568	PLS1103N UNPRGMD	02910 1820-2494	SN5413J	01698 1820-1091
OP-37FJ	02180 1826-0977	PLS1105F UNPRGMD	02910 1820-2820	SN54160N	01698 1820-1024
OP-37FZ	02180 1826-0987	PLS1105N UNPRGMD	02910 1820-2938	SN54192N	01698 1820-1378
OP-37GP	02180 1826-1098	PLS1151N UNPRGMD	02910 1820-3531	SN54196J	01698 1820-1096
OP-37GZ	02180 1826-0982	PLS1153AN UNPRGMD	02910 1820-2864	SN54197J	01698 1820-2043
OP-37GZ	02180 1826-1006	PLS1155N UNPRGMD	02910 1820-3995	SN54199J	01698 1820-1083
OP-421HY	02180 1826-1093	PLS1159N UNPRGMD	02910 1820-3779	SN5423J	01698 1820-1878
OP-50FY	02180 1826-1459	PLS1168AN UNPRGMD	02910 1820-5029	SN5430J	01698 1820-1070
OPA111AM	05436 1826-1650	PLS1179N UNPRGMD	02910 1820-5216	SN5432N	01698 1820-1381
OPA111BM	05436 1813-0437	PLS1179N UNPRGMD	00575 1813-0094	SN5442AJ	01698 1820-2082
OPA606KP	05436 1826-1654	PL1472B-01	00575 1813-0095	SN54474J	01698 1820-1095
OPA606LM	05436 1826-1744	PL1482B-01	00575 1813-0095	SN5474N	01698 1820-0446
P2401	03811 1820-1062	PWR-606A	05436 1813-0517	SN5490AN	01698 1820-0992
P3205	03811 1820-2035	R5310-25	11668 1826-1605	SN5493N	01698 1820-1023
P3208A	03811 1820-1087	R5311-18			

JDEC	Mfr.	HP P/N	SN54LS00J	01698 1820-1879	SN74298N	01698 1820-1100	SN74ALS1623N	01698 1820-3236
SN54LS02J			SN54LS02J	01698 1820-1799	SN7430N	01698 1820-0070	SN74ALS162BN	01698 1820-2778
SN54LS08J			SN54LS08J	01698 1820-2248	SN7432N	01698 1820-0661	SN74ALS163BD	01698 1820-4929
SN54LS10J			SN54LS10J	01698 1820-2249	SN7433N	01698 1820-1124	SN74ALS163BN	01698 1820-2779
SN54LS11J			SN54LS11J	01698 1820-2261	SN74351N	01698 1820-1462	SN74ALS164D	01698 1820-4265
SN54LS138J			SN54LS138J	01698 1820-2529	SN7435AN	01698 1820-2007	SN74ALS164FN	01698 1820-3875
SN54LS174J			SN54LS174J	01698 1820-2064	SN74376N	01698 1820-3152	SN74ALS164N	01698 1820-4313
SN54LS196J			SN54LS196J	01698 1820-2251	SN7437N	01698 1820-0539	SN74ALS165D	01698 1820-4266
SN54LS221J			SN54LS221J	01698 1820-2042	SN7438D	01698 1820-5284	SN74ALS165FN	01698 1820-3813
SN54LS27J			SN54LS27J	01698 1820-1880	SN7438J	01698 1820-2351	SN74ALS166D	01698 1820-4962
SN54LS30J			SN54LS30J	01698 1820-2250	SN7438N	01698 1820-0621	SN74ALS166N	01698 1820-3982
SN54LS669J			SN54LS669J	01698 1820-2559	SN74390N	01698 1820-1463	SN74ALS168AN	01698 1820-3762
SN54LS74AJ			SN54LS74AJ	01698 1820-1798	SN74393N	01698 1820-1464	SN74ALS168BD	01698 1820-4268
SN54S00J			SN54S00J	01698 1820-1253	SN7440N	01698 1820-0071	SN74ALS168BFN	01698 1820-3818
SN54S30J			SN54S30J	01698 1820-2252	SN7442AN	01698 1820-0214	SN74ALS169BD	01698 1820-4269
SN54S40J			SN54S40J	01698 1820-2253	SN7445N	01698 1820-0468	SN74ALS169BFN	01698 1820-3819
SN55453BJG			SN55453BJG	01698 1820-2236	SN7446AN	01698 1820-1037	SN74ALS169BN	01698 1820-3353
SN55461JG			SN55461JG	01698 1820-2282	SN7447AN	01698 1820-0995	SN74ALS170D	01698 1820-4930
SN55462JG			SN55462JG	01698 1820-2283	SN7448N	01698 1820-1038	SN74ALS174N	01698 1820-3465
SN72170N			SN72170N	01698 1820-0398	SN74490N	01698 1820-1465	SN74ALS175D	01698 1820-4935
SN72L022L			SN72L022L	01698 1826-0301	SN7450N	01698 1820-0072	SN74ALS175FN	01698 1820-3411
SN7400N			SN7400N	01698 1820-0054	SN7451N	01698 1820-0063	SN74ALS175N	01698 1820-3466
SN7401N			SN7401N	01698 1820-0327	SN7453N	01698 1820-0084	SN74ALS1804N	01698 1820-4167
SN7402N			SN7402N	01698 1820-0328	SN7454N	01698 1820-0074	SN74ALS1805AN	01698 1820-5183
SN7403N			SN7403N	01698 1820-0269	SN7460N	01698 1820-0085	SN74ALS190D	01698 1820-4270
SN7404N			SN7404N	01698 1820-0174	SN7470N	01698 1820-0065	SN74ALS190FN	01698 1820-3873
SN7405N			SN7405N	01698 1820-0175	SN7472N	01698 1820-0304	SN74ALS190N	01698 1820-3763
SN7406D			SN7406D	01698 1820-5026	SN7473N	01698 1820-0075	SN74ALS191D	01698 1820-4271
SN7406N			SN7406N	01698 1820-0471	SN7474N	01698 1820-0077	SN74ALS191FN	01698 1820-3906
SN7406T			SN7406T	01698 1820-3447	SN7475N	01698 1820-0301	SN74ALS191N	01698 1820-3505
SN7407J			SN7407J	01698 1820-2593	SN7476N	01698 1820-0076	SN74ALS192N	01698 1820-3598
SN7407N			SN7407N	01698 1820-0668	SN7480N	01698 1820-0362	SN74ALS193N	01698 1820-3375
SN7408N			SN7408N	01698 1820-0511	SN7482N	01698 1820-0363	SN74ALS20AD	01698 1820-5075
SN7409N			SN7409N	01698 1820-0513	SN7483AN	01698 1820-0305	SN74ALS20AN	01698 1820-2774
SN74100N			SN74100N	01698 1820-0425	SN7485N	01698 1820-0921	SN74ALS21	01698 1820-2888
SN74104N			SN74104N	01698 1820-1002	SN7486N	01698 1820-0282	SN74ALS22AN	01698 1820-3758
SN74107N			SN74107N	01698 1820-0281	SN7490AN	01698 1820-0055	SN74ALS232AN	01698 1820-4670
SN74109N			SN74109N	01698 1820-1116	SN7491AN	01698 1820-0364	SN74ALS236N	01698 1820-5228
SN74110N			SN74110N	01698 1820-0068	SN7492AN	01698 1820-0056	SN74ALS240A-1N	01698 1820-3782
SN74111N			SN74111N	01698 1820-1229	SN7493AN	01698 1820-0099	SN74ALS240ADW	01698 1820-4787
SN74116N			SN74116N	01698 1820-1793	SN7494N	01698 1820-0366	SN74ALS240AFN	01698 1820-3994
SN74120N			SN74120N	01698 1820-2164	SN7495AN	01698 1820-0367	SN74ALS240AN	01698 1820-2951
SN74121N			SN74121N	01698 1820-0261	SN7496N	01698 1820-0368	SN74ALS241A-1N	01698 1820-4162
SN74122N			SN74122N	01698 1820-0704	SN7497N	01698 1820-074	SN74ALS241ADW	01698 1820-5233
SN74123N			SN74123N	01698 1820-0579	SN74ALSOAD	01698 1820-4291	SN74ALS241AFN	01698 1820-3412
SN74126N			SN74126N	01698 1820-1214	SN74ALSOAN	01698 1820-2656	SN74ALS241AN	01698 1820-4350
SN74128N			SN74128N	01698 1820-1074	SN74ALSO1N	01698 1820-3335	SN74ALS243AD	01698 1820-5179
SN74129N			SN74129N	01698 1820-0907	SN74ALSO2D	01698 1820-4245	SN74ALS243AN	01698 1820-3994
SN74132N			SN74132N	01698 1820-1056	SN74ALSO2N	01698 1820-2739	SN74ALS244A-1N	01698 1820-4233
SN74136N			SN74136N	01698 1820-1250	SN74ALSO3BD	01698 1820-5180	SN74ALS244ADW	01698 1820-4788
SN74139N			SN74139N	01698 1820-0537	SN74ALSO3BN	01698 1820-3270	SN74ALS244AFN	01698 1820-4273
SN74141N			SN74141N	01698 1820-0707	SN74ALSO4BD	01698 1820-4249	SN74ALS244AN	01698 1820-3145
SN74143N			SN74143N	01698 1820-1271	SN74ALSO4BN	01698 1820-2634	SN74ALS244AN	02037 1820-3607
SN74145N			SN74145N	01698 1820-1171	SN74ALSO5AD	01698 1820-4250	SN74ALS245A-1N	01698 1820-3714
SN74147N			SN74147N	01698 1820-0491	SN74ALSO5AFN	01698 1820-3904	SN74ALS245ADW	01698 1820-4790
SN74148N			SN74148N	01698 1820-1082	SN74ALSO5AN	01698 1820-3376	SN74ALS245AFN	01698 1820-4274
SN74149N			SN74149N	01698 1820-1473	SN74ALSO8D	01698 1820-4243	SN74ALS245AN	01698 1820-3121
SN74150N			SN74150N	01698 1820-0640	SN74ALSO8D	01698 1820-2635	SN74ALS257D	02037 1820-2913
SN74151AN			SN74151AN	01698 1820-0622	SN74ALSO9N	01698 1820-3394	SN74ALS251FN	01698 1820-3811
SN74153N			SN74153N	01698 1820-0620	SN74ALS1000AN	01698 1820-3708	SN74ALS251LN	01698 1820-3764
SN74155N			SN74155N	01698 1820-0738	SN74ALS1002AN	01698 1820-3105	SN74ALS253D	01698 1820-4260
SN74156N			SN74156N	01698 1820-1046	SN74ALS1003AN	01698 1820-4349	SN74ALS253FN	01698 1820-3812
SN74157N			SN74157N	01698 1820-0762	SN74ALS1004FN	01698 1820-3797	SN74ALS253N	01698 1820-3439
SN74159N			SN74159N	01698 1820-1257	SN74ALS1004N	01698 1820-3633	SN74ALS257D	01698 1820-4261
SN74160N			SN74160N	01698 1820-0899	SN74ALS1005J	01698 1820-3756	SN74ALS257FN	01698 1820-3874
SN74161N			SN74161N	01698 1820-0716	SN74ALS1005N	01698 1820-3562	SN74ALS257N	01698 1820-3438
SN74162N			SN74162N	01698 1820-1185	SN74ALS1008AN	01698 1820-3480	SN74ALS258N	01698 1820-3765
SN74163N			SN74163N	01698 1820-0713	SN74ALS1010ANF	01698 1820-3799	SN74ALS259D	01698 1820-4263
SN74164N			SN74164N	01698 1820-1064	SN74ALS1010AN	01698 1820-3382	SN74ALS259FN	01698 1820-3439
SN74165N			SN74165N	01698 1820-1042	SN74ALS1011ANF	01698 1820-3804	SN74ALS257D	01698 1820-4075
SN74166N			SN74166N	01698 1820-1107	SN74ALS1020AN	01698 1820-3800	SN74ALS273FN	01698 1820-4277
SN74167N			SN74167N	01698 1820-0909	SN74ALS1032AN	01698 1820-3401	SN74ALS273N	01698 1820-3871
SN74168N			SN74168N	01698 1820-2586	SN74ALS1034N	01698 1820-3343	SN74ALS27D	01698 1820-4246
SN74169N			SN74169N	01698 1820-0577	SN74ALS1035N	01698 1820-3437	SN74ALS27FN	01698 1820-3802
SN74173N			SN74173N	01698 1820-1192	SN74ALS109AD	01698 1820-4288	SN74ALS27N	01698 1820-2881
SN74174N			SN74174N	01698 1820-0788	SN74ALS109AN	01698 1820-2758	SN74ALS28AN	01698 1820-3479
SN74175N			SN74175N	01698 1820-0839	SN74ALS10AD	01698 1820-4252	SN74ALS29827NT	01698 1820-5185
SN74178N			SN74178N	01698 1820-1258	SN74ALS10AN	01698 1820-2775	SN74ALS299FN	01698 1820-3814
SN74179N			SN74179N	01698 1820-1141	SN74ALS11AN	01698 1820-2889	SN74ALS33AN	01698 1820-3318
SN74179T			SN74179T	01698 1820-0618	SN74ALS112AFN	01698 1820-3808	SN74ALS30AD	01698 1820-4353
SN74180N			SN74180N	01698 1820-0435	SN74ALS112AN	01698 1820-2772	SN74ALS30AN	01698 1820-2773
SN74181N			SN74181N	01698 1820-0606	SN74ALS113AN	01698 1820-3761	SN74ALS323DW	01698 1820-5312
SN74182N			SN74182N	01698 1820-0611	SN74ALS114AN	01698 1820-5145	SN74ALS32D	01698 1820-4247
SN74184N			SN74184N	01698 1820-1267	SN74ALS11AD	01698 1820-4244	SN74ALS32N	01698 1820-2657
SN74185AN			SN74185AN	01698 1820-1141	SN74ALS11AN	01698 1820-2889	SN74ALS33AN	01698 1820-3759
SN74190N			SN74190N	01698 1820-0734	SN74ALS1240FN	01698 1820-3805	SN74ALS352N	01698 1820-4642
SN74191N			SN74191N	01698 1820-0545	SN74ALS1244AN	01698 1820-3239	SN74ALS353N	01698 1820-4592
SN74192N			SN74192N	01698 1820-0546	SN74ALS1244FN	01698 1820-3806	SN74ALS35AN	01698 1820-5035
SN74194N			SN74194N	01698 1820-0743	SN74ALS1244AN	01698 1820-3277	SN74ALS365N	01698 1820-4314
SN74195N			SN74195N	01698 1820-1027	SN74ALS1245A-1N	01698 1820-3238	SN74ALS367N	01698 1820-4315
SN74196N			SN74196N	01698 1820-0751	SN74ALS1245AFN	01698 1820-3870	SN74ALS368N	01698 1820-4316
SN74197N			SN74197N	01698 1820-0765	SN74ALS1245AN	01698 1820-3287	SN74ALS373DW	01698 1820-5241
SN74198N			SN74198N	01698 1820-1032	SN74ALS12AN	01698 1820-3468	SN74ALS373FN	01698 1820-3815
SN74199N			SN74199N	01698 1820-0726	SN74ALS131N	01698 1820-4655	SN74ALS374DW	01698 1820-5002
SN74221N			SN74221N	01698 1820-1260	SN74ALS133N	01698 1820-5234	SN74ALS374N	01698 1820-3294
SN74222J			SN74222J	01698 1820-2304	SN74ALS137N	01698 1820-3372	SN74ALS377N	02037 1820-3690
SN74222N			SN74222N	01698 1820-1256	SN74ALS138D	01698 1820-3258	SN74ALS37AN	01698 1820-3402
SN74233N			SN74233N	01698 1820-0538	SN74ALS138FN	01698 1820-309	SN74ALS38AD	01698 1820-4931
SN74247N			SN74247N	01698 1820-1580	SN74ALS138N	01698 1820-3100	SN74ALS38AN	01698 1820-3349
SN7425N			SN7425N	01698 182				

SN74ALS564DW	01698	1820-5132	SN74AS230N	01698	1820-3923	SN74H53N	01698	1820-0380
SN74ALS564AN	01698	1820-4720	SN74AS231N	01698	1820-3922	SN74H54N	01698	1820-0381
SN74ALS569ADW	01698	1820-5232	SN74AS240N	01698	1820-3543	SN74H55N	01698	1820-0382
SN74ALS569AN	01698	1820-3217	SN74AS241N	01698	1820-3745	SN74H60N	01698	1820-0383
SN74ALS573BD	01698	1820-4264	SN74AS242N	01698	1820-4171	SN74H61N	01698	1820-0384
SN74ALS573BN	01698	1820-3876	SN74AS243D	01698	1820-4776	SN74H62N	01698	1820-0385
SN74ALS574ADW	01698	1820-2724	SN74AS243N	01698	1820-3716	SN74H71N	01698	1820-0386
SN74ALS574AFN	01698	1820-4279	SN74AS244N	01698	1820-5325	SN74H72N	01698	1820-0387
SN74ALS574AN	01698	1820-3872	SN74AS245D	01698	1820-3541	SN74H73N	01698	1820-0391
SN74ALS575ANT	01698	1820-2757	SN74AS245W	01698	1820-5334	SN74H74N	01698	1820-0512
SN74ALS576N	01698	1820-2882	SN74AS250NT	01698	1820-4654	SN74H87N	01698	1820-0740
SN74ALS577NT	01698	1820-4076	SN74AS253D	01698	1820-5314	SN74HC00D	01698	1820-4692
SN74ALS580AN	01698	1820-3003	SN74AS253N	01698	1820-3747	SN74HC04D	01698	1820-5220
SN74ALS620AN	01698	1820-4170	SN74AS257D	01698	1820-4285	SN74HC05N	01698	1820-4053
SN74ALS621A-1N	01698	1820-5187	SN74AS257FN	01698	1820-3890	SN74HC08D	01698	1820-4693
SN74ALS622A-1N	01698	1820-5188	SN74AS257N	01698	1820-3748	SN74HC148N	01698	1820-4675
SN74ALS623AN	01698	1820-3905	SN74AS258N	01698	1820-3749	SN74HC166N	01698	1820-4149
SN74ALS632AJD	01698	1820-3559	SN74AS27D	01698	1820-4964	SN74HC190N	01698	1820-4054
SN74ALS639N	02037	1820-3308	SN74AS27N	01698	1820-3606	SN74HC21N	01698	1820-3793
SN74ALS640A-1N	01698	1820-3198	SN74AS28D0	01698	1820-5313	SN74HC258N	01698	1820-4676
SN74ALS640AN	01698	1820-3362	SN74AS280N	01698	1820-4026	SN74HC377N	01698	1820-4208
SN74ALS641AN	01698	1820-3380	SN74AS286N	01698	1820-4375	SN74HC490N	01698	1820-4677
SN74ALS642AN	01698	1820-3668	SN74AS298N	01698	1820-4678	SN74HC522NT	01698	1820-5023
SN74ALS645A-1N	01698	1820-3497	SN74AS299N	01698	1820-4444	SN74HC682N	01698	1820-4179
SN74ALS645AN	01698	1820-3181	SN74AS310N	01698	1820-3734	SN74HC7001N	01698	1820-4534
SN74ALS646DW	01698	1820-5118	SN74AS32D	01698	1820-4283	SN74HC805N	01698	1820-4719
SN74ALS646NT	01698	1820-4391	SN74AS32N	01698	1820-3590	SN74HC7240DW	01698	1820-4737
SN74ALS648NT	01698	1820-5025	SN74AS353N	01698	1820-3750	SN74HC7573N	01698	1820-4150
SN74ALS652NT	01698	1820-4593	SN74AS373D	01698	1820-5316	SN74HC7574DW	01698	1820-5077
SN74ALS653NT	01698	1820-4694	SN74AS373N	01698	1820-3542	SN74HC7574N	01698	1820-4152
SN74ALS654-1NT	01698	1820-4126	SN74AS574DW	01698	1820-5317	SN74HC7646NT	01698	1820-4588
SN74ALS677NT	01698	1820-4649	SN74AS574FN	01698	1820-3824	SN74HC7652NT	01698	1820-4607
SN74ALS678NT	01698	1820-4497	SN74AS574N	01698	1820-3695	SN74L121N	01698	1820-1270
SN74ALS679N	01698	1820-4127	SN74AS533N	01698	1820-3563	SN74L122N	01698	1820-0913
SN74ALS680N	01698	1820-3835	SN74AS534N	01698	1820-3751	SN74L123N	01698	1820-1247
SN74ALS688DW	01698	1820-5259	SN74AS573DW	01698	1820-5133	SN74L153N	01698	1820-1163
SN74ALS688N	01698	1820-3106	SN74AS573N	01698	1820-3881	SN74L154N	01698	1820-1949
SN74ALS74TN	01698	1820-5015	SN74AS574DW	01698	1820-4936	SN74L157N	01698	1820-1218
SN74ALS74AD	01698	1820-4275	SN74AS574FN	01698	1820-3912	SN74L157N	01698	1820-1269
SN74ALS74AFN	01698	1820-3807	SN74AS575N	01698	1820-4318	SN74L164N	01698	1820-0903
SN74ALS74AN	01698	1820-2488	SN74AS575N	01698	1820-4025	SN74L192N	01698	1820-0911
SN74ALS804FN	01698	1820-3798	SN74AS576N	01698	1820-4169	SN74L193N	01698	1820-0912
SN74ALS804N	01698	1820-3560	SN74AS580N	01698	1820-4077	SN74L42N	01698	1820-0777
SN74ALS805FN	01698	1820-3801	SN74AS623N	01698	1820-3882	SN74L46N	01698	1820-1142
SN74ALS805N	01698	1820-3718	SN74AS639N	01698	1820-4211	SN74L47N	01698	1820-1233
SN74ALS808FN	01698	1820-3803	SN74AS640N	01698	1820-3971	SN74L50N	01698	1820-1731
SN74ALS808N	01698	1820-3392	SN74AS641N	01698	1820-4129	SN74L57N	01698	1820-0876
SN74ALS832FN	01698	1820-3869	SN74AS645N	01698	1820-3843	SN74L85N	01698	1820-1268
SN74ALS832N	01698	1820-3467	SN74AS646DW	01698	1820-5323	SN74L93N	01698	1820-0443
SN74ALS841NT	01698	1820-4535	SN74AS646NT	01698	1820-4648	SN74L95N	01698	1820-0497
SN74ALS843NT	01698	1820-4716	SN74AS651NT	01698	1820-4650	SN74L98N	01698	1820-0656
SN74ALS845NT	01698	1820-5148	SN74AS652NT	01698	1820-4097	SN74LS00J	01698	1820-2583
SN74ALS867NT	01698	1820-5169	SN74AS74D	01698	1820-4289	SN74LS00N	01698	1820-1197
SN74ALS86D	01698	1820-4248	SN74AS74FN	01698	1820-3820	SN74LS07N	01698	1820-1891
SN74ALS86FN	01698	1820-3413	SN74AS74N	01698	1820-3493	SN74LS08J	01698	1820-2581
SN74ALS86N	01698	1820-3973	SN74AS756N	01698	1820-4708	SN74LS02N	01698	1820-1144
SN74ALS873NT	01698	1820-3237	SN74AS762N	01698	1820-4631	SN74LS03N	01698	1820-1198
SN74ALS874EDW	01698	1820-5310	SN74AS804AN	01698	1820-3442	SN74LS04J	01698	1820-2582
SN74ALS874NT	01698	1820-3143	SN74AS804BDW	01698	1820-4961	SN74LS04N	01698	1820-1199
SN74ALS876NT	01698	1820-3240	SN74AS804FBN	01698	1820-3891	SN74LS05N	01698	1820-1200
SN74ALS878NT	01698	1820-4657	SN74AS804BN	01698	1820-2557	SN74LS07N	01698	1820-1348
SN74ALS880NT	01698	1820-3381	SN74AS805AFN	01698	1820-3892	SN74LS08J	01698	1820-2305
SN74AS00D	01698	1820-4280	SN74AS805AN	01698	1820-3383	SN74LS08N	01698	1820-1201
SN74AS00N	01698	1820-3591	SN74AS805DW	01698	1820-5321	SN74LS09N	01698	1820-1246
SN74AS02D	01698	1820-4282	SN74AS808AN	01698	1820-3893	SN74LS107AN	01698	1820-1469
SN74AS02N	01698	1820-3729	SN74AS808AN	01698	1820-3443	SN74LS109AN	01698	1820-1282
SN74AS04N	01698	1820-3608	SN74AS808BDW	01698	1820-5020	SN74LS10N	01698	1820-1202
SN74AS08D	01698	1820-4281	SN74AS808N	01698	1820-2558	SN74LS112AN	01698	1820-1212
SN74AS08N	01698	1820-3730	SN74AS821NT	01698	1820-4450	SN74LS113AN	01698	1820-1213
SN74AS100AD	01698	1820-5070	SN74AS822NT	01698	1820-4653	SN74LS113N	01698	1820-1821
SN74AS100AN	01698	1820-4142	SN74AS823NT	01698	1820-4652	SN74LS11N	01698	1820-1203
SN74AS100AD	01698	1820-5038	SN74AS825NT	01698	1820-4715	SN74LS122N	01698	1820-1422
SN74AS100AN	01698	1820-4963	SN74AS826NT	01698	1820-4651	SN74LS123D	01698	1820-4256
SN74AS100BN	01698	1820-3920	SN74AS832AN	01698	1820-3894	SN74LS123F	01698	1820-3901
SN74AS1032AN	01698	1820-3757	SN74AS832AN	01698	1820-3384	SN74LS123J	01698	1820-2305
SN74AS1034N	01698	1820-4591	SN74AS832DW	01698	1820-5320	SN74LS123N	01698	1820-1423
SN74AS1036N	01698	1820-4207	SN74AS841NT	01698	1820-4109	SN74LS123N	01698	1820-3954
SN74AS109N	01698	1820-3735	SN74AS842NT	01698	1820-4033	SN74LS124N	01698	1820-1424
SN74AS110D	01698	1820-4763	SN74AS843NT	01698	1820-4579	SN74LS125AD	01698	1820-4786
SN74AS110N	01698	1820-3731	SN74AS8454NT	01698	1820-4498	SN74LS125AN	01698	1820-1568
SN74AS112D	01698	1820-4290	SN74AS851N	01698	1820-4168	SN74LS126AD	01698	1820-5324
SN74AS112FN	01698	1820-3821	SN74AS866N	01698	1820-4594	SN74LS126AN	01698	1820-1645
SN74AS112N	01698	1820-5387	SN74AS867NT	01698	1820-3634	SN74LS121N	01698	1820-1414
SN74AS111N	01698	1820-3732	SN74AS869NT	01698	1820-4445	SN74LS132N	01698	1820-1425
SN74AS113D	01698	1820-4284	SN74AS86N	01698	1820-3884	SN74LS132N	01698	1820-2237
SN74AS118D	01698	1820-3895	SN74AS882NT	01698	1820-3776	SN74LS145N	01698	1820-1426
SN74AS118FN	01698	1820-3895	SN74AS885NT	01698	1820-2899	SN74LS147N	01698	1820-2200
SN74AS118N	01698	1820-3741	SN74H00N	01698	1820-3770	SN74LS148D	01698	1820-5112
SN74AS116N	01698	1820-3741	SN74H01N	01698	1820-0605	SN74LS151N	01698	1820-4251
SN74AS1162N	01698	1820-4937	SN74H04N	01698	1820-0424	SN74LS151W	01698	1820-3900
SN74AS1163D	01698	1820-3742	SN74H05N	01698	1820-0613	SN74LS151W	01698	1820-1416
SN74AS1163N	01698	1820-3742	SN74H101N	01698	1820-0739	SN74LS151N	01698	1820-1217
SN74AS1168D	01698	1820-3822	SN74H102N	01698	1820-0469	SN74LS153N	01698	1820-1244
SN74AS1168N	01698	1820-3841	SN74H103N	01698	1820-0544	SN74LS155AN	01698	1820-1245
SN74AS1169D	01698	1820-4288	SN74H106N	01698	1820-0715	SN74LS156N	01698	1820-1427
SN74AS1169N	01698	1820-3823	SN74H108N	01698	1820-0631	SN74LS157N	01698	

JDEC

Mfr. HP P/N

SN74LS166AD	01698 1820-5313	SN74LS42N	01698 1820-1118	SN74S174N	01698 1820-1076
SN74LS166AN	01698 1820-1922	SN74LS45N	01698 1820-3650	SN74S175N	01698 1820-1191
SN74LS169AN	01698 1820-2460	SN74LS49N	01698 1820-2759	SN74S181J	01698 1820-1974
SN74LS174N	01698 1820-1196	SN74LS467N	01698 1820-3621	SN74S181N	01698 1820-0999
SN74LS174N	01698 1820-1914	SN74LS47N	01698 1820-1602	SN74S182N	01698 1820-1305
SN74LS174N	01698 1820-3694	SN74LS48N	01698 1820-1604	SN74S194N	01698 1820-1304
SN74LS175N	01698 1820-1195	SN74LS49N	01698 1820-2078	SN74S195N	01698 1820-1303
SN74LS181N	01698 1820-1280	SN74LS491ANS	01698 1820-5184	SN74S196N	01698 1820-1869
SN74LS182N	02037 1820-2563	SN74LS498JS	01698 1820-3303	SN74S197N	01698 1820-1868
SN74LS190N	01698 1820-1279	SN74LS51N	01698 1820-1210	SN74S20N	01698 1820-0688
SN74LS191N	01698 1820-1278	SN74LS51N	01698 1820-3496	SN74S225N	01698 1820-2621
SN74LS192N	01698 1820-1277	SN74LS53N	04092 1820-2719	SN74S22N	01698 1820-0689
SN74LS193N	01698 1820-1194	SN74LS540N	01698 1820-2710	SN74S240N	01698 1820-1633
SN74LS194AD	01698 1820-4267	SN74LS541N	01698 1820-2711	SN74S241N	01698 1820-1624
SN74LS194AN	01698 1820-3902	SN74LS54N	01698 1820-1285	SN74S251N	01698 1820-1302
SN74LS194AN	01698 1820-1276	SN74LS55N	01698 1820-1284	SN74S257N	01698 1820-1301
SN74LS195AN	01698 1820-1300	SN74LS58N	01698 1820-4644	SN74S258N	01698 1820-1309
SN74LS196N	01698 1820-1251	SN74LS59N	01698 1820-3144	SN74S260N	01698 1820-1275
SN74LS197N	01698 1820-1193	SN74LS592N	01698 1820-3167	SN74S280N	01698 1820-1638
SN74LS199N	01698 1820-4187	SN74LS593N	01698 1820-3160	SN74S281N	01698 1820-1456
SN74LS200J	01698 1820-2580	SN74LS595N	01698 1820-3423	SN74S283D	01698 1820-5131
SN74LS200N	01698 1820-1204	SN74LS596N	01698 1820-3960	SN74S283N	01698 1820-1871
SN74LS21N	01698 1820-1205	SN74LS597N	01698 1820-3536	SN74S299N	01698 1820-1457
SN74LS221J	01698 1820-2346	SN74LS598N	01698 1820-4553	SN74S30J	01698 1820-1323
SN74LS221N	01698 1820-1437	SN74LS599N	01698 1820-3022	SN74S32N	01698 1820-1449
SN74LS224N	01698 1820-2939	SN74LS601N	01698 1820-3990	SN74S341N	01698 1820-2832
SN74LS224N	01698 1820-1274	SN74LS603AN	01698 1820-4489	SN74S373J	04092 1820-2185
SN74LS240N	01698 1820-1917	SN74LS604N	01698 1820-2722	SN74S373N	01698 1820-1676
SN74LS241N	01698 1820-1918	SN74LS606N	01698 1820-3161	SN74S373N	04092 1820-3830
SN74LS242N	01698 1820-2104	SN74LS612N	01698 1820-4374	SN74S374N	01698 1820-1677
SN74LS243N	01698 1820-1994	SN74LS620N	01698 1820-2723	SN74S373J	01698 1820-2666
SN74LS244N	01698 1820-2024	SN74LS621N	01698 1820-2967	SN74S374N	01698 1820-1450
SN74LS245N	01698 1820-2075	SN74LS623N	01698 1820-2672	SN74S381N	01698 1820-1458
SN74LS247N	01698 1820-1688	SN74LS624D	01698 1820-5001	SN74S383N	01698 1820-1451
SN74LS248N	01698 1820-1644	SN74LS624N	01698 1820-2622	SN74S40N	01698 1820-0690
SN74LS249N	01698 1820-1643	SN74LS625N	01698 1820-2655	SN74S51N	01698 1820-1158
SN74LS251N	01698 1820-1298	SN74LS628N	01698 1820-3241	SN74S64N	01698 1820-0691
SN74LS253N	01698 1820-1238	SN74LS629D	01698 1820-5040	SN74S65N	01698 1820-0692
SN74LS253N	01698 1820-4575	SN74LS629N	01698 1820-2369	SN74S74N	01698 1820-0693
SN74LS257BN	01698 1820-1438	SN74LS630N	01698 1820-2819	SN74S74N	01698 1820-3953
SN74LS257BN	01698 1820-2194	SN74LS640-1N	01698 1820-3317	SN74S85N	01698 1820-1321
SN74LS258BN	01698 1820-1439	SN74LS640N	01698 1820-2206	SN74S86N	01698 1820-0694
SN74LS258BN	01698 1820-1890	SN74LS642N	01698 1820-2453	SN75068P	01698 1820-1710
SN74LS259BD	01698 1820-5240	SN74LS645-1N	01698 1820-3473	SN75107AN	01698 1820-0723
SN74LS259FN	01698 1820-3903	SN74LS645N	01698 1820-2268	SN75108BN	01698 1820-1310
SN74LS259N	01698 1820-1729	SN74LS646NT	01698 1820-2675	SN75109N	01698 1820-0722
02037 1820-2799	SN74LS647NT	01698 1820-3213	SN7510L	01698 1820-0083	
SN74LS261N	01698 1820-1785	SN74LS648NT	01698 1820-3351	SN75110AN	01698 1820-1110
SN74LS266N	01698 1820-1297	SN74LS651NT	01698 1820-3002	SN75112N	01698 1820-1826
SN74LS268N	01698 1820-1417	SN74LS652NT	01698 1820-3706	SN75114N	01698 1820-2668
SN74LS268N	01698 1820-1889	SN74LS668N	01698 1820-1434	SN75115N	01698 1820-1840
SN74LS273N	01698 1820-1730	SN74LS669N	01698 1820-1435	SN75116N	01698 1820-2128
SN74LS279AN	01698 1820-1440	SN74LS673N	01698 1820-2313	SN75117P	01698 1820-2159
SN74LS279AN	01698 1820-3495	SN74LS674N	01698 1820-3669	SN75119P	01698 1820-2352
SN74LS27J	01698 1820-2579	SN74LS682N	01698 1820-2713	SN75123N	01698 1820-3539
SN74LS27N	01698 1820-1206	SN74LS684N	01698 1820-3305	SN75129N	01698 1820-3540
SN74LS280N	01698 1820-1859	SN74LS686NT	01698 1820-2610	SN75150P	01698 1820-1075
SN74LS283D	01698 1820-4262	SN74LS691N	01698 1820-2937	SN75152N	01698 1820-3379
SN74LS283FN	01698 1820-3898	SN74LS697N	01698 1820-3352	SN75153N	01698 1820-3302
SN74LS283N	01698 1820-1441	SN74LS699N	01698 1820-3771	SN75155D	01698 1820-1493
SN74LS283N	01698 1820-1273	SN74LS73AN	01698 1820-1574	SN75157P	01698 1820-3304
SN74LS290N	01698 1820-1442	SN74LS74J	01698 1820-1668	SN75159N	01698 1820-2362
SN74LS292N	01698 1820-2947	SN74LS74N	01698 1820-1112	SN75160AN	01698 1820-2485
SN74LS293N	01698 1820-1443	SN74LS75N	01698 1820-1411	SN75161AN	01698 1820-2483
SN74LS294N	01698 1820-3118	SN74LS76AN	01698 1820-2464	SN75162AN	01698 1820-2547
SN74LS295BN	01698 1820-1296	SN74LS794N	04092 1820-3868	SN75172N	01698 1820-1735
SN74LS298N	01698 1820-1444	SN74LS83AN	01698 1820-0910	SN75173N	01698 1820-4734
SN74LS30JN	01698 1820-1207	SN74LS85D	01698 1820-4255	SN75174N	01698 1820-2703
SN74LS320N	01698 1820-3460	SN74LS85F	01698 1820-3897	SN75235N	01698 1820-2831
SN74LS31N	01698 1820-1347	SN74LS85N	01698 1820-1419	SN75175N	01698 1820-4138
SN74LS320N	01698 1820-2592	SN74LS86J	01698 1820-2587	SN75176AP	01698 1820-4461
SN74LS321N	01698 1820-4262	SN74LS86N	01698 1820-2937	SN75172N	01698 1820-3333
SN74LS322AN	01698 1820-3956	SN74LS86N	01698 1820-2675	SN75361AN	01698 1820-1833
SN74LS323N	01698 1820-2201	SN74LS90N	01698 1820-1490	SN75361AP	01698 1820-1887
SN74LS324N	01698 1820-2202	SN74LS91N	01698 1820-1784	SN75363N	01698 1820-1982
SN74LS325N	01698 1820-2068	SN74LS93N	01698 1820-1478	SN75365N	01698 1820-0094
SN74LS32J	01698 1820-2585	SN74LS95B	01698 1820-1283	SN75322N	01698 1820-1673
SN74LS32N	01698 1820-1208	SN74LS96N	01698 1820-1421	SN75325N	01698 1820-0568
SN74LS32N	01698 1820-3956	SN74LS98N	01698 1820-0681	SN75327N	01698 1820-2361
SN74LS33J	01698 1820-2578	SN74S02N	01698 1820-1322	SN75361AN	01698 1820-1833
SN74LS33N	01698 1820-1272	SN74S02N	01698 1820-3840	SN75361AP	01698 1820-1887
SN74LS340N	01698 1820-2121	SN74S03N	01698 1820-0682	SN75437AN	01698 1820-3845
SN74LS342N	01698 1820-2536	SN74S04N	01698 1820-0683	SN75446P	01698 1820-3524
SN74LS353N	01698 1820-2046	SN74S05N	01698 1820-0684	SN75447P	01698 1820-2715
SN74LS354N	01698 1820-3393	SN74S08N	01698 1820-1367	SN75450BN	01698 1820-2570
SN74LS356N	01698 1820-2613	SN74S08N	01698 1820-2839	SN75456N	01698 1820-1611
SN74LS365AN	01698 1820-1641	SN74S09N	01698 1820-1448	SN75457AN	01698 1820-2181
SN74LS366AN	01698 1820-1640	SN74S10N	01698 1820-0685	SN75454P	01698 1820-3845
SN74LS367AN	01698 1820-1491	SN74S112D	01698 1820-5238	SN75454P	01698 1820-2053
SN74LS367AN	01698 1820-1892	SN74S112F	01698 1820-3913	SN75455N	01698 1820-0902
SN74LS368AN	01698 1820-1492	SN74S112N	01698 1820-0629	SN75451BP	01698 1820-2593
SN74LS373N	01698 1820-2102	SN74S113N	01698 1820-0695	SN75452BJG	01698 1820-1800
SN74LS374N	01698 1820-2611	SN74S114N	01698 1820-0696	SN75452BL	01698 1820-1669
SN74LS375N	01698 1820-1445	SN74S115N	01698 1820-0686	SN75452BP	01698 1820-0799
SN74LS377D	01698 1820-4278	SN74S124N	01698 1820-1324	SN75453B	01698 1820-1016
SN74LS377FN	01698 1820-3899	SN74S132N	01698 1820-1307	SN75454B	01698 1820-1050
SN74LS377N	01698 1820-1858	SN74S132N	01698 1820-3838	SN754561P	01698 1820-2044
SN74LS378N	01698 1820-2056	SN74S133D	01698 1820-5319	SN75463N	01698 1820-2520
SN74LS379N	01698 1820-2244	SN74S133N	01698 1820-1130	SN75468N	01698 1820-2111
SN74LS379N	01698 1820-1287	SN74S134N	01698 1820-1306	SN75469N	01698 1820-2243
SN74LS382AN	01698 1820-3770	SN74S135N	01698 1820-1639	SN75471P	01698 1820-2207
SN74LS384N	01698 1820-3506	SN74S138N	01698 1820-1240	SN75473P	01698 1820-2850
SN74LS385N	01698 1820-2720	SN74S139N	01698 1820-1072	SN75477D	01698 1820-5568
SN74LS386AN	01698 1820-2764	SN74S140N	01698 1820-0697	SN75477P	01698 1820-2110
SN74LS38J	01698 1820-2584	SN74S151N	01698 1820-1319	SN75478P	01698 1820-3959
SN74LS38N	01698 1820-1209	SN74S153N	01698 1820-0998	SN75491N	01698 1820-1230
SN74LS390D	01698 1820-5311	SN74S157N	01698 1820-1077	SN75492N	01698 1820-1231
SN74LS393D	01698 1820-4789	SN74S158N	01698 1820-1015	SN75497N	01698 1820-2186
SN74LS393N	01698 182				

Safety-Related Service Notes


Service notes from HP relating to personal safety and possible equipment damage are of vital importance to our customers. To make you more aware of these important notes, they are printed on paper with a red border, and the service note number has a "-S" suffix. In order to make you immediately aware of any potential safety problems, we are highlighting safety-related service notes here with a brief description of each problem. Also, in order to draw your attention to safety-related service notes on the service note order form at the back of *Bench Briefs*, each appropriate number is highlighted by being printed in color.

HP 8904A Multifunction Synthesizer

Product Safety Service Note 8904A-01-S describes a possible safety hazard that may exist if the grounding wire from the rear-panel line socket has not been wrapped and soldered in compliance with strict safety standards.

This condition does not create a safety hazard under normal use; however, a safety hazard can develop if the ground wire sustains heavy current for a long period of time, causing the solder connection to erode and disconnect. Should ground contact break, the chassis can no longer be guaranteed to be at ground potential. Or if the ground wire is disabled and the neutral or high lines of the power cord come in contact with the chassis through some other fault. The chassis then becomes a shock hazard.

Order safety service note 8904A-01-S using the *Bench Briefs* order form. The note explains how to check for the possible shock hazard and how to correct it.



HP 85043A System Cabinets

This racked system has had two cases of over-heated circuit breakers and their connecting wires over the past three years. The root cause of the failure in both cases was improper stripping of the insulation of the wires going to the circuit breakers and terminal block.

The fastening screw made poor contact with the wire, pushing its way through the insulation, as it was tightened-down. The resultant heat from the high resistance connection caused the insulation to melt and char.

We recommend that the connecting wires to the circuit breaker and terminal block be stripped to one centimeter and reconnected. The wires should NOT be solder tinned. If severe heat damage is observed on or near the connection, we recommend replacement of the circuit breaker and connecting wires.

This service should be performed as soon as possible. For more information please order safety service note 85043A-01-S from this issue of *Bench Briefs*.

HP 70206A System Graphics Display (used with the HP 70000 Measurement System)

A possible shock hazard may exist if resistor R1 (14.7 ohms) in the primary circuit shorts to the internal ground plane AND safety earth ground has been defeated. Note that this instrument is designed to be operated with safety earth ground intact. If R1 fails, normally the instrument line fuse will be blown, but if the safety earth ground is defeated, line potential will be on the instrument chassis.

If necessary, Hewlett-Packard will repair the HP 70206A at your site at no charge. Please order safety service note 70206A-02-S and contact your local HP Customer Service Center for more information. □

supplement to BENCH BRIEFS SERVICE NOTE INDEX

Need Any Service Notes?

They're free!

Here's the latest listing of service notes. They recommend modifications to Hewlett-Packard instruments to increase reliability, improve performance, or extend their usefulness.

Use the form at the rear of *Bench Briefs* to order, free of charge, service notes for several instruments.

If you would like to purchase large quantities of service notes covering a wide range of instruments, or if you desire a complete history of all service notes documenting all changes to your instruments, Hewlett-Packard offers a microfiche library for a one time charge. There is also a microfiche subscription service available that automatically updates the library on a quarterly schedule.

The part numbers for the service note microfiche library and subscription service are:

Library— 5951-6511
Subscription service— 5951-6517

Contact your local HP Sales Office for ordering information. □

HP 3326A TWO-CHANNEL SYNTHESIZER
3326A-5. Serial numbers 2516A01000 to 2516A01120 and 2516A01000 to 2516A01200. Intermittent phono cable/jack problems.

HP 3453A DIGITAL STIMULUS/RESPONSE UNIT
3453A-6A. All serials. Replacement procedures for the mother board within the 3453A DSRU.

HP 3456A DIGITAL VOLTMETER
3456A-22. All serials. Input circuit redesigned to improve performance.

HP 3457A MULTIMETER

3457A-8. All serials. Modification to prevent simultaneous channel closings on 44491A General Purpose Relay Card and 44492A Ten Channel Multiplexer Card.
3457A-9. Serials 2703A05068 and below. Modification to prevent turn-on failure.

HP 3552A TRANSMISSION TEST SET

3552A-16. All serials. Preferred replacement for A1 logic assembly and A5 power supply assembly.

HP 3562A DIGITAL SIGNAL ANALYZER

3562A-6. All serials. A3 ROM assembly part replacement instructions.
3562A-7. Serials 2502A01863 to 2708A02703. Prevent future failure, replace A2 U305 if the date code is 8637 to 8715.
3562A-8. Serials 2738A02920 and below. Modification to prevent excessive blowing of the line fuse when 220V selected.

HP 35650A SYSTEM MAINFRAME

3565S-1. Serials 2608A00300 and below. Main power switch replacement.
3565S-2. All serials. Recommended main power fuse for 230V operation only.
3565S-3. Serials 2608A00200 and below. Modification to prevent possible mainframe power supply damage.

HP 3764A DIGITAL TRANSMISSION ANALYZER

3764A-10A. All serials. Instructions to retrofit a printer to a 3764A.
3764A-11C. (A) serial prefixes below 2615U; (B) serial prefixes 2615U and above. Instructions to retrofit a tape cassette to a 3764A.

HP 3776A/B PCM TERMINAL TEST SET

3776A-32. All serials. Preferred replacement of A16C23 capacitor (HP P/N 0180-2811).
3776B-37. All serials. Retrofitting instructions for improved loudspeaker performance.
3776B-38. All serials. Preferred replacement of A16C23 capacitor (HP P/N 0180-2811).

HP 3779C/D PRIMARY MULTIPLEX ANALYZER

3779C-34. Serials 00685 and above. Instructions for replacing solder-in protection fuses in assemblies A16, A18, A20 and A31.
3779C-35. Serials 00607 and below. A27 assembly—preferred replacement for HP-IB PHI IC (U43).
3779D-39. Serials 00623 and above. Instructions for replacing solder-in protection fuses in assemblies A16, A18, A20 and A31.
3779D-40. Serials 00585 and below. A27 assembly—preferred replacement for HP-IB PHI IC (U43).

HP 3780A PATTERN GENERATOR/ERROR DETECTOR

3780A-32. All serials. Instructions to retrofit an RS-232-C printer port to the HP 3780A, in place of the standard BCD Printer Port.

HP 3787B DIGITAL DATA TEST SET

3787B-1. Serial numbers 2703U00160 and below, but excluding 2703U00106, 111, 113, 114, 117, 118, 120, 124, 130, 133, 137, 138, 140, 142 and 148 to 158. A modification to make the 3787B compatible with all existing DDS Interface formats.

HP 4278A 1kHz/1MHz CAPACITANCE METER

4278A-1. Serials 2740J00564 and below. (ROM Based Software: Version 2.1 and below). Installing the Option 301 Scanner Interface.

HP 4936A TRANSMISSION IMPAIRMENT MEASURING SET

4936A-9. All serials. Removal of front and rear panel assemblies from the spare parts price list.

HP 4938A NETWORK CIRCUIT ACCESS TEST SET

4938A-2. Serials 2450A00702 and below. Modification to correct a potential failure.

HP 4945A TIMS INTERFACE MODULES

4945A-7. HP 18162A HP-IB and HP 18163A RS-232. Changes to the clock circuits to improve performance.

HP 4947A TRANSMISSION IMPAIRMENT MEASURING SET

4947A-7. All serials. Preferred replacement of A16C23 capacitor (HP P/N 0180-2811).

HP 4951C PROTOCOL ANALYZER

4951C-6. Serials 2547A02689 and below. Clock oscillator may cause an apparent floppy disc drive failure.

HP 4952A PROTOCOL ANALYZER

4952A-1. All serials. Instructions on replacing rear panel studs.
4952A-2. Serials 2725 and below. Improved yoke assembly that reduces time required to do the pincushioning process.
4952A-3. Serials 2726A01194 and below. Clock oscillator may cause an apparent floppy disc drive error.

HP 5335A UNIVERSAL FREQUENCY COUNTER

5335A-20A. All serials. New test procedures "rear panel—external arm switch test" and "rear panel—internal arm slope switch test."

HP 5340A MICROWAVE FREQUENCY COUNTER

5340A-22. Series prefixes 2250A and below. Preamp retrofit kit.

HP 6030A SYSTEM DC POWER SUPPLY

6030A-7. All serials. A8 U8 ROM replacement and signature table.

HP 6031A SYSTEM DC POWER SUPPLY

6031A-9. All serials. A8 U8 ROM replacement and signature table.

HP 6032A SYSTEM DC POWER SUPPLY

6032A-8. All serials. A8 U8 ROM replacement and signature table.

HP 6033A SYSTEM DC POWER SUPPLY

6033A-6. All serials. A8 U8 ROM replacement and signature table.

HP 6038A SYSTEM DC POWER SUPPLY

6038A-4. All serials. A8 U8 ROM replacement and signature table.

HP 8170A LOGIC PATTERN GENERATOR

8170A-7. Serials 2036G01335 and below. Preferred replacement for ROM A1U4 (1818-0917).

HP 8180A/B DATA GENERATOR

8180A-3. Serials 2509G01086 and below. Modification to improve temperature profile of the 8180A.
8180A-4. Serials 2509G01055 and below. Modification to improve temperature sense circuitry.
8180A-5. Serials 2509G00906 and below. Modification to improve rectifier board 08180-66522.
8180A-6. Serials 2739G01106 and below. Substitution of replaceable boards between 8180A and 8180B.
8180B-1. Serials 2640G00100 to 2640G00111 only. Improved firmware revision.

HP 8181A DATA GENERATOR EXTENDER

8181A-3. Serials 2519G00596 and below. Modification to improve temperature profile of the 8181A.
8181A-4. Serials 2509G00586 and below. Modification to improve temperature sense circuitry.

HP 8182B DATA ANALYZER

8182B-1. Serials 2642G00100 to 2642G00111 only. Improved firmware revision.

HP 8481A POWER SENSOR

8481A-4. All serials. Curing high frequency CAL factor holes.

HP 8484A POWER SENSOR

8484A-2. All serials. Curing high frequency CAL factor holes.

HP 8553B SPECTRUM ANALYZER, RF SECTION

8553B-4. Serials 2217 through 2741. Improving input impedance.

HP 8557A SPECTRUM ANALYZER

8557A-1. Serials 2229A02805 and below. Recommended video filter potentiometer replacement.

HP 8559A SPECTRUM ANALYZER

8559A-28A. Serials 2347A04500 and below. Recommended video filter potentiometer replacement.

HP 8562A/B SPECTRUM ANALYZER

8562A-2A. All serials. ROM upgrade kit (HP P/N 08562-60062).

8562B-1A. All serials. ROM upgrade kit (HP P/N 08562-60062).

HP 8565A SPECTRUM ANALYZER

8565A-22. Serials 2608A03152 and below. Modification to prevent the +158 volt fuse from blowing.

HP 8566B SPECTRUM ANALYZER

8566B-12A. All serials and HP 8566AB retrofit kit (formerly 8566A+01K) all serials. Installation procedure for rebuilt A15 controller assembly.

8566B-19. All serials. Replacement RF attenuator retrofit kit with calibration PROM.

HP 8569B SPECTRUM ANALYZER

8569B-10. Serials 2607A02570 and below. Modification to prevent the +158 volt fuse from blowing.

HP 8590A SPECTRUM ANALYZERS

8590A-1. All serials. Replacing firmware ROMs.

8590A-2. All serials. Option H50 CATV retrofit installation instructions.

8590A-3. All serials. Making RS-232 cables for HP printers, plotters, and computers used with the HP 8590A Spectrum Analyzer.

8590A-4. All serials. Modification to create 120 and 9 kHz bandwidths for EMI Option H-51.

HP 8642B/M SYNTHESIZED SIGNAL GENERATOR

8642B-4. Serials 2737A and below. Modification to prevent -15V power supply fuse failure.

8642M-1. Serials 2737A and below. Modification to prevent -15V power supply fuse failure.

HP 8660D SYNTHESIZED SIGNAL GENERATOR

8660D-1. Serials 2733A and below. Modification to improve spurious sidebands.

HP 8671B SYNTHESIZED SIGNAL GENERATOR

8671B-1A. All serials. Modification to eliminate power-up delay.

HP 8672A/S SYNTHESIZED SIGNAL GENERATOR

8672A-18A. All serials. Modification to eliminate power-up delay.

8672S-1. All Serials. Preferred replacement for fuse A9F2.

HP 8673B/C SYNTHESIZED SIGNAL GENERATOR

8673B-10A. All serials. Modification to eliminate power-up delay.

8673C-7A. Serials 2626A and below. Millimetre-wave source modules compatibility kit.

8673C-11A. All serials. Modification to eliminate power-up delay.

HP 8673D/E SYNTHESIZED SIGNAL GENERATOR

8673D-7A. Serials 2626A and below. Millimetre-wave source module compatibility kit.

8673D-12A. All serials. Modification to eliminate power-up delay.

8673E-3. Serials 2708A and below. Recommended insulators for A3Q1 through A3Q4.

8673E-4A. All serials. Modification to eliminate power-up delay.

HP 8753A NETWORK ANALYZER

8753A-10. All serials. HP 8753A firmware rev. 1.00 anomalies and work-arounds.

HP 8904A MULTIFUNCTION SYNTHESIZER

8904A-1-S. Serials 2737A and below. Modification to prevent possible ground wire shock hazard.

HP 8970A NOISE FIGURE METER

8970A-11. All serials. Procedure to improve frequency calibration.

HP 15425A TESTHEAD

15425A-1. Serials 2606G00251 and below. Improved HP-IB control board.

HP 15466A TESTHEAD

15466A-1. Serials 2643G00105 to 2643G00114 only. Check for possible incorrect insertion of 15426A connectors.

15466A-2. Serials 2643G00119 and below. Modification to improve reset circuitry.

HP 35601A SPECTRUM ANALYZER INTERFACE

35601A-1. All serials. Modification to prevent excessive conversion loss.

HP 54111D DIGITIZING OSCILLOSCOPES

54111D-2. Serials 2710A and below. New A1 timebase board (HP P/N 54111-69516) corrects duplicate waveform display.

HP 54201A/D DIGITIZING OSCILLOSCOPES

54201A/D-4A. Serials 2716A and below. New A4 analog board assembly (HP P/N 54201-66507).

54201A/D-8. Model 54201D serials 2706A and below. Occasional failure of state QUAL/CLK test may be caused by firmware.

54201A/D-9. Model 54201A serials 2723A02064 and below; model 54201D serials 2723A01196 and below. New part numbers for firmware PROMs.

HP 64941A FLOPPY DISC DRIVE

64941A-3. Half height floppy disc drive replacement procedure.

HP 70001A MAINFRAME

70001A-5. Serials 2504A00644 and below. Loose HP-IB connector screws require replacement of the HP-MSIB cover.

HP 70205A GRAPHICS DISPLAY

70205A-2. Serials 2607A and below. CRT replacement instructions.

70205A-4. Serial number 2529A00543. Modification to prevent high-voltage failure.

HP 70206A SYSTEM GRAPHICS DISPLAY

70206A-1. Serials 2529A00336 and below. Loose HP-IB connector screws require replacement of the HP-MSIB cover.

70206A-5. Serials 2529A00432 and below. CRT replacement instructions.

70206A-7. Serials 2715A and below. A7 HP-MSIB assembly preferred replacement.

70206A-8. Serials 2529A00784 and below. Modification to prevent high-voltage failure.

70206A-9. Serials 2529A00527 and below. Modification to prevent intermittent blowing of line fuse.

HP 85043A/B SYSTEM CABINETS

85043A-1-S. 85043A serials 2622A01352 and below; 85043B serials 2623A00172 and below. Elimination of a potential safety hazard.

HP 85629A TEST AND ADJUSTMENT MODULE

85629A-1. All serials. Notification of ROM upgrade kit (HP P/N 85629-60002).

HP 86720A FREQUENCY EXTENSION UNIT

86720A-1. All serials. Preferred replacement for fuse A9F2.

Service Note Order Form

If you want service notes, please check the appropriate boxes below and return this form separately to one of the following addresses.

Hewlett-Packard
1820 Embarcadero Road
Palo Alto, California 94303

For European customers (ONLY)

Hewlett-Packard
Nederland BV
Central Mailing Dept.
P.O.Box 529
1180 AM Amstelveen
The Netherlands

Name _____
Firm _____
Address _____
City _____
State _____ Zip _____

- | | | | | |
|------------------------------------|------------------------------------|------------------------------------|-------------------------------------|---------------------------------------|
| <input type="checkbox"/> 3326A-05 | <input type="checkbox"/> 3779D-40 | <input type="checkbox"/> 8180A-03 | <input type="checkbox"/> 8590A-02 | <input type="checkbox"/> 15466A-01 |
| <input type="checkbox"/> 3453A-06A | <input type="checkbox"/> 3780A-32 | <input type="checkbox"/> 8180A-04 | <input type="checkbox"/> 8590A-03 | <input type="checkbox"/> 15466A-02 |
| <input type="checkbox"/> 3456A-22 | <input type="checkbox"/> 3787B-01 | <input type="checkbox"/> 8180A-05 | <input type="checkbox"/> 8590A-04 | <input type="checkbox"/> 35601A-01 |
| <input type="checkbox"/> 3457A-08 | <input type="checkbox"/> 4278A-01 | <input type="checkbox"/> 8180A-06 | <input type="checkbox"/> 8642B-04 | <input type="checkbox"/> 54111D-02 |
| <input type="checkbox"/> 3457A-09 | <input type="checkbox"/> 4936A-09 | <input type="checkbox"/> 8180B-01 | <input type="checkbox"/> 8642M-01 | <input type="checkbox"/> 54201A/D-04A |
| <input type="checkbox"/> 3552A-16 | <input type="checkbox"/> 4938A-02 | <input type="checkbox"/> 8181A-03 | <input type="checkbox"/> 8660D-01 | <input type="checkbox"/> 54201A/D-08 |
| <input type="checkbox"/> 3562A-06 | <input type="checkbox"/> 4945A-07 | <input type="checkbox"/> 8181A-04 | <input type="checkbox"/> 8671B-01A | <input type="checkbox"/> 54201A/D-09 |
| <input type="checkbox"/> 3562A-07 | <input type="checkbox"/> 4947A-07 | <input type="checkbox"/> 8182B-01 | <input type="checkbox"/> 8672A-18A | <input type="checkbox"/> 64941A-03 |
| <input type="checkbox"/> 3562A-08 | <input type="checkbox"/> 4951C-06 | <input type="checkbox"/> 8481A-04 | <input type="checkbox"/> 8672S-01 | <input type="checkbox"/> 70001A-05 |
| <input type="checkbox"/> 3562S-01 | <input type="checkbox"/> 4952A-01 | <input type="checkbox"/> 8484A-02 | <input type="checkbox"/> 8673B-10A | <input type="checkbox"/> 70205A-02 |
| <input type="checkbox"/> 3565S-01 | | | | |
| <input type="checkbox"/> 3565S-02 | <input type="checkbox"/> 4952A-02 | <input type="checkbox"/> 8553B-04 | <input type="checkbox"/> 8673C-07A | <input type="checkbox"/> 70205A-04 |
| <input type="checkbox"/> 3565S-03 | <input type="checkbox"/> 4952A-03 | <input type="checkbox"/> 8557A-01 | <input type="checkbox"/> 8673C-11A | <input type="checkbox"/> 70206A-01 |
| <input type="checkbox"/> 3764A-10A | <input type="checkbox"/> 5335A-20A | <input type="checkbox"/> 8559A-28A | <input type="checkbox"/> 8673D-07A | <input type="checkbox"/> 70206A-05 |
| <input type="checkbox"/> 3764A-11C | <input type="checkbox"/> 5340A-22 | <input type="checkbox"/> 8562A-02A | <input type="checkbox"/> 8673D-12A | <input type="checkbox"/> 70206A-07 |
| <input type="checkbox"/> 3776A-32 | <input type="checkbox"/> 6030A-07 | <input type="checkbox"/> 8562B-01A | <input type="checkbox"/> 8673E-03 | <input type="checkbox"/> 70206A-08 |
| <input type="checkbox"/> 3776B-37 | <input type="checkbox"/> 6031A-09 | <input type="checkbox"/> 8565A-22 | <input type="checkbox"/> 8673E-04A | <input type="checkbox"/> 70206A-09 |
| <input type="checkbox"/> 3776B-38 | <input type="checkbox"/> 6032A-08 | <input type="checkbox"/> 8566B-12A | <input type="checkbox"/> 8753A-10 | <input type="checkbox"/> 85043A-01-S |
| <input type="checkbox"/> 3779C-34 | <input type="checkbox"/> 6033A-06 | <input type="checkbox"/> 8566B-19 | <input type="checkbox"/> 8904A-01-S | <input type="checkbox"/> 85629A-01 |
| <input type="checkbox"/> 3779C-35 | <input type="checkbox"/> 6038A-04 | <input type="checkbox"/> 8569B-10 | <input type="checkbox"/> 8970A-11 | <input type="checkbox"/> 86720A-01 |
| <input type="checkbox"/> 3779D-39 | <input type="checkbox"/> 8170A-07 | <input type="checkbox"/> 8590A-01 | <input type="checkbox"/> 15425A-01 | |

Please photocopy this order form if you do not want to cut off the page.

HEWLETT-PACKARD COMPANY
1820 Embarcadero Road
Palo Alto, California 94303

BENCH BRIEFS
4TH QUARTER 1987

Volume 27 Number 4

Service information from
Hewlett-Packard Company

To obtain a qualification form for a free subscription, send your request to the above address.

Reader comments or technical article contributions are welcomed.

Please send them to the
Bench Briefs Editor.

Editor: Jim Bechtold
Hewlett-Packard

Bulk Rate
U.S. Postage
PAID
Sunnyvale, CA.
Permit No.
804

BECHTOLD, JAMES
WORLDWIDE CUSTOMER SUPPORT
DDIV 5000 / BLDG 36UV

All rights reserved. Permission to reprint Bench Briefs granted upon written request to the Editor.

Printed in U.S.A.