

2205 OSCILLOSCOPE SERVICE

WARNING

THE FOLLOWING SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID PERSONAL INJURY, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO. REFER TO OPERATORS SAFETY SUMMARY AND SERVICE SAFETY SUM-MARY PRIOR TO PERFORMING ANY SERVICE.

Please Check for CHANGE INFORMATION at the Rear of This Manual

First Printing APR 1988



Scans By *Artek Media*

Artek Media 1042 Plummer Cir. SW Rochester, MN 55902

www.artekmedia.com

"High resolution scans of obsolete technical manuals"

If your looking for a quality scanned technical manual in PDF format please visit our WEB site at <u>www.artekmedia.com</u> or drop us an email at <u>manuals@artekmedia.com</u> and we will be happy to email you a current list of the manuals we have available.

If you don't see the manual you need on the list drop us a line anyway we may still be able to point you to other sources. If you have an existing manual you would like scanned please write for details, This can often be done very reasonably in consideration for adding your manual to our library.

Typically the scans in our manuals are done as follows;

- 1) Typed text pages are typically scanned in black and white at 300 dpi.
- 2) Photo pages are typically scanned in gray scale mode at 600 dpi
- Schematic diagram pages are typically scanned in black and white at 600 dpi unless the original manual had colored high lighting (as is the case for some 70's vintage Tektronix manuals).

If you purchased this manual from us (typically through our Ebay name of ArtekMedia) thank you very much. If you received this from a well-meaning "friend" for free we would appreciate your treating this much like you would "share ware". By that we mean a donation of at least \$5-10 per manual is appreciated in recognition of the time (a manual can take as much as 40 hours to reproduce, book, link etc.), energy and quality of effort that went into preserving this manual. Donations via PayPal go to: manuals@artekmedia.com or can be mailed to us the address above.

Thanks par & Symmeth

Dave & Lynn Henderson Artek Media

Copyright © 1988 Tektronix, Inc. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents issued and pending.

TEKTRONIX, TEK, SCOPE-MOBILE, and WWW are registered trademarks of Tektronix, Inc.

Printed in U.S.A. Specification and price change privileges are reserved.

INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a panel insert, tag, or stamped on the chassis. The first two digits designate the country of manufacture. The last five digits of the serial number are unique to each instrument. The country of manufacture is identified as follows:

ć

- B000000 Tektronix, Inc., Beaverton, Oregon, U.S.A.
- E200000 Tektronix United Kingdom, Ltd., London
- G100000 Tektronix Guernsey, Ltd., Channel Islands
- HK00000 Hong Kong
- H700000 Tektronix Holland, NV, Heerenveen, The Netherlands
- J300000 Sony/Tektronix, Japan



TABLE OF CONTENTS

Page

LIST OF ILLUSTRATIONS	iv
LIST OF TABLES	v
OPERATORS SAFETY SUMMARY	vi
SERVICING SAFETY SUMMARY	vii

Section 1 SPECIFICATION

INTRODUCTION		1–1
ACCESSORIES		1–1
PERFORMANCE	CONDITIONS	1–1

Section 2 OPERATING INFORMATION

Page

GRATICULE	2-7
CONNECTING SIGNALS	2-7
OPERATOR'S CHECKS AND	
ADJUSTMENTS	2–8
INITIAL SETUP	2-8
TRACE ROTATION	
ADJUSTMENT	2-8
PROBE COMPENSATION	
(Option 10X Probe)	2-9

Section 3 THEORY OF OPERATION

ĩ

SECTION ORGANIZATION	3–1
INTEGRATED CIRCUIT	
DESCRIPTIONS	3–1
GENERAL DESCRIPTION	3-1
DETAILED CIRCUIT	
DESCRIPTION	3-3
VERTICAL	3-3
TRIGGER AMPLIFIERS AND	
SWITCHING	3-6
TRIGGER GENERATOR	3-8
SWEEP GENERATOR AND	
LOGIC	3-9
HORIZONTAL	3–11
Z-AXIS AMPLIFIER	3–12
POWER SUPPLY AND	
PROBE ADJUST	3–14

TABLE OF CONTENTS (cont)

Page

Page

Section 4	PERFORMANCE CHECK PROCEDURE	Section 5	ADJUSTMENT PROCEDURE
	INTRODUCTION		INTRODUCTION
	PURPOSE		PURPOSE 5-1
	PERFORMANCE CHECK INTERVAL		STRUCTURE
	STRUCTURE		LIMITS AND TOLERANCES 5-1
	TEST EQUIPMENT REQUIRED		ADJUSTMENTS AFFECTED B REPAIRS
	LIMITS AND TOLERANCES 4-1		PREPARATION FOR
	PREPARATION FOR CHECKS4-1		ADJUSTMENT 5–1 INDEX TO ADJUSTMENT PROCEDURE STEPS 5–3
	INDEX TO PERFORMANCE CHECK STEPS		POWER SUPPLY AND CRT DISPLAY
	VERTICAL		INITIAL CONTROL
	INITIAL CONTROL SETTINGS		SETTINGS 5-4 PROCEDURE STEPS 5-4
	PROCEDURE STEPS 4-4		VERTICAL 5–6 INITIAL CONTROL
	HORIZONTAL		SETTINGS 5-6
	INITIAL CONTROL		PROCEDURE STEPS 5-6
	SETTINGS 4-6		HORIZONTAL
	PROCEDURE STEPS 4-6		INITIAL CONTROL
	TRIGGER 4–9		SETTINGS 5-12
	INITIAL CONTROL		PROCEDURE STEPS 5-12
	SETTINGS 4–9	ĩ	TRIGGER 5–16 INITIAL CONTROL
	PROCEDURE STEPS 4-9		SETTINGS 5–16
	EXTERNAL Z-AXIS AND		PROCEDURE STEPS 5-16
	PROBE ADJUST		EXTERNAL Z-AXIS AND
	INITIAL CONTROL SETTINGS		PROBE ADJUST 5–19 INITIAL CONTROL SETTINGS 5–19
	PROCEDURE STEPS 4-12		PROCEDURE STEPS 5–19

TABLE OF CONTENTS (cont)

Page

Page

Section 6	MAINTENANCE	
	STATIC-SENSITIVE	
	COMPONENTS 6-1	
	PREVENTIVE MAINTENANCE 6-2	
	INTRODUCTION	
	GENERAL CARE	C = = 1
	INSPECTION AND	Sect
	CLEANING 6-2	
	LUBRICATION	
	SEMICONDUCTOR CHECKS 6-4	
	PERIODIC READJUSTMENT 6-4	
	TROUBLESHOOTING 6-5	
	INTRODUCTION	
	TROUBLESHOOTING AIDS 6-5	
	TROUBLESHOOTING	
	EQUIPMENT 6-6	
	TROUBLESHOOTING	
	TECHNIQUES	
	CORRECTIVE MAINTENANCE 6-10	
	INTRODUCTION	
	MAINTENANCE	
	PRECAUTIONS 6-10	Sect
	OBTAINING REPLACEMENT	Sect
	PARTS 6-10	
	MAINTENANCE AIDS	Sect
	RIBBON-CABLE	
	CONNECTIONS 6-11	CHA

•

TRANSISTORS AND	
INTEGRATED CIRCUITS	6-12
SOLDERING TECHNIQUES	6-12
REMOVAL AND REPLACE-	
MENT INSTRUCTIONS	6-13

Section 7 OPTIONS AND ACCESSORIES

OPTION	1C		7–1
OPTION	1K		7–1
OPTION	1R		7–1
OPTION	1T		7-1
OPTION	02		7-1
OPTION	22		7–1
OPTION	23		7–2
OPTION	24		7–2
INTERN/		NAL POWER	
CORDS			7–2
OPTION	AL A	ACCESSORIES	7-2
STANDA	٩RD	ACCESSORIES	7-4

Section 8	REPLACEABLE	ELECTRICAL	PARTS

- Section 9 DIAGRAMS
- Section 10 REPLACEABLE MECHANICAL PARTS

CHANGE INFORMATION

LIST OF ILLUSTRATIONS

Figure

Page

	The 2205 Oscilloscope
1–1	Maximum input voltage vs frequency derating curve for CH 1 OR X, CH 2 OR Y, and EXT INPUT OR Z connectors 1-7
1–2	Instrument dimensional drawing 1-8
2-1	Voltage Selector switch, fuse, power-cord receptacle, and plastic clamp 2-2
2–2	Front panel controls, connectors, and indicators 2-4
23	Rear Panel
2–4	Graticule measurement markings 2-7
2–5	Probe compensation 2-9
3–1	Block diagram of the Channel 1 Attenuator 3-3
3–2	Block diagram of the Channel Switching 3-5
3–3	Block diagram of the Sweep Generator and Logic 3-9
3–4	Block diagram of the Horizontal Amplifier 3-11
3-5	Simplified diagram of the DC Restorer 3-13
3–6	Block diagram of the Power Supply 3-15
5-1	Attenuator trimmer adjustments
6-1	Multi-connector holder orientation 6-12
9–1	Color codes for resistors.
9–2	Semiconductor lead configurations.
9–3	Locating components on schematic diagrams and circuit board illustrations.
9–4	Block diagram.
9–5	Component view of A3-Front Panel board.
9–6	Circuit view of A3-Front Panel board.
9-7	A2-Timebase/Attenuator board.
9–8	A1-Main board component view.
9-9	Circuit view of A1-Main board.
9-10	A4-Mains Input board.
9-11	Adjustment locations of A1-Main board component view.
9-12	Adjustment locations of A1-Main board circuit view.
9–13	A2Timebase/Attenuator board adjustment locations.

9-14 A3-Front Panel board adjustment location.

LIST OF TABLES

Table

Page

1-1	Electrical Characteristics	1-2
1–2	Environmental Characteristics	1~6
1–3	Mechanical Characteristics	1–7
4-1	Test Equipment Required	4–2
4–2	Deflection Accuracy Limits	4-4
4–3	Settings for Timing Accuracy Checks	4-7
4–4	Switch Combinations for Triggering Checks	4–9
5–1	Adjustments Affected by Repairs	5–2
5-2	Power Supply Limits	5-4
5-3	Deflection Accuracy Limits	5–7
5–4	Settings for Timing Accuracy Checks 5	5–14
5–5	Settings for Holdoff Checks	5~15
5–6	Switch Combinations for Triggering Checks 5	5–17
6–1	Relative Susceptibility to Static-Discharge Damage	6–1
6–2	External Inspection Checklist	6–3
6–3	Internal Inspection Checklist	6-4
64	Power Supply Voltage and Ripple Limits	
6–5	Maintenance Aids	
7-1	International Power Cords and Fuses	7–2
7–2	Optional Accessories	7–3

ć

OPERATORS SAFETY SUMMARY

The general safety information in this part of the summary is for both operating and service personnel. Specific warnings and cautions will be found throughout the manual where they apply and do not appear in this summary.

Terms in this Manual

CAUTION statements identify conditions or practices that could result in damage to the equipment or other property.

WARNING statements identify conditions or practices that could result in personal injury or loss of life.

Terms as Marked on Equipment

CAUTION indicates a personal injury hazard not immediately accessible as one reads the markings, or a hazard to property, including the equipment itself.

DANGER indicates a personal injury hazard immediately accessible as one reads the marking.

Symbols in this Manual



This symbol indicates where applicable cautionary or other information is to be found. For maximum input voltage see Table 1–1.

Symbols as Marked on Equipment



Protective ground (earth) terminal.



Power Source

This product is intended to operate from a power source that does not apply more than 250 V rms between the supply conductors or between either supply conductor and ground. A protective ground connection, by way of the grounding conductor in the power cord, is essential for safe operation.

Grounding the Product

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before making any connections to the product input or output terminals. A protective ground connection, by way of the grounding conductor in the power cord, is essential for safe operation.

Danger Arising From Loss of Ground

Upon loss of the protective-ground connection, all accessible conductive parts, including knobs and controls that may appear to be insulating, can render an electric shock.

Use the Proper Power Cord

Use only the power cord and connector specified for your product.

Use only a power cord that is in good condition.

For detailed information on power cords and connectors, see Figure 2-2.

Use the Proper Fuse

To avoid fire hazard, use only a fuse of the correct type, voltage rating and current rating as specified in the parts list for your product.

Do Not Operate in Explosive Atmosphere

To avoid explosion, do not operate this instrument in an explosive atmosphere.

Do Not Remove Covers or Panels

To avoid personal injury, do not remove the product covers or panels. Do not operate the product without the covers and panels properly installed.

SERVICING SAFETY SUMMARY

FOR QUALIFIED SERVICE PERSONNEL ONLY

Refer also to the preceding Operators Safety Summary

Do Not Service Alone

Do not perform internal service or adjustment of this product unless another person capable of rendering first aid and resuscitation is present. Disconnect power before removing protective panels, soldering, or replacing components.

Power Source

i

Use Care When Servicing With Power On

Dangerous voltages exist at several points in this product. To avoid personal injury, do not touch exposed connections or components while power is on. This product is intended to operate from a power source that does not apply more than 250 volts rms between the supply conductors or between either supply conductor and ground. A protective ground connection by way of the grounding connector in the power cord is essential for safe operation.



The 2205 Oscilloscope.

SPECIFICATION

INTRODUCTION

The TEKTRONIX 2205 Oscilloscope is a rugged, lightweight, dual-channel, 20 MHz instrument that features a bright, sharply defined trace on an 80 by 100 mm cathode-ray tube (crt).

Its low-noise vertical system supplies calibrated deflection factors from 5 mV to 5 V per division at full bandwidth.

Stable triggering is achieved over the full bandwidth of the vertical system. The flexibility and high sensitivity of the trigger system provides a range of conveniences such as hands-free triggering with the peak-to-peak automatic mode, independent selection of TV line and TV field triggering at any sweep speed, and single-sweep triggering. The trigger signal is dc coupled. An external triggering signal or an external Z-axis modulation signal can be applied via a front-panel connector and the sourceselector switches.

The horizontal system provides calibrated sweep speeds from 0.5 s to 100 ns per division. For greater measurement accuracy, a X10 magnifier circuit extends the maximum sweep speed to 10 ns per division.

ACCESSORIES

The instrument is shipped with the following accessories:

- 1 Operators Manual
- 2 1X Signal Adapters
- 1 Power Cord
- 2 Fuses
- 1 Power Cord Clamp
- 1 Washer

t

1 Screw

Part numbers for these standard accessories, as well as for other optional accessories, are located in Section 7, Options and Accessories. The voltagesensing signal adapters were designed specifically to complement the performance of your 2205.

PERFORMANCE CONDITIONS

The 2205 electrical characteristics listed in Table 1-1 are valid when it has been adjusted at an ambient temperature between +20 C and +30 C, has had a warm-up period of at least 20 minutes, and is operating at an ambient temperature between 0 C and +40 C (unless otherwise noted).

Environmental characteristics are given in Table 1-2. The 2205 meets the requirements of MIL-T-28800C, paragraphs 4.5.5.5.1.3, 4.5.5.1.4, and 4.5.5.1.2.2 for Type III, Class 5 equipment, except where otherwise noted.

Mechanical characteristics of the instrument are listed in Table 1–3.

Table 1-1 Electrical Characteristics

Characteristics	Performance Requirements
VER	FICAL DEFLECTION SYSTEM
Deflection Factor	
Range	5 mV per division to 5 V per division in a 1-2-5 sequence of 9 steps.
Accuracy	
+15°C to +35°C	<u>±3%.</u>
0°C to +15°C and +35°C to +40°C	<u>+</u> 5%.
Variable Control Range	Continuously variable and uncalibrated between step settings. Increases deflection factor by at least 2.5 to 1.
Step Response (Rise Time)	Applicable from 5 mV per division to 5 V per division. Rise times calculated from: $tr = \frac{0.35}{BW \text{ in MHz}}$
+5°C to +35°C	17.5 ns or less. ^a
0°C to +5°C and +35°C to +40°C	23.3 ns or less. ^a
Bandwidth (-3 dB)	
+5°C to +35°C	20 MHz or more.
0°C to +5°C and +35°C to +40°C	15 MHz or more. ^a
Ac Coupled Lower Cutoff Frequency	10 Hz or less at -3 dB. ^a
CHOP Mode Switching Rate	500 kHz ±30%.ª
Input Characteristics	
Resistance	1 MΩ ±2%. ^a
Capacitance	25 pF ±2%. ^a
Maximum Safe Input Voltage	400 V (dc + peak ac) or 800 V ac p-p to 10 kHz or less. ^a
Common-mode Rejection Ratio (CMRR)	At least 10 to 1 at 10 MHz.
Trace Shift	
With VOLTS/DIV Switch Rotation	0.75 division or less (Variable control in CAL detent) ^a
With VOLTS/DIV Variable Control Rotation	1 division or less. ^a
With Channel 2 Inverted	1.5 division or less. ^a
Channel Isolation	Greater than 100:1 at 20 MHz.

^aPerformance requirement not checked in manual.

Table 1-1 (cont)

Characteristics		Performance Requirements	
	TRIGGER SYST		
Trigger Sensitivity			
P-P AUTO/TV LINE and NORM Modes	5 MHz	30 MHz	
Internal Signal	0.3 div	1.0 div	
External Signal	40 mV	150 mV	
Lowest Usable Frequency in P-P AUTO Mode	≥ 20 Hz. ^a		
TV FIELD Mode	1.0 division	of composite sync. ^a	
External Input			
Resistance	1 MΩ ±10%. ^a		
Capacitance	25 pF ±2.5	25 pF ±2.5 pF.ª	
Maximum Input Voltage	400 V (dc -	+ peak ac) or 800 V ac p-p at 10 kHz or less	
Trigger Level Range			
NORM Mode	±15 division	n referred to the appropriate vertical input.	
EXT Source	At least ±1.6 V, 3.2 V p-p.		
EXT/10 Source	At least ±1	6 V, 32 V p-p. ^a	
HORIZON	TAL DEFLECTI	ON SYSTEM	
Sweep Rate Calibrated Range	sequence.	ivision to 0.1 μ s per division in a 1-2-5 Magnification extends maximum usable ad to 10 ns per division. ^a	
Accuracy	Magnified		
	X1	X10	
+15°C to +35°C	±3%	±4%	
0°C to +15°C and +35°C to +40°C	<u>+</u> 4% ^a	± 5% ^a	
	Sweep accu Exclude the speeds and	uracy applies over the center eight divisions. first 25 ns of the sweep for magnified sweep anything beyond the 100th magnified division	

^aPerformance requirement not checked in manual.

Table 1-1 (cont)

Characteristics	Performance Requirements	
HORIZOI	NTAL DEFLECTION SYSTEM (cont)	
Variable Control Range	Continuously variable and uncalibrated between calibrated step settings. Decreases calibrated sweep speeds at least by a factor of 2.5.	
Sweep Linearity	Magnified	
	X1 X10	
	±5% ±7%	
POSITION Control Range	Start of sweep to 10th division in X1, and to 100th division in X10, will position past the center vertical graticule line.	
Registration of Unmagnified and Magnified Traces	0.2 division or less, aligned to center vertical graticule line. ^a	
	Z-MODULATION	
Sensitivity	5 V causes noticeable modulation. Positive-going input decreases intensity.	
Usable frequency range	Dc to 5 MHz. ^a	
Maximum Safe Input Voltage	400 V (dc + peak ac) or 800 V ac p-p to 10 kHz or less. ^a	
×	(-Y OPERATION (X1 MODE)	
Deflection Factors	Same as vertical deflection system with variable controls in the CAL detents. ^a	
Accuracy		
X-Axis	<u>±5%.</u>	
Y-Axis	Same as Vertical Deflection System. ^a	
Bandwidth (-3 dB)		
X-Axis	Dc to at least 1 MHz.	
Y-Axis	Same as Vertical Deflection System.	
Phase difference between X- and Y-Axis Amplifiers	±3° from dc to 50 kHz. ^a	
PRO	DBE ADJUST SIGNAL OUTPUT	
Voltage into 1 MΩ Load	0.5 V ±5%.	
Repetition Rate	1 kHz ±20%. ^a	
· · · · · · · · · · · · · · · · · · ·		

^aPerformance requirement not checked in manual.

Characteristics	Performance Requirements
	POWER REQUIREMENTS
Line Voltage Ranges	
115 V Setting	95 Vac to 128 Vac. ^a
230 V Setting	185 Vac to 150 Vac. ^a
Line Frequency	48 Hz to 440 Hz. ^a
Maximum Power Consumption	40 W (60 VA). ^a
Line Fuse	UL 198.6 3AG (1/4 X 1 1/4 inch)
115 V Setting	0.75 A, Slow.
230 V Setting	0.5 A, Slow.
	CATHODE-RAY TUBE
Display Area	8 X 100 mm. ^a
Standard Phosphor	GH (Р31). ^а
Nominal Accelerating Voltage	1800 ∨ ±10%. ^a

Table 1-1 (cont)

^aPerformance requirement not checked in manual.

ĩ

Table 1-2 Environmental Characteristics

Characteristics	Performance Requirements
Temperature	
Operating	0°C to +40°C (+32°F to +104°F).
Nonoperating	-55°C to +75°C (-67°F to +167°F).
	Tested to MIL-T-28800C, paragraphs 4.5.5.1.3 and 4.5.5.1.4, except in 4.5.5.1.3 steps 4 and 5 (0°C operating test) are performed ahead of step 2 (-55°C nonoperating test). Equipment shall remain off upon return to room ambient during step 6. Excessive condensation shall be removed before operating during step 7.
Altitude	
Operating	To 4,570 meters (15,000 feet). Maximum operating temperature decreased 1°C per 300 m (1000 feet) above 1500 m (5,000 feet).
Nonoperating	To 15,250 meters (50,000 feet).
Relative Humidity	
Operating (+30°C to +40°C)	85%, +0%, -5%.
Nonoperating (+30°C to +60°C)	85%, +0%, -5%.
Vibration	
Operating	15 minutes along each of three major axes at a total displacement of 0.015 inch p-p (2.4 g at 55 Hz) with frequency varied from 10 Hz to 55 Hz to 10 Hz in one minute sweeps. Hold for 10 minutes at 55 Hz in each of three major axes. All major resonances must be above 55 Hz.
Shock	
Operating and Nonoperating	30 g, half-sine, 11-ms duration, three shocks per axis each direction, for a total of 18 shocks.
Radiated and conducted emission requirements	Meets VDE 0871, Class B and FCC Regulations.

Characteristics	Description
Weight with Power Cord	6.7 kg (14.8 lbs) or less.
Domestic Shipping Weight	9.1 kg (20.1 lbs) or less.
Dimensions	
Height	138 mm (5.4 in).
Width	
With Handle	380 mm (15.0 in).
Without Handle	327 mm (12.9 in).
Depth	
Without Front Cover	440 mm (17.2 in).
With Optional Front Cover	445 mm (17.5 in).
With Handle Extended	516 mm (20.3 in).

Table 1–3 Mechanical Characteristics



Figure 1–1. Maximum input voltage vs frequency derating curve for CH 1 OR X, CH 2 OR Y, and EXT INPUT OR Z connectors.



Figure 1-2. Instrument dimensional drawing.

OPERATING INFORMATION

PREPARATION FOR USE

This part gives you important safety information and tells you how to proceed with initial start-up of the TEKTRONIX 2205 Oscilloscope.

SAFETY

Before connecting the 2205 Oscilloscope to a power source, read this entire section. Also refer to the Safety Summary at the front of this manual for power source, grounding, and other safety considerations pertaining to the use of the instrument. Ensure that you have the training required to safely connect inputs to the signals you will be measuring.

ECAUTION S

This instrument may be damaged if operated with the LINE VOLTAGE SELECTOR (on the rear panel) set for the wrong applied ac source voltage or if a wrong line fuse is installed.

LINE VOLTAGE SELECTION

The 2205 operates from either a 115-V or a 230-V nominal ac power line with any frequency from 48 Hz to 440 Hz. Before connecting the power cord to a power source, verify that the LINE VOLTAGE SELECTOR, located on the rear panel, is set correctly and that the proper line fuse is installed. Refer to Table 2-1, Figure 2-1, and the instrument rear panel.

To convert the 2205 for operation on the other line-voltage range, use a flat-bladed screwdriver to move the LINE VOLTAGE SELECTOR to the required position and install the appropriate fuse (listed on the rear panel and in Table 7–1). The detachable power cord may have to be replaced to match the particular power source.

LINE FUSE

The fuse holder is located on the rear panel and contains the line (mains) fuse. Use the following

procedure to verify that the proper fuse is installed or to install a replacement fuse.

- 1. Unplug the power cord from the power source (if applicable).
- 2. Press in and slightly rotate the fuse-holder cap counterclockwise to release it.
- 3. Pull the cap (with the fuse) out of the fuse holder.
- 4. Verify that the fuse is the same type listed on the back of the instrument. The two types of fuses listed are not directly interchangeable; they require different types of fuse caps.
- 5. Reinstall the fuse (or replacement fuse) in the fuse-holder cap.
- 6. Replace the fuse holder and cap.

This instrument has a detachable, three-wire power cord with a three-contact plug for connection to both the power source and protective ground. The ground contact on the plug connects through the power-cord to the external metal parts of the instrument. The power cord may be secured to the rear panel by a cord-set-securing clamp as shown in Figure 2–1. For electrical shock protection, insert this plug only into a power source outlet that has a properly grounded protective-ground contact.

Instruments are shipped with the required power cord as ordered by the customer. Power cord plug information is presented in Table 2–1, and part numbers are listed in Table 7–1.

INSTRUMENT COOLING

Maintain adequate airflow to prevent instrument damage from internally generated heat. Before turning on the power, check that the spaces around the air-intake holes on the sides of the cabinet are free of any obstruction to airflow.



Figure 2-1. Voltage Selector switch, fuse, power-cord receptacle, and plastic clamp.

ί

CONTROLS, CONNECTORS, AND INDICATORS

The following descriptions are intended to familiarize the operator with the location and function of the instrument's controls, connectors, and indicators.

Refer to Figure 2-2 for the location of items 1 through 28.

POWER AND DISPLAY

- 1 INTENSITY Control—Adjusts the brightness of all displayed waveforms.
- (2) **BEAM FIND Button**—Compresses the vertical and horizontal deflection to within the graticule area and intensifies the display to aid the user in locating traces that are overscanned or deflected outside of the crt viewing area.
- 3 **FOCUS Control**-Adjusts for optimum display definition. Once set, proper focusing is maintained over a wide range of display intensity.
- (4) **TRACE ROTATION Control**—Permits alignment of the trace with the horizontal graticule line. This control is a screwdriver adjustment that, once set, should require little attention during normal operation.
- 5 **POWER Switch**—Turns instrument power on or off.
- 6 **Power On Indicator**—Lights up while instrument is operating.

VERTICAL

- (7) Channel 1 Vertical POSITION Control— Controls the vertical display position of the Channel 1 signal. In X-Y mode the control is inactive.
- 8 Channel 2 Vertical POSITION Control-Controls the vertical display position of the Channel 2 signal. In X-Y mode the control vertically positions the display.
 - **MODE Switch CH 1-BOTH-CH 2**—Selects either a single channel for display or the dual-channel display mode.

(9)

CH 1—Selects only the Channel 1 input signal for display.

BOTH—Selects a combination of Channel 1 and Channel 2 input signals for display. The CH 1–BOTH–CH 2 switch must be in the BOTH position for ADD, ALT, and CHOP operation.

CH 2—Selects only the Channel 2 input signal for display.

- (10) MODE Switch NORM-CH 2 INVERT—Inverts the Channel 2 display when in the CH 2 INVERT position. With CH 2 inverted, the oscilloscope may be operated as a differential amplifier when the BOTH-ADD vertical mode is selected. For noninverting Channel 2 display, select NORM position.
- (11)

(12)

MODE Switch ADD-ALT-CHOP-Sets the dual-channel vertical display mode.

ADD—Displays the sum of Channel 1 and Channel 2 input signals when BOTH is also selected. The difference of the Channel 1 and Channel 2 input signals is displayed when the Channel 2 signal is inverted.

ALT—Alternately displays the Channel 1 and Channel 2 input signals. The alternation occurs during retrace at the end of each sweep. ALT vertical mode is most useful for viewing both channel input signals at sweep rates of 0.5 ms per division and faster.

CHOP—Switches the display between the Channel 1 and Channel 2 vertical input signals during the sweep. The chopped switching rate (CHOP frequency) is approximately 500 kHz.

CH 1 and CH 2 VOLTS/DIV Switches--Select the vertical channel deflection factors from 5 mV to 5 V per division in a 1-2-5 sequence.

1X—Front-panel marking that indicates the deflection factor set by the VOLTS/DIV switch when a signal adapter, 1X probe, or a coaxial cable is attached to the channel input connector.

10X PROBE—Front-panel marking that indicates the deflection factor set by the VOLTS/DIV switch when a 10X probe is attached to the channel input connector.



Figure 2-2. Front panel controls, connectors, and indicators.

٤

- (13) Variable VOLTS/DIV Controls—Provide continuously variable deflection factors between calibrated positions of the VOLTS/DIV switch. Reduces gain by at least 2.5 times at the fully counterclockwise rotation of the variable knob. A detent position at full clockwise rotation indicates the calibrated VOLTS/DIV position of the variable knob.
- (14) AC-GND-DC (Input Coupling) Switches-Select the method of coupling the input signal from the CH 1 OR X and CH 2 OR Y connectors to the vertical amplifiers.

AC—Capacitively couples the input signal to the vertical deflection system. The dc component of the input signal is blocked. The lower -3 dB bandpass is 10 Hz or less.

GND—Grounds the input of the vertical deflection channel; provides a zero (ground) reference voltage display (does not ground the input signal).

DC—All frequency components of the input signal are coupled to the vertical deflection and signal acquisition systems.

CH 1 OR X and CH 2 OR Y Input Connectors— Provide for application of signals to the inputs of the deflection systems.

(15)

In X-Y mode, the signal connected to the CH 1 OR X input controls the horizontal deflection, and the signal connected to the CH 2 OR Y input controls the vertical deflection.

HORIZONTAL

- 16 POSITION Control—Positions the display horizontally in all modes.
- (17) MAG Switch-Selects X1 or X10 sweep speed.

X1-Normal sweep speed as selected by the SEC/DIV switch.

X10—Extends the SEC/DIV switch settings by a factor of 10. The fastest sweep speed can be extended to 10 ns per division.

- (18) SEC/DIV Switch—Selects calibrated sweep rates from 0.5 s to 0.01 μs per division in a 1-2-5 sequence of 21 steps. The X-Y position selects the X-Y mode; the CH 1 OR X input signal produces horizontal deflection for X-Y displays, and the CH 2 OR Y input signal produces vertical deflection.
- (19) Variable SEC/DIV Control—Provide continuously variable, uncalibrated sweep speeds to at least 2.5 times slower than the calibrated setting. It extends the slowest sweep speed to at least 1.25 s per division.
- 20 **PROBE ADJUST Terminal**—Provides an approximately 0.5–V, negative-going, square-wave signal (at about 1 kHz) for use in compensating voltage probes and checking the vertical deflection system. The PROBE ADJUST output signal is not intended as a reference for checking either the vertical or the horizontal accuracy of the instrument.
- (21) GND Connector (*m*)—Provides an auxiliary ground connection directly to the instrument chassis via a banana~tip jack.

TRIGGER

(22) SLOPE Switch—Selects either the positive (⊥¬) or negative (¬∟) slope of the trigger signal to start the sweep.

- (23) **LEVEL Control**—Selects the amplitude point on the trigger signal that produces triggering.
- 24 TRIG'D/READY Indicator—A dual-function LED indicator. In P-P AUTO and NORM trigger modes, the indicator is turned on when triggering occurs. In SGL SWP trigger mode, the indicator turns on when the trigger circuit is armed, awaiting a triggering event; it turns off again as soon as the single sweep is triggered.
 - **Trigger MODE Switch**—Determines the sweep triggering mode.

(25)

P-P AUTO-TV LINE—Triggering occurs on trigger signals having adequate amplitude and a repetition rate of about 20 Hz or faster. In the absence of a proper trigger signal, an autotrigger is generated, and the sweep freeruns.

NORM—Permits triggering at all sweep rates (an autotrigger is not generated in the absence of an adequate trigger signal). NORM trigger mode is especially useful for low-frequency and low-repetition-rate signals.

TV FIELD—Permits stable triggering on a television field signal (vertical sync). In the absence of an adequate trigger signal, the sweep freeruns. The instrument otherwise behaves as in P-P AUTO.

SGL SWP—Selects single sweep-operation.

- (26) RESET Button—Arms the trigger circuit for a single sweep. Triggering requirements are the same as in NORM trigger mode. After the completion of a triggered sweep, pressing in the SGL SWP RESET button rearms the trigger circuitry to accept the next triggering event.
- (27) **Trigger SOURCE Switches**—Determine the source of the internal and external trigger signal for the trigger generator circuits.

CH 1—Trigger signal is obtained from the CH 1 OR X input connector.

VERT MODE—Trigger signals are automatically obtained alternately from the CH 1 OR X and CH 2 OR Y input signals in ALT vertical mode. In CHOP vertical mode, the trigger signal source is the sum of the Channel 1 and Channel 2 input signals. CH 2—Trigger signal is obtained from the CH 2 OR Y input. The CH 2 INVERT switch also inverts the polarity of the internal Channel 2 trigger signal when the Channel 2 display is inverted.

EXT—Selects external trigger source. The actual form these triggers take is selected by the second SOURCE switch.

LINE—Routes a sample of the ac-powerline signal to the trigger circuit.

EXT/10—Divides the external signal applied to the EXT INPUT OR Z connector by a factor of ten before applying it to the trigger circuit.

EXT—Routes an external signal applied to the EXT INPUT OR Z connector to the trigger circuit.

EXT=Z—Routes the signal applied to the EXT INPUT OR Z connector to the Z-Axis amplifier rather than the trigger circuit.

(28) EXT INPUT OR Z Connector—Provides for connection of external signals either to the trigger circuit for external triggering or to the Z-Axis amplifier for intensity modulation of the crt display.

REAR PANEL

Refer to Figure 2-3 for items 29 through 31.

(29) Fuse Holder—Contains the ac-power-source fuse. See the rear-panel nomenclature for fuse rating and line-voltage range.

- (30) Detachable-Power-Cord Receptacle-Provides the connection point for the ac-power source to the instrument.
- (31) Line Voltage Selector Switch—Selects the line voltage operating range of either 115 Vac or 230 Vac.



Figure 2-3. Rear Panel.

¢,

OPERATING CONSIDERATIONS

This part contains basic operating information and techniques that should be considered before attempting to make any measurements with the instrument.

GRATICULE

The graticule is internally marked on the faceplate of the crt to eliminate parallax-viewing errors and to enable measurements (see Figure 2-4). The graticule is marked with eight vertical and ten horizontal major divisions. In addition, each major division is divided into five subdivisions. The vertical deflection factors and horizontal timing are calibrated to the graticule so that accurate measurements can be made directly from the crt. Also, percentage marks for the measurement of rise and fall times are located on the left side of the graticule.





CONNECTING SIGNALS

Signal Adapter

The signal adapter supplied with the instrument is usually the most convenient way to connect a signal to the 2205. These signal adapters are shielded to prevent pickup of electromagnetic interference. When connected to the 2205 input, a signal adapter presents 1 M Ω and about 100 pF impedance to the circuit under test. If this capacitance is disruptive to the circuit being tested, use the optional 10X probe.

Waveform Fidelity and Probe Grounds

When using a probe, its ground lead must be used for accurate measurements and observations. Use the shortest ground connection possible for best waveform fidelity.

In some cases, a separate ground from the unit under test to the ground receptacle on the oscilloscope front panel can reduce interference from low-frequency hum and noise. For rough checks of larger signals, such as 5 V logic, a ground lead separate from the probe – or even the safety ground connection, which is shared with the unit under test – may work for a signal ground. Fast signal transitions will be highly distorted, and extraneous noise will be induced without the probe ground connection, and/or with extra ground connections from the 2205 to the circuit being tested.

Probe Compensation (Optional 10X Probe)

Misadjustment of probe compensation is a common source of measurement error. Due to variations in oscilloscope input characteristics, probe compensation should be checked whenever a 10X probe is moved from one oscilloscope to another or from one channel to another on the same oscilloscope. Always compensate the probe to the channel on which it will be used. See the procedure in Section 4, *Checks and Adjustments*.

Probe Handling (Optional Probes)

Both the probe and the probe accessories should be handled carefully to prevent damage. Striking a hard surface can damage both the probe body and the probe tip. Exercise care to prevent the cable from being crushed, kinked, or excessively strained.

Coaxial Cables

To maintain good waveform fidelity and accuracy, use only high-quality, low-loss coaxial cables. When you use 50 Ω or 75 Ω coaxial cable, attach a matching external terminator. Some high frequency response will be lost without external termination.

OPERATOR'S CHECKS AND ADJUSTMENTS

To verify the operation and basic accuracy of your instrument before making measurements, perform the following checks and adjustment procedures. If adjustments are required beyond the scope of these operator's checks and adjustments, refer the instrument to qualified service personnel.

For new equipment checks, before proceeding with these instructions, refer to Preparation for Use in this manual to prepare the instrument for the initial start-up before applying power.

INITIAL SETUP

- 1. Verify that the POWER switch is OFF (switch is in the out position), and the Line Voltage Selector switch is set for the correct source voltage. Then plug the power cord into the ac power outlet.
- 2. Press in the POWER switch (ON) and set the instrument controls to obtain a baseline trace:

Display

INTENSITY Midrange FOCUS Best defined display

Vertical (Both Channels)

POSITION (both)	Midrange
MODE	CH 1, NORM
VOLTS/DIV (both)	10 mV
AC-GND-DC (both)	DC
VOLTS/DIV Variable (both)	CAL (in detent)
Magification (both)	X1 (CAL knobs in)

Horizontal

SEC/DIV SEC/DIV Variable	0.5 ms CAL (in detent)
POSITION	Midrange
MODE	X1

Trigger

HOLDOFF	MIN (fully counter
	clockwise)
SOURCE	VERT MODE
MODE	P-P AUTO
SLOPE	Positive (_/_)
COUPLING	AC
LEVEL	For a stable display (with signal applied)

- 3. Adjust the INTENSITY and FOCUS controls for the desired display brightness and best focused trace.
- 4. Adjust the Vertical and Horizontal POSITION controls to position the trace within the graticule area.
- 5. Allow the instrument to warm up for 20 minutes before commencing the adjustment procedures. Reduce the INTENSITY level during the waiting time.

TRACE ROTATION ADJUSTMENT

NOTE

Normally, the trace will be parallel to the center horizontal graticule line, and TRACE ROTATION adjustment is not required.

1. Preset the instrument controls and obtain a baseline trace as described in Initial Setup.

- 2. Use the CH 1 POSITION control to move the baseline trace to the center horizontal graticule line.
- 3. If the baseline trace is not parallel to the center horizontal graticule line, use a small-bladed screwdriver or alignment tool to adjust the TRACE ROTATION control and align the trace with the graticule line.

PROBE COMPENSATION (Option 10X Probe)

Misadjustment of probe compensation is a source of measurement error. The attenuator probes are equipped with a compensation adjustment. To ensure optimum measurement accuracy, always check probe compensation before making measurements. Probe compensation is accomplished by the following steps:

- 1. Preset the instrument controls and obtain a baseline trace as described in the Initial Setup.
- 2. Connect the two 10X probes (supplied with the instrument) to the CH 1 OR X and CH 2 OR Y input connectors.
- 3. Connect the Channel 1 probe tip to the PROBE ADJUST terminal.
- Use the CH 1 POSITION control to vertically center the display. If necessary, adjust the Trigger LEVEL control to obtain a stable display on the positive (__) SLOPE.

NOTE

Refer to the instruction manual supplied with the probe for more complete information on the probe and probe compensation.

- 5. Check the waveform display for overshoot and rounding (see Figure 2–5); if necessary adjust the probe's compensation. Use a low-reactance alignment tool to adjust the LF comp capacitor for a square front corner on the waveform.
- 6. Disconnect the Channel 1 probe tip from the PROBE ADJUST terminal.
- 7. Connect the Channel 2 probe tip to the PROBE ADJUST terminal.
- 8. Set the Vertical MODE to CH 2.
- 9. Use the CH 2 POSITION control to vertically center the display.
- 10. Repeat step 5 for the Channel 2 probe.



Figure 2-5. Probe compensation.

L

THEORY OF OPERATION

SECTION ORGANIZATION

This section of the manual contains a general summary of instrument functions followed by a detailed description of each major circuit. A basic block diagram, (Figure 9–4), and the schematic diagrams are located in the tabbed Diagrams section at the back of this manual. The block diagram and schematic diagrams are used to show the interconnections between parts of the circuitry and to indicate circuit components.

The schematic diagram number associated with each description is identified in the text and is shown on the block diagrams. For best understanding of the circuit being described, refer to the appropriate schematic diagram and the block diagram.

INTEGRATED CIRCUIT DESCRIPTIONS

Digital Logic Conventions

Digital logic circuits do many functions within the instrument. Functions and operation of the logic

circuits are represented by logic symbology and terminology. Most logic functions are described using the positive-logic convention. Positive logic is a system where the more positive of two levels is the TRUE (or 1) state; the more negative level is the FALSE (or 0) state. In this logic description, the TRUE state is HI, and the FALSE state is LO. Voltage levels for a HI or a LO state vary between specific devices. For detailed device characteristics, refer to the manufacturer's data book.

Linear Devices

The operation of individual linear integrated circuit devices in this section use waveforms or other techniques such as voltage measurement and simplified diagrams to illustrate their circuit operation.

GENERAL DESCRIPTION

In the following functional description of the 2205 Oscilloscope, refer to the block diagram (Figure 9-4) located in the Diagrams section of this manual. In Figure 9-4 the numbered diamond symbol in each major block refers to the appropriate schematic diagram number.

Vertical

Signals to be displayed on the crt (cathode-ray tube) are applied to either or both the CH 1 OR X and the CH 2 OR Y input connectors. The signals may be coupled to the attenuator either directly (DC) or through an input-coupling capacitor (AC). The inputs may also be disconnected, and the input to the attenuators grounded, by switching to the GND position of the input coupling switch. In the GND position, the ac-coupling capacitor is allowed to precharge to the dc level present at the input connector. This precharging prevents large trace shifts of the display when switching from GND to AC coupling. The Attenuators are switched by the front-panel VOLTS/DIV switches and scale the applied signal level to obtain the desired display amplitude.

The output signals from the Attenuators are applied to the Vertical Preamplifiers for amplification. The Channel 2 Preamplifier has additional circuitry, permitting the operator to invert the Channel 2 display on the cathode-ray tube (crt). Trigger pickoffs in each channel supply a trigger signal to the Trigger Amplifier when internal triggering is selected.

Input signals are selected for display by the Channel Switching circuit under control of the frontpanel VERTICAL MODE switches. The output signal from the Channel Switching circuit is applied to the Vertical Output Amplifier. Final amplification of the vertical signal is done by the Vertical Output Amplifier. This stage produces the signal levels that vertically deflect the crt electron beam. For locating the position of off-screen displays, the dynamic range of the Amplifier can be limited with the Beam Find circuitry. This circuitry also intensifies the trace and limits horizontal deflection.

Triggering

The Trigger circuitry uses either the Internal Trigger signal obtained from the input signal(s), an External Trigger signal, or a Line Trigger signal derived from the ac power source to develop trigger signals for the Sweep Generator. The P–P Auto Trigger circuit sets the range of the Trigger Level to conform to within the peak-to-peak amplitude of the selected trigger signal when either P–P Auto or TV Field Trigger mode is selected. This allows triggering on most signals without needing to adjust the TRIGGER LEVEL control. In NORM mode, the TRIGGER LEVEL control must be adjusted to the signal level before a sweep will be triggered.

The triggering circuitry contains the TV Field Sync circuit. This circuit provides stable triggering on television vertical-sync pulses when in the TV Field triggering mode. TV Line triggering is possible using P-P AUTO trigger mode.

Sweep

The Sweep Logic circuit controls the sweep generation and Z-Axis unblanking for the Sweep display. When the TRIGGER Mode switches are set to either P-P AUTO or TV FIELD and no trigger signal is present, the Auto Baseline circuit causes the Sweep Logic circuit to produce a sweep for reference purposes. In the NORM setting, the Auto Baseline circuit is disabled and sweeps are not generated until a trigger event occurs. This is useful for triggering on low-repetition rate signals. The SGL SWP (single sweep) trigger mode allows only one sweep to be generated after being reset. Following the single sweep, the Trigger circuit is disabled until the SGL SWP RESET button is pressed again.

The Sweep Logic circuit controls the operation of the Miller Sweep Generator circuit. The Sweep circuit produces a linear sweep with a ramp time that is controlled by the SEC/DIV switch setting. The sweep signal is applied to the Horizontal Preamplifier for initial amplification and then to the Horizontal Output Amplifier to drive the crt horizontal deflection plates.

Horizontal

The Horizontal Preamplifier gain is increased by a factor of 10 when the Horizontal MAG control is used. Horizontal positioning of the display is done in the Horizontal Preamplifier circuit.

In the X–Y mode of operation, the Channel 1 signal from the internal Trigger circuitry passes through the X–Y Amplifier to the Horizontal Preamplifier. In this operating mode, the Channel 1 Internal Trigger signal supplies the horizontal deflection to the crt, and the Miller Sweep circuit is disabled to inhibit sweep generation.

Z-Axis

The Z-Axis drive from the Sweep Logic circuit is applied to the Z-Axis Amplifier. The output signal from the Z-Axis Amplifier circuit sets the crt intensity. When using Chop Vertical mode, a blanking signal from the Chop Oscillator circuit blanks the crt display while switching between the vertical channels.

The DC Restorer circuit applies the output voltage of the Z-Axis Amplifier between the cathode and grid of the crt. High dc potentials on these elements prohibit direct coupling to the crt.

Power Supply

The Power Supply provides the necessary operating voltages for the instrument. Operating potentials are obtained from a circuit consisting of the Power Transformer, power supply control circuits, inverter, and inverter transformer. The inverter transformer secondary windings provide various ac-levels that are rectified and filtered to produce the operating voltages for the instrument.

Probe Adjust

A front-panel PROBE ADJUST output is provided for use in adjusting probe compensation. The voltage at the PROBE ADJUST connector is a negative-going square wave that has a peak-topeak amplitude of about 500 mV with a repetition rate about 1 kHz.

DETAILED CIRCUIT DESCRIPTION

VERTICAL

Attenuators

The Channel 1 and Channel 2 Attenuator circuits, shown on Diagram 1, are identical except for the additional Invert circuitry in the Channel 2 Paraphase Amplifier. Therefore, only the Channel 1 Attenuator is described, with the Invert circuitry of Channel 2 discussed separately.

The Attenuator circuit (see Figure 3–1) provides control of the vertical deflection factor and the variable volts/division gain. Vertical input signals for display on the crt may be connected to either or both the CH 1 OR X and the CH 2 OR Y input connectors. In the X–Y mode of operation, the input signal applied to the CH 1 OR X connector provides horizontal (X–axis) deflection for the display, and the input signal applied to the CH 2 OR Y connector provides the vertical (Y–axis) deflection for the display.

Input Coupling (AC-GND-DC)

A signal from the CH 1 OR X input connector may be ac or dc coupled to the High-Impedance Attenuator circuit or disconnected completely by the Input Coupling Switch. Signals from the CH 1 OR X input connector are routed through resistor R1 to Input Coupling switch S101. When S101 is set for dc coupling, the Channel 1 signal goes directly to the input of the High-Impedance Attenuator stage. When ac coupled, the ac portion of the input signal passes through the dc-blocking capacitor C2. The blocking capacitor stops the dc component of the input signal from reaching the Attenuator circuit. When switched into the signal path, attenuator AT1 attenuates the input signal by factors of 100, 10, 4, or 2. When S101 is set to GND, the direct signal path is opened and the input of the attenuator is connected to ground. This provides a ground reference without the need to remove the applied signal from the input connector. The coupling capacitor precharges through R2 and R4 to prevent large trace shifts when switching from GND to AC.

Input Attenuator

The effective deflection factor of each vertical channel is determined by the setting of the Channel VOLTS/DIV switch. The basic deflection factor of the Vertical system is 5 mV/DIV. For VOLT/DIV switch settings above 5 mV/DIV, frequency compensated voltage dividers (attenuators) are switched into the circuit. Each channel has $\div 2$, $\div 4$, $\div 10$ and $\div 100$ attenuators that are selected in various combinations to produce the different deflection factors. Each attenuator contains an adjustable series capacitor to provide correct attenuation at high frequencies, and an adjustable shunt capacitor to provide correct.



Figure 3–1. Block diagram of the Channel 1 Attenuator.

Source Follower

The Channel 1 signal from the input attenuator is connected to the source follower Q13A via R6 and C6. Resistor R5 provides the input resistance. Resistor R6 provides input current limiting for Q13A and Q14. FET Q13B is a constant current source for Q13A. Transistors Q13A and Q13B provide a high output impedance for the attenuator stage and the input drive current needed for the Paraphase Amplifier U30 (first stage of amplification).

If excessively high amplitude signals are applied to the source follower Q13A, the signal current will be limited by R6 and Q14 (connected as diode) and the gate-source junction of Q13A. If an excessive negative going signal causes Q14 to become forward biased, Q13A gate is clamped to about -9.3V. An excessive positive going signal will forward bias the gate-source junction of Q13A. As soon as gate current flows, the gate voltage will stop increasing. Gate current is limited by the high resistance of R6.

Paraphase Amplifier

Paraphase Amplifier U30 converts the singleended signal from Q13 into a differential signal for the Vertical Preamplifier. The signal from Q13A pin 5 goes to the base of one transistor in U30. The other input transistor in U30 is biased by the divider network formed by R30, R31, R32 and variable R33. Emitter current for the two input transistors is supplied by R22 and R23. Resistor R29 sets the gain for the stage. The collector current of the two input transistors serves as emitter current for the differential output transistor pairs. Base bias voltages for the output pairs are developed by the divider network formed by R39, R41, R42 and CH 1 VOLTS/DIV Variable control. The transistors of U30 have matched characteristics, so the ratio of currents in the two transistors U83B and U83C, connected as diodes, determines the current ratios in the output transistor pairs of U30.

As CH 1 VOLTS/DIV Variable control is rotated from calibrated to uncalibrated, the conduction level of the transistors connected to R35 increases. Since the transistor pairs are cross connected, the increased conduction in one pair of transistors subtracts from the output current produced by the transistor pair connected to R38, and the overall gain of the amplifier decreases. Potentiometer R33 is adjusted to balance the amplifier for minimal dc trace shift as the CH 1 VOLTS/DIV Variable control is rotated.

Incorporated in the Channel 2 Paraphase Amplifier is circuitry that allows the polarity of the Channel 2 signal to be inverted. When CH 2 INVERT switch S90 is in NORM, the transistor pairs in U80 are biased as they are in U30, and CH 2 trace is not inverted. In CH 2 INVERT position, connections to the bases of the output transistor pairs are reversed, to produce an inverted Channel 2 trace. Potentiometer R83 is adjusted for minimal dc trace shift in CH 2 INVERT when rotating CH 2 VOLTS/DIV Variable control. Potentiometer R84 is switched in with R83 when in INVERT; it is adjusted for minimal dc trace shift when rotating CH 2 VOLTS/DIV Variable control.

Vertical Preamplifiers

The Channel 1 and Channel 2 Vertical Preamplifiers, shown on Diagram 2, are identical in operation. Operation of the Channel 1 amplifier is described. Differential signal current from the Paraphase Amplifier is amplified to produce drive current for the Vertical Output Amplifier. Internal trigger signals for the Trigger circuitry are picked off before the Vertical Preamplifier. The Channel Switch circuitry controls channel selection for the crt display.

Common-base transistors Q102 and Q103, which complete the Paraphase Amplifier portion of the circuitry shown on Diagram 1, convert differential current from the Paraphase Amplifier into levelshifted voltages that drive the bases of the input transistors of Vertical Preamplifier U130 and the Internal Trigger circuitry.

Emitter current for the input transistors of U130 is supplied by Q114 and Q115. The base bias of Q114 and Q115 is adjusted by the Channel 1 VERTICAL POSITION Control R123. The collector current of each input transistor of U130 is the emitter current for two of the differential output transistors. One collector of each output pair is grounded and the other provides output drive to the Vertical Output Amplifier. The base bias voltages of the transistors with grounded collectors are held at ground potential by R136. The base voltages of the other transistors are controlled by the Channel Switch circuitry.

When Channel 1 is selected to drive the Vertical Output Amplifier, the Q output (pin 9) of U540A is HI. The transistors with the ungrounded collectors is then forward-biased, and the Channel 1 signal is conducted through to the Vertical Output Amplifier. If Channel 1 is not selected, then the Q output of U540A is LO. The transistors with the ungrounded collectors are then reverse-biased and the output signals will be conducted to ground by the other transistor pair. The gain of the Preamplifier is set by adjusting R145 to control the signal current that is shunted between the two differential outputs.

Channel Switch Logic

The Channel Switch circuitry, shown on Diagram 2, uses the front-panel VERTICAL MODE switches to select the crt display format. See Figure 3-2 for a block diagram of the circuit.

When any display mode other than X-Y is selected, the XY line connected to S550 is at ground potential. VERTICAL MODE switches S545 and S550 control the connection between the XY control line and the SET(L) and RESET(L) inputs of flip-flop U540A to obtain the various display formats described below.

CHANNEL 1 DISPLAY ONLY. The CH 1 position of S550 grounds the SET input of U540A while the RESET input is held HI by pull-up resistor R539. This produces a HI and a LO on the Q and \overline{Q} outputs of U540A respectively, and the Channel 1 Preamplifier signal then drives the Vertical Output Amplifier (as described in the Vertical Preamplifier section). The Channel 2 Preamplifier will be disabled.

CHANNEL 2 DISPLAY ONLY. The CH 2 position of S550 holds the RESET input of U540A LO through CR538, and the SET input is held HI by pull-up resistor R538. The outputs of U540A are then Q LO and \overline{Q} HI enabling the Channel 2 Preamplifier signal to drive the Vertical Output Amplifier, while the CH 1 Preamplifier is disabled.

To display the ADD, ALT, or CHOP formats, S550 must be in the BOTH position to ground the A, C, and F pins of S545.

ADD DISPLAY. In the ADD position of S545, both the SET and RESET inputs of U540A are held LO by CR534 and CR537. The Q and \overline{Q} outputs of U540A are then both HI, and signal currents from the Channel 1 and Channel 2 Preamplifiers add together to drive the Vertical Output Amplifier.

CHOP DISPLAY. In the CHOP position, the CHOP ENABLE line is held LO, keeping the inputs of U537D and U537C HI. This enables CHOP multivibrator U537D to begin switching. The switching rate is determined primarily by the component values of R544, R545, and C545. The output of U537C (the inverted output of the multivibrator circuit) supplies the CHOP clock to flip-flop U540A via U537A. The output of U537C also drives U537B, the CHOP Blanking Pulse Generator.



Figure 3-2. Block diagram of the Channel Switching.

Coupling capacitor C547 and resistors R547 and R548 form a differentiating circuit that produces positive-going and negative-going short duration pulses. These pulses are inverted by U537B to generate the Chop Blank signal to the Z-Axis Amplifier. The pulses blank the crt during CHOP switching times.

The Alt Sync signal applied to one input of U537A is HI except during Holdoff. This allows the output of U537C to be inverted by U537A which drives the clock input of U540A. Since the \overline{Q} output of U540A is connected back to the D input, and both the SET and RESET inputs are HI, the outputs of U540A tog-gle (change states) with each clock input. The Vertical Output Amplifier is then driven alternately from the Channel 1 and Channel 2 Preamplifiers at the CHOP rate.

ALTERNATE DISPLAY. In ALT, the CHOP ENABLE line is held HI, disabling CHOP multivibrator U537D. The output of U537C will be HI and the Chop Blank signal from U537B will be LO. Input signals to U537A are the HI from U537C and the ALT SYNC from the Holdoff circuitry in the Sweep Generator. The output of U537A will then be the inverted ALT SYNC signal that clocks Channel Select flip-flop U540A. This causes the outputs of U540A to toggle at the end of each sweep so that the Channel 1 and Channel 2 Preamplifiers alternately drive the Vertical Output Amplifier.

Beam Find keeps the vertical trace within the graticule area for locating off-screen and overscanned traces. BEAM FIND switch S390 adjusts the Vertical Output Amplifier biasing to limit the voltage swing at the crt plates. When S390 is in normal out position, the voltage level on pin 3 of U225 is about zero volts. When the BEAM FIND switch is in, pin 3 of U225 goes to -8.6 V, the output of U225 goes low and bias Q202 and Q203 such that the amplifier dynamic range is limited.

Vertical Output Amplifier

The Vertical Output Amplifier provides final amplification of the input signals for application to the vertical deflection plates of the crt. Signals from the preamplifier are applied to a differential amplifier composed of Q230 and Q231 with frequency compensation provided by R241, R280, and C241, and overall gain set by R233. Transistors Q232, Q236, and Q237 form a cascade-feed-back amplifier for driving the positive deflection plate with R243 setting amplifier gain and C243 providing high frequency compensation. Emitter follower of Q232 buffers the input and provides low impedance drive to the two output transistors Q236 and Q237. For slow speed signals, Q236 serves as a current source for Q237, and at high frequencies, the signal is coupled through C232 to the base of Q236. This provides additional pull-up output current to drive the crt at high frequencies. The amplifier consisting of Q234, Q238, and Q239 drives the negative deflection plate the same way the positive deflection plate is driven.

TRIGGER AMPLIFIERS AND SWITCHING

The Trigger Amplifiers shown on Diagram 3, provide signals to the Trigger Generator circuit from either the Vertical Preamplifiers, the EXT INPUT OR Z connector, or the power line. The SOURCE switch selects Channel 1, Channel 2, external, or line as the trigger source.

Internal Trigger

Signals from the Vertical Preamplifiers drive the internal Trigger Amplifier with channel selection determined by the VERTICAL switch.

Trigger pickoff from the Preamplifiers is accomplished by Q450 and Q451 for Channel 1, and Q452 and Q453 for Channel 2. The circuitry associated with Channel 2 is the same as that for Channel 1 except that it does not have a trigger offset adjustment.

Signals from the Channel 1 Preamplifier are applied to Q450 and Q451. These emitter-follower transistors each drive one input transistor in U335, and the collectors of the U335 input transistors in turn supply emitter current to two current-steering transistors. The biasing network of the input transistors of U335 is adjustable while the biasing network of the input transistors of U310 is fixed. Potentiometer R338 adjusts the emitter bias levels of the two input transistors of U335 so that dc offsets between channels can be matched.

The base bias voltage of one transistor in each output differential amplifier pair is fixed by the divider network composed of R443 and R444. The other base voltage is controlled by the CH 1 TRIG signal from the Trigger Channel Switch circuitry. When the CH 1 TRIG signal is LO, the transistors in each output pair, with the collectors connected together, are biased on and the other transistors are off. The collector signal currents are equal in magnitude but opposite in polarity and signal cancellation occurs. If the CH 1 TRIG signal is HI, the other transistors in each pair will be biased on and an output signal will be developed across R339 and R340 to drive the Internal Trigger Amplifier.

Internal trigger channels are chosen by the SOURCE switch S555. The CH 1, VERT MODE, and CH 2 positions of S555 forward biases CR348 and

CR349 to prevent external trigger signals or the line trigger signal from reaching the Trigger Generator. Signals from the Internal Trigger Amplifier are passed to the Trigger Generator through forward-biased CR450.

CHANNEL 1. For triggering from Channel 1, the SOURCE and VERTICAL MODE switches are set to CH 1. Input pin 9 of U300C will be LO, which place a LO at the output of U300C. This LO is passed through U304B to an input of U300B. The output of U300B goes HI enabling Channel 1 signal through U335. The Channel 2 signal path is disabled by the output of U300A being LO.

CHANNEL 2. For triggering from Channel 2, the SOURCE and VERTICAL MODE switches are set to CH 2. Input pin 8 of U300C will be LO, which places a LO at the output of U300C. This LO is passes through U304A to one of the inputs of U300A. The output of U300A goes HI enabling Channel 2 signal through U335. The Channel 1 signal path is disabled by the output of U300B being LO.

VERT MODE. When the SOURCE switch is set to VERT MODE, trigger source selection is determined by the two VERTICAL MODE switches. The outputs of U300A and U300B will be HI, and triggering selection will then be determined by the inputs of U304A and U304B that are controlled by U540A in the Channel Switch circuit.

When Channel 1 is selected (VERTICAL MODE switch set to CH 1), the input to U304B will be HI. The LO from the output of U304B is applied to U300B and causes the CH 1 TRIG line to go HI and enable the Channel 1 trigger signal. The input to U304A will be LO placing a HI at the input of U300A. The LO from the output of U300A causes the Channel 2 trigger signal to be disabled.

When Channel 2 is selected (VERTICAL MODE switch set to CH 2), the outputs of U340B, U300B, U304A, and U300A will be the reverse of the states described for Channel 1 selection. The Channel 2 signal will be selected and the Channel. 1 trigger signal disabled.

When selecting ALT VERTICAL MODE, the inputs of U304A and U304B will toggle with each sweep. The outputs of the two gates will also toggle and the Trigger signal source will alternate with the displayed channel.

In the ADD VERTICAL MODE position, both inputs to U304A and U304B will be LO and both gate outputs of U300A and U300B will be HI. Both Channel 1 and Channel 2 signal paths will be enabled and their output current will be summed at the inputs of the Internal Trigger Amplifier to produce the internal trigger signal.

In CHOP VERTICAL MODE position, the CHOP ENABLE line places a LO on both inputs of U300D. The output of U300D is held HI and applied to the inputs U304A and U304B and the signal to the Internal Trigger Amplifier will be the same as for the ADD mode.

Internal Trigger Amplifier

The Internal Trigger Amplifier converts the differential trigger signals from the Vertical Preamplifiers into a single-ended signal that drives the X-Axis Amplifier and the Trigger Generator.

Signal current is applied to the emitters of U380C and U380D. The collector current of U380C is converted to a voltage across feedback resistor R357. The opposite-phase collector current of U380A causes a voltage drop across R359 that adds to the voltage at the collector of U380D. This voltage appears at the base of U415C which buffers and level shifts the signal back to 0 V. The emitter signal of U415C drives the X-Axis Amplifier, and the base of Q410. The emitter signal of Q410 in turn drives the Trigger Generator whenever CR450 is forward biased.

External Trigger Amplifier

The External Trigger Amplifier buffers signals applied to the EXT INPUT OR Z connector and linefrequency trigger signals. The output of the amplifier is applied to the Trigger Generator.

EXT. When the SOURCE switches are set to EXT, and either EXT=Z, EXT, or EXT/10 is selected, the trigger source is the signal applied to the EXT INPUT OR Z connector. In EXT/10 position the input signal is attenuated by a factor of 10 through the compensated divider composed of R377, R378, C377, and C378.

The external signal is applied to the gate of Q370. FET Q371 supplies source current for Q370 such that there will be no voltage drop across the gate-source junction of Q370. FETS Q370 and Q371 are a matched pair. The source-follower Q370 drives emitter-follower transistor Q412 which lowers the Amplifier output impedance. Protection-diode CR381 clamps the signal at the gate of Q370 to about -9 V. The Amplifier output will drive the Trigger Generator through forward-biased CR451 whenever the SOURCE switch is set to EXT. When the SOURCE switch is not set to EXT, the base-emitter junction of Q370 will be reverse biased via Q411, CR452, CR348 or CR349, and the Amplifier will be disabled.

When the SOURCE switch is set to EXT=Z position, the external signal is buffered by Q370 and applied to the Z-Axis amplifier for intensity modulation.

The line trigger from the power supply is applied to Q370 when the SOURCE switches are set to EXT and LINE positions.

TRIGGER GENERATOR

The Trigger Generator, shown on Diagram 3, supplies trigger signals to the Sweep Generator. Included in the Trigger Generator circuit are the P-P Auto Trigger, Norm Trigger, and TV Triggering circuitry.

Trigger Level Circuit

The Trigger Level Circuit establishes voltages at the ends of the TRIGGER LEVEL potentiometer as a function of the TRIGGER Mode switch selection and trigger signals selected be the SOURCE switch. In the P-P Auto and TV Field mode, U415E is off and CR341 is reverse biased. Diode CR417 is forward biased turning U415A off. Trigger signals selected by the SOURCE switch are applied to peak detectors consisting of U415B-Q415 and U380E-Q465. These peak detectors track dc levels and have a high voltage transfer efficiency. The positive-peak and negative-peak signal levels stored by C418 and C431 are near the peak levels of the trigger signal. Amplifiers U425A and U425B are configured as voltage followers with transistors U415D and Q490 in the feedback loops. These transistors thermally compensate for U415B and Q465 and level shift the amplifier outputs back to the original dc levels of the input trigger signals. The output of U425B will be the positive peak voltage of the input trigger signal and the output of U425A will be the negative peak voltage. Potentiometers R445 and R446 adjust for dc offsets in the trigger circuitry.

In the Norm mode, +8.6 V is applied to the junction of R417 and R432, turning on U415E and forward biasing CR431. Diode CR417 is reverse biased turning U415A on. Input transistors U415B and Q465 are then biased off and no trigger signals will reach the Trigger Level circuit. The inputs and outputs of U425A and U425B will then be fixed voltages and independent of trigger-signal amplitude.

Trigger Level Comparator

The Trigger Level Comparator compares signals selected by the TRIGGER SOURCE switch to a voltage set by the TRIGGER LEVEL control. Positive or negative slope triggering is selected by the TRIGGER SLOPE switch.

Transistors U460B and U460E compare the wiper voltage on the TRIGGER LEVEL control to the input trigger signal, and the transistor with the higher base voltage will conduct more of the available emitter current. The output collector currents supply emitter current to two transistor pairs (U460A–U460F and U460C–4600D) which serve as cross-wired switches that are biased on or off by the TRIGGER SLOPE switch. When S460 is set to the positive slope position, U460A and U460D are biased on and U460C and U460F are biased off. For the negative slope position, the transistors reverse states to invert the comparator output polarity.

Schmitt Trigger and TV Trigger Circuit

This circuitry generates a signal that drives the Trigger Logic as a function of the Trigger Level Comparator output signal and the TRIGGER MODE switches.

The output signals from the Trigger Level Comparator drive Q400 and Q401. These transistors are configured as a current mirror that converts the differential output to a single-ended current to drive amplifier U480C. Potentiometer R481 corrects for dc offsets between positive and negative slope. Shuntfeedback amplifier U480C converts a current input to a voltage output to drive the input of the Schmitt Trigger, U480D, through R485. Positive feedback for the Schmitt Trigger is provided by potentiometer R489, and C489 reduces trigger jitter increasing positive feedback at higher frequencies. The setting of R489 determines the circuit hysteresis.

When TV FIELD is not selected, the $\overline{\text{TVF}}$ line is HI, and is buffered by Q487. Transistors Q488 and Q489 are biased off and a LO is placed on one input of U480A by R492-R493. This LO input will cause U480A to invert the output from U480D. With Q489 off, a LO will be placed on one input of U480B by R495 and U480B will also act as an inverter. The Trigger signal at the output of U480B is therefore the same as the input signal to U480A.

When TV FIELD is selected, the $\overline{\text{TVF}}$ line is LO, and is buffered by Q847. The outputs of U480D will determine the conduction states of Q488 and Q489, and the input of U480A connected to R492 will be HI. The output of U480A will be LO and U480B will invert signal at its other input. Signals at the collector of Q489 are filtered by C495, R495, and C496 to reject
TV video information and average the TV horizontalsync pulses. Setting the trigger-level threshold near the center of the horizontal-sync-pulse swing establishes the untriggered level. When the TV vertical-sync-block occurs, the output of the filter applied to U480B pin 7 rises to a level that will cause U480B to switch. Precise TV field synchronization is obtained as a result of this filtering action. The Trigger signal output will be the inverse of the filtered signal appearing at U480B pin 7.

SWEEP GENERATOR AND LOGIC

The Sweep Generator and Logic circuitry, shown on Diagrams 4 and 5, produce a linear voltage ramp that drives the Horizontal Preamplifier. The Sweep Generator circuit also produces signals that are used to generate correct timing of the crt unblanking and intensity levels used for viewing the display. See Figure 3–3 for the block diagram of the Sweep Generator and Logic circuitry.

Miller Sweep Generator

The Miller Sweep Generator produces a linear voltage ramp that drives the Horizontal Amplifier. It produces the ramp voltage by maintaining a constant current through timing capacitors, causing a linear voltage rise across them as they charge.

Field-effect transistors Q704A and Q704B are matched devices with Q704B acting as the current source for Q704A. Since the gate and source of Q704B are connected together, the source current available to Q704A is just enough so that there is no voltage drop across the gate-source junction of Q704A.

When the sweep is not running, Q701 is biased on, holding the selected timing capacitors in a discharged state. The low impedance of Q701 in the feedback path holds the Miller Sweep output near ground potential. The voltage across Q701, in addition to the base-emitter voltage of Q706, prevents saturation of the output device.



Figure 3-3. Block diagram of the Sweep Generator and Logic.

The sweep ramp starts when Q536 is biased off. The GATE signal going to the base of Q701 from the Sweep Logic circuit turns Q701 off. The timing capacitors then begin charging at a rate set by timing resistors R701, R702 and the position of the SEC/DIV switch S701. One end of timing resistor R701 is connected to the wiper of R721 and the other end is connected to the input of the Miller integrator. Due to feedback from the circuit output through the timing capacitors, the integrator input voltage at the gate of Q704A remains fixed and sets a constant voltage across the timing resistors. This constant voltage produces a constant charging current through the timing capacitors, which results in a linearly increasing voltage ramp at the output of the Miller Sweep circuit.

When the ramp reaches about 12 V, the Sweep Logic circuitry starts the holdoff period in which Q701 is turned on and the Sweep Generator is reset. This holdoff period is necessary so that the timing capacitors can be fully discharged before another sweep starts. Capacitors C704 and C703 are always in the charging circuit and are used for high sweep speeds. For medium sweep speeds, capacitors C701 and C702 are in series. For slow sweep speeds, only capacitor C701 is used.

The SEC/DIV Variable circuitry uses an operational amplifier to maintain a constant reference voltage at one end of R721 independent of the circuit load. The voltage applied to the timing resistors varies with the rotational position of R721, the SEC/DIV Variable control. A fixed dc voltage is applied to the noninverting input of the operational amplifier, and feedback resistors R717 and R718 establish double that voltage at the anode of VR719. Potentiometer R722 adjusts the reference voltage when in 0.5 ms to 10 μ s SEC/DIV ranges to correct for mismatch between timing capacitors C701 and C702.

Sweep Logic

The Sweep Logic circuitry controls sweep generation, as a function of incoming trigger signals and the Trigger mode selected.

NORM. When NORM trigger is selected, the circuit is ready to start the sweep in response to a trigger signal. At the start of the sweep, a U530B has a LO on SET (pin 12), RESET (pin 13), and D input (pin 10). A trigger pulse received at U530B (pin 11) will clock the LO on the D input to the Q output and enable the sweep to start. The output of the sweep generator is fed back via W701-4 into the potential divider R501 and R502. This divider is arranged so that when the ramp voltage reaches about 12 V, U560E is turned on, producing a LO on the input of

inverter U520A. The inverted signal of U520A is applied to the input of U520B. The signal from U520B is inverted by U520C to produce an OR function, then fed to the SET input (pin 12) of U530B. This overrides the CLOCK input of U530B and puts a HI on the Q output (pin 15), resetting the sweep. The sweep reset is also fed to the input (pin 12) of the monostable U500B, which gives a holdoff time dependent on the holdoff capacitor selected and the variable holdoff resistor chain. The holdoff pulse from the monostable maintains the HI on the SET input of U530B until the end of the holdoff period, then the SET is driven LO, allowing the next trigger pulse to start the sweep.

P-P AUTO. In the P-P AUTO mode, the sweep will free-run in the absence of a trigger signal. Should there be more than 50 ms between trigger pulses, the Auto Baseline circuitry consisting of U580B, U520D, U570A and U570B will start a sweep. U580B is a 20 Hz clock pulse generator. This signal is passed through Schmitt trigger U520D to provide a fast rise time. This is to ensure that both D inputs of U570A and U570B switch at the same time.

With no trigger signal, the first clock pulse from U580B resets U570A, putting a HI on D input of U570B. This will then be clocked (giving a LO on TRIGGERED) when the next 50 ms pulse arrives. If the end of sweep has occurred and the holdoff period has elapsed, then the output of U520C will be LO. Because TRIGGERED and P-P AUTO are both LO, the output of U550D will put a LO on pin 7 of U550B. As the other input is also LO, the output of U520B will put a HI on pin 13 of U530B, forcing GATE LO and starting a sweep.

If a trigger occurs, the HI on the D pin of U570A is passed to the Q output of U570A, to resets U570B, and put a HI on the TRIGGERED line. The output of U550B will be LO, allowing U530B to respond to the next trigger signal. When the TRIGGERED line is HI, the TRIG'D/READY LED is turned on via U550A.

SINGLE SWEEP. When the SINGLE SWEEP mode is selected, the SINGLE SWEEP line is LO, holding the D input of U570A LO and effectively disabling the Auto Baseline circuitry. This action also puts a LO on the TRIGGERED line. At the end of a sweep, the holdoff pulse is latched by U530A via U520B and U550C, and the D input of U530B is driven HI and the sweep is disabled. The sweep is enabled by a pulse from the single shot monostable U500A, which clocks the LO on the D input of U530A to the Q output. With a LO at the Q output of U530A, the next trigger signal will start a sweep. Switch debounce circuit U500A along with the timing components R506 and C506 will give a pulse width of about 30 ns, which is shorter than the fastest sweep speed. U500A also sets U510B turning on the TRIG'D/READY LED via U550A. When the holdoff period starts (and

U500A has timed out), U500B will clock a LO back onto the Q output of U540B, allowing the TRIG'D/ READY LED to be extinguished.

X-Y. In the X-Y mode of operation, the \overline{XY} line is LO, holding the input of U520A LO through CR521. The output of U520A via U520B and U520C will hold U530B set and no sweep can be started.

HORIZONTAL

The Horizontal Amplifier circuit, shown on Diagram 5 provides the output signals that drive the horizontal crt deflection plates. Signals applied to the Horizontal Preamplifier can come from either the Miller Sweep Generator (for sweep deflection) or from the XY Amplifier (when X-Y display mode is selected). See Figure 3-4 for the block diagram of the Horizontal Amplifier.

The Horizontal Position control, X10 magnifier circuitry, and the horizontal portion of the Beam Find circuitry are also contained in the Horizontal Amplifier Circuit.

X-Y Amplifier

In the X-Y mode of operation, the \overline{XY} signal (buffered by Q736) is low, biasing Q732 in the linear region. Transistors Q732 and Q737 are a transconductance amplifier that changes an input voltage to output current. The input signal is applied through gain adjust R395. The X Offset adjustment is R736. The signal current flowing out of Q737 is fed into the shunt feedback stage. The sweep is held at a constant low output level when in X-Y mode.

When in sweep mode, the \overline{XY} line is high and biases Q732 off, that biases Q737 off and disables the XY amplifier. The \overline{XY} line also turns on U380B, thereby not allowing the X axis signal to get to the amplifier. The sweep signal is applied through R740 and the gain setting resistor (R744) to the Horizontal Preamplifier stage.

Horizontal Preamplifier

The Horizontal Preamplifier amplifies input signals for application to the Horizontal Output Amplifier.



Figure 3-4. Block diagram of the Horizontal Amplifier.

The preamplifier is a cascode differential pair. The gain is set by the network connected between pins 7 of U755C and 10 of U755D. With MAG switch S601 in X1, the X1 MAG line is high, Q760 and U745E are off, and the current sources consisting of U745A and U755A are on for normal operation with the gain set by R763. When MAG switch is X10, the X1 MAG signal is LO, Q760 and U745E saturate, and the current sources consisting of U755B and U745B are on. This forward biases CR773 and CR774, a low impedance is switched in, and the X10 timing adjustment is made using X10 Mag Gain R777. Magnifier registration is adjusted by R782 so that there is no horizontal trace shift when switching between the X10 and X1 positions. The X1 MAG line is held at a constant high when in X-Y mode.

The sweep signal, or the X-Axis signal (depending on mode of operation) with the horizontal position signal from R726, is buffered by Q750 and Q759 and applied pin 6 of U745C. Pin 9 of U745D is held to a fixed voltage level by Q725. The horizontal position signal adjusts the trace horizontally in both the sweep and X-Y modes.

Horizontal Output Amplifier

The Horizontal Output Amplifier provides final amplification of the horizontal signal to drive the horizontal crt deflection plates.

Signals from the Horizontal Preamplifier circuit are used to drive two shunt feedback amplifiers. The feedback makes the input impedance of these amplifiers low. The base voltages of Q770 and Q780 are at nearly the same dc level due to forwardbiased diodes CR781 and CR791 between the two emitters.

Transistors Q770, Q775, and Q779 form a cascode feedback amplifier for driving the right horizontal crt deflection plate with R784 and R785 setting amplifier gain and C783 providing high frequency compensation. For low-speed signals Q779 serves as a current source for Q775, and at high sweep rates, the ramp is coupled through C785 to the emitter of Q779. This provides additional pull-up output current to drive the crt at high sweep rates. The amplifier, consisting of Q780, Q785, and Q789, drives the left horizontal crt deflection plate as described above with zener diode VR792 level shifting the collector signal of Q780.

The BEAM FIND function is turned on when S390 is closed and the Beam Find signal is connected to the negative supply. Q776 saturates, the cathode voltage of VR776 goes negative, and CR780 and CR890 become forward biased. Current though these diodes causes the output common-mode

voltage of the two shunt-feedback amplifiers to be shifted positively to reduce the available voltage swing at the crt plates. This prevents the trace from being deflected off-screen horizontally.

Z-AXIS AMPLIFIER

The Z-Axis Amplifier, shown on Diagram 7, controls the crt intensity level via several input-signal sources. The effect of these input signals is either to increase or decrease trace intensity or to completely blank portions of the display. The Z-Axis signal current, as determined by the Z-Axis switching logic and the input current from the EXT INPUT OR Z connector (if in use), are summed at the emitter of common-base amplifier Q825 and thereby sets the collector current of the stage. The common-base amplifier provides a low-impedance termination for the input signals and isolates the signal sources from the rest of the Z-Axis Amplifier.

Common-base transistor Q829 passes a constant current through R832. This current is divided between Q825 and Q829, with the portion through Q829 driving the shunt-feedback output amplifier formed by Q835, Q840, and Q845. The bias level of Q825 therefore controls the emitter current available to Q829. The shunt feedback-resistors of R841 and R843 sets the transresistance gain for changing the input current to a proportional output voltage. Emitter-follower Q835 is dc coupled to Q840 and, for low-speed signals, Q845 acts as a current source. Fast transitions couple through C845 providing added current gain through Q845 for fast voltage swings at the output of the Amplifier.

External Z-Axis input voltages establish proportional input currents through R823, and Amplifier sensitivity is determined by the transresistance gain of the shunt-feedback amplifier.

The INTENSITY potentiometer controls the base voltage of Q804 to set the amount of emitter current that flows through that transistor and, therefore, the level of the Z-Axis signal.

When the sweep is displayed, the emitter of Q817 is LO, causing CR817 to be reverse biased. This allows the current through R818 to flow through CR818 and turn on the Z-Axis.

When X-Y is displayed, CR817 is forward biased, reverse biasing CR818. Transistor Q818 is reverse biased allowing the intensity to be set by the current through R820 and CR820.

When CHOP VERTICAL MODE is selected, the CHOP BLANK signal is sent to the collector of Q825 through CR824 during the display-switching time. Diode CR825 is reverse biased and the forward bias

of Q829 rises to the blanking level. When blanked, the output of the Z-Axis Amplifier drops to reduce the crt beam current below viewing intensity.

When the BEAM FIND button is pressed, the BEAM FIND line goes to about -8V sinking about 1 mA from the Z-Axis Amplifier, over-riding any other current combinations, and therefore unblanking the trace.

DC Restorer

The DC Restorer circuit sets the crt control-grid bias and couples the ac and dc components of the Z-Axis Amplifier output to the crt control grid. Direct coupling of the Z-Axis Amplifier output to the crt control grid is not employed because of the high potential differences involved. Refer to Figure 3-5 during the following discussion. Ac drive to the DC Restorer circuit is obtained from pin 3 of T902. The drive voltage has an ac peak amplitude of about 100V, at a frequency of about 20 kHz and is coupled into the DC Restorer circuit through C853 and R853. The cathode of CR851 is biased by the wiper voltage of Grid Bias potentiometer R851, and the ac drive voltage is clamped whenever the positive peaks reach a level that forward biases CR851.

The Z-Axis Amplifier output voltage, which varies between +10 V and +75 V, is applied to the DC Restorer at the anode of CR853. The ac drive voltage holds CR853 reverse biased until the voltage falls below the Z-Axis Amplifier output voltage level. At that point, CR853 becomes forward biased and clamps the junction of CR851, CR853, and R854 to the Z-Axis output level. Thus, the ac-drive voltage is clamped at two levels to produce a square-wave signal with a positive dc-offset level.



Figure 3-5. Simplified diagram of the Dc Restorer.

The DC Restorer is referenced to the -1.8 kV crt cathode voltage through R858 and CR854. Initially, both C855 and C854 charge up to a level determined by the difference between the Z-Axis output voltage and the crt cathode voltage. Capacitor C855 charges from the Z-Axis output through R858, CR854, and CR855, to the crt cathode. Capacitor C854 charges through R858, CR854, R854, and CR853 to the crt cathode.

During the positive transitions of the ac drive, from the lower clamped level toward the higher clamped level, the charge on C854 increases. The voltage increase across C854 is equal to the amplitude of the positive transition. The negative transition is coupled through C854 to reverse bias CR854 and to forward bias CR855. The increased charge of C854 is then transferred to C855 as C854 discharges toward the Z-Axis output level. Successive cycles of the ac input to the DC Restorer charge C855 to a voltage equal to the initial level plus the amplitude of the clamped square-wave input.

The added charge held by C855 sets the controlgrid bias voltage. If more charge is added to that already present on C855, the control grid becomes more negative, and less crt writing-beam current flows. Conversely, if less charge is added, the control-grid voltage level becomes closer to the cathode-voltage level, and more crt writing-beam current flows.

During periods that C854 is charging, the crt control-grid voltage is held constant by the long time-constant discharge path of C855 through R860.

Fast-rise and fast-fall transitions of the Z-Axis output signal are coupled to the crt control grid through C855 to start the crt writing-beam current toward the new intensity level. The DC Restorer output level then follows the Z-Axis output-voltage level to set the new bias voltage for the crt control grid.

Neon lamps DS858 and DS856 protect the crt from excessive grid-to-cathode voltage if the potential on either the control grid or the cathode is lost for any reason.

CRT Supply

The voltage doubler of CR975, CR976, and C980 produces -1.8 kV for the crt cathode. The -1.8 kV supply is filtered by a low-pass filter formed by R976, R978, C976, and C979.

Focus Circuit

Focus voltage is developed from the -1.8 kV supply by a voltage divider formed by R894 and R892 and FOCUS potentiometer R893.

POWER SUPPLY AND PROBE ADJUST

The Power Supply circuitry converts the ac power line voltage into the voltages needed for instrument operation. It consists of Ac Power Input, Start–Up, Current Control, Regulator, and Inverter circuits on the primary side of the high frequency power transformer. The secondary side of the high frequency power transformer provides the necessary supply voltages for the instrument. See Figure 3–6 for the block diagram of the Power Supply.

Ac Power Input

LINE SWITCHING. Ac line voltage of either 115 V or 230 V may provide the primary power for the instrument, depending on the setting of the LINE VOLTAGE SELECTOR switch S902. POWER switch S901 connects the selected line voltage to the primary winding of the transformer T901 via fuse F901. The ac line voltage is filtered by L901, L902, C903, C904, and C905.

LINE RECTIFIER. The secondary of T901 is rectified by CR901, CR902, CR903, and CR904 and filtered by C900. The rectified voltage is about 60 V and is applied to the power supply Start-Up circuit and Current Source.

Start-UP

The control circuits for the power supply require a separate power supply to operate. The independent power supply consists of Q982, Q985, Q988, and associated components.

Initially, when instrument power is applied, the positive plate of capacitor C982 is charged toward the 60 V supply through the resistor string R984, R983, and R970.

When the voltage across C982 reaches about 45 V, a 3 V drop occurs across R987 causing Q985 and Q988 to conduct. The collector current of Q985 passes through VR982, placing 16 V at the base of the emitter follower Q982. Emitter of Q982 drives the 15 V supply. This allows current flow through R989 to the base of Q988, keeping it on. Transistor Q988 is now being kept on by the 15 V supply instead of the 45 V across C982. As long as the 15 V supply remains above the 12 volt level, the positive feedback through R989 will keep Q988 saturated.



Figure 3-6. Block diagram of the Power Supply.

After the initial startup, current passed by Q982 is applied through CR980 via R971 and R980 instead of C982. If there is not enough current to C982, the 15 V supply will drop below the 12 V level turning off Q982, Q985 and Q988.

Current Source and Current Switching

The Current Source and Current Switching circuits provides a regulated dc current that produces 20 V for the high frequency power transformer T902 from the 60 V supply.

CURRENT SOURCE. The Current Source circuit is made up of power MOSFET Q933, inductor L950 and associated components. This circuit provides a triangle-shaped current pulse on top of the dc current (about 1.5 A) to transformer T902. The peak amplitude of the triangle-shaped current pulse is determined by the load requirements. The rise time varies with the voltage level of the 60 V (45 V to 75 V); the fall time is fixed at 8 μ s.

A triangle current signal is developed across L950 by the switching of Q933. With MOSFET Q933 turned on, the 60 V supply from the line rectifier is

applied to one end of L950 via Q933. The other end of L950 is held to 20 V by the capacitive load that is reflected through the high frequency power transformer T902. With a 40 V difference across L950, the current in the inductor increases (rising portion of the triangle-shaped current pulse) until Q933 is turned off by the Current Switch circuit. With Q933 turned off, the stored current in L950 will continue to flow to the center tap of T902. The current decreases with the falling portion of the triangle current pulse. Diode CR950 becomes forward biased clamping Q933 drain to ground. This puts 20 V across L950, opposing the current flow. When Q933 turns on, CR950 becomes reversed biased and 60 V supply is applied to L950 again.

CURRENT SWITCHING. The Current Switching circuit applies the TURN OFF signal from the Regulator circuit to the Current Source circuit. The TURN OFF signal controls the load current through L950. The circuit consist of Q935, Q932, and associated components.

When the power is first turned on, C933 is uncharged and the emitter voltage of Q935 is LO (0 V). Capacitor C933 quickly charges toward the 60 V supply through VR932 and VR933. When C933 is charged to the 60 V supply, the source-gate voltage of Q933 is 0 V, turning it off.

Eventually, the 15 V supply comes up. The TURN OFF signal at the base of Q935 goes LO due to insufficient current passing through L950. Transistor Q932 will now start draining some charge from C933, reducing the voltage on C933 enough to turn on Q933. C933 continues to discharge until the voltage across the source-gate of Q933 reaches 9 V causing zeners VR932 and VR933 to conduct.

When the current through L950 reaches a high enough value, the TURN OFF signal to Q935 goes HI (15 V). The 15 V is applied to one end of C933 through Q935. Since the voltage across a capacitor cannot change instantly, the voltage at the top end of C933 makes the same 15 V upward step change. The voltage at the gate of Q933 is now 6 V higher than its source (60 V supply), turning Q933 off. The 15 V level also turns off Q932 . When the TURN OFF signal goes LO, Q932 and Q933 turns on again and the cycle repeats.

Regulator

The Regulator Circuit senses the -8.6 V from the secondary of T902 and load current from the inverter circuit to develop a TURN OFF signal for the Current Control and Inverter circuits.

The -8.6 V from the secondary is applied to one end of R916 -8.6 V potentiometer. The potentiometer R916 sets the reference voltage for U910B.The dc error voltage from U910B is filtered for any ac components by capacitor C925. Zener VR925 clamps the dc error voltage to 3 V and limits the amount of load current from the Current Source to about 3 amps. The dc error voltage is applied to pin 2 of Comparator U920.

The dc error voltage is proportional to the power requirements of the load. For instance, an increase in the load will lower the -8.6 V increasing the amplitude of the dc error voltage. An increase in the amplitude of the dc error voltage means that more current is needed to maintain the -8.6 V level.

Load current from Inverter circuitry is converted to a voltage level by R910 and applied to pin 3 of U910A. The voltage amplification of U910A is 1 V per ampere of load current. This voltage level represents the instantaneous value of load current.

The voltage level on pin 3 of U920 is compared to the dc error voltage on pin 2 of U920. As long as the voltage level on pin 3 remains below the dc error voltage on pin 2, the output of U920 will be high. The high from U920 will not trigger the monostable pulse generator U930. This will hold the output of U930 in a low state and keep Q933 turned on. The load current will continue to increase until the voltage level on pin 3 exceeds the dc error voltage on pin 2 causing the output of U920 to change state from HI to LO. This LO is applied to pin 2 (trigger input) of U930. The TURN OFF signal from the output of U930 goes HI for a predetermined length of time (about 8 μ s).

With the Current Source (Q933) turned off, the load current voltage from U910A decreases below the level of the dc error voltage. This will put a high on the output of U920 and, when U930 times out, the TURN OFF signal goes back to LO and starts the cycle over again.

Inverter

The Inverter circuit alternately switches current through each leg of the primary winding of the output transformer T902. This switching action produces ac currents in the secondary windings of the output transformer. The inverter circuit consists of D-type, flip-flop switches and power switches connected as discrete Darlington pairs.

The TURN OFF signal from U930 clocks D-type flip-flop U940. The Q and \overline{Q} output of U940 are inverted from each other, and change state only on the leading edge of the clock signal. Although the on time of the pulse generator is not identical to the off time, the period of the on time plus the off time is the same from one cycle to the next. The output switching of U940 will produce a square wave with a 50% duty cycle to the inverter switches.

The two outputs of U940 are applied to the drivers Q939 and Q943. The drivers turn the power switches (Q941 and Q942) (Q945 and Q946) on and off alternately to produce an ac voltage in the secondary winding of the output transformer.

When Q output of U940 goes HI, power switch Q939 conducts and pulls the collector and one end of R941 to 0 V. The base of Q941 and Q942 goes to -2 V causing the emitter-base to become reverse biased turning the inverter switch off. When Q output goes LO, Q939 turns off and inverter switch emitter to base becomes forward biased, turning it on. The output of \overline{Q} performs in the same way as Q output for the other leg of the primary winding of the output transformer.

Low-Voltage Supplies

The secondary windings of T902 provides various ac voltages for rectification. The 200 V supply uses a voltage doubler consisting of CR983, CR984, C985, and C983. The 100 V is rectified by CR985 and filtered by C984. The diode bridge consisting of CR986, CR987, CR988, and CR989 produces the 8.6 V and -8.6 V. Filtering of the 8.6 V is done by C986, C987 and L986; filtering of the -8.6 V is done by C988, C989 and L988. The 5.2 V supply is produced by CR990 and CR991 and filtered by C990, C991, and L990.

CRT Supply

The 900 V from the high-voltage winding of T902 is doubled by C980, CR975, and CR976 to produce -1.8 kV for the crt cathode. The -1.8 kV supply is filtered by a low-pass filter formed by R976, R978, C976, and C979. Neon lamps DS853 and DS856 protect against excessive voltage between the crt cathode and crt grid by conducting if the difference exceeds about 180 V.

Focus Circuit

Focus voltage is also developed from the -1.8 kV supply by a voltage divider formed by R892, R894, FOCUS potentiometer R893, R888, R889, R890, and R891.

Line Signal

Transistor Q900 is a floating differential amplifier with a dc bias network comprising R905, R904 and R902. Resistors R906 and R903 apply a small line frequency signal from the secondary of T901 to the base-emitter junction of Q900. The resultant collector current of Q900 is a line-frequency sine-wave that is applied to the trigger circuit.

Probe Adjust

£

The Probe Adjust circuitry, shown on Diagram 4, is a square-wave generator and diode switching network that produces a negative-going square-wave signal at PROBE ADJUST connector J590. Amplifier U580a forms a multivibrator that has an oscillation period set by the time constant of R587 and C587. When the output of the multivibrator is at the positive supply voltage, CR588 is forward biased. This reverse biases CR589, and the PROBE ADJUST connector signal is held at ground potential by R590. When the multivibrator output switches states and goes to the negative supply voltage level, CR588 is reverse biased. Diode CR589 becomes forward biased, and the circuit output level drops to about -0.5V.

PERFORMANCE CHECK PROCEDURE

INTRODUCTION

PURPOSE

The Performance Check Procedure is used to verify the instrument's Performance Requirements statements listed in Table 1–1 and to determine the need for calibration. The performance checks may also be used as an acceptance test or as a preliminary troubleshooting aid.

PERFORMANCE CHECK INTERVAL

To ensure instrument accuracy, check its performance after every 2000 hours of operation, or once each year if used infrequently. A more frequent interval may be necessary if the instrument is subjected to harsh environments or severe usage.

STRUCTURE

The Performance Check Procedure is structured in subsections to permit checking individual sections of the instrument whenever a complete Performance Check is not required. At the beginning of each subsection there is an equipment-required list showing only the test equipment necessary for performing the steps in that subsection. In this list, the Item number that follows each piece of equipment corresponds to the Item number listed in Table 4–1.

Also at the beginning of each subsection is a list of all the front-panel control settings required to prepare the instrument for performing Step 1 in that subsection. Each succeeding step within a particular subsection should then be performed, both in the sequence presented and in its entirety, to ensure that control-setting changes will be correct for ensuing steps.

TEST EQUIPMENT REQUIRED

The test equipment listed in Table 4–1 is a complete list of the equipment required to accomplish both the Performance Check Procedure in this section and the Adjustment Procedure in Section 5. Test equipment specifications described in Table 4–1 are the minimum necessary to provide accurate results. Therefore, equipment used must meet or exceed the listed specifications. Detailed operating instructions for test equipment are not given in this procedure. If more operating information is required, refer to the appropriate test equipment instruction manual.

When equipment other than that recommended is used, control settings of the test setup may need to be altered. If the exact item of equipment given as an example in Table 4–1 is not available, check the Minimum Specification column to determine if any other available test equipment might suffice to perform the check or adjustment.

LIMITS AND TOLERANCES

The limits and tolerances given in this procedure are valid for an instrument that is operating in and has been previously calibrated in an ambient temperature between +20°C and +30°C. The instrument also must have had at least a 20-minute warm-up period. Refer to Table 1-1 for tolerances applicable to an instrument that is operating outside this temperature range. All tolerances specified are for the instrument only and do not include testequipment error.

PREPARATION FOR CHECKS

٤

It is not necessary to remove the instrument cover to accomplish any subsection in the Performance Check Procedure, since all checks are made using operator-accessible front- and rearpanel controls and connectors.

The most accurate display checks are made with a stable, well-focused, low-intensity display. Unless otherwise noted, adjust the INTENSITY, FOCUS, and Trigger LEVEL controls as needed to view the display.

Table 4-1

Test Equipment Required

Item and Description	Minimum Specification	Purpose	Example of Suitable Test Equipment
1. Calibration Generator	Standard-amplitude signal levels: 5 mV to 50 V. Accuracy: ±0.3%. High-amplitude signal levels: 1 V	Signal source for gain and transient responses.	TEKTRONIX PG 506 Calibration Generator. ^a
	to 60 V. Repetition rate: 1 kHz. Fast-rise signal level: 1 V.		
	Repetition rate: 1 MHz. Rise time: 1 ns or less. Flatness: <u>+</u> 0.5%.		
2. Leveled Sine-Wave Generator	Frequency: 250 kHz to above 100 MHz. Output amplitude: variable from 10 mV to 5 V p-p. Output impedance: 50 Ω . Reference frequency: 50 kHz. Amplitude accuracy: constant within 3% of reference frequency as output frequency changes.	Vertical, horizontal, and triggering checks and adjustments. Display adjustments and Z-Axis check.	TEKTRONIX SG 503 Leveled Sine-Wave Generator. ^a
3. Time-Mark Generator	Marker outputs: 10 ns to 0.5 s. Marker accuracy: ±0.1%. Trig- ger output: 1 ms to 0.1 μs, time-coincident with markers.	Horizontal checks and adjustments. Display adjustment.	TEKTRONIX TG 501 Time-Mark Generator. ^a
 Test Oscilloscope with 10X Probes 	Bandwidth: dc to 50 MHz, Minimum deflection factor: 5 mV/div. Accuracy:±3%.	General troubleshoot- ing, holdoff check.	TEKTRONIX 2225 Oscilloscope.
5. Digital Voltmeter (DMM)	Range: 0 to 250 V. Dc voltage accuracy: ±0.15%, 4-1/2 digit display.	Power supply checks and adjustments. Vertical adjustment.	TEKTRONIX DM 501A Digital Multimeter. ^a
6. Coaxial Cable (2 required)	Impedance: 50Ω . Length: 42 in. Connectors: BNC.	Signal interconnection.	Tektronix Part Number 012-0057-01.
7. Dual Input Coupler	Connectors: BNC female-to- dual-BNC male.	Signal interconnection.	Tektronix Part Number 067-0525-01.
8. Termination	Impedance: 50 Ω Connectors: BNC.	Signal termination.	Tektronix Part Number 011-0049-01.
9. 10X Attenuator	Ratio: 10X. Impedance: 50Ω . Connectors: BNC.	Vertical compensation and triggering checks.	Tektronix Part Number 011-0059-02.
10. Adapter	Connectors: Miniature probe tip to BNC adapter.	Signal interconnection.	Tektronix Part Number 013-0084-02.
11. Alignment Tool	Length: 1-in. shaft. Bit size: 3/32 in. Low Capacitance: insulated.	Adjust variable capacitors.	Tektronix Part Number 003-0675-00.
12. 10X Probe	Bandwidth: 50 MHz. Length: 2 m.	Probe Adjust check.	Tektronix P6103

^aRequires a TM 500-Series Power Module.

INDEX TO PERFORMANCE CHECK STEPS

Vertical

Page

1.	Check Deflection Accuracy and
	Variable Range 4-4
2.	Check Bandwidth 4-4
3.	Check Channel Isolation 4-5
4.	Check Common-Mode Rejection Ratio 4-5

Horizontal

1.	Check	Timing	Accuracy	and	Linearity	• • • • •	4–6
----	-------	--------	----------	-----	-----------	-----------	-----

2. Check Position Range 4-7

Trigger

1.	Check	Internal	Triggering		4–9
----	-------	----------	------------	--	-----

- 2. Check External Triggering 4-10
- 3. Check External Trigger Ranges 4-10
- 4. Check Single Sweep Operation 4-10

External Z-Axis and Probe Adjust

£.

- 1. Check External Z-Axis Operation 4-12
- 2. Check Probe Adjust Operation 4-12

VERTICAL

Equipment Required (See Table 4-1):

Calibration Generator (Item 1) Leveled Sine-Wave Generator (Item 2) $50-\Omega$ Coaxial Cable (Item 6) Dual-Input Coupler (Item 7) $50-\Omega$ Termination (Item 8)

INITIAL CONTROL SETTINGS

Vertical

POSITION (both)	Midrange
MODE	CH 1,NORM
VOLTS/DIV (both)	5 mV
VOLTS/DIV Variable (both)	CAL detent
AC-GND-DC	DC

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	0.5 ms
SEC/DIV Variable	CAL detent

the CH 1 VOLTS/DIV Variable control to the CAL detent and continue with the 50-mV check.

c. Move the cable from the CH 1 OR X input connector to the CH 2 OR Y input connector. Set the Vertical MODE switch to CH 2.

d. Repeat part b using the Channel 2 controls.

e. Disconnect the test equipment from the instrument.

2. Check Bandwidth

a. Set:

VOLTS/DIV (both)	5 mV
SEC/DIV	10 ms

Trigger

SLOPE	Positive ()
LEVEL	Midrange
MODE	P-P AUTO
SOURCE	VERT MODE

PROCEDURE STEPS

1. Check Deflection Accuracy and Variable Range

a. Connect a 20-mV standard-amplitude signal from the calibration generator via a 50- Ω coaxial cable to the CH 1 OR X input connector.

b. CHECK-Deflection accuracy is within the limits given in Table 4-2 for each CH 1 VOLTS/DIV switch setting and corresponding standardamplitude signal. When at the 20-mV VOLTS/DIV switch setting, rotate the CH 1 VOLTS/DIV Variable control fully counterclockwise and check that the display decreases to 2 divisions or less. Then return

Table 4-2
Deflection Accuracy Limits

VOLTS/DIV Switch Setting	STANDARD Amplitude Signal	ACCURACY Limits (Divisions)
5 m ⁱ V	20 mV	3.88 to 4.12
10 mV	50 mV	4.85 to 5.15
20 mV	0.1 V	4.85 to 5.15
50 mV	0.2 V	3.88 to 4.12
0.1 V	0.5 V	4.85 to 5.15
0.2 V	1 V	4.85 to 5.15
0.5 V	2 V	3.88 to 4.12
1 V	5 V	4.85 to 5.15
2 V .	10 V	4.85 to 5.15
5 V	20 V	3.88 to 4.12

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable and a 50- Ω termination to the CH 2 OR Y input connector.

c. Set the generator to produce a 50-kHz, 6-division display.

d. Increase the signal frequency until a 4.2-division display is obtained.

e. CHECK-The frequency is greater than 20 MHz.

f. Repeat parts c through e for all VOLTS/DIV settings from 10 mV to 5 V, up to the output-voltage upper limit of the sine-wave generator being used.

g. Move the cable from the CH 2 OR Y input connector to the CH 1 OR X input connector. Set the Vertical MODE switch to CH 1.

h. Repeat parts c through e for all indicated CH 1 VOLTS/DIV switch settings, up to the output-voltage upper limit of the sine-wave generator being used.

3. Check Channel Isolation

a. Set:

CH 1 VOLTS/DIV	1 V
CH 2 VOLTS/DIV	0.5 V
Channel 2 AC-GND-DC	GND
SEC/DIV	0.05 ms

b. Set the generator to produce a 20-MHz, 5-division display.

c. Set CH 1 VOLTS/DIV switch to 0.5 V for a 10-division display.

d. Set Vertical MODE switch to CH 2 and ALT.

e. CHECK—The display amplitude is less than 0.1 division.

f. Move the test-signal cable from the CH 1 OR X input connector to the CH 2 OR Y input connector.

g. Set:

Vertical MODE	CH 1
Channel 1 AC-GND-DC	GND
Channel 2 AC-GND-DC	DC

h. CHECK—The display amplitude is less than 0.1 division.

i. Disconnect the test equipment from the instrument.

4. Check Common Mode-Rejection Ratio

a. Set:

٤

VOLTS/DIV (both)	10 mV
Channel 1 AC-GND-DC (both)	DC
Vertical MODE	BOTH,
	NORM,
	and ALT

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable, a 50- Ω termination, and dual-input coupler to the CH1 OR X and CH 2 OR Y input connectors.

c. Set the generator to produce a 10-MHz, 6-division display.

d. Set Vertical MODE switch to CH 2 INVERT and ADD.

e. CHECK-Display amplitude is 0.6 division or less.

f. Disconnect the test equipment from the instrument.

HORIZONTAL

Equipment Required (See Table 4-1):

Calibration Generator (Item 1) Leveled Sine-Wave Generator (Item 2) Time-Mark Generator (Item 3)

 $50-\Omega$ Coaxial Cable (Item 6) $50-\Omega$ Termination (Item 8)

INITIAL CONTROL SETTINGS

Vertical

POSITION (both)	Midrange
MODE	CH 1
VOLTS/DIV (both)	0.5 V
VOLTS/DIV Variable (both)	CAL detent
AC-GND-DC (both)	DC

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	0.05 ms
SEC/DIV Variable	CAL detent

Trigger

SLOPE LEVEL MODE	Positive (_/_) Midrange P-P AUTO	SEC/DIV Horizontal MAG	0.1 μs X10
SOURCE	CH 1	a Select 20-ns time marker	e from the ti

PROCEDURE STEPS

1. Check Timing Accuracy and Linearity

a. Connect 50-ns time markers from the timemark generator via a 50– Ω coaxial cable and a 50– Ω termination to the CH 1 OR X input connector.

b. Adjust the Trigger LEVEL control for a stable, triggered display.

c. Use the Horizontal POSITION control to align the second time marker with the second vertical graticule line.

d. CHECK-Timing accuracy is within 3% (0.24 division at the tenth vertical graticule line), and linearity is within 5% (0.10 division over any 2 of the center 8 divisions).

NOTE

For checking the timing accuracy of the SEC/ DIV switch settings from 50 ms to 0.5 s, watch the time marker tips only at the second and tenth vertical graticule lines while adjusting the Horizontal POSITION controls to line up the time markers.

e. Repeat parts b through d for the remaining SEC/DIV and time-mark generator setting combinations shown in Table 4-3 under "X1 Normal" column.

f. Set:

¢

SEC/DIV	0.1 μs
Horizontal MAG	X10

g. Select 20-ns time markers from the timemark generator.

NOTE

The 20-ns time-markers tips are rounded off and cannot be used as measurement reference points. Use the rising edge of the time markers as measurement reference points. Vertically adjust the 50% point of the time markers on the center horizontal graticule line.

h. Use the Horizontal POSITION controls to align the first time marker that is 50 ns beyond the start of the sweep with the second vertical graticule line.

i. CHECK—Timing accuracy is within 4% (0.32 division at the tenth vertical graticule line), and linearity is within 7% (0.14 division over any 2 of the center 8 divisions). Exclude any portion of the sweep past the 50th magnified division.

j. Repeat parts h and i for the remaining SEC/DIV and time-mark generator setting combinations shown in Table 4-3 under the "X10 Magnified" column.

Table 4-3

Settings for Timing Accuracy Checks

SEC/I		Time-Mark Generator Setting			
Swite Settin		X1 No	ormal	X10 M	agnified
0.1	μs	0.1	μs	20	ns
0.2	μs	0.2	μs	20	ns
0.5	μs	0.5	μs	50	ns
1	μs	1	μs	0.1	μs
2	μs	2	μs	0.2	μs
5	μs	5	μs	0.5	μs
10	μs	10	μs	1	μs
20	μs	20	μs	2	μs
50	μs	50	μs	5	μs
0.1 r	ms	0.1	ms	10	μs
0.2 r	ms	0.2	ms	20	μs
0.5 r	ms	0.5	ms	50	μs
1 r	ns	1	ms	0.1	ms
2 r	ms	2	ms	0.2	ms
5 r	ms	5	ms	0.5	ms
10 r	ms	10	ms	1	ms
20 r	ms	20	ms	2	ms
50 r	ms	50	ms	5	ms
0.1	s	0.1	s	10	ms
0.2	s	0.2	s	20	ms
0.5	s	0.5	s	50	ms

2. Check POSITION Range

a. Set:

SEC DIV	0.1 ms
Horizontal MAG	X1

b. Select 0.1 ms time markers from the time-mark generator.

c. CHECK—The start of the sweep can be positioned to the right of the center vertical graticule line by rotating the Horizontal POSITION control fully clockwise.

d. CHECK—The tenth time marker can be positioned to the left of the center vertical graticule line by rotating the Horizontal POSITION control fully counterclockwise.

e. Select 0.5 ms time markers from the time-mark generator.

f. Align the 3rd time marker with the center vertical graticule line using the Horizontal POSITION control.

g. Set the Horizontal MAG switch to X10.

h. CHECK—Magnified time marker can be positioned to the left of the center vertical graticule line by rotating the Horizontal POSITION control fully counterclockwise.

i. CHECK--Start of the sweep can be positioned to the right of the center vertical graticule line by rotating the Horizontal POSITION control fully clockwise.

3. Check Variable Range

a. Set the Horizontal MAG switch to X1 and center the display.

b. Set the SEC/DIV Variable control fully counterclockwise.

c. CHECK-The spacing between time markers is 2 divisions or less.

d. Return the SEC/DIV Variable knob to the CAL detent position.

e. Disconnect the test equipment from the instrument.

4. Check X Gain

a. Set:

VOLTS/DIV (both)	10 mV
SEC/DIV	X-Y

b. Connect a 50-mV, standard-amplitude signal from the calibration generator via a 50- Ω coaxial cable to the CH 1 OR X input connector.

c. CHECK—The display is between 4.85 and 5.15 divisions.

d. Disconnect the test equipment from the instrument.

5. Check X Bandwidth

a. Set both channels VOLTS/DIV switches to 50 mV.

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

c. Set the generator to produce an 8-division horizontal display at an output frequency of 50 kHz.

d. Increase the output frequency until the X-Axis (horizontal) deflection amplitude is 5.7 divisions.

e. CHECK-The frequency is 2 MHz or greater.

f. Disconnect the test equipment from the instrument.

ŝ

TRIGGER

Equipment Required (See Table 4-1):

Leveled Sine-Wave Generator (Item 2) $50-\Omega$ Coaxial Cable (Item 6)

Dual-Input Coupler (Item 7) $50-\Omega$ Termination (Item 8)

INITIAL CONTROL SETTINGS

combination given in Table 4-4. Ensure that the TRIG'D light comes on when triggered.

Vertical

POSITION (both)	Midrange
MODE	CH 1, NORM
CH 1 VOLTS/DIV	0.1 V
CH 2 VOLTS/DIV	1 V
VOLTS/DIV Variable (both)	CAL detent
AC-GND-DC (both)	DC

Horizontal

POSITION (COARSE and FINE) MAG	Midrange X1
SEC/DIV	0.2 ms
SEC/DIV Variable	CAL detent

Trigger

SLOPE	Positive ()
LEVEL	Midrange
MODE	P-P AUTO
SOURCE	VERT MODE

PROCEDURE STEPS

1. Check Internal Triggering

a. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

b. Set the generator to produce a 3-division display at an output frequency of 5 MHz.

c. Set channel 1 VOLTS/DIV switch to 1 V.

d. CHECK-Stable display can be obtained by adjusting the Trigger LEVEL control for each switch

Table 4-4

Switch Combinations for Triggering Checks

Trigger MODE	Trigger SLOPE
NORM	Positive _/
NORM	Negative ~-
P-P AUTO	Negative ~_
P-P AUTO	Positive -

e. Move the test-signal cable from the CH 1 OR X input connector to the CH 2 OR Y input connector. Set the Vertical MODE switch to CH 2.

- f. Repeat part d.
- g. Set:

SEC/DIV	0.01 ms
Horizontal MAG	X10

h. Set the generator output to produce a 30-MHz, 1-division display.

i. Repeat part d.

j. Move the test-signal cable from the CH 2 OR Y input connector to the CH 1 OR X input connector. Set the Vertical MODE switch to CH 1.

k. Repeat part d.

I. Disconnect the test equipment from the instrument.

2. Check External Triggering

a. Set:

CH 1 VOLTS/DIV	20 mV
SEC/DIV	0.2 ms
Horizontal MODE	X1
Trigger MODE	P-P AUTO
Trigger SOURCE	EXT, EXT

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable, a 50- Ω termination, and a dual-input coupler to the CH 1 OR X input connector and EXT INPUT OR Z input connectors.

c. Set the generator to produce a 4-division (80 mV) horizontal display at an output frequency of 5 MHz.

d. CHECK---Stable display can be obtained by adjusting the Trigger LEVEL control for each switch combination given in Table 4-4.

e. Set:

CH 1 VOLT/DIV	50 mV
SEC/DIV	0.05 ms
Horizontal MODE	MAG

f. Set the generator to produce a 3-division (150 mV) horizontal display at an output frequency of 30 MHz.

g. Repeat part d.

h. Disconnect the test equipment from the instrument.

3. Check External Trigger Range

a. Set:

CH 1 VOLTS/DIV	0.5 V
SEC/DIV	20 ms
Trigger SLOPE	Positive
	()

b. Set the leveled sine-wave generator to produce a 50-kHz, 6.4-division display.

c. Position the waveform equally about the center horizontal graticule line.

d. Set:

Trigger	MODE	NORM
Trigger	SOURCE	EXT, EXT

e. CHECK-Display is triggered along the entire positive slope of the waveform as the Trigger LEVEL control is rotated.

f. CHECK-Display is not triggered at either extreme of rotation of the Trigger LEVEL control.

g. Set the Trigger SLOPE switch to negative (\frown) .

h. CHECK-Display is triggered along the entire negative slope of the waveform as the Trigger LEVEL control is rotated.

i. CHECK-Display is not triggered at either extreme of rotation of the Trigger LEVEL control.

j. Disconnect the test equipment from the instrument.

4. Check Single Sweep Operation

a. Set:

CH 1 VOLTS/DIV	10 mV
SEC/DIV	0.5 ms
Trigger SOURCE	CH 1
Trigger SLOPE	Positive
	()

b. Connect 50-mV, standard-amplitude signal from the calibration generator via a $50-\Omega$ coaxial cable to the CH 1 OR X input connector.

c. Adjust the Trigger LEVEL control to obtain a stable display.

d. Set:

Channel 1 AC-GND-DC	GND
Trigger MODE	SGL SWP

e. Press the SGL SWP RESET button. The TRIG'D/READY LED illuminates and remains on.

f. Set the Channel 1 AC-GND-DC switch to DC.

NOTE

The INTENSITY control may require adjustment to observe the single-sweep trace. g. CHECK-TRIG'D/READY LED goes out and a single sweep occurs.

h. Press the SGL SWP RESET button several times.

i. CHECK—A single-sweep trace occurs, and the TRIG'D/READY LED illuminates briefly every time the SGL SWP RESET button is pressed.

j. Disconnect the test equipment from the instrument.

¢

EXTERNAL Z-AXIS AND PROBE ADJUST

Equipment Required (See Table 4-1):

Calibration Generator (Item 2) Two 50- Ω Coaxial Cable (Item 6) Dual-Input Coupler (Item 7) $50-\Omega$ Termination (Item 8) 10X Probe (Item 12)

INITIAL CONTROL SETTINGS

Vertical

CH 1 POSITION	Midrange
MODE	CH 1, NORM
CH 1 VOLTS/DIV	1 V
CH 1 VOLTS/DIV Variable	CAL detent
Channel 1 AC-GND-DC	DC

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	20 ms
SEC/DIV Variable	CAL detent

Trigger

SLOPE	Positive ()
LEVEL	Midrange
MODE	P-P AUTO
SOURCE	EXT, EXT=Z

PROCEDURE STEPS

1. Check External Z-Axis Operation

a. Connect a 5-V standard-amplitude signal from the calibration generator via dual-input coupler to the CH 1 OR X and EXT INPUT OR Z connectors.

NOTE

The INTENSITY level may need adjustment to view the intensity modulation on the displayed waveform.

b. CHECK—For noticeable intensity modulation. The positive part of the sine wave should be of lower intensity than the negative part.

c. Disconnect the test equipment from the instrument.

2. Check Probe Adjust Operation

a. Set:

CH 1 VOLTS/DIV	10 mV
SEC/DIV	0.5 ms
Trigger SOURCE	CH 1

b. Connect the 10X Probe to the CH 1 OR X input connector and clip the probe tip to the PROBE connector on the instrument front panel. If necessary, adjust the probe compensation for a flat-topped square-wave display.

c. CHECK-Display amplitude is 4.75 to 5.25 divisions.

d. Disconnect the probe from the instrument.

ADJUSTMENT PROCEDURE

INTRODUCTION

PURPOSE

The Adjustment Procedure is used to return the instrument to conformance with the Performance Requirement statements listed in Table 1–1. Adjustments contained in this procedure should only be performed after checks from the Performance Check Procedure (Section 4) have indicated a need for readjustment or after repairs have been made to the instrument.

STRUCTURE

This procedure is structured into subsections, each of which can be performed independently to permit adjustment of individual sections of the instrument. For example, if only the Vertical section fails to meet the Performance Requirements or has been repaired, it can be readjusted with little or no effect on other sections of the instrument.

The Power Supply section, however, affects all other sections of the instrument. Therefore, if repairs or readjustments have been made that change the absolute value of any of the supply voltages, the entire Adjustment Procedure should be performed.

At the beginning of each subsection is a list of all the front-panel control settings required to prepare the instrument for performing Step 1 in that subsection. Each succeeding step within a subsection should be performed in sequence and in its entirety to ensure that control settings will be correct for ensuing steps. All steps within a subsection should be completed.

TEST EQUIPMENT REQUIRED

Table 4–1 is a complete list of the test equipment required to accomplish both the Performance Check Procedure in Section 4 and the Adjustment Procedure in this section. To assure accurate measurements, it is important that test equipment used for making these checks meet or exceed the specifications described in Table 4–1. When considering use of equipment other than that recommended, utilize the Minimum Specification column to determine whether available test equipment will suffice.

Detailed operating instructions for test equipment are not given in this procedure. If more operating information is required, refer to the appropriate test equipment instruction manual.

LIMITS AND TOLERANCES

The limits and tolerances stated in this procedure are instrument specifications only if they are listed in the Performance Requirements column of Table1–1. Tolerances given are applicable only to the instrument undergoing adjustment and do not include test equipment error. Adjustment of the instrument must be accomplished at an ambient temperature between +20°C and +30°C, and the instrument must have had a warm-up period of at least 20 minutes.

ADJUSTMENTS AFFECTED BY REPAIRS

Repairs to a circuit may affect one or more adjustment settings of the instrument. Table 5-1 identifies the adjustment(s) affected due to repairs or replacement of components on a circuit board. Refer to Table 5-1 if a partial procedure is performed or if a circuit requires readjustment due to repairs to a circuit. To use Table 5-1, first find, in the leftmost column, the circuit that was repaired. Then move to the right, across that row, until you come to a darkened square, move up the column and check the accuracy of the adjustment found at the heading of that column. Readjust if necessary.

PREPARATION FOR ADJUSTMENT

The instrument cabinet must be removed to perform the Adjustment Procedure. See the Cabinet remove and replace instructions located in the Maintenance section of the manual. All test equipment items listed in Table 4–1 in the Performance Check Procedure section are required to accomplish a complete Adjustment Procedure. At the beginning of each subsection there is an equipment-required list showing only the test equipment necessary for performing the steps in that subsection. In this list, the item number following each piece of equipment corresponds to the item number listed in Table 4–1.

Before performing this procedure, do not preset any internal adjustments and do not change the -8.6 V power-supply adjustment. Altering this adjustment may necessitate a complete readjustment of the instrument, whereas only a partial adjustment might otherwise be required. Only change an internal adjustment setting if a Performance Characteristic cannot be met with the original setting.

Before performing any procedure in this section, set the POWER switch to ON and allow a 20-minute warm-up period.

The most accurate display adjustments are made with a stable, well-focused, low-intensity display. Unless otherwise noted, adjust the INTENSITY, FOCUS, and Trigger LEVEL controls as needed to view the display.

REPAIRS MADE		INTERNAL ADJUSTMENTS AFFECTED													
	-8.6 V ADJ	GRID BIAS AND GEOM	VAR BAL & INVERT BAL	VERTICAL GAIN	ATTENUATOR COMPENSATION	HIGH-FREQUENCY COMPENSATION	1-mS TIMING	MAGNIFIER GAIN	MAGNIFIER REGISTRATION	0.1-mS AND 0.1-MS TIMING	HIGH-SPEED TIMING	X-Y GAIN AND OFFSET	TRIGGER OFFSET	TRIGGER SENSITIVITY	P-P AUTO LEVEL
POWER SUPPLIES		\overline{V}	\overline{V}	\overline{V}				\overline{V}	$\langle \rangle$					\overline{V}	
VERTICAL ATTENUATORS						\langle / \rangle								\overline{V}	
PREAMPS & CHANNEL SW						\overline{V}									
VERTICAL OUTPUT						//									
TRIGGER CIRCUIT															
SWEEP GENERATOR									\overline{V}	V/,					
HORIZONTAL AMPLIFIER							///	\overline{V}	\overline{V}	V/					
CRT		\overline{V}					1					\overline{V}			

Table 5-1 Adjustments Affected by Repairs

6716-13

INDEX TO ADJUSTMENT PROCEDURE STEPS

Power Supply and CRT Display Page

1.	Check/Adjust Power Supply DC Levels §	5–4
2.	Adjust CRT Grid Bias	5-4
3.	Adjust Astigmatism	5–5
4.	Adjust Trace Alignment	5-5
5.	Adjust Geometry	5–5

Vertical

1. Adjust Channel 1 Variable Balance 5-6
2. Adjust Channel 2 Variable Balance 5-6
3. Adjust Channel 2 Invert Balance
4. Adjust Vertical Gain 5-7
5. Check Deflection Accuracy and VOLTS/DIV Variable Range
6. Check Input Coupling 5-7
7. Check Position Range 5-8
8. Adjust Attenuator Compensation 5-8
9. Check Vertical ALT and
CHOP Operation5-9
10. Adjust CHOP Switch Balance 5-9
11. Check ADD MODE Operation 5-9
12. Adjust High-Frequency Compensation 5-9
13. Check Bandwidth 5-10
14. Check Channel Isolation 5-10

15. Check Common-Mode Rejection Ratio .. 5-10

Horizontal

Trigger

1. Adjust Trigger Offset	5-15
2. Adjust Trigger Sensitivity	5–15
3. Adjust Slope Balance	5–16
4. Adjust Auto Level	5-16
5. Check Internal Triggering	5–16
6. Check External Trigger Range	5–16
7. Check External Trigger Range	5-17
8. Check Single Sweep Operation	5–17

External Z-Axis and Probe Adjust

٤

1.	Check External Z-Axis Operation	5-18
2.	Check Probe Adjust Operation	5–18

POWER SUPPLY AND CRT DISPLAY



b. Rotate the INTENSITY control fully counterclockwise.

c. ADJUST-Grid Bias (R851) for a visible dot, then back off the Grid Bias potentiometer until the dot just disappears.

3. Adjust Astigmatism (R870)

a. Set:

Vertical MODE	CH 1
Channel 1 AC-GND-DC	DC
SEC/DIV	5 µs
Trigger Source	CH 1

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

c. Set the generator to produce a 50-kHz, 4division display.

d. ADJUST-Astig (R870) and the front-panel FOCUS control for the best defined waveform.

e. Disconnect the test equipment from the instrument.

4. Adjust Trace Alignment

a. Position the trace to the center horizontal graticule line.

b. ADJUST—Front-panel TRACE ROTATION control for optimum alignment of the trace with the center horizontal graticule line.

5. Adjust Geometry (R871)

a. Set:

t

CH 1 VOLTS/DIV	50 mV
SEC/DIV	0.1 ms

b. Connect 50-ms time markers from the timemark generator via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

c. Position the baseline part of the display below the bottom horizontal graticule line using the CH 1 POSITION control .

d. Adjust the SEC/DIV Variable control for five markers per division.

e. ADJUST-Geom (R871) for minimum curvature of the time markers at the left and right edges of the graticule.

f. Set Channel 1 AC-GND-DC switch to GND.

g. ADJUST—Geom (R871) for minimum curvature of the baseline trace when positioned at the top and bottom horizontal graticule lines using the CH 1 POSITION control.

h. Set the Channel 1 AC-GND-DC switch to DC.

i. Repeat parts e through h for optimum compromise between the vertical and horizontal displays.

j. Disconnect the test equipment from the instrument.

VERTICAL

Equipment Required (See Table 4-1):

Calibration Generator (Item 1) Leveled Sine-Wave Generator (Item 2) $50-\Omega$ Coaxial Cable (Item 6) Dual-Input Coupler (Item 7) $50-\Omega$ Termination (Item 8) 10X Attenuator (Item 9) Miniature Probe Tip to BNC Adapter (Item 10) Alignment Tool (Item 11) 10X Probe (Item 12)

See ADJUSTMENT LOCATIONS 1



at the back of this manual for adjustment locations.

INITIAL CONTROL SETTINGS

Vertical

POSITION (both)	Midrange
MODE	CH 1, NORM
VOLTS/DIV (both)	5 mV
VOLTS/DIV Variable (both)	Cal detent
AC-GND-DC (both)	GND

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	0.5 ms
SEC/DIV Variable	CAL detent

Trigger

SLOPE	Positive (_/_)
LEVEL	Midrange
MODE	P-P AUTO
SOURCE	EXT, EXT

PROCEDURE STEPS

1. Adjust Channel 1 Variable Balance (R33)

a. Rotate the CH 1 VOLTS/DIV Variable control fully counterclockwise.

b. Position the trace on the center horizontal graticule line using the CH 1 POSITION control.

c. Rotate the CH 1 VOLTS/DIV Variable control clockwise to the CAL detent.

d. ADJUST-CH 1 Var Bal (R33) to set the trace to the center horizontal graticule line.

e. Repeat parts a through d until there is no trace shift between the fully clockwise and the fully counterclockwise positions of the CH 1 VOLTS/DIV Variable control.

f. Return the CH 1 VOLTS/DIV Variable control to the CAL detent.

2. Adjust Channel 2 Variable Balance (R83)

a. Set Vertical MODE switch to CH 2.

b. Rotate the CH 2 VOLTS/DIV Variable control fully counterclockwise.

c. Position the trace on the center horizontal graticule line using the CH 2 POSITION control.

d. Rotate the CH 2 VOLTS/DIV Variable control clockwise to the CAL detent.

e. ADJUST-CH 2 Var Bal (R83) to set the trace to the center horizontal graticule line.

f. Repeat parts a through d until there is no trace shift between the fully clockwise and the fully counterclockwise positions of the CH 1 VOLTS/DIV Variable control. g. Return the CH 1 VOLTS/DIV Variable control to the CAL detent

3. Adjust Channel 2 Invert Balance (R84)

a. Position the trace on the center horizontal graticule line using the Channel 2 POSITION control.

b. Set Vertical MODE switch to CH 2 INVERT.

c. ADJUST-CH 2 Invert Bal (R84) to set the trace to the center horizontal graticule line.

d. Set Vertical MODE switch to NORM.

e. Repeat parts a through d until there is no trace shift when switching from NORM to CH 2 INVERT.

4. Adjust Vertical Gain (R145 and R195)

a. Set:

Vertical MODE	CH 1, NORM
CH 1 VOLTS/DIV Variable	CAL detent
AC-GND-DC (both)	DC
Trigger SOURCE	VERT MODE

b. Connect a 20-mV, standard-amplitude signal from the calibration generator via a $50-\Omega$ coaxial cable to the CH 1 OR X input connector.

c. Center the display within the graticule using the CH 1 POSITION control.

d. ADJUST-CH 1 Gain (R145) for an exact 4-division display.

e. Move the test-signal cable from the CH 1 OR X input connector to the CH 2 OR Y input connector.

f. Set the Vertical MODE switch to CH 2.

g. Center the display within the graticule using the CH 2 POSITION control.

h. ADJUST-CH 2 Gain (R195) for an exact 4division display.

i. Repeat parts b through h until the gain of the two channels is identical.

5. Check Deflection Accuracy and VOLTS/DIV Variable Range

a. CHECK—Deflection accuracy is within the limits given in Table 5-3 for each CH 1 VOLTS/DIV switch setting and corresponding standard-amplitude signal. When at the 20-mV VOLTS/DIV switch setting,

rotate the CH 1 VOLTS/DIV Variable control fully counterclockwise and CHECK that the display decreases to two divisions or less. Then return the CH 1 VOLTS/DIV Variable control to the CAL detent and continue with the 50-mV check.

b. Move the cable from the CH 1 OR X input connector to the CH 2 OR Y input connector. Set the Vertical MODE switch to CH 2.

c. Repeat part b using the Channel 2 controls.

Table 5-3 Deflection Accuracy Limits

VOLTS/DIV Switch Setting	STANDARD Amplitude Signal	ACCURACY Limits (Divisions)
5 mV	20 mV	3.88 to 4.12
10_mV	<u>50 m</u> V	4.85 to 5.15
20 mV	<u>0.1 V</u>	4.85 to 5.15
50 mV	0.2 V	3.88 to 4.12
0.1 V	0.5 V	4.85 to 5.15
0.2 V	1 V	4.85 to 5.15
0.5_V	2 V	3.88 to 4.12
1 V	<u>5 V</u>	4.85 to 5.15
2 V	_10 V	4.85 to 5.15
5 V	20 V	3.88 to 4.12

6. Check Input Coupling

a. Set the AC-GND-DC switches (both channels) to GND.

b. Position the trace on the center horizontal graticule line using the CH 2 POSITION control.

c. Change the generator output to 50 mV.

d. Set the Channel 2 AC-GND-DC switch to AC.

e. CHECK-The display is centered about the center horizontal graticule line.

f. Set the Channel 2 AC-GND-DC switch to DC.

g. CHECK—The display is ground referenced on the center horizontal graticule line.

h. Move the test-signal cable from the CH 2 OR Y input connector to the CH 1 OR X input connector.

i. Set the Vertical MODE switch to CH 1.

j. Repeat parts b through g using the Channel 1 controls.

7. Check Position Range

a. Set:

VOLTS/DIV (both)	10 mV
AC-GND-DC (both)	AC
SEC/DIV	0.2 ms
Trigger COUPLING	AC

b. Set the calibration generator for 0.1 V.

c. Adjust the CH 1 VOLTS/DIV Variable control to produce a 5.25-division display.

d. Set the CH 1 VOLTS/DIV to 5 mV.

e. Set the calibration generator to produce a 0.2 V signal.

f. CHECK—The bottom and top of the trace may be positioned above and below the center horizontal graticule line by rotating the CH 1 POSITION control fully clockwise and counterclockwise respectively.

g. Move the cable from the CH 1 OR X input connector to the CH 2 OR Y input connector.

h. Set the Vertical MODE switch to CH 2.

i. Repeat parts b through f using the Channel 2 controls.

j. Disconnect the test equipment from the instrument.

8. Adjust Attenuator Compensation

a. Set:

VOLTS/DIV (both)	10 mV
AC-GND-DC (both)	DC

b. Connect the high-amplitude, square-wave output from the calibration generator via a 50- Ω termination, a miniature probe tip to BNC adapter, and the 10X probe to the CH 2 OR Y input connector.

c. Set the generator to produce a 1-kHz, 5division display and compensate the probe using the probe compensation adjustment (see the probe instruction manual). d. Replace the probe and miniature probe tip to BNC adapter with a $50\text{-}\Omega$ coaxial cable and $50\text{-}\Omega$ termination.

e. Set the generator to produce a 5-division display.

f. ADJUST—Trimmer "1" for flattest response on the square wave signal. See Figure 5–1 for location of the trimmers.



Figure 5-1. Attenuator trimmer adjustments.

g. Replace the 50- Ω coaxial cable and 50- Ω termination with the probe and miniature probe tip to BNC adapter.

h. Set the generator to produce a 5-division square wave.

i. ADJUST-Trimmer "1N" for flattest response on square wave.

j. Set the CH 2 VOLTS/DIV switch to 20 mV.

k. Repeat parts d through i except adjust the "2" and "2N" trimmers in parts f and i respectively.

I. Set the CH 2 VOLTS/DIV switch to 50 mV.

m. Repeat parts d through i except adjust the "3" and "3N" trimmers in parts f and i respectively.

n. Set the CH 2 VOLTS/DIV switch to 0.5 V.

o. Repeat parts d through i except adjust the "4" and "4N" trimmers in parts f and i respectively.

p. Set the Vertical MODE switch to CH 1.

q. Repeat parts b through p for the Channel 1 Attenuators.

r. Disconnect the test equipment from the instrument.

9. Check Vertical ALT Operation

a. Set:

AC-GND-DC (both)	GND
Vertical MODE	BOTH, NORM,
	and ALT
SEC/DIV	0.1 s
Trigger SOURCE	CH 1

b. Position the Channel 1 and Channel 2 traces about two divisions apart using the CH 1 and CH 2 POSITION controls.

c. CHECK-Channel 1 and Channel 2 traces move across the screen alternately.

d. Set Vertical switch to CHOP.

e. CHECK-Channel 1 and Channel 2 traces move across the screen at the same time.

10. Adjust CHOP Switch Balance (R140)

a. Set:

SEC/DIV	1 ms
Trigger MODE	NORM
Trigger SOURCE	VERT MODE

b. Connect the 10X probe to the rear of R242 on top of the A1-Main circuit board and adjust test oscilloscope for a 4-division display.

c. ADJUST-Chop-Sw Bal (R140) for no triggering on chop segments when rotating the Trigger LEVEL control.

11. Check ADD MODE Operation

a. Set:

VOLTS/DIV (both)	20 mV
AC-GND-DC (both)	DC
Vertical MODE	BOTH, NORM,
	and ALT
SEC/DIV	0.5 ms
Horizontal MODE	X1
Trigger SOURCE	CH 1

b. Position both traces on the center horizontal graticule line using the CH 1 and CH 2 POSITION controls.

c. Set the calibration generator to produce a 50-mV signal.

d. Connect the output of the calibration generator to both the CH 1 OR X input and the CH 2 OR Y input with dual-input coupler.

e. Check that both channels show a 2.5-division display.

f. Set: Vertical MODE switch to ADD.

g. CHECK—The resultant display is five divisions 3% (4.85 to 5.15 divisions).

h. Disconnect the test equipment from the instrument.

12. Adjust High-Frequency Compensation (C241, C242, C243, and R241)

a. Set:

VOLTS/DIV (both)	10 mV
Vertical MODE	CH 1
SEC/DIV	0.2 ms

b. Cohnect the positive-going, fast-rise, squarewave output from the calibration generator via a $50-\Omega$ coaxial cable, a 10X attenuator, and a $50-\Omega$ termination to the CH 1 OR X input connector.

c. Set the generator to produce a 1-MHz, 5division display.

d. Set the top of the display to the center horizontal graticule line using the CH 1 POSITION control.

e. ADJUST-HF Comp (C242 and C243) for the 5% or less overshoot (0.3 division) on the displayed signal.

f. ADJUST-HF Comp (C241 and R241) for best flat top on the front corner.

g. Repeat parts e and f until on further improvement is noted.

h. Set the CH 1 VOLTS/DIV switch to 5 mV.

i. Set the generator to produce a 5-division display.

j. Check for aberrations of 5% (0.3 division) or less.

k. Repeat part j for each CH 1 VOLTS/DIV switch settings from 5 mV through 0.5 V. Adjust the generator output and add or remove the 10X attenuator as necessary to maintain a 5-division display at each VOLTS/DIV switch setting.

I. Move the cable from the CH 1 OR X input connector to the CH 2 OR Y input connector. Set the Vertical MODE switch to CH 2.

m. Repeat part k for Channel 2.

n. Disconnect the test equipment from the instrument.

NOTE

Install the instrument cabinet for the remaining vertical checks and allow a 20-minute warm-up period before continuing with the "Adjustment Procedure". See the "Cabinet" remove and replace instructions located in the "Maintenance" section of the manual.

13. Check Bandwidth

a. Set:

VOLTS/DIV (both)	5 mV
Vertical MODE	CH 1
SEC/DIV	10 ms
Trigger SOURCE	VERT MODE

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

c. Set the generator to produce a 50-kHz, 6-division display.

d. Increase the sine-wave frequency until a 4.2-division display is obtained.

e. CHECK-the frequency is greater than 20 MHz.

f. Repeat parts c through e for all CH 1 VOLTS/ DIV switch settings, up to the output-voltage upper limit of the sine-wave generator being used.

g. Move the cable from the CH 1 OR X input connector to the CH 2 OR Y input connector. Set the Vertical MODE switch to CH 2.

h. Repeat parts c through e for all CH 2 VOLTS/ DIV switch settings, up to the output-voltage upper limit of the sine-wave generator being used.

14. Check Channel Isolation

a. Set:

CH 1 VOLTS/DIV	0.5 V
CH 2 VOLTS/DIV	1 V
Channel 1 AC-GND-DC	GND
SEC/DIV	0.05 ms

b. Set the generator to produce a 20-MHz, 5-division display.

c. Set CH 2 VOLTS/DIV switch to 0.5 V for a 10-division display.

d. Set Vertical MODE switch to CH 1 and ALT.

e. CHECK—The display amplitude is less than 0.1 division.

f. Move the test-signal cable from the CH 2 OR Y input connector to the CH 1 OR X input connector.

g. Set:

Vertical MODE	CH 2
Channel 1 AC-GND-DC	DC
Channel 2 AC-GND-DC	GND

h. CHECK—The display amplitude is less than 0.1 division.

i. Disconnect the test equipment from the instrument.

15. Check Common-Mode Rejection Ratio

a. Set:

VOLTS/DIV (both)	10 mV
Channel 2 AC-GND-DC	DC
Vertical MODE	BOTH, NORM,
	and ALT

b. Connect the leveled sine-wave generator output via a $50-\Omega$ coaxial cable, a $50-\Omega$ termination, and a dual-input coupler to the CH 1 OR X and CH 2 OR Y input connectors.

c. Set the generator to produce a 10-MHz, 6-division display.

d. Set Vertical MODE switch to CH 2 INV and ADD.

e. CHECK-Display amplitude is 0.6 division or less.

f. Disconnect the test equipment from the instrument.

NOTE

To continue with the "Adjustment Procedure", remove the instrument cabinet and allow a 20-minute warm-up period. See the "Cabinet" removal instructions located in the "Maintenance" section of the manual.

ί

HORIZONTAL

Equipment Required (See Table 4-1):

Calibration Generator (Item 1) Leveled Sine-Wave Generator (Item 2) Time-Mark Generator (Item 3) Test Oscilloscope (Item 4) $50-\Omega$ Coaxial Cable (Item 6) $50-\Omega$ Termination (Item 8) Alignment Tool (Item 11)

See ADJUSTMENT LOCATIONS 1 and ADJUSTMENT LOCATIONS 2

at the back of this manual for test point and adjustment locations.

INITIAL CONTROL SETTINGS

Vertical

POSITION (both)	Midrange
MODE	CH 1
VOLTS/DIV (both)	0.5 V
VOLTS/DIV Variable (both)	Cal detent
AC-GND-DC (both)	DC

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	1 ms
SEC/DIV Variable	CAL detent

Trigger

SLOPE	Positive (_/_)
LEVEL	Midrange
MODE	P~P AUTO
SOURCE	CH 1

PROCEDURE STEPS

1. Adjust 1-ms Timing (R744)

a. Connect 1-ms time markers from the timemark generator via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

b. Align the first time marker with the first (extreme left) vertical graticule line using the Horizontal POSITION control.

NOTE

When making timing measurements, use the tips of the time markers positioned at the center horizontal graticule line as the measurement reference points.

c. ADJUST-X1 Gain (R744) for one marker per division over the center eight divisions.

2. Adjust Magnifier Gain (R777)

a. Set the MAG switch to X10.

b. Select 100 μ s time markers from the time-mark generator.

c. Align the first time marker with the first (extreme left) vertical graticule line using the Horizontal POSITION control.

d. ADJUST-X10 Mag Gain (R777) for 1 time marker per division.

3. Adjust Magnifier Registration (R782)

a. Set the SEC/DIV switch to 0.2 ms.

b. Select 1 ms time markers from the time-mark generator.

c. Position the middle time marker to the center vertical graticule line using the Horizontal POSITION control.

d. Set the MAG switch from X10 to X1 position.

e. ADJUST-Mag Reg (R782) to position the middle time marker to the center vertical graticule line.

Scans by ArtekMedia © 2006

f. Set the MAG switch from X1 to X10 position and CHECK for no horizontal shift in the time marker.

g. Repeat parts c through f until no further improvement is noted.

4. Check Position Range

a. Set:

SEC/DIV	0.1 ms
Horizontal MAG	X1

b. Select 0.1 ms time markers from the time-mark generator.

c. CHECK—The start of the sweep can be positioned to the right of the center vertical graticule line by rotating the Horizontal POSITION control fully clockwise.

d. CHECK—The tenth time marker can be positioned to the left of the center vertical graticule line by rotating the Horizontal POSITION control fully counterclockwise.

e. Select 0.5 ms time markers from the time-mark generator.

f. Align the 3rd time marker with the center vertical graticule line using the Horizontal POSITION control.

g. Set the Horizontal MAG switch to X10.

h. Check—Magnified time marker can be positioned to the left of the center vertical graticule line by rotating the Horizontal POSITION control fully counterclockwise.

i. Check—The tenth time marker can be positioned to the right of the center vertical graticule by rotating the Horizontal POSITION control fully clockwise.

5. Check Variable Range

a. Set Horizontal MAG switch to X1 and center the display.

b. Set the SEC/DIV Variable control knob fully counterclockwise.

c. CHECK-The spacing between time markers is 2 divisions or less.

d. Return the SEC/DIV Variable knob to the CAL detent position.

6. Adjust 0.1-ms and 0.1- μs Timing (R722 and C703)

a. Set the SEC/DIV switch to 0.1 ms.

b. Select 0.1-ms time markers from the timemark generator.

c. ADJUST-0.1-ms Timing (R722) for 1 marker per division.

d. Set the SEC/DIV switch to 0.1 μ s.

e. Select 0.1- μs time markers from the time-mark generator.

f. ADJUST-0.1- μ s Timing (C703) for 1 marker per division.

7. Adjust High-Speed Timing (C783, C794)

a. Set:

Channel 1 AC-GND-DC	AC
Horizontal MAG	X10

b. Select 20-ns time markers from the timemark generator and set the display for maximum amplitude within the graticule area.

c. Adjust the Trigger LEVEL control for a stable triggered display.

d. ADJUST-HS Timing (C783 and C794) for two divisions between each time marker.

NOTE

The 20-ns time-markers tips are rounded off and cannot be used as measurement reference points. Use the rising edge of the time markers as measurement reference points to adjust the high-speed timing capacitors. Vertically adjust the 50% point of the time markers on the center horizontal graticule line.

8. Check Timing Accuracy and Linearity

a. Set:

CH VOLTS/DIV	0.5 V
Horizontal MAG	X1

b. Select 0.1- μ s time markers from the time-mark generator.

c. Adjust the Trigger LEVEL control for a stable, triggered display.

d. Use the Horizontal POSITION control to align the second time marker with the second vertical graticule line.

e. CHECK—Timing accuracy is within 3% (0.24 division at the tenth vertical graticule line), and linearity is within 5% (0.10 division over any two of the center eight divisions).

NOTE

When checking the timing accuracy for SEC/ DIV switch settings from 50 ms to 0.5 s, watch the time marker tips only at the second and tenth vertical graticule lines while adjusting the Horizontal POSITION control.

f. Repeat parts c through e for the remaining SEC/DIV and time-mark-generator setting combinations shown in Table 5-4 under the "X1 Normal" column.

g. Set:

SEC/DIV	0.1 μs
Horizontal MAG	X10

h. Select 20-ns time markers from the timemark generator.

i. Use the Horizontal POSITION controls to align the first time marker that is 50 ns beyond the start of the sweep with the second vertical graticule line.

j. CHECK—Timing accuracy is within 4% (0.32 division at the tenth vertical graticule line), and linearity is within 7% (0.14 division over any 2 of the center 8 divisions). Exclude any portion of the sweep past the 50th magnified division.

k. Repeat parts i and j for the remaining SEC/DIV and time-mark generator setting combination shown in Table 5-4 under the "X10 Magnified" column.

I. Disconnect the test equipment from the instrument.

9. Adjust X-Axis Gain (R395)

a. Set:

VOLTS/DIV (both)	10 mV
SEC/DIV	X-Y
Horizontal MAG	X1

Table 5-4

Settings for Timing Accuracy Checks

SEC/DIV Time-Mark Generator Setting					
Swite Setti		X1 No			agnified
0.1	μs	0.1	μs	20	ns
0.2	μs	0.2	μs	20	ns
0.5	μs	0.5	μs	50	ns
- 1	μs —	1	μs	0.1	μs
2	μs	2	μs	0.2	μs
5	μs	5	μs	0.5	μs
10	μs	10	μs	1	 μs
20	μs	20	μs	2	μs
50	μs	50	μs	5	μs
0.1	ms	0.1	ms	10	μs
0.2	ms	0.2	ms	20	μs
0.5	ms	0.5	ms	50	μs
1	ms	1	ms	0.1	ms
2	ms	2	ms	0.2	ms
5	ms	5	ms	0.5	ms
10	ms	10	ms	1	ms
20	ms	20	ms	2	ms
50	ms	50	ms	5	ms
0.1	s	0.1	s	10	ms
0.2	S	0.2	s	20	ms
0.5	s	0.5	S	50	ms

b. Connect a 50-mV, standard-amplitude signal from the calibration generator via a 50- Ω coaxial cable to the CH 1 OR X input connector.

c. ADJUST-X Gain (R395) for exactly 5 divisions of horizontal deflection.

10. Adjust X Offset (R736)

a. Set:

Channel 1	AC-GND-DC	GND
SEC/DIV		1 ms

b. Position the trace vertically to the center horizontal graticule line. c. Position the trace horizontally so the start of the trace begins at the first vertical graticule line (extreme left).

d. Set the SEC/DIV switch to X-Y (fully counterclockwise).

e. ADJUST-X Offset (R736) to position the spot at the seventh vertical graticule line.

f. Disconnect the test equipment from the instrument.

10. Check X Bandwidth

a. Set:

VOLTS/DIV (both)	50 mV
AC-GND-DC (both)	DC
Trigger SOURCE	CH 1

b. Connect the leveled sine-wave generator output via a 50- Ω coaxial cable and a 50- Ω termination to the CH 1 OR X input connector.

c. Set the generator to produce an 8-division horizontal display at an output frequency of 50 kHz.

d. Increase the signal frequency until the horizontal deflection (X-axis) is equal to 5.7 divisions in length.

e. CHECK-The frequency is greater than 2 MHz.

f. Disconnect the test equipment from the instrument.

11. Check Sweep Holdoff

a. S	Set:
------	------

VOLTS/DIV (both)	1 V
AC-GND-DC (both)	GND
SEC/DIV	1 ms
Trigger SOURCE	EXT, EXT

b. Connect the test oscilloscope's 10X probe tip to the front end of R704 (toward the front panel). R704 is on the Timing circuit board.

c. CHECK-Holdoff time is between 1.5 ms to 3.0 ms.

d. Repeat part c for SEC/DIV switch settings in Table 5-5.

e. Disconnect the 10X probe from R704.

Table 5-5 Settings for Holdoff Checks

SEC/DIV	Holdoff Time
0.1 ms	0.2 ms to 0.3 ms
10 µs	15 μs to 30 μs
1 μs	1.5 μs to 3.0 μs
TRIGGER

Equipment Required (See Table 4-1):

Leveled Sine-Wave Generator (Item 2) 50-Ω Coaxial Cale (Item 6) Dual-Input Coupler (Item 7) $50-\Omega$ Termination (Item 8) Alignment Tool (Item 11)

See ADJUSTMENT LOCATIONS 1

at the back of this manual for adjustment locations.

INITIAL CONTROL SETTINGS

Vertical

POSITION (both) MODE	Midrange BOTH, NORM and ALT
VOLTS/DIV (both)	50 mV
VOLTS/DIV Variable (both)	Cal detent
AC-GND-DC (both)	DC

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	2 μs
SEC/DIV Variable	CAL detent

Trigger

SLOPE	Positive ()
LEVEL	Midrange
MODE	P-P AUTO
SOURCE	CH 2

PROCEDURE STEPS

1. Adjust Trigger Offset Balance(R338)

a. Set the Channel 1 trace and the Channel 2 trace to the center horizontal graticule line using the Channel 1 and Channel 2 POSITION controls.

b. Connect the digital voltmeter low lead to chassis ground and the high (volts) lead to TP350 (base of Q410).

c. CHECK—The offset voltage reading is less than 100 mV. Note the reading for use in part e.

d. Set the Trigger SOURCE switch to CH 1.

e. ADJUST-Trig Offset Bal (R338) so that the voltage reading is the same as that obtained in part c.

f. Set the Trigger SOURCE switch to CH 2.

g. Repeat parts c through f until there is 1 mV or less difference in the voltmeter readings between the CH 1 and CH 2 positions of the Trigger SOURCE switch.

h. Disconnect the test equipment from the instrument.

2. Adjust Trigger Sensitivity (R489)

a. Set:

Vertical MODE	CH 1
CH 1 VOLTS/DIV	0.1 V
AC-GND-DC (both)	AC
SEC/DIV	10 μs
Trigger SOURCE	VERT MODE

b. Connect the leveled sine-wave generator output via a 50- Ω cable and a 50- Ω termination to the CH 1 OR X input connector.

c. Set the generator to produce a 50-kHz, 2.2-division display.

d. Set the CH 1 VOLTS/DIV switch to 1 V.

e. ADJUST-Trig Sensitivity (R489) while rotating the Trigger LEVEL control slowly so that the trigger is just able to be maintained.

f. CHECK-The TRIG'D/READY LED is on when triggered.

3. Adjust Slope Balance (R481)

a. Set the CH 1 VOLTS/DIV switch to 50 mV.

b. Set the generator to produce a 4-division display.

c. ADJUST-Slope Bal (R481) for a downward vertical shift of 0.22-division at the start of the sweep when changing the Trigger SLOPE switch between the positive (\neg) and negative (\neg) positions.

4. Adjust Auto Level (R445 and R446)

a. Set:

Trigger SLOPE	Positive (_/_)
Trigger LEVEL	Fully clockwise

b. Set the generator to produce a 5-division display.

c. Set the CH 1 VOLTS/DIV switch to 0.5 V.

d. ADJUST-(+) Auto Level (R446) so that the vertical display just solidly triggers on the positive peak of the signal.

e. Set:

Trigger SLOPE	Negative (¬_)
Trigger LEVEL	Fully
	counter-
	clockwise

f. ADJUST-(-) Auto Level (R445) so that the display just solidly triggers on the negative peak of the signal.

5. Check Internal Triggering

a. Set:

CH 1 VOLTS/DIV	5 mV
CH 2 VOLTS/DIV	50 mV
SEC/DIV	0.2 μs

b. Set the generator to produce a 5-MHz, 3-division display.

c. Set the CH 1 VOLTS/DIV switch to 50 mV.

d. CHECK-Stable display can be obtained by adjusting the Trigger LEVEL control for each switch combination given in Table 5-6. Ensure that the TRIG'D/READY LED comes on when triggered.

Table 5-6

Switch Combinations for Triggering Checks

Trigger MODE	Trigger SLOPE
NORM	Positive
NORM	Negative ~-
P-P AUTO	Negative ~_
P-P AUTO	Positive -/

e. Move the cable from the CH 1 OR X input connector to the CH 2 OR Y input connector. Set the Vertical MODE switch to CH 2.

f. Repeat part d.

g. Set:

SEC/DIV	0.1 µs
Horizontal MAG	X10

h. Set the generator to produce a 30-MHz, 1.0-division display.

i. Repeat part d.

j. Move the cable from the CH 2 OR Y input connector to the CH 1 OR X input connector. Set the Vertical Mode switch to CH 1.

k. Repeat part d.

I. Disconnect the test equipment from the instrument.

6. Check External Triggering

a. Set:

CH 1 VOLTS/DIV	20 mV
SEC/DIV	0.2 ms
Horizontal MODE	X1
Trigger MODE	P-P AUTO
Trigger SOURCE	EXT, EXT

b. Connect the leveled sine-wave generator output via a $50-\Omega$ coaxial cable, a $50-\Omega$ termination,

and a dual-input coupler to the CH 1 OR X input connector and EXT INPUT OR Z input connectors.

c. Set the generator to produce a 4-division (80 mV) horizontal display at an output frequency of 5 MHz.

d. CHECK—Stable display can be obtained by adjusting the Trigger LEVEL control for each switch combination given in Table 4-4.

e. Set:

CH 1 VOLT/DIV	50 mV
SEC/DIV	0.05 ms
Horizontal MODE	MAG

f. Set the leveled sine-wave generator to produce a 50-kHz, 3-division (150 mV) display.

g. Set the generator output to 30 MHz.

h. Repeat part d.

7. Check External Trigger Range

a. Set:

CH 1 VOLTS/DIV	0.5 V
SEC/DIV	20 ms
Trigger SLOPE	Positive (_/_)

b. Set the leveled sine-wave generator to produce a 50-kHz, 6.4-division display.

c. Position the waveform equally about the center horizontal graticule line.

d. Set:

Trigger MODE	NORM
Trigger SOURCE	EXT, EXT

e. CHECK-Display is triggered along the entire positive slope of the waveform as the Trigger LEVEL control is rotated.

f. CHECK-Display is not triggered at either extreme of rotation of the Trigger LEVEL control.

g. Set the Trigger SLOPE switch to negative (\sim) .

h. CHECK-Display is triggered along the entire negative slope of the waveform as the Trigger LEVEL control is rotated.

i. CHECK-Display is not triggered at either extreme of rotation of the Trigger LEVEL control.

j. Disconnect the test equipment from the instrument.

8. Check Single Sweep Operation

a. Set:

CH 1 VOLTS/DIV	10 mV	
SEC/DIV	0.5 ms	
Trigger SOURCE	CH 1	
Trigger SLOPE	Positive (_/)	

b. Connect 50-mV, standard-amplitude signal from the calibration generator via a 50- Ω coaxial cable to the CH 1 OR X input connector.

c. Adjust the Trigger LEVEL control to obtain a stable display.

d. Set:

Channel 1 AC-GND-DC GND Trigger MODE SGL SWP

e. Press the SGL SWP RESET button. The TRIG'D/READY LED illuminates and remains on.

f. Set the Channel 1 AC-GND-DC switch to DC.

NOTE

The INTENSITY control may require adjustment to observe the single-sweep trace.

g. CHECK-TRIG'D/READY LED goes out and a single sweep occurs.

h. Press the SGL SWP RESET button several times.

i. CHECK-A single-sweep trace occurs, and the TRIG'D/READY LED illuminates briefly every time the SGL SWP RESET button is pressed.

j. Disconnect the test equipment from the instrument.

EXTERNAL Z-AXIS AND PROBE ADJUST

Equipment Required (See Table 4-1):

Calibration Generator (Item 1) Two 50-Ω Coaxial Cables (Item 6) Dual-Input Coupler (Item 7) $50-\Omega$ Termination (Item 8) 10X Probe (Item 12)

INITIAL CONTROL SETTINGS

Vertical

CH 1 POSITION	Midrange
MODE	CH 1, NORM
CH 1 VOLTS/DIV	1 V
CH 1 VOLTS/DIV Variable	CAL detent
Channel 1 AC-GND-DC	DC

Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	20 ms
SEC/DIV Variable	CAL detent

Trigger

SLOPE	Positive (∠_)
LEVEL	Midrange
MODE	P-P AUTO
SOURCE	EXT, EXT=Z

PROCEDURE STEPS

1. Check External Z-Axis Operation

a. Connect a 5–V standard–amplitude signal from the calibration generator via dual–input coupler to the CH 1 OR X and EXT INPUT OR Z connectors.

NOTE

The INTENSITY level may need adjustment to view the intensity modulation on the displayed waveform.

b. CHECK—For noticeable intensity modulation. The positive part of the sine wave should be of lower intensity than the negative part.

c. Disconnect the test equipment from the instrument.

2. Check Probe Adjust Operation

a. Set:

CH 1 VOLTS/DIV	10 mV
SEC/DIV	0.5 ms
Trigger SOURCE	CH 1

b. Connect the 10X Probe to the CH 1 OR X input connector and clip the probe tip to the PROBE connector on the instrument front panel. If necessary, adjust the probe compensation for a flat-topped square-wave display.

c. CHECK-Display amplitude is $4.75\ \text{to}\ 5.25$ divisions.

d. Disconnect the probe from the instrument.

MAINTENANCE

This section contains information for conducting preventive maintenance, troubleshooting, and corrective maintenance on the instrument. Circuit board removal procedures are included in the Corrective Maintenance part of this section.

STATIC-SENSITIVE COMPONENTS

The following precautions are applicable when performing any maintenance involving internal access to the instrument.

Table 6-1 Relative Susceptibility to Static-Discharge Damage

Semiconductor Classes	Relative Susceptibility Levels ^a
MOS or CMOS microcircuits or discretes, or linear microcircuits with MOS inputs (Most Sensi-	
	1
ECL	2
Schottky signal diodes	3
Schottky TTL	4
High-frequency bipolar transistors	5
JFET	6
Linear microcircuits	7
Low-power Schottky TTL	8
TTL (Least Sensitive)	9

^aVoltage equivalent for levels (voltage discharged from a 100-pF capacitor through a resistance of 100 Ω):

2 = 200 to 500 V 3 = 250 V	6 = 600 to 800 V 7 = 400 to 1000 V (est) 8 = 900 V 9 = 1200 V
-------------------------------	--

5. Keep the component leads shorted together whenever possible.

6. Pick up components by their bodies, never by their leads.

ECAUTION S

Static discharge can damage any semiconductor component in this instrument.

This instrument contains electrical components that are susceptible to damage from static discharge. Table 6–1 lists the relative susceptibility of various classes of semiconductors. Static voltages of 1 KV to 30 KV are common in unprotected environments.

When performing maintenance, observe the following precautions to avoid component damage:

1. Minimize handling of static-sensitive components.

2. Transport and store static-sensitive components or assemblies in their original containers or on a metal rail. Label any package that contains static-sensitive components or assemblies.

3. Discharge the static voltage from your body by wearing a grounded antistatic wrist strap while handling these components. Servicing staticsensitive components or assemblies should be performed only at a static-free work station by qualified service personnel.

4. Nothing capable of generating or holding a static charge should be allowed on the work station surface.

7. Do not slide the components over any surface.

8. Avoid handling components in areas that have a floor or work-surface covering capable of generating a static charge.

9. Use a soldering iron that is connected to earth ground.

10. Use only approved antistatic, vacuum-type desoldering tools for component removal.

PREVENTIVE MAINTENANCE

INTRODUCTION

Preventive maintenance consists of cleaning, visual inspection, and checking instrument performance. When performed regularly, it may prevent instrument malfunction and enhance instrument reliability. The severity of the environment in which the instrument is used determines the required frequency of maintenance. An appropriate time to accomplish preventive maintenance is just before instrument adjustment.

GENERAL CARE

The cabinet minimizes accumulation of dust inside the instrument and should normally be in place when operating the oscilloscope. The optional front cover for the instrument provides both dust and damage protection for the front panel and crt. Whenever the instrument is stored or is being transported, the front cover should be used.

ECAUTION S

Do not use chemical cleaning agents that might damage the plastics used in this instrument. Use a nonresidue-type cleaner, preferably isopropyl alcohol or a solution of 1% mild detergent with 99% water. Before using any other type of cleaner, consult your Tektronix Service Center or representative.

INSPECTION AND CLEANING

The instrument should be inspected and cleaned as often as operating conditions require. Accumulation of dust in the instrument can cause overheating and component breakdown. Dust on components acts as an insulating blanket, preventing efficient heat dissipation. It also provides an electrical conduction path that could result in instrument failure, especially under high-humidity conditions.

Exterior

INSPECTION. Inspect the external portions of the instrument for damage, wear, and missing parts; use Table 6–2 as a guide. Instruments that appear to have been dropped or otherwise abused should be checked thoroughly to verify correct operation and performance. Any problems found that could cause personal injury or could lead to further damage to the instrument should be repaired immediately.



Do not allow moisture to get inside the instrument during external cleaning. Use only enough liquid to dampen the cloth or applicator.

CLEANING. Loose dust on the outside of the instrument can be removed with a soft cloth or small soft-bristle brush. The brush is particularly useful for dislodging dirt on and around the controls and connectors. Dirt that remains can be removed with a soft cloth dampened in a mild detergent-and-water solution. Do not use abrasive cleaners.

A plastic light filter is provided with the oscilloscope. Clean the light filter and the crt face with a soft lint-free cloth dampened with either isopropyl alcohol or a mild detergent-and-water solution.

Interior

To gain access to internal portions of the instrument for inspection and cleaning, refer to the Removal and Replacement Instructions in the Corrective Maintenance part of this section.

ltem	Inspect For	Repair Action	
Cabinet and Front Panel	Cracks, scratches, deformations, and damaged hardware or gaskets.	Touch up paint scratches and replace defective parts.	
Front-panel controls	Missing, damaged, or loose knobs, buttons, and controls.	Repair or replace missing or defective items.	
Connectors	Broken shells, cracked insulation, and deformed contacts. Dirt in connectors.	Replace defective parts. Clean or wash out dirt.	
Carrying Handle	Correct operation.	Replace defective parts.	
Accessories	Missing items or parts of items, bent pins, broken or frayed cables, and damaged connectors.	Replace damaged or missing items, frayed cables, and defective parts.	
Cabinet and Front Panel	Cracks, scratches, deformations, and damaged hardware or gaskets.	Touch up paint scratches and replace defective parts.	
Front-panel controls	Missing, damaged, or loose knobs, buttons, and controls.	Repair or replace missing or defective items.	
Connectors	Broken shells, cracked insulation, and deformed contacts. Dirt in connectors.	Replace defective parts. Clean or wash out dirt.	
Carrying Handle	Correct operation.	Replace defective parts.	
Accessories	Missing items or parts of items, bent pins, broken or frayed cables, and damaged connectors.	Replace damaged or missing items, frayed cables, and defective parts.	

Table 6-2 External Inspection Checklist

INSPECTION. Inspect the internal portions of the instrument for damage and wear, using Table 6–3 as a guide. Deficiencies found should be repaired immediately. The corrective procedure for most visible defects is obvious; however, particular care must be taken if heat-damaged components are found. Overheating usually indicates other trouble in the instrument; therefore, it is important that the cause of overheating be corrected to prevent recurrence of the damage.

If any electrical component is replaced, conduct a performance check for the affected circuit and for other closely related circuits (see Section 4). If repair or replacement work is done on any of the power supplies, conduct a complete performance check and, if so indicated, an instrument readjustment (see Sections 4 and 5).

E CAUTION S

To prevent damage from electrical arcing, ensure that circuit boards and components are dry before applying power to the instrument.

÷

CLEANING. To clean the interior, blow off dust with dry, low-pressure air (approximately 9 psi). Remove any remaining dust with a soft brush or a cloth dampened with a solution of mild detergent and water. A cotton-tipped applicator is useful for cleaning in narrow spaces and on circuit boards.

VOLT/DIV And SEC/DIV SWITCHES. These are maintenance free. DO NOT CLEAN.

ltem	Inspect For	Repair Action	
Circuit Boards	Loose, broken, or corroded solder connections. Burned circuit boards. Burned, broken, or cracked circuit-run plating.	Clean solder corrosion with an eraser and flush with isopropyl alcohol. Resolder defective con- nections. Determine cause of burned items and repair. Repair defective circuit runs.	
Resistors	Burned, cracked, broken, or blistered.	Replace defective resistors. Check for cause of burned component and repair as necessary.	
Solder Connections	Cold solder or rosin joints.	Resolder joint and clean with isopropyl alcohol.	
Capacitors	Damaged or leaking cases. Corroded solder on leads or terminals.	Replace defective capacitors. Clean solder connections and flush with isopropyl alcohol.	
Wiring and Cables	Loose plugs or connectors. Burned, broken, or frayed wiring.	Firmly seat connectors. Repair or replace defective wires or cables.	
Chassis	Dents, deformations, and damaged hardware.	Straighten, repair, or replace defective hardware.	

Table 6-3 Internal Inspection Checklist



Most spray-type circuit coolants contain Freon 12 as a propellant. Because many Freons adversely affect switch contacts, do not use spray-type coolants on the switches or attenuators. Carbon based solvents will damage the circuit board material.

LUBRICATION

Most of the potentiometers used in this instrument are permanently sealed and generally do not require periodic lubrication. All switches, both rotary- and lever-type, are installed with proper lubrication applied where necessary and will rarely require any additional lubrication. A regular periodic lubrication program for the instrument is, therefore, not recommended.

SEMICONDUCTOR CHECKS

Periodic checks of the transistors and other semiconductors in the oscilloscope are not recommended. The best check of semiconductor performance is actual operation in the instrument.

PERIODIC READJUSTMENT

To ensure accurate measurements, check the performance of this instrument every 2000 hours of operation, or if used infrequently, once each year. In addition, replacement of components may necessitate readjustment of the affected circuits.

Complete performance check and adjustment instructions are given in Sections 4 and 5. The performance check procedure can also be helpful in localizing certain troubles in the instrument. In some cases, minor problems may be revealed or corrected by readjustment. If only a partial adjustment is performed, see the interaction chart, Table 5–1, for possible adjustment interaction with other circuits.

TROUBLESHOOTING

INTRODUCTION

Preventive maintenance performed on a regular basis should reveal most potential problems before an instrument malfunctions. However, should troubleshooting be required, the following information is provided to facilitate location of a fault. In addition, the material presented in the Theory of Operation and Diagrams sections of this manual may be helpful while troubleshooting.

TROUBLESHOOTING AIDS

Schematic Diagrams

Complete schematic diagrams are located on tabbed foldout pages in the Diagrams section. Portions of circuitry mounted on each circuit board are enclosed by heavy black lines. The assembly number and name of the circuit are shown near either the top or the bottom edge of the enclosed area.

Functional blocks on schematic diagrams are outlined with a wide grey line. Components within the outlined area perform the function designated by the block label. The Theory of Operation uses these functional block names when describing circuit operation as an aid in cross-referencing between the theory and the schematic diagrams.

Component numbers and electrical values of components in this instrument are shown on the schematic diagrams. Refer to the first page of the Diagrams section for the reference designators and symbols used to identify components. Important voltages and waveform reference numbers (enclosed in hexagonal-shaped boxes) are also shown on each diagram. Waveform illustrations are located adjacent to their respective schematic diagram.

Circuit Board Illustrations

Circuit board illustrations showing the physical location of each component are provided for use in conjunction with each schematic diagram. Each circuit board illustration is found in the Diagrams section on the back of a foldout page, preceding the first schematic diagram(s) to which it relates. The locations of waveform test points are marked on the circuit board illustrations with hexagonal outlined numbers corresponding to the waveform numbers on both the schematic diagram and the waveform illustrations.

Also provided in the Diagrams section is an illustration of the bottom side of the Main circuit board. This illustration aids in troubleshooting by showing the connection pads for the components mounted on the top side of the circuit board. By using this illustration, circuit tracing and probing for voltages and signals that are inaccessible from the top side of the circuit board may be achieved without dismantling portions of the instrument.

Circuit Board Locations

The placement of each circuit board in the instrument is shown in circuit board locator illustrations. These illustrations are located on foldout pages along with the circuit board illustration.

Circuit Board Interconnections

Circuit Board Interconnections (Diagram 9) is provided as an aid in tracing a signal path between circuit boards. All wire, plug, and jack numbers are shown along with their associated wire or pin numbers.

Power Distribution

Power Distribution (Diagram 8) is provided to aid in troubleshooting power-supply problems. This diagram shows the service jumper connections used to apply power to the various circuit boards. Excessive loading on a power supply by a circuit board fault may be isolated by disconnecting the appropriate service jumpers.

Grid Coordinate System

Each schematic diagram and circuit board illustration has a grid border along its left and top edges. A table located adjacent to each diagram lists the grid coordinates of each component shown on that diagram. To aid in physically locating components on the circuit board, this table also lists the grid coordinates of each component on the circuit board illustration. Near each circuit board illustration is an alphanumeric listing of all components mounted on that circuit board. The second column in each listing identifies the schematic diagram in which each component can be found. These component-locator tables are especially useful when more than one schematic diagram is associated with a particular circuit board.

Component Color Coding

Information regarding color codes and markings of resistors and capacitors is located on the colorcoding illustration (Figure 9–1) at the beginning of the Diagrams section.

RESISTOR COLOR CODE. Resistors used in this instrument are carbon-film, composition, or precision metal-film types. They are usually color coded with the EIA color code; however, some metal-film type resistors may have the value printed on the body. The color code is interpreted starting with the stripe nearest to one end of the resistor. Composition resistors have four stripes; these represent two significant digits, a multiplier, and a tolerance value. Metal-film resistors have five stripes representing three significant digits, a multiplier, and a tolerance value.

CAPACITOR MARKINGS. Capacitance values of common plastic capacitors and small electrolytics are marked on the side of the capacitor body. Small, machine-insertable capacitors are numerically coded in picofarads. The first two numbers are the significant digits and the third number (if a three-number code) is the number of zeros following the digits. When there are two numbers separated by the letter "R", the two numbers are the significant digits; the letter marks the radix (decimal point). Some examples of this type of capacitor coding are as follows:

 $\begin{array}{l} 475 = 47 \ 00000 \ pF = 4.7 \ \mu F \\ 472 = 47 \ 00 \ pF = 0.0047 \ \mu F \\ 471 = 47 \ 0 \ pF \\ 470 = 47 \ pF \\ 4R7 = 4.7 \ pF \end{array}$

The code numbers may be difficult to locate and read on installed parts. Capacitor values may be found by referencing the circuit designation number in the Replaceable Electrical Parts list.

DIODE COLOR CODE. The cathode end of each glass-encased diode is indicated by either a stripe, a series of stripes or a dot. For most diodes marked with a series of stripes, the color combination of the stripes identifies three digits of the Tektronix Part Number, using the resistor color-code system. The

cathode and anode ends of a metal-encased diode may be identified by the diode symbol marked on its body.

Semiconductor Lead Configurations

Figure 9–2 in the Diagrams section shows the lead configurations for semiconductor devices used in the instrument. These lead configurations and case styles are typical of those used at completion of the instrument design. Vendor changes and performance improvement changes may result in changes of case styles or lead configurations. If the device in question does not appear to match the configuration shown in Figure 9–2, examine the associated circuitry or consult the manufacturer's data sheet.

TROUBLESHOOTING EQUIPMENT

The equipment listed in Table 4–1 of this manual, or equivalent equipment, may be useful when troubleshooting this instrument.

TROUBLESHOOTING TECHNIQUES

The following procedure is arranged in an order that enables checking simple trouble possibilities before requiring more extensive troubleshooting. The first four steps ensure proper control settings, connections, operation, and adjustment. If the trouble is not located by these checks, the remaining steps will aid in locating the defective component. When the defective component is located, replace it using the appropriate replacement procedure given under Corrective Maintenance in this section.



Before: using any test equipment to make measurements on static-sensitive, currentsensitive, or voltage-sensitive components or assemblies, ensure that any voltage or current supplied by the test equipment does not exceed the limits of the component to be tested.

1. Check Control Settings

Incorrect control settings can give a false indication of instrument malfunction. If there is any question about the correct function or operation of any control, refer to either the Operating Information in Section 2 of this manual or to the Operators Manual.

2. Check Associated Equipment

Before proceeding, ensure that any equipment used with the instrument is operating correctly. Verify that input signals are properly connected and that the interconnecting cables are not defective. Check that the ac-power-source voltage to all equipment is correct.

To avoid electrical shock, disconnect the instrument from the ac power source before making a visual inspection of the internal circuitry.

3. Visual Check

Perform a visual inspection. This check may reveal broken connections or wires, damaged components, semiconductors not firmly mounted, damaged circuit boards, or other clues to the cause of an instrument malfunction.

WARNING

Dangerous potentials exist at several points throughout this instrument. If it is operated with the cabinet removed, do not touch exposed connections or components.

4. Check Instrument Performance and Adjustment

Check the performance of either those circuits where trouble appears to exist or the entire instrument. The apparent trouble may be the result of misadjustment. Complete performance check and adjustment instructions are given in Sections 4 and 5 of this manual.

5. Isolate Trouble to a Circuit

To isolate problems to a particular area, use any symptoms noticed to help locate the trouble. Refer to the troubleshooting charts in the Diagrams section as an aid in locating a faulty circuit.

6. Check Power Supplies

When trouble symptoms appear in more that one circuit, first check the power supplies; then check the affected circuits by taking voltage and waveform readings. Check first for the correct output voltage of each individual supply. These voltages are measured between the power supply test points and ground (see the associated circuit board illustration and Table 6–5).

Voltage levels may be measured either with a DMM or with an oscilloscope. Voltage ripple amplitudes must be measured using an oscilloscope. Before checking power-supply circuitry, set the INTENSITY control to normal brightness, the SEC/DIV switch to 0.1 ms, the Trigger MODE to P-P AUTO, and the Vertical MODE switch to CH 1.

When measuring ripple, use a 1X probe. The ripple values listed are based on a system limited in bandwidth to 30 kHz. Using a system with wider bandwidth will result in higher readings.

If the power-supply voltages and ripple are within the ranges listed in Table 6-4, the supply can be assumed to be working correctly. If they are outside the range, the supply may be either misadjusted or operating incorrectly. Use the Power Supply and CRT Display subsection in the Adjustment Procedure to adjust the -8.6-V supply.

A defective component elsewhere in the instrument can create the appearance of a power-supply problem and may also affect the operation of other circuits.

Power Supply	Test Point	Reading (Volts)	P-P Ripple
-8.6 V ₁	W989	-8.56 to -8.64	5 mV
+5.0 V ₁	W991	+4.85 to +5.15	5 mV
+8.6 V 1	W987	+8.34 to +8.86	5 mV
+102.0 V	W984	+98.9 to +105.0	20 mV
+205.0 V	W985	+198.8 to +211.1	50 mV
+22 V unreg	W752	Approx. +24 V	Approx. 1 V ^a

Table 6-4 Power Supply Voltage and Ripple Limits

^aSet SEC/DIV switch to X-Y.

7. Check Circuit Board Interconnections

After the trouble has been isolated to a particular circuit, again check for loose or broken connections, improperly seated semiconductors, and heat-damaged components.

8. Check Voltages and Waveforms

Often the defective component can be located by checking circuit voltages or waveforms. Typical voltages are listed on the schematic diagrams. Waveforms indicated on the schematic diagrams by hexagonal-outlined numbers are shown adjacent to the diagrams. Waveform test points are shown on the circuit board illustrations.

NOTE

Voltages and waveforms indicated on the schematic diagrams are not absolute and may vary slightly between instruments. To establish operating conditions similar to those used to obtain these readings, see the Voltage and Waveform Setup Conditions preceding the waveform illustrations in the Diagrams section. Note the recommended test equipment, front-panel control settings, voltage and waveform conditions, and cableconnection instructions. Any special control settings required to obtain a given waveform are noted under the waveform illustration. Changes to the control settings from the initial setup, other than those noted, are not reauired.

9. Check Individual Components



To avoid electric shock, always disconnect the instrument from the ac power source before removing or replacing components.

The following procedures describe methods of checking individual components. Two-lead components that are soldered in place are most accurately checked by first disconnecting one end from the circuit board. This isolates the measurement from the effects of the surrounding circuitry. See Figure 9–1 for component value identification and Figure 9–2 for semiconductor lead configurations.



When checking semiconductors, observe the static-sensitivity precautions located at the beginning of this section.

TRANSISTORS. A good check of a transistor is actual performance under operating conditions. A transistor can most effectively be checked by substituting a known-good component. However, be sure that circuit conditions are not such that a replacement transistor might also be damaged. If substitute transistors are not available, use a dynamic-type transistor checker for testing. Static-type transistor checkers are not recommended, since they do not check operation under simulated operating conditions.

When troubleshooting transistors in the circuit with a voltmeter, measure both the emitter-to-base and emitter-to-collector voltages to determine whether they are consistent with normal circuit voltages. Voltages across a transistor may vary with the type of device and its circuit function.

Some of these voltages are predictable. The emitter-to-base voltage for a conducting silicon transistor will normally range from 0.6 V to 0.8 V. The emitter-to-collector voltage for a saturated transistor is about 0.2 V. Because these values are small, the best way to check them is by connecting a sensitive voltmeter across the junction rather than comparing two voltages taken with respect to ground. If the former method is used, both leads of the voltmeter must be isolated from ground.

If voltage values measured are less than those just given, either the device is shorted or no current is flowing in the external circuit. If values exceed the emitter-to-base values given, either the junction is reverse biased or the device is defective. Voltages exceeding those given for typical emitter-tocollector values could indicate either a nonsaturated device operating normally or a defective (opencircuited) transistor. If the device is conducting, voltage will be developed across the resistors in series with it; if open, no voltage will be developed across the resistors unless current is being supplied by a parallel path.

E CAUTION S

When checking emitter-to-base junctions, do not use an ohmmeter range that has a high internal current. High current may damage the transistor. Reverse biasing the emitterto-base junction with a high current may degrade the current-transfer ratio (Beta) of the transistor.

A transistor emitter-to-base junction also can be checked for an open or shorted condition by measuring the resistance between terminals with an ohmmeter set to a range having a low internal source current, such as the R X 1-kW range. The junction resistance should be very high in one direction and much lower when the meter leads are reversed.

When troubleshooting a field-effect transistor (FET), the voltage across its elements can be checked in the same manner as previously described for other transistors. However, remember that in the normal depletion mode of operation, the gate-to-source junction is reverse biased; in the enhanced mode, the junction is forward biased.

INTEGRATED CIRCUITS. An integrated circuit (IC) can be checked with a voltmeter, test oscilloscope, or by direct substitution. A good understanding of circuit operation is essential when troubleshooting a circuit having IC components. Use care when checking voltages and waveforms around the IC so that adjacent leads are not shorted together. An IC test clip provides a convenient means of clipping a test probe to an IC.

E CAUTION S

When checking a diode, do not use an ohmmeter scale that has a high internal current. High current may damage a diode. Checks on diodes can be performed in much the same manner as those on transistor emitterto-base junctions.

DIODES. A diode can be checked for either an open or a shorted condition by measuring the

resistance between terminals with an ohmmeter set to a range having a low internal source current, such as the R X 1-k Ω range. The diode resistance should be very high in one direction and much lower when the meter leads are reversed.

Silicon diodes should have 0.6 V to 0.8 V across their junctions when conducting; Schottky diodes about 0.2 V to 0.4 V. Higher readings indicate that they are either reverse biased or defective, depending on polarity.

RESISTORS. Check resistors with an ohmmeter. Refer to the Replaceable Electrical Parts list for the tolerances of resistors used in this instrument. A resistor normally does not require replacement unless its measured value varies widely from its specified value and tolerance.

INDUCTORS. Check for open inductors by checking continuity with an ohmmeter. Shorted or partially shorted inductors can usually be found by checking the waveform response when high-frequency signals are passed through the circuit.

CAPACITORS. A leaky or shorted capacitor can best be detected by checking resistance with an ohmmeter set to one of the highest ranges. Do not exceed the voltage rating of the capacitor. The resistance reading should be high after the capacitor is charged to the output voltage of the ohmmeter. An open capacitor can be detected with a capacitance meter or by checking whether the capacitor passes ac signals.

10. Repair and Adjust the Circuit

If any defective parts are located, follow the replacement procedures given under Corrective Maintenance in this section. After any electrical component has been replaced, the performance of that circuit and any other closely related circuit should be checked. Since the power supplies affect all circuits, performance of the entire instrument should be checked if work has been done on the power supplies or if the power transformer has been replaced. Readjustment of the affected circuitry may be necessary. Refer to the Performance Check Procedure and Adjustment Procedure, Sections 4 and 5 of this manual and to Table 5–1 (Adjustments Affected by Repairs).

CORRECTIVE MAINTENANCE

INTRODUCTION

Corrective maintenance consists of component replacement and instrument repair. This part of the manual describes special techniques and procedures required to replace components in this instrument. If it is necessary to ship your instrument to a Tektronix Service Center for repair or service, refer to the repackaging information in Section 2 of this manual.

MAINTENANCE PRECAUTIONS

To reduce the possibility of personal injury or instrument damage, observe the following precautions.

1. Disconnect the instrument from the acpower source before removing or installing components.

2. Verify that the line-rectifier filter capacitors are discharged prior to performing any servicing.

3. Use care not to interconnect instrument grounds which may be at different potentials (cross grounding).

4. When soldering on circuit boards or small insulated wires, use only a 15-watt, pencil-type soldering iron.

OBTAINING REPLACEMENT PARTS

Most electrical and mechanical parts can be obtained through your local Tektronix Field Office or representative. However, many of the standard electronic components can usually be obtained from a local commercial source. Before purchasing or ordering a part from a source other than Tektronix, Inc., please check the Replaceable Electrical Parts list for the proper value, rating, tolerance, and description.

NOTE

Physical size and shape of a component may affect instrument performance, particularly at high frequencies. Always use directreplacement components, unless it is known that a substitute will not degrade instrument performance.

Special Parts

In addition to the standard electronic components, some special parts are used in the instrument. These components are manufactured or selected by Tektronix, Inc., to meet specific performance requirements, or are manufactured for Tektronix, Inc., in accordance with our specifications. The various manufacturers can be identified by referring to the Cross Index-Manufacturer's Code number to Manufacturer at the beginning of the Replaceable Electrical Parts list. Most of the mechanical parts used in this instrument were manufactured by Tektronix, Inc. Order all special parts directly from your local Tektronix Field Office or representative.

Ordering Parts

When ordering replacement parts from Tektronix, Inc., be sure to include all of the following information:

1. Instrument type (include all modification and option numbers).

2. Instrument serial number.

3. A description of the part (if electrical, include its full circuit component number).

4. Tektronix part number.

MAINTENANCE AIDS

The maintenance aids listed in Table 6–5 include items required for performing most of the maintenance procedures in this instrument. Equivalent products may be substituted for those given, provided their characteristics are similar.

Description	Specification	Usage	Example
1. Soldering Iron	15 to 25 W.	General soldering and unsoldering.	Antex Precision Model C.
2. Torx Screwdriver	Torx tips #T9 and #T15.	Assembly and disassembly.	Tektronix p/n #T9 003-0965-00 #T15 003-0966-00.
3. Nutdrivers	1/4 inch, 7/16 inch, and 1/2 inch.	Assembly and disassembly.	Xcelite #8, #10, #14, and #16.
4. Open-end Wrench	5/16 inch and 1/2 inch.	Channel Input, EXT BNC connectors and Transformer.	
5. Hex Wrenches	1/16 inch.	Assembly and disassembly.	Allen wrenches.
6. Long-nose Pliers		Component removal and replacement.	
7. Diagonal Cutters		Component removal and replacement.	
8. Vacuum Solder Extractor	No Static Charge Retention.	Unsoldering components.	Pace Model PC-10.
9. 1X Probe		Power supply ripple check.	Tektronix P6101 Probe (X1), p/n 010-6101-03.
10. Lubricant	No-Noise.®	Switch lubrication.	Tektronix p/n 006-0442-02.

Table 6-5 Maintenance Aids

RIBBON-CABLE CONNECTIONS

Connections between circuit boards are accomplished with ribbon cables. One end of the ribbon cables is inserted into the multipin connector while the other end is soldered to the circuit board. The ribbon cable to the multipin connector can be removed or installed by pressing down on the release bar of the connector as shown in Figure 6-1. To remove the ribbon cable, pull it straight out from the connector; to install the ribbon cable, insert the bare wires up to the insulation into the connector. Remove pressure from the release bare, the ribbon cable will be lock firmly into the connector. To provide correct orientation of a cable, a number "1" is stamped on the circuit board and on top of the multipin connector. The index wire of the ribbon is striped a different color than the rest of the cable. Align the index wire with the pin 1 indicator when reinserting the ribbon cable into its connector. Ensure the ribbon cable is evenly trimmed and 5 mm of wire (about 1/4 inch) is exposed for correct insertion into the connector.

If any individual wire in the cable is faulty, the entire ribbon cable should be replaced. When unsoldering the ribbon cable from the circuit board, note the location of the ribbon cable for reinstallation purposes. Align the index wire with the square pad on the circuit board.



Figure 6-1. Multi-connector holder orientation.

TRANSISTORS AND INTEGRATED CIRCUITS

Transistors and integrated circuits should not be replaced unless they are actually defective. If removed from their sockets or unsoldered from the circuit board during routine maintenance, return them to their original circuit board locations. Unnecessary replacement or transposing of semiconductor devices may affect the adjustment of the instrument. When a semiconductor is replaced, check the performance of any circuit that may be affected.

Any replacement component should be of the original type or a direct replacement. Bend transistor leads to fit their circuit board holes, and cut the leads to the same length as the original component. See Figure 9–2 in the Diagrams section for lead-configuration illustrations.

Power-supply transistors Q933, Q942, and Q946 are insulated from the chassis by a heat-transferring pad and insulation bushing. Reinstall the pad and bushing when replacing this transistor.

NOTE

After replacing a power transistor, check that the collector is not shorted to the chassis before applying power to the instrument.

To remove socketed, dual-in-line-packaged (DIP) integrated circuits, pull slowly and evenly on both ends of the device. Avoid disengaging one end of the integrated circuit from the socket before the other, since this may damage the pins.

To remove a soldered DIP IC when it is going to be replaced, clip all the leads of the device and remove the leads from the circuit board one at a time. If the device must be removed intact for possible reinstallation, do not heat adjacent conductors consecutively. Apply heat to pins at alternate sides and ends of the IC as solder is removed. Allow a moment for the circuit board to cool before proceeding to the next pin.

SOLDERING TECHNIQUES

The reliability and accuracy of this instrument can be maintained only if proper soldering techniques are used to remove or replace parts. General soldering techniques, which apply to maintenance of any precision electronic equipment, should be used when working on this instrument.

WARNING

To avoid an electric-shock hazard, observe the following precautions before attempting any soldering: turn the instrument off, disconnect it from the ac power source, and wait at least three minutes for the line-rectifier filter capacitors to discharge.

Use rosin-core wire solder containing 63% tin and 37% lead. Contact your local Tektronix Field Office or representative to obtain the names of approved solder types.

When soldering on circuit boards or small insulated wires, use only a 15-watt, pencil-type soldering iron. A higher wattage soldering iron may cause etched-circuit conductors to separate from the circuit board base material and melt the insulation on small wires. Always keep the soldering-iron tip properly tinned to ensure best heat transfer from the iron tip to the solder joint. Apply only enough solder to make a firm joint. After soldering, clean the area around the solder connection with an approved flux-removing solvent (such as isopropyl alcohol) and allow it to air dry. Attempts to unsolder, remove, and resolder leads from the component side of a circuit board may cause damage to the reverse side of the circuit board.

The following techniques should be used to replace a component on a circuit board:

1. Touch the vacuum desoldering tool to the lead at the solder connection. Never place the iron directly on the circuit board; doing so may damage the circuit board.

NOTE

Some components are difficult to remove from the circuit board due to a bend placed in the component leads during machine insertion. To make removal of machineinserted components easier, straighten the component leads on the reverse side of the circuit board.

2. When removing a multipin component, especially an IC, do not heat adjacent pins consecutively. Apply heat to the pins at alternate sides and ends of the IC as solder is removed. Allow a moment for the circuit board to cool before proceeding to the next pin.

E CAUTION S

Excessive heat can cause the etched-circuit conductors to separate from the circuit board. Never allow the solder extractor tip to remain at one place on the circuit board for more than three seconds. Damage caused by poor soldering techniques can void the instrument warranty.

3. Bend the leads of the replacement component to fit the holes in the circuit board. If the component is replaced while the circuit board is installed in the instrument, cut the leads so they protrude only a small amount through the reverse side of the circuit board. Excess lead length may cause shorting to other conductive parts.

4. Insert the leads into the holes of the circuit board so that the replacement component is positioned the same as the original component. Most components should be firmly seated against the circuit board.

5. Touch the soldering iron to the connection and apply enough solder to make a firm solder joint.

Do not move the component while the solder hardens.

6. Cut off any excess lead protruding through the circuit board (if not clipped to the correct length in step 3).

7. Clean the area around the solder connection with an approved flux-removing solvent. Be careful not to remove any of the printed information from the circuit board.

REMOVAL AND REPLACEMENT INSTRUCTIONS

The exploded view drawings in the Replaceable Mechanical Parts list (Section 10) may be helpful during the removal and reinstallation of individual subassemblies or components. Circuit board and component locations are shown in the Diagrams section.

Cabinet

WARNING

To avoid electric shock, disconnect the instrument from the ac-power-input source before removing or replacing any component or assembly.

To remove the instrument cabinet, perform the following steps:

1. Disconnect the power cord from the instrument. For instruments with a power-cord securing clamp, remove the Phillips-head screw holding the power-cord securing clamp before disconnecting the power cord.

2. Remove two screws and the two power cord retainers from the rear panel (located on each side). Remove the rear panel.

3. Remove two screws from the rear panel (located on each side) and remove it from the instrument.

4. Remove four screws, one from the left-rear side and three from the right-rear side of the cabinet.

5. Use one hand to rise the center rear of the cabinet until the tab clears the slot in the rear chassis. With the other hand, push the instrument chassis forward until it clears the cabinet tab.

6. Pull the front panel and attached chassis forward and out of the cabinet.

7. To reinstall the cabinet, perform the reverse of the preceding steps. Ensure that the cabinet tab is inserted in the rear-chassis slot, and the cabinet is flush with the rear of the chassis.

8. Reinstall the rear panel. Ensure the rear chassis tabs are inserted into the slots in the rear panel properly (slots are located just above the bottom rear feet), and the screw holes in the rear chassis and rear panel are properly aligned.

9. Reconnect the power cord and power-cord securing clamp (if removed in step 1).

Cathode-Ray Tube

WARNING

Use care when handling a crt. Breakage of the crt may cause high-velocity scattering of glass fragments (implosion). Protective clothing and safety glasses should be worn. Avoid striking the crt on any object which may cause it to crack or implode. When storing a crt, either place it in a protective carton or set it face down on a smooth surface in a protected location with a soft mat under the faceplate.

The crt can be removed and reinstalled as follows:

1. Unsolder the Trace Rotation wires (J987) from the Front-Panel circuit board (note the connection locations and wire colors for reinstallation reference).

2. Remove two front-panel screws that retain the plastic crt frame and light filter to the front panel. Remove the crt frame and light filter from the instrument.

3. With the rear of the instrument facing you, place the fingers of both hands over the front edge of the front subpanel. Then, using both thumbs, press forward gently on the crt funnel near the front of the crt. When the crt base pins disengage from the socket, remove the crt and the crt shield through the instrument front panel. Place the crt in a safe place until it is reinstalled. If the plastic crt corner pads fall out, save them for reinstallation.

NOTE

When installing the crt into the instrument, reinstall any loose plastic crt corner pads that are out of place. Ensure all crt pins are straight and that the indexing keys on the crt base, socket, and shield are aligned. Ensure that the ground clip from the crt support bracket makes contact only with the outside of the crt shield.

To reinstall the crt, perform the reverse of the preceding steps.

Power Transformer

ι

The Power Transformer (T901) can be removed and reinstalled as follows:

1. Remove the top Power Supply shield by performing the following instructions.

a. Rotate the instrument until the rear chassis is facing you.

b. Using both hands, place the fingers underneath and the thumbs on top of the Power Supply shield.

c. Gently push the Power Supply shield towards the rear chassis and at the same time pull up on the shield until the tabs are clear of the slots in the inner chassis.

d. Pull the Power Supply shield towards the front of the instrument with a slight upward tilt until the rear tabs are clear of the slots in the rear chassis.

2. Disconnect P902, a seven-wire connector from J902 on the Mains Input circuit board. Note the orientation of the connector for proper reinstallation.

3. Remove the four nuts and lock washers from the Power Transformer (inside the instrument) without removing the support screws (supporting the transformer) from the rear panel. Note the physical orientation of the Power Transformer.

4. Supporting the Transformer with one hand, pull the four screws out until the transformer is free (leaving the screws inside of the supports). Remove the transformer and the four screws and supports from the instrument.

To reinstall the Power Transformer, perform the reverse of the preceding steps.

Mains Input Circuit Board

The Mains Input circuit board can be removed and reinstalled as follows:

1. Perform steps 1 and 2 of the Power Transformer procedure.

2. Unsolder W903, a three wire ribbon from Mains Input circuit board.

3. Remove the POWER knob shaft by inserting a scribe (or similar tool) in the notch between the end of the knob shaft and the end of the Power switch shaft and gentry pry the connection apart. Pull the POWER knob shaft out through the front panel.

4. Remove the two screws and nuts that secure the power cord receptacle to the rear chassis.

5. Remove the grounding screw and nut (top corner) that secure the Mains Input circuit board to the inner chassis.

6. Pull the Mains Input circuit board and attached shield towards the inner chassis and up out of the instrument.

To reinstall the Mains Input circuit board, perform the reverse of the preceding steps.

Timebase/Attenuator Circuit Board Assembly

The Timebase/Attenuator circuit board assembly can be removed and reinstalled as follows:

1. Place the instrument on its side (CRT down) and unsolder the following wire straps and resistors, noting their locations for reinstallation reference:

a. Unsolder the two resistors from the CH 1 VOLTS/DIV and CH 2 VOLTS/DIV switches to the Front-Panel circuit board.

b. Unsolder the wire strap to the CH 1 OR X connector ground lug from the Timebase/ Attenuator circuit board wire strap.

c. Unsolder the wire strap to the CH 2 OR Y connector ground lug from the Timebase/ Attenuator circuit board wire strap.

d. Unsolder and pull the two wire straps from the Front-Panel circuit board that comes from the Attenuator circuit board. 2. Place the instrument down (normal position) and use a 1/16-inch hex wrench to loosen the set screws on the CH 1 VOLTS/DIV, CH 2 VOLTS/DIV, and SEC/DIV Variable knobs.

3. Remove CH 1 VOLTS/DIV, CH 2 VOLTS/DIV, and SEC/DIV Variable knobs and switch knobs from the instrument.

4. Disconnect the following cables from the Timebase/Attenuator circuit board assembly, noting their locations for reinstallation reference:

a. J90, a six-wire cable located at the rear edge of the circuit board.

b. J755, a four-wire cable located at the rear right-hand corner of the circuit board.

c. J30, a four-wire cable located to the left of the CH 1 attenuator switch.

d. J80, a four-wire cable located between the CH 1 and CH 2 attenuator switches.

e. J7, a six-wire cable located between the CH 2 attenuator switch and the SEC/DIV switch.

f. J701, a six-wire cable located at the front right-hand corner of the circuit board.

5. Remove the following three screws that secure the Timebase/Attenuator circuit board to the post spacers.

a. One screw from the right-rear corner of the Timebase/Attenuator circuit board assembly.

b. Two screws from the extreme left side of the Timebase/Attenuator circuit board assembly.

6. Remove the Focus knob shaft by pulling the shaft with one hand towards the front while holding the Focus pot shaft with the other hand.

7. Pull the Timebase/Attenuator circuit assembly board straight back from the front of the instrument until the attenuator switches are clear of the Front-Panel circuit board. Then lift out the entire assembly through the top of the instrument.

NOTE

If accessibility to the bottom of the Timebase/ Attenuator circuit board is desired perform steps 8 through 10. 8. Remove one screw from the center front bottom of the attenuator shield.

9. Remove two screws from the front corners of the Timebase/Attenuator circuit board and two nuts from the front corners of the attenuator shield.

10. Remove the attenuator shield by pulling it back until the shield tab clears the Timebase/ Attenuator ground bracket.

To reinstall the Timebase/Attenuator circuit board assembly, perform the reverse of the preceding steps.

Front-Panel Circuit Board

The Front-Panel circuit board can be removed and reinstalled as follows:

1. Perform the Timebase/Attenuator circuit board assembly removal procedure.

2. Remove the knobs from the following control shafts by pulling them straight out from the front panel:

- a. INTENSITY.
- b. Channel 1 and Channel 2 POSITION.
- c. Horizontal POSITION
- e. LEVEL.

3. Turn the instrument on its side (CRT down) and unsolder the following wire straps and resistors underneath the instrument, noting their locations for reinstallation reference:

a. Unsolder the two resistors and bare straps to the CH 1 OR X and CH 2 OR Y connectors and ground lugs from the Front-Panel circuit board.

b. Unsolder the resistor and ground strap to the EXT INPUT OR Z connector and ground lug from the Front-Panel circuit board.

4. Turn the instrument over again and unsolder the Trace Rotation wires (J987) from the Front-Panel circuit board (note the connection locations and wire colors for reinstallation reference).

5. Remove the Power Switch extension shaft by disengaging from power switch and pulling it out through the Front-Panel circuit board.

6. Disconnect the following six-wire cables from the front edge of Main circuit board, noting their locations for reinstallation reference: J1, J2, J3, J5, and J6. 7. Remove the five screws that secure the Front-Panel circuit board to the front chassis, noting their respective positions.

8. Remove the Front-Panel circuit board from the front chassis taking care not to lose the slider switch covers.

To reinstall the Front-Panel circuit board, perform the reverse of the preceding steps.

Main Circuit Board

All components on the Main circuit board are accessible either directly or by removing either the crt, Power Transformer or the Timebase/Attenuator circuit board assembly. Removal of the Main circuit board is required only when it is necessary to replace the circuit board with a new one.

The Main circuit board can be removed and reinstalled as follows:

1. Perform the Cathode-Ray Tube removal procedure.

2. Perform step 1 of the Power Transformer procedure.

3. Unsolder the three-wire cable from the FOCUS potentiometer. The FOCUS potentiometer is located on the rear of the inner chassis.

4. Unsolder W893 from the Main circuit board. The cable is connected to the Focus pot located on the rear of the inner chassis.

5. Unsolder W903, a three ribbon from the Mains Input circuit board.

6. Disconnect the following cables from the Timebase/Attenuator circuit board assembly, noting their locations for reinstallation reference:

a. J90, a six-wire cable located at the rear edge of the circuit board.

b. J755, a four-wire cable located at the rear right-hand corner of the circuit board.

c. J30, a four-wire cable located to the left of the CH 1 attenuator switch.

d. J80, a four-wire cable located between the CH 1 and CH 2 attenuator switches.

e. J7, a six-wire cable located between the CH 2 attenuator switch and the SEC/DIV switch.

f. J701, a six-wire cable located at the front right-hand corner of the circuit board.

7. Rotate the instrument until the rear chassis is facing you.

8. Remove the two screws (lower right corner) that secure the heat sink for the vertical output transistors to the rear chassis.

9. Remove the one screw (lower left corner) that secures the heat sink for the power supply transistors to the rear chassis.

10. Turn instrument upside down and rotate it until the front is facing you.

11. Unsolder the wire connected to the PROBE ADJUST terminal from the Main circuit board.

12. Remove the bottom power supply shield by inserting a narrow-blade screwdriver at each corner of the projecting edge and gently pry up until the two tabs are cleared of the slots in the Main circuit board. Pull and remove the shield out from underneath the rear chassis.

13. Remove four screws from the middle of the Main circuit board that secures the Timebase/ Attenuator post spacers and inner chassis to the Main circuit board.

14. Remove three screws and two nuts that secure the Main circuit board and Timebase/Attenuator spacer post to the left side of the chassis frame. 15. Remove three screws and nuts that secure the Main circuit board to the right side of the chassis frame.

16. Pull the Main circuit board forward to clear the guides on the rear chassis.

NOTE

The front edge of the Main circuit board needs to be tilted out and away from the instrument to allow the removal of the ribbon cables.

17. Disconnect the following six-wire cables from the front edge of Main circuit board, noting their locations for reinstallation reference: J1, J2, J3, J5, and J6.

18. Lift the Main circuit board out of the instrument.

To reinstall the Main circuit board, perform the reverse of the preceding steps. Ensure that the Main circuit board is secure in the guides of the rear chassis.

ć

OPTIONS AND ACCESSORIES

This section contains a general description of options that can be included with the original instrument order. Options available at the time of manual publication are listed as follows:

Option 1C	Low Cost Camera
Option 1K	Instrument Cart
Option 1R	Rackmounting
Option 1T	Transit Case
Option 02	Front Panel Cover
	and Accessories
	Pouch
Option 22	24-1X Signal
	Adapters
Option 23	Two-10X Standard
	P6103 Probes
Option 24	Two-1X to 10X
	P6062B Selectable-
	Attenuation Probes
Options A1-A5	International Power
	Cords

To obtain any of these options or other accessories after the instrument has been received, refer to Tables 7–1 (Power Cords and Fuses) and Tables 7–2 (Optional Accessories), in this section. For additional information about instrument options and other optional accessories, consult the current Tektronix Product Catalog or contact your local Tektronix Sales Office or distributor.

OPTION 1C

When Option 1C is specified, a Tektronix C-5c Option 04 low-cost camera is included in the shipment. The camera is useful for capturing single events and documenting measurement results.

OPTION 1K

When Option 1K is specified, a K212 Portable Instrument Cart is included in the shipment. The cart provides a stable, movable platform that is well suited for on-site instrument mobility.

OPTION 1R

When the oscilloscope is ordered with Option 1R, it is shipped in a configuration that permits easy installation into virtually any 19-inch wide electronic equipment rack. All hardware is supplied for mounting the instrument into the main frame.

Complete rack mounting instructions are provided in a separate document. These instructions also contain the procedures for converting a standard instrument into the Option 1R configuration by using the separately orderable rack-mounting conversion kit.

OPTION 1T

When Option 1T is specified, a composite case of 24.5" X 16.5" X 11.5" that weighs 12 lbs. 6 oz. is included in the shipment. The composite case is useful as a reusable shipping container or a carryon luggage container for the instrument.

OPTION 02

Option 02 is intended for users who need added front-panel protection and accessories-carrying ease. It includes a protective front panel cover and an accessories pouch that attaches to the top of the instrument.

OPTION 22

When Option 22 is specified, 24 1X Signal Adapters are included with the instrument. Each cable has one BNC Male connector on one end and two clip heads on the other end of the cable.

OPTION 23

When Option 23 is specified, two P6103 10X Probes are included with the instrument.

OPTION 24

When Option 24 is specified, two P6062B 1X to 10X Selectable-Attenuation Probes are included with the instrument.

OPTIONS A1-A5 INTERNATIONAL POWER CORDS

Instruments are shipped with the detachable power cord and fuse configuration ordered by the customer. Table 7–1 identifies the Tektronix part numbers for international power cords and associated fuses. Descriptive information about power cord options is provided in Section 1, Preparation for Use.

OPTIONAL ACCESSORIES

Table 7-2 lists recommended optional accessories for your instrument.

Description	Part Number
Option A1 (Europe)	
Power Cord, 2.5 m	161-0104-06
Fuse, 0.5 A, 250 V, 3AG, ¹ /4"x 1 ¹ /4", Slow	159-0032-00
Option A2 (United Kingdom)	
Power Cord, 2.5 m	161-0104-07
Fuse, 0.5 A, 250 V, 3AG, ¹ /4"x 1 ¹ /4", Slow	159-0032-00
Option A3 (Australia)	
Power Cord, 2.5 m	161-0104-05
Fuse, 0.5 A, 250 V, 3AG, 1/4"x 11/4", Slow	159-0032-00
Option A4 (North America)	
Power Cord, 2.5 m	161-0104-08
Fuse, 0.5 A, 250 V, 3AG, 1/4"x 11/4", Slow	159-0032-00
Option A5 (Switzerland)	
Power Cord, 2.5 m	161-0167-00
Fuse, 0.5 A, 250 V, 3AG, ¹ /4"x 1 ¹ /4", Slow	159-0032-00

Table 7-1 International Power Cords and Fuses

Table 7-2 Optional Accessories

Description	Part Number
Front Panel Protective Cover	200-3397-00
Accessory Pouch	016-0677-02
Front Panel Protective Cover and Accessory Pouch	020-1514-00
Transit Case	016-0792-01
CRT Light Filter, Clear	337-2775-01
Rack Mount Conversion Kit	016-0819-00
Viewing Hoods Collapsible Polarised Binocular	016-0592-00 016-0180-00 016-0566-00
Probe, 10X, 2 m, with accessories	P6103
Alternative Power Cords Standard (United States) European United Kingdom Australian North American Swiss Attenuator Voltage Probes 10X Standard 10X Subminiature 1X-10X Environmental 1X-10X Environmental 1X-10X Selectable 100X High Voltage 1000X High Voltage	161-0104-00 020-0859-00 020-0860-00 020-0861-00 020-0862-00 020-0863-00 P6103 P6130 P603 P6008 P6008 P6009 P6015 P6021, P6022, A6302/AM503, A6303/AM503
Current-Probe Amplifier	134
Probe 10X, FET	P6202A
Active-probe Power Supply	1101A
Ground Isolation Monitor	A6901
Isolator (for multiple, inde- pendently referenced, differential measurements)	A6902B
DC Inverter	1107
DC Inverter Mounting Kit	016-0785-00

Table 7-2 (cont)

Description	Part Number	
Portable Power Supply	1105	
Battery Pack	1106	
Oscilloscope Cameras		
Low-cost	C-5C Option 04	
Motorized	C-7 Option 03 and Option 30	
Portable Instrument Cart	K212	
2205 Service Manual	070-6716-00	

STANDARD ACCESSORIES

Each instrument is shipped with the following standard accessories.

Quantity	Description	Part Number
2	1X Signal Adapters	103-0275-00
1	Operator's Manual	070-6717-00
1	Standard (United States) Power Cord, 2.5 m	161-0230-01
1	Fuse, 0.75 A, 25 V, 3AG, 1/4" x 1 1/4", slow	159-0042-00
1	Fuse, 0.5 A, 250 V, 3AG, 1/4" x 1 1/4", slow	159-0032-00
	For optional power cord and fuse see Table 7-1	
1	Power Cord Clamp	343-0003-00
1	Screw, 6-32	211-0721-00
1	Washer	210-0803-00

ι

REPLACEABLE ELECTRICAL PARTS

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

LIST OF ASSEMBLIES

A list of assemblies can be found at the beginning of the Electrical Parts List. The assemblies are listed in numerical order. When the complete component number of a part is known, this list will identify the assembly in which the part is located.

CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER

The Mfr. Code Number to Manufacturer index for the Electrical Parts List is located immediately after this page. The Cross Index provides codes, names and addresses of manufacturers of components listed in the Electrical Parts List.

ABBREVIATIONS

Abbreviations conform to American National Standard Y1.1.

COMPONENT NUMBER (column one of the Electrical Parts List)

A numbering method has been used to identify assemblies, subassemblies and parts. Examples of this numbering method and typical expansions are illustrated by the following:



Read: Resistor 1234 of Assembly 23



Read: Resistor 1234 of Subassembly 2 of Assembly 23

Only the circuit number will appear on the diagrams and circuit board illustrations. Each diagram and circuit board illustration is clearly marked with the assembly number. Assembly numbers are also marked on the mechanical exploded views located in the Mechanical Parts List. The component number is obtained by adding the assembly number prefix to the circuit number.

The Electrical Parts List is divided and arranged by assemblies in numerical sequence (e.g., assembly A1 with its subassemblies and parts, precedes assembly A2 with its subassemblies and parts).

Chassis-mounted parts have no assembly number prefix and are located at the end of the Electrical Parts List.

TEKTRONIX PART NO. (column two of the Electrical Parts List)

Indicates part number to be used when ordering replacement part from Tektronix.

SERIAL/MODEL NO. (columns three and four of the Electrical Parts List)

Column three (3) indicates the serial number at which the part was first used. Column four (4) indicates the serial number at which the part was removed. No serial number entered indicates part is good for all serial numbers.

NAME & DESCRIPTION (column five of the Electrical Parts List)

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

MFR. CODE (column six of the Electrical Parts List)

Indicates the code number of the actual manufacturer of the part. (Code to name and address cross reference can be found immediately after this page.)

MFR. PART NUMBER (column seven of the Electrical Parts List)

Indicates actual manufacturers part number.

CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

Mfr. <u>Cod</u> e	Manufacturer	Address	City, State, Zip Code
00213	NYTRONICS COMPONENTS GROUP INC SUBSIDIARY OF NYTRONICS INC	ORANGE ST	DARLINGTON SC 29532
00853	SANGAMO WESTON INC COMPONENTS DIV	Sangamo RD Po Box 128	PICKENS SC 29671-9716
01121	ALLEN-BRADLEY CO	1201 S 2ND ST	MILWAUKEE WI 53204-2410
01295	TEXAS INSTRUMENTS INC SEMICONDUCTOR GROUP	13500 N CENTRAL EXPY PO BOX 655012	DALLAS TX 75265
02735	RCA CORP SOLID STATE DIVISION	ROUTE 202	SOMERVILLE NJ 08876
03508	GENERAL ELECTRIC CO SEMI-CONDUCTOR PRODUCTS DEPT	W GENESEE ST	AUBURN NY 13021
04222	AVX CERAMICS DIV OF AVX CORP	19TH AVE SOUTH P 0 BOX 867	MYRTLE BEACH SC 29577
04426	ITW SWITCHES DIV OF ILLINOIS TOOL WORKS INC	6615 W IRVING PARK RD	CHICAGO 1L 60634-2410
047 13	MOTOROLA INC	5005 E MCDOWELL RD	PHOENIX AZ 85008-4229
053 97	SEMICONDUCTOR PRODUCTS SECTOR UNION CARBIDE CORP	11901 MADISON AVE	CLEVELAND OH 44101
05828	MATERIALS SYSTEMS DIV GENERAL INSTRUMENT CORP	600 w John St	HICKSVILLE NY 11802
07716	GOVERNMENT SYSTEMS DIV TRW INC	2850 MT PLEASANT AVE	BURLINGTON IA 52601
13511	TRW IRC FIXED RESISTORS/BURLINGTON AMPHENOL CADRE		LOS GATOS CA
14193	DIV BUNKER RAMO CORP CAL-R INC	1601 OLYMPIC BLVD	SANTA MONICA CA 90406
14750		PO BOX 1397	CAN CARDIEL CA 01770 2000
14752 19396	ILLINOIS TOOL WORKS INC	1710 S DEL MAR AVE 1205 MCCONVILLE RD	SAN GABRIEL CA 91776-3825 LYNCHBURG VA 24502-4535
19 701	PAKTRON DIV MEPCO/CENTRALAB	PO BOX 4539 PO BOX 760	MINERAL WELLS TX 76067-0760
	A NORTH AMERICAN PHILIPS CO MINERAL WELLS AIRPORT		
24546	CORNING GLASS WORKS	550 HIGH ST	BRADFORD PA 16701-3737
31918	ITT SCHADOW INC	550 HIGH ST 8081 WALLACE RD	EDEN PRAIRIE MN 55344-2224
32 997	BOURNS INC TRIMPOT DIV	1200 COLUMBIA AVE	RIVERSIDE CA 92507-2114
34899	FAIR-RITE PRODUCTS CORP	1 COMMERCIAL ROW	WALLKILL NY 12589
51406	MURATA ERIE NORTH AMERICA INC HEADQUARTERS AND GEORGIA OPERATIONS	2200 LAKE PARK DR	SMYRNA GA 30080
52769	SPRAGUE-GOODMAN ELECTRONICS INC	134 FULTON AVE	GARDEN CITY PARK NY 11040-5352
54583	TDK ELECTRONICS CORP	12 HARBOR PARK DR	PORT WASHINGTON NY 11550
55680	NICHICON /AMERICA/ CORP	927 E STATE PKY	SCHAUMBURG IL 60195-4526
56289	SPRAGUE ELECTRIC CO WORLD HEADQUARTERS	92 HAYDEN AVE	LEXINGTON MA 02173-7929
57668	ROHM CORP	8 WHATNEY PO BOX 19515	IRVINE CA 92713
59660	TUSONIX INC	7741 N BUSINESS PARK DR PO BOX 37144	TUCSON AZ 85740-7144
75042	IRC ELECTRONIC COMPONENTS PHILADELPHIA DIV TRW FIXED RESISTORS	401 N BROAD ST	PHILADELPHIA PA 19108-1001
75915	LITTELFUSE INC SUB TRACOR INC	800 E NORTHWEST HWY	DES PLAINES IL 60016-3049
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001
83003	VARO INC	2203 W WALNUT ST PO BOX 401426	GARLAND TX 75042
91637	DALE ELECTRONICS INC	2064 12TH AVE PO BOX 609	COLUMBUS NE 68601-3632
D5243	ROEDERSTEIN E SPEZIALFABRIK FUER KONDENSATOREN GMBN	LUDMILLASTRASSE 23-25	8300 LANDSHUT GERMANY
K0491	SEALECTRO LTD	WALTON ROAD FARLINGTON	PORTSMOUNT ENGLAND
K58 56	RCA LTD	373-399 LONDON ROAD	SURREY ENGLAND
	BEECH HOUSE	CAMBERLEY	-

CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

Mfr.			
Code	Manufacturer	Address	City, State, Zip Code
K7779	SIEMENS LTD SIEMENS HOUSE	WINDMILL ROAD SUNBURY-ON-THAMES	MIDDLESEX TW16 7HS ENGLAND
K8788	PIHER INTERNATIONAL LTD	HORTON ROAD WEST DRAYTON	MIDDLESEX ENGLAND
K8996	MULLARD LIMITED	MULLARD HOUSE TORRINGTON PLACE	LONDON WC1 7 HD ENGLAND
tkooa tko213	G ENGLISH ELECTRONICS LTD TOPTRON CORP	34 BOWATER ROAD	London se18 5TF England Tokyo japan
TK0515	ERICSSON COMPONENTS INC	403 INTERNATIONAL PKY PO BOX 853904	RICHARDSON TX 75085-3904
TK0900	UNITED CHEMI-CON INC	9801 W HIGGINS SUITE 430	ROSEMONT IL 60018-4704
TKODY	A F BULGIN & CO LTD	BYE PASS ROAD BARKING	ESSEX ENGLAND
TK0EA	ARMON ELECTRONICS HERON HOUSE	109 WEMBLY HILL ROAD WEMBLY	MIDDX ENGLAND
tk oe d	COM PONENTS BUREAU UNIT 4	135 DITTON WAY	CAMBRIDGE ENGLAND
TKOEM	MOLEX ELECTRONICS MOLEX HOUSE	Farnham Road Bordon	HAMPSHIRE ENGLAND
TK1450	TOKYO COSMOS ELECTRIC CO LTD	2-268 SOBUDAI ZAWA	KANAGAWA 228 JAPAN
TK1727	PHILIPS NEDERLAND BV AFD ELONCO	POSTBUS 90050	5600 PB EINDHOVEN THE NETHERLANDS
TK1815	Noble - USA Electronic components group	5450 METALBROOK INDUSTRIAL CT	ROLLING MEADOWS IL 60008
U3771	STANLER COMPONENTS BUSINESS CENTRE	HEY LANE	BRAINTREE ENGLAND

.

ι

	Tektronix	Serial/Assembly N).	Mfr.	
<u>Component No.</u>	Part No.	Effective Dsco	it <u>Name & Description</u>	Code	Mfr. Part No
A1	671-0425-00		CIRCUIT BD ASSY:MAIN	80009	671-0425-00
A2	671-0390-00		CIRCUIT BD ASSY:TIMEBASE/ATTEN	80009	671-0390-00
A3	671-0392-00		CIRCUIT BD ASSY: FRONT PANEL	80009	671-0392-00
A4	671-0391-00		CIRCUIT BD ASSY:MAIN INPUT	80009	671-0391-00

ε

A1 671-0425-00 A1C114 281-0767-00 A1C115 281-0775-01 A1C124 281-0775-01 A1C125 281-0772-00 A1C126 283-0051-02 A1C130 283-0108-00 A1C133 281-0775-01 A1C130 283-0108-00 A1C164 281-0775-00 A1C175 281-0775-01 A1C176 283-0051-02 A1C176 283-0108-00 A1C180 283-0108-00 A1C180 283-0108-00 A1C215 281-0775-01 A1C202 290-0183-00 A1C215 281-0771-00 A1C225 281-0771-00 A1C232 281-0771-00 A1C240 281-0771-00 A1C241 281-0775-01 A1C242 281-0075-01 A1C243 281-0775-01 A1C244 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C247 281-0775-01 <th>CIRCUIT BD ASSY:MAIN CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 104F, 20%, 50V CAP, FXD, CER DI: 4700PF, 10%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 0033UF, 5%, 100V CAP, FXD, CER DI: 0. 0033UF, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 200V CAP, FXD, CER DI: 0. 10F, 480-20%, 200V CAP, FXD, CER DI: 0. 10F, 10%, 100V CAP, FXD, CER DI: 0. 10F, 10%, 100V CAP, FXD, CER DI: 0. 10F, 20%, 200V CAP, FXD, CER DI: 2200PF, 10%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V</th> <th>80009 671-0425-00 04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA201C472KAA 04222 SR152A221KAA 04222 MA101A6B0KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR106E1047AA 04222 SR152A221KAA 04222 SR152A221KAA 04222 SR152A221KAA 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SR306E104ZAA 04222 SA106E22MAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA</th>	CIRCUIT BD ASSY:MAIN CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 104F, 20%, 50V CAP, FXD, CER DI: 4700PF, 10%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 0033UF, 5%, 100V CAP, FXD, CER DI: 0. 0033UF, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 100V CAP, FXD, CER DI: 0. 10F, 5%, 200V CAP, FXD, CER DI: 0. 10F, 480-20%, 200V CAP, FXD, CER DI: 0. 10F, 10%, 100V CAP, FXD, CER DI: 0. 10F, 10%, 100V CAP, FXD, CER DI: 0. 10F, 20%, 200V CAP, FXD, CER DI: 2200PF, 10%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	80009 671-0425-00 04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA201C472KAA 04222 SR152A221KAA 04222 MA101A6B0KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR106E1047AA 04222 SR152A221KAA 04222 SR152A221KAA 04222 SR152A221KAA 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SR306E104ZAA 04222 SA106E22MAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA
A1C115 281-0767-00 A1C116 281-0775-01 A1C124 281-0775-01 A1C125 281-0772-00 A1C130 283-0108-00 A1C133 281-0785-00 A1C164 281-0767-00 A1C165 281-0767-00 A1C164 281-0775-01 A1C175 281-0775-01 A1C176 283-0108-00 A1C176 283-0108-00 A1C176 283-0108-00 A1C176 283-0108-00 A1C175 281-0775-01 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0771-00 A1C232 281-0771-00 A1C240 281-0771-00 A1C242 281-0071-00 A1C243 281-0775-01 A1C240 281-0775-01 A1C241 281-0775-01 A1C242 281-0075-01 A1C243 281-0775-01 A1C244 281-0775-01 A1C245 281-0775-01 A1C380 281-0775-01	CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 4700PF, 10%, 100V CAP, FXD, CER DI: 4700PF, 10%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 10F, 10%, 100V CAP, FXD, CER DI: 200PF, 10%, 200V CAP, FXD, CER DI: 200PF, 10%, 200V CAP, FXD, CER DI: 0. 10F, 480-20%, 200V CAP, FXD, CER DI: 0. 10F, 480-20%, 200V CAP, FXD, CER DI: 0. 10F, 480-20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 MA201C472KAA 04222 SR152A221KAA 04222 MA101A6B0KAA 04222 MA101GC331MAA 04222 MA106C331MAA 04222 MA101GC331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 SA106E104ZAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C116 281-0775-01 A1C125 281-0772-00 A1C126 283-0051-02 A1C130 283-0108-00 A1C133 281-0785-00 A1C164 281-0767-00 A1C165 281-0772-01 A1C175 281-0772-01 A1C176 283-0051-02 A1C180 283-0108-00 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0775-01 A1C243 281-0775-01 A1C2445 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C387 281-0775-01 A1C380 281-0775-01	CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:4700PF,10%,100V CAP, FXD, CER DI:220PF,10%,200V CAP, FXD, CER DI:220PF,10%,200V CAP, FXD, CER DI:330PF,20%,100V CAP, FXD, CER DI:330PF,20%,100V CAP, FXD, CER DI:330PF,20%,100V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:200PF,10%,100V CAP, FXD, CER DI:200PF,10%,200V CAP, FXD, CER DI:200VF,10%,35V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,200V CAP, FXD, CER DI:0.1UF,20%,200V CAP, FXD, CER DI:200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V	04222 SA105E104MAA 04222 SA105E104MAA 04222 MA201C472KAA 04222 SR211A332JAATR 04222 SR152A221KAA 04222 MA101A680KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C124 281-0775-01 A1C125 281-0772-00 A1C130 283-0108-00 A1C131 281-0785-00 A1C132 281-0772-00 A1C164 281-0775-01 A1C155 281-0775-01 A1C174 281-0775-01 A1C175 281-0772-00 A1C176 283-0108-00 A1C180 283-0108-00 A1C180 283-0108-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0771-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0075-01 A1C243 281-0775-01 A1C245 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C387 281-0775-01 A1C380 281-0775-01	CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:4700PF,10%,100V CAP, FXD, CER DI:220PF,10%,200V CAP, FXD, CER DI:220PF,10%,200V CAP, FXD, CER DI:330PF,20%,100V CAP, FXD, CER DI:330PF,20%,100V CAP, FXD, CER DI:330PF,20%,100V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.0033UF,5%,100V CAP, FXD, CER DI:220PF,10%,200V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,50V CAP, FXD, CER DI:0.1UF,20%,200V CAP, FXD, CER DI:0.1UF,20%,200V CAP, FXD, CER DI:2200PF,10%,100V CAP, FXD, CER DI:2200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V CAP, FXD, CER DI:2200PF,20%,200V	04222 SA105E104MAA 04222 MA201C472KAA 04222 SR211A332JAATR 04222 SR152A221KAA 04222 MA101A680KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C125 281-0772-00 A1C126 283-0108-00 A1C133 281-0785-00 A1C164 281-0767-00 A1C165 281-0775-01 A1C174 281-0775-01 A1C175 281-0775-01 A1C176 283-0108-00 A1C176 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C215 281-0775-01 A1C222 280-0183-00 A1C223 281-0775-01 A1C240 281-0775-01 A1C232 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-00775-01 A1C242 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01	CAP, FXD, CER DI: 4700PF, 10%, 100V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 220PF, 10%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0.10F, 20%, 50V CAP, FXD, CER DI: 0.10F, 20%, 50V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 0.10F, 10%, 35V CAP, FXD, CER DI: 0.10F, 10%, 35V CAP, FXD, CER DI: 0.10F, 10%, 35V CAP, FXD, CER DI: 0.10F, 480-20%, 200V CAP, FXD, CER DI: 0.10F, 10%, 100V CAP, FXD, CER DI: 2200PF, 10%, 100V CAP, FXD, CER DI: 2200FF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA201C472KAA 04222 SR211A332JAATR 04222 SR152A221KAA 04222 MA101A680KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 05397 T3228105K035AS 04222 SR306E104ZAA 04222 SR306E104ZAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA
A1C126 283-0051-02 A1C130 283-0108-00 A1C133 281-0785-00 A1C164 281-0767-00 A1C165 281-0775-01 A1C174 281-0775-01 A1C175 281-0775-01 A1C176 283-0108-00 A1C180 283-0108-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0775-01 A1C232 281-0775-01 A1C235 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C240 281-0775-01 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01	CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0.10F, 20%, 50V CAP, FXD, CER DI: 0.10F, 20%, 50V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 0.10F, 10%, 35V CAP, FXD, CER DI: 0.10F, 10%, 35V CAP, FXD, CER DI: 0.10F, 480-20%, 200V CAP, FXD, CER DI: 0.10F, 10%, 100V CAP, FXD, CER DI: 2200PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 SR211A332JAATR 04222 SR152A221KAA 04222 MA101A680KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 SR306E104ZAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA 04222 SA106E22ZMAA
A1C130 283-0108-00 A1C133 281-0785-00 A1C164 281-0767-00 A1C165 281-0775-01 A1C175 281-0772-00 A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0775-01 A1C232 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0771-00 A1C243 281-0775-01 A1C244 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C381 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C384 281-0775-01	CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 68PF, 10%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 0.10F, 10%, 35V CAP, FXD, CER DI: 0.1UF, 10%, 35V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, +80-20%, 200V CAP, FXD, CER DI: 0.1UF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 SR152A221KAA 04222 MA101A680KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 SR306E104ZAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C133 281-0785-00 A1C164 281-0767-00 A1C175 281-0775-01 A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0775-01 A1C220 283-0057-00 A1C225 281-0771-00 A1C235 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0775-01 A1C243 281-0775-01 A1C244 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C381 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C389 281-0775-01 A1C389 281-0775-01	CAP, FXD, CER DI: 68PF, 10%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 0033UF, 5%, 100V CAP, FXD, CER DI: 0. 0033UF, 5%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 220PF, 10%, 35V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0. 1UF, 20%, 50V CAP, FXD, CER DI: 0. 1UF, +80-20%, 200V CAP, FXD, CER DI: 0. 1UF, +80-20%, 200V CAP, FXD, CER DI: 2200PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA101A680KAA 04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SR306E104ZAA 04222 SR306E104ZAA 04222 SA105E22MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E22ZMAA
A1C164 281-0767-00 A1C165 281-0775-01 A1C174 281-0772-00 A1C175 281-0772-00 A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C225 281-0775-01 A1C232 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0775-01 A1C243 281-0775-01 A1C244 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C381 281-0775-01 A1C381 281-0775-01 A1C382 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C381 281-0775-01 A1C382 290-0183-00 A1C383 281-0775-01	CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0. 10F, 20%, 50V CAP, FXD, CER DI: 0. 10F, 20%, 50V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 220PF, 10%, 35V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0. 1UF, 480-20%, 200V CAP, FXD, CER DI: 0. 1UF, 480-20%, 200V CAP, FXD, CER DI: 1000PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA106C331MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SR105E104MAA 04222 SA105E104MAA 04222 SA106E104ZAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E22ZMAA
A1C165 281-0775-00 A1C174 281-0775-01 A1C175 281-0772-00 A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0775-01 A1C235 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C240 281-0775-01 A1C242 281-0775-01 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C381 281-0775-01 A1C381 281-0775-01 A1C381 281-0775-01 A1C381 281-0775-01 A1C381 281-0775-01 A1C382 281-0775-01 A1C383 281-0775-01 A1C401 281-0775-01	CAP, FXD, CER DI: 330PF, 20%, 100V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, CER DI: 220PF, 10%, 35V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, +80-20%, 200V CAP, FXD, CER DI: 0.1UF, 10%, 100V CAP, FXD, CER DI: 2200PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA106C331MAA 04222 SA105E104MAA 04222 SA105E104MAA 04222 SR211A332JAATR 04222 SR152A221KAA 05337 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 SR306E104ZAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C174 281-0775-01 A1C175 281-0772-00 A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C215 281-0775-01 A1C225 281-0771-00 A1C232 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C242 281-0771-00 A1C243 281-0775-01 A1C244 281-0775-01 A1C245 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:4700PF, 10%, 100V CAP, FXD, CER DI:0.0033UF, 5%, 100V CAP, FXD, CER DI:220PF, 10%, 200V CAP, FXD, ELCTLT:1UF, 10%, 35V CAP, FXD, ELCTLT:1UF, 10%, 35V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SA105E104MAA 04222 MA201C472KAA 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SA106E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C175 281-0772-00 A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0775-01 A1C232 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C242 281-0771-00 A1C243 281-0775-01 A1C244 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C381 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C389 281-0775-01 A1C402 290-0183-00 A1C401 281-0775-01 A1C488 281-0775-01	CAP, FXD, CER DI: 4700PF, 10%, 100V CAP, FXD, CER DI: 0.0033UF, 5%, 100V CAP, FXD, CER DI: 220PF, 10%, 200V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, 480-20%, 200V CAP, FXD, CER DI: 0.1UF, 480-20%, 200V CAP, FXD, CER DI: 2200PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA201C472KAA 04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C176 283-0051-02 A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0812-00 A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C242 281-0064-00 A1C245 281-0775-01 A1C245 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C383 281-0775-01 A1C384 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 281-0775-01 A1C405 281-0775-01	CAP, FXD, CER DI:0.0033UF, 5%, 100V CAP, FXD, CER DI:220PF, 10%, 200V CAP, FXD, ELCTLT:1UF, 10%, 35V CAP, FXD, ELCTLT:1UF, 10%, 35V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:1000PF, 10%, 100V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SR211A332JAATR 04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SR306E104XAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C180 283-0108-00 A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0812-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C240 281-0771-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C245 281-0775-01 A1C245 281-0775-01 A1C245 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C381 281-0775-01 A1C382 281-0775-01 A1C383 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 281-0775-01 A1C405 281-0775-01	CAP, FXD, CER DI:220PF, 10%, 200V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:1000PF, 10%, 100V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SR152A221KAA 05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C198 290-0183-00 A1C202 290-0183-00 A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0812-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C242 281-0064-00 A1C245 281-0775-01 A1C246 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C381 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C384 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C488 281-0775-01 A1C488 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 290-1150-00	CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, +80-20%, 200V CAP, FXD, CER DI: 1000PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	05397 T3228105K035AS 05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C202 290-0183-00 A1C215 281-0775-01 A1C225 281-0812-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C242 281-0771-00 A1C243 281-0775-00 A1C244 281-0064-00 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 280-0183-00 A1C320 290-0183-00 A1C321 290-0183-00 A1C381 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C381 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C381 281-0775-01 A1C401 281-0775-01 A1C48 281-0775-01 A1C48 290-1150-00 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 </td <td>CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, +80-20%, 200V CAP, FXD, CER DI: 1000PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V</td> <td>05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA</td>	CAP, FXD, ELCTLT: 1UF, 10%, 35V CAP, FXD, CER DI: 0.1UF, 20%, 50V CAP, FXD, CER DI: 0.1UF, +80-20%, 200V CAP, FXD, CER DI: 1000PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	05397 T3228105K035AS 04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C215 281-0775-01 A1C220 283-0057-00 A1C225 281-0812-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C381 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C381 281-0775-01 A1C381 281-0775-01 A1C381 281-0775-01 A1C402 290-0183-00 A1C401 281-0775-01 A1C402 290-0183-00 A1C48 281-0775-01 A1C48 281-0775-01 A1C48 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 <td>CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:1000PF, 10%, 100V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V</td> <td>04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA</td>	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:1000PF, 10%, 100V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SA105E104MAA 04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C220 283-0057-00 A1C225 281-0812-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C381 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C384 281-0775-01 A1C380 281-0775-01 A1C381 281-0775-01 A1C402 290-0183-00 A1C4031 290-0183-00 A1C402 290-0183-00 A1C403 281-0775-01 A1C403 281-0775-01 A1C403 281-0775-01 A1C403 281-0775-01 A1C403 290-1150-00 A1C4048 281-0775-01	CAP, FXD, CER DI:0.1UF, +80-20%, 200V CAP, FXD, CER DI:1000PF, 10%, 100V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SR306E104ZAA 04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C225 281-0812-00 A1C232 281-0771-00 A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-075-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 281-0775-01 A1C405 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C418 290-1150-00 A1C480 281-0775-01 A1C480 281-0775-01 <	CAP, FXD, CER DI: 1000PF, 10%, 100V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 MA101C102KAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C232 281-0771-00 A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 281-0775-01 A1C405 281-0775-01 A1C406 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C418 290-1150-00 A1C480 281-0775-01	CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C235 281-0771-00 A1C239 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C48 281-0775-01 A1C48 290-1150-00 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 290-1150-00 A1C405 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C480 281-0775-01 A1C481 281-0775-01 </td <td>CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V</td> <td>04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA</td>	CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SA106E222MAA 04222 SA106E222MAA 04222 SA106E222MAA
A1C239 281-0771-00 A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 290-1150-00 A1C405 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C480 281-0775-01 A1C481 <t< td=""><td>CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V</td><td>04222 SA106E222MAA 04222 SA106E222MAA</td></t<>	CAP, FXD, CER DI:2200PF, 20%, 200V CAP, FXD, CER DI:2200PF, 20%, 200V	04222 SA106E222MAA 04222 SA106E222MAA
A1C240 281-0771-00 A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0775-01 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C384 281-0775-01 A1C385 281-0775-01 A1C380 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 281-0775-01 A1C405 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C418 290-1150-00	CAP, FXD, CER DI: 2200PF, 20%, 200V	04222 SA106E222MAA
A1C241 281-0205-00 A1C242 281-0064-00 A1C243 281-0064-00 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C247 281-0775-01 A1C247 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C381 281-0775-01 A1C382 290-0183-00 A1C383 281-0775-01 A1C384 281-0775-01 A1C385 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C408 281-0775-01 A1C402 290-0183-00 A1C403 290-1150-00 A1C418 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01		-
AIC242 281-0064-00 AIC243 281-0064-00 AIC245 281-0775-01 AIC246 281-0775-01 AIC247 281-0775-01 AIC248 281-0775-01 AIC247 281-0775-01 AIC248 290-0183-00 AIC321 290-0183-00 AIC322 290-0183-00 AIC380 281-0775-01 AIC381 281-0775-01 AIC389 281-0775-01 AIC401 281-0775-01 AIC402 290-0183-00 AIC448 281-0775-01 AIC448 281-0775-01 AIC480 281-0775-01 AIC481 290-1150-00	CAP. VAR. PLASTIC: 5.5-65 PF-100V	THILD
A1C243 281-0064-00 A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C418 290-1150-00 A1C480 281-0775-01 A1C4418 290-1150-00 A1C481 281-0775-01		TK1727 2222-808-32659
A1C245 281-0775-01 A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C380 281-0775-01 A1C380 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 290-0183-00 A1C405 290-0183-00 A1C406 281-0775-01 A1C407 290-0183-00 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C418 290-1150-00 A1C480 281-0775-01 A1C480 281-0775-01	CAP, VAR, PLASTIC:0.25-1.5PF, 600V	52769 ER-530-013
A1C246 281-0775-01 A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C389 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 290-1150-00 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, VAR, PLASTIC:0.25-1.5PF, 600V	52769 ER-530-013
A1C247 281-0775-01 A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 290-0183-00 A1C380 281-0775-01 A1C382 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C403 281-0775-01 A1C404 290-1150-00 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
A1C248 281-0775-01 A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C382 281-0775-01 A1C384 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C408 281-0775-01 A1C408 281-0775-01 A1C418 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA 04222 SA105E104MAA
A1C320 290-0183-00 A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C389 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01		
A1C321 290-0183-00 A1C322 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01	CAP, FXD, CER DI: 0.1UF, 20%, 50V	04222 SA105E104MAA
A1C322 290-0183-00 A1C380 281-0775-01 A1C381 281-0775-01 A1C389 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, ELCTLT: 1UF, 10%, 35V	05397 T3228105K035AS
A1C380 281-0775-01 A1C381 281-0775-01 A1C387 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, ELCTLT: 1UF, 10%, 35V	05397 T3228105K035AS
A1C381 281-0775-01 A1C387 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, ELCTLT: 1UF, 10%, 35V	05397 T3228105K035AS
A1C387 281-0775-01 A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
A1C389 281-0775-01 A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
A1C401 281-0775-01 A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI: 0.1UF, 20%, 50V	04222 SA105E104MAA
A1C402 290-0183-00 A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
A1C408 281-0775-01 A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
A1C418 290-1150-00 A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, ELCTLT: 1UF, 10%, 35V	05397 T3228105K035AS
A1C431 290-1150-00 A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
A1C480 281-0775-01 A1C481 281-0775-01	CAP, FXD, ELCTLT: 15UF, +50%-10%, 16WVDC	K8996 030~25159
A1C481 281-0775-01	CAP, FXD, ELCTLT: 15UF, +50%-10%, 16WVDC	K8996 030~25159
	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
<u>41C489</u> 281_0810_00	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 SA105E104MAA
		04222 MA101A5R6DAA
A1C490 281-0775-01	CAP, FXD, CER DI: 5.6PF, +/-0.5PF, 100V	04222 SA105E104MAA
A1C495 281-0773-00	CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 MA201C103KAA
A1C496 281-0773-00		04222 MA201C103KAA
A1C500 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V	04222 SA105E104MAA
A1C501 281-0810-00	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V	
A1C503 281-0812-00	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF,+/-0.5PF, 100V	04222 MA101A5R6DAA
1C505 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF,+/-0.5PF, 100V CAP, FXD, CER DI:1000PF, 10%, 100V	04222 MA101A5R6DAA 04222 MA101C102KAA
A1C506 281-0767-00	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF,+/-0.5PF, 100V CAP, FXD, CER DI:1000PF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 MA101A5R6DAA 04222 MA101C102KAA 04222 SA105E104MAA
1000 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF,+/-0.5PF, 100V CAP, FXD, CER DI:1000PF, 10%, 100V	04222 MA101A5R6DAA 04222 MA101C102KAA
A1C525 281-0758-00	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF, +/-0.5PF, 100V CAP, FXD, CER DI:5.6PF, +/-0.5PF, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 MA101A5R6DAA 04222 MA101C102KAA 04222 SA105E104MAA 04222 MA106C331MAA 04222 SA105E104MAA
1C530 281-0775-01	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF, +/-0.5PF, 100V CAP, FXD, CER DI:5.6PF, +/-0.5PF, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:15PF, 20%, 100V	04222 MA101A5R6DAA 04222 MA101C102KAA 04222 SA105E104MAA 04222 MA106C331MAA 04222 SA105E104MAA 04222 SA102A150MAA
1C536 281-0814-00	CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.01UF, 10%, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:5.6PF, +/-0.5PF, 100V CAP, FXD, CER DI:5.6PF, +/-0.5PF, 100V CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 MA101A5R6DAA 04222 MA101C102KAA 04222 SA105E104MAA 04222 MA106C331MAA 04222 SA105E104MAA

•

	Tektronix	Serial/Assembly No.		Mfr.	
<u>Campanent No.</u>	<u>Part No.</u>	Effective Decont	Name & Description	Code	<u>Mfr. Part No.</u>
A1C537	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C538	281 -0 812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A1C539	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A1C540	290-1153-00		CAP, FXD, ELCTLT: 47UF, +50-10%, 10V	K8996	030-24479
A1C545	283-0119-02		CAP, FXD, CER DI: 2200PF, 5%, 200V	59660	855-402-Y5E0222J
A1C547	281-0767-00		CAP, FXD, CER DJ: 330PF, 20%, 100V	04222	MA106C331MAA
A1C550	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C554	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A1C555	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C560	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C561	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A1C562	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C570	281-0775-01		CAP, FXD, CER DI: 0.1UF, 20%, 50V	04222	SA105E104MAA
A1C571	281-0785-00		CAP, FXD, CER DI:68PF, 10%, 100V	04222	MA101A680KAA
A1C572	281-0758-00		CAP, FXD, CER DI: 15PF, 20%, 100V	04222	SA102A150MAA
A1C584	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C587	281-0773-00		CAP, FXD, CER DI:0.01UF, 10%, 100V	04222	MA201C103KAA
A1C776	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C780	281-0771-00		CAP, FXD, CER DI: 2200PF, 20%, 200V	04222	SA106E222MAA
A1C782	281-0775-01		CAP, FXD, CER DI:0.10F, 20%, 50V	04222	SA105E104MAA
A1C783	281-0064-00		CAP, VAR, PLASTIC: 0.25-1.5PF, 600V	52769	ER-530~013
A1C785	285-1101-00		CAP, FXD, PLASTIC: 0.022UF, 10%, 200V	19396	223K02PT485
A1C789	281-0771-00		CAP, FXD, CER DI: 2200PF, 20%, 200V	04222	SA106E222MAA
A1C794	281-0064-00		CAP, VAR, PLASTIC:0.25-1.5PF, 600V	52769	ER-530-013
A1C795	285-1101-00		CAP, FXD, PLASTIC: 0.022UF, 10%, 200V	19396	223K02PT485
A1C799	281-0771-00		CAP, FXD, CER DI: 2200PF, 20%, 200V	04222	SA106E222MAA
A1C824	281-0785-00		CAP, FXD, CER DI:68PF, 10%, 100V	04222	MA101A680KAA
A1C828 A1C832	281-0775-01 281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C832 A1C834	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 04222	SA105E104MAA SA105E104MAA
A1C835	201 0775 01			04000	CA10EE104MAA
A1C845	281-0775-01 281-0771-00		CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:2200PF, 20%, 200V	04222	SA105E1 04MAA SA106E22 2MAA
A1C845	283-0057-00		CAP, FXD, CER DI:2200FF, 20%, 200V CAP, FXD, CER DI:0.1UF, +80-20%, 200V	04222 04222	SR306E104ZAA
A1C849	283-0057-00		CAP, FXD, CER DI:0.10F, +80-20%, 200V	04222	SR306E104ZAA
A1C851	283-0057-00		CAP, FXD, CER DI:0.1UF, +80-20%, 200V	04222	SR306E104ZAA
A1C853	281-0767-00		CAP, FXD, CER DI: 330PF, 20%, 100V	04222	MA106C331MAA
A1C854	283-0279-00		CAP, FXD, CER DI:0.001UF, 20%, 3000V	51406	DHR12Y5S102M3KV
A1C855	285-1184-00		CAP, FXD, MTLZD: 0.01 UF, 20%, 4000V	56289	430P591
A1C871	283-0057-00		CAP, FXD, CER DI:0.1UF, +80-20%, 200V	04222	SR306E104ZAA
A1C875	283-0057-00		CAP, FXD, CER DI:0.1UF, +80-20%, 200V	04222	SR306E104ZAA
A1C893	283-0279-00		CAP, FXD, CER DI:0.001UF, 20%, 3000V	51406	DHR12Y5S102M3KV
A1C901	281-0815-00		CAP, FXD, CER DI: 0.027UF, 20%, 50V	04222	MA205C273MAA
A1C902	281-0775-01		CAP.FXD.CER DI:0.1UF.20%.50V	04222	SA105E104MAA
A1C914	281-0814-00		CAP, FXD, CER DI: 100 PF, 10%, 100V	04222	MA101A101KAA
A1C915	281-0775-01		CAP, FXD, CER DI:0.10F, 20%, 50V	04222	SA105E104MAA
A1C920	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A1C925	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C930	281 -0 812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A1C932	290 -0 806-00		CAP, FXD, ELCTLT: 3.3UF, +75-10%, 350VDC	55680	UHU2V3R3TPA
A1C933	281-0773-00		CAP, FXD, CER DI:0.01UF, 10%, 100V	04222	MA201C103KAA
A1C935	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C941	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C942	281 -0 773 -0 0		CAP, FXD, CER DI: 0.01UF, 10%, 100V	04222	MA201C103KAA
A1C943	281-0814-00		CAP, FXD, CER DI: 100 PF, 10%, 100V	04222	MA101A101KAA
A1C945	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C946	281-0814-00		CAP, FXD, CER DI: 100 PF, 10%, 100V	04222	MA101A101KAA
A1C952	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A1C974	281-0851-00		CAP, FXD, CER DI: 180PF, 5%, 100VDC	04222	MA101A181JAA

٩

<u>Component No.</u>	Tektronix Part No.	Serial/Assembly No. <u>Effective Dscont</u>	Name & Description	Mfr. Code	Mfr. Part No.
A1C976 A1C979 A1C980 A1C982 A1C983 A1C983 A1C984	285-1184-00 285-1184-00 285-1184-00 290-0947-00 290-0806-00 290-0947-00		CAP, FXD, MTLZD:0.01 UF, 20%, 4000V CAP, FXD, MTLZD:0.01 UF, 20%, 4000V CAP, FXD, MTLZD:0.01 UF, 20%, 4000V CAP, FXD, ELCTLT:33UF, +50-10%, 160V W/SLEEVE CAP, FXD, ELCTLT:3.3UF, +75-10%, 350VDC CAP, FXD, ELCTLT:33UF, +50-10%, 160V W/SLEEVE	56289 56289 56289 55680 55680 55680	430P591 430P591 430P591 UHC2C330TFA UHU2V3R3TPA UHC2C330TFA
A1C985 A1C986 A1C987 A1C988 A1C989 A1C989	290-0805-00 290-1159-00 290-1159-00 290-1159-00 290-1159-00 290-1159-00		CAP, FXD, ELCTLT: 3.3UF, +75-10%, 350VDC CAP, FXD, ELCTLT: 1000UF, 20%, 16V CAP, FXD, ELCTLT: 1000UF, 20%, 16V	55680 TKOED TKOED TKOED TKOED TKOED	UHU2V3R3TPA Twss Twss Twss Twss Twss Twss
A1C991 A1C992 A1CR133 A1CR136 A1CR139 A1CR183	290-1159-00 283-0057-00 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		CAP, FXD, ELCTLT:1000UF,20%,16V CAP, FXD, CER DI:0.1UF,+80-20%,200V SEMICOND DVC,DI:SW,SI.30V,150MA,30V,D0-35 SEMICOND DVC,DI:SW,SI.30V,150MA,30V,D0-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35	TK0ED 04222 03508 03508 03508 03508	TWSS SR306E104ZAA DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR186 A1CR189 A1CR265 A1CR266 A1CR300 A1CR301	152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508 03508 03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR302 A1CR319 A1CR344 A1CR348 A1CR349 A1CR349 A1CR381	152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	03508 03508 03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR417 A1CR431 A1CR450 A1CR451 A1CR452 A1CR452	152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508 03508 03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR530 A1CR539 A1CR540 A1CR571 A1CR584 A1CR588	152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508 03508 03508 03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR589 A1CR780 A1CR781 A1CR790 A1CR791 A1CR791	152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508 03508 03508 03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR818 A1CR819 A1CR820 A1CR824 A1CR825 A1CR825 A1CR827	152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508 03508 03508 03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)
A1CR828 A1CR829 A1CR840 A1CR845	152-0141-02 152-0141-02 152-0141-02 152-0141-02		SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	03508 03508 03508 03508	DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152) DA2527 (1N4152)

.

<u>Component_No.</u>	Tektronix Part No.	Serial/Assembly No. Effective Dscont	Name & Description	Mfr. Code	Nfr. Part No
A1CR851	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR853	152-0400-00		SEMICOND DVC,DI:RECT,SI,400V,1A	04713	SR1977KRL
A1CR854	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR855	152-0400-00			04713	SR1977KRL
			SEMICOND DVC, DI :RECT, SI, 400V, 1A		
A1CR933	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR941	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR942	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR945	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR946	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR947	152 -04 00 -0 0		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR950	152-0906-00		SEMICOND DVC, DI: RECT, SI, 400V, 3 AMP, 50 NS	80009	152-0906-00
A1CR975	152-0429-00		SEMICOND DVC, DI:RECT, SI, 5KV, 10MA, ED2137	83003	VG5X-1
A1CR976	152-0429-00		SEMICOND DVC, DI: RECT, SI, 5KV, 10MA, ED2137	8 300 3	VG5X-1
A1CR980	152-0400-00		SEMICOND DVC, DI: RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR981	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR982	152-0400-00		SEMICOND DVC,DI:RECT,SI,400V,1A	04713	SR1977KRL
A1CR983	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, IA	04713	SR1977KRL
A1CR984	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, IA	04713	SR1977KRL
AICKBO4	132-0400-00		SEMICOND DVC, DI. KECT, SI, 4004, IA	04/10	JKIJ//KKL
A1CR985	152-0400-00		SEMICOND DVC, DI: RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR986	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR987	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR988	152-0400-00		SEMICOND DVC.DI:RECT.SI.400V.1A	04713	SR1977KRL
A1CR989	152-0400-00		SEMICOND DVC, DI : RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR990	152-0400-00		SEMICOND DVC, DI:RECT, SI, 400V, 1A	04713	SR1977KRL
A1CR991	152-0400-00		SEMICOND DVC.DI:RECT.SI.400V.1A	04713	SR1977KRL
A1DS856	150-0035-00		LAMP, GLOW: 90V MAX, 0.3MA, AID-T, WIRE LD	TK0213	
A1D5858				TK0213	
	150-0035-00		LAMP, GLOW: 90V MAX, 0.3MA, AID-T, WIRE LD		
A1L321	108-1281-00		COIL, RF: FXD, 2.2UH, 10%	54583	SP0305-2R2K
A1L322	108-1281-00		COIL, RF: FXD, 2.20H, 10%	54583 80009	SP0305-2R2K
A1L950	108-1416-00		COIL, RF: POWER INDUCTOR, 300UH-400UH, 3A	00009	108-1416-00
A1L986	108-1375-00		COIL, RF: FXD, 82UH, 1A	TK00A	RL-1218 -820 K-1A
A1L988	108-1375-00		COIL, RF: FXD, 82UH, 1A	TK00A	RL-1218-820K-1A
A1L990	108-1375-00		COIL, RF: FXD, 82UH, 1A	TKOOA	RL-1218-820K-1A
A1P910	136-0984-00		SKT, PL-IN ELEK: CRT, 14 PIN, CABLE ASSY	80009	136-0984-00
A10102	151-0188-00		TRANSISTOR: PNP.SI.TO-92	80009	151-0188-00
A10103	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A10104	151-0190-00		TDANSISTOD NON ST TO-02	80009	151-0190-00
			TRANSISTOR:NPN, SI, TO-92	80009	151-0190-00
A1Q105	151-0190-00		TRANSISTOR: NPN, SI, TO-92		-
A1Q114	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A1Q115	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A10152	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q153	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q154	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q155	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A10164	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A10165	151-0190-00		TRANSISTOR: NPN.SI, TO-92	80009	151-0190-00
A10202	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A10203	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
·				00000	
A1Q206	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q207	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q230	151-0424-00		TRANSISTOR:NPN,SI,TO-92	04713	SPS8246
A1Q231	151-0424-00		TRANSISTOR:NPN,SI,TO-92	04713	SPS8246
A10232	151-0711-00		TRANSISTOR: NPN, SI, TO-92B	80009	151-0711-00
A1Q234	151-0711-00		TRANSISTOR: NPN, SI, TO-92B	80009	151-0711-00
A1Q236	151-0270-00		TRANSISTOR: PNP, SI, TO-39	04 713	ST919
A10237	151-0124-00		TRANSISTOR: NPN, SI, TO-39	04713	SM8138
A10238	151-0270-00		TRANSISTOR: PNP, SI, TO-39	04713	ST919
A10238 A10239	151-0124-00		TRANSISTOR: PNP, SI, TO-39	04713	SM8138
ATUC 3	151-0124-00		10-32	04/13	Jm0100

<u>Camponent No.</u>	Tektronix Part <u>No.</u>	Serial/Assembly No. Effective <u>Dscont</u>	Name & Description	Nfr. Code	<u>Mfr.</u> Part <u>No.</u>
A1Q370 A1Q371	151-1042-00		SEMICOND DVC SE:FET,SI,TO-92 (MATCHED PAIR WITH A1Q370)	80009	151-1042-00
A10400	151-0712-00		TRANSISTOR: PNP. SI, TO-92	04713	SPS8223
	151-0712-00		TRANSISTOR: PNP, SI, TO-92	04713	SPS8223
A1Q401				80009	
A1Q410	151-0190-00		TRANSISTOR: NPN, SI, TO-92		151-0190-00
A1Q411	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q412	151-0190-00		TRANSISTOR:NPN, SI, TO-92	80009	151-0190-00
A1Q415	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q450	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A1Q451	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A1Q452	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A1Q453	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151~0190-00
A1Q465	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151~0188-00
A1Q487	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q488	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q489	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q490	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q535	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q536	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q770	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q775	151-0573-00		TRANSISTOR: PWR, NPN, TO-126	80009	151-0573-00
A1Q776	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q779	151-0574-00		TRANSISTOR: PWR, PNP, TO-126	80009	151~0574-00
A1Q780	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q785	151-0573-00		TRANSISTOR: PWR, NPN, TO-126	80009	151-0573-00
A1Q789	151-0574-00		TRANSISTOR: PWR, PNP, TO-126	80009	151-0574-00
A1Q804	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151~0188-00
A1Q817	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151~0190-00
A1Q825	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q829	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151~0188-00
A1Q835	151-0199-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0199-00
A1Q840	151 -0347-0 2		TRANSISTOR:NPN,SI,TO-92	56289	CT7916
A1Q845	151-0350-00		TRANSISTOR: PNP, SI, TO-92	04 713	SPS6700
A1Q932	151-0347-02		TRANSISTOR: NPN, SI, TO-92	56289	CT7916
A1Q933	151-1252-00		TRANSISTOR: PWR, MOS FET, P-CHANNEL, 180V, 1 OHM		151-1252-00
A1Q935	151-0190-00		TRANSISTOR:NPN,SI,TO-92	80009	151~0190-00
A1Q9 39	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A1Q941	151-0347-02		TRANSISTOR:NPN,SI,TO-92	56289	CT7916
A1Q942	151 -047 6- 00		TRANSISTOR:NPN,SI,TO-220	80009	151-0476-00
A1Q943	151 -0190-0 0		TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q945	151 -0347-0 2		TRANSISTOR:NPN,SI,TO-92	56289	CT7916
A1Q946	151 -0476-0 0		TRANSISTOR:NPN,SI,TO-220	80009	151-0476-00
A1Q982	151-0347-02		TRANSISTOR:NPN,SI,TO-92	56289	CT7916
A1Q985	151-0350-00		TRANSISTOR: PNP, SI, TO-92	04713	SPS6700
A1Q988	151-0347-02		TRANSISTOR: NPN, SI, TO-92	56289	CT7916
A1R100	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
A1R101	315-0510-00		RES,FXD,FILM:51 0HM,5%,0.25W	19701	5043CX51R00J
A1R102	315-0155-00		RES,FXD,FILM:1.5M OHM,5%,0.25W	19701	5043CX1M500J
A1R103	315-0155-00		RES, FXD, FILM: 1.5M OHM, 5%, 0.25W	19701	5043CX1M500J
A1R104	321-0094-00		RES, FXD, FILM:93.1 OHM, 1%, 0.125W, TC=T0	91637	CMF55116G93R10F
A1R105	321-0094-00		RES, FXD, FILM:93.1 OHM, 1%, 0.125W, TC=T0	91637	CMF55116G93R10F
A1R106	321-0170-00		RES, FXD, FILM: 576 OHM, 1%, 0.125W, TC=T0	07716	CEAD576R0F
A1R108	321-0223-00		RES, FXD, FILM: 2.05K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K05F
A1R109	321-0223-00		RES,FXD,FILM:2.05K OHM,1%,0.125W,TC=T0	19701	5033ED2K05F
A1R114	321-0223-00		RES, FXD, FILM: 2.05K OHM, 1%, 0.125W, TC=TO	19701	5033ED2K05F
A1R115	321-0223-00		RES, FXD, FILM: 2.05K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K05F
A1R116	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57 668	NTR25J-E 100E
A1R117	315-0101-00		RES, FXD, FILM:100 OHM, 5%, 0.25W	57668	NTR25J-E 100E

-

-

<u>Component No.</u>	Tektronix Part No.	Serial/Assembly No. Effective <u>Dscont</u>	Name & Description	Mfr. <u>Code</u>	MfrPart No
A1R118	315-0821-00		RES, FXD, FILM: 820 0HM, 5%, 0.25W	19701	5043CX820R0J
A1R119	315 -0 821-00		RES, FXD, FILM:820 OHM, 5%, 0.25W	19701	5043CX820R0J
A1R120	321-0123-00		RES,FXD,FILM:187 OHM,1%,0.125₩, TC≈TO	07716	CEAD187R0F
A1R121	321-0123-00		RES, FXD, FILM: 187 OHM, 1%, 0.125W, TC=T0	07716	CEAD187R0F
A1R122	321-0089-00		RES,FXD,FILM:82.5 OHM,1%,0.125₩,TC≂T0	91637	CMF55116G82R50F
A1R124	315-0472-00		RES, FXD, FILM: 4.7K OHM, 5%, 0.25W	5 7668	NTR25J-E04K7
A1R125	315-0392-00		RES, FXD, FILM: 3.9K 0HM, 5%, 0.25W	5 7668	NTR25J-E03K9
A1R126	315-0162-00		RES, FXD, FILM: 1.6K OHM, 5%, 0.25W	19701	5043CX1K600J
A1R127	321 -006 8-00		RES, FXD, FILM: 49.9 OHM, 0.1%, 0.125W, TC=T0	91637	CMF55116G49R90F
A1R130	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
A1R131 A1R132	315-0510-00 315-0511-00		RES,FXD,FILM:51 0HM,5%,0.25W RES,FXD,FILM:510 0HM,5%,0.25W	19701 19701	5043CX51R00J 5043CX510R0J
A1R133	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R135	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R136	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R139	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R140 A1R142	311-2364-00 315-0101-00		RES,VAR,NONWW:TRMR,4.7K OHM,0.5W RES.FXD.FILM:100 OHM,5%.0.25W	K8788 57668	TC10-LV10-4K7/A NTR25J-E 100E
A1R143 A1R144	315-0101-00 315 -0471-00		RES,FXD,FILM:100 OHM,5%,0.25W RES,FXD,FILM:470 OHM,5%,0.25W	57668 57668	NTR25J-E 100E NTR25J-E470E
A1R145	311-2364-00		RES, VAR, NONWY: TRMR, 4.7K OHM, 0.5W	K8788 19701	TC10-LV10-4K7/A
A1R150 A1R151	315-0510-00 315 - 0510-00		RES,FXD,FILM:51 0HM,5%,0.25W RES,FXD,FILM:51 0HM,5%,0.25W	19701	5043CX51R00J 5043CX51R00J
A1R152	321-0155-00		RES, FXD, FILM: 51 0HM, 3%, 0.25W, TC=T0	07716	CEAD402R0F
A1R153	321-0155-00		RES.FXD.FILM:402 0HM.1%.0.125W.TC=T0	07716	CEAD402R0F
A1R154	321-0094-00		RES, FXD, FILM: 93.1 0HM, 1%, 0.125W, TC=TO	91637	CMF55116G93R10F
A1R155	321-0094-00		RES.FXD.FILM:93.1 0HM.1%,0.125W,TC≈T0	91637	CMF55116G93R10F
A1R156	321-0170-00		RES, FXD, FILM: 576 0HM, 1%, 0.125W, TC=T0	07716	CEAD576ROF
A1R158	321-0223-00		RES, FXD, FILM: 2.05K 0HM, 1%, 0.125W, TC=T0	19701	5033ED2K05F
A1R159	321-0223-00		RES, FXD, FILM: 2.05K 0HM, 1%, 0.125W, TC=T0	19701	5033ED2K05F
A1R161	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
A1R162	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
A1R164	321-0223-00		RES, FXD, FILM: 2.05K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K05F
A1R165	321-0223-00		RES, FXD, FILM: 2.05K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K05F
A1R166	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R167	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R168	315-0821-00		RES, FXD, FILM:820 0HM, 5%, 0.25W	1970 1	5043CX820R0J
A1R169	315-0821-00		RES, FXD, FILM:820 OHM, 5%, 0.25W	19701	5043CX820R0J
A1R170	321-0123-00		RES,FXD,FILM:187 OHM,1%,0.125W, TC≈TO	0 7716	CEAD187R0F
A1R171	321-0123-00		RES, FXD, FILM: 187 OHM, 1%, 0.125W, TC=TO	07716	CEAD187R0F
A1R172	321-0089-00		RES, FXD, FILM:82.5 0HM, 1%, 0.125W, TC≈T0	91637	CMF55116G82R50F
A1R174	315-0472-00		RES,FXD,FILM:4.7K OHM,5%,0.25W	57668	NTR25J-E04K7
A1R175	315-0392-00		RES, FXD, FILM: 3.9K 0HM, 5%, 0.25W	57668	NTR25J-E03K9
A1R176	315-0162-00		RES, FXD, FILM: 1.6K OHM, 5%, 0.25W	19701	5043CX1K600J
A1R177	321-0068-00		RES, FXD, FILM: 49.9 OHM, 0.1%, 0.125W, TC=T0	91637	CMF55116G49R90F
A1R180	315-0510-00		RES, FXD, FILM: 51 0HM, 5%, 0.25W	19701	5043CX51R00J
A1R181	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
A1R182	315 -0511-0 0		RES,FXD,FILM:510 OHM,5%,0.25W	19701	5043CX510R0J
A1R183	315-0101-00		RES, FXD, FILM: 100 0HM, 5%, 0.25W	57668	NTR25J-E 100E
A1R185	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R186	315-0101-00		RES, FXD, FILM: 100 0HM, 5%, 0.25W	57668	NTR25J-E 100E
A1R189	315-0392-00		RES, FXD, FILM: 3.9K 0HM, 5%, 0.25W	57668	NTR25J-E03K9
A1R192 A1R193	315-0101-00 315-0101-00		RES,FXD,FILM:100 0HM,5%,0.25W RES,FXD,FILM:100 0HM,5%,0.25W	57668 57668	NTR25J-E 100E NTR25J-E 100E
A1R194 A1 R19 5	315-0471-00 311-2364-00		RES,FXD,FILM:470 OHM,5%,0.25W RES,VAR,NONWW:TRMR,4.7K OHM,0.5W	57668 K8788	NTR25J-E470E TC10-LV10-4K7/A
A1R202	321-0178-00		RES, FXD, FILM: 698 0HM, 1%, 0.125W, TC=T0	07716	CEAD698R0F
A1R202	321-0178-00		RES, FXD, FILM: 698 0HM, 1%, 0.125W, TC=TO	07716	CEAD698R0F
11.10.00	261-01/0-00		NEO, NO, TEN. 000 010, 10, 0.1200, 10-10	0//10	

REV JAN 1990

<u>Component No.</u>	Tektronix Part No	Serial/Assembly Effective D		Mfr. <u>Code</u>	Mfr. Part No.
A1R204	321-0089-00		RES, FXD, FILM:82.5 OHM, 1%, 0.125W, TC=T0	91637	CMF55116G82R50F
A1R206	315-0271-00		RES, FXD, FILM: 270 OHM, 5%, 0.25W	57668	NTR25J-E270E
A1R207	315-0271-00		RES, FXD, FILM: 270 OHM, 5%, 0.25W	57668	NTR25J-E270E
A1R212	321-0094-00		RES, FXD, FILM: 93.1 OHM, 1%, 0.125W, TC=T0	91637	CMF55116G93R10F
A1R213	321-0094-00		RES, FXD, FILM:93.1 OHM, 1%, 0.125W, TC=T0	91637	CMF55116G93R10F
A1R215	315-0241-00		RES,FXD,FILM:240 OHM,5%,0.25W	19701	5043CX240ROJ
A1R216	321-0163-00		RES, FXD, FILM: 487 OHM, 1%, 0.125W, TC=T0	07716	CEAD487R0F
A1R217	321-0163-00		RES, FXD, FILM: 487 OHM, 1%, 0.125W, TC=T0	07716	CEAD487R0F
A1R218	321-0109-00		RES, FXD, FILM: 133 OHM, 1%, 0.125W, TC=T0	07716	CEAD133R0F
A1R219	321-0109-00		RES, FXD, FILM: 133 OHM, 1%, 0.125W, TC=TO	07716	CEAD133R0F
A1R220 A1R221	315-0100-00 315-0100-00		RES,FXD,FILM:10 OHM,5%,0.25W RES,FXD,FILM:10 OHM,5%,0.25W	19701 19701	5043CX10RR00J 5043CX10RR00J
A1R222	321-0318-00		RES, FXD, FILM: 20.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED20K00F
A1R223	321-0318-00		RES, FXD, FILM: 20.0K OHM, 1%, 0.125W, TC=TO	19701	5033ED20K00F
A1R225	315-0752-00		RES, FXD, FILM: 7.5K 0HM, 5%, 0.25W	57668	NTR25J-E07K5
A1R226	315- 0 512- 0 0		RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	576 68	NTR25J-E05K1
A1R232	321-0238-00		RES, FXD, FILM: 2.94K OHM, 1%, 0.125W, TC=TO	07716	CEAD29400F
A1R233	321-0139-00		RES, FXD, FILM: 274 0HM, 1%, 0.125W, TC=T0	07716	CEAD274R0F
A1R235	321-0238-0 0		RES.FXD.FILM:2.94K 0HM.1%.0.125W.TC=T0	07716	CEAD29400F
A1R235	315-0120-00		RES, FXD, FILM: 12 OHM, 5%, 0.25W	57668	NTR25J-R12
A1R238	315-0913-00		RES, FXD, FILM:91K OHM, 5%, 0.25W	19701	5043CX91K00J
A1R239	315-0331-00		RES, FXD, FILM:330 0HM, 5%, 0.25W	57668	NTR25J-E330E
A1R241	311-2363-00		RES, VAR, NONWY: TRMR, 1K OHM, 0.5W	K8788	TC10-LV10-1K/A
A1R2 42	323-0310-00		RES, FXD, FILM: 16.5K 0HM, 1%, 0.5W, TC=T0	75042	CECT0-1652F
A1R2 4 3	323-0310-00		RES,FXD,FILM:16.5K OHM,1%,0.5W,TC≃TO	75042	CECT0-1652F
A1R244	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
				57668	
A1R245	315-0222-00		RES, FXD, FILM: 2.2K OHM, 5%, 0.25W		NTR25J-E02K2
A1R246	315-0620-00		RES, FXD, FILM: 62 OHM, 5%, 0.25W	19701	5043CX63R00J
A1R247	315-0120-00		RES, FXD, FILM:12 OHM, 5%, 0.25W	57668	NTR25J-R12
A1R248	315-0331-00		RES,FXD,FILM:330 OHM,5%,0.25W	57668	NTR25J-E330E
A1R249	315-0913-00		RES.FXD.FILM:91K OHM,5%,0.25W	19701	5043CX91K00J
A1R250	315-0222-00		RES. FXD. FILM: 2.2K OHM, 5%, 0.25W	57668	NTR25J-E02K2
A1R251	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
A1R252	315-0620-00		RES, FXD, FILM: 62 OHM, 5%, 0.25W	19701	5043CX63R00J
A1R253	315-0272-00		RES, FXD, FILM:2.7K OHM, 5%, 0.25W	57668	NTR25J-E02K7
A1R258	315-0272-00		RES, FXD, FILM: 2.7K OHM, 5%, 0.25W	57668	NTR25J-E02K7
A1R260	315-0240-00		RES, FXD, FILM: 24 OHM, 5%, 0.25W	57668	NTR25J-E24E0
A1R262	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
1R263	301-0431-00		RES.FXD.FILM:430 OHM.5%,0.5W	19701	5053CX430R0J
1R264	301-0431-00		RES, FXD, FILM: 430 OHM, 5%, 0.5W	19701	5053CX430R0J
1R265	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
1R266	315-0510-00		RES,FXD,FILM:51 OHM,5%,0.25W	19701	5043CX51R00J
1R267	308-0286-00		RES, FXD, WW:8.2K OHM, 5%, 3W	00213	1240S-8200-5
1R268	308-0286-00		RES, FXD, WW:8.2K OHM, 5%, 3W	00213	1240S-8200-5
1R269	315-0510-00		RES, FXD, FILM: 51 0HM, 5%, 0.25W	19701	5043CX51R00J
1R280	321-0148-00		RES, FXD, FILM: 340 OHM, 1%, 0.125W, TC=T0	07716	CEAD340R0F
1R300	315-0273-00		RES, FXD, FILM: 27K 0HM, 5%, 0.25W	57668	NTR25J-E27K0
1R301	315-0273-00		RES, FXD, FILM: 27K OHM, 5%, 0.25W	57668	NTR25J-E27K0
1R302	315 - 0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
1R303	315-0203-00		RES, FXD, FILM: 20K OHM, 5%, 0.25W	57668	NTR25J-E 20K
1R304	315-0103-00		RES, FXD, FILM: 10K 0HM, 5%, 0.25W	19701	5043CX10K00J
1R305	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
1R306 1R308	315-0103-00 315-0203-00		RES,FXD,FILM:10K OHM,5%,0.25W RES,FXD,FILM:20K OHM,5%,0.25W	19701 57 668	5043CX10K00J NTR25J-E 20K
1R309	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
1R310	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
1R311	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
1R312	307-0106-00		RES.FXD,CMPSN:4.7 OHM, 5%, 0.25W	01121	CB 47G5

.
.

Component No.	Tektronix Par <u>t N</u> o	Serial/Assembly No. <u>Effective D</u> scont_	Name & Description	Mfr. Code	Mfr. Part No
A1R316 A1R317 A1R318 A1R318 A1R319 A1R320 A1R322	321-0098-00 315-0241-00 315-0241-00 315-0102-00 315-0102-00 321-0203-00		RES, FXD, FILM: 102 OHM, 1%, 0.125W, TC=TO RES, FXD, FILM: 240 OHM, 5%, 0.25W RES, FXD, FILM: 240 OHM, 5%, 0.25W RES, FXD, FILM: 1K OHM, 5%, 0.25W RES, FXD, FILM: 1K OHM, 5%, 0.25W	07716 19701 19701 57668 57668 07716	CEAD102R0F 5043CX240R0J 5043CX240R0J NTR25JE01K0 NTR25JE01K0 CEAD12700F
A1R322 A1R325 A1R326 A1R326 A1R329 A1R330 A1R331	321-0203-00 321-0170-00 321-0170-00 321-0314-00 321-0317-00 315-0241-00		RES,FXD,FILM:1.27K OHM,1%,0.125W,TC=TO RES,FXD,FILM:1.27K OHM,1%,0.125W,TC=TO RES,FXD,FILM:576 OHM,1%,0.125W,TC=TO RES,FXD,FILM:576 OHM,1%,0.125W,TC=TO RES,FXD,FILM:18.2K OHM,1%,0.125W,TC=TO RES,FXD,FILM:19.6K OHM,1%,0.125W,TC=TO RES,FXD,FILM:240 OHM,5%,0.25W	07716 07716 07716 19701 07716 19701	CEAD12700F CEAD576R0F CEAD576R0F 5043ED18K20F CEAD19601F 5043CX240R0J
A1R332 A1R333 A1R334 A1R335 A1R336 A1R336 A1R337	315-0241-00 315-0102-00 315-0102-00 321-0098-00 321-0194-00 321-0194-00		RES,FXD,FILM:240 OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:102 OHM,1%,0.125W,TC=T0 RES,FXD,FILM:1.02K OHM,1%,0.125W,TC=T0 RES,FXD,FILM:1.02K OHM,1%,0.125W,TC=T0	19701 57668 57668 07716 07716 07716	5043CX240R0J NTR25JE01K0 NTR25JE01K0 CEAD102R0F CEAD10200F CEAD10200F
A1R338 A1R339 A1R340 A1R343 A1R344 A1R350	311-2365-00 321-0170-00 321-0170-00 321-0314-00 321-0317-00 315-0470-00		RES, VAR, NONWW:TRMR, 470 OHM, 0.75W RES, FXD, FILM:576 OHM, 1%, 0.125W, TC=TO RES, FXD, FILM:576 OHM, 1%, 0.125W, TC=TO RES, FXD, FILM:18.2K OHM, 1%, 0.125W, TC=TO RES, FXD, FILM:19.6K OHM, 1%, 0.125W, TC=TO RES, FXD, FILM:47 OHM, 5%, 0.25W	K8788 07716 07716 19701 07716 57668	TC10-LV10-470K/A CEAD576R0F CEAD576R0F 5043ED18K20F CEAD19601F NTR25J-E47E0
A1R351 A1R352 A1R353 A1R354 A1R356 A1R357	315-0470-00 321-0274-00 315-0272-00 315-0272-00 315-0622-00 321-0149-00		RES,FXD,FILM:47 OHM,5%,0.25W RES,FXD,FILM:6.98K OHM,1%,0.125W,TC=TO RES,FXD,FILM:6.98K OHM,1%,0.125W,TC=TO RES,FXD,FILM:2.7K OHM,5%,0.25W RES,FXD,FILM:6.2K OHM,5%,0.25W RES,FXD,FILM:348 OHM,1%,0.125W,TC=TO	57668 19701 19701 57668 19701 07716	NTR25J-E47E0 5043ED6K980F 5043ED6K980F NTR25J-E02K7 5043CX6K200J CEAD348R0F
A1R358 A1R359 A1R360 A1R361 A1R362 A1R363	315-0101-00 321-0148-00 321-0156-00 315-0202-00 315-0112-00 315-0392-00		RES,FXD,FILM:100 OHM,5%,0.25W RES,FXD,FILM:340 OHM,1%,0.125W,TC=TO RES,FXD,FILM:412 OHM,1%,0.125W,TC=TO RES,FXD,FILM:2K OHM,5%,0.25W RES,FXD,FILM:1.1K OHM,5%,0.25W RES,FXD,FILM:3.9K OHM,5%,0.25W	57668 07716 07716 57668 19701 57668	NTR25J-E 100E CEAD340R0F CEAD412R0F NTR25J-E 2K 5043CX1K100J NTR25J-E03K9
A1R364 A1R366 A1R367 A1R368 A1R369 A1R369	315-0104-00 315-0242-00 315-0392-00 315-0152-00 315-0432-00 315-0470-00		RES, FXD, FILM:100K OHM, 5%, 0.25W RES, FXD, FILM:2.4K OHM, 5%, 0.25W RES, FXD, FILM:3.9K OHM, 5%, 0.25W RES, FXD, FILM:1.5K OHM, 5%, 0.25W RES, FXD, FILM:4.3K OHM, 5%, 0.25W RES, FXD, FILM:47 OHM, 5%, 0.25W	57668 57668 57668 57668 57668 57668 57668	NTR25J-E100K NTR25J-E02K4 NTR25J-E03K9 NTR25J-E01K5 NTR25J-E04K3 NTR25J-E47E0
A1R371 A1R372 A1R373 A1R374 A1R380 A1R381	315-0121-00 315-0101-00 315-0120-00 315-0101-00 315-0202-00 315-0101-00		RES, FXD, FILM: 120 OHM, 5%, 0.25W RES, FXD, FILM: 100 OHM, 5%, 0, 25W RES, FXD, FILM: 12 OHM, 5%, 0.25W RES, FXD, FILM: 100 OHM, 5%, 0.25W RES, FXD, FILM: 2K OHM, 5%, 0.25W RES, FXD, FILM: 100 OHM, 5%, 0.25W	19701 57668 57668 57668 57668 57668 57668	5043CX120R0J NTR25J-E 100E NTR25J-R12 NTR25J-E 100E NTR25J-E 2K NTR25J-E 100E
A1R389 A1R394 A1R395 A1R396 A1R400 A1R401	315-0100-00 315-0103-00 311-2365-00 315-0751-00 321-0089-00 321-0089-00		RES,FXD,FILM:10 0HM,5%,0.25W RES,FXD,FILM:10K 0HM,5%,0.25W RES,VAR,NONNW:TRMR,470 0HM,0.75W RES,FXD,FILM:750 0HM,5%,0.25W RES,FXD,FILM:82.5 0HM,1%,0.125W,TC=T0 RES,FXD,FILM:82.5 0HM,1%,0.125W,TC=T0	19701 19701 K8788 57668 91637 91637	5043CX10RR00J 5043CX10K00J TC10-LV10-470K/A NTR25J-E750E CMF55116G82R50F CMF55116G82R50F
A1R402 A1R403 A1R404 A1R405	315-0102-00 315-0470-00 315-0204-00 315-0103-00		RES,FXD,FILM:1K 0HM,5%,0.25W RES,FXD,FILM:47 0HM,5%,0.25W RES,FXD,FILM:200K 0HM,5%,0.25W RES,FXD,FILM:10K 0HM,5%,0.25W	57668 57668 19701 19701	NTR25JE01K0 NTR25J-E47E0 5043CX200K0J 5043CX10K00J

.

REV JAN 1990

ī

<u>Component No.</u>	Tektronix <u>Part No.</u>	Serial/Assembly <u>Effective D</u>	y No. scontName & Description	Mfr. <u>Code</u>	Mfr. Part No
A1R406	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
A1R407	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R408	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
A1R409	315-0302-00		RES, FXD, FILM: 3K OHM, 5%, 0.25W	57668	NTR25J-E03K0
				57668	NTR25J-E03K9
A1R410	315-0392-00		RES, FXD, FILM: 3.9K OHM, 5%, 0.25W		
A1R411	315-0432-00		RES, FXD, FILM: 4.3K OHM, 5%, 0.25W	57668	NTR25J-E04K3
A1R412	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R413	315-0751-00		RES, FXD, FILM: 750 OHM, 5%, 0.25W	57668	NTR25J-E750E
A1R414	315-0752-00		RES, FXD, FILM: 7.5K OHM, 5%, 0.25W	57668	NTR25J-E07K5
A1R415	315-0120-00		RES, FXD, FILM: 12 OHM, 5%, 0.25W	57668	NTR25J-R12
A1R416	315-0823-00		RES, FXD, FILM: 82K OHM, 5%, 0.25W	57668	NTR25J-E82K
A1R417	315-0562-00		RES, FXD, FILM: 5.6K 0HM, 5%, 0.25W	57668	NTR25J-E05K6
410410	215 0204 00			10701	E0430200000 1
A1R418	315-0204-00		RES, FXD, FILM: 200K OHM, 5%, 0.25W	19701	5043CX200K0J
A1R419	315-0470-00		RES, FXD, FILM: 47 OHM, 5%, 0.25W	57668	NTR25J-E47E0
A1R426	315-0751-00		RES, FXD, FILM: 750 OHM, 5%, 0.25W	57668	NTR25J-E750E
A1R427	315-0362-00		RES, FXD, FILM: 3.6K OHM, 5%, 0.25W	19 70 1	5043CX3K600J
A1R428	315-0752-00		RES, FXD, FILM: 7.5K OHM, 5%, 0.25W	57668	NTR25J-E07K5
A1R429	315-0204-00		RES, FXD, F1LM: 200K OHM, 5%, 0.25W	1970 1	5043CX200K0J
A1R 430	315-0823-00		RES, FXD, FILM:82K OHM, 5%, 0.25W	5 76 68	NTR25J-E82K
A1R430	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
A1R432	315-0204-00		RES.FXD.FILM:200K 0HM.5%.0.25W	19701	5043CX200K0J
A1R433	315-0223-00		RES, FXD, FILM: 22K OHM, 5%, 0.25W	19701	5043CX22K00J92U
A1R435	315-0120-00		RES, FXD, FILM: 12 OHM, 5%, 0.25W	57668	NTR25J-R12
A1R441	321-0238-00		RES,FXD,FILM:2.94K OHM,1%,0.125₩,TC=T0	07716	CEAD29400F
A1R442	321-0208-00		RES.FXD.FILM:1.43K OHM.1%.0.125W.TC=T0	19701	5033ED1K43F
A1R443	321-0238-00		RES, FXD, FILM: 2.94K OHM, 1%, 0.125W, TC=T0	07716	CEAD29400F
A1R444	321-0208-00		RES, FXD, FILM: 1.43K OHM, 1%, 0.125W, TC=T0	19701	5033ED1K43F
A1R445	311-1550-00		RES, VAR, NONWY: TRMR, 2M OHM, 0.5W	32997	3352T-1-205
A1R446	311-1550-00		RES, VAR, NONWY: TRMR, 2M OHM, 0.5W	32997	3352T-1-205
A1R450	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
A1R451	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R480	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R481	311-2361-00		RES, VAR, NONWY: TRMR, 10K OHM, 0.5W	K8788	TC10-LV10-10K/A
A1R482	315-0271-00		RES.FXD.FILM:270 OHM.5%.0.25W	57668	NTR25J-E270E
A1R483	315-0431-00		RES, FXD, FILM: 430 0HM, 5%, 0.25W	19701	5043CX430R0J
A1R485	321-0089-00		RES, FXD, F1LM: 82.5 OHM, 1%, 0.125W, TC=T0	91637	CMF55116G82R50F
A1R486	315 -0 222-00		RES.FXD.FILM:2.2K OHM.5%.0.25W	57668	NTR25J-E02K2
A1 R48 7			RES, FXD, FILM: 2.2K UNM, 5%, 0.25W RES, FXD, FILM: 10K UNM, 5%, 0.25W	19701	5043CX10K00J
	315-0103-00				
1R488	315-0391-00		RES, FXD, FILM: 390 OHM, 5%, 0.25W	57668	NTR25J-E390E
A1R489	311-2352-00		RES, VAR, NONWY: TRMR, 220 OHM, D. 5W	K8788	TC10LV2.5220R
\1R490	315 -0 392-00		RES, FXD, FILM: 3.9K 0HM, 5%, 0.25W	57668	NTR25J-E03K9
1R491	315-0391-00		RES,FXD,FILM:390 OHM,5%,0.25W	57668	NTR25J~E390E
1R492	315-0102-00		RES, FXD, FILM:1K OHM, 5%, 0.25W	57668	NTR25JE01K0
1R493	315-0103-00		RES, FXD, FILM: 10K 0HM, 5%, 0.25W	19701	5043CX10K00J
1R495	315-0752-00		RES, FXD, FILM: 7.5K OHM, 5%, 0.25W	57668	NTR25J-E07K5
1R496	315-0752-00		RES, FXD, FILM: 7.5K OHM, 5%, 0.25W	57668	NTR25J-E07K5
1R497	315-0471-00		RES, FXD, FILM: 470 OHM, 5%, 0.25W	57668	NTR25J-E470E
1R498	315-0431-00		RES,FXD,FILM:430 0HM,5%,0.25W	19701	5043CX430R0J
1R501	321-0322-00		RES, FXD, FILM: 22.1K 0HM, 0.1%, 0.125W, TC=T0	19701	5033ED22K10F
1R502	321 -03 18 -0 0		RES, FXD, FILM: 20.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED20K00F
1R503	321-0318-00		RES, FXD, FILM: 20.0K 0HM, 1%, 0.125W, TC=T0	19 70 1	5033ED20K00F
1R504	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
1R505	315-0334-00		RES, FXD, FILM: 330K 0HM, 5%, 0.25W	57668	NTR25J-E 330K
	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
A1R506					
A1R506	215 0100 00			57000	NTDOEJEOIKO
1R506 1R508	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
1R506 1R508 1R512	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
1R506 1R508					

A1R518 A1R520 A1R521 A1R522 A1R523 A1R523 A1R524 A1R526 A1R530 A1R531 A1R532 A1R533 A1R534 A1R535 A1R536	315-0912-00 315-0102-00 315-0102-00 315-0102-00 315-0102-00 315-0102-00 315-0222-00 315-0101-00 315-0102-00 315-0222-00 315-0511-00	RES, FXD, FILM:9.1K OHM, 5%, 0.25W RES, FXD, FILM:1K OHM, 5%, 0.25W RES, FXD, FILM:1.8K OHM, 5%, 0.25W RES, FXD, FILM:1K OHM, 5%, 0.25W RES, FXD, FILM:1K OHM, 5%, 0.25W RES, FXD, FILM:2.2K OHM, 5%, 0.25W RES, FXD, FILM:2.2K OHM, 5%, 0.25W RES, FXD, FILM:2.2K OHM, 5%, 0.25W	57668 57668 57668 57668 57668 57668 57668	NTR25J-E09K1 NTR25JE01K0 NTR25J-E1K8 NTR25JE01K0 NTR25JE01K0 NTR25JE01K0 NTR25J-E02K2
A1R521 A1R522 A1R523 A1R523 A1R524 A1R526 A1R530 A1R531 A1R532 A1R533 A1R533 A1R534 A1R535 A1R536	315-0182-00 315-0102-00 315-0102-00 315-0102-00 315-0222-00 315-0222-00 315-0101-00 315-0102-00 315-0222-00	RES,FXD,FILM:1.8K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:2.2K OHM,5%,0.25W RES,FXD,FILM:2.2K OHM,5%,0.25W	57668 57668 57668 57668 57668	NTR25J-E1K8 NTR25JE01K0 NTR25JE01K0 NTR25JE01K0
A1R522 A1R523 A1R524 A1R525 A1R526 A1R530 A1R531 A1R532 A1R533 A1R533 A1R534 A1R535 A1R536	315-0102-00 315-0102-00 315-0102-00 315-0222-00 315-0222-00 315-0101-00 315-0102-00 315-0222-00	RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:2.2K OHM,5%,0.25W RES,FXD,FILM:2.2K OHM,5%,0.25W	57668 57668 57668 57668	NTR25JE01K0 NTR25JE01K0 NTR25JE01K0
A1R523 A1R524 A1R525 A1R526 A1R530 A1R531 A1R532 A1R533 A1R533 A1R534 A1R535 A1R536	315-0102-00 315-0102-00 315-0222-00 315-0222-00 315-0101-00 315-0102-00 315-0222-00	RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:1K OHM,5%,0.25W RES,FXD,FILM:2.2K OHM,5%,0.25W RES,FXD,FILM:2.2K OHM,5%,0.25W	57668 57668 57668	NTR25JE01K0 NTR25JE01K0
A1R524 A1R525 A1R526 A1R530 A1R531 A1R532 A1R533 A1R534 A1R535 A1R536	315-0102-00 315-0222-00 315-0222-00 315-0101-00 315-0102-00 315-0222-00	RES,FXD,FILM:1K 0HM,5%,0.25W RES,FXD,FILM:2.2K 0HM,5%,0.25W RES,FXD,FILM:2.2K 0HM,5%,0.25W	57668 57668	NTR25JE01K0
A1R525 A1R526 A1R530 A1R531 A1R532 A1R533 A1R534 A1R535 A1R536	315-0222-00 315-0222-00 315-0101-00 315-0102-00 315-0222-00	RES, FXD, FILM: 2.2K OHM, 5%, 0.25W RES, FXD, FILM: 2.2K OHM, 5%, 0.25W	57668	
A1R526 A1R530 A1R531 A1R532 A1R533 A1R534 A1R535 A1R536	315-0222-00 315-0101-00 315-0102-00 315-0222-00	RES, FXD, FILM: 2.2K OHM, 5%, 0.25W		NTD251-50242
A1R530 A1R531 A1R532 A1R533 A1R533 A1R534 A1R535 A1R536	315-0101-00 315-0102-00 315-0222-00			
A1R531 A1R532 A1R533 A1R533 A1R534 A1R535 A1R536	315-0102-00 315-0222-00		57668	NTR25J-E02K2
A1R532 A1R533 A1R534 A1R535 A1R535 A1R536	315-0222-00	RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R533 A1R534 A1R535 A1R536		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R534 A1R535 A1R536	010 0011 00	RES,FXD,FILM:2.2K OHM,5%,0.25W RES,FXD,FILM:510 OHM,5%,0.25W	57668 19701	NTR25J-E02K2 5043CX510R0J
A1R535 A1R536				-
A1R536	315-0511-00	RES, FXD, FILM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
	315-0181-00	RES, FXD, FILM: 180 OHM, 5%, 0.25W	57668	NTR25J-E180E
A10007	315-0181-00	RES, FXD, FILM: 180 OHM, 5%, 0.25W	57668	NTR25J-E180E
A1R537	315-0221-00	RES, FXD, FILM: 220 OHM, 5%, 0.25W	57668	NTR25J-E220E
A1R538 A1R539	315-0512-00 315-0512-00	RES,FXD,F1LM:5.1K 0HM,5%,0.25W RES,FXD,F1LM:5.1K 0HM,5%,0.25W	57668 57668	NTR25J-E05K1 NTR25J-E05K1
				-
A1R540	315-0511-00	RES, FXD, F1LM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
A1R541	315-0511-00	RES, FXD, FILM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
A1R542	315-0103-00	RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R543	315-0103-00	RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R544	315-0431-00	RES, FXD, FILM: 430 OHM, 5%, 0.25W	19701	5043CX430R0J
A1R545	315-0102-00	RES,FXD,FILM:1K OHM,5%,0.25W	57668	NTR25JE01K0
A1R547	315-0102-00	RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R548	315-0102-00	RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R549	315-0621-00	RES, FXD, FILM: 620 OHM, 5%, 0.25W	57668	NTR25J-E620E
A1R550	315-0512-00	RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
A1R551 A1R552	315-0182-00 315-0222-00	RES,FXD,FILM:1.8K 0HM,5%,0.25W RES,FXD,FILM:2.2K 0HM,5%,0.25W	57668 57668	NTR25J-E1K8 NTR25J-E02K2
A1R553	315-0511-00	RES, FXD, FILM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
A1R554	315-0222-00	RES, FXD, FILM: 2.2K OHM, 5%, 0.25W	57668	NTR25J-E02K2
A1R555	315-0391- 0 0	RES, FXD, FILM: 390 OHM, 5%, 0.25W	57668	NTR25J-E390E
A1R556	315-0222-00	RES, FXD, FILM: 2.2K 0HM, 5%, 0.25W	57 66 8	NTR25J-E02K2
A1R557	315-0102-00	RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R560	315-0271-00	RES,FXD,FILM:270 OHM,5%,0.25W	57668	NTR25J-E270E
A1R561	315-0512-00	RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
A1R562	315-0392-00	RES,FXD,FILM:3.9K OHM,5%,0.25W	57668	NTR25J-E03K9
A1 R56 3	315-0222-00	RES, FXD, FILM: 2.2K OHM, 5%, 0.25W	57668	NTR25J-E02K2
A1R564	315-0511-00	RES, FXD, FILM:510 OHM, 5%, 0.25W	19701	5043CX510R0J
A1R565	315-0103-00	RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R566	315-0752-00	RES,FXD,FILM:7.5K OHM,5%,0.25W	57 668	NTR25J-E07K5
A1R567	315-0103-00	RES,FXD,FILM:10K OHM,5%,0.25W	19701	5043CX10K00J
A1R570	315-0392-00	RES,FXD,FILM:3.9K 0HM,5%,Q.25W	57668	NTR25J-E03K9
A1R571	315-0392-00	RES,FXD,FILM:3.9K OHM,5%,0.25W	57668	NTR25J-E03K9
A1R572	315-0222-00	RES, FXD, FILM: 2.2K OHM, 5%, 0.25W	57668	NTR25J-E02K2
A1R573	315-0222-00	RES,FXD,FILM:2.2K OHM,5%,0.25W	57668	NTR25J-E02K2
A1R574	315-0222-00	RES, FXD, FILM:2.2K OHM, 5%, 0.25W	57668	NTR25J-E02K2
A1R576	315-0222-00	RES,FXD,FILM:2.2K OHM,5%,0.25W	57668	NTR25J-E02K2
A1R579	315-0221-00	RES, FXD, FILM: 220 OHM, 5%, 0.25W	57668	NTR25J-E220E
A1R581	315-0103-00	RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
1R582	321-0361-00	RES, FXD, FILM: 56.2K OHM, 1%, 0.125W, TC=T0		CEAD56201F
A1R583	315-0204-00	RES, FXD, FILM: 200K OHM, 5%, 0.25W	19701	5043CX200K0J
1R584	315-0474-00	RES, FXD, FILM:470K 0HM, 5%, 0.25W	19701	5043CX470K0J92U
A1R585	315-0104-00	RES, FXD, FILM: 100K OHM, 5%, 0.25W	57668	NTR25J-E100K
1R586	315-0334-00	RES, FXD, FILM: 330K OHM, 5%, 0.25W	57668	NTR25J-E 330K
1R587	315-0104-00	RES, FXD, F1LM: 100K OHM, 5%, 0.25W	57668	NTR25J-E100K
\1R588	315-0182-00	RES,FXD,FILM:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8

REV JAN 1990

-

<u>Component No.</u>	Tektronix Part No.	Serial/Assembly No. Effective Dscont	Name & Description	Mfr. Code	Nfr. Part No.
A1R589	321-0318-00		RES, FXD, FILM: 20.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED20K00F
A1R590	321-0205-00		RES, FXD, FILM: 1.33K OHM, 1%, 0.125W, TC≈T0	19701	5033ED1K330F
A1R775	315-0181-00		RES, FXD, FILM: 180 OHM, 5%, 0.25W	57668	NTR25J-E180E
A1R776	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R778	321-0396-00		RES, FXD, FILM: 130K OHM, 1%, 0.125W, TC=T0	07716	CEAD13002F
A1R779	321-0306-00		RES, FXD, FILM: 15.0K 0HM, 1%, 0.125W, TC=T0	19701	5033ED15J00F
A1R780	315-0510-00		RES.FXD.FILM:51 0HM.5%.0.25W	19701	5043CX51R00J
A1R781	321-0146-00		RES, FXD, FILM: 324 OHM, 1%, 0.125W, TC=T0	07716	CEAD324R0F
A1R783	315-0623-00		RES, FXD, FILM: 62K 0HM, 5%, 0.25W	19701	5043CX62K00J
A1R784	323-0314-00		RES, FXD, FILM: 18.2K OHM, 1%, 0.5W, TC=T0	75042	CECT0-1822F
A1R785	323-0314-00		RES, FXD, FILM: 18.2K OHM, 1%, 0.5W, TC=T0	75042	CECT0-1822F
A1R786	321-0185-00		RES, FXD, FILM: 825 OHM, 1%, 0.125W, TC=T0	07716	CEAD825R0F
A1R787	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R788	321-0249-00		RES, FXD, FILM: 3.83K OHM, 1%, 0.125W, TC≈TO	19701	5033ED3K83F
A1R789	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
A1R790	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
A1R791	321-0139-00		RES, FXD, FILM: 274 OHM, 1%, 0.125W, TC=T0	07716	CEAD274R0F
A1R792	321-0135-00		RES, FXD, FILM: 249 OHM, 1%, 0.125W, TC=T0	07716	CEAD249R0F
A1R793	315-0623-00		RES, FXD, FILM: 62K OHM, 5%, 0.25W	19701	5043CX62K00J
A1R794	323-0314-00		RES, FXD, FILM: 18.2K OHM, 1%, 0.5W, TC=TO	75042	CECT0-1822F
A1R795	323-0314-00		RES, FXD, FILM: 18.2K OHM, 1%, 0.5W, TC=T0	75042	CECT0-1822F
A1R796	321-0207-00		RES, FXD, FILM: 1.40K OHM, 1%, 0.125W, TC=T0	19701	5033ED1K400F
A1R797	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R798	321-0249-00		RES,FXD,FILM:3.83K OHM,1%,0.125₩,TC≈TO	19701	5033ED3K83F
A1R799	315-0510-00		RES, FXD, FILM:51 0HM, 5%, 0.25W	19 70 1	5043CX51R00J
A1R804	315-0102-00		RES,FXD,FILM:1K OHN,5%,0.25W	57668	NTR25JE01K0
A1R805	315-0562-00		RES, FXD, FILM: 5.6K OHM, 5%, 0.25W	57668	NTR25J-E05K6
A1R818	315-0272-00		RES,FXD,FILM:2.7K OHM,5%,0.25W	57668	NTR25J-E02K7
A1R819	315-0103 -0 0		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R820	315-0362-00		RES, FXD, FILM: 3.6K OHM, 5%, 0.25W	19701	5043CX3K600J
A1R822	321-0361-00		RES,FXD,FILM:56.2K OHM,1%,0.125₩,TC≈T0	07716	CEAD56201F
A1R823	315-0472-00		RES,FXD,FILM:4.7K OHM,5%,0.25W	57668	NTR25J-E04K7
A1R825	315-0101-00		RES,FXD,FILM:100 OHM,5%,0.25W	57668	NTR25J-E 100E
A1R828	315-0203-00		RES, FXD, FILM: 20K OHM, 5%, 0.25W	57668	NTR25J-E 20K
A1R830	321-0205-00		RES,FXD,FILM:1.33K OHM,1%,0.125W,TC≈TO	19701	5033ED1K330F
A1R832	321-0223-00		RES,FXD,FILM:2.05K OHM,1%,0.125W,TC≂TO	19701	5033ED2K05F
A1R834	315-0101-00		RES, FXD, FILM:100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R835	321-0233-00		RES,FXD,FILM:2.61K OHM,1%,0.125₩,TC≈T0	07716	CEAD26100F
A1R836	315-0102-00		RES,FXD,FILM:1K OHM,5%,0.25W	57668	NTR25JE01K0
A1R840	315-0511-00		RES, FXD, FILM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
A1 R841	321-0344-00		RES,FXD,FILM:37.4K OHM,1%,0.125₩,TC≈T0	19701	5033ED 37K40F
A1R842	315-0241-00		RES, FXD, FILM: 240 OHM, 5%, 0.25W	19701	5043CX240R0J
A1R843	321-0344-00		RES, FXD, FILM: 37.4K OHM, 1%, 0.125W, TC=T0	19701	5033ED 37K40F
A1R844	315-0104-00		RES, FXD, FILM: 100K OHM, 5%, 0.25W	57 668	NTR25J-E100K
A1R845	315-0472-00		RES, FXD, FILM: 4.7K OHM, 5%, 0.25W	57 668	NTR25J-E04K7
A1R849	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R850	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57 668	NTR25JE01K0
A1R851	311-2367-00		RES, VAR, NONWA: TRMR, 22K OHM, 0.5W	K8788	TC10-LV10-22K/A
A1R852	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R853	315-0204-00		RES, FXD, FILM: 200K OHM, 5%, 0.25W	19701	5043CX200KOJ
\1R854	315-0472-00		RES, FXD, FILM: 4.7K OHM, 5%, 0.25W	57668	NTR25J-E04K7
A1R855	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
\1R858	315-0511-00		RES, FXD, FILM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
1R860	315-0625-00		RES,FXD,FILM:6.2M OHM,5%,0.25W	01121	CB6255
1R870	311-2358-00		RES, VAR, NONWW: TRMR, 100K OHM, 0.5W	K8788	TC10-LV10-100K/A
1R871	311-2358-00		RES, VAR, NONWW: TRMR, 100K OHM, 0.5W	K8788	TC10-LV10-100K/A
\1R874	315-0513-00		RES,FXD,FILM:51K 0HM,5%,0.25W	57 66 8	NTR25J-E51K0
1R875	315-0513-00		RES, FXD, FILM: 51K OHM, 5%, 0.25W	57 668	NTR25J-E51K0

٠

Component No.	Tektronix <u>Part No.</u>	Serial/Assembly No. Effective Dscont	Name & Description	Mfr. <u>Code</u>	Mfr. Part <u>No.</u>
A1R888	301-0514-00		RES, FXD, FILM: 510K OHM, 5%, 0.5W	19701	5053CX510K0J
A1R889	301-0514-00		RES, FXD, FILM: 510K OHM, 5%, 0.5W	19701	5053CX510K0J
A1R890	301-0514-00		RES, FXD, FILM: 510K OHM, 5%, 0.5W	19701	5053CX510K0J
A1R891	301-0514-00		RES, FXD, FILM: 510K OHM, 5%, 0.5W	19701	5053CX510K0J
A1R892	301-0514-00		RES, FXD, FILM: 510K 0HM, 5%, 0.5W	19701	5053CX510K0J
A1 R 894	315-0753-00		RES,FXD,FILM:75K OHM,5%,0.25W	57668	NTR25J-E75K0
A1R899	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R900	315-0105-00		RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J
A1R901	315-0103-00		RES, FXD, FILM: 10K 0HM, 5%, 0.25W	19701	5043CX10K00J
A1R910 A1R911	308-0499-00 315-0102-00		RES,FXD,WW:0.5 OHM,10%,2.5W,AXIAL RES.FXD.FILM:1K OHM.5%.0.25W	14193 57668	SA31 R500K NTR25JE01K0
A1R912	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R913	315-0102-00		RES, FXD, FILM:1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R914	315-0202-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25J-E 2K
A1R915	315-0512-00		RES, FXD, FILM: 5.1K 0HM, 5%, 0.25W	57668	NTR25J-E05K1
A1R916	311-2364-00		RES, VAR, NONWY: TRMR, 4.7K OHM, 0.5W	K8788	TC10-LV10-4K7/A
A1R917	315-0513-00		RES.FXD.FILM:51K 0HM,5%,0.25W	57668	NTR25J-E51K0
A1R918	321-0344-00		RES, FXD, FILM: 37.4K 0HM, 1%, 0.125W, TC=T0	19701	5033ED 37K40F
A1R919	315-0102-00		RES, FXD, FILM:1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R920	315-0303-00		RES, FXD, FILM: 30K OHM, 5%, 0.25W	19701	5043CX30K00J
A1R922	315-0202-00		RES, FXD, FILM: 2K OHM, 5%, 0.25W	57668	NTR25J-E 2K
A1R926	315-01 03-0 0		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R927	315-0106-00		RES, FXD, FILM: 10M OHM, 5%, 0.25W	01121	CB1065
A1R928	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R929	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R930	315-0511-00		RES, FXD, FILM: 510 OHM, 5%, 0.25W	19701	5043CX510R0J
A1R931	315-0822-00		RES, FXD, FILM:8.2K 0HM, 5%, 0.25W	19701	5043CX8K200J
A1R932	315-0822-00		RES, FXD, FILM: 8.2K OHM, 5%, 0.25W	19701	5043CX8K200J
A1R933 A1R934	315-0241-00 315-0303-00		RES,FXD,FILM:240 OHM,5%,0.25W RES,FXD,FILM:30K OHM,5%,0.25W	19701 19701	5043CX240R0J 5043CX30K00J
10025					
A1 R93 5	315-0303-00		RES, FXD, FILM: 30K OHM, 5%, 0.25W	19701	5043CX30K00J
A1 R936 A1R9 3 9	315-0512-00 315-0303-00		RES,FXD,FILM:5.1K OHM,5%,0.25W RES,FXD,FILM:30K OHM,5%,0.25W	57668 19701	NTR25J-E05K1 5043CX30K00J
A1R939	315-0102-00		RES, FXD, FILM: SUK UHM, 5%, 0.25W RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R941	315-0241-00		RES, FXD, FILM: 240 OHM, 5%, 0.25W	19701	5043CX240R0J
A1 R94 2	315-0510-00		RES, FXD, FILM:51 0HM, 5%, 0.25W	19701	5043CX51R00J
A1R943	315 -030 3-00		RES.FXD.FILM:30K OHM,5%,0.25W	19701	5043CX30K00J
A1R944	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R945	315-0241-00		RES, FXD, FILM: 240 OHM, 5%, 0.25W	19701	5043CX240R0J
A1R946	315-0510-00		RES, FXD, FILM: 51 OHM, 5%, 0.25W	19701	5043CX51R00J
1R947	315-0241-00		RES, FXD, FILM: 240 OHM, 5%, 0.25W	19701	5043CX240R0J
A1 R94 8	315-0241-00		RES, FXD, FILM: 240 OHM, 5%, 0.25W	19701	5043CX240R0J
A1 R949	307-0106-00		RES, FXD, CMPSN: 4.7 OHM, 5%, 0.25W	01121	CB 47G5
\1R955	315-0511-00		RES, FXD, FILM: 510 OHM, 5%, 0, 25W	19701	5043CX510R0J
A1R956	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
\1R957	315-0103-00		RES, FXD, FILM: 10K OHM, 5%, 0.25W	19701	5043CX10K00J
A1R958	315-0303-00		RES, FXD, FILM: 30K OHM, 5%, 0.25W	19701	5043CX30K00J
\1R970	301-0102-00		RES, FXD, CMPSN: 1K OHM, 5%, 0.50W	19701	5053CX1K000J
1R971	301-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.5W	01121	EB1015
1R972	315-0512-00		RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
1R977	315-0303-00		RES, FXD, FILM: 30K OHM, 5%, 0.25W	19701	5043CX30K00J
1R978	315-0512-00		RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
1R979 1R980	315-0301-00 315-0512-00		RES,FXD,FILM:300 OHM,5%,0.25W RES,FXD,FILM:5.1K OHM,5%,0.25W	57668 57668	NTR25J-E300E NTR25J-E05K1
1R981			RES, FXD, FILM: 51K OHM, 5%, 0.25W		NTR25J-E51K0
1R981	315-0513-00 315-0512-00		RES, FXD, FILM: 51K OHM, 5%, 0.25W RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668 57668	NTR25J-E05K1
1R983	301-0102-00		RES, FXD, FILM: 5.1K OHM, 5%, 0.25W RES, FXD, CMPSN: 1K OHM, 5%, 0.50W	19701	5053CX1K000J
1R984	301-0102-00		RES, FXD, CMPSN: IN OHM, 5%, 0.50W	19701	5053CX1K000J
11004	301-0102-00			19/01	JUJUATINUUU

•

٩

Component No.	Tektronix Part No.	Serial/Assembly No. <u>Effective</u> Dscont	Name & Description	Mfr. Code	Mfr. Part No.
A1R985	315-0303-00		RES, FXD, FILM:30K 0HM, 5%, 0.25W	19701	5043CX30K00J
A1R986	315-0272-00		RES, FXD, FILM:2.7K 0HM, 5%, 0.25W	57668	NTR25J-E02K7
A1R987	315-0272-00		RES, FXD, FILM:2.7K 0HM, 5%, 0.25W	57668	NTR25J-E02K7
A1R988	315-0303-00		RES,FXD,FILM:30K OHM,5%,0.25W	19701	5043CX30K00J
A1R989	315-0103-00		RES,FXD,FILM:10K OHM,5%,0.25W	19701	5043CX10K00J
A1R990	301-0102-00		RES,FXD,CMPSN:1K OHM,5%,0.50W	19701	5053CX1K000J
A1R991	301-0102-00		RES,FXD,CMPSN:1KOHM,5%,0.50W	19701	5053CX1K000J
A1R992	301-0102-00		RES,FXD,CMPSN:1KOHM,5%,0.50W	19701	5053CX1K000J
A1R995	301-0103-02		RES,FXD,CMPSN:10KOHM,5%,0.5W	01121	EB1035
A1T902	120-1788-00		XFWR, PWR, STPDN:HIGH FREQUENCY, HIGH VOLTAGE	80009	120-1788-00
A1U130	156-0534-00		MICROCKT, LINEAR:DUAL DIFF AMPL	02735	CA3102E-98
A1U180	156-0534-00		MICROCKT, LINEAR:DUAL DIFF AMPL	02735	CA3102E-98
A1U225 A1U300 A1U304 A1U310 A1U335 A1U380	156-0067-00 156-2988-00 156-2986-00 156-2956-00 156-2956-00 156-2902-00		MICROCKT,LINEAR:BIPOLAR,OPNL AMPL MICROCKT,DGTL:CMOS,QUAD 2 IP NOR MICROCKT,DGTL:CMOS,QUAD 4 IP NOR MICROCKT,LINEAR:DUAL,INDEP PIFF AMPL MICROCKT,LINEAR:DUAL,INDEP PIFF AMPL MICROCKT,LINEAR:	04713 K5856 K5856 K5856 K5856 K5856	MC1741CP1 CD4001BE CD4002BE CA 3054 CA 3054 CA 3054 CA 3046
A1U415 A1U425 A1U460 A1U480 A1U500	156-2902-00 156-0853-00 156-2956-00 156-0205-03 156-1335-00		MICROCKT,LINEAR: MICROCKT,LINEAR:OPNL AMPL,DUAL MICROCKT,LINEAR:DUAL,INDEP PIFF AMPL MICROCKT,DGTL:ECL,QUAD 2-INPUT NOR GATE MICROCKT,DGTL:LSTTL,DUAL RETRIGGERABLE RESE TTABLE MONOSTABLE MV,SCRN	K5856 04713 K5856 04713 80009	CA 3046 LM358N CA 3054 MC10102 L OR P 156-1335-00
A1U520	156-0205-03		MICROCKT,DGTL:ECL,QUAD 2-INPUT NOR GATE	04713	MC10102 L OR P
A1U530	156-1639-00		MICROCKT,DGTL:ECL,DUAL D MA-SLAVE FF	04713	MC10H131(P OR L)
A1U537	156-0721-02		MICROCKT,DGTL:QUAD ST 2-INP NAND GATES	80009	156-0721-02
A1U540	156-0388-03		MICROCKT,DGTL:DUAL D FLIP-FLOP,SCRN	80009	156-0388-03
A1U550	156-0205-03		MICROCKT,DGTL:ECL,QUAD 2-INPUT NOR GATE	04713	MC10102 L OR P
A1U550	156-2902-00		MICROCKT,LINEAR:	K5856	CA 3046
A1U570	156-1639-00		MICROCKT, DGTL:ECL, DUAL D MA-SLAVE FF	04713	MC10H131(P OR L)
A1U580	156-0853-00		MICROCKT, LINEAR:OPNL AMPL, DUAL	04713	LM358N
A1U910	156-0853-00		MICROCKT, LINEAR:OPNL AMPL, DUAL	04713	LM358N
A1U920	156-1126-00		MICROCKT, LINEAR:VOLTAGE COMPARATOR	01295	LM311P
A1U930	156-1408-02		MICROCKT, LINEAR:TIMER	01295	TLC555CP
A1U930	156-0366-00		MICROCKT, DGTL:DUAL D FLIP-FLOP	02735	CD4013BF
A1VR776 A1VR792 A1VR915 A1VR925 A1VR932 A1VR933	152-0217-00 152-0647-00 152-0647-00 152-0278-00 152-0217-00 152-0217-00		SEMICOND DVC, DI:ZEN, SI, 8.2V, 5%, 0.4W, DO-7 SEMICOND DVC, DI:ZENER, SI, 6.8V, 5%, 400MW, DO-7 SEMICOND DVC, DI:ZENER, SI, 6.8V, 5%, 400MW, DO-7 SEMICOND DVC, DI:ZEN, SI, 3V, 5%, 0.4W, DO-7 SEMICOND DVC, DI:ZEN, SI, 8.2V, 5%, 0.4W, DO-7 SEMICOND DVC, DI:ZEN, SI, 8.2V, 5%, 0.4W, DO-7		SZG20 1N957B 1N957B 152-0278-00 SZG20 SZG20
A1VR982	152-0571-00		SEMICOND DVC,DI:ZEN,SI,16V,5%,0.4W,DO-7	04713	SZG35014KIRL
A1VR985	152-0278-00		SEMICOND DVC,DI:ZEN,SI,3V,5%,0.4W,DO-7	80009	152-0278-00
A1VR988	152-0278-00		SEMICOND DVC,DI:ZEN,SI,3V,5%,0.4W,DO-7	80009	152-0278-00
A1W30	174-0640-00		CA ASSY,SP,ELEC:4,26 AWG,135MM L,RIBBON	TKOEM	820265804(135mm)
A1W80	174-0640-00		CA ASSY,SP,ELEC:4,26 AWG,135MM L,RIBBON	TKOEM	820265804(135mm)
A1W90	174-0635-00		CA ASSY,SP,ELEC:6,26 AWG,120MM L,RIBBON	TKOEM	82265806(120mm)
A1W224	174-1166-00		CA ASSY,SP,ELEC:2,26 AWG,8.0 L	80009	174-1166-00
A1W225	174-1166-00		CA ASSY,SP,ELEC:2,26 AWG,8.0 L	80009	174-1166-00
A1W500	131-0566-00		BUS,CONDUCTOR:DUMMY RES,0.094 OD X 0.225 L	24546	OMA 07
A1W590	195-3407-00		LEAD,ELECTRICAL:26 AWG,3.0 L,9-3	80009	195-3407-00
A1W701	174-0637-00		CA ASSY,SP,ELEC:6,26 AWG,300MM L,RIBBON	TK0EM	82265806(300mm)
A1W755	174-0640-00		CA ASSY,SP,ELEC:4,26 AWG,135MM L,RIBBON	TK0EM	820265804(135mm)
A1W893	174-0642-00		CA ASSY,SP,ELEC:3,26 AWG,100MM L,RIBBON	TKOEM	82265803 (100mm)
A1W903	174-0636-00		CA ASSY,SP,ELEC:3,26 AWG,150MM L,RIBBON	TKOEM	82265803 (150mm)
A1W920	131-0566-00		BUS,CONDUCTOR:DUMMY RES,0.094 OD X 0.225 L	24546	OMA 07

<u>Component No.</u>	Tektronix <u>Part No.</u>	Serial/Assembly No. <u>Effective Dscont</u>	Name & Description	Nfr. Code	Mfr. Part No
A1W921	1 31-0566-0 0		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1w925	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W926	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1w947	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W948	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W951	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W976	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W984	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W985	131-0566-00		BUS, CONDUCTOR: DUMMY RES. 0.094 OD X 0.225 L	24546	OMA 07
A1W987	131-0566-00		BUS, CONDUCTOR: DUMMY RES. 0.094 OD X 0.225 L	24546	OMA 07
A1W989	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
A1W991	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07

i

<u>Component No.</u>	Tektronix <u>Part No.</u>	Serial/Assembly <u>Effective</u> Dsc		Mfr. <u>Code</u>	<u>Mfr. Part No.</u>
A2	671-0390-00		CIRCUIT BD ASSY:TIMEBASE/ATTEN	80009	671-0390-00
A2AT1	260-2409-00		SWITCH, ROTARY: 1M OHM, 10 POS ATTENUATOR	TK1815	
A2AT51	260-2409-00		SWITCH, ROTARY: 1M OHM, 10 POS ATTENUATOR	TK1815	
A2C6	283-0000-00		CAP, FXD, CER DI:0.001UF, +100-0%, 500V	59660	831-610-Y5U0102P
A2C13	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C30	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C31	281 -0812- 00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A2C35	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A2C38	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V	04222	MA101C102KAA
A2C56	283-0000-00		CAP, FXD, CER DI: 0.001UF, +100-0%, 500V	59660	831-610-Y5U0102P
A2C63 A2C80	281-0775-01 281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V CAP, FXD, CER DI:0.1UF, 20%, 50V	04222 04222	SA105E104MAA SA105E104MAA
A2C81 A2C85	281-0812-00		CAP, FXD, CER DI: 1000PF, 10%, 100V CAP, FXD, CER DI: 0.1UF, 20%, 50V	04222 04222	MA101C102KAA SA105E104MAA
A2C88	281-0775-01 281-0812-00		CAP, FXD, CER D1:0.10F, 20%, 50V CAP, FXD, CER D1:1000PF, 10%, 100V	04222	MA101C102KAA
A2C93	290-1153-00		CAP, FXD, ELCTLT: 47UF, +50-10%, 100	K8996	030-24479
A2C94	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C95	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
12006	200-1152 00			KOUUE	030-24479
A2C96 A2C97	290-1153-00 281 -0775- 01		CAP, FXD, ELCTLT: 47UF, +50-10%, 10V CAP, FXD, CER DI:0.1UF, 20%, 50V	K8996 04222	030-24479 SA105E104MAA
A2C98	281-0775-01		CAP, FXD, CER DI:0.10F, 20%, 30V CAP, FXD, CER DI:0.10F, 20%, 50V	04222	SA105E104MAA
A2C701	285-1409-00		CAP, FXD, MTLZD: 10F, 1%, 160V, AXIAL, TUB, MI	TKOED	ORDER BY DESCR
A2C702	285-1408-00		CAP, FXD, MTLZD: 100, 1%, 100, AXIAL, TUB, MI	TKOED	ORDER BY DESCR
A2C703	281-0207-00		CAP, VAR, PLASTIC: 2-18PF, 100V	52769	GXA 18000
A2C704	2 83-0674- 00		CAP. FXD. MICA DI:85PF.1%, 500V	00853	D155F850F0
A2C705	281-0813-00		CAP, FXD, CER DI:0.047UF, 20%, 50V	05397	C412C473M5V2CA
A2C706	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C708	281-0756-00		CAP, FXD, CER DI:2.2PF,+/-0.5PF,200V	04222	SA102A2R2DAA
A2C709	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C710	281 -077 5- 01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C712	290-1153-00		CAP.FXD.ELCTLT:47UF.+50-10%.10V	K8996	030-24479
A2C713	290-1153-00		CAP, FXD, ELCTLT: 47UF, +50-10%, 10V	K8996	030-24479
A2C715	290-1153-00		CAP, FXD, ELCTLT: 47UF, +50-10%, 10V	K8996	030-24479
A2C722	281-0773-00		CAP, FXD, CER DI:0.01UF, 10%, 100V	04222	MA201C103KAA
A2C723	290-0183-00		CAP, FXD, ELCTLT: 1UF, 10%, 35V	05397	T3228105K035AS
A2C724	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C727	281-0775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C733	281-0758-00		CAP, FXD, CER DI: 15PF, 20%, 100V	04222	SA102A150MAA
A2C755	281 -0 775-01		CAP, FXD, CER DI:0.1UF, 20%, 50V	04222	SA105E104MAA
A2C767	281-0786-00		CAP, FXD, CER DI: 150PF, 10%, 100V	04222	MA101A151KAA
A2CR14	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-3		DA2527 (1N4152)
A2CR64	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2CR758	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-3	03508	DA2527 (1N4152)
A2CR761	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35		DA2527 (1N4152)
A2CR762	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35		DA2527 (1N4152)
A2CR769	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-3		DA2527 (1N4152)
A2CR773	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35		DA2527 (1N4152)
A2CR774	15 2-0141-0 2		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2E90	276-0752-00		CORE, EM: FERRITE	34899	2743001111
A2E91	276-0752-00		CORE, EM: FERRITE	34899	2743001111
A2E92	276-0752-00		CORE, EM: FERRITE	34899	2743001111
A2E93	276-0752-00		CORE, EM: FERRITE	34899	2743001111
A2L93	120-1631-00		COIL, RF: FXD, 2100H	TK00A	ORDER BY DESCR
A2L96	120-1631-00		COIL, RF: FXD, 210UH	TK 00 A	ORDER BY DESCR
A2L712	120-1631-00		COIL, RF: FXD, 210UH	TK00A	ORDER BY DESCR
A2L713	120-1631-00		COIL, RF: FXD, 2100H	TK00A	ORDER BY DESCR
A2Q13	151-1054-00		TRANSISTOR: FET, N-CHAN, SI, TO-71	80009	151-1054-00
A2Q14	151-1025-00		TRANSISTOR:FET,N-CHAN,SI,TO-92	04713	SPF3036

Component No.	Tektronix Pa <u>rt No.</u>	Serial/Assembly No. <u>Effective Dscont</u>	Name & Description	Nfr. <u>Code</u>	Mfr. Part <u>No.</u>
2063	151-1054-00		TRANSISTOR: FET, N-CHAN, SI, TO-71	80009	151-1054-00
2064	151-1025-00		TRANSISTOR: FET, N-CHAN, SI, TO-92	047 13	SPF3 03 6
20701	151 -0 424-00		TRANSISTOR:NPN,SI,TO-92	047 13	SPS8246
20704	151-1042-00		SEMICOND DVC SE:FET, SI, TO-92	80009	15 1-104 2-00
			(LOCATIONS A & B)		
20706	151-0736-00		TRANSISTOR:NPN, SI, TO-92	80009	151-0736-00
20725	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
20732	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
20736	151-0190-00		TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
20737	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
20750	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
20759	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
20760	151-0188-00		TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
2 R3	315-0330-00		RES, FXD, FILM:33 OHM, 5%, 0.25W	19701	5043CX33R00J
2R5	322-0481-01		RES,FXD,FILM:1M OHM, 0.5%,0.25W,TC=TO	75042	CEBT0-1004D
2R6	315-0474-00		RES, FXD, FILM: 470K OHM, 5%, 0.25W	19701	5043CX470K0J92U
2R13	315-0470-00		RES, FXD, FILM: 47 OHM, 5%, 0.25W	57668	NTR25J-E47E0
2R14	315-0200-00		RES, FXD, FILM: 20 0HM, 5%, 0.25W	19701	5043CX20R00J
2R15	315-0200-00		RES, FXD, FILM: 20 OHM, 5%, 0.25W	19701	5043CX20R00J
2R22	321-0210-00		RES,FXD,FILM:1.50K OHM,1%,0.125W,TC=TO	1 97 01	5033ED1K50F
2R23	321-0210- 0 0		RES, FXD, FILM: 1.50K OHM, 1%, 0.125W, TC=T0	197 01	5033ED1K50F
2R29	321-0068-00		RES,FXD,FILM:49.9 OHM,0.1%,0.125W,TC=T0	91637	CMF55116G49R90F
2R30	315-0472-00		RES,FXD,FILM:4.7K OHM,5%,0.25W	57668	NTR25J-E04K7
2R31	315-0101-00		RES, FXD, FILM:100 0HM, 5%, 0.25W	57668	NTR25J~E 100E
2R32	315-0472-00		RES, FXD, FILM: 4.7K OHM, 5%, 0.25W	57668	NTR25J~E04K7
2R33	311-2368-00		RES, VAR, NONWA: TRMR, 47K. OHM, 0.5W	K8788	TC10-LV10-47K/A
2R35	321-0144-00		RES, FXD, FILM: 309 OHM, 1%, 0.125W, TC=T0	07716	CEAD309R0F
2R36	315-0101-00		RES,FXD,FILM:100 0HM,5%,0.25W	5 7668	NTR25J-E 100E
2R37	315- 01 02-00		RES, FXD, FILM:1K 0HM, 5%, 0.25W	5 7668	NTR25JE01K0
2R38	321-0144-00		RES, FXD, FILM: 309 OHM, 1%, 0.125W, TC=T0	07716	CEAD309R0F
2R39	315-0242-00		RES,FXD,FILM:2.4K OHM,5%,0.25W	57668	NTR25J-E02K4
2R41	321-0154-00		RES, FXD, FILM: 392 OHM, 1%, 0.125W, TC=T0	07716	CEAD392ROF
2R42	315-0333-00		RES, FXD, FILM: 33K OHM, 5%, 0.25W	57668	NTR25J-E33K0
2R53	315-0330-00		RES, FXD, FILM: 33 OHM, 5%, 0.25W	19701	5043CX33R00J
2R55	322-0481-01		RES, FXD, FILM: 1M OHM, 0.5%, 0.25W, TC=TO	7504 2	CEBT0-1004D
2R56	315-0474-00		RES, FXD, FILM: 470K OHM, 5%, 0.25W	19701	5043CX470K0J92U
2R63	315-0470-00		RES, FXD, FILM: 47 0HM, 5%, 0.25W	5 7668	NTR25J-E47E0
2R64	315-0200-00		RES, FXD, FILM: 20 0HM, 5%, 0.25W	19701	5043CX20R00J
2R65	315-0200-00		RES, FXD, FILM: 20 0HM, 5%, 0.25W	19701	5043CX20R00J
2R72	321-0210-00		RES, FXD, FILM: 1.50K 0HM, 1%, 0.125W, TC=T0	19701	5033ED1K50F
2R73	321-0210-00		RES, FXD, FILM: 1.50K 0HM, 1%, 0.125W, TC=T0	19701	5033ED1K50F
2R78	315-0102-00		RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
2R79	321-0068-00		RES, FXD, FILM: 49.9 OHM, 0.1%, 0.125W, TC=T0	91637	CMF55116649R90F
2R80	315-0472-00		RES, FXD, FILM; 4.7K 0HM, 5%, 0. 25W	57668	NTR25J-E04K7
2R81	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
2R82	315-0472-00		RES.FXD.FILM:4.7K 0HM.5%.0.25W	57668	NTR25J-E04K7
2R83	311-2368-00		RES, VAR, NONW: TRMR, 47K OHM, 0.5W	K8788	TC10-LV10-47K/A
2R85	321-0144-00		RES, FXD, FILM: 309 OHM, 1%, 0.125W, TC=T0	07716	CEAD309R0F
2R86	315-0101-00		RES, FXD, FILM: 100 0HM, 5%, 0.25W	57668	NTR25J-E 100E
2R87	315-0102-00		RES.FXD.FILM:1K OHM.5%.0.25W	57668	NTR25JE01K0
2R88	321-0144-00		RES, FXD, FILM: 309 OHM, 1%, 0.125W, TC=T0	07716	CEAD309R0F
2R91	321-0154-00		RES, FXD, FILM: 392 OHM, 1%, 0.125W, TC=TO	07716	CEAD392R0F
2R701	307-0780-01		RES NTWK, FXD, FI:TIMING	80009	307-0780-01
R702	322-0519-01		RES, FXD, FILM: 2.49M OHM, 0.5%, 0.25W, TC=TO	07716	CCAD24903D
R703	315-0100-00		RES, FXD, FILM:10 0HM, 5%, 0.25W	19701	5043CX10RR00J
				57000	NTR25J-E 100E
P704	315_0101_00				
2R704 2R705	315-0101-00 315-0151-00		RES,FXD,FILM:100 0HM,5%,0.25W RES,FXD,FILM:150 0HM,5%,0.25W	57668 57668	NTR25J~E150E

<u>Component No.</u>	Tektronix Part No.	Serial/Assembly No. Effective Dscont	Name & Description	Mfr. Code	Mfr. Part No
A2R715	321-0231-00		RES, FXD, FILM: 2.49K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K49F
A2R716	321-0225-00		RES, FXD, FILM: 2.15K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K15F
A2R717	321-0306-00		RES, FXD, FILM: 15.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED15J00F
A2R718	321-0306-00		RES, FXD, FILM: 15.0K 0HM, 1%, 0.125W, TC=T0	19701	5033ED15J00F
A2R719	315-0330-00		RES, FXD, FILM: 33 OHM, 5%, 0.25W	19701	5043CX33R00J
A2R720	315-0201-00		RES, FXD, FILM:200 OHM, 5%, 0.25W	57 66 8	NTR25J-E200E
A2R721	311-2356-00		RES, VAR, NONWW: PNL, 470 OHM, 20%, 0.2W	K8996	2322 50190194
A2R722	311-2361-00		RES, VAR, NONWAY: TRMR, 10K OHM, 0.5W	K8788	TC10-L V10 -1 0K/ A
A2R723	315-0104-00		RES, FXD, FILM: 100K 0HM, 5%, 0.25W	57 668	NTR25J-E100K
A2R724	315-0302-00		RES, FXD, FILM: 3K OHM, 5%, 0.25W	57 668	NTR25J~E03K0
A2R725	321-0222-00		RES, FXD, FILM: 2.00K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K00F
A2R726	315-0101-00		RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A2R727	321-0254-00		RES, FXD, FILM: 4.32K OHM, 1%, 0.125W, TC=T0	07716	CEAD43200F
A2R728			RES, FXD, FILM: 3.9K OHM, 5%, 0.25W	57668	NTR25J-E03K9
	315-0392-00				
A2R729	315-0512-00		RES, FXD, FILM: 5.1K 0HM, 5%, 0.25W	57668	NTR25J-E05K1
A2R732	321-0254-00		RES, FXD, FILM: 4.32K OHM, 1%, 0.125W, TC=T0	07716	CEAD43200F
A2R733	321-0231-00		RES,FXD,FILM:2.49K OHM,1%,0.125W,TC=T0	19701	5033ED2K49F
A2R734	31 5-0272-00		RES,FXD,FILM:2.7K OHM,5%,0.25W	5 7668	NTR25J-E02K7
A2R735	315-0103-00		RES, FXD, FILM: 10K 0HM, 5%, 0.25W	19 701	5043CX10K00J
A2R736	311-2363-00		RES, VAR, NONWA: TRMR, 1K OHM, 0.5W	K8788	TC10-LV10-1K/A
A2R737	321-0197-00		RES, FXD, FILM: 1.10K OHM, 1%, 0.125W, TC=T0	07716	CEAD11000F
A2R738	315-0562-00		RES. FXD. FILM: 5.6K OHM. 5%. 0.25W	57668	NTR25J-E05K6
A2R740	321-0273-00		RES, FXD, FILM: 6.81K OHM, 1%, 0.125W, TC=T0	07716	CEAD68100F
A2R741	321-0232-00		RES,FXD,FILM:2.55K OHM,1%,0.125W,TC=TO	19701	5043ED2K550F
A2R743	315-0112-00		RES, FXD, FILM:1.1K OHM, 5%, 0.25W	19701	5043CX1K100J
A2R744	311-2232-00		RES, VAR, NONWW: TRMR, 2K OHM, 20%, 0.5W LINEAR	TK1450	GF06UT 2K
A2R745	315-0681-00		RES, FXD, FILM:680 OHM, 5%, 0.25W	57668	NTR25J-E680E
A2R756	315-0203-00		RES, FXD, FILM: 20K OHM, 5%, 0.25W	57 668	NTR25J-E 20K
A2R757	321-0272-00		RES, FXD, FILM: 6.65K OHM, 1%, 0.125W, TC=T0	19701	5043ED6K650F
A2R758	321-0207-00		RES, FXD, FILM: 1.40K OHM, 1%, 0.125W, TC=T0	19701	5033ED1K400F
A2R761	321-0240-00		RES, FXD, FILM: 3.09K 0HN, 1%, 0.125W, TC=T0	07716	CEAD30900F
A2R762	321-0240-00		RES, FXD, FILM: 3.09K OHM, 1%, 0.125W, TC=TO	07716	CEAD30900F
A2R763	321-0207-00		RES, FXD, FILM: 1.40K OHM, 1%, 0.125W, TC=T0	19701	5033ED1K400F
A2R765	315 -0 623- 00		RES, FXD, FILM: 62K OHM, 5%, 0.25W	19701	5043CX62K00J
A2R766	315-0203-00		RES,FXD,FILM:20K OHM,5%,0.25W	5 76 68	NTR25J-E 20K
A2R767	315-0820-00		RES,FXD,FILM:82 OHM,5%,0.25W	57668	NTR25J-E82E0
A2R768	321-0214-00		RES.FXD.FILM:1.65K 0HM.1%.0.125W.TC=T0	19701	5033ED1K65F
A2R769	315-0512-00		RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
A2R770	321-0214-00		RES. FXD. FILM: 1.65K OHM. 1%.0.125W. TC=TO	19701	5033ED1K65F
A2R771	321-0133-00		RES, FXD, FILM: 1:00X 01M, 1%, 0:125W, TC=T0	07716	CEAD237ROF
A2R772 A2R773	321-0133-00 321-0133-00		RES,FXD,FILM:237 OHM,1%,0.125W,TC=T0 RES,FXD,FILM:237 OHM,1%,0.125W,TC=T0	07716 07716	CEAD237ROF CEAD237ROF
100774					
A2R774	321-0133-00		RES, FXD, FILM: 237 OHM, 1%, 0.125W, TC=T0	07716	CEAD237ROF
A2R777	311-2355-00		RES, VAR, NONWY: TRMR, 100 OMM, 20%, 0.5W	K8788	TC10-LV10-100R/A
A2R780	321-0261-00		RES, FXD, FILM: 5.11K OHM, 1%, 0.125W, TC=T0	197 01	5033ED5K110F
A2R782	311-2363-00		RES, VAR, NONWW: TRMR, 1K OHM, 0.5W	K8788	TC10-LV10-1K/A
A2S701	260-2408-00		SWITCH, ROTARY: 4 POLE, 22 POS	80009	260-2408-00
A2U30	156-0534-00		MICROCKT, LINEAR: DUAL DIFF AMPL	02735	CA3102E-98
A2U80	156-0534-00		MICROCKT, LINEAR: DUAL DIFF AMPL	02735	CA3102E-98
A2U83	156-2902-00		MICROCKT, LINEAR, DUAL DIFF AMPL	K5856	CA 3046
A2U715	156-0067-00		MICROCKT, LINEAR: BIPOLAR, OPNL AMPL	04713	MC1741CP1
A2U745	156-2902-00		MICROCKT, LINEAR:	K5856	CA 3046
A2U755	156-2902-00		MICROCKT, LINEAR:	K5856	CA 3046
A2VR704	152-0571-00		SEMICOND DVC, DI:ZEN, SI, 16V, 5%, 0.4W, DO-7	04713	SZG35014KIRL
A2VR710	152-0571-00		SEMICOND DVC, DI: ZEN, SI, 16V, 5%, 0.4W, DO-7	04713	SZG35014KIRL
A2VR719	152-0217-00		SEMICOND DVC, DI:ZEN, SI, 8.2V, 5%, 0.4W, DO-7	04713	SZG20
2W711	131-0566-00		BUS, CONDUCTOR: DUMMY RES, 0.094 OD X 0.225 L	24546	OMA 07
12-17/11	101-0000-00		555,001005101.00111 Nu3,0.034 UD A 0.223 L	L-1J-10	

<u>Component No.</u>	Tektronix Part <u>No</u> .	Serial/Assembly No. Effective Dscont	Name & Description	Mfr. Code	Mfr. Part No.
A2W742 A2W752	131-0566-00 131-0566-00		BUS,CONDUCTOR:DUMMY RES,0.094 OD X 0.225 L BUS,CONDUCTOR:DUMMY RES,0.094 OD X 0.225 L		oma 07 oma 07

¢

<u>Component No.</u>	Tektronix Part No.	Serial/Assembly No. Effective Discont	Name & Description	Nfr. Cod <u>e</u>	Mfr. Part No.
A3	671-0392-00		CIRCUIT BD ASSY: FRONT PANEL	80009	671-0392-00
A3C2	285-1106-00		CAP, FXD, PLASTIC: 0.022UF, 20%, 600V	14752	230B1F223
A3C52	285-1106-00		CAP, FXD, PLASTIC: 0. 022UF, 20%, 600V	14752	230B1F223
A3C377	285-1385-00		CAP, FXD, PLASTIC: 43PF, 2.5%, 630V	K7779	B31063-A6430-H6
A3C378	285-1386-00		CAP, FXD, PLASTIC:390PF, 2.5%, 630V	K7779	B31063-A6391-H6
A3C383	285-1385-00		CAP, FXD, PLASTIC: 43PF, 2.5%, 630V	K7779	B31063-A6430-H6
A3C392	281-0815-00		CAP. FXD. CER DI: 0.027UF.20%.50V	04222	MA205C273MAA
A3CR401	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
3CR534	152-0141-02		SEMICOND DVC.DI:SW.SI.30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
					DAZ 327 (114132)
3CR537	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
3CR538	152-0141-02		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
3DS370	150-1187-00		LT EMITTING DID:GREEN	TK00A	LN31GPHLEXLED5GS
3DS560	150-1187-00		LT EMITTING DIO:GREEN	TK00A	LN31GPHLEXLED5GS
3R2	315-0105-00		RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J
3R4	315-0100-00		RES, FXD, FILM: 10 OHM, 5%, 0.25W	19701	5043CX10RR00J
3R52	315-0105-00		RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J
3R54	315-0100-00		RES,FXD,FILM:10 0HM,5%,0.25W	19701	5043CX10RR00J
3R84	311-2368-00		RES, VAR, NONWW: TRMR, 47K OHM, 0.5W	K8788	TC10-LV10-47K/A
3R89	315-0222-00		RES.FXD.FILM:2.2K 0HM.5%.0.25W	57668	NTR25J-E02K2
3R92	315-0333-00		RES, FXD, FILM: 33K OHM, 5%, 0.25W	57668	NTR25J-E33K0
3R94	315-0333-00		RES, FXD, FILM: 33K OHM, 5%, 0.25W	57668	NTR25J-E33K0
3R113	321-0251-00		RES, FXD, FILM: 4.02K OHM, 1%, 0.125W, TC=T0	19701	5033ED4K020F
3R123	311-2366-00		RES, VAR, NONWA: PNL, 470 OHM, 20%, 0.2W	K8996	PP17/000HFAQA234
3R163	321-0251-00		RES, FXD, FILM: 4.02K OHM, 1%, 0.125W, TC=T0	19701	5033ED4K020F
3R173	311-2366-00		RES, VAR, NONWW: PNL, 470 OHM, 20%, 0, 2W	K8996	PP17/000HFAQA234
3R365	315-0621-00		RES, FXD, FILM: 620 OHM, 5%, 0.25W	57668	NTR25J-E620E
3R376	315-0101-00		RES, FXD, FILM:100 0HM, 5%, 0.25W	57668	NTR25J-E 100E
3R377	315-0394-00		RES, FXD, FILM: 390K OHM, 5%, 0.25W	57 66 8	NTR25J-E390K
3 R3 78	315-0433-00		RES, FXD, FILM: 43K OHM, 5%, 0.25W	19701	5043CX43K00J
3R379	315-0470-00		RES, FXD, FILM: 47 OHM, 5%, 0.25W	57668	NTR25J-E47E0
3R383	315-0564-00		RES, FXD, FILM: 560K 0HM, 5%, 0.25W	19701	5043CX560K0J
3R426	311-2366-00		RES, VAR, NONW: PNL, 470 OHM, 20%, 0.2W	K8996	PP17/000HFAQA234
3R726	311-2366-00		RES, VAR, NONWW: PNL, 470 OHM, 20%, 0.2W	K8996	PP17/000HFAQA234
3R800	315-0682-00		RES, FXD, FILM: 6.8K OHM, 5%, 0.25W	57668	NTR25J-E06K8
3R802	311-2359-00		RES, VAR, NONWA: PNL, 10K OHM, 20%, 0.2W	K8996	PP17000HGA0A4110
3R986	311-2364-00		RES, VAR, NONWAY: TRMR, 4.7K OHM, 0.5W	K8788	TC10-LV10-4K7/A
20007	215 0001 00		RES.FXD.FILM:200 0HM.5%.0.25W	E7660	
3R987	315-0201-00			57668	NTR25J-E200E
3590	260-2291-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TK 2 POS
3S101	260-2293-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 3 POS
S201	260-2293-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 3 POS
35390	260-2290-00		SWITCH, PUSH: 1 BUTTON, 1 POLE, MOMENTARY	TKOEA	SKECCAA061A
\$392	260-2292-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 4 POS
5401	250 2202 00		SUITCH SI THE DONT SECURA 100MAC	112771	ENT/TEK A DOC
3S401	260-2292-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 4 POS
S460	260-2291-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TK 2 POS
S505	260-2290-00		SWITCH, PUSH: 1 BUTTON, 1 POLE, MOMENTARY	TKOEA	SKECCAA061A
\$545	260-2293-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 3 POS
\$550	260-2293-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 3 POS
\$555	260-2292-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TEK 4 POS
0.001	000 0001 00			112224	607 /TV 0 000
35601	260-2291-00		SWITCH, SLIDE: DPDT, 250MA, 100VAC	U3771	607/TK 2 POS
BW1	174-0639-00		CA ASSY, SP, ELEC: 6, 26 AWG, 110MM L, RIBBON	TKOEM	82026- 580 6(95mm)
W2	174-0638-00		CA ASSY, SP, ELEC: 6, 26 AWG, 165MM L, RIBBON	TKOEM	82265806(165mm)
W3	174-0639-00		CA ASSY, SP, ELEC: 6, 26 AWG, 110MM L, RIBBON	TKOEM	82026-5806(95mm)
W5			CA ASSY, SP, ELEC: 6, 26 AWG, 110MM L, RIBBON	TKOEM	82026-5806(95mm)
₩6	174-0639-00 174-0635-00		CA ASSY, SP, ELEC: 6, 26 AWG, 110MM L, RIBBON	TKOEM	82265806(120mm)
3W7	174-0638-00		CA ASSY, SP, ELEC: 6, 26 AWG, 165MM L, RIBBON	TKOEM	82265806(165mm)

.			nbly No.		Mfr.	
<u>Component No.</u>	Part No.	Effective	Dscont	Name & Description	_Code	Mfr. Part No.
A4	671-0391-00			CIRCUIT BD ASSY:MAIN INPUT	80009	671-0391-00
A4C900	290-1201-00			CAP, FXD, ELCTLT: 2200UF, 100V, 30 X 35MM	TK0900	
A4C903	285-1192-00			CAP, FXD, PPR DI:0.0022 UF, 20%, 250VAC	TK0515	PME271Y510
A4C904	285-1192-00			CAP, FXD, PPR DI: 0.0022 UF, 20%, 250VAC	TK0515	PME271Y510
A4C905	285-1252-00			CAP, FXD, PLASTIC:0.15UF, 10%, 250VAC	D5243	F1772-415-2000
A4C907	283-0057-00			CAP, FXD, CER DI:0.1UF, +80-20%, 200V	04222	SR306E104ZAA
A4CR901	152-0066-00			SEMICOND DVC, DI: RECT, SI, 400V, 1A, DO-41	05828	GP10G-020
A4CR902	152-0066-00			SEMICOND DVC, DI:RECT, SI, 400V, 1A, DO-41	05828	GP10G-020
A4CR903	152-0066-00			SEMICOND DVC, DI: RECT, SI, 400V, 1A, DO-41	05828	GP10G-020
A4CR904	152-0066-00			SEMICOND DVC, DI: RECT, SI, 400V, 1A, DO-41	05828	GP10G-020
A4J901	131-3905-00			CONN, RCPT, ELEC: PWR, 250VAC, 6A, CKT BD MT	TKODY	L2157
A4L901	108-1375-00			COIL, RF: FXD, 82UH, 1A	TKOOA	RL-1218-820K-1A
A4L902	108-1375-00			COIL, RF: FXD, 82UH, 1A	TK00A	RL-1218-820K-1A
A4P9 0 2				(PART OF T901)		
A4Q900	15 1-0350-00			TRANSISTOR: PNP, SI, TO-92	04713	SPS6700
A4R902	315 -047 3- 0 0			RES, FXD, FILM: 47K OHM, 5%, 0.25W	5 766 8	NTR25J-E47K0
A4R9 0 3	315 -0 243- 0 0			RES, FXD, FILM: 24K DHM, 5%, 0.25W	5 766 8	NTR25J-E24K0
A4R904	315- 0562- 00			RES,FXD,FILM:5.6K OHM,5%,0.25W	57668	NTR25J-E05K6
A4R905	315- 0104- 00			RES, FXD, FILM: 100K OHM, 5%, 0.25W	5 766 8	NTR25J-E100K
A4R906	315- 01 05 -0 0			RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J
A4R907	315-0510-00			RES, FXD, FILM: 51 OHM, 5%, 0.25W	197 01	5043CX51R00J
A4S901	260-1849-05			SWITCH, PUSH: DPDT, 4A, 250VAC, W/BRACKET	31918	NE-15 SERIES
A4S902	260-2116-00			SWITCH, SLIDE: DPDT, 10A, 125VAC, LINE SEL	04426	18-000-0019
A4W903	174-0636-00			CA ASSY, SP, ELEC: 3, 26 AWG, 150MM L, RIBBON	TKOEM	82265803(150mm)

ι

<u>Component No.</u>	Tektronix <u>Part No.</u>	Serial/Asse Effective	mbly No. Dscont_	Name & Description	Mfr. _Code	Mfr. Part_No
FS901 J100 J151 J300 J590 R1	159-0042-00 131-0955-00 131-0955-00 131-0955-00 131-3898-00 315-0470-00			FUSE, CARTRIDGE: 3AG, 0.75A, 250V, 0.15SEC CONN, RCPT, ELEC: BNC, FEMALE CONN, RCPT, ELEC: BNC, FEMALE CONN, RCPT, ELEC: BNC, FEMALE TERM, FEEDTHRU: 0.658 M X 0.75 DIA, BRS, AU PL RES, FXD, FILM: 47 OHM, 5%, 0.25W	75915 13511 13511 13511 K0491 57668	312.750 31-279 31-279 31-279 001-1401-041140P NTR25J-E47E0
R51 R382 R893 R893 T901	315-0470-00 315-0470-00 311-2357-00 311-2444-00 120-1787-00	HK10100 HK11184	HK11183	RES,FXD,FILM:47 OHM,5%,0.25W RES,FXD,FILM:47 OHM,5%,0.25W RES,VAR,NONWW:PNL,2.2M OHM,20%,0.25W RES,VAR,NONWW:TRMR,2.2,30%,0.25W,PLASTIC SI DE ADJ,LINEAR XFMR,PWR,STPDN:LOW FREQUENCY	57668 57668 TK00C 80009 80009	NTR25J-E47E0 NTR25J-E47E0 ORDER BY DESCR 311-2444-00 120-1787-00
V900	154-0929-00			ELECTRON TUBE:CRT, W/TRACE	80009	154-0929-00

¢

DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS

Symbols

Graphic symbols and class designation letters are based on ANSI Standard Y32.2-1975.

Logic symbology is based on ANSI/IEEE 91-1984. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

The overline on a signal name indicates that the signal performs its intended function when it is in the LO state.

Abbreviations are based on ANSI Y1.1-1972.

Other ANSI standards that are used in the preparation of diagrams by Tektronix, Inc., are:

Y14.15-1966 Y14.2M-1979 ANSI/IEEE 280-1985	Drafting Practices. Line Conventions and Lettering. Letter Symbols for Quantities Used in Electrical Science and Electrical Engineering.
	lational Standards Institute 1430 Broadway

New York, New York 10018

Component Values

Electrical components shown on the diagrams are in the following units unless noted otherwise:

The information and special symbols below may appear in this manual.-

Assembly Numbers and Grid Coordinates

Each assembly in the instrument is assigned an assembly number (e.g., A20). The assembly number appears on the circuit board outline on the diagram, in the title for the circuit board component location illustration, and in the lookup table for the schematic diagram and corresponding component locator illustration. The Replaceable Electrical Parts list is arranged by assemblies in numerical sequence; the components are listed by component number *(see following illustration for constructing a component number). The schematic diagram and circuit board component location illustration have grids. A lookup table with the grid coordinates is provided for ease of locating the component. Only the components illustrated on the facing diagram are listed in the lookup table. When more than one schematic diagram is used to illustrate the circuitry on a circuit board, the circuit board illustration may only appear opposite the first diagram on which it was illustrated; the lookup table will list the diagram number of other diagrams that the circuitry of the circuit board appears on.



Scans by ArtekMedia © 2006



		DECIG	TOPS
COLOR	SIGNIFICANT		STORS
	FIGURES	MULTIPLIER	TOLERANCE
BLACK	0	1	
BROWN	1	10	±1%
RED	2	10 ² or 100	±2%
ORANGE	3	10 ³ or 1 K	±3%
YELLOW	4	10 ⁴ or 10 K	±4%
GREEN	5	10 ⁵ or 100 K	±½%
BLUE	6	10 ⁶ or 1 M	±1/4%
VIOLET	7		±1/10%
GRAY	8		
WHITE	9		
GOLD	_	10 ⁻¹ or 0.1	±5%
SILVER	_	10 ⁻² or 0.01	±10%
NONE	_		±20%
	·		(1001 004)0004 05

(1861-20A)6081-95

Figure 9-1. Color codes for resistors.

Scans by ArtekMedia © 2006

SECTION 9-DIAGRAMS



Figure 9-2. Semiconductor lead configurations.

6716-17

Scans by ArtekMedia © 2006

Digitally Remastered by ArtekMedia © 2002-2006

2205 Service

To identify any component mounted on a circuit board and to locate that compo-

nent in the schematic diagram.

- 1. Locate the Circuit Board Illustration.
 - a. Identify the Assembly Number of the circuit board that the component is on by using the Circuit Board location illustration in this section or the mechanical parts exploded views at the rear of this manual.
 - b. In the manual, locate the tabbed foldout page that corresponds with the Assembly Number of the circuit board. The circuit board assembly numbers and names are printed on the back side of the tabs (facing the rear of the manual).

- 2. Determine the Circuit Number and Schematic Diagram.
 - a. Compare the circuit board with its illustration. Locate the component you are looking for by area and shape on the illustration to determine its Circuit Number.
 - b. Scan the lookup table next to the Circuit Board illustration to find the Circuit Number of the component.
 - c. Read the SCHEM NUMBER column next to the component's circuit number to find the Schematic Diagram number.



1. Determine the Circuit Board Illustration and Component Location.

- To identify any component in a schematic diagram and to locate that component on its respective circuit board.
- a. From the schematic diagram, determine the Assembly Number of the circuit board that the component is on. The Assembly Number and Name is boxed and located in a corner of the heavy line marking the circuit board outline in the schematic diagram.
- b. Find the Component Location table for the Assembly Number found on the schematic. Scan the CIRCUIT NUMBER column to find the Circuit Number of the component.
- Look in the BOARD LOCATION column next to the component number and read its circuit board grid coordinates.

- 2. Locate the Component on the Circuit Board.
 - a. In the manual, locate the tabbed page that corresponds to Assembly Number the component is on. Assembly numbers and names for circuit boards are on the back side of the tabs.

bo d. Fi

Using the Circuit Number of the component and its given grid location, find the component in the Circuit Board illustration.

- 3. Locate the Component on the Schematic Diagram.
 - a. Locate the tabbed page that corresponds to the Schematic Diagram nun ber. Schematic diagram numbers and names are printed on the front sid of the tabs (facing the front of the manual).
 - b. Locate the Assembly Number in the Component Location lookup tab next to the schematic diagram. Scan the CIRCUIT NUMBER column of that table to find the Circuit Number of the component you are looking for in the schematic.

c. From the small circuit board location illustration shown next to the circuit board, find the circuit board's location in the instrument.

d. Find the circuit board in the instrument. Compare it with the circuit board illustration in the manual to locate the component on the circuit board itself.

Digitally Remastered by ArtekMedia @ 2002-2006



2. Locate the Component on the Circuit Board.

- e cirne is oard n the lum-
- a. In the manual, locate the tabbed page that corresponds to Assembly Number the component is on. Assembly numbers and names for circuit boards are on the back side of the tabs.
 - b. Using the Circuit Number of the component and its given grid location, find the component in the Circuit Board illustration.
- c. From the small circuit board location illustration shown next to the circuit board, find the circuit board's location in the instrument.
- d. Find the circuit board in the instrument. Compare it with the circuit board illustration in the manual to locate the component on the circuit board itself.

nber

c. In the SCHEM LOCATION column next to the component, read the grid

d. Using the grid coordinates given, find the component in the schematic







FIG. 9-4

6716-18

2205 Service



	A3—I	FRONT P	ANEL BO	OARD	
CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHE NUME
C2	1	R84	6	S101	6
C2	6	R89	1	S201	1
C52	1	R89	6	S201	6
C52	6	R92	1	S390	6
C377	6	R92	6	S392	6
C378	6	R94	1	S401	6
C383	6	R94	6	S460	6
C392	6	R113	2	S505	4
		R113	6	S505	6
CR401	6	R123	2	S545	2
CR534	2	R123	6	S545	6
CR534	6	R163	2	S550	2
CR537	2	R163	6	S550	6
CR537	6	R173	2	S555	6
CR538	2	R173	6	S601	6
CR538	6	R365	6		
-		R376	6	W1	2
DS370	6	R377	6	W1	4
DS560	4	R378	6	W1	6
DS560	6	R379	6	W2	2
	-	R383	6	W2	6
J987	6	R426	3	W3	3
		R426	6	W3	6
R2	1	R726	6	W3	8
R2	6	R800	6	W5	· 4
R4	1	R802	6	W5	6
R4	6	R986	6	W6	4
R52	1	R987	6	W6	6
R52	6			W7	1
R54	1	S90	1	W7	6
R54	6	S90	6		_
R84	1	S101	1		







COMPONENT NUMBER EXAMPLE



prefix—see end of Replaceable Electrical Parts List.

Ř

VOLTAGE/WAVEFORM SETUP CONDITIONS

WAVEFORMS

On the left-handed pages preceding the schematic diagrams are test waveform illustrations that are intended to aid in troubleshooting the instrument. To test the instrument for these waveforms, perform the Initial Measurements Setup procedure first. Changes to the Initial Measurement Setup are noted at the beginning of each set of waveforms.

DC VOLTAGES

Typical voltage measurements located on the schematic diagrams were obtained with the instrument operating under the conditions specified in the Initial Measurements Setup procedure. Controlsetting changes required for specific voltages are indicated on each waveform page. Voltage measurements are referenced to the chassis ground.

INITIAL MEASUREMENTS SETUP

To test the instrument for waveforms and voltages, set the initial control settings as follows:

Vertical (Both Channels)

POSITION MODE VOLTS/DIV VOLTS/DIV Variable AC-GND-DC Midrange CH 1, NORM 5 mV CAL detent GND Horizontal

POSITION	Midrange
MAG	X1
SEC/DIV	0.2 ms
SEC/DIV Variable	CAL detent
Trigger	
0.005	D 111 (–

SLOPEPositive (___)MODEP-P AUTOSOURCEVERT MODE

RECOMMENDED TEST EQUIPMENT

Test equipment in Table 4–1 in the Performance Check Procedure, Section 4, of this manual meets the required specifications for testing this instrument.

POWER SUPPLY ISOLATION PROCEDURE

Each regulated supply has numerous feed points to external loads through the instrument. Diagram 8, power distribution, is used in conjunction with the schematic diagrams to determine the service jumper or component that may be lifted to isolate loads from the power supply.

If a supply comes up after lifting one of the isolating jumpers, it is very probable that short exists in the circuitry on that supply line. By lifting jumpers or other components in the supply line farther down the line, the circuit in which a short exists may be located.

Always set the POWER switch to OFF before soldering or unsoldering service jumpers or other components and before attempting to measure component resistance values.

OTHER PARTS										
CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER					
J100 J100 J151 J151 J300 J590	1 6 6 4	P902 P906 P910 R1 R1 R51	7 7 1 6 1	R51 R382 R983 T901 V900	6 6 7 7 7					

ι



CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER		SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER
AT1	1	E90	8	R30	1	R729	5
AT1	6	E91	1	R31	1	R732	5
AT51	1	E91	8	R32	1	R733	5
AT51	6	E92	1	R33	1	R734	5
		E92	8	R35	1	R735	5
C6	1	E93	1	R36	1	R736	5
C13	1	E93	8	R37	1	R737	5
C30	1			R38	1	R738	5
C31	1	J7	1	R39	1	R740	5
C35	1	J7	5	R41	1	R741	5
C38	1	J7	6	R42	1	R743	5
C56	1	J30	1	R53	1	R744	5
C63	1	J80	1	R53	6	R745	5
C80	1	J90	1	R55	1	R756	5
C81	1	J90	5	R56	1	R757	5
C85	1	J90	8	R63	1	R758	5
C88	1	J701	5	R64	1	R761	5
C93	1	J755	5	R65	1	R762	5
C94	1			R72	1	R763	5
C95	1	L93	1	R73	1	R765	5
C96	1	L96	Ť	R78	1	R766	5
C97	1	L712	5	R79	1	R767	5
C98	1	L712	8	R80	1	R768	5
C701	5	L713	5	R81	1	R769	5
C702	5	L713	8	R82	1	R770	5
C703	5			R83	1	R771	5
C704	5	Q13	1	R85	1	R772	5
C705	5	Q14	1	R86	1	R773	5
C706	5	Q63	1	R87	1	R774	5
C708	5	Q64	1	R88	1	R777	5
C709	5	Q701	5	R91	1	R780	5
C710	5	Q704	5	R701	5	R782	5
C712	5	Q706	5	R702	5		
C713	5	Q725	5	R703	5	S701	5
C715	5	Q732	5	R704	5		
C722	5	Q736	5	R705	5	U30	1
C723	5	Q737	5	R710	5	U80	1
C724	5	Q750	5	R715	5	U83	1
C727	5	Q759	5	R716	5	U715	5
C733	5	Q760	5	R717	5	U745	5
C755	5			R718	5	U755	5
C767	5	R3	1	R719	5		
		R3	6	R720	5	VR710	5
CR758	5	R5	1	R721	5	VR719	5
CR761	5	R6 •	1	R722	5		
CR762	5	R13	1	R723	5	W711	5
CR769	5	R14	1	R724	5	W742	5
CR773	5	R15	1	R725	5	W752	5
CR774	5	R22	1	R726	5		
		R23	1	R727	5		
E90	1	R29	1	R728	5		



Chassis-mounted components have no Assembly Number prefix—see end of Replaceable Electrical Parts List.

A2-TIME BASE/ATTENUATOR BOARD

VERTICAL ATTENUATORS DIAGRAM 1

ASSEM	BLY A2										
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION
AT1 AT51 C6 C13 C30 C31 C35 C38 C56 C63 C80 C81 C85 C81 C85 C83 C94 C95 C94 C95 C97 C98 E90	1D 4D 1E 3F 4H 4E 4F 6F 7G 8J 7C 7C 8B 8C 7C	5B 5D 4B 5B 2A 3A 2A 2B 4D 5C 2C 3C 2C 2C 1B 1B 1C 1B 1C 1B	E91 E92 E93 J7 J7 J30 J80 J90 L93 L96 O13A Q13B Q14 Q63A Q63B Q64 R3 R5 R6	7C 7C 8C 7E 8G 1L 5L 7B 7B 7B 7B 7B 7B 7B 7B 7B 75 5F 5F 5F 5E 2C 2D 2E	1C 1B 1B 2D 2D 2A 2C 1C 1B 1C 4B 4B 4C 4C 4C 4C 5B 4B 4B 4B	R13 R14 R15 R22 R23 R30 R31 R32 R33 R35 R36 R37 R38 R37 R38 R37 R38 R37 R38 R39 R41 R42 R53 R55 R55 R56 R63 R64	1F 2F 3F 2F 3F 2F 3F 3F 3D 4G 3H 4J 4J 4J 4G CDE F 5 5 F 5 F 5	5B 4A 4B 3B 2B 3A 2A 1B 2B 4B 1B 3B 2B 3B 2B 5D 4D 4C 5C 4C	R65 R72 R73 R78 R80 R81 R82 R83 R85 R86 R86 R87 R88 R91 U30 U80 U83A U83D U83D U83C	6F 6F 5F 6E 6F 6G 6E 6G 6C 7G 6H 7J 7H 1G 5H 5H 2H 4K	4C 4C 2D 3C 2C 2C 2C 2C 4C 2C 3C 3C 3C 3C 3C 3C 3B 2B 2B 2B 2B 2B 2B 2B
ASSEM		agrams 5, 6 and	8.								
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
C2 C52 R2 R4	2B 5B 2B 2B	4C 4C 4B 4B	R52 R54 R84 R89	5B 5B 8E 7F	4C 4C 3C 2C	R92 R94 S90	8F 7F 8E	2D 2C 2C	S101 S201 W7	2C 5C 7F	3B 3C 3D
Partial A3 a	lso shown on di	agrams 2, 3, 4, 6	and 8.								
CHASSI	S MOUNTE	D PARTS									
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
J100	2A	CHASSIS	J151	5A	CHASSIS	R1 ^٤	2B	CHASSIS	R51	5B	CHASSIS

•

•

.

.

Digitally Remastered by ArtekMedia © 2002-2006



Digitally Remastered by ArtekMedia © 2002-2006





COMPONENT NUMBER EXAMPLE





Figure 9-8. A1—Main board component view.

6716-22

				ļ	1— MA II	N BOARI)				
CIRCUIT NUMBER	SCHEM NUMBER										
C114	2	C794	5	CR781	5	Q165	2	R126	2	R246	2
C115 C116	2 2	C795 C799	5 5	CR790 CR791	5 5	Q202 Q203	2	R127 R130	2 2	R247 R248	2 2
C124	2	C824	7	CR817	7	Q206	2	R131	2	R249	2
C125	2	C828	7	CR818	7	Q207	2	R132	2	R250 R251	2 2
C126 C130	2 2	C832 C834	7 7	CR820 CR824	7 7	Q230 Q231	2 2	R133 R135	2	R251	2
C133	2	C835	7	CR825	7	Q232	2	R136	2	R253	2
C164	2	C845	7	CR827	7	Q234	2	R139 R140	2	R258 R260	2 2
C165 C174	2 2	C847 C849	7 7	CR828 CR829	7 7	Q236 Q237	2	R140 R142	2	R260	8
C175	2	C851	7	CR840	7	Q238	2	R143	2	R262	5
C176	2	C853	7	CR845	7	Q239	2	R144	2	R263 R264	2 2
C180 C198	2 2	C854 C855	7 7	CR851 CR853	7 7	Q370 Q371	3 3	R145 R150	2	R265	2
C202	2	C871	7	CR854	7	Q400	3	R151	2	R266	2
C215	2	C875	7	CR855	7	Q401	3	R152	2	R267	2
C220 C225	2 2	C893 C901	7 7	CR933 CR941	7 7	Q410 Q411	3	R153 R154	2	R268 R269	2 2
C232	2	C902	7	CR942	7	Q412	3	R155	2	R280	2
C235	2	C914	7	CR945	7	Q415	3	R156	2	R300	3
C239 C240	2 2	C915 C920	7 7	CR946 CR947	7 7	Q450 Q451	3 3	R158 R159	2	R301 R302	3 3
C240 C241	2	C920 C925	7	CR947 CR950	7	Q451 Q452	3	R161	2	R303	3
C242	2	C930	7	CR975	7	Q453	3	R161	8	R304	3
C243	2 2	C932	7 7	CR976 CR980	7 7	Q465 Q487	3 3	R162 R162	2 8	R305 R306	3 3
C245 C246	2	C933 C935	7	CR981	7	Q488	3	R164	2	R308	3
C247	2	C941	7	CR982	7	Q489	3	R165	2	R309	3
C248	2	C942	7	CR983	7 7	Q490 Q535	3 4	R166 R167	2	R310 R310	3 8
C320 C321	3 3	C943 C945	7 7	CR984 CR985	7	Q535 Q536	4	R167	2	R310	3
C322	3	C946	7	CR986	7	Q770	5	R169	2	R311	8
C380	3	C952	7	CR987	7 7	Q775 Q776	5 5	R170 R171	2	R312 R312	3 8
C381 C387	3 3	C974 C976	7 7	CR988 CR989	7	Q779	5	R171	2	R316	3
C389	3	C979	7	CR990	7	Q780	5	R174	2	R317	3
C401	3	C980	7	CR991	7	Q785	5	R175	2	R318	3
C402 C408	3 3	C982 C983	7 7	DS856	7	Q789 Q804	5 7	R176 R177	2	R319 R320	3 3
C408 C418	3	C984	7	DS858	7	Q817	7	R180	2	R322	3
C431	3	C985	7			Q818	7	R181	2	R323	3
C480 C481	3 3	C986 C987	7 7	J1 J1	2 4	Q825 Q829	7 7	R182 R183	2	R325 R326	3
C489	3	C988	7	J1	6	Q835	7	R185	2	R329	3
C490	3	C989	7	J2	2	Q840	7	R186	2	R330	3
C495	3 3	C990 C991	7 7	J2 J3	6 3	Q845 Q932	7 7	R189 R192	2 2	R331 R332	3 3
C496 C500	4	C991 C992	7	J3	6	Q933	7	R193	2	R333	3
C501	4			J3	8	Q935	7	R194	2	R334	3
C503	4	CR133	2	J5	4 6	Q939 Q941	7 7	R195 R202	2	R335 R336	3
C505 C506	4	CR136 CR139	2	J5 J6	4	Q941 Q942	7	R202 R203	2	R336 R337	3
C520	4	CR183	2	J6	6	Q943	7	R204	2	R338	3
C525	4	CR186	2	1 201		Q945 Q946	77	R206 R207	2 2	R339 R340	3 3
C530 C536	4 2	CR189 CR265	2 2	L321 L322	2 2	Q946 Q982	7	R207 R212	2	R340 R343	3
C537	2	CR266	2	L950	7	Q985	7	R213	2	R344	3
C538	2	CR300	3	L986	7	Q988	7	R215	2 2	R350	3 3
C539 C540	2 2	CR301 CR302	3 3	L988 L990	7 7	R100	2	R216 R217	2	R351 R352	3
C540	2	CR319	3			R101	2	R218	2	R353	3
C547	2	CR344	3	P900	7	R102	2	R219	2	R354	3 3
C550 C554	4 4	CR348 CR349	3 3	P901 P902	7 7	R103 R104	2 2	R220 R221	2 2	R356 R357	3
C554 C555	4	CR381	3	P903	7	R105	2	R222	2	R358	3
C560	4	CR417	3	P904	2	R106	2	R223	2	R359	3
C561 C562	2 2	CR431 CR450	3 3	P905	5	R108 R109	2 2	R225 R226	2 2	R360 R361	3 3
C562 C570	4	CR450	3	Q102	2	R114	2	R232	2	R362	3
C571	4	CR452	3	Q103	2	R115	2	R233	2	R363	3
C572	4	CR521	4	Q104 Q105	2 2	R116 R117	2 2	R235 R237	2 2	R364 R366	3 3
C584 C587	4 4	CR530 CR539	4	Q105 Q114	2	R117	2	R237	2	R367	3
C776	5	CR540	4	Q115	2	R119	2	R239	2	R368	3
C780	5	CR571	4	Q152	2 2	R120	2 2	R241 R242	2 2	R369 R370	3 3
C782 C783	5 5	CR584 CR588	4	Q153 Q154	2	R121 R122	2	R242 R243	2	R370 R371	3
C785	5	CR589	4	Q155	2	R124	2	R244	2	R372	3
C789	5	CR780	5	Q164	2	R125	2	R245	2	R373	3

Scans by ArtekMedia © 2006

. .

				A1–	-MAIN B	OARD (c	ont)				
CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER		SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER		SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER
R374	3	R491	3	R562	4	R830	7	R936	7	U540	2
R380	3	R492	3	R563	4	R832	7	R939	7	U540	4
R381	3	R493	3	R564	4	R834	7	R940	7	U550	4
R389	3	R495	3	R565	4	R835	7	R941	7	U560	2
R394	3	R496	3	R566	2	R836	7	R942	7	U560	4
R395	3	R497	3	R567	2	R840	7	R943	7	U570	4
R396	3	R498	3	R570	4	R841	7	R944	7	U580	4
R400	3	R501	4	R571	4	R842	7	R945	7	U910	7
R401 R402	3 3	R502 R503	4	R572 R573	4	R843 R844	7	R946 R947	7	U920	7
R402 R403	3	R503	4	R574	4	R845	7	R947 R948	7	U930	
R403 R404	3	R504 R505	4	R576	4	R845 R849	7	R948 R949	7	U940	7
R404 R405	3	R505	4	R576 R579	4	R849 R850	7	R949 R955	7	VR776	5
R405 R406	3	R508	4	R581	4	R850 R851	7	R955 R956	7	VR792	5
R406 R407	3	R512	4	R582	4	R852	7	R956 R957	7	VR/92 VR915	5
R407 R408	3	R512 R515	4	R582 R583	4	R853	7	R957 R958	7	VR915 VR925	7
R408 R409	3	R515 R517	4	R584	4	R854	7	R958	7	VR925 VR932	7
R403	3	R518	4	R585	4	R855	7	R971	7	VR933	7
R411	3	R520	4	R586	4	R858	7	R972	7	VR982	7
R412	3	R521	4	R587	4	R860	7	R977	7	VR985	7
R413	3	R522	4	R588	4	R870	7	R978	7	VR988	7
R414	3	R523	4	R589	4	R871	7	R979	7	VH300	,
R415	3	R524	4	R590	4	B874	7	R980	7	W30	2
R416	3	R525	4	R775	5	R875	7	R981	7	W80	2
B417	3	R526	4	B776	5	R888	7	R982	7	W90	7
R418	3	R530	4	R778	5	R889	7	R983	7	W90	8
R419	3	R531	4	R779	5	R890	7	R984	7	W224	2
R426	3	R532	3	R780	5	R891	7	R985	7	W225	2
R427	3	R532	4	R781	5	R892	7	R986	7	W500	4
R428	3	R533	4	R783	5	R894	7	R987	7	W590	4
R429	3	R534	4	R784	5	R899	7	R988	7	W701	4
R430	3	R535	4	R785	5	R900	7	R989	7	W755	5
R431	3	R536	4	R786	5	R901	7	R990	7	W893	7
R431	8	R537	4	R787	5	R910	7	R991	7	W903	7
R432	3	R538	2	R788	5	R911	7	R992	7	W920	7
R433	3	R539	2	R789	5	R912	7	R995	7	W921	7
R435	3	R540	2	R790	5	R913	7			W925	7
R441	3	R541	2	R791	5	R914	7	T902	7	W926	7
R442	3	R542	3	R792	5	R915	7			W947	7
R443	3	R543	3	R793	5	R916	7	U130	2	W948	7
R444	3	R544	2	R794	5	R917	7	U180	2	W951	7
R445	3	R545	2	R795	5	R918	7	U225	2	W976	7
R446	3	R547	2	R796	5	R919	7	U300	3	W984	7
R450	3	R548	2	R797	5	R920	7	U304	3	W984	8
R451	3	R549	2	R798	5	R922	7	U310	3	W985	7
R480	3	R550	4	R799	5	R926	7	U335	3	W987	7
R481 (3	R551	4	R804	7	R927	· 7	U380	3	W987	8
R482	3	R552	4	R805	7	R928	7	U415	3	W989	7
R483	3	R553	4	R818	7	R929	7	U425	3	W989	8
R485	3	R554	4	R819	7	R930	7	U460	3	W991	7
R486	3	R555	4	R820	7	R931	7	U480	3	W991	8
R487	3	R556	4	R822	7	R932	7	U500	4		
R488	3	R557	4	R823	7	R933	7	U520	4		
R489	3	R560	4	R825	7	R934 เ	7	U530	4		
R490	3	R561	2	R828	5	R935	7	U537	2		

I

,

٨

.

.

.

.



Figure 9-9. Circuit view of A1—Main board.

2205 Service

6716-23

CIRCUIT	SCHEM	BOARD	CIRCUIT	SCHEM	BOARD	CIRCUIT	SCHEM	BOARD	CIRCUIT	SCHEM	BOARD
	LOCATION	LOCATION	NUMBER			NUMBER	LOCATION		NUMBER		LOCATION
C114 C115	2F 3F	2H 1H	Q102 Q103	1C 3C	1H 1H	R145 R150	2H 9B	1K 3H	R238 R239	3P 4R	10K 10K
C116	2E	2J	Q104	10	2H	R151	11B	ЗН	R241	6N	8L
C124	2F	1J	Q105	3C	1H	R152	8B	3H	R242	4M	8K
C125	3F	1J	Q114	1F	2J	R153	10B	2H	R243	7M	8K
C126 C130	3F 2G	1J 2K	Q115 Q152	3F 8C	1J 3H	R154 R155	9C 10C	3H 2H	R244 R245	3P 3P	10K 9K
C133	6H	4L	Q153	11C	ЗН	R156	90	3H	R246	3P	9K
C164	9F	ЗН	Q154	8C	ЗН	R158	9B	ЗН	R247	5P	11L
C165 C174	10F 9F	2H 2J	Q155 Q164	11C 8F	2H 3J	R159 R161	10B 10L	3H 3F	R248 R249	7R 8P	3B 10L
C174 C175	10F	2J 2J	Q165	11F	2J	R162	10L	2F	R250	8P	9L
C176	10F	2J	Q202	5K	2K	R164	9E	ЗH	R251	8P	9L
C180	9F	ЗК	Q203	6K	2K	R165	10E	2H	R252	8P	9L
C198 C202	11L 10N	3G 2G	Q206 Q207	5L 6L	2K 2K	R166 R167	9C 10C	3H 2H	R253 R258	2G 10G	2K 3K
C215	5K	2G 3K	Q230	5M	8K	R168	8C	3H ·	R260	10G	7L
C220	8R	8L	Q231	6M	8L	R169	11C	2H	R263	6N	9L
C225	7K	1K	Q232	7N	9L	R170	9F	3H	R264	4N	9K
C232 C235	7P 4P	10L 10K	Q234 Q236	4N 8P	9K 11K	R171 R172	10E 9F	2H 3J	R265 R266	8P 3P	9L 9K
C239	6R	11K	Q237	7P	11L	R174	10F	2J	R267	7P	10L
C240	5P	11K	Q238	3P	11K	R175	9F	3J	R268	3P	10K
C241	5N	8K	Q239	4P	11K	R176	9F	3J	R269	5P	10K
C242 C243	4N 7N	9K 9K	R100	1B	1H	R177 R180	9G 9F	3K 3J	R280 R538	5N 5G	8K 5L
C245	7N 7N	8L	R100	3B	lін	R181	10G	2J	R539	7F	5L 5K
C246	6N	8L	R102	1B	1H	R182	6G	5L	R540	5G	5L
C247	5N	8K	R103	3B	1H	R183	6H	4K	R541	6G	5K
C248 C536	4N 6F	9K 6K	R104 R105	2C 3C	2H 1H	R185 R186	10G 8G	3K 2K	R544 R545	6E 6E	6K 6K
C537	9N	6K	R106	20	1H	R189	6H	4L	R547	5F	6K
C538	5F	5L	R108	2B	1H	R192	8J	2J	R548	5F	6K
C539	7F	5K	R109	2B	1H	R193	9H	ЗК	R549	5G	6K
C540 C545	9M 6E	3J 6L	R114 R115	2E 3E	2H 1H	R194 R195	9H 10J	2J 3K	R561 R566	5D 5D	6K 5K
C547	5F	6K	R116	10	2H	R202	5J	2K	R567	6D	6L
C561	6D	6K	R117	3C	1H	R203	6J	2K			
C562	5C	5K	R118	10	2H	R204	5K	ЗK	U130	1G	1J
CR133	5н	4L	R119 R120	4C 2F	1H 2H	R206 R207	4K 7K	3L 3L	U180 U225	11G 10N	3J 1K
CR136	зн	1K	R121	3E	ĨH	R212	5L	2L	U225	10N	1K
CR139	зн	2J	R122	2F	1J	R213	6L	2L	U537A	6F	6K
CR183	7H	4L	R124	3F	1J	R215	5L	2L	U537B	5F	6K
CR186 CR189	8G 8H	2K 3J	R125 R126	2F 2F	2J 1J	R216 R217	4K 6K	2K 3K	U537C U537D	5E 5E	6K 6K
CR265	8P	9L	R127	2G	2K	R218	4L	2K	U537	10M	6K
CR266	3P	9к	R130	2G	2J	R219	7L	зк	U540A	6G	5K
CR539	7E	5G	R131	3G	1J	R220	6N	9L	U540	10M	5K
J1	3E	1F	R132 R133	6G 5G	5L 4L	R221 R222	4N 5L	9K 2L	U560C	5C	5H
J2	50	1E	R135	1G	2K	R223	6L	2L 2L	W30	1B	1G
			R136	4G	1K	R225	8K	1L	W80	8B	3G
L321	3R 78	10K	R139	5H	4L	R226	8K	1L	W224	5L	2L
L322	7R	10L	R140 R142	6H 2J	3K 1J	R232 R233	6N ⁶ 5M	8L 8K	W224 W225	6L 5M	2L 7K
			R143	ЗH	2K	R235	5N	8K	W225	6M	7K
P904	4R	10K	R144	2H	1J	R237	6P	11K			
artial A1 a	lso shown on di	L agrams 3, 4, 5, 6	, 7 and 8.								
SSEM	BLY A3						-				
	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD
CR534	6A	2B	R113	2D 25	1B	S545	5A 7A	2C 2R	W1	2D	4A
CR537 CR538	6B 7B	2B 2B	R123 R163	2E 10D	1B 1C	S550	7A	2B	W2 W2	5C 9D	2A 2A
0.000	10	20	R173	10E	10				***	50	<u>د</u> ۸

VERTICAL PREAMP & OUTPUT AMPLIFIER DIAGRAM 2

WAVEFORMS FOR DIAGRAM 2

AC Waveforms

VERTICAL MODE

BOTH and CHOP







VERTICAL PREAMP & OUTPUT AMPLIFIER

 $\langle \rangle$

TRIGGER DIAGRAM 3

	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION									
C322 1 J 5D R304 2E 3C R389 6C 2B R467 MM C330 37 4C R306 18 2C R384 4M 4D R467 MM 4C C381 3C C R384 SM 4D R467 MM 4C C383 SC R389 SD R388 SM 4D R467 MM C383 SG R383 SM AD R467 SM A L C R467 SM R47 SM A L C R467 SM R47 SM SG R467 SM SG R468 SM SG	C320	1K	3E	R303	2D	2B	R381	2F	30	R495		6D
C380 3G 4C R366 1B 2C R365 3M 4O R468 7M C381 2F 3G R306 2D 2C R306 3M 4C R423 1G C387 4C 2B R306 2D 2C R400 6F 4C R42 1G C387 4C 2B R306 2A R400 6F 4C R42 1G C408 BH 68 R316 5G 4E R404 9H 68 U3000 1C C418 6C 4B R317 5E 4E R405 9E 3B U3000 1C C431 8C 3G R318 6H 4E R405 8E 3B U3000 1C C469 7H 6D R325 3F 4D R411 9F 6B U304B 3E C486 7L 6D R32						3C			2B			6D
C381 2F 3C R336 2B R386 3H 4C R522 4G C387 4C 2B R306 2C R400 6F 5C R542 1C C387 4C S6 2B R310 1T 3E R400 6F 5C R542 1C C408 S6 2B R310 1T 3E R463 9F 5C R542 1C C408 FH 6E R316 5G 4E R405 8E 3B U300C 2C C418 6C 4B R316 5F 4E R406 8H 6B U300A 3E C480 FH 6A R322 5F 4E R406 8F 6B U304A 2D 1D C480 FH 6A R322 5G 4E R410 6F 6B U304A 2D 1D 1D 1D 1D												6D
C387 4C 28 R 309 2D 2C FA00 6F 6C R542 1C C401 6G 5C R311 11 4D 6G 5C R543 3B C403 1H 6C R311 11 4D R402 9F 5B 4D 4D </td <td></td> <td>6D</td>												6D
C380 58 28 R310 11K 3E R401 6G 5C R533 3B C402 1L 6C R312 11H 8B R402 9F 5B 100000 3E C402 1L 6C R312 11H 8B R402 5C 6A 100000 3E C403 8C 4B R318 6H 4E R402 8H 6B 100000 2C 3E C480 2N 6C R330 6H 3E R407 8U 6B 10300 2M 2C C480 7G 6C R323 5G 4E R409 9F 6B 10304 2P 4E 11H 6F 6B 10304 2P 4E 1411 6F 6B 10304 2P 4B 103106 4A 2P 4B 103106 4A 4A 4A 4A 4B 1310F 4B												6J 4K
CA01 6G SC R311 U BD FA02 9F 5B Job SE C402 11 6C R316 SG 4E R403 9F 6B U3000 1D C408 8H 6B R316 SG 4E R402 8F 3B U3000 2C C413 SG R318 6F 4E R402 8U 6B U300A 2C C480 9H 6A R322 SF 4E R408 8U 6B U304A 2D C480 9H 6A R323 SG 4E R408 8U 4B U310A 4F C480 7L 6D R325 3G 4E R413 7D 4B U310A 4F C480 7L 6D R333 SG 4E R413 7D 4B U310D 4G C480 7L R333 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>4K 4K</td></t<>												4K 4K
C402 1L 6C P312 1H 8B PA04 9H 6A U300A 3E C418 6C 4B P317 5E 4E PA04 9H 6A U300B 1D C413 6C 4B P317 5E 4E PA04 9H 6A U300B 2C C433 6C 3B C416 SE PA04 8H 6B U300A 2D 1C										11040		-11
C418 6C 4B R317 5E 4E R405 8E 3B U300C 2C C480 2N 5C R318 5F 4E R407 8J 6B U300A 2C C480 70 4C R323 5G 4E R408 8J 6B U300A 2Z C486 70 4C R323 5G 4E R411 3E SC U310A 4Z C486 7L 4G R322 3G 4E R411 3E SC U310A 4F C486 7M 6D R328 3G 4E R411 7D 4B U310D 4G C480 7L 8D R333 6L 2E R417 7D 4B U310D 4G C480 7M 8D R333 6L 2E R417 7D 4B U330A 6L C7834 2B										U300A	3E	2B
CA31 BC 3B R18 5H 3E R406 8H 6B U3000 1C C480 7G 6C R320 5H 3E R408 8J 6B U300A 2D C489 7J 4C R323 5F 4E R409 8J 6B U304A 2D C489 7J 4C R323 5F 4E R409 8F 8B U304A 2F C486 7M 6D R323 5F 4E R412 6E 4C U304D 4F C486 7M 6D R323 6M 2E R413 7D 4B U310C 4H C7830 1E 3D R333 6U 3E R416 6D 4B U310C 4G C7830 2E 2C R333 6U 3E R416 6D 4B U3305 4L C R441 R42												2B
CA80 2N 5C R319 5F 4E R407 6J 6B U300 ZM C485 7.7 4C R322 5F 4E R409 8F 6B U304A 3E C486 71 4C R322 5F 4E R409 8F 6B U304A 2N C485 7L 6D R325 3F 4D R411 3E 3C U310A 4F C486 7L 6D R325 3F 4D R411 3E 3C U310A 4F C480 1E 3D R333 4H 5E R414 7D 4B U310D 4G CR301 2E R416 7C 4B U335A 4J C C R333 6J SE R418 7C 4B U335A 4J C C CR344 2B R335 SK SE R428 8D <												2B
C481 7G 6C R320 5H 3E R408 8J 6B U304A 2D C480 9H 6A R322 5G 4E R410 8F 6B U304A 2D C480 7L 6D R325 3F 4E R411 3E 3C U310B 5F C480 7L 6D R325 3F 4E R411 3E 4C U310B 5F CR300 2E 2C R333 6L 3E R416 6D 4B U310B 5G CR301 2E 2C R333 6L 3E R417 7C 4B U310D 4G CR302 2E 2C R333 6L 3E R417 7C 4B U335D 5L CR344 4K 3D R33 6K 2E R428 8D 38 U335D 5L CR431 BD												2B 2B
C489 TJ 4C R322 5F 4E R409 8F 6B U304B 3E C490 TL 6D R325 3F 4D R411 3E 3C U310A 4F C496 TM 6D R325 3F 4D R411 3E 3C U310A 4F C1980 TM 6D R328 4F SE R411 7D 4B U310C 4H CR300 1E 3D R332 SM 4E R416 7D 4B U310F 4G CR301 2E 2C R332 SM SE R416 7D 4B U310F 4G CR304 2B 2B R335 SK 3E R418 9G 6A U335A 4L CR344 4K 3D R335 6K 3E R428 8D 3B U335D 4L GE R428 BD												2B 2C
C4400 C4496 PH T 6A C496 R323 T 5G C 4E C R410 R411 5E SE C U304 SE 2N SE C496 T C R325 3G R326 4E R412 R412 6E R413 4C U310B 5F R415 CR300 E 3D R330 R4H SE R415 RD R414 7D R48 4B U310D 4G R413 CR301 ZE R416 2C R331 SM S4 SE R416 RD R416 RD R48 4B U310E 4G R48 U310D 4G R48 U310D 4G R48 U330A 4L V SE R416 RC R48 4G R48 U330A 4L V V SE R417 RD R38 BS R333C 6K R42 R27 R42 8D R38 U335C 4L V SE R433 R33 6K R42 R33 U335C 4L V V SE R427 RD R38 U335C												20 20
C448 7M 6D R328 3G 4E R412 6E 4C U310C 4H CR300 1E 3D R330 4H 5E R414 7D 4B U310C 4H CR301 ZE 2C R331 5J 3E R415 7D 4B U310C 4G CR302 ZE 2C R332 6M 2E R416 7C 4B U310F 4G CR344 4K 3D R334 6L 2E R418 9G 6A U335B 5K CR344 2B R335 6K 3E R428 8D 3B U335C 4L CR345 2B R337 6K 2E R427 8D 3B U335C 4L CR450 3D 3C R433 9D 4B U380C 3L J3 6B 12B R351 3L 3D R433												2C
CR300 CR301 IE SD R329 R330 4F SE R413 R415 7D 4B U310D 4H CR301 ZE 2C R331 SJ 3E R415 BD 4B U310D 4G CR302 ZE 2C R332 SM 2E R416 7C 4B U310P 4G CR314 4G 4D R333 6J 3E R417 7C 4B U335A 4J CR344 4K 3D R334 6L 2E R418 9C 6A U335A 4L CR344 2B 2B R337 6K 2E R428 BD 3B U335C 4L CR431 5D 2B R337 6K 2E R428 BD 3B U335C 4L CR431 4D 3C R338 3K 3D R433 BD 4B U336D 3L CR451	C495	7L	6D	R325	3F		R411					4E
CR300 TE 3D R330 4H SE R414 TD 4B U310E 4G CR301 ZE 2C R331 5M ZE R416 TC 4B U310E 4G CR302 ZE 2C R332 5M ZE R416 TC 4B U310E 4G CR344 4K 3D R334 6L ZE R417 TC 4B U335A 4J CR344 2B ZB R335 5K 3E R418 9G 6A U335B 5K CR346 2B ZB R337 6L ZE R428 7D 3B U335C 4L CR411 3D SC R338 SK 3D R428 7D 3B U335F 5L CR431 3D R433 3L 3D R433 9D 4B U380B MM CR431 BC R433 <td>C496</td> <td>7M</td> <td>6D</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>4E</td>	C496	7M	6D									4E
CR302 ZE 2C R331 SJ SE R415 6D 4B U310E 5G CR302 ZE ZC R332 SM ZE R416 7C 4B U310E 5G CR314 4G 4D R333 SJ SE R416 7C 4B U310E 4G CR344 2B ZB R335 5K 3E R418 9G 6A U335B 5K CR349 2B ZB R337 6L 2E R427 8D 3B U335C 4L CR417 TD 4B R338 6K 2E R428 8D 3B U335F 4K CR451 4D 3C R340 3L 3E R429 7C 3B U335F 4K GR461 4D 3C R343 5L 3D R433 9D 4B U380C 3J J3 6B												4E
CR302 2E 2C R332 5M 2E R416 7C 4B U310F 4G CR314 4G 4D R333 6L 3E R417 7C 4B U310F 4G CR344 2B 2B R335 5K 3E R419 9G 6A U335A 4J CR344 2B 2B R335 5K 3E R426 8D 3B U335C 4L CR311 3D R429 7C 3B U335E 5L 3D R429 7C 3B U335F 4K CR451 4D 3C R343 5L 3D R433 9D 48 U3306 3M J3 6B 12B R351 3J 3D R433 9D 48 U3806 3J J3 6B 12B R351 3J 3D R432 9D 48 U3806 3J												4E
CR314 4G 4D R333 6J 3E R417 7C 4B U310 1M CR344 2B 2B R335 5K 3E R418 9G 6A U335A 4J CR344 2B 2B R335 5K 3E R426 8D 3B U335C 4L CR341 5B 2B R337 6L 2E R427 8D 3B U335C 4L CR417 7D 4B R338 6K 2E R427 8D 3B U335C 4L CR451 4D 3C R340 3L 3E R429 7C 3B U335F 4K CR452 4B 3B R344 4J 3E R432 9D 4B U3800 3J J3 6B 12B R351 3J 3D R442 4G 3E U380C 3J G371 5C												4E 4E
CR344 4K 3D R334 6L 2E R418 6C 4B U335A 4J CR348 2B 2B R335 5K 3E R419 9G 6A U335C 4L CR341 2B 2B R335 6K 3E R427 8D 3B U335C 4L CR417 7D 4B R339 6K 2E R428 8D 3B U335C 4L CR431 8D 3C R339 3K 3D R429 7C 3B U335C 5L CR451 4D 3C R343 5L 3D R431 1L 6C U380A 3H CR452 4B 3B R344 4J 3E R433 9D 4B U380A 3H J3 6B 12B R351 3J 3D R443 5K 2E U415A 7D 3C U380A 3H												4E
CR341 28 28 R336 6K 3E R427 8D 3B U335C 4L CR311 5B 28 R337 6L 2E R428 8D 3B U335C 4L CR417 7D 4B R338 6K 2E R428 8D 3B U335C 4L CR451 4D 3C R339 3K 3D R429 7C 3B U335C 4K CR452 4B 3B R344 4U 3E R433 9D 4B U380A 3H CR452 4B 3B R344 4U 3E R433 9D 4B U380A 3H CR452 4B 3B R350 2L 3D R441 4G 3E U380A 3H J3 6B 12B R353 3J 3D R442 4G 3E U415A 7D G370 4C												2E
CR381 5B 2B R337 6L 2E R427 6D 3B U335D 4L CR417 7D 4B R338 6K 2E R428 8D 3B U335E 5L CR430 3D 3C R339 3K 3D R428 8D 3B U335E 5L CR451 4D 3C R343 5L 3D R431 1L 6C U380A 3H CR452 4B 3B R354 4J 3E R432 9D 4B U380B 3M GR452 4B 3B R354 3J 3D R435 7D 3C U380D 2J G370 4C 2A R353 3J 3D R442 4G 3E U415A 7D G400 7F 5B R356 2J 3D R444 5K 2E U415C 2G G410 7G	CR348	2B			5K						5K	2E
CR417 TD 4B R338 6K 2E R429 TC 3B U335E 5L CR430 3D 3C R339 3K 3D R429 TC 3B U335E 5L CR450 3D 3C R340 3L 3E R429 TC 3B U335F 4K CR451 4D 3C R343 5L 3D R431 1L 6C U380A 3H CR452 4B 3B R344 4J 3E R433 9D 4B U380A 3H J3 6B 12B R551 3J 3D R443 7D 3C U380D 2J G370 4C 2A R353 3J 3D R442 4G 3E U415A TD G371 5C 2A R356 2J 3D R442 4G 3E U415A TD G410 2F												2E
CR431 BD 3C R339 3K 3D F429 7C 3B U335F 4K CR450 3D 3C R340 3L 3E R430 8C 4A U335F 1M CR451 4D 3C R343 5L 3D R431 1L 6C U380A 3H CR452 4B 3B R350 2K 3D R433 9D 4B U380B 3J J3 6B 12B R351 3J 3D R435 7D 3C U380C 3J G371 5C 2A R353 3J 3D R443 5K 2E U415A 7D G400 7F 5B R356 2H 4C R444 5K 2E U415C 2G G410 2F 3C R358 2J 3D R445 RC 5A U415C 2G G411 4C												2E
CR450 3D 3C R340 3L 3E PH30 8C 4A U35 IM CR451 4D 3C R343 5L 3D R431 1L 6C U380A 3H CR452 4B 3B R344 4J 3E R433 9D 4B U380C 3J J3 6B 12B R351 3J 3D R435 7D 3C U380C 3J G370 4C 2A R354 2J 3D R442 4G 3E U416A 7D 3C U490E 8D 0316 7D 020 7F 5B R356 2J 3D R442 4G 3E U416D 7B 0410 7F 5B R357 2H 3C R446 8C 5A U415D 7B 0411 4C 3B R446 8C U415D 7B 0411 4C 3B R446 3C												2E
CR451 4D 3C R343 5L 3D R431 1L 6C U380A 3H J3 6B 12B R350 2K 3D R433 9D 4B U380C 3J J3 6B 12B R351 3J 3D R441 4G 3E U380C 3J Q370 4C 2A R353 3J 3D R441 4G 3E U380E 8D Q370 4C 2A R353 3J 3D R441 4G 3E U415A 7D Q400 7F 5B R356 2H 4C R444 5K 2E U415C 2G Q401 2F 3C R358 2J 3D R446 8C 5A U415C 7B Q411 4C R451 8E 4C U425B 6B U460A 8F Q412 5C 2B R360												2E 2E
CR452 4B 3B R344 4J 3E R432 9D 4B U380B 3M J3 6B 12B R351 3J 3D R435 7D 3C U380D 2J 0370 4C 2A R353 3J 3D R441 4G 3E U380E 8D 0370 4C 2A R353 3J 3D R442 4G 3E U380E 8D 0371 5C 2A R354 2J 3D R442 4G 3E U380E 8D 0400 7F 5B R356 2H 3C R445 7C 5B U415D 7B 0410 2F 3C R359 2G 4C R445 7C 5B U415D 7B 0411 4C 3B R359 2G 4C R450 4D 3B U425A 7B 0412 5C <												3C
J3 6B 12B R350 2K 3D R433 9D 4B U380C 3J 0370 4C 2A R352 2J 3D R441 4G 3E U380D 2J 0370 4C 2A R353 3J 3D R442 4G 3E U415A 7D 0400 7F 5B R356 2H 4C R444 5K 2E U415C 2G 0400 7F 5B R356 2H 4C R444 5K 2E U415C 2G 0411 4C 3B R455 7C 5B U415D 7B 0412 5C 2B R360 2H 4C R451 8E 4C U425A 7B 0412 5C 2B R361 3D 3C R482 7H 6B U426A 8F 0451 5L 4E R366 3D <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>3C</td></t<>												3C
O370 AC 2A R352 2J 3D R441 4G 3E U380E 8D 0371 5C 2A R354 2J 3D R443 5K 2E U415A 7D 0400 7F 5B R366 2H 4C R444 5K 2E U415B 7E 0401 2F 3C R358 2J 3D R445 7C 5B U415D 2G 0411 4C 3B R455 7C 5B U415D 7B 0411 4C 3B R465 7C 5B U415D 7B 0411 4C 3B R465 7C 5B U425A 7B 0411 4C 3B R465 7D 3B U425A 7B 0415 7D 4B R360 2H 4C R451 8E 4C U425B 6B 0455 5L <				R350	2K	3D	R433	9D	4B	U380C	3J	3C
Q370 4C 2A R353 3J 3D R442 4G 3E U415A 7D Q371 5C 2A R354 2J 3D R443 5K 2E U415B 7E Q400 7F 5B R356 2H 4C R444 5K 2E U415B 7E Q401 7G 5B R357 2H 3C R445 7C 5B U415D 7B Q411 4C 3B R359 2G 4C R445 7C 5B U415D 7B Q411 4C 3B R359 2G 4C R450 4D 3B U425A 7B Q412 5C 2B R361 3C 3B R460 7G 5C U425 2M Q451 5J 2E R362 3D 3C R481 7H 5C U460A 8F Q453 5E <t< td=""><td>J3</td><td>6B</td><td>12B</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>3C</td></t<>	J3	6B	12B									3C
Q371 5C 2A R354 2J 3D R443 5K 2E U415B 7E Q400 7F 5B R356 2H 4C R444 5K 2E U415D 2G Q410 2F 3C R357 2H 3C R445 7C 5B U415D 7B Q410 2F 3C R358 2J 3D R446 8C 5A U415E 9D Q411 4C 3B R359 2G 4C R450 4D 3B U425A 7B Q412 5C 2B R360 2H 4C R451 8E 4C U425 2M Q450 5L 2E R362 3D 3C R481 7H 6B U425 2M Q453 5E 4E R366 4B 3B R483 7J 5C U460D 8G Q465 7E <td< td=""><td>0070</td><td>10</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>3C</td></td<>	0070	10										3C
Q400 7F 5B R356 2H 4C R444 5K 2E U415C 2G Q401 7G 5B R356 2J 3C R445 7C 5B U415D 7B Q411 4C 3B R359 2G 4C R466 8C 5A U415E 9D Q411 4C 3B R359 2G 4C R450 4D 3B U425A 7B Q412 5C 2B R360 2H 4C R451 8E 4C U425B 6B Q415 7D 4B R363 3D 3C R481 7H 6B U460A 8F Q451 5L 2E R362 3D 3C R482 7H 5C U460B 9F Q452 5H 4E R366 4B 3B R485 7J 5C U460C 8G Q485 7E <												4B 4B
Q401 7G 5B R357 2H 3C R445 7C 5B U415D 7B Q410 2F 3C R358 2J 3D R446 8C 5A U415E 9D Q411 4C 3B R359 2G 4C R450 4D 3B U425A 7B Q412 5C 2B R360 2H 4C R451 8E 4C U425B 6B Q415 5L 2E R362 3D 3C R481 7H 6B U425A 2B Q450 5L 2E R362 3D 3C R481 7H 6B U460A 8F Q451 5J 3E R363 3D 3C R482 7H 5C U460A 8F Q453 5E 4E R366 4B 3B R485 7J 5C U460C 8G Q485 7E <												4B 4B
Q410 2F 3C R558 2J 3D R446 8C 5A U415E 9D Q411 4C 3B R359 2G 4C R450 4D 3B U425A 7B Q415 7D 4B R360 2H 4C R451 8E 4C U425B 6B Q415 7D 4B R361 3C 3B R480 7G 5C U425 2M Q451 5L 2E R362 3D 3C R481 7H 6B U425A 8F Q452 5H 4E R364 4B 3B R485 7J 5C U460D 8G Q453 5E 4E R366 4B 3B R485 7J 5C U460D 8G Q487 6K 6C R368 4C 3B R486 7K 6D U460 1N Q488 7L <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>4B</td></td<>												4B
Q412 5C 2B R360 2H 4C R451 8E 4C U425B 6B Q415 7D 4B R361 3C 3B R480 7G 5C U425 2M Q450 5L 2E R362 3D 3C R481 7H 6B U460A 8F Q451 5J 3E R363 3D 3C R481 7H 5C U460A 8F Q452 5H 4E R366 4B 3B R483 7J 5C U460D 8G Q453 5E 4E R366 4B 3B R483 7J 5C U460D 8G Q457 6K 6C R368 4C 3B R487 6K 6C U460F 8F Q489 7L 5D R370 4B 2B R489 8J 4C U480A 8L Q490 8B <t< td=""><td>Q410</td><td>2F</td><td></td><td>R358</td><td>2J</td><td>3D</td><td>R446</td><td>8C</td><td></td><td>U415E</td><td></td><td>4B</td></t<>	Q410	2F		R358	2J	3D	R446	8C		U415E		4B
Q415 7D 4B R361 3C 3B R480 7G 5C U425 2M Q450 5L 2E R362 3D 3C R481 7H 6B U460A 8F Q451 5J 3E R363 3D 3C R481 7H 5C U460A 8F Q452 5H 4E R364 4B 3B R483 7J 5C U460D 8G Q453 5E 4E R366 4B 3B R485 7J 5C U460D 8G Q465 7E 3C R367 4D 3B R485 7K 6C U460P 8G Q487 6K 6C R368 4C 3B R487 6K 6C U460P 8F Q488 7K 5D R370 4B 2B R489 8J 4C U480A 8L Q490 8B <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>ЗA</td></t<>												ЗA
Q450 5L 2E R362 3D 3C R481 7H 6B U460A 8F Q451 5J 3E R363 3D 3C R482 7H 5C U460A 8F Q452 5H 4E R364 4B 3B R482 7H 5C U460D 8G Q453 5E 4E R366 4B 3B R485 7J 5C U460D 8G Q455 7E 3C R367 4D 3B R485 7J 5C U460D 8G Q485 7E 3C R367 4D 3B R485 7K 6C U460F 8F Q488 7K 5D R368 4C 3B R488 7K 6D U460 8L Q490 8B 3A R371 5C 2B R499 8J 4C U480A 8L Q490 8B <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>3A</td></t<>												3A
Q451 5J 3E R363 3D 3C R482 7H 5C U460B 9F Q452 5H 4E R364 4B 3B R483 7J 5C U460B 8G Q453 5E 4E R366 4B 3B R485 7J 5C U460D 8G Q465 7E 3C R367 4D 3B R486 7K 6C U460E 9G Q487 6K 6C R368 4C 3B R487 6K 6C U460F 8F Q488 7K 5D R369 5D 3B R489 8J 4C U460A 8L Q490 8B 3A R371 5C 2B R490 7K 6D U480B 7M R300 1D 4K R373 5C 2B R492 7L 6C U480D 7J R301 3C <												3A 5B
Q452 5H 4E R364 4B 3B R483 7J 5C U460C 8G Q453 5E 4E R366 4B 3B R485 7J 5C U460C 8G Q453 5E 4E R366 4B 3B R485 7J 5C U460C 8G Q457 6K 6C R367 4D 3B R486 7K 6C U460F 8G Q487 6K 6C R368 4C 3B R486 7K 6D U460F 8F Q488 7K 5D R370 4B 2B R489 8J 4C U480A 8L Q490 8B 3A R371 5C 2B R490 7K 6D U480B 7M R300 1D 4K R373 5C 2B R492 7L 6C U480D 7J R302 1B <												5B
Q453 5E 4E R366 4B 3B R485 7J 5C U460D 8G Q465 7E 3C R367 4D 3B R486 7K 6C U460D 9G Q487 6K 6C R368 4C 3B R487 6K 6C U460F 8F Q488 7K 5C R368 4C 3B R487 6K 6C U460F 8F Q489 7L 5D R370 4B 2B R489 8J 4C U480A 8L Q490 8B 3A R371 5C 2B R499 8J 4C U480C 7H R300 1D 4K R373 5C 2B R491 8K 4C U480D 7J R301 3C 4K R374 5B 2B R493 8L 6C U480 2M R302 1B <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>5B</td></t<>												5B
Q465 7E 3C R367 4D 3B R486 7K 6C U460E 9G Q487 6K 6C R368 4C 3B R487 6K 6C U460E 9G Q487 6K 6C R368 4C 3B R487 6K 6C U460E 8F Q489 7L 5D R369 5D 3B R488 7K 6D U460 1N Q490 8B 3A R371 5C 2B R490 7K 6D U480B 7M R300 1D 4K R372 4C 2B R491 8K ^t 4C U480D 7J R301 3C 4K R374 5B 2B R493 8L 6C U480D 2M R302 1B 2C R380 2G 4C P 8L 6C U480D 2M R380												5B
Q488 7K 5C R369 5D 3B R488 7K 6D U460 1N Q489 7L 5D R370 4B 2B R489 8J 4C U480A 8L Q490 8B 3A R371 5C 2B R490 7K 6D U480A 8L R300 1D 4K R373 5C 2B R491 8K ⁴ 4C U480A 8L R300 1D 4K R373 5C 2B R492 7L 6C U480D 7J R301 3C 4K R374 5B 2B R493 8L 6C U480 2M R302 1B 2C R380 2G 4C 2B R493 8L 6C U480 2M Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8.	Q465	7E		R367	4D		R486		6C			5B
Q489 Q490 7L 8B 5D 3A R370 R371 4B 5C 2B 2B R489 R490 8J R490 4C U480A U480B 8L 7M R300 1D 4K R372 4C 2B R491 8K ⁻¹ 4C U480A 8L R300 1D 4K R373 5C 2B R492 7L 6C U480D 7H R301 3C 4K R374 5B 2B R493 8L 6C U4800 2M Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8. ZG 4C Description Descripion Descripion Descri												5B
Q490 8B 3A R371 5C 2B R490 7K 6D U480B 7M R300 1D 4K R372 4C 2B R491 8K ^c 4C U480B 7H R300 1D 4K R373 5C 2B R491 8K ^c 4C U480C 7H R301 3C 4K R374 5B 2B R493 8L 6C U4800 2M Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8. 2G 4C PA 8L 6C U4800 2M												5B
R300 R301 R301 R302 1D 3C B 4K 4K 4K 2C R372 R373 R374 R374 4C 5C 5C 5B 2B R380 2B 2B R493 R491 R492 BL 8K ¹ 7L 6C 4C U480D U480 7H 7J U480 Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8.												5C
R300 R301 R301 R301 R302 1D 3C HK 4K 4K R374 R374 R373 5B SB 2G 5C 2B 2B 4C R492 R493 7L 8L 6C U480D U480 7J 2M Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8.	4 490	00	ЗА									5C 5C
R301 R302 3C 1B 4K 2C R374 R380 5B 2G 2B 4C R493 8L 6C U480 2M Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8.	R300	1D	4K									5C
Partial A1 also shown on diagrams 2, 4, 5, 6, 7 and 8. ASSEMBLY A3 CIRCUIT SCHEM BOARD												5C
ASSEMBLY A3 CIRCUIT SCHEM BOARD CIRCUIT SCHEM BOARD CIRCUIT SCHEM BOARD CIRCUIT SCHEM BO	R302	1B	2C	R380	2G	4C						
CIRCUIT SCHEM BOARD CIRCUIT SCHEM BOARD CIRCUIT SCHEM BOARD CIRCUIT SCHEM BOARD CIRCUIT SCHEM BO	R302	1B	2C	R380								
	ASSEM	BLY A3										
												BOARD
R426 7A 1F W3 6A 4D												=

WAVEFORMS FOR DIAGRAM 3

0.1 V AC 5μs

AC Waveforms

VOLTS/DIV	
AC-GND-DC	
SEC/DIV	

Input signal

4-division, 50 kHz reference sine wave



ç



TRIGGER

 \diamond
WAVEFORMS FOR DIAGRAM 4



AC Waveforms for 4E through 4N

VOLTS/DIV	0.1 V
AC-GND-DC	AC
SEC/DIV	5µs

Input signal

4-division, 50 kHz reference sine wave





Scans by ArtekMedia © 2006

SWEEP LOGIC DIAGRAM 4

•

,

.

.

.

•

٠

.

ASSEMI	BLY A1										
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION
C500 C501 C503 C505 C506 C525 C530 C555 C550 C554 C555 C560 C571 C572 C584 C587 C8530 C8540 C8570 C8540 C8571 C8584 C8571 C8584 C8571 C8584 C8571 C8584 C8589 J1 J5 J5 J6	1F 4B 6C 3D 3D 3D 3D 3D 3D 3D 3D 3D 3D 3D 3D 3D	유감원 영감 남 6 8 8 8 4 4 2 4 2 4 2 8 8 4 4 2 4 2 4 2 4	Q535 Q536 R501 R502 R503 R504 R505 R506 R506 R506 R508 R515 R515 R515 R517 R518 R520 R521 R522 R523 R522 R523 R523 R524 R525 R526 R531 R531 R534 R535 R536 R537 R536 R537 R550 R551	3J 3J 4B 8B 86 C 2 C C C E H C 6B 86 4 4 F 4 D 67 C 7 C 63 D 67 H 4 J 3 3 6 6	ዽዽዸዽኇዸዸኇዸዽዽ፟ዄኇዸዸኇኇዸኇኇኇኇዸዸኇኇኇኇኇኇ	R552 R553 R554 R555 R556 R557 R560 R562 R563 R564 R565 R570 R571 R572 R573 R574 R573 R574 R579 R581 R579 R581 R582 R583 R584 R585 R584 R585 R588 R589 R590 U500A U500A	7H H 5G 2D G E G K K C 2E K L E F F F G E C 8B 8B B 7 J K K K K L 4D 6C	ቋድ ሰት ተቋቋቋ ሰው የሰው የሰው የሰው የሰው የሰው የሰው የሰው የሰው የሰው	U500 U520A U520B U520D U520D U520D U520D U520D U530A U530B U550A U550B U550C U550D U550C U550D U550C U550D U560B U560B U560B U560B U570A U570A U570A U570A U580A U580B U570A U580B U570A U580B U570A U580B	1F D 4E 4F D G 5H H 3G 6J H F 7G H 6J 6K E 6C E 6G J 7J 7B 5B 7L 3.5B 5B 7L 3.5B	8 부 부 부 부 주 장 장 장 주 주 주 주 운 당 구 주 추 추 주 주 주 관 장 양 양
Partial A1 a	lso shown on di	agrams 2, 3, 5, 6	, 7 and 8.								
ASSEM	BLY A3				_					-	
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
DS560	6M	2F	S505	2B	2F	W1 W5	1B 2B	4A 4E	W5 W6	6L 6L	4E 4F
Partial A3 a	lso shown on di	agrams 1, 2, 3, 6	and 8.		<u></u>	•					
CHASS	IS MOUNTE	ED PARTS				ĩ					
	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
J590	7L	CHASSIS					<u></u>				



SWEEP LOGIC

 \diamond

SWEEP GENERATOR & HORIZONTAL AMPLIFIER DIAGRAM 5

,

.

.

.

÷

	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
C776	2К	9Н	P905	2M	11J	R779	2M	11H	R793	4K	эн
C780	2L	9H				R780	1K	9H	R794	3L	10H
C782	3L	10H	Q770	1L	10J	R781	1L	9J	R795	3L	10H
C783	2L	10,1	Q775	2M	10J	R783	2K	9J	R796	4M	9H
C785	1M	13B	Q776	4K	9J	R784	2L	10,	R797	4M	11J
C789 C794	1M 4L	11J 10H	Q779 Q780	1M 3L	10J 10H	R785 R786	2L 3L	10J ອJ	R798	3M	11J
C794 C795	4L 3M	101	Q785	3L 4M	10H	R787	3L 2M	90 11J	R799 R828	3M 4J	11H 8J
C799	3M	11H	Q789	3M	10H	R788	1M	11J	H020	40	~
0/00			u /00			R789	2M	11J	VR776	2K	9Н
CR780	1K	9Н	R262	4K	8J	R790	ЗK	9H	VR792	3L	10H
CR781	2L	9J	R775	ЗK	9J	R791	3L	9H			
CR790	зк	9H	R776	2K	8H	R792,	3L	ୟ	W755	1J	7A
CR791	2L	9H	R778	3M	11J						
ASSEM		agrams 2, 3, 4, 6,	rand 0.								
CIRCUIT UMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATIO
C701	6B	4F	J755	1H	1F	R722	7F	1D	R769	8H	2F
C702	7B	4E	0700			R723	7F	1D	R770	8H	2F 2F
C703	4C	5F	L712	1B	1C	R724	7L	2F	R771	8J	1F
C704	4C	5F	L713	1B	1C	R725	6M	3F	R772	8J	1F
C705	4D	5F				R726	2F	3F	R773	8J	3F
C706	5D	5F	Q701	5B	4F	R727	2F	3F	R774	8L	1F
	5D	5F	Q704A	5D	5F	R728	3B	2D	R777	7K	1E
C708							3C	2D	R780	7M	2F
C709	5C	4E	Q704B	5D	5G	R729		10			
C709 C710	5C 3E	5F	Q706	5D	5F	R732	2D	1D	R782	6K	2F
C709 C710 C712	5C 3E 1C	5F 1C	Q706 Q725	5D 6L	5F 2G	R732 R733	2D 2E	3E	R782	6К	2F
C709 C710 C712 C713	5C 3E 1C 1C	5F 1C 1C	Q706 Q725 Q732	5D 6L 3D	5F 2G 3E	R732 R733 R734	2D 2E 3D	3E 2D			
C709 C710 C712	5C 3E 1C	5F 1C	Q706 Q725	5D 6L	5F 2G	R732 R733	2D 2E	3E	R782	6K 8C	2F 2E
C709 C710 C712 C713 C715	5C 3E 1C 1C 8E 6B 5C	5F 1C 1C 2E	Q706 Q725 Q732 Q736	5D 6L 3D 3D	5F 2G 3E 3D	R732 R733 R734 R735	2D 2E 3D 2C	3E 2D 3E	R782 S701	6К	2F
C709 C710 C712 C713 C715 C722 C723 C724	5C 3E 1C 1C 8E 6B 5C 2F	5F 1C 2E 4E 4E 3E	Q706 Q725 Q732 Q736 Q737 Q750 Q759	5D 6L 3D 2F 4G 4G	5F 2G 3E 3D 3E 3G 3G	R732 R733 R734 R735 R736 R737 R738	2D 2E 3D 2C 1D 2F 4F	3E 2D 3E 1D 3E 3E	R782 S701 U715A U745A U745B	6K 8C 8E 8J 8K	2F 2E 1E 2F 2F
C709 C710 C712 C713 C715 C722 C723 C724 C727	5C 3E 1C 8E 6B 52F 2G	5F 1C 2E 4E 4E 3E 3E	Q706 Q725 Q732 Q736 Q737 Q750	5D 6L 3D 3D 2F 4G	5F 2G 3E 3D 3E 3G	R732 R733 R734 R735 R736 R737 R738 R740	2D 2E 3D 2C 1D 2F 4F 4E	3E 2D 3E 1D 3E 3E 3F	R782 S701 U715A U745A U745B U745B U745C	6К 8С 8Ј 8Ј 8К 7К	2F 2E 1E 2F 2F 2F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C733	5C 3E 1C 8B 5C 2F 2E 2E	5F 1C 2E 4E 3E 3E 3E 3E	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760	5D 6L 3D 2F 4G 7H	5F 2G 3E 3D 3E 3G 3G 2F	R732 R733 R734 R735 R736 R737 R738 R738 R740 R741	2D 2E 3D 2C 1D 2F 4F 4E 4F	3E 2D 3E 1D 3E 3E 3F 3G	R782 S701 U715A U745A U745B U745C U745C U745D	6K 8C 8J 8K 7K 7L	2F 2E 1E 2F 2F 2F 2F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C733 C755	5C 3E 1C 1C 8 8 8 5 2 F 2 2 E 2 8 J	5F 1C 1C 4E 4E 3E 3E 2F	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701	5D 6L 3D 2F 4G 7H 6E	5F 2G 3E 3D 3E 3G 2F 4F	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743	2D 2E 3D 2C 1D 2F 4F 4E 4F 7G	3E 2D 3E 1D 3E 3E 3F 3G 3G	R782 S701 U715A U745A U745B U745C U745C U745D U745E	6К 8С 8Ј 8К 7К 7L 8Н	2F 2E 2F 2F 2F 2F 2F 2F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C733	5C 3E 1C 8B 5C 2F 2E 2E	5F 1C 2E 4E 3E 3E 3E 3E	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701 R702	5D 6L 3D 2F 4G 4G 7H 6E 6E	5F 2G 3D 3E 3G 2F 4F 5F	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744	2D 2E 3D 2C 1D 2F 4F 4F 4F 4F 7G 4E	3E 2D 3E 1D 3E 3F 3G 3G 3F	R782 S701 U715A U745A U745B U745C U745D U745E U755A	6K 8C 8J 8K 7K 7L 8H 8L	2F 2E 2F 2F 2F 2F 2F 2F 2F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C733 C755 C767	5С 3E С 3E С 1 С 8E 85 2F 22E 8J 7K	5F 1C 1E 4E 4E 3E 3E 2F 1E	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701 R702 R703	5D 6L 3D 2F 4G 47 H 6E E 6C	5F 2G 3D 3E 3G 3G 2F 4F 54F	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744 R745	2D 2E 3D 2C 1D 2F 4F 4F 4F 7G 4F 4G	3E 2D 3E 1D 3E 3F 3G 3G 3G 3F 4G	R782 S701 U715A U745A U745B U745C U745C U745C U745E U755A U755B	6K 8C 8J 8K 7K 7L 8H 8L 8L	2F 2E 2F 2F 2F 2F 2F 1F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C723 C727 C733 C755 C767 C767	5C 3E C C 8E 85 2F G 2E 8J 7K 8G	5F 1C 2E 4E 3E 3E 2F 1E 2F	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701 R702 R703 R704	5D 6L 3D 2F 4G 7H 6E 6E 4B 40	5F 2G 3D 3E 3G 2F 4F 5F 4F 4F	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744 R745 R756	2D 2E 3C 1D 4F 4E 4G 4G 7G	3E 2D 3E 3E 3E 3G 3G 3F 3G 2E	R782 S701 U715A U745A U745B U745C U745C U745C U745E U755B U755B U755C	6K 8C 8E 8J 8K 7K 8H 8L 8L 6J	2F 2E 2F 2F 2F 2F 1F 1F
C709 C710 C712 C713 C722 C723 C723 C724 C727 C733 C755 C767 C767 CR758 CR761	5C 3E C C 8E 85 2F 2G E 8J 7K 8G 7K	5F 1C 2E 4E 3E 3E 3E 2F 1E 2G	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701 R702 R703 R704 R705	5D 6L 3D 2F 4G 7H 6E 4C 8D	5F 2G E 3D 3E G 3G 2F 4F F 4F F 4F F	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744 R745 R756 R757	2D 2E 3C 1D 2F 4E 4F 4E 4G 5K	3E 2DE 1D 3E 3F 3G 3F 4G 2G	R782 S701 U715A U745A U745B U745C U745C U745C U755A U755B U755C U755C	6K 8C 8E 8J 8K 7K 7L 8H 8L 8L 8L 6J 6L	2F 2E 1E 2F 2F 2F 2F 1F 1F 1F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C723 C725 C767 C767	5C 3E C C 8E 85 2F G 2E 8J 7K 8G	5F 1C 2E 4E 3E 3E 2F 1E 2F	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701 R702 R703 R704	5D 6L 3D 2F 4G 4T 4 6E 4C 8D 5E	5F 2G 3E 3G 3E 3G 3F 4F 4F 4F 5D	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744 R745 R756 R757 R758	2D 2E 3C 1D 2F F 4E F G E G G K 6K	3E 2D = 1D 3E = 3F 3G G F 4G = 2G 2G	R782 S701 U715A U745A U745B U745C U745C U745C U745E U755B U755B U755C	6K 8C 8E 8J 8K 7K 8H 8L 8L 6J	2F 2E 2F 2F 2F 2F 1F 1F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C723 C727 C723 C725 C767 C755 C767 CR758 CR761 CR762	5С 3E С С 2E 85 2F 22 2E 87 K 86 K 65 2F 22 2E 87 K 86 K 65 K	5F 1C 2E 4E 4E 3E 2F 1 2F 2F 2F	Q706 Q725 Q732 Q736 Q737 Q750 Q759 Q760 R701 R702 R703 R704 R705 R710	5D 6L 3D 2F 4G 7H 6E 4C 8D	5F 2G E 3D 3E G 3G 2F 4F F 4F F 4F F	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744 R745 R756 R757	2D 2E 3C 1D 2F 4E 4F 4E 4G 5K	3E 2DE 1D 3E 3F 3G 3F 4G 2G	R782 S701 U715A U745A U745B U745C U745C U745C U755A U755B U755C U755C	6K 8C 8E 8J 8K 7K 7L 8H 8L 8L 8L 6J 6L	2F 2E 1E 2F 2F 2F 2F 1F 1F 1F
C709 C710 C712 C713 C715 C722 C723 C724 C727 C733 C755 C767 CR761 CR758 CR761 CR762 CR769	50 3E C C E B SC F G E B J K 8G K K 66 K	5F 1C 2E 4E 3E 3E 3E 2F 1E 2G 2G 2G 2G	Q706 Q725 Q732 Q736 Q737 Q750 Q750 Q760 R701 R702 R703 R704 R705 R710 R715 R716 R717	5D 6L 3D 2F 4G 7H 6E 4C 8D 3E 8E 8E 78F	5F G E 30 G F F F F F F F 50 E D E 32 C F F F F F F 50 E D E 1 E	R732 R733 R734 R735 R736 R737 R738 R740 R741 R741 R743 R744 R745 R756 R756 R757 R758 R751 R761 R762 R763	2D 2E 3C 1D 2F F E 4 4 F 7 5 6 K 6 K 6 K 6 K 6 K K 6 K 7 K	3E 2D 55 1D 35 1D 35 10 35 10 35 10 35 10 35 10 35 10 35 10 25 10 25 10 25 10 10 10 10 10 10 10 10 10 10 10 10 10	R782 S701 U715A U745A U745B U745C U745C U745C U755A U755C U755C U755C U755C	6K 8C 8E 8K 7K 8H 8L 8L 6L 8J 6L 8J	2F 2E 2F 2F 2F 2F 1F 1F 1F 1F
C709 C710 C713 C715 C725 C723 C724 C727 C733 C755 C767 CR758 CR761 CR761 CR769 CR774	5C 3E C C 8E 85C F G 2E 8J K 8G K K K K 8G K K K K K K K K K K K K K K K K K K K	5F 1C 0 2E 4E 4 3E 3E 3E 2F 1E 2F 2G F 2G 1E 1E	Q706 Q725 Q732 Q736 Q750 Q750 Q759 Q760 R701 R702 R703 R704 R705 R710 R715 R716 R716 R717 R718	5D 6L 3D 2F 4G 7H 6E 6E 4B 5D 8E 7E F 8E	5F G E 30 E G 33 G F F F F F F F F F F F 5F 5 2 E 10 E 1 E 1	R732 R733 R734 R735 R736 R736 R736 R738 R740 R741 R743 R743 R744 R745 R756 R756 R757 R758 R761 R762 R763 R765	2D 2E D 2C 1D 2F F 4 E 4 F 7 G E 4 G 7 K 6 K 6 L K 8 G	3E 2D = 1D 3E = 3F 3G 3G F 4G = 2G 2F 2F = 12E	R782 S701 U715A U745B U745B U745C U745C U745C U755B U755C U755C U755C U755C U755C U755C	6K 8C 8E 8K 7K 8H 8L 8L 8L 8L 8J 6L 8 8F	2F 2E 1E 2F 2F 2F 2F 1F 1F 1F 1F 1D 1E
C709 C710 C712 C713 C715 C722 C723 C724 C727 C733 C755 C767 CR758 CR761 CR762 CR769 CR773 CR774 J7	5C 3E C C E B SC F G E B K 8G K K 66 K K 1 F	5F 1C 2E 4E 4E 3E 3E 2F 2G 2F 2G 2F 2G 1E 1E 2D	Q706 Q725 Q732 Q736 Q737 Q759 Q760 R701 R702 R703 R704 R705 R710 R715 R716 R717 R718 R718 R719	5D 6L 3D 2F 4G 7H 6E 6E C 8 5 8 5 8 5 8 5 8 8 8 8 8 8 8 8	5F G E 3D E G 3G F F F F F F F 5D E D E E E	R732 R733 R734 R735 R736 R737 R738 R740 R741 R743 R744 R745 R756 R756 R756 R757 R758 R758 R761 R762 R763 R765 R765	2D 2E D 2C D F F F E F G E G G K K K G L K G 8H	3E 2D 55 1D 55 55 55 56 56 56 56 56 56 56 56 56 56	R782 S701 U715A U745B U745C U745D U745E U755A U755C U755C U755C U755C U755C V755C V755C V755C W75710 VR719	6K 8C 8E 8K 7K 8L 8L 8L 8L 8L 8L 8L 8L 8 5D	2F 2E IEF2F2F2F 2FF1FF1F 1FF1F 1F 1F 4G
C709 C710 C713 C715 C722 C723 C724 C727 C733 C755 C767 CR758 CR761 CR762 CR769 CR774	5C 3E C C 8E 85C F G 2E 8J K 8G K K K K 8G K K K K K K K K K K K K K K K K K K K	5F 1C 0 2E 4E 4 3E 3E 3E 2F 1E 2F 2G F 2G 1E 1E	Q706 Q725 Q732 Q736 Q750 Q750 Q759 Q760 R701 R702 R703 R704 R705 R710 R715 R716 R716 R717 R718	5D 6L 3D 2F 4G 7H 6E 6E 4B 5D 8E 7E F 8E	5F G E 30 E G 33 G F F F F F F F F F F F 5F 5 2 E 10 E 1 E 1	R732 R733 R734 R735 R736 R736 R736 R738 R740 R741 R743 R743 R744 R745 R756 R756 R757 R758 R761 R762 R763 R765	2D 2E D 2C 1D 2F F 4 E 4 F 7 G E 4 G 7 K 6 K 6 L K 8 G	3E 2D = 1D 3E = 3F 3G 3G F 4G = 2G 2F 2F = 12E	R782 S701 U715A U745B U745B U745C U745C U745C U755B U755C U755C U755C U755C U755C U755C	6K 8C 8E 8K 7K 8H 8L 8L 8L 8L 8J 6L 8 8F	2F 2E 1E 2F 2F 2F 2F 1F 1F 1F 1F 1D 1E



SWEEP GENERATOR & HORIZONTAL AMPLIFIER

 $\langle \mathbf{5} \rangle$





Scans by ArtekMedia © 2006

Static Sensitive Devices See Maintenance Section

COMPONENT NUMBER EXAMPLE Component Number A23, A2 R1234

Subassembly

Number (if used) Chassis-mounted components have no Assembly Number prefix—see end of Replaceable Electrical Parts List.

Assembl Numbe

Schematic Circuit

Number

5

A4—MAINS INPUT BOARD										
CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER	CIRCUIT NUMBER	SCHEM NUMBER					
0000										
C900 C903	7	FC001	-	R903	7					
	7	FS901	7	R904	7					
C904	7		_	R905	7					
C905	7	J901	7	R906	7					
C907	7	J902	7	R907	7					
CR901	7	L901	7	S901	7					
CR902	7	L902	7	S902	7					
CR903	7									
CR904	7	Q900	7	W903	7					
F901	7	R902	7							

Г

ί

FRONT PANEL CONTROLS DIAGRAM 6

ASSEM	BLY A1										
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION
J1 J2	1B 2B	1F 1E	J3 J5	3B 3L	12B 1B	J6	5L	1A			
Partial A1 a	lso shown on dia	agrams 2, 3, 4, 5,	, 7 and 8.	.		······································					
ASSEM	BLY A2			<u> </u>		·					
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION
AT1 AT51	2L 2L	5B 5D	J7	5B	2D	R3 R53	2L 2L	5B 5D			
Partial A2 a	lso shown on di	agrams 1, 5 and	8.		L		·	L		L	
ASSEM	BLY A3										
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
C2 C52 C377 C378 C383 C392 CR401 CR534 CR537 CR538 DS370 DS370 DS560	1 J 3 J 8 H 7 K 5 G 3 F 3 G 2 E 6 K 8 E 6 K	4C 4C 2E 2E 2F 2F 2B 2B 2B 2B 2B 2B 2B 2B 2B 2B 2B 2B 2B	J987** R2 R4 R52 R54 R84 R89 R92 R94 R123 R163 R173 R365 R376	8B 1J 1J 3J 3J 6E 5D 5C 5C 2D 2D 2D 2C 8F 8J	2A 4B 4C 4C 3C 2C 2D 2C 2D 2C 2D 2C 3A 3F	R377 R378 R379 R383 R426 R726 R800 R800 R800 R987 S90 S101 S201 S390	7J 8H 8K 4C 7C 1E 1E 8D 5E 1K 3K 1C	2F 2E 2F 1F 1E 2A 3A 2A 2C 3B 3C 2A	S392 S401 S460 S505 S555 S601 W1 W2 W3 W5 W6 W7	7J 5G 4D 4K 2G 4H 7F 1C 2C 3C 3L 6L 5C	3F 2F 1F 2C 2B 3F 2E 4A 4D 4E 4F 3D
		agrams 1, 2, 3, 4	and 8.								
CHASS		BOARD	CIRCUIT	SCHEM	BOARD	CIRCUIT	SCHEM	BOARD	CIRCUIT	SCHEM	BOARD
NUMBER			NUMBER			NUMBER			NUMBER		
J100 J151	1L 3L	CHASSIS CHASSIS	J300	8L	CHASSIS	R1 R51	1К 3К	CHASSIS CHASSIS	R382	7L	CHASSIS

**Not in Electrical Parts List

.

•

.

•

•

•

•

.

•

•

٠

•

Ъ

. .

•



FRONT PANEL CONTROLS \diamond

WAVEFORMS FOR DIAGRAM 7

AC Waveforms

SEC/DIV

20 µs







1 VOLT PER DIVISION EQUALS 1 AMP PER DIVISION FOR WAVEFORM 7F

POWER	SUPPLY,	Z-AXIS,	& CRT	DIAGRAM	7
-------	---------	---------	-------	---------	---

CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATIO
C824	 3D	6G	CR942	8J	8A	R832	1E	7Н	R946	8H	8A
C828	3E	7J	CR945	8ĸ	80	R834	3F	7J	R947	9H	9B
C832	1E	8H	CR946	8J	8A	R834	4F	7J	R948	7H	8B
C834	4F	7J	CR947	5K	10B	R835	3E	7J	R949	6K	10F
C835	3F	8.	CR950	5H	10B	R836	3E	7J	R955	6F	11B
C845	3F	8มี	CR975	5K	10E	R840	3F	8H	R956	7H	8B
C847	2G	8J	CR976	5K	11E	R841	2F	8H	R957	10H	9B
C849	1G	8J	CR980	6F	9D	R842	2G	8G	R958	7G	8B
C851	4H	7F	CR981	6E	9D	R843	3F	7J	R970	6E	100
C853	4J	8G	CR982	7L	9F	R844	2F	8J	R971	6J	80
C854	3J	8G	CR983	8L	9E	R845	2F	8J	R972	6E	9D
C855	2G	9G	CR984	8L	9E	R849	1G	8J	R977	5C	90
C871	4L	6F	CR985	8L	9E	R850	3H	8F	R978	4J	100
C875	зк	7G	CR986	9L	8C	R851	3H	6E	R979	3E	7J
C893	2L	9H	CR987	9K	80	R852	4H	6E	R980	6J	8C
C901	5B	6A	CR988	9K	8C	R853	4J	8G	R981	6D	9D
C902	5B	2A	CR989	9L	8C	R854	3J	8G	R982	6E	90
C914	8E	11C	CR990	7K	9E	R855	3H	6E	R983	5E	90
C915	9G	10D	CR991	7K	9E	R858	2J	10G	R984	2J	90
C920	10F	11D				R860	2H	10G	R984	5E	90
C925	9E	110	DS856	2H	10G	R870	4K	6F	R985	6D	90
C930	7F	11B	DS858	2H	. 10G	R871	3K	7G	R986	5D	90
C932	5E	10B				R874	ЗK	7G	R987	6D	9D
C933	6G	10B	L950	5H	9B	R875	3K	7G	R988	6D	9D
C935	6G	10B	L986	9L	7B	R888	3J	8G	R989	7D	9D
C941	7H	8B	L988	9L	80	R889	3J	8G	R990	10M	6E
C942	8J	8C	L990	7L	7E	R890	2J	8G	R991	10M	8E
C943	7J	8B			. –	R891	2J	9G	R992	10M	90
C945	эн	9B	P900**	5L	9G	R892	2J	9G	R995	5K	9E
C946	9.1	9B	P901**	4L	9G	R894	2J	9G			
C952	7E	8B	P902**	4L	9G	R899	5B	2A	T902	5K	9D
C974	3E	7J	P903**	4L	7F	R900	5B	2A			
C976	5J	11G				R901	5B	6A	U910A	8F	100
C979	4J	11G	Q804	3C	6G	R910	8H	9B	U910B	9F	100
C980	5K	10E	Q817	2C	5H	R911	8G	10C	U920	8D	110
C982	6E	10D	Q818	3C	4G	R912	8F	10C	U930	8F	108
C983	8L	7E	Q825	1D	7H	R913	8F	10C	U940	7G	7A
C984	8L	8F	Q829	2E	8H	R914	8E	11C			
C985	8L	8E	Q835	3F	8J	R915	9G	11D	VR915	9G	110
C986	9L	7B	Q840	3G	8H	R916	9G	10D	VR925	9D	100
C987	9M	7B	Q845	2G	8H	R917	9G	10D	VR932	5F	10E
C988	9L	70	Q932	6F	10A	R918	9G	11D	VR933	5F	10E
C989	9M	70	Q933	5G	10A	R919	10F	10C	VR982	6E	9D
C990	7L	8E	Q935	7G	10B	R920	9F	10C	VR985	5D	90
C991	7L	7D	Q939	6H	80	R922	9F	10C	VR988	7D	90
C992	10M	6E	Q941	7J	8A	R926	9D	11C			
		_	Q942	7J	8A	R927	8D	11C	W90	9M	6D
CR817	2C	6H	Q943	9H	9B	R928	8D	11D	W893	2L	9G
CR818	2D	6G	Q945	90	9A	R929	8E	11C	W903	6B	90
CR820	3D	6G	Q946	8J	9A	R930	7F	11B	W920	9E	100
CR824	1E	7H	Q982	6E	9D	R931	7F	11B	W921	10F	110
CR825	1E	7H	Q985	6E	90	R932	7F	11B	W925	10E	100
CR827	2E	7J	Q988	6D	9D	R933	6G	10B	W926	10E	100
CR828	3E	7J		-	_	R934	5F 4	10B	W947	7K	8B
CR829	2E	7H	R804	3C	5G	R935	7F	11B	W948	8K	8B
CR840	3F	8J	R805	2C	6G	R936	7G	9B	W951	5G	10A
CR845	2F		R818	2D	6G	R939	7H	8B	W976	5J	10F
CR851	3H	8F	R819	10	6G	R940	6J	8B	W984	8M	6E
CR853	3H	8G	R820	2D	6G	R941	ยั	8B	W985	8M	6E
CR854	2J	9G	R822	3D	2D	R942	7H	8A	W987	9M	6D
CR855	2H	9G	R823	3D	6G	R943	8H	8B	W989	9M	6C
CR933	7G	10B	R825	1D	6G	R944	9J	9B	W991	7M	6D
CR941	8K	8C	R830	2E	7H	R945	ູ	9B			

Partial A1 also shown on diagrams 2, 3, 4, 5, 6 and 8.

**Not in Electrical Parts List



FRONT PANEL CONTROLS

POWER SUPPLY, Z-AXIS, & CRT DIAGRAM 7 (CONT)

٠

.

.

ς.

ς.

ASSEM	BLY A4										
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION
C900 C903 C904 C905 C907 CR901 CR902 CR903	6C 9B 9C 8B 7B 7B 7B 7B 7B	2D 3C 3D 3B 1C 1D 1C 1C	CR904 F901 FS901 J901 J902	78 98 98 108 78	1C 1A 1A 2A 2B	L901 L902 Q900 R902 R903 R904	98 98 68 78 6C 68	3C 1B 1D 1D 1D 1D	R905 R906 R907 S901 S902 W903	68 78 78 9C 8C 68	1D 1D 1C 4C 4A 1D
CHASS	IS MOUNTE	ED PARTS									
CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION	CIRCUIT NUMBER	SCHEM LOCATION	BOARD LOCATION		SCHEM LOCATION	BOARD LOCATION
P902 P906 P910	7A 3L 2M	CHASSIS CHASSIS CHASSIS	R983	2L	CHASSIS	T901	7A	CHASSIS	V900	. 1N	CHASSIS

¢





2205

6716-40

POWER DISTRIBUTION (8)

 \diamond

Digitally Remastered by ArtekMedia © 2002-2006



Figure 9-11. Adjustment locations of A1—Main board component view.

6716-27





R804

C875

3978 3858



Figure 9-13. A2—Timebase/Attenuator board adjustment locations.



Figure 9-14. A3—Front Panel board adjustment location.

¢

REPLACEABLE MECHANICAL PARTS

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

ITEM NAME

In the Parts List, an item Name is separated from the description by a colon(:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

FIGURE AND INDEX NUMBERS

Items in this section are referenced by figure and index numbers to the illustrations.

INDENTATION SYSTEM

This mechanical parts list is indented to indicate item relationships. Following is an example of the indentation system used in the description column.

1 2 3 4 5 Name & Description

Assembly and/or Component Attaching parts for Assembly and/or Component

END ATTACHING PARTS

Detail Part of Assembly and/or Component Attaching parts for Detail Part

END ATTACHING PARTS

Parts of Detail Part Attaching parts for Parts of Detail Part

END ATTACHING PARTS

Attaching Parts always appear in the same indentation as the item it mounts, while the detail parts are indented to the right. Indented items are part of, and included with, the next higher indentation.

Attaching parts must be purchased separately, unless otherwise specified.

ABBREVIATIONS

Abbreviations conform to American National Standards Institute YI.I

i.

CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

lfr. Code	Manufacturer	Address	City, State, Zip Code
01536	TEXTRON INC		ROCKFORD IL 61108
	CAMCAR DIV SEMS PRODUCTS UNIT	1818 CHRISTINA ST	
06915	RICHCO PLASTIC CO	5825 N TRIPP AVE	CHICAGO IL 60646-6013
07416	NELSON NAME PLATE CO	3191 CASITAS	LOS ANGELES CA 90039-2410
2327	FREEWAY CORP	9301 ALLEN DR	CLEVELAND OH 44125-4632
13511	Amphenol cadre DIV Bunker Ramo Corp		LOS GATOS CA
16428	COOPER BELDEN ELECTRONIC WIRE AND CA SUB OF COOPER INDUSTRIES INC		RICHMOND IN 47374
57771	STIMPSON CO INC	900 SYLVAN AVE	BAYPORT NY 11705-1012
619 3 5	SCHURTER INC	1016 CLEGG COURT	PETALUMA CA 94952-1152
70903	COOPER BELDEN ELECTRONICS WIRE AND C SUB OF COOPER INDUSTRIES INC	2000 S BATAVIA AVE	GENEVA IL 60134-3325
1400	BUSSMANN DIV OF COOPER INDUSTRIES INC	114 OLD STATE RD PO BOX 14460	ST LOUIS MO 63178
73743	FISCHER SPECIAL MFG CO	111 INDUSTRIAL RD	COLD SPRING KY 41076-9749
75915	LITTELFUSE INC SUB TRACOR INC	111 INDUSTRIAL RD 800 E NORTHWEST HWY	DES PLAINES IL 60016-3049
78189		ST CHARLES ROAD	ELGIN IL 60120
30009		14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001
32330	WICKMAN CORP THE MICRODOT MFG INC	10325 CAPITAL AVE	OAK PARK MI 48237-3103
3385	MICRODOT MFG INC GREER-CENTRAL DIV	3221 W BIG BEAVER RD	TROY MI 48098
3486	ELCO INDUSTRIES INC	1101 SAMUELSON RD	ROCKFORD IL 61101
6113	MICRODOT MFG INC CENTRAL SCREW-KEENE DIV	149 EMERALD ST	KEENE NH 03431-3628
3907	TEXTRON INC CAMCAR DIV	600 18TH AVE	ROCKFORD IL 61108-5181
(1935	JERMYN DISTRIBUTION VESTRY ESTATE	OTFORD ROAD SEVENOAKS	KENT ENGL AN D
2504	RS COMPONENTS LTD	PO BOX 99	CORBY NORTHANTS NN17 9RS ENGLAND
3109	FELLER	72 Veronica Ave Unit 4	Summerset NJ 08873
K0174	BADGLEY MFG CO	1620 NE ARGYLE	PORTLAND OR 97211
K0433	PORTLAND SCREW CO	6520 N BASIN	PORTLAND OR 97217-3920
K0892	GEROME CORP	OLIVER RD PO BOX 1089	UNIONTOWN PA 15041
KOEC	CARON ENG. SERVICE	10-11 STATION CLOSE POTTERS BAR	HERTS ENGLAND
K0EH	HARLOW SPRINGS 1 + 2 ROYDONBURY IND EST	HARLOW	ESSEX ENGLAND
K0Ej	THE PINNACLES IMP WORKS	ESSEX ROAD	HERTS ENGLAND
K0EL	MOLBRY LTD	Hoddesddn Holland Way	DDRSET ENGLAND
K0E0	PLANET JIG & TOOL	BLANDFORD BAKER STREET	BUCKS ENGLAND
KOES	SMALL POWER MACHINE CO	HIGH WYCOMBE BATH ROAD	WILTSHIRE ENGLAND
KOET	INDUSTRIAL ESTATE WARTH INTERNATIONAL CHARLY MODE REFINESS CENTER	CHIPPENHAM CHARLWOODS ROAD	EAST GRINDSTEAD ENGLAND
V1210	CHARLWOODS BUSINESS CENTER	1910 16 TH AVE	EDDEST COOVE OD 07116
K1319	MORELLIS Q & D PLASTICS	1812 16-TH AVE	FOREST GROVE OR 97116
K1336	PARSONS MEG CORP	1055 OBRIEN	MENLO PARK CA 94025 VAICENTALLO 62/45S ITALY
K1373 K2165	PATELEC-CEM (ITALY) TRIQUEST CORP	10156 TORINO 3000 LEWIS AND CLARK HWY	VAICENTALLO 62/453 TTALT VANCOUVER WA 98661-2999
VC100	INIQUEST WORF	JUUU LEWIJ MNU ULAKN NWI	MILOUTLN WA 30001-2333

Fig. &		
Index	Tektronix	Seria
No	Part No.	Fffe

ig.& Index	Tektronix	Serial/Asser	boly No.			Mfr.
D.	Part No.	Effective	Discont	Qty_	12345 Name & Description	<u>Code Mfr. Part No.</u>
l-1	426-1765-02		_	1	FRAME, CRT: POLYCARBONATE, GRAY ATTACHING PARTS	TK2165 ORDER BY DESCR
-2	211 -0690-0 1			2	SCREW, MACHINE: 6-32 X 0.875 PNH, SST END ATTACHING PARTS	86113 ORDER BY DESCR
-3	337-2775-00			1	SHLD, IMPLOSION: FILTER, BLUE 2211/2213/2215	80009 337-2775-00
-4	348-0660-00			4	CUSHION, CRT: POLYURETHANE	80009 348-0660-00
-5	366-0636-00			5	KNOB: GRAY, 10MM X 12MM H	TKOEJ ORDER BY DESCR
-6	384-1575-00			1	EXTENSION SHAFT: 8.805 L, W/KNOB, PLASTIC	80009 384-1575-00
-7	358-0550-00			1	BUSHING, SHAFT: 0.15 ID X 0.488 L, PLSTC	TK2165 ORDER BY DESCR
-8	366-1480-03			1	PUSH BUTTON: BLACK, OFF	80009 366-1480-03
-9	384-1364-00			1	EXTENSION SHAFT: 10.818 L X 0.187 SQ, NYL, BLK	TK2165 ORDER BY DESCR
-10	331-0498-00			2	DIAL, CONTROL: 32MM X 3.75MM, MKD 1 THRU 50	TKOEJ ORDER BY DESCR
-11	210-1436-00			2	WASHER, FLAT: 9.4MM ID X 12.5MM OD X 2MM THK, ALUMINUM	TKOEL ORDER BY DESCR
-12	366-0640-00			3	KNOB GRAY CAL W/ARROW 10MM X 2MM X 12MM H	TKOES ORDER BY DESCR
-13	331-0499-00			1	DIAL, CONTROL: 32MM X 3.75MM, MKD 2 X LINES	TKOEJ ORDER BY DESCR
-14	366-0635-00			2	PUSH BUTTON: GRAY, 4.45MM X 7.75MM X	TKOEJ ORDER BY DESCR
-15				1	TERM. FEEDTHRU: (SEE J590 REPL)	
-16				3	CONN, RCPT, ELEC: BNC, FEMALE (SEE J100, J151, J300 REPL)	
-17	210-0255-00			3	TERMINAL, LUG: 0.391 ID, LOCKING, BRS CD PL	12327 ORDER BY DESCR
-18	386-5483-00			1	SUBPANEL, FRONT:	TKOEJ ORDER BY DESCR
-19	333-3565-00			ī	PANEL . FRONT :	80009 333~3565-00
-20	334-7234-00			1	MARKER, IDENT: MARKED VOLTAGE/FUSE SELECT	80009 334-7234-00
-21	334-7088-00			1	MARKER, IDENT: MARKED CAUTION	80009 334-7088-00
-22	200-3335-01			ī	COVER, REAR: ATTACHING PARTS	80009 200-3335-01
-23	211-0712-00			2	SCR, ASSEM WSHR:6-32 X 1.25, PNH, STL, TORX END ATTACHING PARTS	01536 ORDER BY DESCR
-24	343-1278-00			2	RTNR, POWER CORD: POLYCARBONATE GRAY	TK2165 ORDER BY DESCR
-25	348-0964-00			2	FOOT, REAR COVER: BLACK, PLASTIC	TKOEJ ORDER BY DESCR
-26	437-0370-01			1	CABINET, SCOPE: ATTACHING PARTS	TKOED ORDER BY DESCR
-27	211-0730-00			4	SCR, ASSEM WSHR:6-32 X 0.375, PNH, STL CD PL, TORX T15 END ATTACHING PARTS	80009 211-0730-00
-28	367-0356-00			1	HANDLE, CARRYING: ATTACHING PARTS	TKOEJ ORDER BY DESCR
-29	212-0144-00			2	SCREW, TPG, TF:8-16 X 0.562 L, PLASTITE, SPCL HD	93907 225-38131-012
-30	214-3984-00			2	END ATTACHING PARTS SPRING,HLCPS:0.71 OD X 12.0MM L,OPEN ENDS	TKOEH ORDER BY DESCR

¢

.

•

•





Fig.& Index No.	Tektronix Part No.	Serial/A Effecti	ssendo)y No. ve Dscont	Qty	12345 Name & Description	Mfr. Code	Mfr. Part No.
2-1	441-1752-01						
2-1	441-1/52-01			1	CHASSIS, SCOPE: FRONT ATTACHING PARTS	TK0E0	ORDER BY DESCR
-2	211-0718-00			2		83486	ORDER BY DESCR
-2.1	213-0882-00			1	SCREW, MACHINE: 6-32 X 0.312, FLH, 100 DEG, STL SCREW, TPG, TR: 6-32 X 0.437 TAPTITE, PNH, STL END ATTACHING PARTS	83385	ORDER BY DESCR
-3	337- 33 97 -0 0			1	SHIELD, ELEC: CH1, CH2 SEPARATION	TKOE0	ORDER BY DESCR
-4	407-3714-00			1	BRKT,CRT SPRT:REAR ATTACHING PARTS		407-3714-00
-5	211-0730-00			3	SCR,ASSEM WSHR:6~32 X 0.375,PNH,STL CD PL, TORX T15 END ATTACHING PARTS	80009	211-07 3 0-00
-6	214-1061-06			1	SPRING GROUND CRT SHIFLD	80009	214-1061-06
-7	426-1766-00			ī	SPRING, GROUND:CRT SHIELD MOUNT, RESILIENT:CRT, REAR SKT. PL-IN ELEK:CRT.14 PIN.CABLE ASSY	80009	426-1766-00
-8				ĩ			
-9	337 -346 8-00	HK10100	HK10499	1	SHIELD, CRT:	80009	337-3468-00
	337- 346 8-01	HK10500		1	SHIELD, ELEC: 2205 MAGNETIC METAL	TK0892	ORDER BY DESCR
-10	334-1379- 0 0			1	MARKER, IDENT: MKD HI VACUUM	07416	ORDER BY DESCR
-11	386-5360-00			1			337-3468-00 ORDER BY DESCR ORDER BY DESCR ORDER BY DESCR
-12	211-0730-00			1	SCR, ASSEM WSHR: 6-32 X 0.375, PNH, STL CD PL, TORX T15		211-0730-00
	213-0882-00			1	SCREW, TPG, TR:6-32 X 0.437 TAPTITE, PNH, STL END ATTACHING PARTS	83385	ORDER BY DESCR
-13				1	CIRCUIT BD ASSY:TIMEBASE/ATTEN (SEE A2) ATTACHING PARTS		
-14	211-0730- 0 0			4	SCR, ASSEM WSHR:6-32 X 0.375, PNH, STL CD PL, TORX T15		
-15	210-0457-00			2	NUT, PL, ASSEM WA:6-32 X 0.312, STL CD PL END ATTACHING PARTS	78189	511-061800-00
-16	376-0224-01			1	CPLG, SHAFT, RGD: W/213-0153-00	TKOEC	ORDER BY DESCR
-17 -18	384-1714-00	1,		1 1	END ATTACHING PARTS CPLG, SHAFT, RGD:W/213-0153-00 EXTENSION SHAFT:133MM L X 2MM OD, SST CIRCUIT BD ASSY:FRONT PANEL (SEE A3 REPL) ATTACHING PARTS	80009	384-1714-00
-19	211-0305-00			6	SCR, ASSEM WSHR:4-40 X 0.437, PNH, STL, CD PL END ATTACHING PARTS		ORDER BY DESCR
-20	337-3365-00			1	SHIELD, ELEC: ATTENUATOR ATTACHING PARTS	TKOE0	ORDER BY DESCR
-21	211-0730-00			3	SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL CD PL, TORX T15 END ATTACHING PARTS	80009	211-0730-00
-22	129-1105-00			2		TKOFI	ORDER BY DESCR
	129-1106-00			1	SPACER, POST:23.5MM L,4-40 BOTH ENDS,AL,HEX SPACER, POST:25.4MM L,W 6-32 THD THRU,BRASS, 6.3MM HEX	TKOEL	ORDER BY DESCR
-23	211-0325-00			1	SCR, ASSEM WSHR: 4-40 X 0.25, PNH, STL, TORX T9	01536	ORDER BY DESCR
-24	337-3364-01			2	SHIELD, ELEC: POWER SUPPLY		ORDER BY DESCR
-25				1	RES, VAR, NONWA: (SEE R893 REPL)		
-26 -27	384-1710-00 441-1751-02	HK10100	HK11183	1 1	EXTENSION SHAFT:13MM X 7MM OD,W/STEP,4MM ID CHASSIS,SCOPE:INNER		ORDER BY DESCR 441-1751-02
-29	211-0730-00			2	ATTACHING PARTS SCR,ASSEM WSHR:6-32 X 0.375, PNH, STL CD PL, TORX T15	80009	211-0730-00
-30				1	END ATTACHING PARTS CIRCUIT BD ASSY:MAIN INPUT (SEE A4 REPL) ATTACHING PARTS		
-31	211-0730-00			4	SCR,ASSEM WSHR:6-32 X 0.375, PNH, STL CD PL, TORX T15	80009	211-0730-00
-32	211-0730-00			6	SCR,ASSEM WSHR:6-32 X 0.375, PNH, STL CD PL, TORX T15	80009	211-0730-00
-33	210-0457-00			2	NUT, PL, ASSEM WA: 6-32 X 0.312, STL CD PL END ATTACHING PARTS	78189	511-061800-00
-34	337-3484-00			1	SHIELD, ELEC: MAINS INPUT	80009	337-3484-00
-35	358-0281-00			1	GROMMET, PLASTIC: BLACK U-SHAPED, 0.375 ID	TK1319	
-36	200-3647-00			i	CAP, FUSE: USE W/0.25 X 1.25 FUSE		345-101-020
	200-3648-00			1	CAP, FUSE: USE W/5 X 20MM FUSE	75915	345-121-020
-37	352 -089 5- 0 0			1	FUSEHOLDER:15 A,250V	7 59 15	345-101-010
-38				1	XFMR, PWR, STDN: (SEE T901 REPL) ATTACHING PARTS		

Fig. &						
Index <u>No.</u>	Tektronix Part No.	Serial/Assembly No. Effective Dscont	Qty	12345_ Name & Description	Mfr. Code	Mfr. Part No.
2-39	212-0093-00		4	SCREW, MACHINE:8-32 X 2.625, HEX HD, STL		ORDER BY DESCR
-40	22 0-05 55-00		4	NUT, PLAIN, HEX: 8-32 X 0.25 HEX, STL CD PL		ORDER BY DESCR
	210-0409-00	HK10500	4	NUT, PLAIN, HEX: 8-32 X 0.312, BRS CD PL		3046-402
	210-0007-00		4	WASHER, LOCK: #8 EXT, 0.02 THK, STL END ATTACHING PARTS	78189	1108-00-00-0541C
-41	361-0561-00		4	SPACER, SLEEVE: 0.95 L X 0.218 ID, AL	80009	361-0561-00
-42			1	CIRCUIT BD ASSY:MAIN (SEE A1 REPL) ATTACHING PARTS		
-43	211-0730-00		5	SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL CD PL, TORX T15	8 000 9	211-0730-00
-44	210-0457-00		5	NUT, PL, ASSEM WA: 6-32 X 0.312, STL CD PL		511-061800-00
-45	407-3 539 -0 0		1	.BRACKET, HEAT SK: ALUMINUM ATTACHING PARTS		ORDER BY DESCR
-46	211-0730-00		1	.SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL CD PL, .TORX T15		211-0730-00
-47	213-0882-00		1	.SCREW, TPG, TR:6-32 X 0.437 TAPTITE, PNH, STL END ATTACHING PARTS	83385	ORDER BY DESCR
-48			3	.TRANSISTOR:(SEE A1Q933,Q942,Q946 REPL) ATTACHING PARTS		
-49	211-0305-00		3	.SCR,ASSEM WSHR:4-40 X 0.437,PNH,STL,CD PL		ORDER BY DESCR
-50	210-0586-00		3	.NUT,PL,ASSEM WA:4-40 X 0.25,STL CD PL END ATTACHING PARTS		211-041800-00
-51	342-0829-00		3	. INSULATOR, PLATE: TRANSISTOR, SIL-PAD		ORDER BY DESCR
	342-0804-00		3	.INSULATOR, WSHR: 5.6MM OD X 3.0MM ID X 1.6MM .THK, NYLON	80009	342-08 04- 00
-52	214-4112-00		1	HEAT SINK:ALUMINUM, 2205 ATTACHING PARTS		214-4112-00
-53	211-0730-00		2	.SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL CD PL, .TORX T15 END ATTACHING PARTS	80009	211-0730-00
-54	214-4039-00		4	.HEAT SINK, XSTR: TO-5, ALUMINUM		J25-1204
-55	361-1435-00		4	.SPACER, XSTR: POLYPROPYLENE, TO-5		402-175
-56	441-1830-00		1	CHASSIS, SCOPE: REAR, ALUMINUM ATTACHING PARTS	80009	441-1830-00
-57	211-0718-00		2	SCREW, MACHINE: 6-32 X 0.312, FLH, 100 DEG, STL END ATTACHING PARTS	83486	ORDER BY DESCR
-58	134-0202-00		1	PLUG, BUTTON: STEEL	57771	
	334-7256-00		1	MARKER, IDENT: MARKED CAUTION (A101D139)		334-7256-00
	33 7-3 384 -0 0		7	ŠHIELD, ELÉC: (A10ID49)	TKOEJ	ORDER BY DESCR
	337-3385-00		7	SHIELD, ELEC: (A10ID50)	TK0EJ	ORDER BY DESCR
	337-3422-00		3	(AlODD21)	TK0EJ	ORDER BY DESCR
	342-0803-00		2	(AIGIDIEI) INSULATOR, WSHR:6.4MM OD X 2.54MM ID X 4.5MM THK, POLYPROPYLENE (AIGIDIEI)	80009	342-0803-00

i

Fig.& Index No	Tektronix Part_No.	Serial/A Effecti	ussendbìy No. ve Disc <u>ont</u>	Qty	12345	Name & Description	Mfr. Code	Mfr. Part No.
3-								
					S	STANDARD ACCESSORIES		
	070-6717-00			1	MANUAL	, TECH: OPERATORS, 2205	80009	070-6717-00
	103-0275-00			2	ADAPTE	R,CONN:X1 SIGNAL	80009	103-0275-00
	159-0121-00			1	FUSE, C	ARTRIDGE:DIN,0.4A,250V,5SEC	61935	FSF034.1512
	159-0182-00			1	FUSE,C	ARTRIDGE:5 X 20MM,0.5A,250V,FAST BLOW	82330	19200 .5A
	159-0032-00	HK10100	HK10499	1		ARTRIDGE: 3AG, 0.5A, 250V, SLOW BLOW		MDL 1/2
-1	161-0104-00			1		ASSY, PWR, : 3 WIRE, 98.0 L, W/RTANG CONN		CH8352, FH-8352
-2	343-0003-00			1		LOOP:0.25 ID,PLASTIC		E4 CLEAR ROUND
-3	211-0721-00			1		MACHINE: 6-32 X 0.375, PNH, STL		ORDER BY DESCR
-4	210-0803-00			1		,FLAT:0.15 ID X 0.375 OD X 0.032,STL	12327	
	020-0859-00		HK10499	1		ENT KIT: EUROPEAN	80009	
-	020-1684-00	HK10500		1		ENT KIT: EUROPEAN POWER CORD ASSY	80009	
-5	161-0104-06			1		ASSY, PWR, :3 X 0.75MM SQ, 220V, 98.0 L	S3109	ORDER BY DESCR
	020-0860-00	LIV10100	HK10499	ī		ON A1 ONLY) ENT KIT:UNITED KINGDOM	80009	020-0860-00
	020-1685-00		HK10499	1		ENT KIT: UNITED KINGDOM PWR CORD AS		020-1685-00
-6	161-0104-07	1110300		1		ASSY, PWR, :3 X 0.75MM SQ, 240V, 98.0 L		A25UK-RA
-0	101-0104-0/			1		ASST, FWR, 13 X 0.7544 50,2404,50.0 E	1813/3	ACJUNTA
	020-0861-00	HK10100	HK10499	1		ENT KIT: AUSTRALIAN	80009	020-0861-00
	020-1686-00		11120-000	1		ENT KIT: AUSTRALIAN PWR CORD ASSY		020-1686-00
-7	161-0104-05			1		ASSY, PWR, :3,18 AWG, 240V, 98.0 L	S3109	
				-		ON A3 ONLY)		
	020-0862-00	HK10100	HK10499	1	•	ENT KIT:NORTH AMERICAN	80009	020-0862-00
	020-1687-00			1		ENT KIT: NORTH AMERICAN PWR CORD AS		020-1687-00
-8	161-0104-08			1		ASSY, PWR, :3,18 AWG, 240V, 98.0 L		ORDER BY DESCR
					. (OPTIC	ON A4 ONLY)		
	020-0863-00	HK10100	HK10499	1	COMPONE	ENT KIT:SWISS	80009	020-0863-00
	020-1688-00	HK10500		1	COMPONE	ENT KIT:SWISS POWER CORD ASSY		020-1688-00
-9	161-0167- 0 0			1		ASSY, PWR, :3.0 X 0.75, 6A, 240V, 2.5M L	S3109	ORDER BY DESCR
					.(OPTIC	ON AS ONLY)		
						MPONENT KIT CONTAINS THE APPROPRIATE		
						CORD, 159-0032-00 FUSE CARTRIDGE,		
						03-00 LOOP CLAMP, 211-0721-00 SCREW,		
					AND 210)-0803-00 WASHER.		
					OP	PTIONAL ACCESSORIES		
	016 0100 00			•			THOLOS	
	016-0180-00			1	•	CRT: FOLDING		ORDER BY DESCR
	016-0566-00			1	VISOR,C			ORDER BY DESCR
	016-0592-00			1 1	VISOR, C			ORDER BY DESCR
	016-0677-02			T	OPTION	CCESSORY:W/PLATE	150174	016-0677-02
	016-0785-00			1	• •	RY KIT: MOUNTING, 1107 TO 2200	80009	016-0785-00
	016-0792-01			1		RRYING:24.5 X 16.5 X 11.5		ORDER BY DESCR
				-	(OPTION		112000	SAGER DI DEGOR

ĩ

016-0/85-00	1	ACCESSORY KIT: MOUNTING, 11
016-0792-01	1	CASE, CARRYING: 24.5 X 16.5
		(OPTION 1T)
016-0819-02	1	ADAPTER, RACK: RACKMOUNT
		(OPTION 1R)
020-1514-00	1	ACCESSORY KIT:
070-6716-00	1	MANUAL, TECH: SERVICE, 2205
200-3397-00	1	COVER, SCOPE: FRONT
		(OPTION 02)
337-2775-01	1	SHLD, IMPLOSION:

REV JAN 1990

•

80009 016-0819-02

80009 020-1514-00 80009 070-6716-00 80009 200-3397-00

80009 337-2775-01



At Tektronix, we continually strive to keep up with latest electronic developments by adding circuit and component improvements to our instruments as soon as they are developed and tested.

Sometimes, due to printing and shipping requirements, we can't get these changes immediately into printed manuals. Hence, your manual may contain new change information on following pages.

A single change may affect several sections. Since the change information sheets are carried in the manual until all changes are permanently entered, some duplication may occur. If no such change pages appear following this page, your manual is correct as printed.

ç

.

.



Page 1 of 1



Date: 2-15-89

Change Reference:

Product: 2205 SERVICE

Manual Part Number: _

M67537 070-6716-00

DESCRIPTION

Product Group 46

SEE BELOW FOR EFFECTIVE SERIAL NUMBERS:

REPLACEABLE ELECTRICAL PARTS LIST CHANGES

ADD:

A2CR14 151-0141-02 HK10100 A2CR64 151-0141-02 HK10100 SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35 SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35

REPLACEABLE MECHANICAL PARTS LIST CHANGES

CHANGE TO:

- 2-9
- 337-3468-01 HK10500

1 SHIELD,CRT:

DIAGRAM CHANGES

DIAGRAM VERTICAL ATTENUATORS

> Add diodes CR14 and CR64 to pins 2 and 3 of U30 and U80 respectively as shown with the partial schematics. Schematic locations are 2G and 6G.







Page 1 of 1



Date: 01-20-90

Change Reference: _____

M67539 070-6716-00

Product: 2205 SERVICE

_____ Manual Part Number: _____

Product Group 46

EFFECTIVE SERIAL NUMBER: HK10500

REPLACEABLE ELECTRICAL PARTS LIST CHANGES

DESCRIPTION

CHANGE TO:

U940 U540 156-0366-00 156-0388-00 4013DUAL FLIP-FLOP 74LS74N DUAL FLIP-FLOP

REPLACEABLE MECHANICAL PARTS LIST CHANGES

REMOVE:

Fig. & Index	Part Number	Qty	Name & Description	
	342-0804-00	3		
	211-0305-00	6		
ADD:				
	211-1178-00	3	Washer, shoulder: u/w TO-220 transistor	
	211-0304-00	6	4-40 X .312, pan head, T9 torx	

NOTE

To keep the vertical output transistors cool add a thin layer of thermal grease #249 thermalloy (006-2655-00) on the cases of vertical output transistors Q236, Q237,Q238, Q239 and on both sides of the white washer which is part of (214-4039-00) that is shown as item 54 in exploded view Fig.2 of the service manual.

EFFECTIVE SERIAL NUMBER: HK10700

A3 FRONT PANEL CIRCUIT BOARD ASSEMBLY

CHANGE TO:

C378

281-0767-00

CAPACITOR, 330 pF, 20%, 100V.

Page 1 of 3



Date: 01-20-90

Change Reference: _____M67539

Manual Part Number: ____070-6716-00

Product: 2205 SERVICE

DESCRIPTION

Product Group 46

DIAGRAM CHANGES



Change the value of capacitor C378 (location 8H) to 330 pF.

EFFECTIVE SERIAL NUMBER: HK11110

REPLACEABLE ELECTRICAL PARTS LIST CHANGES

DELETE:

L712	120-1631-00
L713	120-1631-00
L93	120-1631-00
L96	120-1631-00
E90	276-0752-00
E91	276-0752-00
E92	276-0752-00
E93	276-0752-00

CHANGE TO:

L93	R97	307-0106-00 RESISTOR, FIXED; 4.7 Ω, 5% 1/4W.
L96	R96	307-0106-00 RESISTOR, FIXED; 4.7 Ω, 5% 1/4W.
E90	R92	307-0106-00 RESISTOR, FIXED; 4.7 Ω, 5% 1/4W.
E91	R93	307-0106-00 RESISTOR, FIXED; 4.7 Ω, 5% 1/4W.
E92	R94	307-0106-00 RESISTOR, FIXED; 4.7 Ω, 5% 1/4W.
E93	R95	307-0106-00 RESISTOR, FIXED; 4.7 Ω , 5% 1/4W.
L712	W712	131-0566-03 DUMMY RESISTOR.
L713	W713	131-0566-03 DUMMY RESISTOR.

FIG. 9–7 A2 TIMEBASE/ATTENUATOR BOARD.

CHANGE TO:

L712	W712 grid location (1C).
L713	W713 grid location (1C).
L93	R97 grid location (1B).
L96	R96 grid location (1C).
E90	R92 grid location (1A).
E91	R93 grid location (1B).
E92	R94 grid location (1A).
E93	R95 grid location (1B).

Page 2 of 3



Date: 01-20-90

Change Reference: _

M67539

Product: 2205 SERVICE

____ Manual Part Number: __

ber: <u>070-6716-00</u>

DESCRIPTION

Product Group 46

DIAGRAM CHANGES

DIAGRAM 1 VERTICAL ATTENUATORS

Change the value and circuit number of L93 (location 7B) to R97 4.7 Ω . Change the value and circuit number of L96 (location 7B) to R96 4.7 Ω . Change the value and circuit number of E90 (location 8B) to R92 4.7 Ω . Change the value and circuit number of E91 (location 7B) to R93 4.7 Ω . Change the value and circuit number of E92 (location 8B) to R94 4.7 Ω . Change the value and circuit number of E93 (location 7B) to R95 4.7 Ω .





Date: 5-2-89

Change Reference: M68110 Manual Part Number:

070-6716-00

Product: 2205 SERVICE

Product Group 46

DESCRIPTION **EFFECTIVE SERIAL NUMBER: HK11184 REPLACEABLE ELECTRICAL PARTS LIST CHANGES** (CHASSIS PARTS) CHANGE TO: R893 311-2444-00 RES, VAR, NONWW: TRMR, 2.2M OHM, 30% **REPLACEABLE MECHANICAL PARTS LIST CHANGES REMOVE:** Fig. & Part Number Qty Name & Description Index 384-1710-00 EXTENSION SHAFT: 13MM X 7MM OD,W/STEP,4MM ID 2-26 1



Date: 3-20-90

Change Reference: C2/0390

Manual Part Number: _____070-6716-00

Product: 2205 OSCILLOSCOPE SERVICE

DESCRIPTION

Product Group 46

EFFECTIVE SERIAL NUMBER: ALL

TEXT CHANGES

PAGE 1-4

CHANGE TO:

Table 1-1 (cont)

Characteristics		Performance Requirements			
Sweep Linearity	Mag	nified			
	X1	X10			
	±7%1	± 10% ²			
		red over any 2 of the c red over any 2 of the c	center 8 divisions. enter 8 divisions, excluding the		

PAGE 4-6

CHANGE:

Step 1, parts d and h.

- d. CHECK Timing accuracy is within 3% (0.24 division at the tenth vertical graticule line) and linearity is within 7% (0.14 division over any 2 of the center 8 divisions).
- h. Use the Horizontal POSITION controls to align the first time marker that is 40 ns beyond the start of the sweep with the second vertical graticule line.

PAGE 4-7

CHANGE:

Step 1, part i.

i. CHECK – Timing accuracy is within 4% (0.32 division at the tenth vertical graticule line) and linearity is within 10% (0.2 division over any 2 of the center 8 divisions). Exclude any portion of the sweep past the 50th magnified division.

PAGE 5-14

CHANGE:

Step 8, parts e, i, and j.

- e. CHECK -- Timing accuracy is within 3% (0.24 division at the tenth vertical graticule line) and linearity is within 7% (0.14 division over any 2 of the center 8 divisions).
- i. Use the Horizontal POSITION controls to align the first time marker that is 40 ns beyond the start of the sweep with the second vertical graticule line.
- j. CHECK Timing accuracy is within 4% (0.32 division at the tenth vertical graticule line) and linearity is within 10% (0.2 division over any 2 of the center 8 divisions). Exclude any portion of the sweep past the 50th magnified division.

Page 1 of 1

Scans by ArtekMedia © 2006