
2430A

DIGITAL OSCILLOSCOPE USER REFERENCE GUIDE






Copyright  $\circledcirc$  1989 Tektronix, Inc. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and trademarks of Tektronix, Inc.



Printed in U.S.A. Specification and price change privileges are reserved.

### **INSTRUMENT SERIAL NUMBERS**

Each instrument has a serial number on a panel insert, tag, or stamped on the chassis. The first number or letter designates the country of manufacture. The last five digits of the serial number are assigned sequentially and are unique to each instrument. Those manufactured in the United States have six unique digits. The country of manufacture is identified as follows:

B000000	Tektronix, Inc., Beaverton, Oregon, USA
G100000	Tektronix Guernsey, Ltd., Channel Islands
E200000	Tektronix United Kingdom, Ltd., Marlow
J300000	Sony/Tektronix, Japan
H700000	Tektronix Holland, NV, Heerenveen, The Netherlands
HK00000	Tektronix, Inc., Hong Kong
	·

First Printing May 1989 Revised June 1989

# Contents

Complete Service Services			Page
		Preface	iii
	1	Getting Started/Front Panel	1
	2	CRT Readout Display	4
	3	STATUS Menu	5
	4	Powering Up	<i>7</i>
	5	CRT Display Menus	10
	6	Auto Setup	12
	7	PRGM AutoStep	14
	8	Measure	17
	9	Output	21
	10	Vertical	23

11	Horizontal	26
12	Cursors	27
13	Delay Functions	30
14	Triggering	,32
15	A Triggering	36
16	B Triggering	38
17	Acquisition	41
18	Save and Display Reference	43
19	GPIB Status	45



Figui	re	Page
1	Front Panel Buttons and Controls	. 3
2	CRT Readout Display	. 4
3	Status Menu Display	. 5
4	POWER and MENU OFF Button	. 7
5	INTENSITY Control, SELECT and STATUS/HELP Buttons	10
6	AUTO SETUP Button	. 12
7	PRGM Button	. 14
8	MEASURE Button	. 18
9	OUTPUT Button	. 21
10a	Vertical Buttons and Controls	. 23
10b	Vertical Buttons and Controls	. 24
11	Horizontal Buttons and Controls	. 26
12	Cursor Buttons and Controls	. 27
13	Delay Buttons and Controls	. 30
14	Trigger CPLG, SET VIDEO, and SET WORD Buttons	32
15	Trigger SOURCE, INIT @50%, and TRIG STATUS Buttons	34
16	A Trigger MODE, TRIG POSITION, A/B TRIG Buttons	36
17	B Trigger A/B TRIG, CPLG, INIT @50%, MODE, TRIG POSITION SOURCE Buttons	. 38
18	Storage ACQUIRE Button	. 40
19	Storage SAVE and DISPLAY REF Button	43

# SAFETY NOTE

This manual is a quick reference guide to the 2430A features. It does not replace the 2430A Operators manual. The 2430A Operators manual contains information related to safe use of this instrument as well as information necessary to prevent damage to the instrument or to other property. Users should refer to the 2430A Operators manual before operating this instrument. In particular, read the Operators Safety Summary at the beginning of the Operators manual, and "Preparation for Use" in Section 1.

### **GETTING STARTED**

See Front Panel (Figure 1) for locating the controls on the 2430A.

### Power On

200 - 100 PM

Press the POWER switch, located on the front panel below the CRT.

The 2430A performs a power-on test each time it is turned on. When the test progresses to the point of being able to display, the message "RUNNING SELF TEST" is shown on the CRT. At the end of the self test, the message is removed.

If the 2430A fails the self test, it will enter the extended diagnostics (see "MENU OFF/EXTENDED FUNCTIONS" below for explanation). The 2430A may still be usable if the failed area does not affect the measurements to be made. Press MENU OFF to exit extended diagnostic and enter Scope mode.

The CAL/DIAG menu displays the message "NOT WARMED UP" for ten minutes after each power-on.

### Menu Off/Extended Functions

In the CAL/DIAG menu, PASS or FAIL indicates the results of the last calibration or self diagnostic run. No label will appear if calibration has not been run since the last cold start.<sup>a</sup> If an "UNCALD" message appears in the extended diagnostics menu, it may indicate that the last attempt of extended calibration failed. In this case, allow the 2430A to warm up and do a SELF CAL. If the UNCALD message persists after a SELF CAL or some other area has failed, the previous calibration constants will not be overwritten, and the scope may be used. However, calibration should be checked by referring the instrument to a qualified service person. Press MENU OFF to exit extended diagnostics and enter Scope mode. More information on the self test and diagnostics is found in Appendix A of the Operators Manual.

<sup>a</sup>Cold Start is a complete initialization of the system, done only at the factory.



### Initialization

Connect a standard accessory probe to the CH 1 input BNC.

Connect the probe tip to the CALIBRATOR loop; connect the probe ground lead to scope ground.

Press the PRGM SETUP button, located below the A AND B SEC/DIV knob.

Select INIT PANEL menu choice by pressing the bezel button directly below the INIT PANEL menu label.

The initial settings for major front-panel controls are as follows:

**VERTICAL MODE** 

CH 1

CH 1 and CH 2 VOLTS/DIV

1V (With 10X probe)

A AND B SEC/DIV

1 ms

TRIGGER MODE

AUTO LEVEL

TRIGGER SOURCE

VERT (CH 1)

Input Coupling

1 MΩ DC

STORAGE MODE

ACQUIRE

ACQUIRE MODE

NORM

Verify that CH 1 Vertical Mode is selected (CH1 VOLT/DIV readout is in upper left corner of CRT). If CH 1 Vertical Mode is not selected, press Vertical MODE button and select CH 1 (see Section 10, Vertical Mode).

Press ACQUIRE button on front panel.

#### NOTE

Connecting a probe to the signal source and pressing the Auto Setup frontpanel button will provide a scaled and triggered display. If no vertical channel is selected AUTO Setup will default to Channel 1. Auto Setup will not change the channel selected if either or both of the two channels are on. If the display intensity is set too low and the scaled display is not easy to see, Auto Setup boosts intensity so the display can be seen. Auto Setup does not affect readout or graticule intensity.

# FRONT PANEL




Figure 1. Front Panel buttons and Controls.

### CRT READOUT DISPLAY




Figure 2. CRT Readout Display.

### STATUS MENU




Figure 3, Status Menu Display.

The Status Menu display will appear on screen when the STATUS/HELP frontpanel button is selected. It provides an overview of instrument configuration at the time the selection is made. This menu will enable you to determine if you are currently operating in the desired modes, or if you are set in a conflicting mode (causing the instrument to appear to operate incorrectly). Special attention should be paid to the TRIGGER STATUS comment and the ACQ MODE statement in the lower-left quadrant of the screen, which enables you to determine the instrument's current activity.

You should become very familiar with this entire menu and the location and meaning of the readout characters. They will help you determine the cause of possible operational difficulties.

### **POWERING UP**

(1)**POWER** Button

Does a power-on self test with each turn on. (See Section 1 for a more detailed description of POWER.)

(2)MENU **FUNCTIONS** Button

Turns off any displayed menu or turns on the OFF/EXTENDED EXTENDED FUNCTIONS menu if a menu is not being displayed. When pressed to remove a menu display, all the scope hardware is reset to match the soft frontpanel settings. Messages sent via GPIB will be erased. (See Section 1 for more a detailed description of MENU OFF/EXTENDED FUNCTIONS.)




Figure 4. POWER and MENU OFF Button.

#### Menu Off/Extended Functions Menu

#### 2. MENU OFF/EXTENDED **FUNCTIONS**

Turns off any menu being displayed or, if none is on, calls up the EXTENDED FUNCTIONS menus. See Appendix A in the Operators Manual for the Extended Functions Calibration and Diagnostics menus.

#### **EXT FUNCT**

SYSTEM SPÉCIAL CAL/DIAG

Second-level menu for SYSTEM.

**PREFLT** 

**PANEL** 

MISC

ON!OFF

VIDEO OPT

Third-level menu for PANEL.

----TEKSECURE----

PWR ON

**ERASE** 

LASTIINIT

MEMORY

Fourth-level menu for TEKSECURE ERASE MEMORY. WARNING: WFM & PRGM MEMORY WILL BE ERASED.

ERASE

Third-level menu for MISC.

ROLL

BELL ON!OFF

TRIG T **AUTO** ON:OFF

PROBE

MENU ONIOFF

Fourth-Level menu for AUTO PROBE.

SELECT PROBE IDENTIFY FUNCTION

**AUTO** 

STEP

SAVE/

SETUP INIT@50% ACQUIRE PRGM

Third-level menu for SYSTEM VIDEO OPT.

TV SYS

CNT RST

MINON/M BOTHIF1

Second-level menu for SPECIAL.

WARNING: SERVICE ONLY-SEE MANUAL (if enabled) DISABLED-SEE MANUAL (if disabled)

COLD START

CAL

CCD SIDES CCD ADJ

CAL PATH **ON!OFF** 

FORCE DAC

Second-level menu for CAL/DIAG.

CAL

<status> <status> NOT WARMED UP **\$ELF** EXT

SELF

DIAG

**EXT** DIAG

2430A Users Reference Guide

Second-level	menu for C/	AL/DIAG.	
<status></status>	<status></status>	<status></status>	NOT WARMED UP
SELF	EXT	SELF	EXT
CAL	CAL	DIAG	DIAG

# (Instruments Serial # B019999 & Below)

2. MENU OFF/EXTENDED **FUNCTIONS** 

Turns off any menu being displayed or, if none are on, calls up the EXTENDED FUNCTIONS menus. See Appendix A in the Operators Manual for the Extended Functions Calibration and Diagnostics menus:

**EXT FUNCT** 

SYSTEM SPECIAL CAL/DIAG

Second-level menu for SYSTEM.

PREFLT

MISC

ON:OFF

VIDEO OPT

Third-level menu for SYSTEM PANEL.

PWR ON

PANEL.

LASTIINIT

Third-level menu for SYSTEM MISC.

BELL TRIG T

ONIOFF ON:OFF

Third-level menu for SYSTEM VIDEO OPT.

TV SYS CNT RST

MINON/M BOTHIF1

Second-level menu for SPECIAL...

WARNING: SERVICE ONLY-SEE MANUAL (if enabled) DISABLED--SEE MANUAL (if disabled)

COLD START CAL PATH ON!OFF

DAC

FORCE

Second-level menu for CAL/DIAG.

<status> <status> NOT WARMED UP SELF SELF EXT EXT CAL CAL DIAG DIAG

### CRT DISPLAY MENUS

1 INTENSITY

A continuous rotating pot, the Intensity control adjusts the intensity of any of four screen elements (readout, display, A INTEN zone, and graticule). It always controls the element last selected in the Select menu, except when STATUS is selected. It then controls the readout intensity.

2 SELECT Button

Toggles between readout and display after turning on the menu.




Figure 5. INTENSITY Control, SELECT and STATUS/HELP Buttons.

3 STATUS/HELP
Button

10

Pressing this button displays a Status menu (see Page 5) which can help you determine why a display is not seen or triggering is not occurring. Some common conditions to check for are:

- Channel called up?
- · Display intensity setting?
- Ground indicator (+) and trigger position (T) at top or bottom edge (vertical position)?

Common triggering conditions:

- Single sequence on?
- Save Mode?
- · Events on?
- Delay on?
- · Trig wait state?
- · Ext clk on?

The top three lines of the status menu update with front control changes. Remaining lines are updated with a press of the status button.

Pushing MENU OFF or calling up another menu turns off the status display.

HELP (see below).

CRT Display On-Screen Menus

	CRT Display On-Screen Menus
2. SELECT	INTENSITY VECTORS READOUT DISP INTENS GRAT ON!OFF
	INTENS: Controls brightness of intensified zone in A Intensified.
	GRAT: Controls graticule intensity.
3. STATUS/HELP	Presents an instrument status display (see Page 5) and increases the readout intensity to 65% to ensure visibility. Intensity adjustment will now control readout intensity. Intensity control will return to function selected before entering STATUS menu mode when the STATUS menu is removed.  Pressing MENU OFF or any other front-panel control that requires a menu display removes the STATUS display from
	the CRT.  When HELP mode is selected, operating any front-panel knob or button will cause a screen full of information to be displayed. If -MORE- appears at the lower-left corner of the screen, selection of MORE will cause additional information to be displayed. Press EXIT MENU to return to normal operation.

2430A Users Reference Guide

## **AUTO SETUP**

1 AUTO SETUP

Selecting this button will cause the scope to set the vertical, horizontal, and triggers to display the input signal on the selected vertical channel or channels.

View Mode

Selects sweep speed for 2-5 cycles on screen.

Other modes optimize scaling for selected signal type.




Figure 6. AUTO SETUP Button.

Auto Setup On-Screen Menus								
1. AUTO SETUP				EDGE	RES			
	VIEW	PERIOD	PULSE	_ <i>_</i> _/_\	HI:LO			
			·					

#### NOTE

RES HILO only appears when in Measurement modes, (i.e., PERIOD, PULSE, or EDGE).

### PRGM AUTOSTEP

**PRGM Button** 

Selecting PRGM displays the AUTOSTEP SEQUENCER menu. This menu lets you save and recall typically 50 to 200 front-panel setups, and associated control and I/O actions, in as many as named test or measurement procedures.

To save a single front panel:

- 1. Press PRGM (Program) on front panel.
- 2. Select SAVE bezel button.
- 3. Select SAVE bezel button in second level menu.
- 4. Set up front panel that you want to save.
- 5. Press PRGM (Program) button on front panel.
- 6. Press SAVE SEQ bezel button.





Figure 7. PRGM Button.



2430A Users Reference Guide

16

### **AutoStep Sequencer Control Menus (cont)** Second-level menu for RECALL. First Labeled Sequence Second Labeled Sequence nth Labeled Sequence -----SELECT-----RECALL **EXIT** Second-level menu for DELETE. First Labeled Sequence Second Labeled Sequence nth Labeled Sequence --SELECT----DELETE EXIT Second-level menu for EDIT. First Labeled Sequence Second Labeled Sequence nth Labeled Sequence -----SELECT-----**EDIT** COPY EXIT Third-level menu for EDIT. -----SELECT-----DELETE TO BUF ADD EXIT Third-level menu for COPY. USE ARROW KEYS TO CHANGE NAME: **ROLL-CHARS** CURSOR < > SAVE EXIT Fourth-level menu for ADD. LOAD **BUFFER EXIT**

### MEASURE

MEASURE
Button
(Waveform
Parameter
Extraction)

Pressing this front panel button displays MEASURE menu on screen.

Provides selects for measurement type, setup and snapshots.

#### NOTE

In MEASURE menu, MARK ON selection turns on "X" markers that indicate measurement locations, i.e., 10%-90% risetime locations.

#### NOTE

If WINDOW menu is selected, time cursors must be manually selected. The cursors can then be set to bracket the portion of the waveform to be measured.




Figure 8. MEASURE Button.

#### Measure Menus

3. MEASURE		MEAS	SETUP	DISPLAY	WINDOW
	SNAPSHOT	TYPE		ONIOFF	ONIOFF

Second-level menu for SNAPSHOT when more than one display source is displayed.

#### TARGET:

CH1 CH2 MULT/ADD REF

Resulting display when either SNAPSHOT is pressed and only one display source is on screen or when the TARGET waveform is selected.

#### SNAPSHOT READOUT:

SNAPSHOT OF CHx USING MIN/MAX METHOD:

DIS=4.35 V	TOP=5.01 V	WID=20.3 $\mu$ S
MES=2.12V	BASE=2.00 mV	DUTY=50%
PRX=-1.23 mV	MEAN=2.32 V	FREQ=24.6 kH
MAX≕5.15 V	OVRS=2.0%	$PER = 40.6 \mu S$
MID=2.47 V	UNDS=1.0%	RISE=28.4 nS
MIN=21.4 mV	RMS=2.65 V	FALL=18.3 nS
P-P=5.36 V	AREA=47.5 nVs	
DIST=90.0%	MES=50.0%	PROX=10.0%
AGAIN		İ

1: Returns the scope to the MEASURE Menu.

AGAIN: Initiates another snapshot.

#### Measure Menus (cont)

Second-level menu for SETUP.

......METHOD...... MIN/MAX HIST CURSOR MARK LEVEL ON!OFF

This menu is used to set up criteria for extraction of LEVEL. Pushing the menu button labeled LEVEL displays a third level menu which allows the DISTAL, MESIAL, and PROXimal levels on the waveform to be specified.

Third-level menu for LEVEL.

#### ADJUST LEVELS WITH CURSOR/DELAY KNOB

nn% DISTAL nn%

n.nV

nn%

MESIAL PROXIMAL MESIAL2 %!VOLT

Second-level menu for MEAS TYPE.

MEAS TYPE: The continuous parameter extraction function is executed by selecting up to four parameters for display from a parameter matrix. Pushing the menu button labeled MEAS causes the Parameter Selection menu to be displayed:

DISTAL	MESIAL	PROX	MAX	MID
MIN	PK-PK	TOP	BASE	MEAN
OVRSHT	UNDRSHT	RMS	AREA	WIDTH
DUTY	FREQ	PERIOD	RISE	FALL
DELAY	•			

→ ↓ ON OFF

#### Measure Menus (cont)

Third-level menu for MEAS TYPE when more than one display source is displayed and DELAY is not selected in the parameter matrix.

#### TARGET:

CH1

CH2 MULT/ADD

REF

Selection of DELAY as the parameter to be extracted causes a different third- and fourth-level TARGET menu to be displayed.

Third-level menu for MEAS TYPE when more than one display source is displayed and DELAY is selected in the parameter matrix.

#### **DELAY FROM**

TARGET:

CH1

CH2

MUL/ADD

MUL/ADD

REF

Fourth-level menu for MEAS TYPE when more than one display source is displayed and DELAY is selected in the parameter matrix.

**DELAY TO** 

TARGET:

CH1

CH2

REF

# **OUTPUT**

### 4 OUTPUT Button

Calls up the OUTPUT menu for configuring the GPIB.




Figure 9. OUTPUT Button.

#### **OUTPUT Control Menus**

4. OUTPUT	STATUS	SETUP	DEBUG	TRANSMIT/(	PRINT)		
	STATUS calls up an on-screen display of most GPIB parameters in which a system user might be interested.						
	TRANSMIT/PRINT/PLOT switches to ABORT when transmitting, printing, or plotting. TRANSMIT/PRINT/PLOT disappears in OFF BUS mode.						
	Second-level menu for GPIB SETUP.						
	OUTPUT	SETUP					
	MODE	TERM	ADDR	ENCDG			
	Third-level menu for GPIB MODE.						
	T/ONLY	L/ONLY	T/L	DEVICES	OFF BUS		
	Selecting DEVICES changes TRANSMIT to PRINT (or PLOT) in the OUTPUT control menu. Selecting OFF BUS turns off the TRANSMIT/PRINT/PLOT choice.						
	Fourth-level menu for DEVICES.						
	HPGL	THINKJET					
	PLOTTER	PRINTER	<del></del>	SETUP			

22

#### **OUTPUT Control Menus (cont)**

Fifth-level menu for SETUP. **PGSIZE** SETTINGS TEXT GRAT WFM ONIOFF ONIOFF ON:OFF ON:OFF US:A4 Fourth-level menu for GPIB T/ONLY. ...... SEND CURVE ....... WFMPRE/CURVE SEND PRGM ONLY Third-level menu for GPIB TERM. EOI LF/EOI Third-level menu for GPIB ADDR. **GPIB ADDRESS** nn Third-level menu for GPIB ENCDG. PARTIAL WFMS ...........WHOLE WFMS...... RP ASCII RP RI RI RI encoding is a two's-complement format. RP is positive-integer format. At power-on the scope assumes that the data is formatted RI. The user must select RP (or send ENCDG RP via GPIB) to get positive-integer formats interpreted correctly. Second-level menu for GPIB DEBUG. DEBUG .... MONITOR .... -SCREEN UPDATE-PAUSE ONIOFF BUSISCOPE INIOUT SLOW

### VERTICAL

**VERTICAL POSITION** Controls

CH 1 is the HORIZONTAL POSITION control in XY mode.

(2) VARIABLE **Buttons** 

CH 1 VARIABLE uncalibrates the ADD mode readout, but the CH 2 VARIABLE does not. This feature lets you input a sample of an unwanted signal into CH 2 and adjust the CH 2 VARIABLE to cancel the unwanted signal in the ADD display. See Section 3 of the Operators Manual for use of this feature.

Arrow (1 and 1) menu button functions are continuous when held down. CAL returns V/D to calibrated setting.

VOLTS/DIV **Switches** 

2430A User Reference Guide

Readouts automatically adjust to the correct readout scale factor when 1X, 10X, 100X, and 1000X TEK coded-attenuator probes are attached.

VOLTS/DIV is the vertical expansion control in SAVE storage mode and the extended range control in AVG ACQUIRE mode.




Figure 10a. Vertical Buttons and Controls.

23

Initiates Vertical MODE menu on screen. Active selections are underscored.

The resultant signal of a MULT display is scaled down by a factor of 5.12 to maintain the display within the graticule area.

XY mode automatically turns on the CH 1 and CH 2 signals REF 1 vs REF 2, may be displayed as XY REF.

#### NOTE

In this menu, CH 1, CH 2, ADD and MULT buttons are push/push; one push turns the mode on, another turns it off. Also, selecting ADD turns MULT off, and vice versa. Pushing YT:XY toggles the mode between YT and XY. Functions are underscored when turned on.




Figure 10b. Vertical Buttons and Controls.

5 COUPLING/ INVERT Buttons

May be used to switch through the available coupling choices after menu is called up.

AC coupling and 50  $\Omega$  termination are mutually exclusive.

6 BANDWIDTH Button

May be used to scroll through menu choices after menu is called up.

	Verl	ical On-Sc	reen Menus			
2. VARIABLE	CH1 VAF	RIABLE				
	CAL	<u></u>				
	CH2 VAF	RIABLE				
	CAL	1	t			
4. VERTICAL MODE	In YT Mode.					
	VERTICAL	. MODE				
	CH1	CH2	ADD	MULT	YX:TY	
	In XY Mode.					
	VERTICAL				YTIXY	
	CH1 vs					
5. COUPLING	CH1 COUPLI			50 Ω	INVERT	
INVERT	AC	DC	GND	ON:OFF	ONIOFF	
	CH2 COUPLI	NG		50 Ω	INVERT	
	AC	DC	GND	ONIOFF	ONIOFF	
6. BANDWIDTH	(For Instruments with Serial # B020000 & Above)					
	USB=xxxxH	z USR:	=xxxx s	SR=xxxxS/	s	
		BANDWIDT	Ή		SMOOTH	
	20 MHz	50 MHz	FULL		ONIOFF	
	The number > setting, and to			quisition Mode	e, the SEC/DIV	
6. BANDWIDTH	(For Instrume	nts with Se	rial # B0199	99 & Below)		
	USB=xxxxHz USR=xxxx s					
		BANDWIDT	Н		SMOOTH	
	20 MHz	50 MHz	FULL_		ONIOFF	
	The number x			quisition Mode	e, the SEC/DIV	

2430A User Reference Guide

### HORIZONTAL

(1) A Button Selects A Horizontal mode. SEC/DIV switch (2) will control A SEC/DIV.

2 A AND B SEC/DIV Used in SAVE mode to horizontally expand display. Do not change Horizontal mode after entering SAVE storage mode if using horizontal expansion. ROLL mode replaces AUTO mode in the A TRIGGER mode menu for A SEC/DIV settings ≤ 100 ms/div.

3 A INTEN Selects A INTENsified Horizontal mode. SEC/DIV switch
Button (2) will control the B SEC/DIV.

4 B Button Selects B Delayed sweep operation. SEC/DIV switch will now control B sweep rate.




Figure 11. Horizontal Buttons and Controls.

### **CURSORS**

1 FUNCTION Button

Displays CURSOR FUNCTION menu on screen.
Selecting a cursor function (VOLTS, etc.) from the menu advances to the second level ATTACH cursors menu.
When neither the CURSOR FUNCTION or ATTACH CURSORS menu is displayed, pressing CURSOR FUNCTION twice steps through the CURSOR FUNCTION menu to the ATTACH CURSOR menu.
Turning a cursor function off and back on also displays the ATTACH CURSOR menu.

2 UNITS Button

Displays UNITS menu on screen.

3 SELECT Button

Selects which cursor the CURSOR/DELAY knob (4) controls.

#### NOTE

No cursor, regardless of type, can be positioned off screen; all cursors are bound at the screen perimeter. For cursor functions displaying time cursors, attempting to move either cursor past either edge of the screen causes the display to horizontally reposition. Pressing SELECT moves the bound cursor to center screen.




Figure 12. Cursor Buttons and Controls.



CURSOR/DELAY Controls active cursor positioning, adjusts DELAY TIME Control or DELAY EVENTS.

> When time cursors are displayed and active, the CURSOR/DELAY knob may be used to scroll through the entire record length. Cursors will operate similarly for a reference waveform when attached to that displayed reference waveform.

CURSOR/DELAY knob is a shared control. It positions cursors for cursor functions and sets delay times or delay events number for DELAY functions.

#### NOTE

Bezel buttons operate in a push/push mode, selecting and deselecting the function. Selection of an alternate function will deselect a previous mode.

2430A User Reference Guide

#### **Cursor On-Screen Menus**

1. FUNCTION	CURSOR FL	INCTION						
	VOLTS	TIME	V@T	SLOPE	1/TIME			
	Second-level menu for a CURSOR FUNCTION selection.							
	In YT Mode.	In YT Mode.						
	ATTACH CU	ATTACH CURSORS TO:						
	No ∆ delay	No Δ delay						
	CH1	CH2	(func)	(func)∆	REF n			
	Δ delayCH	Δ delayCH1 on						
	CH1	CH1A	(func)	(func)∆	REF n			
	Δ delay—CH	Δ delay—CH1 and CH2 on						
	CH1	СН2Δ	(func)	(func)∆	REF n			
	Function is either ADD or MULT; they are mutually exclusive. Pressing REF rolls through the displayed reference waveforms. Only waveforms called up for display are included in the ATTACH CURSORS menu.							
	In XY Mode (with CH1 vs CH2 and XYREF selected).							
	ATTACH CURSORS TO:							
	CH1 v	s CH2	XYREF					

Cursor	On-Screen	Menus	(cont)

	Cursor	On-Scre	en Menus (co	1t)	
2. UNITS	In VOLTS or	V@Τ.			
	UNITS	VOLT	S CURS REF	= <b>XXXXX</b>	
	VOLTS	%	dB	NEW REF	Δ¦ABS
	In SLOPE.				
	UNITS		SLOPE CUR	S REF=xxxx	xx
•	SLOPE	%	DEGREES	NEW REF	
	In 1/TIME.				
	UNITS		1/TIME CUR	S REF=xxxx	xx
	Hz	%	DEGREES	NEW REF	ΔIABS
	In TIME.				
	UNITS		TIME CURS	S REF=xxxxx	×
	SEC	%	DEGREES	NEW REF	Δ¦ABS

29

## **DELAY FUNCTIONS**

- CURSOR/DELAY Sets delay times or delay event number for Delay functions. It defaults to cursors control when neither Delay function menu is displayed.
- 2 EVENTS Selects DELAY by EVENTS function and directs the CURSOR/DELAY knob (1) to control the events count.
- 3 TIME Button Selects DELAY by TIME, and switches between Main Delay and Delta Delay functions. CURSOR/DELAY control knob (1) is used to set time delay.

Triggers must be supplied by means of the B trigger circuitry to obtain Event triggering when EVENTS is on. A delayed by B events and B delayed by time may be used sequentially.




Figure 13. Delay Buttons and Controls.

DELAY by	EVENTS START AT A TRIG	EVENTS
VENTS	EVENTS COUNT = xxxxx B TRIGS	ONIOFF
DELAY by	With Δ TIME OFF.	
	DELAY TIME = XXXXXX B	ΔΤΙΜΕ
		ONIOFF
	With ΔTIME ON.	
	DELAY TIME = xxxxxx B	ΔΤΙΜΕ
	ΔDELAY TIME = XXXXXX B	ONIOFF
	DELAY by TIME button is pressed to sw position knob between the Main DELAY DELAY TIME when ΔΤΙΜΕ is ON.	

## **TRIGGERING**

1 CPLG Button Switches through the menu choices (except VIDEO) when pushed repeatedly.

2 SET VIDEO
Button
Displays A VIDEO COUPLING menu (on scopes equipped with Video trigger only). Video coupling is selected by means of the A TRIGGER COUPLING menu; mode (or type) of video coupling is selected by means of the A VIDEO COUPLING menu.

Video signal must be interlaced for field 2 to appear in on-screen readout.

3 SET WORD Displays the Word Recognizer Probe configuration menu.




Figure 14. Trigger CPLG, SET VIDEO, and SET WORD Buttons.

	Trig	ger On-Scr	een Menus			
1. TRIGGER CPLG	Without the Video Option.					
-	A COUPLING		RE	JECT		
	DC	AC	NOISE	HF LF		
	With the Vide	o Option in	stalled.			
	A COUPLING	VIDEO		JECT HF LF		
2. SET VIDEO	Video Option					
2. SET VIDEO	Video Option	Offiny (101 in i	eriacea sign	aio).		
	A VIDEO COL	JPLING			CLAMP	
	FIELD 1	FIELD 2	ALT	TVLINE	ONIOFF	
	Video Option	only (for no	n-interlaced	signals).		
	A VIDEO COL	JPLING			CLAMP	
	FIELD 1			TVLINE	ONIOFF	
3. SET WORD	RADIX	CL		_	ET	
	OCTIHEX	<u></u>	\_ ASYNC	B	ITS	
	Second-level	menu for S	ET BITS.			
	In HEXadecim	ial:		-	-	
	TRIG WORD:					
	CLK=*		x >	(XXX XXXX XXX	C XXXX	
	1	0	X	<b>-</b>		
	*Setting for cl	ock in the f	irst-level me	nu appears he	re.	
	In OCTal:		•			
	TRIG WORD:					
	CLK=*	000000	x	(XX XXX XXX X	x xxx	
	1	0	Х	<b>+</b>	<b>→</b>	
	*Setting for cl	ock in the f	irst-level me	nu appears he	re.	

SOURCE Toggles between 1 and 2 if channel or external trigger is **Button** the selected source. A and B trigger conditions must be met to obtain a trigger in A 'AND' B. SOURCE remains as the last valid choice. EXTernal GAIN selection is made from the second level of the Trigger SOURCE menu. INIT @50% Causes the 2430A to do a single Auto Level Trigger cycle automatically, setting the trigger level at 50% of Button peak-to-peak signal value.

TRIG STATUS Activates the TRIGGER STATUS menu, which shows the current Trigger mode, Source, Coupling and Trigger **Button** position selection for the A and B triggers.




Figure 15. Trigger SOURCE, INIT @50%, and TRIG STATUS Buttons.

	Trigge	r On-Screen	Menus (co	ont)		
4. TRIGGER SOURCE	A TRIG SOU	RCE				
	VERT	CHAN	EXT			
	CH1	112	112	LINE	A*B!WORD	
	CH2					
	ADD					
	MULT					
	Second-level menu for A EXT.					
	A EXT					
	SOURCE	A AI	ND B EXT (	3AIN		
	112	EXT 1 EX	T 1/5 EXT	2 EXT2/5		
6. TRIG STATUS	TRIG STATU	IS				
	A*B MODE	SOURCE	CPLG	TRIG POS		
	<b></b> -					
	A (Setup con	ditions for th	e A Trigger	Controls.)		
	B (Setup con	ditions for th	e B Trigger	Controls.)		

E THE PARTY OF THE

The second of the second

1777

## A TRIGGERING

7 MODE Button Displays TRIGGER MODE menu. Steps through the mode choices in menu, except SINGLE SEQ, when pushed repeatedly.

8 TRIG Displays TRIGGER POS the menu choices when Button

Displays TRIGGER POSITION MENU. Steps through the menu choices when pushed repeatedly.

9 A/B TRIG
Button
Selects between A and B Trigger menu displays for configuration. SLOPE, MODE, SOURCE, CPLG, LEVEL and TRIG POSITION controls are shared by A and B trigger system.




Figure 16. A Trigger MODE, TRIG POSITION, A/B TRIG Buttons.

A Trigger On-Screen Menus					
7. TRIGGER MODE	A TRIG MOD AUTO LEVEL	AUTO	NORMAL	SINGLE SEQ	
	AUTO switch	nes to ROLL	. at 100 ms/div	and slower.	
8. TRIGGER POSITION	A TRIGGER 1/8	POSITION 1/4	1/2	3/4	7/8

#### NOTE

If a position other than 1/8, 1/4, 1/2, 3/4, 7/8 is selected over GPIB, then no on-screen selection will be underlined.



2430A User Reference Guide

2430A User Reference Guide

Toggles the trigger controls between controlling the A and B trigger systems.

**CPLG Button** 

Displays TRIGGER COUPLING menu. Switches through the menu choices when pushed repeatedly.

**INIT 50%** Button

Causes the 2430A to do a single Auto Level Trigger cycle automatically, setting the trigger level at 50% of peak-to-peak signal value.

**MODE Button** 

Toggles between RUNS AFTER and TRIG AFTER when pressed repeatedly.

EXT CLK ON sets the time cursor readouts and the delay time numbers to CLK (clock) units. A clock signal must be provided by means of the B trigger circuitry to obtain triggering.




Figure 17. B Trigger A/B TRIG, CPLG, INIT @50%, MODE, TRIG POSITION, SOURCE Buttons.

(13) TRIG POSITION Button

Displays the control menu used to select the Record Trigger position in the waveform display.

SOURCE Button

The state of the s

Trans.

Displays the B TRIGGER SOURCE menu.

**B Trigger On-Screen Menus** 

-		.330								
10. TRIGGER CPLG	In B TRIG A	In B TRIG AFTER Delay Mode.								
	B COUPLING	B COUPLING								
	B. EXT CLK	CPLG (with	EXT CLOCK	(ON)						
		CPLG (with t								
		NTS (with b								
				REJECT	·					
	DC	AC	NOISE	HF	LF					
	In B RUNS AFTER Delay Mode.									
	EVENTS CC	PLG (with EX	h DELAY by	N) · EVENTS ON)						
				REJECT						
	DC	AC	NOISE	HF	LF					
12, TRIGGER	B TRIG	RUNS	TRIG	EXT CLK						
MODE		AFTER	AFTER	ONIOFF						
13. TRIG	B TRIGGER	POSITION								
POSITION	1/8	1/4	1/2	3/4	7/8					

### 6

#### **B Trigger On-Screen Menus (cont)** 14. TRIGGER In B TRIG AFTER Delay Mode. SOURCE B TRIG SOURCE B. EXT CLOCK SOURCE (with EXT CLOCK ON) B, EVENTS SOURCE (with DELAY by EVENTS ON) B, EXT CLK, EVNT SOURCE (with both ON) SOURCE **VERT** CHAN EXT 1;2 WORD CH1 112 Committee () CH<sub>2</sub> ADD In B RUNS AFTER Delay Mode. B TRIG SOURCE EXT CLK SOURCE (with EXT CLOCK ON) EVENTS SOURCE (with DELAY by EVENTS ON) EVENTS, EXT CLK SOURCE (with both ON) SOURCE **VERT** CHAN EXT WORD CH1 112 112 CH2 ADD Second-Level menu for B EXT. B EXT Frank SOURCE -----A AND B EXT GAIN-----112 EXT 1 EXT 1/5 EXT 2 EXT 2/5

### **ACQUISITION**

1 ACQUIRE

Starts/restarts the acquisition from SAVE mode.

At the completion of a single-sequence acquisition, the scope switches to SAVE storage mode and displays the SAVE menu. Pushing ACQUIRE button momentarily switches to ACQUIRE menu, but a fast-completing single sequence will switch it back to SAVE menu before the ACQUIRE menu can be used. Turn SINGLE SEQ off in TRIGGER MODE menu before pushing ACQUIRE to use ACQUIRE menu.

NORMAL, ENVELOPE<sup>1</sup>, and AVG select the acquisition mode. REPET extends the bandwidth for repetitive waveforms to 150 MHz when ON. SAVE ON  $\Delta$  causes the scope to enter SAVE (SAVE ON  $\Delta$  switches to off) when a live waveform exceeds boundary limits set by a reference envelope waveform. If GPIB mode is set for PRINTER output, screen data will be printed. Then SAVE ON  $\Delta$  will be turned back on to continue monitoring the incoming live waveforms (not done in ROLL mode).

If GPIB mode is selected for the talk/listen mode, the 2430A will issue an SRQ notifying the Controller of the SAVE event.

Average and Envelope acquisitions in progress will be restarted by any of these front-panel control changes:

- 1. Any vertical or horizontal mode change.
- 2. A volts/div setting change of either channel.
- A vertical position change of either channel. (Average but not Envelope.)
- 4. Input coupling changes to either channel.
- Changes in the Trigger mode.
- Pressing the MENU/OFF button to turn off menus.
- Delay-by-Events or Delay-by-Time changes (Average only).
- Changing the trigger slope.

<sup>1</sup>For instruments with serial numbers below B020000, ENVELOPE mode is not available when in ADD or MULT Vertical mode; turning ENVELOPE on turns off ADD or MULT and removes both menu choices from the Vertical mode menu.




Figure 18. Storage ACQUIRE Button.

# SAVE AND DISPLAY REFERENCE

**SAVE Button** 

Displays the SAVE menu and "freezes" waveforms on screen. SAVE mode is also entered when a single sequence completes, or when Save-On-Delta occurs on an out-of-limits waveform. It also occurs momentarily during plotting or printing via the GPIB.

Pressing STACK REF in the SAVEREF SOURCE menu treats the reference memories as a stack; waveforms are stored in predetermined reference memories, depending on what source (CH 1, ADD, etc.) they are displayed in.

**DISPLAY REF Button** 

Toggles between DISPLAY and HORIZontal position selection menus.




Figure 19. Storage SAVE and DISPLAY REF Button.

and Advantage of

The second second

in the second of 
The state of the s

The same of the sa

#### Storage On-Screen Menus (cont)

	SAVERE	F SOURCE		STACK		
CH1	CH2	(function)	REF	REF		
Second-level menu for a SAVEREF SOURCE selection (except REF or STACK REF). If REF is selected, or if $\Delta$ DELAY TIME is turned on while B is the HORIZONTAL MODE setting, this menu becomes a third-level menu.						
	SAVEREF DESTINATION SAVEREF					
REF1	REF2	REF3	REF4	SOURCE		
Second-Leve TIME.	menu for S	SAVEREF SO	URCE in Δ (	(delta) DELAY by		
l		hannel)				
Second-Leve	l menu for F	REF.				
SAVER	EF SOURC	E-REF		SAVEREF		
REF1	REF2	REF3	REF4	SOURCE		
In YT Mode.						
DISPLAY RE	F					
REF1	REF2	REF3	REF4	POS REF		
l		eference men	u choice if r	o valid		
In XY Mode.						
				HORIZ		
XYREF			· · · · · ·	POS REF		
Second-level menu for HORIZ POS REF. (In YT Mode.)						
}	HORIZONTA	AL POSITION	<b></b>	REF HPOS		
REF1P	REF2P	REF3P	REF4P	INDILOCK		
Second-level	menu for H	ORIZ POS RE	EF. (In XY N	1ode.)		
}	HORIZONTA	AL POSITION		REF HPOS		
XY REFP				IND!LOCK		
	CH1  Second-level REF or STAC turned on wh becomes a th  REF1  Second-Leve TIME.  SAVEREF SC DELAY 1  Second-Leve SAVERI REF1  In YT Mode.  DISPLAY RE REF1  EMPTY appe waveform is: In XY Mode.  XYREF  Second-level  REF1P  Second-level	SAVERE CH1 CH2  Second-level menu for a REF or STACK REF). If turned on while B is the becomes a third-level me SAVEREF C REF1 REF2  Second-Level menu for S TIME.  SAVEREF SOURCE—(c DELAY 1 DELAY 2  Second-Level menu for F  SAVEREF SOURC REF1 REF2  In YT Mode.  DISPLAY REF REF1 REF2  EMPTY appears above is waveform is stored.  In XY Mode.  XYREF  Second-level menu for H HORIZONTA REF1P REF2P  Second-level menu-for H HORIZONTA	CH1 CH2 (function)  Second-level menu for a SAVEREF SC REF or STACK REF). If REF is selecte turned on while B is the HORIZONTAL becomes a third-level menu. SAVEREF DESTINATION REF1 REF2 REF3  Second-Level menu for SAVEREF SO TIME.  SAVEREF SOURCE—(channel) DELAY 1 DELAY 2  Second-Level menu for REF.  SAVEREF SOURCE—REF REF1 REF2 REF3  In YT Mode.  DISPLAY REF REF1 REF2 REF3  EMPTY appears above reference men waveform is stored.  In XY Mode.  XYREF  Second-level menu for HORIZ POS REF1 REF2 REF3P  Second-level menu for HORIZ POS REF1P REF2P REF3P  Second-level menu for HORIZ POS REF1P REF2P REF3P  Second-level menu for HORIZ POS REF1P REF2P REF3P	CH1 CH2 (function) REF  Second-level menu for a SAVEREF SOURCE sele REF or STACK REF). If REF is selected, or if $\Delta$ D turned on while B is the HORIZONTAL MODE sele becomes a third-level menu. SAVEREF DESTINATION REF1 REF2 REF3 REF4  Second-Level menu for SAVEREF SOURCE in $\Delta$ of TIME.  SAVEREF SOURCE—(channel) DELAY 1 DELAY 2  Second-Level menu for REF.  SAVEREF SOURCE—REF REF1 REF2 REF3 REF4  In YT Mode.  DISPLAY REF REF1 REF2 REF3 REF4  EMPTY appears above reference menu choice if revaveform is stored.  In XY Mode.  XYREF  Second-level menu for HORIZ POS REF. (In YT Mode) HORIZONTAL POSITION REF1P REF2P REF3P REF4P  Second-level menu-for HORIZ POS REF. (In XY Mode) HORIZONTAL POSITION		

## GPIB STATUS

**GPIB Status On-Line Screen** 

· CH1 100mV	A 1ms	35.2mV EXT1
ADDR 3	RQS ON	START = 256
MODE THINKJET	OPC ON	STOP = 512
TERM EOI	CER ON	
	EXR ON	EVENTS
FASTXMIT	EXW ON	NONE
OFF	INR ON	
1 WFMS REQSTD	PID OFF	
RIBINARY	USER OFF	
SOURCE CH1	PATH ON	
TARGET REF1	LONG ON	
ENCOG RIBINARY	DEBUG OFF	
BINWFM→SCOPE RI	DEVIDEP ON	

The GPIB Status menu is displayed on screen when STATUS is selected from the OUTPUT menu. Each underscored item is a GPIB-related function and the adjacent non-underlined item(s) is the setting(s) for the function. The listing "ADDR 3" means the scope's address (a function) is set to 3. The remaining listings at the top of the screen vary with current instrument setup.

45

Tankson III

Separate Sep

The same of the sa

### Interpretation of GPIB STATUS menu listings:

ADDR=	ADDRESS SELECTION		ASSERT SRQ ON EXECUTION ERROR
MODE ==	MODE SELECTION		ASSERT SRQ ON EXECUTION WARNING
TERM=	TERMINATION	INR=	ASSERT SRQ ON INTERNAL ERROR
SOURCE=	WAVEFORM DATA SOURCE	PID=	ASSERT SRQ ON PROBE IDENTIFICATION
TARGET=	WAVEFORM DATA TARGET	USER=	ASSERT SRQ ON BEZEL BUTTON PUSH
ENCDG=	ENCODING	PATH=	SEND COMPLETE PATH IN QUERY RESPONSE
	INCOMING BINARY WAVEFORM INTERPRETATION MODE	LONG=	USE LONG FORM IN QUERY RESPONSE
RQS=	ASSERT SRQ IF PENDING EVENT	DEBUG=	TURN ON DEBUG MODE
OPC=	ASSERT SRQ ON OPERATION COMPLETE	DEVDEP=	≖ASSERT SRQ IF TRANSMIT PUSHED
CER=	ASSERT SRQ ON COMMAND ERROR	401=	POWER ON SRQ (TYPICAL EVENT)

