

WARNING

THE FOLLOWING SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID PERSONAL INJURY, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.

For Service Manuale Control MALINITION FECHING Control B Charty Free Re Chimics Oson 749 Re Chimics Fol: 01844-351894 Fax: 01544-358556 Email: enquines@maunitron.co.uk

PLEASE CHECK FOR CHANGE INFORMATION AT THE REAR OF THIS MANUAL.

475A OSCILLOSCOPE WITH OPTIONS SERVICE

INSTRUCTION MANUAL

Tektonix, Inc. P.O. Box 500 Beaverton, Oregon 97077

Serial Number ____

First Printing AUG 1976 Revised DEC 1984

'0-2162-00 oduct Group 40 Copyright [®] 1976 Tektronix, Inc. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Tektronix, Inc.

in the second

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and are registered trademarks of Tektronix, Inc. TELEQUIPMENT is a registered trademark of Tektronix U.K. Limited.

Printed in U.S.A. Specification and price change privileges are reserved.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tet:-01844-351694 Fax:-01844-352554 Email:-enquines@mauritron.co.uk

104

INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a pañel insert, tag, or stamped on the chassis. The first number or letter designates the country of manufacture. The last five digits of the serial number are assigned sequentially and are unique to each instrument. Those manufactured in the United States have six unique digits. The country of manufacture is identified as follows:

B000000	Tektronix, Inc., Beaverton, Oregon, USA
100000	Tektronix Guernsey, Ltd., Channel Islands
200000	Tektronix United Kingdom, Ltd., London
300000	Sony/Tektronix, Japan
700000	Tektronix Holland, NV, Heerenveen,
	The Netherlands

Page

4-4 4-4 4-6 4-6 4-6 4-6 4-6 4-6 4-7 4-10 4-14 4-18 4-19 4-19 4-20 4-22 4-29 4-30 4-31 4-31 4-32 4-32 4-32 4-34

> 5-1 5-1 5-1 5-1 5-1

5-3 5-4 5-4 5-4 5-4 5-4 5-5 5-9 5-15 5-15 5-19

TABLE OF CONTENTS

Page SECTION 4 MAINTENANCE (cont)	
LIST OF ILLUSTRATIONS II PREVENTIVE MAINTEI	
LIST OF TABLES iii Introduction	NANCE
SECTION 1 SPECIFICATION Cleaning	
Visual Inspection	
Introduction I-I Lubrication	
Characteristics 1-1 Semiconductor Checks	
SECTION 2 OPERATING INFORMATION Recalibration	
TROUBLESHOOTING	
PRELIMINARY INSTRUCTIONS Introduction	
Introduction 2-1 Troubleshooting Aids	
Safety Information 2-1 Troubleshooting Equip	ment
Operating Power Sources 2-1 Troubleshooting Techn	
Line Voltage and Regulating Range 2-1 Special Troubleshootin	
Options 2-2 CORRECTIVE MAINTE	NANCE
CONTROLS AND CONNECTORS Introduction General 2-2 Obtaining Replacement	Deste
General 2-2 Obtaining Replacement Cathode-Ray Tube (CRT) and Display 2-2 Soldering Techniques	Parts
Vertical Deflection System (Channel 1 & Small Component Repl	acamant
Channel 2) 2-2 Circuit Board Replacen	
A and B Triggering 2-5 Power Transformer Rer	
A and B Sweep 2-6 Cathode-Ray Tube Ren	
Calibrator and Power 2-7 Cathode-Ray Tube Inst	
Rear Panel 2-8 High-Voltage Multiplier	
OBTAINING BASIC DISPLAYS Delay Line Removal	
Introduction 2-8 Recalibration After Rep	air
Normal Sweep Display 2-8 Instrument Repackagin	g
Magnified Sweep Display 2-9 RACKMOUNTING	
Delayed Sweep Displays 2-9 SECTION 5 PERFORMANCE CHEC Mixed Sweep Display 2-9	ĸ
Mixed Sweep Display 2-9 X-Y Display 2-9 Introduction	
Using This Procedure	
SECTION 3 CIRCUIT DESCRIPTION TEST EQUIPMENT REC	QUIRED
General	
Introduction 3-1 Special Calibration Fixt Digital Logic 3-1 Performance Check For	
Digital Logic 3-1 Performance Check Equ OUTLINE FOR CIRCUIT DESCRIPTION 3-1 Alternatives	uipment
BLOCK DIAGRAM 3-2 OUTLINE FOR PERFOR	
CHANNEL 1 PREAMP 3-4 PRELIMINARY PROCEI	
CHANNEL 2 PREAMP 3-6 PERFORMANCE CHEC	
VERTICAL CHANNEL SWITCHING 3-7 Operating Voltage	
VERTICAL OUTPUT AMPLIFIER 3-9 Power Source	
A TRIGGER GENERATOR 3-10 Warm Up	
B TRIGGER GENERATOR 3-12 Operating Temperature	
SWEEP AND Z-AXIS LOGIC 3-12 DISPLAY AND VERTIC.	ALSYSTEM
SWEEP GENERATORS (AND) TIMING	FCK
AND HORIZONTAL DISPLAY TRIGGER SYSTEM CHI SWITCHING 3-16 DM44 DIGITAL MULTI	
HORIZONTAL AMPLIFIER 3-20 INSTRUCTIONS	
LOW-VOLTAGE POWER SUPPLY 3-21 HORIZONTAL SYSTEM	
CRT CIRCUIT 3-24 GATE OUTPUTS, EXTE	
CALIBRATOR 3-27 AND CALIBRATOR CH	ECKS
FAN MOTOR CIRCUIT 3-27 SECTION 6 CALIBRATION	
Internet instance	
SECTION 4 MAINTENANCE Introduction Calibration Interval	
Maintenance Section Outline 4-1 Tektronix Field Service	
CABINET AND RACK ADAPTER REMOVAL Using This Procedure	
Standard Cabinet Removal 4-2 TEST EQUIPMENT REC	QUIRED
Standard Cabinet Installation 4-3 General	
Rack Adapter Removal 4-3 Special Calibration Fixt	ures
Rack Adapter Installation 4-4 Calibration Equipment	Alternatives

REV. A, DEC. 1977

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

i

6-1 6-1 6-1 6-1 6-1 6-1 6-1 Fig.

TABLE OF CONTENTS (cont)

SECTION 6	CALIBRATION (cont)	Page	SECTION 7	
	OUTLINE FOR CALIBRATION PROCEDURE PRELIMINARY PROCEDURE FOR	6-5	OPTION INF	A CARLE ELECTRICAL PARTS
	CALIBRATION Operating Voltage Cabinet Removal Power Source Warm Up Operating Temperature Step Titles POWER SUPPLY DISPLAY AND Z-AXIS VERTICAL SYSTEM TRIGGER SYSTEM HORIZONTAL SYSTEM DM44 DIGITAL MULTIMETER INSTRUCTIONS GATE OUTPUTS, EXTERNAL Z-AXIS AND CALIBRATOR	6-7 6-7 6-7 6-7 6-7 6-7 6-8 6-11 6-22 6-33 6-34 6-44	SECTION 8 SECTION 9	DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS REPLACEABLE MECHANICAL PARTS AND ILLUSTRATIONS
		0.44	CHANGE INF	ORMATION

LIST OF ILLUSTRATIONS

N	5.).	Page No.
1-1	475A Portable Oscilloscope.	
1-2	Delay Time and Differential Time Measurement Accuracy (Detailed)	1-7
2-1	Regulating Range Selector and Line Fuse.	2-2
2-2	Front panel and rear panel controls and connectors.	2-3
3-1	Basic block diagram of the 475A.	3-3
3-2	Detailed block diagram of the Channel 1 Vertical Preamplifier circuit.	3-5
3-3	Detailed block diagram of the Channel 2 Vertical Preamplifier circuit.	3-7
3-4	Detailed block diagram of the Vertical Channel Switching circuit	3-8
3-5	Detailed block diagram of the A Trigger Generator circuit.	3-10
3-6	Detailed block diagram of the Sweep and Z-Axis Logic circuits.	3-13
3-7	Detailed block diagram of the Seeep Generator circuits.	3-17
3-8	Detailed block diagram of the Horizontal Amplifier circuit	3-20
3-9	Detailed block diagram of the Power Supply circuit	3-22
3-10	Detailed block diagram of the CRT circuit.	3-25
3-11	Detailed block diagram of the Calibrator circuit.	3-27
4-1	Removing the standard cabinet.	4-2
4-2	Color codes for resistors and capacitors.	4-8
4-3	Lead configurations of semiconductors used in this instrument.	4-9
4-4	Troubleshooting chart for the 475A Oscilloscope.	4-12

Fig No		Page No.
4-5	Locations of circuit boards in the 475A Oscilloscope.	4-23
4-6	Locations of power transformer secondary wires.	4-23
4-7	Slide-out track assemblies.	4-29
4-8	Hardware to mount instrument in the rack.	4-36
4-9	Locating mounting holes for stationary sections.	4-37
4-10		4-37
4-11	Supporting the rear of the stationary sections.	4-38
4-12	Rear support kit.	4-39
4-13	Installing the support block on the instrument.	4-39
4-14	Inserting or removing the instrument with slide-out tracks.	4-40
4-15	Alignment adjustments for correct operation.	4-41
4-16	Alternative method of installing the instrument.	4-41
4-17	Dimensional drawing.	4-42
6-1	Typical display when Z-Axis Compensation is properly adjusted. Circle surrounds compensated portion of waveform.	6-11
6-2	Typical display when checking Trigger Sensitivity.	6-23
6-3	Typical display when checking Trigger Symmetry.	6-24
6-4	Proper connection of current probe to horizontal deflection plate leads for High-Speed Timing calibration.	6-38
6-5	Typical display on test oscilloscope when High- Speed Timing is properly adjusted (475A set at 2 nanoseconds/division).	6-38
adjusti	llowing illustrations for use with Section 6 are local ment locations pullout pages at the rear of Sec ims pullout pages.	ted on tion 8

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

LIST OF ILLUSTRATIONS (cont)

ADJUSTMENT LOCATIONS 1:

Locations of Calibration adjustments and test points on A9-Main Interface.

ADJUSTMENT LOCATIONS 2:

Locations of Calibration adjustments on A3-Vertical Preamp and A1, A2-Channel 1,2 Attenuators.

Locations of Calibration adjustments and test points on A5-Vertical Output.

ADJUSTMENT LOCATIONS 3:

Locations of Calibration adjustments on A8-Trigger Generator and Z-Axis Logic.

ADJUSTMENT LOCATIONS 4:

Locations of Calibration adjustments on A7-Timing.

Locations of Calibration adjustments on A9-Main Interface.

The following illustrations are located opposite their associated diagrams in Section 8 Diagrams pullout pages.

- 8-1 A through F, Channel 1 Component Locations.
- 8-2 A through F, Channel 2 Component Locations.
- 8-3 A through D, Channel Switching Component Locations.
- 8-4 A & B, Vertical Output Component Locations.
- 8-5 A through C, 'A' Trigger Generator Component Locations.
- 8-6 A through C, 'B' Trigger Generator Component Locations.
- 8-7 A through D, Sweep and Z-Axis Component Locations.
- 8-8 A through C, Sweep Generators Component Locations.
- 8-9 A & B, Timing and Horizontal Switching Component.
- 8-10 A through C, Horizontal Amplifier Component Locations.
- 8-11 A through D, Power Supply Component Locations.
- 8-12 A through D, CRT Circuit Component Locations.
- 8-13 A through D, Calibrator and Fan Component Locations.

LIST OF TABLES

Table

No	-	Page No.
1-1	ELECTRICAL	1-2
1-2	ENVIRONMENTAL	1-11
1-3	PHYSICAL	1-12
2-1	Regulating Ranges	2-1
3-1	Input/Output Logic for U370	3-8
	Horizontal Display Sweep Generator Terminology	3-16
	Circuit Number-to-Diagram Locator	4-7
	Power Supply Tolerance and Ripple	4-7
	Power Supply Resistance Check	
	Fuse Rating, Location and Functions	4-15
		4-22
. •	Calibration Interaction After Repair or Adjustment	4-33

Tab No		Page No.
5-1	Test Equipment Required for Performance Check	5-2
5-2	Vertical Deflection Accuracy	5-7
5-3	Differential Delay Time Accuracy	5-17
5-4	Delay Time Settings	5-18
6-1	Test Equipment Required for Calibration	6-2
6-2	Power Supply Accuracy	6-8
6-3	Vertical Deflection Accuracy	6-15
6-4	1 Millisecond Differential Delay Time Accuracy	6-35
6-5	Differential Delay Time Accuracy	6-41
6-6	Delay Time Settings	6-41



For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

2162-01

Fig. 1-1. 475A Oscilloscope.

SPECIFICATION

Introduction

The 475A Oscilloscope is a 250 megahertz bandwidth portable instrument designed to operate in a wide range of environmental conditions. The lightweight, compact design combines accurate high-frequency measurement capability and ease of transportation.

The dual-channel, DC-to-250 megahertz vertical deflection system provides calibrated deflection factors from 5 millivolts to 10 volts/division. A BW/TRIG VIEW switch permits limiting the bandwidth of the vertical system to reduce interference from high-frequency signals when viewing lower-frequency, low-level signals. The switch also permits displaying of the signal applied to the 'A' Trigger Generator on the CRT.

sweep to trigger in a stable manner on aperiodic signals or complex digital words. The horizontal deflection system has calibrated sweep rates from 0.5 second to 0.01 microsecond/division. A X10 magnifier increases each sweep rate by a factor of 10 to provide a maximum sweep rate of one nanosecond per division in the .01 μ s position. The delayed and mixed sweep features allow the start of B sweep to be delayed a selected amount from the start of A sweep to provide accurate relative-time measurements. Calibrated X-Y measurements can be made with Channel 2 providing the vertical deflection and Channel 1 providing the horizontal deflection (TIME/DIV switch fully counterclockwise and VERT MODE switch to CH 2). Regulated DC power supplies provide stable instrument performance over a wide range of line voltages and frequencies. Maximum power consumption of the instrument is approximately 100 watts.

The trigger circuits provide stable sweep triggering to beyond the 250 megahertz bandwidth of the vertical deflection system. Separate controls are provided to select the desired mode of triggering for the A and B sweeps. The A sweep can be operated in one of three modes; automatic triggering, normal triggering, or single sweep. A variable trigger holdoff control permits the A

Characteristics

The following instrument specifications apply over an ambient temperature range of -15° C to $+55^{\circ}$ C unless otherwise specified. Warmup time for specified accuracies is 20 minutes. The calibration procedure given in Section 6, if performed completely, will ensure the instrument meets the electrical characteristics listed in this section.

For Service Manuals Contact MURITRON TECHNICAL SERVICES & Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquines@maunitron.co.uk

TABLE 1-1

ELECTRICAL

Characteristics	Performance Requirements	Supplemental Information	
V	1 and CH 2)		
Deflection Factor Calibrated Range	5 mV to 10 V/DIV in 11 steps; 1-2-5 sequence.		
Cascaded Operation (CH 2 VERT SIGNAL OUT Connected to CH 1	Deflection Factor to approximately 2.5 mV/div into 50 Ω. Bandwidth: DC to ≥50 MHz.	CH 2 VERT SIGNAL OUT into CH 1 input. DC coupled using a 50 Ω , 42" RG58A/U cable terminated in 50 Ω at CH 1 input.	
Uncalibrated (VAR VOLTS/DIV) Range	Provides continuously variable de- flection factors between the cali- brated steps. Extends maximum un- calibrated deflection factor to at least 25 volts per division in the 10 V/DIV position.	At least 2.5:1.	
Low Frequency Linearity		0.1 division or less compression or expansion of 2 division signal at center screen positioned to the upper and lower extremes of the graticule area.	
Deflection Factor Accuracy	Within 3% of indicated deflection.	With GAIN set at 10 mV/DIV.	
Bandwidth	DC to 250 MHz or greater.		
Risetime	1.4 ns or less (Calculated) ¹ .		
AC Coupled Lower -3 dB Point	10 Hz or less with 1X probe.	1 Hz or less with 10X probe.	
Bandwidth with 100 or 20 MHz BW Switch in 20 MHz Position	Approximately 20 MHz.	-3 dB point between 15 MHz and 20 MHz.	
Bandwidth with 100 or 20 MHz BW Switch in 100 MHz Position	Approximately 100 MHz.	-3 dB point between 75 MHz and 125 MHz.	
nput Resistance and Capaci- ance	1 MΩ within 2% paralleled by ap- proximately 20 pF.		

Risetime is calculated from the formula:

0.35 BW (in megahertz)

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4OY Tel: 01844-35169/ Fax:-01844-352554 Email:- enquines@maunitron.co.uk

@

TABLE 1-1 (cont)

ELECTRICAL

Characteristics	Performance Requirements	Supplemental Information		
	VERTICAL DEFLECTION SYSTEM	VERTICAL DEFLECTION SYSTEM (cont)		
Step Response				
Positive-Going Step Aberrations (0°C to 40°C)				
At 10 mV/DIV		+4%, -4%, 4% P-P.		
Negative-Going Step		Add 3% to positive-going step aberrations.		
Added Mode		Add 3% to positive-going step aberrations.		
Common-Mode Rejection Ratio (ADD Mode with CH 2 inverted)		20:1 at 1 kHz for common-mode sig- nals of 8 divisions or less.		
Trace Shift as VAR is Rotated		Adjusts to 2 divisions or less.		
INVERT Trace Shift		Within 1 division from center screen when switching from normal to in- verted.		
Channel Isolation		At least 100:1 at 50 MHz.		
Position Range		At least +12 and -12 divisions from graticule center.		
ignal Delay Between CH 1 nd CH 2		0.25 ns or less at 5 mV/DIV.		
laximum Input Voltage	DC coupled: 250 V (DC + peak AC) or 500 V P-P AC at 1 kHz or less AC coupled: 500 V (DC + peak AC) or 500 V P-P AC at 1 kHz or less.			
hopped Mode Repetition Rate	Approximately 1 MHz.	-20%, +30%.		

ELECTRICAL				
Characteristics	Performance Requirements	Supplemental Information		
	TRIGGER SYSTEM			
Sensitivity				
DC Coupled	0.3 div internal or 50 mV external from DC to 40 MHz, increasing to 2.0 div internal or 250 mV external at 250 MHz.			
AC Coupled	0.3 div internal or 50 mV external from 60 Hz to 40 MHz, increasing to 2.0 div internal or 250 mV external at 250 MHz. Attenuates signals below about 60 Hz.			
HF REJ Coupled	0.5 div internal or 100 mV external from 60 Hz to 50 kHz. Attenuates signals below about 60 Hz and above about 50 kHz.			
LF REJ Coupled	0.5 div internal or 100 mV external from 50 kHz to 40 MHz, increasing to 2.0 div internal or 500 mV ex- ternal at 250 MHz. Attenuates sig- nals below about 50 kHz.	For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk		
rigger Jitter	0.2 ns or less at 250 MHz at 1 ns/DIV sweep rate (X10 MAG on).			
External Trigger Input Maximum Input Voltage	250 V DC + peak AC or 250 V P-P AC (1 kHz or less).			
Input Resistance and Capa- citance	1 M Ω within 10%, paralleled by approximately 20 pF.			

TABLE 1-1 (cont)

ELECTRICAL

¢

TABLE 1-1 (cont)

ELECTRICAL

Characteristics	Performance Requirements	Supplemental Information
	TRIGGER SYSTEM (cont)	
LEVEL Control Range		
EXT	At least + and -2 V, 4 V P-P.	
EXT ÷10	At least + and -20 V, 40 V P-P. Exclude LF REJ coupling mode.	
Trigger View		
Deflection Factor	Approximately 50 mV/DIV.	±20%. Exclude LF REJ and HF REJ trigger coupling modes.
Risetime		<4.0 ns over the 10% to 90% part of the fast-rise portion.
Delay Difference	For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk	\leq 2.5 ns with a 5 division signal having 1 ns or less risetime from a 25 Ω source, centered vertically with equal cable length from signal source to vertical channel and ex- ternal trigger inputs, each termin- ated in 50 Ω.
Centering of Trigger Point		Adjustable to within 1.0 division of center screen.
	HORIZONTAL DEFLECTION SYSTEM	Λ
Calibrated Sweep Range		
A Sweep or B DLY'D Sweep	0.5 s/DIV to 0.01 μ s/DIV in 24 steps; 1-2-5 sequence. X10 MAG extends max- imum sweep rate to 1 ns/DIV.	
A Delaying Sweep (or A INTEN)	0.5 s/DIV to 0.05 μ s/DIV in 22 steps; 1-2-5 sequence.	

TABLE 1-1 (cont)

ELECTRICAL

Characteristics	Performance Requirements		Supplemental Information
	HORIZONTAL DEFLE	CTION SYSTE	(cont)
Calibrated Sweep Accuracy	UNMAGNIFIED	MAGNIFIED	
+20°C to +30°C			Accuracy specification applies over th full 10 divisions of deflection unles otherwise specified.
A or B DLY'D Sweep			For all sweeps; exclude the first 25 n when checking 0.01 and 0.02 μ s/div un magnified sweep rates.
5 ms/DIV to 0.01 μs/DIV	±1%	±2%	For all sweeps except B; exclude the firs 25 ns or 2 unblanked div (whichever is greater) and all beyond the 100th divi-
0.5 s/DIV to 10 ms/DIV	±2%	±3%	sion of the sweep when checking magnified sweep rates. For B sweep exclude the first 25 ns or 5 unblanked div
A INTEN Sweeps (or A Delaying)			(whichever is greater) and all beyond the 100th division of the sweep when check- ing B magnified sweep rates.
0.5 s/DIV to 0.05 μs/DIV	±2%	±3%	_
-15°C to +55°C			-
All Sweeps	±3%	±4%	
X10 Magnified Sweep Accuracy	Within 5% over any 2 div interval.	vision	
Mixed Sweep Accuracy	Within 3% For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tet: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk		Accuracy applies over 8 divisions of deflection. B sweep must be at least 1 TIME/DIV setting faster than A Sweep on all ranges. When checking A TIME/DIV accuracy, exclude the first 0.5 division after the display start; when checking B TIME/DIV accuracy, exclude the first 0.2 division or 0.1 μ s (whichever is greater) after the transition of A to B.
AR TIME/DIV Control Range	Continuously variable between cali- brated settings. Extends the slowest A sweep rate to at least 1.25 sec- onds per division.		At least 2.5:1.
weep Length (A Only)			At least 10.1 divisions.
Trigger Holdoff	Increases sweep holdoff t least 9 times the TIME/DI setting.	ime to at V switch	

TABLE 1-1 (cont)

ELECTRICAL

	ELE	CTRICAL		
Characteristics Performance Requirements		Supplemental Information		
	HORIZONTAL DEF	LECTION SYSTEM (cont)	
Magnified Registration			Within 0.5 division from graticule center at 1 ms/DIV when switching X10 magnifier from on to off.	
POSITION Control Range			Start of sweep must position to right graticule center. End of sweep must position to left of graticule center. Chec made at 1 ms/DIV.	
Delay Time and Differential Time Measurement Accuracy (simplified)	+15°C to +35°C (+60°F to +95°F)	-15°C to +55°C (+5°F to +131°F)		
Over One or More Major Dial Divisions	±1%	±1.5%	tings of 0.00 thru 1.00 for .5 μ s thru .05 μ s/DIV delaying sweep rates.	
Over Less Than One Major Dial Division	±0.01 Major Dial Division	±0.02 Major Dial Division		
Delay Time and Differential Time Measurement Accuracy (see Fig. 1-2)		-15°C to +55°C +15°C to +32°C 3 4 5 6 Y TIME POSITION Dial Divisions of M ay Time and Differenti		
Delay Pickoff Jitter	Within 0.002% (less than one part in 50,000) of the maximum available de- lay time when operating the instru- ment on power line frequencies above 52 Hz, decreasing to 0.005% (less than one part in 20,000) on power line frequencies of 48 to 52 Hz.		For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel: 01844-351694 Fax:- 01844-352554 Email: enquines@mauritron.co.uk For Service Manuals Contact MAURITE	
Delay Range	From 0.05 μs or less t seconds after the star laying (A) sweep. Maximum available de times the setting of th switch.	rt of the de- elay time is ten	Te/	

1-7

TABLE 1-1 (cont)

ELECTRICAL

Characteristics	Performance Requirements	Supplant
	X-Y OPERATION	Supplemental Information
Sensitivity	Same as vertical deflection system.	TIME/DIV switch. CH 2 OR X-X button
Deflection Accuracy	Same as vertical deflection system.	of VERT MODE switch must be pushe
Variable Range	Same as vertical deflection system.	
X-Axis Bandwidth	DC to 3 MHz.	
Input Capacitance	Same as vertical deflection system.	
Input Resistance	Same as vertical deflection system.	
Maximum Input Voltage	Same as vertical deflection system.	
Phase Difference Between X an Y Axis Amplifiers	d	Within 1° from DC to 1 MHz. Within 3° from 1 MHz to 2 MHz.
X Axis Low Frequency Linearity		0.2 div or less compression or ex- pansion of a 2 div signal at center screen, positioned to horizontal extremes of display area.
Output Voltage	CALIBRATOR	
, at vonage		Adjusted to within 0.5% at 25°C, ±5°C
0°C to +40°C	300 mV within 1.0%.	
−15°C to +55°C		300 mV within 1.5%.
Repetition Rate	Approximately 1 kHz.	Within 25%.
Dutput Resistance		
Dutput Current		Approximately 9.4 Ω.
+20°C to +30°C	30 mA within 2%.	
-15°C to +55°C	2	30 mA with 1 0 m
	Z AXIS INPUT	30 mA within 2.5%
ensitivity	5 V P-P signal causes noticeable mod- ulation at normal intensity.	Positive-going signal from ground decreases intensity.
eable Frequency Range	DC to 50 MHz.	
aximum Input Voltage		
	1	100 V (DC plus peak AC)

100 V (DC plus peak AC). 100 V P-P AC at 1 kHz or less.

1-8

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

TABLE 1-1 (cont)

ELECTRICAL

Characteristics	Performance Requirements	Supplemental Information
	SIGNAL OUTPUTS	
CH 2 VERT SIGNAL OUT	One division of deflection gives approximately 20 mV into 1 M Ω load.	
Output Voltage	One division of deflection gives approximately 10 mV into 50 Ω load.	
Output Resistance		Approximately 50 Ω.
Bandwidth	DC to at least 50 MHz into 50 Ω .	
Output DC Level	Approximately 0 V.	
and B + GATE Outputs		
Output Voltage	Approximately 5 V positive-going.	
Output Resistance		Approximately 500 Ω.

POWER SOURCE

16 V to 264 V.
07 V to 253 V.
98 V to 242 V.
08 V to 132 V.
03.5 V to 126.5 V.
9 V to 121 V.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

TABLE 1-1 (cont)

ELECTRICAL

Characteristics	Performance Requirements	Supplemental Information
	CATHODE-RAY TUBE	
Horizontal Resolution		
Vertical Resolution		At least 15 lines/division
		At least 15 lines/division.
Display Area	8 x 10 cm.	
Geometry		
		0.1 division or less of tilt or bowing.
Raster Distortion		
		0.1 division or less.
Normal Accelerating Potential		Approximately 18,000 V.
Frace Rotation Range		
		Adequate to align trace with hori- zontal center line.
Standard Phosphor	P31.	
Optional Phosphor	P11.	

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@

TABLE 1-2

ENVIRONMENTAL

Characteristics	Performance Requirements	Supplemental Information
Temperature		
Operating (AC)	−15°C to +55°C.	
Storage	-55°C to +75°C.	
Altitude		
Operating	To 15,000 feet. Maximum operating temperature decreased 1°C/1,000 feet above 5,000 feet.	
Storage	To 50,000 feet.	
Humidity (Operating and Stor- age)	5 cycles (120 hours) referenced to MIL-E-16400F.	
Vibration (Operating)	15 minutes along each of three major axes at a total displacement of 0.025 inch P-P (4 g's at 55 Hz) with frequency varied from 10 Hz to 55 Hz to 10 Hz in one minute sweeps. After sweep vibration in each axis, hold frequency steady at each major res- onance for 3 minutes, or if no such resonances are found, hold at 55 Hz for three minutes.	
hock (Operating and Non- perating)	30 g's, 1/2 sine, 11 ms duration, 2 shocks per axis each direction for a total of 12 shocks.	
ransportation	Meets the limits of National Safe Transit Committee test procedure 1A with a 30-inch drop.	

TABLE 1-3

PHYSICAL

Characteristics	Information
Construction	
Chassis	Aluminum alloy.
Panel	Aluminum alloy with anodized finish.
Cabinet	Blue vinyl-coated aluminum alloy.
Circuit Boards	Glass laminate etched-wiring.
Overall Dimension	
Height	
With Feet and Pouch	7.5 inches (19.1 cm).
Without Pouch	6.2 inches (15.7 cm).
Width	
With Handle	12.9 inches (32.8 cm).
Without Handle	11.5 inches (29.2 cm).
Depth	
Including Panel Cover	18.1 inches (46 cm).
Handle Extended	20.3 inches (51.5 cm).
Weight	
With Panel Cover, Acces- sories, and Accessory Pouch	25.3 pounds (11.5 kg).
Without Panel Cover, Ac- cessories, and Accessory Pouch.	22.8 pounds (10.3 kg).
mestic Shipping Weight	32.7 pounds (14.8 kg).
port Shipping Weight	Approximately 48.0 pounds (21.8 kg).

Standard Accessories

Standard accessories supplied with the 475A are listed in the Mechanical Parts List, in this Service manual. For optional accessories available for use with the 475A, see the Tektronix, Inc., catalog.

OPERATING INFORMATION

PRELIMINARY INSTRUCTIONS

Introduction

This section of the manual is intended to allow the operator to become familiar with the instrument's power requirements, functions of controls and connectors, and how to obtain a few basic displays. For more complete operating information refer to the 475A Operators Instruction Manual.

Safety Information



This instrument may be damaged if operated with the Line Voltage Selector Switch or the Regulating Range Selector set for the wrong applied line voltage. Please read the following instructions before operating to be sure that the requirements for instrument power and user safety are met.

Conductor	Color	Alternate Color	
Ungrounded (Line)	Brown	Black	
Grounded (Neutral)	Blue	White	
Grounding (Earthing)	Green-Yellow	Green-Yellow	

Power Cord Conductor Identification

This instrument is designed to operate from a singlephase power source with one of the current-carrying conductors (the neutral conductor) at ground (earth) potential. Operation from power sources where both current-carrying conductors are live with respect to ground (such as phase-to-phase on a 3-wire system) is not recommended, since only the line conductor has overcurrent (fuse) protection within the instrument.

This instrument has a 3-wire power cord with a 3terminal polarized plug for connection to the power source and safety-earth. The ground terminal of the plug is directly connected to the instrument frame. For electricshock protection, insert this plug in a mating outlet with a safety-earth contact. If a 3-to-2 wire adapter is used to connect this instrument to a 2-wire ac power system, be sure to connect the ground lead of the adapter to earth (ground). Failure to complete the ground system may allow the chassis of this instrument to be elevated above ground potential and pose a shock hazard.

Operating Power Sources

This instrument can be operated from either a 115 volt or 230 volt nominal line voltage source, 48 to 440 Hertz. The Line Voltage Selector switch in the instrument converts the instrument from a one nominal operating voltage to the other. The Regulating Range Selector assembly on the instrument rear panel selects 1 of 3 regulating ranges for each nominal line voltage, and also contains the line fuse for overload protection.

Line Voltage and Regulating Range

To select the correct nominal line voltage, regulating range and line fuse, proceed as follows:

1. Disconnect the instrument from the power source.

2. Set the Line Voltage Selector switch (located near the right rear of instrument) to indicate the desired nominal line voltage.

3. Loosen the 2 captive screws that hold the cover on the Regulating Range Selector assembly; then pull on the cover to remove.

4. Check Table 2-1 for the recommended rating of the line fuse to be used with the desired nominal line voltage. Check the fuse in the selector switch cover for the recommended rating or install a fuse with the recommended rating. The instrument Accessory Pouch should contain a spare fuse for each nominal line voltage at any time.

TABLE 2-1

Regulating Ranges			
Regulating Range			
		230 Volts Nominal	
LO (Switch bar in lower holes)	99 to 121 volts	198 to 242 volts	
M (Switch bar in middle holes)	103.5 to 126.5 V	207 to 253 V	
HI (Switch bar in upper holes)	108 to 132 volts	216 to 264 volts	
Fuse Rating	1.5 A 3AG Fast-blow	0.75 A 3AG Fast-blow	

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@



Fig. 2-1. Regulating Range Selector and Line Fuse.

5. Check Table 2-1 for the recommended range position of the Range Selector Switch Bar (see Figure 2-1). Select a range which is centered about the average line voltage to which the instrument is to be connected. The middle position ("M") is a typical setting.

6. If necessary, gently pull out the Range Selector Switch Bar, slide the bar to the desired position and plug it back in.

Install the cover on the Regulating Range Selector assembly and gently tighten the 2 captive screws.

8. Connect the instrument to the recommended power source, pull the instrument POWER switch to ON and begin usage of the 475A Oscilloscope.

Options

Options are available to alter oscilloscope performance to meet particular applications. A number in either MOD slot (see instrument rear panel) indicates that the instrument contains an option.

Refer to the Option section in this manual to find any change in operating instructions as a result of the option.

CONTROLS AND CONNECTORS

General

The major controls and connectors for operation of the 475A are located on the front panel of the instrument. A few auxiliary functions are provided on the rear panel. Fig. 2-2 shows the front and rear panels of the 475A. A brief description of each control and connector is given here. More detailed operating information is given in the 475A Oscilloscope Operators Manual.

Cathode-Ray Tube (CRT) and Display

BEAM FINDER	Limits the display to within the graticule area, independently of display position or applied signals and sets the display brightness to a normal viewing level.
INTENSITY	Controls brightness of the dis- play.
FOCUS	Provides adjustment for op- timum display definition.
SCALE ILLUM	Controls graticule brightness.
ASTIG	Screwdriver adjustment used in conjunction with the FOCUS control to obtain a well-defined display. Does not require read- justment in normal use.
TRACE ROTATION	Screwdriver adjustment to align the trace with the horizontal graticule lines.
Vertical Deflection Sy	stem (Channel 1 & Channel 2)
POSITION	Controls the vertical position of the trace. In the X-Y mode of operation, the CH 2 control positions on the Y-axis (ver- tically) and the CH 1 POSITION control positions on the X-axis (horizontally).
CH 1 OR X	Input connector for Channel 1 deflection signals or X-axis deflection in the X-Y mode of operation.



A. FRONT PANEL



B. REAR PANEL

2162-02

2-3

Fig. 2-2. Front panel and rear panel controls and connectors.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

CH 2 OR Y	Input connector for Channel 2
	deflection signals or Y-axis
	deflection in the X-Y mode of operation.

GAIN (5 and 10 mV) Screwdriver adjustments to set the gain of the Vertical Preamp.

VOLTS/DIV Selects vertical deflection factor in a 1-2-5 sequence (VAR control must be in the calibrated detent for the indicated deflection factor).

VAR Provides continuously variable uncalibrated deflection factors between the calibrated settings of the VOLTS/DIV switch.

UNCAL Light indicates that the VAR control is not in the calibrated position.

Input CouplingSelects the method of coupling(AC-GND-DC)signal to the input of the Vertical
Amplifier.

AC: Signal is capacitively coupled to the Vertical Amplifier. DC component of signal is blocked. Lowfrequency limit (lower -3 dB point) is about 10 Hertz.

GND: Input signal is removed and the input circuit is grounded. Does not ground the input signal.

DC: All components of the input signal are passed to the Vertical Amplifier.

100 OR 20 MHz BW/Multi-purpose switch that limitsTRIG VIEWvertical bandwidth or displays
an external triggering signal.

vertical bandwidth or displays an external triggering signal. Full bandwidth of 250 MHz is provided in the switch position obtained when the TRIG VIEW is pushed in, then released. The full bandwidth position serves as the reference for the following settings. 100 (MHz): When TRIG VIEW button is pulled to the first detent (100 indicated on yellow band of TRIG VIEW knob) the upper bandwidth of the complete Vertical Deflection System is limited to approximately 100 MHz.

20 (MHz): When TRIG VIEW button is pulled to the second detent (100 and 20 indicated on yellow band of TRIG VIEW knob) the upper bandwidth of the complete Vertical Deflection System is limited to approximately 20 MHz.

TRIG VIEW: When the TRIG VIEW button is pushed and held, the output of the Vertical Preamplifier is interrupted, and the trigger signal selected by the setting of A TRIGGER SOURCE switch is displayed on the crt.

When the TRIG VIEW button is pushed and held, the crt display available is explained in each of the following settings of the A TRIGGER SOURCE switch.

NOTE

The signals displayed are affected by the coupling characteristics of the A TRIGGER COUPLING switch positions (see A Trigger Coupling information in this section).

The A TRIGGER LEVEL control affects the triggering and the vertical positioning when using a TRIG VIEW display.

> NORM: Any signal that is displayed in full bandwidth position is viewed with an increase in signal amplitude.

CH 1: Any signal that is displayed in CH 1 of VERT MODE, in full bandwidth position, is viewed with an increase in signal amplitude.

2-4

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk

		Operatir	ng Information—475A Service
	CH 2: Any signal that is dis- played in CH 2 of VERT MODE, in full bandwidth position, is viewed with an increase in signal amplitude.		CH 2 OR X-Y: Displays Channel 2 only. Must be pushed when operating in X-Y mode.
i		A and B Triggering (both where applicable)
	LINE: The power line signal is displayed at an amplitude ap- proximately equalling full ver- tical graticule deflection.	COUPLING	Determines the method used to couple signal to input of trigger circuits.
	EXT: The signal present at the A TRIGGER external input con- nector will be displayed.		AC: Rejects DC and attenuates signals below about 60 Hz. Accepts signals above about 60 Hz.
th Co W	EXT ÷ 10: The signal present at the A TRIGGER external input connector will be displayed, but will be reduced approximately 10 times of that viewed in EXT.	For Service Manuals Contact MAURITRON TECHNICAL SERVICES	LF REJ: Rejects DC and atten- uates signals below about 50 kHz. Accepts signals above about 50 kHz.
INVERT	8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk the Channel 2 display.	Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554	HF REJ: Accepts signals between 60 Hz and 50 kHz. Rejects DC and attenuates all signals outside the above range.
VERT MODE	Selects the vertical mode of operation.		DC: Accepts all trig ger signals between DC and 200 MHz or greater.
	CH 1: Displays Channel 1 only.	SOURCE	Selects source of trigger signal.
	ALT: Dual-trace display of signals using both channels. Display is switched between channels at the end of each sweep.		NORM: Internal trigger signal obtained from Vertical Deflec- tion System. Actual source is signal(s) displayed on crt.
	ADD: Signals applied to the CH 1 OR X and the CH 2 OR Y connectors are algebraically added and the sum is displayed on the ort. The INIVERT switch		CH 1: A sample of the signal connected to the CH 1 OR X input connector is used as a trigger signal.
	on the crt. The INVERT switch in Channel 2 allows the display to be CH $1 + CH 2$ or CH $1 - CH$ 2.		CH 2: A sample of the signal connected to the CH 2 OR Y input connector is used as a trigger signal.
	CHOP: Dual-trace display of signals on both channels. Display is switched between channels at an approximate repetition rate of 1 megahertz.		EXT: Trigger signal obtained from signal connected to the External Trigger Input connec- tor.

Operating Informa	tion—475A Service		
	EXT ÷ 10 (A Trigger circuit only): External trigger signal attenuated by a factor of 10. STARTS AFTER DELAY (B trigger circuit only): B sweep starts immediately after the delay time selected by the DELAY TIME POSITION dial		NORM: With the proper trigger control settings, A Sweep can be initiated by signals that are within the frequency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misad- justed, there is no trace.
	and the DELAY TIME switch. LINE (A trigger circuit only): Trigger signal obtained from a sample of the line voltage applied to the instrument.		SINGL SWP: After a sweep is displayed, further sweeps can- not be presented until the SINGL SWP pushbutton is pressed again. The display is triggered as for NORM opera- tion using the A Triggering con- trols.
SLOPE	Selects the slope of the trigger signal which starts the sweep. +: Sweep can be triggered from the positive-going portion of the trigger signal.	TRIG Indicator	A light on condition indicates that A Sweep Generator is triggered and will produce a stable display.
LEVEL	-: Sweep can be triggered from the negative-going portion of the trigger signal. Selects the amplitude point on the trigger signal at which the	A TRIG HOLDOFF	Provides control of holdoff time between sweeps to obtain stable displays when triggering in aperiodic signals (such as complex digital words). Variable can increase hold-off time up to at least 9 times the setting of the TIME/DIV switch. In the B ENDS A position (fully clockwise), the A Sweep is reset
	sweep is triggered.		at the end of the B Sweep to provide the fastest possible sweep repetition rate for delayed sweep presentations.
A TRIG MODE	Determines the operating mode for the A Trigger Circuit. AUTO: With the proper trigger control settings, A Sweep can be initiated by signals that have	External Trigger Input (not labeled)	Input connectors for external trigger signals.
	repetition rates above about 20 Hertz and are within the fre- quency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger con- trols are misadjusted, the sweep free-runs to produce a reference trace.	A and B Sweep DELAY TIME POSITION	Provides variable sweep delay between 0.00 and 10.00 times the delay time indicated by the DELAY TIME switch.
2-6			@

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.4k

MIX: The first part of the horizontal sweep is displayed at a rate set by the A TIME/DIV switch and the latter part of the sweep at a rate set by the B TIME/DIV switch. Relative amounts of the display allocated to each of the two rates are determined by the setting of the DELAY TIME POSITION dial.

A INTEN: Displayed sweep rate determined by the A TIME/DIV switch. An intensified portion appears on the display during the B sweep time. This switch position provides a check of the duration and position of the B sweep (delayed sweep) with respect to the delaying sweep (A).

B DLYD: Sweep rate determined by the B TIME/DIV switch with the delay time determined by the setting of the DELAY TIME (A TIME/DIV) switch and the DELAY TIME POSITION dial.

Positions the display horizontally.

Provides more precise horizontal position adjustments.

Increases the displayed sweep rate by a factor of 10.

Calibrator and Power

X10 MAG Pushbutton

Horizontal POSITION

Horizontal FINE

CALIBRATOR A combination current loop/squarewave voltage output device. Provides a 30 mA squarewave current, 300 mV squarewave voltage signal with a repetition rate of approximately 1 kHz.

off.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email: enquiries@mauritron.co.uk

A AND B TIME/DIV AND DELAY TIME

VAR

A TIME/DIV switch (clear plastic outer flange) selects the basic delay time to be multiplied by the DELAY TIME POSITION dial setting) for delayed-sweep operation. The B TIME/DIV switch (inner dark knob) selects the sweep rate for A only displays or for the B portion of a delayed sweep display. VAR control must be in the calibrated detent for calibrated sweep rates. Disables sweep for X-Y operation.

Provides continuously variable (uncalibrated) sweep rates between the calibrated settings of the TIME/DIV switch. Varies the A Time Base sweep rate in the nondelayed mode of horizontal operation and the B Time Base sweep rate in the delayed sweep mode. Extends the slowest sweep rate to at least 1.25 seconds/division. Sweep rate is calibrated when the control is rotated fully clockwise to the calibrated detent.

UNCAL Light that indicates when the VAR TIME/DIV control is out of the calibrated detent and the horizontal sweep rate is uncalibrated.

X10 MAG Indicator Light that indicates when the X10 MAG is turned on.

READY Light that indicates that A Sweep has been prepared to present a single sweep upon receipt of an adequate trigger signal.

HORIZ DISPLAY Selects the horizontal mode of operation.

A: Horizontal deflection provided by ATIME/DIV switch.

LOW LINE Indicator	Light that indicates the applied line voltage is below the lower	OBTAINING	BASIC DISPLAYS
	limit of the regulating range selected by the Regulating Range Selector assembly.	is unfamiliar with the op basic displays common	tions will allow the operator who peration of the 475A to obtain the ly used. Before proceeding with set the instrument controls as
Rear Panel		Vertical Controls	
A + GATE	Output connector providing a positive-going rectangular pulse coincident with the A sweep time.	VERT MODE Switch VOLTS/DIV Switches	CH 1 Proper position determined by amplitude of signal to be applied.
		Controls Input Coupling	Calibrated detent.
B + GATE	Output connector providing a positive-going rectangular	Switches Vertical POSITION	AC
	pulse coincident with the B sweep time.	Controls 100 or 20 MHz	Midrange
		BW Switch	Not limited (Yellow band not visible).
CH 2 VERT SIGNAL	Output connector providing a	INVERT Switch INTENSITY Control FOCUS Control	Button out Fully counterclockwise Midrange
OUT	sample of the signal applied to the CH 2 input connector.	SCALE ILLUM Control	Midrange
		Trigger Controls (bot	h A and B if applicable)
EXT Z AXIS Input	Input connector for intensity modulation of the crt display.	SLOPE Switch LEVEL Control SOURCE Switch COUPLING Switch TRIG MODE Switch A TRIG HOLDOFF	+ 0 NORM AC AUTO
Regulating Range Selector	Selects the regulating range of the internal power supplies (low, medium, high; determined	Control	NORM
	by specific line voltage applied to the instrument).	Horizontal Sweep Cor	ntrols
		TIME/DIV Switches TIME/DIV VAR HORIZ DISPLAY Switch	Locked together at 1 ms Calibrated detent A
PROBE POWER	Connectors that make operating power available for active device probe systems.	X10 MAG Switch POSITION Control FINE Control	Off (button out) Midrange Midrange
		Normal Sweep Displa	у
Rear Panel Feet	Provide temporary support for the instrument and provide a convenient cord wrap to store	 Pull the POWER s several minutes for instru- 	switch to on (button out). Allow ument warmup.
	power cord when instrument is not in use.	2. Connect an exter connector.	mal signal to the CH 1 input
0.0			0

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquines@mauritron.co.uk 3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FINDER pushbutton and adjust the CH 1 VOLTS/DIV switch until the display is reduced in size vertically; then center the compressed display with the vertical and horizontal POSITION controls; release the BEAM FINDER pushbutton. Adjust the FOCUS control for a well-defined display.

4. Set the CH 1 VOLTS/DIV switch and CH 1 POSITION control for a display that remains in the display area vertically.

5. Adjust the A Trigger LEVEL control for a stable display.

6. Set the TIME/DIV switch and the horizontal POSITION control for a display that remains in the display area horizontally.

Magnified Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Adjust the horizontal POSITION control to move the area to be magnified to within the center graticule division of the crt. If necessary, change the TIME/DIV switch setting so the complete area to be magnified is within the center division.

3. Set the X10 MAG switch to the on position (button in) and adjust the horizontal POSITION control for precise positioning of the magnified display. Divide the TIME/DIV setting by 10 to determine the magnified sweep rate.

Delayed Sweep Displays

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Set the HORIZ DISPLAY switch to A INTEN and the B Trigger SOURCE switch to STARTS AFTER DELAY.

3. Pull out the B TIME/DIV switch knob and turn clockwise so the intensified zone on the display is the desired length. Adjust the INTENSITY control to achieve the desired display brightness.

 Adjust the DELAY TIME POSITION dial to position the intensified zone to the portion of the display to be delayed.

Operating Information—475A Service

5. Set the HORIZ DISPLAY switch to B DLYD. The intensified zone on the display noted in step 3 is now being displayed in the delayed form. The delayed sweep rate is indicated by the line on the B TIME/DIV switch knob.

6. For a delayed sweep display that will exhibit less jitter, set the B Trigger SOURCE switch to the same position as the A Trigger SOURCE switch and adjust the B Trigger LEVEL control for a stable display. If the A Trigger SOURCE switch is in the LINE position, a sample of the line voltage will have to be supplied to the B Trigger circuit externally.

Mixed Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Pull out the B TIME/DIV switch knob and turn clockwise to the desired sweep rate. Adjust the INTEN-SITY control to achieve the desired display brightness.

3. Set the HORIZ DISPLAY switch to MIX. The crt display now contains more than one time factor on the horizontal axis. The first portion of the display is at the A Time Base sweep rate and the latter part is at the B Time Ease sweep rate. The start of the B Time Base portion of the display can be changed by adjusting the DELAY TIME POSITION control.

X-Y Display

1. Preset the instrument controls and turn the instrument power on. Allow several minutes for instrument warm-up.

2. Set the TIME/DIV switch to X-Y and the VERT MODE to CH 2. Apply the vertical signal to the CH 2 OR Y input connector and the horizontal signal to the CH 1 OR X input connector. The CH 2 POSITION control will provide vertical positioning and the CH 1 POSITION control will provide horizontal positioning.

3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FINDER pushbutton and adjust the CH 1 and CH 2 VOLTS/DIV switches until the display is reduced in size both vertically and horizon-tally; then center the compressed display with the POSITION controls; release the BEAM FINDER pushbutton. Adjust the FOCUS control for a well-defined display.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

2-9

CIRCUIT DESCRIPTION

Introduction

This section of the manual describes the circuitry used in the 475A Oscilloscope. The description begins with a discussion of the instrument, using a basic block diagram. Next, each circuit is described in detail, using detailed block diagrams when appropriate, to show the relationships between the stages in each major circuit.

Digital Logic

Digital logic techniques are used to perform many functions within this instrument. The function and operation of the logic circuits are described using logic symbology and terminology. All logic functions are described using the positive logic convention. Positive logic is a system of notation where the more positive of two levels (HI) is called the true or 1 state; the more negative level (LO) is called the false or 0 state. The HI-LO method of notation is used in this logic description. The specific voltages that constitute a HI or LO state vary between individual devices.

NOTE

The HI-LO logic notation can be conveniently converted to 1-0 notation by disregarding the first letter of each step. Thus:

It should be noted that not all of the integrated circuit devices in this instrument are digital logic devices. The function of non-digital devices are described individually, using operating waveforms or other techniques to illustrate their function.

OUTLINE FOR CIRCUIT DESCRIPTION

BLOCK DIAGRAM

General	Page 3-2
CHANNEL 1 PREAMP	
General	Page 3-4
Input Coupling	Page 3-5
Input Attenuator	Page 3-5
First Cascode Amplifier	Page 3-5
Second Cascode Amplifier	Page 3-6
Third Cascode Amplifier	Page 3-6



General	·
First Cascode	Amplifier

Page 3-6 Page 3-7

VERTICAL CHANNEL SWITCHING

VERTICAL CHANNEL SWITCHING 3	
General	Page 3-7
Channel Switch IC	Page 3-8
Switching Logic Flip-Flops	Page 3-8
Two Megahertz Clock	Page 3-9
Chop Blanking Amplifier	Page 3-9
Channel 2 Signal Output Amplifier	Page 3-9
Normal Trigger Pickoff Amplifier	Page 3-9
Scale-Factor Switching Circuits	Page 3-9
VERTICAL OUTPUT AMPLIFIER	
General	Page 3-9
First IC Amplifier	Page 3-9
Second IC Amplifier	Page 3-10
A TRIGGER GENERATOR	
General	Page 3-10
Trigger Source	Page 3-11
Trigger Coupling	Page 3-11
Input Source Follower	Page 3-11
Paraphase Amplifier	Page 3-11
Tunnel Diode Driver	Page 3-11
Trigger View Amplifier	Page 3-11
B TRIGGER GENERATOR	
General	Page 3-12
Trigger Source	Page 3-12
SWEEP AND Z-AXIS LOGIC	
General	Page 3-12
Sweep Control Integrated Circuit	Page 3-13
Main Gate Comparator	Page 3-14
Delayed Gate Comparator	Page 3-14
A Trigger TD Reset Circuit	Page 3-14
Holdoff Start Circuit	Page 3-14

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Z Axis Logic Multivibrator

B Trigger TD Reset Circuit

LOW LINE Indicator Circuit

Delaying Sweep Latch Circuit

Main Sweep Holdoff Gate and Delayed Sweep Override Amplifier

A +GATE And B +GATE Amplifiers

Page 3-14

Page 3-15

Page 3-15

Page 3-15

Page 3-15

Page 3-15

Circuit Description—475A Service

SWEEP GENERATORS (8)

TIMING AND HORIZONTAL DISPLAY SWITCHING

	•
General	Page 3-16
Delaying Sweep Generator	Page 3-17
Main Gate Amplifier	Page 3-17
Sweep Disconnect Amplifier	Page 3-17
Sawtooth Sweep Generator	Page 3-18
Sweep Start Amplifier	Page 3-18
Output Buffer Amplifier	Page 3-18
Delaying Sweep End Difference	-
Amplifier	Page 3-18
Delay Pickoff Comparator	Page 3-18
Non-Delaying Sweep Generators	Page 3-19
"B" Gate Amplifier	Page 3-19
Non-Delaying Sweep Generator	-
Differences	Page 3-19
Mixed Mode Operation	Page 3-19
Non-Delaying Sweep End Difference	
Amplifier	Page 3-19
TIME/DIV Functions (Knobs Unlocked)	Page 3-20

HORIZONTAL AMPLIFIER

General	Page 3-20
Input Paraphase Amplifier	Page 3-21
Gain Setting Amplifier	Page 3-21
Output Amplifier	Page 3-21

LOW-VOLTAGE POWER SUPPLY

General	Page 3-21
Power Input	Page 3-23
Secondary Circuit	Page 3-23
+50-Volt Supply	Page 3-23
+110-Volt Supply	Page 3-24
+15-Volt Supply	Page 3-24
+5-Volt Supply	Page 3-24
-8-Volt Supply	Page 3-24
-15-Volt Supply	Page 3-24

CRT CIRCUIT

General	Page 3-24
High-Voltage Oscillator	Page 3-25
High-Voltage Regulator	Page 3-25
High-Voltage Rectifiers and Output	Page 3-26
Control-Grid DC Restorer	Page 3-26
CRT Control Circuits	Page 3-26
Z-Axis Amplifier	Page 3-26
CALIBRATOR	
General	Page 3-27
Multivibrator	Page 3-27
Output Amplifier	Page 3-27

Page 3-27

FAN MOTOR CIRCUIT

General

BLOCK DIAGRAM

General

The following discussion is provided to aid in understanding the overall concept of the 475A Oscilloscope before the individual circuits are discussed in detail. A basic block diagram of the 475A Oscilloscope is shown in Fig. 3-1. Only the basic interconnections between the individual blocks are shown on this diagram. Each block represents a major circuit within the instrument. The numbered diamond in each block refers to the complete circuit diagram of that major circuit and this diagram can be found in the Diagrams Section of this manual.

A complete block diagram is located in the Diagrams Section of this manual. This block diagram shows the overall relationship between all of the circuits. Complete schematics of each circuit are also given in the Diagrams Section. Refer to these diagrams throughout the following circuit description for electrical values, waveforms and relationships of the front panel controls to the individual stages.

Signals to be displayed on the CRT are applied to the CH 1 OR X or CH 2 OR Y connectors. The input signals are then amplified by the Preamplifier circuits. Each Preamplifier circuit includes separate vertical deflection factor, input coupling, balance, gain, and variable attenuation controls. The Channel 2 Preamplifier circuit also contains an INVERT feature to invert the Channel 2 signal as displayed on the CRT

The output of each Vertical Preamplifier circuit connects to the Vertical Channel Switching circuit. This circuit selects the channel(s) to be displayed. An output signal from this circuit connects to the Z Axis Amplifier circuit to blank out the switching transients between channels when in the chopped mode of operation. The Vertical Channel Switching circuit also provides the Channel 2 VERT SIG OUT signal (available on the instrument rear panel) as well as the signals used for sweep triggering in the NORM, CH 1, and CH 2 positions of the trigger SOURCE switches and the signal used for Xaxis deflection in the X-Y mode of horizontal operation.

The output of the Vertical Channel Switching circuit connects to the Vertical Output Amplifier through the Delay Line. The Delay Line provides a fixed amount of signal delay through the vertical deflection system to allow viewing the leading edge of a triggering waveform. The Vertical Output Amplifier circuit provides the final amplification for the signal before it is connected to the vertical deflection plates of the CRT. This circuit includes the BEAM FINDER switch, which limits the vertical and horizontal deflection to within the viewing area, and sets the display brightness to a normal viewing level to aid in locating an off-screen display.



Fig. 3-1. Basic block diagram of the 475A.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk 3-3

Circuit Description—475A Service



Fig. 3-2. Detailed block diagram of the Channel 1 Vertical Preamplifier circuit.

Input Coupling

Signals applied to the input connector can be AC coupled, DC coupled, or internally disconnected from the input to the Vertical Input Amplifier circuit. When Input Coupling switch S20A is set for DC coupling, the input signal is coupled directly to the Input Attenuator stage. When AC coupled, the input signal passes through capacitor C12. This capacitor prevents the DC component of the signal from passing to the amplifier. In the GND position, S20A opens the signal path and connects the input of the amplifier to ground through R24. This provides a ground reference without the need to disconnect the applied signal from the input connector. Resistor R22, connected across the input coupling switch. allows C12 to be pre-charged in the ground position, which prevents generation of large voltage transients at the input to the amplifier and allows the trace to remain on screen when switched to the AC position.

Input Attenuator

The effective overall deflection factor of each channel of the 475A is determined by the appropriate VOLTS/DIV switch setting. The basic deflection factor of the Vertical Deflection System is 10 millivolts/division of CRT deflection. To achieve the deflection factor values indicated on the front panel, precision attenuators are switched into the circuit and, in the 5 mV position, the gain of the Second Cascode Amplifier stage is increased. For the VOLTS/DIV switch positions above 10 mV, attenuators are switched into the circuit singly or in pairs to help produce the vertical deflection factors indicated. These attenuators are frequency-compensated voltage dividers. In addition to providing constant attenuation at all frequencies within the bandwidth of the instrument, the Input Attenuators are designed to maintain the same input RC characteristics for each setting of the VOLTS/DIV switch. Each attenuator contains an adjustable series capacitor to provide correct attenuation at high frequencies and an adjustable shunt capacitor to provide correct input capacitance.

NOTE

Each attenuator is a hybrid encapsulated plug-in assembly; therefore, replacement of individual components within the attenuator are not possible. Should defects occur, the attenuator must be replaced as a unit.

First Cascode Amplifier

The first amplifier stage in the Channel 1 Preamplifier circuit is hybrid circuit U120. U120 basically consists of an integrated emitter-coupled, push-pull, cascode amplifier and two discrete field-effect transistors (FET) mounted on a ceramic substrate with the thick-film resistors. The stage is a paraphase amplifier and converts the single-ended input signal to push-pull output signals. CR104 and CR107 provide protection for the input to U120 if large negative-going signals or DC levels are applied to the CH 1 OR X input connector.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Circuit Description—475A Service

This input amplifier stage contains the CH 1 VAR VOLTS/DIV control. This control provides continuously variable (uncalibrated) vertical deflection factors between the calibrated positions of the VOLTS/DIV switch. With the VAR control in its calibrated detent (wiper at ground), the output transistors of U120, whose collectors connect to pins 5 and 9, are conducting; the output transistors whose collectors connect to pins 6 and 8 are biased off. Thus, the current available to the following amplifier stage is that flowing from pins 5 and 9.

When the VAR control is rotated out of its calibrated detent, the transistors whose collectors connect to pins 6 and 8 begin to conduct. The current they conduct is robbed from the other output transistors. This causes two things to occur:

1. The current flowing in the collectors of the transistors connected to pins 5 and 9 is less now than when the VAR control was in its calibrated detent.

2. The current available to the following amplifier stage is the algebraic sum of the currents in the collectors tied together (i.e., pins 8 and 9 and pins 5 and 6). Since the two collectors tied together have signals of opposite polarity, the signal available to the following amplifier stage is less than that when the VAR control was in its calibrated detent. The component values selected for the variable function provide a variable attenuation ratio of approximately 2.5 to 1. The Channel 1 Variable Balance adjustment R110 adjusts for no trace shift in the display when rotating the VAR control. The Channel 1 UNCAL light indicates when the Channel 1 VAR control is out of its calibrated detent. The components connected between pins 2 and 3 of U120 provide high-frequency compensation for the stage.

The gain of U140 is determined by biasing the output transistors connected to pins 6 and 8 to conduct more or less current. As more current is conducted through the transistors connected to pins 6 and 8, that much less is conducted through the transistors connected to pins 5 and 9. The current conducted by the transistors connected to pins 5 and 9 in the 5 mV position of the VOLTS/DIV switch is approximately 2.5 times the current conducted by the same transistors in all of the other VOLTS/DIV switch positions. This results in increased gain and a DC level shift at the signal output terminals of U140. The VOLTS/DIV switch compensates for a shift in the DC level by shorting out part of the common-mode resistance (R157) when operating with 5 mV sensitivity. Gain Switch Balance adjustment R135 adjusts the DC balance of the stage, so there is no baseline shift in the CRT display when switching between the 5 mV and 10 mV positions of the CH 1 VOLTS/DIV switch. The remainder of the components connected between pins 2 and 3 of U140 provide high-frequency compensation for the stage.

Third Cascode Amplifier

The third amplifier stage in the Channel 1 Preamplifier circuit is a discrete component cascode amplifier made up of Q172, Q178, Q182, Q184, and Q188. Q184 is a relatively constant current source for Q172 and Q182. Q172 and Q182 convert the input voltage signals into current signals which are in turn converted back to voltage signals by Q178 and Q188 respectively. R172 and R182 provide thermal compensation and C172 and C182 AC-couple the signal around R172 and R182 to reduce Miller effect. C175 and R175 are variable high-frequency compensation adjustments while CR170, CR174, and RT170 offset compensation changes associated with variations in ambient temperature. As temperature increases, the value of RT170 decreases. This results in a decrease in voltage across CR170 and CR174. CR170 and CR174 are voltagevariable capacitance semiconductors whose capacitance increases with a decrease in reverse voltage across them. Thus, CR170 and CR174 will provide more peaking at higher temperatures. T178 is a toroid inductor that cancels high-frequency common-mode signals generated by the previous stages. The Channel 1 Vertical Position Centering adjustment centers the range of control of the Channel 1 POSITION control.

Second Cascode Amplifier

The second amplifier stage in the Channel 1 Preamplifier circuit is U140. U140 is an integrated emittercoupled, push-pull, cascode amplifier similar to that used in U120. It is used as a push-pull amplifier and has 5 mV and 10 mV gain adjustments that determine the overall gain of the Channel 1 Preamplifier circuit. The output signals available to the next stage for amplification are taken from pins 5 and 9 of U140.



2

General

The Channel 2 Preamp circuit is virtually the same as the Channel 1 Preamp circuit. Only the differences between the two circuits are described here. Portions of this circuit not described in the following description operate in the same manner as for the Channel 1 Preamp circuit. Fig. 3-3 shows a detailed block diagram of the Channel 2 Preamp circuit. A schematic of this circuit is shown on Diagram 2, at the rear of this manual.



Fig. 3-3. Detailed block diagram of the Channel 2 Vertical Preamplifier circuit.

First Cascode Amplifier

Basically, the First Cascode Amplifier stage in Channel 2 operates as described for the First Cascode Amplifier stage in Channel 1. However, the Channel 2 First Cascode Amplifier also contains the INVERT switching function. This allows the Channel 2 signal to be inverted as displayed on the CRT. The INVERT switch, when pushed, changes the biasing on the output transistors of U220 so that the normally inactive transistors are now carrying the signal. Since their outputs are cross-coupled from side to side the output signal is of opposite polarity to that available in the normal (button out) position of the INVERT switch. The Channel 2 Invert Balance adjustment R215 adjusts the DC balance of the stage to eliminate baseline shift in the display when switching from a normal to an inverted display.

VERTICAL CHANNEL SWITCHING



The Vertical Channel Switching circuit determines whether the Channel 1 or the Channel 2 Preamp signal or both will be connected to the Vertical Output Amplifier circuit. In the ALT and CHOP modes of operation, both channels are alternately displayed on a shared-time basis. The Vertical Channel Switching circuit also provides several internal trigger signals to the Trigger Generator circuits, the Channel 2 VERT SIGNAL OUT signal to a connector on the rear panel, and the chopped blanking signal to the Z Axis Amplifier. Fig. 3-4 shows a detailed block diagram of the Vertical Channel Switching circuit. A schematic of this circuit is shown on Diagram 3 at the rear of this manual.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

3



Fig. 3-4. Detailed block diagram of the Vertical Channel Switching circuit.

Channel Switch IC

The Channel Switch IC U370 determines which of the Preamp signals will be passed to the Vertical Output Amplifier. The push-pull Preamp signals connect between pins 2 and 3 (Channel 2) and between pins 10 and 11 (Channel 1) of U370. The logic levels connected to pins 1, 12, 13, and 16 determine what signals are presented at output pins 14 and 15. The following logic truth table (Table 3-1) defines the switching function of U370.

TABLE 3-1	1862-85
Input/Output Logic for U370	

Pin 1	Pin 12	Pin 13	Pin 16	Output Signal Pins 14, 15
1	0	1	0	Channel 2
0	1	0	1	Channel 1
1	1	0	0	Add (Algebraic sum of Channel 1 and 2)

U370 also makes available samples of the Channel 1 signal at pins 8 and 9 and samples of the Channel 2 signal at pins 4 and 5. The output signals at pins 4, 5, 8, and 9 are always present when signals are applied to the channel inputs regardless of the switching logic levels applied to U370. The Channel 1 signal present at pin 9 provides drive to the Horizontal Amplifier in the X-Y mode of horizontal operation. The Channel 1 signal at pin 8 and the Channel 2 signal at pin 4 are used by the Trigger Generator circuits in the appropriate positions of the Trigger SOURCE switches. The Channel 2 signal at pin 5 connects to the Channel 2 Vertical Signal Out Amplifier.

Switching Logic Flip-Flops

U350A and U350B are edge-triggered flip-flops that derive the switching logic for the Channel Switch IC U370. In the CH 1, CH 2, and ADD positions of the VERT MODE switch the output logic from U350A and U350B is determined by the voltage levels applied to the clear (pins 1 and 13) and preset (pins 4 and 10) inputs. In the ALT mode of operation the flip-flops are switched by the alternate-trace sync pulse applied to their clock inputs through Q338 and U330B. In the CHOP mode, the clock pulse generated by U330C and U330D switch the flip-flops at a one-megahertz rate.

Two Megahertz Clock

U330C and U330D form an astable multivibrator having a repetition rate of two megahertz. The rectangular output waveform connects to the Switching Logic Flip-Flops through nand gate U330B. Only in the CHOP position of the VERT MODE switch is a LO level applied to the input of inverter U330A. This puts a logical HI in pin 13 of U330D, which permits the astable multivibrator to free-run. At the same time, Q338 is biased on, which puts a logical HI on pin 5 of U330B. Thus, the signal present at pin 6 of U330B will be the two-megahertz clock signal.

Chop Blanking Amplifier

The Chop Blanking Amplifier Q348 provides an output pulse to the Z Axis Amplifier circuit, which blanks out the transitions between the Channel 1 and Channel 2 traces when operating in the CHOP mode. The inherent propogation delay of inverters U340A, U340B, and U340C are used to provide some signal delay to the chop blanking signal. This allows the blanking signal and the channel switching transient to arrive in the CRT simultaneously.

Channel 2 Signal Output Amplifier

Q420 and Q430 compose the Channel 2 Vertical Signal Output Amplifier. A sample of the Channel 2 signal from pin 5 of Channel Switch IC U370 is amplified and inverted by Q420. CR422 provides thermal compensation for the base-emitter junction of Q420. Common-base amplifier Q430 provides the final amplification and isolates the output from the internal amplifier circuitry. Output impedance of the amplifier is equal to the parallel combination of R431 and R432 (approximately 50 ohms).

Normal Trigger Pickoff Amplifier

The trigger signal for NORM trigger operation is obtained from a sample of the vertical deflection signal that is available from pin 15 of U370. Normal Trigger DC Center Adjustment R425 sets the DC level of the normal trigger output signal so that the sweep is triggered at the 0 level of the displayed signal when the Triggering LEVEL control is set to 0. Q390 and Q396 are connected as a noninverting feedback amplifier. Gain of the stage is approximately 2.75.

Scale-Factor Switching Circuits

The vertical deflection factor for each channel is indicated by back-lighting the appropriate figures imprinted on the flange of each VOLTS/DIV knob. For purposes of explanation, only the circuit action of the Channel 1 Scale-Factor Switching circuit is discussed.

Circuit Description—475A Service

With a cable or an X1 probe connected to the CH 1 OR X input connector, the probe coding ring terminal on the connector is not contacted, and therefore presents an open to the base of Q312. This causes Q312 to be biased off and the X10 display factor bulb to be off. The base level of Q314 is held low by this action, thus Q314 is biased on and conducts current to light the X1 display factor bulb.

When an X10 probe with a scale-factor switching connector is attached to the CH 1 OR X input connector, the probe coding ring terminal on the connector is contacted; the base of Q312 is connected through R311, R310 and an 11,000-ohm resistor (within the probe) to ground. Now, Q312 conducts through X10 display-factor bulb DS312. The positive level at the collector of Q312 turns Q314 off, the X10 display factor bulb is on, and the X1 display factor bulb is off.

VERTICAL OUTPUT AMPLIFIER <

General

The Vertical Output Amplifier provides the final amplification for the vertical deflection signal. This circuit includes the BEAM FINDER function. The BEAM FINDER pushbutton, when pressed, limits the vertical and horizontal deflection to within the viewing area and sets the trace intensity to a normal viewing level to aid in locating an offscreen display. A schematic of the Vertical Output Amplifier is shown on Diagram 4 at the rear of this manual.

First IC Amplifier

The first amplifier stage in the Vertical Output Amplifier is integrated circuit U450. U450 is basically an emittercoupled, push-pull, cascode amplifier cell. Biasing is arranged so that there is no phase-inversion through the stage. The signal from the delay line is applied to the amplifier through C441, L441, L442, C445, and L444. These inductances and capacitances are part of the etched runs of the circuit board and provide some highfrequency peaking by forming a T-coil circuit without mutual coupling. Most of the remaining external components connected between pins 2 and 3 of U450 provide high-frequency compensation for the delay line. Connected between pins 2 and 3 of U450, internally, a resistor (approximately 33 ohms) has a large effect on the gain of the stage.

RT452 changes in value with variations in ambient temperature to compensate for temperature-associated changes in amplifier gain. The BEAM FINDER pushbutton, when pressed, removes -8 volts from the top of R459. This reduces the dynamic swing capabilities of the stage to limit the display on the CRT to within the viewing area. The gain of the Vertical Output Amplifier section is adjusted in this stage by adjusting Vertical Output Gain R449.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351634 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

4
Second IC Amplifier

The second amplifier stage in the Vertical Output Amplifier is integrated circuit U470. U470 is a multi-stage cascode amplifier cell. The input signal is applied to pins 1 and 5 with the inverted output signal taken from pins 9 and 12. Pins 2 and 4 are emitter connections. Some of the components connected between pins 2 and 4 provide slower time constants to compensate for signal rolloff that occurs in the delay line, while the remaining components compensate for thermal considerations in the stage. The Output Bias adjust (R487) sets the DC levels within the stage to optimize the operating performance of U470. The output signal from U470 connects directly to the deflection plates of the CRT.

A TRIGGER GENERATOR

(5)



The A Trigger Generator circuit produces the trigger pulse used to start the Sweep Generator circuit that provides the A portion of the CRT display. The trigger pulse is derived from the internal trigger signal from the vertical deflection system, an external signal connected to the external trigger input connector, or a sample of the line voltage connected to the instrument. Controls are provided to select trigger level, slope, coupling, and source. Fig. 3-5 shows a detailed block diagram of the A Trigger Generator circuit. A schematic of this circuit is shown on Diagram 5 at the rear of this manual.



Fig. 3-5. Detailed block diagram of the A Trigger Generator circuit.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Trigger Source

Trigger SOURCE switch S505 selects the source of the trigger signal. The sources available to the A Trigger Generator circuit are the signal being displayed (NORM), Channel 1 (CH 1), Channel 2 (CH 2), the instrument line voltage (LINE), and external signals (EXT and EXT \div 10). Emitter followers Q502, Q504, and Q506 provide isolation between the input to the A Trigger Circuit and the output of the Vertical Channel Switching Circuit.

In the LINE mode of triggering, a sample of the power line frequency is obtained from the secondary of the power transformer T1400 in the Low Voltage Power Supply circuit. The Trigger COUPLING switches should not be in the LF REJ mode when using the instrument line voltage as a trigger signal source.

Trigger Coupling

The Trigger COUPLING switches offer a means of accepting or rejecting certain components of the trigger signal. In the AC, LF REJ, and HF REJ mode of trigger coupling, the DC component of the trigger signal is blocked by coupling capacitors C515 or C516. Frequency components below about 60 Hz are attenuated when using AC or HF REJ coupling and below about 50 kHz when using LF REJ coupling. The higher frequency components of the trigger signal are passed without attenuation. In the HF REJ mode of triager coupling, the high frequency components of the trigger signal (above about 50 kHz) are attenuated, while the lower frequency components (between about 60 Hz and 50 kHz) are passed without attenuation. The DC mode of trigger coupling passes unattenuated all signals from DC to 250 MHz and above.

Input Source Follower

Transistor Q522 is a FET (field-effect transistor) connected as a source follower. It provides a high input impedance (set primarily by R517) for the trigger signal; it also provides isolation between the Trigger Generator circuit and the trigger signal sources. CR519 provides input protection for Q522 if excessively high amplitude negative-going input signals are present. Q524 is a highimpedance, relatively constant current source for Q522 and provides a measure of temperature compensation for Q522. The output signal from the Source Follower is taken from Emitter Follower Q526.

Paraphase Amplifier

U520 is a paraphase amplifier stage that converts the single-ended input from Emitter Follower Q526 into a dual-ended push-pull output, which is applied to one of the Tunnel Diode Driver stages. Trigger Centering adjustment R534 sets the level at pin 14 of U520 (through emitter follower Q532) so that the display is correctly triggered

when the LEVEL control is centered. The LEVEL control varies the level at pin 14 of U520 to select the point on a trigger signal where triggering occurs.

The slope of the input signal that triggers the Sweep Generator circuit is determined by the setting of the SLOPE switch S530. When the SLOPE switch is set to the + position, the output signal at pin 8 of U520 is inverted with respect to the input signal, and the output signal at pin 9 is in phase with respect to the input signal. When the SLOPE switch is set to the – position, the output signal at pin 8 is in phase with respect to the input signal, and the output signal at pin 9 is inverted with respect to the input signal.

Tunnel Diode Driver

Q552, Q556, Q562 and Q566 are common-emitter amplifier stages that provide the signal currents necessary to switch the triggering tunnel diodes. CR556 and CR566 are ten-milliampere tunnel diodes. Quiescently, CR556 and CR566 are biased into their low voltage states and Q566 cannot provide sufficient current to switch CR566 to its high voltage state. When the input signal increases the current in Q556 slightly above its quiescent state, this current and the current through R555 is sufficient to bias CR556 into its high voltage state. The anode of CR556 steps positive to an approximately +0.5 volt level. Since less current is required to maintain a tunnel diode in its high voltage state than is required to switch it to its high voltage state, approximately 6 mA of current is additionally available to switch CR566 to its high voltage state. Thus, the next time Q566 conducts signal current, CR566 steps to its high voltage state sending a positive pulse to the logic circuit to initiate sweep action. The A Trig Sensitivity adjustment, R565, adjusts the tunnel diode bias to the proper level that will not allow CR566 to be switched to his high voltage state until CR556 has been switched to its high voltage state. At the end of the sweep time and during holdoff, a negative level is applied to the junction of R558 and R566, thereby resetting both CR556 and CR566 to their low voltage states. The reset level remains during holdoff time to ensure that a sweep gating signal is not generated until the sweep circuit has returned to its quiescent state.

Trigger View Amplifier

The Trigger View Amplifier circuit amplifies a sample of the signal present in the A Trigger Generator circuit and passes it on to the Vertical Output Amplifier for display on the CRT when the TRIG VIEW pushbutton is pressed. This provides a method of making a quick and convenient check of the signal being used to trigger the oscilloscope and is intended primarily to be used to check the timing difference between the trigger signal and the vertical deflection signal.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

Circuit Description—475A Service

The amplifier consists of two emitter-coupled pushpull amplifier stages. The emitter source voltage for Q662 and Q672 is switched on and off by the TRIG VIEW pushbutton. With the TRIG VIEW bushbutton not pushed, the emitters of Q662 and Q672 are returned to ground through R665. This reverse-biases the base-emitter junctions of the transistors, preventing any loading of the A Trigger Generator circuit. When the TRIG VIEW pushbutton is pushed, the emitters are now returned to +15 volts through R663 and R679. This forward biases Q662 and Q672 to allow signal amplification. Trigger View Centering adjustment R673 adjusts for correct DC balance in the circuit.

Normally, the output of the Vertical Channel Switching circuit is applied to the input of the Delay Line. When the TRIG VIEW pushbutton is pushed, the signal from the Vertical Channel Switching circuit is removed and the output from the Trigger View Amplifier is applied in its place.

B TRIGGER GENERATOR

General

The B Trigger Generator circuit produces the trigger pulse used to start the Sweep Generator circuit that provides the B portion of the CRT display. The B Trigger Generator circuit is virtually the same as the A Trigger Generator circuit and only the differences between the two are discribed here. A schematic of this circuit is shown on Diagram 6 at the rear of this manual.

Trigger Source

The B Trigger Generator circuit has no LINE or EXT \div 10 positions on its Trigger SOURCE switch. If the Generator is to be triggered from a line voltage signal or the external trigger signal is to be attenuated, it must be accomplished in some other manner. The B Trigger SOURCE switch does have a STARTS AFTER DELAY position, however, the A Trigger SOURCE switch does not. This position allows the B portion of a display to start immediately after the selected delay time without waiting for a triggering signal.

SWEEP AND Z-AXIS LOGIC <7

General

The Sweep and Z Axis Logic Circuit derives the logic levels necessary to control the sequence of events associated with sweep generation and CRT unblanking. The +A and +B GATE signals are also generated in this circuit. Positive logic terminologies and symbologies are used in the following explanation of circuit operation. Fig. 3-6 shows a detailed block diagram of the Sweep and Z-Axis Logic circuits. A schematic of this circuit is shown on Diagram 7 at the rear of this manual.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



Fig. 3-6. Detailed block diagram of the Sweep and Z-Axis Logic circuits.

Sweep Control Integrated Circuit

U600 is the Sweep Control Integrated Circuit. Several functions are performed in this stage, depending on the mode of operation of the instrument sweep generators. The following is a brief explanation of the function associated with each pin of the IC.

Pin 1. This is the positive tunnel diode input. The signal connected here comes from the A Firing TD in the A Trigger Generator circuit. The voltage level switches from 0 to ± 0.5 volts and is compared with pin 2 internally.

Pin 2. This is the negative tunnel diode input. A fixed DC level established by R602 and R603 provides the reference for comparison with pin 1.

Pin 3. This is the positive tunnel diode output terminal. In the AUTO mode of operation (TRIG MODE set to AUTO) at the end of the holdoff time period, pin 1, pin 16 and pin 19 are LO, and pin 8 is HI. This causes the gate level at pin 3 to step LO to turn Q574 on, which initiates a sweep. **Pin 4.** This is the negative tunnel diode output terminal; connected to +5 volts in this application.

Pin 5. Input terminal for a negative 5 volts through VR608 from the -8-volt supply.

Pin 6. This is the auto RC timing terminal. R609 and C609 determine the amount of time between loss of trigger signal and the generation of an auto gate at pin 3 when TRIG MODE is set to AUTO.

Pin 7. This terminal lights the TRIG light when a triggering gate has occurred, causing pin 1 to go HI.

Pin 8. This is the holdoff timing terminal. The time between the end of an individual sweep and the start of the next sweep is determined by RC components that affect the time constant of voltage of pin 8. The TIME/DIV. control selects fixed components in the holdoff timing circuit and the A TRIG HOLDOFF control allows a variable holdoff setting in each position of the TIME/DIV control. When pin 8 goes HI, pin 17 will go LO and allow the trigger tunnel diodes to fire on an incoming signal or generate an auto gate in the Auto mode if pin 6 is HI.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

Circuit Description—475A Service

Pin 9. Ground terminal.

Pin 10. This is the holdoff output; connected to ground in this application.

Pin 11. This terminal lights the READY light when operating in the single sweep mode.

Pin 12. This is the single sweep mode terminal. When +5 volts is connected to this terminal, the sweep operates in the single sweep mode; when the terminal is left open or grounded, the sweep operates in the repetitive mode.

Pin 13. Connected to ground in this application.

Pins 14 and 15. Single Sweep reset terminals. Pressing the SINGL SWP pushbutton prepares the single sweep circuitry to respond to the next triggering event. Also, this action causes the READY light to be lit.

Pin 16. This is the holdoff start input terminal. A HI on this pin resets the sweep and starts the holdoff period. This sets pin 17 HI to reset and hold the trigger tunnel diodes LO and allows pin 3 to go HI.

Pin 17. This is the sweep disable output terminal. The gate level at this terminal is HI during holdoff and LO otherwise.

Pin 18. This is the lockout input terminal; +5 volts applied to this terminal disables all sweep action.

Pin 19. This is the auto mode terminal. Grounding this terminal enables auto sweep operation.

Pin 20. Input terminal for the +5-volt supply.

Main Gate Comparator

Q572 and Q574 form the Main Gate Comparator and are connected as a voltage comparator, where both transistors do not conduct at the same time. The input signal to the stage is the positive-going trigger signal from the A Firing Trigger TD in the A Trigger Generator circuit. The signal at the collector of Q574 is inverted by Q588, is connected to the Z Axis Logic Multivibrator to control CRT blanking, and to Q584 to generate the A + GATE output signal. The signal at the collector of Q572 connects to the base of the Main Gate Amplifier stage (Q902) in the Sweep Generators circuit to initiate sweep generation.

Delayed Gate Comparator

Q802 and Q804 form the Delayed Gate Comparator and are connected as a voltage comparator where both transistors do not conduct at the same time. The input signal to the stage is the positive-going trigger signal from the B Firing Trigger TD in the B Trigger Generator circuit. The signal at the collector of Q804 is inverted by Q826 and is connected to the Z Axis Logic Multivibrator to control CRT blanking and to Q824 to generate the B + GATE output signal. The signal at the collector of Q802 connects to the base of the Delayed Gate Amplifier stage (Q996) in the Sweep Generators circuit to initiate sweep generation.

A Trigger TD Reset Circuit

Transistors Q612 and Q628 are connected as a Schmitt Trigger circuit and form the A Trigger TD Reset Circuit. (A Schmitt Trigger circuit is a bistable pulse generator in which an output pulse of constant amplitude exists only as long as the input voltage exceeds a certain dc value.)

At the start of holdoff, pin 17 of U600 steps HI. This turns on Q612 and turns Q628 off. The collector signal of Q612 connects to the Trigger Tunnel Diodes in the A Trigger Generator circuit and resets them to their LO state. At the end of holdoff pin 17 steps LO, Q612 turns off, and Q628 turns on to allow the tunnel diodes to fire on the next trigger signal.

Holdoff Start Circuit

Q594 and Q596 form the Holdoff Start Circuit. The input signal to the stage is a momentary positive-going end-of-sweep signal from the Sweep Generators circuit or from the Delayed Latch circuit. The positive-going signal turns Q594 on which in turn turns on Q596. The positivegoing signal at the collector of Q596 is connected to pin 16 of U600 to reset the sweep and start the holdoff period. This signal is also used in the Vertical Switching Circuit to switch between channels in the ALT mode of operation.

Z Axis Logic Multivibrator

Q688 and Q698 are basically a Schmitt Trigger circuit and form the Z Axis Logic Multivibrator. Quiescently, with the CRT display blanked, Q688 is on and Q698 is off. The signal to switch states of the multivibrator (and thereby unblank the CRT) can come from the Main Gate Comparator (via Q588 and CR681) or from the Delayed Gate Comparator (via Q826 and C684). The negative going signals turn off Q688 and cause Q698 to turn on. The positive going signals that return the multivibrator to its original state (thereby blanking the CRT display) come from Q588 via CR682 and CR683, or from Q680 via CR680 and CR683. Q680 is used primarily to ensure proper early turn-off of the CRT display at faster sweep rates. In the MIX or A INTEN positions of the HORIZ DISPLAY switch, some additive unblanking is accomplished to slightly increase the intensity of the B portion of the display. In these positions of the switch, -8 volts is connected to the cathodes of CR693 and CR694 through R692. Now, when the Z-Axis signal from the collector of Q826 steps negative at the beginning of the B portion of the display, CR693 is made to conduct less current, which makes a slight amount of additional unblanking current available to the Z-Axis Amplifier through CR694 and R692.

Delaying Sweep Latch Circuit

Q788, Q794, and Q796 form the Delaying Sweep Latch Circuit. The circuit function is used during the three delayed sweep modes of operation that the instrument is capable of (MIX, A INTEN, and B DLY'D). Q938A, in the Delay Pickoff Comparator of the Delaying Sweep Generator, is the current source for the emitters of Q794 and Q796. Prior to the end of the delay time selected by the A TIME/DIV switch and DELAY TIME POSITION control, Q938A is off, thereby causing both Q794 and Q796 to be off also. The base level of Q794 sits at a more negative level than does the base of Q796 so that when Q938A turns on, at the delay pickoff point, Q794 will turn on and Q796 will remain off. The resultant positive movement at the collector of Q794 is connected to the B Trigger TD Reset Circuit.

The end-of-sweep pulse from the Non-Delaying Sweep Generators connects to the emitter of Q788. When this pulse steps positive at the end of a delayed sweep, Q788 turns off and the current through R788 pulls the base of Q794 positive. This turns off Q794 and causes Q796 to turn on. The circuit remains in this state until the Delaying Sweep Generator ends its sweep and resets the Delay Pickoff Comparator. In the B ENDS A position of the A TRIG HOLDOFF control, +5 volts is connected to R798. This enables the diode gate composed of CR799 and CR592. Now, when the end-of-sweep pulse signals the end of a delayed sweep, the positive movement at the collector of Q796 is connected to the base of Q594 and ends the delayed sweep instead of waiting until the end of the delaying sweep. This mode of operation gives the fastest possible sweep repetition rate when operating in the delayed sweep mode.

B Trigger TD Reset Circuit

Q790 and Q792 are connected as a Schmitt Trigger and form the B Trigger TD Reset Circuit. At all times other than when the Non-Delaying Sweep Generators are running, Q790 is on, which holds the trigger tunnel diodes in the B Trigger Generator circuit in their LO states. At the end of the delay time selected by the A TIME/DIV switch and DELAY TIME POSITION control, the positive movement at the collector of Q794 turns on Q792 and causes Q790 to turn off. The tunnel diodes in the B Trigger Generator are capable of being biased into their HI states. Also, if the B Triggering SOURCE switch is in the STARTS AFTER DELAY TIME position, the negative movement at the collector of Q792 reverse biases CR811, letting the -8 volt supply pull down on the base of Q804 in the Delayed Gate Comparator. This turns on Q804 and causes Q802 to turn off, which initiates a delayed sweep.

Main Sweep Holdoff Gate and Delayed Sweep Override Amplifier

During the interval of the main gate, Q798 functions as a holdoff gate and is biased off to provide a forward bias on Q1002 (Q1002 is located on diagram 9). This turns on Q1002, discharges the holdoff capacitors and maintains a current path to keep the capacitors discharged.

During the delayed sweep, Q798 functions as an override amplifier. It is possible, with the right combination of control settings, to achieve a delayed sweep presentation where the delayed sweep would normally want to continue running after the end of the delaying sweep. For instance, if the TIME/DIV controls are set only 1 or 2 ranges apart and the DELAY TIME POSITION control is set to a 8.50 setting. Under these conditions the delaying sweep end-of-sweep pulse occurs before the delayed sweep end-of-pulse. The positive movement on the collector of Q588 at the time of the delaying sweep end-of-sweep pulse turns Q798 on. The negative movement on the collector of Q798 pulls down on the collectors of Q794 and Q796, through CR793 and CR792 respectively, which in turn pulls down on the base of Q792. This turns off Q792 and causes Q790 to turn on, which resets the B Trigger Tunnel Diodes to their LO states, thereby terminating the delayed sweep.

A +GATE And B +GATE Amplifiers

Q584 and Q824 are the A +GATE and B +GATE amplifiers respectively. They provide the +GATE output signals available at the instrument rear panel. These output gate signals are positive-going rectangular waveforms, approximately 5 volts in amplitude, coincident with their respective sweep waveforms.

LOW LINE Indicator Circuit

Q1492, Q1498, and their associated circuitry monitor the unregulated voltage in the +50 volt supply and provide a visual indication (via the LOW LINE indicator on the front panel) when the applied line voltage falls below the lower regulating limit selected by the Regulating Range Selector assembly. Q1482 provides operating power to the CRT graticule lights that is adjustable via the SCALE ILLUM control R1480.

Circuit Description—475A Service

SWEEP GENERATORS 8 TIMING AND HORIZONTAL DISPLAY SWITCHING 9

General

The Sweep Generators provide several sweep display modes, dependent upon the horizontal mode selected by the HORIZ DISPLAY switch. One sweep generator may be employed as a delay circuit for a second sweep generator, permitting a variety of useful display modes. Before the discussion of sweep generation, it is helpful to become familiar with each principle mode of horizontal display and its associated sweep generator, sweep gate and sweep display labeling. See Table 3-2 for a list of sweep generator, sweep gate and sweep display terminology whenever needed throughout the following sweep generators discussion.

The Sweep Generators produce the sawtooth voltages that are amplified by the Horizontal Amplifier to provide horizontal deflection on the CRT. These sawtooth voltages are produced on command (trigger pulses) from the Trigger Generator circuits. The Sweep Generator circuits also produce gate waveforms that are used by the Z Axis Logic circuit to unblank the CRT during sweep time, and by the Sweep Logic circuit to terminate sweep generation. There are three Sweep Generator circuits in the instrument. Operation of all three is very similar; therefore only the operation of the Delaying Sweep Generator and the differences in operation of the three generators is discussed. Fig. 3-7 shows a detailed block diagram of the Sweep Generators. A schematic of the Sweep Generators is shown on Diagram 8 and a schematic of the Timing And Horizontal Display Switching is shown on Diagram 9 at the rear of this manual.

TABLE 3-2				
Horizontal Display Sw	veep Generate	or Terminology		

1862-86

HORIZ DISPLAY Switch Setting	CRT Display		
	Portion of Sweep Displayed on CRT	Sweep Generator Used for Display	Gate that Initiates Sweep
A (TIME/DIV Knobs Locked)	A	Non-Delaying	Main
(TIME/DIV Knobs Unlocked)	А	Delaying	Main
MIX	A (First Portion)	Delaying	Main
	B (Last Portion)	Non-Delaying	Delayed
A INTEN	A	Delaying	Main
	B (Intensified Portion)	Non-Delaying	Delayed
B DLY'D	В	Non-Delaying (After being delayed by Delaying Sweep)	Delayed

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



Fig. 3-7. Detailed block diagram of the Sweep Generator circuits.

Delaying Sweep Generator

Basically the Delaying Sweep Generator is composed of Q904, Q920, Q922, and Q914. This generator runs in the A INTEN, MIX, and B DLY'D positions of the HORIZ DISPLAY switch and generates the A portion of the display. In these modes the sweep rate is selected by the A TIME/DIV switch (skirt knob).

Main Gate Amplifier

Q902 is the Main Gate Amplifier stage. The negativegoing Main Gate waveform from the Sweep Logic circuit is applied to the base of Q902. The amplified and inverted waveform at the collector of Q902 is applied to the Delaying Sweep Generator (through CR903), or to both of the Non-Delaying Sweep Generators (through Q992) in the A sweep mode. This initiates sweep generation.

Sweep Disconnect Amplifier

Q904 is the Sweep Disconnect Amplifier. The biasing on the base of this stage determines whether the Delaying Sweep Generator will run. In the A position of the HORIZ DISPLAY switch, the anode of CR907 is connected to +5 volts through R908 and the HORIZ DISPLAY switch circuit. This biases the base of Q904 far enough positive that the positive-going gates on the emitter cannot turn off Q904. Q904 therefore conducts all of the timing current through R905, R904, and timing resistor R₀, charging timing capacitance C_t . When the HORIZ DISPLAY switch is in any position other than A, CR907 is reverse-biased, which lets the base of Q904 be biased at a level that will allow the positive-going gates on the emitter of Q904 to interrupt the current flow through Q904. When Q904 turns off, the timing current starts to discharge timing capacitance C.

Circuit Description—475A Service

Sawtooth Sweep Generator

Q920 and Q922 form a Miller Integrator circuit. When the current through the Sweep Disconnect Amplifier Q904 is interrupted, timing capacitance C_t begins to discharge through timing resistor R_t . The timing resistor and capacitance are selected by the A TIME/DIV switch to provide the various sweep rates listed on the instrument front panel. The output signal at the collector of Q922 is a negative-going sawtooth voltage waveform.

Sweep Start Amplifier

Just before the sweep starts to run down, the levels at the bases of Q914 are approximately equal. When the sweep starts to run down, the base of Q914B goes negative, which increases the forward bias on CR914B. This in turn decreases the forward bias on CR914A, which very shortly after the start of the sweep, becomes reverse biased to interrupt the current through Q914A. The circuit remains in this condition until after the sweep retrace is complete. When the circuit returns to quiescence, Q914A begins to conduct through R904. This sets the current through Q904 which in turn establishes the DC level starting point for the sweep.

Output Buffer Amplifier

Q940 and Q956 form the Output Buffer Amplifier. Q940 is an emitter follower and Q956 is a common-base amplifier whose emitter is current-driven by the signal. The Output Buffer Amplifier provides the output sawtooth signal current to the Horizontal Amplifier and provides a measure of isolation between the Sawtooth Generator and the Horizontal Amplifier. Intensified Gain adjustment R950 adjusts the gain of the stage to match the output signal amplitude with that of the Non-Delaying Sweep Generators.

The Delaying Sweep Output Buffer Amplifier passes the signal to the Horizontal Amplifier when the HORIZ DISPLAY switch is in the A INTEN position and the TIME/DIV switches are not in the X-Y position. When the TIME/DIV switches are in the X-Y position the anode of CR956 is connected to +5 volts. This sets the base of Q956 at a positive enough level to reverse bias Q956 and prevent passage of the Delaying Sweep signal to the Horizontal Amplifier. With the TIME/DIV switches not in the X-Y position and the HORIZ DISPLAY switch in the A INTEN position, R955 is connected to -8 volts (through Q1099 in the Horizontal Display Switching circuit) and the anode of CR956 is not connected to any voltage. This forward biases CR955 and sets the base of Q956 at a DC level of approximately +4.3 volts. Now Q956 is forward biased and the Delaying Sweep signal is passed to the Horizontal Amplifier.

Delaying Sweep End Difference Amplifier

Q944 and Q946 are connected as a voltage comparator and generate the logic pulses that signal the end of sweep and blank the CRT display at the end of the sweep. Prior to the generation of a sawtooth voltage waveform by the Delaying Sweep Generator, the base of Q944 is at an approximate -1.6 volt level. The base of Q946 is held at about -3 volts by the divider made up of R948 and R949. Therefore, Q946 is reversed biased and not conducting and Q944 is forward biased and is conducting. When the sweep voltage at the emitter of Q940 begins to go in a negative direction, the base of Q944 follows until the base of Q944 goes more negative than the base of Q946. Q944 turns off and Q946 turns on, generating a positive pulse at the collector of Q944 and a negative pulse at the collector of Q946. The positive pulse at the collector of Q944 signals the end of sweep and starts the holdoff period. The negative pulse at the collector of Q946 signals the Z-Axis Logic circuit to blank the CRT and prevent any further display.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Delay Pickoff Comparator

The Delay Pickoff Comparator stage allows selection of the amount of delay from the start of the Delaying Sweep Generator before one of the Non-Delaying Sweep Generators is turned on. The amount of delay available is variable from 0.00 to 10.00 times the setting of the A TIME/DIV switch. The sweep rate of the Delayed (nondelaying) Sweep Generator is determined by the setting of the B TIME/DIV switch.

Q926A and Q926B are connected as a voltage comparator. Q928 is a relatively constant current source for Q926. Q938 is also connected as a voltage comparator circuit and is used to improve the switching capabilities of the stage. The reference voltage for the Delay Pickoff Comparator stage is provided by DELAY TIME POSITION control R930. U930 is an integrated circuit containing two high-gain amplifier cells used in a feedback amplifier configuration. They provide accurate fixed voltages (determined by settings of Delay Start, R938, and Delay Stop, R936) connected to the DELAY TIME POSITION control to allow precise delay pickoff. The instrument is calibrated so that the major dial divisions of the DELAY TIME POSITION control correspond to major divisions of horizontal deflection on the CRT graticule. For example, if the DELAY TIME POSITION control is set to 5.00, the Non-Delaying Sweep Generator is delayed five divisions of the Delaying Sweep time before it can produce a sweep.

The sawtooth voltage waveform from the Delaying Sweep Generator is connected to the gate of Q926B. The quiescent level of the delaying sawtooth biases Q926B on and its drain is negative enough to bias Q938B on. Q926A and Q938A are off and not conducting. As the Delaying Sweep sawtooth voltage goes down, the gate of Q926B also goes down. When it goes more negative than the level at the gate of Q926A (established by the DELAY TIME POSITION control), Q926A conducts and Q926B turns off. This also switches the states of Q938A and B and produces a positive-going rectangular current pulse at the collector of Q938A. This initiates the B sweep when B TRIG SOURCE is set to STARTS AFTER DELAY or enables the B Trigger Tunnel Diodes in all other positions of B TRIG SOURCE switch. When the Delaying Sweep resets, Q926B again conducts and Q926A is turned off. This switches Q938A and B back to their original states.

Non-Delaying Sweep Generators

There are two Non-Delaying Sweep Generators. In any position of the HORIZ DISPLAY switch, one of these generators will be running. They generate the displayed sweep in the A position of the HORIZ DISPLAY switch and the B portion of a display in the remaining positions. The B TIME/DIV switch (DLY'D SWEEP knob) selects the sweep rate for these generators. One generator provides the 0.5 second through 1 microsecond sweep rates, while the other generator provides the 0.5 microsecond through 0.01 microsecond sweep rates.

Either the "Main" Gate or the Delayed Gate can initiate sweep generation by the Non-Delaying Sweep Generators. When the HORIZ DISPLAY switch is in the A position and the TIME/DIV knobs are locked, a positive voltage is applied to the emitter of Q992, through R922 and Q1062. Q992 is forward biased, and the "Main" Gate is passed on to the Non-Delaying Sweep Generators through CR922 and CR971 or CR1001. In all the other positions of the HORIZ DISPLAY switch and when the TIME/DIV knobs are unlocked, a negative voltage is applied to the emitter of Q922 to reverse bias Q992 and prevent the "Main" Gate from reaching the generators. Now, only the "B" Gate can initiate sweep action in the Non-Delaying Sweep Generators.

"B" Gate Amplifier

Q996 is the "B" Gate Amplifier stage. The negativegoing waveform from the Sweep Logic circuit is applied to the base of Q996. The amplified and inverted waveform at the collector of Q996 is applied to the Non-Delaying Sweep Generators through CR996 and CR971 or CR1001 to initiate sweep generation.

Non-Delaying Sweep Generator Differences

Basically the Non-Delaying Sweep Generators operate in the same manner as the Delaying Sweep Generator. The "fast" generator (Q1004, Q1010, Q1014, and Q1018) has only one timing capacitance (the parallel combination of C1008 and C1009). The capacitance is variable to achieve precise timing accuracy. Timing resistors are selected by the B TIME/DIV switch to provide the fastest six sweep speeds listed on the front panel.

Q988 and Q1018 are Sweep Start Amplifiers and establish the DC level starting points for the sweeps. The "slow" generator (Q974, Q980, Q984, Q988, and Q972) has an additional emitter follower (Q972). This emitter follower increases the current-gain of the loop to speed up the retrace time of the generator (determined by the time required to discharge the timing capacitor).

Mixed Mode Operation

Normally, Q1086 is an emitter follower with a fixed dc level at its base established by R1094 and R1095. The fixed level at the emitter of Q1086, in turn, is applied to the bases of Q1018 and Q988 through CR1017 and CR987 respectively. This sets the quiescent current flow through Q988 and Q1018 to establish the dc level starting points for the sweeps as previously explained. However, when the HORIZ DISPLAY switch is in the MIX position, the fixed level at the base of Q1086 is replaced by the sawtooth voltage waveform being generated by the Delaying Sweep Generator. Now, the dc level starting point of the Non-Delaying Generator that is running is constantly being changed by the Delaying Sweep sawtooth until the Delaying Sweep runs down to a voltage determined by the setting of the DELAY TIME POSITION control. At this time, one of the disconnect transistors (Q974 in the "slow" Non-Delaying Generator, or Q1004 in the "fast" Non-Delaying Generator, depending on the settings of the TIME/DIV controls) is turned off, allowing the appropriate Non-Delaying Generator to begin a ramp waveform determined by the setting of B DLY'D control. The output waveform from the Non-Delaying Sweep Generator that is running will be a composite sawtooth waveform with the first and last parts occurring at a rate determined by the Delaying Sweep Generator (last part blanked out of CRT display) and the middle part occurring at a rate determined by one of the Non-Delaying Sweep Generators.

Non-Delaying Sweep End Difference Amplifier

Q1044 and Q1034 are connected as a voltage comparator, and generate the same sort of logic pulses as the Logic Comparator in the Delaying Sweep Generator circuit. The positive-going pulse at the collector of Q1034 signals the end of the Non-Delaying Sweep, and the negative-going pulse at the collector of Q1044 blanks the display at the end of the Non-Delaying Sweep. However, the logic pulses from this comparator are not always allowed to pass to the Sweep and Z-Axis Logic circuits.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

Circuit Description—475A Service

In the A INTEN position of the HORIZ DISPLAY switch, +5 volts is connected to the anode of CR1049. This forward biases CR1044, which sets the collector of Q1044 at approximately +0.7 volts. This keeps CR1046 reversed biased and prevents completely blanking the CRT at the end of the Non-Delaying Sweep portion of the display. In the A INTEN, MIX, and B DLY'D positions of the HORIZ DISPLAY switch, -8 volts is connected to the anode of CR1036 through R1090. This turns off the diode gate (CR1034 and CR1037) preventing a Non-Delaying Sweep end-of-sweep pulse output from Q1034 collector which would terminate the Delaying Sweep. This pulse is allowed to reset the Non-Delaying Sweep through Q788. In the A position of the HORIZ DISPLAY switch (knobs locked), a more positive voltage is connected to the anode of CR1036. This enables CR1034 and CR1037, thus allowing the Main Sweep end-of-sweep pulse to pass to the Sweep Logic circuit. The logic levels are generated by the HORIZ DISPLAY switch, Q1062, Q1066 and Q1099.

TIME/DIV Functions (Knobs Unlocked)

Normally, when the HORIZ DISPLAY switch is set to A, the Non-Delaying Sweep Generator is being used to display A Sweep. When the DLY'D SWEEP control (inner knob of TIME/DIV) is unlocked and set to a faster sweep rate, the Non-Delaying Sweep Generator is then being used to display A Sweep. In this mode, the A TIME/DIV (skirt knob) must be used to control A Sweep rates.

HORIZONTAL AMPLIFIER



General

The Horizontal Amplifier circuit provides the output signals to the CRT horizontal deflection plates. The signal applied to the input of the Horizontal Amplifier is determined by the TIME/DIV switch. The signal can be a sawtooth waveform generated within the instrument, or some external signal applied to the CH 1 OR X input connector (X-Y mode of operation). The Horizontal Amplifier also contains the X10 magnifier, horizontal positioning controls, and some beam finder circuitry. Fig. 3-8 shows a detailed block diagram of the Horizontal Amplifier circuit. A schematic of this circuit is shown on Diagram 10 at the rear of this manual.



For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QV Tel:- 01844-35160 / Sax- 01844-352554 Email:- enquines@mauritron.co.uk

Input Paraphase Amplifier

Q1124 and Q1134 form the Input Paraphase Amplifier. This is an emitter-coupled amplifier stage that converts the single-ended input signal to a push-pull output signal. The X10 Magnifier circuitry is in this stage and consists of a divide-by-ten attenuator R1106-R1107-R1108. When the X10 Magnifier is on, the input signal is applied unattenuated to the Input Paraphase Amplifier. When the X10 Magnifier is off, the input signal is applied to the Input Paraphase Amplifier through the attenuator. X10 MAG indicator DS1110 lights when the X10 Magnifier is being used. CR1121 and CR1122 limit signal amplitudes at the input to the amplifier to prevent amplifier overdrive. Q1140 is a relatively constant current source for Q1124 and Q1134. CR1140 provides temperature compensation for the base-emitter junction of Q1140. Magnifier Registration adjustment R1130 balances quiescent DC current in Q1124 and Q1134 so that a center screen display does not change position when the X10 Magnifier is turned on.

Q1112 and Q1114 together form a temperature compensated current source that is an interruptable path for the horizontal positioning currents. When the TIME/DIV switch is in any position other than X-Y, the anodes of CR1103, CR1104, and CR1111 are connected to -8 volts through R1104, which reverse-biases them. In the X-Y position of the TIME/DIV switch, +5 volts is connected directly to the anodes of CR1103, CR1104, and CR1111. This accomplishes three things. First, the emitter-base junction of Q1114 is reverse biased, which prevents the Horizontal POSITION and FINE controls from having any effect on the display. Second, relay K1103 is energized, which connects the X-axis signal from the Channel 1 Preamplifier to the input to the Horizontal Amplifier. Third, +5 volts is connected to the Channel 1 Scale Factor Switching circuit so that both deflection factor indicators are operating. When operating in the X-Y mode, R1102 adjusts for correct X-axis gain and L1103 adjusts to reduce the phase differences between the horizontal (X) and vertical (Y) signal paths.

Gain Setting Amplifier

Q1152 and Q1162 are an emitter-coupled push-pull amplifier stage. The gain of this stage is adjusted to match the CRT sensitivity. When the BEAM FINDER pushbutton is pushed, R1168 is switched into the circuit. This reduces the current through this stage, thereby limiting horizontal deflection to within the limits of the CRT viewing area. Q1152 and Q1162 operate in an overdriven mode. This means at the extremes of signal amplitude, one side will be turned off while the other side is still conducting. This condition generates some common-mode signal differences between Q1152 and Q1162. Q1164 monitors any common-mode signal differences (through R1165 and R1167) and conducts to minimize them.

Output Amplifier

The push-pull signal from the Gain Setting Amplifier is connected to the Output Amplifier. Each half of the Output Amplifier can be considered as a single-ended feedback amplifier, which amplifies the signal at its input to produce a voltage output to drive one of the horizontal deflection plates of the CRT. Both halves of the Output Amplifier are basically the same with only minor differences; therefore, only the upper amplifier (drives the + horizontal deflection plate) and the differences will be explained.

Q1172 and Q1174 are connected in a Darlington configuration. Q1234 is a feedback amplifier in the feedback path for the output amplifier. Q1234 sets DC levels and reduces the impedance of the feedback path. Q1202 and Q1204 form a complementary amplifier that provides the output signal to drive the + deflection plate of the CRT. CR1173 clips excessive signal amplitudes and sets a sweep start voltage level for the positive deflection plate. R1175, C1233, and C1179 are high-frequency compensation adjustments. R1256 centers the output signal swing within the dynamic swing capabilities of the output amplifier.

There are two signal paths through each half of the Output Amplifiers. Slow signal transitions are applied to the CRT through Q1172, Q1174, and Q1204 with feedback via R1233 and R1235. C1235, C1233, and C1178-C1179 compensate the amplifier and provide a fast AC signal path from one side of the amplifier to the other. The lower amplifier (drives the – horizontal deflection plate) is basically the same as the upper except for two things. Q1188 is a relatively constant current source for Q1182 and Q1184. VR1216 shifts the DC level of the signal from the collectors of Q1182 and Q1184 to the emitter level of Q1214.

LOW-VOLTAGE POWER SUPPLY

General

The Low-Voltage Power Supply circuit provides the operating power for this instrument from six regulated power supplies and one unregulated power supply. Electronic regulation is used to provide stable, low-ripple output voltages. Fig. 3-9 shows a detailed block diagram of the Power Supply circuit. A schematic of this circuit is shown on Diagram 11 at the rear of this manual.







3-22

@

Power Input

Power is applied to the primary of transformer T1400 through Line Fuse F1401, POWER switch S1401, Thermal Cutout S1402, Line Voltage Selector switch S1403, and the Regulating Range Selector. Line Voltage Selector switch S1403 connects the split primaries of T1400 in parallel for 115-volt nominal operation, or in series for 230volt nominal operation. Line Fuse F1401 should be changed for each nominal line voltage (current rating of fuse for 230-volt operation must be 0.75A fast; for 115-volt operation current rating of fuse must be 1.5A fast).

Thermal cutout S1402 provides thermal protection for this instrument. If the internal temperature of the instrument exceeds a safe operating level, S1402 opens to interrupt the applied power. When the temperature returns to a safe level, S1402 automatically closes to reapply the power.

The vacant windings between pins 10, 10A, 11, 12, and 12A of T1400 are intended for use with the optional Inverter Circuit Board (Option 7) or for use with a 475A Oscilloscope modification, a Power Supply Board (475A DM44).

Secondary Circuit

The -8 volt, -15 volt, +5 volt, +15 volt, +50 volt, and +110 volt supplies are series-regulated supplies. U1418, U1454A and B, and U1464A and B are high-gain amplifier cells with differential inputs. These amplifiers monitor variations in the output voltages and generate error signals to maintain relatively constant output levels. Each regulated supply contains a current-limiting circuit that provides short circuit protection to prevent instrument damage if a supply is inadvertently shorted to ground. Additionally, unregulated voltages are used from the +15 volt and +50 volt supplies.

+50-Volt Supply. The +50-Volt Power Supply provides the reference voltage for all remaining regulated supplies in the instrument. The following discussion includes the description of the +50-Volt Series Regulator, +50-Volt Feedback Amplifier, +50-Volt Reference, and +50-Volt Current Limiting stages. Since these stages are closely related in the production of the +50-volt regulated output voltage, their operation is most easily understood when discussed as a unit.

Circuit Description—475A Service

CR1412 functions as a full-wave, center-tapped, bridge rectifier and provides an unregulated output voltage (approximately +65 volts) for the +50-Volt Power Supply. This voltage is filtered by C1414 and is connected to the +50-Volt Series Regulator, Q1426, to provide a sufficient collector supply for stable regulation over a wide range of ac power line voltages. Zener diode VR1416 sets a reference level of about +9 volts at the positive input of Feedback Amplifier U1418. A sample of the output voltage from the +50-Volt Supply is connected to the negative input of U1418 through divider R1430-R1431-R1432. R1430 in this divider is adjustable to set the output level of the +50-Volt Supply. The 2 input voltages at Feedback Amplifier U1418 are compared and any error between the 2 inputs is amplified. The amplified error output from U1418 drives Q1424 and Q1426 and controls the output voltage of the power supply.

Regulation occurs as follows: If the output level of this supply decreases (due to an increase in load, for example) the voltage across divider R1430-R1431-R1432 decreases also. This results in a more negative feedback level at pin 2 of U1418 than that established by the reference voltage at pin 3. The difference in voltage levels is amplified and polarity is inverted by U1418. The result is that voltage increases at pin 1 of U1418. This increase in voltage causes a more positive voltage at the base of Q1424. More current is allowed to flow through Q1424 to result in increased conduction of the +50-volt Series Regulator Q1426. The output voltage increases, thereby achieving regulation of the +50-volt power supply.

The +50-volt Current Limiting stage, Q1432, protects the +50-Volt Series Regulator if excess current is demanded from this supply. Since the load is connected to this supply through R1426, all current must flow through this resistor. When excess current is demanded from the +50-Volt Series Regulator, due to a short circuit or similar malfunction at the output of this supply, the voltage drop across R1426 increases, causing a higher positive voltage at the emitter of Q1426 than the supply output voltage. This increased voltage is coupled through the emitter-tobase junction of Q1426 to voltage divider R1424 and R1425. Under normal conditions, this divider sets the base level of Q1432 for a biased-off condition. However, when the power supply load increases beyond preset limits, or the supply output becomes short circuited, the positive going change across the divider R1424-R1425 causes Q1432 to become biased on. The collector current of Q1432 reduces the voltage at the base of Q1424 to limit the conduction of current through Q1426 and R1426 to a preset value. This mode of operation is called foldback because both the supply voltage and current are reduced during overload. The supply automatically returns to normal operation when the overload is removed.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:-01844-351894 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

Circuit Description—475A Service

+110-Volt Supply. CR1412 functions as a full-wave center-tapped rectifier and provides an unregulated output voltage (approximately +136 volts) for the +110-Volt Power Supply. This voltage is filtered by C1412 and is connected to the +110-Volt Series Regulator, Q1496, to provide sufficient collector supply for stable regulation over a wide range of ac power line voltages. Transistors Q1490 and Q1494 are connected as a comparator. A sample of the output voltage from the +110-Volt Supply, through divider R1486, R1487, is connected to the +50-Volt Supply to provide a reference voltage. The error output at the collector of Q1494 reflects the difference, if any, between these 2 inputs. This error output drives Q1496 and controls the output voltage of the power supply.

Regulation occurs as follows: If the output level of this supply decreases (due to an increase in load, for example) the voltage at the base of Q1490 decreases also. This decreased voltage when compared to the reference voltage at the base of Q1494 results in a decreased voltage at the collector of Q1494. A portion of this decreased voltage is connected to the base of Q1496 causing increased conduction. The output voltage increases, thereby achieving regulation of the +110-volt power supply.

A current limiting stage, Q1497, protects the +110-Volt Supply if excess current is demanded from this supply. All output current from the +110-Volt Supply must flow through R1489. Transistor Q1497 senses the voltage drop across R1489. Under normal operating conditions, Q1497 is biased off. However, when excess current is demanded from the +110-Volt Series Regulator due to a short circuit or similar malfunction at the output of this supply, the voltage drop across R1489 increases until it is sufficient to forward bias Q1497. The collector current of Q1497 pulls the base of Series Regulator Q1496 positive and turns it off. The output current from the supply is then limited by R1488 and the +110-Volt Supply is thereby protected.

+15-Volt Supply. Basic operation of all stages in the +15-Volt Supply is the same as for the +50-Volt Supply. The +15 volt reference for this supply is established by divider R1444-R1445 between +50 volts and ground. Any change in the output level of the supply is compared at Feedback Amplifier U1454A, which produces a signal of inverted polarity at its output (pin 1). This change is coupled to +15-Volt Series Regulator Q1448 through Q1446 to correct the change in output voltage. Transistor Q1444 provides current limiting (foldback operation) if the supply load increases beyond preset limits or becomes shorted to ground. +5-Volt Supply. Basic operation of all stages in the +5-Volt Supply is the same as described in the +50-Volt Supply and the +15-Volt Supply. The +5 volt reference for this supply is established by divider R1454-R1455 between +50 volts and ground. Any change in the output level of the supply is compared at Feedback Amplifier U1454B which produces a signal of inverted polarity at its output (pin 7). This change is coupled to +5-Volt Series Regulator Q1456 to correct the change in the output voltage. Transistor Q1454 provides current limiting (foldback operation) if the supply load increases beyond preset limits or becomes shorted to ground.

-8-Volt Supply. Basic operation of all stages in the -8-Volt Supply is the same as described in previous supplies. The reference level for this supply (0 volt) is established by the ground connection through R1463 to pin 2 of Feedback Amplifier U1464A. Feedback voltage to pin 3 of U1464A is provided by divider R1464-R1465 between ± 50 volts and the --8-Volt Supply output. The divider ratio of R1464-R1465 is 10:1 so the level at pin 3 is 0 volt when the supply is operating properly. Any change in the output level of the supply is compared at U1464A, which produces a correction signal of the same polarity as its output (pin 1). This change is coupled to the -8-volt Series Regulator, Q1468, through Q1466 to correct the change in output voltage. Transistor Q1464 provides current limiting (foldback operation) if the supply load increases beyond preset limits or becomes shorted to ground.

-15-Volt Supply. Basic operation of all stages in the -15-Volt Supply is the same as described in the -8-Volt Supply. The reference level for this supply (0 volt) is established by the ground connection through R1473 to pin 6 of Feedback Amplifier U1464B. The feedback voltage (0 volt) to pin 5 of U1464B is provided by divider R1474-R1475 between +50 volts and the -15-Volt Supply output. Any change in the output voltage of the supply is compared at U1464B, which produces a correction signal of the same polarity at its output (pin 7). This change is coupled to the base of -15-Volt Series Regulator Q1478 to correct the change in output voltage. Transistor Q1474 provides current limiting (foldback operation) if the supply load increases beyond preset limits or becomes shorted to ground.

CRT CIRCUIT



General

The CRT Circuit provides the voltage levels and control circuits necessary for operation of the cathode-ray tube (CRT). Fig. 3-10 shows a detailed block diagram of the CRT Circuit. A schematic of this circuit is shown on Diagram 12 at the rear of this manual.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk



Fig. 3-10. Detailed block diagram of the CRT circuit.

High-Voltage Oscillator

Q1318 and associated circuitry compose the highvoltage oscillator that produces the drive for high-voltage transformer T1320. When the instrument is turned on, current through Q1316 provides forward bias for Q1318. Q1318 conducts and the collector current increases, which develops a voltage across the collector winding of T1320. This produces a corresponding voltage increase in the feedback winding of T1320, which is connected to the base of Q1318, and Q1318 conducts even harder. Eventually the rate of collector current increase in Q1318 becomes less than that required to maintain the voltage across the collector winding and the output voltage drops. This turns Q1318 off by way of the feedback voltage to the base. The voltage waveform at the collector of Q1318 is a sine wave at the resonant frequency of T1320. Q1318 remains off during the negative half cycle while the field collapses in the primary of T1320. When the field is collapsed sufficiently, the base of Q1318 becomes forward biased into conduction again and the cycle begins anew. The amplitude of sustained oscillation depends upon the average current delivered to the base of Q1318. The frequency of oscillation is approximately 50 kilohertz. Fuse F1318 protects the unregulated +15-volts supply in the event the High-Voltage Oscillator stage becomes shorted. C1318 and L1318 decouple the +15-volt supply line and prevent the current changes present in the circuit from affecting the +15-volt regulated supply.

High-Voltage Regulator

Feedback from the CRT cathode -2450 volt supply is applied to the base of Q1306 through R1303A. Any change in the level at the base of Q1306 produces an error signal at the collector of Q1306, which is amplified by Q1308 and Q1316 and applied to the base of Q1318 through the feedback winding of T1320. Regulation occurs as follows.

If the output voltage at the -2450 volt test point starts to go positive (less negative), this positive-going change is applied to the base of Q1306. Q1306 conducts harder, which in turn causes Q1308 and Q1316 to conduct harder. This results in greater bias current to the base of Q1318 through the feedback winding of T1320. Now, Q1318 is biased closer to its conduction level so that it comes into conduction sooner to produce a larger induced voltage in the secondary winding or T1320. This increased voltage appears as a more negative voltage at the -2450 volt test point to correct the original positive-going change. By sampling the output from the CRT cathode supply in this manner, the total output of the High-Voltage Supply is held relatively constant.

Circuit Description—475A Service

Q1312 and Q1310 compose an overvoltage protection circuit. In the event the regulating action of the circuit should cause the CRT cathode supply to approach approximately -3000 volts, the voltage level at the emitter of Q1316 will be very close to -6 volts. Normally Q1312 and Q1310 are biased off and do not conduct. When the voltage level at the emitter of Q1316 reaches approximately -6 volts, Q1312 is biased into conduction, which in turn biases Q1310 on. Q1310 now starts to reduce the base drive applied to Q1318 and prevents the amplitude of oscillations from increasing. This prevents the CRT cathode supply from going more negative than approximately -3300 volts.

High-Voltage Rectifiers and Output

The high-voltage transformer T1320 has two output windings. One winding provides filament voltage for the cathode-ray tube. The filament voltage can be supplied from the High-Voltage Supply, since the cathode-ray tube has a very low filament current drain. The filament of the cathode-ray tube is elevated to the cathode level to prevent cathode-to-filament arcing. The other winding of T1320 is used to derive both the negative cathode potential and the positive anode accelerating potential.

The positive accelerating potential is supplied by High Voltage Multiplier U1321. Regulated output voltage is approximately +15,500 volts. The negative cathode potential is supplied by a voltage doubler circuit, C1320, CR1320 and CR1321. Voltage output is -2450 volts. Variations in supply voltage are monitored by the High-Voltage Regulator circuit to provide a regulated high-voltage output.

Control-Grid DC Restorer

The Control-Grid DC Restorer couples dc and low frequency components of the Z-Axis Amplifier signal to the CRT control grid. This allows the Z-Axis Amplifier to control the CRT beam current (intensity). The potential difference between the Z-Axis Amplifier output and the control grid (about 2450 volts) prohibits direct coupling.

The dc restorer is actually a cathode-referenced bias supply for the CRT control grid. Quiescently, its output voltage is more negative than the CRT cathode by an amount set by the voltage level across VR1374, the setting of Grid Bias adjustment R1375, and the voltage at the output of the Z-Axis Amplifier.

When the secondary-winding output of T1320 swings positive, C1372 charges through C1326, R1326, R1372, CR1379, and R1379 to a voltage level that equals the voltage determined by VR1374 and the setting of Grid Bias adjustment R1375. At this voltage level, (approximately +15 volts) CR1373 turns on, preventing any additional increase in positive voltage. When the secondary-winding output swings negative, CR1373 turns off, then CR1371 turns on and clamps the less positive voltage swing at C1372 to the voltage level of the Z-Axis Amplifier. During this less positive voltage swing, C1372 discharges through CR1377 into C1371. Capacitor C1371 holds the voltage constant at the CRT control grid; it also provides a path for the fast rising and falling portions of the Z-Axis Amplifier output to be coupled to the CRT control grid for blanking and unblanking.

CRT Control Circuits

Focus of the CRT display is controlled by FOCUS control R1380. The Focus Tracking control, R1335B, located in a series resistor network with the FOCUS control, is ganged with the INTENSITY control to reduce focus variations when changing the INTENSITY setting. The ASTIG adjustment R1397 which is used in conjunction with the FOCUS control to provide a well-defined display, varies the positive level on the astigmatism grid. Geometry adjustment R1390 varies the positive level on the horizontal deflection plate shields to control the overall geometry of the display.

Two adjustments control the trace alignment by varying the magnetic field around the CRT. Y Align adjustment R1385 controls the current through L1385, which affects the CRT beam after vertical deflection but before horizontal deflection. Therefore, it affects only the vertical (Y) components of the display. TRACE ROTATION adjustment R1386 controls the current through L1386 and affects both vertical and horizontal rotation of the beam.

Z-Axis Amplifier

The Z-Axis Amplifier circuit controls the CRT intensity level from several inputs. The effect of these input signals is to either increase or decrease the trace intensity, or to completely blank portions of the display. The input transistor, Q1338, is a current-driven, low input impedance amplifier. It provides termination for the input signals as well as isolation between the input signals and the following stages. The current signals from the various control sources are connected to the emitter of Q1338 and the algebraic sum of the signals determines the collector conduction level.

Q1344, Q1352, Q1354, Q1358, and Q1362 compose a feedback amplifier stage. R1369 is the feedback resistor and C1352 provides high-frequency compensation. Q1344 is an emitter follower that provides drive to the output complementary amplifier made up of Q1352, Q1354, and Q1358. Q1358 is a device with higher frequency characteristics than Q1354 and is used to improve the overall frequency capabilities of the Z-Axis Amplifier. On the fast positive-going output signal peaks, Q1358 depletes the charge on C1358. Then, on the negativegoing signal peaks, Q1362 is pulsed on to renew the charge on C1358. CR1367 provides protection to the Z-Axis Amplifier circuitry in the event of short duration arcing in the CRT High-Voltage Power Supplies.

In the 0.1 s, 0.2 s, 0.5 s, and X-Y positions of the TIME/DIV switch, the anode of CR1337 is connected to ground. This limits how negative the operating level at the emitter of Q1338 can go to reduce the unblanking capabilities of the amplifier, thereby reducing the possibility of inadvertently burning the CRT phosphor. When the BEAM FINDER pushbutton is pressed, -8 volts is connected to the junction of R1342 and R1346. This biases Q1338 off which in turn causes CR1343 to be reverse biased. Now the output of the Z-Axis Amplifier is isolated from all of the circuit's normal signal inputs. The output level of the amplifier is set at a nearly fixed level (approximately +25 volts) determined by the parallel value of R1343 and R1346 divided into the feedback resistance of the amplifier. This sets the sweep intensity to a normal viewing level.

CALIBRATOR



General

The Calibrator circuit produces a square-wave output signal with accurate voltage and current amplitudes. This output is available as a voltage or current at the CALIBRATOR current loop on the instrument front panel. Fig. 3-11 shows a detailed block diagram of the Calibrator circuit. A schematic of this circuit is shown on Diagram 13 at the rear of this manual.



Fig. 3-11. Detailed block diagram of the Calibrator circuit.

Multivibrator

Q1502 and Q1504 along with their associated circuitry compose an astable multivibrator. The basic frequency of the multivibrator is approximately one kilohertz and is essentially determined by the RC combination of C1505, R1502, and R1504. Q1502 and Q1504 alternately conduct, producing a square-wave signal that is taken from the collector of Q1504.

Output Amplifier

General

The output signal from the Multivibrator overdrives Output Amplifier Q1512 to produce a square wave at the output. When the base of Q1512 goes positive, Q1512 is cut off and the collector level drops down to ground. When the base goes negative, Q1512 biased into saturation and the collector of Q1512 rises positive to about +5 volts. Amplitude adjustment R1515 adjusts the resistance between the collector of Q1512 and ground to determine the amount of current allowed to flow, which in turn determines the voltage developed across R1517.

FAN MOTOR CIRCUIT



The fan motor used in the 475A is a brushless DC motor using Hall Effect devices. The fan motor control circuitry varies the rotational speed of the fan as the operating temperature changes.

Two Hall Effect devices inside the motor, and 4 transistors U8061A, B, C, and D (U1690A-D for early SN) compose a sine-wave generator to drive the motor windings. Each of the 4 transistors is controlled by 1/2 of a Hall element to generate 1/4 of the sine-wave cycle.

As the ambient temperature increases, the value of thermistor RT8038 (RT1696 for early SN) decreases. This biases Q8067 (Q1698 for early SN) on harder to conduct more current through the Hall devices and turn the motor winding control transistor on harder. The harder the transistor is conducting, the faster the fan rotates.

Typical fan speed variation with ambient temperature is:

−15°C,	approx.	800 F	RPM
+25°C,	approx.	2000	RPM
+55°C,	approx.	3100	RPM

REV A SEP 1980

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

Page 4-6

Page 4-6

Page 4-6

Page 4-6

Page 4-7

Page 4-7

Page 4-7

Page 4-10

Page 4-10

Page 4-10

Page 4-10

MAINTENANCE

Circuit Board Illustrations

Resistor Color-Code

Capacitor Color-Code

Troubleshooting Equipment

2. Test Oscilloscope

3. Multimeter

1. Semiconductor Tester

4. Variable Autotransformer

Diode Color-Code

Adjustment Locations Illustrations

Semiconductor Lead Configuration

This section of the manual contains directions for cabinet removal, preventive maintenance, trouble-shooting and corrective maintenance of the 475A.

MAINTENANCE SECTION OUTLINE

Preventive Maintenance

Standard Cabinet Removal	Page 4-2
Standard Cabinet Installation	Page 4-3
Rack Adapter Removal	Page 4-3
Rack Adapter Installation	Page 4-4

Cabinet and Rack Adapter Removal

		Troubleshooting Techniques	Page 4-10
Introduction	Page 4-4	1. Check Control Settings	Page 4-10
Cleaning	Page 4-4	2. Check Associated Equipment	- Page 4-10
Switch Contacts	Page 4-5	3. Check Instrument Calibration	Page 4-10
General Interior	Page 4-5		0
Exterior	Page 4-5	4. Visual Check	Page 4-10
OPT Face Filter and Ohiold	-	5. Isolate Trouble to a Circuit	Page 4-10
CRT Face, Filter and Shields	Page 4-5	6. Circuit Troubleshooting Sequence	Page 4-10
Air Filter	Page 4-5	7. Check Circuit Board Interconnection	Page 4-11
Visual Inspection	Page 4-6	8. Check Voltages and Waveforms	Page 4-11
Lubrication	Page 4-6	9. Check Individual Components	Page 4-11
Semiconductor Checks	Page 4-6	10. Repair and Readjust the Circuit	Page 4-14
Recalibration	Page 4-6		
		Special Troubleshooting Information	Page 4-14
Troubleshooting		General	Page 4-14
Introduction	Page 4-6	Troubleshooting the L.V. Power Supplies	Page 4-15
Troubleshooting Aids	Page 4-6	Troubleshooting the High-Voltage Circuit	Page 4-16
Diagrams	Page 4-6	Troubleshooting the Sweep Circuits	Page 4-16

@

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Maintenance—475A Service

Troubleshooting the Horizontal Amplifier	Page 4-18
Troubleshooting the Vertical System	Page 4-18
Troubleshooting the Z-Axis Circuit	Page 4-18

Corrective Maintenance

Introduction	Page 4-18
Obtaining Replacement Parts	Page 4-19
Standard Parts	Page 4-19
Special Parts	Page 4-19
Ordering Parts	Page 4-19
Soldering Techniques	Page 4-19
Small Component Replacement	Page 4-20
General	Page 4-20
Transistor and I.C. Replacement	Page 4-20
Interconnecting Pin Replacement	Page 4-21
Ceramic Terminal Strip Replacement	Page 4-21

Fuse Replacement Page 4-22 Cam Switch Replacement Page 4-22 **Circuit Board Replacement** Page 4-22

Vertical Preamp Board Removal Page 4-24 Vert Mode-Gain Switch Board Removal Page 4-25

.	Ţ.
Trigger Generator And Z-Axis Logic Board Removal	Page 4-25
Timing Board Removal	Page 4-26
Vertical Output Board Removal	Page 4-26
Fan Motor Board Removal	Page 4-26
Inverter Board Removal (Option 7 only)	Page 4-27
Power Supply Board Removal (475A DM44)	
(475A DIM44)	Page 2-47
Main Interface Board Removal	Page 4-28
Power Transformer Removal	Page 4-29
Cathode-ray Tube Removal	Page 4-30

Cathode-ray Tube Installation	Page 4-31
High-Voltage Multiplier Removal	Page 4-31
Delay Line Removal	Page 4-32
Recalibration After Repair	Page 4-32
Instrument Repackaging	Page 4-32

CABINET AND RACK ADAPTER REMOVAL

Standard Cabinet Removal

The standard instrument cabinet can be removed in the following manner:

1. Disconnect the instrument power cord from the power source.

2. Install the front-panel cover and set the instrument face on a flat surface.

3. Unwrap the power cord from the instrument feet.

4. Remove the 6 screws indicated in Fig. 4-1 and remove the rear cabinet frame with feet and screws from the instrument as an intact assembly.





4-2

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel:- 01844-351694 Fax-- 01844-352554 Email:- enquiries@maunitron.cu.uk

@

5. Lift the cabinet up until it is separated from the instrument and power cord.

WARNING

Dangerous potentials exist at several points throughout this instrument. When the instrument is operated with the cabinent removed, do not touch exposed connections or components. Some transistors may have elevated cases. Disconnect power before cleaning the instrument or replacing parts.

Standard Cabinet Installation

The standard instrument cabinet should be installed in the following manner:

1. Disconnect the instrument power cord from the power source.

2. If the Vertical Output circuit-board cover is not in place, install the cover on the top of main chassis. Where parts were removed or replaced check all sections of the instrument for proper assembly. It may by helpful to use the diagrams in Section 9, Mechanical Parts List, for the locations of parts.

3. 475A DM44—If the DM44 main circuit-board is not in place, install the board on the main chassis.

4. Install the front-panel cover and set the instrument face on a flat surface.

5. Place the cabinet handle against the bottom of the cabinet (bottom of cabinet is nearest the carrying handle pivot points).

6. Pull the power cable through the cabinet and slide the cabinet over the instrument using care to avoid pinching cables or damaging components that protrude from circuit boards.

7. Using both hands, press lightly on the top and bottom sides of the cabinet until the front edge of the cabinet is inserted into the braided gasket groove around the full periphery of the front cabinet frame.

8. Pull the power cord through the rear cabinet frame, align a cutout portion in the frame for proper fit at the regulating-range selector cover and work the frame into place.

Maintenance—475A Service

9. Set the feet and screws in place and exert a light downward pressure on the rear cabinet frame with 1 hand and arm. Press lightly on the top and bottom sides of cabinet with the other hand, checking that cabinet edge is properly seated in the gasket groove of both front and rear frames. Continue to exert a downward pressure and tighten the 6 screws of the rear frame to a snug fit. Do not over-tighten these screws.

The standard cabinet protects this instrument from dust in the interior and also provides protection to personnel from the operating potentials present. In addition, the cabinet reduces the emi (electromagnetic interference) radiation from the instrument and interference to the display due to other equipment.

The front-panel cover provides a dust-tight seal around the front panel and protects the front panel when storing or transporting the instrument.

Rack Adapter Removal

The Rack Adapter can be removed from the instrument in the following manner:

1. Remove the hardware that fastens the Rack Adapter to the rack and pull the adapter partially out. Disconnect the instrument power cord from the power source and remove any interconnecting cables.

NOTE

If it is desired to tilt the Rack Adapter and instrument, remove a screw from the rear of each slide section mounted to the Rack Adapter. These securing screws are an important part of the mounting and should be installed when tilt operation is not necessary.

2. Remove the Rack Adapter, with instrument, from the rack and set the bottom of the complete assembly on a flat surface.

3. Remove 2 setscrews from the top, front of Rack Adapter chassis, (A 0.125-inch Allen wrench is required to remove the setscrews.) It may be helpful to use the diagrams in Section 9, Mechanical Parts List for the locations of parts.

4. Remove 10 screws that hold the rear support plate to an angle bracket on one side, to the Rack Adapter chassis on the opposite side, and to the rear of the instrument. Remove the rear support-plate and blue-plastic rear frame. 5. Slide the instrument forward through the adapter cabinet, using both hands (front and rear) to lift and guide the instrument until separated from the Rack Adapter.



Dangerous potentials exist at several points throughout this instrument. When the instrument is operated with the Rack Adapter removed, do not touch exposed connections or components. Some transistors may have elevated cases. Disconnect power before cleaning the instrument or replacing parts.

Rack Adapter Installation

The Rack Adapter should be installed in the following manner:

1. Disconnect the instrument power cord from the power source.

2. If the Vertical Output circuit-board cover is not in place, install the cover on the top of the 475A main chassis. Check all sections of the instrument where parts were removed or replaced for proper assembly. It may be helpful to use the diagrams in Section 9, Replaceable Mechanical Parts for the locations of parts.

3. Set the bottom of the Rack Adapter on a flat surface, pull the power cord through the cabinet portion of the Rack Adapter and slide the instrument rearward using both hands (front and rear) to lift and guide the instrument until fully inserted. Use care to avoid pinching cables or damaging components that protrude from circuit boards.

4. Check that the front edge of the cabinet portion of the Rack Adapter is inserted into the braided gasket groove around the full periphery of the instrument frontframe. Pull the power cord through the blue-plastic rear frame, align a cutout portion in the plastic frame for proper fit at the regulating-range selector cover, and work the frame into place.

5. Apply the rear support bracket to the rear of the Rack Adapter. Install, without tightening, 6 screws that secure the rear support bracket through the blue-plastic frame to the rear of the instrument and 4 screws that secure the rear support bracket to an angle bracket and to the Rack Adapter chassis.

6. Check that all parts of the complete assembly are properly seated, then tighten to a snug fit the screws at the rear of the instrument and the screws at the adapter chassis. Do not overtighten these screws.

7. Install 2 setscrews at the top-front of the Rack Adapter chassis. (A 0.125-inch Allen wrench is required to install the setscrews.)

8. Mount the Rack Adapter slide sections to the rack slide assemblies, connect the power cord, connect any interconnecting cables, push the Rack Adapter into final operating position, and install the adapter-to-rack hardware.

The Rack Adapter cabinet (Part No. 016-0556-00) for the 475A provides the proper electrical environment for the instrument, reduces dust collection, reduces handling damage to a minimum, and provides a means for mounting the instrument solidly to a surface such as a rack or console.

PREVENTIVE MAINTENANCE

Introduction

Preventive maintenance consists primarily of cleaning and visual inspection. When performed on a regular basis, preventive maintenace can prevent instrument breakdown and improves the reliability of this instrument. The severity of the environment to which the 475A is subjected will determine the frequency of maintenance. A convenient time to perform preventive maintenance is just prior to recalibration of the instrument.

Cleaning

The cabinet provides protection against dust in the interior of the instrument. Operation without the cabinet in place necessitates more frequent cleaning. The front cover provides a measure of dust protection for the front panel and the crt face. The front-panel cover should be installed when storing or transporting the instrument.



The volts/division attenuators use a plastic material (polyphenylene oxide) that is easily damaged by the use of carbon-based solvents. Avoid the use of chemical cleaning agents which might damage the plastics used in this instrument. Do not use chemicals that contain acetone, benzene, toluene, xylene, petroleum ether, white kerosene, carbon tetrachloride, methylene chloride, trichloroethane, trichlorotrifluoroethane (freon 113, -tf, -ta, -tmc) and trichlorethylene. Recommended cleaning agents for general interior cleaning, except switch contacts, are isopropyl alcohol, kelite (1 part kelite, 20 parts water), and a solution of 1% mild detergent and 99% water. (Read the information under Cleaning, Switch Contacts, before attempting to clean in the area of the volts/division attenuators). As a second choice, in the absence of these cleaners, it is safe to use ethyl alcohol (fotocol, ethanol) and methyl alcohol (methanol).

Most spray circuit-coolants contain freon 12 as a propellant. Because many freons adversely affect switch contacts, check the contents and brand name before using a spray coolant. Use the following brand names for an acceptable coolant in areas other than the volts/division attenuators: Artic Freeze, Quik-Freeze, and Can-O-Gas. Do not use Zero Mist brand of circuit coolant. The recommended circuit coolants for the volts/division attenuators are dry ice (CO_2) or isopropyl alcohol.

Switch Contacts. Most of the switching in the 475A is accomplished with circuit-board mounted, cam-actuated contacts. Care must be exercised to preserve the highfrequency charcteristics of these switches. Seldom is switch cleaning necessary, but if it is required, observe the following precautions.

For cleaning the switch contacts, isopropyl alcohol is the recommended solvent to use. Apply the isopropyl alcohol with a camel-hair brush. Do not use cotton swabs as they tend to snag on contacts, possibly causing damage, and leave strands of cotton, causing intermittant electrical contact.

General Interior. Dust in the interior of the instrument should be removed occasionally due to its electrical conductivity under high-humidity conditions. Accumulations of dirt should be removed as often as operating conditions require because dirt can cause overheating and component breakdown. Dirt on components acts as an insulating blanket and prevents efficient heat dissipation. It also provides an electrical conduction path that can result in instrument failure. The best way to clean the interior is to blow off the accumulated dust with dry, low-pressure air (approximately 9 lb/in²). Remove any dirt that remains with a soft brush or a cloth dampened with a mild detergent and water solution. A cotton-tipped applicator is useful for cleaning in narrow spaces or for cleaning ceramic terminal strips and circuit boards.

Exterior. Loose dust accumulated on the outside of the 475A can be removed with a soft cloth or small paint brush. The paint brush is particularly useful for dislodging dirt on and around the front-panel controls. Dirt that remains can be removed with a soft cloth dampened in a mild detergent and water solution. Abrasive cleaners should not be used.

CRT Face, Filter and Shields. Clean the individual blue or clear plastic implosion shields and the crt face with a soft, lint-free cloth dampened with denatured alcohol (ethyl alcohol) or a mild detergent and water solution. Install only one implosion shield between the bezel and crt face. The optional crt mesh filter can be cleaned in the following manner:

REV OCT 1983

1. Hold the filter in a vertical position and brush lightly with a soft watercolor brush to remove light coatings of dust and lint.

2. Greasy residues or dried-on dirt can be removed with a solution of warm water and a neutral pH liquid detergent. Use the brush to lightly scrub the filter.

3. Rinse the filter thoroughly in clean water and allow to air dry.

4. If any lint or dirt remains, use clean low-pressure air (approximately 9 lb/in²) to remove. Do not use tweezers or other hard cleaning tools on the filter as the special finish may be damaged.

5. When not in use, store the mesh filter in a lint-free, dust proof container such as a plastic bag.

Air Filter. The air filter should be visually checked every few weeks and cleaned or replaced if dirty. More frequent inspections are required under severe operating conditions. The following procedure is suggested for cleaning the filter. If the filter is to be replaced, order new air filters from your local Tektronix Field Office or representative; order by Tektronix Part No. 378-0044-01.

1. Remove the filter by pulling it out of the retaining frame on the rear panel. Be careful not to drop any of the accumulated dirt into the instrument.

2. Flush the loose dirt from the filter with a stream of hot water.

3. Place the filter in a solution of mild detergent and hot water and let it soak for several minutes.

4. Squeeze the filter to wash out any dirt which remains.

5. Rinse the filter in clear water and allow it to dry.

6. Coat the dry filter with an air-filter adhesive (available from air conditioner suppliers, or order Tektronix Part No. 006-0580-00).

7. Let the adhesive dry thoroughly.

8. Install the filter in the retaining frame.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351894 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk 4-5

Maintenance-475A Service

Visual Inspection

The instrument should be inspected occasionally for such defects as broken connections, broken or damaged ceramic strips, improperly seated semiconductors, damaged or improperly installed circuit boards, and heatdamaged parts.

The corrective procedure for most visible defects is obvious; however, particular care must be taken if heatdamaged components are found. Overheating usually indicates other trouble in the instrument; therefore, it is important that the cause of overheating be corrected to prevent recurrence of the damage.

Lubrication

The fan motor and most of the potentiometers used in the 475A are permanently sealed and generally do not require periodic lubrication. The switches used in the 475A, both cam- and lever-type, are installed with proper lubrication applied where necessary and will only rarely require any additional lubrication. It is recommended that a regular periodic lubrication program not be performed on any of the components used in the 475A.

Semiconductor Checks

Periodic checks of the transistors and other semiconductors in the 475A are not recommended. The best check of semiconductor performance is actual operation in the instrument.

Recalibration

To ensure accurate measurements, check the calibration of this instrument after each 1000 hours of operation or every six months if used infrequently. In addition, replacement of component may necessitate recalibration of the affected circuits. The calibration procedure can also be helpful in localizing certain troubles in the instrument. In some cases, minor troubles may be revealed and/or corrected by recalibration. Complete calibration instructions are given in the Calibration section.

TROUBLESHOOTING

Introduction

The following information is provided to facilitate troubleshooting of the 475A. Information contained in other sections of this manual should be used along with the following information to aid in locating the defective component. An understanding of the circuit operation is helpful in locating troubles, particularly where integrated circuits are used. See the Circuit Description section for this information.

Troubleshooting Aids

Diagrams. Complete circuit diagrams are given on foldout pages in the Diagram section. The component number and electrical value of each component in this instrument are shown on the diagrams (see first page of the Diagrams section for definition of the reference designators and symbols used to identify components in this instrument). Each main circuit is assigned a series of component numbers. Table 4-1 lists the main circuits in the 475A and the series of component numbers assigned to each. Important voltages and waveforms are also shown on the diagrams. The portions of the circuit mounted on circuit boards are enclosed with blue lines.

Circuit Board Illustrations. To aid in locating circuit boards in the instrument, a circuit board location illustration is placed on the back of the pullout page preceding the circuit diagram. An illustration of the circuit board, with circuit components of the following circuit diagram identified, is also included on this page. Each circuit board illustration is arranged to facilitate rapid physical location of components listed on the schematic diagrams.

Adjustment Locations Illustrations. To aid in locating test points and adjustable components, the Adjustment Locations pullout pages (normally used with the calibration procedure) permit very rapid location of test points and adjustments because only these components are identified. The Adjustment Location illustrations will be found following the Calibration Procedure (Section 6 of this manual).

Resistor Color-Code. In addition to the brown composition resistors, some metal-film resistors and some wire-wound resistors are used in the 475A. The resistance values of wire-wound resistors are usually printed on the body of the component. The resistance values of composition resistors and metal-film resistors are color-coded on the components with EIA color-code (some metal-film resistors may have the value printed on the body). The color-code is read starting with the stripe nearest the end of the resistor. Composition resistors have four stripes, which consist of two significant figures, a multiplier, and a tolerance value (see Fig. 4-2). Metal-film resistors have five stripes consisting of three significant figures, a multiplier, and a tolerance value.

Capacitor Color-Code. The capacitance values of common disc capacitors and small electrolytics are marked on the side of the component body. The white ceramic and epoxy-coated tantalum capacitors used in the 475A are color-coded, using a modified EIA code (see Fig. 4-2).

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tet: 01844-351694 Fax:- 01844-352554 Email:- enguiries@mauritron.co.uk

TABLE 4-1

Circuit Number-to-Diagram Locator

Circuit Number Series	Name of Circuit	Diagram Number
10 - 49	CH 1 ATTENUATORS	
100 — 199	CH 1 VERTICAL PREAMP	
<u>10 — 69</u> 200 — 299	CH 2 ATTENUATORS	
	CH 2 VERTICAL PREAMP	
300 — 439	VERTICAL CHANNEL SWITCHING	
440 — 499	VERTICAL OUTPUT AMPLIFIER	$\langle 4 \rangle$
500 — 570, R579 (See LV POWER SUPPLY for more 500-series numbers) 660 — 679 700 — 709	A TRIGGER GENERATOR	\$
710 — 786, R789	B TRIGGER GENERATOR	6
571 — 629 540 — 649 580 — 699 787 — 829 492 — 1499 (See LV 20WER SUPPLY for more 490-series numbers)	SWEEP AND Z AXIS LOGIC	
00 — 1049	SWEEP GENERATORS	8
050 — 1099	TIMING AND HORIZONTAL DISPLAY SWITCHING	$\langle \mathfrak{g} \rangle$
100 — 1269 507. R507. C508. R508. R529	HORIZONTAL AMPLIFIER	$\langle 0 \rangle$
1335. LR1335. C1336. LR1336 100 — 1490 1495. Q1494. Q1496. Q1497	LV POWER SUPPLY	\Diamond
300 — 1399	CRT CIRCUIT	
500 — 1519 590 — 1699	CALIBRATOR	· ·
i90 1699	FAN CIRCUIT	43

Diode Color-Code. The cathode end of each glassencased diode is indicated by a stripe, a series of stripes, or a dot. For most silicon or germanium diodes with a series of stripes, the color-code identifies the three significant digits of the Tektronix Part Number using the resistor color-code system (e.g., a diode color-coded pink - or - blue -, brown - gray - green indicates Tektronix Part No. 152-0185-00). The cathode and anode ends of metal-encased diodes can be identified by the diode symbol marked on the body.

Semiconductor Lead Configuration. Fig. 4-3 shows the lead configuration for the semiconductors used in this instrument, as viewed from the bottom of the semiconductors.

Troubleshooting Equipment

The following equipment is useful for troubleshooting in the 475A.

5

6

7

8

9

_---

10⁵ or 100 K

10⁶ or 1 M

GREEN

BLUE

VIOLET

GRAY

WHITE

GOLD

SILVER

NONE



10⁵ or

100,000 10⁶ or 1,000,000

10⁷ or

10,000,000

10⁻² or 0.01

±5%

+80%

-20%

±10%

±0.5pF

±0.25pF

±1pF

±1pF

25VDC

35VDC

50VDC

3VDC

 L			-20%	
 		10 ⁻¹ or 0.1	±10%	
 10 ⁻¹ or 0.1	±5%			
10 ⁻² or 0.01	±10%			

±1/2%

±1/4%

±1/10%

±20%

Fig. 4-2. Color codes for resistors and capacitors.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@

Maintenance-475A Service





REV NOV 1981

Maintenance—475A Service

1. Semiconductor Tester

Description: Dynamic — type tester. Must be capable of measuring reverse breakdown voltages of at least 400 volts.

Purpose: To test the semiconductors used in this instrument.

Recommended type: Tektronix 576 Curve Tracer or Tektronix 577 (D1 or D2) Curve Tracer with 177 Test Fixture.

2. Test Oscilloscope

Description: Frequency response, dc to 75 megahertz or greater; deflection factor, 1 millivolt to 5 volts/division; Input impedance, 1 megohm, 20 picofarads; sweep rate, 0.5 second/division to 50 nanoseconds/division. A 10X, 10-megohm voltage probe should be used to reduce circuit loading for waveform measurements. A 1X, 1megohm voltage probe should be used for power supply ripple checks.

Purpose: To check operating waveforms in this instrument.

Recommended type: Tektronix 7603 Oscilloscope with 7A13 Amplifier and 7B50 Time-Base units. Use a P6053 10X probe and a P6011 1X probe.

3. Multimeter

Description: Non-loading Digital Multimeter. Voltmeter, 10 megohm input impedance and 0 to 150 volts range; dc voltage accuracy, within 0.15%; display, 4-1/2 digits. Ohmmeter, 0 to 20 megohms.

Purpose: To check voltages and for general troubleshooting in this instrument.

Recommended type: Tektronix DM 501 Digital Multimeter (requires a TM 500-series power module).

4. Variable Autotransformer

Description: Output variable from 0 to 140 volts, 1.2 amperes minimum rating. Must have 3-wire power cord, plug, and receptacle.

Purpose: To vary the input line voltage when troubleshooting in the power supply.

Recommended type: General Radio W8MT3VM or W10MT3W Metered Variac Autotransformer.

Troubleshooting Techniques

This troubleshooting procedure is arranged in an order which checks the simple trouble possibilities before proceeding with extensive troubleshooting. The first few checks ensure proper connection, operation and calibration. If the trouble is not located by these checks, the remaining steps aid in locating the defective component. When the defective component is located, it should be replaced following the replacement procedure given under Corrective Maintenance.

1. Check Control Settings. Incorrect control settings can indicate a trouble that does not exist. If there is any question about the correct function or operation of any control, see the Operating Instructions section of this manual.

2. Check Associated Equipment. Before proceeding with troubleshooting of the 475A, check that the equipment used with this instrument is operating correctly. Check that the signal is properly connected and that the interconnecting cables are not defective. Also, check the power source.

3. Check Instrument Calibration. Check the calibration of this instrument, or the affected circuit if the trouble exists in only one circuit. The apparent trouble may only be a result of misadjustment and may be corrected by calibration. Complete calibration instructions are given in the Calibration section of this manual.

4. Visual Check. Visually check the portion of the instrument in which the trouble is located. Many troubles can be located by visual indications such as unsoldered connections, broken wires, damaged circuit boards, damaged components, etc.

5. Isolate Trouble to a Circuit. To isolate trouble to a particular circuit, note the trouble symptom. The symptom often identifies the circuit in which the trouble is located. When trouble symptoms appear in more than one circuit, check affected circuits by taking voltage and waveform readings. Typical voltages and waveforms are given on the schematics in the Diagrams section.

6. Circuit Troubleshooting Sequence. If the instrument is found to have inoperative functions in more than one area of the main oscilloscope circuits, repair the circuits in the order specified in the following list:

a. L.V. POWER SUPPLY (Check +50 V, +110 V, +15 V, +5 V, --15 V and -8 V supplies.)

b. HIGH VOLTAGE (Check oscillator and regulator, over-voltage protection circuit and secondary load.)

c. A SWEEP (Set TRIG MODE to AUTO; repair until sweep is repetitive.)

d. HORIZONTAL AMPLIFIER (Turn horizontal POSI-TION; repair until each deflection plate output has proper voltage swing.)

e. VERTICAL OUTPUT AMPLIFIER (Turn vertical POSITION; repair until each deflection plate output has proper voltage swing.)

f. Z AXIS (set TRIG MODE to SINGL SWP; repair until spot display is controlled by INTENSITY.)

g. All remaining inoperative functions.

The preceding recommended troubleshooting sequence is intended to be a quick approach to circuit troubleshooting. See Special Troubleshooting Information listing in this section for detailed troubleshooting instructions.

Fig. 4-4 provides a guide in locating a defective circuit. This chart may not include checks for all possible defects; use steps 7 through 9 in such cases. Start from the top of the chart and perform the given checks on the left side of the page until a step is found which does not produce the indicated results. Further checks and/or the circuit in which the trouble is probably located are listed to the right of this step.

After the defective circuit has been located, it may be helpful to read the applicable part of the Circuit Description section and Special Troubleshooting Information part of this section to aid in locating defective components. After doing this, see steps 7 through 9 for additional information.

7. Check Circuit Board Interconnections. After the trouble has been isolated to a particular circuit, check for loose or broken connections at circuit-board interconnecting pins, plugs and end-lead connectors.

8. Check Voltages and Waveforms. Often the defective component can be located by checking for the correct voltage or waveform in the circuit. Typical voltages and waveforms are given on the diagrams.

Maintenance-475A Service

NOTE

Voltages and waveforms given on the diagrams are not absolute and may vary slightly between instruments. To obtain operating conditions similar to those used to take these readings, see the voltage and waveforms page with each schematic diagram. On this page, note the recommended test equipment, front-panel control settings, voltage and waveform conditions, and test equipment cable connection instructions. Voltages and waveforms given on the schematics should be checked against each instrument while it is operating properly. Deviations should be noted on the schematics for later reference.

9. Check Individual Components. The following procedures describe methods of checking individual components. Components which are soldered in place should be checked after disconnecting one end from the circuit. This isolates the measurement from the effects of surrounding circuitry.

a. SEMICONDUCTORS.



Power switch must be turned off before removing or replacing components.

A good check of transistor operation is actual in-circuit performance under operating conditions and most transistors in the 475A can be checked this way. A transistor can be most effectively checked by substituting a new component for it (or one which has been checked previously). However, be sure that circuit conditions are not such that a replacement transistor might also be damaged. If substitute transistors are not available, use a dynamic tester. Static-type testers are not recommended, since they do not check operation under simulated operating conditions.

When troubleshooting transistors with a voltmeter, measure the emitter-to-base and emitter-to-collector voltages to determine if the voltages are consistent with normal circuit voltage. Voltages across a transistor vary with the type of device and its circuit function. Some of these voltages are predictable. The emitter-to-base voltage of a conducting silicon transistor will normally be 0.6 to 0.8 volts. The emitter-to-collector voltage of saturated transistors is approximately 0.2 volts. Because these values are small, the best way to check them is by connecting the voltmeter across the junction and using a sensitive voltmeter setting, rather than by comparing 2 voltages taken with respect to ground (both leads of the voltmeter must be isolated from ground if this method is used.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk

4-11



Fig. 4-4. Troubleshooting chart for the 475A Oscilloscope.

Maintenance—475A Service

4-12

@

•



Fig. 4-4. Troubleshooting chart for the 475A Oscilloscope (cont).

Maintenance—475A Service

Maintenance—475A Service

If values less than these are obtained, either the device is short-circuited or no current is flowing in the circuit. If values are in excess of the base-emitter values given, the junction is back-biased or the device is defective. Values in excess of those given for emitter-collector could indicate either a non-saturated device operating normally, or a defective (open-circuited) transistor. If the device is conducting, voltage will be developed across resistances in series with it; if it is open, no voltage will be developed across resistances in series with it unless current is being supplied by a parallel path.

When troubleshooting field-effect transistors, the voltage across its elements can be checked in the same manner as transistors. However, it should be remembered that usual operation has the gate-to-source junction reverse biased, or 0 biased, as is used in many circuits in the 475A.

IC's (integrated circuits) can be checked with a voltmeter, test oscilloscope, or by direct substitution. A good understanding of circuit operation is essential to troubleshooting circuits using IC's. Use care when checking voltages and waveforms around the IC's so that adjacent leads are not shorted together. A convenient means of clipping a test probe to the 14- and 16-pin IC's is with an IC test clip. This device also doubles as an extraction tool. The lead configuration for the semiconductors used in this instrument are shown on Fig. 4-3.

b. DIODES. A diode can be checked for an open or shorted condition by measuring the resistance between terminals after disconnecting one end from the circuit. With an ohmmeter set to the R X 1k scale, the resistance should be very high in one direction and very low when the leads are reversed.

CAUTION

Do not measure tunnel diodes with an ohmmeter; use a dynamic tester (such as a Tektronix Type 576 Transistor-Curve Tracer).

Voltmeter checks on diodes can be performed in much the same manner as on transistor emitter-to-base junctions. Silicon diodes should have 0.6 to 0.8 volts across the junction when conducting. Higher readings indicate that they are either back biased or defective, depending on polarity.

c. RESISTORS. Check the resistors with an ohmmeter after disconnecting one end from the circuit. Check the Electrical Parts List for the tolerance of the resistors used in this instrument. Resistors normally do not need to be replaced unless the measured value varies widely from the specified value. d. INDUCTORS. Check for open inductors by checking continuity with an ohmmeter. (It may be helpful to disconnect one end of the inductor when checking continuity.) Shorted or partially shorted inductors can also be found by checking the waveform response when high-frequency signals are passed through the circuit. Partial shorting often reduces high-frequency response (increases roll-off).

e. CAPACITORS. A leaky or shorted capacitor can be detected by checking resistance with an ohmmeter, on the highest scale, after disconnecting one end from the circuit. Do not exceed the voltage rating of the capacitor (some ohmmeters use 30 volts as source voltage). The resistance reading should be high after initial charge of the capacitor. An open capacitor can also be detected with a capacitance meter or by checking whether the capacitor passes ac signals.

f. ATTENUATORS. The thick film attenuators are best checked by substitution. If only one channel of the 475A is not operating properly, and there is reason to believe an attenuator is defective, replace the suspected attenuator with the same attenuator from the other channel and check instrument operation. If proper operation results, order a new attenuator. (See Component Replacement for replacement instructions.)

10. Repair and Readjust the Circuit. If any defective parts are located, follow the replacement procedures given in this section. Be sure to check the performance of any circuit that has been repaired or that has had any electrical components replaced. Recalibration of the affected circuit may be necessary.

Special Troubleshooting Information

General. The following information provides a procedure for troubleshooting some of the more complex circuits in the 475A. A thorough understanding of the circuit operation is essential before troubleshooting in these areas. Read the applicable portions of the Circuit Description in Section 3 before proceeding. This troubleshooting procedure refers to the diagrams, operating voltages, and waveforms given in Section 8. Specifications for the equipment necessary to troubleshoot in these procedures are given earlier in this section under Troubleshooting Equipment.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauntron.co.uk

Troubleshooting the L.V. Power Supplies. Incorrect operation of all circuits often indicates trouble in the power supply. Check first for correct voltage of the individual supplies. A defective component elsewhere in the instrument can appear as a power-supply trouble and may also affect the operation of other circuits. Table 4-2 lists the tolerances of the power supplies in this instrument. Check or repair the power supplies in the sequence specified in Table 4-2. These voltages are measured between the power-supply test points and ground. If a power-supply voltage is within the listed tolerance, the supply can be assumed to be working correctly. If outside the tolerance, the +50-volt supply may be misadjusted or other supplies may by operating incorrectly. Use the procedure given in the Calibration section to adjust the +50-volt supply if adjustment is necessary. Use Adjustment Locations 1 pullout page in the Calibration section to locate power-supply test points.

TABLE 4-2

Power Supply Tolerance and Ripple

Power Supply	Tolerance	Typical Ripple (peak-to-peak)	
+50 V	0.5% (250 mV)	2 mV	
+110 V	3% (3.3 V)	1 V	
+15 V	1.5% (225 mV)	2 mV	
+5 V	1.5% (75 mV)	2 mV	
-15 V	1.5% (225 mV)	2 mV	
-8 V	1.5% (120 mV)	2 mV	

Connect the 475A to a variable autotransformer. Then, check each power supply for correct ripple with a test oscilloscope, while varying the autotransformer throughout the regulating range of this instrument (see rear panel regulating range selector cover for regulating range). Table 4-2 lists the typical ripple of the power supplies in this instrument. Measure the ripple between the power supply test points and ground.

A malfunction in the power supply can be caused by one or more supplies being shorted to ground. Check the resistance of the individual supplies to ground against the typical resistances listed in Table 4-3. Be sure the instrument is not connected to a power source when making these measurements to prevent error in resistance readings and to prevent possible meter damage.

TABLE 4-3

Power Supply Resistance Check¹

		Typical Resistance To Ground ³	
Supply	Ohmmeter Scale ²	+ Lead At Supply	 Lead At Supply
+110 V	20 K	11 kΩ	9.3 kΩ
+50 V	20 K	2.7 kΩ	2.7 kΩ
+15 V	2 K	63 Ω	63 Ω
+5 V	2 K	46 Ω	46 Ω
—15 V	2 K 20 K	480 Ω	 10 kΩ
-8 V	2 K	32 Ω	32 Ω
UNREG	20 K	14 kΩ	
+50 V	2 K		500 Ω
+105/	20 K	12 kΩ	
160 V	2 K		1 kΩ

If any of the supplies are shorted to ground, repair them until normal resistance readings are obtained. Connect the instrument to the correct power source and check the supplies for proper voltages listed in Table 4-2. If two or more of the individual supplies have incorrect voltages, repair them in the order listed in Table 4-2.

The ± 50 volt supply is the reference for all other supplies and must be repaired first. The ± 15 volt supply and the ± 5 volt supply should be working properly before repair on the -8 volt supply or the -15 volt supply is attempted.

When repairing a power supply in the 475A the following information may be helpful. The +50-volt supply is used as an example to identify component functions.

1. Check for proper voltage and ripple from the diode bridge rectifier (CR1412 in the \pm 50-volt supply; check at collector of the series regulator for any supply).

Instrument power cord should be removed from power source.

²Readings taken with a digital ohmmeter (see item 3 under Troubleshooting Equipment in this section).

Readings are normal if within 50% of listed value.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon CX9 4QY Tel: 01844-351694 Fax: 01644-352554 Email: enquiries@maunitron.co.uk

Maintenance—475A Service

2. Check that the current-limiting transistor is off (Q1432 in the +50 volt supply) by measuring base-toemitter voltage. If the supply is current limiting, remove the power from circuit boards, individually, until the supply voltage returns to normal and the circuit board drawing excess power is identified. To remove power to circuit boards, disconnect plugs, or desolder and lift one end of decoupling networks, or move circuit boards enough to clear interconnecting pins.

3. Measure the reference voltage at the supply operational amplifier and check for proper voltage (pin 3 of U1418 of +50 volt supply; negative input of the operational amplifier of any supply).

Troubleshooting the High-Voltage Circuit. There are 3 major areas of concern when troubleshooting this circuitry; the high-voltage oscillator and regulator, the overvoltage protection circuit, and the secondary load including the crt and the high-voltage multiplier. By disconnecting the appropriate circuit, the high voltage should come up. It may be helpful to use the following information, in sequence, to troubleshoot an inoperative high-voltage circuit.

1. Check the collector of Q1316 for approximately -0.7 volts to approximately +1.6 volts.

2. Check the positive end of C1318 for approximately +21 volts.

3. Check the collector of Q1318 for approximately +21 volts.

4. Disconnect and lift one end of CR1329.

5. Disconnect the crt base socket to eliminate crt loading.

6. Check or replace C1316.

7. If the oscillator still does not come up, the highvoltage multiplier could be defective. Remove the Vertical Preamp board to expose the multiplier and disconnect the center tap of the high-voltage transformer from the multiplier tie point. Troubleshooting the Sweep Circuits. The sweep circuits should be repaired in the following order:

A (Sweep) A INTEN (Intensified Sweep) B DLY'D (Sweep) MIX (Sweep)

A Sweep and Logic

1. Remove all external signals to the instrument, set TIME/DIV to 1 ms (lock knobs), set HORIZ DISPLAY to A and set TRIG MODE to AUTO.

2. Remove Q572 from its socket. This will cause only the Slow Non-Delaying Sweep Generator (A Sweep), which normally should be in operation, to stay at a low voltage level. Check the collector of Q984 for approximately +0.3 volt. Check the collector of Q1014 for approximately +16.4 volts. Check the collector of Q922 for approximately +14.6 volts.

Set TIME/DIV to 0.5 μ s or faster. This should cause the Slow-Non-Delaying Sweep Generator to run up and the Fast Non-Delaying Sweep Generator to run down. Check the collector of Q984 for approximately +16.4 volts and check the collector of Q1014 for approximately +0.3 volt.

At this point, the A Sweep holdoff should be in a reset condition. Check TP588 for approximately -4 volts. Check the emitter of Q644 for approximately 0 volt.

When Q572 was removed from its socket, pin 16 of U600 went positive, which is the equivalent of a holdoff start pulse. Check pin 16 of U600 for approximately +2.5 volts. Check pin 17 of U600 for approximately +1.7 volts. Check TP572 for approximately 0 volt. Check pin 3 of U600 for approximately +0.2 volt.

3. Install Q572 and remove Q574 from its socket. This will cause only the Fast Non-Delaying Sweep Generator, which normally should be in operation, to stay at a start (high) voltage level. Check the collector of Q1014 for approximately +14 volts. Set TIME/DIV to 1 ms. Check the collector of Q984 for approximately +14 volts.

At this point the A Sweep holdoff should be at a high level. Check TP588 for approximately +2 volts. Check the emitter of Q644 for approximately +4.3 volts.

@

Now, pin 3 of U600 should have a low auto gate voltage. Check TP572 for approximately 0 volt. Check pin 16 of U600 for approximately 0 volt. Check pin 17 of U600 for approximately -0.7 volt. Check pin 6 of U600 for approximately +4.8 volts. Check pin 3 of U600 for approximately -0.2 volt. Install Q574 and check the collector of Q984 for a repetitive sweep waveform.

A INTEN Sweep and Logic

Remove all external signals to the instrument, set TIME/DIV to 1 ms (lock knobs), set HORIZ DISPLAY to A INTEN and set TRIG MODE to AUTO.

1. Remove Q572 from its socket. This will cause the A Intensified Sweep Generator (A Sweep), which normally should be in operation, to stay at a low voltage level. Check the collector of Q922 for approximately ± 0.3 volt. Check the collector of Q1014 for approximately ± 16.4 volts. Check the collector of Q984 for approximately ± 14 volts.

The A Sweep holdoff should now be in a reset condition. Check TP588 for approximately -4 volts. Check the emitter of Q644 for approximately 0 volt.

When Q572 was removed from its socket, pin 16 of U600 went positive, which is the equivalent of a holdoff start pulse. Check pin 16 of U600 for approximately +2.5 volts. Check pin 17 of U600 for approximately +1.7 volts. Check TP572 for approximately 0 volt. Check pin 3 of U600 for approximately +0.2 volt.

2. Install Q572 and remove Q574 from its socket. This will cause only the A Intensified Sweep Generator, (which normally should be in operation) to stay at a start (high) voltage level. Check the collector of Q922 for approximately +13.9 volts.

At this point, the A Sweep holdoff should be at a high voltage level. Check TP588 for approximately +2 volts. Check the emitter of Q644 for approximately +4.3 volts.

Pin 3 of U600 should now have a low auto gate voltage. Check TP572 for approximately 0 volt. Check pin 16 of U600 for approximately 0 volt. Check pin 17 of U600 for approximately -0.7 volt. Check pin 6 of U600 for approximately +4.8 volts. Check pin 3 of U600 for approximately -0.2 volt. Install Q574 and check the collector of Q922 for a repetitive sweep waveform. B DLY'D Sweep and Logic

The A Sweep and A INTEN sweep should be working properly before starting this procedure. Remove all external signals to the instrument, set TIME/DIV to 1 ms (lock knobs), set HORIZ DISPLAY to B DLY'D and set TRIG MODE to AUTO.

1. Remove Q574 from its socket. Check the collector of Q922 for approximately +14.5 volts. Check the base of Q792 for approximately -5 volts. Check the collector of Q792 for approximately +1.2 volts. Check TP802 for approximately 0 volt. Check TP826 for approximately -1.8 volts. Check TP996 for approximately -3.7 volts. Check the collector of Q984 for approximately +14 volts.

2. Install Q574 and remove Q572. Check the collector of Q922 for approximately ± 0.2 volt. Check the base of Q792 for approximately ± 2 volts. Check the collector of Q792 for approximately ± 0.7 volt. Check TP802 for approximately ± 0.7 volt. Check TP802 for approximately ± 3.8 volts. Check TP996 for approximately ± 1.7 volts. Check the collector of Q984 for approximately 0.2 volt. Install Q572 and check the collector of Q984 for a repetitive sweep waveform.

MIX Sweep and Logic

The A Sweep, A INTEN Sweep and B DLY'D Sweep should be working properly before starting this procedure. Remove all external signals to the instrument, set A TIME/DIV to 1 ms, unlock knobs and set B TIME/DIV to 0.1 ms, set HORIZ DISPLAY to MIX, set TRIG MODE to AUTO and set B TRIGGER SOURCE to STARTS AFTER DELAY.

Compare the waveform obtained at pin 10 of J5 against the waveform at the collector of Q922 and check for similarity. Check TP996 for a delayed gate, with an amplitude of approximately -1.7 volts, that occurs during the run down ramp on the collector of Q922. The time position of the delayed gate can be controlled with DELAY TIME POSITION. Check the collector of Q984 for a fast ramp waveform that occurs during a slow ramp waveform. The fast ramp waveform runs down at a rate set by the B TIME/DIV control and is positioned in time by the DELAY TIME POSITION control.

Maintenance—475A Service

Troubleshooting the Horizontal Amplifier. The Horizontal Amplifier contains push-pull circuitry that can be checked in the following manner:

Set TIME/DIV to 1 ms (lock knobs) and set TRIG MODE to SINGL SWP. Remove Q1114, Q956 and Q1026 from their sockets. Connect a voltmeter between the base of Q1152 and the base of Q1162; adjust R1130 for 0 volt. Check the voltages in the amplifier against the voltages listed on the Horizontal Amplifier schematic diagram. Check the voltage at the bases of Q1124 and Q1134 for balance and apply this balance check procedure to each stage, proceeding toward the amplifier output.

Install Q1114, Q956 and Q1026 in their sockets and check for a repetitive sweep.

Troubleshooting the Vertical System. The instrument front panel TRIG VIEW control provides a quick way to find trouble in this circuitry. Press the TRIG VIEW pushbutton and adjust A TRIGGER LEVEL control to bring the trace to the crt viewing area. If unable to obtain a trace, look for a problem in the Vertical Output Amplfier. If a trace can be obtained, look for a problem in the Channel 1 or Channel 2 Preamplifier or the Vertical Channel Switching circuitry.

When troubleshooting the vertical deflection system, the best procedure is to start from the input and work to the output of the problem-circuit area (determined by previous checks using TRIG VIEW pushbutton).

Preamplifier Troubleshooting

The following procedure can be used for Channel 1 or Channel 2 Preamplifier. Channel 1 is described as an example to identify circuit functions.

Remove any external signal from the instrument input. Check the input of U120 (pin 13) for 0 volt. Connect a voltmeter between pins 5 and 9 of U120 and adjust CH 1 VAR BAL (R110) for 0 volt. Measure from pin 5 or 9 of U120 to ground and check for the recommended voltage listed on the appropriate Vertical Preamp schematic diagram.

Connect the voltmeter between pins 5 and 9 of U140 and adjust CH 1 VOLTS/DIV BAL (R135) for 0 volt. Measure from pin 5 or 9 of U140 to ground and check for the recommended voltage on the diagram. Check the collectors of Q172 and Q182 for voltages listed on the diagram.

Connect the voltmeter between the collectors of Q178 and Q188 and adjust the vertical POSITION control for 0 volt. Measure from the collector of Q178 or Q188 to ground and check for voltages listed on the diagram.

4-18

Vertical Channel Switch Troubleshooting

The collector voltages of Q178 and Q188 must by balanced as detailed in the preceding steps before starting this procedure.

Set VERT MODE to CH 1 and check the dc voltages in the channel switching circuitry for the voltages listed on the Vertical Channel Switching schematic diagram. Do not check waveforms until dc operation is normal.

Vertical Output Amplifier Troubleshooting

Disconnect the delay line connection on the Vertical Preamp board. This requires the use of a soldering iron (a 40 to 60 Watt iron works best) to unsolder the delay line ground connection.

Check for the recommended voltages listed on the Vertical Output Amplifier diagram.

Troubleshooting the Z-Axis Circuit (CRT Circuit). Set TIME/DIV to 1 ms (lock knobs) and set TRIG MODE to SINGL SWP. Disconnect and lift one end of CR1343. Check the voltage at TP1364 for approximately +6 volts. Press the BEAM FINDER pushbutton and check the voltage at TP1364 for approximately +25 volts. If these voltages cannot be obtained, check the voltage across VR1362 for approximately +6.2 volts. Remove Q1362 from its socket and check the voltage at the base of Q1352 for approximately +1.3 volts. Check the base of Q1344 for approximately +0.6 volt.

If the above-mentioned voltages can be obtained, disconnect and lift one end of CR1341. Check the voltage swing at the collector of Q1338 for approximately +7.8 volts to -1.3 volts while turning INTENSITY control from full counterclockwise to full clockwise. If these voltages cannot be obtained, check the voltage at the base of Q1338 for -1.75 volts. Remove Q1332 from its socket. Disconnect J1333 and J1334 (coaxial-type end-lead connectors) from their sockets. Repeat the voltage swing check at the collector of Q1338 as performed previously.

Connect J1333, J1334, CR1343 and CR1341 to the circuit board. Install Q1362 and Q1332 in their sockets.

CORRECTIVE MAINTENANCE

Introduction

Corrective maintenance consists of component replacement and instrument repair. Special techniques required to replace components in this instrument are given here.



@
Obtaining Replacement Parts

Standard Parts. All electrical and mechanical parts replacements for the 475A can be obtained through your local Tektronix Field Office or representative. However, many of the standard electronic components can be obtained locally in less time than is required to order them from Tektronix, Inc. Before purchasing or ordering replacement parts, check the parts list for value, tolerance, rating and description.

ΝΟΤΕ

Physical size and shape of a component may affect instrument performance, particularly at high frequencies. Always use direct-replacement components, unless it is known that a substitute will not degrade instrument performance.

Special Parts. In addition to the standard electronic components, some special components are used in the 475A. These components are manufactured or selected by Tektronix, Inc. to meet specific performance requirements, or are manufactured for Tektronix, Inc. in accordance with our specifications. Most of the mechanical parts used in this instrument have been manufactured by Tektronix, Inc. Order all special parts directly from your local Tektronix Field Office or representative.

Ordering Parts. When ordering replacement parts from Tektronix, Inc., it is imperative that all of the following information be included in the order to ensure receiving the proper parts.

1. Instrument type (include modification or option numbers).

2. Instrument serial number.

3. A description of the part (if electrical, include the circuit number).

4. Tektronix Part number.

Soldering Techniques



Always disconnect the instrument from the power source before attempting to solder in the instrument.

Ordinary 60/40 solder and a 15- to 40-watt pencil-type soldering iron can be used to accomplish the majority of the soldering to be done in the 475A. If a higher wattagerating soldering iron is used on the etched circuit boards, excessive heat can cause the etched circuit wiring to separate from the board base material.



The Vertical Preamplifier Attenuator circuit boards are made of material easily damaged by excessive heat. When soldering to these boards, do not use a soldering iron with a rating of more than approximately 15 watts. Avoid prolonged applications of heat to circuit-board connections. Use only isoproplyl alcohol when cleaning this circuit board.

The following technique should be used to replace a component on a circuit board. Most components can be replaced without removing the boards from the instrument.

1. Grip the component lead with long-nose pliers. Touch the soldering iron to the lead at the solder connection. Do not lay the iron directly on the board, as it may damage the board.

2. When the solder begins to melt, pull the lead out gently. If unable to pull the lead without using force, try removing the other end of component as it may remove easier.

NOTE

The reason that some component leads seem troublesome to remove is due to a bend placed on each lead during machine insertion of the component in the circuit-board manufacturing process. The purpose of the bent leads is to hold the component in place during a flow-soldering, manufacturing process that solders all components at once.

If a component lead is extremely difficult to remove, it may be helpful to straighten the leads on the back side of the board with a small screwdriver or pliers while heating the soldered connection.

Desolder the component from the circuit board using heat on the component lead so that the solder will stay behind on the board. If it is desired to remove solder from a circuit board hole for easier installation of a new component, a vacuum-type desoldering tool or a solderremoving wick should be used for this purpose.

3. Bend the leads of the new component to fit the holes in the board. If the component is replaced while the board is mounted in the instrument, cut the leads so they will just protrude through the board. Insert the leads into the holes in the board so the component is firmly seated against the board (or as positioned originally). If it does not seat properly, heat the solder and gently press the component into place.

4. Touch the iron to the connection and apply a small amount of solder to make a firm solder joint. To protect heat-sensitive components, hold the lead between the component body and the solder joint with a pair of longnose pliers or other heat sink.

5. Clip the excess lead that protrudes through the board (if not clipped in step 3).

6. Clean the area around the solder connection with a flux-remover solvent. Be careful not to remove information printed on the board.

When soldering to the ceramic strips in the instrument a slightly larger soldering iron can be used. It is recommended that a solder containing about 3% silver be used when soldering to these strips to avoid destroying the bond to the ceramic material. This bond can be broken by repeated use of ordinary tin-lead solder or by the application of too much heat; however, occasional use of ordinary solder will not break the bond if excessive heat is not applied.

Observe the following precautions when soldering to a ceramic terminal strip:

1. Use a hot iron for a short time. Apply only enough heat to make the solder flow freely.

2. Maintain a clean, properly tinned tip.

3. Avoid putting pressure on the ceramic terminal strip.

4. Do not attempt to fill the terminal-strip notch with solder; use only enough solder to cover the wires adequately.

5. Clean the flux from the terminal strip with a flux-remover solvent.

If it becomes necessary to solder in the general area of any of the high-frequency contacts in the instrument, clean the contacts immediately upon completion of the soldering. Refer to Cleaning—Switch Contacts under PREVENTIVE MAINTENANCE for recommended cleaners and procedures.

Small Component Replacement

W	A	R	N	I	N	G

Always disconnect the instrument from the power source before attempting to replace components.

General. The exploded-view drawings associated with the Mechanical Parts List (located at rear of manual) may be helpful in the removal or disassembly of individual components or sub-assemblies.

Transistor and IC Replacement. Transistors and IC's (integrated circuits) should not be replaced unless they are actually defective. If removed from their sockets during routine maintenance return them to their original sockets. Unnecessary replacement or switching of semiconductor devices may affect the calibration of the instrument. When a transistor is replaced, check the operation of the part of the instrument that may be affected.

Any replacement component should be of the original type or a direct replacement. Bend the leads to fit the socket and cut the leads to the same length as on the component being replaced. See Fig. 4-3 for lead configurations and basing used in this instrument.

If a replacement transistor is made by a different manufacturer than the original, check the manufacturer's basing diagram for correct basing. All transistor sockets in this instrument are wired for the standard basing as used for metal-cased transistors.

The chassis-mounted power supply transistors and their mounting bolts are insulated from the chassis. In addition, silicone grease is used to increase heat transfer capabilities. Install the insulators and replace the silicone grease, when replacing these transistors. The grease should be applied to both sides of the mica insulators, and should be applied to the bottom side of the transistor where it comes in contact with the insulator.



Handle silicone grease with care. Avoid getting silicone grease in the eyes. Wash hands thoroughly after use.

NOTE

After replacing a power transistor, check that the collector is not shorted to ground before applying power.

WARNING

Voltages are present on the exterior surface of the chassis-mounted power supply transistors if the power is applied to the instrument and the POWER switch is on. Also, voltages may be present several minutes after the instrument is turned off.

Interconnecting Pin Replacement. Two methods of interconnection are used in this instrument to connect the circuit boards with other boards and components. When the interconnection is made with a coaxial cable, a special end-lead connector plugs into a socket on the board. Other interconnections are made with a pin soldered onto the board. Two types of mating connections are used for these interconnecting pins. If the mating connector is on the end of a lead, an end-lead pin connector is used which mates with the interconnecting pin. The following information provides the replacement procedure for the various types of interconnecting methods.

a. COAXIAL-TYPE END-LEAD CONNECTORS.

Replacement of the coaxial-type end-lead connectors requires special tools and techniques; only experienced maintenance personnel should attempt replacement of these connectors. It is recommended that the cable or wiring harness be replaced as a unit. For cable or wiring harness part numbers, see the Mechanical Parts List. An alternative solution is to refer the replacement of the defective connector to your local Tektronix Field Office or representative.

b. CIRCUIT-BOARD PINS.

NOTE

A circuit-board pin replacement kit including necessary tools, instructions, and replacement pins is available from Tektronix, Inc. Order Tektronix Part No. 040-0542-00.

To replace a pin which is mounted on a circuit board, first disconnect any pin connectors. Then, unsolder the damaged pin and pull it out of the circuit board with a pair of pliers. Be careful not to damage the wiring on the board with too much heat. Remove the ferrule from the new interconnecting pin and press the new pin into the hole in the circuit board. Position the pin in the same manner as the old pin. Then, solder the pin on both sides of the circuit board. If the old pin was bent at an angle to mate with a connector, bend the new pin to match the assoicated pins.

c. CIRCUIT-BOARD PIN SOCKETS.

The pin sockets on the circuit boards are soldered to the rear of the board. To replace one of these sockets, first unsolder the pin (use a vacuum-type desoldering tool or a solder-removing wick to remove excess solder). Then straighten the tabs on the socket and remove it from the hole in the board. Place the new socket in the circuit board hole and press the tabs down against the board. Solder the tabs of the socket to the circuit board; be careful not to get solder into the socket.

NOTE

The spring tension of the pin sockets ensures a good connection between the circuit board and the pin. This spring tension can be destroyed by using the pin sockets as a connecting point for spring-loaded probe tips, alligator clips, etc.

e. END-LEAD PIN CONNECTORS.

The pin connectors used to connect the wires to the interconnecting pins are clamped to the ends of the associated leads. To replace damaged end-lead pin connectors, remove the old pin connector from the end of the lead and clamp the replacement connector to the lead.

Some of the pin connectors are grouped together and mounted in a plastic holder; the overall result is that these connectors are removed and installed as a multi-pin connector. To provide correct orientation of this multi-pin connector when it is replaced, an arrow is stamped on the circuit board and a matching arrow is molded into the plastic housing of the multi-pin connector. Be sure these arrows are aligned as the multi-pin connector is replaced. If the individual end-lead pin connectors are removed from the plastic holder, note the color of the individual wires for replacement.

Ceramic Terminal Strip Replacement. Replacement strips (including studs) and spacers are supplied under separate part numbers. However, the old spacers may be re-used if they are not damaged. The applicable Tektronix Part Numbers for the ceramic strips and spacers used in this instrument are given in the Mechanical Parts List.

To replace a ceramic terminal strip, use the following procedure.

REMOVAL:

1. Unsolder all components and connections on the strip. To aid in replacing the strip, it may be advisable to mark each lead or draw a sketch to show location of the components and connections.

2. Pry or pull the damaged strip from the chassis.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

3. If the spacers come out with the strip, remove them from the stud pins for use on the new strip (spacers should be replaced if they are damaged).

REPLACEMENT:

1. Place the spacers in the chassis holes.

2. Carefully press the studs of the strip into the spacers until they are completely seated. If necessary, use a soft mallet and tap very lightly, directly over the stud, to seat the strip completely.

3. If the stud extends through the spacers, cut off the excess.

4. Replace all components and connections. Observe the soldering precautions given under Soldering Techniques in this section.

Fuse Replacement. Table 4-4 gives the rating, location, and functions of the fuses used in this instrument.

TABLE 4-4

Fuse Rating, Location and Functions

Circuit Number	Rating	Location	Function
F1401 F1401	1.5 A Fast 0.75 A Fast	Rear Panel Rear Panel	115-volt line
F1318	1.5 A Fast	Rear of Main Interface Board	230-volt line High Voltage
F1601	15 A Fast	Front of Inverter Chassis	Inverter Input (Option 7 Only)

Cam Switch Replacement. A complete cam switch is actually a cam switch assembly. Each assembly consists of a delrin-material cam that is rotated by a front-panel knob and a set of contacts (mounted on an adjacent circuit board) that are actuated by the lobes on the cam.



Repair of cam-type switches should be undertaken only by experienced maintenance personnel. Switch alignment and spring tension of the contacts must be carefully maintained for proper operation of the switch. For this reason, it is recommended that the switch assembly be replaced as a unit. For assistance in maintenance of cam-type switches, contact your local Tektronix Field Office or representative. If a cam switch must be removed from a circuit board the circuit board containing the cam switch must be removed from the instrument. See the circuit-board replacement part of this section for circuit board removal instructions.

Disconnect the flexible coupling between cam switch and variable controls. Remove two connecting screws from each support block that holds the cam to the circuit board. Carefully lift the cam assembly from the circuit board and perform an inspection, cleaning or replacement as intended.

Reassemble the cam-switch assembly by reversing the previous process. Give careful attention to alignment and spacing of support blocks as the cam is mated to its circuit board. Do not bend circuit boards at any time in reassembly and use a very low torque to tighten the mounting screws (two fingers on the screwdriver is enough torque).

Circuit Board Replacement

Occasionally it may be necessary to gain access to the reverse side of a circuit board or to remove one circuit board to gain access to another. The following procedures outline the necessary steps to facilitate instrument disassembly. Most of the connections to the circuit boards in the instrument are made with pin connectors. However, some connections are soldered to the board. Observe the soldering precautions given under Soldering Techniques given in this section.



Always disconnect the instrument from the power source before attempting to remove circuit boards.

To aid in identifying and locating circuit boards in the instrument, see Fig. 4-5 for the locations of circuit boards. In the following circuit-board replacement procedure, determine the circuit board to be removed or replaced, find the name of the board listed within this procedure, and follow the removal or installation instructions. To aid in identifying small components described in this procedure, use the diagrams in Section 9, Mechanical Parts List, in this manual.





Vertical Preamp Board Removal. Remove the board as follows:

1. 475A DM44 only—Disconnect five multi-conductor ribbon-cables and one single conductor from the DM55 Main circuit board. Remove the screws from the rear of the Main circuit board chassis and separate the board and chassis assembly from the instrument chassis.

2. Remove both vertical POSITION control shafts. This requires a 0.050-inch Allen wrench to loosen the front setscrew in each coupling.

3. Remove the TRIG VIEW, 100 OR 20 MHz BW control shaft. Loosen the coupling setscrew with a 0.050-inch Allen wrench.

4. Remove the INVERT control extension shaft. Insert a scribe or small screwdriver between the end of the white plastic switch-shaft and the inside end of the black plastic extension-shaft and pry gently.

5. Disconnect eight coaxial cables from the front and back sides of the board and confirm color coding of each cable with its jack number in the following list. Record any exceptions to this procedure for reference when reassembling.

a. Cable to J380 is white with black and brown stripes.

b. Cable to J385 is white with black and red stripes.

c. Cable to J399 is white with a yellow stripe.

d. Cable to J430 is white with a violet stripe.

e. Cable to J405 is white with a blue stripe.

f. Cable to J410 is white with a green stripe.

g. Cable to J400 (back of board) is white with a brown stripe.

h. Cable to J349 (bottom, back of board, rear of INVERT switch) is white with a red stripe.

6. Disconnect the delay-line connection on the Vertical Preamp board. This requires the use of a soldering iron (a 40 to 60-Watt iron works best) to unsolder the delay-line ground connection. 7. Unsolder the capacitor lead at the Vertical Preamp board (bottom, back of board, between the rear of the INVERT switch and J349) using a 15-Watt soldering iron.

8. At the Vertical Preamp board unsolder one end of a wire braid that connects between the bottom of the Vertical Preamp and the Main Interface board under the high-voltage shield.

9. Disconnect three ribbon-cables from the Vertical Mode-Gain Switch board and confirm the number of wires in each cable with its plug number in the following list. Note locations of cables to facilitate correct reinstallation.

a. Disconnect a six-wire cable from P329.

b. Disconnect a seven-wire cable from P160.

c. Disconnect a ten-wire cable from P260.

10. At a feed-through terminal near U120 and U220, unsolder two 30-ohm resistors that connect each attenuator to the Vertical Preamp board. Loosen attenuator screws for clearance if necessary.

11. Remove the Vertical Preamp board mountinghardware at eight locations described in the following list. A small Phillips screwdriver is required.

a. Remove the screw, cabinet-ground spring, and hexagonal post at center of the board.

b. Remove two screws that mount the board to two long posts on the main chassis near top and bottom center of the Vertical Preamp board.

c. Remove three screws that mount the board to the rear preamp bracket (at left edge of board).

d. Remove two screws at the right edge of the board (one screw mounts each attenuator chassis to the board).

12. Remove the Vertical Preamp circuit-board, using care to prevent damage to any of the components as the board is removed.

To install the Vertical Preamp circuit-board, reverse the removal procedure.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd Chinnor Oxon OX9 40Y Tel: 01844-3515t - Fox: 01844-352554 Email: - enquines@mauritron.co.uk

@

Vertical Mode-Gain Switch Board Removal. The Vertical Mode-Gain Switch board and the Channel 1 and Channel 2 attenuators are removed as a unit.

1. Remove the Vertical Preamp circuit-board as outlined previously.

2. Remove the two UNCAL light lenses (VAR VOLTS/DIV UNCAL). Pry them away from front panel with a fingernail and pull them straight out.

3. Remove the VAR and VOLTS/DIV knobs. Set these knobs fully clockwise and loosen their setscrews. This requires a 1/16-inch Allen wrench.

4. Remove the AC-GND-DC switch knobs by pulling the knobs away from the switch, using a tight finger-grip.

5. Remove both attenuator shields, using a small Phillips screwdriver (each is held with five screws and washers).

6. Disconnect four ribbon-cables from the Vertical Mode-Gain Switch board and confirm the number of wires in each cable with its plug number in the following list. Note the locations of cables to facilitate correct reinstallation.

a. Disconnect a five-wire cable from the Main Interface board at P300.

b. Disconnect a one-wire cable from the Main Interface board at P128.

c. Disconnect two three-wire cables from the VOLTS/DIV sensitivity indicator-lights at P310 and P320.

7. Unsolder the braid connecting the CH 2 attenuator to the Main Interface, at the Main Interface board.

8. Remove the four nuts that secure the attenuators to the front casting and remove the two screws that mount the board to two posts on the main chassis.

9. Remove the Vertical Mode-Gain Switch circuitboard and attenuator assembly from the instrument, using care to prevent damage to any of the components as the board is removed. To install the Vertical Mode-Gain Switch circuit-board and attenuator assembly, reverse the removal procedure. To align the VERT MODE switch pushbuttons, hold the assembly in place with a slight forward pressure and use a small tool to reach through the front panel to align the buttons. Do not tighten the circuit-board securing screws until the securing nuts at the front of the attenuator chassis are tight and the circuit board is aligned properly.

Trigger Generator and Z-Axis Logic Board Removal. Remove the board as follows:

1. 475A DM44 only—Disconnect five multi-conductor ribbon-cables and one single conductor from the DM44 Main circuit board. Remove two screws from the rear of the main circuit-board chassis and separate the board chassis from the instrument chassis.

2. Remove the LOW LINE, READY, and TRIG light lenses. Pry them away from the front panel with a fingernail and pull them straight out.

3. Remove the POWER extension shaft from the power-switch plastic actuator. Use a small flat-blade screwdriver to pry apart the coupling of the shaft and actuator, using caution to prevent damage to the coupling.

4. Disconnect four ribbon-cables from the board as directed in the following list.

a. Disconnect a four-wire cable near Q752 at the top of the board (cable from B TRIGGER LEVEL control).

b. Disconnect a four-wire cable near J706, located two inches below the cable previously removed (cable from A TRIGGER LEVEL control).

c. Disconnect one-wire cable near the left end of J3 at the bottom of the board.

d. Disconnect a five-wire cable from P644 at the bottom, back of the board (cable from A TRIG HOLDOFF control).

5. Disconnect eight coaxial cables from the front and back sides of the board and confirm color coding of each cable with its jack number in the following list. Record any exceptions to this procedure for reference when reassembling.

- a. Cable to J704 is white with a blue stripe.
- b. Cable to J702 is white with a green stripe.

c. Cable to J706 is white with a yellow stripe.

d. Cable to J664 is white with black and brown stripes.

e. Cable to J674 is white with black and red stripes.

f. Cable to J694 is white with black and orange stripes.

g. Cable to J824 is white with an orange stripe.

h. Cable to J584 is white with a red stripe.

6. Unsolder the 33-ohm resistors from the external trigger input connectors.

7. Remove the POWER switch mounting-bracket from the board. A 3/16-inch nut driver will be required to remove a mounting nut.

8. Remove five board-mounting screws (two each at left and right edges, and one screw at the top center of the board).

9. Remove the Trigger Generator and Z-Axis Logic circuit-board from the instrument.

To install the Trigger Generator and Z-Axis Logic board, reverse the removal procedure.

Timing Board Removal. Remove the board as follows:

1. Remove the Trigger Generator and Z-Axis Logic circuit-board as outlined previously.

2. Remove the X10 MAG and UNCAL light lenses. Pry them away from the front panel with a fingernail and pull them straight out.

3. Remove the VAR and TIME/DIV knobs. Set these knobs fully clockwise and loosen their setscrews. A 1/16-inch Allen wrench is required.

4. Remove the hexagonal post and the board mounting-screws.

5. Remove the Timing circuit-board from the instrument. Use caution to prevent damage to the connecting pins on bottom of the board.

To install the Timing circuit-board, reverse the removal procedure.

Vertical Output Board Removal. Remove the board as follows:

1. Remove the Vertical Output circuit-board shield (if installed).

2. Disconnect the three-wire cable from the top-front of the Vertical Output board.

3. Disconnect two wires from the board at the crt neck pins.

4. Unsolder the delay-line ground terminal at the delay-line connection with the board (a 40 to 60-Watt soldering iron works best). Disconnect and dress the delay line away from the board.

5. Unsolder the flexible grounding braid from the case of integrated circuit U470 using a 40 to 60-Watt soldering iron.

6. Remove the integrated-circuit mounting-nut from the main chassis. A 1/4-inch open-end wrench may be necessary to remove the nut.

7. Remove the two circuit-board screws along the top edge of the board and remove the Vertical Output circuit-board.

To install the Vertical Output circuit-board, reverse the removal procedure.

Fan Motor Board Removal. Remove the board as follows:

1. Remove the Vertical Preamp circuit-board as outlined previously.

2. Disconnect a two-wire ribbon-cable at the Fan Motor board.

3. Loosen the setscrew in the fan impeller coupling with a 0.050-inch Allen wrench.

4. Remove two thread-forming screws nearest the Fan Motor circuit-board, that hold the fan motor mount to the main chassis.

5. Remove the fan motor and Fan Motor circuit-board as a unit.

To install the Fan Motor circuit-board, reverse the removal procedure.

Inverter Board Removal (Option 7 only). Remove the board as follows:

1. Remove the Vertical Output circuit-board shield (if installed).

2. Unsolder five wires from the power-transformer

terminals and confirm each wire color with its location in the following list.

a. Wire to terminal 10 is white with a brown stripe.

b. Wire to terminal 10A is white with a red stripe.

c. Wire to terminal 11 is white with a gray stripe.

d. Wire to terminal 12A is white with an orange stripe.

e. Wire to terminal 12 is white with a yellow stripe.

3. Remove two screws from the inverter chassis (one screw at the front and one at the rear of the inverter chassis, near the top of the instrument main chassis). Remove one remaining screw from the main chassis to the inverter chassis, accessible through the space along the bottom of the power transformer. A long Phillips screwdriver is necessary to remove all three screws.

4. Remove the Inverter chassis from the instrument, using care to prevent damage to interconnecting wires that pass through the hole in the main chassis.

5. Remove the screws holding the Inverter circuitboard to the Inverter chassis.

To install the Inverter circuit-board, reverse the removal procedure.

Power Supply Board Removal (475A DM44 only). Remove the board as follows:

1. Remove the Vertical Output circuit-board shield (if installed).

Maintenance—475A Service

2. Disconnect one ribbon-cable from the rear of the 475A DM44 Main circuit-board and guide the plug through a slotted opening in the main circuit-board chassis.

3. Unsolder five-wires from the power transformer and confirm each wire color with its location in the following

a. Wire to terminal 10 is white with a brown stripe.

b. Wire to terminal 10A is white with a red stripe.

c. Wire to terminal 11 is white with an orange stripe.

d. Wire to terminal 12A is white with a yellow stripe.

e. Wire to terminal 12 is white with a green stripe.

4. Remove two screws from the Power Supply board chassis (one screw each at the front and rear of the Power Supply board chassis near the top of the 475A main chassis). Remove one remaining screw from the main chassis to the power supply chassis (accessible through the space along the bottom of power transformer). A long Phillips screwdriver is necessary to remove all three

5. Remove the power supply chassis from the instrument, using care to prevent damage to interconnecting wires that pass through the hole in the main chassis.

6. Remove a piece of tape from the insulation-wrap to gain access to the board components.

7. Remove the two screws holding the Power Supply circuit-board to the power supply chassis.

8. Remove three Keps nuts and a plastic bar that hold a transistor and two integrated circuits to the power supply

9. Unsolder two ribbon-cables, noting the color codes and wire positions. If board replacement is intended, connect the wires to the new board.

To install the Power Supply circuit-board, reverse the removal procedure.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Main Interface Board Removal. If repair is necessary on the reverse side of the Main Interface circuit-board, it may be possible to gain access to that area by removal of one or two circuit boards as outlined previously. Consider this first or proceed with the Main Interface board removal procedure.

CAUTION

If the Main Interface board becomes defective, it is recommended that your local Tektronix Field Office or representative be contacted to arrange instrument repair at a Tektronix Service Center.

The Main Interface circuit-board can be removed as follows:

1. Remove the Vertical Preamp circuit-board as outlined previously.

2. Remove the Trigger Generator and Z-Axis Logic board as outlined previously.

3. Remove the high-voltage shield and remove the Vertical Output circuit-board shield (if installed).

4. Remove the BEAM FINDER and X10 MAG pushbutton extension-shafts. Insert a scribe or small screwdriver between the end of the white plastic switch-shaft and the inside end of the black plastic extension-shaft and pry gently.

5. Remove the INTENSITY, FOCUS, SCALE ILLUM, ASTIG and TRACE ROTATION control extension-shafts. Loosen the front setscrew in each coupling with a 0.050-inch Allen wrench.

6. Disconnect twelve ribbon or wire cableconnectors from the Main Interface circuit-board and confirm the number and color of wires for each plug and its location in the following list.

a. Disconnect one-wire from pin E at the top-left of the board.

b. Disconnect a two-wire cable from pins B and C at the top-left of the board.

c. Disconnect a two-wire cable near the rear of the INTENSITY control (cable from the y-axis alignment coil).

d. Disconnect a two-wire cable near Q1482 (cable from the graticule lamps).

e. Disconnect a four-wire cable at the right-center of the board (cable from POSITION and FINE controls).

f. Disconnect a four-wire cable at the rear of the A TRIG HOLDOFF control (cable from the DELAY TIME POSITION control).

g. Disconnect a two-wire cable from the CALIBRATOR current loop.

h. Disconnect four, two-wire cables near F1318 at the bottom-left of the board. The cable wires to +15 are red with a brown stripe. The cable wires to -15 are violet with a brown stripe. Cable wires to the pins nearest the fuse (GND) are black. Cable wires to the remaining pins are red with a black stripe.

7. Disconnect two coaxial-cables from the left-center of the board. The cable to J1302 is white with a gray stripe and the cable to J1334 is white with black and orange stripes.

8. Disconnect the horizontal deflection plate leads at the crt. This requires a pair of long-nose pliers or tweezers for best removal or reinstallation.

9. Disconnect a three-wire cable from the Vertical ³ Output board.

10. Disconnect a two-wire cable from the Fan Motor board.

11. Unsolder a 10-ohm, 1/2 watt resistor from the center-tap terminal of the ceramic thick-film resistor mounted near the Vertical Output circuit-board.

12. Unsolder ten wires from the Main Interface circuitboard and confirm each wire color with its location in the following list (all wires from crt socket).

a. Wire to pad 5 is white with a green stripe.

- b. Wire to pad 10 is white with black and brown stripes.
- c. Wire to pad 7 is white with a violet stripe.
- d. Wire to pad 8 is white with a gray stripe.

e. Wire to the one-notch ceramic-strip is white with a yellow stripe.

4-28

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@

f. Wire to the -2450 test point is solid red.

g. Wire to the right-hand notch on the three-notch ceramic-strip is white with an orange stripe.

h. Wire to pad 14 (lowest of a pair of wires between the large high-voltage capacitors) is white with brown and yellow stripes.

i. Wire to pad 1 (upper pad between the large highvoltage capacitors) is white with a brown stripe.

j. Wire to second notch on the five-notch ceramic-strip (notch containing junction of a 0.01 microfarad capacitor, a 10-megohm resistor, and a diode) is white with brown and red stripes.

13. Remove the three power transistor mountingscrews from Q1468, Q1426, and Q1448 on the rear subpanel bracket.

14. Remove the mounting screw from transistor Q1456 near the lower-rear corner of the board.

15. Remove the mounting screw from transistor Q1482 near the top-right corner of the board.

16. Remove the four hexagonal posts that mount the high-voltage shield. Use a 3/16-inch nut driver.

17. Remove seven Main Interface board mountingscrews.

18. Disconnect the crt anode-lead plug from the highvoltage multiplier jack. Ground this lead to the instrument main-chassis to remove any stored charge. Pry the multiplier jack from its mounting clip with a medium-size screwdriver.

19. Separate the Main Interface circuit-board from the instrument chassis, using care to prevent damage to components and wiring. Carefully thread the interconnecting cables through the board and chassis, as necessary, to avoid strain on any cable. Let the board pivot on the power-transformer leads still connected to the board.

Perform repairs on the reverse side of the Main Interface board, if repair is intended. To reinstall the board, reverse the removal procedure. If intentions are to replace the Main Interface circuit-board, continue with this procedure.

20. Unsolder the power-transformer wires from the Main Interface board and confirm each wire color with its location in Fig. 4-6. Record any exceptions to this procedure to facilitate reassembly.



Fig. 4-6. Locations of power transformer secondary wires.

21. Remove the Main Interface circuit-board, using care to prevent strain on any of the wires.

22. Remove the solder from the holes in the circuitboard wire-terminal pads, where wires were removed in this procedure, to facilitate installation.

To install the Main Interface circuit-board, reverse the removal procedure.

Power Transformer Removal

CAUTION

If the Power Transformer becomes defective, it is recommended that your local Tektronix Field Office or representative be contacted to arrange instrument repair at a Tektronix Service Center. If the Power Transformer is to be replaced, be sure to replace only with a direct replacement Tektronix transformer.

The Power Transformer can be removed as follows:

1. Remove the Trigger Generator and Z-Axis Logic circuit-board as outlined previously.

2. Remove the regulating-range selector cover and the blue rear-panel of the instrument.

3. Option 4 only—Remove the power line input filter (emi filter).

4. Remove the transformer leads from the regulatingrange selector body. It will be necessary to use a special pin removing tool available from Tektronix (Part Number 003-0707-00). It is only necessary to use this tool to remove the transformer leads from the regulating-range selector body. The leads may be installed by simply pushing them into place. Record the color and location of each wire to facilitate correct reassembly.

5. Option 7 only—Unsolder five wires from the transformer terminals and confirm each wire color with its location in the following list.

a. Wire to terminal 10 is white with a brown stripe.

- b. Wire to terminal 10A is white with a red stripe.
- c. Wire to terminal 11 is white with a gray stripe.
- d. Wire to terminal 12A is white with an orange stripe.

e. Wire to terminal 12 is white with a yellow stripe.

6. 475A DM44 only—Unsolder five wires from the transformer terminals and confirm each wire color with its location in the following list.

a. Wire to terminal 10 is white with a brown stripe.

- b. Wire to terminal 10A is white with a red stripe.
- c. Wire to terminal 11 is white with an orange stripe.
- d. Wire to terminal 12A is white with a yellow stripe.
- e. Wire to terminal 12 is white with a green stripe.

7. Remove two screws and Keps nuts that hold the transformer bracket to the rear of the main chassis. Remove two Keps nuts that hold the transformer bracket to the main chassis and the transformer electrical shield. A 5/16-inch, nut-driver wrench is helpful for easiest removal of these nuts.

8. Unsolder the wires from the thermal cutout on the transformer bracket and note the wire colors.

9. Unsolder the transformer wires from the Main Interface board as directed in the Main Interface board removal procedure, part 20.

10. Remove the transformer from the instrument.

11. Remove the solder from the holes in the circuitboard wire-terminal pads, where wires were removed in this procedure, to facilitate installation.

To install a new Power Transformer, reverse this removal procedure.

Cathode-ray Tube Removal

WARNING

Use care when handling a crt. Protective clothing and safety glasses should be worn. Avoid striking it on any object which might cause it to crack or implode. When storing a crt, place it in a protective carton or set it face down on a smooth surface in a protected location with a soft mat under the faceplate to protect it from scratches.

1. 475A DM44 only—Disconnect three ribbon-cables from the DM44 main circuit-board. Remove two screws from the rear of the main circuit-board chassis and separate the board and chassis assembly from the instrument chassis.

2. Remove the Vertical Output circuit-board shield (if installed).

3. Remove two flat-head screws from the blue-plastic cover at the rear of the instrument. Carefully position the blue-plastic cover to allow access to the screws holding the crt rear cover, then remove the crt rear cover.

4. Disconnect the crt anode plug from the high-voltage jack and touch the lead to the chassis to remove any stored charge.

	Manuals Contact
	ECHNICAL SERVICES
8 Cherni	The Roll Chinnor
	, jfa
Tel:- 01222	5 to 4
E stiere	

@

Í

5. Disconnect the crt base socket from the rear of the crt.

6. Disconnect the four vertical deflection plate leads from the Vertical Output board at the crt neck pins.

7. Disconnect the two horizontal deflection plate leads from the Main Interface board at the crt neck pins (accessible through an opening at center of the Main Interface board).

8. Remove the crt bezel and implosion shield.

9. Hold one hand on the crt base and slowly push the crt forward, guiding the crt face with the other hand. Guide the anode plug through the crt shield opening while slowly pulling the crt out of the instrument. The plastic cornerpads may fall loose when the crt is removed; save them for reinstallation. Set the crt on a soft material to prevent scratching.

Cathode-ray Tube Installation

1. Position the crt rear-support (plastic centering bracket) inside the crt shield approximately 1-1/2-inches from the rear of the shield.

2. Check that the plastic corner-pads are in place and seated at the front corners of the crt opening.

3. Insert the crt into the shield. Guide the crt anode lead through the hole in the shield.

4. Slowly push the crt the rest of the way into the crt shield. If the crt does not go in all the way, pull it part way out and find the reason for binding. It may be necessary to reposition the rear-support bracket or a plastic corner-pad for best installation.

5. Clean the crt faceplate, implosion shield and bezel as directed under Cleaning—Exterior information at the beginning of this section and install the parts. Lightly tighten the four bezel screws (approximately 5-inch pounds).

6. Connect the crt base socket, install the crt rear cover with two round-head screws and install the blue-plastic cover on the rear of the instrument with two flat-head screws.

 Connect the crt anode lead and carefully connect the deflection plate leads. After each lead is connected, lightly pull on the lead to be sure that it will remain in place.

8. 475A DM44 only—Install the DM44 main circuitboard chassis on the 475A chassis. Install two screws at the rear of the main circuit-board chassis and connect three ribbon-cables to the board.

9. If the crt was replaced, part of the 475A calibration will need to be checked or adjusted. See Table 4-5 under Recalibration After Repair (later in this section) for a listing of calibration checks and adjustments that need to be checked after crt replacement.

High-Voltage Multiplier Removal

1. Remove the Vertical Preamp circuit-board as outlined previously.

2. Remove the cathode-ray tube as outlined previous-ly.

3. Remove the high-voltage shield from the Main Interface circuit-board and remove one screw near the INTENSITY potentiometer.

4. Remove four hexagonal posts, used to mount the high-voltage shield, from the Main Interface board with a 3/16-inch nut-driver.

5. Remove the two nylon nuts from the Main Interface board near C1328.

6. Remove three screws holding the multiplier shield to the main chassis and remove the shield.

7. Unsolder the black wire from the Multiplier at the Main Interface board.

8. Unsolder one wire from a post on the High-Voltage Multiplier.

9. Unsolder the flexible grounding-braid from the case of integrated circuit U470 (on the Vertical Output board), using a 40 to 60-Watt soldering iron.

10. Remove one screw that holds the crt neck shield to the black-plastic rear bracket.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tre:: Rd: Chinnor Oxon CY9 4QY Tel:-01844-351694 Env:: 01844-352564 Email:- enquirise@mauritron.co.uk

11. Hold the crt base socket away from the neck shield and slide the shield to the rear of the instrument about 2 inches.

12. Pry the Multiplier jack from its mounting clip on the main chassis.

13. Remove the High-Voltage Multiplier. If necessary, carefully pry the Main Interface board away for easier removal and guide the Multiplier jack through the main chassis.

14. To install the High-Voltage Multiplier, reverse the removal procedure. Use the Cathode-ray Tube Installation procedure for installing the crt.

Delay Line Removal

1. Remove the cathode-ray tube as outlined previously.

2. Disconnect a two-wire cable near the rear of the INTENSITY control (cable from y-axis alignment coil).

3. Remove a screw connecting a solder lug and heavy braid from the Vertical Output board at the crt neck shield.

4. Remove one screw that holds the crt neck shield to the black-plastic rear bracket.

5. Hold the crt base socket away from the neck shield and remove the crt neck shield through the main chassis rear opening, using care to guide the y-axis coil cable through the board and chassis holes.

6. Remove the Keps nut and delay-line bracket holding the Delay Line to the main chassis.

7. Disconnect the Delay Line ends at the Vertical Preamp and Vertical Output boards. This may require the use of a soldering iron (a 40 to 60-Watt iron works best). 8. Remove the Delay Line, using care to guide the delay Line ends through the main chassis holes without causing sharp bends in the line.

To install the Delay Line, reverse the removal procedure. Use the Cathode-ray Tube Installation procedure for installing the crt.

Recalibration After Repair

After any electrical component has been replaced, the calibration of that particular circuit should be checked, as well as the calibration of other closely related circuits. Table 4-5 lists the adjustments that may interact with a repair in a particular circuit. The table is also useful as a list of calibration adjustments that should be checked if an adjustment is made when performing the Calibration procedure. Perform a calibration check of each interaction, using the appropriate step in the Calibration procedure found in Section 6 of this manual.

Instrument Repackaging

If the Tektronix instrument is to be shipped to a Tektronix Service Center for service or repair, attach a tag showing: owner (with address) and the name of an individual at your firm that can be contacted. Include complete instrument serial number and a description of the service required.

Save and re-use the package in which your instrument was shipped. If the original packaging is unfit for use or not available, repackage the instrument as follows:

Surround the instrument with polyethylene sheeting to protect the finish of the instrument. Obtain a carton of corrugated cardboard of the correct carton strength and having inside dimensions of no less than six inches more than the instrument dimensions. Cushion the instrument by tightly packing three inches of dunnage or urethane foam between carton and instrument, on all sides. Seal carton with shipping tape or industrial stapler.

The carton test strength for your instrument is 275 pounds.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk ŧ

		-	_				_																					
2 CALIBRATION PROCEDURE ADJUSTMENTS TO BE MADE FOR INTERACTION 1 AREA REPAIRED OR ADJUSTED	POWER SUPPLY DC LEVELS	HIGH VOLTAGE POWER SUPPLY	CRT GRID BIAS	CRT TRACE ROTATION	CRT Y-AXIS ALIGNMENT	GEOMETRY	Z-AXIS COMPENSATION	VERTICAL OUTPUT BIAS	VERTICAL SHIELD VOLTAGE	DELAY-LINE DC CENTER	CH 1 OR CH 2 VAR VOLTS/DIV BALANCE	CH 1 OR CH 2 VOLTS/DIV BALANCE	CH 1 OR CH 2 POSITION CENTERING	VERTICAL OUTPUT GAIN	CH 1 OR CH 2 GAIN	(VERTICAL) HIGH-FREQ. COMPENSATION	VERTICAL TRANSIENT RESPONSE	A OR B TRIGGER SENS, SYMM AND CTRG	A TRIGGER DC CENTERING	TRIGGER VIEW CENTERING	HORIZONTAL GAIN	INTENSIFIED GAIN	DELAY START AND DELAY STOP	MAGNIFIED REGISTRATION	A TIMING	X GAIN	X-Y PHASE DIFFERENCE	CALIBRATOR OUTPUT AMPLITUDE
LOW VOLTAGE POWER SUPPLY			-								-		-	-			-		-	-				_				
HIGH VOLTAGE POWER SUPPLY												+				-+												
Z-AXIS AMPLIFIER CIRCUIT				-												-+				-								-
TRACE ROTATION										-				-+		-+												
CRT Y-AXIS ALIGN														\dashv				\neg					-			-		
GEOMETRY	┢┤													I		-†			-							-		
VERTICAL PREAMP CIRCUIT																				-								-
VERTICAL OUTPUT AMPLIFIER CIRCUIT													٦															-
VERTICAL CHANNEL SWITCHING CIRCUIT																		-										-
VERTICAL OUTPUT BIAS	\square																	_		-								1
VERTICAL SHIELD VOLTAGE	Π																											٦
DELAY-LINE DC CENTER														T		-									-	_		1
CH 1 OR CH 2 VAR VOLTS/DIV BALANCE				-																								
CH 1 OR CH 2 VOLTS/DIV BALANCE																												-
VERTICAL OUTPUT GAIN	\square																											٦
CH 1 OR CH 2 GAIN	\square												1															٦
VERTICAL TRANSIENT RESPONSE																							-					1
TRIGGER GENERATOR CIRCUIT																												
A OR B TRIGGER SENS, SYMM AND CTRG												T			1	-†												
A TRIGGER DC CENTERING																_†												
HORIZONTAL AMPLIFIER CIRCUIT																												
HORIZONTAL GAIN																												
SWEEP GENERATORS CIRCUIT																T												
SWEEP AND Z-AXIS LOGIC CIRCUIT																												J
A TIMING													T				Τ									1		
XGAIN													1		1	-1	1											
X-Y PHASE DIFFERENCE																												
CRT CHANGE																												

CALIBRATION INTERACTION AFTER REPAIR OR ADJUSTMENT

TABLE 4-5

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax- 01844-352554 Email:- enquines@mauritron.co.uk

RACKMOUNTING

Introduction

The TEKTRONIX R475A Oscilloscope is designed to mount in a 19-inch rack. When mounted in accordance with the following mounting procedure, the instrument will meet all electrical and environmental characteristics given in Section 1.

Clearance Requirements

Figure 4-17 is a dimensional drawing showing the assembled Rack Adapter and instrument. At least 7 inches of vertical space is required to mount the instrument (with attached Adapter) into an equipment rack. Minimum width of the opening between the left and the right front rails in the rack must be 17 5/8 inches. Total depth of the rack must be at least 18 inches. These clearances will allow sufficient space for air circulation and for accommodation of the power cord and mounting hardware.

Slide-Out Tracks

The slide-out tracks provided with the R475A permit it to be extended out of the rack for maintenance or calibration without removing the instrument from the rack. In the fully extended position, the R475A can be tilted up so the bottom of the instrument can be reached for maintenance or calibration. To operate the R475A in the extended position, be sure the power cord and any interconnecting cables are long enough for this purpose.



During rackmount installation, interchanging the left and right slide-out track assemblies defeats the extension stop (safety latch) feature of the tracks. Equipment could, when extended, come out of the slides and fall from the rack, possibly causing personal injury and equipment damage.

When mounting the supplied slide-out tracks, inspect both assemblies to find the LH (left hand) and RH (right hand) designations to determine correct placement. Install the LH assembly to your left side as you face the front of the rack and install the RH assembly to your right side. Refer to the rackmounting instructions in this manual for complete information.

The slide-out tracks consist of two assemblies—one for the left side of the instrument and one for the right side. Fig. 4-7 shows the complete slide-out track assemblies. The stationary section of each assembly attaches to the front and rear rails of the rack, and the chassis section is attached to the instrument. The intermediate section slides between the stationary and chassis sections and allows the R475A to be extended out of the rack. When the instrument is shipped, the stationary and immediate sections of the tracks are packaged as matched sets and should not be separated. To identify the left or right assembly, note the position of the automatic latch (see Fig. 4-7). When mounted in the rack, the automatic latch should be at the top of both assemblies. The chassis sections are installed on the instrument at the factory.

The hardware needed to mount the slide-out tracks is shown in Fig. 4-8. Since the hardware supplied is intended to make the tracks compatible with a variety of cabinet racks and installation methods, not all of it will be needed for this installation. Use only the hardware that is required for the mounting method used.

Mounting Procedure

The following mounting procedure uses the rear support kit (see Fig. 4-12 and Fig. 4-13) to meet the environmental characteristics of the instrument (shock and vibration). Two alternative mounting methods are described at the end of this procedure. However, when mounted according to these alternative methods, the instrument may not meet the given environmental characteristics for shock and vibration.

The mounting flanges of the stationary sections may be mounted in front of or behind the front rails of the rack depending on the type of rack. If the front rails of the rack are tapped for 10-32 screws, the mounting flanges are placed in front of the rails. If the front rails of the rack are not tapped for 10-32 screws, the mounting flanges are placed behind the front rail and a bar nut is used. Fig. 4-11 shows these methods of mounting the stationary sections.

The rear of the stationary sections must be firmly supported to provide a shock-mounted installation. This rear support must be located 17.471 inches, ± 0.031 inch, from the outside surface of the front rail when the mounting flange is mounted outside of the rail, or 17.531 inches, ± 0.031 inch, from the rear surface of the front rail when the mounting flange is mounted behind the front rail. If the cabinet rack does not have a strong supporting member located the correct distance from the front rail, an additional support must be added. The instrument will not meet the environmental specifications unless firmly supported at this point. Fig. 4-11 illustrates a typical rear installation using the rear support kit and gives the necessary dimensions.

Use the following procedure to install the R475A in a rack:

1. Select the proper front-rail mounting holes for the stationary section using the measurements shown in Fig. 4-11.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquirite@mauritron.co.uk 2a. If the mounting flanges of the stationary sections are to be mounted in front of the front rails (rails tapped for 10-32 screws), mount each stationary section as shown in Fig. 4-10A.

2b. If the mounting flanges of the stationary sections are to be mounted behind the front rails (rails not tapped for 10-32 screws), mount each stationary section as shown in Fig. 4-10B.

3. Attach an angle bracket to both rear rails of the rack through the spacer block, stationary section and into the rear rail of the rack. Note that the holes in the spacer block are not centered. Be sure to mount the block with the narrow edge toward the front of the rack; otherwise, the instrument may not slide all the way into the rack. Do not tighten the mounting screws. Fig. 4-12 shows the parts in the rear support kit and the order in which they are assembled.

4. Assemble the support pin to the angle bracket in the order shown in Fig. 4-12. Leave the spacer (washer) off, but install the neoprene washer.

5. Install a support block on each side of the instrument as shown in Fig. 4-13.

6. Refer to Fig. 4-14 to insert the instrument in the rack. Do not connect the power cord or install the securing screws until all adjustments have been made.

7. With the instruments pushed all the way into the rack, adjust the angle brackets so the neoprene washers on the support pins are seated firmly against the rear of the instrument and the support pins are correctly positioned in the support block on the rear of the instrument. Tighten all screws.

8. Pull the instrument partially out of the rack.

 Remove the neoprene washers from the support pins and place the spacers on the pins. Replace the neoprene washers.

10. Position the instrument so the pivot screws (widest part of the instrument) are approximately even with the front rails.

11. Adjust the alignment of the stationary sections according to the procedure outlined in Fig. 4-15. (If the rear alignment is changed, recheck the rear support pins for correct alignment.)

12. After the tracks operate smoothly, connect the power cord to the power source.

Maintenance—475A Service

13. Push the instrument all the way into the rack and secure it to the rack with the securing screws and washers as shown in Fig. 4-14.

NOTE

The securing screws are an important part of the shock-mounted installation. If the front rails are not tapped for the 10-32 securing screws, other means must be provided for securing the instrument to the rack.

Alternative Rear Mounting Methods

CAUTION

Although the following methods provide satisfactory mounting under normal conditions, they do not provide solid support at the rear of the instrument. If the instrument is subjected to severe shock or vibration when mounted using the following methods, it may be damaged.

An alternative method of supporting the rear of the instrument is shown in Fig. 4-16. The rear support brackets supplied with the instrument allow it to be mounted in a rack which has a spacing between the front and rear rails of 11 to 24 inches. Fig. 4-16A illustrates the mounting method if the rear rails are tapped for 10-32 screws, and Fig. 4-16B illustrates the mounting method if the rear rails are not tapped for 10-32 screws. The rear support kit is not used for this installation.

If the rack does not have a rear rail, or if the distance between the front and rear rails is too large, the instrument may be mounted without the use of the slide-out tracks. Fasten the instrument to the front rails of the rack with the securing screws and washers. This mounting method should be used only if the instrument will not be subjected to shock or vibration and if it is installed in a stationary location.

Removing or Installing the Instrument

After initial installation and adjustment of the slide-out tracks, the R475A can be removed or installed by following the instructions given in Fig. 4-14. No further adjustments are required under normal conditions.

Slide-Out Track Lubrication

The slide-out tracks normally require no lubrication. The special finish on the sliding surfaces provides permanent lubrication. However, if the tracks do not slide smoothly even after proper adjustment, a thin coating of paraffin rubbed onto the sliding surfaces may improve operation.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk



Fig. 4-7. Slide-out track assemblies.



Fig. 4-8. Hardware needed to mount the instrument in the cabinet rack.

4-36

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@

Ť



Fig. 4-9. Locating the mounting holes for the left stationary section. Same dimensions apply to right stationary section.



Fig. 4-10. Methods of mounting the stationary section to the front rails.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk



Fig. 4-11. Supporting the rear of the stationary sections: (A) Dimensions necessary; (B) Completed installation.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



Fig. 4-12. Rear Support kit.



Fig. 4-13. Installing the support block on the instrument.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



- 1. Pull the intermediate section (A) of each slide-out track out to its fully extended position.
- 2. Insert the chassis section (B) (on instrument) into the intermediate sections.
- 3. Press both stop latches (C) and push the instrument into the rack until the latches snap into the stop latch holes (D).
- 4. Connect the power cord to the power source.
- 5. Again press the stop latches (D) and push the instrument all the way into the rack.
- 6. To secure the R475A to the rack, insert the 4 securing screws (E), with finishing washers and tellon washers, through the slots in the instrument front panel and screw them into the front rails of the rack.

•

aa Hill

(C

(B)

(D

2 ာ ့ ေန

5

C

TO REMOVE THE R475A:

- 1. Remove the securing screws and washers (E).
- 2. Pull the instrument outward until the stop latches snap into the stop latch holes.
- 3. Disconnect the power cord.
- Press both stop latches (D) and pull the instru-ment out of the rack.

Fig. 4-14. Procedure for inserting or removing the instrument after the slide-out tracks have been installed.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

10000

(E)







Fig. 4-16. Alternative method of installing the instrument using rear support brackets.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



NOTES: 1. ALL DIMENSIONS ARE REFERENCE DIMENSIONS EXCEPT AS NOTED

ŧ



Fig. 4-17. Dimensional Drawing.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk 2102-51

@



2162-50

4-43

Fig. 4-17. Dimensional Drawing (cont).

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4OY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquines@mauritron.co.uk

@

PERFORMANCE CHECK

IMPORTANT-PLEASE READ BEFORE USING THIS PROCEDURE

Introduction

The following procedure is intended to be used for incoming inspection to determine the acceptability of newly purchased or recently recalibrated instruments. This procedure does not check every facet of the instrument's calibration; rather it is concerned primarily with those portions of the instrument that are essential to measurement accuracy and correct operation. Removing the instrument cabinet is not necessary to perform this procedure. All checks are made from the front panel. This procedure is also useful as an aid in troubleshooting and preventive maintenance.

Using This Procedure

Outline. To aid in locating a step in the Performance Check, an outline is given preceding the Performance Check procedure.

Partial Procedures. A partial check of performance is often desirable after replacing components or to verify performance of a portion of the instrument betwen major recalibrations. To check only part of the instrument, set the controls as given under the nearest preceding Control Settings and use the Equipment Required list preceding the desired portion of the procedure.

TEST EQUIPMENT REQUIRED

General

The following test equipment and accessories, or its equivalent, is required for a complete performance check of the 475A. Specifications given for the test equipment are the minimum necessary for accurate calibration. Therefore, some of the specifications listed here may differ from the actual performance capabilities of the test equipment. All test equipment is assumed to be correctly calibrated and operating within the listed specifications. Detailed operating instructions for the test equipment are not given in this procedure. Refer to the instruction manual for the test equipment if more information is needed. Minimum test equipment specifications must include the use of any special required accessories (such as the precision output cable included with the SG 503).

Special Calibration Fixtures

Special Tektronix calibration fixtures are used only where they facilitate checking instrument performance. These special calibration fixtures are available from Tektronix, Inc. Order by part number through your local Tektronix Field Office or representative.

Performance Check Equipment Alternatives

All of the listed test equipment is required to completely check this instrument. However, complete checking may not always be necessary or desirable. The user may be satisfied with checking only selected characteristics, thereby reducing the amount of test equipment actually required.

The equipment listed in the Performance Check Procedure is based on the first item of equipment given as an example of applicable equipment. When other equipment is substituted, control settings or equipment setups may need to be altered to meet the requirements of the substitute equipment. If the exact item of test equipment given as an example in the Test Equipment list is not available, first check the Specifications column carefully to see if any other equipment is available which might suffice. Then check the Usage column to see what this item is used for. If used for a check or adjustment that is of little or no importance to your measurement requirements, the item and corresponding step(s) can be deleted.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax-01844-352554 Email:-enquines@mauritron.co.uk

TABLE 5-1

Test Equipment Required For Performance Check

Description	Minimum Specifications		
1. Amplitude Calibra	ator Amplitude accuracy, within	Usage n Vertical checks. Trigger vie	Examples
	0.25%; signal amplitude, 2 millivolts to 20 volts; outpu signal, 1 kilohertz square wave.	dain check: External 7 A	bration Generator. ¹ b. Tektronix 067-0502-0
2. Sine-Wave Genera			calibration fixture.
2. Gine-wave Genera	ator Frequency, 350 kilohertz to above 250 megahertz; output amplitude, variable from 15 millivolts to 4 volts peak-to peak; output impedance, 50 ohms; reference frequency, 50 to 350 kilohertz; ampli- tude accuracy, constant with in 3% of reference frequency as output frequency changes	and isolation checks; Trigge checks; X bandwidth check.	h a. Tektronix SG 503 Level r Sine-Wave Generator. ¹ (U for all frequencies.) b. Tektronix Type 191 Constant-Amplitude Sign Generator. (Use at fre quencies of 100 megaher and below).
3. Time Mark O		>.	AND Wavetek Model 1001A (use only for checking 250 mega- hertz bandwidth and trig- gering).
	or Marker outputs, 2 nano- seconds to 0.5 second; marker accuracy, within 0.1%; trigger output, 1 milli- second to 0.1 microsecond, time coincident with markers	Horizontal timing checks.	a. Tektronix TG 501 Time- Mark Generator.' b. Tektronix 2901 Time- Mark Generator.
4. Low-Frequency Generator	Frequency, 10 Hertz to 50 kilohertz; output amplitude, variable from 10 millivolts to 4 volts peak-to-peak.	Low-frequency trigger checks	a. Tektronix SG 502 Oscil- lator. ¹ b. General Radio 1310 B Os- cillator with a binding post to BNC adapter.
. Cable (2 required)	Impedance, 50 ohms; length, 42 inches; connectors, BNC.	Used throughout procedure	a. Tektronix Part Number 012-0057-01.
Cable (2 required)	Impedance, 50 ohms; length 18 inches; connectors, BNC.	Used throughout procedure	a. Tektronix Part Number 012-0076-00.
50-Ohm Signal ckoff	Frequency response, 50 kilo- hertz to 875 megahertz; im- pedance, 50 ohms for signal input, signal output and trig- ger output.	ļ1	a. Tektronix CT-3 Signal Pickoff. Part Number 017-0061-00.
Adapter	Connectors, BNC Female to BNC Female.	Used throughout procedure a for signal interconnection.	. Tektronix Part Number 03-0028-00.

Requires a TM 500-Series Power Module.

TA	BLE	5-1	(cont)
----	-----	-----	--------

Description	Minimum Specifications	Usage	Examples
9. Adapter	Connectors, GR874 to BNC Female.	Trigger checks.	a. Tektronix Part Number 017-0063-00.
10. Adapter	Connectors, GR874 to BNC Male.	Used in Trigger System procedure for signal intercon nection.	a. Tektronix Part Number 017-0064-00.
11. Elbow Adapter	Connectors, BNC Male to BNC Female.	Used in Trigger System pro- cedure for signal intercon- nection.	a. Tektronix Part Number 103-0031-00.
12. T-Connector	Connectors, BNC	Used throughout procedure for signal interconnection.	a. Tektronix Part Number 103-0030-00.
13. 10X Attenuator	Ratio, 10X; impedance, 50 ohms; connectors, BNC	Vertical bandwidth check. Trigger checks.	a. Tektronix Part Number 011-0059-02
14. 5X Attenuator	Ratio, 5X; impedance, 50 ohms; connectors, BNC	Trigger checks.	a. Tektronix Part Number 011-0060-02
15. Termination (2 required)	Impedance, 50 ohms; con- nectors, BNC.	Used throughout procedure for proper signal termination.	a. Tektronix Part Number 011-0049-01.
16. 10X Probe	Scale-factor switching; con- nector, BNC.	brator check.	a. Tektronix P6075 Probe (supplied with 475A oscil- loscope).
· · · · · · · · · · · · · · · · · · ·			b. Tektronix P6065 Probe.
17. 500 MHz Filter	Impedance, 50 ohms; fre- quency, adjustable; con- nectors, BNC.	checks.	a. Tektronix 500 MHz Filter calibration fixture. Part Number 067-0684-00.
8. Screwdriver	Length, three-inch shaft; bit size, 3/32 inch.	Used to adjust TRACE ROTATION, ASTIG, GAIN.	a. Xcelite R-3323.

OUTLINE FOR PERFORMANCE CHECK

DISPLAY AND VERTICAL SYSTEM CH	IECK	5. Check ADD Mode Operation	Page 5-7
1. Check Display Controls	Page 5-5	6. Check ALT Mode Operation	Ū
2 Check Vertical Insut 5		6. Check ALT Mode Operation	5-7
2. Check Vertical Input Functions	5-6	7. Check CHOP Mode Operation	5-8
3. Check CH 1 and CH 2 Gain	5-6	8. Check Vertical Amplifier Bandwidth	5-8
4. Check CH 2 and CH 1 VAR VOLTS/DIV	J	9. Check Bandwidth Limit Operation	5-8
Range	5-7	10. Check Cascaded Bandwidth	5-8

@

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax- 01844-352554 Email:- enquiries@mauritron.co.uk

TRIGGER SYSTEM CHECK

11. Check A Low-Frequency Triggering	Page 5-9	23. Check A INTEN Timing Accuracy	Page 5
12. Check B Low-Frequency Triggering	5-11	24. Check A INTEN Magnified Timing Ac- curacy	900
13. Check B 40 Megahertz Triggering	5-12		5-
14. Check A 40 Megahertz Triggering	5-12	25. Check A Magnified Timing Accuracy 26. Check Differential Date	5-
15. Check A 250 Megahertz Triggering	5-13	26. Check Differential Delay Time Ac- curacy	5 - -
16. Check B 250 Megahertz Triggering	5-13	27. Check Delay Time Jitter	5-1
17. Check TRIG MODE NORM Operation	5-14	28. Check MIX (Mixed Sweep) Timing Ac- curacy	
18. Check TRIG MODE SINGL SWP Operation		29: Check X Gain	5-1
19. Check TRIG VIEW Operation	5-14	30. Check X Bandwidth	5-1{
DM44 DIGITAL MULTIMETER	5-14		5-19
INSTRUCTIONS	5-15		
HORIZONTAL SYSTEM CHECK 20. Check VAR TIME/DIV RANGE		GATE OUTPUTS, EXTERNAL Z-AXIS AND CALIBRATOR CHECKS	
	5-15	31. Check A and B +GATE Outputs	5-19
21. Check Sweep Length and Horizontal POSITION Range	5-16	32. Check CH 2 VERT SIGNAL OUT	5-20
22. Check A Timing Accuracy	5-16	33. Check EXT Z-Axis Operation	5-20
	0-10	34. Check CALIBRATOR Operation	5-20

PRELIMINARY PROCEDURE FOR PERFORMANCE CHECK

Operating Voltage

Before applying power to the instrument, check that the line voltage selector and the regulating range selector are in the correct positions for the line voltage the instrument will be operated on.

Power Source

Connect the 475A to a power source that meets the voltage and frequency requirements of this instrument.

5-4

Warm Up

Turn on the 475A and allow at least 20 minutes before starting the Performance Check procedure.

Operating Temperature

The performance of this instrument can be checked at an ambient temperature within -15°C to +55°C unless stated otherwise in the procedure. This instrument should be checked at an ambient temperature of $\pm 20^{\circ}$ C to $\pm 30^{\circ}$ C for best overall accuracy.

For Service Manuals Contact **MAURITRON TECHNICAL SERVICES** 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

DISPLAY AND VERTICAL SYSTEM CHECK

Equipment Required	6. 10X BNC Attenuator
1. Amplitude Calibrator	
2. Sine-Wave Generator	7. 50-Ohm BNC Termination (2 required)
3. 42-inch 50-Ohm BNC Cable (2 required)	8. BNC Female-to-BNC Female Adapter
4. 18-inch 50-Ohm BNC Cable (2 required)	9. BNC T-Connector
5. 10X Probe (see Table 5-1, 10X Probe examples)	10. Screwdriver

Control Settings

POWER	ON
	Display
INTENSITY	Midrange
FOCUS	Midrange
SCALE ILLUM	Midrange

Vertical (CH 1 and CH 2)

POSITION	Midrange
VOLTS/DIV	10 m V
VAR VOLTS/DIV	Calibrated detent
AC-GND-DC	DC
INVERT	Off (button out)
VERT MODE	CH 1
100 or 20 MHz BW	20

Trigger (A and B)

COUPLING	AC
LEVEL	0
SLOPE	+
A TRIGGER SOURCE	NORM
B TRIGGER SOURCE	STARTS AFTER DELAY
TRIG MODE	AUTO
A TRIGGER HOLDOFF	NORM

Sweep

A TIME/DIV	1 ms
B TIME/DIV	1 ms
VAR TIME/DIV	Calibrated detent
DELAY TIME POSITION	Fully counterclockwise
HORIZ DISPLAY	A
X10 MAG	Off (button out)
POSITION (Horiz)	Midrange
FINE	Midrange

1. Check Display Controls

a. Turn the INTENSITY control through its range and return to a normal intensity setting.

b. CHECK-For control of trace intensity from minimum to maximum intensity.

c. Turn CH 1 POSITION through its range and return to a midrange setting.

d. CHECK---That the trace can be positioned over the entire graticule area.

e. Set VERT MODE to CH 2, turn CH 2 POSITION through its range and return to a midrange setting.

f. CHECK—That the trace can be positioned over the entire graticule area.

g. Return VERT MODE to CH 1 and position the trace to the center horizontal graticule line.

h. CHECK—That the trace is aligned with the center horizontal graticule line.

i. ADJUST-TRACE ROTATION (front panel screwdriver adjustment) to align the trace with the center horizontal graticule line.

j. Turn the SCALE ILLUM control through its range.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax-01844-352554 Email:-enquiries@mauritron.co.uk

k. CHECK—For control of graticule illumination from minimum to maximum settings.

I. Set the amplitude calibrator for a 50 millivolt output and connect to CH 1 input through a 42-inch 50-ohm BNC cable.

m. Set A TRIGGER LEVEL for a stable display.

n. CHECK-For well-defined focusing on front corners of the displayed waveform.

o. ADJUST-FOCUS control and ASTIG (front panel screwdriver adjustment) together for the best-defined front corners on the displayed waveform.

p. Turn INTENSITY fully counterclockwise and press BEAM FINDER pushbutton.

q. CHECK—For a compressed waveform of normal intensity, within graticule area.

r. Release BEAM FINDER pushbutton and return INTENSITY to a normal setting.

2. Check Vertical Input Functions

a. Position the bottom of CH 1 display to the center horizontal graticule line.

b. Set CH 1 AC-GND-DC switch to GND.

c. CHECK—For no vertical deflection and that trace is at center horizontal graticule line.

d. Set CH 1 AC-GND-DC switch to AC.

e. CHECK-That display is centered in graticule area.

f. Move test signal cable to CH 2 input and set VERT MODE to CH 2.

g. Position the bottom of CH 2 display to the center horizontal graticule line.

h. Set CH 2 AC-GND-DC switch to GND.

i. CHECK—For no vertical deflection and that trace is at center horizontal graticule line.

j. Set CH 2 AC-GND-DC switch to AC.

k. CHECK—That display is centered in graticule area.

I. Disconnect all test equipment.

m. CHECK—That the light under 10 mV of CH 2 VOLTS/DIV knob is on.

n. Connect a 10X probe with a scale-factor switching connector to CH 2 input.

NOTE

Use a probe listed in test equipment required, Table 5-1, under 10X Probe examples.

o. CHECK—That the light under 10 mV is extinguished and the light under .1 V comes on.

p. Set VERT MODE to CH 1.

q. CHECK—That the light under 10 mV of CH 1 VOLTS/DIV knob is on.

r. Move the 10X probe to CH 1 input.

s. CHECK—That the light under 10 mV is extinguished and the light under .1 V comes on.

t. Remove the 10X probe.

3. Check CH 1 and CH 2 GAIN

a. Set the amplitude calibrator for a 50 millivolt output and connect to CH 1 input through a 42-inch 50-ohm BNC cable.

b. Set CH 1 and CH 2 AC-GND-DC switches to DC.

c. CHECK-The display for 5 divisions of amplitude.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk d. ADJUST-CH 1 GAIN, 10 mV adjustment, through the upper 10 mV access hole at left side of cabinet for 5 divisions of amplitude.

e. CHECK—All settings of CH 1 VOLTS/DIV for accuracy, within 3%, using the settings listed in Table 5-2.

	TABLE 5-2
Vertical	Deflection Accuracy

VOLTS/DIV Switch Setting	Amplitude Calibrator Output	Vertical Deflection in Divisions	Maximum Error for 3% Accuracy
5 mV	20 millivolts	4	Previously set
10 mV	50 millivolts	5	±0.15 div
20 mV	0.1 volt	5	±0.15 div
50 mV	0.2 volt	4	±0.12 div
0.1 V	0.5 volt	5	±0.15 div
0.2 V	1 volt	5	±0.15 div
0.5 V	2 volts	4	\pm 0.12 div
<u> </u>	5 volts	5	\pm 0.15 div
2 V	10 volts	5	±0.15 div
5 V	20 volts	4	±0.12 div
10 V	50 volts	5	±0.15 div

f. Set VERT MODE to CH 2, set amplitude calibrator for a 50 millivolt output and move signal cable to CH 2 input.

g. CHECK-The display for 5 divisions of amplitude.

h. ADJUST-CH 2 GAIN, 10 mV adjustment, through the lower 10 mV access hole at left side of cabinet for 5 divisions of amplitude.

i. CHECK—All settings of CH 2 VOLTS/DIV for accuracy, within 3%, using the settings listed in Table 5-2.

4. CHECK CH 2 and CH 1 VAR VOLTS/DIV Range

a. Set the amplitude calibrator to 50 millivolts and set CH 1 and CH 2 VOLTS/DIV to 10 mV.

b. Turn CH2VAR VOLTS/DIV fully counterclockwise.

c. CHECK—That the CH 2 UNCAL light turns on when the CH 2 VAR VOLTS/DIV control is out of calibrated detent.

d. CHECK—That display amplitude reduces to 2 divisions or less.

e. Return CH 2 VAR VOLTS/DIV to calibrated detent.

f. Set VERT MODE to CH 1 and move signal cable to CH 1 input.

g. Turn CH 1 VAR VOLTS/DIV fully counterclockwise.

h. CHECK—That the CH 1 UNCAL light turns on when the CH 1 VAR VOLTS/DIV control is out of calibrated detent.

i. CHECK-That display amplitude reduces to 2 divisions or less.

j. Return CH 1 VAR VOLTS/DIV to calibrated detent.

5. Check ADD Mode Operation

a. Set VERT MODE to ADD and set CH 1 and CH 2 VOLTS/DIV to 10 mV.

b. Remove the test signal cable from CH 1 input. Connect to the cable: a BNC female-to-BNC female adapter, a BNC T-connector, two 18-inch 50-ohm BNC cables and connect the cables to CH 1 and CH 2 inputs.

c. Set the amplitude calibrator for a 20 millivolt output and center the display on graticule using equal settings of CH 1 and CH 2 POSITION controls.

d. CHECK—For a display of 4 divisions, within 3% (0.12 division).

e. Press INVERT pushbutton.

f. CHECK—That display amplitude reduces to approximately 0.

g. Return INVERT pushbutton to normal (button out).

h. Disconnect all test equipment.

6. Check ALT Mode Operation

a. Set VERT MODE to ALT, set 100 OR 20 MHz BW control to full bandwidth position and set A TRIGGER LEVEL fully clockwise.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

b. Position the 2 traces approximately 4 divisions apart.

c. CHECK—That the traces alternate at all settings of TIME/DIV except X-Y.

7. Check CHOP Mode Operation

a. Set VERT MODE to CHOP, set TIME/DIV to 1 μ s, set CH 1 and CH 2 AC-GND-DC switches to GND and adjust A TRIGGER LEVEL for a stable display.

b. CHECK—For complete blanking of switching transients between chopped segments.

c. CHECK—That the duration of 1 cycle is approximately 1 division.

8. Check Vertical Amplifier Bandwidth

a. Set VERT MODE to CH 1, set TIME/DIV to 0.5 ms and set CH 1 and CH 2 AC-GND-DC switches to DC.

NOTE

See test equipment required. Table 5-1, for selection of sine-wave generator with a 250 megahertz output.

b. Connect the sine-wave generator output cable to a 10X BNC attenuator, to a 50-ohm termination, to CH 1 input.

c. Set the sine-wave generator for a 6 division display of reference frequency. (It may be necessary to insert more attenuation to reduce display amplitude.)

NOTE

If generator has no reference frequency setting, set for 5 megahertz.

d. Without changing the generator output amplitude, increase the output frequency until the display is reduced to 4.2 divisions.

e. CHECK—For a generator frequency reading of 250 megahertz or more.

f. Set VERT MODE to CH 2 and move test signal setup to CH 2 input.

g. CHECK-Repeat the bandwidth check procedure, parts c, d and e.

9. Check Bandwidth Limit Operation

a. Set 100 OR 20 MHz BW control to 100.

NOTE

It may be necessary to change sine-wave generators. See test equipment required, Table 5-1 for selection of generator with an output of 100 megahertz and below.

 b. Set the sine-wave generator for a 6 division display of reference frequency.

c. Without changing the generator output amplitude, increase the output frequency until the display is reduced to 4.2 divisions.

d. CHECK—For a generator reading of approximately 100 megahertz.

e. Set 100 OR 20 MHz BW control to 20.

f. Set the sine-wave generator for a 6 division display of reference frequency.

g. Without changing the generator output amplitude, increase the output frequency until the display is reduced to 4.2 divisions.

h. CHECK—For a generator reading of approximately 20 megahertz.

i. Return 100 OR 20 MHz BW control to full bandwidth.

10. Check Cascaded Bandwidth

a. Set VERT MODE to CH 1.

b. Connect CH 2 VERT SIGNAL OUT (output connector on rear panel) through a 42-inch 50-ohm BNC cable, to a 50-ohm termination and connect to CH 1 input.

c. Set the sine-wave generator for a 6 division display of reference frequency.

d. Without changing the generator output amplitude, increase the output frequency until the display is reduced to 4.2 divisions.

- e. CHECK—For a reading of 50 megahertz or more.
- f. Disconnect all test equipment.

TRIGGER SYSTEM CHECK

Equipment Required	8. GR-To-BNC Male Adapter
1. Sine-Wave Generator	
2. Low-Frequency Generator	9. BNC Female-To-BNC Female Adapter
3. Amplitude Calibrator	10. BNC Elbow
4. 50-Ohm Signal Pickoff	11. BNC T-Connector
5. 42-Inch 50-Ohm BNC Cable	12. 10X BNC Attenuator
6. 18-Inch 50-Ohm BNC Cable (2 required)	13. 5X BNC Attenuator
7. GR-To-BNC Female Adapter	14. 50-Ohm BNC Termination (2 required)

Control Settings

Control Settings		Sweep	
POWER	ON	A TIME/DIV B TIME/DIV	50 μ s (new setting) 50 μ s (new setting)
	Display	VAR TIME/DIV DELAY TIME POSITION	Calibrated detent Fully counterclockwise
INTENSITY FOCUS SCALE ILLUM	Midrange Midrange Midrange	HORIZ DISPLAY X10 MAG POSITION (Horiz) FINE	A Off (button out) Midrange Midrange

Vertical (CH 1 and CH 2)

POSITION VOLTS/DIV VAR VOLTS/DIV AC-GND-DC INVERT	Midrange 5 mV Calibrated detent DC
VERT MODE 100 OR 20 MHz BW	Off (button out) CH 1 Full bandwidth (push in, then release)

Trigger (A and B)

COUPLING	AC
LEVEL	0
SLOPE	+
A TRIGGER SOURCE	NORM
B TRIGGER SOURCE	NORM (new setting)
TRIG MODE	AUTO
A TRIGGER HOLDOFF	NORM

11. Check A Low-Frequency Triggering

a. Connect the low-frequency generator output to a 42-inch 50-ohm BNC cable, to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch 50ohm BNC cables, to CH 1 input and A TRIGGER external input.

b. Set the low-frequency generator for a 5 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

c. CHECK-That a stable triggered display can be obtained in AC, LF REJ, HF REJ and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

d. Set CH 1 VOLTS/DIV to 5 mV.

e. Set the low-frequency generator for a 3 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

f. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

g. Set the low-frequency generator for a 2 division, 50 kilohertz display, then set A TRIGGER SOURCE to EXT (100 millivolts at external input).

h. CHECK-Repeat part c.

i. Set CH 1 VOLTS/DIV to 0.1 V and set A TRIGGER SOURCE to EXT \div 10.

j. Set the low-frequency generator for a 5 division, 50 kilohertz display (500 millivolts at inputs), then set CH 1 VOLTS/DIV to 0.5 V.

k. CHECK-Repeat part f.

I. Set CH 1 VOLTS/DIV to 10 mV and set A TRIGGER SOURCE to EXT.

m. Set the low-frequency generator for a 5 division, 50 kilohertz display (50 millivolts at external input), then set CH 1 VOLTS/DIV to 50 mV.

n. CHECK-Repeat part f.

o. Set A TRIGGER SOURCE to NORM, set CH 1 VOLTS/DIV to 5 mV, set TIME/DIV to 10 ms and set 100 OR 20 MHz BW control to 20.

p. Set the low-frequency generator for a 5 division,
60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

q. CHECK—That a stable triggered display can be obtained in DC, HF REJ and AC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

r. Set A TRIGGER COUPLING to LF REJ.

s. CHECK—That a stable triggered display cannot be obtained with adjustment of A TRIGGER LEVEL.

t. Set CH 1 VOLTS/DIV to 5 mV and set A TRIGGER COUPLING to AC.

u. Set the low-frequency generator for a 3 division, 60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

v. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

w. Set the low-frequency generator for a 2 division, 60 Hertz display, then set A TRIGGER SOURCE to EXT (100 millivolts at external input).

x. CHECK-Repeat part q.

y. Set A TRIGGER COUPLING to LF REJ.

z. CHECK-Repeat part s.

aa. Set A TRIGGER COUPLING to AC.

ab. Set the low-frequency generator for a 1 division, 60 Hertz display (50 millivolts at external input).

ac. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

ad. Disconnect all test equipment.

NOTE

Use a sine-wave generator with an output of 100 megahertz and below for the following parts.

ae. Connect the sine-wave generator output cable to a BNC female-to-BNC female adapter, to a BNC Tconnector, to two 18-inch 50-ohm BNC cables. Connect an 18-inch cable through a 50-ohm termination to CH 1 input and connect the other 18-inch cable through a 50ohm termination to A TRIGGER external input.

af. Set TIME/DIV to 0.5 µs.

ag. Set the sine-wave generator for a 2 division, 3 megahertz display (100 millivolts at external input).

ah. Set A TRIGGER COUPLING to HF REJ.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

ai. CHECK—That a stable triggered display cannot be obtained with adjustment of A TRIGGER LEVEL.

aj. Set CH 1 VOLTS/DIV to 5 mV, set TIME/DIV to 2 μs and set A TRIGGER SOURCE to NORM.

ak. Set the sine-wave generator for a 5 division, 1 megahertz display, then set CH 1 VOLTS/DIV to 50 mV.

al. CHECK-Repeat part ai.

am. Return A TRIGGER COUPLING to AC.

an. Disconnect all test equipment.

12. Check B Low-Frequency Triggering

a. Set TIME/DIV to 50 μ s, set CH 1 VOLTS/DIV to 5 mV and set HORIZ DISPLAY to B DLY'D. (B DLY'D sweep will not appear when not triggered).

b. Connect the low-frequency generator output to a 42-inch 50-ohm BNC cable, to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch 50-ohm BNC cables, to CH 1 input and B TRIGGER external input.

c. Set the low-frequency generator for 50 kilohertz, then set the generator for a 5 division display and set CH 1 VOLTS/DIV to 50 mV.

d. CHECK—That a stable triggered display can be obtained in AC, LF REJ, HF REJ and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

e. Set CH 1 VOLTS/DIV to 5 mV.

f. Set the low-frequency generator for a 3 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

g. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

h. Set the low-frequency generator for a 2 division, 50 kilohertz display, then set B TRIGGER SOURCE to EXT (100 millivolts at external input).

i. CHECK-Repeat part d of this step.

j. Set CH 1 VOLTS/DIV to 10 mV.

k. Set the low-frequency generator for a 5 division, 50 kilohertz display (50 millivolts at external input), then set CH 1 VOLTS/DIV to 50 mV.

I. CHECK-Repeat part g.

m. Set B TRIGGER SOURCE to NORM, set CH 1 VOLTS/DIV to 5 mV and set TIME/DIV to 10 ms.

n. Set the low-frequency generator for a 5 division, 60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

o. CHECK—That a stable triggered display can be obtained in HF REJ, DC and AC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

p. Set B TRIGGER COUPLING to LF REJ.

q. CHECK—That a stable triggered display cannot be obtained with adjustment of B TRIGGER LEVEL.

r. Set CH 1 VOLTS/DIV to 5 mV and set B TRIGGER COUPLING to AC.

s. Set the low-frequency generator for a 3 division, 60 hertz display, then set CH 1 VOLTS/DIV to 50 mV.

t. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

u. Set the low-frequency generator for a 2 division, 60 hertz display, then set B TRIGGER SOURCE to EXT (100 millivolts at external input).

v. CHECK-Repeat part o.

- w. Set B TRIGGER COUPLING to LF REJ.
- x. CHECK-Repeat part q.
- y. Set B TRIGGER COUPLING to AC.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Ernail:- enquiries@mauritron.co.uk
z. Set the low-frequency generator for a 1 division, 60 Hertz display (50 millivolts at external input). (It may be necessary to maintain triggering as amplitude is reduced.)

aa. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

ab. Disconnect all test equipment.

NOTE

Use a sine-wave generator with an output of 100 megahertz and below for the following parts.

ac. Connect the sine-wave generator output cable to a BNC female-to-BNC female adapter, to a BNC Tconnector, to two 18-inch 50-ohm BNC cables. Connect an 18-inch cable through a 50-ohm termination to CH 1 input and connect the other 18-inch cable through a 50ohm termination to B TRIGGER external input.

ad. Set TIME/DIV to 0.5 μs and set B TRIGGER SOURCE to STARTS AFTER DELAY.

ae. Set the sine-wave generator for a 2 division, 3 megahertz display (100 millivolts at external input).

af. Set B TRIGGER COUPLING to HF REJ and set B TRIGGER SOURCE to EXT.

ag. CHECK—That a stable triggered display cannot be obtained with adjustment of B TRIGGER LEVEL.

ah. Set CH 1 VOLTS/DIV to 5 mV, set TIME/DIV to 2 μ s and set B TRIGGER SOURCE to STARTS AFTER DELAY.

ai. Set the sine-wave generator for a 5 division, 1 megahertz display, then set CH 1 VOLTS/DIV to 50 mV, and set B TRIGGER SOURCE to NORM.

aj. CHECK-Repeat part ag.

ak. Set B TRIGGER COUPLING to AC and set B TRIGGER SOURCE to STARTS AFTER DELAY.

13. Check B 40 Megahertz Triggering

a. Set TIME/DIV to 0.05 μ s and set 100 OR 20 MHz BW to full bandwidth (push in, then release).

5-12

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquirites@mauritron.co.uk b. Set the sine-wave generator for a 1 division, 40 megahertz display, then set B TRIGGER SOURCE to EXT (50 millivolts at external input).

c. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

d. Set B TRIGGER SOURCE to NORM, set CH 1 VOLTS/DIV to 5 mV, set CH 2 VOLTS/DIV to 50 mV and move signal cable setup from B TRIGGER external input to CH 2 input.

e. Set the sine-wave generator for a 3 division, 40 megahertz display, set CH 1 VOLTS/DIV to 50 mV, retrigger if necessary, then set the display to graticule center with CH 1 POSITION.

f. Set VERT MODE to CH 2 and move the display to graticule center with CH 2 POSITION. (Retrigger if necessary.)

g. Return VERT MODE to CH 1.

h. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

i. Return B TRIGGER COUPLING to AC.

j. CHECK—That a stable triggered display can be obtained in NORM, CH 1 and CH 2 positions of B TRIGGER SOURCE with adjustment of B TRIGGER LEVEL.

k. Return B TRIGGER SOURCE to NORM.

14. Check A 40 Megahertz Triggering

a. Set HORIZ DISPLAY to A and check that A TRIGGER SOURCE is in NORM and A TRIGGER COUPLING is in AC.

b. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

c. Return A TRIGGER COUPLING to AC.

d. CHECK—That a stable triggered display can be obtained in CH 1 and CH 2 positions of A TRIGGER SOURCE with adjustment of A TRIGGER LEVEL.

e. Return A TRIGGER SOURCE to NORM and move test signal cable from CH 2 input to A TRIGGER external input.

f. Set the sine-wave generator for a 1 division, 40 megahertz display, then set A TRIGGER SOURCE to EXT.

g. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

h. Return A TRIGGER SOURCE to NORM and A TRIGGER COUPLING to AC.

i. Disconnect all test equipment.

15. Check A 250 Megahertz Triggering

NOTE

It may be necessary to change to a sine-wave generator with a 250 megahertz output.

Trigger jitter is measured horizontal trace excursion minus normal horizontal trace width observed at low frequency.

a. Connect the sine-wave generator output cable through a GR-to-BNC female adapter to the through signal input of the 50-ohm signal pickoff. Connect the through signal output of the signal pickoff to a GR-to-BNC male adapter, to a 10X BNC attenuator, to a 50-ohm BNC termination, to a BNC elbow, to A TRIGGER external input.

b. Connect the 10% signal output of the signal pickoff to an 18-inch 50-ohm BNC cable, to a 50-ohm termination, to CH 1 input.

c. Set the sine-wave generator for a 2.0 division, 250 megahertz display.

d. Set TIME/DIV to 0.01 μs and press X10 MAG to on.

e. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC, LF REJ and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

f. Set TIME/DIV to 0.1 ms and set A TRIGGER SOURCE to EXT.

g. Set the sine-wave generator for a 5 division display of reference frequency (250 millivolts at external input), then set to 250 megahertz.

NOTE

If generator has no reference frequency setting, set for 5 megahertz.

h. Set TIME/DIV to 0.01 µs.

i. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

j. Replace the 10X BNC attenuator in test signal setup with a 5X BNC attenuator (500 millivolts at external input) and set A TRIGGER COUPLING to LF REJ.

k. CHECK-That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A TRIGGER LEVEL.

16. Check B 250 Megahertz Triggering

a. Move test signal setup from A TRIGGER external input to B TRIGGER external input.

b. Set A TRIGGER SOURCE to NORM, set A TRIGGER COUPLING to AC, set HORIZ DISPLAY to B DLY'D, set B TRIGGER SOURCE to EXT and set B TRIGGER COUPLING to LF REJ.

c. CHECK--That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A and B TRIGGER LEVEL controls.

d. Replace the 5X BNC attenuator with a 10X BNC attenuator (250 millivolts at external input).

e. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of A and B TRIGGER LEVEL controls.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax-01844-352554 Email:-enquiries@mauritron.cu.uk 5-13

f. Set B TRIGGER SOURCE to STARTS AFTER DELAY and set TIME/DIV to 1 $\mu s.$

g. Set the sine-wave generator for a 2.0 division, 250 megahertz display.

h. Set B TRIGGER SOURCE to NORM and set TIME/DIV to 0.01 $\mu s.$

i. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC, LF REJ, and DC positions of B TRIGGER COUPLING with adjustment of A and B TRIGGER LEVEL controls.

j. Disconnect all test equipment.

17. Check TRIG MODE NORM Operation

a. Set HORIZ DISPLAY to A, set TIME/DIV to 1 ms, set X10 MAG to off (button out), set INTENSITY, if necessary, for a convenient trace intensity and set B TRIGGER COUPLING to AC.

b. Set the amplitude calibrator for a 50 millivolt output and connect to CH 1 input through a 42-inch 50-ohm BNC cable.

c. Set A TRIGGER LEVEL for a stable triggered display.

d. Set TRIG MODE to NORM.

- e. CHECK-For a stable triggered display.
- f. Remove the test signal from CH 1 input.
- g. CHECK-For no visible trace.

5-14

- 18. Check TRIG MODE SINGL SWP Operation
 - a. Return the test signal cable to CH 1 input.
 - b. Press and release SINGL SWP pushbutton.
 - c. Remove the test signal cable from CH 1 input.
 - d. Press and release SINGL SWP pushbutton.
 - e. CHECK-That READY light turns on.
 - f. Return the test signal cable to CH 1 input.
 - g. CHECK-That READY light is extinguished.
- h. Press and release SINGL SWP pushbutton.
- i. CHECK—For a single-sweep display (1 sweep only).
- j. Set TRIG MODE to AUTO.

19. Check TRIG VIEW Operation

a. Move signal cable from CH 1 input to A TRIGGER external input and set A TRIGGER SOURCE to EXT.

b. Set the amplitude calibrator for a 200 millivolt output.

c. Press TRIG VIEW and hold it in.

d. Position the waveform for a maximum amplitude display with A TRIGGER LEVEL control.

- e. CHECK—For approximately 4 divisions of display.
- f. Release TRIG VIEW.
- g. Disconnect all test equipment.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-2500 Unitati- enguiles@mauritroit.com

@

NOTE

DM44 DIGITAL MULTIMETERS

FOR OSCILLOSCOPES WITH DIGITAL MULTIMETERS ATTACHED, REFER TO THE DIGITAL MULTIMETER MANUAL AT THIS POINT. CONTINUE WITH 475A DM44 HORIZONTAL SYSTEM PERFORMANCE CHECK, THEN RETURN TO GATE OUTPUTS, EXTERNAL Z-AXIS AND CALIBRATOR CHECKS SECTION IN THIS PERFOR-

FOR OSCILLOSCOPES WITHOUT DIGITAL MULTIMETERS, CONTINUE WITH HORIZONTAL SYSTEM CHECK.

HORIZONTAL SYSTEM CHECK

Equipment Required

- 1. Time-Mark Generator
- 2. Sine-Wave Generator
- 3. Amplitude Calibrator

Control Settings

POWER

ON

INTENSITY
FOCUS
SCALE ILLUM

Midrange Midrange Midrange

Vertical (CH 1 and CH 2)

Display

POSITION VOLTS/DIV VAR VOLTS/DIV AC-GND-DC NVERT /ERT MODE 00 OR 20 MHz BW	Midrange 0.5 V (new setting) Calibrated detent DC Off (button out) CH 1 Full bandwidth (push in, then release)
--	--

11	rıg	ger	(A	and	B)
----	-----	-----	----	-----	----

AC

LEVEL	AC
SLOPE	U
A TRIGGER SOURCE	+
B TRIGGER SOURCE	NORM (new setting)
COORCE	STARTS AFTER DELAY
TRIG MODE	(new setting)
	AUTO
A TRIGGER HOLDOFF	NORM

4. 500 MHz Filter

- 5. 42-inch 50-Ohm BNC Cable (2 required)
- 6. 50-Ohm BNC Termination (2 required)
- 7. 10X Probe (see Table 5-1, 10X Probe examples)
- Sweep A TIME/DIV B TIME/DIV VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY А X10 MAG POSITION (Horiz) FINE

1 ms 1 ms Calibrated detent Fully counterclockwise Off (button out) Midrange Midrange

20. Check VAR TIME/DIV Range

a. Set the time-mark generator for 5 millisecond time marks and connect through a 42-inch 50-ohm BNC cable, to a 50-ohm BNC termination, to CH 1 input.

b. Set A TRIGGER LEVEL for a stable triggered display, then set VAR TIME/DIV fully counterclockwise.

c. CHECK-That VAR TIME/DIV UNCAL light is illuminated.

d. CHECK-For at least 6 time marks between first and last graticule lines.

e. Return VAR TIME/DIV control to calibrated detent.

٧

1

COUPLING

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

21. Check Sweep Length and Horizontal POSITION Range

a. Set time-mark generator for 1 millisecond time marks.

b. CHECK--Sweep length for approximately 10.1 divisions.

c. Turn POSITION and FINE (Horiz) controls fully clockwise. (Also check that each control will position the trace.)

d. CHECK—That the start of sweep is to the right of graticule center.

e. Turn POSITION and FINE (Horiz) controls fully counterclockwise.

f. CHECK-That the end of sweep is to the left of graticule center.

g. Recenter POSITION and FINE (Horiz) controls.

22. Check A Timing Accuracy

a. Set TIME/DIV to $0.01 \,\mu$ s, set the time-mark generator for 10 nanosecond time marks, set TRIG MODE to NORM, and set A TRIGGER LEVEL for a stable triggered display.

NOTE

Unless otherwise stated, set POSITION and FINE (Horiz) controls so first time mark will coincide with first graticule line and check that a time mark will coincide with last vertical graticule line.

b. CHECK—TIME/DIV settings from 0.01 μ s to 5 ms/division for accuracy, at first and 11th graticule lines, within 1%, from +20°C to +30°C; within 3%, from -15°C to +55°C.

NOTE

Turn INTENSITY full on, note the start of sweep and exclude the first 25 nanoseconds from start of sweep when checking 0.01 and 0.02 µs/division. Set time-mark generator, as necessary, to provide 1 or more time marks/division as each TIME/DIV setting is selected, throughout the horizontal check procedure.

5-16

c. CHECK—TIME/DIV settings from 10 ms to 0.5 s/division for accuracy, at first and 11th graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

23. Check A INTEN Timing Accuracy

a. Set HORIZ DISPLAY to A INTEN, set TIME/DIV to 0.05 μ s and set time-mark generator for 50 nanosecond time marks (DELAY TIME POSITION should be fully counterclockwise).

b. CHECK—TIME/DIV settings from 0.05 μ s to 0.5 s/division for accuracy, at first and 11th graticule lines. within 2%, from +20°C to +30°C; within 3%, from -15°C to +55°C.

24. Check A INTEN Magnified Timing Accuracy

a. Set TIME/DIV to 0.05 μ s, set time-mark generator for 5 nanosecond time marks and press X10 MAG to on.

b. CHECK—TIME/DIV settings from 0.05 μ s to 0.5 s/division for accuracy, at first and 11th graticule lines, within 3%, from +20°C to +30°C; within 4%, from -15°C to +55°C (see following note).

NOTE

Turn INTENSITY fully on, note the start of sweep and exclude the first 25 nanoseconds from start of sweep or first 2 major unblanked divisions at normal intensity (whichever is greater) and all beyond the 100th division.

25. Check A Magnified Timing Accuracy

a. Set TIME/DIV to 0.01 μ s, set A TRIGGER SOURCE to EXT and set A TRIGGER COUPLING to LF REJ.

b. Set the time-mark generator for 2 nanosecond time marks and connect trigger output through a 42-inch 50-ohm BNC cable, to a 50-ohm BNC termination, to A TRIGGER external input (if a 2901 time-mark generator is used, set trigger selector for 0.1 microsecond triggers).

Insert a 500 megahertz filter between the 50-ohm BNC termination and CH 1 input. Adjust the filter for minimum unwanted modulation from the time mark generator, as necessary, whenever 2 or 5 nanosecond time marks are used in this step.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@

c. Set CH 1 VOLTS/DIV to maintain a convenient display amplitude and set A TRIGGER LEVEL for a stable display. (It may be necessary to adjust A TRIGGER HOLDOFF for best triggered display through this step).

d. CHECK—TIME/DIV settings from 0.01 to 0.05 μ s/division for accuracy, at first and 11th graticule lines, within 2%, from + 20°C to +30°C; within 4%, from -15°C to +55°C.

e. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval at all TIME/DIV settings (see following note).

NOTE

If waveform has modulation, check 2 division accuracy between adjacent time marks of equal amplitude.

Turn INTENSITY full on, note the start of sweep and exclude the first 25 nanoseconds from start of sweep or first 2 major unblanked divisions at normal intensity (whichever is greater) and all beyond the 100th division.

f. Remove the trigger cable setup from A TRIGGER external input, set A TRIGGER SOURCE to NORM and set A TRIGGER COUPLING to AC. Remove the 500 megahertz filter.

g. Set TIME/DIV to 0.1 μ s, set time-mark generator for 10 nanosecond time marks and set CH 1 VOLTS/DIV to maintain a convenient display amplitude.

h. CHECK—TIME/DIV settings from 0.1 μ s to 5 ms/division for accuracy, at first and 11th graticule lines, within 2%, from +20°C to +30°C, within 4%, from -15°C to +55°C.

26. Check Differential Delay Time Accuracy

a. Set HORIZ DISPLAY to B DLY'D and set TIME/DIV to 0.05 $\mu s.$ Pull and unlock DLY'D SWP knob, set to 0.01 μs and set X10 MAG to off.

b. Set time-mark generator for 50 nanosecond time marks.

REV A SEP 1980

c. Turn DELAY TIME POSITION to set time mark nearest 1.000 on dial to coincide with graticule center and note reading.

d. Turn DELAY TIME POSITION to set time mark nearest 2.000 on dial to coincide with graticule center and note reading.

e. CHECK—For a difference in readings of 1.000, within 0.010, from \pm 15°C to \pm 35°C; within 0.020, from \pm 15°C to \pm 55°C.

f. Turn DELAY TIME POSITION to set every adjacent time-mark to coincide with graticule center and note reading.

g. CHECK—Each reading between any 2 adjacent time-marks for 1.000, within 0.010, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.020, from -15° C to $+55^{\circ}$ C. Also, check the difference between any time marks separated by more than 1 major dial division not to exceed maximum error as listed in Table 5-3.

Difference in Major Dial Divisions	Maximum Error +15°C to +35°C	Maximum Error 15°C to +55°C
1.000	±0.010	±0.020
2.000	±0.019	±0.029
3.000	±0.027	±0.042
4.000	±0.033	±0.053
5.000	±0.039	±0.064
6.000	±0.043	±0.073
7.000	±0.047	±0.082
8.000	±0.049	±0.089
9.000	±0.050	±0.095

	TABLE	5-3	
Differential	Delav	Time	Accuracy

h. CHECK—Display time accuracy as directed in part g, at all settings listed in Table 5-4 not to exceed maximum error listed in Table 5-3.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquines@mauritron.co.uk

DELAY TIME POSITION Exclusions	A TIME/DIV Switch Setting	B TIME/DIV Switch Setting	¹ Time-Mark Generator Setting
Exclude dial	0.05 μs	0.01 µs	50 nanosecond
settings of	0.1 µs	0.01 μs	0.1 microsecond
0.000 through	0.2 μs	0.02 μs	0.2 microsecond
1.000	0.5 μs	0.05 µs	0.5 microsecond
	1 μs	0.1 μs	1 microsecond
	2 μs	0.2 μs	2 microsecond
	5 μs	0.5 μs	5 microsecond
	10 µs	1 µs	10 microsecond
[20 μs	2 µs	20 microsecond
Exclude dial	50 μs	5 μs	50 microsecond
settings of	0.1 ms	10 μs	0.1 millisecond
0.000 through	0.2 ms	20 μs	0.2 millisecond
0.050	0.5 ms	50 μs	0.5 millisecond
	1 ms	0.1 ms	1 millisecond
	2 ms	0.2 ms	2 millisecond
	5 ms	0.5 ms	5 millisecond
	10 ms	1 ms	10 millisecond
	20 ms	2 ms	20 millisecond
	50 ms	5 ms	50 millisecond
	0.1 s	10 ms	0.1 second
-	0.2 s	20 ms	0.2 second
	0.5 s	50 ms	0.5 second

TABLE 5-4 Delay Time Settings

¹If the time-mark generator being used does not have a 1-2-5 sequence, set for 1 or more time marks/division on DELAY TIME POSITION dial.

27. Check Delay Time Jitter

a. Set DLY'D SWP to 0.2 μ s, set A TIME/DIV to 1 ms and set time-mark generator for 1 millisecond time marks.

b. Set DELAY TIME POSITION to 1.000 on dial and position nearest time-mark to graticule center.

c. CHECK-That jitter on the leading edge of the time mark does not exceed 1 division (60 Hertz line) or 2.5 division (50 Hertz line).

d. Set DELAY TIME POSITION to view each time-mark from 2.000 to 9.000 on dial and check delay time jitter for limits stated in part c.

28. Check MIX (Mixed Sweep) Timing Accuracy

a. Set DLY'D SWP to 0.02 $\mu s,$ A TIME/DIV to 0.05 $\mu s,$ HORIZ DISPLAY to MIX and DELAY TIME POSITION fully clockwise.

b. Set time-mark generator for 50 nanosecond timemarks. c. CHECK—A TIME/DIV settings from 0.02 μ s to 0.5 s/division for accuracy at 2nd and 10th graticule lines (8 division timing), within 3%. Exclude the first 0.5 division from start of sweep when checking A sweep. Set DLY'D SWP at least 1 sweep setting faster than A sweep setting on all ranges. Set time-mark generator to maintain appropriate time marks.

d. Set DELAY TIME POSITION fully counterclockwise, DLY'D SWP to 0.05 μ s, ATIME/DIV to 0.1 μ s and set time-mark generator for 50 nanosecond time marks.

e. CHECK—DLY'D SWP settings from $0.05 \,\mu$ s to 0.5 s/division for accuracy at 2nd and 10th graticule lines (8 division timing), within 3%. Exclude the first 0.2 division or 0.1 microsecond (whichever is greater) after the transition of A to B. Set DLY'D SWP at least 1 sweep setting faster than A sweep setting on all ranges. Set time-mark generator to maintain appropriate time marks.

f. Disconnect all test equipment.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquines@mauritron.co.uk

29. Check X Gain

a. Set TRIG MODE to AUTO, set DLY'D SWP to lock knobs, set TIME/DIV to X-Y, set VERT MODE to CH 2 and set X (CH 1) VOLTS/DIV to 10 mV.

b. Set amplitude calibrator to 50 millivolts and connect to X (CH 1) input through a 42-inch 50-ohm BNC cable.

c. Set X (CH 1) and Y (CH 2) POSITION controls to set the 2-dot display at graticule center.

d. CHECK-The deflection between the 2 displayed dots for 5 divisions within 3%.

30. Check X Bandwidth

NOTE

See test equipment required, Table 5-1, for selection of sine-wave generator with an output of 100 megahertz and below.

a. Connect the sine-wave generator output cable to a 50-ohm termination, to X input.

b. Set the sine-wave generator for a 4 division horizontal display of reference frequency.

c. Increase the frequency of the sine-wave generator until the display is reduced to 2.8 divisions.

d. CHECK-The sine-wave generator for a reading of 3 megahertz or higher.

e. Disconnect all test equipment.

e. Disconnect all test equipment.

GATE OUTPUTS, EXTERNAL Z-AXIS AND **CALIBRATOR CHECKS**

Equipment Required

1. Amplitude Calibrator

- 2. 42-Inch 50-ohm BNC Cable (2 required)
- 3. 50-Ohm BNC Termination
- 4. 10X Probe (see Table 5-1, 10X Probe examples)

Control Settings	
------------------	--

POWER

INTENSITY

SCALE ILLUM

FOCUS

ON

Display

Midrange Midrange Midrange

Vertical (CH 1 and CH 2)

POSITION Midrange VOLTS/DIV VAR VOLTS/DIV AC-GND-DC DC INVERT VERT MODE 100 OR 20 MHz BW

2 V (new setting) Calibrated detent Off (button out) CH 1 (new setting) 20 (new setting)

Trigger (A and B) COUPLING AC LEVEL SLOPE A TRIGGER SOURCE **B TRIGGER SOURCE**

TRIG MODE

A TRIG HOLDOFF

Fully clockwise (new setting) +NORM STARTS AFTER DELAY AUTO NORM

Sweep

A TIME/DIV **B TIME/DIV** VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY X10 MAG **POSITION** (Horiz) FINE

10 μ s (new setting) 10 µs (new setting) Calibrated detent Fully counterclockwise A INTEN (new setting) Off (button out) Midrange Midrange

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

31. Check A and B +GATE Outputs

a. Connect A +GATE (output connector on rear panel) to CH 1 input through a 42-inch 50-ohm BNC cable.

b. CHECK—The display for a positive pulse amplitude of approximately 5 volts (it may be necessary to increase INTENSITY to view leading edge of positive pulse).

c. Move cable from A +GATE to B +GATE (output connectors on rear panel).

d. CHECK-Repeat part b.

e. Disconnect the cable between B $\pm GATE$ and CH 1 connectors.

32. Check CH 2 VERT SIGNAL OUT

a. Set HORIZ DISPLAY to A, set TIME/DIV to 0.5 ms, set CH 1 VOLTS/DIV to 0.1 V and set CH 2 VOLTS/DIV to 5 mV.

b. Set VERT MODE to CHOP, set CH 1 and CH 2 POSITION controls for 2 traces superimposed on center horizontal graticule line, then set VERT MODE to CH 1.

c. Connect CH 2 VERT SIGNAL OUT (output connector on rear panel) to CH 1 input through a 42-inch 50-ohm BNC cable.

d. Set amplitude calibrator for a 20 millivolt output and connect to CH 2 input through a 42-inch 50-ohm BNC cable.

e. Set A TRIGGER LEVEL for a stable triggered display.

f. CHECK—The square-wave display for approximately 1 division of amplitude with the bottom of waveform near center horizontal graticule line. g. Set CH 1 VOLTS/DIV to 50 mV and insert a 50-ohm termination between CH 1 input and the connected BNC cable.

h. CHECK-Repeat part f.

i. Disconnect all test equipment.

33. Check EXT Z-AXIS Operation

a. Set amplitude calibrator for a 5 volt output and connect to EXT Z-AXIS (input connector on rear panel) through a 42-inch 50-ohm BNC cable.

b. CHECK---For noticeable modulation at normal intensity. Adjust VAR TIME/DIV, if necessary to observe modulation, then return to calibrated detent.

c. Disconnect all test equipment.

34. Check CALIBRATOR Operation

a. Set CH 1 VOLTS/DIV to 10 mV and set TIME/DIV to 1 ms.

b. Connect a 10X probe with a scale-factor switching connector between CH 1 input and CALIBRATOR current loop.

NOTE

Use a probe listed in test equipment required, Table 5-1, under 10X Probe examples.

c. CHECK—The square-wave display for 3 divisions of amplitude and for approximately 1 cycle/division.

d. Disconnect all test equipment.

This completes the performance check procedure for the 475A. If the instrument has met all performance requirements given in this procedure, it is currently calibrated and within specifications.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk

CALIBRATION

IMPORTANT-PLEASE READ BEFORE USING THIS PROCEDURE

Introduction

The following procedure returns the 475A to correct calibration. All limits and tolerances given in this procedure are calibration guides and should not be interpreted as instrument specifications except as specified in the performance requirements portion of the Specifications section in this Service manual.

Calibration Interval

To ensure instrument accuracy, check the calibration of the 475A every 1000 hours of operation, or every 6 months if used infrequently. Before complete calibration, thoroughly clean and inspect this instrument as outlined in the Maintenance section of this manual.

Tektronix Field Service

Tektronix, Inc. provides complete instrument repair and recalibration at local Field Service Centers and at the Factory Service Center. Contact your local Tektronix Field Office or representative for further information.

Using This Procedure

Outline. To aid in locating a step in the Calibration procedure, an outline is given preceding the Calibration procedure.

Calibration Procedure. Completion of each step in the Calibration procedure ensures that this instrument meets the electrical specifications given in the first section of this manual. Where possible, instrument performance is checked before an adjustment is made. For best overall instrument performance when performing a complete calibration procedure, make each adjustment to the exact setting, even if the CHECK— is within the allowable tolerance. It will be necessary to remove the cabinet in order to have full access to the internal adjustments and test points.

Partial Procedures. A partial check or adjustment is often desirable after replacing components or to touch up the adjustment of a portion of the instrument between major recalibrations. To check or adjust only part of the instrument, set the controls as given under the nearest preceding Control Settings and use the Equipment Required list preceding the desired portion of the procedure. To prevent unnecessary recalibration of other parts of the instrument, readjust only if the tolerance given in the CHECK— part of the step is not met. If readjustment is necessary, also check any steps listed in the INTERACTION— part of the step.

TEST EQUIPMENT REQUIRED

General

The following test equipment and accessories, or its equivalent, is required for complete calibration of the 475A. Specifications given for the test equipment are the minimum necessary for accurate calibration. Therefore, some of the specifications listed here may differ from the actual performance capabilities of the test equipment. All test equipment is assumed to be correctly calibrated and operating within the listed specifications. Detailed operating instructions for the test equipment are not given in this procedure. Refer to the instruction manual for the test equipment if more information is needed. Minimum test equipment specifications must include the use of any special required accessories (such as the precision output cable included with the SG 503).

Special Calibration Fixtures

Special Tektronix calibration fixtures are used only where they facilitate instrument calibration. These special calibration fixtures are available from Tektronix, Inc. Order by part number through your local Tektronix Field Office or representative.

Calibration Equipment Alternatives

All of the listed test equipment is required to completely check and calibrate this instrument. However, complete checking or calibration may not always be necessary or desirable. The user may be satisfied with checking only selected characteristics, thereby reducing the amount of test equipment actually required.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

The equipment listed in the Calibration procedure is based on the first item of equipment given as an example of applicable equipment. When other equipment is substituted, control settings or calibration setup may need to be altered to meet the requirements of the substitute equipment. If the exact item of test equipment given as an

example in the Test Equipment list is not available, first check the Specifications column carefully to see if any other equipment is available which might suffice. Then check the Usage column to see what this item is used for. If used for a check or adjustment that is of little or no importance to your measurement requirements, the item and corresponding step(s) can be deleted.

TABLE 6-1

Test Equipment Required For Calibration

Description	Minimum Specifications	Usage	Examples
1. Variable Auto-trans- former.	Capable of supplying 1.2 amperes over a range of 103.5 to 126.5 volts.		a. General Radio W8MT3VM Variac Autotransformer.
2. Digital Voltmeter	Range, 0 to 150 volts; dc voltage accuracy, within 0.15%; display, 4 1/2 digits.	Low-voltage power supply checks and adjustments; CRT grid bias check; Vertical and horizontal centering adjust- ments; Calibrator output volt- age adjustment.	 a. Tektronix DM 501 Digital Multimeter.¹ b. Any digital voltmeter that meets minimum specifications.
3. DC Voltmeter	Range, 0 to 2500 volts; cali- brated to 1% accuracy at 2450 volts.	High-voltage power supply check.	a. Triplett Model 630-NA. b. Simpson Model 262.
 Test Oscilloscope system with 10X probes. 	Bandwidth, DC to 100 mega- hertz; minimum deflection factor, 5 mV/division; accu- racy, within 3%; dual trace.	CRT Z-Axis compensation; Vertical 2 mV gain adjust- ment; A Trigger Hold-off check; High-speed timing ad- justment; A and B +Gate out- put signals check.	 a. Tektronix 465 Oscilloscope with 2 10X probes (included). b. Tektronix 475A Oscilloscope with 2 10X probes (included).
5. Amplitude Calibrator	Amplitude accuracy, within 0.25%; signal amplitude, 2 millivolts to 20 volts; out- put signal, 1 kilohertz square wave.	Vertical checks and adjust- ments; Trigger View gain check; X gain adjustment; Ex- ternal Z-Axis check.	 a. Tektronix PG 506 Calibration Generator.¹ b. Tektronix 067-0502-01 calibration fixture.
6. Sine-Wave Generator	above 250 megahertz; output amplitude, variable from	and isolation checks; Trigger checks and adjustments; X bandwidth check.	a. Tektronix SG 503 Leveled Sine-Wave Generator. ¹ (use for all frequencies.) b. Tektronix Type 191 Constant-Amplitude Signal Generator. (use at fre- quencies of 100 megahertz and below). AND Wavetek Model 1001A (use only for checking 200 mega- hertz bandwidth and trig- gering.)

Requires a TM 500-Series Power Module.

Description	Minimum Specifications	Usage	Examples
7. Time-Mark Generator	Marker outputs, 2 nano- seconds to 0.5 second; marker accuracy, within 0.1%; trigger output, 1 milli- second to 0.1 microsecond, time coincident with markers.	CRT Y-Axis and geometry adjustments; Auto trigger check; Horizontal timing checks and adjustments.	a. Tektronix TG 501 Time- Mark Generator. ¹ b. Tektronix 2901 Time- Mark Generator.
8. Low-Frequency Generator	Frequency, 10 Hertz to 50 kilohertz; output ampli- tude, variable from 10 milli- volts to 4 volts peak-to- peak.	Low-Frequency trigger checks.	 a. Tektronix SG 502 Oscillator.¹ b. General Radio 1310B Oscillator with a binding post to BNC adapter.
9. Square-Wave Generator	Repetition rate, 1 kHz to 100 kHz; risetime, 1 nano- second or less from fast- rise output; output ampli- tude at least 60 volt pulse supplying at least 11 milliamperes from high- amplitude output; aber- rations, within 2% from fast-rise output.	Vertical Systems compensa- tion adjustments.	a. Tektronix PG 506 ¹ . b. Tektronix Type 106 Square-Wave Generator.
10. Tunnel Diode Pulser	Output amplitude, approxi- mately 200 millivolts into 50 ohms; risetime, approxi- mately 100 picoseconds into 50 ohms; aberrations less than 1% into 50 ohms.	Driven by PG 506 or Type 106 for Vertical transient response checks and ad- justments; Trigger View risetime and delay checks.	a. Tektronix Tunnel Diode Pulser calibration fixture. Part Number 067-0681-01.
11. 50-Ohm Signal Pickoff	Frequency response, 50 kilo- hertz to 875 megahertz; im- pedance, 50 ohms for signal input, signal output and trig- ger output.	Trigger checks and adjust- ments.	a. Tektronix CT-3 Signal Pickoff. Part Number 017-0061-00.
12. Current Probe	Sensitivity, 1 milliampere/ millivolt; bandwidth, 8.5 kilo- hertz to 100 megahertz.	Used for major recalibration of Horizontal High-Speed Timing.	a. Tektronix P6022 AC Cur- rent Probe with Passive Termination.
13. Cable (2 required)	Impedance, 50 ohms; length, 42 inches; connectors, BNC.	Used throughout procedure for signal interconnection.	a. Tektronix Part Number 012-0057-01.
14. Cable (2 required)	Impedance, 50 ohms; length 18 inches; connectors, BNC.	Used throughout procedure for signal interconnection.	a. Tektronix Part Number 012-0076-00.
15. Adapter	Connectors, GR874 to BNC Female.	Vertical compensation adjust- ments. Trigger adjustments.	a. Tektronix Part Number 017-0063-00.

TABLE 6-1 (cont)

¹Requires a TM 500-Series Power Module.

Description	Minimum Specifications	Usage	Examples	
16. Adapter Connectors, GR874 to BNC Male.		Used in Trigger adjustment procedure for signal interconnection.	a. Tektronix Part Number	
17. Adapter	Connectors, BNC Female to BNC Female.	 Used throughout procedure for signal interconnection. 	a. Tektronix Part Number 103-0028-00.	
18. Elbow Adapter	Connectors, BNC Male to BNC Female.	Used in Trigger system pro- cedure for signal intercon- nection.	a. Tektronix Part Number 103-0031-00.	
19. T-Connector	Connectors, BNC.	Used throughout procedure for signal interconnection.	a. Tektronix Part Number 103-0030-00.	
20. 10X Attenuator	Ratio, 10X; impedance, 50 ohms; connectors, BNC.	Vertical System compen- sation adjustments. Vertical bandwidth check. Trigger ad justments.	a. Tektronix Part Number 011-0059-02.	
21. 5X Attenuator	Ratio, 5X; impedance, 50 ohms; connectors, BNC.	Vertical System compen- sation adjustments. Trigger adjustments.	a. Tektronix Part Number 011-0060-02.	
22. 2X Attenuator	Ratio, 2X; impedance, 50 ohms; connectors, BNC.	Vertical System compen- sation adjustments.	a. Tektronix Part Number 011-0069-02.	
23. Termination (2 required)	Impedance, 50 ohms; con- nectors, BNC.	Used throughout procedure for proper signal termination.	a. Tektronix Part Number 011-0049-01.	
24. 500 MHz Filter	Impedance, 50 ohms; fre- quency, adjustable; con- nectors, BNC.	Used for High-Speed Timing checks and adjustments.	a. Tektronix 500 MHz Filter calibration fixture. Part Number 067-0684-00.	
25. Screwdriver	Length, three-inch shaft; bit size 3/32 inch.	Used throughout procedure to adjust variable resistors.	a. Xcelite R-3323.	
6. Low-Capacitance crewdriver	Length; approximately 4 inches; bit size 3/32 inch.	Used throughout procedure to adjust all variable cap- acitors.	a. J.F.D. Electronics Adjust- ment Tool Number 5284.	
7. Adapter			a. Tektronix Part Number 013-0084-01.	

TABLE 6-1 (cont)

For Service Manuals Contact MAURITRON TECHNICAL SERVICES B Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

6-4

@

Ī

OUTLINE FOR CALIBRATION PROCEDURE

POWER SUPPLY	Page 6-7
1. Adjust Power Supply DC Levels	Page 6-8
2. Check High Voltage Power Supply	Page 6-8
DISPLAY AND Z-AXIS	Page 6-8
3. Adjust CRT Grid Bias	Page 6-9
4. Check Display Controls	Page 6-9
5. Adjust CRT Y-Axis Alignment	Page 6-10
6. Adjust Geometry	Page 6-10
7. Adjust Z-Axis Compensation	Page 6-10
VERTICAL SYSTEM	Page 6-11
8. Adjust Vertical Output Bias	Page 6-12
9. Adjust Vertical Shield Voltage	Page 6-12
10. Adjust Delay-Line DC Center	Page 6-12
11. Adjust CH 1 VAR VOLTS/DIV Balance	e Page 6-12
12. Adjust CH 1 VOLTS/DIV Balance	Page 6-13
13. Adjust CH 2 VAR VOLTS/DIV Balance	Page 6-13
14. Adjust CH 2 VOLTS/DIV Balance	Page 6-13
15. Adjust CH 2 INVERT Balance	Page 6-13
16. Adjust CH 2 POSITION Centering	Page 6-13
17. Adjust CH 1 POSITION Centering	Page 6-14
18. Check CH 1 and CH 2 AC-GND-DC Functions	Page 6-14
19. Check Scale-Factor Indicator Lights	Page 6-14
20. Adjust CH 1 Gain and Vertical Output Gain	Page 6-14
21. Adjust CH 2 Gain	Page 6-16
22. Check CH 1 and CH 2 VAR VOLTS/DIV Range	Page 6-16

Calibration—475A Service

23. Check ADD MODE Operation	Page 6-16
24. Check Compression and Expansion	Page 6-16
25. Check Cascaded Gain	Page 6-17
26. Check ALT Mode Operation	Page 6-17
27. Check CHOP Mode Operation	Page 6-17
28. Adjust High-Frequency Compensation	Page 6-17
29. Adjust CH 1 VOLTS/DIV Compensa- tion	Page 6-18
30. Adjust CH 2 VOLTS/DIV Compensa- tion	Page 6-19
31. Adjust Vertical Transient Response	Page 6-20
32. Check Vertical Amplifier Bandwidth	Page 6-21
33. Check Bandwidth Limit Operation	Page 6-21
34. Check Cascaded Bandwidth	Page 6-22
35. Check Vertical Channel Isolation	Page 6-22

	TRIGGER SYSTEM	Page 6-22
Page 6-13	36. Adjust A Trigger Sensitivity, Symmetry and Centering	
ce Page 6-13		raye 0-25
Page 6-13	37. Adjust B Trigger Sensitivity, Symmetry and Centering	Page 6-24
Page 6-13	38. Adjust A Trigger DC Centering	Page 6-25
Page 6-13	39. Check B Trigger DC Centering	Page 6-26
Page 6-14 C	40. Check B Internal 40 Megahertz Triggering	Page 6-26
Page 6-14 Page 6-14	41. Check A Internal 40 Megahertz Triggering	Page 6-26
t Page 6-14	42. Check A Internal 250 Megahertz Triggering	Page 6-26
Page 6-16	43. Check B Internal 250 Megahertz Triggering	Page 6-27
/ Page 6-16	44. Check B External 40 Megahertz Triggering	Page 6-27

45. Check A External 40 Megahertz Triggering	Page 6-27
46. Check A External 250 Megahertz Triggering	z Page 6-28
47. Check B External 250 Megahertz Triggering	z Page 6-28
48. Check B LF REJ, HF REJ and Low- Frequency Triggering	Page 6-28
49. Check A LF REJ, HF REJ and Low- Frequency Triggering	Page 6-29
50. Adjust Trigger View Centering	Page 6-31
51. Check TRIG VIEW Deflection Factor	Page 6-31
52. Check TRIG VIEW Risetime	Page 6-31
53. Check TRIG VIEW Delay Difference	Page 6-31
54. Check LINE Triggering	Page 6-32
55. Check A TRIGGER LEVEL Control External Range	Page 6-32
56. Check B TRIGGER LEVEL Control External Range	Page 6-32
57. Check SINGL SWP Triggering	Page 6-32
58. Check TRIG MODE NORM Triggering	Page 6-32
59. Check TRIG MODE AUTO Triggering	Page 6-33

HORIZONTAL SYSTEM DM44 DIGITAL MULTIMETER	Page 6-33
INSTRUCTIONS	Page 6-34
60. Adjust Horizontal Gain	Page 6-34
61. Adjust Intensified Gain	Page 6-34
62. Adjust Delay Start and Delay Stop	Page 6-34
63. Check 1 Millisecond Differential Delay	
Time Accuracy	Page 6-35
64. Adjust Magnified Registration	Page 6-35
65. Check VAR TIME/DIV Range	Page 6-35

66. Check Sweep Length and Horizontal POSITION Range	Page 6-35
67. Adjust 10 Microsecond Timing	Page 6-36
68. Adjust 0.1 Microsecond Timing	Page 6-36
69. Adjust Horizontal Output Centering	Page 6-37
70. Adjust High-Speed Timing (Visual Method)	Page 6-37
71. Adjust High-Speed Timing (Current Probe Method)	Page 6-38
72. Check A Timing Accuracy	Page 6-40
73. Check A INTEN Timing Accuracy	Page 6-40
74. Check A INTEN Magnified Timing Ac- curacy	Page 6-40
75. Check A Magnified Timing Accuracy	Page 6-40
76. Check Differential Delay Time Ac- curacy	Page 6-40
77. Check Delay Time Jitter	Page 6-42
78. Check MIX (Mixed Sweep) Timing Ac- curacy	Page 6-42
79. Adjust X Gain	Page 6-42
80. Adjust X-Y Phase Difference	Page 6-42
81. Check X Bandwidth	Page 6-43
82. Check B ENDS A Operation	Page 6-43

83. Check A TRIG HOLDOFF Operation Page 6-43

GATE OUTPUTS, EXTERNAL Z-AXIS
AND CALIBRATORPage 6-4484. Check A and B + GATE OutputsPage 6-4485. Check EXT Z-AXIS OperationPage 6-4486. Adjust CALIBRATOR Output
AmplitudePage 6-4487. Check CALIBRATOR FrequencyPage 6-45

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax- 01844-352554 Email:- enquiries@mauritron.co.uk

@

4.74

6-6

PRELIMINARY PROCEDURE FOR CALIBRATION

Operating Voltage

Before applying power to the instrument, check that the line voltage selector and the regulating range selector are in the correct positions for the line voltage the instrument will be operated on.

Cabinet Removal

Remove the cabinet from the instrument as outlined in the Maintenance section of this manual. Also, remove the vertical output circuit board cover from the top of main chassis. This will allow access to vertical output adjustments.



Power should not be applied to the instrument when cleaning or replacing parts. When the instrument is operated with the cabinet removed, do not touch exposed connections or components. High voltage exists at several points and transistors may have elevated cases throughout the instrument.

Power Source

Connect the 475A through the autotransformer to a power source that meets the voltage and frequency requirements of this instrument.

Warm Up

Turn on the 475A, set the autotransformer output voltage to the center of the voltage range selected by the line voltage selector and allow at least 20 minutes warm up before starting the calibration procedure.

Operating Temperature

This instrument should be calibrated at an ambient temperature of $+20^{\circ}$ C to $+30^{\circ}$ C for best overall accuracy. This instrument can be calibrated within environmental limits listed in the Specifications section of this manual to approximate the expected environmental usage.

Step Titles

Each procedure step is preceded by a number and each procedure part is set in alphabetical order. Steps containing adjustments and checks are titled (Adjust) steps; steps containing only checks are titled (Check) steps. Where possible, the performance requirement is checked before an adjustment is made. If a check meets its requirements, it is not necessary to make the related adjustment.

POWER SUPPLY

Equipment Required	3. DC Vo	ltmeter
1. Variable Autotransformer		
2. Digital Voltmeter	4. Screwe	driver
Before you begin, see	ADJUSTMENT LOCATIONS 1	in the pullout pages.

Control Settings

POWER	

INTENSITY

SCALE ILLUM

FOCUS

Display Midrange Midrange Midrange

ON

Vertical (CH 1 and CH 2)

POSITION VOLTS/DIV VAR VOLTS/DIV AC-GND-DC INVERT VERT MODE 100 OR 20 MHz BW Midrange 10 mV Calibrated detent DC Off (button out) CH 1 20

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Trigger (A and B)

COUPLING	AC
LEVEL	0
SLOPE	+
A TRIGGER SOURCE	NORM
B TRIGGER SOURCE	STARTS AFTER DELAY
TRIG MODE	AUTO
A TRIGGER HOLDOFF	NORM

Sweep

	1 ms
B TIME/DIV	1 ms
VAR TIME/DIV	Calibrated detent
DELAY TIME POSITION	Fully counterclockwise
HORIZ DISPLAY	A
X10 MAG	Off (button out)
POSITION (Horiz)	Midrange
FINE	Midrange

1. Adjust Power Supply DC Levels

a. Connect the digital voltmeter between test points listed in Table 6-2 and ground on main interface board. See ADJUSTMENT LOCATIONS 1.

TABLE 6-2

Power Supply Accuracy

Power Supply	Test Point	Tolerance	Reading
+50 volt	+50 V	0.5%	+49.75 to +50.25
+15 volt	+15 V	1.5%	+14.77 to +15.23
-15 volt	-15 V	1.5%	-14.77 to -15.23
+5 volt	+5 V	1.5%	+4.92 to +5.08
-8 volt	—8 V	1.5%	-7.88 to -8.12
+110 volt	+110 V	3%	+106.7 to +113.3

NOTE

If +50 volt supply is within specified tolerance, proceed with part c. If +50 volt adjustment is to be made, the accuracy of all circuits will be affected. The entire calibration procedure should be performed to verify instrument performance.

b. ADJUST—+50 volt supply. R1430, for +50 volts within 50 millivolts. See ADJUSTMENT LOCATIONS 1.

c. Decrease line voltage with the variable autotransformer until the LOW LINE indicator light starts to blink.

d. CHECK—The variable autotransformer ac voltmeter for approximately 104 volts ac or less.

e. Return the variable autotransformer to 115 volts ac.

2. Check High Voltage Power Supply

a. Set the POWER switch to off.

b. Connect the dc voltmeter positive lead to ground and connect negative leads to TP2450. See ADJUST-MENT LOCATIONS 1.

c. Set the POWER switch to ON.

d. CHECK—For a reading of -2450 volts within 49 volts.

e. Set the POWER switch to off and disconnect the dc voltmeter. Return the POWER switch to ON.

DISPLAY AND Z AXIS

Equipment Required	5. 42-Inch 50-Ohm BNC Cable
1. Digital Voltmeter	6. 50 Ober DNG Termination
2. Amplitude Calibrator	6. 50-Ohm BNC Termination
3. Time-Mark Generator	7. Screwdriver
4. Test Oscilloscope With 10X Probe	8. Low-Capacitance Screwdriver

Before you begin, see

ADJUSTMENT LOCATIONS 1 in the pullout pages.

Control Settings

POWER

ON

Display

INTENSITY	Fully counterclockwise
FOCUS SCALE ILLUM	(new setting) Midrange Midrange

Vertical (CH 1 and CH 2)

POSITION	Midrange
VOLTS/DIV	10 mV
VAR VOLTS/DIV	Calibrated detent
AC-GND-DC	DC
INVERT	Off (button out)
VERT MODE	CH 1
100 OR 20 MHz BW	20

Trigger (A and B)

COUPLING	AC
LEVEL	0
SLOPE	+
A TRIGGER SOURCE	NORM
B TRIGGER SOURCE	STARTS AFTER DELAY
TRIG MODE	SINGL SWP (new setting)
A TRIGGER HOLDOFF	NORM

Sweep

A TIME/DIV	1 ms
B TIME/DIV	1 ms
VAR TIME/DIV	Calibrated detent
DELAY TIME POSITION	
HORIZ DISPLAY	Fully counterclockwise
X10 MAG	A
	Off (button out)
POSITION (Horiz)	Midrange
FINE	Midrange

3. Adjust CRT Grid Bias

a. Connect the digital voltmeter between TP1364 and ground. See ADJUSTMENT LOCATIONS 1.

b. Set INTENSITY control for a reading of +15 volts.

c. CHECK—The display for a well-defined spot of low intensity near left vertical graticule line. Adjust FOCUS and POSITION (Horiz) if necessary.

d. ADJUST--CRT Grid Bias, R1375, for the dimmest, visible spot. See ADJUSTMENT LOCATIONS 1.

e. Turn CH 1 POSITION, FOCUS and INTENSITY controls fully clockwise.

f. CHECK-For a reading of +20 volts to +30 volts.

g. Press BEAM FINDER pushbutton.

h. CHECK—For a reading of approximately +25 volts.

i. Release BEAM FINDER pushbutton and disconnect all test equipment.

j. Set INTENSITY, FOCUS and CH 1 POSITION controls to midrange. Set TRIG MODE to AUTO.

k. Adjust FOCUS and INTENSITY controls for a welldefined trace of normal intensity.

4. Check Display Controls

a. Turn the INTENSITY control from fully counterclockwise to fully clockwise and return to normal intensity.

b. CHECK—For trace intensity to increase smoothly from minimum to maximum intensity.

c. Turn the FOCUS control through its range and return to focused trace.

d. CHECK—For trace defocus at each extreme position of the FOCUS control.

e. Turn ASTIG control (front panel screwdriver adjustment) through its range.

f. CHECK-For control of trace focus.

g. Set the amplitude calibrator for a 20 millivolt output and connect to CH 1 through a 42-inch 50-ohm BNC cable.

h. Adjust A TRIGGER LEVEL for a stable display.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

i. ADJUST-FOCUS and ASTIG controls for well-defined front corners on the displayed waveform.

j. Turn INTENSITY control fully counterclockwise and press BEAM FINDER pushbutton.

k. CHECK—For a compressed waveform of normal intensity.

I. Release BEAM FINDER pushbutton, return INTEN-SITY to a normal setting and disconnect all test equipment.

m. Turn the SCALE ILLUM control through its range.

n. CHECK-For a smooth increase in illumination.

o. Position the trace to the center horizontal graticule line.

p. CHECK---That the trace is aligned with the center horizontal graticule line.

q. ADJUST-TRACE ROTATION (front panel screwdriver adjustment) to align the trace with the center horizontal graticule line.

5. Adjust CRT Y-Axis Alignment

a. Connect 1 millisecond time marks from the timemark generator through a 42-inch 50-ohm BNC cable and a 50-ohm termination to the CH 1 input.

b. Set CH 1 VOLTS/DIV to 50 mV. Position the display baseline below crt viewing area.

c. Adjust A TRIGGER LEVEL, FOCUS and INTENSITY controls for a well-defined, stable display.

d. Adjust the TIME/DIV and VAR TIME/DIV controls for exactly 1 time mark/division with coincidence of time marks on each major vertical graticule line.

e. CHECK—For no more than 0.1 division of tilt when comparing the center time mark to the center vertical graticule line.

6-10

f. ADJUST —Y-Axis Alignment, R1385, to align the center time mark with the center vertical graticule line. See ADJUSTMENT LOCATIONS 1.

g. INTERACTION—Between Y-Axis Alignment and TRACE ROTATION adjustment. Repeat both adjustments for best display.

6. Adjust Geometry

a. CHECK—The display for no more than 0.1 division of vertical bowing of the time marks at left and right edges of the graticule.

b. ADJUST—Geometry, R1390, for minimum bowing of the time marks at left and right edges of the graticule. See ADJUSTMENT LOCATIONS 1.

c. INTERACTION—Between Geometry adjustment and Y-Axis Alignment. Repeat both adjustments for best display.

d. Remove the time-mark signal cable and 50-ohm termination from CH 1 input. Return VAR TIME/DIV to calibrated detent.

e. CHECK—For no more than 0.1 division of trace curvature when trace is positioned to the top and bottom graticule lines.

7. Adjust Z-Axis Compensation

NOTE

Any reference to 475A through the calibration procedure refers to the instrument under calibration.

a. Connect a 10X probe from the test oscilloscope to the 475A Z-Axis fast-rise test point, TP1366. See ADJUST-MENT LOCATIONS 1.

b. Connect a 42-inch 50-ohm BNC cable from the test oscilloscope external trigger input to the 475A A +GATE output connector (on rear panel) and set the 475A TIME/DIV to 0.05 μ s.

c. Set test oscilloscope: time/division to 0.2 microsecond, volts/division to 0.2, trigger source to external and adjust trigger level to view the positive step of the Z-Axis waveform.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

d. Adjust 475A INTENSITY for a positive step amplitude of 1 volt (5 divisions) on test oscilloscope display. See Figure 6-1.

e. CHECK-For a flat-top waveform in the first 20 nanoseconds from front corner. See Figure 6-1.

f. ADJUST-ZAxis Compensation, C1352, using a low-capacitance screwdriver, for the best flat-top waveform in the first 20 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 1.

g. Disconnect all test equipment.



Fig. 6-1. Typical display when Z-Axis Compensation is properly adjusted. Circle surrounds compensated portion of waveform.

10. 42-Inch 50-Ohm BNC Cable (2 required)

11. 18-Inch 50-Ohm BNC Cable (2 required)

14. 50-Ohm BNC Termination (2 required)

16. Low-Capacitance Screwdriver

17. BNC Male-to-Probe tip adapter

VERTICAL SYSTEM

9. BNC T-Connector

12. 10X BNC Attenuator

13. 5X BNC Attenuator

15. Screwdriver

Equipment Required

- 1. Sine-Wave Generator
- 2. Digital Voltmeter
- 3. Amplitude Calibrator
- 4. Square-Wave Generator
- 5. Test Oscilloscope With 10X Probes
- 6. Tunnel-Diode Pulser Calibration Fixture
- 7. GR-To-BNC Female Adapter
- 8. BNC Female-To-BNC Female Adapter

Before you begin, see

ON

ADJUSTMENT	LOCATIONS	1&2

in the pullout pages.

Vertical (CH 1 and CH 2)

Control Settings

POWER

INTENSITY

FOCUS

Display SCALE ILLUM

Midrange Midrange Midrange POSITION VOLTS/DIV VAR VOLTS/DIV AC-GND-DC INVERT VERT MODE 100 OR 20 MHz BW

Midrange 10 mV (new setting) Calibrated detent DC Off (button out) CH1 20

@

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax- 01844-352554 Email:- enquines@mauritron.co.uk

Trigger (A and B)

COUPLING	AC
LEVEL	0
SLOPE	+
A TRIGGER SOURCE B TRIGGER SOURCE TRIG MODE	NORM STARTS AFTER DELAY
A TRIGGER HOLDOFF	NORM

Sweep

A TIME/DIV	1 ms (new setting)
B TIME/DIV	1 ms (new setting)
VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY	Calibrated detent Fully counterclockwise
X10 MAG	Off (button out)
POSITION (Horiz)	Midrange
FINE	Midrange

8. Adjust Vertical Output Bias

a. Set the amplitude calibrator for a 20 millivolt output and connect to CH 1 input through a 42-inch 50-ohm BNC cable.

b. ADJUST-Vertical Output Bias, R488, for maximum amplitude of the display. See ADJUSTMENT LOCATIONS 2-B.

c. Disconnect all test equipment.

9. Adjust Vertical Shield Voltage

a. Measure the voltage on each vertical deflection plate with the digital voltmeter. (Take readings at the terminals of the ceramic thick-film resistor mounted near the Vertical Output circuit board.) See ADJUSTMENT LOCATIONS 2-B.

b. While measuring voltage level at the resistor terminals (approximately +34 volts), check the display for a trace and note the voltage on each deflection plate.

NOTE

If trace disappears during voltage measurement, the vertical output circuitry is oscillating with the measuring equipment. To stop the oscillation, connect a small 1,000-ohm resistor between the positive lead of the digital voltmeter and the point being measured. c. Adjust CH 1 POSITION control for equal voltage on both vertical deflection plates and note the final reading.

d. Remove the 1,000-ohm resistor if used, and connect the digital voltmeter positive lead to TP1395. See AD-JUSTMENT LOCATIONS 1.

e. CHECK—For a reading within 0.5 volts of final reading noted in part c.

f. ADJUST---Vertical Shield Volts, R1395, for a reading equal to the final reading noted in part c. See ADJUST-MENT LOCATIONS 1.

NOTE

The preceding procedure is intended to initially set the vertical shield voltage. If the best crt focus is required, readjust Vertical Shield Volts, R1395, FOCUS and ASTIG together for best overall focus.

g. Disconnect all test equipment.

10. Adjust Delay-Line DC Center

a. Connect the digital voltmeter across the delay-line end pins on the vertical preamp circuit board. See ADJUSTMENT LOCATIONS 2-A.

b. Adjust the CH 1 POSITION control for a reading of 0 volts.

c. Connect the digital voltmeter between chassis ground and one of the delay-line end pins.

d. CHECK-For a reading of 0 volts.

 e. ADJUST—Delay-Line DC Centering, R385, for a reading of 0 volts. See ADJUSTMENT LOCATIONS 2-A.

f. Disconnect all test equipment.

11. Adjust CH 1 VAR VOLTS/DIV Balance

a. Set CH 1 POSITION for a trace on the center horizontal graticule line.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk b. CHECK—That the CH 1 UNCAL light turns on when the CH 1 VAR VOLTS/DIV control is out of calibrated detent.

c. CHECK—The display for 2 divisions or less of trace shift when turning the CH 1 VAR VOLTS/DIV control through its range.

d. ADJUST—CH 1 Variable Balance, R110, for minimum shift when turning the CH 1 VAR VOLTS/DIV control through its range. See ADJUSTMENT LOCATIONS 2-A.

e. Return CH 1 VAR VOLTS/DIV control to calibrated detent.

12. Adjust CH 1 VOLTS/DIV Balance

a. CHECK—The display for 0.5 division or less of trace shift when switching CH 1 VOLTS/DIV from 10 mV to 5 mV.

b. ADJUST-CH 1 VOLTS/DIV Balance, R135, for minimum trace shift when switching CH 1 VOLTS/DIV from 10 mV to 5 mV. See ADJUSTMENT LOCATIONS 2-A.

13. Adjust CH 2 VAR VOLTS/DIV Balance

a. Set VERT MODE to CH 2, set CH 2 VOLTS/DIV to 10 mV and adjust CH 2 POSITION for a trace on the center horizontal graticule line.

b. CHECK—That the CH 2 UNCAL light turns on when the CH 2 VAR VOLTS/DIV control is out of calibrated detent.

c. CHECK—The display for 2 divisions or less of trace shift when turning the CH 2 VAR VOLTS/DIV control through its range.

d. ADJUST-CH 2 Variable Balance, R210, for minimum trace shift when turning the CH 2 VAR VOLTS/DIV control through its range. See ADJUSTMENT LOCATIONS 2-A.

e. Return the CH 2 VAR VOLTS/DIV control to calibrated detent.

14. Adjust CH 2 VOLTS/DIV Balance

a. CHECK—The display for 0.5 division or less of trace shift when switching CH 2 VOLTS/DIV from 10 mV to 5 mV.

b. ADJUST-CH 2 VOLTS/DIV Balance, R235, for minimum trace shift when switching CH 2 VOLTS/DIV from 10 mV to 5 mV. See ADJUSTMENT LOCATIONS 2-A.

15. Adjust CH 2 INVERT Balance

a. Set CH 2 VOLTS/DIV to 10 mV and adjust CH 2 POSITION for a trace on the center horizontal graticule line.

b. CHECK—The display for 1 division or less of trace shift when INVERT pushbutton is pressed from normal to inverted.

c. ADJUST—Invert Balance, R215, for minimum trace shift when INVERT pushbutton is pressed from normal to inverted. See ADJUSTMENT LOCATIONS 2-A.

d. Return INVERT pushbutton to normal (button out).

16. Adjust CH 2 POSITION Centering

a. Set CH 2 VOLTS/DIV to 20 mV and set AC-GND-DC switch to AC.

NOTE

See test equipment required, Table 6-1, for selection of sine-wave generator with an output of 100 megahertz and below.

b. Connect the sine-wave generator output cable through a 50-ohm termination to CH 2 input.

c. Set the sine-wave generator for a 6 division, 350kilohertz display, then set CH 2 VOLTS/DIV to 5 mV.

d. CHECK—That top of display can be positioned at least to the center horizontal graticule line and that bottom of display can be positioned at least to the center horizontal graticule line.

e. ADJUST—CH 2 Position Centering, R276, so the top and bottom of display can be positioned through the center horizontal graticule line an equal amount. See ADJUSTMENT LOCATIONS 2-A.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enguiries@mauritron.co.uk

17. Adjust CH 1 Position Centering

a. Set VERT MODE to CH 1, set CH 1 VOLTS/DIV to 20 mV and AC-GND-DC switch to AC.

b. Move test signal cable to CH 1 input.

c. Set the sine-wave generator for a 6 division display, then set CH 1 VOLTS/DIV to 10 mV.

d. CHECK—That top of display can be positioned at least to the center horizontal graticule line and that bottom of display can be positioned at least to the center horizontal graticule line.

e. ADJUST—CH 1 Position Centering, R176, so the top and bottom of display can be positioned through the center horizontal graticule line an equal amount. See ADJUSTMENT LOCATIONS 2-A.

f. Disconnect all test equipment.

18. Check CH 1 and CH 2 AC-GND-DC Functions

a. Set CH 1 and CH 2 AC-GND-DC switches to DC, set amplitude calibrator for a 20 millivolt output and connect to CH 1 input through a 42-inch 50-ohm BNC cable.

b. Position the bottom of CH 1 display to the center horizontal graticule line.

c. Set CH 1 AC-GND-DC switch to GND.

d. CHECK—For no vertical deflection and that trace is at center horizontal graticule line.

e. Set CH 1 AC-GND-DC switch to AC.

f. CHECK-That display is centered in graticule area.

g. Move test signal cable to CH 2 input and set VERT MODE to CH 2.

h. Position the bottom of CH 2 display to the center horizontal graticule line.

i. Set CH 2 AC-GND-DC switch to GND.

6-14

j. CHECK—For no vertical deflection and that trace is at center horizontal graticule line.

k. Set CH 2 AC-GND-DC switch to AC.

- I. CHECK-That display is centered in graticule area.
- m. Disconnect all test equipment.

19. Check Scale-Factor Indicator Lights

a. CHECK-That the light under 10 mV of CH 2 VOLTS/DIV knob is on.

b. Connect a 10X probe with a scale-factor switching connector to CH 2 input.

NOTE

Use a probe listed in test equipment required, Table 6-1, under test oscilloscope examples.

c. CHECK—That the light under 10 mV is extinguished and the light under .1 V comes on.

d. Set VERT MODE to CH 1.

e. CHECK—That the light under 10 mV of CH 1 VOLTS/DIV knob is on.

f. Move the 10X probe to CH 1 input.

g. CHECK—That the light under 10 mV is extinguished and the light under .1 V comes on.

h. Remove the 10X probe.

20. Adjust CH 1 Gain and Vertical Output Gain

a. Set VERT MODE to CH 1, set CH 1 VOLTS/DIV to 5 mV and set CH 1 AC-GND-DC switch to DC.

b. Set the amplitude calibrator for a 20 millivolt output and connect to CH 1 input through a 42-inch 50-ohm BNC cable.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@maunitron.co.uk

c. Set the test oscilloscope: time/div to 1 millisecond, both volts/div to 5 millivolts, vertical mode to add, Channel 2 to invert and trigger source to normal.

d. Connect both 10X probes from the test oscilloscope to the delay-line end pins on the Vertical Preamp circuit board. See ADJUSTMENT LOCATIONS 2-A.

e. ADJUST-CH 1 5 mV Gain, R195, for 200 millivolts peak-to-peak (4 divisions of display) on the test oscillo-scope. See ADJUSTMENT LOCATIONS 2-A.

f. Disconnect the 10X probes from delay line.

g. ADJUST—Vertical Output Gain, R449, for exactly 4 divisions of amplitude. See ADJUSTMENT LOCATIONS 2-B.

h. Set CH 1 VOLTS/DIV to 10 mV and set the amplitude calibrator for a 50 millivolt output.

i. ADJUST-CH 1 10 mV Gain, R165, for exactly 5 divisions of amplitude. See ADJUSTMENT LOCATIONS 2-A.

j. CHECK—All settings of CH 1 VOLTS/DIV for accuracy, within 3%, using the settings listed in Table 6-3.

TABLE 6-3

Vertical Deflection Accuracy

VOLTS/DIV Switch Setting	Amplitude Calibrator Output	Vertical Deflection in Divisions	Maximum Error for 3% Accuracy
5 mV	20 millivolts	4	
10 mV	50 millivolts		Previously set
20 mV		5	Previously set
50 mV	0.1 volts	5	±0.15 div
	0.2 volts	4	±0.12 div
0.1 V	0.5 volts	5	±0.15 div
0.2 V	1 volts	5	±0.15 div
0.5 V	2 volts		
1 V	5 volts	4	±0.12 div
2 V		5	±0.15 div
	10 volts	5	±0.15 div
5 V	20 volts	4	±0.12 div
10 V	50 volts	5	±0.12 div

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquines@mauritron.co.uk

21. Adjust CH 2 Gain

a. Set VERT MODE to CH 2, set CH 2 VOLTS/DIV to 5 mV and set CH 2 AC-GND-DC switch to DC.

b. Set the amplitude calibrator for a 20 millivolt output and move signal cable to CH 2 input.

c. ADJUST—CH 2, 5 mV Gain, R295, for exactly 4 divisions of amplitude. See ADJUSTMENT LOCATIONS 2-A.

d. Set CH 2 VOLTS/DIV to 10 mV and set the amplitude calibrator for a 50 millivolt output.

e. ADJUST-CH 2, 10 mV Gain, R265, for exactly 5 divisions of amplitude. See ADJUSTMENT LOCATIONS 2-A.

f. Press CH 2 INVERT pushbutton to invert CH 2 display.

g. CHECK—That inverted gain is equal to normal gain within 1% (0.04 division).

h. Return CH 2 INVERT pushbutton to normal (button out).

i. CHECK---All settings of CH 2 VOLTS/DIV for accuracy within 3% using the settings listed in Table 6-3.

22. Check CH 1 and CH 2 VAR VOLTS/DIV Range

a. Set the amplitude calibrator to 50 millivolts and set CH 1 and CH 2 VOLTS/DIV to 10 mV.

b. Turn CH 2 VAR VOLTS/DIV fully counterclockwise.

c. CHECK—That display reduces to less than 2 divisions of amplitude.

d. Return CH 2 VAR VOLTS/DIV to calibrated detent.

e. Set VERT MODE to CH 1 and move signal cable to CH 1 input.

f. Turn CH 1 VAR VOLTS/DIV fully counterclockwise.

g. CHECK-That display reduces to less than 2 divisions of amplitude.

h. Return CH 1 VAR VOLTS/DIV to calibrated detent.

23. Check ADD Mode Operation

a. Set VERT MODE to ADD and set CH 1 and CH 2 VOLTS/DIV to 10 mV.

b. Remove the test signal cable from CH 1 input. Connect to the cable; a BNC female-to-BNC female adapter, a BNC T-connector, two 18-inch 50-ohm BNC cables, then the CH 1 and CH 2 inputs.

c. Set the amplitude calibrator for a 20 millivolt output and center display on graticule using equal settings of CH 1 and CH 2 POSITION controls.

d. CHECK—For a display of 4 divisions within 3% (0.12 division).

e. Remove the test signal cables.

24. Check Compression and Expansion

a. Set VERT MODE to CH 1.

b. Connect 20 millivolts of output from amplitude calibrator to CH 1 input through a 42-inch 50-ohm BNC cable and note exact amplitude of the display at graticule center.

c. Position top of display to the top graticule line.

d. CHECK—The display for 0.1 division or less of compression or expansion.

e. Position bottom of display to the bottom graticule line.

f. CHECK-The display for 0.1 division or less of compression or expansion.

g. Move the test signal cable to CH 2 input, set VERT MODE to CH 2 and note exact amplitude of the 2 division display at graticule center.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd Chimogr (Cherry Tree Rd Cherry Tree Rd Cherry Tree Rd Cherry (Cherry Tree Rd Cherry Tree Rd Cherry (Cherry Tree Rd Cherry Tree Rd Cherry (Cherry (Ch

i. CHECK-The display for 0.1 division or less of compression or expansion.

j. Position bottom of display to the bottom graticule line.

k. CHECK-The display for 0.1 division or less of compression or expansion.

25. Check Cascaded Gain

a. Set VERT MODE to CH 1 and set CH 1 and CH 2 VOLTS/DIV to 5 mV.

b. Set the amplitude calibrator for an output of 10 millivolts into CH 2 input.

c. Connect a 42-inch 50-ohm BNC cable from CH 2 VERT SIGNAL OUT (on rear panel), through a 50-ohm termination to CH 1 input.

d. CHECK-For a display of 4 divisions within 1 division.

e. Disconnect all test equipment.

26. Check ALT Mode Operation

a. Set VERT MODE to ALT, set 100 OR 20 MHz BW control to full bandwidth position and set A TRIGGER LEVEL fully clockwise.

b. Position the 2 traces approximately 4 divisions apart.

c. CHECK—That the sweeps alternate at all settings of TIME/DIV except X-Y.

27. Check CHOP Mode Operation

a. Set VERT MODE to CHOP, set TIME/DIV to 1 μ s, set CH 1 and CH 2 AC-GND-DC switches to GND and adjust A TRIGGER LEVEL for a stable display.

b. CHECK—For complete blanking of switching transients between chopped segments.

REV. A, SEPT. 1976

c. CHECK-That the duration of one cycle is approximately 1 division.

28. Adjust High-Frequency Compensation

a. Set CH 1 and CH 2 VOLTS/DIV to 10 mV, set VERT MODE to CH 1, set TIME/DIV to 20 μ s and set CH 1 and CH 2 AC-GND-DC switches to DC.

b. Connect the square-wave generator fast-rise + output through a GR-to-BNC female adapter, to a 42-inch 50-ohm BNC cable, to a 10X BNC attenuator, to a 50-ohm termination, to CH 1 input.

c. Set the square-wave generator for a 5 division, 10 kilohertz display.

d. CHECK—The display for a flat-top waveform within +4%, -4%, or a total of 4% aberrations.

e. ADJUST—R109 for the best flat-top waveform in the first 20 microseconds from front corner. See ADJUST-MENT LOCATIONS 2-A.

f. ADJUST—R494B for the best flat-top waveform in the first 15 microseconds (approximately) from front corner. See ADJUSTMENT LOCATIONS 2-B.

NOTE

R494B is a factory optional component and may not appear in your instrument.

g. Set TIME/DIV to 10 µs.

h. ADJUST-R139 for a flat-top waveform in the first 5 microseconds from front corner. See ADJUSTMENT LOCATIONS 2-A.

i. Set TIME/DIV to 5 μ s.

j. ADJUST----R475 for a flat-top waveform in the first 2 microseconds from front corner. See ADJUSTMENT LOCATIONS 2-B.

k. Set the square-wave generator repetition rate to 100 kilohertz.

I. Set TIME/DIV to 0.5 μs.

For Service Manuals Ophilact MAURITRON TECHNICAL SERVICES 8 Cherry Tres Rd Channer Oxon OX9 405 Tel: 01844-351654 East, f. Rda Decision Email: enquines@machiltenco.c 6-17

m. CHECK—The display for a flat-top waveform within +4%, -4%, or a total of 4% aberrations.

n. ADJUST—C471, for a flat-top waveform in the first 200 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2-B.

o. Set TIME/DIV to 0.1 μ s.

p. ADJUST—C477 for a flat-top waveform in the first 50 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2-B.

q. Set VERT MODE to CH 2, set TIME/DIV to 20 $\mu s,$ and move test signal from CH 1 input to CH 2 input.

r. Adjust the square-wave generator for a 5 division, 10 kilohertz display.

s. CHECK—The display for a flat-top waveform within +4%, -4%, or a total of 4% aberrations.

t. ADJUST—R209 for the best flat-top waveform in the first 20 microseconds from front corner. See ADJUST-MENT LOCATIONS 2-A.

u. Set TIME/DIV to 10 μ s.

v. ADJUST—R239 for a flat-top waveform in the first 5 microseconds from front corner. See ADJUSTMENT LOCATIONS 2-A.

w. Set TIME/DIV to 5 µs.

x. ADJUST—R475 for the best flat-top waveform in both CH 1 and CH 2 in the first 2 microseconds from front corner. See ADJUSTMENT LOCATIONS 2-B.

y. Set the square-wave generator repetition rate to 100 kilohertz.

z. Set TIME/DIV to 0.5 μ s.

aa. CHECK—The display for a flat-top waveform within +4%, -4%, or a total of 4% aberrations.

ab. ADJUST—C471 for the best flat-top waveform in both CH1 and CH2 in the first 200 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2-B.

ac. Set TIME/DIV to 0.1 µs.

ad. ADJUST—C477 for the best flat-top waveform in both CH 1 and CH 2 in the first 50 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2-B.

ae. Repeat parts u through ad if necessary for the best flat-top waveform in both CH 1 and CH 2.

af. Disconnect all test equipment.

For Service Manuals Centeet MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tet- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV. A, APR. 1977

ţ

29. Check/Adjust CH 1 VOLTS/DIV Compensation

NOTE

C10, in the CH 1 Preamp, is set at the factory to give C50, in the CH 2 Preamp, enough range to match CH 2 input capacitance with CH 1 input capacitance. Unless there is a circuit malfunction, C10 should not need readjustment. When adjusting C10, C50 or other adjustments in this section, if the low-capacity screwdriver contains a metal bit, the metal may affect the adjustment. Check adjustment after the screwdriver is removed, and re-adjust as necessary.

a. Set: VOLTS/DIV (both)	10 mV (see note)
VERT MODE	CH 1
A TIME/DIV	.2 ms (see note)
100 OR 20 MHz (PULL)	20 MHz (shows yellow)

NOTE

In Steps 29 and 30 all VOLTS/DIV settings assume the use of a 10X probe with Scale-Factor switching (preferably the probe supplied as a standard accessory with the oscilloscope you are calibrating). If it is necessary to use a 10X probe without Scale-Factor switching, set the VOLTS/DIV knob to indicate one tenth of the setting listed (10 mV instead of .1 V etc). When adjusting compensation, one adjustment will affect the waveform front corner, and another will affect the flat top. Ignore the front corner when making the flat top adjustment and vice-versa. The A TIME/DIV should be set to 1 ms for the flat top, and to .2 ms for front corner checks and adjustments.

b. Connect a 10X probe to the CH 1 input (note that the VOLTS/DIV Scale-Factor switching will now indicate .1 V).

c. Connect the square-wave generator high-amplitude output to a 2X, 5X, or 10X BNC attenuator (depending on generator amplitude), to a 50 Ω termination, to a BNC-to-probe tip adapter, to the tip of the 10X probe.

Calibration—475A Service

d. Adjust the square-wave generator for a 5 division, 1 kilohertz display and add or remove attenuators and termination as needed to maintain a 5 division display throughout Steps 29 and 30.

e. Adjust the probe compensation adjustment for the best flat-top waveform. Do not re-adjust probe compensation throughout the remainder of Steps 29 and 30.

f. Set VOLTS/DIV to 50 mV.

g. CHECK—The display for a flat-top waveform within 2%.

h. Set VOLTS/DIV to .2 V.

i. CHECK—Compensation for all VOLTS/DIV settings listed in the VOLTS/DIV COMPENSATION table for display overshoot, roll-off, and flat-top within 2% (5 div ± 0.1 div). If all settings are within 2%, skip part j, otherwise perform part j.

j. ADJUST—any adjustment pair (see Table) as necessary so compensation for all settings is within 2%.

VOLTS/DIV	COMPENSATION
-----------	--------------

	Ad	djust
VOLTS/DIV Setting (10X Scale-Factor)	(T/Div 1 ms) Flat	(T/Div .2 ms) Corner
.2 V	C37	C36
.5 V	C35	C34
1 V	C33	C32
2 V	Check	Check
5 V	Check	Check
10 V	C31	C30

NOTE

If the oscilloscope is to be used primarily with a 50 ohm signal source, more accurate reproduction of the waveform front corner may be achieved by calibrating with a 50 ohm system. To accomplish this, substitute a properly terminated 50 ohm cable for the 10X probe while making the corner adjustments listed in VOLTS/DIV COMPENSATION table.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Charry Tree, Bd. Chinnor

30. Adjust CH 2 VOLTS/DIV Compensation

a. Set: VERT MODE CH 2

b. Transfer the 10X probe from the CH 1 input to the CH 2 input.

c. Adjust the square-wave generator for a 5 division, 1 kilohertz display and add or remove attenuators and termination as needed to maintain a 5 division display throughout the remainder of this step.

d. CHECK—The display for a flat-top waveform within 2%.

e. ADJUST-C50 in the CH 2 preamp for the best flattop waveform using a low-capacitance screwdriver.

f. Repeat Step 29 parts f through j for CH 2.

g. Disconnect test setup.

31. Adjust Vertical Transient Response

a. Set CH 1 and CH 2 VOLTS/DIV to 10 mV, set VERT MODE to CH 1 and TIME/DIV to 0.01 μ s and set 100 OR 20 MHz BW control to full bandwidth position.

b. Connect a 100 kilohertz signal from the squarewave generator high amplitude output through a GR-to-BNC female adapter and a 42-inch 50-ohm BNC cable to the input of the tunnel diode pulser calibration fixture. Connect the output of the tunnel diode pulser through a 5X BNC attenuator and a 50-ohm termination to the CH 1 input.

c. Increase the square-wave generator amplitude and adjust the pulser triggered level until the display suddenly increases to about 4.6 divisions of amplitude; do not overdrive. Use the resultant positive-step amplitude to check or adjust vertical response. Keep VAR VOLTS/DIV in calibrated detent.

d. CHECK—The display for flat-top and aberrations within +4%, -4%, or a total of 4% in the first 10 nanoseconds from front corner.

e. ADJUST—R450, C450, R470, C470, R175, C175, R112, C112, R466, C466, R133 and C133 for a flat-top waveform and aberrations within 4%, in the first 20 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2. Use the low capacitance screwdriver to adjust variable capacitors. NOTE

f. CALIBRATION AID—Set R450 for minimum resistance (fully counterclockwise). Adjust C450 fo minimum aberrations with a fast leading edge. Set R47(near maximum resistance (near clockwise stop). Adjus C470 for the best flat-top display, 5 to 10 nanoseconds from front corner. Set R175 near maximum resistance (near clockwise stop). Adjust C175 for the best flat-top display 10 to 20 nanoseconds from front corner. Set R112 near minimum resistance (near counterclockwise stop). Adjust C112 for uniform aberrations. Adjust R466, C466, R133 and C133 for best aberrations and flat-top display. Adjust C450 for a fast leading edge and best response.

g. INTERACTION—All transient response adjustments interact in this step. Repeat the adjustment procedure in part e, as necessary to obtain optimum response.

h. Set CH 1 VOLTS/DIV to 50 mV and remove the 5X attenuator from the test signal setup. Note the slope, if slope exists, in the first 2 nanoseconds from the front corner.

i. ADJUST—C104 for the same slope between the 10 mV and 50 mV positions of the CH 1 VOLTS/DIV in the first 2 nanoseconds from the front corner. See ADJUST-MENT LOCATIONS 2-A.

j. Set CH 1 VOLTS to 10 mV and replace the 5X attenuator in the test-signal setup.

k. ADJUST—C175 for a flat-top waveform in the first 2 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2-A.

I. Set VERT MODE to CH 2 and move test signal setup to CH 2 input.

m. CHECK—The display for flat-top and aberrations within $\pm 4\%$, -4%, or a total of 4% in the first 10 nanoseconds from front corner.

n. ADJUST—R275, C275, R212, C212, R233 and C233 for a flat-top waveform and aberrations within 4%, in the first 20 nanoseconds from front corner. See ADJUST-MENT LOCATIONS 2-A.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

o. CALIBRATION AID—Set R275 near maximum resistance (near clockwise stop). Adjust C275 for the best flat-top display, 10 to 20 nanoseconds from front corner. Set R212 near minimum resistance (near counterclockwise stop). Adjust C212 for uniform aberrations. Adjust R233 and C233 for the best aberrations and flat-top display.

p. INTERACTION—All transient response adjustments interact in this step. Repeat part n, as necessary, to obtain optimum response.

q. CALIBRATION AID—It may be necessary to readjust R450, C450, R470, C470, R466 and C466 for a flat-top display and aberrations within 4% in both CH 1 and CH 2. Readjust as necessary, using part f calibration aid.

r. Set CH 2 VOLTS/DIV to 50 mV and remove the 5X attenuator in the test-signal setup. Note the slope, if slope exists, in the first 2 nanoseconds from the front corner.

s. ADJUST-C204 for the same slope between 10 mV and 50 mV positions of CH 2 VOLTS/DIV in the first 2 nanoseconds from the front corner. See ADJUSTMENT LOCATIONS 2-A.

t. Set CH 2 VOLTS/DIV to 10 mV and replace the 5X attenuator in the test-signal setup.

u. ADJUST---C275 for a flat-top waveform in the first 2 nanoseconds from front corner. See ADJUSTMENT LOCATIONS 2-A.

v. Disconnect all test equipment.

32. Check Vertical Amplifier Bandwidth

a. Set CH1 and CH 2 VOLTS/DIV to 10 mV, set VERT MODE to CH 1 and TIME/DIV to 0.5 ms.

NOTE

See test equipment required, Table 6-1, for selection of sine-wave generator with a 250 megahertz output.

 b. Connect the sine-wave generator output cable to a 5X BNC attenuator, to a 50 ohm termination, to CH 1 input.

REV. A, DEC. 1977

c. Set the sine-wave generator for a 6 division display of reference frequency.

NOTE

If generator has no reference frequency setting, set for 5 megahertz. If generator being used is other than the generators listed in Test Equipment required, Table 6-1, more attenuation may be needed to reduce amplitude.

d. Increase frequency until the display is reduced to 4.2 divisions.

e. CHECK—For a reading of 250 megahertz or more.

f. Set VERT MODE to CH 2 and move test signal setup from CH1 input to CH2 input.

g. Repeat the bandwidth check procedure, parts c, d and e.

33. Check Bandwidth Limit Operation

a. Set 100 OR 20 MHz BW control to 100.

NOTE

It may be necessary to change sine-wave generators. See Table 6-1 for selection of generator with an output of 100 megahertz and below.

b. Set the sine-wave generator for a 6 division display of reference frequency.

c. Increase frequency until the display is reduced to 4.2 divisions.

d. CHECK—For a reading of approximately 100 megahertz.

e. Set 100 OR 20 MHz BW control to 20.

f. Set the sine-wave generator for a 6 division display of reference frequency.

g. Increase frequency until the display is reduced to 4.2 divisions.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Emeil:- enquiries@mauritron.co.uk

6-21

h. CHECK—For a reading of approximately 20 megahertz.

i. Return 100 OR 20 MHz BW control to full bandwidth.

34. Check Cascaded Bandwidth

a. Set VERT MODE to CH 1.

b. Connect CH 2 VERT SIGNAL OUT (output connector on rear panel) through a 42-inch 50-ohm BNC cable, to a 50-ohm termination and connect to CH 1 input.

c. Set the sine-wave generator for a 6 division display of reference frequency.

d. Increase frequency until the display is reduced to 4.2 divisions.

e. CHECK—For a reading of 50 megahertz or more.

f. Disconnect cable and termination from CH 2 VERT SIGNAL OUT and CH 1 input. Remove 5X attenuator from test signal setup.

35. Check Vertical Channel Isolation

a. Set CH 2 VOLTS/DIV to 0.2 V and CH 1 AC-GND-DC switch to GND.

b. Set the sine-wave generator for a 4 division, 50 megahertz display.

c. Set CH 1 and CH 2 VOLTS/DIV to 20 mV and set VERT MODE to CH 1.

d. CHECK—The display amplitude for 0.4 division or less.

e. Set CH 1 AC-GND-DC switch to DC, set CH 2 AC-GND-DC switch to GND and set VERT MODE to CH 2.

f. Move test signal setup from CH 2 input to CH 1 input.

g. CHECK-The display amplitude for 0.4 division or less.

h. Disconnect all test equipment.

TRIGGER SYSTEM

Equipment Required	10. GR-To-BNC Female Adapter	
1. Sine-Wave Generator	11. GR-To-BNC Male Adapter	
2. Low-Frequency Generator	12. BNC Female-To-BNC Female Adapter	
3. Amplitude Calibrator		
4. Square-Wave Generator	13. BNC Elbow	
5. Time-Mark Generator	14. BNC T-Connector	
6. Tunnel-Diode Pulser Calibration Fixture	15. 10X BNC Attenuator	
7. 50-Ohm Signal Pickoff	16. 5X BNC Attenuator	
8. 42-Inch 50-Ohm BNC Cable	17. 50-Ohm BNC Termination (2 required)	
9. 18-Inch 50-Ohm BNC Cable (2 required)	18. Screwdriver	

Before you begin, see

ADJUSTMENT LOCATIONS 2&3

in the pullout pages.

REV. A, DEC. 1977

a. Connect the sine-wave generator output cable through a GR-to-BNC female adapter to the through signal input of the 50-ohm signal pickoff. Connect the through signal output of the signal pickoff to a GR-to-BNC male adapter, to a 10X BNC attenuator, to a 50-ohm BNC termination, to a BNC elbow, to A TRIGGER external

b. Connect the 10% signal output of the signal pickoff to an 18-inch 50-ohm BNC cable, to a 50-ohm termination, to CH 1 input.

c. Set the sine-wave generator for a 3.5 division, 350 kilohertz display. (35 millivolts at external input).

d. Set CH 1 VOLTS/DIV to 20 mV and position the display start to graticule center with POSITION (Horiz).

e. Turn A TRIGGER LEVEL slowly counterclockwise through the range of stable triggering and note maximum amplitude of positive slope before the first peak of displayed waveform. See Figure 6-2.

f. CHECK—The triggered display for an amplitude of 0 to 0.2 division of positive slope before the first peak of displayed waveform when turning A TRIGGER LEVEL slowly counterclockwise through the range of stable triggering. See Figure 6-2.

NOTE

The preceding check is for calibration purposes only, if unable to obtain a proper display (as described in part f), check trigger operation as directed in performance check section to determine if trigger sensitivity needs adjustment.





For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Control Settings

POWER

Display

ON

INTENSITY	Midrange
FOCUS	Midrange
SCALE ILLUM	Midrange

Vertical (CH 1 and CH 2)

POSITION
VOLTS/DIV
VAR VOLTS/DIV
AC-GND-DC
INVERT
VERT MODE
100 OR 20 MHz BW

Midrange 10 mV (new setting) Calibrated detent DC (new setting) Off (button out) CH 1 (new setting) Full bandwidth (push in, then release)

Trigger (A and B)

COUPLING	AC
LEVEL	0
SLOPE	+
A TRIGGER SOURCE	EXT (new setting)
B TRIGGER SOURCE	STARTS AFTER DELAY
TRIG MODE	AUTO
A TRIGGER HOLDOFF	NORM

Sweep

A TIME/DIV **B TIME/DIV** VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY X10 MAG POSITION (Horiz) FINE

> 2 µs (new setting) 2 µs (new setting) Calibrated detent Fully counterclockwise Α Off (button out) Midrange Midrange

36. Adjust A Trigger Sensitivity, Symmetry and Centering

NOTE

See test equipment required, Table 6-1, for selection of sine-wave generator with an output of 100 megahertz and below.

g. ADJUST—A Trigger Sensitivity, R565, for a maximum amplitude of 0.2 division of positive slope before the first peak of displayed waveform when turning A TRIGGER LEVEL slowly counterclockwise through the range of stable triggering. See ADJUSTMENT LOCATIONS 3.

NOTE

After adjustment of R565, set TRIG MODE to NORM, A TRIGGER SOURCE to NORM, VERT MODE to CH 2, and CH 2 VOLTS/DIV to 10 mV. Rotate A TRIGGER LEVEL throughout its range and check for no visible trace. If there is a trace at any LEVEL setting, slightly readjust R565 until the trace just disappears. (If R565 required readjustment, complete the Trigger System Calibration Steps through Step 59 then perform Steps 11 through 19 of the Performance Check and if any of the Trigger System Performance Check Requirements are not met, repeat Calibration Step 36 and readjust as necessary to ensure that the instrument meets all A TRIGGER Performance Requirements.)

Set TRIG MODE to AUTO, A TRIGGER SOURCE to EXT, and VERT MODE to CH 1, then proceed to Step 36, part h.

h. Set CH 1 VOLTS/DIV to 50 mV.

i. Set the sine-wave generator for a 4 division, 350 kilohertz display (200 millivolts at external input) and center the display on center horizontal graticule line.

j. Set A TRIGGER SLOPE to - and set A TRIGGER LEVEL for a triggered display.

NOTE

The following parts k, I and m require that a short circuit be placed between the 2 terminals at the rear of A TRIGGER SLOPE/LEVEL control. (A short circuit allows viewing of + and - slope without disturbing A TRIGGER LEVEL. Any convenient way of shorting the terminals may be used; screwdriver tip, alligator clip, etc).

k. Note where the display starts on first negative slope, short together the rear terminals of A TRIGGER SLOPE/LEVEL control and note where the display starts on first positive slope.

I. CHECK—For a 0.5 division of over ap to 2 divisions of space between the start of negative slope and the start of positive slope. See Figure 6-3.

m. ADJUST—A Trigger Symmetry, R547, for 0.7 division of space between the start of negative slope and the start of positive slope. (Apply and remove the short circuit between the terminals several times while making adjustment.) See ADJUSTMENT LOCATIONS 3.

n. Set CH 1 VOLTS/DIV to 0.5 V, set A TRIGGER SLOPE to +, set A TRIGGER SOURCE to NORM and set A TRIGGER LEVEL for a stable triggered display.

o. CHECK-TRIG light for an on indication.

p. CHECK—That A TRIGGER LEVEL knob index is approximately aligned with 0 on front panel.

NOTE

If A TRIGGER LEVEL knob index is aligned with 0, preceed with part s.

q. Set A TRIGGER LEVEL knob index to 0.

r. ADJUST—A Trigger Centering, R534, for a stable triggered display. See ADJUSTMENT LOCATIONS 3.

s. INTERACTION—Between A Trigger Sensitivity, A Trigger Symmetry and A Trigger Centering adjustments. Repeat the adjustments as necessary.

37. Adjust B Trigger Sensitivity, Symmetry and Centering

a. Disconnect the test signal setup from A TRIGGER external input and connect to B TRIGGER external input.

b. Set CH 1 VOLTS/DIV to 10 mV, set B TRIGGER SOURCE to EXT and set HORIZ DISPLAY to B DLY'D.

c. Set the sine-wave generator for a 3.5 division, 350 kilohertz display (35 millivolts at external input), then set CH 1 VOLTS/DIV to 20 mV.

d. Turn B TRIGGER LEVEL slowly counterclockwise through the range of stable triggering and note maximum amplitude of positive slope before the first peak of displayed waveform. See Figure 6-2.

e. CHECK—The triggered display for a full length sweep and for an amplitude of 0 to 0.2 division of positive slope before the first peak of displayed waveform when turning B TRIGGER LEVEL slowly counterclockwise through the range of stable triggering. See Figure 6-2.



Fig. 6-3. Typical display when checking Trigger Symmetry.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk REV A SEP 1980

NOTE

The preceding check is for calibration purposes only. If unable to obtain a proper display (as described in part e), check trigger operation as directed in performance check section to determine if trigger sensitivity needs adjustment.

f. ADJUST—B Trigger Sensitivity, R785, for a maximum amplitude of 0.2 division of positive slope before the first peak of displayed waveform and for a full length sweep, when turning B TRIGGER LEVEL slowly counterclockwise through the range of stable triggering. See ADJUSTMENT LOCATIONS 3.

NOTE

After adjustment of R785, set TRIG MODE to NORM, B TRIGGER SOURCE to NORM, VERT MODE to CH 2, and CH 2 VOLTS/DIV to 10 mV. Rotate B TRIGGER LEVEL throughout its range and check for no visible trace. If there is a trace at any LEVEL setting, slightly readjust R785 until the trace just disappears. (If R785 required readjustment, complete the Trigger System Calibration Steps through Step 59 then perform Steps 11 through 19 of the Performance Check and if any of the Trigger System Performance Requirements are not met, repeat Calibration Step 37 and readjust as necessary to ensure that the instrument meets all B TRIGGER Performance Requirements.)

Set TRIG MODE to AUTO, B TRIGGER SOURCE to EXT, and VERT MODE to CH 1; then proceed to Step 37, part g.

g. Set CH 1 VOLTS/DIV to 50 mV.

h. Set the sine-wave generator for a 4 division, 350 kilohertz display (200 millivolts at external input) and center the display on center horizontal graticule line.

i. Set B TRIGGER SLOPE to - and set B TRIGGER LEVEL for a triggered display.

NOTE

The following parts j, k and I require that a short circuit be placed between the 2 terminals at the rear of B TRIGGER SLOPE/LEVEL control. (A short circuit allows viewing of + and - slope without disturbing B TRIGGER LEVEL. Any convenient way of shorting the terminals may be used; screwdriver tip, alligator clip, etc.).

j. Note where the display starts on first negative slope, short together the rear terminals of B TRIGGER SLOPE/LEVEL control and note where the display starts on first positive slope.

k. CHECK—For 0.5 division of overlap to 2 divisions of space between the start of negative slope and the start of positive slope. See Figure 6-3.

I. ADJUST—B Trigger Symmetry, R767, for 0.7 division of space between the start of negative slope and the start of positive slope. (Apply and remove the short circuit between the terminals several times while making adjustment.) See ADJUSTMENT LOCATIONS 3.

m. Set CH 1 VOLTS/DIV to 0.5 V, set B TRIGGER SLOPE to +, set B TRIGGER SOURCE to NORM and set B TRIGGER LEVEL for a stable triggered display.

n. CHECK—That B TRIGGER LEVEL knob index is approximately aligned with 0 on front panel.

NOTE

If B TRIGGER LEVEL knob index is aligned with 0, proceed with part q.

o. Set B TRIGGER LEVEL knob index to 0.

p. ADJUST—B Trigger Centering, R745, for a stable triggered display. See ADJUSTMENT LOCATIONS 3.

q. INTERACTION—Between B Trigger Sensitivity, B Trigger Symmetry and B Trigger Centering adjustments. Repeat the adjustments as necessary.

38. Adjust A Trigger DC Centering

a. Set HORIZ DISPLAY to A, set A TRIGGER SOURCE to NORM, set A TRIGGER COUPLING to DC and set A TRIGGER LEVEL to 0.

b. Set CH 1 POSITION to obtain a stable triggered display.

c. CHECK—That entire display is within the graticule area.

d. Set the display to graticule center with CH 1 POSITION.

e. ADJUST—Normal Trigger DC Centering, R425, for a stable triggered display. See ADJUSTMENT LOCATIONS 2-A.

f. Set A TRIGGER SOURCE to CH 1.

g. Set CH 1 POSITION to obtain a stable triggered display.

h. CHECK—That entire display is within the graticule area.

i. Set the display to graticule center with CH 1 POSITION.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinner Oxon OX9 40Y Tel: 01844-351694 Say: 01844-352554 Email: enquines@mauritron.co.uk

j. ADJUST—Channel 1 DC Trigger Centering, R403, for a stable triggered display. See ADJUSTMENT LOCATIONS 2-A.

k. Set VERT MODE to CH2, set A TRIGGER SOURCE to CH2, set CH2 VOLTS/DIV to 0.5 V and move test signal setup from CH 1 input to CH2 input.

I. Set CH 2 POSITION to obtain a stable triggered display.

m. CHECK-That display is within the graticule area.

39. Check B Trigger DC Centering

a. Set HORIZ DISPLAY to B DLY'D, set B TRIGGER SOURCE to NORM, set B TRIGGER COUPLING to DC and set B TRIGGER LEVEL to 0.

b. Set CH 2 POSITION to obtain a stable triggered display.

c. CHECK-That entire display is within the graticule area.

d. Set B TRIGGER SOURCE to CH 2.

e. Set CH 2 POSITION to obtain a stable triggered display.

f. CHECK—That entire display is within the graticule area.

g. Set VERT MODE to CH 1, set B TRIGGER SOURCE to CH 1 and move test signal setup from CH 2 input to CH 1 input.

h. Set CH 1 POSITION to obtain a stable triggered display.

i. CHECK—That entire display is within the graticule area.

40. Check B Internal 40 Megahertz Triggering

a. Set TIME/DIV to 0.05 $\mu s,$ set CH 1 VOLTS/DIV to 5 mV, set A and B TRIGGER SOURCE to NORM and set A and B TRIGGER COUPLING to AC.

c. Set the sine-wave generator for a 3 division, 40 megahertz display.

d. Set CH 1 and CH 2 VOLTS/DIV to 50 mV and move the display to graticule center with CH 1 POSITION.

e. Set VERT MODE to CH 2 and move the display to graticule center with CH 2 POSITION.

f. Return VERT MODE to CH 1.

g. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

h. Return B TRIGGER COUPLING to AC.

i. CHECK—That a stable triggered display can be obtained in NORM, CH 1 and CH 2 positions of B TRIGGER SOURCE with adjustment of B TRIGGER LEVEL.

j. Return B TRIGGER SOURCE to NORM.

41. Check A Internal 40 Megahertz Triggering

a. Set HORIZ DISPLAY to A, set A TRIGGER SOURCE to NORM and set A TRIGGER COUPLING to AC.

b. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

c. Return A TRIGGER COUPLING to AC.

d. CHECK—That a stable triggered display can be obtained in NORM, CH 1 and CH 2 positions of A TRIGGER SOURCE with adjustment of A TRIGGER LEVEL.

e. Return A TRIGGER SOURCE to NORM.

42. Check A Internal 250 Megahertz Triggering

a. Set the sine-wave generator for a 2.0 division, 250 megahertz display.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk @

NOTE

It may be necessary to change to a sine-wave generator with a 250 megahertz output.

Trigger jitter is measured horizontal trace excursion minus normal horizontal trace width observed at low frequency.

b. Set TIME/DIV to 0.01 μs and press X10 MAG to on.

c. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC, LF REJ and DC positions of A TRIGGER COUPLING with adjustments of A TRIGGER LEVEL.

d. Return A TRIGGER COUPLING to AC and set A TRIGGER SOURCE to CH 1.

e. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A TRIGGER LEVEL.

f. Set VERT MODE to CH 2 and set sine-wave generator for a 2.0 division, 250 megahertz display.

g. Set A TRIGGER SOURCE to CH 2.

h. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A TRIGGER LEVEL.

i. Return A TRIGGER SOURCE to NORM.

43. Check B Internal 250 Megahertz Triggering

a. Set HORIZ DISPLAY to B DLY'D.

b. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC, LF REJ, and DC positions of B TRIGGER COUPLING with adjustment of A and B TRIGGER LEVEL controls.

c. Return B TRIGGER COUPLING to AC and set B TRIGGER SOURCE to CH 2.

d. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A and B TRIGGER LEVEL controls.

@

e. Set VERT MODE to CH 1 and set B TRIGGER SOURCE to CH 1.

f. Set the sine-wave generator for a 2.0 division, 250 megahertz display.

g. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A and B TRIGGER LEVEL controls.

44. Check B External 40 Megahertz Triggering

NOTE

It may be necessary to change to a sine-wave generator with an output of 100 megahertz and below.

a. Move test signal setup from CH 2 to B TRIGGER external input.

b. Set TIME/DIV to 0.05 μ s, set CH 1 VOLTS/DIV to 10 mV and return X10 MAG to off (button out).

c. Set the sine-wave generator for a 5 division, 40 megahertz display. (50 millivolts at external input).

d. Set CH 1 VOLTS/DIV to 50 mV and set B TRIGGER SOURCE to EXT.

e. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

45. Check A External 40 Megahertz Triggering

a. Move test signal setup from B TRIGGER external input to A TRIGGER external input.

b. Set HORIZ DISPLAY to A and set A TRIGGER SOURCE to EXT.

c. CHECK---That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

6-27
46. Check A External 250 Megahertz Triggering

NOTE

It may be necessary to change to a sine-wave generator with a 250 megahertz output.

a. Set the sine-wave generator for a 5 division display of reference frequency (250 millivolts at external input), then set to 250 megahertz.

NOTE

If generator has no reference frequency setting, set for 5 megahertz.

b. Set TIME/DIV to 0.01 μ s and press X10 MAG to on.

c. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

d. Replace the X10 BNC attenuator with a 5X BNC attenuator (500 millivolts at external input) and set A TRIGGER COUPLING to LF REJ.

e. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A TRIGGER LEVEL.

47. Check B External 250 Megahertz Triggering

a. Replace the 5X BNC attenuator with a 10X BNC attenuator and move test signal setup from A TRIGGER external input to B TRIGGER external input (250 millivolts at external input).

b. Set A TRIGGER SOURCE to NORM, set A TRIGGER COUPLING to AC and set HORIZ DISPLAY to B DLY'D.

c. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of A and B TRIGGER LEVEL controls.

d. Replace the 10X BNC attenuator with a 5X BNC attenuator (500 millivolts at external input) and set B TRIGGER COUPLING to LF REJ.

e. CHECK—That a stable triggered display, with no more than 0.2 division of jitter, can be obtained with adjustment of A and B TRIGGER LEVEL controls.

f. Disconnect all test equipment.

48. Check B LF REJ, HF REJ and Low-Frequency Triggering

a. Return X10 MAG to off (button out), set B TRIGGER SOURCE to NORM, set TIME/DIV to 50 μs and set CH 1 VOLTS/DIV to 5 mV.

b. Connect the low-frequency generator output to a 42-inch 50-ohm BNC cable, to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch 50-ohm BNC cables, to CH 1 input and B TRIGGER external input.

c. Set the low-frequency generator for a 5 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

d. CHECK—That a stable triggered display can be obtained in LF REJ, HF REJ, DC and AC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

e. Set CH 1 VOLTS/DIV to 5 mV.

f. Set the low-frequency generator for a 3 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

g. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

h. Set the low-frequency generator for a 2 division, 50 kilohertz display, then set B TRIGGER SOURCE to EXT (100 millivolts at external input).

i. CHECK-Repeat part d of this step.

j. Set CH 1 VOLTS/DIV to 10 mV.

k. Set the low-frequency generator for a 5 division, 50 kilohertz display (50 millivolts at external input), then set CH 1 VOLTS/DIV to 50 mV.

I. CHECK--Repeat part g.

m. Set B TRIGGER SOURCE to NORM, set CH 1 VOLTS/DIV to 5 mV, set TIME/DIV to 20 ms and set 100 OR 20 MHz BW control to 20.

n. Set the low-frequency generator for a 5 division, 60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

o. CHECK—That a stable triggered display can be obtained in HF REJ, DC and AC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

p. Set CH 1 VOLTS/DIV to 5 mV.

q. Set the low-frequency generator for a 3 division,60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

r. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

s. Set B TRIGGER COUPLING to LF REJ.

t. CHECK—That a stable triggered display cannot be obtained with adjustment of B TRIGGER LEVEL.

u. Set the low-frequency generator for a 2 division, 60 Hertz display, then set B TRIGGER SOURCE to EXT (100 millivolts at external input).

v. CHECK-Repeat part o.

w. Set the low-frequency generator for a 1 division, 60 Hertz display (50 millivolts at external input).

x. CHECK—That a stable triggered display can be obtained in AC and DC positions of B TRIGGER COUPLING with adjustment of B TRIGGER LEVEL.

y. Set B TRIGGER COUPLING to LF REJ.

z. CHECK-Repeat part t.

aa. Disconnect all test equipment.

NOTE

Use a sine-wave generator with an output of 100 megahertz and below for the following parts.

ab. Connect the sine-wave generator output cable to a BNC female-to-BNC female adapter, to a BNC Tconnector, to two 18-inch 50-ohm BNC cables. Connect an 18-inch cable through a 50-ohm termination to CH 1 input and connect the other 18-inch cable through a 50ohm termination to B TRIGGER external input.

ac. Set TIME/DIV to 0.5 µs.

ad. Set the sine-wave generator for a 2 division, 3 megahertz display (100 millivolts at external input).

ae. Set B TRIGGER COUPLING to HF REJ.

af. CHECK—That a stable triggered display cannot be obtained with adjustment of B TRIGGER LEVEL.

ag. Set CH 1 VOLTS/DIV to 5 mV, set TIME/DIV to 2 μ s and set B TRIGGER SOURCE to NORM.

ah. Set the sine-wave generator for a 5 division, 1 megahertz display, then set CH 1 VOLTS/DIV to 50 mV.

ai. CHECK-Repeat part af.

aj. Disconnect all test equipment.

49. Check A LF REJ, HF REJ and Low-Frequency Triggering

a. Set HORIZ DISPLAY to A, set TIME/DIV to 50 μs and set CH 1 to 5 mV.

b. Connect the low-frequency generator output to a 42-inch 50-ohm BNC cable, to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch 50-ohm BNC cables, to CH 1 input and A TRIGGER external input.

c. Set the low-frequency generator for a 5 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

d. CHECK—That a stable triggered display can be obtained in LF REJ, HF REJ, DC and AC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

e. Set CH 1 VOLTS/DIV to 5 mV.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

f. Set the low-frequency generator for a 3 division, 50 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

g. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

h. Set the low-frequency generator for a 2 division, 50 kilohertz display, then set A TRIGGER SOURCE to EXT (100 millivolts at external input).

i. CHECK-Repeat part d.

j. Set CH 1 VOLTS/DIV to 0.1 V and set A TRIGGER SOURCE to EXT \div 10.

k. Set the low-frequency generator for a 5 division, 50 kilohertz display (500 millivolts at external input), then set CH 1 VOLTS/DIV to 0.5 V.

I. CHECK-Repeat part g.

m. Set CH 1 VOLTS/DIV to 10 mV and set A TRIGGER SOURCE to EXT.

n. Set the low-frequency generator for a 5 division, 50 kilohertz display (50 millivolts at external input), then set CH 1 VOLTS/DIV to 50 mV.

o. CHECK-Repeat part g.

p. Set A TRIGGER SOURCE to NORM, set CH 1 VOLTS/DIV to 5 mV and set TIME/DIV to 20 ms.

q. Set the low-frequency generator for a 5 division,60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

r. CHECK—That a stable triggered display can be obtained in HF REJ, DC and AC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

s. Set CH 1 VOLTS/DIV to 5 mV.

t. Set the low-frequency generator for a 3 division, 60 Hertz display, then set CH 1 VOLTS/DIV to 50 mV.

u. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

v. Set A TRIGGER COUPLING to LF REJ.

w. CHECK—That a stable triggered display cannot be obtained with adjustment of A TRIGGER LEVEL.

x. Set the low-frequency generator for a 2 division, 60 Hertz display, then set A TRIGGER SOURCE to EXT (100 millivolts at external input).

y. CHECK-Repeat part r.

z. Set the low-frequency generator for a 1 division, 60 Hertz display (50 millivolts at external input).

aa. CHECK—That a stable triggered display can be obtained in AC and DC positions of A TRIGGER COUPLING with adjustment of A TRIGGER LEVEL.

ab. Set A TRIGGER COUPLING to LF REJ.

ac. CHECK-Repeat part w.

ad. Disconnect all test equipment.

NOTE

Use a sine-wave generator with an output of 100 megahertz and below for the following.

ae. Connect the sine-wave generator output cable to a BNC female-to-BNC female adapter, to a BNC Tconnector, to two 18-inch 50-ohm BNC cables. Connect an 18-inch cable through a 50-ohm termination to CH 1 input and connect the other 18-inch cable through a 50ohm termination to A TRIGGER external input.

af. Set TIME/DIV to 0.5 μ s.

ag. Set the sine-wave generator for a 2 division, 3 megahertz display (100 millivolts at external input).

ah. Set A TRIGGER COUPLING to HF REJ.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

ai. CHECK—That a stable triggered display cannot be obtained with adjustment of A TRIGGER LEVEL.

aj. Set CH 1 VOLTS/DIV to 5 mV, set TIME/DIV to 2 μ s and set A TRIGGER SOURCE to NORM.

ak. Set the sine-wave generator for a 5 division, 1 megahertz display, then set CH 1 VOLTS/DIV to 50 mV.

al. CHECK-Repeat part ai.

50. Adjust TRIGGER VIEW Centering

a. Set A TRIGGER COUPLING to AC and set A TRIGGER SOURCE to EXT.

b. Set the sine-wave generator for a 1 division, 1 megahertz display (50 millivolts at external input) and adjust A TRIGGER LEVEL for a stable triggered display.

c. Press TRIG VIEW and hold it in.

d. CHECK—That display center is within 1 division of the center horizontal graticule line.

e. ADJUST—Trigger View Centering, R673, to center the display on the center horizontal graticule line. See ADJUSTMENT LOCATIONS 3.

f. Release TRIG VIEW.

g. Disconnect all test equipment.

51. Check TRIG VIEW Deflection Factor

a. Set TIME/DIV to 1 ms.

b. Set the amplitude calibrator for a 200 millivolt output and connect to A TRIGGER external input through a 42-inch 50-ohm BNC cable.

c. Press TRIG VIEW and hold it in.

d. Position the display to graticule center with A TRIGGER LEVEL.

e. CHECK—For approximately 4 divisions of display.

- f. Release TRIG VIEW.
- g. Disconnect all test equipment.

52. Check TRIG VIEW Risetime

a. Set TIME/DIV to 5 µs.

b. Connect a 100 kilohertz signal from the squarewave generator high amplitude output through a GR-to-BNC female adapter and a 42-inch 50-ohm BNC cable to the input of the tunnel diode pulser calibration fixture. Connect the output of the tunnel diode pulser through a 50-ohm termination to A TRIGGER external input.

c. Press TRIG VIEW and hold it in.

d. Adjust A TRIGGER LEVEL to set the display to graticule center.

e. Increase the square-wave generator amplitude and adjust the pulser triggered level until the display suddenly increases to about 5 divisions of amplitude.

f. Set TIME/DIV to 0.01 μ s, set X10 MAG to on and set leading edge of waveform to graticule center.

g. CHECK—The display between the 10% and 90% points on the leading edge of waveform for 4 horizontal divisions or less (4 nanoseconds or less, risetime).

h. Release TRIG VIEW.

53. Check TRIG VIEW Delay Difference

a. Remove the test signal setup from A TRIGGER external input and disconnect the 50-ohm termination from the pulser. Connect the output of the tunnel diode pulser to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch BNC cables, Connect a cable through a 50-ohm termination to CH 1 input and connect other cable through a 50-ohm termination to A TRIGGER external input.

b. Set TIME/DIV to 0.05 μ s, set X10 MAG to off and set CH 1 VOLTS/DIV to 20 mV.

c. Adjust the pulser triggered level until the display suddenly increases.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01944-352554 Email:- enquiries@mauritron.co.uk

d. Press and hold TRIG VIEW, and adjust A TRIGGER LEVEL to set the center of overall display amplitude to graticule center and note amplitude of the display.

e. Release TRIG VIEW, set CH 1 VAR VOLTS/DIV for same amplitude noted in part d and set the center of overall display amplitude to graticule center with CH 1 POSITION.

f. Set TIME/DIV to 0.01 μ s, set X10 MAG to on and set leading edge of waveform to graticule center with POSITION (Horiz).

g. Press TRIG VIEW and note difference in horizontal position from graticule center.

h. CHECK—For 2.5 divisions or less (2.5 nanoseconds or less of difference).

i. Release TRIG VIEW.

j. Disconnect all test equipment.

54. Check LINE Triggering

a. Set CH 1 VAR VOLTS/DIV to calibrated detent, set X10 MAG to off, set A TRIGGER SOURCE to LINE and set TIME/DIV to 5 ms.

b. Press and hold TRIG VIEW.

c. CHECK—For a triggered display starting on the slope selected by A TRIGGER SLOPE.

d. Release TRIG VIEW.

55. Check A TRIGGER LEVEL Control External Range

a. Set TIME/DIV to 1 ms, set CH 1 VOLTS/DIV to 1 V and set A TRIGGER SOURCE to EXT.

b. Connect the low-frequency generator output to a 42-inch 50-ohm BNC cable, to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch 50-ohm BNC cables, to CH 1 input and A TRIGGER external input.

6-32

c. Set the low-frequency generator for a 4 division,
 1 kilohertz display.

d. CHECK—That display is triggered through midrange and not triggered at both stops of A TRIGGER LEVEL in + and - positions of A TRIGGER SLOPE.

56. Check B TRIGGER LEVEL Control External Range

a. Set HORIZ DISPLAY to B DLY'D, set B TRIGGER SOURCE to EXT and set A TRIGGER SOURCE to NORM.

b. Move test signal cable from A TRIGGER external input to B TRIGGER external input.

c. CHECK—That display is triggered through midrange and not triggered at both stops of B TRIGGER LEVEL in + and - positions of B TRIGGER SLOPE.

57. Check SINGL SWP Triggering

a. Set HORIZ DISPLAY to A and set CH 1 VOLTS/DIV to 5 mV.

b. Set the low-frequency generator for a 5 division, (
 1 kilohertz display, then set CH 1 VOLTS/DIV to 50 mV.

c. Set A TRIGGER LEVEL for stable triggering with display start at top of first positive peak.

d. Set CH 1 AC-GND-DC switch to GND and momentarily press SINGL SWP pushbutton of TRIG MODE.

e. CHECK-That READY light turns on.

f. Set CH 1 AC-GND-DC switch to DC.

g. CHECK—For a display of 1 sweep and that READY light is extinguished.

58. Check TRIG MODE NORM Triggering

a. Set TRIG MODE to NORM and set A TRIGGER LEVEL for a stable triggered display.

- b. Set CH 1 AC-GND-DC switch to GND.
- c. CHECK-For no visible trace.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

d. Disconnect all test equipment.

59. Check TRIG MODE AUTO Triggering

a. Set TRIG MODE to AUTO, set TIME/DIV to 10 ms, CH 1 VOLTS/DIV to 0.5 V and set CH 1 AC-GND-DC switch to DC.

b. Set the time-mark generator for 10 millisecond time marks and connect through a 42-inch 50-ohm BNC cable, to a 50-ohm BNC termination, to CH 1 input.

c. CHECK—That a stable triggered display can be obtained with adjustment of A TRIGGER LEVEL.

d. Set TIME/DIV to 0.1 s and set the time-mark generator for 0.1 second time marks.

e. CHECK—That a stable triggered display cannot be obtained with adjustment of A TRIGGER LEVEL.

Trigger (A and B)

0

+

NORM

AUTO

NORM

Midrange

(new setting)

HORIZONTAL SYSTEM

Equipment Required 1. Time-Mark Generator	8. 18-Inch 50-Ohm BNC Cable (2 required)
2. Sine-Wave Generator	9. 50-Ohm BNC Termination (2 required)
3. Digital Voltmeter	10. BNC Female-To-BNC Female Adapter
4. Amplitude Calibrator	11. BNC T-Connector
5. Test Oscilloscope	12. 500 MHz Filter
6. Current Probe	13. Screwdriver
7. 42-Inch 50-Ohm BNC Cable (2 required)	 Low-Capacitance Screwdriver (use for all variable capacitance adjustments)

Before you begin, see **ADJUSTMENT LOCATIONS 4** in the pullout pages.

Control Settings

POWER

Display

ON

INTENSITY	Midrange
FOCUS	Midrange
SCALE ILLUM	Midrange

Vertical (CH 1 and CH 2)

POSITION
VOLTS/DIV
VAR VOLTS/DIV
AC-GND-DC
INVERT
VERT MODE
100 OR 20 MHz BW

Midrange 0.5 V Calibrated detent DC Off (button out) CH 1 Full bandwidth (push in, then release)

A TIME/DIV B TIME/DIV VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY X10 MAG POSITION (Horiz) FINE

A TRIGGER SOURCE

B TRIGGER SOURCE

A TRIGGER HOLDOFF

COUPLING

TRIG MODE

LEVEL

SLOPE

Sweep 1 ms (new setting) (1 ms new setting) Calibrated detent DN Fully counterclockwise A Off (button out) Midrange

AC (new setting)

STARTS AFTER DELAY

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

6-33

NOTE

DM44 DIGITAL MULTIMETERS.

FOR OSCILLOSCOPES WITH DIGITAL MULTIMETERS ATTACHED, REFER TO THE DIGITAL MULTIMETER MANUAL AT THIS POINT. CONTINUE WITH THE 475A DM44 HORIZONTAL SYSTEM CALIBRATION PROCEDURE, THEN RETURN TO GATE OUTPUTS, EXTERNAL Z-AXIS AND CALIBRATOR SECTION IN THIS CALIBRATION PROCEDURE.

FOR OSCILLOSCOPES WITHOUT DIGITAL MULTIMETERS, CONTINUE WITH HORIZONTAL SYSTEM CALIBRATION.

60. Adjust Horizontal Gain

a. Set the time-mark generator for 1 millisecond time marks and connect through a 42-inch 50-ohm BNC cable and 50-ohm BNC termination to CH 1 input.

b. Set A TRIGGER LEVEL for a stable triggered display.

NOTE

Unless otherwise stated, set POSITION and FINE (Horiz) controls so first time mark will coincide with first vertical graticule line and check that a time mark will coincide with last vertical graticule line.

c. CHECK—That first and 11th time marks coincide with graticule lines, within 1%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

d. ADJUST—Horizontal Gain, R1155, for 1 timemark/division. See ADJUSTMENT LOCATIONS 4-B.

NOTE

Effective range of R1155 is determined by the selected value of R1154. The value of R1154 may be altered to obtain necessary range for R1155.

e. Press X10 MAG pushbutton and set time-mark generator for 0.1 millisecond time marks.

f. CHECK-That X10 MAG light is illuminated.

g. CHECK—That first and 11th time marks coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

h. Set X10 MAG pushbutton to off and set the timemark generator for 1 millisecond time marks.

61. Adjust Intensified Gain

a. Set HORIZ DISPLAY to A INTEN.

b. CHECK—That first and 11th time marks coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

c. ADJUST—Intensified Gain, R950, for 1 timemark/division. See ADJUSTMENT LOCATIONS 4-B.

62. Adjust Delay Start and Delay Stop

a. Pull and unlock DLY'D SWP knob (B TIME/DIV) and set to 10 μ s. Set HORIZ DISPLAY to B DLY'D and set DELAY TIME POSITION to 1.000 on dial.

b. CHECK—That the start of displayed time mark is near beginning of sweep.

c. ADJUST—Delay Start, R938, so that the start of displayed time mark starts at beginning of sweep. See ADJUSTMENT LOCATIONS 4-B.

d. Turn DELAY TIME POSITION to set the start of displayed time mark to coincide with graticule center and note reading on dial.

e. Turn DELAY TIME POSITION to set time mark nearest 9.000 on dial to coincide with graticule center and note reading.

f. CHECK—For a difference in readings, noted in parts d and e, of 8.000, within 0.049, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.089, from -15° C to $+55^{\circ}$ C.

NOTE

If the difference in readings in part f was within specifications, proceed with part i.

6-34

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chunnor Oxon OX9 4QY Tel:-01844-351694 Fax-01844-352554 Email:-enquiries@mauritron.co.uk g. Add the dial reading noted in part d, to 8.000 and set DELAY TIME POSITION dial to indicate the sum.

h. ADJUST—Delay Stop, R936, to set the start of displayed time mark to coincide with graticule center. See ADJUSTMENT LOCATIONS 4-B.

i. INTERACTION—Between Delay Start and Delay Stop adjustments. Repeat parts a through h as necessary.

63. Check 1 Millisecond Differential Delay Time Accuracy

a. Turn DELAY TIME POSITION to set time mark nearest 1.000 on dial to graticule center and note reading.

b. Turn DELAY TIME POSITION to set time mark nearest 2.000 on dial to graticule center and note reading.

c. CHECK—For a difference in readings of 1.000, within 0.010, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.020, from -15° C to $+55^{\circ}$ C.

d. Turn DELAY TIME POSITION to set every adjacent time mark to graticule center and note reading.

e. CHECK—Each reading between any 2 adjacent time marks for 1.000, within 0.010, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.020, from -15° C to $+55^{\circ}$ C. Also, check the difference between any time marks separated by more than 1 major dial division for maximum error as listed in Table 6-4.

TABLE 6-4

1 Millisecond Differential Delay Time Accuracy

Difference in Major Dial Divisions	Maximum Error +15°C to +35°C	Maximum Error -15°C to +55°C
1.000	±0.010	±0.020
2.000	±0.019	±0.029
3.000	±0.027	±0.042
4.000	±0.033	±0.053
5.000	±0.039	±0.064
6.000	±0.043	±0.073
7.000	±0.047	±0.082
8.000	±0.049	±0.089
9.000	±0.050	±0.095

64. Adjust Magnified Registration

a. Set DLY'D SWP to 1 ms (lock knobs) and set HORIZ DISPLAY to A.

b. Set the time-mark generator for 5 millisecond time marks.

c. Press X10 MAG pushbutton, set the center time mark of the display to graticule center with POSITION (Horiz), then set X10 MAG pushbutton to off.

d. CHECK-That center time mark is within 0.5 division of graticule center.

e. ADJUST-Magnified Registration, R1130, to set center mark to graticule center. See ADJUSTMENT LOCATIONS 4-B.

f. Repeat parts c through e, as necessary, for minimum shift when switching from magnified to unmagnified.

65. Check VAR TIME/DIV Range

a. Set VAR TIME/DIV fully counterclockwise.

b. CHECK-That TIME/DIV UNCAL light is illuminated.

c. CHECK-For at least 6 time marks in 10 divisions.

d. Return VAR TIME/DIV control to calibrated detent.

66. Check Sweep Length and Horizontal POSITION Range

a. Set time-mark generator for 1 millisecond time marks.

b. CHECK-Sweep length for at least 10.1 divisions.

c. Turn POSITION and FINE (Horiz) controls fully clockwise. (Also check that each control will position the trace).

d. CHECK---That the start of sweep is to the right of graticule center.

e. Turn POSITION and FINE (Horiz) controls fully counterclockwise.

f. CHECK-That the end of sweep is to the left of graticule center.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

g. Recenter POSITION and FINE (Horiz) controls.

67. Adjust 10 Microsecond Timing

a. Set TIME/DIV to 10 μ s, set time-mark generator for 10 microsecond time marks and align the first time mark with first graticule line using POSITION and FINE (Horiz) controls.

b. CHECK—That the first and 11th time marks coincide with graticule lines, within 1%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

c. ADJUST—C1064 for 1 time-mark/division. See AD-JUSTMENT LOCATIONS 4-A.

d. Set HORIZ DISPLAY to B DLY'D, pull and unlock DLY'D SWP knob and set to 0.2 $\mu s.$

e. Turn DELAY TIME POSITION to set time mark nearest 1.000 on dial to coincide with graticule center and note reading.

f. Turn DELAY TIME POSITION to set time mark nearest 9.000 on dial to coincide with graticule center and note reading.

g. CHECK—For a difference in readings, noted in parts e and f, of 8.000, within 0.049, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.089, from -15° C to $+55^{\circ}$ C.

NOTE

If the difference in readings in part g was within specifications, proceed with step 68. Otherwise proceed with part h.

h. Add the dial reading noted in part e, to 8.000 and set DELAY TIME POSITION to indicate the sum.

i. ADJUST-C1023 to set the start of displayed time mark to coincide with graticule center. See ADJUST-MENT LOCATIONS 4-A.

j. INTERACTION—Between setting of DELAY TIME POSITION at 1.000 and adjustment of C1023. Repeat parts e through i as necessary to obtain a difference in readings of 8.000, within limits specified in part g.

6-36

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4OY Tet: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

68. Adjust 0.1 Microsecond Timing

a. Set HORIZ DISPLAY to A, set DLY'D SWP to 10 μ s (lock knobs) and set TIME/DIV to 0.1 μ s.

b. Set time-mark generator for 0.1 microsecond time marks.

c. CHECK—That first and 11th time marks coincide with graticule lines, within 1%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

d. ADJUST-C1009 for 1 time mark/division. See ADJUSTMENT LOCATIONS 4-B.

e. Set HORIZ DISPLAY to B DLY'D, pull and unlock DLY'D SWP knob and set to 0.01 μ s.

f. Turn DELAY TIME POSITION to set time mark nearest 1.000 on dial to coincide with graticule center and note reading.

g. Turn DELAY TIME POSITION to set time mark nearest 9.000 on dial to coincide with graticule center and note reading.

h. CHECK—For a difference in readings of 8.000, within 0.049, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.089 from -15° C to $+55^{\circ}$ C.

NOTE

If the difference in readings in part h was within specifications, proceed with step 69. Otherwise proceed with part i.

i. Add the dial reading noted in part f, to 8.000 and set DELAY TIME POSITION to indicate the sum.

j. ADJUST—C1025 to set the start of display time mark to coincide with graticule center. See ADJUSTMENT LOCATIONS 4-A.

k. INTERACTION—Between setting of DELAY TIME POSITION at 1.000 and adjustment of C1025. Repeat parts f through j as necessary to obtain a difference in readings of 8.000, within limits specified in part h.

69. Adjust Horizontal Output Centering

a. Set HORIZ DISPLAY to A, set DLY'D SWP to 0.1 μs (lock knobs), set TIME/DIV to X-Y, set VERT MODE to CH 2 and set CH 1 AC-GND-DC switch to GND.

b. Set the dot display to graticule center with X (CH 1) and Y (CH 2) POSITION controls.

c. Connect the digital voltmeter (set to read at least 50 volts) negative lead to GND test point on main interface circuit board and compare readings between the collectors (transistor cases) of Q1204 and Q1214. See ADJUST-MENT LOCATIONS 4-B.

d. Set POSITION (HORIZ) for equal readings between the transistor collectors of Q1204 and Q1214 and note the final reading.

e. CHECK—For a reading of approximately +50 volts.

f. ADJUST---Horizontal DC Centering R1256, for a reading of +50 volts. See ADJUSTMENT LOCATIONS 4-B.

g. Disconnect the digital voltmeter.

NOTE

The preceding procedure is intended to initially set the Horizontal Output Centering. It may be helpful to readjust Horizontal DC Centering, R1256, later in this procedure if step 71 must be performed.

70. Adjust High-Speed Timing (Visual Method)

NOTE

This step is intended to check high-speed timing and, if necessary, perform minor recalibration. If timing cannot be adjusted to within specified accuracy, major recalibration will be performed in step 71.

a. Set TIME/DIV to 0.05 μ s, set VERT/MODE to CH 1, press X10 MAG to on, set A TRIGGER SOURCE to EXT and set A TRIGGER COUPLING to LF REJ.

b. Set the time-mark generator for 5 nanosecond time marks and connect trigger output through a 42-inch 50ohm BNC cable to a 50-0hm BNC termination, to A TRIGGER external input. (If a 2901 time-mark generator is used, set trigger selector for 0.1 microsecond triggers). Insert a 500 megahertz filter between the 50-ohm BNC termination and CH 1 input. Adjust the filter for minimum unwanted modulation from the time-mark generator, as necessary, through the high-speed timing procedure.

c. Set CH 1 VOLTS/DIV to maintain a convenient display amplitude in this step. Set A TRIGGER LEVEL for a stable triggered display through the high-speed timing procedure.

d. CHECK—That first and 11th time marks coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

e. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval. (See following note).

NOTE

(1) If waveform has modulation, check 2 division accuracy between adjacent time marks of equal amplitude.

(2) Turn INTENSITY full on and position the spot at start of the sweep to graticule area with POSITION (Horiz).

Exclude the first 25 nanoseconds from start of sweep or first 2 major unblanked divisions at normal intensity (whichever is greater) and all beyond the 100th division.

f. ADJUST-C1253 and C1233, in equal amounts, for 1 cycle/division. See ADJUSTMENT LOCATIONS 4-B.

g. Set TIME/DIV to $0.02 \,\mu s$ and set time-mark generator for 2 nanosecond time-marks.

NOTE

It may be necessary to adjust A TRIGGER HOLDOFF for best triggered display through this step.

h. CHECK—That first and 11th time marks coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

i. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval.

6-37

For Service Manuals Contact MAURITRON TECHINICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

j. ADJUST---C1179 for 1 cycle/division. See ADJUST--MENT LOCATIONS 4-B.

k. INTERACTION—Between 0.05 and 0.02 microsecond magnified timing. Set TIME/DIV to 0.05 μ s, set time-mark generator for 5 nanosecond time marks and repeat parts d through i as necessary for best timing accuracy.

I. Set TIME/DIV to 0.01 μs.

m. CHECK—That first and 6th cycles coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

n. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval.

o. ADJUST-1 Nanosecond Timing, R1075, for 1 cycle/2 divisions. See ADJUSTMENT LOCATIONS 4-A.

NOTE

If timing cannot be adjusted to within specified accuracy, proceed with step 71. If timing is within specified accuracy, proceed with step 72.

71. Adjust High-Speed Timing (Current Probe Method)

NOTE

This step is intended only for major recalibration of high-speed timing. Any reference to 475A through the calibration procedure refers to the instrument under calibration.

a. Set TIME/DIV to 0.02 $\mu s,$ center the display on graticule with POSITION (Horiz) and press X10 MAG to on.

b. Set time-mark generator for 2 nanosecond time marks and set CH 1 VOLTS/DIV to maintain a convenient display amplitude through this step.

c. Connect the current probe with passive termination to channel 1 of test oscilloscope. Set passive termination to 1 mA/mV

d. Connect the probe head around the crossed horizontal deflection plate leads. See ADJUSTMENT LOCATIONS 4-B. See Figure 6-4 for proper probe connection.



Fig. 6-4. Proper connection of current probe to horizontal deflection plate leads for High-Speed Timing calibration.

e. Set the test oscilloscope: vertical mode to channel 1, time/division to 0.2 microseconds, X10 magnifier to on and channel 1 volts/division to 20 millviolts. Position current pulse at beginning of sweep to graticule center.

f. CHECK—Test oscilloscope display for a symmetrical, flat-top current waveform similar to that in Figure 6-5.





g. ADJUST— C1253, C1233, C1179, R1185 and R1175 for a symmetrical, flat-top current waveform. See AD-JUSTMENT LOCATIONS 4-B.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

@

6-38

h. CALIBRATION AID—Preset C1253 and C1233 for approximately 1/4 of maximum capacitance, preset C1179 near maximum capacitance (near clockwise stop) and preset R1185 near maximum resistance (near clockwise stop).

Adjust R1175 for a flat top and fast leading edge on current waveform at 475A TIME/DIV settings of 0.02 μ s and 0.01 μ s. Adjust R1185 for best overall flat top on current waveform at 475A TIME/DIV setting of 0.02 μ s. C1253 and C1233 may be adjusted individually for a symmetrical current waveform with a fast trailing edge.

NOTE

It may be helpful to readjust Horizontal DC Centering, R1256, for best symmetrical current waveform. See ADJUSTMENT LOCATIONS 4-B.

i. INTERACTION—Between all adjustments in this step. Repeat the adjustment procedure in part g, as necessary, to obtain the best symmetrical, flat-top current waveform.

j. Set 475A TIME/DIV to 0.05 μ s and set time-mark generator for 5 nanosecond time marks.

k. CHECK—That first and 11th cycles coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

I. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval. (See following note.

NOTE

(1) If waveform has amplitude modulation, check 2 division accuracy between adjacent time marks of equal amplitude.

(2) Turn INTENSITY full on and position the spot at start of the sweep to graticule area with POSITION (Horiz).

Exclude the first 25 nanoseconds from start of sweep or first 2 major unblanked divisions at normal intensity (whichever is greater) and all beyond the 100th division.

m. ADJUST---C1253 and C1233, in equal amounts, for 1 cycle/division. See ADJUSTMENT LOCATIONS 4-B.

n. Set TIME/DIV to $0.02 \,\mu s$ and set time-mark generator for 2 nanosecond time marks.

NOTE

In the following parts, it may be necessary to adjust R1185 and R1175 to maintain a symmetrical, flat-top current waveform.

o. CHECK—That first and 11th cycles coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

p. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval.

q. ADJUST-C1179 for 1 cycle/division. See AD-JUSTMENT LOCATIONS 4-B.

r. INTERACTION — Between 0.05 and 0.02 microsecond magnified timing. Repeat parts j through p, as necessary for best timing accuracy.

s. Set TIME/DIV to 0.01 µs.

t. CHECK—That first and 6th cycles coincide with graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

u. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval.

v. ADJUST-1 Nanosecond Timing, R1075, for 1 cycle/2 divisions. See ADJUSTMENT LOCATIONS 4-A.

w. Disconnect the current probe without disturbing the deflection plate leads.

x. INTERACTION—Between timing with current probe connected and timing without current probe. Repeat parts j through u for best timing accuracy. (Disregard note between n and o).

y. Set X10 MAG to off, TIME/DIV to 0.1 μ s, set CH 1 AC-GND-DC switch to DC and set time-mark generator for 0.1 microsecond time marks.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352557 El: 01844-351694 Fax: 01844-352557

z. CHECK—That first and 11th time marks coincide with graticule lines, within 1%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

aa. ADJUST-C1009 for 1 time mark/division. See ADJUSTMENT LOCATIONS 4-B.

ab. INTERACTION—Between adjustment of C1009 and high-speed timing. If adjustment was made in part aa, press X10 MAG to on and repeat parts j through v for best timing accuracy.

ac. Remove the trigger cable setup from A TRIGGER external input, set A TRIGGER SOURCE to NORM and set A TRIGGER COUPLING to AC.

72. Check A Timing Accuracy

a. Set CH 1 AC-GND-DC switch to DC, set CH 1 VOLTS/DIV to 0.5 V and set TRIG MODE to NORM.

b. CHECK—TIME/DIV settings from 0.01 μ s to 5 ms/division for accuracy, at first and 11th graticule lines, within 1%, from +20°C to +30°C; within 3%, from -15°C to +55°C. Set time-mark generator to maintain appropriate time marks through this step. Exclude the first 25 nanoseconds from start of sweep when checking 0.01 and 0.02 μ s/division.

c. CHECK—TIME/DIV settings from 10 ms to 0.5 s/division for accuracy, at first and 11th graticule lines, within 2%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 3%, from -15° C to $+55^{\circ}$ C.

73. Check A INTEN Timing Accuracy

a. Set HORIZ DISPLAY to A INTEN and set DELAY TIME POSITION fully counterclockwise.

b. CHECK—TIME/DIV settings from $0.05 \,\mu s$ to 0.5 s/division for accuracy, at first and 11th graticule lines, within 2%, from +20°C to +30°C; within 3%, from -15°C to +55°C. Set time-mark generator to maintain appropriate time marks.

- 74. Check A INTEN Magnified Timing Accuracy
 - a. Press X10 MAG to on.

b. CHECK—TIME/DIV settings from $0.05 \,\mu s$ to $0.5 \,s$ /division for accuracy, at first and 11th graticule lines, within 3%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C. Set time-mark generator to maintain appropriate time marks. See NOTE following step 71, part I.

75. Check A Magnified Timing Accuracy

a. Set HORIZ DISPLAY to A.

b. CHECK—TIME/DIV settings from 0.01 μ s to 5 ms/division for accuracy, at first and 11th graticule lines, within 2%, from +20°C to +30°C; within 4%, from -15°C to +55°C. Set time-mark generator to maintain appropriate time marks through this step. See NOTE following step 71, part I.

c. CHECK—TIME/DIV settings from 10 ms to 0.5 s/division for accuracy, at first and 11th graticule lines, within 3%, from $+20^{\circ}$ C to $+30^{\circ}$ C; within 4%, from -15° C to $+55^{\circ}$ C.

d. CHECK—That accuracy is within 5% (0.1 division) over any 2 division interval at all TIME/DIV settings.

76. Check Differential Delay Time Accuracy

a. Set HORIZ DISPLAY to B DLY'D and set TIME/DIV to 0.05 μ s. Pull and unlock DLY'D SWP knob, set to 0.01 μ s and set X10 MAG to off.

b. Set time-mark generator for 50 nanosecond time marks.

c. Turn DELAY TIME POSITION to set time mark nearest 1.000 on dial to coincide with graticule center and note reading.

d. Turn DELAY TIME POSITION to set time mark nearest 2.000 on dial to coincide with graticule center and note reading.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk e. CHECK—For a difference in readings of 1.000, within 0.010, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.020, from -15° C to $+55^{\circ}$ C.

TABLE 6-5

Differential Delay Time Accuracy

Difference in Major Dial Divisions	Maximum Error +15°C to +35°C	Maximum Error -15°C to +55°C
1.000	±0.010	±0.020
2.000	±0.019	±0.029
3.000	±0.027	±0.042
4.000	±0.033	±0.053
5.000	±0.039	±0.064
6.000	±0.043	±0.073
7.000	±0.047	±0.082
8.000	±0.049	±0.089
9.000	±0.050	±0.095

f. Turn DELAY TIME POSITION to set every adjacent time mark to coincide with graticule center and note reading.

g. CHECK—Each reading between any 2 adjacent time marks for 1.000, within 0.010, from $+15^{\circ}$ C to $+35^{\circ}$ C; within 0.020, from -15° C to $+55^{\circ}$ C. Also, check the difference between any time marks separated by more than 1 major dial division for maximum error as listed in Table 6-5.

@

h. CHECK--Differential delay time accuracy as directed in part g, at all settings listed in Table 6-6 not to exceed maximum error listed in Table 6-5.

Delay Time Settings						
DELAY TIME POSITION Exclusions	A TIME/DIV Switch Setting	B TIME/DIV Switch Setting	¹ Time-Mark Generator Setting			
Exclude dial settings of	0.05 μ s	0.01 µs	50 nanosecond			
0.000 through 1.000	0.1 μs	0.01 µs	0.1 microsecond			
	0.2 μs	0.02 µs	0.2 microsecond			
	0.5 μs	0.05 µs	0.5 microsecond			
	1 μs	0.1 μs	1 microsecond			
	2 μs	0.2 µs	2 microsecond			
	5 μs	0.5 µs	5 microsecond			
	10 μs	1 μs	10 microsecond			
	20 μs	2 µs	20 microsecond			
Exclude dial settings of	50 μs	5 µs	50 microsecond			
0.000 through 0.050	0.1 ms	10 µs	0.1 millisecond			
	0.2 ms	20 µs	0.2 millisecond			
	0.5 ms	50 μs	0.5 millisecond			
	1 ms	0.1 ms	1 millisecond			
	2 ms	0.2 ms	2 millisecond			
	5 ms	0.5 ms	5 millisecond			
	10 ms	1 ms	10 millisecond			
	20 ms	2 ms	20 millisecond			
	50 ms	5 ms	50 millisecond			
	0.1 s	10 ms	0.1 second			
	0.2 s	20 ms	0.2 second			
	0.5 s	50 ms	0.5 second			

TABLE 6-6

¹If the time-mark generator being used does not have a 1-2-5 sequence, set for 1 or more time marks per division on DELAY TIME POSITION dial.

6-41

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40V Tel: 01844-351694 Fax: 01844-352554 Email: enquines@mauritron.co.uk

77. Check Delay Time Jitter

a. Set DLY'D SWP to 0.2 μ s, set A TIME/DIV to 1 ms and set time-mark generator for 1 millisecond time marks.

b. Set DELAY TIME POSITION to 1.000 on dial and position nearest time mark to graticule center.

c. CHECK—That jitter on the leading edge of the time mark does not exceed 1 division (60 Hertz line) or 2.5 division (50 Hertz line).

d. Set DELAY TIME POSITION to view each time mark from 2.000 to 9.000 on dial and check delay time jitter for limits stated in part c.

78. Check MIX (Mixed Sweep) Timing Accuracy

a. Set DLY'D SWP to 0.02 μs , A TIME/DIV to 0.05 μs , HORIZ DISPLAY to MIX and DELAY TIME POSITION fully clockwise.

b. Set time-mark generator for 50 nanosecond time marks.

c. CHECK—A TIME/DIV settings from 0.02 μ s to 0.5 s/division for accuracy at 2nd and 10th graticule lines, (8 division timing), within 3%. Exclude the first 0.5 division from start of sweep when checking A sweep. Set DLY'D SWP at least 1 sweep setting faster than A sweep setting on all ranges. Set time-mark generator to maintain appropriate time marks.

d. Set DELAY TIME POSITION fully counterclockwise, DLY'D SWP to 0.05 μ s, ATIME/DIV to 0.1 μ s and set time-mark generator for 50 nanosecond time marks.

e. CHECK—DLY'D SWP settings from $0.05 \,\mu s$ to 0.5 s/division for accuracy at 2nd and 10th graticule lines, (8 division timing), within 3%. Exclude the first 0.2 division or 0.1 microsecond (whichever is greater) after the transition of A to B. Set DLY'D SWP at least 1 sweep setting faster than A sweep setting on all ranges. Set time-mark generator to maintain appropriate time marks.

f. Disconnect all test equipment.

6-42

79. Adjust X Gain

a. Set TRIG MODE to AUTO, set DLY'D SWP to lock knobs and set TIME/DIV to X-Y. Set VERT MODE to CH2, set X (CH 1) VOLTS/DIV to 5 mV, and set X (CH 1) AC-GND-DC switch to DC.

b. Set amplitude calibrator to 20 millivolts and connect to X (CH 1) input through a 42-inch 50-ohm BNC cable.

c. Set X and Y POSITION controls to set the 2-dot display at graticule center.

d. CHECK—The deflection between the 2 displayed dots for 4 divisions within 3%.

e. ADJUST---X Gain, R1102, for 4 divisions of deflection between the 2 displayed dots. See ADJUSTMENT LOCATIONS 4-B.

f. Adjust X VAR VOLTS/DIV and X POSITION for exactly 2 divisions between the displayed dots at graticule center.

g. Position right dot of display to extreme right graticule line.

h. CHECK—The display for 0.2 division or less of compression or expansion.

i. Position left dot of display to extreme left graticule line.

j. CHECK—The display for 0.2 divisions or less of compression or expansion.

k. Disconnect all test equipment.

80. Adjust X-Y Phase Difference

a. Return X VAR VOLTS/DIV to calibrated detent and set X AC-GND-DC switch to GND.

b. Set Y VOLTS/DIV to 5 mV.

@

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4OY Tel:-01844-351894 Fax:-01844-35255 Email:- enquines@mauritron.co.ut

NOTE

See test equipment required, Table 6-1, for selection of sine-wave generator with an output of 100 megahertz and below.

c. Connect the sine-wave generator output cable to a BNC female-to-BNC female adapter, to a BNC T-connector, to two 18-inch 50-ohm BNC cables. Connect the 18-inch cables through 50-ohm terminations to X and Y inputs.

d. Set the sine-wave generator for an 8 division display of reference frequency, then set X AC-GND-DC switch to DC.

e. Center the lissajous display on graticule with X and Y POSITION controls.

f. CHECK—For 0.14 division or less of opening at center of the lissajous display. (Measure horizontally).

g. ADJUST-L1103 for minimum opening of the lissajous display. See ADJUSTMENT LOCATIONS 4-B.

h. Increase the frequency of the sine-wave generator to 2 megahertz.

i. CHECK—For 0.42 division or less of opening at center of the lissajous display. (Measure horizontally).

j. Disconnect all test equipment.

81. Check X Bandwidth

a. Connect the sine-wave generator output cable to a 50-ohm termination, to X input.

b. Set the sine-wave generator for a 4 division horizontal display of reference frequency.

c. Increase the frequency of the sine-wave generator until the display is reduced to 2.8 divisions.

d. CHECK—The sine-wave generator for a reading of 3 megahertz or higher.

e. Disconnect all test equipment.

82. Check B ENDS A Operation

a. Set TIME/DIV to 1 ms, pull and unlock DLY'D SWP knob and set to 0.1 ms, set VERT MODE to CH 1, set HORIZ DISPLAY to A INTEN and set A TRIG HOLDOFF to B ends A detent.

b. Increase INTENSITY until A sweep is visible.

c. Turn DELAY TIME POSITION through its range.

d. CHECK—That A sweep ends after the intensified portion at all settings of DELAY TIME POSITION dial.

83. Check A TRIG HOLDOFF Operation

a. Set HORIZ DISPLAY to A, set A TRIG HOLDOFF to NORM and set DLY'D SWP (B TIME/DIV) to 1 ms (lock knobs).

b. Connect A +GATE (output connector on rear panel) to channel 1 of test oscilloscope through a 42-inch 50-ohm BNC cable.

c. Set test oscilloscope: time/division to 1 millisecond, X10 magnifier to off, channel 1 volts/division to 2 volts and trigger slope to negative.

d. Adjust A TRIG HOLDOFF for maximum time of negative pulse on test oscilloscope display. (Avoid setting near B ENDS A detent where negative portion decreases).

e. CHECK—That maximum holdoff time is 9 or more times the TIME/DIV setting on the 475A.

f. CHECK--475A TIME/DIV settings from 0.01 μ s to 0.5 s for maximum holdoff time of 9 or more times the TIME/DIV setting on the 475A.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk

GATE OUTPUTS, EXTERNAL Z AXIS AND CALIBRATOR

Equipment Required		3. Amplitude Calibrator
1. Test Oscilloscope Wi	th 10X Probe	
2. Digital Voltmeter		4. 42-Inch 50-ohm BNC Cable
Before yo	ou begin, see ADJUSTMEN	T LOCATIONS 4 in the pullout pages.
Control Settings		
-		84. Check A and B +GATE Outputs
POWER	ON	a. Connect A +GATE (output connector on rear pane to channel 1 of test oscilloscope through a 42-inch 50-oh BNC cable.
D	isplay	b. Set tost oscillossesses time/div.t. t. 111
INTENSITY FOCUS	Midrange Midrange	 b. Set test oscilloscope: time/div to 1 millisecon channel 1 for 2 volts/division and trigger slope to positiv
SCALE ILLUM	Midrange	c. CHECK—Test oscilloscope display for a positive pulse amplitude of approximately 5 volts.
Vertical (C	H 1 and CH 2)	d. Set HORIZ DISPLAY to A INTEN and move cab
POSITION VOLTS/DIV	Midrange 5 mV	from A +GATE connector to B +GATE connector.
VAR VOLTS/DIV AC-GND-DC	Calibrated detent DC	e. CHECK—Repeat part c.
INVERT VERT MODE	Off (button out) CH 1	f. Disconnect all test equipment.
100 OR 20 MHz BW	20 (new setting)	85. Check EXT Z-Axis Operation
		a. Set HORIZ DISPLAY to A and set TIME/DIV to 1 m
	(A and B)	
COUPLING LEVEL SLOPE	AC 0 +	b. Set amplitude calibrator for a 5 volt output ar connect to EXT Z-AXIS (input connector on rear pane through a 50-ohm BNC cable.
A TRIGGER SOURCE	NORM	
B TRIGGER SOURCE TRIG MODE A TRIG HOLDOFF	STARTS AFTER DELAY AUTO NORM (new setting)	c. CHECK—For noticeable modulation at normal ir tensity. Adjust VAR TIME/DIV, if necessary, to observ modulation, then return to calibrated detent.
		d. Disconnect all test equipment.
	veep	
A TIME/DIV B TIME/DIV VAR TIME/DIV	0.2 ms (new setting) 0.2 ms (new setting) Calibrated detent	86. Adjust CALIBRATOR Output Amplitude a. Connect the digital voltmeter between th
DELAY TIME POSITION	Fully counterclockwise (new setting)	CALIBRATOR current loop and ground test point. Se ADJUSTMENT LOCATIONS 4-B.
HORIZ DISPLAY X10 MAG	A Off (hutter out)	
POSITION (Horiz) FINE	Off (button out) Midrange Midrange	 b. Apply a short circuit between the calibrator tespoints, TP1503 and TP1504. See ADJUSTMEN LOCATIONS 4-B.
14		For Service Manuals Contact
		MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554

c. CHECK—For a reading of 0.3 volts, within 3 millivolts, from 0%°C to +40°C; within 4.5 millivolts, from -15°C to +55°C.

d. ADJUST-Calibrator Amplitude, R1515, for a reading of 0.3 volt. See ADJUSTMENT LOCATIONS 4-B.

e. Remove the short circuit between calibrator test points and disconnect all test equipment.

87. Check CALIBRATOR Frequency

a. Set CH 1 VOLTS/DIV to 10 mV and set TIME/DIV to 1 ms.

b. Connect a 10X probe from CALIBRATOR current loop to CH 1 input.

c. CHECK-For approximately 1 cycle/division.

This completes the calibration procedure for the 475A. Disconnect all test equipment, replace the vertical output circuit board cover and replace the cabinet. See Cabinet Installation instructions in the Maintenance Section of this manual for important installation information.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REPLACEABLE ELECTRICAL PARTS

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number

Change information, if any, is located at the rear of this manual.

LIST OF ASSEMBLIES

A list of assemblies can be found at the beginning of the Electrical Parts List. The assemblies are listed in numerical order. When the complete component number of a part is known, this list will identify the assembly in which the part is located.

CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER

The Mfr Code Number to Manufacturer index for the Electrical Parts List is located immediately after this page. The Cross Index provides codes, names and addresses of manufacturers of components listed in the Electrical Parts List.

ABBREVIATIONS

Abbreviations conform to American National Standard Y1.1

COMPONENT NUMBER (column one of the Electrical Parts List)

A numbering method has been used to identify assemblies, subassemblies and parts. Examples of this numbering method and typical expansions are illustrated by the following:



Read: Resistor 1234 of Assembly 23





Only the circuit number will appear on the diagrams and circuit board illustrations. Each diagram and circuit board illustration is clearly marked with the assembly number. Assembly numbers are also marked on the mechanical exploded views located in the Mechanical Parts List. The component number is obtained by adding the assembly number prefix to the circuit number.

The Electrical Parts List is divided and arranged by assemblies in numerical sequence (e.g., assembly A1 with its subassemblies and parts, precedes assembly A2 with its subassemblies and parts).

Chassis-mounted parts have no assembly number prefix and are located at the end of the Electrical Parts List

TEKTRONIX PART NO. (column two of the Electrical Parts List)

Indicates part number to be used when ordering replacement part from Tektronix.

SERIAL/MODEL NO. (columns three and four of the Electrical Parts List)

Column three (3) indicates the serial number at which the part was first used. Column four (4) indicates the serial number at which the part was removed. No serial number entered indicates part is good for all serial numbers.

NAME & DESCRIPTION (column five of the Electrical Parts List)

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

MFR. CODE (column six of the Electrical Parts List)

Indicates the code number of the actual manufacturer of the part. (Code to name and address cross reference can be found immediately after this page.)

MFR. PART NUMBER (column seven of the Electrical Parts List)

Indicates actual manufacturers part number

REV MAR 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquines@mauritron.co.uk

CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code	e Manufacturer	Address	City, State, Zip
000LI	TOPTRON CORP		
00853	SANGAMO ELECTRIC CO., S. CAROLINA DIV.	B.O. BOX 100	TOKYO, JAPAN
01121	ALLEN-BRADLEY COMPANY	P.O. BOX 128	PICKENS, SC 29671
01295	TEXAS INSTRUMENTS, INC.	1201 2ND STREET SOUTH	MILWAUKEE, WI 53204
0.200			
01963		P.O. BOX 5012	DALLAS, TX 75222
02111	CHERRY ELECTRICAL PRODUCTS CORPORATION	3600 SUNSET AVENUE	WAUKEGAN, IL 60085
	SPECTROL ELECTRONICS CORPORATION	17070 EAST GALE AVENUE	CITY OF INDUSTRY, CA 91745
02114	FERROXCUBE CORPORATION	PO BOX 359, MARION ROAD	SAUGERTIES, NY 12477
02735	RCA CORPORATION, SOLID STATE DIVISION	ROUTE 202	SOMERVILLE, NY 08876
03508	GENERAL ELECTRIC COMPANY, SEMI-CONDUCTOR		COMENTIELE, NT 08076
	PRODUCTS DEPARTMENT	ELECTRONICS PARK	SYRACUSE, NY 13201
04222	AVX CERAMICS, DIVISION OF AVX CORP.	P O BOX 867	
04713	MOTOROLA, INC., SEMICONDUCTOR PROD. DIV.	5005 E MCDOWELL RD,PO BOX 20923	MYRTLE BEACH, SC 29577
05828	GENERAL INSTRUMENT CORP ELECTRONIC	SOUS E MODOWELE ND, FO BOX 20923	PHOENIX, AZ 85036
	SYSTEMS DIV.	600 W JOUNI CT	
07263	FAIRCHILD SEMICONDUCTOR, A DIV. OF	600 W JOHN ST.	HICKSVILLE LI, NY 11802
	FAIRCHILD CAMERA AND INSTRUMENT CORP.		
08806	GENERAL ELECTRIC CO., MINIATURE	464 ELLIS STREET	MOUNTAIN VIEW, CA 94042
	LAMP PRODUCTO DEPARTMENT		
09353	LAMP PRODUCTS DEPARTMENT	NELA PARK	CLEVELAND, OH 44112
12697	C AND K COMPONENTS, INC.	103 MORSE STREET	WATERTOWN, MA 02172
	CLAROSTAT MFG. CO., INC.	LOWER WASHINGTON STREET	DOVER, NH 03820
12954	SIEMENS CORPORATION, COMPONENTS GROUP	8700 E THOMAS RD, P O BOX 1390	SCOTTSDALE, AZ 85252
2969	UNITRODE CORPORATION	580 PLEASANT STREET	WATERTOWN, MA 02172
3511	AMPHENOL CARDRE DIV., BUNKER RAMO CORP.		
4552	MICRO SEMICONDUCTOR CORP.	2830 E FAIRVIEW ST.	LOS GATOS, CA 95030
5238	ITT SEMICONDUCTORS, A DIVISION OF INTER		SANTA ANA, CA 92704
	NATIONAL TELEPHONE AND TELEGRAPH CORP.	P.O. BOX 168, 500 BROADWAY	
5454	RODAN INDUSTRIES, INC.		LAWRENCE, MA 01841
7856	SILICONIX, INC.	2905 BLUE STAR ST.	ANAHEIM, CA 92806
8324	SIGNETICS CORP.	2201 LAURELWOOD DRIVE	SANTA CLARA, CA 95054
9701		811 E. ARQUES	SUNNYVALE, CA 94086
2229	ELECTRA-MIDLAND CORP., MEPCO ELECTRA INC.	P O BOX 760	MINERAL WELLS, TX 76067
2223	SOLITRON DEVICES, INC.,		
4931	SEMICONDUCTOR GROUP	8808 BALBOA AVENUE	SAN DIEGO OPERS, CA 92123
	SPECIALITY CONNECTOR CO., INC.	2620 ENDRESS PLACE	GREENWOOD, IN 46142
5088	SIEMENS CORP.	186 WOOD AVE. S	ISELIN, NJ 08830
7014	NATIONAL SEMICONDUCTOR CORP.	2900 SEMICONDUCTOR DR.	SANTA CLARA, CA 95051
1918	IEE/SCHADOW INC.	8081 WALLACE ROAD	
2997	BOURNS, INC., TRIMPOT PRODUCTS DIV.	1200 COLUMBIA AVE.	EDEN PRAIRIE, MN 55343
3095	SPECTRUM CONTROL, INC.	152 E MAIN STREET	RIVERSIDE, CA 92507
0157	MIDWEST COMPONENTS INC.	P. O. BOX 787	FAIRVIEW, PA 16415
0434	HEWLETT-PACKARD COMPANY	1981 PORT CITY BLVD.	MUSKEGON, MI 49443
642	CENTRE ENGINEERING INC.	640 PAGE MILL ROAD	PALO ALTO, CA 94304
2306	HIGH VOLTAGE DEVICES, INC.	2820 E COLLEGE AVENUE	STATE COLLEGE, PA 16801
2769	SPRACIE GOODMAN ELEO HIO	7485 AVENUE 304	VISALIA, CA 93277
5289	SPRAGUE GOODMAN ELEC., INC.	134 FULTON AVENUE	GARDEN CITY PARK, NY 11040
	SPRAGUE ELECTRIC CO.	87 MARSHALL ST.	NORTH ADAMS, MA 01247
668	R-OHM CORP.	16931 MILLIKEN AVE.	IRVINE, CA 92713
660	TUSONIX INC.	2155 N FORBES BLVD	TUCSON, AZ 85705
821	CENTRALAB INC	7158 MERCHANT AVE	EL PASO, TX 79915
	SUB NORTH AMERICAN PHILIPS CORP		
400	BUSSMAN MFG., DIVISION OF MCGRAW-		
	EDISON CO.	2536 W. UNIVERSITY ST.	
590	CENTRALAB ELECTRONICS, DIV. OF	LOUG W. UNIVERSIT ST.	ST. LOUIS, MO 63107
	GLOBE-UNION, INC.	B O BOX 858	
982	ERIE TECHNOLOGICAL PRODUCTS, INC.	P O BOX 858	FORT DODGE, IA 50501
138	BECKMAN INSTRUMENTS INC.	644 W. 12TH ST.	ERIE, PA 16512
276	BECKMAN INSTRUMENTS, INC., HELIPOT DIV.	2500 HARBOR BLVD.	FULLERTON, CA 92634
970	SIGNALITE DIV., GENERAL INSTRUMENT CORP.	1933 HECK AVE.	NEPTUNE, NJ 07753
	JOHNSON, E. F., CO.	299 10TH AVE. S. W.	WASECA, MN 56093
042	TRW ELECTRONIC COMPONENTS, IRC FIXED		
	RESISTORS, PHILADELPHIA DIVISION	401 N. BROAD ST.	PHILADELPHIA, PA 19108
493	BELL INDUSTRIES, INC.,		
	MILLER, J. W., DIV.	19070 REYES AVE., P O BOX 5825	COMPTON CA 00224
488	STACKPOLE CARBON CO.	TO DUA 3023	COMPTON, CA 90224
009	TEKTRONIX, INC.		ST. MARYS, PA 15857
389	SWITCHCRAFT, INC.	P O BOX 500	BEAVERTON, OR 97077
003	VARO, INC.	5555 N. ELSTON AVE.	CHICAGO, IL 60630
201		P O BOX 411, 2203 WALNUT STREET	GARLAND, TX 75040
	MALLORY CAPACITOR CO., DIV. OF	3029 E. WASHINGTON STREET	
	P. R. MALLORY AND CO., INC.	P. O. BOX 372	INDIANAPOLIS, IN 46206

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code	Manufacturer	Address	City, State, Zip
91637	DALE ELECTRONICS, INC.	P. O. BOX 609	COLUMBUS, NE 68601
91836	KINGS ELECTRONICS CO., INC.	40 MARBLEDALE ROAD	TUCKAHOE, NY 10707
92966	SYLVANIA MINIATURE LIGHTING PRODUCTS,		
	INC., SUB OF GTE SYLVANIA, LIGHT. PROD.	526 ELM STREET	KEARNY, NJ 07032
3410	ESSEX INTERNATIONAL, INC., CONTROLS DIV.		
	LEXINGTON PLANT	P. O. BOX 1007	MANSFIELD, OH 44903
5348	GORDOS CORPORATION	250 GLENWOOD AVENUE	BLOOMFIELD, NJ 07003
6733	SAN FERNANDO ELECTRIC MFG CO	1501 FIRST ST	SAN FERNANDO, CA 91341
3629	PANEL COMPONENTS CORP.	2015 SECOND ST.	BERKELEY, CA 94170
0058	NEC ELECTRON INC.	252 HUMBOLT COURT	SUNNYVALE, CA 94086

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk

Ckt No.	Tektronix Part No.	Eff	odel No. Dscont	Name & Description	Mfr	
				Name a Description	Code	Mfr Part Number
A1	670-3120-01					
A2	670-3120-01			CKT BOARD ASSY:ATTENUATOR	80009	670-3120-01
A3	670-2240-03			CKT BOARD ASSY:ATTENUATOR	80009	
A3				CKT BOARD ASSY:VERTICAL PREAMP	80009	
A3	670-2240-04			(SEE DM MANUAL FOR ALTERNATE VERSION)		0.0 2240-00
A3				CKT BOARD ASSY VERTICAL PREAMP	80009	670 2240 04
/.0				(OPTION 07 ONLY)	00003	670-2240-04
A4	670-2243-01			CKT BOARD ASSY:GAIN SWITCH		
A5	670-2242-02	B010100	B012999	CKT BOARD ASSY:VERTICAL OUTPUT	80009	670-2243-01
A5	670-2242-04	B013000	B019489	CKT BOARD ASSY:VERTICAL OUTPUT	80009	670-2242-02
A5	670-2242-06	B019490		CKT BOARD ASSY:VERTICAL OUTPUT	80009	670-2242-04
A6	670-2245-00	B010100	B016199	CKT BOARD ASSY.VERTICAL OUTPUT	80009	670-2242-06
A6	670-6002-01	B016200	0010135	CKT BOARD ASSY:FAN MOTOR	80009	670-2245-00
		0010200		CKT BOARD ASSY:FAN MOTOR	80009	670-6002-01
A7 A7	670-3468-01	B010100	B011629	CKT BOARD ASSY:TIMING	00000	070.0.0
				(SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-3468-01
A7	670-3468-02	B011630		CKT BOARD ASSY: TIMING		
A7				(SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-3468-02
48	670-2241-02	B010100	B010399	CKT BOARD ASSY TRICOTO ALIERNAIE VERSION)		
48			2010033	CKT BOARD ASSY:TRIGGER GEN & Z AXIS LOGIC (SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-2241-02
. 0	070.000			(SEE SHI MONONE FOR ALIERNATE VERSION)		
48 48	670-2241-03	B010400		CKT BOARD ASSY: TRIGGER GEN & Z AXIS LOGIC	80009	670-2241-03
19	 670 0000 o.t			(SEE DM MANUAL FOR ALTERNATE VERSION)	00003	010-2241-03
	670-2239-04	B010100	B012999	CKT BOARD ASSY:MAIN	00000	
19				(SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-2239-04
9	670-2239-08	B013000	B014658	CKT BOARD ASSY:MAIN		
.9				(SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-2239-08
9	670 000					
9	670-2239-10	B014659	B020119	CKT BOARD ASSY:MAIN	80009	670-2239-10
9				(SEE DM MANUAL FOR ALTERNATE VERSION)	00003	010-2203-10
9	670-2239-12	B020120	B020838	CKT BOARD ASSY:MAIN	80000	670 0000 10
				(SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-2239-12
9	670-2239-21	B020839		CKT BOARD ASSY:MAIN		
9				(SEE DM MANUAL FOR ALTERNATE VERSION)	80009	670-2239-21
10	670-2279-00			,		
10	670-2744-01			CKT BOARD ASSY:CRT SCALE ILLUMINATION	80009	670-2279-00
	0,0-2/44-UI			CKT BOARD ASSY:INVERTER	80009	670-2744-01
690	147-0035-00	B010100	Barassa		20000	0, 0-L1 44*V1
8045		B010100	B016199	MOTOR, DC: BRUSHLESS, 10-15VDC, 145MA	25088	1AD3001-0A
0	147-0035-00	B016200		MOTOR, DC: BRUSHLESS, 10-15VDC, 145MA	25088	
-	281-0064-00			CAP., VAR, PLSTC: 0.25-1.5PF, 600V	74970	1AD3001-0A
1	282 0000 00				/ 49/0	273-0001-101
2	283-0000-00			CAP.,FXD,CER DI:0.001UF, + 100-0%,500V	50660	821610VEU04005
	285-0816-01			CAP.,FXD,PLSTC:0.019UF,10%,600V	59660	831610Y5U0102P
3	283-0000-00			CAP.,FXD,CER DI:0.001UF, + 100-0%,500V	80009	285-0816-01
0	307-1014-01			ATTENUATOR, FXD: 100X	59660	831610Y5U0102P
0				(QUANTITY OF 2)	8 0009	307-1014-01
1				(PART OF C30)		
2	307 1013 01					
2	307-1013-01			ATTENUATOR, FXD:10X	80009	207 1012 01
3				(QUANTITY OF 2)	00003	307-1013-01
				(PART OF C33)		
1	307-1012-00			ATTENUATOR, FXD:5X	80000	007 4040 5
1				(QUANTITY OF 2)	80009	307-1012-00
5				(PART OF C34)		
	307-1010-01					
)				ATTENUATOR,FXD:2X	80009	307-1010-01
i				(QUANTITY of 2)	50000	007-1010-01
i				(PART OF C36)		
	000 010			CAP., FXD, CER DI: 1000PF, + 100-0%, 200V		
i	283-0156-00					
•	281-0064-00			CAP., VAR. PLSTC:0 25-1 5PE 600V	96733	R2670
i				CAP., VAR, PLSTC: 0.25-1.5PF, 600V	74970	273-0001-101
	281-0064-00			CAP.,VAR,PLSTC:0.25-1.5PF,600V CAP.,FXD,CER DI:0.001UF,+100-0%,500V		

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

Replaceable Electrical Parts—475A Service

Ckt No.	Tektronix Part No.	Serial/Model No. Eff Dscor	Name & Description	Mfr	
0.5.6			Name a Description	Code	Mfr Part Number
C53	283-0000-00		CAP.,FXD,CER DI:0.001UF, + 100-0%,500V		
C61	283-0156-00		CAP.,FXD,CER DI:1000PF, + 100-0%,200V	59660	831610Y5U0102P
C104	281-0064-00		CAP, VAP PLOTO 2 25 / 275 00000000000000000000000000000000000	96733	
C105	283-0080-00		CAP.,VAR,PLSTC:0.25-1.5PF,600V	74970	
C107	283-0111-00		CAP., FXD, CER DI:0.022UF, + 80-20%, 25V	59821	
C109	283-0191-00		CAP.,FXD,CER DI:0.1UF.20%.50V	96733	
	200-0191-00		CAP., FXD, CER DI:0.022UF, 20%, 50V		
C112	281 0100 00			72982	8121N075Z5U0223
C113	281-0122-00		CAP., VAR, CER DI: 2.5-9PF, 100V		
	283-0156-00		CAP., FXD, CER DI: 1000PF, + 100-0%, 200V	59660	518-000A2.5-9
C119	283-0191-00		CAP.,FXD,CER DI:0.022UF,20%,50V	96733	R2670
C123	283-0080-00		CAR EXD CER DI 0 000107	72982	8121N075Z5U0223
C127	283-0080-00		CAP., FXD, CER DI:0.022UF, + 80-20%, 25V	59821	2DDU60E223Z
C133	281-0123-00		CAP., FXD, CER DI:0.022UF, + 80-20%, 25V	59821	2DDU60E223Z
			CAP., VAR, CER DI:5-25PF, 100V	59660	
C136	283-0213-00			00000	518-000A5-25
C137	283-0178-00		CAP., FXD, CER DI: 300PF, 5%, 100V	70000	
C138			CAP.,FXD,CER DI:0.1UF.+80-20% 100V	72982	8121N130C0G0301
2139	283-0177-00		CAP., FXD, CER DI: 1UF, +80-20%, 25V	72982	8131N145651 104Z
	283-0238-00		CAP.,FXD,CER DI:0.01UF,10%,50V	04222	SR302E105ZAA
2142			(PART OF CIRCUIT BOARD)	72982	8121N075X7R0103K
2144	290-0534-00				
			CAP., FXD, ELCTLT: 1UF, 20%, 35V	56289	196D105X0035HA1
147					1000 100X000001A1
151			(PART OF CIRCUIT BOARD)		
152			(PART OF CIRCUIT BOARD)		
153			(PART OF CIRCUIT BOARD)		
157	281-0504-00	B025938	CAP., FXD, CER DI: 10PF, +/-1PF, 500V	• • • • •	
158	290-0534-00		CAP.,FXD,ELCTLT:1UF,20%,35V	04222	7001-COG-100F
156	283-0156-00		CAP.,FXD,CER DI:1000PF,+100-0%,200V	56289	196D105X0035HA1
			0/1/ 1/ ND, CER DI. 1000PF, + 100-0%, 200V	96733	R2670
170	119-1467-00	B023830	COMPONENT LOOK		
172	283-0103-00		COMPONENT ASSY:(1)VVC (1)FXD CER CAP	80009	119-1467-00
175	281-0123-00		CAP.,FXD,CER DI:180PF,5%,500V	59660	831-518-Z5D0181J
82	283-0103-00		CAP., VAR, CER DI:5-25PF. 100V	59660	
204			CAP., FXD, CER DI: 180PF, 5%, 500V		518-000A5-25
205	281-0064-00		CAP., VAR, PLSTC: 0.25-1.5PF, 600V	59660	831-518-Z5D0181J
.05	283-0080-00		CAP., FXD, CER DI:0.022UF, + 80-20%, 25V	74970	273-0001-101
			10102/101000002201, +80-20%,25V	59821	2DDU60E223Z
07	283-0111-00		CAP.,FXD,CER DI:0.1UF,20%,50V		
09	283-0191-00		CAP EXD CER DI 0 000 UT 000	96733	R2632
12	281-0122-00		CAP., FXD, CER DI:0.022UF, 20%, 50V	72982	8121N075Z5U0223M
13	283-0156-00		CAP., VAR, CER DI:2.5-9PF, 100V	59660	518-000A2.5-9
19	283-0191-00		CAP., FXD, CER DI: 1000PF, + 100-0%, 200V	96733	R2670
23	283-0080-00		CAP.,FXD,CER DI:0.022UF.20%.50V	72982	
	200-0000-00		CAP.,FXD,CER DI:0.022UF, +80-20%,25V		8121N075Z5U0223M
27	000 000 00			59821	2DDU60E223Z
33	283-0080-00		CAP., FXD, CER DI:0.022UF, +80-20%, 25V		
	281-0123-00		CAP., VAR, CER DI:5-25PF, 100V	59821	2DDU60E223Z
36	283-0213-00		CAP.,FXD,CER DI:300PF,5%,100V	59 660	518-000A5-25
37	283-0178-00		CAR EXD CED DI GUUPT, 5%, 100V	72982	8121N130C0G0301J
8	283-0177-00		CAP., FXD, CER DI:0.1UF, +80-20%, 100V	72982	8131N145651 104Z
9	283-0238-00		CAP., FXD, CER DI: 1UF, + 80-20%, 25V	04222	SR302E105ZAA
			CAP., FXD, CER DI:0.01UF, 10%, 50V	72982	
2				12302	8121N075X7R0103K
4			(PART OF CIRCUIT BOARD)		
	290-0534-00		CAP.,FXD,ELCTLT:1UF,20%,35V		
7			(PART OF CIRCUIT BOARD)	56289	196D105X0035HA1
1			(PART OF CIRCUIT BOARD)		
2			(PART OF CIRCUIT BOARD)		
3	281-0504-00	B025938	(PART OF CIRCUIT BOARD)		
		2023330	CAP.,FXD,CER DI: 10PF, +/-1PF,500V	04222	7001-COG-100F
3					
7			(OPTION 07)		
	290-0534-00		CAP., FXD, ELCTLT: 1UF, 20%, 35V	50000	
3	283-0156-00		CAP.,FXD,CER DI:100PF, + 100-0%,200V	56289	196D105X0035HA1
)	119-1467-00 E	3023830	COMPONENT ACOVIANALO VIENE	96733	R2670
?	283-0103-00		COMPONENT ASSY:(1)VVC (1)FXD CER CAP	80009	119-1467-00
;	281-0123-00		CAP., FXD, CER DI: 180PF, 5%, 500V	59660	831-518-Z5D0181J
			CAP., VAR, CER DI:5-25PF, 100V		518-000A5-25
	283-0103-00		CAP.,FXD,CER DI:180PF,5%,500V		

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY **Tel:**-01844-351694 Fax:-01844-352554 **Email:**-enquines@mauriton.co.uk

REV DEC 1984

11000X5P331K	20660 30	CAPFXD.CEH DI:330PF,10%,500V	,	581-0546-00	2090
Z+01369000	28821 21		4 		209.0
73010052400		CAP., FXD, CER DI:0.10F, +80-20%, 25V		283-0081-00	90SO
01-000C0G0220K		CAP., FXD, ELCTLT:4.7UF, 20%, 10V		290-0524-00	C204
5632		CAP., FXD, CER DI:222PF, +/-2.2PF, 500V		281-0211-00	C200
5632		CAP.,FXD,CER DI:0.1UF,20%,50V		583-0111-00	
6690	96133 E	CAP., FXD, CER DI:0.1 UF, 20%, 50V		283-0111-00	C466
		(SELECTED AND ADDED IF NECESSARY)			C498 C494
		1			1013
121N153X7R0473K	12982 8	(USED AT LOCATION C494B)			C494
	00002	CAP.,FXD,CER DI:0.047UF,10%,100V		583-0341-00	C464
C1025U223M050B	F6289	(USED AT LOCATION C494B)			
32-212-Z2D0105K		CAP., FXD, CER DI: 0.22UF, 20%, 50V		283-0198-00	C494
M1010MSU00-10		CAP., FXD, CER DI:0.001 UF, 10%, 200V		283-0067-00	C464
1410 FONGLIUUU 100	E 09965	CAP., FXD, CER DI: 100PF, + /-20PF, 500V		283 0052 00	C491
12632	96733 F			00 0030 180	C486
52-2A000-81		CAP., FXD, CER DI:0.1UF, 20%, 50V		283-0111-00	0010
M100-050-X5F151M		CAP., VAR, CER DI:5-25PF, 100V		281-0123-00	C482
		V02,902FH DI:150PF,20%,50V			C477
01547B821J		CAP., FXD, CER DI:820PF, 5%, 500V		583-0139-00	C476
0010202810476		CAP., FXD, CER DI:10PF, +/-1PF, 200V		583-0116-00	S7475
S5-006-D9-35	72982	CAP., VAR, CER DI:9-35PF, 200V		281-0613-00	C472
				281-0097-00	1740
6-2.SA000-813		V001,399-52:10 P32,RAV,.9AD			
6-2.SA000-812	09969	V01F, 396 - 3.5.1 D - 3.5.		281-0122-00	C470
R2632		CAP. YAP.CER DI:0.1UF,20%,50V		281-0122-00	C466
8151N504 E 262M	72982	CAP. EXD CER DI-0 111E 20% E01		283-0111-00	C460
1C20X7R273K100B	26289	CAP., FXD, CER DI:5600PF, 20%, 200V		583-0180-00	C422
6-8.SA000-818		CAP., FXD, CER DI:0.027UF, 10%, 100V		583-0028-00	C424
	00001	CCP., VAR, CER DI:S.5-9PF, 100V		281-0122-00	C420
		(YRASSEDEN FI DEDDA DNA DETERS)			01/0
		(SELECTED AND ADDED IF NECESSARY)			C442
raheeooxeordaer	26289	(SELECTED AND ADDED IE NECESSADY)			C441
1AH8E00X8010881	26289	CAP., FXD, ELCTLT: 1UF, 20%, 35V		290-0534-00	C439
2000622332	12865	CAP., FXD, ELCTLT:1UF, 20%, 35V		290-0534-00	C438
2DDU60E223Z	12865	CAP., FXD, CER DI:0.022UF, +80-20%, 25V		583-0080-00	
	10003	CAP, FXD, CER DI:0.022UF, + 80-20%, 25V		283-0080-00	C437
LAH2E00X2010361	68299				C436
2001COJ287C	04555	CAP.,FXD,ELCTLT:1UF,20%,35V		290-0234-00	00+0
1AH2E00X2010361	68299	CAP., FXD, CER DI:2.7PF, 10%, 500V		281-054 00	C430
7001-COG-120J	04555	CAPFXD,ELCTLT:1UF,20%,35V		281 0642 00 290-0234-00	C450
301-000C0G01501		CAP., FXD, CER DI: 12PF, +/-0.6PF, 500V			C403
14H3E00X2010361	09969	V002,%8,9981:10 ABO,0X3,.9AO		281-0508-00	C399
\$113666X301G361	68295	CAP., FXD, ELCTLT:1UF, 20%, 35V		281-0628-00	86EC
27AS-LOD1007	7771.0			290-0534-00	96EO
301-000C0H0439C	04555	V008,%01,347.5:ID A30,0X3,.9A0			
	09969	CAP.,FXD,CER DI:4.3PF,+/-0.25PF,500V		281-0547-00	C364
D155F161F0	62800	CAP., FXD, MICA D: 160PF, 1%, 100V		281-0659-00	C393
301-000C0G05401	09965	CAP., FXD.CER DI:24PF, 5%, 500V		283-0640-00	848D
301055X5P271K	28627	CAP., FXD, CER DI:270PF, 10%, 500V		281-0564-00	275D
301-000U2J0680K	09969	CAP., FXD, CER DI:68PF, 10%, 500V		281-0543-00	C346
				281-0549-00	C343
		TO COLLECTOR OF Q338)			
		SAB MORA DEDED FROM BASE			C338
					C338
7001-COG-100F	04555	CAP.,FXD,CER DI:10PF,+/-1PF,500V			C338
D155E820F0	6853	CAP.,FXD,MICA D:82PF,1%,500V		281-0504-00	C338
D155E820F0	00823	CAP. FXD MICA D ROLE 10 FOR		283-0677-00	C336
		CAP., FXD, MICA D:82PF, 1%, 500V		583-0677-00	C332
21211008325U01042	72982	CAP.,FXD,CER DI:0.1UF, + 80-20%,50V			1000
931610Y5U0102P	09965	CAP. FXD CFR DIO 111E 1 90 000 501		283-0024-00	C353
831610Y5U0102P	09965	CAP., FXD, CER DI:0.001 UF, + 100-0%, 500V		583-0000-00	C350
196D2255X0020HA1	26289	CAP., FXD, CER DI:0.001UF, +100-0%, 500V		583-0000-00	
196D225X0020HA1	26233	CAP., FXD, ELCTLT: 2.2UF, 20%, 20V		290-0523-00	C310
196D475X0050KA1	26238	CAP.,FXD,ELCTLT:2.2UF,20%,20V		290-0523-00	2620
	00093	CAP., FXD, ELCTLT:4.7UF, 20%, 50V			C292
	2000			290-0525-00	C291
Mfr Part Number	epoO	Name & Description			<u> </u>
Mfr Part Number	Mtr Code		Serial/Model No. Eff Dscont	Part No.	CKt NO.

Au.co.notinusm@seiniupne -:lism3 YOA 0XO noxO 8 Cherry Tree Rd, Chinnor MAURITRON TECHNICAL SERVICES For Service Manuals Contact

CAP.,FXD,CER DI:0.01UF, + 80-20%,150V

CAP., FXD, ELCTLT:4.7UF, 20%, 10V

CAP., FXD, ELCTLT:4.7UF, 20%, 10V

CAP.,FXD,ELCTLT:4.7UF,20%,10V

CAP.,FXD,ELCTLT:2.2UF,20%,20V

CAP., FXD, CER DI: 8PF, + /-0.5PF, 500V

CAP., FXD, CER DI:82PF, +/-8.2PF, 500V

2-2

ZE011099H00Z

TDC475M010EL

TDC475M010EL

TEC475M010EL

196D225X0020HA1

0301-080-COHO-80

301-000U2M0820K

12869

10206

10206

10206

68299

09969

09969

308-000C0G0470K 09969 CAP.,FXD,CER DI:47PF,+/-4.7PF,500V 7027-C0G-330J 04555 00-01-0-182 CAP., FXD, CER DI:33PF, 5%, 600V \$89C ZE010364002 12865 281-0059-00 CAP.,FXD,CER DI:0.01UF, + 80-20%,150V C683 ZEDH66J103Z 12865 583-0003-00 CAP.,FXD,CER DI:0.01UF, + 80-20%,150V 6290 308-000C0G0350F 09969 00-2000-282 CAP., FXD, CER DI: 35PF, 1%, 500V 929C 931610Y5U0102P 09969 CAP., FXD, CER DI:0.001UF, + 100-0%, 500V 281-0632-00 8290 583-0000-00 0290 (SELECTED) 2001L66U103Z 12862 ----CAP., FXD, CER DI:0.01UF, +80-20%, 150V 6990 CAP., FXD, CER DI: 100PF, +/-20PF, 500V M1010MSU000-105 09969 583-0003-00 8990 200166J1032 12865 CAP.,FXD,CER DI:0.01UF, + 80-20%,150V 581-0523-00 279C 831610Y5U0102P 09969 CAP., FXD, CER DI:0.001UF, + 100-0%, 500V 283-0003-00 744C TDC475M010EL 10206 583-0000-00 CAP., FXD, ELCTLT:4.7UF, 20%, 10V 229C 290-0524-00 C622 0301080COH0428 D 09969 CAP..FXD,CER DI:4.7PF,+/-0.5PF,500V 10206 281-0592-00 CAP., FXD, ELCTLT:4.7UF, 20%, 10V 1190 68299 590-0524-00 CAP., FXD, ELCTLT:1UF, 20%, 35V 0190 10206 290-0634-00 CAP.,FXD,ELCTLT:4.7UF,20%,10V 6090 10206 290-0524-00 8090 CAP., FXD, ELCTLT:4.7UF, 20%, 10V 10206 290-0524-00 CAP., FXD, ELCTLT:6.8UF, 20%, 6V 2090 500-0256-00 9090 (SEE DM MANUAL) 10206 CAP., FXD.ELCTLT:4.7UF, 20%, 10V 509D 09969 590-0524-00 CAP., FXD, CER DI:47PF, +/-4.7PF, 500V 0090 10206 00-6150-182 CAP.,FXD,ELCTLT:4.7UF,20%,10V 6690 09969 CAP., FXD, CER DI:150PF, + /-30PF, 500V 500-0254-00 9690 09969 281-0254-00 CAP., FXD, CER DI: 15PF, 10%, 200V C293 00-7180-185 78SO 09969 CAP., FXD, CER DI: 100PF, + /-20PF, 500V 10206 281-0523-00 CAP.,FXD,ELCTLT:4.7UF,20%,10V C283 68299 590-0524-00 CAP., FXD, ELCTLT:4.7UF, 20%, 50V 1290 10206 530-0252-00 CAP., FXD, ELCTLT:4.7UF, 20%, 10V 0290 12869 CAP., FXD, CER DI:0.01UF, +80-20%, 150V 290-0524-00 \$9\$C 12869 283-0003-00 CAP., FXD, CER DI:0.01UF, + 80-20%, 150V C262 283-0003-00 2990 09969 CAP.,FXD,CER DI:100PF,+/-20PF,500V 10206 281-0223-00 CAP., FXD, ELCTLT:4.7UF, 20%, 10V 9990) 04555 590-0524-00 CAP., FXD, CER DI:12PF, +/-0.6PF, 500V 9990 12869 281-0508-00 CAP., FXD, CER DI:0.01UF, +80-20%, 150V #990 12869 CAP.,FXD,CER DI:0.01UF,+80-20%,150V 283-0003-00 975O 09965 00°£000°£8Z CAP., FXD, CER DI:7.5PF, 500V C243 00-1090-182 9290 12865 CAP.,FXD,CER DI:0.01UF,+80-20%,150V 12863 283-0003-00 CAP., FXD, CER DI:0.01UF, +80-20%, 150V C252 12865 583-0003-00 CAP.,FXD,CER DI:0.01UF,+80-20%,150V C25¢ 09969 00-E000-E8S CAP.,FXD,CER DI:22PF,+/-2.2PF,500V C251 10206 281-0511-00 CAP.,FXD,ELCTLT:4.7UF,20%,10V C250 12869 290-0524-00 CAP. FXD, CER DI:0.01UF, + 80-20%, 150V 61SO 283-0003-00 9150 09969 CAP.,FXD,CER DI:200PF,10%,500V 281-0605-00 (ARIW AJBATSULDA TROHS) 9190 09969

nscont

ΗB

Serial/Model No.

Part No.

XinontxleT

CKt NO.

TDC475M010EL 196D105X0035HA1 TDC475M010EL TDC475M010EL TDC685M00NLE TDC475M010EL 308-000C0G0470K TDC475M010EL MISIUSX000105 374-018-C0G0150K M1010MSU000-105 TDC475M010EL 196D475X0050KA1 TDC475M010EL ZED166J103Z 2DDH66J103Z M1010MSU000-105 TDC475M010EL 1001-COG-120J 200166J1032 ZEDIL66J103Z 301-000C0H0759D 2501L68H0032 ZED1660103Z ZEDH66J103Z 301-000C0G0220K TDC475M010EL ZED1103Z 301000A2D501K 301-000H3M0100D CAP.,FXD,CER DI:10PF,+/-0.5PF,500V C213 301-012C0G0120K 09969 281-0662-00 CAP., FXD, CER DI:12PF, +/-1.2PF, 500V 115D 301-000C0G0520K 09969 281-0505-00 CAP., FXD, CER DI:22PF, + /-2.2PF, 500V 0150 Z0013690002 12869 CAP., FXD, CER DI:0.10F, + 80-20%, 25V 281-0511-00 6090 283-0081-00 80SD Mfr Part Number apon

Name & Description

лw

REV DEC 1984

#120

£1/0

C112

1120

8690

S69C

8690

00-2000-282

590-0524-00

590-0524-00

290-0524-00

590-0523-00

281-0203-00

00-8Z90-L8Z

Replaceable Electrical Parts-475A Service

SE0-E010-781	07647	V02S, 494. 2-5. 1:10 AIA, AAV, 9AO		281-0168-00	6001O
					00010
06010H0029081118	09965	CAP., FXD, CER DI: 7PF, 5%, 500V		583-0122-00	C1008
931610Y5U0102P	09965	CAP., FXD, CER DI:0.001UF, + 100-0%, 500V		583-0000-00	
301-000C0H0629C	09969	CAP., FXD, CER DI:6.2PF, +/-0.25PF, 500V			20010
7001-NPO-210J	04555			281-0658-00	786C
196D2255X00201		CAP., FXD, CER DI:21PF, 5%, 500V		281-0226-00	9260
	68283	CAP., FXD, ELCTLT:2.SUF, 20%, 20V		280-0253-00	6960
TDC475M010EL	10206	CAP., FXD, ELCTLT:4.7UF, 20%, 10V		590-0254-00	2960
1AH0200X8220861	60700				2000
196D225X00201	26289 26289	CAP., FXD, ELCTLT:2.2UF, 20%, 20V		500-0253-00	596C
		CAP., FXD, ELCTLT:2.2UF, 20%, 20V		290-0523-00	C96C
196D225X0020HA1	68295	CAP., FXD, ELCTLT:2.2UF, 20%, 20V		500-0253-00	1960
831610Y5U0102P	09965	CAP., FXD, CER DI:0.001UF, + 100-0%, 500V			
196D225X0020H	68295	CAP., FXD, ELCTLT: 2.2UF, 20%, 20V		583-0000-00	C947
		(NOT USED WITH DM44)		290-0523-00	C633
					C923
1AH2E00X2010301	68295	V2C, %0S, 7U1: T1T2, GX4, 9A2		590-0634-00	0700
301-080-C0G0150K	09969	CAP., FXD, CER DI:15PF, +/-15PF, 500V			C923
301000X00010E	09965	CAP. FXD.CER DI:470PF, +, -94PF, 500V		281-0509-00	C922
196D475X0050KA1				281-0525-00	216O
	26289	CAP., FXD, ELCTLT: 4.7UF, 20%, 50V		5 0-0252-00	£160
196D2255X0020HA1	56289	CAP.,FXD,ELCTLT:2.2UF,20%,20V		290-0523-00	
931610Y5U0102P	09969	CAP., FXD, CER DI:0.001UF, + 100-0%, 500V	600070		S06C
			050839	583-0000-00 E	C901
196DS25X00201	68295	CAP., FXD, ELCTLT:2.SUF, 20%, 20V		590-0253-00	
TDC475M010EL	10206	CAP., FXD, ELCTLT: 4.7UF, 20%, 10V			C856
374-018-COG0150K	09965	V002,007 115 13 13 14 14 14 14 14 14 14 14 14 14 14 14 14		290-0524-00	C826
301-000U2M0101M	09969			281-0012-00	C854
TDC475M010EL		CAP.,FXD,CER DI:100PF,+/-20PF,500V		281-0523-00	C823
	10206	CAP.,FXD,ELCTLT:4.7UF,20%,10V		590-0254-00	6180
301-080-C0G0150K	09969	CAP.,FXD,CER DI:15FF,+,+,APE,:ID RED,DXA,.9AD		281-050-050	1180
rah0200x822d86f					1180
	26289	CAP.,FXD,ELCTLT:2.2UF,20%,20V		290-0523-00	C803
93161075U0102P	09965	CAP., FXD, CER DI:0.001UF, +100-0%, 500V		583-0000-00	
196D225500201	68295	CAP., FXD, ELCTLT:2.2UF, 20%, 20V			6620
2DDH61L502P	12865	CAP.,FXD,CER DI:0.005UF,+100-0%,500V		290-0523-00	8670
0301080COH0479 D	09965	CAP. FXD CFR DI-0 005115 + 100 0% 600V		283-0001-00	96ZO
TDC475M010EL		CAP., FXD, CER DI:4.7PF, +/-0.5PF, 500V	3056345	281-0592-00	£620
13010M92000T	10206	CAP.,FXD,ELCTLT:4.7UF,20%,10V		590-0524-00	5820
2DDH66J103Z	12865				2020
ZDDH66J103Z		CAP.,FXD,CER DI:0.01UF, +80-20%,150V		283-0003-00	£820
	12862	CAP., FXD, CER DI:0.01UF, +80-20%, 150V		283-0003-00	
301-000U2M0101M	09965	CAP.,FXD,CER DI:100PF,+/-20PF,500V			2220
TDC475M010EL	10206	CAP., FXD, ELCTLT:4, 7UF, 20%, 10V		281-0523-00	9220
7001-COG-120J	04555			290-0524-00	922O
2DDH66J103Z	12865	CAP., FXD, CER DI:12PF, +/-0.6PF, 500V		281-0508-00	\$220
200910011000	10003	CAP.,FXD,CER DI:0.01UF,+80-20%,150V		283-0003-00	1220
200166J103Z	12865	CAP.,FXD,CER DI:0.01UF,+80-20%,150V			
TDC475M010EL	10206			283-0003-00	9920
ZEDH66J103Z		CAP.,FXD,ELCTLT:4.7UF,20%,10V		290-0524-00	\$92O
	12865	CAP., FXD, CER DI:0.01UF, +80-20%, 150V		283-0003-00	
TDC475M010EL	10206	CAP.,FXD,ELCTLT:4.7UF,20%,10V			£920
301-000C0H0759D	09965	CAP. FXD, CER DI.7.5PF, 500V		290-0524-00	C162
ZDDH66J103Z	12865	AUG1 (%) 27-00 ± (1010) 210 EUG 10 10 10 10 10 10 10 10 10 10 10 10 10		281-0601-00	972O
		V021, FXD, CER DI:0.01UF, +80-20%, 150V		583-0003-00	C745
ZEDH66J103Z	12865	CAP.,FXD,CER DI:0.01UF, +80-20%,150V			
2DDH66J103Z	12865			283-0003-00	C144
TDC475M010EL		CAP., FXD, CER DI:0.01UF, +80-20%, 150V		583-0003-00	L720
	10206	CAP.,FXD,ELCTLT:4.7UF,20%,10V		590-0254-00	
2DDH66J103Z	12862	CAP., FXD, CER DI:0.010F, +80-20%, 150V			6243
30100075D201K	09969	CAP., FXD, CER DI:200PF, 10%, 500V		283-0003-00	9820
ZEO166J103Z	12865			281-0605-00	987D
		CAP.,FXD,CER DI:0.01UF, + 80-20%,150V		583-0003-00	C129
301-000H3M0100D	09969	CAP.,FXD,CER DI:10FF,+/-0.5PF,500V			
301-012C0G0120K	09965			281-0662-00	C722
301-000C0C0C0S20K	09965	CAP.,FXD,CER DI:12PF,+/-1.2PF,500V		00-2020-182	L2721
		CAP., FXD, CER DI:22PF, + /-2.2PF, 500V		281-0511-00	
301-000C0G0550K	09965	CAP., FXD, CER DI:22PF, + /-2.2PF, 500V			6120
301-000C0G0520K	09965	CAP., FXD.CER DI:22PF, +/-2.2PF, 500V		281-0211-00	812D
200166J1032	12865	CAP., FXD, CER DI:0.01UF, + 80-20%, 150V		281-0611-00	212O
				283-0003-00	S115
Mfr Part Number	Sode	Name & Description			
	ЧW		Eff Dscont	Part No.	CKt No.
			Serial/Model No.	Tektronix	

8-7

REV DEC 1984

 For Service Manuals Contact

 Maugrifrou TECHNICAL SERVICES
 Maugrifrou Technical Service

 Maugrifrou Technical Service
 Charve Technical Service

 Oxon OX9 4QY
 Oxon OX9 4QY

 Tels: 01844-351694 Fax- 01844-355554
 Email: enquirise

Tel:-01844-351694 Fax:-01844-352554 Email:-enquines@maunton.co.uk For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 407. Oxon OX9 404.455555

REV DEC 1984

		(DRAOB TIUDRID AO TRA9)			
S00-9010-7	01 07057			*****	C1255
2 0106 00E		CAP., AAA, AAA, AAA, AAA, AAA, AAA, AAA,		00-0010	
031513191	00853 D1	CAP., FXD, MICA D:130PF, 1%, 100V		581-0153-00	C1253
C00-0010-11	.	(PART OF CIRCUIT BOARD)		283-0638-00	C1251
900-9010-21		V08S, A901-7, 1:10 AIA, AAV, 'AAO			C1532
121E131E0		V001,%1,39061:0 AOIM,0X1,3AU		281-0153-00	C1233
80502605052010	26289 10	CAP., FXD, CER DI:0.05UF, + 100-20%, 50V		283-0638-00	C1231
				283-0010-00	C1216
131//30022001036		CAP.,FXD,CER DI:0.01UF, +100-0%,250V			
121/130022001036		CAP., FXD.CER DI:0.01UF, +100-0%, 250V		283-0002-00	C1212
121/130025U0103P		CAP.,FXD,CER DI:0.01UF, + 100-0%,250V		283-0002-00	C1211
131//30025U0103P		CAP., FXD.CER DI:0.01UF, + 100.0%, 250V		283-0005-00	C1205
C10Z5U503Z050B	1 68295	CAP. FXD.CER DI:0.05UF. + 100-20%,50V		283-0005-00	C1201
18M231	25269 G	CAP. EXD CER 7010 06115 / 100 000 1001		283-0010-00	28110
		V3T1,3906-8:0 ADIM, RAV., 9AD		281-0118-00	62110
0115175210	00823 D	A000'%/ 1' / 1001 : 0 Month			02110
ZE01L03Z	26821 2	CAP., FXD, MICA D: 150PF, 1%, 500V		583-0644-00	82110
ZE01699HQQ	20851 5	CAP., FXD, CER DI:0.01UF, + 80-20%, 150V		283-0003-00	29110
12632		CAP., FXD, CER DI:0.01UF, +80-20%, 150V		283-0003-00	
8090ZE0909Z0101		CAP., FXD, CER DI:0.1 UF, 20%, 50V		283-0111-00	C1152
L128874210		CAP., FXD, CER DI:0.05UF, + 100-20%, 50V		283-0010-00	C1145
	00003	CAP., FXD, CER DI:820PF, 5%, 500V		283-0110-00	C1140
L1288742108	09969			00 9110 580	C1134
1C102203032020B		CAP.,FXD,CER DI:820PF,5%,500V		00-01/0 00-	
	00099	CAP., FXD, CER DI:0.05UF, + 100-20%, 50V		583-0116-00	C1154
201-COJ-287C	77750	(VRASSED AND ADDED IF NECESSARY)		283-0010-00	61114
D165F2750F0	00010	V002,001,397.25ID R30,0X44A0			20110
196D22550020HA1	00823	V002,%1,34375;0 ADIM,0X4,,4AD		281-0547-00	20110
**************************************	56289	CAP., FXD, ELCTLT:2.2UF, 20%, 20V		283-0670-00	C1103
196022520301				290-0523-00	C1033
LAHOCODY ACCUART	68295	CAP., FXD, ELCTLT: 2.2UF, 20%, 20V			
		(SEE FOOTNOTE ON C1071)		290-0523-00	16010
		(SEE EODINOLE ON CI021)			C1082
595-0163-00	60008	CAP SET, MATCHED: (2)EA,0.1UF,10UF,985UF			C1083
M1010MSU000-105	09969	CAP.,FXD,CER DI:100PF,+/-20PF,500V		592-0163-00	C1082
801-547P2G330G	09969	CAP. FXD.CER DI:33PF,1%,500V		581-0523-00	18010
		CAP, EXD CER DI338E 19/ E001		583-0144-00	92010 92010
					32010
		THE TIMING CAPACITORS IN THE ASSY. EXAMPLE: 285-XXXX-XX F-)			£2010
		THE TOLERANCE SHOULD BE THE SAME FOR ALL			£2010 £2010
		THE TOLERANCE SHOLLD BE THE SAME SOFT			-
		CAPACITOR TO BE REPL. THE LETTER SUFFIX &			C1013
		SUFFIX & TOLERANCE PRINTED ON THE TIMING			E2010
		BE ORDERED BY THE 9-DIGIT P.N., LETTER			C1013
		150/4/100/			£2013
		INDIVIDUAL TIMING CAPS IN THI SASY MUST			
295-0163-00	60008	(C1071 THRU C1073, AND C1082 THRU C1085,			E7013
5.2A620-717-62	33095	CAP SET,MATCHED:(2)EA.0.1UF,10UF,985UF			2701D
SDDH66J103Z	12865			595-0163-00	12010
TLS365K125B1A	+	V021.%02-08+,3U10.0:10 A30,0X4,.4A0		281-0096-00	C1064
1 0101/12003 11	10206	CAP., FXD, ELCTLT:3.6UF, 10%, 125V		583-0003-00	C1062
301055X5P271K	7067 /			290-0392-00	C1028
81210155X750473K	72982	CAP., FXD, CER DI:270PF, 10%, 500V			
196D475X0950KA1	72982	V001, %01, 3UT40 DI:0.047UF, 10%, 100V		281-0543-00	C1058
CITIODS200010E	26289	CAP., FXD, ELCTLT:4.7UF, 20%, 50V		283-0341-00	9901D
ZE0109500105	72982	CAP., FXD, CER DI:170PF, 5%, 500V		590-0525-00	C1054
2010001010100	12862	CAP., FXD, CER DI:0.01UF, + 80-20%, 150V		281-0589-00	C1052
831610Y5U0102P	09 9 65	CAP., FXD, CER DI:0.001 UF, + 100-0%, 500V		283-0003-00	C1020
		CAP EXD CER DIG 001115 1100 000		283-0000-00	C1042
301-000U2J0680K	09969				27010
		CAP., FXD, CER DI:68PF, 10%, 500V		581-0549-00	C1033
TDC475M010EL	10206	(OPTION 07)			
5.2A920-717-68	960EE	CAP.,FXD.ELCTLT:4.7UF,20%,10V		590-0524-00	C1056
8.8A6S0-717-£8	33095	V035,3981-2.3:10 RIA,RAV, 9AD		00-9600-182	C1056
2DDH66J103Z	12865	CAP., VAR, AIR DI:5.5-18PF, 350V		00-9600-185	C1025
		CAP.,FXD,CER DI:0.010F, +80-20%,150V			C1053
Mir Part Number				283-0003-00	01010
Mfr Part Miner	Sode	Name & Description	10000		
	Mfr	1	Ett Dacon	Part No.	CKF NO.
			Serial/Model No.	Tektronix	
				· -	

Replaceable Electrical Parts—475A Service

Tektronix

200H69J203Z	29851 SC	AP.,FXD,CER DI:0.02UF, +80-20%,150V	c		283-0004-00	
96096-0		AP., FXD.ELCTLT.10000F, + 75-10%, 75V	^			
FP351MN1J3P2	90201 bi	AP., FXD, ELCTLT: 350UF, + 75-10%, 75V	5		590-0586-00	
46013662-17	18 09965		n)		590-0585-00	
00075005 12	0 03903	A0.000, 000 + , 1010.01 IG RADIO			583-0068-00	
71-533E103P	8 09969	34P.,FXD,CEA DI:0.01UF,+100-0%,500V SPTION 04)))			
		ACCENTION OF A THEORY OF A TOP OF A THEORY	כ		583-0068-00	
71-533E103P	8 09965	OPTION 04))			ç
		24P., FXD, CER DI:0.01UF, + 100-0%, 500V			583-0068-00	ç
95013663-170	8 09969	CAP.,FXD.CER DI:0.01UF, + 100-0%,500V OPTION 04)) \			ģ
4901 2000-1 //			1		283-0068-00	9
921-533E103P	8 09965	CAP., FXD, CER DI:0.01UF, + 100-0%, 500V	•		00-000-007	ţ
					283-0068-00	4
931610Y5U0102P		CAP.,FXD.CER DI:0.001UF,+100-0%,500V (OPTION 04)				ε
Z401 129241N1618	72982	CAP.,FXD,CER DI:0.1UF.+80-20%,100V CAP.,FXD,CER DI:0.001UF ±1000			583-0000-00	ء 2
200H61L502P		CAP.,FXD.CER DI:0.005UF, + 100-0%, 500V			283-0178-00	6
2DDH61L502P		CAP.,FXD,CER DI:0.005UF, + 100-0%,500V			583-0001-00	2
2DDH61L502P	12862	CAP.,FXD,CER DI:0.005UF, +100-0%,500V			283-0001-00	14
196D225X002041	60700				283-0001-00	00
196D225X0020HA1	68299 26286	CAP., FXD, ELCTLT:2.2UF, 20%, 20V			00-07-00-	
430P522	26289	CAP., FXU, ELCTLT:2.2UF, 20%, 20V			590-0253-00 590-0253-00	88
7A802132010002	26289	CAP., FXD, PLSTC:0.0012UF, 10%, 4000V			280 0623 00	28
Z401 129541N1618	72982	CAP.,FXD,ELCTLT:1UF, + 50-10%,150V			290-0164-00	80 74
430P522	68299	CAP., FXD, PLSTC:0.0012UF, 10%, 4000V CAP., FXD, CER DI:0.1UF, + 80-20%, 100V			583-0178-00	27 23
		CAP EXD PLSTO 0.0121 PLSTO			585-1040-00	22
430P522 77001-COK-1R0C	26289	CAP., FXD, PLSTC: 0.0012UF, 10%, 4000V				
2C2025U104Z200B	04555	CAP., FXD, CEH DI:1PF, + /-0.25PF, 500V			585-1040-00	12
SC2025U104Z200B	26289 26289	V002.802-08+,3U1.0:10 H3D,0X1,.4AD			281-0627-00	99
8131//30025U0103P	28627	V002.80-201UF, + 80-20%.200V			283-0057-00	E91
101-1000-573	02672	CAP., FXD, CER DI:0.01UF, +100-0%, 250V			283-006-00 283-006-00	858
100.000		V009, 792.1-25.0: OT219, RAV, .9AD			281-0064-00	324 325
8131/30025U0103P	28627	V025, 00-01 + , 101-0:01 P3D, 079, 250V				636
200196901032 0801 247X5F0102M	12862	CAP., FXD.CER DI:0.01UF, + 80-20%, 500V			283-0005-00	348
MS01033X743 1080	09969	V002,%02,3U100.0:10 R3O,0X4,.4AO			283-0002-00	346
TDC475M010EL	10206 10206	CAP., FXD, CER DI:0.0010F, 20%. 500V			283-0078-00	936
ZE01169HQQS	10206	V01,002,3U7,4C110,4C10V			583-0078-00	332
	10003	CAP.,FXD,CER DI:0.01UF,+80-20%,500V			290-0524-00 290-0524-00	330
4306507	68295	A0000'8/ 07' 100000101-			283 0002 00	329
3905SF602Y55682Z	09969	CAP.,FXD,CER DI:0.0068UF,+80-30%,5000V CAP.,FXD,PPR DI:0.0068UF,+80-30%,5000V		B016520	10-6050-582	328
308-000C0C0C0470K	09969	CAP.,FXD,CER DI:47PF, +/-4.7PF,500V	6129108	0010108	283-0071-00	1328
4305256027556822	26289	CAP., FXD, PPR DI:0.0068UF, 20%, 5000V			281-0519-00	1326
430P505756027555937	09969	V0002 %05-08 + , JU8900.0:10 H30, 0X1, 4A0	6100100	B016520	10-0050-285	1323
2030069	26289	CAP., FXD, PPR DI:0.0068UF, 20%, 5000V	6168108	0010108	283-0071-00	1353
39055F602Y556822	09965			B016520	10-0050-285	1355
39028F401Z5U0103	09969	CAP., FXD, CER DI:0.0068UF, +80.30%, 5000V	616510B	0010108	00-1/00-007	
222500X9740021	262293	CAP., FXD, CER DI:0.01UF, 2000V		0010100	283-0011-00 283-0011-00	1322
TDC106M025FL	10201	CAP., FXD, ELCTLT:47UF, 10%, 35V			283 0011 00	1350
TAH2E00X2010961	68299	CAP., FXD, ELCTLT: 10UF, 20%, 25V CAP., FXD, ELCTLT: 10UF, 20%, 25V			590-0536-00	8161
1AH0200X4010301	26289	CAP., FXD, ELCTLT:0.10F, 20%, 50V			590-0534-00	21813 21316
1 AL0200X2720361		CAP EYD ELCTITO ALLE OF T			290-0572-00	50613
rAH2600X2010301	20289	CAP., FXD, ELCTLT:2.7UF, 20%, 50V				
ZE0E0U224E2-248	26289				590-0213-00	\$0CLC
TDC106M025FL	20500 10206	CAP., CER DI:0.03UF, + 80-20%, 200V			590-0234-00	21305
IDC106M025FL	10206	VAP.,FXD,ELCTLT:10UF,20%,25V			583-0035-00	21267
TDC106M025FL	10200	CAP., FXD, ELCTLT:10UF, 20%, 25V			590-0236-00 590-0236-00	01565
		CAP., FXD, ELCTLT: 10UF, 20%, 25V			290.0536.00	C1563 C1561
Mfr Part Number	Sode	Undussa n sure	_			19010
-	Mfr	Name & Description	Dscont	Eff	Part No.	CKI NO.
			.oN I9bo	M/Isin92		Okt NIC

REV DEC 1984

01-7

91410 41410 C1412 C1408 C1408 20410 20410 C1406 C1409 C1402 C1402 C1404 C1404 C1403 C1403 66E10 2681D C1394 C1330 C1388 7851C C1380 \$2613 61373 C1372 12810

C1366

C1363

C1358 C1324 C1352

C1348

0134P

C1338 C1332 C1330 C1329

Au.co.notinusm@eeniupne -:lism3 10: 01844 321634 Eax. 01844-362554 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY For Service Manuals Contact MURITRON TECHNICAL SERVICES

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 40Y Tel: 01844-351694 Fax: 01844-352554 Temail: enquires@mauritron.co.uk

11-2

REV DEC 1984

-533E103P	1/9 00000	(20 NOILdO))		
	128 09969	CAP.,FXD,CER DI:0.01UF, + 100-0%,500V)		C1685
			, ,	283-0068-00	C1685
-533E103P	128 09965	(20 NOLTO)	1		-
		CPP.,FXD.CER DI:0.01UF, +100-0%,500V		00-000-007	C1684
1-233E103b	28 09965	CAP.,FXD.CER DI:0.01UF, + 100-0%,500V (OPTION 07)		583-0068-00	C1684
1610Y5U0102P		CAP. FXD. CFR Div0 01115 1 100 001 5000		583-0068-00	C1683
COLUISVOIAL	68 09965	CAP.,FXD,CER DI:0.001UF,+100-0%,500V (OPTION 07)			C1683 C1683
				583-0000-00	S8810
1-533E103P	48 0996 5	(20 NOIL90)			00310
					18910
86566Y5R0222M	28 09965			283-0068-00	1891O
1417770110		CAP., FXD, CER DI:0.0022UF, 20%, 3000V		583-0563-00	\$291C
28226Y5R0222M	28 09965	CAP., FXD, CER DI:0.0022UF, 20%, 3000V (OPTION 07.MOUNTED ON 475A REAR PANEL)		283-0263-00	¢1674
		CAP. EXD CER DI-0 0000 11 1000 010		583-0563-00	C1672
L1740032280168	0 00000	(20 NOILdO)			C1672
11100132380168	0 09965	V002,%2,39074:10 A30,540,500V			12910
Z205-3-742-28	8 09965	(10 1011 10)		583-0035-00	12910
		CAP.,FXD,CER DI:0.005UF,+80-20%,150V			C1664
2205-347-E-5022	8 09969	(10 NOUL 10)		583-0110-00	C1664
		CAP.,FXD,CER DI:0.005UF,+80-20%,150V		00-01-0	C1662
		,		283-0110-00	C1662
2209-3-747-E-502Z	3 09965	CAP.,FXD,CER DI:0.005UF,+80-20%,150V (OPTION 07)			
2205-347-E-5022		CAP. FXD. CEB DI-0 005115 (00 0001 10)		583-0110-00	C1654
2003 3 273 338	09969	CAP.,FXD.CER DI:0.005UF,+80-20%,150V (OPTION 07)			C1654 C1652
196D156X0050PE4	26289			583-0110-00	C1652
	08039	CAP., FXD, ELCTLT:15UF, 20%, 50V			C1626
				290-0528-00	C1626
TDC337M006WLD	10206	(70 NOIT90)			
11/00000000		CAP., FXD, ELCTLT: 330UF, 20%, 6V		00-000-007	C1622
1AL0200X27SQ301	68295	CPP.,FXD,ELCTLT:2.7UF,20%,50V (OPTION 07)		590-0233-00	C1622
Z401 129541N1618	70.00			00-6720-062	\$1910
2101 133311M1518	28627	CAP.,FXD,CER DI:0.1UF,+80-20%,100V (OPTION 07)			C1614
				583-0178-00	6091C)
C1W010MLC	10206	(20 NOILGO)			00310
	10000	CAP., FXD, ELCTLT: 100UF, 20%, 10V			S0910
Z401 129241N1618	72982	(/0 NOU 40)		290-0531-00	C1605
Aa . – .		CAP., FXD, CER DI:0.10F, +80-20%, 100V		283-0178-00	C1603
500D158	68295	(OPTION 07)		283-0128 00	C1603
0301080C0G0510K		CAP.,FXD,ELCTLT:330UF,+75-10%,50V		00-7660-062	C1601
DIMO000000000000000000000000000000000000	09965	CAP., FXD, CER DI:27PF, +/-2.7PF, 500V			C1601
192P68392M465	90204 26289			281-0212-00	C1512
2001-1363	04222	V001.%01.3U880.0:OT214,0X4,.4AO		590-0532-00	C1510
196D225X0020HA1	68295			285-0686-00	C1505
ZE0E0N9Z7E9-978	09965			281-0551-00	C1504
		CAP., FXD, CER DI:0.03UF, + 80-20%, 200V		590-0523-00	C1492
8131/145651 1042	72982			283-0092-00	68410
TDC100W052EL	10206	CAP., FXD, CER DI.0.1UF, +80-20%, 100V		283-0178-00	
68D10490	56289	CAP.,FXD,ELCTLT:3000UF, +100-10%,35V CAP.,FXD,ELCTLT:3000UF, +100-10%,35V		283 0128 00	C1483
PFP552GN4A3P2	26289	CAP., FXD, ELCTLT: 33UF, 20%, 10V		290-0583-00	8741D
196D336X0010KA1	10206	CAP., FXD, ELCTLT:5500UF, + 100-10%, 30V		590-0535-00	61458 57473
	68295	CAP., FXD.ELCTLT:33UF.20%, 10V		00-4820-062	C1462
200169HDDS	12865			290-0535-00	C1458
PFP20-36043	10206	CAP., FXD, CER DI:0.02UF, + 80-20%, 150V			
TDC106M025FL	10206			583-0004-00	C1422
PEP552GN4A3P2	90204			590-0221-00	C1452
	09965	CAF., FXD, ELC/1LT:5500UF + 100-10% 30V		290-0536-00 290-0584-00	C1448
196D475X0050KA1	68295	CAP., FXD.CER DI:330PF, 10%, 500V		00-9420-082	C1445
12011101		CAP., FXD. ELCTLT:4. TUF, 20%, 50V		290-0525-00	C1431
Mfr Part Number	Sode	Name & Description			C1458
	чtМ	tritorio 2 ameli	Ett Daco	Part No.	
			Serial/Model No.		CKI NO.
			2	· • • • • • •	

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY 701: 01844-351694 Fax:- 01844-352554 Email:- enquines@mauriton.co.uk

REV DEC 1984

ì

NDP0263 (1N4152) 696ZL SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 122-0141-05 NDP0263 (1N4152) E07HO 696ZI SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 15969 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35 NDP0263 (114152) 152-0141-02 15969 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 10280 152-0141-02 NDP0263 (1N4152) SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 669HO 696ZL 152-0141-02 (2214N1) 29204QN ¢6980 15966 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 152-0141-02 CE693 15969 SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 152-0141-02 689HO NDP0263 (1N4152) 152-0141-02 15969 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 289HC NDP0263 (1N4152) SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 696ZL 152-0141-02 (2214N1) 29204QN SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 CH683 6967 L 152-0141-02 NDP0263 (1N4152) SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 6967 L CH682 152-0141-02 NDP0263 (1N4152) 189AD 696ZL SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 NDP0263 (114152) 152-0141-02 69671 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 08980 152-0141-02 27980 152-0141-02 NDP0263 (1N4152) S0980 69671 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 15969 SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35 152-0141-02 NDP0263 (1N4152) SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 \$098C 696ZL NDP0263 (1N4152) 152-0141-02 15969 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 109AD 152-0141-02 NDP0263 (1N4152) CH592 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 69671 152-0141-02 \$88AO (SELECTED, ALTERNATE PN 152-0386-00) 152-0141-02 CR582 96601WS 80550 995HO SEMICOND DEVICE: TUNNEL, 8PF, 10MA (SELECTED, ALTERNATE PN 152-0386-00) 152-0140-01 Seedtms 80550 995HO SEMICOND DEVICE: TUNNEL, 8PF, 10MA 05140 803508 955RO SEMICOND DEVICE:SW,SI,40V,200MA NDP0263 (1N4152) 152-0140-01 15969 SEMICOND DVC.DI:SW.SI,30V,150MA,30V,DO-35 955RO NDP0263 (114152) 152-0246-00 696ZL SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 613AD 152-0141-02 CB480 152-0141-02 NDP0263 (1N4152) 696ZL CB422 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (114152) SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35 696ZL NDP0263 (1N4152) 152-0141-02 15969 SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35 698HO 152-0141-02 NDP0263 (1N4152) 69671 SEMICOND DVC.DI:SW,SI,30V,150MA,30V,DO-35 896AO NDP0263 (1N4152) 152-0141-02 15969 CB361 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 122-0141-05 SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35 69883 696ZL 152-0141-02 CB352 NDP0263 (1N4152) 152-0141-02 696ZL CB351 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 15969 SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35 NDP0263 (114152) 152-0141-02 CB336 696ZL SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 152-0141-02 CH322 15969 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 152-0141-02 15969 CB312 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 NDP0263 (1N4152) 152-0141-02 15969 90ERO SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 152-0141-02 CB301 NDP0263 (1N4152) 152-0141-02 69671 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 CB290 SMV1264 61740 SEMICOND DEVICE:SILICON,4V,7PF 2WV1264 152-0141-02 CB282 81740 SEMICOND DEVICE:SILICON,4V,7PF NDP0263 (1N4152) 125-0455-00 15969 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35 CB274 6285209 0010108 125-0455-00 10130 07280 80950 SEMICOND DEVICE:SILICON, 35V, 0.1A 152-0141-02 10130 803508 2028D SEMICOND DEVICE:SILICON, 35V, 0.1A 152-0323-01 CB205 152-0323-01 10130 80550 CB204 SEMICOND DEVICE:SILICON, 35V, 0.1A NDP0263 (1N4152) SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35 696ZL 192-0323-01 5MV1264 CB203 61740 SEMICOND DEVICE:SILICON,4V.7PF 152-0141-02 2MV1264 CR182 04113 NDP0263 (1N4152) SEMICOND DEVICE:SILICON,4V,7PF 125-0455-00 15969 #2180 SEMICOND DVC,DI:SW2:I2,00,120MA,300,D0-35 6785209 0010108 152-0422-00 1013Q 07180 80920 SEMICOND DEVICE:SILICON, 35V, 0.1A 152-0141-02 20180 152-0323-01 10130 80550 SOLAD SEMICOND DEVICE:SILICON, 35V.0.1A 10130 803508 SEMICOND DEVICE:SILICON, 35V, 0.1A TDC106M025FL 152-0323-01 40180 10206 CAP., FXD, ELCTLT: 10UF, 20%, 25V 152-0323-01 TDC106M025FL C01HO 10206 CAP., FXD, ELCTLT: 10UF.20%, 25V B016200 290-0536-00 ¢9080 6619108 0010108 971-533E103P 290-0536-00 09969 (70 NOIT90) 8691D CAP., FXD. CER DI:0.01UF, + 100-0%, 500V 98910 00-8900-682 Mfr Part Number 98910 epoo Name & Description ЦW nocont ΗÐ Part No. CKI NO. Serial/Model No. Tektronix

Tel:- 01844-351694 Fax:- 01844-3**525554** Email:- enquiries@mauriton.co.uk For Service Manuals Contact MAURITRON TECHNICAL SERVICES & Cherry Tree Rd, Chinnor Oxon OX9 4QY Tal- n18AA-35180A Fry- n18AA-353555

REV DEC 1984

2-13

NDP0263 (144152)	12969 И	35-00, V05, AM021, V05, IS, W2:10, DV-35	6	152-0141-02	F 601110
NDP0263 (114152)				00 1710 031	CE1034
VDP0263 (1N4152)	12969	55-00,V06,AM021,V06,I2,W2:I0,DV2 0V0,D0-35	5	152-0141-02	6701110
NDP0263 (114152)		EMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	6	152-0141-02	CH1028 CH1028
NDP0263 (1N4152)		SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	5	152-0141-02	CB1036
NDP0263 (1N4152)		SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35	<u>;</u>	152-0141-02	CR1023
ND60263 (1N4152)		SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	;	152-0141-02	810190
(CALMAL) FACUADA	12969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	;	152-0141-02	210193
ND60263 (104152)					210103
NDP0263 (1N4152)	-	SEMICOND DAC, DI: SW, SI, 30V, 150MA, 30V, DO-35		152-0141-02	2101AD
NDP0263 (114152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02	900180
NDP0263 (1N4152)		SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35		152-0141-02	100193
ND60263 (1N4152)	15969	SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35		152-0141-02	96680
NDP0263 (1N4152)		SEMICOND DVC.DI:SW,SI,30V,150MP,30V,D0-35		152-0141-02	88690
Correction Cocoddin	09001	SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35		152-0141-02	286HO
NDP0263 (144152)	15969				20000
NDP0263 (114152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MB,30V,DO-35		152-0141-02	586HO
NDP0263 (1N4152)	12966	SEMICOND DVC, DI: SW, SI, 30V, 150MB, 30V, DO-35		152-0141-02	92680
ND60263 (104152)	69621	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02	12683
NDP0263 (1N4152)	15960	SEMICOND DVC,DI:SW,SI,30V,150MP,30V,D0-35		152-0141-02	95680
NDP0263 (114152)		SEMICOND DVC, DI:SW,SI,30V,150MA,30V,D0-35		152-0141-02	55680 55680
(0311/11/ 23C0801)	15969	SEMICOND DVC, DI:SW,SI,30V,150MA,30V,DO-35	0210108		59090 79690
NDP0263 (1N4152)	15963				13000
NDP0263 (1N4152)	12960	SEMICOND DVC,DI:SW,SI,30V,150M6,35V		152-0141-02	CH952
NDP0263 (1N4152)	12966	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35		152-0141-02	54680
NDP0263 (1N4152)		SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35		152-0141-02	CB946 CB944
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35		152-0141-02	
2085-5672	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02	CH943
0290 0805	50434	SEMICOND DEVICE:SILICON, 15V, HOT CARRIER		152-0322-00	07680
5082-2672	20434				72680
NDP0263 (1N4152)		SEMICOND DEVICE:SILICON, 15V, HOT CARRIER		125-0355-00	CH926
NDP0263 (114152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02	
22D5402	15969	SEMICOND DVC.DI:SW.SI.30V,150MA,30V,DO-35		152-0141-02	CH923
NDP0263 (1N4152)	61740	PEMICOND DEVICE: SILICON, 70V, 200MA		152-0501-00	CH922
NDP0263 (1N4152)	15963	SEMICOND DVC,DI,SWS,IS,WS,ID,DVD,DV-35			CH914
CATHUR FACORON	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02 152-0141-02	016AD
ND60263 (1N4152)	00071			00 1010 031	20680
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SWS;130V,150MA,30V,DO-35		152-0141-02	000010
NDP0263 (1N4152)	15969	25-00,V05,AM021,V05,I2,W2:I0,0V0 UN00IM38		152-0141-02	CH903
NDP0263 (1N4152)	15969	3E-00, V0E, AM021, V0E, I2, W2:10, DV- DO-35		152-0141-02	CH824
NDP0263 (1N4152)	15969	SEMICOND DVC, DI:SWS, 130V, 150MA, 30V, DO-35			CB822
ND60263 (1N4152)	15969	25-00, V05, AM021, V05, I2, W2, IQ, DV0 UNUTINES		152-0141-02	\$18AD
(Cathut) Facuadu	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02	CH812
NDP0263 (1N4152)				152-0141-02	118AD
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SWSII,30V,150MA,30V,DO-35		152-0141-02	
ND60263 (1N4125)	15969	35-00,V05,AM021,V05,I2,W2:I0,DV0 UNUDIMES		152-0141-02	CH806
NDP0263 (1N4152)	15966	SEMICOND DVC,DI,SWS,IS,WS,ID,DVD DVDIMAS		162-0141-02	CH802
ND60263 (104152)	15969	25-00,V05,AM021,V05,I2,W2:I0,DVU UNDUMES			CH801
NDP0263 (1N4152)	15969	SEMICOND DVC, DI; 30V, 150MA, 30V, DO. 35		152-0141-02	66280
(Carnut) Facuadu	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02 152-0141-02	26280
NDP0263 (1N4152)				CO 1710-C91	96280
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		70-1610-701	
NDP0263 (1N4152)	15969	2E-00, V0E, AM021, V0E, IZ, W2: 10, DVG UNODIMES		152-0141-02	567AD
NDP0263 (1N4152)	15969	3E-00,V06,AM021,V06,I2,W2:I0,DV0 0V00IM38		152-0141-02	\$67AO
	15963	25-00,V05,AM021,V05,I2,W2:I0,DV0 UNOUMER		152-0141-02	C6793
NDP0263 (1N4152)	15963	SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35		152-0141-02	267AD
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0141-02	887AO
				152-0141-02	28280
6666666666666		(SELECTED, ALTERNATE PN 152-0586-00)			
Seedtms	80550	SEMICOND DEVICE: TUNNEL, 8PF, 10MA			98280
		(SELECTED, ALTERNATE PN 152-0586-00)		152-0140-01	98280
Seedtws	80560	SEMICOND DEVICE: TUNNEL, 8PF, 10MA			92280
DE140	80560	SEMICOND DEVICE:SW,SI,40V,200MA		152-0140-01	97780
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		152-0246-00	667AO
		Sector is the id over directives		152-0141-02	902HO
Mfr Part Number	Sode	Name & Description			
	ЧШ	itoitopon & ameli	Eff Dacont	Part No.	CKI NO.
			1044 100001411001		

Serial/Model No.

Tektronix

Au.co.norinuem@seniupne -:liem3
Tel:- 01844-351694 Fax:- 01844-352554
INTERXO UDXO
8 Cherry Tree Rd, Chinnor
MAURITRON TECHNICAL SERVICES
For Service Manuals Contact

BEV DEC 1984

-

FDH5004	£9270	SEMICOND DVC:SIG.SI,225V,0.2A,D0-7			152-0242-00	6761379
		SEMICOND DVC:36(2,255,0,0,25,0)			125-0545-00	775193
FDH5004	67263				152-0061-00	EZE180
FDH2161	67263	SEMICOND DEVICE:SILICON,175V,100MA				
FDH2161	67263	SEMICOND DEVICE:SILICON, 175V, 100MA			152-0061-00	175193
FDH2161	67263	SEMICOND DEVICE:SILICON, 175V, 100MA			152-0061-00	CE1368
1912HQ3	01563	SEMICOND DEVICE:SILICON, 175V, 100MA			152-0061-00	7361AO
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SW;SIZ,W021,50MS;A00,000			152-0141-02	CB1366
2229	15969	SEMICOND DEVICE:SILICON,400V,400MA			152-0107-00	CB1360
(1010263 (104152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CE1358
(2514NL) 292040N	12969	SEMICOND DVC, DI:SW,SI,30V,150MA,30V,D0-35			152-0141-02	CB1324
		SEMICOND DEVICE:SILICON, 1564, 100MA			152-0061-00	CB1323
FDH2161	01263				152-0141-02	CB1352
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35				
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW2ID,30V,150MA,30V,DO-35		B013000	152-0141-02	CB1346
						01011/0
ND60563 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1345
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1344
(2214N1) 292040N	15969	SEMICOND DVC,DI:SWS:ID, 20V, 50MA, 30V, DO-35		B020120	152-0141-02	CR1343
ED7003	01263	SEMICOND DVC,DI;IS,W2:IQ,DVD DVC,BMAC,D00,AM05,V01,IS,W2:IQ,DVD	6110208	0010108	122-0123-00	CB1343
		SEMICOND DVC,DI:SW,SI,30V,150MS,30V,DO-35			152-0141-02	CB1345
NDP0263 (1N4152)	15969			0710700	122-0322-00	CB1341
5082-2672	50434	SEMICOND DEVICE:SILICON,15V,HOT CARRIER		B020120	162,0322,00	116100
					00-0010-701	1-0110
ED7003	67263	SEMICOND DVC, DI:SW,SI,10V,50MA,D0-7	B020119	0010108	152-0153-00	CB1341
ND60263 (1N4152)	15966	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	TEETAD
ND60563 (1N4152)	15969	SEMICOND DVC,DI:SWS:IQ, 30V, 50MA, 30V, DO-35		B020120	152-0141-02	CB1331
ED7003	01263	5200,4M08,V01,I2,W2:I0,0V0 0N00IM32	B020119	0010108	122-0123-00	CB1331
2729	15963	SEMICOND DEVICE:SILICON,400V,400MA			152-0107-00	CE1329
					162-0429-00	CB1321
VG5X-1	83003	SEMICOND DEVICE:SILICON, 5000V, 10MA			00 0010 091	100100
1-XSDV	83003	SEMICOND DEVICE:SILICON, 50001, 10MA			125-0459-00	CE1320
ND60263 (1N4152)	15966	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	TIE1AD
					152-0333-00	CB1316
DISO11	80550	SEMICOND DAC DI SW SI 22A 500MA, D0-35				
ND60563 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1314
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SWS:IQ,00C,00C,00C,00C,00C,00C,00C			152-0141-02	CE1312
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1310
DJ2011	80560	SEMICOND DVC DI:SW,SI,55V,200MA,D0-35			152-0333-00	CE1304
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SWS:IS,W2:10,000 DOC)MB2			152-0141-02	CB1237
2085-2672	20434	SEMICOND DEVICE SILICON, 15V, HOT CARRIER			125-0355-00	CB1183
2292-2672					162-0322-00	CH1173
	20434					
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1164
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SWS:ID,000,150MB,30V,DO-35			152-0141-02	04118O
7.07 7000					00-7700-701	7711100
2082-2672	50434	SEMICOND DEVICE:SILICON, 15V, HOT CARRIER			152-0322-00	CB1122
5082-2672	50434	SEMICOND DEVICE:SILICON, 15, HOT CARRIER			152-0322-00	CR1121
ND60263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	LTTT RD
ND60263 (1N4152)	15969	SEMICOND DVC,DI:SWS:ID, 20V, 150MA, 30V, DO-35			152-0141-02	CB1104
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35			152-0141-02	CB1103
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SWS;IS,WS;ID,00,00			152-0141-02	CE1102
	03001					007720
NDP0263 (1N4152)	15963	SEMICOND DVC, DIS, WS, 10, 20V, DO-35			152-0141-02	CB1062
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	1901HO
EDH2161		SEMICOND DEVICE:SILICON,175V,100MA			152-0061-00	CB1060
	01263					
FDH2161	67263	SEMICOND DEVICE:SILICON,175V,100MA			152-0061-00	CE1058
FDH2161	69270	SEMICOND DEVICE:SILICON, 175V, 100MA			152-0061-00	CB1056
FDH2161	01263	SEMICOND DEVICE:SILICON, 1504, 100MA			152-0061-00	CE1054
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1052
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35			152-0141-02	CE1049
ND60263 (1N4152)	15966	SEMICOND DVC,DI:SW2:I,30V,150MC,35			152-0141-02	CE1046
ND60363 (104162)					152-0141-02	CB1044
	15969	SEMICOND DAC DI:SW SI 30A 120M 90A DO 32				
(2214N1) 29209ON	15969	SEMICOND DVC,DI:SW,SI,30V,50MA,30V,DO-35			152-0141-02	2E0183
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CE1036
	2000		Dscont		- CN - LIP	CKI NO.
Mfr Part Number	Sode	Name & Description		Eff	Part No.	
	ч₩		ON 9	boM\lsin92	Tektronix	

41-7

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY 191: 01844-351694 Fax:- 01844-352554 Fmail:- enquines@mauritron.co.uk

REV DEC 1984

21-75

34524-TINNED	99626	LAMP, INCAND: 5V, 60MA			120-0130-00	D2355
34524-TINNED	99676					
34524 LINNED		LAMP, INCAND: 5V, 60MA			150-0130-00	D2314
AL1105/200HL	1000				120-0130-00	D2315
AU1105/200HU	000	LAMP, GLOW: 900, 300, 400, 700, 700, 700, 700, 700, 700, 7			150-0035-00	D2528
119-0388-00	60008	LAMP, GLOW: 900, 300, 300, 700, 700, 700, 700, 700, 7			150-0035-00	D2128
NDP0263 (1N4152)	69621	DELAY LINE, ELEC. 78NS, 100 OHM			116-0388-00	DF380
(031010) C3C08014	09001	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35		0029108	152-0141-02	990880
NDP0263 (1N4152)	696Z L	36-00, V06, AM021, V06, I2, W2: ID, DV, DO. 35				
ND60263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MB,30V,DO-35		B016200		CH8048
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35		B016200		CB8046
ND60263 (104152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,D0-35		B016200		CH8044
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	6619108	8016200		CB8042
NDP0263 (1N4152)	15963	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	6619108	0010108	152-0141-02 152-0141-02	6691HO
(70) (1) (27)				0010104	CO 1710 CS1	969180
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35	661610B	0010108	152-0141-02	P69180
NDP0263 (114152)	15963	SEMICOND DVC, DI: SW, SI, 30V, 150MA, 30V, DO-35	6619108	0010108	152-0141-02	CB1602
NDP0263 (1N4152)	69621	SEMICOND DAC DI:SWSI'30A'150MP,30V,DO-35	6619108	8010100	152-0141-02	169190
		(70 NOLTAO)				
1/2624	80550	SEMICOND DEVICE:SILICON, 200V, 3A			152-0198-00	CR1643
		(70 NOIT90)				CB1643
						CB1634
D12011	80550	SEMICOND DVC DI:SW,SI,55V,200MA,D0-35			122-0333-00	CB1634
		(70 NOIT9O)				CR1631
DJ2011	80560	SEMICOND DVC DI:SW,SI,55V,200MA,D0-35			152-0333-00	CB1633
		(20 NOIT90)				
6727	15969	SEMICOND DEVICE:SILICON,400V,400MA			152-0107-00	CE1628
		(70 NOIT90)				CE1628 52152
						209100
6727	15969	SEMICOND DEVICE:SILICON,400V,400MA			152-0107-00	7581AD
(7.0		(TO NOITGO)				929180
2279	15969	SEMICOND DEVICE:SILICON,400V,400MA			152-0107-00	CB1626
17.00		(70 NOITGO)				CB1625
6727	15969	SEMICOND DEVICE:SILICON,400V,400MA			152-0107-00	CB1625
		(TO NOITAO)				CB1624
D12011	80550					
F1001 G	03608	SEMICOND DVC DI SW, SI, 55V, 200MA, D0-35			122-0333-00	CB1624
1/2054	80960	(20 NOIT90)				CB1601
NDP0263 (1N4152)	69621	SEMICOND DEVICE:SILICON, 2004, 3A			152-0198-00	109190
NDP0263 (1N4152)	12969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CR1512
2725	13069	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0141-02	CB1502
202.0	09001	SEMICOND DEVICE:SILICON,400V,400VA			152-0107-00	CB1489
GP10G-020	02828	14-00, A L, V004, IS, TOBR: D OVD DVOIMBS				
TIEADS	61240	SEMICOND DEVICE:SILICON.2004140000			152-0066-00	8741AO
GP10G-020	02828	SEMICOND DEVICE SILICON 2004 160044			152-0488-00	CE1472
NDP0263 (1N4152)	69621	SEMICOND DVC DI:RECT,SI,400V,1A,D0-41			122-0066-00	CE1468
EA076ADM	61740	SEMICOND DVC,DI:SWSI120,DO-35			152-0141-02	CB1466
GP10G-020	02828	SEMICOND DEVICE: RECT, SI, 2004, 14, 564			122-0462-00	CB1462
	20020	SEMICOND DVC DI:RECT,SI,400V,1A,D0.41			152-0066-00	CH1458
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SWS;120V,150MB;30V,DO-35				
TIEADS	61740	SEMICOND DAVE DISW SI 30V 150VV 1500MA			152-0141-02	CB1456
GP10G-020	02828	SEMICOND DVC DI:RECT,SI,40041,000 100241			152-0488-00	CE1452
KBC005-8	02828				122-0066-00	CB1448
NDP0263 (1N4152)	15969	SEMICOND DEVICE:BRIDGE,50V,150MA,30V,DO-35 SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			122-0226-00	CB1442
GP10G-020	02828	SEMICOND DVC DISW SI 30V 160MV 30V DO 36			152-0141-02	CB1432
		SEMICOND DVC DI:RECT,SI,400V,1A,D0.41			122-0066-00	CE1428
GP10G-020	82820	SEMICOND DVC DI:RECT,SI,400V,1A,D0-41				
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI,30V,150MA,30V,DO-35			152-0066-00	CB1426
FDH2161	67263	SEMICOND DEVICE:SILICON,175V,100MA			152-0141-02	CB1424
NDP0263 (1N4152)	15969	SEMICOND DVC,DI:SW,SI:30V,150MA,30V,DO-35			152-0061-00	CB1422
2229	15963	SEMICOND DEVICE:SILICON, 400V, 400MA			152-0141-02	CB1421
T1EAG2	61740	SEMICOND DEVICE:SILICON, 2004, 1500MA			152-0107-00	CR1415
		SEMICOND DEVICE SHICON 2004 15001			152-0488-00	CR1412
Mfr Part Number	epog	Londuced to surger				
	1W	Name & Description	Dscont	#3	Part No.	CKT NO.
	-74 4		odel No.	V/Isin92	Tektronix	-
					—	

Replaceable Electrical Parts-475A Service

	Tektronix	Serial/Mo	del No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
DS324	150-0130-00			LAMP, INCAND: 5V, 60MA	92966	34254-TINNED
DS608	150-0130-00			LAMP,INCAND:5V,60MA	92966	34254-TINNED
DS610	150-0130-00			LAMP, INCAND: 5V, 60MA	92966	34254-TINNED
DS1091	150-0035-00			LAMP,GLOW:90V,0.3MA,AID-T,WIRE LD	000LI	JH005/3011JA
DS1110	150-0035-00			LAMP,GLOW:90V,0.3MA,AID-T,WIRE LD	000LI	JH005/3011JA
DS1382	150-0002-00			LAMP,GLOW:0.5 MA 60/125V	74276	NE-2T(T2)
001000	150 0000 00				74070	
DS1383	150-0002-00			LAMP,GLOW:0.5 MA 60/125V	74276	NE-2T(T2)
DS1482	150-0129-00			LAMP,INCAND:6.3V,200MA	08806	2112D
DS1483	150-0129-00			LAMP, INCAND: 6.3V, 200MA	08806	2112D
DS1492	150-0130-00			LAMP, INCAND: 5V, 60MA	92966	34254-TINNÉD
1318	159-0016-00			FUSE,CARTRIDGE:3AG,1.5A,250V,FAST-BLOW	71400	AGC 1 1/2
=1401	159-0016-00			FUSE,CARTRIDGE:3AG,1.5A,250V,FAST-BLOW	71400	AGC 1 1/2
F1401	159-0042-00			FUSE,CARTRIDGE:3AG,0.75A,250V,FAST-BLOW	71400	AGC 3/4
F1401				(OPTION A1,A2,A3,A4)	71400	AGC 3/4
F1402	159-0172-00			FUSE, CARTRIDGE: TYPE C, 13 AMP	S3629	PCC-1089
F1402				(OPTION A2 ONLY)		
FL1401	119-0376-01			FILTER,RAD INT:2 X 3A.250V.400 HZ	80009	119-0376-01
E1401				(OPTION 04)	00003	113-0370-01
					74 400	10015
=1601 =1601	159-0038-00			FUSE,CARTRIDGE:3AG,15A,32V,FAST-BLOW (OPTION 07)	71400	AGC15
110	131-0679-02			CONNECTOR, RCPT, BNC, MALE, 3 CONTACT	24931	28JR270-1
50	131-0679-02			CONNECTOR, RCPT, BNC, MALE, 3 CONTACT	24931	28JR270-1
349	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
380	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
385	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
399	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
400	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
405	131-1003-00				80009	131-1003-00
				CONN, RCPT, ELEC: CKT BD MT, 3 PRONG		
410 430	131-1003-00 131-1003-00			CONN.RCPT.ELEC:CKT BD MT,3 PRONG CONN.RCPT.ELEC:CKT BD MT,3 PRONG	80009 80009	131-1003-00 131-1003-00
-00	101-1000-00			CONN, NOF T, ELEC. CR T DD MT, 3 FRONG	00003	101-1003-00
430	131-1315-01	B010100	B015866	CONN.RCPT,ELEC:BNC,FEMALE	24931	28JR 306-1
430				(OPTION 04)		
430	131-1315-01	B015867		CONN,RCPT,ELEC:BNC,FEMALE	24931	28JR 306-1
430				(OPTION 04)		
435	131-0955-00			CONN, RCPT, ELEC: BNC, FEMALE	13511	31-279
510	131-0955-00			CONN, RCPT, ELEC: BNC, FEMALE	13511	31-279
504	101 1000 00				00000	131-1003-00
584	131-1003-00	0040400		CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	
584 584	131-1315-01	B010100	B015866	CONN,RCPT,ELEC:BNC,FEMALE (OPTION 04)	24931	28JR 306-1
584	131-1315-01	B015867		CONN,RCPT,ELEC:BNC,FEMALE	24931	28JR 306-1
584				(OPTION 04)		
589	131-0955-00			CONN, RCPT, ELEC: BNC, FEMALE	13511	31-279
664	131 1003 00			CONN BORT ELECTORT BR MT 3 DRONG	80009	131-1003-00
674	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG		131-1003-00
	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	
594	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
702	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
704	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
706	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
720	131-0955-00			CONN,RCPT,ELEC:BNC,FEMALE	13511	31-279
824	131-1003-00			CONN,RCPT,ELEC:CKT BD MT,3 PRONG	80009	131-1003-00
829	131-0955-00			CONN,RCPT,ELEC:BNC,FEMALE	13511	31-279
829		B010100	D015966		24931	28JR 306-1
329 329	131-1315-01	B010100	B015866		24301	20011-000-1
629 829	131-1315-01	B015867		(OPTION 04) CONN,RCPT,ELEC:BNC,FEMALE	24931	28JR 306-1
329				(OPTION 04)		

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Replaceable Electrical Parts—475A Service

Ckt No.	Tektronix	Serial/Mo	del No.			
Ckt No.	Part No.	Eff	Dscont	Name & Description	Mfr	
				Name & Description	Code	Mfr Part Numbe
J1101	131-1003-00			00		
J1302	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80000	
J1330				CONN, RCPT, ELEC: CKT BD MT.3 PRONG	80009	
J1330	131-0955-00			CONN, RCPT, ELEC: BNC, FEMALE	80009	
	131-1315-01	B010100	B015866	CONN, RCPT, ELEC: BNC, FEMALE	13511	31-279
J1330				(OPTION 04)	24931	
J1330	131-1315-01	B015867			-	2001 000-1
		201000		CONN, RCPT, ELEC: BNC, FEMALE	24931	00.10.000
J1330					24931	28JR 306-1
J1333				(OPTION 04)		
	131-1003-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG		
J1334	131-1003-00			CONNECT FLED OUT DO WILL PRONG	80009	131-1003-00
J1478	131-0771-00			CONN, RCPT, ELEC: CKT BD MT, 3 PRONG	80009	131-1003-00
J1479	131-0771-00			CONN, RCPT, ELEC: 4 CONT, QUICK DISCONNECT	91836	
K1103	148-0076-00			CONN, RCPT, ELEC:4 CONT.OUICK DISCONNECT		1904-2M58
	140-0070-00			RELAY, REED:1 FORM A,5V,0.25A,100V	91836	1904-2M58
141				10.2014,1004	95348	F81-1447
				(PART OF CIRUIT BOARD)		
.142				(PART OF CIRLUT DOADD)		
_147				(PART OF CIRUIT BOARD)		
.148				(PART OF CIRUIT BOARD)		
.151				(PART OF CIRUIT BOARD)		
152				(#26 WIRE ACTING AS INDUCTANCE)		
				(#26 WIRE ACTING AS INDUCTANCE)		
				(A MALE A OTHER AS INDUCTANCE)		
170	108-0440-00					
171	276-0528-00			COIL, RF: 8UH, TOROIDAL INDUCTOR	80009	108-0440-00
172	276-0507-00			SHIELDING BEAD,:0.1UH	02114	
174				SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D		56-0590-65C/3B
178	276-0528-00			SHIELDING BEAD,:0.1UH	02114	56-590-65B/3B
	276-0543-00			SHLD BEAD,ELEK:FERRITE	02114	56-0590-65C/3B
178					80009	276-0543-00
				(SELECTED)		
80	108-0440-00					
82	276-0507-00			COIL, RF:8UH, TOROIDAL INDUCTOR	00000	
88				SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	80009	108-0440-00
-	276-0543-00			SHLD BEAD,ELEK:FERRITE	02114	56-590-65B/3B
88					80009	276-0543-00
41				(SELECTED)		
42				(PART OF CIRUIT BOARD)		
				(PART OF CIRUIT BOARD)		
47				,		
48				(PART OF CIRUIT BOARD)		
-				(PART OF CIRUIT BOARD)		
51				(#26 MUDE ACTIVE ACTIVE		
52				(#26 WIRE ACTING AS INDUCTANCE)		
70	108-0440-00			(#26 WIRE ACTING AS INDUCTANCE)		
71				COIL, RF:8UH, TOROIDAL INDUCTOR	00000	
•	276-0528-00			SHIELDING BEAD,:0.1UH	80009	108-0440-00
					02114	56-0590-65C/3B
2	276-0507-00					
'4	276-0528-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
8	276-0543-00			SHIELDING BEAD,:0.10H	02114	
8			:	SHLD BEAD,ELEK:FERRITE		56-0590-65C/3B
0			((SELECTED)	80009	276-0543-00
	108-0440-00			COIL, RF:8UH, TOROIDAL INDUCTOR		
2	276-0507-00				80009	108-0440-00
				SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114	56-590-65B/3B
В	276-0543-00					
В			5	SHLD BEAD,ELEK:FERRITE	80009	076 05 40 CC
1			(SELECTED)	00009	276-0543-00
	108-0440-00			COIL.RF:8UH.TOROIDAL INDUCTOR		
2	108-0440-00		, r	COLLARE BUH, TOROIDAL INDUCTOR	80009	108-0440-00
,	108-0440-00				80009	108-0440-00
5	108-0182-00		ι -	OIL, RF:8UH, TOROIDAL INDUCTOR	80009	108-0440-00
			c	OIL,RF:FIXED,285NH	80009	
i	109 0190 00				00009	108-0182-00
	108-0182-00		C	OIL,RF:FIXED,285NH		
	276-0588-00		Č	ORE,EM:TOROID,FERRITE	80009	108-0182-00
	108-0440-00		5		78488	57-3114
			C	OIL, RF:8UH, TOROIDAL INDUCTOR	80009	108-0440-00
			(F	PART OF CIRUIT BOARD)		
			(P	ART OF CIRUIT BOARD)		
			(P	ART OF CIRUIT BOARD)		
			· ·			

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

7-17

Replaceable Electrical Parts—475A Service

.	Tektronix	Serial/Mo	del No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
L480	276-0528-00	B010100	B012999	SHIELDING BEAD,:0.1UH	02114	56-0590-65C/3B
L480				(REPLACED WITH R480)		
L498	108-0440-00			COIL, RF: 8UH, TOROIDAL INDUCTOR	80009	108-0440-00
L499	108-0440-00			COIL, RF: 8UH, TOROIDAL INDUCTOR	80009	108-0440-00
L506	276-0507-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114	56-590-65B/3B
L506				(SELECTED AND ADDED IF NECESSARY)		· · · · · · · · · · · · · · · · · · ·
L546	108-0433-00			COIL,RF:0.09UH	80009	108-0433-00
L551	108-0433-00			COIL,RF:0.09UH	80009	108-0433-00
L572	276-0507-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
_574	276-0507-00			SHIELDING BEAD, FERRITE,0.138 OD X 0.0411D	02114	
-588	276-0507-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114	56-590-65B/3B
_600	120-0402-00			XFMR,TOROID:3 TURNS SINGLE	80009	56-590-65B/3B 1 20-0402- 00
.669	070 0507 00				00000	120-0402-00
_669	276-0507-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
_716	276-0507-00			(SELECTED AND ADDED IF NECESSARY)		
.716	270-0307-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114	56-590-65B/3B
.746	276-0507-00			(SELECTED AND ADDED IF NECESSARY)		
.746	276-0507-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D (SELECTED AND ADDED IF NECESSARY)	02114	56-590-65B/3B
.771	108-0433-00			COIL,RF:0.09UH	80009	108-0433-00
772	276-0528-00			SHIELDING BEAD,:0.1UH	02114	56-0590-65C/3B
781	108-0433-00			COIL, RF: 0.09UH	80009	108-0433-00
782	276-0528-00			SHIELDING BEAD,:0.1UH	02114	56-0590-65C/3B
802	276-0507-00			SHIELDING BEAD .: FERRITE .0.138 OD X 0.0411D	02114	56-590-65B/3B
804	276-0507-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114	56-590-65B/3B
826	276-0507-00					
901	276-0507-00	B020839		SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
917	108-0750-00	00200033			02114	56-590-65B/3B
922	276-0507-00				80009	108-0750-00
982	276-0543-00	B010150		SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
984	276-0507-00	B010150		SHLD BEAD,ELEK:FERRITE SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	80009 02114	276-0543-00 56-590-65B/3B
				STREEDING BEAD, FERTIL, 5.155 OD X 5.04 HD	02114	50-590-05D/3B
1018 1026	120-0407-00			XFMR, TOROID:5 TURNS SINGLE	80009	120-0407-00
	108-0245-00			COIL,RF:3.9UH	76493	B6310-1
1026				(OPTION 07)		
1091	276-0507-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.041ID	02114	56-590-65B/3B
1093	276-0507-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
102	108-0538-00			COIL, RF: FIXED, 2.7UH	76493	JWM#B7059
103	114-0278-00			COIL, RF: 4.6-16.7UH, CORE 276-0568-00	80009	114-0278-00
231	276-0507-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114	56-590-65B/3B
232	276-0507-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	02114	56-590-65B/3B
232				(SELECTED AND ADDED IF NECESSARY)	VZ 114	20-220-020/20
251	276-0507-00			SHIELDING BEAD,:FERRITE,0.138 OD X 0.0411D	00444	FO 500 550/00
252	276-0507-00			SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D SHIELDING BEAD, FERRITE, 0.138 OD X 0.0411D	02114 02114	56-590-65B/3B 56-590-65B/3B
252						
252 261	108-0245-00			(SELECTED AND ADDED IF NECESSARY) COIL.RF:3.9UH	76400	D6210 1
263	108-0245-00				76493	B6310-1
265	108-0245-00			COIL,RF:3.9UH	76493	B6310-1
318	108-0422-00			COIL,RF:3.9UH	76493	B6310-1
330	108-0422-00			COIL,RF:FIXED,82UH COIL,RF:8UH,TOROIDAL INDUCTOR	80009	108-0422-00
				COLLAR BOR, FOROIDAL INDUCTOR	80009	108-0440-00
385	108-0714-00			COIL, TUBE DEFLE: Y AXIS ALIGNMENT	80009	108-0714-00
386	108-0713-00			COIL, TUBE DEFLE: TRACE ROTATION	80009	108-0713-00
387	108-0245-00			COIL,RF:3.9UH	76493	B6310-1
388	108-0245-00			COIL, RF:3.9UH	76493	B6310-1
394	276-0541-00			SHIELDING BEAD,:	80009	276-0541-00
511	108-0245-00			COIL,RF:3.9UH	7 6 493	B6310-1

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

7-18
	Tektror		al/Model No.			
Ckt No.	Part No	D. Eff	Dsc	ant.	Mfr	
1 1 5 1 7				Name & Description	Cod	
L1517	108-026		830			
LR377	108-076	0-00		COIL, RF:FIXED, 510NH	8000	
LR378	108-0760	00-0		COIL.RF:FIXED,56NH		100-0202-00
LR467	108-0328	3-00		COIL, RF: FIXED, 56NH	8000	
LR496	108-0685	5-00		COIL, RF:0.3UH	8000	
LR497	108-0685			COIL, RF:62NH	8000	100 0020-00
				COIL, RF: 62NH	8000	9 108-0685-00
LR1335	108-0537	00			8000	9 108-0685-00
LR1336	108-0537			COIL, RF: 200UH		
P1601				COIL, RF:200UH	8000	9 108-0537-00
P1601	131-1333	-00		CONNECTOR, RCPT, POWER	8000	9 108-0537-00
Q172				(OPTION 07)	8000	
	151-0271.			TRANSISTOR OF IT		9 131-1333-00
Q178	151-0434.	-00		TRANSISTOR: SILICON, PNP	04713	
				TRANSISTOR: SILICON, PNP		4, COL00
Q182	151-0271-	00			04713	SS7144
Q184	151-0188-	00		TRANSISTOR: SILICON, PNP	• • • • •	
Q188	151-0434-			TRANSISTOR: PNP.SLT0.92	04713	
Q272	151-0271-0			I RANSISTOR: SILICON PNP	T0058	
Q278	151-0434-(TRANSISTOR: SILICON PNP	04713	
Q282				TRANSISTOR: SILICON, PNP	04713	
	151-0271-(JU DI		TRANSISTOR:SILICON,PNP	04713	0.00100
Q284				NUMBER OF SILICON, PNP	04713	•••
	151-0188-0			TRANSICTOR THE	01110	3F36236
Q288	151-0434-0	10		TRANSISTOR: PNP, SI, TO-92	TOOSP	0
Q312	151-0435-0	0		TRANSISTOR: SILICON, PNP	T0058	2N3906
Q314	151-0301-0	0		I RANSISTOR: SILICON PNP	04713	SS7144
Q322	151-0435-0			TRANSISTOR: SILICON PNP	04713	SPS8335
Q324	151-0301-0			TRANSISTOR: SILICON, PNP	27014	2N2907A
	101-0007-01	U		TRANSISTOR: SILICON, PNP	04713	SPS8335
Q338	151 000	_		- CONCILICON, FINP	27014	2N2907A
Q348	151-0301-00			TRANSISTOR: SILICON.PNP		
Q390	151-0301-00			TRANSISTOR SILICON PNP	27014	2N2907A
	151-0441-00)		TRANSISTOR: SILICON, PNP	27014	
Q396	151-0271-00	1		TRANSISTOR: SILICON, NPN	04713	2N2907A
Q420	151-0223-00	B010100	PO14050	TRANSISTOR: SILICON, PNP		SRF501
Q420	151-0190-00		B014658	LRANSISTOR:NPN.SLTO-92	04713	SPS8236
		0014059		TRANSISTOR:NPN,SI,TO-92	04713	SPS8026
Q430	151-0188-00				04713	SPS7969
Q444	151-0301-00			TRANSISTOR: PNP, SI, TO-92		
Q502				TRANSISTOR: SILICON, PNP	T0058	2N3906
Q504	151-0367-00			TRANSISTOR: SILICON NEW OF	27014	2N2907A
Q506	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q522	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q522	151-1042-00			THANSIS I UNISILICON NEW SEL EDOM ACTION	04713	
				SEMICOND DVC SE:MATCHED PAIR FET		SPS 8811
Q524					22229	S2089
Q526	151-0221-00			(PART OF Q522)		
Q532	151-0188-00			TRANSISTOR: SILICON, PNP	.	
Q552	151-0434-00			TRANSISTOR: PNP. SI TO-92	04713	SPS246
Q556	151-0221-00			THANSISTOR: SILICON PNP	T0058	2N3906
Q562	151 0404 05			TRANSISTOR:SILICON,PNP	04713	SS7144
	151-0434-00			TRANSISTOR:SILICON,PNP	04713	SPS246
Q566				Since on Sicioun, PNP	04713	SS7144
	151-0221-00			TRANSISTOR OF LET		
Q572	151-0199-00			TRANSISTOR: SILICON, PNP	04713	SB604C
Q574	151-0199-00			TRANSISTOR: PNP, SI, TO-92	04713	SPS246
Q584	151-0190-00			TRANSISTOR: PNP, SI, T0-92		SPS6866K
Q588	151-0199-00			TRANSISTOR:NPN.SLTO-92	04713	SPS6866K
Q594	151-0190-00			IRANSISTOR: PNP. SI T0-92	04713	SPS7969
	/00.90-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS6866K
Q596	151.0100.00				04713	SPS7969
Q612	151-0188-00			TRANSISTOR: PNP, SI, TO-92		
Q612	151-0223-00	B010100	B014658	TRANSISTOR:NPN,SI,TO-92	T0058	2N3906
	151-0190-00	B014659		TRANSISTOR NON 2: 22		SPS8026
Q628	151-0223-00	B010100	B014658	TRANSISTOR:NPN.SI,TO-92		
Q628	151-0190-00	B014659	20,4030	TRANSISTOR:NPN,SI,TO-92	• • • • •	SPS7969
Q644	151-0350-00			IRANSISTOR:NPN.SLTO.92	A 17 1 A	SPS8026
				TRANSISTOR: SILICON, PNP		SPS7969
A A A A	151 0004 00				04713	SPS6700
Q662	151-0221_00					
0662	151-0221-00			TRANSISTOR: SILICON, PNP	04713	SPS246

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

	Tektronix	Serial/Mo	del No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
Q664	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q672	151-0221-00			TRANSISTOR: SILICON, PNP	04713	SPS246
Q674	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q680	151-0188-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
Q688	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q698	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q712	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q714	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q716	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q742	151-1042-00			SEMICOND DVC SE:MATCHED PAIR FET	22229	S2089
Q744				(PART OF Q742)		
Q746	151-0221-00			TRANSISTOR: SILICON, PNP	04713	SPS246
Q752	151-0188-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
Q772	151-0434-00			TRANSISTOR: SILICON, PNP	04713	SS7144
Q776	151-0221-00			TRANSISTOR: SILICON, PNP	04713	SPS246
Q782	151-0434-00			TRANSISTOR: SILICON, PNP	04713	SS7144
Q786	151-0221-00			TRANSISTOR: SILICON, PNP	04713	SPS246
Q788	151-0190-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q790	151-0223-00	B010100	B014658	TRANSISTOR:NPN.SI,TO-92	04713	SPS8026
Q790	151-0190-00	B014659	2014000	TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q792	151-0223-00	B010100	B014658	TRANSISTOR:NPN,SI,TO-92	04713	SPS8026
Q792	151-0190-00	B014659	2011000	TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q794	151-0188-00			TRANSISTOR:PNP.SI,TO-92	T0058	2N3906
Q796	151-0188-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
Q798	151-0190-00			TRANSISTOR NON OLTO DO	A 17 1 A	0007000
Q802	151-0199-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q804	151-0199-00			TRANSISTOR:PNP,SI,T0-92 TRANSISTOR:PNP,SI,T0-92	04713	SPS6866K
Q824	151-0190-00			TRANSISTOR: NPN, SI, TO-92 TRANSISTOR: NPN, SI, TO-92	04713	SPS6866K
Q826	151-0199-00			TRANSISTOR:PNP,SI,T0-92	04713 04713	SPS7969 SPS6866K
Q902	151-0199-00			TRANSISTOR:PNP,SI,T0-92	04713	SPS6866K
Q904	151-0190-01			TRANSISTOR OF CONTRACT		
Q914	151-0261-00				80009	151-0190-01
Q920	151-1025-00			TRANSISTOR: SILICON, PNP, DUAL	04713	SD441
Q922	151-0127-00			TRANSISTOR: SILICON, JFE.N-CHANNEL	01295	SFB8129
Q926	151-1036-00			TRANSISTOR:SILICON,NPN	07263	S006075
Q928	151-0190-00			TRANSISTOR:SILICON,JFE.N-CHANNEL,DUAL TRANSISTOR:NPN,SI,TO-92	17856 04713	DN1663 SPS7969
0020	151 0001 00					
Q938	151-0261-00			TRANSISTOR: SILICON, PNP, DUAL	04713	SD441
Q940 Q944	151-0223-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS8026
	151-0190-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q946	151-0190-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q956 Q972	151-0188-00 151-0188-00			TRANSISTOR:PNP,SI,TO-92 TRANSISTOR:PNP,SI,TO-92	T0058	2N3906
GOVE	101-0100-00			TRANSISTOR. PRP, 51, 10-92	T0058	2N3906
Q974	151-0190-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q980	151-1025-00			TRANSISTOR: SILICON, JFE, N-CHANNEL	01295	SFB8129
Q984	151-0127-00			TRANSISTOR: SILICON, NPN	07263	S006075
Q988	151-0188-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
Q992	151-0188-00			TRANSISTOR:PNP,SI,TO-92	T0058	2N3906
Q996	151-0199-00			TRANSISTOR:PNP,SI,T0-92	04713	SPS6866K
Q1002	151-0347-00			TRANSISTOR: SILICON, NPN	56289	T7916
Q1004	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	04713	SPS 8811
Q1008	151-0347-00			TRANSISTOR: SILICON, NPN	56289	T7916
Q1010	151-1025-00			TRANSISTOR: SILICON, JFE, N-CHANNEL	01295	SFB8129
Q1014	151-0127-00			TRANSISTOR: SILICON, NPN	07263	S006075
Q1018	151-0188-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
Q1022	151-0223-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS8026
-					V-1.10	=: =====

7-20

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

Ckt No.	Tektronix Part No.	Serial/N Eff	Model No.		Mfr	
			Dscont	Name & Description	Code	Mfr Part Number
Q1026	151-0188-00	n				
Q1034	151-0190-00			TRANSISTOR: PNP, SI, TO-92	T0058	010000
Q1044				TRANSISTOR:NPN,SI,TO-92		
Q1052	151-0190-00			TRANSISTOR:NPN,SI,TO-92	04713	0.0.000
	151-0350-00			TRANSISTOR: SILICON, PNP	04713	
Q1054	151-0350-00			TRANSISTOR:SILICON,PNP	04713	SPS6700
Q1056	151-0350-00			TRANSISTOR:SILICON,PNP	04713	SPS6700
				THANSIS TOR: SILICON, PNP	04713	SPS6700
Q1058	151-0350-00			TRANSISTOR: SILICON, PNP		
Q1062	151-0188-00			TRANSISTOR: PNP,SI,TO-92	04713	SPS6700
Q1066	151-0188-00			TRANSISTOR PUP OF TO SE	T0058	2N3906
Q1086	151-0190-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
Q1099	151-0190-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q1112	151-0302-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
	101-0002-00			TRANSISTOR: SILICON, NPN	07263	S038487
Q1114	151-0127-00				0.200	0000407
Q1124	151-0212-00			TRANSISTOR: SILICON, NPN	07263	S006075
Q1134				TRANSISTOR: SILICON, NPN	04713	
Q1140	151-0212-00			TRANSISTOR: SILICON, NPN		SRF 518
Q1140	151-0223-00	B010100	B014658	TRANSISTOR:NPN,SI,TO-92	04713	SRF 518
	151-0192-00	B014659		TRANSISTOR:SELECTED	04713	SPS8026
Q1152	151-0325-00	B010100	B015902	TRANSISTOR: SILICON, PNP, SEL FROM 2N4258	04713	SPS8801
01150				The second	80009	151-0325-00
Q1152	151-0220-00	B015903		TRANSISTOR: PNP, SI, TO-92		
Q1162	151-0325-00	B010100	B015902	TRANSISTOR:SILICON, PNP, SEL FROM 2N4258	07263	S036228
Q1162	151-0220-00	B015903		TRANSISTOR SILICON, PNP, SEL FROM 2N4258	80009	151-0325-00
Q1164	151-0188-00			TRANSISTOR:PNP,SI,TO-92	07263	S036228
21172	151-0325-00	B010100	D015000	TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
21172	151-0220-00		B015902	TRANSISTOR: SILICON, PNP, SEL FROM 2N4258	80009	151-0325-00
	101-0220-00	B015903		TRANSISTOR: PNP, SI, TO-92	07263	S036228
21174	151-0325-00	D010100			07203	5030228
21174	151-0220-00	B010100	B015902	TRANSISTOR: SILICON, PNP, SEL FROM 2N4258	80009	151 0225 00
21182		B015903		TRANSISTOR: PNP, SI, TO-92		151-0325-00
21184	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	07263	S036228
	151-0127-00			TRANSISTOR: SILICON, NPN	04713	SPS 8811
1188	151-0302-00			TRANSISTOR:SILICON,NPN	07263	S006075
1202	151-0270-00			TRANSISTOR:SILICON,PNP	07263	S038487
				THENOISTON, SILICON, PNP	04713	ORD BY DESCR
1204	151-0124-00			TRANSISTOR: SILICON, NPN, SEL FROM 2N3501		
1212	151-0270-00			TRANSISTOR:SILICON,PNP	04713	SM8138
1214	151-0124-00			TRANSISTOR SILICON, PNP	04713	ORD BY DESCR
1234	151-0188-00			TRANSISTOR: SILICON, NPN, SEL FROM 2N3501	04713	SM8138
1254	151-0188-00			TRANSISTOR:PNP,SI,TO-92	T0058	2N3906
1306	151-0126-00			TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
				TRANSISTOR: SILICON, NPN	04713	ST1046
1308	151-0301-00				04710	0.1040
1310	151-0190-00			TRANSISTOR: SILICON, PNP	27014	2N2907A
1312	151-0188-00			TRANSISTOR: NPN, SI, TO-92	04713	SPS7969
1316				TRANSISTOR: PNP, SI, TO-92		
	151-0136-00			TRANSISTOR: SILICON, NPN	T0058	2N3906
1318	151-0140-00			TRANSISTOR: SILICON, NPN	02735	35495
332	151-0199-00			TRANSISTOR: PNP, SI, T0-92	02735	36568
220					04713	SPS6866K
338	151-0367-00			TRANSISTOR: SILICON, NPN, SEL FROM 3571TP		
344	151-0188-00			TRANSISTOR:PNP,SI,TO-92	04713	SPS 8811
352	151-0407-00			TRANSISTOD SILLOON ART	T0058	2N3906
354	151-0406-00			TRANSISTOR:SILICON,NPN	04713	SS2456
358		B010100	P010000	TRANSISTOR: SILICON, PNP	04713	ORD BY DESCR
358			B012999	TRANSISTOR PNP, SI, T0-92	04713	SPS6866K
	101-0220-00	B013000		TRANSISTOR: PNP, SI, TO-92	07263	S036228
362	151-0188-00					
424				TRANSISTOR: PNP, SI, TO-92	T0058	2N3906
	151-0347-00			TRANSISTOR: SILICON, NPN		
426	151-0349-00			TRANSISTOR: SILICON, NPN, SEL FROM MJE280	56289	T7916
432	151-0347-00			TRANSISTOR:SILICON,NPN	04713	SJE924
144	151-0302-00			TRANSISTOR:SILICON,NPN		T7916
46	151-0302-00			TRANSISTOR:SILICON,NPN		S038487
					07263	S038487
48	151-0349-00			TRANSISTOR:SILICON,NPN,SEL FROM MJE280		
					04713	

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

O (),),	Tektronix	Serial/N	lodel No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
					0000	win Fart Number
Q1454	151-0302-00			TRANSISTOR: SILICON, NPN	07000	
Q1456	151-0390-00			TRANSISTOR:SILICON,NPN	07263	S038487
Q1464	151-0302-00			TRANSISTOR:SILICON,NPN	04713	SPS3414
Q1466	151-0302-00			TRANSISTOR:SILICON,NPN	07263	S038487
Q1468	151-0349-00				07263	S038487
Q1474	151-0302-00			TRANSISTOR: SILICON, NPN, SEL FROM MJE280	04713	SJE924
				TRANSISTOR: SILICON, NPN	07263	S038487
Q1478	151-0260-02					
Q1482	151-0390-00			TRANSISTOR: SILICON, NPN	04713	ST1149
Q1490	151-0190-00			TRANSISTOR: SILICON, NPN	04713	SPS3414
Q1492				TRANSISTOR:NPN,SI,TO-92	04713	SPS7969
Q1494	151-0302-00			TRANSISTOR: SILICON, NPN	07263	S038487
	151-0347-00			TRANSISTOR: SILICON, NPN	56289	T7916
Q1496	151-0280-00			TRANSISTOR: SILICON, PNP	04713	SS8065
0					• • • • •	886665
Q1497	151-0301-00			TRANSISTOR: SILICON, PNP	27014	2012007.4
Q1498	151-0302-00			TRANSISTOR: SILICON, NPN	07263	2N2907A
Q1502	151-0342-00			TRANSISTOR: SILICON, PNP		S038487
Q1504	151-0342-00			TRANSISTOR:SILICON,PNP	07263	S035928
Q1512	151-0164-00			TRANSISTOR:PNP,SI,TO-92	07263	S035928
Q1606	151-0301-00			TRANSISTOR:SILICON,PNP	04713	2N2907A
				THANSISTOR. SILICON, PNP	27014	2N2907A
Q1606						
Q1608	151-0301-00					
Q1608				TRANSISTOR:SILICON,PNP	27014	2N2907A
Q1622	151-0302-00			(OPTION 07)		
Q1622				TRANSISTOR: SILICON, NPN	07263	S038487
Q1626				(OPTION 07)		
021020	151-0506-00			SCR:SILICON	03508	C106B2X283
Q1626						
				(OPTION 07)		
Q1642	151-0302-00			TRANSISTOR: SILICON, NPN	07263	S038487
Q1642				(OPTION 07)	0,200	0000407
Q1644	151-0335-00			TRANSISTOR: SILICON, PNP	04713	SJE917
Q1644				(OPTION 07)	04715	332917
Q1652	151-0436-00			TRANSISTOR: SILICON, NPN	04713	0.15000
					04713	SJE966
Q1652				(OPTION 07)		
Q1654	151-0436-00			TRANSISTOR:SILICON,NPN		
Q1654				(OPTION 07)	04713	SJE966
Q1662	151-0436-00					
Q1662				TRANSISTOR: SILICON, NPN	04713	SJE966
Q1664	151-0436-00			(OPTION 07)		
	701-0400-00			TRANSISTOR: SILICON, NPN	04713	SJE966
Q1664						
Q1698	151-0301-00			(OPTION 07)		
Q8067		B010100	B016199	TRANSISTOR: SILICON, PNP	27014	2N2907A
	151-0301-00	B016200		TRANSISTOR: SILICON, PNP	27014	2N2907A
R9	307-0103-00	B023830		RES.,FXD,CMPSN:2.7 OHM,5%,0.25W	01121	CB27G5
R10	315-0430-00			RES.,FXD,CMPSN:43 OHM,5%,0.25W	01121	CB4305
R13	315-0101-00			RES., FXD, CMPSN: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
					57000	111233-E 100E
R22	315-0105-00			RES.,FXD,CMPSN:1M OHM,5%,0.25W	01121	CB1055
R22				(QUANTITY OF 2)	01121	CB1055
R24	315-0510-00			RES.,FXD,CMPSN:51 OHM,5%,0.25W		
R24				(QUANTITY OF 2)	57668	NTR25J-E51E0
R31		B010100	B010715			
R31	317-0100-00	B010716	2010/10	(QUANTITY OF 2)(SELECTED)		
		20.0710		RES.,FXD,CMPSN:10 OHM,5%,0.125W	01121	BB1005
R31						
R32	317-0082-00	P010100	Dooroon	(QUANTITY OF 2.NOMINAL VALUE, SELECTED)		
R32		B010100	B025937	RES.,FXD,CMPSN:8.2 OHM,5%,0.125W	01121	BB82G5
R32	217 0056 00			(QUANTITY OF 2.NOMINAL VALUE SELECTED)		
	317-0056-00	B025938		RES.,FXD,CMPSN:5.6 OHM,5%,0.125W	01121	BB56G5
R32				(QUANTITY OF 2.NOMINAL VALUE, SELECTED)	_	
R33	315-0360-00			RES.,FXD,CMPSN:36 OHM,5%,0.25W	01121	CB3605
022					_	
R33				(QUANTITY OF 2)		

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

	Tektronix	Serial/Mo	del No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Numbe
R34	317-0300-00	B010100	025937	RES.,FXD,CMPSN:30 OHM,5%,0.125W	01121	BB3005
R34				(QUANTITY OF 2.NOMINAL VALUE, SELECTED)		
R34	317-0240-00	B025593		RES.,FXD,CMPSN:24 OHM,5%,0.125W	01121	BB2405
R34				(QUANTITY OF 2.NOMINAL VALUE SELECTED)		
R35	317-0390-00	B010100	B010715	RES.,FXD,CMPSN:39 OHM,5%,0.125W	01121	BB3905
R35				(QUANTITY OF 2.NOMINAL VALUE, SELECTED)		
R35	317-0330-00	B010716		RES.,FXD,CMPSN:33 OHM,5%,0.125W	01121	BB3305
R35				(QUANTITY OF 2.NOMINAL VALUE, SELECTED)	01121	000000
R36	317-0330-00	B010100	B010715	RES.,FXD,CMPSN:33 OHM,5%,0.125W	01121	BB3305
R36				(QUANTITY OF 2.NOMINAL VALUE, SELECTED)		
36	317-0300-00	B010716		RES.,FXD,CMPSN:30 OHM,5%,0.125W	01121	BB3005
R36				(QUANTITY OF 2.NOMINAL VALUE, SELECTED)		
337				(QUANTITY OF 2)(SELECTED)		
39	321-0481-00			RES.,FXD,FILM:1M OHM,1%,0.125W	91637	CMF55116G10003
39				(QUANTITY OF 2)	51007	CIVII 33110G10003
R41	317-0474-00			RES.,FXD,CMPSN:470K OHM,5%,0.125W	01121	BB4745
342	315-0510-00	B010100	B010715	RES.,FXD,CMPSN:51 OHM,5%,0.25W	57668	NTR25J-E51E0
342				(NOMINAL VALUE, SELECTED)		
342	315-0560-00	D010716				
342	313-0360-00	B010716			57668	NTR25J-E56E0
149	307-0103-00	B023830		(NOMINAL VALUE, SELECTED)	01101	000305
350	315-0430-00	0023030		RES.,FXD,CMPSN:2.7 OHM,5%,0.25W RES.,FXD,CMPSN:43 OHM,5%,0.25W	01121 01121	CB27G5 CB4305
153	315-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
861	317-0474-00			RES.,FXD,CMPSN:470K OHM,5%,0.125W	01121	BB4745
					0.121	
162	315-0510-00	B010100	B010715	RES.,FXD,CMPSN:51 OHM,5%,0.25W	57668	NTR25J-E51E0
162				(NOMINAL VALUE, SELECTED)		
162	315-0560-00	B010716		RES.,FXD,CMPSN:56 OHM,5%,0.25W	57668	NTR25J-E56E0
162 1103				(NOMINAL VALUE, SELECTED)		
103	317-0120-00			RES.,FXD,CMPSN:12 OHM,5%,0.125W	01121	BB1205
105				(ADDED IF NECESSARY)		
104	317-0391-00			RES.,FXD,CMPSN:390 OHM,5%,0.125W	01121	BB3915
105	315-0470-00			RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
107	317-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.125W	01121	BB1015
108	317-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.125W	01121	BB1015
109	311-1268-00			RES., VAR, NONWIR: 10K OHM, 10%, 0.50W	32997	3329P-L58-103
110	311-1228-00			RES.,VAR,NONWIR:10K OHM,20%,0.50W	32997	3386F-T04-103
111	315-0103-00			RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
112	311-1259-00			RES.,VAR,NONWIR:100 OHM,10%,0.50W	32997	3329P-L58-101
113	317-0681-00			RES.,FXD,CMPSN:680 OHM,5%,0.125W	01121	BB6815
114	315-0151-00			RES.,FXD,CMPSN:150 OHM,5%,0.25W	57668	NTR25J-E150E
119	315-0300-00			RES.,FXD,CMPSN:30 OHM,5%,0.25W	01121	CB3005
120	315-0154-00			RES., FXD, CMPSN: 150K OHM, 5%, 0.25W	57668	NTR25J-E150K
122	321-0239-00				~ ~ ~ ~ ~	MEE10-000-00-
122	315-0101-00			RES.,FXD,FILM:3.01K OHM,1%,0.125W	91637 57668	MFF1816G30100F
124	321-0307-00			RES.,FXD,CMPSN:100 OHM,5%,0.25W RES.,FXD,FILM:15.4K OHM,1%,0.125W	57668 91637	NTR25J-E 100E MFF1816G15401F
125	315-0222-00			RES.,FXD,CMPSN:2.2K OHM,5%,0.25W	57668	NTR25J-E02K2
126	321-0277-00			RES.,FXD,FILM:7.5K OHM,1%,0.125W	91637	MFF1816G75000F
127	315-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
100	211 1 400 00					
128 128	311-1403-00			RES.,VAR,NONWIR:5K OHM,20%,0.50W	01121	18M651
129	315-0105-00			(FURN AS A SET W/S128)	01101	CB1055
130	321-0133-00			RES.,FXD,CMPSN:1M OHM,5%,0.25W RES. FXD FILM:237 OHM 1% 0 125W	01121	CB1055 MEE1816G237B0E
131	321-0133-00			RES.,FXD,FILM:237 OHM,1%,0.125W RES.,FXD,FILM:237 OHM,1%,0.125W	91637 91637	MFF1816G237R0F MFF1816G237R0F
132	317-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.125W	01121	BB1015
133	311-1259-00			RES., VAR, NONWIR: 100 OHM, 10%, 0.50W	32997	3329P-L58-101

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

CL+ N-	Tektronix		odel No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
R134	317 0101 00					art Humbe
R135	317-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.125W	01121	BB1015
	311-1222-00			RES., VAR, NONWIR: 100 OHM, 20%, 0.50W	32997	
R136	317-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.125W		3386F-T04-101
R137	317-0242-00			RES.,FXD,CMPSN:2.4K OHM,5%,0.125W	01121	BB1015
R138	317-0202-00			RES.,FXD,CMPSN:2K OHM,5%,0.125W	01121	BB2425
R139	311-0635-00			RES., VAR, NONWW: TRMR, 1K OHM, 10%, 0.5%, 0.5W	01121	BB2025
				120,011,101000,11101,11 OHM,10%,0.5%,0.5W	02111	65Y102T010
R141	317-0120-00	B010100	B010467	RES.,FXD,CMPSN:12 OHM,5%,0.125W		
R141				(NOMINAL VALUE,SELECTED)	01121	BB1205
R141	317-0082-00	B010460		RES.,FXD,CMPSN:8.2 OHM,5%,0.125W		
R141				(NOMINAL VALUE,SELECTED)	01121	BB82G5
R142	321-0072-00			RES.,FXD,FILM:54.9 OHM,1%,0.125W	.	
R142				(NOMINAL VALUE,SELECTED)	91637	MFF1816G54R90F
				(NOMINALE VALUE, SELECTED)		
R143	321-0072-00			RES.,FXD,FILM:54.9 OHM.1%,0.125W	0.007	
R143				(NOMINAL VALUE, SELECTED)	91637	MFF1816G54R90F
R144	317-0120-00	B010100	B010467	RES.,FXD,CMPSN:12 OHM,5%,0.125W		
R144					01121	BB1205
3144	317-0082-00	B010468		(NOMINAL VALUE, SELECTED)		
3144		2070400		RES.,FXD,CMPSN:8.2 OHM,5%,0.125W	01121	BB82G5
				(NOMINAL VALUE, SELECTED)		
R145	315-0620-00			RES EXD CMDENIES OTHERS A STOL		
R151	321-0076-00			RES.,FXD,CMPSN:62 OHM,5%,0.25W	01121	CB6205
152	321-0076-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	91637	MFF1816G60R40F
153	317-0220-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	91637	MFF1816G60R40F
153				RES.,FXD,CMPSN:22 OHM,5%,0.125W	01121	BB2205
1154	321-0076-00			(NOMINAL VALUE, SELECTED)		
	021-00/0-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	91637	MFF1816G60R40F
155	321-0076-00					
156	321-0081-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	91637	MFF1816G60R40F
157	321-0018-00			RES.,FXD,FILM:68.1 OHM,1%,0.125W	91637	MFF1816G68R10F
158				RES.,FXD,FILM:15 OHM,1%,0.125W	91637	MFF1816G15R00F
158	317-0220-00			RES.,FXD,CMPSN:22 OHM,5%,0.125W	01121	BB2205
161				(NOMINAL VALUE, SELECTED)		
.01	315-0511-00			RES.,FXD,CMPSN:510 OHM,5%,0.25W	01121	CB5115
162	321-0172-00					
163				RES.,FXD,FILM:604 OHM,1%,0.125W	91637	MFF1816G604R0F
164	321-0201-00			RES.,FXD,FILM:1.21K OHM,1%,0.125W	91637	MFF1816G12100F
	321-0179-00			RES.,FXD,FILM:715 OHM,1%,0.125W	91637	MFF1816G715R0F
165	311-1225-00			RES., VAR, NONWIR: 1K OHM, 20%, 0.50W	32997	
168	315-0222-00			RES.,FXD,CMPSN:2.2K OHM,5%,0.25W		3386F-T04-102
170	315-0122-00	B010100	B010467	RES.,FXD,CMPSN:1.2K OHM,5%,0.25W	57668	NTR25J-E02K2
					57668	NTR25J-E01K2
70	315-0112-00	B010468		RES.,FXD,CMPSN:1.1K OHM,5%,0.25W	01101	001105
70				(NOMINAL VALUE,SELECTED)	01121	CB1125
72	315-0331-00			RES.,FXD,CMPSN:330 OHM,5%,0.25W		
73	321-0053-00			RES.,FXD,CMPSN:330 OHM,5%,0.25W RES.,FXD,FILM:34.8 OHM,1%,0.125W	57668	NTR25J-E330E
74	315-0154-00			RES EVD CMPCNUTCK OUM TO STOR	91637	MFF1816G34R80F
75	311-1260-00			RES.,FXD,CMPSN: 150K OHM,5%,0.25W	57668	NTR25J-E150K
				RES.,VAR,NONWIR:250 OHM,10%,0.50W	32997	3329P-L58-251
76	311-1226-00			RES VAR NONWID OF FIL OUT A DOM A TOWN		
77	317-0100-00			RES.,VAR,NONWIR:2.5K OHM.20%,0.50W	32997	3386F-T04-252
78	315-0391-00			RES.,FXD,CMPSN:10 OHM,5%,0.125W	01121	BB1005
79	321-0164-00			RES.,FXD,CMPSN:390 OHM,5%,0.25W	57668	NTR25J-E390E
80	315-0122-00	B010100	B010407	RES.,FXD,FILM:499 OHM,1%,0.125W	91637	MFF1816G499R0F
B0	315-0112-00	B010100	B010467	RES.,FXD,CMPSN:1.2K OHM,5%,0.25W	57668	NTR25J-E01K2
	010-0112-00	B010468		RES.,FXD,CMPSN:1.1K OHM,5%,0.25W	01121	CB1125
80						
31	315-0101-00			(NOMINAL VALUE, SELECTED)		
32				RES., FXD, CMPSN: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
33	315-0331-00			RES.,FXD,CMPSN:330 OHM,5%,0.25W	57668	NTR25J-E330E
	321-0053-00			RES.,FXD,FILM:34.8 OHM,1%,0.125W	91637	MFF1816G34R80F
34	321-0051-00			RES.,FXD,FILM:33.2 OHM,1%,0.125W	91637	MFF1816G33R20F
85	311-1397-00			RES., VAR, NONWIR: 2 X 5K OHM, 20%, 0.25W	01121	73W1G040L502M
16	321-0127-00				01121	7011100400002101

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

Ckt No.	Tektronix Part No.	Serial/Mode Eff		Mfr	
			Dscont Name & Description	Code	Mfr Part Numbe
R187	321-0231-00				
R188	315-0391-00		RES., FXD, FILM: 2.49K OHM, 1%, 0.125W	91637	MEE1810000000
R189			RES., FXD, CMPSN: 390 OHM, 5%, 0.25W		10100240001
R193	321-0164-00		RES., FXD, FILM: 499 OHM, 1%, 0.125W	57668	
	321-0078-00		RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	
R194	321-0078-00		BES EXD EILM:52.4 OHM 10, 125W	91637	MFF1816G63R40F
R195	311-1225-00		RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G63R40F
Bioc			RES., VAR, NONWIR: 1K OHM, 20%, 0.50W	32997	
R196	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W		
R198	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
R203	317-0120-00		DEC. FXD. OMPON. I. BK OHM, 5%, 0.25W	57668	NTR25J-E1K8
R204	317-0391-00		RES.,FXD,CMPSN:12 OHM,5%,0.125W	01121	BB1205
R205	315-0470-00		RES.,FXD,CMPSN:390 OHM,5%,0.125W	01121	
R207			RES.,FXD,CMPSN:47 OHM,5%,0.25W		BB3915
1207	317-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.125W	57668 01121	NTR25J-E47E0 BB1015
R208	317-0101-00			01121	001013
3208			RES.,FXD,CMPSN:100 OHM,5%,0.125W	01121	BB1016
R209			(ADDED IF NECESSARY)	01121	BB1015
	311-1268-00		RES., VAR, NONWIR: 10K OHM, 10%, 0.50W		
7210	311-1228-00		RES VAR NONIMIENTOK OUTLOOK OF THE	32997	3329P-L58-103
3211	315-0103-00		RES., VAR, NONWIR: 10K OHM, 20%, 0.50W	32997	3386F-T04-103
3212	311-1259-00		RES., FXD, CMPSN: 10K OHM, 5%, 0.25W	57668	NTR25J-E10K0
	0.11 (200-00		RES., VAR, NONWIR: 100 OHM, 10%, 0.50W	32997	3329P-L58-101
1213	317-0681-00		PES EVD CMPCN COD CURLENT		
214	315-0151-00		RES.,FXD,CMPSN:680 OHM,5%,0.125W	01121	BB6815
215	311-1268-00		RES.,FXD,CMPSN:150 OHM,5%,0.25W	57668	
216			RES., VAR, NONWIR: 10K OHM, 10% 0.50W		NTR25J-E150E
217	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	32997	3329P-L58-103
	321-0277-00		RES.,FXD,FILM:7.5K OHM,1%,0.125W	57668	NTR25J-E10K0
218	321-0277-00		RES EXD FILM 7 5K OHM 19 0 125W	91637	MFF1816G75000F
			RES.,FXD,FILM:7.5K OHM,1%,0.125W	91637	MFF1816G75000F
219	315-0300-00		RES.,FXD,CMPSN:30 OHM,5%,0.25W		
220	315-0154-00		RES. EXD. CMPSN.30 UHM,5%,0.25W	01121	CB3005
221	321-0307-00		RES., FXD, CMPSN: 150K OHM, 5%, 0.25W	57668	NTR25J-E150K
222	321-0253-00		RES.,FXD,FILM:15.4K OHM,1%,0.125W	91637	
223			RES., FXD, FILM: 4.22K OHM, 1%, 0.125W		MFF1816G15401F
	315-0101-00		RES., FXD, CMPSN: 100 OHM, 5%, 0.25W	91637	MFF1816G42200F
224	321-0307-00		RES.,FXD,FILM:15.4K OHM,1%,0.125W	57668 91637	NTR25J-E 100E
25	315-0222-00			91037	MFF1816G15401F
26			RES.,FXD,CMPSN:2.2K OHM,5%,0.25W	57668	
27	321-0253-00		RES.,FXD,FILM:4.22K OHM,1%,0.125W		NTR25J-E02K2
	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	91637	MFF1816G42200F
28	311-1403-00		RES. VAD NONIMID SK ONN SK. U.25W	57668	NTR25J-E 100E
28			RES., VAR, NONWIR: 5K OHM, 20%, 0.50W	01121	18M651
29	315-0105-00		(FURN AS A SET W/S228)		
20			RES.,FXD,CMPSN:1M OHM,5%,0.25W	01121	CB1055
30	321-0133-00		RES.,FXD,FILM:237 OHM,1%,0.125W		
31	321-0133-00		RES.,FXD,FILM:237 OHM,1%,0.125W	91637	MFF1816G237R0F
32	317-0101-00		RES EVD CM0201 100 00000	91637	MFF1816G237R0F
33	311-1259-00		RES.,FXD.CMPSN:100 OHM,5%,0.125W	01121	BB1015
34	317-0101-00		RES., VAR, NONWIR: 100 OHM, 10%, 0.50W	32997	3329P-L58-101
35			RES.,FXD,CMPSN:100 OHM.5% 0 125W		
55	311-1222-00		RES., VAR, NONWIR: 100 OHM. 20%, 0.50W	01121 32997	BB1015
6	217 0101 00			32997	3386F-T04-101
7	317-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.125W	01121	BD101C
	317-0242-00		RES., FXD, CMPSN: 2.4K OHM, 5%, 0.125W		BB1015
8	317-0202-00		RES., FXD, CMPSN: 2K OHM, 5%, 0.125W	01121	BB2425
9	311-0635-00		RES VAR NONWAY TRUE OF ALL SW	01121	BB2025
1	317-0120-00		RES., VAR, NONWW: TRMR, 1K OHM, 10%, 0.5%, 0.5W	02111	65Y102T010
1			RES.,FXD,CMPSN:12 OHM,5%,0.125W	01121	BB1205
_			(NOMINAL VALUE, SELECTED)		
2	321-0072-00		RES., FXD, FILM: 54.9 OHM, 1%, 0.125W	- ·	
2			(NOMINAL VALUE OF 5000	91637	MFF1816G54R90F
3	321-0072-00		(NOMINAL VALUE, SELECTED)		
3			RES.,FXD,FILM:54.9 OHM,1%,0.125W	91637	MFF1816G54R90F
\$ \$			(NOMINAL VALUE, SELECTED)	0.007	UNIT TO TO COSHEISUP
•	317-0120-00		RES.,FXD,CMPSN:12 OHM,5%,0,125W	01121	BB1205
•			(NOMINAL VALUE, SELECTED)	01121	BB1205
			•		
	315-0620-00		RES.,FXD,CMPSN:62 OHM,5%,0.25W		

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

O	Tektronix	Serial/M	odel No.		• • •	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Mfr	
				Harrie & Description	Code	Mfr Part Numbe
R251	321-0076-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W		
R252	321-0076-00			BES EXD EU M/60 4 OHM, 1%, 0, 125W	91637	MFF1816G60R40F
R253	317-0220-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	91637	
R253				RES.,FXD,CMPSN:22 OHM,5%,0.125W	01121	BB2205
R254				(NOMINAL VALUE, SELECTED)		002200
R255	321-0076-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	01637	
n233	321-0076-00			RES.,FXD,FILM:60.4 OHM.1%,0.125W	91637	MFF1816G60R40F
				0.0.123W	91637	MFF1816G60R40F
R256	321-0081-00			RES.,FXD,FILM:68.1 OHM,1%,0.125W		
R257	321-0018-00			BES EXD FILM.15 OUM 18/ 9 10000	91637	MFF1816G68R10F
R258	317-0220-00			RES.,FXD,FILM:15 OHM,1%,0.125W	91637	MFF1816G15R00F
R258				RES.,FXD,CMPSN:22 OHM,5%,0.125W	01121	BB2205
R261	315-0511-00			(NOMINAL VALUE, SELECTED)		
R262				RES.,FXD,CMPSN:510 OHM,5%,0.25W	01121	CREATE
11202	321-0172-00			RES.,FXD,FILM:604 OHM,1%,0.125W		CB5115
0000					91637	MFF1816G604R0F
R263	321-0201-00			RES.,FXD,FILM:1.21K OHM,1%,0.125W		
R264	321-0179-00			RES EXD FILM: 715 OUNA 100 0 405100	91637	MFF1816G12100F
7265	311-1225-00			RES.,FXD,FILM:715 OHM,1%,0.125W	91637	MFF1816G715R0F
7268	315-0222-00			RES., VAR.NONWIR:1K OHM, 20%, 0.50W	32997	3386F-T04-102
R270	315-0122-00	BO40400		RES., FXD, CMPSN: 2.2K OHM, 5%, 0.25W	57668	NTR25J-E02K2
R270		B010100	B010467	RES.,FXD,CMPSN:1.2K OHM.5%.0.25W	57668	
	315-0112-00	B010468		RES.,FXD,CMPSN:1.1K OHM,5%,0.25W		NTR25J-E01K2
0070					01121	CB1125
3270				(NOMINAL VALUE, SELECTED)		
3272	315-0331-00			RES.,FXD,CMPSN:330 OHM,5%,0.25W		
1273	321-0053-00			RES. FXD 50 A 24 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	57668	NTR25J-E330E
274	315-0154-00			RES.,FXD,FILM:34.8 OHM,1%,0.125W	91637	MFF1816G34R80F
275	311-1260-00			RES.,FXD,CMPSN:150K OHM,5%,0.25W	57668	NTR25J-E150K
276				RES., VAR, NONWIR: 250 OHM, 10%, 0, 50W	32997	
270	311-1226-00			RES., VAR, NONWIR: 2.5K OHM, 20%, 0.50W		3329P-L58-251
077					32997	3386F-T04-252
277	317-0100-00			RES.,FXD,CMPSN:10 OHM,5%,0.125W		
278	315-0391-00			RES.,FXD,CMPSN:390 OHM,5%,0.25W	01121	BB1005
279	321-0164-00			REC. FXD CIMP 3N.390 OHM, 5%, 0.25W	57668	NTR25J-E390E
280	315-0122-00	B010100	D040467	RES.,FXD,FILM:499 OHM,1%,0.125W	91637	MFF1816G499R0F
280	315-0112-00		B010467	RES.,FXD,CMPSN:1.2K OHM,5%,0.25W	57668	NTR25J-E01K2
280		B010468		RES.,FXD,CMPSN:1.1K OHM,5%.0.25W	01121	
200				(NOMINAL VALUE, SELECTED)	01121	CB1125
281	0.5 0.0.0			· · · ·,		
	315-0101-00			RES.,FXD,CMPSN:100 OHM,5%.0.25W	67000	
282	315-0331-00			RES.,FXD,CMPSN:330 OHM,5%,0.25W	57668	NTR25J-E 100E
283	321-0053-00			RES. EVD EIL M.24 8 OLIMA 49/ 0 40200	57668	NTR25J-E330E
284	321-0051-00			RES.,FXD,FILM:34.8 OHM,1%,0.125W	91637	MFF1816G34R80F
285	311-1397-00			RES.,FXD,FILM:33.2 OHM,1%,0.125W	91637	MFF1816G33R20F
286	321-0127-00			RES., VAR, NONWIR: 2 X 5K OHM, 20%, 0.25W	01121	73W1G040L502M
	521-0127-00			RES.,FXD,FILM:205 OHM,1%,0.125W	91637	
87	201 0004 00				51007	MFF1816G205R0F
	321-0231-00			RES.,FXD,FILM:2.49K OHM,1%,0.125W	01007	
88	315-0391-00			RES.,FXD,CMPSN:390 OHM,5%,0.25W	91637	MFF1816G24900F
89	321-0164-00			RES.,FXD,FILM:499 OHM,1%,0.125W	57668	NTR25J-E390E
91	307-0106-00			RES. EVD. CMDON.4.7. 0000 000 0000	91637	MFF1816G499R0F
92	307-0106-00			RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
93	321-0078-00			RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
	52,-0070-00			RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G63R40F
94	301 0070 00					
95	321-0078-00			RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MEE10160contor
	311-1225-00			RES., VAR, NONWIR: 1K OHM, 20%, 0.50W		MFF1816G63R40F
96	315-0182-00			RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	32997	3386F-T04-102
97	307-0106-00			BES EXD CMPSN/47 OUNA For a prive	57668	NTR25J-E1K8
98	315-0182-00			RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
)1	321-0164-00			RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
				RES.,FXD,FILM:499 OHM,1%,0.125W	91637	MFF1816G499R0F
12	321-0131-00					
4				RES.,FXD,FILM:226 OHM,1%,0.125W	91637	MFF1816G226R0F
	315-0102-00			RES., FXD, CMPSN: 1K OHM, 5%, 0.25W		
6	315-0121-00			RES.,FXD,CMPSN:120 OHM,5%,0.25W	57668	NTR25JE01K0
0	315-0101-00			RES EXD CMPSN:100 OUT 5% 0 0000	01121	CB1215
1	315-0152-00			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
2	315-0120-00			RES.,FXD,CMPSN:1.5K OHM,5%,0.25W	57668	NTR25J-E01K5
				RES.,FXD,CMPSN:12 OHM,5%,0.25W	57668	NTR25J-R12
3	315-0222-00			RES.,FXD,CMPSN:2.2K OHM,5%,0.25W		

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon C: 9 4 QY Tel: 01844-35160 (Sax: 01844-3525) Email: enguines@mauritron.co.t

į

Ckt No.	Tektronix Part No.	Serial/Model No.		Mfr	
		Eff Dscont	Name & Description	Code	Mfr Part Number
R314					
R314	315-0822-00		RES.,FXD,CMPSN:8.2K OHM,5%,0.25W	01121	CDAOOS
R320	315-0473-00		RES.,FXD,CMPSN:47K OHM,5%,0.25W	57668	CB8225
R321	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W		
	315-0152-00		RES.,FXD,CMPSN:1.5K OHM,5%,0.25W	57668	NTR25J-E 100E
R322	315-0120-00		RES.,FXD,CMPSN:12 OHM,5%,0.25W	57668	NTR25J-E01K5
R323	315-0222-00		RES.,FXD,CMPSN:2.2K OHM,5%,0.25W	57668	NTR25J-R12
566				57668	NTR25J-E02K2
R324	315-0822-00		RES.,FXD,CMPSN:8.2K OHM,5%,0.25W	01104	
R325	315-0473-00		RES.,FXD,CMPSN:47K OHM,5%,0.25W	01121	CB8225
R331	315-0102-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25J-E47K0
R332	315-0123-00		RES.,FXD,CMPSN:12K OHM,5%,0.25W	57668	NTR25JE01K0
R333	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E12K0
R335	315-0123-00		RES.,FXD,CMPSN:12K OHM,5%,0.25W	57668	NTR25J-E1K8
			HE3., 1XB, CMPSN: 12K OHM, 5%, U.25W	57668	NTR25J-E12K0
R336	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W		
R338	315-0203-00		BES EVD CMPSN. LOK OHM.5%,0.25W	57668	NTR25J-E1K8
R339	315-0222-00		RES.,FXD,CMPSN:20K OHM,5%,0.25W	57668	NTR25J-E20K0
R341	315-0102-00		RES.,FXD,CMPSN:2.2K OHM,5%,0.25W	57668	NTR25J-E02K2
R342	315-0132-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R343	315-0511-00		RES.,FXD,CMPSN:1.3K OHM,5%,0.25W	57668	NTR25J-E01K3
-			RES.,FXD,CMPSN:510 OHM,5%,0.25W	01121	CB5115
R346	315-0102-00				- · · -
R347	315-0102-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R348	315-0331-00		RES., FXD, CMPSN: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
R351			RES.,FXD,CMPSN:330 OHM,5%,0.25W	57668	NTR25J-E330E
R353	315-0202-00		RES.,FXD,CMPSN:2K OHM,5%,0.25W	57668	NTR25J-E02K0
R353	321-0152-00		RES.,FXD,FILM:374 OHM,1%,0.125W	91637	
1334	321-0114-00		RES.,FXD,FILM:150 OHM,1%,0.125W	91637	MFF1816G374R0F
2255				51037	MFF1816G150R0F
3355	321-0174-00		RES.,FXD,FILM:634 OHM,1%,0.125W	01627	MEE1010000100-
3356	321-0114-00		RES.,FXD,FILM:150 OHM,1%,0.125W	91637	MFF1816G634R0F
357	321-0174-00		RES.,FXD,FILM:634 OHM,1%,0.125W	91637	MFF1816G150R0F
358	321-0152-00		RES.,FXD,FILM:374 OHM,1%,0.125W	91637	MFF1816G634R0F
3359	315-0202-00		RES.,FXD,CMPSN:2K OHM,5%,0.25W	91637	MFF1816G374R0F
361	315-0202-00		RES.,FXD,CMPSN:2K OHM,5%,0.25W	57668	NTR25J-E02K0
			NES., ND, CMPSN.2K UHM, 5%, 0.25W	57668	NTR25J-E02K0
1363	321-0152-00		RES.,FXD,FILM:374 OHM,1%,0.125W		
1364	321-0114-00		RES.,FXD,FILM:150 OHM,1%,0.125W	91637	MFF1816G374R0F
365	321-0174-00		RES.,FXD,FILM:634 OHM,1%,0.125W	91637	MFF1816G150R0F
366	321-0114-00		RES. FXD FILM.034 OHM, 1%, 0.125W	91637	MFF1816G634R0F
367	321-0174-00		RES.,FXD,FILM:150 OHM,1%,0.125W	91637	MFF1816G150R0F
368	321-0152-00		RES.,FXD,FILM:634 OHM,1%,0.125W	91637	MFF1816G634R0F
			RES.,FXD,FILM:374 OHM,1%,0.125W	91637	MFF1816G374R0F
369	315-0202-00		REC EXP CMRCh of China and China		
370			RES.,FXD,CMPSN:2K OHM,5%,0.25W	57668	NTR25J-E02K0
371	315-0470-00		(SEE DM44 MANUAL)		
372	315-0470-00		RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
373	315-0470-00		RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
374	315-0470-00		RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
	0.0-0470-00		RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
380	321-0078-00				
381	321-0078-00		RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G63R40F
382	323-0130-00		RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G63R40F
183	323-0130-00		RES.,FXD,FILM:221 OHM,1%,0.50W	91637	MFF1226G221R0F
84	322-0107-00		RES.,FXD,FILM:221 OHM,1%,0.50W	91637	MFF1226G221R0F
85	311-1221-00		RES.,FXD,FILM:127 OHM,1%,0.25W	75042	CEBT0-1270F
	011-1221-00		RES., VAR, NONWIR:50 OHM, 20%, 0.50W	32997	3386F-T04-500
88	315-0270-00				
91			RES.,FXD,CMPSN:27 OHM,5%,0.25W	01121	CB2705
91	321-0163-00		RES.,FXD,FILM:487 OHM,1%,0.125W	91637	MFF1816G487R0F
91			(USED AT LOCATION R391A)		
91	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
			(USED AT LOCATION R391B)		
92	321-0122-00	1	RES.,FXD,FILM:182 OHM,1%,0.125W	91637	MFE1816G182P05
	321-0122-00		RES.,FXD,FILM:182 OHM,1%,0.125W RES.,FXD,CMPSN:270 OHM,5%,0.25W	91637	MFF1816G182R0F

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

	Tektronix	Serial/M	odel No.		× 44	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Mfr	
			·		Code	Mfr Part Number
R394	321-0146-00			RES. EXD FILM ON OUT A 191 O LOT		
R395	322-0156-00			RES.,FXD,FILM:324 OHM,1%,0.125W	91637	MFF1816G324R0F
R396	307-0106-00			RES.,FXD,FILM:412 OHM,1%,0.25W	75042	CEBT0-4120F
R397	315-0471-00			RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
R398	317-0430-00			RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E470E
R399	315-0330-00			RES.,FXD,CMPSN:43 OHM,5%,0.125W	01121	BB4305
1000	313-0330-00			RES.,FXD,CMPSN:33 OHM,5%,0.25W	01121	CB3305
R401	221 0122 00					
R402	321-0132-00			RES.,FXD,FILM:232 OHM,1%,0.125W	91637	MFF1816G232R0F
R403	321-0078-00			RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G63R40F
	311-1221-00			RES., VAR, NONWIR: 50 OHM, 20%, 0.50W	32997	3386F-T04-500
R404	321-0132-00			RES.,FXD,FILM:232 OHM,1%,0.125W	91637	MFF1816G232R0F
R405	321-0078-00			RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G63R40F
R411	321-0132-00			RES.,FXD,FILM:232 OHM,1%,0.125W	91637	MEE18160000000
					51007	MFF1816G232R0F
R412	321-0078-00			RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	
R414	321-0132-00			RES.,FXD,FILM:232 OHM,1%,0.125W		MFF1816G63R40F
R415	321-0078-00			RES.,FXD,FILM:63.4 OHM,1%,0.125W	91637	MFF1816G232R0F
R419	321-0068-00			RES.,FXD,FILM:49.9 OHM,1%,0.125W	91637	MFF1816G63R40F
R420	315-0200-00			RES.,FXD,CMPSN:20 OHM,5%,0.25W	91637	MFF1816G49R90F
R421	321-0151-00			RES.,FXD,FILM:365 OHM,1%,0.125W	01121	CB2005
				NES.,FXD,FIEM.365 OHM,1%,0.125W	91637	MFF1816G365R0F
R422	321-0210-00			RES EVD EILMALEK OUTSTAN OF STORY		
R423	321-0076-00			RES.,FXD,FILM:1.5K OHM,1%,0.125W	91637	MFF1816G15000F
R425	311-1227-00			RES.,FXD,FILM:60.4 OHM,1%,0.125W	91637	MFF1816G60R40F
R426	322-0161-00			RES.,VAR,NONWIR:5K OHM,20%,0.50W	32997	3386F-T04-502
R427	315-0271-00			RES.,FXD,FILM:464 OHM,1%,0.25W	91637	CMF6042G464R0F
R430	315-0471-00			RES.,FXD,CMPSN:270 OHM,5%,0.25W	01121	CB2715
	515-0471-00			RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E470E
R431	201 0074 00					
R432	321-0071-00			RES.,FXD,FILM:53.6 OHM,1%,0.125W	91637	MFF1816G53R60F
R436	321-0184-00			RES.,FXD,FILM:806 OHM,1%,0.125W	91637	MFF1816G806R0F
	315-0100-00			RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R437	315-0100-00			RES., FXD, CMPSN: 10 OHM, 5%, 0.25W	57668	NTR25J-E 10E0
R438	307-0106-00			RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
R441	321-0068-00			RES.,FXD,FILM:49.9 OHM,1%,0.125W	91637	MFF1816G49R90F
					31037	MFF1818G49R90F
R443	317-0510-00			RES.,FXD,CMPSN:51 OHM,5%,0.125W	01101	BB5105
R445	321-0068-00			RES.,FXD,FILM:49.9 OHM,1%,0.125W	01121	BB5105
R446	317-0510-00			RES.,FXD,CMPSN:51 OHM,5%,0.125W	91637	MFF1816G49R90F
R447	321-0201-00	B010100	B019489	RES.,FXD,FILM:1.21K OHM,1%,0.125W	01121	BB5105
R447	321-0184-00	B019490		RES.,FXD,FILM:806 OHM,1%,0.125W	91637	MFF1816G12100F
R448	321-0135-00	B010100	B019489	RES.,FXD,FILM:249 OHM,1%,0.125W	91637	MFF1816G806R0F
				HEO., ND, HEM.249 OHM, 1%, 0.125W	91637	MFF1816G249R0F
R448	321-0143-00	B019490		RES. EXD Ell M/201 OLIM 10/ D 10514		
R449	311-1238-00			RES.,FXD,FILM:301 OHM,1%,0.125W	91637	MFF1816G301R0F
R450	311-1260-00			RES.,VAR,NONWIR:5K OHM,10%,0.50W	73138	72-27-0
R451	317-0750-00			RES., VAR, NONWIR: 250 OHM, 10%, 0.50W	32997	3329P-L58-251
R452	317-0200-00			RES.,FXD,CMPSN:75 OHM,5%,0.125W	01121	BB7505
R453	317-0200-00			RES.,FXD,CMPSN:20 OHM,5%,0.125W	01121	BB2005
	517-0200-00			RES.,FXD,CMPSN:20 OHM,5%,0.125W	01121	BB2005
R454	317 0004 00					
R455	317-0681-00			RES.,FXD,CMPSN:680 OHM,5%,0.125W	01121	BB6815
	317-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.125W	01121	BB1025
R456	315-0220-00			RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
R457	321-0163-00			RES.,FXD,FILM:487 OHM,1%,0.125W	91637	MFF1816G487R0F
R458	321-0163-00			RES.,FXD,FILM:487 OHM,1%,0.125W	91637	MFF1816G487R0F
R459	315-0102-00			RES., FXD, CMPSN: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
					57000	ATH255E0TK0
R460	315-0270-00			RES.,FXD,CMPSN:27 OHM,5%,0.25W	01121	CB2705
R461	321-0198-00			RES.,FXD,FILM:1.13K OHM,1%,0.125W		
R462	323-0147-00			RES.,FXD,FILM:332 OHM,1%,0.50W	91637	MFF1816G11300F
R463	315-0561-00				75042	CECT0-3320F
R464	323-0147-00			RES.,FXD,CMPSN:560 OHM,5%,0.25W	01121	CB5615
R465	315-0561-00			RES.,FXD,FILM:332 OHM,1%,0.50W	75042	CECT0-3320F
				RES.,FXD,CMPSN:560 OHM,5%,0.25W	01121	CB5615
R466	311-1278-00			RES.,VAR,NONWIR:250 OHM,10%,0.5W	32997	

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

	Mfr	
Name & Description	Coc	
	000	le Mfr Part Number
RES.,FXD,CMPSN:24 OHM,5%,0.125W		
TES., FXD, CMPSN: 43 OHM 5% 0 125W	0112	21 BB2405
RES.,FXD,FILM:42.2 OHM,1%,0.125W	0112	
RES.,FXD,FILM:42.2 OHM,1%,0.125W	9163	
RES.,VAR,NONWIR:500 OHM,10%,0.50W	9163	7 MFF1816G42R20F
RES EXD CMPSNULK OUN STORE	3299	10100421205
RES.,FXD,CMPSN:1K OHM.5%,0.25W	5766	002011-200-301
REC EXP ON DOM -	0,00	8 NTR25JE01K0
RES.,FXD,CMPSN:20 OHM,5%,0.25W	0110	
RES.,FXD.CMPSN:20 OHM,5%,0.25W	0112	002000
HES., FXD, CMPSN:24 OHM 5% 0 125W	01121	02000
HES., FXD, CMPSN:43 OHM 5% 0 125W	01121	002400
HES., VAH, NONWIR: 10K OHM 10% 0 50W	01121	22,000
RES.,FXD,CMPSN:1.8K OHM,5%,0.125W	73138	72-28-0
01111,5 %,0,125W	01121	BB1825
RES.,FXD,CMPSN:820 OHM,5%,0.25W		
RES.,FXD,FILM:499 OHM,1%,0.125W	57668	NTR25J-E 820E
RES. EXD FUNA 499 OHM, 1%, 0.125W	91637	
RES.,FXD,FILM: 499 OHM, 1%,0.125W	91637	
RES.,FXD,CMPSN:51 OHM,5%,0.25W		
RES.,FXD,FILM:24.9 OHM,1%,0.125W	57668	NTR25J-E51E0
RES., FXD, FILM: 24.9 OHM, 1%, 0.125W	91637	CMF55116G24R90F
	91637	CMF55116G24R90F
ES.,FXD,FILM:422 OHM,1%,0.25W		
ES.,FXD,FILM:422 OHM,1%,0.25W	75042	CEBT0-4220F
ES.,FXD,CMPSN:56 OHM,5%,0.25W	75042	CEBT0-4220F
ES EXD CMPSN:10 OUN1 5%,0.25W	57668	NTR25J-E56E0
ES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25 LE 10ED
ES.,FXD,CMPSN:300 OHM,5%,0.25W	57668	NTR25J-E 10E0
ES., VAR, NONWIR: 250 OHM, 10%, 0.50W		NTR25J-E300E
	73138	72-22-0
ES.,FXD,CMPSN:910 OHM,5%,0.25W		
S.,FXD,CMPSN:10K OHM 5% 0 25W	57668	NTR25J-E910E
S.,FXD,CMPSN:10 OHM,5%,0.50W	57668	NTR25J-E10K0
S.,FXD.FILM:243 OHM,1%,0.50W	01121	EB1005
S.,FXD,FILM:243 OHM,1%,0.50W	91637	MFF1226G243R0F
S.,FXD,CMPSN:620 OHM,5%,0.125W	91637	MFF1226G243R0F
0,17 MB;0MI SN:020 OHM;5%;0.125W	01121	BB6215
ED AT LOCATION R494A)		550215
S VAR NONNIE SUCCESSION R494A)		
S., VAR, NONWIR: 5K OHM, 10%, 0.50W	73138	80.00 4
UED IF NECESSARYVUSED AT LOCATION DATE	10100	82-30-1
2.1 AD FILM 243 OHM 1% 0 5014	01007	
5.,FXD,FILM:243 OHM 1% 0 50W	91637	MFF1226G243R0F
S.,FXD,FILM: 182.5 OHM	91637	MFF1226G243R0F
	80009	307-0292-00
FXD,CMPSN:4.7 OHM.5%,0.25W		
FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
EXD CMPSNISC OUNT SW	01121	CB47G5
FXD,CMPSN:56 OHM,5%,0.25W	57668	
.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E56E0
-FAD, CMPSN: 1.5K OHM 5% 0.25W	57668	NTR25J-E220E
.,FXD,CMPSN:220 OHM,5%,0.25W		NTR25J-E01K5
	57668	NTR25J-E220E
FXD,CMPSN:1.5K OHM,5%,0.25W		
FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E01K5
FXD,CMPSN:1.5K OHM,5%,0.25W	57668	NTR25J-E47E0
EXD CMPSN: 10K OUM 5% 0.25W	57668	NTR25J-E01K5
FXD,CMPSN:10K OHM.5%,0.25W		NTR25J-E10K0
FXD,CMPSN:270K OHM,5%,0.25W		NTR25J-E270K
FXD,CMPSN:56 OHM,5%.0.25W		
	0,000	NTR25J-E56E0
FXD,CMPSN:33 OHM,5%,0.25W	01101	
FXD,CMPSN:820K OHM 5% 0 2514	A	CB3305
"XU,CMPSN:510K OHM 5% 0.25W		CB8245
AD, CMPSN: 4.7M OHM 5% D 2514	19701 5	5043CX510K0J
TXD.CMPSN 180K OHM 5% 0 0014		CB4755
XD CMPSN: 100K OLIM St. 2 2		CB1845
10,000 SN: TUUK OHM,5%,0.25W	-	ITR25J-E100K
YD CMPCN SOL OF	1	
AD, UMPSN: 56K OHM, 5%, 0.25W	01121	85635
-) =)	XD,CMPSN:180K OHM,5%,0.25W XD,CMPSN:100K OHM,5%,0.25W KD,CMPSN:56K OHM,5%,0.25W	XD,CMPSN:180K OHM,5%,0.25W 01121 C XD,CMPSN:100K OHM,5%,0.25W 57668 N KD,CMPSN:56K OHM,5%,0.25W 20102

Ckt No	Tektronix	Serial/Model No.		Mfr	
<u>Ckt No.</u>	Part No.	Eff Dscont	Name & Description		M/ 5
				Code	Mfr Part Number
R517	315-0105-00		RES.,FXD,CMPSN:1M OHM.5%.0.25W		
R518	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	01121	
R519	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 10E0
R520	315-0560-00		RES.,FXD,CMPSN:56 OHM,5%,0.25W	57668	NTR25J-E 100E
R521	315-0101-00		RES. FXD CMPSN 100 CHM 5% U.25W	57668	NTR25J-E56E0
R522	315-0150-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	
			RES., FXD, CMPSN: 15 OHM, 5%, 0.25W	01121	
R523	315-0150-00				
R524	315-0101-00		RES.,FXD,CMPSN:15 OHM,5%,0.25W	01121	CB1505
R525	315-0821-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R526	315-0220-00		RES.,FXD,CMPSN:820 OHM,5%,0.25W	57668	NTR25J-E 820E
R527	322-0178-00		RES., FXD, CMPSN:22 OHM.5%, 0.25W	01121	CB2205
R528	315-0220-00		RES.,FXD,FILM:698 OHM,1%,0.25W	75042	CEBT0-6980F
	010-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
R529	315-0103-00				001200
R530	311-1192-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
R530			RES., VAR, NONWIR: 10K OHM, 20%, 1W, W/SW	71590	BA-232-001
R532	315-0122-00		(FURN AS A SET W/S530)		5, (-202-001
R533			RES.,FXD,CMPSN:1.2K OHM,5%,0.25W	57668	NTR25J-E01K2
R534	315-0821-00		RES.,FXD,CMPSN:820 OHM,5%,0.25W	57668	
11004	311-1230-00		RES., VAR, NONWIR: 20K OHM, 20%, 0.50W	32997	NTR25J-E 820E
R535	015 0000 00			32337	3386F-T04-203
	315-0302-00		RES.,FXD,CMPSN:3K OHM,5%,0.25W	57000	
R536	315-0131-00		RES.,FXD,CMPSN:130 OHM,5%,0.25W	57668	NTR25J-E03K0
R537	315-0152-00		RES.,FXD,CMPSN:1.5K OHM,5%,0.25W	01121	CB1315
R538	315-0332-00		RES. FXD,CMPSN:3.3K OHM,5%,0.25W	57668	NTR25J-E01K5
R541	315-0682-00		RES.,FXD,CMPSN:6.8K OHM,5%,0.25W	57668	NTR25J-E03K3
R542	315-0392-00		RES.,FXD,CMPSN:3.9K OHM,5%,0.25W	57668	NTR25J-E06K8
			120.1 XD,000 31.3.5K 0HM,5%,0.25W	57668	NTR25J-E03K9
R543	315-0221-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W		
R544	315-0302-00		RES. EXD. CMPON OK OUN 5% 0.25W	57668	NTR25J-E220E
R545	315-0242-00		RES. FXD, CMPSN:3K OHM, 5%, 0.25W	57668	NTR25J-E03K0
R546	315-0470-00		RES.,FXD,CMPSN:2.4K OHM,5%,0.25W	57668	NTR25J-E02K4
R547	311-1230-00		RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
R550	317-0560-00		RES. VAR,NONWIR:20K OHM,20%,0.50W	32997	3386F-T04-203
			RES.,FXD,CMPSN:56 OHM,5%,0.125W	01121	BB5605
R551	321-0082-00				
R552	322-0283-00		RES.,FXD,FILM:69.8 OHM,1%,0.125W	91637	MFF1816G69R80F
R553	321-0082-00		RES.,FXD,FILM:8.66K OHM,1%,0.25W	91637	MFF1421G86600F
R554	321-0059-00		RES., FXD, FILM: 69.8 OHM, 1%, 0.125W	91637	MFF1816G69R80F
R555	321-0185-00		RES.,FXD,FILM:40.2 OHM,1%,0.125W	91637	MFF1816G40R20F
R556			RES.,FXD,FILM:825 OHM,1%,0,125W	91637	MFF1816G825R0F
	321-0047-00		RES.,FXD,FILM:30.1 OHM,1%,0.125W	91637	MFF1816G30R10F
R557	331 0334 00			51007	WIT TOTOGSON TUP
R558	321-0224-00		RES.,FXD,FILM:2.1K OHM,1%,0.125W	91637	MFF1816G21000F
R559	321-0044-00		RES.,FXD,FILM:28 OHM,1%,0.125W	91637	MFF1816G28R00F
R560	321-0259-00		RES.,FXD,FILM:4.87K OHM,1%,0.125W	91637	
	317-0560-00		RES.,FXD,CMPSN:56 OHM,5%,0.125W		MFF1816G48700F
R561	321-0082-00		RES.,FXD,FILM:69.8 OHM,1%,0.125W	01121	BB5605
R562	322-0283-00		RES.,FXD,FILM:8.66K OHM,1%,0.25W	91637	MFF1816G69R80F
Dree				91637	MFF1421G86600F
R563	321-0082-00		RES.,FXD,FILM:69.8 OHM,1%,0.125W	01007	
R564	315-0242-00		RES.,FXD,CMPSN:2.4K OHM,5%,0.25W	91637	MFF1816G69R80F
R565	311-1228-00		RES., VAR, NONWIR: 10K OHM, 20%, 0.50W	57668	NTR25J-E02K4
R566	321-0044-00		RES.,FXD,FILM:28 OHM,1%,0.125W	32997	3386F-T04-103
R567	321-0224-00		RES.,FXD,FILM:2.1K OHM,1%,0.125W	91637	MFF1816G28R00F
R568	315-0101-00		RES EXD CMPSN: 100 OUM 5% O OFW	91637	MFF1816G21000F
			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R569	321-0279-00				
R570	301-0181-00		RES.,FXD,FILM:7.87K OHM,1%,0.125W	91637	MFF1816G78700F
R571	315-0100-00		RES.,FXD,CMPSN:180 OHM,5%,0.5W	57668	TR50J-E180E
R572	321-0187-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R574	315-0432-00		RES.,FXD,FILM:866 OHM,1%,0.125W	91637	MFF1816G866R0F
R575	315-0151-00	1	RES.,FXD,CMPSN:4.3K OHM,5%,0.25W	57668	NTR25J-E04K3
	010-0101-00	ł	RES.,FXD,CMPSN:150 OHM,5%,0.25W	57668	NTR25J-E150E
R577	321-0246-00				_
	JE	Ŧ	RES.,FXD,FILM:3.57K OHM,1%,0.125W	91637	MFF1816G35700F

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4 QY Tel: 01844-351694 Fax- 01844-352554 Email: enquiries@maunitron.co.uk

REV DEC 1984

Ckt No.	Tektronix Part No.	Serial/Model No.		Mfr	
	Part No.	Eff Dscont	Name & Description	Code	Mfr Part Number
				0000	win Fait Number
R578	321-0164-00		RES.,FXD,FILM:499 OHM,1%,0.125W		
R579	301-0201-00		RES.,FXD,CMPSN:200 OHM,5%,0.5W	91637	
R580	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	57668	TR50J-E200E
R581	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	01121	CB2205
R582	315-0471-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R583	315-0331-00		RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E470E
			RES.,FXD,CMPSN:330 OHM,5%,0.25W	57668	NTR25J-E330E
R584	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W		
R588	301-0121-00		BES EXD CMPON 400 CHM,5%,0.25W	01121	CB2205
R590	315-0102-00		RES.,FXD,CMPSN:120 OHM,5%,0.5W	57668	R50J 120 OHM
R591	321-0242-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R592	321-0222-00		RES., FXD, FILM: 3.24K OHM, 1%, 0.125W	91637	MFF1816G32400F
R593			RES.,FXD,FILM:2K OHM,1%,0.125W	91637	MFF1816G20000F
	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
R594	315-0162-00		DEC. EVE ON DOLL OF DUE T		
R595	315-0102-00		RES.,FXD,CMPSN:1.6K OHM,5%,0.25W	01121	CB1625
R596	307-0106-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R597			RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
R598	315-0221-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	
	315-0221-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E220E
R599	321-0318-00		RES.,FXD,FILM:20K OHM,1%,0.125W	91637	NTR25J-E220E
R600	307 0106 00			31007	MFF1816G20001F
R601	307-0106-00		RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
	315-0472-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W	57668	NTR25J-E04K7
7602	315-0472-00		RES.,FXD,CMPSN:4.7K OHM,5%.0.25W		
1603	315-0241-00		RES.,FXD,CMPSN:240 OHM,5%,0.25W	57668	NTR25J-E04K7
1604	315-0393-00		RES.,FXD,CMPSN:39K OHM,5%,0.25W	01121	CB2415
8605			(SEE DM44 MANUAL)	57668	NTR25J-E39K0
0607	0.1.8. A		· · · · · · · · · · · · · · · · · · ·		
1607	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	E7000	
1608	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 100E
609	315-0104-00		RES.,FXD,CMPSN:100K OHM,5%,0.25W	57668	NTR25J-E 10E0
610	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E100K
611	321-0174-00		RES EXD EU M.624 OUM.5%,U.25W	57668	NTR25J-E 10E0
612	321-0190-00		RES.,FXD,FILM:634 OHM,1%,0.125W	91637	MFF1816G634R0F
			RES.,FXD,FILM:931 OHM,1%,0.125W	91637	MFF1816G931R0F
613	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W		
622	307-0103-00		RES EXD CMPSN:27 OUNTRY 2 200	57668	NTR25J-E 100E
626	315-0201-00		RES.,FXD,CMPSN:2.7 OHM,5%,0.25W	01121	CB27G5
627	315-0101-00		RES.,FXD,CMPSN:200 OHM.5%,0.25W	57668	NTR25J-E200E
528	321-0184-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
529	321-0205-00		RES.,FXD,FILM:806 OHM,1%,0.125W	91637	MFF1816G806R0F
	321-0203-00		RES.,FXD,FILM:1.33K OHM,1%,0.125W	91637	MFF1816G13300F
541	321-0222-00		REC. EVD EN MON ON MAN		
542	321-0275-00		RES.,FXD,FILM:2K OHM,1%,0.125W	91637	MFF1816G20000F
544	311-1401-00		RES.,FXD,FILM:7.15K OHM,1%,0.125W	91637	MFF1816G71500F
544			RES., VAR, NONWIR: 100K OHM, 20%, 0.50W	01121	15M503
47			(FURN AS A SET W/S644)		
	315-0473-00		RES., FXD, CMPSN: 47K OHM, 5%, 0.25W	57668	NTR25 E4740
61	315-0430-00		RES.,FXD,CMPSN:43 OHM,5%,0.25W	01121	NTR25J-E47K0 CB4305
62	315 0150 00			01121	
63	315-0150-00		RES.,FXD,CMPSN:15 OHM,5%,0.25W	01121	CB1505
	322-0207-00		RES.,FXD,FILM:1.4K OHM,1%,0.25W	91637	CMF6042G14000F
64 65	315-0510-00		RES.,FXD,CMPSN:51 OHM,5%,0.25W	57668	
65	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W		NTR25J-E51E0
66	315-0102-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25J-E10K0
67	315-0510-00		RES.,FXD,CMPSN:51 OHM,5%,0.25W	57668 57668	NTR25JE01K0
20	004 0476 55			57000	NTR25J-E51E0
58 50	321-0178-00		RES.,FXD.FILM:698 OHM,1%,0.125W	91637	MFF1816G698R0F
59 70	315-0160-00	-	RES.,FXD,CMPSN:16 OHM,5%,0.25W	01121	
70	315-0470-00		RES.,FXD,CMPSN:47 OHM,5%,0.25W		CB1605
71	315-0430-00		RES.,FXD,CMPSN:43 OHM,5%,0.25W	57668	NTR25J-E47E0
72	315-0150-00		RES.,FXD,CMPSN:15 OHM,5%,0.25W	01121	CB4305
				01121	CB1505
73	311-1223-00				
73 74	311-1223-00	ļ	RES., VAR, NONWIR: TRMR, 250 OHM, 0.5W	73138	72-5-0

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

	Tektronix	Serial/Model No.			
Ckt No.	Part No.	Eff Dscont	Name & Description	Mfr	
			Name & Description	Code	Mfr Part Numbe
R675	321-0155-00		RES EXD FILM (00 putter)		
R676	315-0102-00		RES.,FXD,FILM:402 OHM,1%,0.125W	9163	
R677	315-0510-00		RES., FXD, CMPSN: 1K OHM, 5%, 0.25W		
R678	321-0178-00		RES.,FXD,CMPSN:51 OHM,5% 0 25W	57668	
R679			RES.,FXD.FILM:698 OHM,1%,0.125W	57668	
	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	91637	MFF1816G698R0F
R680	321-0225-00		BES EXD 50 M 0 45% 0000	01121	CB2205
			RES.,FXD,FILM:2.15K OHM,1%,0.125W	91637	40000
R681	321-0209-00			0.007	MFF1816G21500F
R682	315-0102-00		RES.,FXD,FILM:1.47K OHM,1%,0.125W	04007	
R683			RES., FXD, CMPSN: 1K OHM, 5%, 0.25W	91637	
R684	315-0202-00		RES.,FXD,CMPSN:2K OHM,5%,0.25W	57668	NTR25JE01K0
	321-0248-00		BES EXD FILM 2 74K OHM, 5%, 0.25W	57668	NTR25J-E02K0
R685	321-0248-00		RES.,FXD,FILM:3.74K OHM,1%,0.125W	91637	MFF1816G37400F
R686	321-0210-00		RES.,FXD,FILM:3.74K OHM,1%,0.125W	91637	
			RES.,FXD,FILM:1.5K OHM,1%,0.125W		MFF1816G37400F
R687	201 0000 00		, 	91637	MFF1816G15000F
	321-0209-00		RES., FXD, FILM: 1.47K OHM, 1%, 0.125W		
R688	321-0141-00		BES EXD EL M.007 OLIVER 1%,0.125W	91637	MFF1816G14700F
7689	315-0432-00		RES.,FXD,FILM:287 OHM,1%,0.125W	91637	MFF1816G287R0F
7692	315-0472-00		RES., FXD, CMPSN: 4.3K OHM, 5%, 0.25W	57668	NTDOC / CONTROL
7693	315-0471-00		HES.,FXD,CMPSN:4.7K OHM 5% 0 25W		NTR25J-E04K3
1694			RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E04K7
1034	315-0470-00		BES EXD CMPSN:47 OUNA 50 a grun	57668	NTR25J-E470E
			RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
1695	321-0204-00				
696	321-0222-00		RES.,FXD,FILM:1.3K OHM,1%,0.125W	01607	
697			RES.,FXD,FILM:2K OHM,1%,0.125W	91637	MFF1816G13000F
698	321-0178-00		RES.,FXD,FILM:698 OHM,1%,0.125W	91637	MFF1816G20000F
	315-0100-00		BES EXD CMPSN 10 OUN TO 125W	91637	MFF1816G698R0F
699	315-0472-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
701	315-0152-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W	57668	NTROS LEONE
			RES.,FXD,CMPSN:1.5K OHM,5%,0.25W		NTR25J-E04K7
702	215 0160 00			57668	NTR25J-E01K5
703	315-0162-00		RES.,FXD,CMPSN:1.6K OHM,5%,0.25W		
	315-0152-00		RES.,FXD,CMPSN:1.5K OHM,5%,0.25W	01121	CB1625
704	315-0162-00		RES. FXD. OMPSIN: 1.5K OHM,5%,0.25W	57668	NTR25J-E01K5
705	315-0152-00		RES.,FXD,CMPSN:1.6K OHM,5%,0.25W	01121	
706	315-0162-00		HES., FXD, CMPSN: 1.5K OHM 5% 0.25W		CB1625
11			RES.,FXD,CMPSN:1.6K OHM,5%,0.25W	57668	NTR25J-E01K5
••	315-0152-00		RES.,FXD,CMPSN:1.5K OHM,5%,0.25W	01121	CB1625
			12-14 AD;6111 614.1.5K OHWI,5%,0.25W	57668	NTR25J-E01K5
12	315-0221-00				
13	315-0152-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	
14	315-0221-00		RES., FXD, CMPSN: 1.5K OHM.5% 0.25W		NTR25J-E220E
15			RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E01K5
16	315-0151-00		RES.,FXD,CMPSN: 150 OHM,5%,0.25W	57668	NTR25J-E220E
	315-0152-00		RES EXD CMPSN 156 OHM, 5%, 0.25W	57668	NTR25J-E150E
17	315-0620-00		RES.,FXD,CMPSN:1.5K OHM,5%,0.25W	57668	NTR25J-E01K5
			RES.,FXD,CMPSN:62 OHM,5%,0.25W	01121	
8	315-0620-00			01121	CB6205
9			RES.,FXD,CMPSN:62 OHM,5%,0.25W		
21	315-0620-00		RES.,FXD,CMPSN:62 OHM,5%,0.25W	01121	CB6205
	315-0330-00		RES EXD CMPSN 22 OUM 250	01121	CB6205
2	315-0684-00		RES.,FXD,CMPSN:33 OHM,5%,0.25W	01121	CB3305
3	315-0474-00		HES., FXD, CMPSN: 680K OHM 5% 0.25W	01121	
9	315-0101-00		HES., FXD, CMPSN: 470K OHM 5% 0 25W		CB6845
	010-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E470K
1				57668	NTR25J-E 100E
1	315-0332-00		RES EVE CHECKLO AND A		
5	315-0104-00		RES.,FXD,CMPSN:3.3K OHM,5%,0.25W	57668	NTR25 EO2KO
6	315-0563-00		RES.,FXD,CMPSN:100K OHM 5% 0 25W		NTR25J-E03K3
7	315.0105.00		HES., FXD, CMPSN: 56K OHM. 5% 0.25W	57668	NTR25J-E100K
3	315-0105-00	1	RES.,FXD,CMPSN:1M OHM,5%,0.25W	01121	CB5635
	315-0100-00		BES EXD CMPSNI10 CUM Stars	01121	CB1055
)	315-0101-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W		NTR25J-E 10E0
	-	ł i	RES., FXD, CMPSN: 100 OHM, 5%, 0.25W	57668	NTR251 E toor
	315-0101-00			07000	NTR25J-E 100E
		F	RES.,FXD,CMPSN:100 OHM,5%,0.25W		
	315-0150-00	r.	RES FYD CMPSN 15 OUN COLOR	57668	NTR25J-E 100E
	315-0150-00		RES.,FXD,CMPSN:15 OHM,5%,0.25W	A 1 1 A 1	CB1505
	315-0101-00	F	ES.,FXD,CMPSN:15 OHM,5%,0.25W		CB1505
	315-0821-00	F	ES.,FXD,CMPSN:100 OHM.5% 0 25W		
		F	ES.,FXD,CMPSN:820 OHM,5%,0.25W		NTR25J-E 100E
	315-0220-00	R	ES.,FXD,CMPSN:22 OHM,5%,0.25W		NTR25J-E 820E
				01121	CB2205
	322-0178-00		ES.,FXD.FILM:698 OHM,1%,0.25W	01121	682205

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

REV DEC 1984

Ckt No.	Tektronix Part No.	Serial/Mod Eff	Dscont		Mfr	
			DSCONT	Name & Description	Code	Mfr Part Numbe
R748	315-0220-00					
R750	311-1192-00			RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
R750				RES., VAR, NONWIR: 10K OHM, 20%, 1W, W/SW	71590	
R752			(FURN AS A SET W/S750)	/1590	BA-232-001
R753	315-0122-00			RES.,FXD,CMPSN:1.2K OHM,5%,0.25W		
R754	315-0821-00		1	RES., FXD, CMPSN: 820 OHM, 5%, 0.25W	57668	LOUNT COUNT
n/34	311-1230-00		I	RES., VAR, NONWIR: 20K OHM, 20%, 0.50W	57668	
D365				2017 01 01 01 01 01 01 01 01 00 00 00 00 00	32997	3386F-T04-203
R755	315-0302-00		F	ES.,FXD,CMPSN:3K OHM,5%,0.25W		
R756	315-0131-00			ES. FXD CMPCN 480 O(M, 5%, 0.25W	57668	NTR25J-E03K0
R758	315-0152-00			ES.,FXD,CMPSN:130 OHM,5%,0.25W	01121	CB1315
R759	321-0259-00		г г	ES.,FXD,CMPSN:1.5K OHM,5%,0.25W	57668	NTR25J-E01K5
R761	315-0682-00		F -	ES.,FXD,FILM:4.87K OHM,1%,0.125W	91637	MFF1816G48700F
R762	315-0392-00		F	ES.,FXD.CMPSN:6.8K OHM,5%,0.25W	57668	
	010-0092-00		F	ES.,FXD,CMPSN:3.9K OHM,5%,0.25W	57668	NTR25J-E06K8
R763	215 0001 00				57000	NTR25J-E03K9
9764	315-0221-00		я	ES.,FXD,CMPSN:220 OHM,5%,0.25W	57000	
	315-0302-00		R	ES.,FXD,CMPSN:3K OHM,5%,0.25W	57668	NTR25J-E220E
765	315-0242-00		R	ES.,FXD,CMPSN:2.4K OHM,5%,0.25W	57668	NTR25J-E03K0
R766	315-0470-00		R	ES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E02K4
3767	311-1230-00				57668	NTR25J-E47E0
1769	321-0279-00		п р	ES., VAR, NONWIR: 20K OHM, 20%, 0.50W	32997	3386F-T04-203
			н	ES.,FXD,FILM:7.87K OHM,1%,0.125W	91637	MFF1816G78700F
8771	321-0082-00		_			
772	322-0283-00		RI	ES.,FXD,FILM:69.8 OHM,1%,0.125W	91637	MEEIRICOCODAL
773			RI	ES.,FXD,FILM:8.66K OHM,1%,0,25W		MFF1816G69R80F
774	321-0082-00		RE	S.,FXD,FILM:69.8 OHM,1%,0.125W	91637	MFF1421G86600F
775	321-0059-00		RE	S.,FXD,FILM:40.2 OHM,1%,0.125W	91637	MFF1816G69R80F
	321-0185-00		RE	S.,FXD,FILM:825 OHM,1%,0.125W	91637	MFF1816G40R20F
776	321-0047-00		BE	S.,FXD,FILM:30.1 OHM,1%,0.125W	91637	MFF1816G825R0F
				0.,1 XD,FILW.30.1 OHM,1%,0.125W	91637	MFF1816G30R10F
777	321-0224-00					
778	321-0044-00			S.,FXD,FILM:2.1K OHM,1%,0.125W	91637	MFF1816G21000F
781	321-0082-00		RE	S.,FXD,FILM:28 OHM,1%,0.125W	91637	MFF1816G28R00F
782	322-0283-00		RE	S., FXD, FILM: 69.8 OHM, 1%, 0.125W	91637	MEETBICOCODDO
783			RE	S.,FXD,FILM:8.66K OHM,1%,0.25W	91637	MFF1816G69R80F
784	321-0082-00		RE	S.,FXD,FILM:69.8 OHM,1%,0.125W		MFF1421G86600F
04	315-0242-00		RE	S.,FXD,CMPSN:2.4K OHM.5%,0.25W	91637	MFF1816G69R80F
				01101,5 %,0.25W	57668	NTR25J-E02K4
85	311-1228-00		BE	S.,VAR,NONWIR:10K OHM,20%,0.50W		
86	321-0044-00		RE	S.,FXD,FILM:28 OHM,1%,0.125W	32997	3386F-T04-103
87	321-0224-00		DE	S. FXD.FILMI.28 OHM, 1%, 0.125W	91637	MFF1816G28R00F
88	315-0472-00		nc.	5.,FXD,FILM:2.1K OHM,1%,0.125W	91637	MFF1816G21000F
89	315-0221-00		ME:	6., FXD, CMPSN: 4.7K OHM, 5%, 0.25W	57668	NTR25J-E04K7
92	315-0220-00		RES	6.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E220E
	070-0220-00		RES	5.,FXD,CMPSN:22 OHM,5%,0.25W	01121	
93	331 0000 00				01121	CB2205
94	321-0289-00		RES	FXD,FILM:10K OHM,1%,0.125W	04007	
	321-0260-00		RES	.,FXD,FILM:4.99K OHM,1%,0.125W	91637	MFF1816G10001F
95	321-0225-00		RES	FXD.FILM:2.15K OHM,1%,0.125W	91637	MFF1816G49900F
96	321-0227-00		RES	.,FXD,FILM:2.15K OHM,1%,0.125W	91637	MFF1816G21500F
97	315-0101-00		DEG	EXD CMRSN 100 CHM, 1%, U.125W	91637	MFF1816G22600F
98	321-0249-00		nco	.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
			RES	.,FXD,FILM:3.83K OHM,1%,0.125W	91637	MFF1816G38300F
9	315-0102-00					
11	315-0332-00		RES	FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25 IEA1MA
2			RES	.,FXD,CMPSN:3.3K OHM,5%,0,25W	57668	NTR25JE01K0
3	315-0221-00		RES	FXD,CMPSN:220 OHM,5%,0.25W		NTR25J-E03K3
	307-0103-00		RES	FXD,CMPSN:2.7 OHM,5%,0.25W	57668	NTR25J-E220E
4	321-0166-00		RES	FXD,FILM:523 OHM,1%,0.125W	01121	CB27G5
5	321-0193-00		REC	EXD EN MITK OHAN 100 C 1000	91637	MFF1816G523R0F
			1120.	FXD.FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
6	315-0681-00					
7	321-0254-00		HES.	FXD,CMPSN:680 OHM,5%,0.25W	57668	NTR25J-E680E
3	321-0250-00		RES.	FXD,FILM:4.32K OHM,1%,0.125W	91637	MFF1816G43200F
))			RES.	FXD,FILM:3.92K OHM,1%,0.125W		MEE19160000000
	315-0101-00		RES.	FXD,CMPSN:100 OHM,5%,0.25W	57660	MFF1816G39200F
)	315-0201-00		RES.	FXD,CMPSN:200 OHM,5%,0.25W	57668	NTR25J-E 100E
	315-0202-00		BES	FXD,CMPSN:2K OHM,5%,0.25W		NTR25J-E200E
2			neo.,	1 X0,000 510,2K OHM,5%,0.25W	57668	NTR25J-E02K0

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

.

	Tektronix	Serial/Model No.		Mfr	
Ckt No.	Part No.	Eff Dscont	Name & Description	Code	Mfr Part Number
2010	045 0454 00				
7813	315-0151-00		RES.,FXD,CMPSN:150 OHM,5%,0.25W	57668	NTR25J-E150E
814	315-0102-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
1815	321-0232-00		RES.,FXD,FILM:2.55K OHM,1%,0.125W	91637	MFF1816G25500F
8816	321-0155-00		RES.,FXD,FILM:402 OHM,1%,0.125W	91637	MFF1816G402R0F
817	315-0221-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E220E
818	321-0187-00		RES.,FXD,FILM:866 OHM,1%,0.125W	91637	MFF1816G866R0F
3819	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	
7821	315-0101-00				NTR25J-E 10E0
1822			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
	315-0471-00		RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E470E
1823	315-0331-00		RES.,FXD,CMPSN:330 OHM,5%,0.25W	57668	NTR25J-E330E
824	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
8825	307-0106-00		RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
826	307-0106-00		RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
1900	321-0225-00		RES., FXD, FILM: 2.15K OHM, 1%, 0.125W	91637	MFF1816G21500F
1901	315-0220-00	B020839	RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
1902	321-0155-00		RES.,FXD,FILM:402 OHM,1%,0.125W	91637	
1902	315-0221-00				MFF1816G402R0F
1903	315-0221-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W RES.,FXD,FILM:549 OHM,1%,0.125W	57668 91637	NTR25J-E220E MFF1816G549R0F
	52. 0100-00			31037	WEE TO LOGO4ARDE
1905	307-0106-00		RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
1906	321-0268-00		RES.,FXD,FILM:6.04K OHM,1%,0.125W	91637	MFF1816G60400F
1907	321-0289-00		RES.,FXD,FILM:10K OHM,1%,0.125W	91637	MFF1816G10001F
1908	321-0294-00		RES.,FXD.FILM:11.3K OHM,1%,0.125W	91637	CMF55116G11301F
1910	321-0220-00		RES.,FXD,FILM:1.91K OHM,1%,0.125W	91637	MFF1816G19100F
1911	321-0314-00		RES.,FXD,FILM:18.2K OHM,1%,0.125W	91637	MFF1816G18201F
010	004 0001 05				
912	321-0261-00		RES.,FXD,FILM:5.11K OHM,1%,0.125W	91637	MFF1816G51100F
1913	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
1916	308-0539-00		RES.,FXD,WW:2.25K OHM,0.5%,3W	91637	RS2BK22500D
917	315-0471-00		RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E470E
918	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
1920	317-0202-00	B023830	RES., FXD, CMPSN: 2K OHM, 5%, 0.125W	01121	BB2025
921	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
922	315-0471-00				
923			RES.,FXD,CMPSN:470 OHM,5%,0.25W	57668	NTR25J-E470E
	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
924	301-0682-00		RES.,FXD,CMPSN:6.8K OHM,5%,0.50W	57668	TR50J-E6K8
925	321-0218-00		RES.,FXD,FILM:1.82K OHM,1%,0.125W	91637	MFF1816G18200F
926	321-0193-00		RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
927	321-0238-00		RES.,FXD,FILM:2.94K OHM,1%,0.125W	91637	MFF1816G29400F
928	321-0193-00		RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
929	315-0123-00				
930	311-1458-00		RES.,FXD,CMPSN:12K OHM,5%,0.25W	57668	NTR25J-E12K0
			RES.,VAR,WW:50K OHM,5%	73138	7266-322-0
930			(SEE DM MANUAL FOR ALTERNATE VERSION)		
930	311-1709-00		RES.,VAR,WW:PNL,20K OHM,2W	32997	35415-461-203
931	315-0392-00		RES.,FXD,CMPSN:3.9K OHM,5%,0.25W	57668	NTR25J-E03K9
932	315-0102-00		RES., FXD, CMPSN: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
933	321-0338-00		RES., FXD, FILM: 32.4K OHM, 1%, 0.125W	91637	MFF1816G32401F
34	321-0193-00		RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
035	321-0274-00		RES.,FXD,FILM:1K 0HM,1%,0.125W	91637	CMF55116G69800F
36	311-1226-00		RES., FXD, FILM:0.96K OHM, 1%,0.125W RES., VAR, NONWIR:2.5K OHM, 20%,0.50W	32997	3386F-T04-252
937	321-0196-00		RES.,FXD,FILM:1.07K OHM,1%,0.125W	91637	MFF1816G10700F
938	311-1225-00		RES.,VAR,NONWIR:1K OHM,20%,0.50W	32997	3386F-T04-102
939	321-0258-00		RES.,FXD,FILM:4.75K OHM,1%,0.125W	91637	MFF1816G47500F
940	315-0153-00		RES.,FXD,CMPSN:15K OHM,5%,0.25W	01121	CB1535
941	321-0193-00		RES., FXD, FILM: 1K OHM, 1%, 0.125W	01121	ORD BY DESCR
42	321-0145-00		RES.,FXD,FILM:316 OHM,1%,0.125W	91637	MFF1816G316R0F
10	004 0/20 00				
943	321-0152-00		RES.,FXD,FILM:374 OHM,1%,0.125W	91637	MFF1816G374R0F

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351654 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

	Tektronix	Serial/Model No.		Mfr	
Ckt No.	Part No.	Eff Dscont	Name & Description	Code	Mfr Part Number
	· · · · · · · · · · · · · · · · · · ·	······································			
R944	321-0231-00		RES.,FXD,FILM:2.49K OHM,1%,0.125W	91637	MFF1816G24900F
R946	321-0216-00		RES.,FXD,FILM:1.74K OHM,1%,0.125W	91637	MFF1816G17400F
R947	315-0220-00		RES. FXD.CMPSN:22 OHM.5%.0.25W	01121	CB2205
R948	321-0239-00		RES., FXD, FILM: 3.01K OHM, 1%, 0.125W	91637	MFF1816G30100F
R949	321-0260-00		RES., FXD, FILM: 4.99K OHM, 1%, 0.125W	91637	MFF1816G49900F
R950	311-1222-00		RES.,VAR,NONWIR:100 OHM,20%.0.50W	32997	3386F-T04-101
				02007	
R951	321-0183-00		RES.,FXD,FILM:787 OHM,1%,0.125W	91637	MFF1816G787R0F
R952	321-0198-00		RES., FXD, FILM: 1.13K OHM, 1%, 0.125W	91637	MFF1816G11300F
R955	315-0272-00		RES., FXD, CMPSN: 2.7K OHM, 5%, 0.25W	57668	NTR25J-E02K7
R956	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
R961	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R963	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R965	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R967	307-0106-00		RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
R969	307-0106-00		RES.,FXD,CMPSN:4.7 OHM,5%,0.25W	01121	CB47G5
R971	315-0472-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W	57668	NTR25J-E04K7
R972	321-0287-00		RES.,FXD,FILM:9.53K OHM,1%,0.125W	91637	MFF1816G95300F
R973	321-0155-00		RES.,FXD,FILM:402 OHM,1%,0.125W	91637	MFF1816G402R0F
R974	321-0268-00		RES.,FXD,FILM:6.04K OHM,1%,0.125W	91637	MFF1816G60400F
R975	321-0354-00		RES.,FXD,FILM:47.5K OHM,1%,0.125W	91637	CMF55116G47501F
R976	315-0562-00		RES.,FXD,CMPSN:5.6K OHM,5%,0.25W	57668	NTR25J-E05K6
R981	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
R982	315-0101-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R985	301-0622-00		RES.,FXD,CMPSN:6.2K OHM,5%,0.50W	01121	EB6225
R986	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
R987	315-0332-00		RES.,FXD,CMPSN: 10K OHM,5%,0.25W	57668	NTR25J-E03K3
R988	315-0680-00		RES.,FXD,CMPSN:68 OHM,5%,0.25W	57668	NTR25J-E68E0
R994	321-0225-00		RES.,FXD,FILM:2.15K OHM,1%,0.125W	91637	MFF1816G21500F
R995	321-0155-00		RES.,FXD,FILM:402 OHM,1%,0.125W	91637	MFF1816G402R0F
R996	315-0221-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E220E
1000	010-0221-00			0,000	
R1001	315-0392-00		RES.,FXD,CMPSN:3.9K OHM,5%,0.25W	57668	NTR25J-E03K9
R1002	315-0332-00		RES.,FXD,CMPSN:3.3K OHM,5%,0.25W	57668	NTR25J-E03K3
R1004	321-0268-00		RES.,FXD,FILM 6.04K OHM,1%,0.125W	91637	MFF1816G60400F
R1005	321-0354-00		RES.,FXD,FILM:47.5K OHM,1%,0.125W	91637	CMF55116G47501F
R1006	321-0287-00		RES.,FXD,FILM:9.53K OHM,1%,0.125W	91637	MFF1816G95300F
R1007	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CB2205
R1010	321-0414-00		RES.,FXD,FILM:200K OHM,1%,0.125W	91637	MFF1816G20002F
R1011	315-0182-00		RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
R1012			(SELECTED, ADDED IF NECESSARY)		
R1015	301-0682-00		RES.,FXD,CMPSN:6.8K OHM,5%,0.50W	57668	TR50J-E6K8
R1016	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
R1017	315-0332-00		RES.,FXD,CMPSN:3.3K OHM,5%,0.25W	57668	NTR25J-E03K3
				04404	000005
R1018	315-0330-00		RES.,FXD,CMPSN:33 OHM,5%,0.25W	01121	CB3305
R1022	315-0153-00		RES.,FXD,CMPSN:15K OHM,5%,0.25W	01121	CB1535
R1023	321-0185-00		RES.,FXD,FILM:825 OHM,1%,0.125W	91637	MFF1816G825R0F
R1024	321-0197-00		RES.,FXD,FILM:1.1K OHM,1%,0.125W	91637 57668	MFF1816G11000F NTR25J-E10K0
R1028	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E02K7
R1029	315-0272-00		RES.,FXD,CMPSN:2.7K OHM,5%,0.25W	57000	1111 LOU-LUEINI
B1021	221 0102 00		RES.,FXD.FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
R1031	321-0193-00		RES.,FXD,FILM:1K OHM,1%,0.125W RES.,FXD,FILM:316 OHM,1%,0.125W	91637	MFF1816G316R0F
R1032 R1033	321-0145-00 321-0149-00		RES.,FXD,FILM:318 OHM,1%,0.125W	91637	MFF1816G348R0F
R1035	321-0222-00		RES.,FXD,FILM:2K OHM,1%,0.125W	91637	MFF1816G20000F
R1042	321-0228-00		RES.,FXD,FILM:1.43K OHM,1%,0.125W	91637	MFF1816G14300F
R1042	315-0220-00		RES.,FXD,CMPSN:22 OHM,5%.0.25W	01121	CB2205
	U.U 0110-00				
R1046	321-0239-00		RES.,FXD,FILM:3.01K OHM,1%,0.125W	91637	MFF1816G30100F

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4 QY Tel: 01844-351694 Fax- 01844-352554 Email: enquiries@mauritron.co.uk

Ckt No. R1047 R1049 R1050 R1051	Part No. 321-0260-00	Serial/Model No. Eff Dscon	t Name & Description	Mfr		
R1049 R1050 R1051	321-0260-00		Name & Description			
R1049 R1050 R1051	321-0260-00			Cod	• • • · ·	
R1050 R1051				Cod	e Mfr Part Number	
R1051	315-0102-00		RES.,FXD,FILM:4.99K OHM,1%,0.125W			
	315-0220-00		RES.,FXD,CMPSN:1K OHM 5% 0.25W	9163	7 MFF1816G49900F	
— · — · — ·	315-0101-00		TES., FAD, CMPSN:22 OHM 5% 0.25W	5766	8 NTR25JE01K0	
R1052	315-0563-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W	0112	1 CB2205	
R1053	315-0432-00		RES.,FXD,CMPSN:56K OHM,5%,0.25W	57668	3 NTR25J-E 100E	
	0,0-0402-00		RES.,FXD,CMPSN:4.3K OHM,5%,0.25W	01121	CB5635	
R1056	321-0352-00		011 1.51 Of 101,5%,0.25W	57668		
R1057			RES.,FXD,FILM:45.3K OHM,1%,0.125W		200 2041(3	
R1058	315-0204-00		RES.,FXD,CMPSN:200K OHM.5%,0.25W	91637	MFF1816G45301F	
R1059	315-0105-00		RES.,FXD,CMPSN:1M OHM,5%,0.25W	01121	CB2045	
R1060	315-0103-00		RES.,FXD,CMPSN:10K OHM,5%,0.25W	01121		
R1061	315-0561-00		BES EXD CMBSN 500 CHM,5%,0.25W	57668		
	315-0102-00		RES.,FXD,CMPSN:560 OHM,5%,0.25W	01121	CB5615	
R1062			RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0	
R1064	315-0472-00		RES EVD CHIDON A THE		WH25JEUTKU	
R1064	315-0472-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W	57668	NTROST	
-	315-0432-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W	57668	NTR25J-E04K7	
R1067	315-0133-00		RES.,FXD,CMPSN:4.3K OHM,5%,0.25W	57668	NTR25J-E04K7	
R1070	311-1702-00		DES., FXD, CMPSN: 13K OHM 5% 0.25M	01121	NTR25J-E04K3	
R1070			HES., VAR, NONWIR: 20K OHM 20% 1W		CB1335	
_			(FURN AS A SET W/S1070)	01121	13M214	
R1071	321-0472-04					
R1072	321-0481-04		RES.,FXD,FILM:806K OHM,0.1%,0.125W	0		
R1073	321-0976-04		HES., FXD, FILM: 1M OHM 0 1% 0 125W	91637	CMF55116D80602B	
R1074	321-0431-04		RES.,FXD,FILM:602 OHM.0.1% 0 125W	91637	CMF55116D10003B	
R1075	311-1246-00		HES., FXD, FILM: 301K OHM 0 1% 0 125W	91637	HFF188D60202B	
R1076	321-0973-04		HES., VAR, NONWIR: 50K OHM 10% 0 50W	91637	MFF1816D30102B	
			RES.,FXD,FILM:60.2K OHM,0.1%,0.125W	02111	E4A503	
R1077	321-0977-04			91637	MFF1816D60201B	
R1078	321-0973-04		RES.,FXD,FILM:120.4K OHM,0.1%,0.125W			
R1079	321-0973-04		RES.,FXD,FILM:60.2K OHM,0.1%,0.125W	91637	MFF1816D12042B	
R1081	315-0101-00		RES.,FXD,FILM:60.2K OHM,0.1%,0.125W	91637	MFF1816D60201B	
R1082	321-0973-04		RES.,FXD,CMPSN:100 OHM,5%,0.25W	91637	MFF1816D60201B	
R1083			RES.,FXD,FILM:60.2K OHM,0.1%,0.125W	57668	NTR25J-E 100E	
	321-0472-04		RES.,FXD,FILM:806K OHM,0.1%,0.125W	91637	MFF1816D60201B	1
R1084	321-0481-04		1.0000K OHM,0.1%,0.125W	91637	CMF55116D80602B	
R1085	321-0976-04		RES.,FXD,FILM:1M OHM,0.1%,0.125W			
R1086	321-0431-04		RES.,FXD,FILM:602 OHM,0.1%,0.125W	91637	CMF55116D10003B	
R1087	321-0431-04		RES.,FXD,FILM:301K OHM,0.1%,0.125W	91637	HFF188D60202B	
R1088	321-0975-04		RES.,FXD,FILM:180.6K OHM,0.1%,0.125W	91637	MFF1816D30102B	
R1089	321-0973-04		RES.,FXD,FILM:60.2K OHM,0.1%,0.125W	91637	MFF1816D18062B	
	321-0973-04		BES FXD FILM:50.2K OHM.0.1%,0.125W	91637	MFF1816D60201B	
R1090	045 0450		RES.,FXD,FILM:60.2K OHM,0.1%,0.125W	916 37	MFF1816D60201B	
R1091	315-0472-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W		1010201B	
R1092	315-0105-00		RES.,FXD,CMPSN:1M OHM,5%,0.25W	57668	NTR25J-E04K7	
R1093	315-0154-00		BES EXD CMPSN IM UHM,5%,0.25W	01121	CB1055	
R1094	315-0101-00		RES.,FXD,CMPSN:150K OHM,5%,0.25W	57668	NTR25J-E150K	
	321-0164-00		RES.,FXD,CMPSN:100 OHM,5%,0.25W		NTR25J-E 100E	
R1095	321-0274-00		RES.,FXD,FILM:499 OHM,1%,0.125W	91637	MFF1816G499R0F	
R1000	•		RES.,FXD,FILM:6.98K OHM,1%,0.125W		CMF55116G69800F	
R1096	315-0220-00			0,001	CMF35116G69800F	
R1098	315-0511-00		RES.,FXD,CMPSN:22 OHM,5%,0.25W	01121	CRAAS	
R1099	315-0242-00		RES.,FXD,CMPSN:510 OHM,5%,0.25W		CB2205	
R1101	321-0068-00		HES., FXD, CMPSN: 2.4K OHM 5% 0.25W		CB5115	
R1102	311-1223-00		HES., FXD, FILM: 49.9 OHM 1% 0 125W		NTR25J-E02K4	
R1103	315-0272-00		RES., VAR, NONWIR: TRMR. 250 OHM 0 5W		MFF1816G49R90F	
			RES.,FXD,CMPSN:2.7K OHM,5%,0.25W		72-5-0	
R1104	315-0103-00			57668 1	NTR25J-E02K7	
R1105	315-0510-00	i	RES.,FXD,CMPSN:10K OHM,5%,0.25W	5300-		
R1106	321-0118-04		HES., FXD, CMPSN:51 OHM 5% 0.25W	57668 N	NTR25J-E10K0	
R1107	321-0738-04		HES., FXD, FILM: 165 OHM.0 1% 0 125W	57668 N	VTR25J-E51E0	
R1108	321-0118-04	,	1ES.,FXD,FILM: 1.485K OHM 0.1% 0.125W	91637 N	MFF1816D165R0B	
R1109	315-0154-00	r	150.,FXU,FILM:165 OHM 0 1% 0 125W	91637 C	MF55116D14850B	
		F	RES.,FXD,CMPSN:150K OHM,5%,0.25W	91637 N	IFF1816D165R0B	
81110	315-0105-00				ITR25J-E150K	
		F	RES.,FXD,CMPSN:1M OHM,5%,0.25W			
				01121 C	B1055	

7-36

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel: 01844-351634 Fax: 01844-35255 Email: enguines@mauritron.co.ui

	Tektronix	Serial/Mo	odel No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
					0000	Mill Fall Number
R1111	315-0201-00			RES.,FXD,CMPSN:200 OHM,5%,0.25W	53000	
R1112	315-0100-00			RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E200E
R1112				(USED AT LOCATION R1112A)	57668	NTR25J-E 10E0
R1112	321-0212-00			RES.,FXD,FILM:1.58K OHM,1%,0.125W		
R1112					91637	MFF1816G15800F
R1113	315-0100-00			(USED AT LOCATION R1112B)		
				RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R1113						
R1113	321-0300-00			(USED AT LOCATION R1113A)		
R1113				RES.,FXD,FILM:13K OHM,1%,0.125W	91637	MFF1816G13001F
R1114	321-0126-00			(USED AT LOCATION R1113B)		
R1116	315-0182-00			RES.,FXD,FILM:200 OHM,1%,0.125W	91637	MFF1816G200R0F
R1117				RES.,FXD,CMPSN:1.8K OHM,5%,0.25W	57668	NTR25J-E1K8
	315-0303-00			RES.,FXD,CMPSN:30K OHM,5%,0.25W	01121	CB3035
R1118	215 0151 00					
	315-0151-00			RES.,FXD,CMPSN:150 OHM.5%,0.25W	57668	NTR25J-E150E
R1119	311-1411-00			RES., VAR, NONWIR: 1K OHM X 10K OHM, 20%, 0.50W	01121	18M654
R1120	315-0433-00			RES.,FXD,CMPSN:43K OHM,5%,0.25W	57668	NTR25J-E043K
R1120	******			(ADDED IF NECESSARY)		
R1124	315-0361-00			RES.,FXD,CMPSN:360 OHM,5%,0.25W	01121	CB3615
R1125	321-0134-00			RES.,FXD,FILM:243 OHM,1%,0.125W	91637	MFF1816G243R0F
				• • • •	2.00	
R1126	321-0108-00			RES.,FXD,FILM:130 OHM,1%,0.125W	91637	MFF1816G130R0F
R1128	321-0045-00			RES., FXD, FILM: 28.7 OHM, 1%, 0.125W	91637	MFF1816G28R70F
R1130	311-1230-00			RES., VAR, NONWIR: 20K OHM, 20%, 0.50W	32997	3386F-T04-203
R1131	315-0273-00			RES.,FXD,CMPSN:27K OHM,5%,0.25W	57668	
R1132	315-0151-00			RES.,FXD,CMPSN:150 OHM,5%,0.25W		NTR25J-E27K0
71133	321-0193-07	B010100	B011629	RES.,FXD,FILM:1K OHM.0.1%,0.125W	57668	NTR25J-E150E
		20.0.00	2011025	NES., ND, NEM. IN ORM, 0.1%, 0.125W	91637	MFF1816C10000B
31133				(SEE DM MANUAL FOR ALTERNATE VERSION)		
31133	321-0928-07	B011630				
31133		5011050		RES.,FXD,FILM:250 OHM,0.1%,0.125W	91637	MFF1816C250R0B
31134	315-0431-00			(SEE DM MANUAL FOR ALTERNATE VERSION)		
31135	321-0134-00			RES.,FXD,CMPSN:430 OHM,5%,0.25W	01121	CB4315
R1136	321-0222-07	B010100	0044600	RES.,FXD,FILM:243 OHM,1%,0.125W	91637	MFF1816G243R0F
	521-0222-07	B010100	B011629	RES.,FXD,FILM:2K OHM,0.1%,0.125W	91637	CMF55116C20000B
31136						
31136		D011000		(SEE DM MNAUAL FOR ALTERNATE VERSION)		
1136	321-0612-07	B011630		RES.,FXD,FILM:500 OHM,0.1%,0.125W	91637	MFF1816C500R0B
1137		D040400		(SEE DM MANUAL FOR ALTERNATE VERSION)		
	321-0193-07	B010100	B011629	RES.,FXD,FILM:1K OHM,0.1%,0.125W	91637	MFF1816C10000B
11137				(SEE DM MANUAL FOR ALTERNATE VERSION)		
11137	321-0928-07	B011630		RES.,FXD,FILM:250 OHM,0.1%,0.125W	91637	MFF1816C250R0B
11137				(SEE DM MANUAL FOR ALTERNATE VERSION)		
1138	321-0045-00			RES.,FXD,FILM:28.7 OHM,1%,0.125W	91637	MFF1816G28R70F
1140	321-0097-00			RES.,FXD,FILM:100 OHM,1%,0.125W	91637	MFF1816G100R0F
1141	321-0193-00	B010100	B014658	RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
1141	321-0201-00	B014659		RES.,FXD,FILM:1.21K OHM,1%,0.125W	91637	MFF1816G12100F
1142	321-0164-00			RES.,FXD,FILM:499 OHM,1%,0.125W	91637	MFF1816G499R0F
					0.007	10111011004001101
1152	315-0121-00			RES.,FXD,CMPSN:120 OHM,5%,0.25W	01121	CB1215
1153	321-0147-00			RES.,FXD,FILM:332 OHM,1%,0.125W	91637	
1154	321-0106-00			RES.,FXD,FILM:124 OHM,1%,0.125W		MFF1816G332R0F
1155	311-1258-00			RES.,VAR,NONWIR:50 OHM,10%,0.50W	91637 32007	MFF1816G124R0F
1156	321-0159-00				32997	3329P-L58-500
1159	321-0159-00			RES.,FXD,FILM:442 OHM,1%,0.125W	91637	MFF1816G442R0F
	021-0700-00			RES.,FXD,FILM:442 OHM,1%,0.125W	91637	MFF1816G442R0F
1162	315-0121-00			REC. EVD. CMRCN.400. OUNLESS & COM		00/0/-
1163				RES.,FXD,CMPSN:120 OHM,5%,0.25W	01121	CB1215
	321-0147-00			RES.,FXD,FILM:332 OHM,1%,0.125W	91637	MFF1816G332R0F
1164	315-0223-00			RES.,FXD,CMPSN:22K OHM,5%,0.25W	57668	NTR25J-E 22K
1165	321-0193-00			RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
1100	315-0513-00			RES.,FXD,CMPSN:51K OHM,5%,0.25W	57668	NTR25J-E51K0
1166						
1166 1167	321-0193-00			RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR
				RES.,FXD,FILM:1K OHM,1%,0.125W	01121	ORD BY DESCR

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Charry Tree Rc. Channor Charl 2019 400 T 199343:162 Fear 01844-35554 - - enquires@mauntron.c.u.

	Tektronix	Serial/Model No.			
Ckt No.	Part No.			Mfr	
		EffDscont	Name & Description	Code	Mfr Part Number
R1169					in rait Number
R1172	315-0161-00		RES.,FXD,CMPSN:160 OHM,5%,0.25W	57660	
	321-0157-00		RES.,FXD,FILM:422 OHM,1%,0.125W	57668	NTR25J-E 160E
R1173	321-0157-00		RES.,FXD,FILM:422 OHM,1%,0.125W	91637	MFF1816G422R0F
R1174	315-0751-00		RES.,FXD,CMPSN:750 OHM,5%,0.25W	91637	MFF1816G422R0F
R1175	311-1258-00		RES., VAR, NONWIR:50 OHM, 10%, 0.50W	57668	NTR25J-E750E
R1182	321-0145-00		RES.,FXD,FILM:316 OHM,1%,0.125W	32997	3329P-L58-500
			1204, 10, 121, 10, 10, 01, 10, 01, 12, 544	91637	MFF1816G316R0F
R1183	321-0131-00		RES.,FXD,FILM:226 OHM,1%,0.125W		
R1184	315-0751-00		RES.,FXD,CMPSN:750 OHM,5%,0.25W	91637	MFF1816G226R0F
R1185	311-1258-00		RES.,VAR,NONWIR:50 OHM,10%,0.50W	57668	NTR25J-E750E
R1186	321-0182-00		RES.,FXD,FILM:768 OHM,1%,0.125W	32997	3329P-L58-500
R1187	321-0162-00		RES. EXD 511 M 475 OLIM 491 0 105W	91637	MFF1816G768R0F
R1188	321-0114-00		RES.,FXD,FILM:475 OHM,1%,0.125W	91637	MFF1816G475R0F
			RES.,FXD,FILM:150 OHM,1%,0.125W	91637	MFF1816G150R0F
R1189	315-0102-00				
R1201	315-0102-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1202	321-0218-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1203	321-0234-00		RES.,FXD,FILM:1.82K OHM,1%,0.125W	91637	MFF1816G18200F
R1204	321-0213-00		RES.,FXD,FILM:2.67K OHM,1%,0.125W	91637	MFF1816G26700F
R1209	321-0121-00		RES.,FXD,FILM:1.62K OHM,1%,0.125W	91637	MFF1816G16200F
	321-0121-00		RES.,FXD,FILM:178 OHM,1%.0.125W	91637	
R1211	215 0100 00			0.007	MFF1816G178R0F
R1212	315-0102-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTROSICONICO
R1216	321-0218-00		RES.,FXD,FILM:1.82K OHM,1%,0.125W	91637	NTR25JE01K0
R1232	321-0153-00		RES., FXD, FILM: 383 OHM, 1%, 0.125W		MFF1816G18200F
	317-0621-00		RES.,FXD,CMPSN:620 OHM,5%,0.125W	91637	MFF1816G383R0F
R1233	321-0260-00		RES.,FXD,FILM:4.99K OHM,1%,0.125W	01121	BB6215
R1234	315-0100-00		RES.,FXD,CMPSN:10 OHM,5%,0.25W	91637	MFF1816G49900F
Diese				57668	NTR25J-E 10E0
R1235	321-0385-00		RES.,FXD,FILM:100K OHM,1%,0.125W		
R1237	321-0193-00		RES.,FXD,FILM:1K OHM,1%,0.125W	91637	MFF1816G10002F
R1239	321-0365-00		RES.,FXD,FILM:61.9K OHM,1%,0.125W	01121	ORD BY DESCR
R1252	317-0621-00		RES. EXD. CMRSN: 620. OLIM. 5%, 0.125W	91637	MFF1816G61901F
R1253	321-0260-00		RES.,FXD,CMPSN:620 OHM,5%,0.125W	01121	BB6215
R1254	315-0100-00		RES.,FXD,FILM:4.99K OHM,1%,0.125W	91637	MFF1816G49900F
			RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R1255	321-0385-00		REC. EVO EN MILLONG DUNI		
R1256	311-1230-00		RES.,FXD,FILM:100K OHM.1%,0.125W	91637	MFF1816G10002F
R1257	321-0385-00		RES. VAR, NONWIR: 20K OHM, 20%, 0.50W	32997	3386F-T04-203
R1258	321-0202-00		RES.,FXD,FILM:100K OHM,1%,0.125W	91637	MFF1816G10002F
R1259	321-0287-00		RES.,FXD,FILM:1.24K OHM,1%,0.125W	91637	MFF1816G12400F
R1267	315-0101-00		RES., FXD, FILM: 9.53K OHM, 1%, 0.125W	91637	MFF1816G95300F
			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R1268	315-0473-00				
R1302	315-0203-00		RES.,FXD,CMPSN:47K OHM,5%,0.25W	57668	NTR25J-E47K0
R1303	307-0290-03		RES.,FXD,CMPSN:20K OHM,5%,0.25W	57668	NTR25J-E20K0
R1304	315-0244-00	1	RES.,FXD,FILM:500K OHM	80009	307-0290-03
R1305		I	RES., FXD, CMPSN: 240K OHM, 5%, 0, 25W	01121	
R1306	315-0822-00	ŀ	RES.,FXD,CMPSN:8.2K OHM,5%,0,25W	01121	CB2445
	315-0123-00	F	RES., FXD, CMPSN: 12K OHM, 5%, 0.25W	57668	CB8225
R1307	045 0000 00			57666	NTR25J-E12K0
R1308	315-0683-00	F	RES.,FXD,CMPSN:68K OHM,5%,0.25W	57660	
	315-0102-00	F	RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25J-E68K0
R1310	315-0392-00	F	ES.,FXD,CMPSN:3.9K OHM,5%,0.25W		NTR25JE01K0
R1312	315-0242-00	F	ES.,FXD,CMPSN:2.4K OHM,5%,0.25W		NTR25J-E03K9
R1313	321-0327-00	F	IES.,FXD,FILM:24.9K OHM,1%,0.125W		NTR25J-E02K4
R1314	315-0103-00	R	ES.,FXD,CMPSN:10K OHM,5%,0.25W		MFF1816G24901F
-			2011 XB, 0111 814: 1010 01101, 3 %, 0.25W	57668	NTR25J-E10K0
R1315	315-0473-00	B	ES.,FXD,CMPSN:47K OHM,5%,0.25W		
R1316	315-0472-00	B	ES. EXD CMPSN:47K OHM,5%,0.25W	57668	NTR25J-E47K0
R1317	321-0329-00	n 9	ES. FXD,CMPSN:4.7K OHM,5%,0.25W		NTR25J-E04K7
R1322	315-0103-00	n	ES.,FXD,FILM:26.1K OHM,1%,0.125W		MFF1816G26101F
R1326	315-0394-00	n	ES.,FXD,CMPSN:10K OHM,5%,0.25W		NTR25J-E10K0
R1328	321-0157-00	H T	ES.,FXD,CMPSN:390K OHM,5%,0.25W		TR25J-E390K
		H	ES.,FXD,FILM:422 OHM,1%,0.125W		MFF1816G422R0F
R1329	315-0106-00	-			
		H.	ES.,FXD,CMPSN:10M OHM,5%,0.25W	01121 (CB1065

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email- enginee@maurikon.es.uk

REV DEC 1984

	Tektronix	Serial/Mo	del No.		Mfr	
 Ckt No. 	Part No.	Eff	Dscont	Name & Description	Code	Mfr. David Microsoft and
					00e	Mfr Part Number
R1330	315-0182-00			RES.,FXD,CMPSN:1.8K OHM,5%,0.25W		
R1331	301-0153-00			RES.,FXD,CMPSN:15K OHM,5%,0.25W	57668	NTR25J-E1K8
R1333	315-0221-00				57668	TR50J-E 15K
R1335	311-1533-00			RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E220E
R1336	321-0206-00			RES., VAR, NONWIR:5K OHM X 2.5M OHM, 10%	32997	81C2D-E20-BA0002
R1337	321-0206-00			RES.,FXD,FILM:1.37K OHM,1%,0.125W	91637	MFF1816G13700F
111007	321-0200-00			RES.,FXD,FILM:1.37K OHM,1%,0.125W	91637	MFF1816G13700F
R1339	321-0174-00			RES.,FXD,FILM:634 OHM,1%,0.125W	01007	
R1340	321-0120-00			RES.,FXD,FILM:174 OHM,1%,0.125W	91637	MFF1816G634R0F
R1341	322-0197-00			RES.,FXD,FILM:1.1K OHM,1%,0.25W	91637	MFF1816G174R0F
R1342	315-0331-00			RES.,FXD,CMPSN:330 OHM,5%,0.25W	91637	MFF1421G11000F
R1343	321-0322-00			RES.,FXD,FILM:22.1K OHM,1%0.125W	57668	NTR25J-E330E
R1344	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	91637	MFF1816G22101F
	010 0102-00			HES., FXD, GMFSN. IK UHM, 5%, U.25W	57668	NTR25JE01K0
R1345	315-0201-00			RES.,FXD,CMPSN:200 OHM,5%,0.25W	57668	NTR25J-E200E
R1346	315-0682-00			RES.,FXD,CMPSN:6.8K OHM,5%.0.25W	57668	
R1352	315-0911-00	B010100	B015902	RES.,FXD,CMPSN:910 OHM,5%,0.25W	57668	NTR25J-E06K8
R1354	301-0752-00		2010002	RES.,FXD,CMPSN:7.5K OHM,5%,0.50W		NTR25J-E910E
R1355	302-0273-00			RES.,FXD,CMPSN:27K OHM,10%,0.50W	57668	TR50J-E7K5
R1356	301-0752-00			RES.,FXD,CMPSN:7.5K OHM,5%,0.50W	01121	EB2731
				1125.,1 XD,001 314.7.5K 01101,5%,0.30W	57668	TR50J-E7K5
R1358	315-0241-00			RES.,FXD,CMPSN:240 OHM,5%,0.25W	01121	CB2415
R1362	315-0332-00			RES.,FXD,CMPSN:3.3K OHM,5%,0.25W	57668	NTR25J-E03K3
R1363	315-0332-00			RES.,FXD,CMPSN:3.3K OHM,5%,0.25W	57668	NTR25J-E03K3
R1364	315-0470-00			RES.,FXD,CMPSN:47 OHM,5%,0.25W		
R1368	315-0271-00			RES.,FXD,CMPSN:270 OHM,5%,0.25W	57668	NTR25J-E47E0
R1369	323-0307-00			RES.,FXD,FILM:15.4K OHM,1%,0.50W	01121	CB2715
				120.1 XD,1 12141. 13.4K ONN, 178,0.30W	75042	CECT0-1542F
R1371	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1372	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1373	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1375	311-1231-00			RES.,VAR,NONWIR:25K OHM,20%,0.50W	32997	
R1376	315-0103-00			RES.,FXD,CMPSN:10K OHM,5%,0.25W		3386F-T04-253
R1378	315-0226-00			RES.,FXD,CMPSN:22M OHM,5%,0.25W	57668 01121	NTR25J-E10K0 CB2265
					01121	082203
R1379	315-0103-00			RES.,FXD,CMPSN:10K OHM,5%,0.25W	57668	NTR25J-E10K0
R1380	311-0075-00			RES., VAR, NONWIR:5M OHM, 20%	12697	381-CM16993
R1384	302-0121-00			RES., FXD, CMPSN: 120 OHM, 10%, 0.50W	01121	EB1211
R1385	311-1227-00			RES., VAR, NONWIR: 5K OHM, 20%, 0.50W	32997	3386F-T04-502
R1386	311-1373-00			RES., VAR, NONWIR: 5K OHM, 20%, 1W	01121	73U4G040L502M
R1390	311-1235-00			RES., VAR, NONWIR: 100K OHM, 20%, 0.50W	32997	3386F-T04-104
				-		
R1391	315-0470-00			RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
R1393	321-0231-00			RES.,FXD,FILM:2.49K OHM,1%,0.125W	91637	MFF1816G24900F
R1394	321-0248-00			RES.,FXD,FILM:3.74K OHM,1%,0.125W	91637	MFF1816G37400F
R1395	311-1226-00			RES., VAR, NONWIR: 2.5K OHM, 20%, 0.50W	32997	3386F-T04-252
R1396	315-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R1397	311-1372-00			RES.,VAR,NONWIR:100K OHM,20%,1W	01121	73M1G040L104M
R1398	315-0100-00					
R1399	315-0470-00			RES.,FXD,CMPSN:10 OHM,5%,0.25W	57668	NTR25J-E 10E0
R1416				RES.,FXD,CMPSN:47 OHM,5%,0.25W	57668	NTR25J-E47E0
R1410	323-0265-00			RES.,FXD,FILM:5.62K OHM,1%,0.50W	75042	CECT0-5621F
	321-0282-00			RES.,FXD,FILM:8.45K OHM,1%,0.125W	91637	MFF1816G84500F
R1418 R1422	315-0181-00			RES.,FXD,CMPSN:180 OHM,5%,0.25W	57668	NTR25J-E180E
111722	315-0682-00			RES.,FXD,CMPSN:6.8K OHM,5%,0.25W	57668	NTR25J-E06K8
R1423	303-0822-00			DES EYD CMDSNIP OK OLIM EN AM	A1104	000005
R1424	315-0122-00			RES.,FXD,CMPSN:8.2K OHM,5%,1W	01121	GB8225
R1425	315-0563-00			RES.,FXD,CMPSN:1.2K OHM,5%,0.25W	57668	NTR25J-E01K2
R1425				RES.,FXD,CMPSN:56K OHM,5%,0.25W	01121	CB5635
R1420	307-0052-00			RES.,FXD,CMPSN:3 OHM,5%,0.50W	01121	EB30G5
R1430	311-1226-00			RES.,VAR,NONWIR:2.5K OHM,20%,0.50W	32997	3386F-T04-252
	321-0351-00			RES.,FXD,FILM:44.2K OHM,1%,0.125W	91637	MFF1816G44201F
R1432	321-0284-00				01627	MEE10100007007
	02.0204-00			RES.,FXD,FILM:8.87K OHM,1%,0.125W	91637	MFF1816G88700F

. ...

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4OY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

0.4.1	Tektronix	Serial/Model N	lo.		
Ckt No.	Part No.		Soon!	Mfr	
			Name & Description	Cod	
R1444	321-0761-03			000	e Mfr Part Number
R1445	321-0684-00		RES.,FXD,FILM:35K OHM.0.25%,0.125W		
R1446	315-0471-00		RES.,FXD,FILM: 15K OHM,0.5%,0.125W	9163	7 MFF1816D35001C
R1447	315 0000 00		RES.,FXD,CMPSN:470 OHM,5%,0.25W	9163	7 MFF1816D15001D
R1448	315-0622-00		RES.,FXD,CMPSN:6.2K OHM,5%,0.25W	5766	8 NTR25J-E470E
R1454	308-0245-00		BES EXD WIMO COULD THE SW,0.25W	0112	1 CB6225
m1434	321-0775-03		RES.,FXD,WW:0.6 OHM.5%,2W	9163	
			RES.,FXD,FILM:45K OHM,0.25%,0.125W	9163	
R1455	321-0816-03			0100	7 MFF1816D45001C
R1456	315-0331-00		RES.,FXD,FILM:5K OHM,0.25%.0.125W	0100	• • • • • • • • • • • • • • • • • • • •
R1457	315-0302-00		HES., FXD, CMPSN: 330 OHM 5% 0.25W	91637	
R1458	308-0245-00		RES., FXD, CMPSN: 3K OHM 5% 0.25W	57668	
R1463	321-0273-00		RES.,FXD,WW:0.6 OHM,5%,2W	57668	NTR25J-E03K0
R1464			RES.,FXD,FILM:6.81K OHM,1%,0.125W	91637	CW2B30 0.60HM 5%
	321-0756-03		RES.,FXD,FILM:50K OHM,0.25%,0.125W	91637	MFF1816G68100F
R1465			0.125W, 0.125W	91637	MFF1816D50001C
	321-0962-03		RES EVD FULL OF ALL ALL		10100300010
R1466	315-0561-00		RES.,FXD,FILM:8K OHM,0.25%,0.125W	91637	
R1467	315-0432-00		RES.,FXD,CMPSN:560 OHM,5%,0.25W	01121	MFF1816D80000C
R1468	308-0245-00		RES., FXD, CMPSN: 4.3K OHM 5% 0.25W		CB5615
R1473	321-0287-00		HES., FXD, WW:0.6 OHM 5% 2W	57668	NTR25J-E04K3
R1474	321-0756-03		RES., FXD, FILM: 9.53K OHM 1% 0 125W	91637	CW2B30 0.60HM 5%
			RES.,FXD,FILM:50K OHM,0.25%,0.125W	91637	MFF1816G95300F
R1475	321 0004 00		12010 Chim, 0.2076, 0.120W	91637	MFF1816D50001C
R1476	321-0684-00		RES.,FXD,FILM:15K OHM,0.5%,0.125W		
R1477	315-0331-00		BES EXD CMRSN 220 OHM 0. 125W	91637	MFF1816D15001D
	315-0472-00		RES.,FXD,CMPSN:330 OHM,5%,0.25W	57668	NTR25J-E330E
R1478	307-0052-00		RES.,FXD,CMPSN:4.7K OHM.5%,0.25W	57668	NTR25J-E04K7
R1480	311-1373-00		RES.,FXD,CMPSN:3 OHM,5%,0.50W	01121	
R1481	315-0302-00		RES., VAR, NONWIR: 5K OHM, 20%, 1W		EB30G5
	. – – – –		RES., FXD, CMPSN: 3K OHM, 5%, 0.25W	01121	73U4G040L502M
R1483	315-0472-00			57668	NTR25J-E03K0
R1484	315-0203-00		RES.,FXD,CMPSN:4.7K OHM,5%,0.25W		
R1485	315-0273-00		RES.,FXD,CMPSN:20K OHM,5%,0.25W	57668	NTR25J-E04K7
31486			RES.,FXD,CMPSN:27K OHM,5%,0.25W	57668	NTR25J-E20K0
R1487	321-0364-00		RES.,FXD,FILM:60.4K OHM,1%,0.125W	57668	NTR25J-E27K0
1488	321-0356-00		BES EXD FILM 10 9K 9K	91637	CMF55116G60401F
1400	308-0127-00		RES.,FXD,FILM:49.9K OHM,1%,0.125W	91637	MFF1816G49901F
			RES.,FXD,WW:2.5K OHM,5%,5W	91637	CWE 25000 -
1489	315-0180-00			57057	CW5-25000J
1493	315-0104-00		RES.,FXD,CMPSN:18 OHM,5%,0.25W	01101	
1494	315-0104-00		HES., FXD, CMPSN: 100K OHM 5% 0.25W	01121	CB1805
1495	315-0221-00		RES., FXD, CMPSN: 100K OHM 5% 0.25W	57668	NTR25J-E100K
1496	321-0357-00		RES.,FXD,CMPSN:220 OHM,5%,0.25W	57668	NTR25J-E100K
1497			RES.,FXD,FILM:51.1K OHM,1%,0.125W	57668	NTR25J-E220E
	321-0280-00		RES.,FXD,FILM:8.06K OHM,1%,0.125W	91637	MFF1816G51101F
1498	• · - ·		1003, 103, 12M.8.00K OHM, 1%, 0.125W	91637	MFF1816G80600F
	315-0153-00		RES EVD CHADON AND A		
499	315-0102-00		RES.,FXD,CMPSN: 15K OHM,5%,0.25W	01121	CR1525
1501	315-0912-00		RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	CB1535
502	315-0433-00		RES.,FXD,CMPSN:9.1K OHM,5%,0.25W		NTR25JE01K0
503	315-0822-00		nes. PXD, CMPSN: 43K OHM 5% 0 25W	57668	NTR25J-E09K1
504	315-0473-00		RES., FXD, CMPSN: 8.2K OHM 5% 0 25W	57668	NTR25J-E043K
	0.0-04/0-00		RES.,FXD,CMPSN:47K OHM,5%,0.25W	01121	CB8225
506	215 0540 00		0.11 M CHIM, 5 %, 0.25 W	57668	NTR25J-E47K0
515	315-0512-00		RES.,FXD,CMPSN:5.1K OHM,5%,0.25W		
	311-1221-00		RES VAR NONWID SO SUMM, 5%, 0.25W	57668	NTR25J-E05K1
516	321-0107-00		RES., VAR, NONWIR:50 OHM, 20%, 0.50W	32997	3386F-T04-500
517	321-0001-00		RES.,FXD,FILM:127 OHM,1%,0.125W	91637	
504	315-0202-00		RES.,FXD,FILM:10 OHM,1%,0.125W	75042	MFF1816G127R0F
504			RES., FXD, CMPSN: 2K OHM, 5%, 0, 25W		CEATO-10R00F
			(OPTION 07)	57668	NTR25J-E02K0
05	315-0752-00				
05			RES.,FXD,CMPSN:7.5K OHM,5%,0.25W		
07			(OPTION 07)	57668	NTR25J-E07K5
	315-0272-00				
07 00			RES.,FXD,CMPSN:2.7K OHM,5%,0.25W (OPTION 07)	57668	NTR25J-E02K7
09	315-0511-00				LUCK/
09			RES.,FXD,CMPSN:510 OHM,5%,0.25W	01121 (
			(OPTION 07)	VIIZI (CB5115
11	315-0511-00				
11			RES.,FXD,CMPSN:510 OHM,5%,0.25W	01121 (
			(OPTION 07)		CB5115

7-40

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Ckt No.	Tektronix Part No.	Serial/Mod Eff	el No. Dscont	Name & Description	Mfr Code	Mfr Part Number
R1613 R1613	311-1248-00			RES.,VAR.NONWIR:500 OHM,10%,0.50W	73138	72-23-0
R1614	315-0202-00			(OPTION 07) RES.,FXD,CMPSN:2K OHM,5%,0.25W	57668	NTR25J-E02K0
R1614				(OPTION 07)	57000	NTR255-EU2RU
R1617	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1617				(OPTION 07)		
R1618	315-0101-00			RES.,FXD,CMPSN:100 OHM,5%,0.25W	57668	NTR25J-E 100E
R1618				(OPTION 07)		
R1622 R1622	315-0102-00			RES.,FXD.CMPSN:1K OHM,5%,0.25W (OPTION 07)	57668	NTR25JE01K0
R1623	316-0103-00			RES.,FXD,CMPSN:10K OHM,10%,0.25W	01121	CB1031
R1623				(OPTION 07)	07121	001001
R1624	315-0302-00			RES.,FXD,CMPSN:3K OHM,5%,0.25W	57668	NTR25J-E03K0
R1624				(OPTION 07)	57000	NTN200-200N0
R1625	316-0101-00			RES.,FXD,CMPSN:100 OHM,10%,0.25W	01121	CB1011
R1625				(OPTION 07)		
R1626 R1626	308-0450-00			RES.,FXD,WW:70 OHM,1%,3W (OPTION 07)	91637	RS2B-B70R00F T/R
R1627	315 0371 00	010146				
R1627	315-0271-00	B010445		RES.,FXD.CMPSN:270 OHM,5%,0.25W (OPTION 07)	01121	CB2715
R1631	308-0450-00			RES.,FXD,WW:70 OHM,1%,3W	91637	RS2B-B70R00F T/R
R1631				(OPTION 07)	01007	
71633	311-1501-00			RES., VAR, NONWIR: 20 OHM, 10%, 0.50W	73138	72-37-0
31633				(OPTION 07)		
31639	315-0153-00			RES.,FXD,CMPSN:15K OHM,5%,0.25W	01121	CB1535
R1639				(OPTION 07)		
R1640 R1640	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	57668	NTR25JE01K0
R1641	315-0153-00			(OPTION 07) RES.,FXD,CMPSN:15K OHM,5%,0.25W	01121	CB1535
81641				(OPTION 07)	01121	001000
31642	315-0473-00			RES.,FXD,CMPSN:47K OHM,5%,0.25W	57668	NTR25J-E47K0
1642				(OPTION 07)		
1645	307-0113-00			RES.,FXD,CMPSN:5.1 OHM,5%,0.25W	01121	CB51G5
81645 81652	308-0459-00			(OPTION 07)	0.007	
1652				RES.,FXD,WW:1.1 OHM,5%,3W (OPTION 07)	91637	CW2B-1R100J TR
				()		
1654 11654	308-0459-00			RES.,FXD,WW:1.1 OHM,5%,3W	91637	CW2B-1R100J TR
1662	308-0459-00			(OPTION 07) RES.,FXD,WW:1.1 OHM, 5%,3 W	91637	CW2B-1R100J TR
11662				(OPTION 07)	51057	CW2D-111005 11
1664	308-0459-00			RES.,FXD,WW:1.1 OHM,5%,3W	91637	CW2B-1R100J TR
1664				(OPTION 07)		
1671	308-0349-00			RES.,FXD,WW:3.6K OHM,1%,3W	91637	RS2B-36000F-TR
1671				(OPTION 07)		
1691 1692	303-0150-00		B016199	RES.,FXD,CMPSN:15 OHM,5%,1W	01121	GB1505
1693	321-0062-00 323-0140-00		B016199 B016199	RES.,FXD,FILM:43.2 OHM,1%,0.125W RES.,FXD,FILM:280 OHM,1%,0.50W	91637 75042	CMF55-116G43R20F
1694	323-0140-00		B016199	RES.,FXD,FILM:280 OHM,1%,0.50W	75042 75042	CECT0-2800F CECT0-2800F
1695	321-0228-00		B016199	RES.,FXD,FILM:2.32K OHM,1%,0.125W	91637	MFF1816G23200F
1697 1698	321-0201-00 315-0363-00		B016199	RES.,FXD,FILM:1.21K OHM,1%,0.125W	91637	MFF1816G12100F
8033	321-0228-00	B010100 B016200	B016199	RES.,FXD,CMPSN:36K OHM,5%,0.25W RES.,FXD,FILM:2.32K OHM,1%,0.125W	57668 91637	NTR25J-E36K0 MFF1816G23200F
8035	321-0201-00	B016200		RES.,FXD,FILM:2.32K OHM, 1%,0.125W	91637	MFF1816G12100F
8036	315-0363-00	B016200		RES.,FXD,CMPSN:36K OHM,5%,0.25W	57668	NTR25J-E36K0
8054	323-0140-00	B016200		RES.,FXD,FILM:280 OHM,1%,0.50W	75042	CECT0-2800F

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

	Tektronix	Serial/Mo	del No.		Mfr	
Ckt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
R8056	323-0140-00	B016200		RES.,FXD,FILM:280 OHM,1%,0.50W	75042	CECT0-2800F
R8058	303-0150-00	B016200		RES.,FXD,CMPSN:15 OHM,5%,1W	01121	GB1505
R8065	321-0062-00	B016200		RES.,FXD,FILM:43.2 OHM,1%,0.125W	91637	CMF55-116G43R20F
RT170	307-0181-00			RES.,THERMAL: 100K OHM, 10%, 4MW/DEG C	15454	1DE104-K-220EC
RT270	307-0181-00			RES.,THERMAL:100K OHM,10%,4MW/DEG C	15454	1DE104-K-220EC
RT452	307-0125-00			RES., THERMAL: 500 OHM, 10%, 25 DEG C	50157	2D1595
RT559	307-0124-00			RES.,THERMAL:5K OHM,10%	50157	1D1618
RT759	307-0124-00			RES.,THERMAL:5K OHM,10%	50157	1D1618
RT1103	307-0125-00			RES.,THERMAL:500 OHM,10%,25 DEG C	50157	2D1595
RT1696	307-0124-00	B010100	B016199	RES.,THERMAL:5K OHM,10%	50157	1D1618
RT8038	307-0124-00	B016200	2010100	RES.,THERMAL:5K OHM,10%	50157	1D1618
S20	105-0282-01	0010200			80009	
520	105-0202-01			ACTUATOR,CAM SW:DC,GND,AC	80009	105-0282-01
S20				(USED AT LOCATION S20A)(QUANTITY OF 2)		
S20	105-0343-01			ACTUATOR,CAM SW:ATTEN	80009	105-0343-01
S20				(USED AT LOCATION S20B)(QUANTITY OF 2)		
S128				(FURN AS A SET W/R128)		
S225	260-1208-00			SWITCH, PUSH: DPDT, 28VDC, PUSH-PUSH	31918	ORDER BY DESCR
S228				(FURN AS A SET W/R228)		
S300	260-1424-00			SWITCH, PUSH:5 STA, INTERLOCK, NON-SHORT	59821	2KBC050000607
S375	263-1019-00			SW CAM ACTR AS:VOLTS/DIV	80009	263-1019-00
S375				(USED AT LOCATION S375A)	00003	200-1019-00
S375	105-0421-00			ACTUATOR, SWITCH: MOMENTARY	80009	105 0421 00
S375				(USED AT LOCATION S375B,C)	80009	105-0421-00
S450	260-1310-01			SWITCH, PUSH: 4PDT MOMENTARY, NON-SHORTING	59821	2KAA001000549
0505	105 0100 00					
S505	105-0400-00			ACTUATOR, SWITCH: A SOURCE	80009	105-0400-00
S508	105-0399-00			ACTUATOR, SWITCH: COUPLING	80009	105-0399-00
S530				(FURN AS A SET W/R530)		
S600	260-1422-00			SWITCH, PUSH: 3 STA, INTERLOCK	59821	EKBC030000594
S644				(FURN AS A SET W/R644)		
S705	105-0401-00			ACTUATOR,SWITCH:B SOURCE	80009	105-0401-00
S708	105-0399-00			ACTUATOR, SWITCH: COUPLING	80009	105-0399-00
S750				(FURN AS A SET W/R750)		
S1050	263-1091-00	B010100	B012224	SW CAM ACTR AS:TIME/CM	80009	263-1091-00
S1050	263-1091-01	B012225		SW CAM ACTR AS:TIME/CM	80009	263-1091-01
51070				(FURN AS A SET W/R1070)		
51090	260-1423-00			SWITCH, PUSH: 4 STA, INTERLOCK, NON-SHORT	59821	2KBC040000593
51099	260-1309-00			SWITCH, SENS: SPDT, 5A, 250AC	01963	E63-10H
51110	260-1209-00			SWITCH, PUSH: 4PDT, 1A, 25VDC	31918	601347
51401	260-0834-00					
51402	260-0638-00	B010100	0000000	SWITCH, TOGGLE: DPDT, 5A, 125VAC, 0.25-40 THD	09353 93410	U21-SHZQE 430-364
51402	260-0038-00	B010100	B023829	SW,THERMOSTATIC: 10A,240V,OPEN 75 DEG C		
51402 51403		B023830		SWITCH, THRMSTC:NC, OPEN 83.3, CL 66.7, 10V	93410	430-367
51403	260-1300-01			SWITCH,SLIDE:DPDT,3A,125V	82389	46206LFE
51601	260-0834-00			SWITCH,TOGGLE:DPDT,5A,125VAC,0.25-40 THD	09353	U21-SHZQE
61601				(OPTION 07)		
51665	260-0760-00			SWITCH,SENS:SUBMINIATURE,10A,125/240VAC	01963	E62-10A
61665				(OPTION 07)		
178	120-0469-00			XFMR, TOROID:3 TURNS BIFILAR	80009	120-0469-00
278	120-0469-00			XFMR,TOROID:3 TURNS BIFILAR	80009	120-0469-00
1320	120-0815-01			XFMR,PWR,SDN&SU:HV(MOLDED)	80009	120-0815-01
1400	120-0799-01			XFMR,PWR,STPDN:LV	80009	120-0799-01
1601	120-0637-00			XFMR.TOROID:5 TURNS BIFILAR	80009	120-0637-00
1601				(OPTION 07)		
1631	120-0852-00			XFMR,TOROID:2 WINDINGS	80009	120-0852-00
1631				(OPTION 07)	00003	, 20-0002-00
1120	155-0085-01			MICROCIRCUIT, LI: HYB, DUAL FET INPUT/AMPL, SEL	80009	155-0085-01

7-42

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

÷.

Ckt No.	Tektronix Part No.	Serial/Mo Eff			Mfr	
		<u></u> 11	Dscont	Name & Description	Code	Mfr Part Number
U140	455 0070 00				0000	
U140	155-0078-03	B010100	B013449	MICROCIRCUIT, LI: ML, VERTICAL AMPL, SEL	00000	
	155-0078-10	B013450		MICROCIRCUIT, LI:ML, VERTICAL AMPLIFIER	80009	
U220	155-0085-01			MICROCIRCUIT, LI:HYB, DUAL FET INPUT/AMPL, SEL	80009	
U240	155-0078-03	B010100	B013459	MICROCIRCUIT LIMENTERTION AND A	80009	155-0085-01
U240	155-0078-10	B013450	2010400	MICROCIRCUIT.LI:ML,VERTICAL AMPL,SEL	80009	
U330	156-0030-03	2010430		MICROCIRCUIT, LI:ML, VERTICAL AMPLIFIER	80009	155-0078-10
	.00-0000-00			MICROCIRCUIT, DI: QUAD 2-INP NAND GATE, SCRN	01295	SN7400(NP3 OR JF
U340	156-0030-03					ON TOURTS ON J
U350	156-0041-05			MICROCIRCUIT, DI:QUAD 2-INP NAND GATE, SCRN	01295	SN7400(NP3 OR JF
U370	155-0091-00			MICROCIRCUIT, DI: DUAL D-FLIP FLOP	01295	SN7474
U450				MICROCIRCUIT, LI: ML, CHANNEL SWITCH	80009	
	155-0078-03	B010100	B013449	MICROCIRCUIT, LI:ML, VERTICAL AMPL, SEL		155-0091-00
U450	155-0078-10	B013450		MICROCIRCUIT, LI: ML, VERTICAL AMPLIFIER	80009	155-0078-03
U470	155-0168-00			MICROCIRCUIT, LI:OUTPUT AMPLIFIER, TESTED	80009	155-0078-10
11500				AMPLIFIER, IESTED	80009	155-0168-00
U520	155-0032-01			MICROCIRCUIT, LI: MONOLITHIC, INPUT PRE-AMPL		
U600	155-0049-01	B010100	B010299	MICROCIRCUIT, DI: MONOLITHIC, SWEEP CONTROL	80009	155-0032-01
U600	155-0049-02	B010300		MICROCIBCUIT DI SWEED CONTROL	80009	155-0049-01
U720	155-0032-01			MICROCIRCUIT, DI:SWEEP CONTROL, W/LOCKOUT	80009	155-0049-02
U930	156-0158-00			MICROCIRCUIT, LI:MONOLITHIC, INPUT PRE-AMPL	80009	155-0032-01
J1321	152-0552-00			MICROCIRCUIT, LI: DUAL OPERATIONAL AMPLIFIER	18324	MC1458N
	.01 0002-00			SEMICOND DEVICE:V MULTR,5KV IN,15KV OUT	52306	CMX315
J1418	156-0158-00					
J1454	156-0158-00			MICROCIRCUIT, LI: DUAL OPERATIONAL AMPLIFIER	18324	MC1458N
J1464	156-0158-00			MICROCIRCUIT, LI: DUAL OPERATIONAL AMPLIFIER	18324	MC1458N
1690				MICROCIRCUIT, LI: DUAL OPERATIONAL AMPLIEIER		
	156-0281-00	B010100	B016199	MICROCIRCUIT, LI:4 TRANSISTOR ARRAY	18324	MC1458N
8061	156-0281-00	B016200		MICROCIRCUIT, LI:4 TRANSISTOR ARRAY	02735	8 9164
1380	154-0677-10			ELECTRON TUBE:CRT	02735	8 9164
					80009	154-0677-10
R144	152-0166-00			SEMICOND DEVICE:ZENER,0.4W,6.2V,5%	-	
R161	152-0166-00			SEMICOND DEVICE:ZENER,0.4W,6.2V,5%	04713	SZ11738RL
R244	152-0166-00			SEMICOND DEVICE.ZENER,0.4W,6.2V,5%	04713	SZ11738RL
R261	152-0166-00			SEMICOND DEVICE:ZENER.0.4W,6.2V,5%	04713	SZ11738RL
R290	152-0166-00			SEMICOND DEVICE: ZENER, 0.4W, 6.2V, 5%	04713	SZ11738RL
R396	152-0166-00			SEMICOND DEVICE: ZENER 0.4W 6 2V 5%	04713	SZ11738RL
	102-0100-00			SEMICOND DEVICE: ZENER, 0.4W, 6.2V, 5%	04713	SZ11738RL
R462	152-0195-00					CETTOONE
R464	152-0195-00			SEMICOND DEVICE: ZENER, 0.4W, 5.1V, 5%	04713	SZ11755
3465	152-0149-00			SEMICOND DEVICE: ZENER.0.4W.5.1V.5%	04713	SZ11755
R467				SEMICOND DEVICE: ZENER, 0, 4W, 10V 5%	04713	
	152-0278-00			SEMICOND DEVICE:ZENER,0.4W,3V,5%		SZG35009K3
1482	152-0195-00			SEMICOND DEVICE:ZENER,0.4W,5.1V,5%	04713	SZG35009K20
3570	152-0217-00			SEMICOND DVC,DI:ZEN,SI,8.2V,5%,0.4W	04713	SZ11755
					04713	SZG20
1608	152-0278-00			SEMICOND DEVICE:ZENER,0.4W,3V,5%	04740	07005000
1796	152-0226-00			SEMICOND DEVICE:ZENER,0.4W,5.1V,5%	04713	SZG35009K20
798	152-0278-00			SEMICOND DEVICE:ZENER,0.4W,3.1V,5%	14552	TD3810980
930	152-0265-00			SEMICOND DEVICE ZENERALINA W. 3V,5%	04713	SZG35009K20
938	152-0304-00			SEMICOND DEVICE:ZENER,0.4W,24V,5%	04713	SZG35009K8
956	152-0278-00			SEMICOND DEVICE:ZENER,0.4W,20V,5%	15238	Z5411
				SEMICOND DEVICE:ZENER,0.4W,3V,5%	04713	SZG35009K20
1026	152-0278-00			SEMICOND DEVICE TENED		
1124	152-0175-00			SEMICOND DEVICE:ZENER,0.4W,3V,5%	04713	SZG35009K20
1134	152-0166-00			SEMICOND DEVICE: ZENER, 0.4W, 5.6V, 5%	04713	SZG35008
1216	152-0055-00			SEMICOND DEVICE: ZENER, 0, 4W, 6, 2V, 5%	04713	SZ11738RL
1267				SEMICOND DEVICE: ZENER.0.4W.11V.5%	04713	SZG35009K1
1329	152-0166-00			SEMICOND DEVICE: ZENER, 0, 4W, 6, 2V, 5%	04713	
1323	152-0289-00			SEMICOND DEVICE:ZENER.0.4W.180V.5%	04713	SZ11738RL SZ12484KRL
362	152.0166.00				04710	UL IZADANAL
374	152-0166-00			SEMICOND DEVICE: ZENER, 0.4W, 6.2V, 5%	04713	SZ11738RL
	152-0357-00			SEMICOND DEVICE ZENER 0.4W 82V 5%		
416	152-0411-00		:	SEMICOND DEVICE:ZENER,0.25W,9V,5%	04713	SZ12461KRL
418	152-0022-00		1	SEMICOND DEVICE:ZENER,1W,25V,5%	04713	SZ12483KRL
422	152-0283-00		9	SEMICOND DEVICE:ZENER,0.4W,43V,5%	04713	SZ12815
	152-0304-00			SEMICOND DEVICE:ZENER,0.4W,43V,5%	12954	DZ750903B1N976B
423	102-0004-00		2			
423 480	152-0127-00			SEMICOND DEVICE.ZENER,U.4W,20V,5%	15238	Z5411

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel: 01844-351894 Fax: 01844-352554 Email: enquiries@mauritron.co.uk

	Tektronix Part No.	Serial/Model No.			Mfr	
Ckt No.		Eff	Dscont	Name & Description	Code	Mfr Part Number
VR1604	152-0306-00			SEMICOND DEVICE:ZENER.0.4W.9.1V.5%	15238	Z5409
VR1604	132-0300-00			(OPTION 07)	10200	20400
VR1605	152-0306-00			SEMICOND DEVICE:ZENER.0.4W.9.1V.5%	15238	Z5409
VR1605				(OPTION 07)		
VR1622	152-0241-00			SEMICOND DEVICE: ZENER, 0.4W, 33V, 5%	04713	SZG35009K5
VR1622				(OPTION 07)		
VR1639	152-0279-00			SEMICOND DEVICE:ZENER,0.4W,5.1V,5%	04713	SZG35010RL
VR1639				(OPTION 07)		
VR1641	152-0279-00			SEMICOND DEVICE: ZENER, 0.4W, 5.1V, 5%	04713	SZG35010RL
VR1641				(OPTION 07)		

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV DEC 1984

OPTION INFORMATION

Your instrument may be equipped with one or more options. This section describes those options, or directs the reader to where the option is documented.

Pages

Option 4	EMI Environmental:	Described in this section.	2
Option 7 ¹	EXT DC Operation:	Described in this section.	12
Option 78	P11 Phosphor:	Described in this section.	1

¹Instruments equipped with DM series Digital Multimeters do not have Option 7 available.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon C:(9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

OPTION 4

This section describes the features of Option 4 as it pertains to the 475A Oscilloscope. This circuitry modifies the instrument to meet conducted and radiated interference requirements over the frequency range of 150 kHz to 25 MHz (conducted) and 150 kHz to 1 GHz (radiated).

The following additions and changes were made to the standard circuitry to meet the specification requirements:

EMI filter (FL1401) added in series with the input power cord.

Cathode ray tube mesh filter installed to minimize crt faceplate radiation.

Four signal-output bnc connectors on the rear plenum chamber changed to a type that improves shielding of the connected signal leads.

Capacitors added across the transformer secondary windings.



Fig. Option 4-1. 475A Option 4 primary winding with power-line filter.

Plak Nim	Tektronix Part No.	Serial/Model No.			Mfr	
Ckt No.		Eff	Dscont	Name & Description	Code	Mfr Part Number
				OPTION 04		
C1403	283-0000-00			CAP.,FXD,CER DI:0.001UF, +100-0%,500V		
C1404	283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V	59660	831610Y5U0102P
C1405	283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V	59660	871-533E103P
C1406	283-0068-00			CAP.,FXD,CER DI:0.010F,+100-0%,500V	59660	871-533E103P
				OAT ., I AD, OEIT DI. 0.010F, +100-0%,500V	59660	871-533E103P
C1407	283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V		
21408	283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V	59660	871-533E103P
				0A1.,1 XD,0EH D1.0.010F, +100-0%,500V	59660	871-533E103P
L1401	119-0376-01			FILTER, RAD INT:2 X 3A, 250V, 400 HZ	80009	119-0376-01
					00000	110-0070-01
430	131-1315-01	B010100	B015866	CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1
420						
430	131-1315-01	B015867		CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1
584	131-1315-01	B010100	B015866	CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1
584	131-1315-01	B015867		CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1
829	131-1315-01	B010100	B015866	CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1
829	131-1315-01	B015867		CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1
1330	131-1315-01	B010100	B015866	CONN, RCPT, ELEC: BNC, FEMALE	24931	
					24551	28JR 306-1
1330	131-1315-01	B015867		CONN, RCPT, ELEC: BNC, FEMALE	24931	28JR 306-1

Fig. & Index No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Qty	1 2 3 4 5 Name & Description	Mfr Code	Mfr Part Number
	119-0376-01		1	FILTER,RAD INT:2 X 3A,250V,400 HZ	80009	119-0376-01
	211-0038-00 210-0586-00		1 1	SCREW,MACHINE:4-40 X 0.312,FLH,100 DEG NUT,PL,ASSEM WA:4-40 X 0.25,STL (END ATTACHING PARTS)	83385 83385	ORD BY DESCR ORD BY DESCR
	131-0707-00 131-0708-00 131-1310-00		1 1 1 4	CONNECTOR, TERM:22-26 AWG, BRS & CU BE GOLD CONTACT, ELEC:0.48°L, 28-32 AWG WIRE CONTACT, ELEC:MESH FILTER GROUND CONNECTOR, RCPT: (SEE J430, J584, J829, J1330 R	22526 22526 80009	47439 47437 131-1310-00
	179-2162-00 210-0774-00 210-0775-00 378-0726-00 348-0239-00	B018468	1 2 2 1 1	WIRING HARNESS:OPTION NO.4 EYELET,METALLIC:0.152 OD X 0.245 INCH L,BR EYELET,METALLIC:0.126 OD X 0.23 INCH L,BRS FILTER,MESH:EMI GROMMET,PLASTIC:DK GRAY,U-SHAPE,0.27 ID	80009 80009 80009 80009 80009 80009	179-2162-00 210-0774-00 210-0775-00 378-0726-00 348-0239-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 AQY Tel: 01844-35169.⁴ Fax: 01844-352554 Email: enquines@mauritron.co.uk

OPTION 7

Option 7 is a dc to ac inverter that permits Tektronix Oscilloscopes to operate on 12 or 24 V dc with no performance deterioration. Circuitry is provided to protect against damage due to connection of 24 V when in the 12 V mode of operation.

The 24-volt external input permits use with conventional dc power (marine and aircraft).

Option 7 is an integral part of the oscilloscope. The modified oscilloscope has a three-position voltage input selection slide switch (visible through the right-hand side panel) at the rear of the line voltage selector switch. A dc input connector is located below the fan cover on the rear panel.

SPECIFICATIONS

AC Requirements

No increase in ac requirements over those of oscilloscopes not having Option 7.

DC Requirements

11.5 to 14 volts or 22 to 28 volts. 11.5-volt operation excludes graticule light operation and Option 5. Operating range may be extended to 15 volts or 30 volts with a series dropping resistor. Maximum elevation for + or - power lead is 60 V with respect to oscilloscope chassis ground.

Temperature

The same operating and non-operating range as the oscilloscope without Option 7.

SAFETY CONSIDERATIONS

Option 7 becomes a part of the modified instrument. The safety considerations for the unmodified instrument apply.

FUNCTION OF CONTROLS AND CONNECTORS

Mode Switch¹

AC Applies ac power to the oscilloscope power switch.

¹Be sure that the 1106 Line Selector switch is set to the correct line voltage for proper battery charging.

DC 24 Permits 24 V operation of the instrument from either an external 24 V power source or from the 1106 Power Supply, which may be mechanically attached to the oscilloscope.

Dc Input Connector

Option 7 mode switch and dc input connector are located on the modified oscilloscope.

OPERATION AND INSPECTION

Set the oscilloscope and Option 7 for the power source available as listed.

TABLE 1					
Power Source	Oscilloscope Line Selector	Option 7 Mode Switch			
115 V AC	115	AC			
230 V AC	230	AC			
12 V DC		12			
24 V DC		24			
1106 ¹		24			

Turn the oscilloscope on. Check that the oscilloscope operates properly on any of the listed power sources that may be available.

Connect the oscilloscope frame to a ground (earth) reference before using.

CIRCUIT DESCRIPTION

Option 7 is a dc to ac inverter. It operates on 12 or 24 V dc. The circuit description is for 24 V operation unless noted otherwise. Refer to the schematic diagrams (Figs. Option 7-2 and 7-3) throughout the detailed circuit description.

The operating frequency of the inverter is approximately 400 Hz.

Option 7 Page 1

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tet- 01844-351694 Fax: 01844-35254 Email: enquiries@mauritron.co.uk

Options—475A Service

Simplified Block Diagram

See Fig. Option 7-1. The dc source is applied to the turn-off level circuit, the start circuit and the primary of T1400. If the dc source is above the level set by Turn-Off Level Adjustment R1613, the turn-off circuit does not operate.

The start circuit provides a large current surge through T1631 secondary to the bases of Q1652, Q1662, Q1654 and Q1664. This starts the inverter.

The turn-off circuit is activated in two ways. In 24 V operation, Q1622 is turned on by the source voltage dropping below 22 V. In 12 V mode of operation, Q1626 is turned on by the accidental application of 24 V dc.

Turn-Off Level Circuit

For the following description, refer to Fig. Option 7-2.

The voltage reference for the base of Q1606 is set by R1604, VR1604 and VR1605 for about 9.1 V. This establishes the junction of R1607 and the emitters of Q1606 and Q1608 at about 9.7 V. C1605 helps to hold the 9.1 V level, preventing inverter transients from activating the turn-off circuit and prevents Q1608 from turning on when the inverter is started. This allows the power source time to recover after providing the initial-start surge.

Source voltages higher than 22 V dc cause increased current through R1607, Q1606 and R1609. Q1608 is kept cut off by the increased voltage across R1609 and the resulting change across divider R1611-R1613-R1614. Thi, permits no current through R1617. Since R1617 furnishes bias to Q1622, the transistor is cut off. This permits the collector of Q1622 and the rest of the turn-off circuit to rise to a voltage determined by the inverter circuit and the dc source voltage. The collector of Q1622 may be about 24 V (with respect to minus dc) with a 12 V dc source and about 36 V with a 24 V dc source.

If the dc source voltage drops to less than 22 V, the current through divider R1609, R1611, R1613 and R1614 is decreased. Q1608 conducts, taking current from Q1606, and causing less drop across R1609. This makes Q1608 conduct more and Q1606 is cut off. Current flow through R1617 turns Q1622 on. Q1622 saturates, dropping its collector voltage to about 0.2 V. R1618 limits the maximum base current of Q1622.

During 12 V dc operation, there is no current flow through VR1604 and VR1605, since their series rating, about 18 volts, exceeds the applied voltage. The base current of Q1606, through R1605, turns Q1606 on enough to take all the current through R1607, which causes Q1608, to be cut off.



Fig. Option 7-1. Option 7 simplified block diagram.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax- 01844-352554 Email: enquirise@mauritron.co.uk

Turn-Off Circuit

Q1622 is off under normal operating conditions until the dc source drops below 22 V and causes Q1622 to conduct. Q1622 does not conduct during 12 V dc operation, since the turn-off level circuit is disabled, CR1625, CR1626, CR1627, and CR1628 form a bridge rectifier. The inverter waveform is rectified to provide operating power for the turn-off circuit. C1626 filters the inverter spikes to keep them from firing Q1626 (scr). R1623 prevents C1626 from charging to the peak-to-peak inverter spikes.

Q1622 saturates when it is turned on. C1622 provides the high current path for feedback current via CR1625 or CR1626. Once the inverter is shut down, R1622 establishes a path to discharge C1622.

If 24 V dc is accidentally applied when the mode switch is in the 12 V position, tranformer T1400 attempts to produce two times the correct feedback. This is sufficient to cause VR1622 to conduct. VR1622 provides the firing current for the scr, Q1626. Scr Q1626 fires and shorts out the bridge rectifier and the primary of T1631, stopping the inverter. R1625 prevents Q1626 from being fired by inverter noise. R1624 and C1626 provide holding current for Q1626, keeping it conducting until the surge current created by the over-voltage conditions have terminated. CR1624 permits rapid charging of C1626.

Start Circuit

When S1601 is closed, the external dc source is applied to C1614, VR1641, and R1645. The initial surge is coupled to Q1642 through C1614, VR1639, and R1641. Transistor Q1642 saturates until C1614 charges through R1639 to the value determined by VR1639 and the base-emitter junction of Q1642 (about 5.7 volts), then Q1642 is cut off. R1641 limits the base current in Q1642. Zender diode VR1639, once C1614 is charged, makes Q1642 insensitive to input variations. R1642 limits Q1642 collector current. Q1644, R1645, and VR1641 provide a constant current during the time Q1642 is saturated, regardless of the dc source voltage. CR1643 is reverse biased by this starting current. The starting current is applied to the inverter transistors through T1631.

Inverter Circuit

The starting surge is applied to the bases of Q1652, Q1662, Q1654, and Q1664 trough T1631, R1652, R1662, R1654, and R1664. Since the transistors do not have identical parameters, one pair will conduct before the other, and start the inverter. Operating base current is provided through CR1643.

R1626, R1631, and T1631 primary and secondary are the main frequency-determining components for the inverter. Four base resistors, R1652, R1662, R1654, and





REV. A, DEC. 1977

For Service Manuals Contact MURITRON TECHNICAL SERVICES 8 Cherry Trac 36 Continor Committee Act Continor Tet- 01844-2000 (01 Kny) Email: enquiliesgrmauticettee

Option 7 Page 3

Options—475A Service

R1664, distribute the drive evenly between the four transistors, C1652, C1662, C1654 and C1664 degenerate the high frequency response and reduce transients.

Feedback to maintain inverter operation is provided from T1400 primary to T1631 primary through R1626, R1631, R1633, CR1632 and CR1634. Resistors R1626 and R1631 provide frequency stability and current limiting. R1633, CR1632, and CR1634 compensate for differences in transistors and components. CR1632 and CR1634 conduct during different inverter half-cycles and permit R1633 to balance the drive to T1400.

C1681, C1682, C1683, C1684, C1685 and C1686 are added to the secondary of T1400 with Option 7 to provide optimum reduction of transients during inverter operation.

DC Input

External power is applied through P1601. CR1601 is normally reverse biased. If the wrong polarity external power is applied, CR1601 becomes forward biased and blows fuse F1601. Low-pass network T1601, C1601, C1603, and C1609 is a filter to reduce transients to the dc source.

Start-Stop Switch

S1601, Section A in the off (stop) position discharges the capacitors in the turn-off and start circuits. Thi ensures the correct time constants when S1601 is changed to the on (start) position. In the start position, the dc input is applied to the inverter circuitry by S1601, Section A. At the same time S1601, section B is closed, completing the feedback loop for the inverter transistors, S1601, section B stops the inverter in the off position by opening the feedback loop between T1400 and T1631.

Power-Mode Switch (S1665)

See Fig. Option 7-3. Sections A and F connect filter C1671 and R1671 to T1400 during 12 or 24 V operation to reduce converter transients. Sections C and D select either transformer terminals 10A and 12A or 10 and 12, to provide the same secondary output when operating on 12 or 24 V. Sections B and E connect transformer terminals 10 and 12 to S1665, C and D, and to the inverter feedback circuit during both 12 and 24 V operation.



Fig. Option 7-3. 475A Option 7 primary winding.

Option 7 Page 4

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk



Fig. Option 7-4. Partial 475A Sweep Generators Diagram 8, showing modification with Option 7.

MAINTENANCE

Obtaining Replacement Parts

STANDARD PARTS. All electrical and mechanical part replacements for Option 7 can be obtained through your local Tektronix Field Office or representative. However, many of the standard electronic components can be obtained locally in less time than is required to order them from Tektronix, Inc. Before purchasing or ordering replacement parts, check the parts list for value, tolerance, rating and description.

SPECIAL PARTS. In addition to the standard electronic components, some special components are used in Option 7. These components are manufactured or selected by Tektronix, Inc., to meet specific performance requirements, or are manufactured for Tektronix, Inc., in accordance with our specifications. Most of the mechanical parts used in this instrument have been manufactured by Tektronix, Inc. Order all special parts directly from your local Tektronix Field Office or representative.

ORDERING PARTS. When ordering replacement parts from Tektronix, Inc., include the following information:

- 1. Instrument type.
- 2. Instrument serial number.

3. A description of the part (if electrical, include the circuit number).

4. Tektronix part number.

@

Circuit Board Chassis Removal

The circuit board is mounted on a small chassis located between the power transformer and the crt shield. To remove the chassis, remove three screws. Two threadforming screws are located at the top of the chassis. One screw is at the bottom of the chassis and is removed from the right-hand side by going just below the power transformer.

CALIBRATION

Option 7 may be calibrated without removing it from the oscilloscope.

The reference letters (A), (B), etc., refer to points indicated on the schematic and circuit board illustrations.

Equipment Required

DC VOLTMETER. 22 V to 28 V.

TEST OSCILLSOCOPE. Used to verify the inverter balance adjustment. If the instrument under test and Option 7 are operational and the power source has a negative ground, they may be used as the test oscilloscope for this check.

DC POWER SOURCE. Voltage from 22 V to 28 V and from 11.5 V to 14 V. A source voltage of less than 22 volts will turn off Option 7 when it is operating in the 24 V mode. Starting current in 24 V mode is approximately 4 to 10 A. The dc source must be capable of handling this surge without dropping to 22 V or less. The 12 V starting surge is approximately 15 A.

NOTE

Option 7 is calibrated at the factory using a power supply (having the specifications listed first under the equipment required list). This permits the most accurate setting of the turn-off volts and inverter balance adjustments. Because this type of power supply may not be available, several alternate possibilities are given. The alternate power supplies have drawbacks, including voltage stability vs. time with high discharge rates, see Fig. Option 7-5.

1. Variable power supply with the aformentioned capabilities.

2. Variable power supply with an adequate current rating, in series with items 4 or 5.

Option 7 Page 5

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Trib Bo Chinnor Oron C K9 40Y Tel: 01844-351900 Faxr- 01844-352554 Email: enquires@inaurifron.co.uk

Options—475A Service

3. 1106 Power Supply battery pack.²

4. Two 12-volt wet-cell storage batteries, in series, tapped at 20, 22, or 24 $V.^3$

5. 18 to 23 Ni Cd cells, 4.0 amp hr (D cells) or greater, furnishing 20 to 28 V. 3



Fig. Option 7-5. Typical battery pack discharge curves.



This procedure is for an external dc source with the negative lead at ground potential (negative ground system).

Operating Range

a. Connect the dc source to the oscilloscope equipped with Option 7. Operate the oscilloscope in the 24 V mode. Connect the voltmeter between fuse, F1601 (B) and the common negative return (A). Vary the dc source from 28 V to 22 V.

CHECK—Oscilloscope should operate over the voltage range.

²To set the turn-off level, the battery is charged above the cut-off point (22 V). An oscilloscope is connected and the battery allowed to discharge while its voltage is being monitored. As it reaches 22 V the turn-off point is set to cut off Option 7. The turn-off point on Option 7 approximately coincides with the meter zero on the 1106.

³This does not permit accurate adjustment of the turn-off level. Ni Cd batteries can be used, following the technique used for item 3.

Option 7 Page 6

b. Change the dc source to 12 V. Operate the oscilloscope in the 12 V mode. Vary the dc source from 14 V to 11.5 V.

CHECK—Oscilloscope should operate over the voltage range.

Inverter Balance

NOTE

If the major oscilloscope use is with a 12-volt source, do this step while operating the oscilloscope and dc source on 12 volts.

Operate the oscilloscope in the 24 V mode. Set the dc source to 24 V. Connect the test oscilloscope between C1601 (C) and the common negative return (A).

CHECK-Signal should be flat. See Fig. Option 7-6.

ADJUST—Inverter Balance (R1633) for the flattest signal.



Fig. Option 7-6. Inverter Balance.

NOTE

There is a slow drift (about a second) after the inverter balance adjustment has been moved. This is due to transistor characteristics and will require a slight Inverter Balance readjustment.

A very close approximation of the preceding method can be obtained by setting the inverter balance control for the minimum sound coming from the inverter.

Turn-Off Level

Set the dc source for 21.8 V.

ADJUST--Turn-Off Level (R1613) slowly until Option 7 turns off.

For Service Mainuáls Contact MAURITRON TECHNICAL SERVICES & Chern Trop Rd. Chinnor Contact NO 4 Chinnor Kel-01844 - Contact No 44-352554 Email: enguinacemauritron.co.uk @



Fig. Option 7-7. A11 circuit board layout with test voltages.



Fig. Option 7-8. Typical idealized waveforms.

REV FEB 1982

For Bervice Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor 03.30 C 9 AOY Tel: 01844-35180 Fax: 01844-352554 Email: engunes@maurirron.c...uk

Option 7 Page 7


Fig. Option 7-9. All circuit board layout with component locator grid.

3C

R1639

Option 7 Page 8

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree 3d, Chilthor Oxon C V AQY Tet-01844-35168 Gax-01844-352554 Email: enquiries@ffautitron.co.uk

R1604

1C

CR1627 1B

REV FEB 1982

Tektronix	Serial/N	lodel No.		Mfr	
Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
			OPTION 07		
290-0667-00			CAP.,FXD,ELCTLT:330UF,+75-10%,50V	56289	500D158
283-0032-00			CAP.,FXD,CER DI:470PF,5%,500V	59660	0831085Z5E00471J
283-0263-00			CAP.,FXD,CER DI:0.0022UF,20%,3000V	59660	828556Y5R0222M
			(MOUNTED ON 475A REAR PANEL)		
283-0263-00			CAP., FXD, CER DI:0.0022UF, 20%, 3000V	59660	828556Y5R0222M
			(MOUNTED ON 475A REAR PANEL)		
283-0068-00			CAP.,FXD,CER DI:0.01UF, +100-0%,500V	59660	871-533E103P
283-0000-00			CAP.,FXD,CER DI:0.001UF, +100-0%,500V	59660	831610Y5U0102P
283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V	59660	871-533E103P
283-0068-00			CAP.,FXD,CER DI:0.01UF, +100-0%,500V	59660	871-533E103P
283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V	59660	871-533E103P
283-0068-00			CAP.,FXD,CER DI:0.01UF, + 100-0%,500V	59660	871-533E103P
159-0038-00			FUSE,CARTRIDGE:3AG,15A,32V,FAST-BLOW	71400	AGC15
131-1333-00			CONNECTOR, RCPT, : POWER	80009	131-1333-00
151-0436-00			TRANSISTOR: SILICON, NPN	04713	SJE966
151-0436-00			TRANSISTOR: SILICON, NPN	04713	SJE966
151-0436-00			TRANSISTOR: SILICON, NPN	04713	SJE966
151-0436-00			TRANSISTOR: SILICON, NPN	04713	SJE966
308-0349-00			RES.,FXD,WW:3.6K OHM,1%,3W	91637	RS2B-36000F-TR
260-0834-00			SWITCH.TOGGLE:DPDT.5A.125VAC.0.25-40 THD	09353	U21-SHZQE
105-0479-00					105-0479-00
260-0760-00			SWITCH,SENS:SUBMINIATURE,10A,125/240VAC	01963	E62-10A
	Part No. 290-0667-00 283-0032-00 283-0263-00 283-0263-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 159-0038-00 159-0038-00 151-0436-00 151-0456-00 151-0456-00 151-0456-00 151-0456-00 151-0456-00 151-0456	Part No. Eff 290-0667-00 283-0032-00 283-0263-00 283-0263-00 283-0263-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 159-0038-00 151-0436-00 151-0436-00 151-0436-00 151-0436-00 151-0436-00 308-0349-00 260-0834-00 105-0479-00 105-0479-00	Part No. Eff Dscont 290-0667-00 283-0032-00 283-0263-00 283-0263-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 283-0068-00 159-0038-00 151-0436-00 151-0436-00 151-0436-00 151-0436-00 151-0436-00 151-0436-00 308-0349-00 260-0834-00 105-0479-00	Part No. Eff Dscont Name & Description 0PTION 07 0PTION 07 290-0667-00 CAP.,FXD,ELCTLT:330UF,+75-10%,50V 283-0032-00 CAP.,FXD,CER DI:470PF,5%,500V 283-0263-00 CAP.,FXD,CER DI:0.0022UF,20%,3000V	Part No. Eff Dscont Name & Description Code OPTION 07 290-0667-00 CAP.,FXD,ELCTLT:330UF,+75-10%,50V 56289 283-0032-00 CAP.,FXD,CER DI:470PF,5%,500V 59660 283-0263-00 CAP.,FXD,CER DI:0.0022UF,20%,3000V 59660 283-0263-00 CAP.,FXD,CER DI:0.0022UF,20%,3000V 59660 283-0263-00 CAP.,FXD,CER DI:0.002UF,20%,3000V 59660 283-0068-00 CAP.,FXD,CER DI:0.01UF,+100.0%,500V 59660

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon (199 4 OY Tel:- 01844-351694 hax- 01844-352554 Email:- enquines@mauritron.co.uk

REV MAR 1984

Option 7 Page 9

Ckt No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Name & Description	Mfr Code	Mfr Part Number
A3 A11	670-2240-04 670-2744-01		CKT BOARD ASSY:VERTICAL PREAMP CKT BOARD ASSY:INVERTER	80009 80009	670-2240-04 670-2744-01
C338	281-0 504-00		CAP.,FXD,CER DI:10PF,+/-1PF,500V	04222	7001-COG-100F
C338 C338 C1026 C1026 C1026	 290-0524-00 		(SEE DIAGRAM 3, C338 IS ADDED FROM BASE TO COLLECTOR OF Q338) CAPFXD,ELCTLT:4.7UF,20%,10V (SEE PARTIAL SCHEMATIC IN THIS SECTION OR GRAY TINT ON DIAGRAM 8)	90201	TDC475M010EL
C1603	283-0178-00		CAP.,FXD,CER DI:0.1UF, +80-20%,100V	72982	8131N145651 104Z
C1605 C1609 C1614 C1622 C1626 C1652	290-0531-00 283-0178-00 290-0573-00 290-0533-00 290-0528-00 283-0110-00		CAP.,FXD,ELCTLT:100UF,20%,10V CAP.,FXD,CER DI:0.1UF, + 80-20%,100V CAP.,FXD,ELCTLT:2.7UF,20%,50V CAP.,FXD,ELCTLT:330UF,20%,.6V CAP.,FXD,ELCTLT:15UF,20%,50V CAP.,FXD,CER DI:0.005UF, + 80-20%,150V	90201 72982 56289 90201 56289 59660	TDC107M010WLC 8131N145651 104Z 196D275X0050JA1 TDC337M006WLD 196D156X0050PE4 855-547-E-502Z
C1654 C1662 C1664	283-0110-00 283-0110-00 283-0110-00		CAP.,FXD,CER DI:0.005UF,+80-20%,150V CAP.,FXD,CER DI:0.005UF,+80-20%,150V CAP.,FXD,CER DI:0.005UF,+80-20%,150V	59660 59660 59660	855-547-E-502Z 855-547-E-502Z 855-547-E-502Z
CR1601 CR1624	152-0198-00 152-0333-00		SEMICOND DEVICE:SILICON,200V,3A SEMICOND DEVICE:SILICON,55V,200MA	03508 07263	1N5624 FDH-6012
CR1625 CR1626 CR1627 CR1628 CR1632 CR1634	152-0107-00 152-0107-00 152-0107-00 152-0107-00 152-0333-00 152-0333-00		SEMICOND DEVICE:SILICON,400V,400MA SEMICOND DEVICE:SILICON,400V,400MA SEMICOND DEVICE:SILICON,400V,400MA SEMICOND DEVICE:SILICON,400V,400MA SEMICOND DEVICE:SILICON,55V,200MA SEMICOND DEVICE:SILICON,55V,200MA	12969 12969 12969 12969 07263 07263	G727 G727 G727 G727 FDH-6012 FDH-6012
CR1643	152-0198-00		SEMICOND DEVICE:SILICON,200V,3A	03508	1N5624
L1026 L1026	108-0245-00 		COIL,RF:3.9UH (SEE PARTIAL SCHEMATIC IN THIS SECT OR DIAG	76493	B6310-1
Q1606	151-0301-00		TRANSISTOR:SILICON,PNP	27014	2N2907A
Q1608 Q1622 Q1626 Q1642 Q1644	151-0301-00 151-0302-00 151-0506-00 151-0302-00 151-0335-00		TRANSISTOR:SILICON,PNP TRANSISTOR:SILICON,NPN SCR:SILICON TRANSISTOR:SILICON,NPN TRANSISTOR:SILICON,PNP	27014 07263 03508 07263 04713	2N2907A S038487 C106B2X283 S038487 SJE917
R1604 R1605 R1607 R1609 R1611 R1613	315-0202-00 315-0752-00 315-0272-00 315-0511-00 315-0511-00 311-1248-00		RES.,FXD,CMPSN:2K OHM,5%.0.25W RES.,FXD,CMPSN:7.5K OHM,5%,0.25W RES.,FXD,CMPSN:2.7K OHM,5%,0.25W RES.,FXD,CMPSN:510 OHM,5%,0.25W RES.,FXD,CMPSN:510 OHM,5%,0.25W RES.,VAR,NONWIR:500 OHM,10%,0.50W	01121 01121 01121 01121 01121 73138	CB2025 CB7525 CB2725 CB5115 CB5115 72-23-0
R1614 R1617 R1618 R1622 R1623 R1624	315-0202-00 315-0102-00 315-0101-00 315-0102-00 316-0103-00 315-0302-00		RES.,FXD,CMPSN:2K OHM,5%,0.25W RES.,FXD,CMPSN:1K OHM,5%,0.25W RES.,FXD,CMPSN:100 OHM,5%,0.25W RES.,FXD,CMPSN:1K OHM,5%,0.25W RES.,FXD,CMPSN:10K OHM,10%,0.25W RES.,FXD,CMPSN:3K OHM,5%,0.25W	01121 01121 01121 01121 01121 01121 01121	CB2025 CB1025 CB1015 CB1025 CB1031 CB3025

Option 7 Page 10

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REV MAR 1984

Options—475A Service

	Tektronix	Serial/Mod	del No.		Mfr	
Jkt No.	Part No.	Eff	Dscont	Name & Description	Code	Mfr Part Number
R1625	316-0101-00			RES.,FXD,CMPSN:100 OHM,10%,0.25W	01121	CB1011
R1626	308-0450-00			RES.,FXD,WW:70 OHM,1%,3W	91637	RS2B-B70R00F
R1627	315-0271-00	B010445		RES.,FXD,CMPSN:270 OHM,5%,0.25W	01121	CB2715
R1631	308-0450-00			RES.,FXD,WW:70 OHM,1%,3W	91637	RS2B-B70R00F
R1633	311-1501-00			RES.,VAR,NONWIR:20 OHM,10%,0.50W	73138	72-37-0
R1639	315-0153-00			RES.,FXD,CMPSN:15K OHM,5%,0.25W	01121	CB1535
R1640	315-0102-00			RES.,FXD,CMPSN:1K OHM,5%,0.25W	01101	001005
R1641	315-0153-00			RES.,FXD,CMPSN:15K OHM,5%,0.25W	01121	CB1025
R1642	315-0473-00			RES.,FXD,CMPSN:47K OHM,5%,0.25W	01121	CB1535
R1645	307-0113-00			RES.,FXD,CMPSN:5.1 OHM,5%,0.25W	01121	CB4735
R1652	308-0459-00			RES.,FXD,WW:1.1 OHM,5%,3W	01121	CB51G5
R1654	308-0459-00			RES.,FXD,WW:1.1 OHM,5%,3W	91637	CW2B-1R100J TR
11100+	000-0400-00			RES.,FXD,WW.1.1 OHW,5%,5W	91637	CW2B-1R100J TR
R1662	308-0459-00			RES.,FXD,WW:1.1 OHM,5%,3W	91637	CW2B-1R100J TR
R1664	308-0459-00			RES.,FXD,WW:1.1 OHM,5%,3W	91637	CW2B-1R100J TR
T1601	120-0637-00			XFMR, TOROID:5 TURNS BIFILAR	80009	120-0637-00
T1631	120-0852-00			XFMR,TOROID:2 WINDINGS	80009	120-0852-00
	120-0002-00			AT MIR, TOHOID.2 WINDINGS	80009	120-0652-00
VR1604	152-0306-00			SEMICOND DEVICE:ZENER,0.4W,9.1V,5%	15238	Z5409
VR1605	152-0306-00			SEMICOND DEVICE:ZENER,0.4W,9.1V,5%	15238	Z5409 Z5409
VR1622	152-0241-00			SEMICOND DEVICE:ZENER.0.4W.33V.5%	04713	25409 SZG35009K5
VR1639	152-0279-00			SEMICOND DEVICE:ZENER.0.4W,53V,5%	04713	SZG35009R5
VR1641	152-0279-00			SEMICOND DEVICE:ZENER.0.4W.5.1V.5%	04713	SZG35010RL SZG35010RL
	.02 02/0-00			SEMICOND DEVICE.2ENER,0.444,3.14,5%	04713	320330 TUNE

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

Option 7 Page 11

Mfr Part Number

ORD BY DESCR

441-1171-00

AN960-3

75060-012

343-0443-00

212-0011-00

ORD BY DESCR

ORD BY DESCR

343-0451-00

348-0141-00

348-0055-00

ORD BY DESCR

3038-0228-402

ORD BY DESCR

ORD BY DESCR 12157-50

342-0229-00 407-1341-00

105-0479-00 E62-10A

386-2649-00

214-1925-00

U21-SHZQE

2X20224-402

179-1963-00

200-1414-03

334-2268-00

131-1333-00

348-0365-00

OBD

230

1214-05-00-0541C

2157-06-01-2520N

ORD BY DESCR

1206-00-00-0541C

ŝ.

357001

OBD

3046-402

Mfr Code

80009

83385

75497

22526

80009

80009

73743

83385

83385

80009

08530

80009

80009

75915

83385

78189

73743 80009

80009

83385

80009

80009

70903

Fig. & Index	Tektronix	Serial/Model N	0.		
No.	Part No.		cont Qty	12345	Name & Description
-1	441-1171-00		1	CHASSIS,SCOP	E:INVERTER ACHING PARTS)
	211-0008-00		2		NE:4-40 X 0.250, PNH, STL, POZ
	210-0938-00		2	WASHER, FLAT:	0.109 ID X 0.25 INCH OD,STL ATTACHING PARTS)*******
-2			1	•	SY:DC INVERTER(SEE A11 REPL)
-3	136-0252-07		15		ONN:W/O DIMPLE
-4			1	XFMR,TOROID	(SEE T1601 REPL) ACHING PARTS)
-5	343-0443-00		1	.RETAINER, XFM	
-6	212-0011-00		1		NE:8-32 X 0.750 INCH,FLH STL
-7	210-0409-00		1	NUT,PLAIN,HE>	K.:8-32 X 0.312 INCH,BRS ATTACHING PARTS)******* ACHING PARTS)*******
-8	211-0116-00		2		SHR:4-40 X 0.312 INCH,PNH BRS ATTACHING PARTS)*******
-9			4		SEE Q1652,Q1654,Q1662,Q1664 RI ACHING PARTS)********
-10	210-0586-00		3		WA:4-40 X 0.25,STL
-11	343-0451-00		1	RETAINER,XSTF	
-12	342-0195-00		1		ATE:0.70 X 3 INCHES LONG ATTACHING PARTS)*******
-13	348-0141-00		1	GROMMET, PLA	STIC:U-SHP,0.625 X 0.658 INCH
-14	348-0055-00		1	GROMMET, PLA	STIC:0.25 INCH DIA
-15	352-0031-00		1	FUSEHOLDER:3	AG FUSE ACHING PARTS)********
-16	211-0507-00		1	,	NE:6-32 X 0.312 INCH,PNH STL
-17	210-0006-00		1	,	#6 INTL,0.018 THK,STL CD PL
-18	210-0407-00		1		.:6-32 X 0.25 INCH,BRS ATTACHING PARTS)*******
	342-0229-00		1	INSULATOR, FILI	M:1 X 2.55 INCH
-19	407-1341-00		1		SW:ALUMINUM ACHING PARTS)********
-20	211-0101-00		2	SCREW, MACHIN	NE:4-40 X 0.25,100 DEG,FLH STL
-21	105-0479-00		1	•	TCH:SLIDE,INVERTER
-22	260-0760-00		6	SWITCH, SENS:S	SUBMINIATURE, 10A, 125/240VAC ACHING PARTS)
-23	211-0212-00		2		NE:2-56 X 1.75 INCH, PNH STL
-24	210-0405-00		1	NUT, PLAIN, HEX	.:2-56 X 0.188 INCH,BRS

		00000
6	SWITCH,SENS:SUBMINIATURE,10A,125/240VAC	01963
2	SCREW, MACHINE: 2-56 X 1.75 INCH, PNH STL	83385
1	NUT,PLAIN,HEX.:2-56 X 0.188 INCH,BRS	73743
1	PL,ACTR GUIDE:INVERTER	80009
1	SPRING, SW ACT: POWER SOURCE	80009
1	SWITCH,TOGGLE:DPDT,5A,125VAC,0.25-40 THD (ATTACHING PARTS)	09353
1	NUT, PLAIN, HEX.: 0.25-40 X 0.312 INCH, BBS	73743
1	WASHER,LOCK:0.261 ID,INTL,0.018 THK,BRS	78189
1	WIRING HARNESS: OPTION NO.7	80009
1	GROMMET, RUBBER: 0.50 INCH DIA	70485
1	COVER,SCOPE:REAR	80009
1	TERMINAL,LUG:0.146 INCH DIA DE,45 DEG BE	78189
1	MARKER,IDENT:	80009
1	CONNECTOR, RCPT, : POWER	80009
2	SCREW, MACHINE: 4-40 X 0.25, 100 DEG, FLH STL	83385

FOOT, CABINET: PLASTIC, W/LATCH GROOVE

CABLE ASSY, PWR, :3 WIRE, 36 INCHES LONG

ACCESSORIES

4

1

161-0094-00

386-2649-00

214-1925-00

260-0834-00

210-0562-00

210-0046-00

179-1963-00

348-0005-00

200-1414-03

210-0204-00

334-2268-00

131-1333-00

211-0101-00

348-0365-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Ovon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauntron.co.uk

REV MAR 1984

-25

-26

-27

-28

Option 7 Page 12





Fig. Option 7-10

Option 7 Page 13

REV OCT 1981

Options—475A Service

OPTION 78

This option adds a Type P11 phosphor CRT to the instrument.

Parts List Changes

DELETE:

V1380 154-0677-10 CRT, P31 Phosphor

ADD:

V1380 154-0677-14 CRT, P11 Phosphor

If this option is being added to an instrument which is already equipped with a different phosphor, or if the cathode-ray tube requires replacement, use the following procedure:

1). Follow the crt removal and installation procedure in the maintenance section of this manual.

2). After completing crt installation, check Table 4-5 (Recalibration After Repair) for calibration adjustments which may require re-adjustment.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tet- 01844-351694 Fax:- 01844-352554 Email:- enquines@mauritron.co.uk

The voltages and wa test set-ups listed below.	VOLTAGES AND WAVEFO	y using the recommended test equ
ITEM	RECOMMENDED TEST EQUIPME	· • • • • •
Test oscilloscope	SPECIFICATIONS	NT
Probe	Frequency responseDC to 75 MHzDeflection factor1 mV to 5 V/DivInput impedance1 MΩ 20 pFSweep rate50 nsFast-rise 10X attenuation probe compatible with vertical amplifier of testoscilloscope.	RECOMMENDED TYI Tektronix 7603 equipped with 7 Amplifier and 7B50 Time-base equivalent. Tektronix P6053B, or equivalent
Voltmeter (Non-loading Digital Multimeter) 475A Control Settings	Input Impedance 10 MΩ Range 0 to 500 V	Tektronix DM 501 Digital Multim equivalent.

4 ol Settings

	30		
Display Controls INTENSITY FOCUS SCALE ILLUM	Midrange Midrange Midrange	Sweep Controls TIME/DIV VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY	0.1 ms Calibrated detent Full counterclockwis A
Vertical Controls (CH POSITION VOLTS/DIV	Center trace on graticule 5 mV for do you	X10 MAG POSITION (Horiz) FINE	Off (button out) Midrange Midrange
VAR VOLTS/DIV	IV IOr Wayof	Voltage Measurements	
AC-GND-DC INVERT VERT MODE 100 or 20 MHz BW	Calibrated detent DC Off (button out) CH 1 Full bandwidth (Push in, then release)	Woltage measurements are and the trace positioned to the line. The voltmeter common ground. Waveform Conditions	is connected to chas.
Trigger Controls (A and B COUPLING LEVEL SLOPE SOURCE TRIG MODE A TRIGGER HOLDOFF	B) AC 0 + NORM	Apply the 475A calibrator sig. P6075 10X probe (supplied with +GATE (rear panel) through a 4 to test oscilloscope external tr cilloscope trigger source to exter for ac coupling. For waveforms w centerline labeled 0 V, set the tr input for dc coupling. Set test oscilloscope VOLTS/E trols as indicated on readout symb Tolerance of voltages and wave	42-inch 50-ohm BNC cabi rigger input. Set test os ernal and set vertical inpu which have the horizonta test oscilloscope vertical DIV and TIME/DIV con-
MAURITRO	vice Manuals Contact DN TECHNICAL SERVICES		

8 Cherry Tree Rd, Chinor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email: enquiries@mauritron.co.uk

The voltages and waveforms shown on this diagram were obtained by using the recommended test equip test set-ups listed below.

ITEM	RECOMMENDED TEST EQUIPME	NT.	
Test oscilloscope	SPECIFICATIONS		
Probe	Frequency responseDC to 75 MHzDeflection factor1 mV to 5 V/DivInput impedance1 MΩ 20 pFSweep rate50 nsFast-rise 10X attenuation probe compatible with vertical amplifier	equivalent.	
Voltmeter (Non-Ioading Digital Multimeter)	oscilloscope.	Tektronix P6053B, or equivalent.	
475A Control Settings	0 to 500 V	Tektronix DM 501 Digital Multimet- equivalent.	

4 or Settings

Display Controls Sweep Controls INTENSITY TIME/DIV Midrange FOCUS VAR TIME/DIV 0.1 ms SCALE ILLUM Midrange Calibrated detent DELAY TIME Midrange POSITION Full counterclockwise HORIZ DISPLAY X10 MAG А Off (button out) POSITION (Horiz) Vertical Controls (CH 1 and CH 2) Midrange FINE POSITION Midrange Center trace on graticule VOLTS/DIV 5 mV for dc voltages Voltage Measurements 100 mV for waveforms VAR VOLTS/DIV Calibrated detent AC-GND-DC Voltage measurements are taken with no signal appliec and the trace positioned to the center horizontal graticule INVERT DC line. The voltmeter common is connected to chassis Off (button out) VERT MODE 100 or 20 MHz BW CH 1 Full bandwidth (Push in, Waveform Conditions then release) Apply the 475A calibrator signal to CH 1 input through a P6075 10X probe (supplied with 475A). Connect 475A A +GATE (rear panel) through a 42-inch 50-ohm BNC cable to test oscilloscope external trigger input. Set test os-Trigger Controls (A and B) cilloscope trigger source to external and set vertical input COUPLING for ac coupling. For waveforms which have the horizontal AC LEVEL centerline labeled 0 V, set the test oscilloscope vertical SLOPE 0 input for dc coupling. SOURCE -+-NORM TRIG MODE Set test oscilloscope VOLTS/DIV and TIME/DIV con-A TRIGGER HOLDOFF NORM trols as indicated on readout symbols on each waveform. Tolerance of voltages and waveforms shown are 20%.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351594 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

The voltages and waveforms shown on this diagram were obtained by using the recommended test equipment ar test set-ups listed below.

RECOMMENDED TEST EQUIPMENT					
ITEM	SPECIFICATIONS				
Test oscilloscope	Frequency responseDC to TDeflection factor1 mV toInput impedance1 MΩ 2Sweep rate50 ns	5 V/Div Amplifier and 70 co T			
Probe	Fast-rise 10X attenuation prob patible with vertical amplifier c oscilloscope.	e com- De com- De test			
Voltmeter (Non-loading Digital Multimeter)	Input Impedance 10 MΩ Range 0 to 500 V	Tektronix DM 501 Digital Multimeter or equivalent.			

475A Control Settings

Display Controls INTENSITY FOCUS SCALE ILLUM	Midrange Midrange Midrange	Sweep Controls TIME/DIV VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY	0.1 ms Calibrated detent Full counterclockwise A	
Vertical Controls (CH 1 POSITION VOLTS/DIV	Center trace on graticule 5 mV for dc voltages	X10 MAG POSITION (Horiz) FINE	Off (button out) Midrange Midrange	
VAR VOLTS/DIV AC-GND-DC INVERT VERT MODE 100 or 20 MHz BW	100 mV for waveforms Calibrated detent DC Off (button out) CH 1 Full bandwidth (Push in, then release)	Voltage Measurements Voltage measurements are taken with no signal applied and the trace positioned to the center horizontal graticule line. The voltmeter common is connected to chassis ground. Waveform Conditions		
Trigger Controls (A and E COUPLING LEVEL SLOPE SOURCE TRIG MODE	AC 0 + NORM AUTO (for waveforms) SINGL SWP (for dc		trigger input. Set test os- ternal and set vertical input	
A TRIGGER HOLDOFF	voltages. READY light off).	Set test oscilloscope VOLT. trols as indicated on readout sy	S/DIV and TIME/DIV con- mbols on each waveform.	

off). A TRIGGER HOLDOFF NORM

Tolerance of voltages and waveforms shown are 20%.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tet- 01844-351804 Fax: 01844-352554 Email: enquines@mauniron.co.uk

475A Service

VOLTAGES AND WAVEFORMS

The voltages and waveforms shown on this diagram were obtained by using the recommended test equipment and test set-ups listed below.

ITEM	SPECIFICATIONS	RECOMMENDED TYPE		
Test oscilloscope	Frequency responseDC to 7Deflection factor1 mV toInput impedance1 MΩ 20Sweep rate50 ns	5 MHz Tektronix 7603 equipped with 7A13 5 V/Div Amplifier and 7B50 Time-base units or		
Probe	Fast-rise 10X attenuation probe patible with vertical amplifier o oscilloscope.			
Voltmeter (Non-loading Digital Multimeter)	Input Impedance 10 MΩ Range 0 to 500 V	Tektronix DM 501 Digital Multimeter or equivalent.		

RECOMMENDED TEST EQUIPMENT

475A Control Settings

Display Controls	
INTENSITY	Midrange
FOCUS	Midrange
SCALE ILLUM	Midrange

Vertical Controls (CH 1 ar	d CH 2)
POSITION	Center trace on graticule
VOLTS/DIV	5 mV for dc voltages
	100 mV for waveforms
VAR VOLTS/DIV	Calibrated detent
AC-GND-DC	DC
INVERT	Off (button out)
VERT MODE	CH 1
100 or 20 MHz BW	Full bandwidth (Push in,
	then release)

Trigger Controls (A and B)	
COUPLING	AC
LEVEL	0
SLOPE	+
SOURCE	NORM
TRIG MODE	AUTO (for waveforms)
	SINGL SWP (for dc
	voltages. READY light
	off).
A TRIGGER HOLDOFF	NORM

Sweep Controls TIME/DIV VAR TIME/DIV DELAY TIME	0.1 ms Calibrated detent
POSITION	Full counterclockwise
HORIZ DISPLAY	A
X10 MAG	Off (button out)
POSITION (Horiz)	Midrange
FINE	Midrange

Voltage Measurements

Voltage measurements are taken with no signal applied and the trace positioned to the center horizontal graticule line. The voltmeter common is connected to chassis ground.

Waveform Conditions

Apply the 475A calibrator signal to CH 1 through a P6075 10X probe (supplied with 475A). Connect 475A A +GATE (rear panel) through a 42-inch 50-ohm BNC cable to test oscilloscope external trigger input. Set test oscillosocpe trigger source to external and set vertical input for ac coupling. For waveforms which have the horizontal centerline labeled 0 V DC, set the test oscilloscope vertical input for dc coupling.

Set test oscilloscope VOLTS/DIV and TIME/DIV controls as indicated on readout symbols on each waveform.

Tolerance of voltages and waveforms shown are 20%.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

ŧ



(B) Board Location.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

REPLACEABLE **MECHANICAL PARTS**

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available. and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order. Part number, instrument type or number, serial number, and modification number if applicable

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number

Change information, if any is located at the rear of this manual

SPECIAL NOTES AND SYMBOLS

x000 Part first added at this serial number

00X Part removed after this serial number

FIGURE AND INDEX NUMBERS

Items in this section are referenced by figure and index numbers to the illustrations

ELCTRN

HEX SOC

ELECTRON

ELECTRICAL

INDENTATION SYSTEM

This mechanical parts list is indented to indicate item relationships. Following is an example of the indentation system used in the description column

12345

Name & Description

Assembly and or Component Attaching parts for Assembly and or Component Detail Part of Assembly and or Component Attaching parts for Detail Part

> . . . ' Parts of Detail Part Attaching parts for Parts of Detail Part

Attaching Parts always appear in the same indentation as the item it mounts, while the detail parts are indented to the right Indented items are part of, and included with, the next higher indentation. The separation symbol - - - * - - - indicates the end of attaching parts

Attaching parts must be purchased separately, unless otherwise specified.

ITEM NAME

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible

SE

S٤

so

ŚW

v

w

	INCH	ELCTRM
	NUMBER SIZE	ELEC
ACTR	ACTUATOR	ELCTLT
ADPTR	ADAPTER	ELEM
ALIGN	ALIGNMENT	EPL
AL	ALUMINUM	EOPT
ASSEM	ASSEMBLED	EXT
ASSY	ASSEMBLY	FIL
ATTEN	ATTENUATOR	FLEX
AWG	AMERICAN WIRE GAGE	FLH
BD	BOARD	FLTR
BRKT	BRACKET	FR
BRS	BRASS	FSTNR
BAZ	BRONZE	FT
BSHG	BUSHING	FXD
CAB	CABINET	GSKT
CAP	CAPACITOR	HDL
CER	CERAMIC	HEX
CHAS	CHASSIS	HEX HD
CKT	CIRCUIT	HEX SO
COMP	COMPOSITION	HLCPS
CONN	CONNECTOR	HLEXT
COV	COVER	HV
CPLG	COUPLING	ŀC
CRT	CATHODE RAY TUBE	ID
DEG	DEGREE	IDENT
DWR	DRAWER	IMPLR

ABBREVIATIONS

ELECTROLYTIC ELEMENT ELECTRICAL PARTS LIST EQUIPMENT EXTERNAL FILLISTER HEAD FLEXIBLE FLAT HEAD FILTER FRAME or FRONT FASTENER FOOT GASKET HANDLE HEXAGON HEXAGONAL HEAD HEXAGONAL SOCKET HELICAL COMPRESSION HELICAL EXTENSION HIGH VOLTAGE INTEGRATED CIRCUIT INSIDE DIAMETER IMPELLER

IN	INCH
INCAND	INCANDESCENT
INSUL	INSULATOR
INTL	INTERNAL
LPHLDR	LAMPHOLDER
MACH	MACHINE
MECH	MECHANICAL
MTG	MOUNTING
NIP	NIPPLE
NIP NON WIRE OBD OD PH BAZ PL PL PN PNH PWR RCPT RES RGD RLF RTNR	
SCH	SOCKET HEAD
SCOPE	OSCILLOSCOPE
SCR	SCREW

SINGLE END SECT SECTION SEMICOND SEMICONDUCTOR SHLD SHIELD SHOULDERED SHLDR SOCKET SLIDE SKT SLFLKG SELF-LOCKING SLEEVING SLVG SPR SPRING SOUARE SST STAINLESS STEEL STEEL STL SWITCH TUBE TERM TERMINAL THREAD THD THICK тнк TENSION TNSN TAPPING TPG TRH TRUSS HEAD VAR VARIABLE WITH WASHER WSHR TRANSFORMER XEMR TRANSISTOR XSTR

CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code	Manufacturer	Address	City, State, Zip
000BK	STAUFFER SUPPLY	105 SE TAYLOR	PORTLAND, OR 97214
000CY	NORTHWEST FASTENER SALES, INC.	7923 SW CIRRUS DRIVE	BEAVERTON, OR 97005
000EX	O'HARA METAL PRODUCT COMPANY	542 BRANNAN STREET	SAN FRANCISCO, CA 94107
00779	AMP, INC.	P.O. BOX 3608	HARRISBURG, PA 17105
01963	CHERRY ELECTRICAL PRODUCTS CORPORATION	3600 SUNSET AVENUE	WAUKEGAN, IL 60085
04811	PRECISION COIL SPRING COMPANY	P O BOX 5450, 10107 ROSE ST.	EL MONTE, CA 91734
05006	TWENTIETH CENTURY PLASTICS, INC.	415 E WASHINGTON BLVD.	LOS ANGELES, CA 90015
05129	KILO ENGINEERING COMPANY	2015 D	LA VERNE, CA 91750
05820	WAKEFIELD ENGINEERING, INC.	AUDUBON ROAD	WAKEFIELD, MA 01880
06666	GENERAL DEVICES CO., INC.	525 S. WEBSTER AVE.	INDIANAPOLIS, IN 46219
07700	TECHNICAL WIRE AND PRODUCTS, INC.	129 DERMODY ST.	CRANFORD, NJ 07016
08261	SPECTRA-STRIP CORP.	7100 LAMPSON AVE.	GARDEN GROVE, CA 92642
08530	RELIANCE MICA CORP.	342-39TH ST.	BROOKLYN, NY 11232
09353	C AND K COMPONENTS, INC.	103 MORSE STREET	WATERTOWN, MA 02172
09922	BURNDY CORPORATION	RICHARDS AVENUE	NORWALK, CT 06852
12014	CHICAGO RIVET AND MACHINE CO.	950 S. 25TH AVENUE	BELLWOOD, IL 60104
12327	FREEWAY CORPORATION	9301 ALLEN DRIVE	CLEVELAND, OH 44125
12360	ALBANY PRODUCTS CO., DIV. OF PNEUMO		· · · · · · · · · · · · · · · · · · ·
	DYNAMICS CORPORATION	145 WOODWARD AVENUE	SOUTH NORWALK, CT 06586
13103	THERMALLOY COMPANY, INC.	2021 W VALLEY VIEW LANE	
	· · ·	P O BOX 34829	DALLAS, TX 75234
13511	AMPHENOL CARDRE DIV., BUNKER RAMO CORP.		LOS GATOS, CA 95030
22526	BERG ELECTRONICS, INC.	YOUK EXPRESSWAY	NEW CUMBERLAND, PA 17070
22670	G.M. NAMEPLATE, INC.	2040 15TH AVENUE WEST	SEATTLE, WA 98119
23050	PRODUCT COMPONENTS CORP	30 LORRAINE AVE.	MT VERNON, NY 10553
24011	ELECTRONIZED CHEMICALS CORPORATION	S BEDFORD STREET	BURLINGTON, MA 01803
24931	SPECIALITY CONNECTOR CO., INC.	2620 ENDRESS PLACE	GREENWOOD, IN 46142
28520	HEYMAN MFG. CO.	147 N. MICHIGAN AVE.	KENILWORTH, NJ 07033
28817	CAL-METEX CORP., SUBSIDIARY OF METEX		
	CORP.	509 HINDRY AVE.	INGLEWOOD, CA 90301
42838	NATIONAL RIVET AND MFG. CO.	1-21 EAST JEFFERSON ST.	WAUPUN, WI 53963
51316	ANGELUS WASHER AND STAMPING CO.	1411 ESPERANZA ST.	LOS ANGELES, CA 90023
56878	STANDARD PRESSED STEEL COMPANY	BENSON EAST	JENKINTOWN, PA 19046
57668	R-OHM CORP.	16931 MILLIKEN AVE.	IRVINE, CA 92713
63743	WARD LEONARD ELECTRIC CO., INC.	31 SOUTH ST.	MOUNT VERNON, NY 10550
70278	ALLIED STEEL AND CONVEYORS, DIV. OF		
	SPARTON CORP.	17333 HEALY	DETROIT, MI 48212
70485	ATLANTIC INDIA RUBBER WORKS, INC.	571 W. POLK ST.	CHICAGO, IL 60607
70903	BELDEN CORP.	2000 S BATAVIA AVENUE	GENEVA, IL 60134
71159	BRISTOL SOCKET SCREW, DIV. OF		
	AMERICAN CHAIN AND CABLE CO., INC.	P O BOX 2244, 40 BRISTOL ST.	WATERBURY, CT 06720
71279	CAMBRIDGE THERMIONIC CORP.	445 CONCORD AVE.	CAMBRIDGE, MA 02138
71400	BUSSMAN MFG., DIVISION OF MCGRAW-		
	EDISON CO.	2536 W. UNIVERSITY ST.	ST. LOUIS, MO 63107
71590	CENTRALAB ELECTRONICS, DIV. OF		- ,
	GLOBE-UNION, INC.	P O BOX 858	FORT DODGE, IA 50501
1785	TRW, CINCH CONNECTORS	1501 MORSE AVENUE	ELK GROVE VILLAGE, IL 60007
73743	FISCHER SPECIAL MFG. CO.	446 MORGAN ST.	CINCINNATI, OH 45206
73803	TEXAS INSTRUMENTS, INC., METALLURGICAL		
	MATERIALS DIV.	34 FOREST STREET	ATTLEBORO, MA 02703
4445	HOLO-KROME CO.	31 BROOK ST. WEST	HARTFORD, CT 06110
5497	LAMSON AND SESSIONS CO.	5000 TIEDEMAN ROAD	CLEVELAND, OH 44144
5915	LITTELFUSE, INC.	800 E. NORTHWEST HWY	DES PLAINES, IL 60016
7250	PHEOLL MANUFACTURING CO., DIVISION		
	OF ALLIED PRODUCTS CORP.	5700 W. ROOSEVELT RD.	CHICAGO, IL 60650
8189	ILLINOIS TOOL WORKS, INC.		
	SHAKEPROOF DIVISION	ST. CHARLES ROAD	ELGIN, IL 60120
9136	WALDES, KOHINOOR, INC.	47-16 AUSTEL PLACE	LONG ISLAND CITY, NY 11101
9807	WROUGHT WASHER MFG. CO.	2100 S. O BAY ST.	MILWAUKEE, WI 53207
0009	TEKTRONIX, INC.	P O BOX 500	BEAVERTON, OR 97077
0033	PRESTOLE EVERLOCK, INC.	P. O. BOX 278,1345 MIAMI ST.	TOLEDO, OH 43605
0126	PACIFIC ELECTRICORD CO.	747 W. REDONDO BEACH,P O BOX 10	GARDENA, CA 90247
3294	ARROW FASTENER CO., INC.	271 MAYHILL ST.	SADDLE BROOK, NJ 07662
3385	CENTRAL SCREW CO.	2530 CRESCENT DR.	BROADVIEW, IL 60153
4256	AVIBANK MFG., INC.	210 S VICTORY BLVD, PO BOX 391	BURBANK, CA 91503
	PENN FIBRE AND SPECIALTY CO., INC.	2032 E. WESTMORELAND ST.	PHILADELPHIA, PA 19134
6445			
16445 16928	SEASTROM MFG. COMPANY, INC.	701 SONORA AVENUE	GLENDALE, CA 91201

REV DEC 1984

For Service Manuals Contact MAURITRON LECHINICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel: 01844-351694 Fax:- 01844-352554 Email: enquires@mauritron.co.uk

City, State, Zip

STATESVILLE, NC 28677 VAN NUYS, CA 91409 NEW YORK, NY 10007 SAN JOSE, CA 95112 TUCKAHOE, NY 10707 MANSFIELD, OH 44903 ROCKFORD, IL 61101 IRVINGTON, NJ 07111

SOUTH PASADENA. CA 91030

SANTA ROSA, CA 95406

-

CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER

Mfr. Coo	de Manufacturer	THE CODE NUMBER TO MA
		Address
88245 89663 91260 91836 93410 93907 97464	DIV. LITTON SYSTEMS. INC., USECO DIV. REESE, J. RAMSEY, INC. CONNOR SPRING AND MFG. CO. KINGS ELECTRONICS CO., INC. ESSEX INTERNATIONAL, INC., CONTROLS DIV. LEXINGTON PLANT TEXTRON INC. CAMCAR DIV	P. O. BOX 1360 13536 SATICOY ST. 71 MURRAY STREET 1729 JUNCTION AVE. 40 MARBLEDALE ROAD P. O. BOX 1007
98278	INDUSTRIAL RETAINING RING CO. MALCO A MICRODOT COMPANY, INC. CONNECTOR AND CARLE DIVISION	600 18TH AVE 57 CORDIER ST.
S3109	C/O PANEL COMPONENTS CORP.	220 PASADENA AVE. P.O. BOX 6626

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

REV DEC 1984

Fig. &

Index Tektronix Serial/Model No. No. Part No. Eff Dscont Qty 12345 Mfr Name & Description Code Mfr Part Number 1-1 200-1411-00 RTNR,IMPLOSION:5.422 X 4.743 X 0.441,GRAY 1 -2 213-0313-00 THUMBSCREW: 4-40 X 0.45 INCH,KNURLED 4 -3 80009 337-1674-00 200-1411-00 SHLD, ELCTRN TUB: CRT 1 80009 -4 366-0494-00 213-0313-00 KNOB: GRAY WITH SETSCREW 2 80009 213-0153-00 337-1674-00 1 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 -5 366-0494-00 366-1031-02 2 KNOB:RED,VAR,0.127 ID X 0.392 OD 000CY ORD BY DESCR 213-0153-00 1 SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 -6 366-1031-02 366-1425-02 2 KNOB: VOLTS/DIV 000CY 213-0153-00 ORD BY DESCR 2 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 -7 366-1425-02 366-0215-02 2 KNOB:LEVER SWITCH -8 000CY ORD BY DESCR 366-1402-31 PUSH BUTTON: GRAY -- INVERT -9 1 80009 366-0215-02 366-1402-42 PUSH BUTTON:--BEAM FINDER 80009 -10 1 366-1257-20 366-1402-31 PUSH BUTTON: GRAY -- CH2 80009 -11 366-1402-42 366-1402-37 1 PUSH BUTTON: GRAY -- CHOP 80009 -12 366-1257-16 366-1257-20 PUSH BUTTON: GRAY -- ADD 1 80009 -13 366-1402-37 366-1402-36 1 PUSH BUTTON: GRAY -- ALT 80009 -14 366-1257-16 366-1257-19 1 PUSH BUTTON: SIL GY, CH 1 80009 -15 366-1402-36 366-1023-01 3 KNOB:GY,0.127 ID X 0.392 OD X 0. 80009 366-1257-19 213-0153-00 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 1 -16 366-1023-01 366-1402-33 PUSH BUTTON:GRAY-X10 1 000CY ORD BY DESCR -17 366-1327-00 80009 1 KNOB:GRAY 366-1402-33 213-0153-00 1 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 -18 366-1327-00 366-1280-00 1 000CY KNOB:GRAY ORD BY DESCR 213-0153-00 1 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 -19 366-1278-00 366-0494-00 KNOB: GRAY WITH SETSCREW 1 000CY ORD BY DESCR 213-0153-00 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 1 -20 366-0494-00 366-1346-02 000CY ORD BY DESCR KNOB:RED 213-0153-00 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 1 -21 366-1346-00 366-1219-01 KNOB:GRAY--DLYD SWP 000CY ORD BY DESCR 1 213-0890-00 80009 2 .SETSCREW:6-32 X 0.25 L,STL BLK OXD -22 366-1219-01 354-0442-02 RING, KNOB SKIRT: PLASTIC, 1.45 INCH DIA 83294 ORD BY DESCR 213-0004-00 B010100 B012387 .SETSCREW:6-32 X 0.188 INCH, HEX.SOC S 80009 1 354-0442-02 213-0004-00 B012388 SETSCREW:6-32 X 0.188 INCH, HEX.SOC S 74445 2 ORD BY DESCR 384-1087-00 74445 SHAFT, PUSH, ACTR: 0.76 L X 0.065 STEPPED -23 ORD BY DESCR 401-0080-00 B010100 B012224 BRG,KNOB SKIRT:0.789 ID X 0.866 OD PLASTIC 80009 1 384-1087-00 401-0080-01 B012225 BRG,KNOB SKIRT:0.789 ID X 8.66 OD PLASTIC 80009 401-0080-00 -24 366-1489-36 PUSH BUTTON: GRAY -- A LOCK KNOBS 80009 -25 1 401-0080-01 366-1402-29 PUSH BUTTON: GRAY -- MIX 80009 366-1489-36 -26 1 366-1402-44 PUSH BUTTON: GRAY -- A INTEN 80009 366-1402-29 -27 1 366-1402-35 PUSH BUTTON:GRAY -- B DLY'D 80009 1 366-1402-44 -28 366-1402-38 80009 PUSH BUTTON: GRAY -- AUTO 366-1402-35 -29 366-1402-39 1 80009 PUSH BUTTON: GRAY -- NORM -30 366-1402-38 366-1257-29 PUSH BUTTON: SIL GY, SINGL SWP 80009 1 366-1402-39 -31 366-1278-00 80009 2 KNOB:GRAY 366-1257-29 213-0153-00 80009 1 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 366-1278-00 -32 366-1280-00 000CY 2 ORD BY DESCR KNOB:GRAY 213-0153-00 .SETSCREW:5-40 X 0.125,STL BK OXD,HEX 80009 1 366-1278-00 -33 358-0378-01 B010100 B012559 000CY BUSHING, SLEEVE: 0.250 OD X 0.131 ID, PRESS M 12 ORD BY DESCR 358-0378-01 B012560 BUSHING, SLEEVE: 0.250 OD X 0.131 ID, PRESS M 9 80009 358-0378-01 358-0599-00 B012560 80009 3 BUSHING, SLEEVE: 0.125 ID X 0.234 THK, PLSTC 358-0378-01 (ATTACHING PARTS) 28520 B-187-125 210-0540-00 6 NUT, PLAIN, HEX.: 0.312-18 X 0.50 INCH, STL 210-0583-00 75497 NUT,PLAIN,HEX:0.25-32 X 0.312 INCH,BRS 3 ORD BY DESCR 210-0940-00 73743 3 WASHER, FLAT: 0.25 ID X 0.375 INCH OD, STL 2X20317-402 (END ATTACHING PARTS) 79807 ORD BY DESCR -34 358-0216-01 B010100 B025889 2 -35 GROMMET, PLASTIC: 378-0803-01 80009 2 LENS,LIGHT:CLEAR,ATTENUATOR 358-0216-01 -36 426-0681-00 80009 16 FR, PUSH BUTTON: 378-0803-01 378-0803-00 5 LENS,LIGHT:CLEAR 80009 426-0681-00 80009 1 378-0803-00 RES., VAR, WW: (SEE R930 REPL) (ATTACHING PARTS) 331-0328-00 DIAL,CONTROL:10 TURN FOR 0.25 DIA SHAFT 1 213-0048-00 05129 461-S-70 1 .SETSCREW:4-40 X 0.125 INCH,HEX SOC S 74445 ORD BY DESCR

(END ATTACHING PARTS)

For Service Manuals Contact MAURITRON TECHNICAL SERVICES

8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquines@mauritron.co.uk

-37

-38

-39

ALC: NO

Fig. &

	Index Tektr No. Part		Serial/Model	NO.					
	No. Part	<u>No.</u> E		Dscont	011	1.0.0.			
	1.00				Qty	12345	Name & Description		Mfr
	1-40 378-0	635-00							Code Mfr Part Num
	-41 384-1 -42				4	LENS,LIGHT:W	'HITE		Code Mfr Part Num
	42				1	EXTENSION SE		A	378-0635-00
	44				1	RES., VAR, NON	WIR:A TRIGGER(SEE R530 REPL WIR:B TRIGGER(SEE R530 REPL	8 8	0,0-0033-00
	45				1	RES., VAR.NON	WIR:A TRIGGER(SEE R530 REPL WIR:B TRIGGER(SEE R750 REPL WIR:TRIG HOLDOSTING	_)	0009 384-1162-01
		-			1	RES., VAR, NONI	WIR:B THIGGER(SEE R750 REPL WIR:TRIG HOLDOFF(SEE R644 R	.)	
	-46 210.050				1	RES., VAR, NONV	WIR: I HIG HOLDOFF(SEE R644 R WIR: POSITION(SEE R1119 REPL)	IEPL	
	410-036	83-00			1	ATT	ACHING PARTS))	
	-47 210-094	40-00			1	NUT, PLAIN, HEX	:0.25-32 X 0.312 INCH,BRS		
	48 333 165					WASHER, FLAT:C	0.25 ID X 0.375 INCH, BRS	73	743 2X20317-402
	.48 333-163 49 131-095	6-04			1		ATTACHING PARTS)		807 ORD BY DESCR
	131-095	5-00							OND DT DESCR
-{	50 210-025	5.00				CONN, RCPT, ELE	C:BNC,FEMALE	80	009 333-1636-04
	210-025	5-00				-1A11A		13	511 31-279
-5	51 119-0373	2.00				ERMINAL,LUG:(D.391 ID,LOCKING,BRS CD PL		
		5-00			1 (COIL,CAL:	D.391 ID,LOCKING,BRS CD PL TTACHING PARTS)	800	09 210-0255-00
-5	2 210-0586	-00				*****************	, 		
-5	3 210-0851	-00			2 N	UT PL ASSEN	CHING PARTS	800	09 119-0373-00
-54	4 210-0811.	-00						_	
-55	^o 361-0059.	01		2	2 N	VSHR SHOLLDER	19 ID X 0.375 INCH OD,ST	781	
-56	210-0593-	00		1	1 IN	SULATOR DI AT	RED:0.125 ID X 0.50 INCH OD,ST 1 092 X 0.50 INCH OD	1232	ORD BY DESCR
_				2	2 N	UT.FINISHING O	25 US3 X 0.343 X 0.125 INC	8692	8 5604-47
-57	352-0340-	00			**	***********************	CHING BUS	8000	001-0039-01
				2	LA	AMPHOLDER SC	ACTING PARTS)	8000	9 210-0593-00
-58	211-0001-0	00			•••	(ATTAC)	HING DADES	8000	0
				2	SC	REW, MACHINE	2-56 X 0.25 INCH, PNH STL	0000	9 352-0340-00
50	344-0339-0	0 B02589	90		•••	(END ATT	2-56 X 0.25 INCH,PNH STL ACHING PARTS)	87308	000
-59	348-0276-0	0		2	CL	IP,GROUND:ATTI	EN SWITCH SHAFT,CU-BE		B ORD BY DESCR
-60 -61				FT	Г SH	LD,GSKT,ELEK:0	.026 OD NPRN W/WIRE NET CO	80009	244.0000
-62	352-0329-00	0		1	CK	T BD ASSY:CRT	SCALE ILLIUM(SEE A10 REPL)	28817	V-+-0339-00
-63	378-0728-00)		1	.LA	MPHOLDER:SCA	LE ILLIUM(SEE A10 REPL)		01-0404-3719
-64	175-0825-00)		1				80009	352-0329-00
-65	131-0707-00	1		FT	.WI	RE,ELECTRICAL	2 WIRE RIBBON	80009	378-0728-00
-66	352-0169-02			2 1		CONCELED 22		80009	175-0825-00
-67	386-2340-00			4	.HL[DR.TERM CONN	2 WIRE RED	22526	47439
	426-1108-01				00,	UNI UNI FROM	JT.	80009	352-0169-00
-68	213-0183-00			'	-HA	ME SECT, CAB .: F	RONT	80009	386-2340-00
-	213-0183-00			4		ATTACHU	C DADTO	80009	426-1108-01
-69	337-1688-00	.				, IPG, THD FOR:6	20 X 0.5 TYPE B.PNH,STL		
	337-1688-03	B010100	B013902	1	SHIP	END ATTAC	20 X 0.5 TYPE B,PNH,STL CHING PARTS)	83385	ORD BY DESCR
	00/01008-03	B013903		1					
-70	211-0065-00	Data						80009	337-1688-00
	211-0661-00	B010100	B020319	3	SCRF		G PARTS)	80009	337-1688-03
		B020320		3	SCRF	W MACHINE:4-4(X 0.188 INCH, PNH STL	770	
71	348-0115-00				******	*****/FND ATTA ~:	X 0.188 INCH,PNH STL X 0.25 INCH,PNH,STL	77250	ORD BY DESCR
72				1	GROM	MET PLASTIC	IX 0.25 INCH.PNH.STL HING PARTS)	78189	ORD BY DESCR
				1	CKT B	OARD ASSY. FAL	-SHP,0.548 X 0.462 INCH	80009	
73	213-0088-00				******	ATTACHING	MOTOR(SEE A6 REPL)	00009	348-0115-00
				2	SCR,T	PG THD CTG 4 2	1 PAR (S)		
					*******	END ATTACH	A X 0.25 INCH, PNH STL	83385	
4	136-0269-02	B010100	D010000	-	CKT BO	DARD ASSY INCL	UDEO	00000	ORD BY DESCR
5	131-0608-00		B016200	1					
6	136-0252-07			2				09922	DII 81400 100
	136-0220-00			-				22526	DILB149P-108 48283-036
	136-0350-00			-		IN ELEK: TRANC	ISTOD & AAL		75060-012
,				-	.SOCKE	T.PLUG-IN:3 PIN	LOW PROFILE		133-23-11-034
	426-0781-00						REPLY		136-0350-00
	337-1762-00			•	- NOON I	MUTOR:			
	426-0781-00			1	SHLD,EL	ECTRICAL FAN I	MOTOR	80009	426-0781-00
				1 1	MOUNT	MOTOR:		80000	
	010 000					MOTOR:		80009 (337-1762-00
	213-0088-00			•	********	****(ATTACHING	ARTS)		337-1762-00 \$26-0781-00
	213-0088-00			2 5	SCR.TPG	THD CTG: 4 24 A	ARTS) (0.25 INCH,PNH STL G PARTS)		337-1762-00 \$26-0781-00

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 40Y Tet: 01844-351694 Fax: 01844-352554 Email: enguines@maurikon.co.uk

9-5

	Fig. &										
	Index No.	Tektronix	Serial/M	lodel No.							
	<u>NO.</u>	Part No.	Eff	Dscor							
	1-82			DSCO		⊇ty	12345	•.			
	1-82							Name & Descripti	on	1	Mfr
	-83	11.00.0			1		TRANSISTOR				Code Mfr Part
	-84	11-0012-00 10-0205-00			•			CHAS MTG(SEE Q1318 RE ACHING PARTS)	EPU		
	-85 3	58-0214-00			2 1		SCHEW MACH		•		
	••				2		I ERMINAL LUC	A CONSTRAINT			
	-86 2 -87 AC	4-1610-00			-						3385 ORD BY D
	-67 40	7-1153-00			1	1	HEAT SINK FL	HG:0.25 DIA X 0.188 INCH ATTACHING PARTS)******	· L		5442-7
	-88 21				1		JHACKET VOTO	OUTOR		24	011 ORD BY DE
	- 21	0-0586-00			-	•	······/ATTA	ALUMINUM		80(214-1610-00
	-89 34/	-0339-00			2	N	UT.PL,ASSEM	CHING PARTS) VA:4-40 X 0.25, STL CD PL		800	009 407-1153-00
		-0039-00			4		***********/END		-	-	
	-90 212	0020-00			7	- F(PAR [S]******		781	89 211-041800-0
	•.				4	S	ATTAC	VCORD WRAP		800(
	348.	0349-00				***	MACHINE	HING PARTS)******* :8-32 X 1.0 INCH,PNH STI TACHING PARTONI		0000	348 -0339-00
	426-	0970-00			FT	SH	LD GSKT EL	:8-32 X 1.0 INCH,PNH STI TACHING PARTS)*******	L.	9390	
-	-93 211.0	516			1	- FR	SECT CAR	UIA 2 75 ET 1			ORD BY DES
		516-00			2		ATT O			0770	
	94 378-0	044-01			2	SCI	REW, MACHINE	HING PARTS) -32 X 0.875, PNH STL, CD		80008	426-0970-00
-{	95 131-0	955-00			1	Eur	END ATT	5-32 X 0.875, PNH STL, CD ACHING PARTS)*******	PL	8200-	
.9					4	CON	ER ELEM,AIR:2	5 X 2.5 X 0 25		83385	ORD BY DESC
-5	210-0	55-00				*****	IN,RCPT,ELEC:E	INC, FEMALE		80009	
-9	7 131 07	•			4 ·	TERI	MINALLUGA	ING PARTS)		13511	378-0044-01 31-279
	/ 131-07	/1-00			•	******	THEND IT	" ID, LUCKING BRS CD D			01-2/9
-98	620-05/	1 00				CON			-	80009	210-0255-00
-99	210-00	2-00			-		ATTA OUN	UNCK DISCONNE	Ст	0	
-10	_			2		чо л. г		····••)		91836	1904-2M58
-10	J00-240	B-00				*****	ER,LOCK:INTL,	A X 0.437 INCH 0.384 ID,INTL,0.022 TH		73743	000 -
-101	334-337	9-00 B012	950	1	PL	LATE	CONNI NATO			78189	ORD BY DESCR
	200-141. 200-1414	-06 B010	100 B022	1	M,	ARK	ER IDENT MAR	UMINUM ED GROUND SYMBOL			1220-02-00-05410
		-13 B023	830		CC	OVEF	R.SCOPE:REAR	ED GROUND SYMBOL		80009	38 6-2408-00
-102	211-0101	.00		1	- CC	JVFA	SCODE			80009	33 4-3379-00
				2			ATTA OLIVIA	PARTS)		80009 80009	200-1414-06
-103					****	·····	MACHINE:4-40	ARTS) MARTS) DEG, STL		00009	200-1414-13
.00	200-1399-	02		•	CON	VER	(END ATTACH INCLUDES:	X 0.25, FLH, 100 DEG, STL ING PARTS)		83385	
-104	105-0616- 378-0807-0	00		1	.CO	VER.	FAN IMPLE	,			ORD BY DESCR
	131-1333-(1		UP.F					
	210-0586-0	002303	10	1				(0.020.4)		80009	200-1399-02
	211-0038-0	D02000	0	2	CON	INEC	TOR, RCPT, POV	VER		0009	105-0616-00
-105 -106	200-1445-0		0	2							378-0807-01
100	352-0102-00)		1	Cov	ASC	MACHINE:4-40 X Y,LINE V:	X 0.25,STL CD PL 0.312,FLH,100 DEG		-	131-1333-00
107	212 0747			1	.+USE	EHOI	DEP.0 analy		83	385 0	211-041800-00 DRD BY DESCR
	213-0717-00 214-077 3- 03			•	.******		ATTACHING PA	UBE FOR CRTG FUS		2003 2	00-1445-01
				2 2	SCRE	EW T	PG TE A AN	(13)	80	009 3,	52-0102-00
108	204-0549-01	Pototos			.NUT,F	PLAII	N:6-32 X 0.324 D ND ATTACHING	A PRS OF T	03		
	204-0549-03	B010100 B017260	B017259	1	BODY	(E	ND ATTACHING	IA.BRS CD PL PARTS)	800	0	RD BY DESCR
09		2017260		1	BODY	ASS	Y,LINE:			21	4-0773-03
10	210-0407-00					*****	ATTA OLIVIA		800	09 20.	4-0549-01
-	210-0006-00			2	NUT,PL	AIN	ATTACHING PA (ATTACHING PA) HEX.:6-32 X 0.24 OCK:#6 INTL 0.0	PTS)******	800	09 204	4-0549-01 4-0549-03
				4	WASHE	BIC	0.2	NCH.BRS	34-		
	131-1318-01				********	***/EI	ND ATT O	18 THK,STL CD PI	7374	000	8-0228-402
	214-0778-00	B0toto-		- 1	SODY LI	INE \	VOLTAGE	-AHIS)*******	7818	9 120	6-00-00-0541C
	214-0778-01	B010100 B017260	B017529	1		DNDL	JCTOR:				
	210-0666-00	~~./200		1 .0	CONTAC	SSY	ELEC:LINE V S	EL.LOW/MED/HI	8000	1.31	1318-01
	344-0135-00			t	IVET TI	UBU	AD ANA		80009		0778-00
				2.0	LIP,ELE	ECTR	LAR:0.188 L X 0	125 OD,BRS BE ALBALOY PL	80009	214-(0778-01
							CUSE,CU	BE ALBALOY PI	12014	3329.	-3-16LONG
									80009		135-00

For Service Manuals Contact MAURITRON TECHTOR SERVICES 8 Cherry Troc Re Chinnor Oxon OX9 4 QV Tel: 01844-351694 Fax: 01844-35254 Email: enquiries@mauritron.co.uk

REV DEC 1984

9-6

Fig.	&
------	---

Index No.	Tektronix Part No.	Serial/I Eff	Model No. Dscont	•						
			DSCON	Qty	1	2	3	4	5	
1-111	161,0032.07									

	Part No.	Eff	Dscont	O +				
			200011	Qty	12345	Name & Description		Mfr
1-1	111 161-0033-07	7				diffe d Description		Code Mfr Part Number
	161-0033-35		-	1	CABLE ASSV D	ND O HUN-		Code Mfr Part Numbe
		5 B022405	2	1	CABLE ASSY D	WR.:3 WIRE.92 INCH LONG		
	161-0033-36	Deee	_	-				161-0033-07
		B022405)	1,			5	3109 ORD BY DESCR
	161-0033-37		6		OPTION AD UNIT	VR:3,0.75MM SQ.240V,91.0 L	_	
		B022405		1 a.	CARLE ADDI	TED KINGDOM ONLY)	8	0126 ORD BY DESCR
	161-0033-38				COLL NOOT PM	R'307ELALA GAGUES		
		B022405		1			S	3109 ORD BY DESCR
					CHUCK ASST PW	18.3 19 ANNO OLONIA		22061
-112	050.000			•			80	126 13E67.5E-TC
-113	000-00/1-00							
-114				1				
-114	358-0372-00			1	CABLE, NIP., ELEC	:0.265 ID X 0.38"OD W/FLG	80	009 358-0371-00
				1	BSHG,STRAIN RL	F:180 DEG,0.156" DIA HOLE	800	200-1004-00
	334-1529-00	B022405					800	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
				1				358-0372-00
-115	386-2332-01			-	(OPT. A1,A2,A3,A4)	800	00 201 1755
				ł	PANEL REAR I INC	VOIT	000	09 334-1529-00
-116	211-0105-00				·····		800	00 000
-117	211-0038-00			1	SCREW MACHINE	HING PARTS)	800	09 386-2332-01
-118	210-0201-00						000	
-119	210-0586-00			1	ERMINAL LUO	4-40 X 0.312,FLH,100 DEG	833	OND DI DESCR
	210-0201-00	D0.1-					8338	ORD BY DESCR
	210-0202-00	B010100	B015314				8692	ORD BY DESCR
	210-0202-00	B015315					7818	19 211-041800-00
	210-0586-00	B010100	B015314				8692	8 ORD BY DESCR
	210-0457-00	B015315					7818	9 2104-06-00-2520N
-120				' N	UT, PL, ASSEM WA:	6-32 X 0.312,STL CD PL	7818	9 211-041800-00
-120	200-1459-00					CHING PARTS)	8338	5 ORD BY DESCR
				1 C	OVER,CRT:REAR	(Antis)		OND DI DESCH
-121	211-0008-00			••	ATTACH	NG PARTS	80009	200-1459-00
			2	2 S(REW, MACHINE 4	40 X 0.250,PNH,STL,POZ		200-1459-00
-122	386-2246-00			**	(END ATTA	40 X 0.250,PNH,STL,POZ CHING PARTS)	83385	
-123	348-0145-00		1	l SL	PPORT.CRT:REAP	CHING PARTS)	00000	ORD BY DESCR
-124	407-1128-00		1	GF	OMMET PLASTIC		80009	000.00
			1	BF	KT CRT SHIELD D	U-SHP,1.0 X 0.42 INCH		000-2240-00
-125	211-0507-00			••••	KT.CRT SHIELD:R	EAR,NYLON	80009	348-0145-00
-126	210-0803-00		3	SC		AR,NYLON	80009	407-1128-00
-127	210-0202-00		1				0000-	
-128	220-0419-00		1				83385	ORD BY DESCR
-129	210-0457-00		2				12327	ORD BY DESCR
	210-0457-00		1				78189	2104-06-00-2520N
-130	242 0000		•				83385	ORD BY DESCR
-131	343-0088-00		1				83385	ORD BY DESCR
								-10011
132			1	001		VICION	80009	343-0088-00
	343-0217-00					AIS(SEE L1385 REPL) B PARTS)******		
133	211-0147-00		1					
134	210-0994-00		2	SCR	EW.MACHINE A AO	X 0.25 INCH, PNH STL	80009	343-0217-00
135	210-0201-00		2	WAS	HER, FLAT: 0.125 ID	A 0.25 INCH, PNH STL	83385	045-0217-00 OBD DX D520-
	-		1				86928	ORD BY DESCR
36	337-1645-00			******	FND ATTACH	LUCKING, BRZ TIN PL	86928	5702-201-20
	136-0513-01		1		D,ELEC:CRT NEC		00320	ORD BY DESCR
37 1	136-0202-01		1	SOCH	ET,PLUG-IN:CRT	ĸ	80000	000
38 1	131-0707-00		1	SOC	(FT PLUC IN:CRT		80009	337-1645-00
39 <u>3</u>	352-0162-00		4	CONT	ET,PLUG-IN:14 PI	N	80009	136-0513-01
-	31-0472-01		1	HIDE	TERM OC	WG,BRS & CU BE GOLD	80009	136-0202-01
			2				22526	47439
	169-0031-01		1	00/11/	NULLELEU FEMALE	E Contraction of the second seco	80009	352-0162-00
\$1 •	05-0507-00			IMPLE	FAN,CENTR:		80009	131-0472-01
1 1 1	13-0022-00		1	.STOP	SFT END PLAS	TIC	80009	369-0031-01
11 1 2	10 000		1	SEIS	CREW: 4-40 X 0 189	INCLUSING AND A	80009	105-0507-00
11 11 2 12 34	48-0056-00		3	GROM	MET, PLASTIC:0.37		74445	ORD BY DESCR
11 11 22 12 34 3 34	48-0056-00 48-0253-00							
11 11 22 12 34 3 34 4 34	48-0056-00 48-0253-00 48-0063-00		1				80009	348-0056-00
11 11 22 34 3 34 4 34 34	48-0056-00 48-0253-00 48-0063-00 48-0064-00		1 2	GROM	MET.PLASTIC:BLA	CK,OBLONG,3.0X0.925	80009	348-0056-00
11 11 22 34 3 34 4 34 34	48-0056-00 48-0253-00 48-0063-00		1 2 2	GROM	MET, PLASTIC:BLA MET, PLASTIC:0.50 MET, PLASTIC:GRA	CK,OBLONG,3.0X0.925 INCH DIA	80009	348-0056-00 348-0253-00
11 11 22 34 3 34 4 34 34	48-0056-00 48-0253-00 48-0063-00 48-0064-00		1 2	GROMI GROMI CLIP,EL	MET, PLASTIC:BLA MET, PLASTIC:0.50 MET, PLASTIC:GRA	CK.OBLONG.3.OXO.925 INCH DIA Y.ROUND.0.582 ID	80009 80009 80009	348-0056-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Ro. Chinnor Oxon OX9 40Y Tel:-01844-351694 Fax--01844-352554 Email:-enquiries@mauritron.co.uk

Index	Tektronix	Serial/Mo	ođel No.					
No.	Part No.	Eff	Dscont	Qty	12345	Name & Description	Mfr	
			· · · · · · · · · · · · · · · · · · ·			Name a Description	Code	Mfr Part Numbe
1-146	211-0008-00			1	SCREW MACUIN			
-147	210-0586-00			1		NE:4-40 X 0.250, PNH.STL, POZ	83385	ORD BY DESCR
				•	··············	WA:4-40 X 0.25.STL CD PL ATTACHING PARTS)	78189	211-041800-00
-148				1		C:(SEE DL380 REPL)		
				·	······································	ACHING PARTS)		
-149	407-1138-00			1	BRKT,DELAY LIN			
-150	210-0457-00			1	NUT.PL.ASSEM	WA:6-32 X 0.312,STL CD PL	80009	407-1138-00
					(END A	TTACHING PARTS)	83385	ORD BY DESCR
				-	DELAY LINE INC	LUDES:		
	131-1002-02			1	CONN, DELAY LI			
	131-1313-00			1		EEDELAY LINE TERMINAL	80009	131-1002-02
151	260-0638- 00			1	SW, THERMOSTA	TIC:10A,240V,OPEN 75 DEG C	80009	131-1313-00
						CHING PARTS)	93410	430-364
152	213-0044-00			2	SCR, TPG, THD FC	DR:5-32 X 0.188 INCH,PNH STL	00007	
					(END A	TTACHING PARTS)	83385	ORD BY DESCR
153				1	XFMR, PWR, STPL	DN:(SEE T1400 REPL)		
						CHING PARTS)		
154	211-0538-00			2	SCREW, MACHIN	E:6-32 X 0.312"100 DEG,FLH	0000F	
155	210-0457-00			4	NUT, PL, ASSEM V	VA:6-32 X 0.312.STL CD PL	83385	ORD BY DESCR
					(END A	TACHING PARTS)	83385	ORD BY DESCR
				•	TRANSFORMER	INCLUDES:		
156	212-0522-00			4	SCREW, MACHIN	E:10-32 X 2.50",HEX HD STL	83385	
157	210-0812-00			4	.WASHER,NONME	TAL:#10.FIBER	86445	ORD BY DESCR
58	166-0457-00			4	INSUL SLVG, ELE	C:0.19 ID X 1.875"LONG MYLA	80009	ORD BY DESCR
59	200-1544-01			1	COVER, XFMR:3	L X 2.5 W X 0.65 INCH	80009	166-0457-00
60	210-0056-00			4	.WASHER,LOCK:S	PLIT,0.195 ID X 0.32" OD,P	83385	200-1544-01
61 60	220-0561-00			4	.NUT,PLAIN,HEX .:	10-32 X 0.25 INCH.BRS	80009	ORD BY DESCR
62	407-1066-00			1	.BRACKET, XFMR:	ALUMINUM	80009	220-0561-00
63	337-1763-01			1	SHIELD, ELEC: TRA	NSFORMER	80009	407-1066-00
64 67				1	TRANSISTOR:CH	AS MTG(SEE Q1458 REPL)	00009	337-1763-01
65 62				1	TRANSISTOR:CH	AS MTG(SEE Q1426 REPL)		
66				1	TRANSISTOR: CH/	AS MTG(SEE Q1448 REPL)		
67	211 0040 00				(ATTACHING	G PARTS FOR EACH XSTRI		
68	211-0012-00			1	SCREW, MACHINE	:4-40 X 0.375,PNH STL CD PL	83385	ORD BY DESCR
00	210-0071-00			1	WASHER, SPR TNS	SN:0.146 ID X 0.323" OD STI	78189	4706-05-01-0531
59	240.0160.00				(END AT	TACHING PARTS)******		
70	342-0163-00			3	INSULR, PLATE: XS	TR,0.675 X 0.625 X 0.001	80009	342-0163-00
71	441-1084-03			1	COIL, DEFLE: TRAC	E ROTATION(SEE L1386 REPL)		0.20.00.00
72	214-0291-00			1	CHASSIS,SCOPE:	MAIN	80009	441-1084-03
2	214-0291-00			1	.CONTACT,SPRING	G:1.188 X 0.375 X 0.25 INCH	80009	214-0291-00
	210-0633-01				ATTAC	HING PARTS)		
	210-0033-01			1	.EYELET,METALLI	C:0.20 DIA X 0.093 INCH LON	80009	210-0633-01
'3	175-0825-00				(END ATT	ACHING PARTS)		-
4	175-0826-00				WIRE, ELECTRICAL	.:2 WIRE RIBBON	80009	175-0825-00
5	175-0827-00			FT 1	WIRE, ELECTRICAL	.3 WIRE RIBBON	80009	175-0826-00
6	175-0828-00			FT (LABLE.SP.ELEC:4,	26 AWG,STRD.PVC JKT,RBN	08261	SS04267(1061)0C
7	175-0829-00				WIRE.ELECTRICAL	:5 WIRE RIBBON	08261	SS-0526-710610C
8	175-0830-00				WIRE ELECTRICAL	:6 WIRE RIBBON	08261	SS-0626-710610C
-	175-0833-00				WIRE, ELECTRICAL	:7 WIRE RIBBON	08261	SS-0726-710610C
	352-0171-00			FT N	WIRE, ELECTRICAL	10 WIRE RIBBON	08261	SS-1026-7
	352-0169-00			2 }	LDR, TERM CONN	1 WIRE, BLACK	80009	352-0171-00
	352-0161-00			2 1	ILDR, TERM CONN	2 WIRE,BLACK	80009	352-0169-00
	352-0162-00		4	\$ F	LUH. IERM CONN	3 WIRE, BLACK, 0.1 SPACING	80009	352-0161-00
_	352-0163-00		2		LDR, TERM CONN	4 WIRE BLACK	80009	352-0162-00
	352-0164-00				I DR TERM CONN	5 WIRE BLACK,0.1 SPACING	80009	352-0163-00
_	352-0165-00		1		LDR, TERM CONN		80009	352-0164-00
	352-0168-00		1	- F	LDR, TERM CONN		80009	352-0165-00
	131-0707-00			i4 C	LDR, TERM CONN	IU WINE,BLACK	80009	352-0168-00
_	131-0371-00				ONTAUT, ELEC:22-	26 AWG,BRS & CU BE GOLD	22526	47439
	131-1119-00		2		ONTACT, ELEC: FO	R NO.26 AWG WIRE	98278	122-0182-019
	210-0774-00				UNIAUI, ELEC: FO	R NO. 22-26 AWG WIRE	22526	75374-001
	210-0775-00		5	- E	TELET, METALLIC:	0.152 OD X 0.245 INCH L,	80009	210-0774-00
	343-0088-00		5		YELET, METALLIC: LAMP, LOOP:0.062	0.126 OD X 0.23 INCH L,	80009	210-0775-00

For Service Manuals Contact MAURITRON LECHNICAL SERVICES 8 Cherry Tree Rd. Chinnor Oxon OX9 4 QY Tel: 01844-351894 Fax: 01844-352554

Email:- enquiras@maunition.co.uk

REV DEC 1984

ŝ

9-8

NO	Part No.	Eff						
		-	Dscont	Qty	12345	Name & Description	Code	Mfr Part Numbe
	384-1159-00			1	EXTENSION SH	AFT:10.384 INCH LONG.W/KNOB	80000	204 1150 00
2	214-1756-00			1	ACTUATOR, SWI		80009 80009	384-1159-00 214-1756-00
3				1	SWITCH, TOGGL	E:POWER(SEE S1401 REPL) ACHING PARTS)	80009	214-1750-00
4	210-0562-00			1		:0.25-40 X 0.312 INCH, BBS	73743	2X20224-402
5	210-0046-00			1	WASHER,LOCK:	0.261 ID,INTL.0.018 THK,BRS ITTACHING PARTS)******	78189	1214-05-00-05410
6				1		INE SELECTOR(SEE S1403 REPL) ACHING PARTS)		
7	211-0101-00			2	·····(END A	IE:4-40 X 0.25,FLH,100 DEG,STL ITTACHING PARTS)******	83385	ORD BY DESCR
8	200-1526-00			1	CON, INV SW HO		80009	200-1526-00
9	407-1133-00			1		CHING PARTS)	80009	407-1133-00
10	210-0406-00			1		4-40 X 0.188,BRS,CD PL	73743	12161-50
11	210-0994-00	-		1		125 ID X 0.25" OD,STL	86928	5702-201-20
12	211-0116-00	B010100	B021289	1		HR:4-40 X 0.312 INCH,PNH BRS	83385	ORD BY DESCR
2	211-0292-00	B021290		1		HR:4-40 X 0.29,BRS NI PL	78189	ORD BY DESCR
4	210-0551-00 386-2660-00			1	·····(END A	4-40 X 0.25 INCH,STL TTACHING PARTS)*******	000BK	ORD BY DESCR
5				1	SUPPORT, CKT E		80009	386-2660-00
5				-	(SEE A8 REPL)	SY:TRIG GEN/Z AXIS LOGIC		
6	211-0207-00	B010100	B018768	5		HR:4-40 X 0.312 DOUBLE SEMS	83385	ORD BY DESCR
	211-0244-00	B018769		5	SCR, ASSEM WS	HR:4-40 X 0.312 INCH,PNH STL TTACHING PARTS)	78189	ORD BY DESCR
				-	CKT BOARD ASS	SY INCLUDES:		
7	214-0579-00			9	.TERM, TEST POI	NT:BRS CD PL	80009	214-0579-00
8	131-0566-00			9	.BUS CONDUCTO	R:DUMMY RES,2.375,22 AWG	57668	JWW-0200E0
9	131-1003-00			8	.CONN,RCPT,ELE	C:CKT BD MT,3 PRONG	80009	131-1003-00
0	136-0252-07			-	.SOCKET, PIN CO	NN:W/O DIMPLE	22526	75060-012
	136-0220-00			-	.SKT,PL-IN ELEK:	TRANSISTOR 3 CONTACT, PCB M	71785	133-23-11-034
	136-0350-00			-	.SOCKET,PLUG-II	N:3 PIN,LOW PROFILE	80009	136-0350-00
1	131-0608-00			9	.TERMINAL,PIN:0	.365 L X 0.025 PH BRZ GOLD	22526	48283-036
	131-1343-00			1	.TERM. SET, PIN:	36-0.525 L X 0.025 SQ	22526	65501-136
2	136-0499-02			1	.CONNECTOR,RC	PT,:2 CONTACT	00779	4-380949-2
3	136-0499-10			1	.CONNECTOR,RC	PT,:10 CONTACT	00779	4-380949-0
\$	136-0499-12			1	.CONNECTOR,RC	PT,:12 CONTACT	00779	4-380949-2
5	355-0175-00			1	.STUD.SELF-LKG	4-40 X 0.35 INCH LONG	80009	355-0175-00
5	200-0945-00			2	.COVER,HALF XS	TR:DUAL TO-18,ALUMINUM	80009	200-0945-00
-	200-0945-01			2	.*********(ATTAC	TR:DUAL TO-18,W/2-56 THD HING PARTS)	80009	200-0945-01
7 3	211-0062-00			2	(END AT	E:2-56 X 0.312,PNH,STL FACHING PARTS)******	83385	ORD BY DESCR
9	352-0331-00 105-0419-00			3 2		CH:COUPLING(SEE S508 REPL)	80009	352-0331-00
,)	214-1126-02			1	ACTUATOR,SWI		80009	105-0419-00
, ,	214-1125-02			2 2	SPRING,FLAT:RE		80009	214-1126-02
2	351-0355-00			2	GUIDE,SLIDE SV	T:0.125 DIA X 0.125,SST	80009 80009	214-1127-00 351-0355-00
	376-0142-00			1		V: LG:SLIDE TO SHAFT	80009	376-0142-00
	213-0048-00			1		X 0.125 INCH,HEX SOC S	74445	ORD BY DESCR
				1		CH:A SOURCE(SEE S505 REPL)	14440	UND DI DESCH
	105-0418-00			1	ACTUATOR,SWI		80009	105-0418-00
	214-1126-01			2		7 X 0.125,CU BE GRN CLR	80009	214-1126-01
	214-1127-00			2		T:0.125 DIA X 0.125,SST	80009	214-1127-00
	351-0355-00			1	GUIDE,SLIDE SV		80009	351-0355-00
	376-0142-00			1			80009	376-0142-00
•	213-0048-00			1		X 0.125 INCH,HEX SOC S	74445	ORD BY DESCR
				1	ACTUATOR,SWIT	CH:B SOURCE(SEE S705 REPL)		
	105-0417-00			1	ACTUATOR,SWIT		80009	105-0417-00
)	214-1126-01 214-1127-00			2 2		7 X 0.125,CU BE GRN CLR 1:0.125 DIA X 0.125,SST	80009 80009	214-1126-01 214-1127-00

REV DEC 1984

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Teb: 01944-351694 Fax:- 018 14-352554 Enaut: enguines@mauritron.co.uk

	Tektronix	Serial/N	Model No.					
No.	Part No.	Eff	Dscont	Qty	12345	Nama & Description	Mfr	
						Name & Description	Code	Mfr Part Numbe
2-42	351-0355-00	1		1	GUIDE,SLIDE SW	1.		
-43	376-0142-00	I		1	ADDE SUAFT OD		80009	351-0355-00
	213-0048-00			1	CETCODEW 4.40	LG:SLIDE TO SHAFT	80009	376-0142-00
.44	384-1160-00				SEISCHEW:4-40	X 0.125 INCH, HEX SOC S	74445	ORD BY DESCR
-45	214-1770-00			4		FT:LEVER SWITCH	91260	ORD BY DESCR
	2,4-17,0-00			4	LEVER, SLIDE SW	:	80009	214-1770-00
-46	354 0165 00				. ATTACI	HING PARTS)		214-1770-00
	354-0165-00			2	.RING, RETAINING:	0.114 FREE ID X 0.025 INCH	97464	1000 15
47					(END ATT,	ACHING PARTS)	57404	1000-15
-47	131-1031-00			23	CONTACT ASSY.E	L:CAM SWITCH, TOP	80000	404 445 44
					.***********(ATTACH	ING PARTS)	80009	131-1031-00
-48	210-0779-00	B010100	B015654	23	BIVET TUBULAR	0.051 OD X 0.115 INCH LONG		
	210-3082-00	B015655		23	EYELET METALLIC	C:0.047 OD X 0.133 L,BRASS	42838	RA-29952715
						ACHING PARTS)	80009	210-3082-00
49	386-2376-00			1		CHING PARIS		
				1	PLATE, LEVER MT	G:SLIDE SWITCH	80009	386-2376-00
50	210-0657-01				(AI IACH	IING PARTS)		
	210-0007-01			1	.EYELET,METALLIC	0.089 OD X 0.218 IN LONG	80009	210-0657-01
51	407 1157 00				END ATTA	CHING PARTS)		
	407-1157-00	D	_	1	BRACKET, ELEC SV	V:ALUMINUM	80009	407-1157-00
	672-0459-02	B010100	B012224	1	CKT BOARD ASSY	TIMING	80009	672-0459-02
	672-0459-03	B012225	B018402	1	CKT BOARD ASSY	TIMING	80009	
	672-0459-06	B018403		1	CKT BOARD ASSY			672-0459-03
					******************/ATTACH	HING PARTS)	80009	672-0459-06
52	211-0116-00	B010100	B021289	1	SCR ASSEM WSHE	1:4-40 X 0.312 INCH,PNH BRS		
	211-0292-00	B021290		1	SCR ASSEM WOHR	1:4-40 X 0.29,BRS NI PL	83385	ORD BY DESCR
53	129-0386-01			1	SPACED BOOT 4 50	1.4-40 X U.29,BRS NI PL	78189	ORD BY DESCR
				,	3FACEN,FUS1:1.59	3 L,W/4-40 TAP 1 END	80009	129-0386-01
					(END ATT	ACHING PARTS)		
4	384-1136-00			-	CKT BOARD ASSY	INCLUDES:		
5	384-1101-00			3	EXTENSION SHAFT	1:0.95 INCH LONG	80009	384-1136-00
6				4	.EXTENSION SHAFT	4.14 INCH LONG	80009	384-1101-00
7	384-1105-00			1	.EXTENSION SHAFT	:8.241 L X 0.081 INCH OD	80009	384-1105-00
/				1	.SWITCH, PUSH: MIC	RO(SEE S1099 REPL)	00003	304-1103-00
_						NG PARTS)		
8	352-0379-01			t	HOLDER,MICR:		00000	
9	210-0586-00			1		:4-40 X 0.25,STL CD PL	80009	352-0379-01
	211-0112-00				SCREW MACHINE	2-56 X 0.375,FLH,100 DEG	78189	211-041800-00
	210-0001-00				WASHER LOCK #2	INTL.0.013 X 0.18 OD,STL	83385	ORD BY DESCR
	210-0405-00				NHT PLAIN HEV.O.E	INTL.0.013 X 0.18 OD,STL	78189	1202-00-00-0541C
					INUT, PLAIN, HEX:2-5	6 X 0.188, BRS, CD PL	73743	12157-50
)	105-0554-01				END ATTAC	CHING PARTS)		
				1	ACTUATOR, SWITCH	1:MICROSWITCH	80009	105-0554-01
				1	.DRUM ASSY,CAM S	S:(SEE S1050 REPL)		
	014 0440 00				. ATTACHIN	G PARTS)		
	211-0116-00	B010100	B012224	8	SCR, ASSEM WSHR	4-40 X 0.312 INCH, PNH BRS	83385	
	211-0244-00	B012225		8	SCR.ASSEM WSHR	4-40 X 0.312 INCH, PNH STL		ORD BY DESCR
						HING PARTS)	78189	ORD BY DESCR
				-	ACTUATOR ASSY IN			
2	200-1724-00			1	COVER,CAM SW:18			
				•	ATTACUIN	C BADTONNENIS	80009	200-1724-00
2	211-0008-00			8.	ATTACHIN	G PARIS		
	210-0004-00				SCREW, MACHINE:4	-40 X 0.250, PNH, STL, POZ	83385	ORD BY DESCR
				8.	WASHER,LOCK:#4	INTL.0.015 THK,STL CD PL	000BK	ORD BY DESCR
1	131-0963-00					HING PARTS)		
					CONTACT, ELEC: GR		000EX	ORD BY DESCR
	210-0406-00			2.	NUT, PLAIN, HEX: 4-4(0 X 0.188, BRS, CD PL	73743	12161-50
	214-1139-02				SPRING FLAT GREE		80009	
	214-1139-03			1.	SPRING, FLAT: RED C	COLORED		214-1139-02
2	214-1127-00	B010100	B012224	2 .	ROLLER DETENT O	125 DIA X 0.125,SST	80009	214-1139-03
2	214-1752-00	B012225			ROLLER, DETENT:	20 DIG A 0.123,331	80009	214-1127-00
	101-0081-02	B010100	B012224			BONT	80009	214-1752-00
2		B012225			BEARING,CAM SW:F		80009	401-0081-02
2 4	101-0180-00			1	BEARING,CAM SW:F	HONT & REAR	80009	401-0180-00
2 4	101-0180-00					PARTS)		
2 4 4		B010100	D04000 -			-,		
2 4 4 3	354-0391-00	B010100	B012224	1	RING.RETAINING:0.3	95"FREE ID X 0.025" S	97464	3100-43-CD
2 4 4 3	354-0391-00	B010100 B012225	B012224	1 1	RING.RETAINING:0.3 RING.RETAINING:0.3	95"FREE ID X 0.025" S 38 ID X 0.025" THK.STL	97464 79136	3100-43-CD 5100-37MD
2 4 4 3 3	354-0391-00 354-0390-00	B012225	B012224	1 1	RING.RETAINING:0.3 RING.RETAINING:0.3	95"FREE ID X 0.025" S 38 ID X 0.025" THK.STL	97464 79136	3100-43-CD 5100-37MD
2 4 4 3 3 1	354-0391-00 354-0390-00			1 1 	RING.RETAINING:0.3 RING.RETAINING:0.3	95"FREE ID X 0.025" S 38 ID X 0.025" THK,STL ING PARTS)"""""	79136	

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel:- 01944-351894 Fax:- 01944-352554 E...au: enquiries@mauritron.co.uk

9-10

Index	Tektronix	Serial/Mo	del No.			Mfr	
No.	Part No.	Eff	Dscont	Qty	1 2 3 4 5 Name & Description	Code	Mfr Part Numbe
2-72	210-0406-00			4	NUT, PLAIN, HEX: 4-40 X 0.188, BRS, CD PL	73743	12161-50
-73	407-1199-00			1	BRACKET,COVER:ABS	80009	407-1199-00
74	210-0406-00			4	NUT, PLAIN, HEX: 4-40 X 0.188, BRS, CD PL	73743	12161-50
75	214-2185-00	B010100	B012224	1	PIN,GRVD,HDLS:LOCKOUT,0.377 INCH LONG	84256	BLCBA105A
76	354-0350-00	B010100	B012224	1		79136	5133-9MD
77	214-1378-00					04000	
78		0010100	5010004	1	SPRING,HLCPS:0.125 OD X 0.3 INCH L	91260	ORD BY DESCR
/0	401-0083-01	B010100	B012224	1	BEARING,CAM SW:CENTER	80009	401-0083-01
	401-0178-02	B012225	B018402	1	BEARING,CAM SW:0.428 ID,PLASTIC	80009	401-0178-02
	401-0178-01	B018403		1	BEARING,CAM SW:CENTER/REAR	80009	401-0178-01
79	105-0624-00	B010100	B012224	1	ACTUATOR,CAM SW:TIME/CM,REAR	80009	105-0624-00
	105-0624-01	B012225		1	ACTR ASSY,CAM S:TIME/CM,REAR 	80009	105-0624-01
80	354-0391-00	B010100	B012224	1	RING,RETAINING:0.395"FREE ID X 0.025" ST	07464	2100 42 CD
	354-0390-00	B012225		1		97464	3100-43-CD
	JJ7-0J30-0U	0012220		I	RING,RETAINING:0.338 ID X 0.025" THK,STL (END ATTACHING PARTS)	79136	5100-37MD
81	210-0406-00			1	NUT, PLAIN, HEX: 4-40 X 0.188, BRS, CD PL	73743	12161-50
82	214-1139-02			1	SPRING,FLAT:GREEN COLORED	80009	214-1139-02
	214-1139-03			1	SPRING,FLAT:RED COLORED	80009	214-1139-03
83	214-1127-00	B010100	B012224	2	ROLLER,DETENT:0.125 DIA X 0.125,SST	80009	
-	214-1752-00	B012225		2	ROLLER, DETENT:	80009	214-1127-00
84	401-0081-02	B012225	B012224	1			214-1752-00
04			DU12224		BEARING,CAM SW:FRONT	80009	401-0081-02
	401-0180-00	B012225		1	BEARING,CAM SW:FRONT & REAR	80009	40 1-0180-00
	384-0878-02			1	SHAFT,CAM SW:	80009	38 4-0878-02
	384-0878-00	B012225		1	SHAFT,CAM SW:W/DRIVER	80009	384-0878-00
	210-1160-00	B012225		1	WASHER, FLAT: 0.129 ID X 0.031 THK, TEFLON	86928	5612-32-31
	210-0949-00	B018403		1	WASHER,FLAT:0.141 ID X 0.50 INCH OD,BRS	12327	ORD BY DESCR
	354-0392-00	B018403		2	RING.RETAINING:	79136	5555-12ZD
	361-1033-00	B018403		1	SPACER, SLEEVE: 1.613 L X 0.09 ID, AL	80009	361-1033-00
	384-0882-06	B018403		1	SHAFT,CAM SW:7.875 L,INTMD CNCTRC,W/DRIV	80009	384-0882-06
85				1	.RES.,VAR,NONWIR:(SEE R1070 REPL)	00003	304-0002-00
86	361-0515-00			1		00000	004 0545 00
87	376-0141-00	B010100	B018104		SPACER, SWITCH: PLASTIC	80009	361-0515-00
07	376-0039-00	B018105	B010104	1	CPLG,SHAFT,RGD:FOR 0.08 TO 0.125 DIA SHAF	80009	376-0141-00
		0010100		1	ADPT,SHAFT,CPLG:0.128 AND 0.082 DIA SHAFT	80009	376-0039-00
	213-0239-00			2	SETSCREW:3-48 X 0.062 INCH,HEX SOC	71159	ORD BY DESCR
	213-0075-00			1	SETSCREW:4-40 X 0.094,STL BK OXD,HEX	000BK	ORD BY DESCR
88				1	.CKT BOARD ASSY:TIMING(SEE A7 REPL)		
89	136-0252-07		-	-	SOCKET,PIN CONN:W/O DIMPLE	22526	75060-012
	136-0220-00			•	SKT,PL-IN ELEK:TRANSISTOR 3 CONTACT,PCB	71785	133-23-11-034
	136-0350-00			-	SOCKET, PLUG-IN:3 PIN, LOW PROFILE	80009	136-0350-00
90	131-0608-00			19	TERMINAL, PIN: 0.365 L X 0.025 PH BRZ GOLD	22526	48283-036
91	131-0604-00			43	CONTACT,ELEC:CKT BD SW,SPR,CU BE	80009	131-0604-00
) 2	131-1261-00			32	CONTACT.ELEC:F-SHAPED	00779	1-380953-0
93				1	SW.PUSH BUTTON:TRIG MODE(SEE S600 REPL)		
94	361-0411-00			4	SPACER, PUSH SW:0.13 W X 0.375 INCH L, PLS	71590	J64285-00
95	352-0331-00			2	LAMPHOLDER:	80009	352-0331-00
96				1	SW.PUSH BUTTON:HORIZ MODE(SEE S1090 REPL	00009	002-0001-00
)7	361-0385-00	B010100	B017796	4		00000	061 0005 00
••		B010100	B017786		SPACER,PB SW:0.164 INCH LONG	80009	361-0385-00
	361-0385-00	B017787		8	SPACER,PB SW:0.164 INCH LONG	80009	361-0385-00
	361-0542-00	B017787		4	SPACER, PUSH SW:0.078 L, POLYPROPYLENE	71590	J-64281
8	337-0896-00			1	PLATE,ELEC SHLD:CKT BOARD MOUNT,BRS	80009	337-0896-00
19	337-1810-00			1	SHIELD,ELEC:DELAY LINE	80009	337-1810-00
	337-2079-00			1	SHIELD,ELEC:VO AMP	80009	337-2079-00
				-	(DM VERSION ONLY)		
00	213-0088-00			6	SCR,TPG,THD CTG:4-24 X 0.25 INCH,PNH STL	83385	ORD BY DESCR
01					"""""(END ATTACHING PARTS)"""""		
01				1	CKT BOARD ASSY:VERTICAL OUTPUT(SEE A5 REPL		
02	211-0207-00	B010100	B018768	2	SCR,ASSEM WSHR:4-40 X 0.312 DOUBLE SEMS	83 385	ORD BY DESCR
	211-0244-00	B018769	20.0700	2	SCR,ASSEM WSHR:4-40 X 0.312 INCH,PNH STL	78189	
03	220-0456-00	20.0103		2			ORD BY DESCR
03					NUT, PLAIN, HEX.: 6-32 X 0.25 INCH, STL	73743	9038
U4	210-1092-00			1	WASHER, FLAT: 0.147 ID X 0.312" OD, BRS	12327	ORD BY DESCR

REV DEC 1984

For Service Manuals Contact MAURITROM FECHICUCAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel: 01844-351694 Fax- 01844-352554 Email: enquiries@mauntron.co.uk

9-11

Fig. & Index No.	Tektronix Part No.	Serial/N Eff	fodel No. Dscont	Qty	12345	Name & Description	Mfr Code	Mfr Part Number
2- -105 -106 -107 -108	407-1201-00 131-0608-00 136-0252-07 136-0220-00 136-0350-00 361-0008-00			- 1 3 - - 3	.MICROCIRCUI .BRACKET,GNE .TERMINAL,PIN .SOCKET,PIN C .SKT,PL-IN ELE .SOCKET,PLUG	SSY INCLUDES: T:(SEE U470 REPL) D:MICROCIRCUIT,BRASS D:0.365 L X 0.025 PH BRZ GOLD ONN:W/O DIMPLE K:TRANSISTOR 3 CONTACT,PCB M -IN:3 PIN,LOW PROFILE YE:0.28L X 0.111 ID	80009 22526 22526 71785 80009 80009	407-1201-00 48283-036 75060-012 133-23-11-034 136-0350-00 361-0008-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Fig. a	8
--------	---

Fig. &	-	•					
Index	Tektronix	Serial/Mo				Mfr	
No.	Part No.	Eff	Dscont	Qty	1 2 3 4 5 Name & Description	Code	Mfr Part Numb
3-1	131-1428-00			2	CONTACT.ELEC:GROUNDING CLIP	80009	131-1428-00
2	211-0012-00			~	(ATTACHING PARTS)		
3	166-0030-00			2	SCREW, MACHINE: 4-40 X 0.375, PNH STL CD PL	83385	ORD BY DESCR
5	100-0030-00			2	SPACER,SLEEVE:0.25 OD X 0.188 INCH LONG 	80009	166-0030-00
	672-0045-02			1	CKT BOARD ASSY:GAIN	80000	670 0045 00
	0,200,000			•	(ATTACHING PARTS)	80009	672-0045-02
4	211-0207-00	B010100	B018768	2	SCR,ASSEM WSHR:4-40 X 0.312 DOUBLE SEMS	83385	ORD BY DESCR
	211-0244-00	B018769	2010100	2	SCR.ASSEM WSHR:4-40 X 0.312 INCH,PNH STL	78189	ORD BY DESCR
				-	(END ATTACHING PARTS)	10105	0.10 01 02001
				-	ATTENUATOR ASSY INCLUDES:		
5	200-1439-00			2	COVER, CHASSIS: ATTENUATOR	80009	200-1439-00
					.*************************************		
-6	213-0176-00			2	.SCR,TPG,THD FOR:2-32 X 0.156 INCH,PNH,STL	83385	ORD BY DESCR
7	210-0938-00			2	.WASHER,FLAT:0.109 ID X 0.25 INCH OD,STL	75497	AN960-3
8	211-0008-00	B010100	B020319	8	.SCREW,MACHINE:4-40 X 0.250,PNH.STL,POZ	83385	ORD BY DESCR
`	211-0661-00	B020320		8	.SCREW,MACHINE:4-40 X 0.25 INCH,PNH,STL	78189	ORD BY DESCR
9	210-0851-00	B010100	B017669	8	WASHER, FLAT: 0.119 ID X 0.375 INCH OD, ST	12327	ORD BY DESCR
	210-1307-00	B017670		8	WASHER,LOCK:0.115 ID,SPLIT.0.025 THK	86928	A384-25N
10	131-0679-02			2	CONNECTOR RCRT RNC MALE 2 CONTACT		00.0070
	101-00/ 9-02			2	CONNECTOR, RCPT, : BNC, MALE, 3 CONTACT	24931	28JR270-1
11	210-1039-00			2	WASHER,LOCK:INT,0.521 ID X 0.625 INCH O	24931	
12	210-0845-00			2	WASHER, FLAT: 0.500 ID X 0.625 INCH OD, ST	89663	ORD BY DESCR 634-R
13	220-0695-00			2	NUT,PLAIN,DODEC:0.500-28 X 0.90 INCH,BRS	73743	ORD BY DESCR
				-	(END ATTACHING PARTS)	/3/43	UND BI DESCH
14	441-1058-00			2	.CHASSIS,SCOPE:ATTENUATOR	80009	441-1058-00
					(ATTACHING PARTS)	00000	111-1000-00
15	129-0299-00			8	POST.ELEC-MECH:HEX,0.333 INCH LONG	80009	129-0299-00
16	211-0097-00			4	SCREW, MACHINE: 4-40 X 0.312 INCH, PNH STL	83385	ORD BY DESCR
17	210-0004-00			12	.WASHER,LOCK:#4 INTL,0.015 THK,STL CD PL	000BK	ORD BY DESCR
18	211-0001-00			4	SCREW, MACHINE: 2-56 X 0.25 INCH, PNH STL	87308	ORD BY DESCR
19	210-0053-00			4	.WASHER,LOCK:INTL,0.092 ID X 0.175"OD	83385	ORD BY DESCR
20	210-1008-00			4	.WASHER,FLAT:0.09 ID X 0.188" OD,BRS	12360	ORD BY DESCR
21	210-0405-00			4	.NUT,PLAIN,HEX:2-56 X 0.188,BRS,CD PL	73743	12157-50
22					(END ATTACHING PARTS)		
22	 131-1030-00			2	CKT BD ASSY:CH1,CH2 ATTEN(SEE A1,A2 REPL)		
20	131-1030-00			10	CONT ASSY, ELEC: CAM SWITCH, BOTTOM	80009	131-1030-00
	101-1001-00			10	CONTACT ASSY,EL:CAM SWITCH,TOP	80009	131-1031-00
	210-0779-00	B010100	B015654	10	(AT ACHING PARTS) RIVET,TUBULAR:0.051 OD X 0.115 INCH LONG	42838	RA-29952715
	210-3082-00	B015655		10	EYELET,METALLIC:0.047 OD X 0.133 L,BRASS	80009	210-3082-00
						00005	2.0-0002-00
24	136-0252-01			36	CONTACT,ELEC:0.178 INCH LONG	00779	1-332095-2
	136-0333-00			2	SOCKET,PIN TERM:U/W 0.03 DIA PINS	00779	1-331677-4
5	337-1406-00			1	.SHLD, ELECTRICAL: CAM CONTACTS	80009	337-1406-00
6	384-1178-00			2	EXTENSION SHAFT:0.123 OD X 6.1 INCH LONG	80009	384-1178-00
27	105-0243-00			2	ACTUATOR, SWITCH: AC, DC	80009	105-0243-00
-					.*************(ATTACHING PARTS)********		
28	213-0214-00			2	SCREW,CAP SCH:2-56 X 0.375 HEX HD STL	70278	ORD BY DESCR
	101 1014 00			•	(END ATTACHING PARTS)		
	131-1314-00			2	CONTACT,ELEC:GROUNDING	80009	131-1314-00
				-	(MAY BE REPLACED BY INDEX NUMBERS 41		
	263-1014-00			- 2	.AND 42 ON AVAILABILITY OF STOCK) .SW CAM ACTR AS:VOLTS/DIV	00000	060 1014 00
	200-1014-00			2		80009	263-1014-00
9	211-0116-00	B010100	B021289	12	SCR,ASSEM WSHR:4-40 X 0.312 INCH,PNH BRS	83365	ORD BY DESCR
-	211-0292-00	B021290	5021203	12	SCRASSEM WSHR:4-40 X 0.312 INCH,PNH BRS	83385 78189	ORD BY DESCR
					(END ATTACHING PARTS)	10103	UND DI DESUR
				-	EACH ACTUATOR ASSY INCLUDES:		
0	131-0963-00			2	CONTACT,ELEC:GROUNDING	000EX	ORD BY DESCR
1	214-1139-03			2	SPRING,FLAT:RED COLORED	80009	214-1139-03
2	214-1752-00			2	ROLLER,DETENT:	80009	214-1752-00
3	210-0406-00			2	NUT, PLAIN, HEX: 4-40 X 0.188, BRS, CD PL	73743	12161-50

For Service Manuals Contact MAURITRON TECHNICAL SERVICES B Cherry Tree Rd. Chinnor Oxon OX9 40Y Tel: 01844/do1601 Fax: 01844-352554 Email: enguine@mauriron.co.uk

Index		Serial/	Model No.						
No.	Part No.	Eff	Dscont	Qt	y 12345		Mfr		
					,	Name & Description	Code	Mfr Part Number	
3-34	401-0180-00)							-
				1	BEARING,CAM S	W:FRONT & REAR	80009	401-0180-00	
-35	354-0390-00	•			(ATTAC	HING PARTS)			
				1	RING, RETAINING	0.338 ID X 0.025" THK,STL	79136	5100-37MD	
-36	384-0878-02				(END ATT	ACHING PARTS)		0100-071015	
-37	105-0282-01			1	SHAFT,CAM SW:		80009	384-0878-02	
-38	210-0406-00			1	ACTUATOR,CAM	SW:DC,GND,AC	80009	105-0282-01	
.39				4	NUT,PLAIN,HEX:4	-40 X 0.188,BRS,CD PL	73743		
.39	401-0178-00			1	BEARING,CAM SI	W:CENTER	80009	12161-50	
40	054.0440.00				**********(ATTACI	HING PARTS)	00003	401-0178-00	
40	354-0443-00			1	RING, RETAINING:	0.328 FREE ID X 0.448 OD	97464	000.07	
					(END ATT.	ACHING PARTS)	57404	200-37	
41	210-1189-00			1	.WASHER, FLAT:0.1	195 ID X 0.367 INCH OD.BR	51010		
42	214-2043-00			1	SPRING HI CPS C	ONICAL,0.20 INCH LONG	51316	ORD BY DESCR	
43	105-0343-01			1	ACTUATOR,CAM	SWIATTEN	80009	214-2043-00	
44	384-0880-00			1	SHAFT,CAM SW:F		80009	105-0343-01	
45	210-0406-00			4	NUT PLAIN HEV.A	-40 X 0.188,BRS,CD PL	80009	384-0880-00	
46	214-1139-02			1	SPRING ELATION	-40 X 0.188,BHS,CD PL	73743	12161-50	
	214-1139-03			1	SPRING,FLAT:GRE		80009	214-1139-02	
\$7	214-1752-00			2	SPRING,FLAT:RED		80009	214-1139-03	
48	401-0180-00				ROLLER, DETENT:		80009	214-1752-00	
19				1	BEARING, CAM SW	V:FRONT & REAR	80009	401-0180-00	
50	131-0589-00			1	CKT BOARD ASSY	GAIN SWITCH(SEE A4 REPL)			
51	131-0608-00			6	TERMINAL,PIN:0.4	6 L X 0.025 SQ	22526	48283-029	
52				2 9	TERMINAL,PIN:0.3	65 L X 0.025 PH BRZ GOLD	22526	48283-036	
~	131-1031-00			10	CONTACT ASSY,E	L:CAM SWITCH, TOP	80009	131-1031-00	
2	040 0770 00				************(ATTACH	ING PARTS)	00003	131-1031-00	
3	210-0779-00	B010100	B015654	10	RIVET,TUBULAR:0	.051 OD X 0.115 INCH LONG	42838	BA 20050745	
	210-3082-00	B015655		10	EYELET, METALLIC	:0.047 OD X 0.133 L,BRASS		RA-29952715	
						CHING PARTS)	80009	210-3082-00	
4	136-0252-07			-	SOCKET,PIN CONN				
	136-0220-00			-	SKT PL IN ELEK TE	RANSISTOR 3 CONTACT, PCB	22526	75060-012	
	136-0350-00				SOCKET,PLUG-IN:	PINLOW PROFILE	71785	133-23-11-034	
5	376-0051-00			2			80009	136-0350-00	
	213-0022-00			4	SETSOREMULA 40 Y	:0.127 ID X 0.375 ID DELR	80009	376-0051-00	1
6				1	BEC VAD NONHUD	0.188 INCH, HEX SOC S	74445	ORD BY DESCR	
7	361-0515-00			1	CRACED ONUTOUR	(SEE R128/S128 REPL)			
3					SPACER,SWITCH:P		80009	361-0515-00	
Э	361-0515-00			1	RES.,VAR,NUNWIH	(SEE R228/S228 REPL)			
)	337-1418-01	B010100	BOISCOS	1	SPACER,SWITCH:P	PLASTIC	80009	361-0515-00	
	337-1418-02	B015686	B015685	2	SHIELD,ELEC:CAM		80009	337-1418-01	
	007-1410-02	DU12000		2	SHIELD,ELÉC:CIRC		80009	337-1418-02	
I	213-0277-00				**************(ATTACHII	NG PARTS)*******			
				6	SCR,TPG,THD FOR:	:2-56 X 0.312 INCH,PNH ST	83385	ORD BY DESCR	
2	210-0053-00			6	WASHER,LOCK:INT	L,0.092 ID X 0.175"OD	83385	ORD BY DESCR	
•	210-1134-00			6	WASHER,FLAT:0.09	ID X 0.25 INCH OD.BRS	12327	ORD BY DESCR	
					(END ATTAC	CHING PARTS)	16021	UND DT DESUK	
				1	SW, PUSH BUTTON	VERT MODE(SEE S300 REPL)			
	361-0411-00			4	SPACER.PUSH SW	0.13 W X 0.375 INCH L.PLS	71500	104005.00	
	352-0331-00			2	LAMPHOLDER:	LITE TO A GOLD MON LIFES	71590	J64285-00	
	384-1175-00			2		0.123 OD X 5.7 INCH LONG	80009	352-0331-00	
	384-1100-00			1	EXTENSION SHAFT	0.12 SQ X 6.215" LONG,PLST	80009	384-1175-00	
	384-1129-00			5	EXTENSION SHAFT:	ENTINGUL ONO	80009	384-1100-00	
	376-0029-00			2	EXTENSION SHAFT:5	100 INCH LONG	80009	384-1129-00	
	213-0022-00			4	CFLO, SHAFT, KGD:0.1	128 ID X 0.312 OD X 0.5"L	80009	376-0029-00	
	131-1428-00				CONTACT TI TO TT	188 INCH, HEX SOC S	74445	ORD BY DESCR	
	213-0075-00			2	CONTACT, ELEC:GRO	UNDING CLIP	80009	131-1428-00	
				4	SEISCREW: 4-40 X 0	.094,STL BK OXD,HEX	000BK	ORD BY DESCR	
	211-0008-00				ATTACHIN	IG PARTS)			
				1	SCREW, MACHINE: 4-4	0 X 0.250, PNH, STL, POZ	83385	ORD BY DESCR	
	210-0054-00			1	WASHER,LOCK:#4 SI	PLIT,0.025 THK STL CD P	83385	ORD BY DESCR	
	210-0994-00			1	WASHER, FLAT: 0.125 I	D X 0.25" OD.STL	86928	5702-201-20	
					(END ATTAC	HING PARTS	00020	0,02-201-20	
	*****			1	CKT BOARD ASSY VE	ERT PREAMP(SEE A3 REPL)			
					(ATTACHIN	G PARTS			
	211-0116-00	B010100	B021289	7	SCR ASSEM WSHD.4	-40 X 0.312 INCH,PNH BRS			
	211-0292-00	B021290		7	SCR ASSEM WORK(4-	AO X 0.00 DDC AN D	83385	ORD BY DESCR	
	129-0413-01	B010100	B023829		SCR.ASSEM WSHR:4	- V A U.29,BHS NI PL	78189	ORD BY DESCR	
	166-0026-00	B023829	3020023	1	SPACER, POST: 0.538 L		80009	129-0413-01	
	211-0116-00	B023829		1	SPACER, SLEEVE: 0.37	5 L X 0.125 ID,AL 40 X 0.312 INCH,PNH BRS	71590	P7610-1	
				1					

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.cc.uk

REV DEC 1984

Index	Tektronix	Serial/Mc	del No.			Mfr	
ю.	Part No.	Eff	Dscont	Qty	1 2 3 4 5 Name & Description	Code	Mfr Part Numbe
•				•	CKT BOARD ASSY INCLUDES:		
7	131-1058-00			2	.CONN,PLUG,ELEC:2 FEMALE BLADE CONT	71785	S-302CCT
8	136-0269-00			3	.SOCKET, PLUG-IN: 14 CONTACT, LOW CLEARANCE	73803	CS9002-14
9	136-0252-07			-	SOCKET, PIN CONN: W/O DIMPLE	22526	75060-012
	136-0220-00			-	.SKT,PL-IN ELEK:TRANSISTOR 3 CONTACT,PCB M	71785	133-23-11-034
	136-0350-00			-	.SOCKET, PLUG-IN:3 PIN, LOW PROFILE	80009	136-0350-00
0	214-0579-00			4	TERM, TEST POINT: BRS CD PL	80009	214-0579-00
1	131-06 08-0 0			1	.TERMINAL,PIN:0.365 L X 0.025 PH BRZ GOLD	22526	48283-036
32	131-1031-00			9	.CONTACT ASSY, EL: CAM SWITCH, TOP	80009	131-1031-00
	131-1030-00			8	.CONT ASSY,ELEC:CAM SWITCH,BOTTOM	80009	131-1030-00
33	210-0779-00	B010100	B015654	9	RIVET, TUBULAR: 0.051 OD X 0.115 INCH LONG	42838	RA-29952715
	210-3082-00	B015655	2010001	9	EYELET, METALLIC: 0.047 OD X 0.133 L, BRASS	80009	210-3082-00
	014 1010 00			•	(END ATTACHING PARTS)	05000	010 40
34	214-1813-00			2	HEAT SINK, ELEC: TRANSISTOR	05820	213-AB
5	214-1799-00			1	HEAT SINK, ELEC: TRANSISTOR	05820	215AB
16	131-1003-00			8	CONN,RCPT,ELEC:CKT BD MT,3 PRONG	80009	131-1003-00
37				1	SW.PUSH BUTTON: INVERT(SEE S225 REPL)	74500	104005 00
8	361-0411-00			1	SPACER, PUSH SW:0.13 W X 0.375 INCH L, PLST	71590	J64285-00
	105-0421-00			1	ACTUATOR, SWITCH: MOMENTARY	80009	105-0421-00
39				1	.RES.,VAR,NONWIR:(SEE R185 REPL)		
90				1	RES., VAR, NONWIR: (SEE R285 REPL)		
91	105-0420-00			1	ACTUATOR, SWITCH: MOMENTARY	80009	105-0420-00
92	214-1779-00			1	SPRING, HLCPS: 0.156 OD X 0.844 INCH LONG	04811	ORD BY DESCR
93	351-0359-00			1	GUIDE,SLIDE SW:	80 009	351-0359-00
	105-0582-00			1	ACTR ASSY, SL SW: OUTPUT ATTEN	80 009	105-0582-00
94	376-0146-00			1	CPLG,SHAFT,RGD:FOR 0.125 INCH DIA SHAFT	80009	376-0146-00
	213-0048-00			1	SETSCREW:4-40 X 0.125 INCH,HEX SOC S	74445	ORD BY DESCR
95	105-0517-00			1	ACTUATOR,SWITCH:SLIDE,BANDWIDTH LIMIT	80 009	105-0517-00
96	214-1126-01			1	SPRING,FLAT:0.7 X 0.125,CU BE GRN CLR	80 009	214-1126-01
97	214-1127-00			1	ROLLER, DETENT: 0.125 DIA X 0.125, SST	80 009	214-1127-00
8	351-0355-00			1	GUIDE,SLIDE SW:	80009	351-0355-00
99	348-0253-00			1	GROMMET, PLASTIC: BLACK, OBLONG, 3. OXO. 925	80009	348-0253-00
00	407-1127-00			1	BRACKET, PREAMP: REAR, BRASS CU-SN-ZN PL	80009	407-1127-00
101	210-0586-00			2	NUT, PL, ASSEM WA: 4-40 X 0.25, STL CD PL	78189	211-041800-00
102	100 0205 00			~	•••••••(END ATTACHING PARTS)•••••• SPACER.POST:1.77 L.W/6-32 & 4-40 THD EN	80000	100 0385 00
03	129-0385-00			3 1	RES., VAR, FILM: (SEE R1303A, B, C, D REPL)	80009	129-0385-00
					·······(ATTACHING PARTS)······		
04	211-0507-00			2	SCREW, MACHINE: 6-32 X 0.312, PNH STL, CD PL	83385	ORD BY DESCR
05	210-0202-00			1	TERMINAL, LUG: 0.146 ID, LOCKING, BRZ, TIN PL	78189	2104-06-00-2520N
06	210-0457-00			2	NUT,PL,ASSEM WA:6-32 X 0.312,STL CD PL ········(END ATTACHING PARTS)········	83385	ORD BY DESCR
07	407-1236-00			1	BRACKET, RES: ALUMINUM (ATTACHING PARTS)	80009	407-1236-00
08	210-0586-00			2	NUT.PL.ASSEM WA:4-40 X 0.25,STL CD PL	78189	211-041800-00
09	337-1711-00			1	SHIELD, ELEC: HI VOLTAGE	80009	337-1711-00
10	211-0008-00			4	SCREW,MACHINE:4-40 X 0.250,PNH,STL,POZ	83385	ORD BY DESCR
••	242 0164 00			•	INSULATOR FUMA 2 55 X 4 7 HIGH VOLTAGE	80000	342 0164 00
11	342-0164-00			1	INSULATOR, FILM:3.65 X 4.7, HIGH VOLTAGE	80009	342-0164-00
12	342-0159-00			1	INSULATOR, FILM:5.10 X 12.4 INCH	80009	342-0159-00
13	129-0413-00			4	POST,ELEC-MECH:0.538 INCH L (ATTACHING PARTS)	80009	129-0413-00
14	210-0994-00			1	WASHER,FLAT:0.125 ID X 0.25" OD,STL 	86928	5702-201-20
15				1	TRANSISTOR: CHAS MTG(SEE Q1456 REPL)		
16	211-0062-00			1	SCREW,MACHINE:2-56 X 0.312,PNH,STL	83385	ORD BY DESCR
17	210-1156-00			1	WASHER,SHLDR:0.09 ID X 0.085 D,NYL,0.2 O	80009	210-1156-00
18	342-0166-00			1	INSULATOR, PLATE: TRANSISTOR	80009	342-0166-00
19	214-1845-00	B010100	B017786	1	HEAT SINK,ELEC:TRANSISTOR	80009	214-1845-00
	214-1845-01	B017787	2011100	1	HEAT SINK,XSTR:0.125 DIA HOLE,AL	80009	214-1845-01
					·······(END ATTACHING PARTS)		

For Service Manuals Contact MAURITHUR (ECH YUAL SERVICES 8 Cherry Tree Rd Chinnor Oxon OX940Y Tel: 01844-051894 Fax- 01844-352554 Email: enquinas@mauritron.co.uk

Index	Tektronix	Serial/M	lodel No.					
No.	Part No.	Eff	Dscont	Qty	12345 Name & Description	Mfr		
					Name & Description	Code	Mfr Part Number	_
3-120				1	TRANSISTOR: CHAS MTG(SEE Q1482 REPL)			
					(ATTACHING PARTS)			
121	211-0182-00			1	SCR,ASSEM WSHR:2-56 X 0.312 INCH,PNH,STL	12360		
122	210-1156-00			1	WASHER, SHLDR: 0.09 ID X 0.085 D, NYL, 0.2 O	80009	ORD BY DESCR 210-1156-00	
					(END ATTACHING PARTS)	00000	210-1130-00	
123	342-0166-00			1	INSULATOR, PLATE: TRANSISTOR	80009	342-0166-00	
124	343-0088-00			1	CLAMP,LOOP:0.062 INCH DIA	80009	343-0088-00	
125	384-1101-00			2	EXTENSION SHAFT: 4.14 INCH LONG	80009	384-1101-00	
126 127	384-1175-00			1	EXTENSION SHAFT: 0.123 OD X 5.7 INCH LONG	80009	384-1175-00	
127	376-0029-00			2	CPLG.SHAFT,RGD:0.128 ID X 0.312 OD X 0.5*L	80009	376-0029-00	
128	213-0075-00 384-1179-00			2	SETSCREW:4-40 X 0.094,STL BK OXD,HEX	000BK	ORD BY DESCR	
129	384-1176-00			1	EXTENSION SHAFT: 9.312 INCH LONG	80009	384-1179-00	
130	384-1172-00			1	EXTENSION SHAFT: 0.125 OD X 1.45 INCH LONG	80009	384-1176-00	
131	384-1171-00			1	EXTENSION SHAFT: 0.125 OD X 1.7 INCH LONG	80009	384-1172-00	
32	376-0051-00			1	EXTENSION SHAFT: 1.05 L X 0.125 OD AL	80009	384-1171-00	
	213-0022-00			2 4	CPLG,SHAFT,FLEX:0.127 ID X 0.375 ID DELRIN	80009	376-0051-00	
	376-0051-01			4	SETSCREW:4-40 X 0.188 INCH,HEX SOC S	74445	ORD BY DESCR	
	213-0048-00			4	CPLG.SHAFT,FLEX:0.127 ID X 0.375 OD	80009	376-0051-01	
33				1	SETSCREW:4-40 X 0.125 INCH,HEX SOC S	74445	ORD BY DESCR	
				•	CKT BOARD ASSY:INTERFACE(SEE A9 REPL)			
34	211-0207-00	B010100	B018768	7	SCR.ASSEM WSHR:4-40 X 0.312 DOUBLE SEMS			
	211-0244-00	B018769		7	SCR.ASSEM WSHR:4-40 X 0.312 DOUBLE SEMS	83385	ORD BY DESCR	
	210-0261-00			1	TERMINAL,LUG:0.14 ID,PLAIN,BRASS	78189	ORD BY DESCR	
					(END ATTACHING PARTS)	80009	210-0261-00	
				-	CKT BOARD ASSY INCLUDES:			
35	131-1003-00			4	CONN,RCPT,ELEC:CKT BD MT,3 PRONG	80009	121 1002 00	
36	131-0566-00			7	BUS CONDUCTOR: DUMMY RES,2.375,22 AWG	57668	131-1003-00 JWW-0200E0	
37	136-0252-04			-	SOCKET, PIN TERM: U/W 0.016-0.018 DIA PINS	22526	75060-007	
	136-0220-00			-	.SKT, PL-IN ELEK: TRANSISTOR 3 CONTACT, PCB M	71785	133-23-11-034	
	136-0350-00			-	SOCKET, PLUG-IN: 3 PIN, LOW PROFILE	80009	136-0350-00	
38	210-0966-00	B010100	B016519	2	.WASHER,NONMETAL:0.312 ID X 0.875" OD,RBR	80009	210-0966-00	
39	210-0966-00	B016520		1	WASHER, NONMETAL: 0.312 ID X 0.875" OD, RBR	80009	210-0966-00	
39 40	136-0499-10			2	CONNECTOR, RCPT, 10 CONTACT	00779	4-380949-0	
41	136-0499-12 344-0154-00			1	CONNECTOR, RCPT,: 12 CONTACT	00779	4-380949-2	
42	214-0579-00			2	CLIP, ELECTRICAL: FUSE, CKT BD MT	80009	344-0154-00	
13	131-0608-00			26	TERM.TEST POINT:BRS CD PL	80009	214-0579-00	
14	131-1261-00			25	TERMINAL, PIN:0.365 L X 0.025 PH BRZ GOLD	22526	48283-036	
5	214-1291-00	B010100	B018893	24 1	CONTACT, ELEC: F-SHAPED	00779	1-380953-0	
	214-2593-00	B018894	D010095	1	HEAT SINK, ELEC: XSTR, 0.72 OD X 0.375"H	05820	207SB	
6	124-0093-00	2010001		1	HEAT SINK,XSTR:(1) TO-5 ALUMINUM	13103	2257B	
	355-0046-00			2	TERMINAL BOARD:5 NOTCH CERAMIC,CLIP MTD	80009	124-0093-00	
7	124-0092-00			1	MOUNT,TERM. BD:0.577 INCH H .TERMINAL BOARD:3 NOTCH,CERAMIC,CLIP MTD	80009	355-0046-00	
	355-0046-00			1	MOUNT,TERM. BD:0.577 INCH H	80009	124-0092-00	
8	124-0118-00			1	TERMINAL BOARD:1 NOTCH,CERAMIC,CLIP MTD	80009	355-0046-00	
	355-0046-00			1	MOUNT,TERM. BD:0.577 INCH H	80009	124-0118-00	
9	131-0382-00			1	TERMINAL,STUD:0.812 L,INSULATED	80009 71279	355-0046-00	
					(ATTACHING PARTS)	/12/9	572-4822-01-05-1	
0	210-0586-00			1	NUT, PL, ASSEM WA: 4-40 X 0.25, STL CD PL	78189	211-041800-00	
					(END ATTACHING PARTS)	/0103	211-041800-00	
1	361-0007-00	B010100	B016519	11	SPACER, SLEEVE: 0.250 INCH DIA, PLASTIC	80009	361-0007-00	
-	361-0007-00	B016520		8	SPACER, SLEEVE: 0.250 INCH DIA, PLASTIC	80009	361-0007-00	
2				-	.RES., VAR, NONWIR: FOCUS(SEE R1380 REPL)		001-0001-00	
•	010 0555 55				(ATTACHING PARTS)			
3	210-0583-00			1	.NUT,PLAIN,HEX:0.25-32 X 0.312 INCH,BRS	73743	2X20317-402	
4 5	210-0940-00			1	.WASHER,FLAT:0.25 ID X 0.375 INCH OD,STL	79807	ORD BY DESCR	
5	210-0046-00			1	.WASHER,LOCK:0.261 ID,INTL,0.018 THK,BRS	78189	1214-05-00-0541C	
8	386 3433 00				(END ATTACHING PARTS)			
6 7	386-2433-00			1	SUPPORT, VAR RES: CIRCUIT BOARD MOUNTING	80009	386-2433-00	
				1	SEMICOND DEVICE: VOLT MULT(SEE U1321 REPL)			
8	220-0736-00			•	(ATTACHING PARTS) NUT.PL.EXT WSHR:8-32 X 0.344 HEX.NYLON			
	LLV-V/JD-UU			2		23050		

For Service Manuals Contact MAURITRON TECHNICAL SERVICES

8 Cherry Tree Rd. Chinner Oxon OX9 40Y Tel: 01944-351694 Fay: 01844-359554 ELiaid- enguines@mauritron.co.uk

9-16

Fig. & Index	Tektronix	Serial/M	lodel No.				Mfr	
No.	Part No.	Eff	Dscont	Qty	12345	Name & Description	Code	Mfr Part Number
3-159				1	.SW, PUSH BUT	TON:X10 MAG(SEE S1110 REPL)		
160	361-0384-00			2		V:0.133L, RED POLYCARBONATE	80009	361-0384-00
161				1	.SW,PUSH BUT	TON:BEAM FINDER(SEE S450 REPL)		
162	361-0385-00			2	.SPACER,PB SV	V:0.164 INCH LONG	80009	361-0385-00
-163				1	.RES.,VAR,NON	WIR:INTENSITY		
164	361-0607-00			1	.SPACER,SWIT	CH:PLASTIC	80009	361-0607-00
				-	(SEE R1335A,B	REPL)		
-165				1	RES., VAR, NON	WIR:SCALE ILLUM		
				-	(SEE R1480 RE	PL)		
	361-0607-00			1	SPACER,SWIT	CH:PLASTIC	80009	361-0607-00
-166				1	.RES.,VAR,NON	WIR:ASTIG(SEE R1397 REPL)		
	361-0607-00			1	.SPACER,SWIT	CH:PLASTIC	80009	361-0607-00
-167				1	.RES.,VAR,NON	WIR:TRACE ROT(SEE R1386 REPL)		
	361-0607-00			1	SPACER,SWIT	CH:PLASTIC	80009	361-0607-00
-168	179-1934-00			1	WIRING HARNE	SS,:TRIGGER	80009	179-1934-00
-169	210-0774-00			5	.EYELET,META	LIC:0.152 OD X 0.245 INCH L,	80009	210-0774-00
-170	210-0775-00			5	EYELET.META	LIC:0.126 OD X 0.23 INCH L,	80009	210-0775-00
	179-1907-00			1	WIRING HARNE		80009	179-1907-00
-171	131-0707-00			2	.CONTACT.ELÉ	C:22-26 AWG,BRS & CU BE GOLD	22526	47439
-172	352-0171-00			2		ONN:1 WIRE,BLACK	80009	352-0171-00
	210-0774-00			10	EYELET, META	LLIC:0.152 OD X 0.245 INCH L,	80009	210-0774-00
	210-0775-00			10	.EYELET,META	LLIC:0.126 OD X 0.23 INCH L,	80009	210-0775-00
	179-1906-00			1	WIRING HARNE	SS,:PROBE POWER	80009	179-1906-00
	131-0707-00			8	.CONTACT,ELE	C:22-26 AWG,BRS & CU BE GOLD	22526	47439
-173	352-0169-00			4	.HLDR,TERM C	ONN:2 WIRE,BLACK	80009	352-0169-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Fig. & Index	Tektronix	Serial/Mo	del No.				Mfr	
No.	Part No.	Eff	Dscont	Qty	12345	Name & Description	Code	Mfr Part Number
4-1	437-0141-02			1	CAB,ELEC EQUI	P.STANDARD		
.2	348-0080-01			4	.FOOT,CABINET		80009	437-0141-02
3	352-0263-00	B010100	B022414	1			80009	348-0080-01
-	352-0263-01	B022415	0022714	4		SSY:TEK BLUE POLYCARBONATE	80009	352-0263-00
4	200-1412-00	0022413				SSY:TEK BLUE POLYCARBONATE	80009	352-0263-01
	367-0195-07				COVER,SCOPE:		80009	200-1412-00
5	200-0602-00					ING: 12.722 L, BLACK VINYL	80009	367-0195-07
5				1		TCH:2.12 DIA X 0.7, ACETAL	80009	200-0602-00
0	367-0195-00			1	HANDLE,CARRY		80009	367-0195-00
7	040 0007 00					CHING PARTS)		
7	213-0227-00			4		OR:6-32 X 0.50 DEG,FLH ST TTACHING PARTS)	83385	ORD BY DESCR
8	334-1999-01			1	.PLATE, IDENT: M	,	22670	ORD BY DESCR
Э	214-0516-00	B010100	B023829	2		0.959 DIA X 1.250 INCH LONG	80009	214-0516-00
10	214-1987-00	B010100	B023829	2	INDEX, HDL RING		80009	214-0516-00
11	214-0515-02	B010100	B023829	2		:1.42 DIA X 0.565 THK,AL CD	80009	
				-		CHING PARTS)	00009	214-0515-02
12	213-0139-00			2		D:10-24 X 0.375 INCH LONG	00001	
3	210-1182-00	B010100	B022499	2		N:0.218 ID X 0.69 INCH OD	000CY	ORD BY DESCR
	210-0805-00	B022500	2022403	2			80009	210-1182-00
	2.0 0000-00	0022000		4		.204 ID X 0.438 INCH OD TTACHING PARTS)	12327	ORD BY DESCR

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

.

Fig. & Index No.	Tektronix Part No.	Serial/M		•				Mfr	
NO.	Part No.	Eff	Dscont	Qty	123	4 5	Name & Description	Code	Mfr Part Number
5-	016-0556-01			1		RACK M			
1	367-0022-00			2	.HAND	LE,BOW:1	.5 X 4.5 INCH CHING PARTS)*******	80009 88245	016-0556-01 15986
2	213-0090-00			4	.SCRE	W,MACHIN	IE:10-32 X 0.50,HEX HD,STL,CD	83385	ORD BY DESCR
3	134-0067-00			4			GRAY PLASTIC	80009	134-0067-00
4	213-0334-00			2			0-28 X 0.750 INCH.SOC S	56878	ORD BY DESCR
5	351-0104-00			1	.SLIDE	SECT.DW	R:12.625 X 2.25 CHING PARTS)*******	06666	C-1353
6	212-0023-00			2			E:8-32 X 0.375,PNH,STL,CD PL	83385	ORD BY DESCR
7	210-0458-00			2	.NUT,P	L,ASSEM	WA:8-32 X 0.344,STL,CD PL TACHING PARTS)	78189	511-081800-00
8	210-0808-00			2	.EYELE	T,METALL	IC:CENTERING PARTS FOR EACH)*****	63743	25151.13-3
9	211-0507-00			1			E:6-32 X 0.312,PNH STL,CD PL	83385	ORD BY DESCR
10	210-0457-00			1	.NUT,PI	LASSEM	WA:6-32 X 0.312,STL CD PL TACHING PARTS)	83385	ORD BY DESCR
11	386-2669-00			1	.SUPPC	ORT, CABIN		80009	386-2669-00
12	212-0023-00			4			E:8-32 X 0.375, PNH, STL, CD PL	83385	ORD BY DESCR
13	210-0458-00			2	.NUT,PL	.,ASSEM \	NA:8-32 X 0.344,STL,CD PL TACHING PARTS)	78189	511-081800-00
14	407-1350-00			1	.BRACK	ET,ANGLE	EVIBRATION DAMPER, ALUMINUM CHING PARTS)	80009	407-1350-00
15	212-0023-00			2	.SCREV	MACHIN	E:8-32 X 0.375, PNH, STL, CD PL	83385	ORD BY DESCR
16	210-0458-00			2	.NUT,PL	.ASSEM V	VA:8-32 X 0.344,STL,CD PL TACHING PARTS)	78189	511-081800-00
7	211-0517-00			2			E:6-32 X 1 INCH, PNH, STL	83385	ORD BY DESCR
8	212-0033-00			4			E:8-32 X 0.750 INCH, PNH STL	83385	ORDER BY DESCR
9	437-0154-03			1		ET, SCOPE		80009	437-0154-03
0	351-0101-00	B010100	B018538	1	.SLIDE,	OWR,EXT:	18.0 X 1.69	80009	351-0101-00
	351-0101-02	B018539		1	.SLIDE,	WR,EXT:	W/CLOSED MOUNTING SLOTS	80009	351-0101-02
21	016-0099-00			1	.HDW K	IT,ELEK E	D:RACKMOUNT HDW TACHING PARTS)	80009	016-0099-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauritron.co.uk 4

ſ

Fig. & Index	Tektronix	Serial/Model No.			Mfr	
No.	Part No.	Eff Dscont	Qty	1 2 3 4 5 Name & Description	Code	Mfr Part Numbe
6-1	441-1171-00		1	CHASSIS,SCOPE:INVERTER	80009	441-1171-00
	211-0008-00		2	SCREW,MACHINE:4-40 X 0.250,PNH,STL,POZ	83385	ORD BY DESCR
	210-0938-00		2	WASHER, FLAT: 0.109 ID X 0.25 INCH OD.STL	75497	AN960-3
2	·····		1	CKT BOARD ASSY:DC INVERTER(SEE A11 REF	°L)	
3	136-0252-07		15	.SOCKET, PIN CONN:W/O DIMPLE	22526	75060-012
4			1	.XFMR,TOROID:(SEE T1601 REPL) (ATTACHING PARTS)		
5	343-0443-00		1	.RETAINER,XFMR:	80009	343-0443-00
5	212-0011-00		1	.SCREW,MACHINE:8-32 X 0.750 INCH,FLH STL	80009	212-0011-00
7	210-0409-00		1	.NUT,PLAIN,HEX.:8-32 X 0.312 INCH,BRS	73743	3046-402
3	211-0116-00		2	SCR,ASSEM WSHR:4-40 X 0.312 INCH,PNH BR:	S 83385	
9	*		4	TRANSISTOR:(SEE Q1652,Q1654,Q1662.	- 00000	ORD BY DESCR
	***** *****		-	Q1664 REPL)		
0	210-0586-00		3	MUT BLASSEN WARA ON A 25 CTL OD DI	70.00	
1	343-0451-00		1	NUT,PL,ASSEM WA:4-40 X 0.25,STL CD PL RETAINER.XSTR:	78189	211-041800-00
2	342-0195-00		1	INSULATOR, PLATE: 0.70 X 3 INCHES LONG	80009 08530	343-0451-00
			•	(END ATTACHING PARTS)	08530	ORD BY DESCR
3	348-0141-00		1	GROMMET, PLASTIC: U-SHP.0.625 X 0.658 INCH	80009	348-0141-00
4	348-0055-00		1	GROMMET, PLASTIC: 0.25 INCH DIA	80009	348-0055-00
5	352-0031-00		1	FUSEHOLDER: 3AG FUSE	75915	357001
6	211-0507-00		1	CATTACHING PARTS) SCREW, MACHINE: 6-32 X 0.312, PNH STL, CD PL	00005	
7	210-0006-00		1	WASHER,LOCK:#6 INTL,0.018 THK,STL CD PL	83385 78189	ORD BY DESCR
8	210-0407-00		1	NUT, PLAIN, HEX .: 6-32 X 0.25 INCH, BRS	73743	1206-00-00-0541C 3038-0228-402
	342-0229-00		1	INSULATOR, FILM: 1 X 2.55 INCH		
9	407-1341-00		1	BRACKET,ELEC SW:ALUMINUM	80009	342-0229-00
			•	(ATTACHING PARTS)	80009	407-1341-00
0	211-0101-00		2	SCREW, MACHINE: 4-40 X 0.25, FLH, 100 DEG, STL	83385	ORD BY DESCR
				······(END ATTACHING PARTS)······		
1	105-0479-00		1	ACTUATOR, SWITCH: SLIDE, INVERTER	80009	105-0479-00
2	260-0760-00		6	SWITCH,SENS:SUBMINIATURE,10A,125/240VAC	01963	E62-10A
3	211-0212-00		2	SCREW,MACHINE:2-56 X 1.75 INCH,PNH STL	83385	ORD BY DESCR
4	210-0405-00		1	NUT,PLAIN,HEX:2-56 X 0.188,BRS,CD PL	73743	12157-50
5	386-2649-00		1	PL,ACTR GUIDE:INVERTER	80009	386-2649-00
	214-1925-00		1	SPRING,SW ACT:POWER SOURCE	80009	214-1925-00
3	260-0834-00		1	SWITCH.TOGGLE:DPDT,5A,125VAC,0.25-40 THD (ATTACHING PARTS)	09353	U21-SHZQE
,	210-0562-00		1	NUT,PLAIN,HEX.:0.25-40 X 0.312 INCH,BBS	73743	2X20224-402
3	210-0046-00		1	WASHER,LOCK:0.261 ID,INTL,0.018 THK,BRS	78189	1214-05-00-0541C
	179-1963-00		1	WIRING HARNESS:OPTION NO.7	80009	179-1963-00
	348-0005-00		1	GROMMET,RUBBER:0.50 INCH DIA	70485	230
	200-1414-03		1	COVER,SCOPE:REAR	80009	200-1414-03
	210-0204-00		1	TERMINAL,LUG:0.146 INCH DIA DE,45 DEG BE	78189	2157-06-01-2520N
	334-2268-00		1	MARKER, IDENT:	80009	334-2268-00
	131-1333-00		1		80009	131-1333-00
	211-0101-00		2	SCREW,MACHINE:4-40 X 0.25,FLH,100 DEG,STL	83385	
	348-0365-00		4	FOOT,CABINET:PLASTIC,W/LATCH GROOVE	80009	ORD BY DESCR 348-0365-00
	161-0094-00		1	CABLE ASSY,PWR.:3 WIRE.36 INCHES LONG	70903	ORD BY DESCR

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Fig. & Index No.	Tektronix Part No.	Serial/Mo Eff	del No. Dscont	Qty	<u>12345</u> N	ame & Description	Mfr	
7-1 -2 -3 -4 -5 6	016-0535-02 016-0537-00 010-6075-13 010-6106-03 337-1674-01 134-0016-01 159-0016-00	B010100 B011145	B011144	1 1 2 2 1 1	POUCH, ACCESSORY: POUCH, ACCESSORY: LEAD, TEST:6 FOOT PROBE VOLTAGE:2 ME SHLD, IMPLOSION:CLE PLUG, TIP: W/BINDING F	W/HARDWARE.STANDARD VINYL,W/ZIPPER ETER,YEL,W/ACCESS AR 20ST	Code 80009 05006 80009 80009 80009	Mfr Part Number 016-0535-02 ZIP-6X91D 010-6075-13 010-6106-03 337-1674-01
	 159-0042-00			2 - 1	FUSE,CARTRIDGE:3AG (FOR USE AT 115V - AL FUSE,CARTRIDGE:3AG	1 54 2501/ 54 07 01 011	80009 71400 71400	134-0016-01 AGC 1 1/2
	070-2162-00 070-2163-00 119-0376-01 211-0038-00			1 1 1	(FOR USE AT 230V) MANUAL.TECH:INSTRU MANUAL.TECH:OPERAT FILTER.RAD INT:2 X 3A, 	ICTION FORS 250V 400 HZ	80009 80009 80009	AGC 3/4 070-2162-00 070-2163-00 119-0376-01
2 ⁻ 13	210-0586-00 131-0707-00 131-0708-00			1 NUT,PL,ASSEM WA	NUT,PL,ASSEM WA:4-40	4-40 X 0.312.FLH,100 DEG	83385 78189	ORD BY DESCR 211-041800-00
	131-1310-00 179-2162-00			1 1 4	CONTACT, ELEC: 0.48°L, 2 CONTACT, ELEC: MESH F CONNECTOR, RCPT: (SEE J1330 REPL)	8-32 AWG WIRE	22526 22526 80009	47439 47437 131-1310-00
	210-0774-00 210-0775-00 378-0726-00	B018468		1 2 2 1	WIRING HARNESS:OPTIC EYELET.METALLIC:0.152 EYELET.METALLIC:0.126 FILTER.MESH:EMI GROMMET.PLASTIC:DK (OD X 0.245 INCH L. OD X 0.23 INCH L.	80009 80009 80009 80009 80009	179-2162-00 210-0774-00 210-0775-00 378-0726-00 348-0239-00

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

and a state of the local division of the loc

The voltages and waveforms shown on this diagram were obtained by using the recommended test equipment ar test set-ups listed below.

170	RECOMMENDE	RECOMMENDED TEST EQUIPMENT					
Test oscilloscope	SPECIFIC						
Probe	Frequency response Deflection factor Input impedance Sweep rate	DC to 75 MHz 1 mV to 5 V/Div 1 MΩ 20 pF 50 ns	RECOMMENDED TYPE Tektronix 7603 equipped with 7A13 Amplifier and 7B50 Time-base units, c equivalent.				
	Fast-rise 10X attenuat patible with vertical ar oscilloscope.	ion probe com- nplifier of test	Tektronix P6053B, or equivalent.				
Voltmeter (Non-Ioading Digital Multimeter)	I Wanas	MΩ 2 500 V	Tektronix DM 501 Digital Multimeter or equivalent.				

475A Control Settings

Display Controls INTENSITY FOCUS SCALE ILLUM Vertical Controls (CH 1	Midrange Midrange Midrange and CH 2)	Sweep Controls TIME/DIV VAR TIME/DIV DELAY TIME POSITION HORIZ DISPLAY X10 MAG POSITION (Horiz) FINE	0.1 ms Calibrated detent Full counterclockwise A Off (button out) Midrange Midrange		
VOLTS/DIV	Center trace on graticule 5 mV for dc voltages 100 mV for waveforms	Voltage Measurements	ange		
VAR VOLTS/DIV AC-GND-DC INVERT VERT MODE 100 or 20 MHz BW	Calibrated detent DC Off (button out) CH 1 Full bandwidth (Push in	Voltage measurements are taken with no signal applied and the trace positioned to the center horizontal graticule line. The voltmeter common is connected to chassis ground. Waveform Conditions			
Trigger Controls (A and B COUPLING LEVEL SLOPE SOURCE TRIG MODE A TRIGGER HOLDOFF) AC 0 + NORM AUTO NORM	Apply the 475A calibrator si P6075 10X probe (supplied w +GATE (rear panel) through a to test oscilloscope external cilloscope trigger source to ex for ac coupling. For waveforms centerline labeled 0 V, set the input for dc coupling. Set test oscilloscope VOLTS trols as indicated on readout syn Tolerance of voltages and wa	trigger input. Set test os- ternal and set vertical input s which have the horizontal test oscilloscope vertical S/DIV and TIME/DIV con- mbols on each waveform.		
		Pruels Contact			

MAURI S Cherry Free Rd, Clunnor O'on OX9 4OY Tel:- 01844-351694 Fax- 01844-352554 Email:- enquiries@mauritron.co.uk



(E) Board Locations.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk E.

C



g. &

dex).	Tektronix Part No.	Serial/Mo Eff	del No. Dscont	Qty	1 2 3 4 5 Name & Description	Mfr	
	016-0535-02 016-0537-00 010-6075-13 010-6106-03 337-1674-01 134-0016-01 159-0016-00 	B010100 B011145	B011144	1 1 2 2 1 1 2 - 1 -	POUCH, ACCESSORY: W/HARDWARE, STANDARD POUCH, ACCESSORY: VINYL, W/ZIPPER LEAD, TEST:6 FOOT PROBE VOLTAGE:2 METER, YEL, W/ACCESS SHLD, IMPLOSION: CLEAR PLUG, TIP: W/BINDING POST FUSE, CARTRIDGE: 3AG, 1.5A, 250V, FAST-BLOW (FOR USE AT 115V - ALSO FOR F1318 REPL) FUSE, CARTRIDGE: 3AG, 0.75A, 250V, FAST-BLOW (FOR USE AT 230V)	Code 80009 05006 80009 80009 80009 80009 71400 71400	Mfr Part Number 016-0535-02 ZIP-6X91D 010-6075-13 010-6106-03 337-1674-01 134-0016-01 AGC 1 1/2 AGC 3/4
	070-2163-00			1	MANUAL, TECH: INSTRUCTION MANUAL, TECH: OPERATORS	80009 80009	070-2162-00 070-2163-00

475A/R475A OSCILLOSCOPE SERVICE

MAR 1984
475A Service

DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS

Symbols and Reference Designators

Electrical components shown on the diagrams are in the following units unless noted otherwise:

Values one or greater are in picofarads (pF). Capacitors = Values less than one are in microfarads (μ F). Ohms (Ω) . Resistors =

BLOCK DIAGRAM For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 40Y Tel:- 01844-351694 Fax:- 01844-352554 Email: enquiries@mauritron.co.uk

Symbols used on the diagrams are based on USA Standard Y32.2-1967.

Logic symbology is based on MIL-STD-806B in terms of positive logic. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

The following prefix letters are used as reference designators to identify components or assemblies on the diagrams.

A	Assembly, separable or repairable	н
		нв
AT	Attenuator, fixed or variable	
8	Motor	HY
BT	Battery	J
		ĸ
-		L
		LR
CR	Diode, signal or rectifier	
DL	Delay line	м
DS	Indicating device (lamp)	Р
E	Spark Gap	a
F	Fuse	-
FL	Filter	R
	AT B BT C CB CR DL DS E	(circuit board, etc.)ATAttenuator, fixed or variableBMotorBTBatteryCCapacitor, fixed or variableCBCircuit breakerCRDiode, signal or rectifierDLDelay lineDSIndicating device (lamp)ESpark GapFFuse

The following special symbols are used on the diagrams:

н	Heat dissipating device (heat sink,
	heat radiator, etc.)
HR	Heater
НΥ	Hybrid circuit
J	Connector, stationary portion
к	Relay
L	Inductor, fixed or variable
LR	Inductor/resistor combination
M	Meter
P	Connector, movable portion
a.	Transistor or silicon-controlled
-	rectifier
	Resistor, fixed or variable

- Thermistor **RT** s
- Switch т
 - Transformer Thermocouple
- тс ΤР Test point
 - Assembly, inseparable or non-repairable (integrated circuit, etc.)
- Electron tube ν

υ

7

- Voltage regulator (zener diode, etc.) VR
 - Crystal Phase shifter







Million of the Article of the Article



vice

formed

airable

tc.)

s List

÷



CHANNEL 2 COMPONENTS



.

REV JUN 1983



 $\langle v \rangle$

FRONT



**Part of etched circuit board *See Parts List for serial number ranges.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4,0Y Tet: 01844-351694 Fax: 01844-352554 Email: enquines@mauniron.co.uk



(B) Board Location.

Fig. 8-4 A & B, Vertical Output Component Locations,

CINENIO

REV A, FEB 1979



amiruming



Fig. 8-5 A through C, 'A' Trigger Generator Component Locations

475A Service

0



(B) Board Segment Location.

· • • •

proven

1. 1



۲

ł

. . .





VERTICAL OUTPUT







'A' TRIGGER GENERATOR 🌖

REV SEP 1982

475A OSCILLOSCOPE



\$

Tel:-01844-351694 Fax:-01844-352554 Email:-enquines@mauntron.co.uk 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY MAURITRON TECHNICAL SERVICES For Service Manuals Contact

REV 55P 1982

475A05C1LL05C0PE



475A Service

SWEEP AND Z-AXIS SWEEP AND Z-AXIS



,

REV B SEP 1980

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquiries@mauriton.co.uk



V

For Service Manuals Contact MAURITRON TECHNICAL SERVICES & Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



CONFORMENTS

Located on back of board: C1062 C1071 C1072 C1072 C1022 C1082 D51091 D51110 D51110 S1090 R1061

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:- enquiries@mauritron.co.uk



Fig. 8-9 A & B, Timing and Horizontal Switching Component Locations.

0



~



TIMING & HORIZONTAL







For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax: 01844-352554 Email: enquines@mauritron.co.uk ✨



POWER SUPPLY COMPONENTS



475A Service

VOLTAGES AND WAVEFORMS

The voltages and waveforms shown on this diagram were obtained by using the recommended test equipment and test set-ups listed below.

ITEM	SPECIFICATIONS		RECOMMENDED TYPE		
Test oscilloscope	Frequency response Deflection factor Input impedance Sweep rate	DC to 75 MHz 1 mV to 5 V/Div 1 MΩ 20 pF 50 ns	Tektronix 7603 equipped with 7A13 Amplifier and 7B50 Time-base units, or equivalent.		
Probe	Fast-rise 10X attenuation probe com- patible with vertical amplifier of test oscilloscope.		Tektronix P6053B, or equivalent.		
Voltmeter (Non-loading Digital Multimeter)) MΩ to 500 V	Tektronix DM 501 Digital Multimeter or equivalent.		

RECOMMENDED TEST EQUIPMENT

475A Control Settings

Display Controls	
INTENSITY	Midrange
FOCUS	Midrange
SCALE ILLUM	Midrange

Vertical Controls (CH 1 and CH 2)

POSITION	Center trace on graticule
VOLTS/DIV	5 mV for dc voltages
	100 mV for waveforms
VAR VOLTS/DIV	Calibrated detent
AC-GND-DC	DC
INVERT	Off (button out)
VERT MODE	CH 1
100 or 20 MHz BW	Full bandwidth (Push in,
	then release)

Trigger Controls (A and B)
COUPLING	AC
LEVEL	0
SLOPE	÷.
SOURCE	NORM
TRIG MODE	AUTO
A TRIGGER HOLDOFF	NORM

Sweep Controls TIME/DIV VAR TIME/DIV DELAY TIME	0.1 ms Calibrated detent
POSITION	Full counterclockwise
HORIZ DISPLAY	A
X10 MAG	Off (button out)
POSITION (Horiz)	Midrange
FINE	Midrange

Voltage Measurements

Voltage measurements are taken with no signal applied and the trace positioned to the center horizontal graticule line. The voltmeter common is connected to chassis ground.

Waveform Conditions

Apply the 475A calibrator signal to CH 1 input through a P6075 10X probe (supplied with 475A). Connect 475A A +GATE (rear panel) through a 42-inch 50-ohm BNC cable to test oscilloscope external trigger input. Set test oscilloscope trigger source to external and set vertical input for ac coupling. - ACCERT

1

Set test oscilloscope VOLTS/DIV and TIME/DIV controls as indicated on readout symbols on each waveform.

Tolerance of voltages and waveforms shown are 20%.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor For Service Maxwell Contact MAURITRON RECENSION OF A Structure 8 Cherry Free Rd, Chinghofon c.uk Chon 0X9 40Y Tel: 01244-351894 Fax: 01844-35254 Email: enguinesig/mentiling.co.uk



L V POWER SUPPLY

 $\langle \psi \rangle$



COMPONENTS



*



.



475A Service

REV A SEP 1980





1862-41

A9-MAIN INTERFACE B. Board Locations.

. 969 Adjustment Locations 1, A and B

0



Adjustment Locations 3, A and B.

0
475A Service

VOLTAGES AND WAVEFORMS

The voltages and waveforms shown on this diagram were obtained by using the recommended test equipment and test set-ups listed below.

RECOMMENDED TEST EQUIPMENT

ITEM	SPECIFICATIONS	RECOMMENDED TYPE
Test oscilloscope	Frequency responseDC to 75 MHzDeflection factor1 mV to 5 V/DInput impedance1 MΩ 20 pFSweep rate50 ns	
Probe	Fast-rise 10X attenuation probe com patible with vertical amplifier of test oscilloscope.	- Tektronix P6053B, or equivalent.
Voltmeter (Non-loading Digital Multimeter)	Input Impedance 10 MΩ Range 0 to 500 V	Tektronix DM 501 Digital Multimeter or equivalent.

475A Control Settings

100 or 20 MHz BW

Trigger Controls (A and B)

A TRIGGER HOLDOFF NORM

COUPLING

LEVEL

SLOPE

SOURCE

TRIG MODE

Display Controls INTENSITY FOCUS	Midrange	TIME/DIV VAR TIME/DIV DELAY TIME	0.1 ms Calibrated detent
SCALE ILLUM	Midrange Midrange	POSITION	Full counterclockwise
	marange	HORIZ DISPLAY	А
		X10 MAG	Off (button out)
		POSITION (Horiz)	Midrange
		FINE	Midrange
Vertical Controls (CH 1	and CH 2)		
POSITION	Center trace on graticule		
VOLTS/DIV	5 mV for dc voltages	Voltage Measurements	
VAR VOLTS/DIV AC-GND-DC INVERT VERT MODE	100 mV for waveforms Calibrated detent DC Off (button out) CH 1	Voltage measurements are taken with no signal applie and the trace positioned to the center horizontal graticul line. The voltmeter common is connected to chass ground.	

Full bandwidth (Push in,

then release)

AC

0

+-

NORM

AUTO

Waveform Conditions

Sweep Controls

Apply the 475A calibrator signal to CH 1 input through a P6075 10X probe (supplied with 475A). Connect 475A A +GATE (rear panel) through a 42-inch 50-ohm BNC cable to test oscilloscope external trigger input. Set test oscilloscope trigger source to external and set vertical input for ac coupling.

Set test oscilloscope VOLTS/DIV and TIME/DIV controls as indicated on readout symbols on each waveform.

Tolerance of voltages and waveforms shown are 20%.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd Chirinor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4.0Y Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

475A Service

омноиеится сомноиеится сомноиеится



 τ^{α}

!...

Fig. 8-3 A through D, Channel Switching Component Locations

1862-24

(C) Board Locations.

A3-VERTICAL PREAMP

**See diagram 11 for C329

(D) Partial A4-Vertical Mode-Gain Switch board.

Located on back of board: C320 S300 R315 R325

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4,0Y Tel:- 01844-351694 Fax:- 01844-35254 Email:- enquines@mauriton.co.uk



13 Inits, or

ient and

leter or

ise

upplied aticule chassis ough a

175A A Ccable est osest osti input form.







ming.

0



475A/R475A OSCILLOSCOPE SERVICE

9





A. FRONT PANEL



B. REAR PANEL

2162-02

2-3

Fig. 2-2. Front panel and rear panel controls and connectors.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon CX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Operating Informa	tion—475A Service	
CH 2 OR Y	Input connector for Channel 2 deflection signals or Y-axis deflection in the X-Y mode of operation.	
GAIN (5 and 10 mV)	Screwdriver adjustments to set the gain of the Vertical Preamp.	
VOLTS/DIV	Selects vertical deflection fac- tor in a 1-2-5 sequence (VAR control must be in the calibrated detent for the in- dicated deflection factor).	
VAR	Provides continuously variable uncalibrated deflection factors between the calibrated settings of the VOLTS/DIV switch.	
UNCAL	Light indicates that the VAR control is not in the calibrated position.	
Input Coupling (AC-GND-DC)	Selects the method of coupling signal to the input of the Vertical Amplifier.	
	AC: Signal is capacitively coupled to the Vertical Amplifier. DC component of signal is blocked. Low- frequency limit (lower -3 dB point) is about 10 Hertz.	
	GND: Input signal is removed and the input circuit is ground- ed. Does not ground the input signal.	The sig charac switch tion in
	DC: All components of the in- put signal are passed to the Vertical Amplifier.	The A ing and VIEW d
100 OR 20 MHz BW/ TRIG VIEW	Multi-purpose switch that limits vertical bandwidth or displays an external triggering signal. Full bandwidth of 250 MHz is provided in the switch position obtained when the TRIG VIEW is pushed in, then released. The full bandwidth position serves as the reference for the follow- ing settings.	

100 (MHz): When TRIG VIEW button is pulled to the first detent (100 indicated on yellow band of TRIG VIEW knob) the upper bandwidth of the complete Vertical Deflection System is limited to approximately 100 MHz.

20 (MHz): When TRIG VIEW button is pulled to the second detent (100 and 20 indicated on yellow band of TRIG VIEW knob) the upper bandwidth of the complete Vertical Deflection System is limited to approximately 20 MHz.

TRIG VIEW: When the TRIG VIEW button is pushed and held, the output of the Vertical Preamplifier is interrupted, and the trigger signal selected by the setting of A TRIGGER SOURCE switch is displayed on the crt.

When the TRIG VIEW button is pushed and held, the crt display available is explained in each of the following settings of the A TRIGGER SOURCE switch.

NOTE

ignals displayed are affected by the coupling cteristics of the A TRIGGER COUPLING h positions (see A Trigger Coupling informathis section).

TRIGGER LEVEL control affects the triggerd the vertical positioning when using a TRIG display.

> NORM: Any signal that is displayed in full bandwidth position is viewed with an increase in signal amplitude.

CH 1: Any signal that is displayed in CH 1 of VERT MODE, in full bandwidth position, is viewed with an increase in signal amplitude.

		Operatir	ng Information—475A Service
	CH 2: Any signal that is dis- played in CH 2 of VERT MODE, in full bandwidth position, is viewed with an increase in signal amplitude.		CH 2 OR X-Y: Displays Channel 2 only. Must be pushed when operating in X-Y mode.
	LINE: The power line signal is displayed at an amplitude ap- proximately equalling full ver- tical graticule deflection.	A and B Triggering (I COUPLING	both where applicable) Determines the method used to couple signal to input of trigger circuits.
	EXT: The signal present at the A TRIGGER external input con- nector will be displayed.		AC: Rejects DC and attenuates signals below about 60 Hz. Accepts signals above about 60 Hz.
	EXT \div 10: The signal present at the A TRIGGER external input connector will be displayed, but will be reduced approximately 10 times of that viewed in EXT.		LF REJ: Rejects DC and atten- uates signals below about 50 kHz. Accepts signals above about 50 kHz.
INVERT	Pushbutton switch that inverts the Channel 2 display.		HF REJ: Accepts signals between 60 Hz and 50 kHz. Rejects DC and attenuates all signals outside the above range.
VERT MODE	Selects the vertical mode of operation.		DC: Accepts all trigger signals between DC and 200 MHz or greater.
	CH1: Displays Channel 1 only.	SOURCE	Selects source of trigger signal.
	ALT: Dual-trace display of signals using both channels. Display is switched between channels at the end of each sweep.		NORM: Internal trigger signal obtained from Vertical Deflec- tion System. Actual source is signal(s) displayed on crt.
	ADD: Signals applied to the CH 1 OR X and the CH 2 OR Y connectors are algebraically added and the sum is displayed on the crt. The INVERT switch	i	CH 1: A sample of the signal connected to the CH 1 OR X input connector is used as a trigger signal.
	in Channel 2 allows the display to be CH 1 + CH 2 or CH 1 - CH 2.	c	CH 2: A sample of the signal connected to the CH 2 OR Y nput connector is used as a rigger signal.
	CHOP: Dual-trace display of signals on both channels. Display is switched between channels at an approximate repetition rate of 1 megahertz.	fi E	EXT: Trigger signal obtained rom signal connected to the External Trigger Input connec- or.

Operating Information—475A Service

EXT ÷ 10 (A Trigger circuit only): External trigger signal attenuated by a factor of 10.

STARTS AFTER DELAY (B trigger circuit only): B sweep starts immediately after the delay time selected by the DELAY TIME POSITION dial and the DELAY TIME switch.

LINE (A trigger circuit only): Trigger signal obtained from a sample of the line voltage applied to the instrument.

SLOPE

Selects the slope of the trigger signal which starts the sweep.

+: Sweep can be triggered from the positive-going portion of the trigger signal.

-: Sweep can be triggered from the negative-going portion of the trigger signal.

Selects the amplitude point on the trigger signal at which the sweep is triggered.

A TRIG MODE

LEVEL

Determines the operating mode for the A Trigger Circuit.

AUTO: With the proper trigger control settings, A Sweep can be initiated by signals that have repetition rates above about 20 Hertz and are within the frequency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misadjusted, the sweep free-runs to produce a reference trace.

within the frequency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misadjusted, there is no trace. SINGL SWP: After a sweep is displayed, further sweeps cannot be presented until the SINGL SWP pushbutton is pressed again. The display is

NORM: With the proper trigger

control settings, A Sweep can

be initiated by signals that are

A light on condition indicates that A Sweep Generator is triggered and will produce a stable display.

triggered as for NORM operation using the A Triggering con-

trols.

Provides control of holdoff time between sweeps to obtain stable displays when triggering in aperiodic signals (such as complex digital words). Variable can increase hold-off time up to at least 9 times the setting of the TIME/DIV switch. In the B ENDS A position (fully clockwise), the A Sweep is reset at the end of the B Sweep to provide the fastest possible sweep repetition rate for delayed sweep presentations.

External Trigger Input (not labeled)

TRIG Indicator

A TRIG HOLDOFF

Input connectors for external trigger signals.

A and B Sweep

DELAY TIME POSITION

Provides variable sweep delay between 0.00 and 10.00 times the delay time indicated by the DELAY TIME switch.

2-6

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Operating Information—475A Service

		Opera	ung information—475A Service
A AND B TIME/DIV AND DELAY TIME	A TIME/DIV switch (clear plastic outer flange) selects the basic delay time to be multiplied by the DELAY TIME POSITION dial setting) for delayed-sweep operation. The B TIME/DIV switch (inner dark knob) selects the sweep rate for A only dis- plays or for the B portion of a delayed sweep display. VAR control must be in the calibrated detent for calibrated sweep rates. Disables sweep for		MIX: The first part of the horizontal sweep is displayed at a rate set by the A TIME/DIV switch and the latter part of the sweep at a rate set by the B TIME/DIV switch. Relative amounts of the display allocated to each of the two rates are determined by the set- ting of the DELAY TIME POSITION dial.
VAR	X-Y operation. Provides continuously variable (uncalibrated) sweep rates between the calibrated settings of the TIME/DIV switch. Varies the A Time Base sweep rate in the nondelayed mode of horizontal operation and the B Time Base sweep rate in the delayed sweep mode. Extends		A INTEN: Displayed sweep rate determined by the A TIME/DIV switch. An inten- sified portion appears on the display during the B sweep time. This switch position provides a check of the duration and position of the B sweep (delayed sweep) with respect to the delaying sweep (A).
	the slowest sweep rate to at least 1.25 seconds/division. Sweep rate is calibrated when the control is rotated fully clockwise to the calibrated de- tent.		B DLYD: Sweep rate deter- mined by the B TIME/DIV switch with the delay time determined by the setting of the DELAY TIME (A TIME/DIV) switch and the DELAY TIME POSITION dial.
UNCAL	Light that indicates when the VAR TIME/DIV control is out of the calibrated detent and the horizontal sweep rate is un-	Horizontal POSITION Horizontal FINE	Positions the display horizon- tally.
	calibrated.	Honzontal PINE	Provides more precise horizon- tal position adjustments.
X10 MAG Indicator	Light that indicates when the X10 MAG is turned on.	X10 MAG Pushbutton	Increases the displayed sweep rate by a factor of 10.
READY	Light that indicates that A Sweep has been prepared to present a single sweep upon receipt of an adequate trigger signal.	Calibrator and Power CALIBRATOR	A combination current loop/s- quarewave voltage output device. Provides a 30 mA squarewave current, 300 mV
HORIZ DISPLAY	Selects the horizontal mode of operation.		squarewave voltage signal with a repetition rate of ap- proximately 1 kHz.
	A: Horizontal deflection provided by ATIME/DIV switch.	POWER	Turns instrument power on and off.
@		For Service Manuals Conta	ct 2-7

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel: 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Operating Information—475A Service

LOW LINE Indicator	Light that indicates the applied line voltage is below the lower	OBTAININ	G BASI	C DISPLAYS
	limit of the regulating range	Introduction		
	selected by the Regulating Range Selector assembly.	basic displays commo	operation only used.	Il allow the operator who of the 475A to obtain the Before proceeding with instrument controls as
Rear Panel				
A + GATE		Vertical Controls		
	Output connector providing a positive-going rectangular pulse coincident with the A sweep time.	VERT MODE Switch VOLTS/DIV Switche	es Proper	position determined by de of signal to be
			applied	
		VOLTS/DIV VAR Controls	0-11	
B + GATE		Input Coupling	Calibra	ted detent.
B + GATE	Output connector providing a positive-going rectangular	Switches Vertical POSITION	AC	
	pulse coincident with the B sweep time.	Controls	Midrang	je
		100 or 20 MHz BW Switch	Not lim	ited (Vallander b
			visible).	ited (Yellow band not
		INVERT Switch	Button	
CH 2 VERT SIGNAL	Output connector providing a	INTENSITY Control FOCUS Control	Fully co	unterclockwise
OUT	sample of the signal applied to	SCALE ILLUM	Midrang	e
	the CH 2 input connector.	Control	Midrang	e
				le la constante de la constante
		Trigger Controls (bot	th A and E	-
EXT Z AXIS Input	Input connector for intensity	SLOPE Switch	+	
	modulation of the crt display.	LEVEL Control	0	
		SOURCE Switch COUPLING Switch	NORM	
		TRIG MODE Switch	AC AUTO	For Service Manuals Contact
Regulating Range		A TRIG HOLDOFF		MAURITRON TECHNICAL SERVICES 8 Cherry Tree Bd China
Selector	Selects the regulating range of the internal power supplies (low, medium, high; determined	Control	NORM	Tel:- 01844 25400 OX9 4QY
	by specific line voltage applied to the instrument).	Horizontal Sweep Cor	ntrols	Email:- enquiries@mauritron.co.uk
		TIME/DIV Switches TIME/DIV VAR HORIZ DISPLAY	Calibrate	ogether at 1 ms d detent
PROBE POWER	Connectors that make	Switch X10 MAG Switch	A Off (butto	
	operating power available for	POSITION Control	Midrange	
	active device probe systems.	FINE Control	Midrange	
		Normal Sweep Display		
Rear Panal				n (hutton aut) All
Rear Panel Feet	Provide temporary support for the instrument and provide a convenient cord wrap to store	1. Pull the POWER sy several minutes for instru	ment war	n (button out). Allow mup.
	power cord when instrument is	2. Connect an extern	nal signal	to the CH 1 incut
	not in use.	connector.	iai siyiidi	

3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FINDER pushbutton and adjust the CH 1 VOLTS/DIV switch until the display is reduced in size vertically; then center the compressed display with the vertical and horizontal POSITION controls; release the BEAM FINDER pushbutton. Adjust the FOCUS control for a well-defined display.

4. Set the CH 1 VOLTS/DIV switch and CH 1 POSITION control for a display that remains in the display area vertically.

5. Adjust the A Trigger LEVEL control for a stable display.

6. Set the TIME/DIV switch and the horizontal POSITION control for a display that remains in the display area horizontally.

Magnified Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Adjust the horizontal POSITION control to move the area to be magnified to within the center graticule division of the crt. If necessary, change the TIME/DIV switch setting so the complete area to be magnified is within the center division.

3. Set the X10 MAG switch to the on position (button in) and adjust the horizontal POSITION control for precise positioning of the magnified display. Divide the TIME/DIV setting by 10 to determine the magnified sweep rate.

Delayed Sweep Displays

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Set the HORIZ DISPLAY switch to A INTEN and the B Trigger SOURCE switch to STARTS AFTER DELAY.

3. Pull out the B TIME/DIV switch knob and turn clockwise so the intensified zone on the display is the desired length. Adjust the INTENSITY control to achieve the desired display brightness.

4. Adjust the DELAY TIME POSITION dial to position the intensified zone to the portion of the display to be delayed.

@

Operating Information—475A Service

5. Set the HORIZ DISPLAY switch to B DLYD. The intensified zone on the display noted in step 3 is now being displayed in the delayed form. The delayed sweep rate is indicated by the line on the B TIME/DIV switch knob.

6. For a delayed sweep display that will exhibit less jitter, set the B Trigger SOURCE switch to the same position as the A Trigger SOURCE switch and adjust the B Trigger LEVEL control for a stable display. If the A Trigger SOURCE switch is in the LINE position, a sample of the line voltage will have to be supplied to the B Trigger circuit externally.

Mixed Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Pull out the B TIME/DIV switch knob and turn clockwise to the desired sweep rate. Adjust the INTEN-SITY control to achieve the desired display brightness.

3. Set the HORIZ DISPLAY switch to MIX. The crt display now contains more than one time factor on the horizontal axis. The first portion of the display is at the A Time Base sweep rate and the latter part is at the B Time Base sweep rate. The start of the B Time Base portion of the display can be changed by adjusting the DELAY TIME POSITION control.

X-Y Display

1. Preset the instrument controls and turn the instrument power on. Allow several minutes for instrument warm-up.

2. Set the TIME/DIV switch to X-Y and the VERT MODE to CH 2. Apply the vertical signal to the CH 2 OR Y input connector and the horizontal signal to the CH 1 OR X input connector. The CH 2 POSITION control will provide vertical positioning and the CH 1 POSITION control will provide horizontal positioning.

3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FINDER pushbutton and adjust the CH 1 and CH 2 VOLTS/DIV switches until the display is reduced in size both vertically and horizon-tally; then center the compressed display with the POSITION controls; release the BEAM FINDER pushbutton. Adjust the FOCUS control for a well-defined display.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4OY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.co.uk

CIRCUIT DESCRIPTION

V

A

Introduction

This section of the manual describes the circuitry used in the 475A Oscilloscope. The description begins with a discussion of the instrument, using a basic block diagram. Next, each circuit is described in detail, using detailed block diagrams when appropriate, to show the relationships between the stages in each major circuit.

Digital Logic

Digital logic techniques are used to perform many functions within this instrument. The function and operation of the logic circuits are described using logic symbology and terminology. All logic functions are described using the positive logic convention. Positive logic is a system of notation where the more positive of two levels (HI) is called the true or 1 state; the more negative level (LO) is called the false or 0 state. The HI-LO method of notation is used in this logic description. The specific voltages that constitute a HI or LO state vary between individual devices.

NOTE

The HI-LO logic notation can be conveniently converted to 1-0 notation by disregarding the first letter of each step. Thus:

HI = 1 LO = 0

It should be noted that not all of the integrated circuit devices in this instrument are digital logic devices. The function of non-digital devices are described individually, using operating waveforms or other techniques to illustrate their function.

OUTLINE FOR CIRCUIT DESCRIPTION

BLOCK DIAGRAM

General	Page 3-2
CHANNEL 1 PREAMP	
General Input Coupling Input Attenuator First Cascode Amplifier Second Cascode Amplifier Third Cascode Amplifier	Page 3-4 Page 3-5 Page 3-5 Page 3-5 Page 3-6 Page 3-6

CHANNEL 2 PREAMP

General	
First Cascode Amplifier	

Page 3-6 Page 3-7

VERTICAL CHANNEL SWITCHING

General Channel Switch IC Switching Logic Flip-Flops Two Megahertz Clock Chop Blanking Amplifier Channel 2 Signal Output Amplifier Normal Trigger Pickoff Amplifier Scale-Factor Switching Circuits	Page 3-7 Page 3-8 Page 3-8 Page 3-9 Page 3-9 Page 3-9 Page 3-9 Page 3-9
/ERTICAL OUTPUT AMPLIFIER General First IC Amplifier Second IC Amplifier	Page 3-9 Page 3-9 Page 3-10
TRIGGER GENERATOR 5	Page 3-10

General	Page 3-10
Trigger Source	Page 3-11
Trigger Coupling	Page 3-11
Input Source Follower	Page 3-11
Paraphase Amplifier	Page 3-11
Tunnel Diode Driver	Page 3-11
Trigger View Amplifier	Page 3-11

B TRIGGER GENERATOR

General

Trigger Source

Page 3-12 Page 3-12

SWEEP AND Z-AXIS LOGIC (7)

-	
General	Page 3-12
Sweep Control Integrated Circuit	Page 3-13
Main Gate Comparator	Page 3-14
Delayed Gate Comparator	Page 3-14
A Trigger TD Reset Circuit	Page 3-14
Holdoff Start Circuit	Page 3-14
	-
Z Axis Logic Multivibrator	Page 3-14
Delaying Sweep Latch Circuit	Page 3-15
B Trigger TD Reset Circuit	Page 3-15
Main Sweep Holdoff Gate and	. ugo o 10
Delayed Sweep Override Amplifier	Daga 2 15
	Page 3-15
A +GATE And B +GATE Amplifiers	Page 3-15
LOW LINE Indicator Circuit	Page 3-15

SWEEP GENERATORS

TIMING AND HORIZONTAL DISPLAY SWITCHING

General	
	Page 3-16
Delaying Sweep Generator Main Gate Amplifier	Page 3-17
Sween Disconnect A	Page 3-17
Sweep Disconnect Amplifier	Page 3-17
Sawtooth Sweep Generator Sweep Start Amplifier	Page 3-18
Output Buffer Amplifier	Page 3-18
Delaying Swoon End Dire	Page 3-18
Delaying Sweep End Difference Amplifier	
Delay Pickoff Comparator	Page 3-18
Non-Delaying Sweep Generators	Page 3-18
"B" Gate Amplifier	Page 3-19
Non-Delaying Sweep Generator	Page 3-19
Differences	
Mixed Mode Operation	Page 3-19
Non-Delaying Sweep End Difference	Page 3-19
Amplifier	_
TIME/DIV Functions (Knobs Unlocked	Page 3-19
Chiefens (Khobs Unlocked	d) Page 3-20

HORIZONTAL AMPLIFIER

General	_
Input Paraphase Amplifier	Page 3-20
Gain Setting Amplifier	Page 3-21
Output Amplifier	Page 3-21
a a that Withhimet	Page 3-21

LOW-VOLTAGE POWER SUPPLY

General	•
Power Input	Page 3-21
Secondary Circuit	Page 3-23
+50-Volt Supply	Page 3-23
+110-Volt Supply	Page 3-23
+15-Volt Supply	Page 3-24
+5-Volt Supply	Page 3-24
-8-Volt Supply	Page 3-24
-15-Volt Supply	Page 3-24
10-von Supply	Page 3-24

CRT CIRCUIT

1

General	Page 3-24
High-Voltage Oscillator	Page 3-25
High-Voltage Regulator	Page 3-25
High-Voltage Rectifiers and Output	Page 3-26
Control-Grid DC Restorer	Page 3-26
CRT Control Circuits	Page 3-26
Z-Axis Amplifier	Page 3-26
CALIBRATOR 3	
General	Page 3-27
Multivibrator	Page 3-27
Output Amplifier	Page 3-27
FAN MOTOR CIRCUIT	

Page 3-27

BLOCK DIAGRAM

General

The following discussion is provided to aid in understanding the overall concept of the 475A Oscilloscope before the individual circuits are discussed in detail. A basic block diagram of the 475A Oscilloscope is shown in Fig. 3-1. Only the basic interconnections between the individual blocks are shown on this diagram. Each block represents a major circuit within the instrument. The numbered diamond in each block refers to the complete circuit diagram of that major circuit and this diagram can be found in the Diagrams Section of this manual.

A complete block diagram is located in the Diagrams Section of this manual. This block diagram shows the overall relationship between all of the circuits. Complete schematics of each circuit are also given in the Diagrams Section. Refer to these diagrams throughout the following circuit description for electrical values, waveforms and relationships of the front panel controls to the individual stages.

Signals to be displayed on the CRT are applied to the CH 1 OR X or CH 2 OR Y connectors. The input signals are then amplified by the Preamplifier circuits. Each Preamplifier circuit includes separate vertical deflection factor, input coupling, balance, gain, and variable attenuation controls. The Channel 2 Preamplifier circuit also contains an INVERT feature to invert the Channel 2 signal as displayed on the CRT.

The output of each Vertical Preamplifier circuit connects to the Vertical Channel Switching circuit. This circuit selects the channel(s) to be displayed. An output signal from this circuit connects to the Z Axis Amplifier circuit to blank out the switching transients between channels when in the chopped mode of operation. The Vertical Channel Switching circuit also provides the Channel 2 VERT SIG OUT signal (available on the instrument rear panel) as well as the signals used for sweep triggering in the NORM, CH 1, and CH 2 positions of the trigger SOURCE switches and the signal used for Xaxis deflection in the X-Y mode of horizontal operation.

The output of the Vertical Channel Switching circuit connects to the Vertical Output Amplifier through the Delay Line. The Delay Line provides a fixed amount of signal delay through the vertical deflection system to allow viewing the leading edge of a triggering waveform. The Vertical Output Amplifier circuit provides the final amplification for the signal before it is connected to the vertical deflection plates of the CRT. This circuit includes the BEAM FINDER switch, which limits the vertical and horizontal deflection to within the viewing area, and sets the display brightness to a normal viewing level to aid in locating an off-screen display.



Fig. 3-1. Basic block diagram of the 475A.

3-3

The A and B Trigger Generator circuits produce an output pulse that initiates generation of the sawtooth sweep signals produced by the A or B Sweep Generator circuits. The input signal to the Trigger Generator circuits can be individually selected from the Channel 1 signal, Channel 2 signal, the signal(s) displayed on the CRT (NORM), a signal connected to the external trigger input connectors, or a sample of the line voltage applied to the instrument. Each trigger circuit contains separate level, slope, coupling, and source controls.

There are three sweep generator circuits in the 475A. For purposes of explanation, they are called Delaying, Slow Non-Delaying, and Fast Non-Delaying. The Delaying Sweep generates a range of sweep rates from 0.5 second to 0.05 microsecond/division. The Slow Non-Delaying Sweep generator provides the 0.5 second through 1 microsecond/division sweep rates and the Fast Non-Delaying Sweep Generator provides the sweep rates of 0.5 through 0.01 microsecond/division.

The Delaying Sweep runs when the instrument is operated in a delayed-sweep mode (MIX, A INTEN or B DLY'D) and is displayed as the A portion of a MIX or A INTEN display. In B DLY'D mode the Delaying Sweep is used to delay the Non-Delaying Sweep, which is displayed on the CRT. The sweep rate for the Delaying-Sweep Generator is selected by the A TIME/DIV switch (skirt knob). One of the Non-Delaying Sweeps (depending on the sweep rate selected) will run and may be displayed in all modes of the HORIZ DISPLAY switch. In the A mode (knobs locked) the Non-Delaying Sweep is displayed as the A Sweep and in the MIX mode, displayed as the B DLY'D Sweep. In the A INTEN mode, the Non-Delaying Sweep is displayed as the intensified portion and in the B DLY'D mode is displayed as the B DLY'D Sweep. The sweep rate for the Non-Delaying Sweep Generator is selected by the B TIME/DIV switch (DLY'D SWEEP knob). It may be helpful to see Table 3-2, found later in this section.

The TRIG MODE switch controls the mode of operation of the sweep generator deriving the A portion of a display. In the AUTO position, the absence of an adequate trigger signal causes the sweep to free run. In the NORM position, a horizontal sweep is presented only when correctly triggered by an adequate trigger signal. Pushing the SINGL SWP pushbutton allows one (and only one) sweep to be presented. The Z Axis Logic circuit produces an unblanking gate signal to unblank the CRT so that the display can be presented. This gate signal is coincident with the sawtooth produced by the sweep generator. The Z Axis Logic Circuit also produces, at the end of each sweep, a gate signal that is supplied to the Vertical Channel Switching circuit. This pulse switches the display between channels at the end of each sweep when the Vertical Deflection System is operating in the ALT mode.

The outputs of the sweep generators are amplified by the Horizontal Amplifier to produce horizontal deflection for the CRT except in the fully counterclockwise (X-Y) position of the TIME/DIV switch. The Horizontal Amplifier contains a 10X magnifier to increase the sweep rate by a factor of 10 in any A or B TIME/DIV switch position. Other horizontal deflection signals can be connected to the Horizontal Amplifier by using the X-Y mode of operation. When the TIME/DIV switch is set to X-Y, the X-axis signal is connected to the Horizontal Amplifier circuit through the Channel 1 Vertical Preamplifier circuit.

The Z Axis Amplifier circuit determines the CRT intensity and blanking. The Z Axis Amplifier circuit sums the current inputs from the INTENSITY control, the Vertical Channel Switching circuit (chopped blanking), the Z Axis Logic circuit (unblanking), and the external Z AXIS INPUT connector. The output level of the Z Axis Amplifier circuit controls the trace intensity through the CRT circuit. The CRT circuit provides the voltages and contains the controls necessary for operation of the cathode-ray tube.

The Power Supply circuit provides the low voltage power necessary for operation of this instrument. This voltage is distributed to all of the circuits in the instrument.

The Calibrator circuit provides a square-wave output with accurate voltage and current amplitudes, which can be used to check the calibration of the instrument and the compensation of probes. The CALIBRATOR current loop provides an accurate current source for calibration of current measuring probe systems.

CHANNEL 1 PREAMP

General

Input signals for vertical deflection on the CRT can be connected to the CH 1 OR X input connector. In the X-Y mode of operation, the input signal connected to the CH 1 OR X connector provides the horizontal (X-axis) deflection (TIME/DIV switch set to X-Y, VERT MODE switch set to CH 2 OR X-Y). The Channel 1 Preamp circuit provides control of input coupling, vertical deflection factor, gain, and DC balance. Fig. 3-2 shows a detailed block diagram of the Channel 1 Preamp circuit. A schematic of this circuit is shown on Diagram 1 at the rear of this manual.

Circuit Description—475A Service



Fig. 3-2. Detailed block diagram of the Channel 1 Vertical Preamplifier circuit.

Input Coupling

Signals applied to the input connector can be AC coupled, DC coupled, or internally disconnected from the input to the Vertical Input Amplifier circuit. When Input Coupling switch S20A is set for DC coupling, the input signal is coupled directly to the Input Attenuator stage. When AC coupled, the input signal passes through capacitor C12. This capacitor prevents the DC component of the signal from passing to the amplifier. In the GND position, S20A opens the signal path and connects the input of the amplifier to ground through R24. This provides a ground reference without the need to disconnect the applied signal from the input connector. Resistor R22, connected across the input coupling switch, allows C12 to be pre-charged in the ground position, which prevents generation of large voltage transients at the input to the amplifier and allows the trace to remain on screen when switched to the AC position.

Input Attenuator

The effective overall deflection factor of each channel of the 475A is determined by the appropriate VOLTS/DIV switch setting. The basic deflection factor of the Vertical Deflection System is 10 millivolts/division of CRT deflection. To achieve the deflection factor values indicated on the front panel, precision attenuators are switched into the circuit and, in the 5 mV position, the gain of the Second Cascode Amplifier stage is increased. For the VOLTS/DIV switch positions above 10 mV, attenuators are switched into the circuit singly or in pairs to help produce the vertical deflection factors indicated. These attenuators are frequency-compensated voltage dividers. In addition to providing constant attenuation at all frequencies within the bandwidth of the instrument, the Input Attenuators are designed to maintain the same input RC characteristics for each setting of the VOLTS/DIV switch. Each attenuator contains an adjustable series capacitor to provide correct attenuation at high frequencies and an adjustable shunt capacitor to provide correct input capacitance.

NOTE

Each attenuator is a hybrid encapsulated plug-in assembly; therefore, replacement of individual components within the attenuator are not possible. Should defects occur, the attenuator must be replaced as a unit.

First Cascode Amplifier

The first amplifier stage in the Channel 1 Preamplifier circuit is hybrid circuit U120. U120 basically consists of an integrated emitter-coupled, push-pull, cascode amplifier and two discrete field-effect transistors (FET) mounted on a ceramic substrate with the thick-film resistors. The stage is a paraphase amplifier and converts the single-ended input signal to push-pull output signals. CR104 and CR107 provide protection for the input to U120 if large negative-going signals or DC levels are applied to the CH 1 OR X input connector.

This input amplifier stage contains the CH 1 VAR VOLTS/DIV control. This control provides continuously variable (uncalibrated) vertical deflection factors between the calibrated positions of the VOLTS/DIV switch. With the VAR control in its calibrated detent (wiper at ground), the output transistors of U120, whose collectors connect to pins 5 and 9, are conducting; the output transistors whose collectors connect to pins 6 and 8 are biased off. Thus, the current available to the following amplifier stage is that flowing from pins 5 and 9.

When the VAR control is rotated out of its calibrated detent, the transistors whose collectors connect to pins 6 and 8 begin to conduct. The current they conduct is robbed from the other output transistors. This causes two things to occur:

1. The current flowing in the collectors of the transistors connected to pins 5 and 9 is less now than when the VAR control was in its calibrated detent.

2. The current available to the following amplifier stage is the algebraic sum of the currents in the collectors tied together (i.e., pins 8 and 9 and pins 5 and 6). Since the two collectors tied together have signals of opposite polarity, the signal available to the following amplifier stage is less than that when the VAR control was in its calibrated detent. The component values selected for the variable function provide a variable attenuation ratio of approximately 2.5 to 1. The Channel 1 Variable Balance adjustment R110 adjusts for no trace shift in the display when rotating the VAR control. The Channel 1 UNCAL light indicates when the Channel 1 VAR control is out of its Calibrated detent. The components connected between pins 2 and 3 of U120 provide high-frequency compensation for the stage.

The gain of U140 is determined by biasing the output transistors connected to pins 6 and 8 to conduct more or less current. As more current is conducted through the transistors connected to pins 6 and 8, that much less is conducted through the transistors connected to pins 5 and 9. The current conducted by the transistors connected to pins 5 and 9 in the 5 mV position of the VOLTS/DIV switch is approximately 2.5 times the current conducted by the same transistors in all of the other VOLTS/DIV switch positions. This results in increased gain and a DC level shift at the signal output terminals of U140. The VOLTS/DIV switch compensates for a shift in the DC level by shorting out part of the common-mode resistance (R157) when operating with 5 mV sensitivity. Gain Switch Balance adjustment R135 adjusts the DC balance of the stage, so there is no baseline shift in the CRT display when switching between the 5 mV and 10 mV positions of the CH 1 VOLTS/DIV switch. The remainder of the components connected between pins 2 and 3 of U140 provide high-frequency compensation for the stage.

Third Cascode Amplifier

The third amplifier stage in the Channel 1 Preamplifier circuit is a discrete component cascode amplifier made up of Q172, Q178, Q182, Q184, and Q188. Q184 is a relatively constant current source for Q172 and Q182. Q172 and Q182 convert the input voltage signals into current signals which are in turn converted back to voltage signals by Q178 and Q188 respectively. R172 and R182 provide thermal compensation and C172 and C182 AC-couple the signal around R172 and R182 to reduce Miller effect. C175 and R175 are variable high-frequency compensation adjustments while CR170, CR174, and RT170 offset compensation changes associated with variations in ambient temperature. As temperature increases, the value of RT170 decreases. This results in a decrease in voltage across CR170 and CR174. CR170 and CR174 are voltagevariable capacitance semiconductors whose capacitance increases with a decrease in reverse voltage across them. Thus, CR170 and CR174 will provide more peaking at higher temperatures. T178 is a toroid inductor that cancels high-frequency common-mode signals generated by the previous stages. The Channel 1 Vertical Position Centering adjustment centers the range of control of the Channel 1 POSITION control.

Second Cascode Amplifier

The second amplifier stage in the Channel 1 Preamplifier circuit is U140. U140 is an integrated emittercoupled, push-pull, cascode amplifier similar to that used in U120. It is used as a push-pull amplifier and has 5 mV and 10 mV gain adjustments that determine the overall gain of the Channel 1 Preamplifier circuit. The output signals available to the next stage for amplification are taken from pins 5 and 9 of U140.

CHANNEL 2 PREAMP



General

The Channel 2 Preamp circuit is virtually the same as the Channel 1 Preamp circuit. Only the differences between the two circuits are described here. Portions of this circuit not described in the following description operate in the same manner as for the Channel 1 Preamp circuit. Fig. 3-3 shows a detailed block diagram of the Channel 2 Preamp circuit. A schematic of this circuit is shown on Diagram 2, at the rear of this manual.



Fig. 3-3. Detailed block diagram of the Channel 2 Vertical Preamplifier circuit.

First Cascode Amplifier

Basically, the First Cascode Amplifier stage in Channel 2 operates as described for the First Cascode Amplifier stage in Channel 1. However, the Channel 2 First Cascode Amplifier also contains the INVERT switching function. This allows the Channel 2 signal to be inverted as displayed on the CRT. The INVERT switch, when pushed, changes the biasing on the output transistors of U220 so that the normally inactive transistors are now carrying the signal. Since their outputs are cross-coupled from side to side the output signal is of opposite polarity to that available in the normal (button out) position of the INVERT switch. The Channel 2 Invert Balance adjustment R215 adjusts the DC balance of the stage to eliminate baseline shift in the display when switching from a normal to an inverted display.

VERTICAL CHANNEL SWITCHING



General

The Vertical Channel Switching circuit determines whether the Channel 1 or the Channel 2 Preamp signal or both will be connected to the Vertical Output Amplifier circuit. In the ALT and CHOP modes of operation, both channels are alternately displayed on a shared-time basis. The Vertical Channel Switching circuit also provides several internal trigger signals to the Trigger Generator circuits, the Channel 2 VERT SIGNAL OUT signal to a connector on the rear panel, and the chopped blanking signal to the Z Axis Amplifier. Fig. 3-4 shows a detailed block diagram of the Vertical Channel Switching circuit. A schematic of this circuit is shown on Diagram 3 at the rear of this manual.



Fig. 3-4. Detailed block diagram of the Vertical Channel Switching circuit.

Channel Switch IC

The Channel Switch IC U370 determines which of the Preamp signals will be passed to the Vertical Output Amplifier. The push-pull Preamp signals connect between pins 2 and 3 (Channel 2) and between pins 10 and 11 (Channel 1) of U370. The logic levels connected to pins 1, 12, 13, and 16 determine what signals are presented at output pins 14 and 15. The following logic truth table (Table 3-1) defines the switching function of U370.

TABLE 3-1	1862-85
Input/Output Logic for U370	

Pin 1	Pin 12	Pin 13	Pin 16	Output Signal Pins 14, 15
1	0	1	0	Channel 2
0	1	0	1	Channel 1
1	1	0	0	Add (Algebraic sum of Channel 1 and 2)

U370 also makes available samples of the Channel 1 signal at pins 8 and 9 and samples of the Channel 2 signal at pins 4 and 5. The output signals at pins 4, 5, 8, and 9 are always present when signals are applied to the channel inputs regardless of the switching logic levels applied to U370. The Channel 1 signal present at pin 9 provides drive to the Horizontal Amplifier in the X-Y mode of horizontal operation. The Channel 1 signal at pin 8 and the Channel 2 signal at pin 4 are used by the Trigger Generator circuits in the appropriate positions of the Trigger SOURCE switches. The Channel 2 signal at pin 5 connects to the Channel 2 Vertical Signal Out Amplifier.

Switching Logic Flip-Flops

U350A and U350B are edge-triggered flip-flops that derive the switching logic for the Channel Switch IC U370. In the CH 1, CH 2, and ADD positions of the VERT MODE switch the output logic from U350A and U350B is determined by the voltage levels applied to the clear (pins 1 and 13) and preset (pins 4 and 10) inputs. In the ALT mode of operation the flip-flops are switched by the alternate-trace sync pulse applied to their clock inputs through Q338 and U330B. In the CHOP mode, the clock pulse generated by U330C and U330D switch the flip-flops at a one-megahertz rate.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

Two Megahertz Clock

U330C and U330D form an astable multivibrator having a repetition rate of two megahertz. The rectangular output waveform connects to the Switching Logic Flip-Flops through nand gate U330B. Only in the CHOP position of the VERT MODE switch is a LO level applied to the input of inverter U330A. This puts a logical HI in pin 13 of U330D, which permits the astable multivibrator to free-run. At the same time, Q338 is biased on, which puts a logical HI on pin 5 of U330B. Thus, the signal present at pin 6 of U330B will be the two-megahertz clock signal.

Chop Blanking Amplifier

The Chop Blanking Amplifier Q348 provides an output pulse to the Z Axis Amplifier circuit, which blanks out the transitions between the Channel 1 and Channel 2 traces when operating in the CHOP mode. The inherent propogation delay of inverters U340A, U340B, and U340C are used to provide some signal delay to the chop blanking signal. This allows the blanking signal and the channel switching transient to arrive in the CRT simultaneously.

Channel 2 Signal Output Amplifier

Q420 and Q430 compose the Channel 2 Vertical Signal Output Amplifier. A sample of the Channel 2 signal from pin 5 of Channel Switch IC U370 is amplified and inverted by Q420. CR422 provides thermal compensation for the base-emitter junction of Q420. Common-base amplifier Q430 provides the final amplification and isolates the output from the internal amplifier circuitry. Output impedance of the amplifier is equal to the parallel combination of R431 and R432 (approximately 50 ohms).

Normal Trigger Pickoff Amplifier

The trigger signal for NORM trigger operation is obtained from a sample of the vertical deflection signal that is available from pin 15 of U370. Normal Trigger DC Center Adjustment R425 sets the DC level of the normal trigger output signal so that the sweep is triggered at the 0 level of the displayed signal when the Triggering LEVEL control is set to 0. Q390 and Q396 are connected as a noninverting feedback amplifier. Gain of the stage is approximately 2.75.

Scale-Factor Switching Circuits

The vertical deflection factor for each channel is indicated by back-lighting the appropriate figures imprinted on the flange of each VOLTS/DIV knob. For purposes of explanation, only the circuit action of the Channel 1 Scale-Factor Switching circuit is discussed.

Circuit Description—475A Service

With a cable or an X1 probe connected to the CH 1 OR X input connector, the probe coding ring terminal on the connector is not contacted, and therefore presents an open to the base of Q312. This causes Q312 to be biased off and the X10 display factor bulb to be off. The base level of Q314 is held low by this action, thus Q314 is biased on and conducts current to light the X1 display factor bulb.

When an X10 probe with a scale-factor switching connector is attached to the CH 1 OR X input connector, the probe coding ring terminal on the connector is contacted; the base of Q312 is connected through R311, R310 and an 11,000-ohm resistor (within the probe) to ground. Now, Q312 conducts through X10 display-factor bulb DS312. The positive level at the collector of Q312 turns Q314 off, the X10 display factor bulb is on, and the X1 display factor bulb is off.

VERTICAL OUTPUT AMPLIFIER

General

The Vertical Output Amplifier provides the final amplification for the vertical deflection signal. This circuit includes the BEAM FINDER function. The BEAM FINDER pushbutton, when pressed, limits the vertical and horizontal deflection to within the viewing area and sets the trace intensity to a normal viewing level to aid in locating an offscreen display. A schematic of the Vertical Output Amplifier is shown on Diagram 4 at the rear of this manual.

First IC Amplifier

The first amplifier stage in the Vertical Output Amplifier is integrated circuit U450. U450 is basically an emittercoupled, push-pull, cascode amplifier cell. Biasing is arranged so that there is no phase-inversion through the stage. The signal from the delay line is applied to the amplifier through C441, L441, L442, C445, and L444. These inductances and capacitances are part of the etched runs of the circuit board and provide some highfrequency peaking by forming a T-coil circuit without mutual coupling. Most of the remaining external components connected between pins 2 and 3 of U450 provide high-frequency compensation for the delay line. Connected between pins 2 and 3 of U450, internally, a resistor (approximately 33 ohms) has a large effect on the gain of the stage.

RT452 changes in value with variations in ambient temperature to compensate for temperature-associated changes in amplifier gain. The BEAM FINDER pushbutton, when pressed, removes –8 volts from the top of R459. This reduces the dynamic swing capabilities of the stage to limit the display on the CRT to within the viewing area. The gain of the Vertical Output Amplifier section is adjusted in this stage by adjusting Vertical Output Gain R449.

For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk



Second IC Amplifier

The second amplifier stage in the Vertical Output Amplifier is integrated circuit U470. U470 is a multi-stage cascode amplifier cell. The input signal is applied to pins 1 and 5 with the inverted output signal taken from pins 9 and 12. Pins 2 and 4 are emitter connections. Some of the components connected between pins 2 and 4 provide slower time constants to compensate for signal rolloff that occurs in the delay line, while the remaining components compensate for thermal considerations in the stage. The Output Bias adjust (R487) sets the DC levels within the stage to optimize the operating performance of U470. The output signal from U470 connects directly to the deflection plates of the CRT.

A TRIGGER GENERATOR



@

General

The A Trigger Generator circuit produces the trigger pulse used to start the Sweep Generator circuit that provides the A portion of the CRT display. The trigger pulse is derived from the internal trigger signal from the vertical deflection system, an external signal connected to the external trigger input connector, or a sample of the line voltage connected to the instrument. Controls are provided to select trigger level, slope, coupling, and source. Fig. 3-5 shows a detailed block diagram of the A Trigger Generator circuit. A schematic of this circuit is shown on Diagram 5 at the rear of this manual.



Fig. 3-5. Detailed block diagram of the A Trigger Generator circuit.

For Service Manuals Control MAURITRON TECHNICAL STRUCT 8 Cherry Tree Rol Chirinos Oxon OX9 40V Tel:- 01944-35104 Fax:- 01844-355 Email:- enguines@mauniton.c

Trigger Source

Trigger SOURCE switch S505 selects the source of the trigger signal. The sources available to the A Trigger Generator circuit are the signal being displayed (NORM), Channel 1 (CH 1), Channel 2 (CH 2), the instrument line voltage (LINE), and external signals (EXT and EXT \div 10). Emitter followers Q502, Q504, and Q506 provide isolation between the input to the A Trigger Circuit and the output of the Vertical Channel Switching Circuit.

In the LINE mode of triggering, a sample of the power line frequency is obtained from the secondary of the power transformer T1400 in the Low Voltage Power Supply circuit. The Trigger COUPLING switches should not be in the LF REJ mode when using the instrument line voltage as a trigger signal source.

Trigger Coupling

The Trigger COUPLING switches offer a means of accepting or rejecting certain components of the trigger signal. In the AC, LF REJ, and HF REJ mode of trigger coupling, the DC component of the trigger signal is blocked by coupling capacitors C515 or C516. Frequency components below about 60 Hz are attenuated when using AC or HF REJ coupling and below about 50 kHz when using LF REJ coupling. The higher frequency components of the trigger signal are passed without attenuation. In the HF REJ mode of trigger coupling, the high frequency components of the trigger signal (above about 50 kHz) are attenuated, while the lower frequency components (between about 60 Hz and 50 kHz) are passed without attenuation. The DC mode of trigger coupling passes unattenuated all signals from DC to 250 MHz and above.

Input Source Follower

Transistor Q522 is a FET (field-effect transistor) connected as a source follower. It provides a high input impedance (set primarily by R517) for the trigger signal; it also provides isolation between the Trigger Generator circuit and the trigger signal sources. CR519 provides input protection for Q522 if excessively high amplitude negative-going input signals are present. Q524 is a highimpedance, relatively constant current source for Q522 and provides a measure of temperature compensation for Q522. The output signal from the Source Follower is taken from Emitter Follower Q526.

Paraphase Amplifier

U520 is a paraphase amplifier stage that converts the single-ended input from Emitter Follower Q526 into a dual-ended push-pull output, which is applied to one of the Tunnel Diode Driver stages. Trigger Centering adjustment R534 sets the level at pin 14 of U520 (through emitter follower Q532) so that the display is correctly triggered

when the LEVEL control is centered. The LEVEL control varies the level at pin 14 of U520 to select the point on a trigger signal where triggering occurs.

The slope of the input signal that triggers the Sweep Generator circuit is determined by the setting of the SLOPE switch S530. When the SLOPE switch is set to the + position, the output signal at pin 8 of U520 is inverted with respect to the input signal, and the output signal at pin 9 is in phase with respect to the input signal. When the SLOPE switch is set to the – position, the output signal at pin 8 is in phase with respect to the input signal, and the output signal at pin 9 is inverted with respect to the input signal.

Tunnel Diode Driver

Q552, Q556, Q562 and Q566 are common-emitter amplifier stages that provide the signal currents necessary to switch the triggering tunnel diodes. CR556 and CR566 are ten-milliampere tunnel diodes. Quiescently, CR556 and CR566 are biased into their low voltage states and Q566 cannot provide sufficient current to switch CR566 to its high voltage state. When the input signal increases the current in Q556 slightly above its quiescent state, this current and the current through R555 is sufficient to bias CR556 into its high voltage state. The anode of CR556 steps positive to an approximately +0.5 volt level. Since less current is required to maintain a tunnel diode in its high voltage state than is required to switch it to its high voltage state, approximately 6 mA of current is additionally available to switch CR566 to its high voltage state. Thus, the next time Q566 conducts signal current, CR566 steps to its high voltage state sending a positive pulse to the logic circuit to initiate sweep action. The A Trig Sensitivity adjustment, R565, adjusts the tunnel diode bias to the proper level that will not allow CR566 to be switched to his high voltage state until CR556 has been switched to its high voltage state. At the end of the sweep time and during holdoff, a negative level is applied to the junction of R558 and R566, thereby resetting both CR556 and CR566 to their low voltage states. The reset level remains during holdoff time to ensure that a sweep gating signal is not generated until the sweep circuit has returned to its quiescent state.

Trigger View Amplifier

The Trigger View Amplifier circuit amplifies a sample of the signal present in the A Trigger Generator circuit and passes it on to the Vertical Output Amplifier for display on the CRT when the TRIG VIEW pushbutton is pressed. This provides a method of making a quick and convenient check of the signal being used to trigger the oscilloscope and is intended primarily to be used to check the timing difference between the trigger signal and the vertical deflection signal.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:- 01844-351694 Fax:- 01844-352554 Email:- enquiries@mauritron.co.uk

The amplifier consists of two emitter-coupled pushpull amplifier stages. The emitter source voltage for Q662 and Q672 is switched on and off by the TRIG VIEW pushbutton. With the TRIG VIEW bushbutton not pushed, the emitters of Q662 and Q672 are returned to ground through R665. This reverse-biases the base-emitter junctions of the transistors, preventing any loading of the A Trigger Generator circuit. When the TRIG VIEW pushbutton is pushed, the emitters are now returned to +15 volts through R663 and R679. This forward biases Q662 and Q672 to allow signal amplification. Trigger View Centering adjustment R673 adjusts for correct DC balance in the circuit.

Normally, the output of the Vertical Channel Switching circuit is applied to the input of the Delay Line. When the TRIG VIEW pushbutton is pushed, the signal from the Vertical Channel Switching circuit is removed and the output from the Trigger View Amplifier is applied in its place.

B TRIGGER GENERATOR



General

The B Trigger Generator circuit produces the trigger pulse used to start the Sweep Generator circuit that provides the B portion of the CRT display. The B Trigger Generator circuit is virtually the same as the A Trigger Generator circuit and only the differences between the two are discribed here. A schematic of this circuit is shown on Diagram 6 at the rear of this manual.

Trigger Source

The B Trigger Generator circuit has no LINE or EXT ÷10 positions on its Trigger SOURCE switch. If the Generator is to be triggered from a line voltage signal or the external trigger signal is to be attenuated, it must be accomplished in some other manner. The B Trigger SOURCE switch does have a STARTS AFTER DELAY position, however, the A Trigger SOURCE switch does not. This position allows the B portion of a display to start immediately after the selected delay time without waiting for a triggering signal.

SWEEP AND Z-AXIS LOGIC

General

The Sweep and Z Axis Logic Circuit derives the logic levels necessary to control the sequence of events associated with sweep generation and CRT unblanking. The +A and +B GATE signals are also generated in this circuit. Positive logic terminologies and symbologies are used in the following explanation of circuit operation. Fig. 3-6 shows a detailed block diagram of the Sweep and Z-Axis Logic circuits. A schematic of this circuit is shown on Diagram 7 at the rear of this manual.

> For Service Manuals Contact MAURITRON TECHNICAL SERVICES 8 Cherry Tree Rd, Chinnor Oxon OX9 4QY Tel:-01844-351694 Fax:-01844-352554 Email:-enquiries@mauritron.cu.uk



Fig. 3-6. Detailed block diagram of the Sweep and Z-Axis Logic circuits.

Sweep Control Integrated Circuit

U600 is the Sweep Control Integrated Circuit. Several functions are performed in this stage, depending on the mode of operation of the instrument sweep generators. The following is a brief explanation of the function associated with each pin of the IC.

Pin 1. This is the positive tunnel diode input. The signal connected here comes from the A Firing TD in the A Trigger Generator circuit. The voltage level switches from 0 to +0.5 volts and is compared with pin 2 internally.

Pin 2. This is the negative tunnel diode input. A fixed DC level established by R602 and R603 provides the reference for comparison with pin 1.

Pin 3. This is the positive tunnel diode output terminal. In the AUTO mode of operation (TRIG MODE set to AUTO) at the end of the holdoff time period, pin 1, pin 16 and pin 19 are LO, and pin 8 is HI. This causes the gate level at pin 3 to step LO to turn Q574 on, which initiates a sweep. **Pin 4.** This is the negative tunnel diode output terminal; connected to +5 volts in this application.

Pin 5. Input terminal for a negative 5 volts through VR608 from the -8-volt supply.

Pin 6. This is the auto RC timing terminal. R609 and C609 determine the amount of time between loss of trigger signal and the generation of an auto gate at pin 3 when TRIG MODE is set to AUTO.

Pin 7. This terminal lights the TRIG light when a triggering gate has occurred, causing pin 1 to go HI.

Pin 8. This is the holdoff timing terminal. The time between the end of an individual sweep and the start of the next sweep is determined by RC components that affect the time constant of voltage of pin 8. The TIME/DIV control selects fixed components in the holdoff timing circuit and the A TRIG HOLDOFF control allows a variable holdoff setting in each position of the TIME/DIV control. When pin 8 goes HI, pin 17 will go LO and allow the trigger tunnel diodes to fire on an incoming signal or generate an auto gate in the Auto mode if pin 6 is HI.

	Mfr Part Number	016-0556-01 10353-8-1032-25A	ORD BY DESCR	134-0057-00 ORD BY DESCR	C-1353 ORD BY DFSCR	ORD BY DESCR	25151.13.3	ORD BY DESCR	386-2669-00	ORD BY DESCR ORD BY DESCR	407-1350-00	ORD BY DESCA ORD BY DESCR	ORD BY DESCR ORD BY DESCR	437-0154-03 351-0101-00	351-0101-02 016-0099-00
	Mfr Code	80009 06540	83385	80009 56878	06666 83385	83385	63743	83385 83385	80008	83385 83385	60008	83385 83385	83385 83385	60008	80008
	y 12345 Name & Description	ADPTR,RACK MTG: .HANDLE,BOW:1.5 X 4.5 INCH	SCREW.MACHING PARTS)	BUTTON, PLUG: GRAY PLASTIC .BUTTON, PLUG: GRAY PLASTIC .SETSCREW: 0.250-28 X 0.750 INCH, SOC S	.SLIDE SECT,DWR:12.625 X 2.25 (ATTACHING PARTS) .SCREW,MACHINE:8-32 X 0.375 PNH.STL CD PL	.NUT.PL.ASSEM WA:8-32 X 0.344 INCH.STL	EYELET METALLIC:CENTERING	UUT.PLASSEM WAS-32 X 0.312.NLC.PL NUT.PLASSEM WAS-32 X 0.312.SLC PL 	SUPPORT, CABINET: REAR	SCREW.MACHINE:8-32 X 0.375,PNH,STL CD PL .NUTLASSEM WA:8-32 X 0.344 INCH.STL .NUTTPLESEM MA:8-32 X 0.344 INCH.STL	BRACKET ANGLE VIBRATION DAMPER, ALUMINUM	SCREW.MACHINE:8-32 X 0.375, PNH.STL CD PL .NUTLASEBM WA:8-32 X 0.344 INCH.STL 	SCREW, MACHINE 6-32 X 1 INCH, PNH, STL SCREW, MACHINE 6-32 X 1 INCH, PNH, STL SCREW, MACHINE 8-32 X 0.750 INCH, PNH STL	.CABINET,SCOPE: SLIDE,DWR,EXT:18.0 X 1.69	.SLIDE_DWR.EXT.WICLOSED MOUNTING SLOTS HDW KIT.ELEK EQ.RACKMOUNT HDW
	el No. Dscont Qty	т N	4	4 0	5 7	5	~ •		-	40	 .	(1) (1)	6 4	1 B018538 1	
	Serial/Model No. Eff Dsco														
	Tektronix Part No.	016-0556-01 367-0022-00	213-0090-00	134-0067-00 213-0334-00	351-0104-00 212-0023-00	210-0458-00	210-0808-00	210-0457-00	386-2669-00	212-0023-00 210-0458-00	407-1350-00	212-0023-00 210-0458-00	211-0517-00 212-0033-00		351-0101-02 6 016-0099-00
	No.	44	Ģ	ማላነ	ν, φ	r, 1	φ a	9	Ę :	17 17	<u>4</u>	<u>5</u>	-17 -18	-19 -20	-21 REV MAR 1984
) 0				Mfr Part Number	437-0141-02	348-0080-01 352-0263-00	2200-1412-00 267-0195-07	200-0602-00 367-0195-00	ORD BY DESCR	OBD 214-0516-00	214-1987-00 214-0515-02	OHD BY DESCR 210-1182-00	ORD BY DESCR	REV
		\langle			Mfr Code	60008	60008 60008	60008 80008	80008 80008	83385	22670 80009	80008	000CY 80009	12327	
	0)				Gty 1 2 3 4 5 Name & Description		 FOUT CABINELISO FLOM HLDR POUCH ASSYTER BLUE POLYCARBONATE HLDR POLICH ASSYTER BLUE BOLYCARBONATE 	1 COVER, SCOPE, FRONT 1 HANDLE, CARRYING: 12, 722 L, BLACK VINYL	1 .COVER.HDL LATCH:2.12 DIA X 0.7,ACETAL HANDLE,CARPYING:	A	1 PLATE.IDENT:MARKED 475A 2 SPRING.HLCPS:0959 DIA X 1.250 INCH LONG 140052 VID DIA 200359 DIA X 1.250 INCH LONG		2 SCR,CAP,HEX H0:10-24 X 0.375 INCH LONG 2 WSHR,SPR TNSN:0.218 ID X 0.69 INCH OD	2 WASHER, FLAT: 0.204 ID X 0.438 INCH OD.ST 	SERVICE
Vices assesse					odel No. Dscont		B022414				B023829 B023829	B023829	B022499		OSCOPE
Nicku SER Rd, Chin 9 40Y @mauritonu					Serial/Model No. Eff Dscor		B010100 B022415				B010100 B010100	B010100	B010100	B022500	V OSCILL
For Service Manuals Contact MURITRON TECHNICAL SERVICES B Cherry Trae Rd, Chinnor B Cherry Trae Rd, Chinnor B Cherry Trae Rd, Chinnor Hensi: enquines@mauriton.co.uk					Tektronix Part No.	437-0141-02 348-0060-01	352-0263-00 352-0263-00	200-1412-00 367-0195-07	200-0602-00 367-0195-00	213-0227-00	334-1999-01 214-0516-00 214-1987-00	214-0515-02	213-0139-00 210-1182-00	210-080 5-00	475A/R475A OSCILLOSCOPE SERVICE
です。 で し の で に し し し し し し し し し し し し し				Fig. &	No.	4 d	9	d n	òκġ	7-	αγ σ, F	÷	12		7

