TYPE 5BDP- CATHODE-RAY TUBES

The Du Mont Type 5BDP- is a five inch, flatfaced, electrostatically focused and deflected Cathode-ray Tube with two independently controlled beams and incorporating an intensifier sub-divided into several steps. This feature permits operation at high voltages and ratios of intensifier to second anode voltage resulting in a high writing rate. The deflector leads are brought out directly through the bulb wall in order to minimize lead inductance and capacitance. To prevent film-fogging, and for maximum brightness and stability in performance, all screens are provided with a highly reflective metal backing.

Metallized screen types other than those listed

below are available on special order.



GENERAL CHARACTERISTICS (Note 1)

Electrical Data

Heater Voltage			6.	3 Volts
Heater Current		0.6	\pm 10% A	Amperes
Focusing Method Electrostatic				
Deflecting Method		*******	Elec	trostatic
Phosphor	No. 1	No. 2	No. 7	No. 11
Fluorescence	Green	Green	\mathbf{Blue}	Blue
Phosphorescence		Green	Yellow	
Persistence	Medium	Long	Long	Short
Direct Interelectrode Capacitances		Min.	Max.	
Cathode to all			4.4	$\mu\mu f$
Grid No. 1 to all		3.1	4.1	$\mu\mu f$
D1 to D2		1.8	2.7	$\mu\mu f$
D3 to D4		1.3	2.1	$\mu\mu \mathbf{f}$
D1 to all		5.3	6.8	$\mu\mu f$
D2 to all		5.3	6.8	$\mu\mu f$
D3 to all		4.5	5.8	μμf
D4 to all		4.5	5.8	$\mu\mu\mathbf{f}$

Mechanical Data

Overall Length Greatest Diameter of Bulb Minimum Useful Screen Diameter Bulb Contacts — Recessed Small Ball Cap Neck Contacts — Skirted Miniature Base — Medium Shell Diheptal, 12 pin Basing	5½ ± 3/32 Inches
Base Alignment Base Key aligns with the D1D2 trace	
Positive voltage on D2 deflects the beam approximately towards B Positive voltage on D3 deflects the beam approximately towards Ba	ase Key
Bulb Contact Alignment Bulb Contacts Align with D3D4 trace	+ 10 Degrees
Bulb Contacts on same side as Bose Pin No. 4 Trace Alignment	To Degrees
D1D2 trace aligns with D3D4 trace Corresponding traces of each gun align within	90 ± 2 Degrees ± 2 Degrees

MAXIMUM RATINGS (Design Center Values)

Post-Accelerator Voltage	25,500	Max.	Volts D-C
Accelerator Voltage (Note 2)	3,500	Max.	Volts D-C
Ratio Post-Accelerator Voltage to Accelerator Voltage			10 Max.
Focusing Voltage	1,550	Max,	Volts D-C

Grid No. 1 Voltage				
Negative Bias Value	200	Max.	Volts	D-C
Positive Bias Value	0	Max.	Volts	D-C
Positive Peak Value	0	Max.	Volts	D-C
Peak Heater to Cathode Voltage				
Heater Negative with respect to Cathode	. 180	Max.	Volts	D-C
Heater Positive with respect to Cathode	. 180	Max.	Volts	D-C
Peak Voltage between Accelerator and any Deflection Electrode		1,200	Max. `	Volts

TYPICAL OPERATING CONDITIONS


For Post-Accelerator Voltage of (Note 3) For Accelerator Voltage of (Note 3)	
Focusing Voltage	400 to 630 Volts
Grid No. 1 Voltage (Note 4)	
Modulation (Note 5)	45 Max. Volts
Line Width "A" (Note 5)	
Line Width "B" (Note 5)	
Interaction Factor: (Note 6)	14 x 10-6 In./Volt D-C Max.
Deflection Factors:	
D1 and D2	
D3 and D4	
Spot Position (Undeflected) (Note 7)	Within a 16 mm Square
Useful Scan (Note 8)	
Pattern Distortion (Note 9 & 10)	

CIRCUIT DESIGN VALUES

Focusing Voltage
Focusing Current for any operating conditions
Grid No. 1 Voltage (Note 4) —22.5 to —37.5 Volts per Kilovolt of Accelerator Voltage
Grid No. 1 Circuit Resistance 1.5 Max. Megohms
Resistance in any Deflecting-Electrode Circuit (Note 11)


NOTES

- 1. Values are for each unit unless otherwise stated. 2. Accelerator power input (Avg.) should be limited to six watts. At 100 μ A D-C beam current, the cathode current shall not exceed 2 mA D-C. To protect tube against damage this measurement should be taken by pulsing the grid from cutoff to the specified beam current at a 10% cycle and multiplying the current meter readings by 10.
- 3. Equally divided over the three intensifier electrodes. Suggested method of connection:



- 4. Visual extinction of undeflected focused spot. 5. For an Ib3 of 50 μA D-C. 6. The deflection of one beam when balanced D-C voltages are applied to the deflection electrodes of the other beam will not be greater than the specified value.
- 7. With the tube shielded against external influences, Eb3 = 14,000 volts, Eb2 = 2,000volts, and Eb1 adjusted for focus centered with respect to the tube face.


- 8. Minimum useful scan diameter is limited at high ratios of Eb3/Eb2 to 4 inches at 5:1, 3.5 inches at 7:1 and 2.5 inches at 10:1.
- 9. The total vertical movement of the upper edge of a 3 inch vertical trace, (centered with respect to the tube face), deflected horizontally 1.5 inches to the left and right of the center of the tube face, shall not exceed 0.12 inch. The total vertical movement of the lower edge of the 3 inch trace also shall not exceed 0.12 inch. The D3D4 trace shall be considered vertical.
- 10. The sum of the total horizontal movement of the left and right edges of a 3 inch horizontal trace, (centered with respect to the tube face), deflected vertically 1.5 inches above and below the center of the tube face, shall not exceed 0.12 inch. The D1D2 trace shall be considered horizontal.
- 11. It is recommended that the deflecting electrode circuit resistances be approximately equal. Higher resistance values up to 5.0 megohms may be used for low beam current operation.



BOTTOM VIEW

UNIT A			UNIT B		
PIN	NO. ELEMENT	PIN NO	ELEMENT		
1	HEATER	7	HEATER		
2	CATHODE	8	HEATER		
3	GRID NO. I	9	CATHODE		
4	NO CONNECTION	10	GRID NO. I		
5	FOCUSING ELECTRODE	11	NO CONNECTION		
14	HEATER	12	FOCUSING ELECTRODE		

TYPE 5BDP-



TYPE 5BDP-AVERAGE CHARACTERISTICS

