ADJUSTMENT DJ-C1T/C1E

1) Settings

Power supply voltage 4.0V DC

^{item} 1. Reference voltage	Procedure Tune in 144.95 MHz and set P/D voltage to 1.7 V. (VCO case attached) Adjust L214	Set to 1.7 ± 0.1 V
2. Reference frequency	Transmit on 145.05 MHz and set reference frequency to 145.05 MHz. Adjust TC202	145.05 MHz ± 0.5 Hz
3. Transmission power	Transmit on 145.05 MHz and set $300 \text{ mW} \pm 20 \text{ r}$ transmission power to 300 mW.Adjust VR201	
4. MIC modulation deviation	Transmit on 145.05 MHz and input a 1 kHz - 50 mV low-frequency signal to the MIC input pin. Then, set modulation to 4.5 kHz. Adjust VR202	4.5 ± 0.1 kHz
2) Checks		
2) Checks Item 1. Transmission frequency	Requirement 145.05 MHz ± 200 Hz	Factory-clearance ±500Hz
Item 1. Transmission	•	-
Item 1. Transmission frequency 2. Transmission	145.05 MHz ± 200 Hz On 145.05 MHz transmission frequency 300 mW ± 30 mW On 145.05 MHz transmission frequency • With 1 kHz - 50 mV AF signal 4.5 kHz ± 0.2 kHz	±500Hz
Item 1. Transmission frequency 2. Transmission power 3. Modulation	145.05 MHz ± 200 Hz On 145.05 MHz transmission frequency 300 mW ± 30 mW On 145.05 MHz transmission frequency • With 1 kHz - 50 mV AF signal	±500Hz Same as on left

ltem 4. Spurious emission	Requirement	Factory-clearance
4. Spurious emission	On 145.05 MHz transmission frequency Max55 dB	Same as on left
5. Transmission S/N	On 145.05 MHz transmission frequency	
	Min. 33 dB (Measuring instrument's audio filter OFF	Same as on left
	at 0.3 ~ 3 kHz)	
6. Reception sensitivity	On 144.95 MHz reception frequency	
	FM Max9 dBμ (EMF) (12 dB SINAD)	Same as on left
	 On 129.95 MHz reception frequency AM Max. 5 dBµ (EMF) (10 dB S/N) 	Same as on left
		Same as officia
7. Audio (32 Ω)	Volume-control VR7	
	Distortion Max. 4%	Same as on left
	Volume-control VR8 Output Min. 20 mW	Same as on left
		Game as on left
8. Reception S/N	On 144.95 MHz reception frequency	
	Min. 40 dB	Same as on left
9. Unwanted radiation	On 145.995 MHz reception frequency	
	-55 dB and below	Same as on left
10. Squelch	a) Squelch fully opens at 0 level.	Same as on left
	 b) Squelch opens when receiving -8 dBµ reference signal at squelch level 2. 	Same as on left

.

DJ-C4T/C4E/C4C

1) Settings

) Settings					
Power supply voltage 4.0V DC	C For	T-version E-version C-version		F2 = 444.95MHz F2 = 434.95MHz F2 = 433.80 MHz	
Item	Procedur	e	Set to		
1. Reference frequency	Transmit frequency Adjust TC		F1 ± 100 Hz		
2. Transmission power		on F1 and se ion power to 3201	300 mW* ± 20 mW		
3. MIC modulation	Transmit	on F1 and in	4.5 kHz ± 0.1 kHz		
deviation	1 kHz - 50 mV AF signal to the MIC input pin. Then, set modulation to 4.5 kHz. Adjust VR202				
2) Checks					
ltem	Requiren	nent		Factory-clearance	
1. Transmission frequency	F1 ± 500Hz			±1 kHz	
2. Transmission power		nsmission fr ± 30 mW	Same as on left		
3. Modulation Deviation	• With 1 k 4.5 kHz • With 67,	Hz - 50 mV ± 0.2 kHz /250.4 Hz CT	•		
		50 Hz tone b ersions only)		Same as on left Same as on left	
4. Spurious emission	On F1 tra Max55	nsmission fr dB	Same as on left		
5. Transmission S/N	Min. 33 d	ng instrumen	Same as on left		
* 10mW +- 2mW for DJ-C4C					

*10mW +- 2mW for DJ-C4C

ltem	Procedure	Set to		
6. Reception sensitivity				
	FM Max8 dBµ (EMF)	Same as on left		
7. Audio (32Ω)	Volume-control VR7			
	Distortion Max. 4%	Same as on left		
	Volume-control VR8			
	Output Min. 20 mW	Same as on left		
8. Reception S/N	On F2 reception frequency			
	Min. 40 dB	Same as on left		
9. Unwanted radiation	On F2 reception frequency			
	-55 dB and below	Same as on left		
10. Squeich	a) Squeich fully opens at 0 level.	Same as on left		
	 b) Squelch opens when receiving -8 dB reference signal at squelch level 2. 	Same as on left		