TECH FILE

Preliminary Technical Service Manual

MODEL 140 Type II Noise Reduction

dbx Professional Products May 1, 1991

Manufactured under one or more of the following U.S. patents: 3,377,792; 3,681,618; 3,714,462; 3,789,143; 4,097,767; 4,329,598; 4,403,199; 4,409,500; 4,425,551; 4,473,795. Other patents pending.

This dbx-branded product has been manufactured by AKG Acoustics, Inc.

© 1991 AKG Acoustics, Inc.

dbx Professional Products

a division of AKG Acoustics, Inc. 1525 Alvarado Street San Leandro, CA 94577 USA Telephone: (1) 415/351-3500 Fax: (1) 415/351-0500 Telex: 17-1480

User/Operator Description

INTRODUCTION

The dbx Model 140 simultaneous encode/decode broadcast noise reduction system is a two-channel compressor/expander providing a minimum of 30 dB broadband audio noise reduction with a 10 dB increase in a system headroom. The two channels feature independent encode and decode circuitry.

In the record mode, the system compresses the input signal by a 2:1 ratio, linear in decibels over a 100 decibel range. Upon playback, the circuitry produces an exact mirror image 1:2 expansion of the encoded signal.

True RMS level sensing insures perfect encode/decode tracking for accurate transient response irrespective of phase shifts in the transmission or storage medium. There is no audible breathing, pumping or other coloration of the sound with this encode/decode system, and there are no pilot tones or routine calibration procedures necessary for its use.

The dbx system eliminates tape hiss in recording and prevents the noise build-up normally encountered in transferring information from one recorded medium to another; it does not remove noise present in the original signal. The dbx 140 noise reduction system is built to professional standards using the latest advances in circuit design and technology and is fully warranted (parts and labor) for two years.

APPLICATION

Participation and

For recording live announce or studio productions on cartridges, the dbx Model 140 noise reduction system completely eliminates the tape hiss which usually accompanies the recording process. This allows spots or other program content originating on cartridges (historically the noisiest link in the broadcast chain) to approach the sound quality of live broadcasting.

When used for transfer of program material to cartridge from other recorded sources, the dbx encoding prevents any additional noise build up beyond that contained in the original material.

The result of dbx encoding is to minimize the audible quality differences between cart playback and live announce or between one cart and another. dbx encoding also minimizes the effect of "automated sound" and allows a fully automated station to approach live sound quality.

Non-cartridge-related broadcast uses for the dbx 140 system include improving the signal-to-noise ratio of reel-to-reel studio recorders, eliminating hiss from TV audio tracks and cleaning up noisy full-frequency land lines or microwave links from the studio to the transmitter. A modest investment in dbx 140 noise reduction units can protect a much larger investment by prolonging the useful life of major studio equipment and installations that might not otherwise meet contemporary performance standards.

The dbx 140 may also be used as a playback-only device to decode dbx encoded discs or tapes for broadcast.

1000

FRONT PANEL LAYOUT

When depressed, noise reduction circuitry is hardwire bypassed, allowing audio signal to pass directly through the 140 without processing, even if AC power is off.

When depressed, audio signals going to the tape machine or transmission line are dbx encoded. Audio signals coming from the tape machine or transmission line are decoded. When depressed, audio signals coming from console outputs are decoded according to dbx disc curve. Encoded signal is fed directly to the tape machine or transmission line outputs.

0 0	dbx 140	TYPE I NORE REDUCTION BYSTEM	°	0	AND	0

Trim adjustments to match 140 operation to the levels with which it will operate. These trims are for operating convenience and will not effect the encode/decode linearity in any way.

HOW TO USE THE FUNCTION SELECT BUTTONS ON YOUR 140 (PUSH ONLY ONE BUTTON AT A TIME)

W	IAT YOU PUS	SH .	
TAPE	BYPASS	dbx DISC	WHAT YOU GET
			dbx ENCODED PROGRAM Program coming FROM CONSOLE OUTPUTS will be encoded and sent TO RECORDER INPUTS.
			dbx DECODED PROGRAM Program coming FROM RECORDER OUTPUTS will be decoded. and sent TO CONSOLE OUTPUTS.
			NO SIGNAL PROCESSING FROM RECORDER Program coming FROM CONSOLE OUTPUTS will be sent directly TO RECORDER INPUTS, and program coming FROM RECORDER OUTPUTS will be sent directly TO CONSOLE INPUTS with no encoding or decoding
-			dbx DISC/SOURCE DECODING Program coming FROM CONSOLE OUTPUTS will be internally connected to the terminals labelled FROM RECORDER OUTPUTS, then decoded and fed TO CONSOLE INPUTS. The encoded dbx disc program fed FROM CONSOLE OUTPUTS will also be fed TO RECORDER INPUTS, in encoded form.

REAR PANEL LAYOUT

Connect audio output (line level) from mixing console to these terminals.

Connect audio input (line level) of the mixing console to these terminals. Connect audio output (line level) from tape machine or transmission line to these terminals.

Connect audio input (line level) of the tape machine or transmission line to these terminals.



AC Line Cord connects the 140 to 117 VAC, 50 or 60 HZ AC power source only. Models for use with other sources are available outside the continental United States. Contact factory for information.

NOTE: The 140 is not equipped with a power ON/OFF switch but is designed instead to be connected to the master switched AC outlet of your audio system. Since the 140 draws very little AC power, it can be plugged into an unswitched AC outlet and left ON all the time.

TYPICAL SIGNAL CONNECTIONS - INPUT AND OUTPUT

Input Connections (FROM CONSOLE OUTPUTS, FROM RECORDER OUTPUTS)

For balanced or floating lines, connect the signal leads to the (+) and (-) terminals, and the shield to the chassis ground $(\frac{1}{2})$ terminal. For unbalanced lines, connect the signal high lead to the (+) terminal and jumper the (-) and chassis ground $(\frac{1}{2})$ together for connection of the shield. When using an unbalanced connection, reversing the (+) and (-) input terminals will cause the output signal to be 180° out of phase (reverse polarity) relative to the input signal. The Model 140 input impedance is 75,000 ohms when connected in the balanced configuration but is 54,000 ohms when connected in the unbalanced configuration.

Output Connections (TO CONSOLE INPUTS, TO RECORDER INPUTS)

The output of the dbx 140 is designed to feed balanced or unbalanced 600 ohm or greater loads. The output stage is single ended so that in normal operation the (-) signal output terminal is internally connected to the (\pm) terminal. When the system bypass is engaged, the signal inputs are directly connected to the signal outputs. For maximum hum rejection, avoid common grounding at the input and output (avoid "double-grounding"). One grounding method that usually works is to ground the shield at the 140's output (\pm) terminal and also ground it at the input of the following device. Do not connect the shield at the 140's input (\pm) terminal. Leave the input shield connected only to the output of device feeding the 140.

SETTING THE LEVEL ADJUST CONTROLS

The dbx Model 140 is factory calibrated for nominal input and output levels of 1 Volt. The three screwdriver adjustable LEVEL ADJUST controls on the front panel are provided to maintain similar input and output levels in encode and decode modes and to optimize level matching between the dbx 140 and the rest of your system for the best headroom and lowest noise. Each control adjusts two channels simultaneously so proper stereo balance is maintained.

Before making adjustments, make sure your tape machine or transmission line is adjusted or aligned according to the manufacturer's specifications. Connect the 140 to your system using inputs and outputs as shown.

RECORD Level Adjustment

- 1. Depress BYPASS button on 140.
- 2. Run a 1 KHz tone through your console so that the meters indicating the console output levels to the 140 read at nominal operating levels (0 VU).
- 3. Adjust tape recorder input gain so that the tape recorder meters read 0 VU.
- 4. Depress TAPE button. Adjust 140 RECORD LEVEL ADJUST, if necessary, so that tape recorder meters again read 0 VU.

PLAY Level Adjustment

- 1. Depress BYPASS button on 140.
- 2. Using the 1 KHz tone on the appropriate alignment tape, adjust your tape recorder output gain so that the meters indicating the recorder output levels to the 140 read at nominal operating levels (0 VU).
- 3. Adjust console input gain so that the meters indicating the output levels from the 140 read 0 VU.
- 4. Depress TAPE button. Adjust the 140 PLAY LEVEL ADJUST, if necessary, so that console meters indicating the output levels from the 140 again read 0 VU.

DISC Level Adjustment

 If 140 is connected to a tape recorder, put recorder in SOURCE mode. (Make sure that tape recorder acts as a unity gain device when in SOURCE mode.) If you are not using the tape recorder, connect the appropriate terminals of the 140's FROM RECORDER OUTPUTS and TO RECORDER OUTPUTS together.

2. Depress BYPASS button.

- 3. Using the 1 KHz tone from the appropriate test record, set the console "send" gain so that the console meters indicating the console output levels to the 140 read nominal operating level (0 VU).
- 4. Adjust console "receive" gain so that the console meters indicating output levels from the 140 read 0 VU.
- 5. Depress the DISC button. Adjust the DISC LEVEL ADJUST so that the console meters indicating the output levels from the 140 again read 0 VU.

When the 140 is adjusted in the above manner, it will act as a unity gain device for a 1 KHz tone at nominal operating levels, whether it is bypassed or is encoding or decoding.

CONVERTING THE 140 TO TRANSFORMER BALANCED OUTPUTS

The dbx Model 140 has unbalanced outputs with +24 dBm drive capability. If you wish to have transformer balanced outputs, the 140's circuit board has been designed to accept transformer number JE-123-SLPC (or alternatively JE-123-SPC) manufactured by and available from Jensen Transformers of North Hollywood, California. Four transformers are necessary.

The procedure for installing these transformers is as follows:

1. Remove the screws securing the sides to the front and back extrusions (four screws per side).

ويكلونا

- 2. Slide the top and bottom plates out of the extrusions.
- 3. Locate the transformer positions marked T2 through T5 on the circuit board.
- 4. There are two jumpers associated with each transformer position. Cut out and discard these jumpers labelled Y1 through Y8.
- 5. Insert the eight-pin transformers into locations T2 through T5 on the circuit board. The transformers are electrically symmetrical so they will function properly in either of the two possible orientations. Solder into place.
- 6. Slide top and bottom covers back into the extrusion.
- 7. Replace the screws holding the sides to the extrusions (four screws per side).

SPECIFICATIONS

Input Impedance .

Output Impedance Input Level Output Level Distortion

Equivalent Input Noise Frequency Response

Slew Rate

Effective Noise Reduction

Dynamic Range (peak signal to A weighted background noise)

Optional Output Transformer

Dimensions

Power Line

Power Consumption

Warranty

75 kohm balanced 54 kohm single ended

Low, designed to drive 600 ohm or greater

+24 dBm maximum

+24 dBm maximum into 600 ohm

<.5% THD 30 Hz to 100 Hz <.1% THD 100 Hz to 20 kHz (measured with encode output connected directly to decode input)

Unweighted, 20 kHz bandwidth, -- 85 dBm

+.5 dB 40 Hz to 20 kHz,--1 dB @ 30 Hz (encode/decode, typical program material tracking)

710 V/1 sec.

30 dB plus 10 dB of headroom

110 dB

Jensen #JE 123-S-PC or JE 123-S-LPC

1 3/4"H x 19"W x 12 1/2"D (4.4 cm x 48.3 cm x 31.8 cm)

117 VAC, 50-60 Hz

15 W

dbx products are covered under a limited warranty (parts and labor) for two years from date of original purchase.

Test Procedures

CHANNEL BALANCING FOR THE dbx 140 AND 180 NOISE-REDUCTION UNITS

Temporarily disconnect your unit from its ac power supply, in order to remove the top cover safely. To do this, first remove all the screws holding the rack ears on (both rack ears must be off). Then firmly slide off the top cover, moving it toward the back. On many units the fit of this cover is quite snug, so gentle tapping with a rubber hammer may be necessary. When the cover is off, plug the unit back into its ac jack and let it warm up for 5-10 minutes.

This procedure requires a 1-kHz tone at 0 dBV (1 V rms).

ENCODER In and Out (Note: "From Console Outputs" is the Input, "To Recorder Inputs" is the Output)

1) Put 1 kHz at 1 V rms into both channels. Level-match Channel 2, using your unit's front-panel Record trim pot (R121). That is, turn the pot until the unit puts out 1 kHz at the same level as the input: 1 V rms. Channel 2 is now at unity gain.

2) Then take the cover off the unit, being sure to stay away from the power supply and transformer. Locate trim pot R68 and turn it to match Channel 1 to Channel 2.

DECODER In and Out (Note: "From Recorder Outputs" is the Input, "To Console Inputs" is the Output)

1) Again put 1 kHz at 1 V rms into both channels. Level-match Channel 2, using the unit's front-panel Play trim pot (R173). That is, turn the pot until the unit puts out 1 kHz at the same level as the input: 1 V rms. Channel 2 is now at unity gain.

2) Then locate trim pot R169 inside the unit and turn it to match Channel 1 to Channel 2.

Model 140/180

. •

TEST PROCEDURE ADDENDUM

The following should replace the Prequency Response Test (section 8) for the 140 and 180 as outlined beolw:

Model 140

8a) Encoder section Level-match lkHz at EXACTLY 1.000Vrms. The response should be within the ranges listed below: (using DVM)

Freq. (Hz)	Output (Vrms)
32	1.297 to 1.455
50	1.098 to 1.232
100	0.999 to 1.121
400	0.979 to 1.099
2k	0.835 to 0.937
10k	0.656 to 0.736
20k	1.366 to 1.533

b) Decoder Section. Again, Level-match 1kHz to EXACTLY 1Vrms and check that the response is within the ranges below:

Freq. (H	z) Output (Vrms)	
32	0.444 to 0.498	
50	0.705 to 0.792	
100	0.869 to 0.975	
400	0.888 to 0.997	
2k	1.206 to 1.354	·
10k	2.00 to 2.24	
20k	0.473 to 0.530	
	Model 180	
8a) As above, Level-match		(ENCODE section)
		(Incode Section)
Freq. (Hz)		
32	0.892 to 1.001	
50	0.778 to 0.873	
100	0.699 to 0.784	
400	0.767 to 0.861	
2k	0.975 to 1.094	
lOk	0.571 to 0.640	
20k	0.491 to 0.551	
b) DECODE section	ı.	
Freq. (Hz)	Output (Vrms)	
32	1.142 to 1.261	
50	1.471 to 1.650	-
100	1.764 to 1.979	
400	1.473 to 1.613	
2 k	0.884 to 0.992	• • •
- 10k	2.65 to 2.98	-
_ 20k	3.65 to 4.13	
• •		
	-	

<u> </u> -			dbx F	lodel 1	40	180	-		ia.	ie i	Ā	DUT	lanne	M
	5/7/81 LAC	I	nitial	Factory	Test P	Procedu	re	•	(Hz)	(dBv)		DUT Mode	nel	Modu
	Prelimi	nary		•		4	Page	l of 6		2				
- `-				-										
	Cal	libra	te tes	CALIBRA t equipm ibration	ent acc		to the	e Test :						-
~	2. LED, a)	Appl BYP	y powe: and DI:	T r to the SC switc ppropria	hes in	turn. C	Ineck 1				BYP	***		
	Ъ)	If t	he swi	tches bi	nd, lub	ricate	them.				Ì			
	3. POW	ER SU	PPLY A	DJUST		•								.
		RH s the	ide of RH sid	e COMMON Rl3 (gr e of R8. 4.990 an	ound) a Adjust	ind the R5 fo:	+ prol	be to			BYP	BYP		
	Ъ)	and		e DVM + for a re										
С	c)	chec		e DVM to a readin										
	d)	chec	ect th k for 70VDC.	e DVM to a readin	the RH	H side (en -19	of R18 .30 an	and d						
	4. RMS	SYMM	IETRY A	DJUST										
	a)	conn acit of t grou	hect th fors li the pro und cli	oscillato ne scope sted bel obe is or .p is on not suff	probe a low. Be h the + the oth	across sure t cap le ner lea	the RM hat th ad and	e tip the	100Hz	Odbv	BYP .	TAPE		Bac T Ba
	ъ)	resp wave	ective form.	AS cap or trimpot Do this rical a w	careful	qual pe lly so	aks on as to	obtain						
			-				-				-			
-				RMS Cap	-	Trimp				-				
	 *	•.		C34 C65 C96	•	R45 R96 R14	5 - 1 16 -			-				
· · ·		-		C126		R20	ַ -							
	·			-			•							
بير سيميني = درد				-	-	•						 		-
				· · · · · · · · · · · · · · · · · · ·							· · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·		1

/

Prelimina LÀC 5/7/81	ary dbx Model 140/180 Initial Factory Test Procedure	q. (Hz)	±l (dBv)	:renca d	UT ode	rianne 1	้ากเ	
	PAGE 20F 6		ļ	<u> </u>	ļ	ļ	<u></u>	
6. VCA	SYMMETRY ADJUST				-			
a)	Set the oscillator and switches as shown and adjust Rl21 (front panel) for OdBV output.	100Hz	Odbv	BYP	TAPE	2.	EN	
b)	Switch to Channel 1 and adjust R68 for OdBV output.					1		
c)	Set the Distortion Meter for 200Hz and adjust R59 for minimum distortion. The reading should be 0.032% or less.							
đ)	Switch to Channel 2 and adjust R110 for min- imum distortion. The reading should be 0.032% or less.					2		
e) [.]	Switch the TA to PLAY and adjust R173 (front panel) for a OdBV output.	-			<i>11</i> .		DEC	
f)	Switch to Channel 1 and adjust R169 for a OdBV output. Then adjust R152 for minimum distortion. The reading should be 0.032% or less.					ב		
g) ¥	Switch back to channel 2 and adjust R205 for minimum distortion. The reading should be 0.032% or less.					2		
7. LOG	SLOPE ADJUST							
a)	Set the oscillator and switches as shown, and the Distortion Filter to 2kHz.	1000	-20	BYP	TAPE	2		
ъ)	Connect the resistor sub box between the +15V supply and the R215/R216 junction. Adjust the sub box for an output between +1 and -1dBV, and then adjust R214 for minimum distortion. The reading should be 0.1% or less.							
c)	Switch to Channel 1 and connect the sub box from +15V to the R162/R163 junction. Adjust the sub box for an output between +1 and -1dB Adjust R161 for minimum distortion. The reading should be 0.1% or less.					l		
đ)	Set the switches as shown and connect the sub box between the $-15V$ supply and the R61/R62 junction. Adjust the sub box for an output between +1 and -1 dBV. Then adjust R60 for minimum distortion. The reading should be 0.1% or less.	-				-	E:	
		-	•	•		-		

. ۲

)

•	Prelim	nary dbx Model 140 /180	q. (el (erenci e			
	° 5/7/81 LAC	Initial Factory Test Procedure	(H2)	(dBv)	C. Ø			
<u> </u>		FAGE 3 OF 6				<u> </u>		
j	•							
	7.	OG SLOPE ADJUST (cont.)						
	e)	Set the TA to Channel 2, and connect the sub box from the -15V supply to the Rll2/Rll3 junction. Adjust the sub box for an output between +1 and -1dBV. Then adjust Rll1 for minimum distortion. The reading should be 0.1% or less.	1000	-20	BYP	TAPE	2	ENC
	(£ بلا	Disconnect the sub box and set the oscillator to 100Hz, OdBV and the Distortion filter to 200Hz. Check the distortion on both channels. The readings should be 0.032% or less.	100	Odbv			1,2	•
		Set the TA to ENCODE and check the distortion in REC mode. The readings for both channels should be 0.032% or less.						DEC
	8. TRA	CKING TEST						
	a)	Set the oscillator and switches as shown, and adjust R173 (front panel) for OdB output.	1000	OđBV			2	
	Ъ)	Switch to Channel 1 and adjust R169 for a OdB output. This adjustment must be done to a tolerence of ± 0.1 dB. Now recheck that both channels are within 0.1dB of each other.						
	c)	Rotate R173 over its entire range and check that the output swings from -10 to +10dB and then reset it for 0dB output.						
	ā)	Switch the TA to ENCODE Channel 2, and adjust R121 (front panel) over its entire travel. Check that the output swings from -8 to +8dB. Now set the output to OdEV.					2	ENC
	e)	Switch to Channel 1 and adjust R68 for OdBV output ±0.1dB. Recheck that both channels are within 0.1dB of each other.						
	f)	Set the TA to Back-to-Back mode and check the outputs of channels 1 and 2 at the following levels. The outputs should be within the ranges shown:			-		-	-
· .)		Osc Level (dBV) 0 Level matched -10 -11 to -9			-			
el.		$\begin{array}{cccc} -20 & -21 \text{ to } -19 \\ -30 & -31 \text{ to } -29 \\ -40 & -41 \text{ to } -39 \\ -50 & 51 \text{ to } -49 \\ -60 & -61 \text{ to } -59 \end{array}$	-		•		-	. <u>-</u>
						ł		· .
• •					نوم روانی در از رواد . در هر هاه هم هر در در در . در هر هاه هاه هاه شون در سرد .	,	ren na seres Alexandres	aliario a

	đbx Mode	1 140/180	q .	et.	er	1 7 1	10	Ē	
Preliminary 5/7/81	Initial Fac	tory Test Procedure	(Hz)	(dBv)	eranca e	EUT Mode	Channel	ก่อนน	42
LAC		PAGE 4 OF 6		.~			1-		·
· · · · · · · · · · · · · · · · · · ·	······································			1	-	1	1	T)
8. FREQUENC	Y RESPONSE TEST			• .					
	the switches as shown		1		BYP	TAPE	: 1,2		
puts liste	of both channels at ed below. The levels s es shown:	the frequencies		Odbv	BIP	TAPE		Ē	
	Freq.(Hz)	Output (dBV)							
	1000 10k 100 20 20k	Level-matched -4.0 to -2.0 -0.5 to +1.5 +3.5 to +5.5 +2.5 to +4.5				•			
· outpi	ch the TA to DECODE an uts of both channels a es listed below:	d check that the						D	
	Freq.(Hz)	Output (dBV)							
-	20k 20 100 1000 10k	-7.5 to -5.5 -16.5 to -14.0 -1.5 to +0.5 Level matched +5.5 to +7.5					x		- \
adjus	the DUT and the TA int st R174 (front panel) & that both channel ou	o DISC mode, and for a OdBV output.	1000	Odev	BYP	DISC	1,2	I)
both	the oscillator to 20Hz channels have outputs -18.5dBV.								
9. 10kHz DIS	STORTION TEST								
and s	the oscillator and swi set the distortion met ing should be 0.1% or	er to 30kHz. The	10k -			TAPE	ı	Ba I	
look	ce the oscillator leve at the waveform on th crossover distortion i	e scope. Check for							
c) Repea	at steps (a) and (b) f	or Channel 2.							
	•								
-						- <u>-</u>			
· .					-				
-					•	-			(ت
	•		1	ļ	ļ	ł	ł		

[-		dbx Model 140//80	Eq.	c. Vel	ferenc de			
	Prelim 5/7/81 LAC	nary .Initial Factory Test Frocedure	(Hz)	(dBv)	ance		-	
		PAGE 5 DE 6	<u> </u>	<u> </u>	ļ		ļ	1
						-		
	10.	CLIPPING TEST	• - , •					
		•	1					
		 a) Set the oscillator and switches as shown, and increase the oscillator level until the wave- form begins to clip as observed on the scope. Measure the output level on the DVM. The level should reach 12.6 VRMS before clipping occurs. 	1000	***	BYP	TAPE	1	DEC
		b) Repeat step (a) for channel 2.					2	
	11.	TONEBURST TEST	-					
		 a) Connect the Toneburst generator to the Reference unit and connect the ref. unit to the DUT. Set the Toneburst generator to 1000Hz, 8 cycle on, 128 cycle off. 			REC	TAPE	2	DE:
		b) Look at the waveform on the oscilloscope and check that there is no more than 10% over- shoot on the first cycle, and none at all for the remaining cycles including the end of the waveform.						•
ل)	c) Repeat step (b) for Channel 1.					1	
		d) Switch the Reference unit to BYP and the TA to BACK-TO-BACK. Repeat step (b).			BYP	na di Ma Subtraction Subtraction A		BA
		e) Repeat step (d) for Channel 2.					2	£.
	12.	NOISE TEST						
-		Disconnect the Toneburst generator from the Ref. unit and short the input to the Ref. unit. Check that the output is -70dB or lower (typ- ically -85).	,		BYP			
		b) Repeat for Channel 1.					1	
	NOTI	: The noise figure for the Model 140 is better then -85dBV with the covers and side panels in place. The above figure is relaxed to take into account their abscence.						
	13.	FINAL DISTORTION CHECK.			-			·
)	- - -	a) Set the oscillator and switches as shown, and adjust R121 for a OdBV output. Check that the distortion is 0.032% or less, with the Dis- tortion filter set to 200Hz.	100	Ođev	-		- -	ENCC
	· · · ·		•		-			
		· · · · · · · · · · · · · · · · · · ·		, T -	1.	. 1	ł	
1.1.	Marinine		n de services En de services de				eren jaran era	

Prelim 5/7/81 LAC		بتر د			đbx Moć	del 14	•	E 6 DF 6	-, (Hz)	±l (dBv)	srence \$			
⁻						-								
13.			STORTION to Cha				step (a)	100	OđBV	BYP	TAPE	2	EN
	c)		h the TA Voutput				ust Rl	73 for		•				DE
	d)	Repeat	: Step (c) for	Channe	11.							1	
	e)	Odbv c	the osc output. ls are	Check 1	that th	e outj	puts o	f both	1000				1,2	
×	đ)	output	to ENC . Check of each	that t	the two	t R12. o outpr	l for uts ar	a OdBV e within				- - - -		ENC
		· .												
										•				
										~				
								-						
				-			•							
				-				• -						
				•		· 	-	• •	•		,		-	
				-				Ĩ	I	1	I	-	- 1	

)

)



Schematics, Assembly Drawings, Parts List

								•
	olk	dbx _{inc} [Waltham, Mass.	PACKING É SHIPPING . 70A USED ASSY ON	PL SBOOBO	NUMBER 080	REV. 00	s' ET	05
· · ·	ITEM No.	REF. DESIGNATION	DESCRIPTION			QUANTITY		
			MAIN ASSEMBLY	400095	5 \	22	63	
-	2				·			
-	б		MANUAL	6002/7				
	4		WARRANTY CARD	600038	\			
. " .	Ś						- <u> </u>	
. 1	9	-				- 		
* <u>-</u>	~	-				\uparrow		
	Ø		BOX	390113				
	6		PLASTIC BAG 18 × 30	390044	· ~			
	0/	-	END CAP	390114	a			
	1							
A	12							
	B.							
× °° .	4							
- 1	গ							
. 3	6					\top	+	
	21	-						
· ·	/8							
	6/							
ī.	20							
1	bľ ≲{	PL 580080						

dbx		ASSEMBLY	14C 100	101 PL 580082	082 HEV.	2 OF 2	
ITEM	REF. DES	DESIGNATION	DES	DESCRIPTION	PART NUMBER		1
			MAIN ASSE	ASSEMBLY	400095	-	1
2							T
m			MANUAL		600217	-	T
4	-		WARRANTY	CARD	600038	-	1
S.							1
٩							1
7			OUTER BOX		390146		1
Ø			END CAP		390180	2	1
6							Υ <u></u>
0			PLASTIC BAG,	5, 12" X 24	61106E	-	Í
-							T
51 J			TAPE, MASKING,	ig, '/2" wide	310514	AIR	1
E1 :							1
14							1
15					•		1
91	•						T
17							<u> </u>
8							1
61							1
02							ł
ЪГ	58,0082					~	1
							1

nan o <mark>Billiona andala</mark> data a sona ana ana s

N I

)

.

ن د			-		-
	Inc. MODEL HOA(EU)	14UM (EV)		ر ' ا)
ITEM	REF. DESIGNATION	LECRIPTION	PART NUMBER	ατγ	ļ · .
-		P.C. ASSEMBLY	460250	-	
2					
n					
4		EXTRUSION FRONT	2907092	-	$ \triangleleft$
ŝ		OVERLAY FRONT	210238	-	$ \triangleleft$
٩		EXTRUSION, OVERLAY SUB-ASS'Y	380222	-	
~					
Ø		BRACKET, RACK MOUNT SIDE	290412	Q	18-
σ		COVER, 16.937"X 5.968", RM-18-2	290411		K
<u>0</u>					
=		SCREW, PHMS, X-REC, 4-40 × 1/4	311023	0	
2		WASHER INT TOOTH #4	311642	0	1
Ū					
4		SCREW # 6-32 X 5/8	311046	4	
<u>n</u>		WASHER INT TOOTH # 6	311643	<u>0</u> 0	104
<u>0</u>		HEX NUT # 6-32	311665	<u> </u>	4D
2		SCREW, TAPPING * 6×5/8 LG, BLK 0XD	310100		184
0		BUTTON SWITCH, CHROME	310322	2	
6		TRANSFORMER, POWER	230027	-	0
20		LINECORD	320133	-	
PL4	400155				

n an an an an an an an Ann Ann Ann an

•

- : <u>-</u>

· .

i

-

	UNA Inc. MODEL 140A(EU)			ר ז ו
ITEM	REF. DESIGNATION	DESCRIPTION	PART NUMBER	άτγ
12 .		CONNECTOR INSULATED	280089	m
. 22		TERMINAL STRIP, IZ POSITION	280233	2
. 23		DIODE , XC-4850-G, GREEN WITH TABS	140141	2
24		LED HOLDER 2 PIECE	310365	2
25		CABLÈ TIE	310124	AIR
56		FOAM TAPE 1/8" THK X 16" LG.	310683	4
: 27		UL CAUTION LABEL	210168	<u>ง</u> ก
28		STRAIN RELIEF	310137	-
62		SCREW, MACH. PAN HD # 6-32 X /2 LG.	311045	2 7
On M				
ลิ		WASHER FLAT # 6	311608	2
2 1 1 1 1 1				
33		GROMMET RUBBER 181.D, 3/16 0.D	310625	2 2
5 5 7				
32				
୬ ଜ				
76				
38	_		-	
66				
40			-	
ЪГ,	400155			
•				
-				

...

<u> </u>				
Ð	dbx inc Assémely	520025 77 (U-3, 100)	10 520	LZ OF Z
TEM	REF. DESIGNATION	DESCRIPTION	PART NUMBER OTY	
-		MAIN ASSEMBLY	400155	
N				
m		MANUAL	600217	-
4				
ហ				
٩				-
7		OUTER BOX	390146	
ð Ø		END CAP	390180	N
6				
<u>0</u>		PLASTIC BAG, 12" X 24	611062	-
-				
21		TAPE, MASKING , '/2" WIDE	310514	AIR
m				
4				
5-			-	
9	-			
21	-			-
8				
6-				
202				
	PL 580083			. 1

- -

95 REV. SHEET	PART NUMBER QTY	460250 1			290709 1 4	210238 1 2	290710 I D	290712 1	290412 7	290411 2 00		311023 6	311642 6		311046 4 0	311643 2 3	311665 2 4	310100 4 4	310322 2	230027 1 27	320087 1	
USED ~N 140A(DO) PL 400095	DESCRIPTION	P.C. ASSEMBLY			EXTRUSION FRONT	OVERLAY FRONT	EXTRUSION REAR	OVERLAY REAR	BRACKET, RACK MOUNT SIDE	COVER , 16.937" X 5.968" , RM-18-2		SCREW, PHMS, X-REC, 4-40 X 1/4	WASHER INT TOOTH #4		SCREW # 6-32 X 5/8	WASHER INT TOOTH # 6	HEX NUT # 6-32	SCREW, TAPPING #6×5/8LG BLK OXD	BUTTON SWITCH, CHROME	TRANSFORMER, POWER	LINECORD	
bx inc. MAIN ASSEMBLY	REF. DESIGNATION		-													•						400095
	EM.	_	2	n	4	ហ	ى	1	Ø	σ	<u>○</u>	=	2	m.	4	<u>N</u>	<u>७</u>	17	8	6	50	

)

. .)

ق	– m	·]			<			8				0		0		1	1	1	I	ł	1	
	SHLE I 3 OF 3	ατγ	N	2	2	N	AIR	4	N		~		N		2								
	195 REV.	PART NUMBER	280089	280233	140141	310365	310124	310683	210168		311045		311608		310625								
)	USE ON PL 40005	DESCRIPTION	CONNECTOR INSULATED	TERMINAL STRIP, IZ POSITION	DIODE , XC- 4850-G, GREEN WITH TABS	LED HOLDER 2 PIECE	CABLE TIE	FOAM TAPE 1/8" THK X 16" LG.	UL CAUTION LABEL		SCREW, MACH, PAN HD # 6-32 x /2 LG.		WASHER FLAT # 6		GROMMET RUBBER 181.D. 3/16 0.D.								
	DX Inc. MAIN ASSEMBLY	REF. DESIGNATION																					400095
Ð	P	ITEM	12	22	53	24	22	92	27	: 28	62	0 E	ิติ	ເ	33	34	35	36	37	38	95	40	

xqp	DX In. SUB-ASSY MODEL 140A(EU)	toA(EU) USED ON PL 380222	222 REV 00	SHEET 2 OF 2
ITEM	REF. DESIGNATION	DESCRIPTION	PART NUMBER	ατγ
		REAR EXTRUSION	290710	-
N		REAR OVERLAY	290712	
Ŋ		LABEL 240VAC	210084	
4				
5				
0				
7				
8				
6				
01				
11 -				
512			-	
ы М				
4				
15	•	Χ.		
9				
17				
8				
6-				
20				
БГ	380222		• • 2	
				¢

)			j	
	dbx	XINULTANEOUS	TION 1 JA (EU), (DO) PL 360250	1250 REV.	SHEET 2 OF 7
	ITEM	REF. DESIGNATION	DESCRIPTION	PART NUMBER	ατγ
···· •			P.C BOARD	260458	-
	N				-
	ŝ				
	4				
	S	R1,4,39,42,101,104,	RESISTOR, IK, 14W, 1%	100110	හ
	٩	R139, 142			
• •	2	R2, 5, 40, 43, 102, 105,	30K1,14W,1%	013012	8
	ß	R140, 143			
	6	R3, 6, 41, 44, 103, 106,	23K2, 14W, 1%	012322	ω
	0	R141,144			
	-	R7, 107	35K7 , 1/4W, 1%	013572	ما
	21	R 8, 108	121 K, 14 W, 1%	011213	2
	Ē	R9, 22,46, 59,109,122,	10 K, 14 W, 1%	011002	හ
	4	R146, 159			
	-15	R10,21,23,26,45,58,60,63,	33K2, 14W, 1%	013322	16
	9	R110,121,123,126,145,158,160,163			
	2-	R11, 50, 150	POT TRIM 5 K, VERTICAL MOUNT	r 070286 *	m
	8	R12, 51, 112, 151	RESISTOR, 6K98, 14W, 1%	016981	4
	61	RI3, 52, 113, 152	47 R5, 14W, 1%	014759	4
	20	R14,47,114,147	1 51 , 14W, 5%	054510	4
	Г Ь	360250 * ALTERNATE	PART #070029		

:• •*;*•

dP	dbx In NOISE REDUCTION	TION 1 JA (EU), (DO) PL 360250	250 REV.	SHEET 3 OF 7
ITEM	REF. DESIGNATION	DESCRIPTION	PART NUMBER	ατγ
โป	RI5,48,115,148	RESISTOR, 180K, 14W, 5%	054184	4
22	R16, 34, 49, 71, 116, 134	POT TRIM SO K, HORIZONTAL MOUNT	070068	£
23	R149,171			
24	RI7, 55, 117, 155	RESISTOR, 3K9 , 14W, 5%	054392	4
22	RI8, 54, 118, 154	10 K 1 1/4 W, 5%	054103	4
92 50	R19, 56, 119, 156	33 K , 1/4 W, 5%	054333	4
27	R 20, 57, 120, 157	39, 14W, 5%	054390	4
28				_
50	R24, 61, 124, 161	90K9 , 14 W, 1%	260610	4
0 E	R25, 62, 125, 162	4K75, 14W, 1%	014751	4
พิ				
32	RZT, 64, 127, 164	GK81,14W,1%	016811	4
33	R28, 65, 128, 165	165 K, 14W, 1%	011653	4
34	R29, 66, 129, 166	13K7, 14W, 1%	011372	4
35	R30, 67, 130, 167	ZZM, 14W, 5%	054226	4
36	R31,68,131,168	20, 14W, 5%	054200	4
15	R32, 69, 132, 169	39 K, 14 W, 5%	054393	4
38	R33, 70,76,133,170	ZOK, 14W, 5%	054203	2
39	R35,72,135,172	1 K , 1/4 W, 5%	054102	4
40	R36, 73, 136, 173	1 604 K, 14W, 1%	016043	4
	360250			2. 0. 2. 0.

}

)		>			*
qp	dbx In Noise REDUCTION			150 Htv. 1	SHEE I 4 OF 7
ITEM	REF. DESIGNATION	Δ	DESCRIPTION	RT NUMBER	ατγ
14	R37,74,137,174	RESISTOR,	10, 14W, 5%		4
42	R 38,75,138,175	SELECT RESIS	ECT RESISTOR, ZMZ, NOM.	SELECT PER 168002	4
43	R 53 , 153	RESISTOR,	20K, 14W, 1%	012002	2
44	R78 R100	Ž	NOT USED		
45	R176	RESISTOR,	ZK4 , 14W, 5%	054242	
46	R77,177	RESISTOR ,	1K8, 1/4W, 5%	054182	2
47	R111	POT, TRIM,	5K, HORIZ. MOUNT	070143	
48					
49					
20					-
5	C1, 2, 15, 16, 28, 29, 41,	CAPACITOR,	100P , CD, SZL +5%	121259	14
52	CI01,102,115,116,128,129,141)	_			
53	C3, 6, 30, 33, 103, 1		220P , PP ±5%MAX	125126	භ
54	CI06, I30, I33				
52	C4,7,31,34,104,107,		33P , CD, NPO ± 5%	121175	8
20	CI31, 134				
15	C5,10,13,14,22,25,27,32,	. ~	1/50V, RAD, EL ±20%	127084	30
5 5 7	C37, 38,40,48,51,53,105,110,				
59	C113,114,122,125,127,132,137,	-			
09	C138,140,148, 151, 153,178, 179				
	3¢0250				

qp	dby In NOISE REDUCTION	NOL	T JA (EU), (DO)	PL 360250	50 HEV	S OF 7
ITEM	REF. DESIGNATION	-	DESCRIPTION		PART NUMBER	ατγ
6	C11,42,111,142	CAPACITOR	YM, NOI ,	15%	123025	4
29	C12, 35, 112, 135		BOON, MY, :	±5%	123196	4
63			•			
64						
65	C8,9,17,18,43,44,	~~	W NOOI	15%	123149	12
۔ ق ق	C108,109,117,118,143,144					-
67	C19, 20,45,46,119,120	2	W CNE	15%	123350	ß
68	C145, 146					,
69	C21,47,121,147		330P , PP :	12.5%	125173	4
. 70						
12	C23,49, I23,149		ZZN, MY	15%	123050	4
72	C26, 52, 126, 152		IO , RAD, EI	EL	SELECT PER 166005	4
13	C 36, 136		ZOOP , PP	12.5%	125121	N
74	C 39, C 54 C100		NOT USED			
. 75	C139, C154 - C165, 171		NOT USED			
76	C172, 173, 176, 177		ION, CD, Y5E	, T I	121533	4
LL.	C168,169		1000/35 V, RAD, EL	EL -10%	127523	2
. 78	C174, 175		10/25V, RAD,EL	1. +50%	127198	N
61	C24,50,124,150		ZNZ, PP,	12.5%	125802	4
80	C166,167	•••	ION, CD, 100V -	1001 ± 20%, Z5U	121530	N
Ц	360250			-		
•						

· _

-

)

)

).				
<u>p</u>	dby in Noise Reductio	TION 1, 2A (EU). (DO) PL 360250	60250 HEV.	SHEET
ITEM	REF. DESIGNATION	DESCRIPTION	ך ∠ ר	4
18				
82				
83 -				
. 84	CR1, 2, 3, 4	DIODE, IN4003GP	140022	~
: 85	CR5, 6	DIODE, IN 5818	140206	+ 1
86))	J
87		LEAD CONNECTOR, LED	210472	0
88			J 	3
68	IC1, 3, 5, 7	IC, LOW DISTORTION	267911	4
06	IC2,4,6,8	IC, RMS	146742	- 4
16				•
56				
56	OA1, 3, 5, 7	OP, AMP LF353	146241	<
94	0A2, 4, 6,8	OP, AMP NE 5532	140.202	+ <
36				4
96				
16				-
98	тг, з, 4, 5	NOT USED CUSTOMER OPTION, JENSEN	SEN JE-123-5	
66				-
001				
	360250			
-	-			*

	In NOISE REDUCTION	$\frac{1}{1} \frac{1}{2A} \frac{1}{(EU)_{1}(DO)} PL$	360250 HEV.	J OF 7
ITEM	REF. DESIGNATION	DESCRIPTION	PART NUMBER	ατγ
101	VRI	VOLTAGE REG. 7815 CU	146366	
201	VR2.		146356	
E01	VR3	~ 7915 CU	146367	-
104	VR4	~ 7905cU	146355	-
105				
106				
101	51, 52	SWITCH BPDT	250053	2
108				-
8	イー イラ	JUMPER , ZERO-OHM	110085	E1
011		JUMPER , TWISTED PAIR	320231	2
Ξ		WIRE-WRAP WIRE, 24 AWG, 4.75 LG	320232	24
211		HEAT SINK , TALL	310450	N
EI.	-	SCREW PAN HD X-REC 4-40 X 5/16 LG.	311024	4
114		HEX NUT 4-40	311664	4
115		WASHER, INT TOOTH #4	311642	4
116		WASHER, NYLON , SHOULDER	310443	N
117	-	INSULATOR	310417	N
811		-		
611				
120		5WAGE SPACER, 4-40×1/8 LG.	310022	IJ.
	360250			

)



:



З.

THESE I ARE THE SHALL A SHALL A SALE OF WRUTTEN 1213

1.814

ŝ

L REFERENCE PARTS LIST NO. 360250. 2. PREBEND TRANSISTOR LEADS WHERE TRANSISTOR FADS ARE NOT USED.

4. TRANSISTOR PAIRS QA213, QA516, QA819, AND QAIG12 TO BE PUSHED TOGETHER AND APPLY A SMALL AMOUNT OF CONFORMAL COATING (ITEM 90) TO TOPS OF PAIRS TO ENSURE A GOOD MECHANICAL BOND.

				140 USED ON					
UNLESS OTHERM	APPROVAL DATE		11						
MILLIMETERS (mm). TOLERANCE ON INCHES XX ± 015 XXX ± .005 TOLERANCE ON MILLIMETERS (mm).		PV	1/25/80	dbx nc Newton, Ma.					
		CHECKED	1/26/80	PC BOARD ASSEMBLY					
(XX) ± 38 (mm) (.XXX) ± .15 (mm) ANGLES FRACTIONS	PROJ ENG	1/2/11	TWO CHANNEL SIMULTANEOUS						
± 1/2*	± 1/32	CH ENG.	1/ 1	NOISE REDUCTION					
APPROVED FOR PRODUCTION TOOLING		RELEASED	120/81	SCALE / SIZE NUMBER AEV					
	DATE	AT	14 1	SHT / OF D 460250 01					



2, 1. REFERENCE PARTS LIST NO. 360250, 2. PREBEND TRANSISTOR LEADS WHERE TRANSISTOR PADS ARE NOT USED.

4. TRANSISTOR PAIRS QA213, QA516, QA819, AND QAIKIZ TO BE PUSHED TOGETHER AND APPLY A SMALL AMOUNT OF CONFORMAL COATING (ITEM 90) TO TOPS OF PAIRS TO ENSURE A GOOD MECHANICAL BOND.

-	· · · · · · · · · · · · · · · · · · ·		·····		140	USED	0N		
LE DRAWINGS THE PROPERT L NOT BE REP AS THE BASIS OF APPARATUS TEN AUTHORIZ	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES AND/O	APPROVAL	DATE	· 11	•				
	MILLIMETERS (mm) - TOLERANCE ON INCHES	PV PV	125/80	dbx inc. Newton, Ma.					
	.XX ± .015 .XXX ± .005 TOLERANCE ON MILLIMETERS (mm)	CHECKED	1/26/80	PC BOARD ASSEMBLY					
	(.XX) ± .38 (mm) (.XXX) ± .15 (mm) ANGLES FRACTIONS	PROJ.ENG.	'belsi	TWO CHANNEL SIMULTANEOUS					
	± 1/2* ± 1/32	CH. ENG.	1/20/81	NOISE REDU	N				
	APPROVED FOR PRODUCTION TOOLING APPR'D DATE	RELEASED	1/21/1	JUNIC: 1/1	MBER 4607	250	REV OI		