



All resistors marked ** = Power devices
 * For MC450 R14 = R16 = 560R
 R28 = R29 = 2K7
 Delete R4, R8, Q7, Q13, R22, R26
 One channel only shown