

A

Addresses, 13
 ALL_STATUS?, ALST?, Query, 63
 ARM_ACQUISITION, ARM, Command, 64
 ASCII
 waveform storage, 11
 ATTENUATION, ATTN, Command/Query, 65
 AUTO_CALIBRATE, ACAL, Command/Query, 66
 AUTO_SCROLL, ASCR, Command/Query, 67
 AUTO_SETUP, ASET, Command, 68

B

BANDWIDTH_LIMIT, BWL, Command/Query, 69
 BASICA, 15, 37
 Binary blocks, 39
 Block Data, 10
 Buffers, 14
 BUZZER, BUZZ, Command, 71

C

CAL?, Query, 72
 CAL_OUTPUT, COUT, Command/Query, 73
 CALL_HOST, CHST, Command/Query, 74
 Character data, 9
 CLEAR_MEMORY, CLM, Command, 75
 CLEAR_SWEEPS, CLSW, Command, 76
 *CLS, Command, 77
 CMR (Command Error Status Register), 47, 49
 CMR?, Query, 78
 COLOR, COLR, Command/Query, 80
 COLOR_SCHEME, CSCH, Command/Query, 83
 Colors
 list of colors and their short form names, 81
 COMM_FORMAT, CFMT, Command/Query, 84

COMM_HEADER, CHDR, Command/Query, 86
 COMM_HELP, CHLP, Command/Query, 87
 COMM_HELP_LOG?, CHL?, Query, 88
 COMM_ORDER, CORD, Command/Query, 89
 COMM_RS232, CORS, Command/Query, 91
 Commands and Queries, 6
 How they are described, 52
 Notation, 52
 Overview, 52
 Configuring
 Printing, 22
 Continuous Polling, 19
 Controller Timeout, 7, 14, 18, 20, 258
 COUPLING, CPL, Command/Query, 94
 CURSOR_MEASURE, CRMS, Command/Query, 95
 CURSOR_SET, CRST, Command/Query, 98
 CURSOR_VALUE?, CRVA?, Query, 100

D

Data
 Arrays, 35
 Formatting, 37, 51
 HEX mode, 29, 31, 51
 Horizontal position, 40
 Interpretation, 37, 39
 Sparsing, 51
 Values, 36, 39
 Vertical reading, 39
 DATA_POINTS, DPNT, Command/Query, 102
 DATE, Command/Query, 103
 DDR (Device Dependent Error Status Register), 50
 DDR?, Query, 104
 DEFINE, DEF, Command/Query, 106
 DELETE_FILE, DELF, Command, 112
 Descriptor
 Block, 35
 Values, 36, 39
 Device Dependent Error Status Register. *see* DDR

DIRECTORY, DIR, Command/Query, 113
DISPLAY, DISP, Command/Query, 115
DOT_JOIN, DTJN, Command/Query, 116
DUAL Array, 35
DUAL_ZOOM, DZOM, Command/Query, 117

E

ENABLE_KEY, Command/Query, 118
Error Messages, 6
ESE (Standard Event Status Enable Register), 19, 47, 49
*ESE, Command/Query, 119
ESR (Standard Event Status Register), 19, 47, 49
*ESR?, Query, 120
Execution Error Status Register. *see* EXR
EXR (Execution Error Status Register), 47, 50
EXR?, Query, 123
External Monitor port, 5, 6

F

FAT_CURSOR, FATC, Command/Query, 125
FILENAME, FLNM, Command/Query, 126
FIND_CTR_RANGE, FCR, Command, 127
FORMAT_CARD, FCRD, Command/Query, 128
FORMAT_FLOPPY, FFLP, Command/Query, 130
FORMAT_HDD, FHDD, Command/Query, 132
FULL_SCREEN, FSCR, Command/Query, 134
FUNCTION_RESET, FRST, Command, 135

G

GLOBAL_BWL, GBWL, Command/Query, 136
GPIB
 Addresses, 13
 ATN (ATteNtion), 14
 Data lines, 13
 DCL (Device CLear), 14
 EOI (End Or Identify), 6, 14
 GET (Group Execute Trigger), 15, 18
 GTL (Go To Local), 15, 18
 Handshake lines, 14
 Hard copies, 22
 Hardcopy, 22, 23

Hardware configuration, 15
IEEE 488.1, 14
IEEE 488.2, 14
IFC (InterFace Clear), 14, 15
INE (Internal State Change Enable Register), 19
INR (Internal State Change Status Register), 19
Listener address, 23
LLO (Local LOkout), 15
MLA (Listen address), 13
MTA (Talker address), 13
Polling, 19
port, 5
PRE (Parallel Poll Enable Register), 21
Printing, 23
Program for IBM PC, 256, 258, 256, 258
Programming service requests, 18
Programming transfers, 15
REN (Remote ENable), 14, 15
RQS (ReQuest for Service), 20
SDC (Selected Device CLear), 14, 18
Signals, 13
Software configuration, 15
SRE (Service Request Enable Register), 18
SRQ (Service Request), 18, 19
SRQ (Service ReQuest), 14
Standard, 6
Structure, 13
Talker address, 23
Transfers, 15
UNL (Universal unlisten), 13, 22, 23
UNT (Universal untalk), 13, 22, 23
GRID, Command/Query, 137

H

Hard copies. *see* GPIB
HARDCOPY_SETUP, HCSU, 138
HARDCOPY_TRANSMIT, HCTR, Command, 141
Header, 7
Header Path, 7
Help Messages, 6
HOR_MAGNIFY, HMAG, Command/Query, 142
HOR_POSITION, HPOS, Command/Query, 143

I

*IDN?, Query, 145
 IEEE 488.1, 5
 IEEE 488.2, 6, 47, 49
 IEEE Standards. see GPIB
 INE (Internal State Change Enable Register), 19, 49, 50
 INE (INternal State Change Enable Register), 47
 INE, Command/ Query, 146
 INR (Internal State Change Status Register, 19
 INR (Internal State Change Status Register), 19, 50
 INR?, Query, 147
 INSPECT? Queries, 36
 INSPECT?, INSP?, Query, 149
 INTENSITY, INTS, Command/ Query, 151
 Interface Capabilities, 13
 Interface messages, 13
 INTERLEAVED, ILVD, Command/ Query, 152
 Internal State Change Enable Register. see INE
 Internal State Change Status Register. see INR
 IST Polling, 22, 47, 50
 *IST?, Query, 153

K

KEY, Command, 154

L

Line Splitting. see RS-232-C
 Logical Data Blocks, 35
 LOGO, Command/ Query, 155

M

MASK, Command/ Query, 156
 Math functions
 CLEAR_SWEEPS, CLSW, Command, 76
 CLEAR_MEMORY, CLM, Command, 75
 DEFINE, DEF, Command/ Query, 106
 FIND_CTR_RANGE, FCR, Command, 127
 FUNCTION_RESET, FRST, Command, 135
 MathCad®, 11
 MEASURE_GATE, MGAT, Command/ Query, 158

MEMORY_SIZE, MSIZ, Command/ Query, 159
 MESSAGE, MSG, Command/ Query, 160
 MULTI_ZOOM, MZOM, Command/ Query, 161
 Multipliers, 9

N

Numeric Data, 9

O

OFFSET, OFST, Command/ Query, 162
 *OPC, Command/ Query, 163
 *OPT?, Query, 164

P

PANEL_SETUP, PNSU, Command/ Query, 166
 Parallel Poll Enable Register. see PRE
 Parallel Polling, 21
 Parameter measurements, 87
 PARAMETER_CLR, PACL, Command, 167
 PARAMETER_CUSTOM, PACU, Command/ Query, 168
 PARAMETER_DELETE, PADL, Command, 171
 PARAMETER_STATISTICS?, PAST?, Query, 172
 PARAMETER_VALUE?, PAVA?, Query, 173
 PASS_FAIL_CONDITION, PFCO, Command/ Query, 176
 PASS_FAIL_COUNTER, PFCT, Command/ Query, 178
 PASS_FAIL_DO, PFDO, Command/ Query, 179
 PASS_FAIL_MASK, PFMS, Command, 181
 PASS_FAIL_STATUS?, PFST?, Query, 182
 PER_CURSOR_SET, PECS, Command/ Query, 183
 PER_CURSOR_VALUE?, PECV?, Query, 185
 PERSIST, PERS, Command/ Query, 186
 PERSIST_COLOR, PECL, Command/ Query, 187
 PERSIST_LAST, PELT, Command/ Query, 188
 PERSIST_SAT, PESA, Command/ Query, 189
 PERSIST_SETUP, PESU, Command/ Query, 190

Polling, 19
 Continuous, 19
 IST Polling, 22
 Parallel, 21
 Serial, 20
 PRE (Parallel Poll Enable Register), 21, 47, 50
 *PRE, Command/Query, 191
 PROBE_CAL?, PRCA?, Query, 192
 PROBE_DEGAUSS?, PRDG?, Query, 193
 PROBE_NAME?, PRNA?, Query, 194
 Program Messages, 6

Q

Quotation marks
 their use in command notation, 10

R

*RCL, Command, 195
 REAR_OUTPUT, ROUT, Command/Query, 196
 RECALL, REC, Command, 197
 RECALL_PANEL, RCPN, Command, 198
 Response Messages, 10
 RIS Acquisition Times (RISTIME), 35
 RISTIME, 35, 40
 RQS (ReQuest for Service), 20
 RS-232-C
 Configuration, 29
 Echo, 29
 Editing, 29
 Handshake control, 29
 Immediate commands, 29
 Line splitting, 30
 Message terminators, 30
 port, 5, 6
 Simulating GPIB Commands, 31
 SRQ (Service ReQuest), 30
 RS-232-C computer cabling, 11
 *RST, Command, 199

S

SAMPLE_CLOCK, SCLK, Command/Query, 200
 *SAV, Command, 201

ScopeExplorer™, 11
 SCREEN_DUMP, SCDP, Command/Query, 202
 SCREEN_SAVE, SCSVG, Command/Query, 203
 SELECT, SEL, Command/Query, 204
 SEQUENCE, SEQ, Command/Query, 205
 Serial Polling, 20
 Service Request Enable Register. see SRE
 Service Request Reporting, 47
 Service requests, 30
 SIMPLE, 35
 SLEEP, Command, 207
 SRE (Service Request Enable Register), 18, 47, 49, 50
 *SRE, Command/Query, 208
 SRQ (Service Request), 18, 19, 30, 49
 Standard Event Status Register. see ESR
 Status Byte Register. see STB
 Status Register Reporting, 47
 STB (Status Byte Register), 18, 49
 *STB?, Query, 209
 STOP, Command, 211
 STORE, STO, Command, 212
 STORE_PANEL, STPN, Command, 213
 STORE_SETUP, STST, Command/Query, 214
 STORE_TEMPLATE, STTM, Command, 215
 String Data, 10

T

Talker, 22
 TDISP, Command/Query, 216
 Template, 35, 36, 39, 40, 263
 TEMPLATE?, TMPL?, Query, 217
 Terminators, 6, 30, 39
 TIME_DIV, TDIV, Command/Query, 218
 TRACE, TRA, Command/Query, 219
 TRACE_OPACITY, TOPA, Command/Query, 220
 *TRG, Command, 221
 TRIG_COUPLING, TRCP, Command/Query, 222
 TRIG_DELAY, TRDL, Command/Query, 223
 TRIG_LEVEL, TRLV, Command/Query, 225
 TRIG_MODE, TRMD, Command/Query, 226
 TRIG_SELECT TRSE, Command/Query, 227

TRIG_SLOPE, TRSL, Command/Query, 230
 TRIG_WINDOW, TRWI, Command/Query, 231
 Trigger Times (TRIGTIME), 35
 TRIGTIME, 35, 40
 *TST?, Query, 232

U

URR (User Request Status Register), 50
 URR?, Query, 233
 User Request Status Register. *see* URR
 USERTEXT, 35

V

VERT_MAGNIFY, VMAG, Command/Query, 235
 VERT_POSITION, VPOS, Command/Query, 236
 VOLT_DIV, VDIV, Command/Query, 237

W

*WAI, Command, 238
 WAIT, Command, 239
 Warning Messages, 6
 WAVEDESC. *see* Descriptor
 WAVEFORM
 Command, 41
 Query, 37, 41
 Transfer optimization, 41

Waveform Template, 263
 WAVEFORM, WF, Command/Query, 240
 WAVEFORM_SETUP, WFSU, Command/Query, 243
 WAVEFORM_TEXT, WFTX, Command/Query, 245

X

XY_ASSIGN?, XYAS?, Query, 246
 XY_CURSOR_ORIGIN, XYCO, Command/Query, 247
 XY_CURSOR_SET, XYCS, Command/Query, 248
 XY_CURSOR_VALUE?, XYCV?, Query, 250
 XY_DISPLAY, XYDS, Command/Query, 252
 XY_RENDER, Command/Query, 253
 XY_SATURATION, XYSA, Command/Query, 254