




## ND30 - METER OF POWER NETWORK PARAMETERS ND30IoT - METER OF POWER NETWORK PARAMETERS FOR IoT APPLICATIONS

- Measurement of 54 power network parameters, including **current and voltage harmonics up to 63rd** in 1-phase 2-wire or 3-phase 3 or 4-wire balanced and unbalanced systems.
- The **MQTT protocol** is ideal for **communication in distributed acquisition systems** data - IoT applications (ND30IoT).
- High accuracy class (0.2S for active energy).
- **Graphical color display:** LCD TFT 3,5", 320 x 240 pixels, **fully configurable by a user** (10 views, 8 parameters in each).
- **Additional 2 pages for harmonics presentation and 1 dedicated page for visualization in the form of an analog meter.**
- Indications include the values of programmed ratios.
- Memory of minimum and maximum values.
- 2 configurable alarm outputs.
- Optional: analog output 0/4...20 mA and 2 PT 100 inputs (eg. for measurement of transformer temperature), 2 galvanically isolated binary inputs 0/5...24V d.c.
- Archiving of up to 32 measured parameters in the internal memory 8 GB (option).
- Digital output RS-485 - MODBUS protocol.
- **Modern and user-friendly Ethernet interface** 10/100 BASE-T (option):
  - protocol: MODBUS TCP/iP, HTTP, FTP,
  - protocol: MQTT (ND30IoT),
  - services: www server, ftp server, DHCP client.
- Programming of parameters using **free eCon software**.
- Battery backup RTC.
- Overall dimensions: 96 x 96 x 77 mm.
- **Supervisory relay mode for alarm outputs (ND30 and ND30IoT)**
- **MQTT protocol (for ND30)**


### Remarks:

- New features available from 1.07 firmware version.
- To make functions active, order appropriate licence key – details in ordering code.
- Functions can be also activated on the devices which have been already installed on the facility after software upgrade.

### EXAMPLE OF APPLICATION



## EXAMPLE OF APPLICATION



## MEASUREMENT AND VISUALIZATION OF POWER NETWORK PARAMETERS

- phase voltages:  $U_1, U_2, U_3$
- phase-to-phase voltages:  $U_{12}, U_{23}, U_{31}$
- phase currents  $I_1, I_2, I_3$
- active phase powers:  $P_1, P_2, P_3$
- reactive phase powers:  $Q_1, Q_2, Q_3$
- apparent phase powers:  $S_1, S_2, S_3$
- active power factors:  $\text{PF}_1, \text{PF}_2, \text{PF}_3$
- reactive/active power factors:  $\text{tg}\varphi_1, \text{tg}\varphi_2, \text{tg}\varphi_3$
- active, reactive and apparent 3-phase power:  $P, Q, S$
- mean 3-phase power factors:  $\text{PF}, \text{tg}\varphi$
- frequency  $f$
- mean 3-phase voltage:  $U_s$
- mean phase-to-phase voltage:  $U_{mf}$
- mean 3-phase current:  $I_s$
- 15, 30, 60 minutes' mean active power:  $P_{\text{demand}}$
- mean apparent power  $S_{\text{demand}}$
- average current  $I_{\text{demand}}$
- active, reactive and apparent 3-phase energy:  $E_nP, E_nQ, E_nS$
- active, reactive and apparent energy from external counter:  $E_nPE, E_nQE, E_nSE$
- total harmonic content coefficients for phase voltages and currents  $\text{THD}_{U_1}, \text{THD}_{U_2}, \text{THD}_{U_3}, \text{THD}_{I_1}, \text{THD}_{I_2}, \text{THD}_{I_3}$  and for 3-phase voltages and currents  $\text{THD}_U, \text{THD}_I$
- harmonics for current and phase voltage up to 63rd!
- temperature (2 x Pt100 input)

FEATURES	INPUTS	OUTPUTS	GALVANIC ISOLATION

## TECHNICAL DATA

### MEASURING RANGE

Measured value	Measuring range	L1	L2	L3	$\Sigma$	Class
Current 1/5 A 1 A~ 5 A~	0.002 .. 0.100 .. 1.200 A 0.010 .. 0.500 .. 6.000 A ... 100.000 kA ( $tr\_I \neq 1$ )	.	.	.		0.2 (EN 61557-12)
Voltage L-N 57.7 V~ 110 V~ 230 V~ 400 V~	5.700 .. 11.500 .. 70.000 V 11.000 .. 22.000 .. 132.000 V 23.000 .. 46.000 .. 276.000 V 40.000 .. 80.000 .. 480.000 V ... 1920.0 kV	.	.	.		0.2 (EN 61557-12)
Voltage L-L 100 V~ 190 V~ 400 V~ 690 V~	10.000 .. 20.000 .. 120.000 V 19.000 .. 38.000 .. 228.000 V 40.000 .. 80.000 .. 480.000 V 69.000 .. 138.000 .. 830.000 V ... 1999.0 kV ( $tr\_U \neq 1$ )	.	.	.		0.5 (EN 61557-12)
Active power P	-19999 MW .. 0,000 W .. .. 19999 MW ( $tr\_U \neq 1, tr\_I \neq 1$ )	.	.	.	.	0.5 (EN 61557-12)
Reactive power Q	-19999 MVar .. 0,000 Var .. .. 19999 MVar ( $tr\_U \neq 1, tr\_I \neq 1$ )	.	.	.	.	1 (EN 61557-12)
Apparent power S	0.000 .. 1999.9 VA .. .. 19999 MVA ( $tr\_U \neq 1, tr\_I \neq 1$ )	.	.	.	.	0.5 (EN 61557-12)
Active energy EnP (imported or exported)	0.000 .. 99 999 999.999 kWh				.	0.2S (EN 62053-22)
Reactive energy EnQ (inductive or capacitive)	0.000 .. 99 999 999.999 kVarh				.	1 (EN 61557-12)
Apparent energy EnS	0.000 .. 99 999 999.999 kWh				.	0.5 (EN 61557-12)
Active power factor PF	-1.00 .. 1.00	.	.	.	.	1 (EN 61557-12)
Coefficient tg (ratio of reactive power to active power)	-999.99 .. -1.20 .. 0 .. 1.20 .. 999.99	.	.	.	.	1
Frequency f	45.00 .. 65.000 .. 100.00 Hz				.	0.1 (EN 61557-12)
Total harmonic distortion of voltage THDU and current THDI	0.0 .. 100.0 %	.	.	.	.	5 (EN 61557-12)
Amplitudes of the voltage $U_{h2} \dots U_{h63}$ and current $I_{h2} \dots I_{h63}$	0.0 .. 100.0 %	.	.	.		II (IEC61000-4-7)

$tr\_I$  - Current transformer ratio = Transformer primary current / Current transformer secondary current

$tr\_U$  - Voltage transformer ratio = Transformer primary voltage / Voltage transformer secondary voltage

### ADDITIONAL INPUTS

Input type	Properties
Input Pt100 (T1, T2) - option	2 x Pt100, 2-wire, -50...400°C, basic error 0.5 %
Binary inputs - option	0V d.c. – binary input inactive, 5...24V d.c. – binary input active

### DIGITAL INTERFACE

Interface type	Transmission protocol	Remarks
RS-485	Modbus RTU 8N2,8E1,8O1,8N1   Address 1..247	baud rate: 4.8, 9.6, 19.2, 38.4, 57.6, 115.2 kbit/s
Ethernet 10/100 Base-T - option	Modbus TCP,HTTP,FTP MQTT	WWW server, FTP server, DHCP client

## EXTERNAL FEATURES

<b>Readout field</b>	graphic color display LCD TFT 3,5", 320 x 240 pixels	
<b>Overall dimensions</b>	96 x 96 x 77 mm	mounting hole 92.5 x 92.5 mm
<b>Weight</b>	0.3 kg	
<b>Protection grade</b>	from frontal side: IP65	from terminal side: IP20


## RATED OPERATING CONDITIONS

<b>Supply voltage</b>	→○ 85...253 V a.c. (40...50...400 Hz), 90...300 V d.c. or 20...40 V a.c., 20...60 V d.c.	power consumption ≤ 6 VA
<b>Power consumption</b>	in voltage circuit ≤ 0.2 VA	in current circuit ≤ 0.1 VA
<b>Input signal</b>	0...0.1...1.2 In; 0.1...0.2...1.2 Un for current, voltage, PF, tgφ	frequency 45...50...60...100 Hz, sinusoidal (THD ≤ 8%)
<b>Power factor</b>	-1...0...1	
<b>Preheating time</b>	5 min.	
<b>Ambient temperature</b>	-10...23...55°C, class K55 acc. to EN61557-12	
<b>Humidity</b>	0...40...65...95%	without condensation
<b>Operating position</b>	any	
<b>External magnetic field</b>	≤ 40...400 A/m d.c.	≤ 3 A/m a.c. 50/60 Hz
<b>Short-term overload</b>	voltage input: 2 Un (5 sec.)	current input 50 A (1 sec.)
<b>Admissible crest factor</b>	current: 2	voltage: 2
<b>Additional error (in % of the intrinsic error)</b>		from ambient temperature change: < 50% / 10°C

## SAFETY AND COMPABILITY REQUIREMENTS

<b>Electromagnetic compatibility</b>	noise immunity	acc. to EN 61000-6-2
	noise emissions	acc. to EN 61000-6-4
<b>Isolation insured by the casing</b>	double	acc. to EN 61010-1
<b>Isolation between circuits</b>	basic	acc. to EN 61010-1
<b>Polution level</b>	2	acc. to EN 61010-1
<b>Installation category</b>	III	acc. to EN 61010-1
<b>Maximal phase-to-earth voltage</b>	<ul style="list-style-type: none"> <li>for supply circuit and relay outputs 300 V</li> <li>for measuring input 500 V</li> <li>for circuits of RS-485, Ethernet, pulse input and output, analog outputs: 50 V</li> </ul>	acc. to EN 61010-1
<b>Altitude a.s.l.</b>	< 2000 m	

## CONNECTION DIAGRAMS



Description of meter connections strips

Indirect measurement in 4-wire network - connection of input signals

## DISPLAYING OF MEASUREMENT PARAMETERS

A1	A2	T1: 52°C T2: 31°C	12% 12%	TX	15/03/16 11:33:16
U1	V	I1	1.005		
U2	V	I2	2.105		
U3	V	I3	1.805		
f	Hz	avg	1.638		

A1	A2	T1: 52°C T2: 57°C	12% 12%	TX	15/03/16 12:02:57
U1	V	S1	226.57		
I1	A	PF1	0.913		
P1	W	tg1	0.447		
Q1	var	f	49.999		

A1	A2	T1: 131°C T2: 329°C	12% 12%	TX	15/03/16 13:04:26
$\Sigma P$	W	21 660 807.201			
$\Sigma Q$	var	2 786 343.635			
$\Sigma S$	kVA	13 760.862			
24 853 934.200	En S kVAh	12 035.698			
En Q± kvarh					


A1	A2	T1: 49°C T2: 53°C	12% 12%	TX	22/09/15 13:36:31
U1	%	I1	0.905		
U2	%	I2	0.905		
U3	%	I3	0.903		

**Har. 5**



up to 10 programmable screens  
(8 parameters per page);  
ability to change color for all screens

Available colors for digital indications:



two screens dedicated to harmonics;  
indication of individual harmonic  
for voltages and currents (up to 51st);  
bargraph presentation for all harmonics  
with zoom function

presentation in the form of analog  
meter view with min/max preview  
for display value and zoom function

easy to use and intuitive menu;  
information bar with status of: phase  
sequence, alarm outputs, temperature  
measurements\*, archiving and memory\*,  
Ethernet\* and RS-485 interfaces,  
time and date

\*- availability of feature depends on  
hardware version of ND30IoT, ND30

## METER CONFIGURATION WITH FREE eCON SOFTWARE

The screenshot shows the e-Con Device configurator software interface. On the left, there's a sidebar for 'Select device' with a 'Filter' dropdown set to 'Meters'. Below it are sections for 'Communication' (Port: RS485, Device ID: 1, Baud rate: 9600, Mode: RTU BH2, Timeout: 1000 ms) and 'Status' (port disconnected). On the right, the main window is titled 'ND30 - configuration' with a sub-section 'Pages display'. It shows a grid for selecting pages (1-12) and various settings like 'Display brightness' (Minimum), 'Display dimmer delay' (0-3600 s), and 'Pages color' (Green). A 'Save' button is at the bottom. A note at the top right says '[Configuration not downloaded]'.

ability to configure and update ND30iot, ND30  
with free eCon software  
(via RS-485 or Ethernet\* interface)

\*- availability of feature depends on hardware  
version of ND30iot, ND30

## REMOTE READOUT OF PARAMETERS THROUG ETHERNET: WWW SERVER, FTP

The screenshot shows the LUMEL 3-PHASE POWER NETWORK METER TYPE ND30 web interface. It includes several data tables (Page 1-5) with parameters like voltage, current, power, and energy. Below the tables are navigation icons for 'Measure values', 'Energy counters', and 'Ethernet' settings. A 'Harmonics numbers' section displays two bar charts for harmonics U and I. The top chart for U shows a dominant harmonic at the 4th order. The bottom chart for I shows a dominant harmonic at the 13th order. At the bottom of the page, there's a footer with copyright information and a 'Close' button.

WEB server\* for remote reading  
of current measurement data;  
FTP server\* for downloading  
archived CSV files

\*- availability of feature depends on hardware  
version of ND30iot, ND30

## ORDERING CODE

Meter ND30	X	X	X	X	XX	X	X
<b>Input voltage (phase/phase-to-phase) Un:</b>							
3 x 57.7 / 100 V, 3x 230 / 400 V	1						
3 x 110 / 190 V, 3 x 400 / 690 V	2						
<b>Additional outputs /inputs:</b>							
2 relays	1						
2 relays, 1 analog output, 2 inputs PT100	2						
2 relays, 1 analog output, 2 isolated binary inputs	3						
<b>Interface:</b>							
RS-485		1					
RS-485 and Ethernet, internal memory		2					
<b>Supply:</b>							
85...253 V a.c., 90...300 V d.c.			1				
20...40 V a.c., 20...60 V d.c.			2				
<b>Version:</b>							
standard				00			
supervisory relay				SR			
custom-made*				XX			
<b>Language:</b>							
Polish/English				M			
other*				X			
<b>Acceptance tests:</b>							
without additional quality requirements				0			
with an extra quality inspection certificate				1			
with an extra calibration certificate				2			
acc.to customer's request				X			

\* only after agreeing with the manufacturer

### ORDERING WAY OF ADDITIONAL FUNCTIONS (SUPERVISORY RELAY, MQTT PROTOCOL)

Ordering code	Description of the license key
LKEYWXND30MQ	activation of the MQTT protocol in ND30
LKEYWXND30SR	activation of the supervisory relay function in ND30
LKEYWXND30MS	activation of the MQTT protocol and the supervisory relay function in ND30

**Important:** When ordering, please provide the meter's execution code and serial number ND30. It is placed on the meter's nominal plate, in the configuration menu in the Information mode (see below - figure 1) or on the bar in the eCon program (Fig.2)

### Order example:

The code: **ND30\_122100M0** means:

**ND30** - meter ND30  
**1** - input voltage 3 x 57.7 / 100 V, 3x 230 / 400 V  
**2** - 2 relays, 1 analog output, 2 inputs PT100  
**1** - RS-485 and Ethernet, internal memory  
**0** - supply: 85...253 V a.c., 90...300 V d.c.  
**00** - standard version  
**M** - Polish/ English language version  
**0** - without additional quality requirements.

Meter ND30IoT	X	X	2	X	XX	X	X
<b>Input voltage (phase/phase-to-phase) Un:</b>							
3 x 57.7 / 100 V, 3x 230 / 400 V	1						
3 x 110 / 190 V, 3 x 400 / 690 V	2						
<b>Additional outputs /inputs:</b>							
2 relays	1						
2 relays, 1 analog output, 2 inputs PT100	2						
2 relays, 1 analog output, 2 isolated binary inputs	3						
<b>Interface:</b>							
RS-485 and Ethernet, internal memory		2					
<b>Supply:</b>							
85...253 V a.c., 90...300 V d.c.			1				
20...40 V a.c., 20...60 V d.c.			2				
<b>Version:</b>							
MQTT protocol				MQ			
supervisory relay + MQTT protocol				MS			
<b>Language:</b>							
Polish/ English				M			
other*				X			
<b>Acceptance tests:</b>							
without additional quality requirements				0			
with an extra quality inspection certificate				1			
with an extra calibration certificate				2			
acc.to customer's request*				X			

\* only after agreeing with the manufacturer

### ORDERING WAY OF ADDITIONAL FUNCTIONS (SUPERVISORY RELAY)

Ordering code	Description of the license key
LKEYWXND30IOTMS	activation of the supervisory relay function in ND30IoT

**Important:** When ordering, please provide the meter's execution code and serial number ND30IoT. It is placed on the meter's nominal plate, in the configuration menu in the Information mode (see below - figure 1) or on the bar in the eCon program (Fig.2)

### Order example:

The code: **ND30IoT\_1221MQM0** means:

**ND30IoT** - meter ND30IoT  
**1** - input voltage 3 x 57.7 / 100 V, 3x 230 / 400 V  
**2** - 2 relays, 1 analog output, 2 inputs PT100  
**1** - RS-485 and Ethernet, internal memory  
**1** - supply: 85...253 V a.c., 90...300 V d.c.  
**MQ** - MQTT version  
**M** - Polish/ English language version  
**0** - without additional quality requirements.

# ND30, ND30IoT - METER OF POWER NETWORK PARAMETERS

**LUMEL**  
EVERYTHING COUNTS





Fig. 2 Serial number in the eCon software bar

For more information about Lumel products  
please visit our website:

[www.lumel.com.pl](http://www.lumel.com.pl)

Join us at Facebook!



ND30-19F\_ND30IoT-19B\_en



**LUMEL**  
EVERYTHING COUNTS

#### LUMEL S.A.

ul. Ślubicka 4, 65-127 Zielona Góra, Poland  
tel.: +48 68 45 75 100, fax +48 68 45 75 508  
[www.lumel.com.pl](http://www.lumel.com.pl)

#### Technical support:

tel.: (+48 68) 45 75 143, 45 75 141, 45 75 144, 45 75 140  
e-mail: [export@lumel.com.pl](mailto:export@lumel.com.pl)

#### Export department:

tel.: (+48 68) 45 75 130, 45 75 131, 45 75 132  
e-mail: [export@lumel.com.pl](mailto:export@lumel.com.pl)

#### Calibration & Attestation:

e-mail: [laboratorium@lumel.com.pl](mailto:laboratorium@lumel.com.pl)